

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Abarth

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 500	AIRBAG	1.4 Turbo 16v	SIEMENS AirBag
 500	AIRBAG	1.4 Turbo 16v (09-..)	Continental AirBag
 500	AUTOM. TRANSMISSI	1.4 Turbo 16v	DELPHI Body Computer
 500	CHASSIS NETWORK	1.4 Turbo 16v	DELPHI Body Computer 2
 500	CHASSIS NETWORK	1.4 Turbo 16v	DELPHI Body Computer Proxi Alignement
 500	CHASSIS NETWORK	1.4 Turbo 16v	Marelli/Microsoft Convergence
 500	CLIMA	1.4 Turbo 16v	DENSO CLIMA Monozona
 500	DASHBOARD	1.4 Turbo 16v	Marelli 2
 500	ELECTRIC STEERING	1.4 Turbo 16v	DELPHI 2
 500	ENGINE MANAGEME	1.4 Turbo 16v	BOSCH Motronic ME7.9.10 CF4-EOBD
 500	LH RIGHT MODULATI	1.4 Turbo 16v	Litronic
 500	MAINTENANCE	1.4 Turbo 16v	DELPHI 2
 500	MAINTENANCE	1.4 Turbo 16v	Litronic
 500	MAINTENANCE	1.4 Turbo 16v	Litronic
 500	MAINTENANCE	1.4 Turbo 16v	Marelli 2
 500	MAINTENANCE	1.4 Turbo 16v	Marelli 2
 500	PARKING HELP	1.4 Turbo 16v	Valeo 2
 500	RH LIGHT MODULATI	1.4 Turbo 16v	Litronic
 500	VISUAL./TELEMATIC	1.4 Turbo 16v	Marelli/Microsoft Convergence
 Punto (199)-Grande Punto	ABS + TRACT. CONT	1.4 Turbo 16v (05-09)	Bosch ESP 8
 Punto (199)-Grande Punto	AIRBAG	1.4 Turbo 16v (05-09)	TRW SRS EP
 Punto (199)-Grande Punto	CHASSIS NETWORK	1.4 Turbo 16v (05-09)	DELPHI Body Computer
 Punto (199)-Grande Punto	CHASSIS NETWORK	1.4 Turbo 16v (05-09)	DELPHI Body Computer CAN Info
 Punto (199)-Grande Punto	CHASSIS NETWORK	1.4 Turbo 16v (05-09)	DELPHI Body Computer Proxi Alignement
 Punto (199)-Grande Punto	CLIMA	1.4 Turbo 16v (05-09)	DENSO
 Punto (199)-Grande Punto	DASHBOARD	1.4 Turbo 16v (05-09)	Marelli Dashboard Comfort
 Punto (199)-Grande Punto	DASHBOARD	1.4 Turbo 16v (05-09)	Marelli Dashboard Modale
 Punto (199)-Grande Punto	ELECTRIC STEERING	1.4 Turbo 16v (05-09)	DELPHI EPS
 Punto (199)-Grande Punto	ELECTRIC STEERING	1.4 Turbo 16v (05-09)	DELPHI EPS EP 3
 Punto (199)-Grande Punto	KEY ENCODE	1.4 Turbo 16v (05-09)	DELPHI Body Computer
 Punto (199)-Grande Punto	MAINTENANCE	1.4 Turbo 16v (05-09)	Bosch ESP 8
 Punto (199)-Grande Punto	MAINTENANCE	1.4 Turbo 16v (05-09)	DELPHI EPS
 Punto (199)-Grande Punto	MAINTENANCE	1.4 Turbo 16v (05-09)	DELPHI EPS EP 3
 Punto (199)-Grande Punto	MAINTENANCE	1.4 Turbo 16v (05-09)	Marelli Dashboard
 Punto (199)-Grande Punto	MAINTENANCE	1.4 Turbo 16v (05-09)	Marelli Dashboard Comfort
 Punto (199)-Grande Punto	MAINTENANCE	1.4 Turbo 16v (05-09)	Marelli Dashboard Comfort
 Punto (199)-Grande Punto	MAINTENANCE	1.4 Turbo 16v (05-09)	Marelli Dashboard Comfort
 Punto (199)-Grande Punto	MAINTENANCE	1.4 Turbo 16v (05-09)	Marelli Dashboard Modale
 Punto (199)-Grande Punto	MAINTENANCE	1.4 Turbo 16v (05-09)	Marelli Dashboard Modale
 Punto (199)-Grande Punto	MAINTENANCE	1.4 Turbo 16v (08-09)	Marelli Dashboard
 Punto (199)-Grande Punto	PARKING HELP	1.4 Turbo 16v (05-09)	Valeo 2
 Punto (199)-Grande Punto	SERVICE LIGHT RES	1.4 Turbo 16v (05-09)	Marelli Dashboard
 Punto (199)-Grande Punto	SERVICE LIGHT RES	1.4 Turbo 16v (08-09)	Marelli Dashboard
 Punto Evo (199)	ABS + TRACT. CONT	1.4 Turbo Multiair 16v (09-..)	Bosch ESP 8
 Punto Evo (199)	AIRBAG	1.4 Turbo Multiair 16v (09-..)	CONTINENTAL SRS EP
 Punto Evo (199)	CHASSIS NETWORK	1.4 Turbo Multiair 16v (09-..)	DELPHI Body Computer
 Punto Evo (199)	CHASSIS NETWORK	1.4 Turbo Multiair 16v (09-..)	DELPHI Body Computer CAN Info
 Punto Evo (199)	CHASSIS NETWORK	1.4 Turbo Multiair 16v (09-..)	DELPHI Body Computer Proxi Alignement
 Punto Evo (199)	CLIMA	1.4 Turbo Multiair 16v (09-..)	DENSO Clima
 Punto Evo (199)	DASHBOARD	1.4 Turbo Multiair 16v (09-..)	Marelli Dashboard Comfort
 Punto Evo (199)	DASHBOARD	1.4 Turbo Multiair 16v (09-..)	Marelli Dashboard Modale
 Punto Evo (199)	ELECTRIC STEERING	1.4 Turbo Multiair 16v (09-..)	DELPHI EPS
 Punto Evo (199)	ELECTRIC STEERING	1.4 Turbo Multiair 16v (09-..)	DELPHI EPS EP 3
 Punto Evo (199)	ENGINE MANAGEME	1.4 Turbo Multiair 16v (09-..)	EOBD
 Punto Evo (199)	ENGINE MANAGEME	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
 Punto Evo (199)	KEY ENCODE	1.4 Turbo Multiair 16v (09-..)	DELPHI Body Computer
 Punto Evo (199)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Bosch ESP 8
 Punto Evo (199)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	DELPHI EPS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Abarth

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
Punto Evo (199)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	DELPHI EPS EP 3
Punto Evo (199)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli Dashboard
Punto Evo (199)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli Dashboard Comfort
Punto Evo (199)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli Dashboard Comfort
Punto Evo (199)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli Dashboard Comfort
Punto Evo (199)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli Dashboard Modale
Punto Evo (199)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli Dashboard Modale
Punto Evo (199)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
Punto Evo (199)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
Punto Evo (199)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
Punto Evo (199)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
Punto Evo (199)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
Punto Evo (199)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
Punto Evo (199)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
Punto Evo (199)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
Punto Evo (199)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
Punto Evo (199)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
Punto Evo (199)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
Punto Evo (199)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
Punto Evo (199)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
Punto Evo (199)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
Punto Evo (199)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
Punto Evo (199)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
Punto Evo (199)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
Punto Evo (199)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
Punto Evo (199)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
Punto Evo (199)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
Punto Evo (199)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
Punto Evo (199)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
Punto Evo (199)	PARKING HELP	1.4 Turbo Multiair 16v (09-..)	Valeo 2
Punto Evo (199)	SERVICE LIGHT RES	1.4 Turbo Multiair 16v (09-..)	Marelli Dashboard
Punto Evo (199)	VISUAL./TELEMATIC	1.4 Turbo Multiair 16v (08-..)	Marelli Convergence

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 145	ABS	1.3 / 1.4	BOSCH ABS 2E
 145	ABS	1.3 / 1.4	BOSCH ABS 5.3
 145	ABS	1.4 TS 16v	BOSCH ABS 2E
 145	ABS	1.4 TS 16v	BOSCH ABS 5.3
 145	ABS	1.6	BOSCH ABS 2E
 145	ABS	1.6	BOSCH ABS 5.3
 145	ABS	1.6 TS 16v	BOSCH ABS 2E
 145	ABS	1.6 TS 16v	BOSCH ABS 5.3
 145	ABS	1.7 16v	BOSCH ABS 2E
 145	ABS	1.7 16v	BOSCH ABS 5.3
 145	ABS	1.8 TS 16v	BOSCH ABS 2E
 145	ABS	1.8 TS 16v	BOSCH ABS 5.3
 145	ABS	1.9 D	BOSCH ABS 2E
 145	ABS	1.9 D	BOSCH ABS 5.3
 145	ABS	1.9 JTD	BOSCH ABS 2E
 145	ABS	1.9 JTD	BOSCH ABS 5.3
 145	ABS	1.9 TD	BOSCH ABS 2E
 145	ABS	1.9 TD	BOSCH ABS 5.3
 145	ABS	2.0 TS 16v	BOSCH ABS 2E
 145	ABS	2.0 TS 16v	BOSCH ABS 5.3
 145	ABS	2.0 TS 16v Q.V.	BOSCH ABS 2E
 145	ABS	2.0 TS 16v Q.V.	BOSCH ABS 5.3
 145	AIRBAG	1.3 / 1.4	TRW AirBag MY 97 (2F)
 145	AIRBAG	1.3 / 1.4	TRW AirBag TRW2
 145	AIRBAG	1.3 / 1.4	TRW-Becker AirBag no Pret.
 145	AIRBAG	1.3 / 1.4 (98-..)	TRW AirBag MY 97 (2F)
 145	AIRBAG	1.3 / 1.4 (98-..)	TRW AirBag MY 97 (2F-2L)
 145	AIRBAG	1.3 / 1.4 (98-..)	TRW AirBag MY 97 (2F-2L-S)
 145	AIRBAG	1.3 / 1.4 (98-..)	TRW AirBag MY 97 (2F-S)
 145	AIRBAG	1.4 TS 16v	TRW AirBag MY 97 (2F)
 145	AIRBAG	1.4 TS 16v	TRW AirBag TRW2
 145	AIRBAG	1.4 TS 16v	TRW-Becker AirBag no Pret.
 145	AIRBAG	1.4 TS 16v (98-..)	TRW AirBag MY 97 (2F)
 145	AIRBAG	1.4 TS 16v (98-..)	TRW AirBag MY 97 (2F-2L)
 145	AIRBAG	1.4 TS 16v (98-..)	TRW AirBag MY 97 (2F-2L-S)
 145	AIRBAG	1.4 TS 16v (98-..)	TRW AirBag MY 97 (2F-S)
 145	AIRBAG	1.6	TRW AirBag MY 97 (2F)
 145	AIRBAG	1.6	TRW AirBag TRW2
 145	AIRBAG	1.6	TRW-Becker AirBag no Pret.
 145	AIRBAG	1.6 (98-..)	TRW AirBag MY 97 (2F)
 145	AIRBAG	1.6 (98-..)	TRW AirBag MY 97 (2F-2L)
 145	AIRBAG	1.6 (98-..)	TRW AirBag MY 97 (2F-2L-S)
 145	AIRBAG	1.6 (98-..)	TRW AirBag MY 97 (2F-S)
 145	AIRBAG	1.6 TS 16v	TRW AirBag MY 97 (2F)
 145	AIRBAG	1.6 TS 16v	TRW AirBag TRW2
 145	AIRBAG	1.6 TS 16v	TRW-Becker AirBag no Pret.
 145	AIRBAG	1.6 TS 16v (98-..)	TRW AirBag MY 97 (2F)
 145	AIRBAG	1.6 TS 16v (98-..)	TRW AirBag MY 97 (2F-2L)
 145	AIRBAG	1.6 TS 16v (98-..)	TRW AirBag MY 97 (2F-2L-S)
 145	AIRBAG	1.6 TS 16v (98-..)	TRW AirBag MY 97 (2F-S)
 145	AIRBAG	1.7 16v	TRW AirBag MY 97 (2F)
 145	AIRBAG	1.7 16v	TRW AirBag TRW2
 145	AIRBAG	1.7 16v	TRW-Becker AirBag no Pret.
 145	AIRBAG	1.7 16v (98-..)	TRW AirBag MY 97 (2F-2L)
 145	AIRBAG	1.7 16v (98-..)	TRW AirBag MY 97 (2F-2L-S)
 145	AIRBAG	1.7 16v (98-..)	TRW AirBag MY 97 (2F-S)
 145	AIRBAG	1.8 TS 16v	TRW AirBag MY 97 (2F)
 145	AIRBAG	1.8 TS 16v	TRW AirBag TRW2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 145	AIRBAG	1.8 TS 16v	TRW-Becker AirBag no Pret.
 145	AIRBAG	1.8 TS 16v (98-..)	TRW AirBag MY 97 (2F)
 145	AIRBAG	1.8 TS 16v (98-..)	TRW AirBag MY 97 (2F-2L)
 145	AIRBAG	1.8 TS 16v (98-..)	TRW AirBag MY 97 (2F-2L-S)
 145	AIRBAG	1.8 TS 16v (98-..)	TRW AirBag MY 97 (2F-S)
 145	AIRBAG	1.9 D	TRW AirBag MY 97 (2F)
 145	AIRBAG	1.9 D	TRW AirBag TRW2
 145	AIRBAG	1.9 D	TRW-Becker AirBag no Pret.
 145	AIRBAG	1.9 D (98-..)	TRW AirBag MY 97 (2F-2L)
 145	AIRBAG	1.9 D (98-..)	TRW AirBag MY 97 (2F-2L-S)
 145	AIRBAG	1.9 D (98-..)	TRW AirBag MY 97 (2F-S)
 145	AIRBAG	1.9 JTD	TRW AirBag MY 97 (2F)
 145	AIRBAG	1.9 JTD	TRW AirBag TRW2
 145	AIRBAG	1.9 JTD	TRW-Becker AirBag no Pret.
 145	AIRBAG	1.9 JTD (98-..)	TRW AirBag MY 97 (2F)
 145	AIRBAG	1.9 JTD (98-..)	TRW AirBag MY 97 (2F-2L)
 145	AIRBAG	1.9 JTD (98-..)	TRW AirBag MY 97 (2F-2L-S)
 145	AIRBAG	1.9 JTD (98-..)	TRW AirBag MY 97 (2F-S)
 145	AIRBAG	1.9 TD	TRW AirBag MY 97 (2F)
 145	AIRBAG	1.9 TD	TRW AirBag TRW2
 145	AIRBAG	1.9 TD	TRW-Becker AirBag no Pret.
 145	AIRBAG	1.9 TD (98-..)	TRW AirBag MY 97 (2F-2L)
 145	AIRBAG	1.9 TD (98-..)	TRW AirBag MY 97 (2F-2L-S)
 145	AIRBAG	1.9 TD (98-..)	TRW AirBag MY 97 (2F-S)
 145	AIRBAG	2.0 TS 16v	TRW AirBag MY 97 (2F)
 145	AIRBAG	2.0 TS 16v	TRW AirBag TRW2
 145	AIRBAG	2.0 TS 16v	TRW-Becker AirBag no Pret.
 145	AIRBAG	2.0 TS 16v (98-..)	TRW AirBag MY 97 (2F)
 145	AIRBAG	2.0 TS 16v (98-..)	TRW AirBag MY 97 (2F-2L)
 145	AIRBAG	2.0 TS 16v (98-..)	TRW AirBag MY 97 (2F-2L-S)
 145	AIRBAG	2.0 TS 16v (98-..)	TRW AirBag MY 97 (2F-S)
 145	AIRBAG	2.0 TS 16v Q.V.	TRW AirBag MY 97 (2F)
 145	AIRBAG	2.0 TS 16v Q.V.	TRW AirBag TRW2
 145	AIRBAG	2.0 TS 16v Q.V.	TRW-Becker AirBag no Pret.
 145	AIRBAG	2.0 TS 16v Q.V. (98-..)	TRW AirBag MY 97 (2F)
 145	AIRBAG	2.0 TS 16v Q.V. (98-..)	TRW AirBag MY 97 (2F-2L)
 145	AIRBAG	2.0 TS 16v Q.V. (98-..)	TRW AirBag MY 97 (2F-2L-S)
 145	AIRBAG	2.0 TS 16v Q.V. (98-..)	TRW AirBag MY 97 (2F-S)
 145	ENGINE MANAGEME	1.3 / 1.4	Marelli IAW 8F.6B
 145	ENGINE MANAGEME	1.4 TS 16v	BOSCH Motronic M2.10.4
 145	ENGINE MANAGEME	1.4 TS 16v	BOSCH Motronic M2.10.4
 145	ENGINE MANAGEME	1.4 TS 16v (98-..)	BOSCH Motronic M1.5.5
 145	ENGINE MANAGEME	1.6	BOSCH Motronic MP3.1
 145	ENGINE MANAGEME	1.6	GM MPI Rochester
 145	ENGINE MANAGEME	1.6	GM MPI Rochester
 145	ENGINE MANAGEME	1.6 TS 16v	BOSCH Motronic M2.10.4
 145	ENGINE MANAGEME	1.6 TS 16v (98-..)	BOSCH Motronic M1.5.5
 145	ENGINE MANAGEME	1.7 16v	BOSCH Motronic M2.10.3
 145	ENGINE MANAGEME	1.7 16v	BOSCH Motronic M2.10.4
 145	ENGINE MANAGEME	1.7 16v + Immob.	BOSCH Motronic M2.10.3
 145	ENGINE MANAGEME	1.8 TS 16v	BOSCH Motronic M2.10.4
 145	ENGINE MANAGEME	1.8 TS 16v (98-..)	BOSCH Motronic M1.5.5
 145	ENGINE MANAGEME	1.9 JTD (.-98)	BOSCH EDC 15 Common Rail
 145	ENGINE MANAGEME	1.9 JTD (99-..)	BOSCH EDC 15 Common Rail (JTD '99)
 145	ENGINE MANAGEME	2.0 TS 16v (98-..)	BOSCH Motronic M1.5.5
 145	ENGINE MANAGEME	2.0 TS 16v Q.V.	BOSCH Motronic M2.10.4
 145	KEY ENCODE	1.3 / 1.4	BOSCH CODE MANUAL
 145	KEY ENCODE	1.4 TS 16v	BOSCH CODE MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 145	KEY ENCODE	1.6	BOSCH CODE MANUAL
 145	KEY ENCODE	1.6 TS 16v	BOSCH CODE MANUAL
 145	KEY ENCODE	1.7 16v	BOSCH CODE MANUAL
 145	KEY ENCODE	1.8 TS 16v	BOSCH CODE MANUAL
 145	KEY ENCODE	1.9 D	BOSCH CODE MANUAL
 145	KEY ENCODE	1.9 JTD	BOSCH CODE MANUAL
 145	KEY ENCODE	1.9 TD	BOSCH CODE MANUAL
 145	KEY ENCODE	2.0 TS 16v	BOSCH CODE MANUAL
 145	KEY ENCODE	2.0 TS 16v Q.V.	BOSCH CODE MANUAL
 145	MAINTENANCE	1.3 / 1.4	BOSCH CODE MANUAL
 145	MAINTENANCE	1.4 TS 16v	BOSCH CODE MANUAL
 145	MAINTENANCE	1.6	BOSCH CODE MANUAL
 145	MAINTENANCE	1.6 TS 16v	BOSCH CODE MANUAL
 145	MAINTENANCE	1.7 16v	BOSCH CODE MANUAL
 145	MAINTENANCE	1.8 TS 16v	BOSCH CODE MANUAL
 145	MAINTENANCE	1.9 D	BOSCH CODE MANUAL
 145	MAINTENANCE	1.9 JTD	BOSCH CODE MANUAL
 145	MAINTENANCE	1.9 TD	BOSCH CODE MANUAL
 145	MAINTENANCE	2.0 TS 16v	BOSCH CODE MANUAL
 145	MAINTENANCE	2.0 TS 16v Q.V.	BOSCH CODE MANUAL
 146	ABS	1.3 / 1.4	BOSCH ABS 2E
 146	ABS	1.4 TS 16v	BOSCH ABS 2E
 146	ABS	1.4 TS 16v	BOSCH ABS 5.3
 146	ABS	1.6	BOSCH ABS 2E
 146	ABS	1.6	BOSCH ABS 5.3
 146	ABS	1.6 TS 16v	BOSCH ABS 2E
 146	ABS	1.6 TS 16v	BOSCH ABS 5.3
 146	ABS	1.7 16v	BOSCH ABS 2E
 146	ABS	1.7 16v	BOSCH ABS 5.3
 146	ABS	1.8 TS 16v	BOSCH ABS 2E
 146	ABS	1.8 TS 16v	BOSCH ABS 5.3
 146	ABS	1.9 D	BOSCH ABS 2E
 146	ABS	1.9 D	BOSCH ABS 5.3
 146	ABS	1.9 JTD	BOSCH ABS 2E
 146	ABS	1.9 JTD	BOSCH ABS 5.3
 146	ABS	1.9 TD	BOSCH ABS 2E
 146	ABS	1.9 TD	BOSCH ABS 5.3
 146	ABS	2.0 TS 16v	BOSCH ABS 2E
 146	ABS	2.0 TS 16v	BOSCH ABS 5.3
 146	ABS	ti	BOSCH ABS 2E
 146	ABS	ti	BOSCH ABS 5.3
 146	AIRBAG	1.3 / 1.4	TRW AirBag MY 97 (2F)
 146	AIRBAG	1.3 / 1.4	TRW AirBag TRW2
 146	AIRBAG	1.3 / 1.4	TRW-Becker AirBag no Pret.
 146	AIRBAG	1.3 / 1.4 (98-..)	TRW AirBag MY 97 (2F)
 146	AIRBAG	1.3 / 1.4 (98-..)	TRW AirBag MY 97 (2F-2L)
 146	AIRBAG	1.3 / 1.4 (98-..)	TRW AirBag MY 97 (2F-2L-S)
 146	AIRBAG	1.3 / 1.4 (98-..)	TRW AirBag MY 97 (2F-S)
 146	AIRBAG	1.4 TS 16v	TRW AirBag MY 97 (2F)
 146	AIRBAG	1.4 TS 16v	TRW AirBag TRW2
 146	AIRBAG	1.4 TS 16v	TRW-Becker AirBag no Pret.
 146	AIRBAG	1.4 TS 16v (98-..)	TRW AirBag MY 97 (2F)
 146	AIRBAG	1.4 TS 16v (98-..)	TRW AirBag MY 97 (2F-2L)
 146	AIRBAG	1.4 TS 16v (98-..)	TRW AirBag MY 97 (2F-2L-S)
 146	AIRBAG	1.4 TS 16v (98-..)	TRW AirBag MY 97 (2F-S)
 146	AIRBAG	1.6	TRW AirBag MY 97 (2F)
 146	AIRBAG	1.6	TRW AirBag TRW2
 146	AIRBAG	1.6	TRW-Becker AirBag no Pret.

Systems supported by ECUREADER / ECUDECODER (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 146	AIRBAG	1.6 (98-..)	TRW AirBag MY 97 (2F)
 146	AIRBAG	1.6 (98-..)	TRW AirBag MY 97 (2F-2L)
 146	AIRBAG	1.6 (98-..)	TRW AirBag MY 97 (2F-2L-S)
 146	AIRBAG	1.6 (98-..)	TRW AirBag MY 97 (2F-S)
 146	AIRBAG	1.6 TS 16v	TRW AirBag MY 97 (2F)
 146	AIRBAG	1.6 TS 16v	TRW AirBag TRW2
 146	AIRBAG	1.6 TS 16v	TRW-Becker AirBag no Pret.
 146	AIRBAG	1.6 TS 16v (98-..)	TRW AirBag MY 97 (2F)
 146	AIRBAG	1.6 TS 16v (98-..)	TRW AirBag MY 97 (2F-2L)
 146	AIRBAG	1.6 TS 16v (98-..)	TRW AirBag MY 97 (2F-2L-S)
 146	AIRBAG	1.6 TS 16v (98-..)	TRW AirBag MY 97 (2F-S)
 146	AIRBAG	1.7 16v	TRW AirBag MY 97 (2F)
 146	AIRBAG	1.7 16v	TRW AirBag TRW2
 146	AIRBAG	1.7 16v	TRW-Becker AirBag no Pret.
 146	AIRBAG	1.7 16v (98-..)	TRW AirBag MY 97 (2F-2L)
 146	AIRBAG	1.7 16v (98-..)	TRW AirBag MY 97 (2F-2L-S)
 146	AIRBAG	1.7 16v (98-..)	TRW AirBag MY 97 (2F-S)
 146	AIRBAG	1.8 TS 16v	TRW AirBag MY 97 (2F)
 146	AIRBAG	1.8 TS 16v	TRW AirBag TRW2
 146	AIRBAG	1.8 TS 16v	TRW-Becker AirBag no Pret.
 146	AIRBAG	1.8 TS 16v (98-..)	TRW AirBag MY 97 (2F)
 146	AIRBAG	1.8 TS 16v (98-..)	TRW AirBag MY 97 (2F-2L)
 146	AIRBAG	1.8 TS 16v (98-..)	TRW AirBag MY 97 (2F-2L-S)
 146	AIRBAG	1.8 TS 16v (98-..)	TRW AirBag MY 97 (2F-S)
 146	AIRBAG	1.9 D	TRW AirBag MY 97 (2F)
 146	AIRBAG	1.9 D	TRW AirBag TRW2
 146	AIRBAG	1.9 D	TRW-Becker AirBag no Pret.
 146	AIRBAG	1.9 D (98-..)	TRW AirBag MY 97 (2F)
 146	AIRBAG	1.9 D (98-..)	TRW AirBag MY 97 (2F-2L)
 146	AIRBAG	1.9 D (98-..)	TRW AirBag MY 97 (2F-2L-S)
 146	AIRBAG	1.9 D (98-..)	TRW AirBag MY 97 (2F-S)
 146	AIRBAG	1.9 JTD	TRW AirBag MY 97 (2F)
 146	AIRBAG	1.9 JTD	TRW AirBag TRW2
 146	AIRBAG	1.9 JTD	TRW-Becker AirBag no Pret.
 146	AIRBAG	1.9 JTD (98-..)	TRW AirBag MY 97 (2F)
 146	AIRBAG	1.9 JTD (98-..)	TRW AirBag MY 97 (2F-2L)
 146	AIRBAG	1.9 JTD (98-..)	TRW AirBag MY 97 (2F-2L-S)
 146	AIRBAG	1.9 JTD (98-..)	TRW AirBag MY 97 (2F-S)
 146	AIRBAG	1.9 TD	TRW AirBag MY 97 (2F)
 146	AIRBAG	1.9 TD	TRW AirBag TRW2
 146	AIRBAG	1.9 TD	TRW-Becker AirBag no Pret.
 146	AIRBAG	1.9 TD (98-..)	TRW AirBag MY 97 (2F)
 146	AIRBAG	1.9 TD (98-..)	TRW AirBag MY 97 (2F-2L)
 146	AIRBAG	1.9 TD (98-..)	TRW AirBag MY 97 (2F-2L-S)
 146	AIRBAG	1.9 TD (98-..)	TRW AirBag MY 97 (2F-S)
 146	AIRBAG	2.0 TS 16v	TRW AirBag MY 97 (2F)
 146	AIRBAG	2.0 TS 16v	TRW AirBag TRW2
 146	AIRBAG	2.0 TS 16v	TRW-Becker AirBag no Pret.
 146	AIRBAG	2.0 TS 16v (98-..)	TRW AirBag MY 97 (2F)
 146	AIRBAG	2.0 TS 16v (98-..)	TRW AirBag MY 97 (2F-2L)
 146	AIRBAG	2.0 TS 16v (98-..)	TRW AirBag MY 97 (2F-2L-S)
 146	AIRBAG	2.0 TS 16v (98-..)	TRW AirBag MY 97 (2F-S)
 146	AIRBAG	ti	TRW AirBag MY 97 (2F)
 146	AIRBAG	ti	TRW AirBag TRW2
 146	AIRBAG	ti	TRW-Becker AirBag no Pret.
 146	AIRBAG	ti (98-..)	TRW AirBag MY 97 (2F)
 146	AIRBAG	ti (98-..)	TRW AirBag MY 97 (2F-2L)
 146	AIRBAG	ti (98-..)	TRW AirBag MY 97 (2F-2L-S)

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 146	AIRBAG	ti (98-..)	TRW AirBag MY 97 (2F-S)
 146	ENGINE MANAGEME	1.3 / 1.4	Marelli IAW 8F.6B
 146	ENGINE MANAGEME	1.4 TS 16v	BOSCH Motronic M2.10.4
 146	ENGINE MANAGEME	1.4 TS 16v (98-..)	BOSCH Motronic M1.5.5
 146	ENGINE MANAGEME	1.6	GM MPI Rochester
 146	ENGINE MANAGEME	1.6	GM MPI Rochester
 146	ENGINE MANAGEME	1.6 TS 16v	BOSCH Motronic M2.10.4
 146	ENGINE MANAGEME	1.6 TS 16v (98-..)	BOSCH Motronic M1.5.5
 146	ENGINE MANAGEME	1.7 16v	BOSCH Motronic M2.10.3
 146	ENGINE MANAGEME	1.7 16v	BOSCH Motronic M2.10.4
 146	ENGINE MANAGEME	1.7 16v + Immob.	BOSCH Motronic M2.10.3
 146	ENGINE MANAGEME	1.8 TS 16v	BOSCH Motronic M2.10.4
 146	ENGINE MANAGEME	1.8 TS 16v (98-..)	BOSCH Motronic M1.5.5
 146	ENGINE MANAGEME	1.9 JTD (..-98)	BOSCH EDC 15 Common Rail
 146	ENGINE MANAGEME	1.9 JTD (99-..)	BOSCH EDC 15 Common Rail (JTD '99)
 146	ENGINE MANAGEME	2.0 TS 16v (98-..)	BOSCH Motronic M1.5.5
 146	ENGINE MANAGEME	ti	BOSCH Motronic M2.10.4
 146	KEY ENCODE	1.3 / 1.4	BOSCH CODE MANUAL
 146	KEY ENCODE	1.4 TS 16v	BOSCH CODE MANUAL
 146	KEY ENCODE	1.6	BOSCH CODE MANUAL
 146	KEY ENCODE	1.6 TS 16v	BOSCH CODE MANUAL
 146	KEY ENCODE	1.7 16v	BOSCH CODE MANUAL
 146	KEY ENCODE	1.8 TS 16v	BOSCH CODE MANUAL
 146	KEY ENCODE	1.9 D	BOSCH CODE MANUAL
 146	KEY ENCODE	1.9 JTD	BOSCH CODE MANUAL
 146	KEY ENCODE	1.9 TD	BOSCH CODE MANUAL
 146	KEY ENCODE	2.0 TS 16v	BOSCH CODE MANUAL
 146	KEY ENCODE	ti	BOSCH CODE MANUAL
 146	MAINTENANCE	1.3 / 1.4	BOSCH CODE MANUAL
 146	MAINTENANCE	1.4 TS 16v	BOSCH CODE MANUAL
 146	MAINTENANCE	1.6	BOSCH CODE MANUAL
 146	MAINTENANCE	1.6 TS 16v	BOSCH CODE MANUAL
 146	MAINTENANCE	1.7 16v	BOSCH CODE MANUAL
 146	MAINTENANCE	1.8 TS 16v	BOSCH CODE MANUAL
 146	MAINTENANCE	1.9 D	BOSCH CODE MANUAL
 146	MAINTENANCE	1.9 JTD	BOSCH CODE MANUAL
 146	MAINTENANCE	1.9 TD	BOSCH CODE MANUAL
 146	MAINTENANCE	2.0 TS 16v	BOSCH CODE MANUAL
 146	MAINTENANCE	ti	BOSCH CODE MANUAL
 147	ABS + TRACT. CONT	1.6 TS 16v 105cv	BOSCH ABS/VDC 5.7
 147	ABS + TRACT. CONT	1.6 TS 16v 105cv (05-..)	BOSCH ABS/VDC 8
 147	ABS + TRACT. CONT	1.6 TS 16v 120cv	BOSCH ABS/VDC 5.7
 147	ABS + TRACT. CONT	1.6 TS 16v 120cv (05-..)	BOSCH ABS/VDC 8
 147	ABS + TRACT. CONT	1.9 JTD 100cv	BOSCH ABS/VDC 5.7
 147	ABS + TRACT. CONT	1.9 JTD 116cv	BOSCH ABS/VDC 5.7
 147	ABS + TRACT. CONT	1.9 JTD 120cv	BOSCH ABS/VDC 5.7
 147	ABS + TRACT. CONT	1.9 JTD 16v	BOSCH ABS/VDC 5.7
 147	ABS + TRACT. CONT	1.9 JTD 16v (05-..)	BOSCH ABS/VDC 8
 147	ABS + TRACT. CONT	1.9 JTDm	BOSCH ABS/VDC 5.7
 147	ABS + TRACT. CONT	1.9 JTDm (05-..)	BOSCH ABS/VDC 8
 147	ABS + TRACT. CONT	1.9 JTDm 16v	BOSCH ABS/VDC 5.7
 147	ABS + TRACT. CONT	1.9 JTDm 16v (05-..)	BOSCH ABS/VDC 8
 147	ABS + TRACT. CONT	2.0 TS 16v	BOSCH ABS/VDC 5.7
 147	ABS + TRACT. CONT	2.0 TS 16v (05-..)	BOSCH ABS/VDC 8
 147	ABS + TRACT. CONT	2.0 TS 16v Selespeed	BOSCH ABS/VDC 5.7
 147	ABS + TRACT. CONT	3.2 V6 GTA (02-..)	BOSCH ABS/VDC 5.7
 147	ABS + TRACT. CONT	3.2 V6 GTA (05-..)	BOSCH ABS/VDC 8
 147	AIRBAG	1.6 TS 16v 105cv	ALLIED AirBag MY 97 (2F-2P)

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 147	AIRBAG	1.6 TS 16v 105cv	ALLIED AirBag MY 97 (2F-2P-2L-2T-I)
 147	AIRBAG	1.6 TS 16v 105cv	ALLIED AirBag MY 97 (2F-2P-2L-I)
 147	AIRBAG	1.6 TS 16v 105cv	ALLIED AirBag MY 97 (2F-2P-2L-I-S)
 147	AIRBAG	1.6 TS 16v 105cv	ALLIED AirBag MY 97 (2F-2P-I)
 147	AIRBAG	1.6 TS 16v 105cv	ALLIED AirBag MY 97 (2F-2P-I-S)
 147	AIRBAG	1.6 TS 16v 105cv	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 147	AIRBAG	1.6 TS 16v 105cv	TRW AirBag MY 97 (2F-2P-2L-I)
 147	AIRBAG	1.6 TS 16v 105cv	TRW AirBag MY 97 (2F-2P-2L-I-S)
 147	AIRBAG	1.6 TS 16v 105cv	TRW AirBag MY 97 (2F-2P-I)
 147	AIRBAG	1.6 TS 16v 105cv	TRW AirBag MY 97 (2F-2P-I-S)
 147	AIRBAG	1.6 TS 16v 120cv	ALLIED AirBag MY 97 (2F-2P)
 147	AIRBAG	1.6 TS 16v 120cv	ALLIED AirBag MY 97 (2F-2P-2L-I)
 147	AIRBAG	1.6 TS 16v 120cv	ALLIED AirBag MY 97 (2F-2P-2L-I-S)
 147	AIRBAG	1.6 TS 16v 120cv	ALLIED AirBag MY 97 (2F-2P-I)
 147	AIRBAG	1.6 TS 16v 120cv	ALLIED AirBag MY 97 (2F-2P-I-S)
 147	AIRBAG	1.6 TS 16v 120cv	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 147	AIRBAG	1.6 TS 16v 120cv	TRW AirBag MY 97 (2F-2P-2L-I)
 147	AIRBAG	1.6 TS 16v 120cv	TRW AirBag MY 97 (2F-2P-2L-I-S)
 147	AIRBAG	1.6 TS 16v 120cv	TRW AirBag MY 97 (2F-2P-I)
 147	AIRBAG	1.6 TS 16v 120cv	TRW AirBag MY 97 (2F-2P-I-S)
 147	AIRBAG	1.6 TS 16v 120cv (02-..)	ALLIED AirBag MY 97 (2F-2P-2L-2T-I)
 147	AIRBAG	1.9 JTD 100cv	ALLIED AirBag MY 97 (2F-2P)
 147	AIRBAG	1.9 JTD 100cv	ALLIED AirBag MY 97 (2F-2P-2L-I)
 147	AIRBAG	1.9 JTD 100cv	ALLIED AirBag MY 97 (2F-2P-2L-I-S)
 147	AIRBAG	1.9 JTD 100cv	ALLIED AirBag MY 97 (2F-2P-I)
 147	AIRBAG	1.9 JTD 100cv	ALLIED AirBag MY 97 (2F-2P-I-S)
 147	AIRBAG	1.9 JTD 100cv	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 147	AIRBAG	1.9 JTD 100cv	TRW AirBag MY 97 (2F-2P-2L-I)
 147	AIRBAG	1.9 JTD 100cv	TRW AirBag MY 97 (2F-2P-2L-I-S)
 147	AIRBAG	1.9 JTD 100cv	TRW AirBag MY 97 (2F-2P-I)
 147	AIRBAG	1.9 JTD 100cv	TRW AirBag MY 97 (2F-2P-I-S)
 147	AIRBAG	1.9 JTD 100cv (02-..)	ALLIED AirBag MY 97 (2F-2P-2L-2T-I)
 147	AIRBAG	1.9 JTD 116cv	ALLIED AirBag MY 97 (2F-2P)
 147	AIRBAG	1.9 JTD 116cv	ALLIED AirBag MY 97 (2F-2P-2L-I)
 147	AIRBAG	1.9 JTD 116cv	ALLIED AirBag MY 97 (2F-2P-2L-I-S)
 147	AIRBAG	1.9 JTD 116cv	ALLIED AirBag MY 97 (2F-2P-I)
 147	AIRBAG	1.9 JTD 116cv	ALLIED AirBag MY 97 (2F-2P-I-S)
 147	AIRBAG	1.9 JTD 116cv	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 147	AIRBAG	1.9 JTD 116cv	TRW AirBag MY 97 (2F-2P-2L-I)
 147	AIRBAG	1.9 JTD 116cv	TRW AirBag MY 97 (2F-2P-2L-I-S)
 147	AIRBAG	1.9 JTD 116cv	TRW AirBag MY 97 (2F-2P-I)
 147	AIRBAG	1.9 JTD 116cv	TRW AirBag MY 97 (2F-2P-I-S)
 147	AIRBAG	1.9 JTD 116cv (02-..)	ALLIED AirBag MY 97 (2F-2P-2L-2T-I)
 147	AIRBAG	1.9 JTD 120cv	ALLIED AirBag MY 97 (2F-2P)
 147	AIRBAG	1.9 JTD 120cv	ALLIED AirBag MY 97 (2F-2P-2L-I)
 147	AIRBAG	1.9 JTD 120cv	ALLIED AirBag MY 97 (2F-2P-2L-I-S)
 147	AIRBAG	1.9 JTD 120cv	ALLIED AirBag MY 97 (2F-2P-I)
 147	AIRBAG	1.9 JTD 120cv	ALLIED AirBag MY 97 (2F-2P-I-S)
 147	AIRBAG	1.9 JTD 120cv	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 147	AIRBAG	1.9 JTD 120cv	TRW AirBag MY 97 (2F-2P-2L-I)
 147	AIRBAG	1.9 JTD 120cv	TRW AirBag MY 97 (2F-2P-2L-I-S)
 147	AIRBAG	1.9 JTD 120cv	TRW AirBag MY 97 (2F-2P-I)
 147	AIRBAG	1.9 JTD 120cv	TRW AirBag MY 97 (2F-2P-I-S)
 147	AIRBAG	1.9 JTD 120cv (02-..)	ALLIED AirBag MY 97 (2F-2P-2L-2T-I)
 147	AIRBAG	1.9 JTD 16v	ALLIED AirBag MY 97 (2F-2P)
 147	AIRBAG	1.9 JTD 16v	ALLIED AirBag MY 97 (2F-2P-2L-2T-I)
 147	AIRBAG	1.9 JTD 16v	ALLIED AirBag MY 97 (2F-2P-2L-I)
 147	AIRBAG	1.9 JTD 16v	ALLIED AirBag MY 97 (2F-2P-2L-I-S)

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 147	AIRBAG	1.9 JTD 16v	ALLIED AirBag MY 97 (2F-2P-I)
 147	AIRBAG	1.9 JTD 16v	ALLIED AirBag MY 97 (2F-2P-I-S)
 147	AIRBAG	1.9 JTD 16v	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 147	AIRBAG	1.9 JTD 16v	TRW AirBag MY 97 (2F-2P-2L-I)
 147	AIRBAG	1.9 JTD 16v	TRW AirBag MY 97 (2F-2P-2L-I-S)
 147	AIRBAG	1.9 JTD 16v	TRW AirBag MY 97 (2F-2P-I)
 147	AIRBAG	1.9 JTD 16v	TRW AirBag MY 97 (2F-2P-I-S)
 147	AIRBAG	1.9 JTDm	ALLIED AirBag MY 97 (2F-2P)
 147	AIRBAG	1.9 JTDm	ALLIED AirBag MY 97 (2F-2P-2L-2T-I)
 147	AIRBAG	1.9 JTDm	ALLIED AirBag MY 97 (2F-2P-2L-I)
 147	AIRBAG	1.9 JTDm	ALLIED AirBag MY 97 (2F-2P-2L-I-S)
 147	AIRBAG	1.9 JTDm	ALLIED AirBag MY 97 (2F-2P-I)
 147	AIRBAG	1.9 JTDm	ALLIED AirBag MY 97 (2F-2P-I-S)
 147	AIRBAG	1.9 JTDm	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 147	AIRBAG	1.9 JTDm	TRW AirBag MY 97 (2F-2P-2L-I)
 147	AIRBAG	1.9 JTDm	TRW AirBag MY 97 (2F-2P-2L-I-S)
 147	AIRBAG	1.9 JTDm	TRW AirBag MY 97 (2F-2P-I)
 147	AIRBAG	1.9 JTDm	TRW AirBag MY 97 (2F-2P-I-S)
 147	AIRBAG	1.9 JTDm 16v	ALLIED AirBag MY 97 (2F-2P)
 147	AIRBAG	1.9 JTDm 16v	ALLIED AirBag MY 97 (2F-2P-2L-2T-I)
 147	AIRBAG	1.9 JTDm 16v	ALLIED AirBag MY 97 (2F-2P-2L-I)
 147	AIRBAG	1.9 JTDm 16v	ALLIED AirBag MY 97 (2F-2P-2L-I-S)
 147	AIRBAG	1.9 JTDm 16v	ALLIED AirBag MY 97 (2F-2P-I)
 147	AIRBAG	1.9 JTDm 16v	ALLIED AirBag MY 97 (2F-2P-I-S)
 147	AIRBAG	1.9 JTDm 16v	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 147	AIRBAG	1.9 JTDm 16v	TRW AirBag MY 97 (2F-2P-2L-I)
 147	AIRBAG	1.9 JTDm 16v	TRW AirBag MY 97 (2F-2P-2L-I-S)
 147	AIRBAG	1.9 JTDm 16v	TRW AirBag MY 97 (2F-2P-I)
 147	AIRBAG	1.9 JTDm 16v	TRW AirBag MY 97 (2F-2P-I-S)
 147	AIRBAG	2.0 TS 16v	ALLIED AirBag MY 97 (2F-2P)
 147	AIRBAG	2.0 TS 16v	ALLIED AirBag MY 97 (2F-2P-2L-2T-I)
 147	AIRBAG	2.0 TS 16v	ALLIED AirBag MY 97 (2F-2P-2L-I)
 147	AIRBAG	2.0 TS 16v	ALLIED AirBag MY 97 (2F-2P-2L-I-S)
 147	AIRBAG	2.0 TS 16v	ALLIED AirBag MY 97 (2F-2P-I)
 147	AIRBAG	2.0 TS 16v	ALLIED AirBag MY 97 (2F-2P-I-S)
 147	AIRBAG	2.0 TS 16v	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 147	AIRBAG	2.0 TS 16v	TRW AirBag MY 97 (2F-2P-2L-I)
 147	AIRBAG	2.0 TS 16v	TRW AirBag MY 97 (2F-2P-2L-I-S)
 147	AIRBAG	2.0 TS 16v	TRW AirBag MY 97 (2F-2P-I)
 147	AIRBAG	2.0 TS 16v	TRW AirBag MY 97 (2F-2P-I-S)
 147	AIRBAG	2.0 TS 16v Selespeed	ALLIED AirBag MY 97 (2F-2P)
 147	AIRBAG	2.0 TS 16v Selespeed	ALLIED AirBag MY 97 (2F-2P-2L-I)
 147	AIRBAG	2.0 TS 16v Selespeed	ALLIED AirBag MY 97 (2F-2P-2L-I-S)
 147	AIRBAG	2.0 TS 16v Selespeed	ALLIED AirBag MY 97 (2F-2P-I)
 147	AIRBAG	2.0 TS 16v Selespeed	ALLIED AirBag MY 97 (2F-2P-I-S)
 147	AIRBAG	2.0 TS 16v Selespeed	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 147	AIRBAG	2.0 TS 16v Selespeed	TRW AirBag MY 97 (2F-2P-2L-I)
 147	AIRBAG	2.0 TS 16v Selespeed	TRW AirBag MY 97 (2F-2P-2L-I-S)
 147	AIRBAG	2.0 TS 16v Selespeed	TRW AirBag MY 97 (2F-2P-I)
 147	AIRBAG	2.0 TS 16v Selespeed	TRW AirBag MY 97 (2F-2P-I-S)
 147	AIRBAG	2.0 TS 16v Selespeed (02-..)	ALLIED AirBag MY 97 (2F-2P-2L-2T-I)
 147	AIRBAG	3.2 V6 GTA (02-..)	ALLIED AirBag MY 97 (2F-2P)
 147	AIRBAG	3.2 V6 GTA (02-..)	ALLIED AirBag MY 97 (2F-2P-2L-2T-I)
 147	AIRBAG	3.2 V6 GTA (02-..)	ALLIED AirBag MY 97 (2F-2P-2L-I)
 147	AIRBAG	3.2 V6 GTA (02-..)	ALLIED AirBag MY 97 (2F-2P-2L-I-S)
 147	AIRBAG	3.2 V6 GTA (02-..)	ALLIED AirBag MY 97 (2F-2P-I)
 147	AIRBAG	3.2 V6 GTA (02-..)	ALLIED AirBag MY 97 (2F-2P-I-S)
 147	AIRBAG	3.2 V6 GTA (02-..)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 147	AIRBAG	3.2 V6 GTA (02-..)	TRW AirBag MY 97 (2F-2P-2L-I)
 147	AIRBAG	3.2 V6 GTA (02-..)	TRW AirBag MY 97 (2F-2P-2L-I-S)
 147	AIRBAG	3.2 V6 GTA (02-..)	TRW AirBag MY 97 (2F-2P-I)
 147	AIRBAG	3.2 V6 GTA (02-..)	TRW AirBag MY 97 (2F-2P-I-S)
 147	AUTOM. TRANSMISSI	2.0 TS 16v Selespeed	Marelli Selespeed CFC208F
 147	CHASSIS NETWORK	1.6 TS 16v 105cv	Alfa Romeo CAN Info
 147	CHASSIS NETWORK	1.6 TS 16v 105cv	Alfa Romeo Proxi Alignement
 147	CHASSIS NETWORK	1.6 TS 16v 105cv	DELPHI/Marelli Body Computer
 147	CHASSIS NETWORK	1.6 TS 16v 120cv	Alfa Romeo CAN Info
 147	CHASSIS NETWORK	1.6 TS 16v 120cv	Alfa Romeo Proxi Alignement
 147	CHASSIS NETWORK	1.6 TS 16v 120cv	DELPHI/Marelli Body Computer
 147	CHASSIS NETWORK	1.9 JTD 100cv	Alfa Romeo CAN Info
 147	CHASSIS NETWORK	1.9 JTD 100cv	Alfa Romeo Proxi Alignement
 147	CHASSIS NETWORK	1.9 JTD 100cv	DELPHI/Marelli Body Computer
 147	CHASSIS NETWORK	1.9 JTD 116cv	Alfa Romeo CAN Info
 147	CHASSIS NETWORK	1.9 JTD 116cv	Alfa Romeo Proxi Alignement
 147	CHASSIS NETWORK	1.9 JTD 116cv	DELPHI/Marelli Body Computer
 147	CHASSIS NETWORK	1.9 JTD 120cv	Alfa Romeo CAN Info
 147	CHASSIS NETWORK	1.9 JTD 120cv	Alfa Romeo Proxi Alignement
 147	CHASSIS NETWORK	1.9 JTD 120cv	DELPHI/Marelli Body Computer
 147	CHASSIS NETWORK	1.9 JTD 16v	Alfa Romeo CAN Info
 147	CHASSIS NETWORK	1.9 JTD 16v	Alfa Romeo Proxi Alignement
 147	CHASSIS NETWORK	1.9 JTD 16v	DELPHI/Marelli Body Computer
 147	CHASSIS NETWORK	1.9 JTDm	Alfa Romeo CAN Info
 147	CHASSIS NETWORK	1.9 JTDm	Alfa Romeo Proxi Alignement
 147	CHASSIS NETWORK	1.9 JTDm	DELPHI/Marelli Body Computer
 147	CHASSIS NETWORK	1.9 JTDm 16v	Alfa Romeo CAN Info
 147	CHASSIS NETWORK	1.9 JTDm 16v	Alfa Romeo Proxi Alignement
 147	CHASSIS NETWORK	1.9 JTDm 16v	DELPHI/Marelli Body Computer
 147	CHASSIS NETWORK	2.0 TS 16v	Alfa Romeo CAN Info
 147	CHASSIS NETWORK	2.0 TS 16v	Alfa Romeo Proxi Alignement
 147	CHASSIS NETWORK	2.0 TS 16v	DELPHI/Marelli Body Computer
 147	CHASSIS NETWORK	2.0 TS 16v Selespeed	Alfa Romeo CAN Info
 147	CHASSIS NETWORK	2.0 TS 16v Selespeed	Alfa Romeo Proxi Alignement
 147	CHASSIS NETWORK	2.0 TS 16v Selespeed	DELPHI/Marelli Body Computer
 147	CHASSIS NETWORK	3.2 V6 GTA (02-..)	Alfa Romeo CAN Info
 147	CHASSIS NETWORK	3.2 V6 GTA (02-..)	Alfa Romeo Proxi Alignement
 147	CHASSIS NETWORK	3.2 V6 GTA (02-..)	DELPHI/Marelli Body Computer
 147	CLIMA	1.6 TS 16v 105cv	DELPHI Klima Bizone
 147	CLIMA	1.6 TS 16v 105cv	DELPHI klima Monozone
 147	CLIMA	1.6 TS 16v 120cv	DELPHI klima Bizone
 147	CLIMA	1.6 TS 16v 120cv	DELPHI klima Monozone
 147	CLIMA	1.9 JTD 100cv	DELPHI klima Bizone
 147	CLIMA	1.9 JTD 100cv	DELPHI klima Monozone
 147	CLIMA	1.9 JTD 116cv	DELPHI klima Bizone
 147	CLIMA	1.9 JTD 116cv	DELPHI klima Monozone
 147	CLIMA	1.9 JTD 120cv	DELPHI klima Bizone
 147	CLIMA	1.9 JTD 120cv	DELPHI klima Monozone
 147	CLIMA	1.9 JTD 16v	DELPHI klima Bizone
 147	CLIMA	1.9 JTD 16v	DELPHI klima Monozone
 147	CLIMA	1.9 JTDm	DELPHI klima Bizone
 147	CLIMA	1.9 JTDm	DELPHI klima Monozone
 147	CLIMA	1.9 JTDm 16v	DELPHI klima Bizone
 147	CLIMA	1.9 JTDm 16v	DELPHI klima Monozone
 147	CLIMA	2.0 TS 16v	DELPHI klima Bizone
 147	CLIMA	2.0 TS 16v	DELPHI klima Monozone
 147	CLIMA	2.0 TS 16v Selespeed	DELPHI klima Bizone
 147	CLIMA	2.0 TS 16v Selespeed	DELPHI klima Monozone

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 147	CLIMA	3.2 V6 GTA (02-..)	DELPHI klima Bizone
 147	CLIMA	3.2 V6 GTA (02-..)	DELPHI klima Monozone
 147	DASHBOARD	1.6 TS 16v 105cv	MANNESMAN/VDO Dashboard
 147	DASHBOARD	1.6 TS 16v 120cv	MANNESMAN/VDO Dashboard
 147	DASHBOARD	1.9 JTD 100cv	MANNESMAN/VDO Dashboard
 147	DASHBOARD	1.9 JTD 116cv	MANNESMAN/VDO Dashboard
 147	DASHBOARD	1.9 JTD 120cv	MANNESMAN/VDO Dashboard
 147	DASHBOARD	1.9 JTD 16v	MANNESMAN/VDO Dashboard
 147	DASHBOARD	1.9 JTDm	MANNESMAN/VDO Dashboard
 147	DASHBOARD	1.9 JTDm 16v	MANNESMAN/VDO Dashboard
 147	DASHBOARD	2.0 TS 16v	MANNESMAN/VDO Dashboard
 147	DASHBOARD	2.0 TS 16v Selespeed	MANNESMAN/VDO Dashboard
 147	DASHBOARD	3.2 V6 GTA (02-..)	MANNESMAN/VDO Dashboard
 147	DRIVER SIDE DOOR	1.6 TS 16v 105cv	TRW 3 Doors
 147	DRIVER SIDE DOOR	1.6 TS 16v 105cv	TRW 5 Doors
 147	DRIVER SIDE DOOR	1.6 TS 16v 120cv	TRW 3 Doors
 147	DRIVER SIDE DOOR	1.6 TS 16v 120cv	TRW 5 Doors
 147	DRIVER SIDE DOOR	1.9 JTD 100cv	TRW 3 Doors
 147	DRIVER SIDE DOOR	1.9 JTD 100cv	TRW 5 Doors
 147	DRIVER SIDE DOOR	1.9 JTD 116cv	TRW 3 Doors
 147	DRIVER SIDE DOOR	1.9 JTD 116cv	TRW 5 Doors
 147	DRIVER SIDE DOOR	1.9 JTD 120cv	TRW 3 Doors
 147	DRIVER SIDE DOOR	1.9 JTD 120cv	TRW 5 Doors
 147	DRIVER SIDE DOOR	1.9 JTD 16v	TRW 3 Doors
 147	DRIVER SIDE DOOR	1.9 JTD 16v	TRW 5 Doors
 147	DRIVER SIDE DOOR	1.9 JTDm	TRW 3 Doors
 147	DRIVER SIDE DOOR	1.9 JTDm	TRW 5 Doors
 147	DRIVER SIDE DOOR	1.9 JTDm 16v	TRW 3 Doors
 147	DRIVER SIDE DOOR	1.9 JTDm 16v	TRW 5 Doors
 147	DRIVER SIDE DOOR	2.0 TS 16v	TRW 3 Doors
 147	DRIVER SIDE DOOR	2.0 TS 16v	TRW 5 Doors
 147	DRIVER SIDE DOOR	2.0 TS 16v Selespeed	TRW 3 Doors
 147	DRIVER SIDE DOOR	2.0 TS 16v Selespeed	TRW 5 Doors
 147	DRIVER SIDE DOOR	3.2 V6 GTA (02-..)	TRW 3 Doors
 147	DRIVER SIDE DOOR	3.2 V6 GTA (02-..)	TRW 5 Doors
 147	ENGINE MANAGEME	1.6 TS 16v 105cv (01-..)	BOSCH Motronic ME7.3.1 EOBD
 147	ENGINE MANAGEME	1.6 TS 16v 120cv (01-..)	BOSCH Motronic ME7.3.1 EOBD
 147	ENGINE MANAGEME	1.9 JTD 100cv	BOSCH EDC 15 Common Rail (JTD '99)
 147	ENGINE MANAGEME	1.9 JTD 116cv	BOSCH EDC 15 Common Rail (JTD '99)
 147	ENGINE MANAGEME	1.9 JTD 120cv	BOSCH EDC 16 Common Rail
 147	ENGINE MANAGEME	1.9 JTD 16v (...03)	BOSCH EDC 16 CF3 Common Rail M-Jet
 147	ENGINE MANAGEME	1.9 JTD 16v (04-..)	BOSCH EDC 16 Common Rail FAP
 147	ENGINE MANAGEME	1.9 JTDm (04-..)	EOBD
 147	ENGINE MANAGEME	1.9 JTDm 16v (04-..)	EOBD
 147	ENGINE MANAGEME	2.0 TS 16v	BOSCH Motronic ME2.1
 147	ENGINE MANAGEME	2.0 TS 16v	BOSCH Motronic ME7.3.1 EOBD
 147	ENGINE MANAGEME	2.0 TS 16v (01-..)	EOBD
 147	ENGINE MANAGEME	2.0 TS 16v Selespeed (01-..)	BOSCH Motronic ME7.3.1 EOBD
 147	ENGINE MANAGEME	3.2 V6 GTA (02-..)	BOSCH Motronic ME7.3.1 EOBD
 147	HATCHBACK DOOR E	1.6 TS 16v 105cv	TRW
 147	HATCHBACK DOOR E	1.6 TS 16v 120cv	TRW
 147	HATCHBACK DOOR E	1.9 JTD 100cv	TRW
 147	HATCHBACK DOOR E	1.9 JTD 116cv	TRW
 147	HATCHBACK DOOR E	1.9 JTD 120cv	TRW
 147	HATCHBACK DOOR E	1.9 JTD 16v	TRW
 147	HATCHBACK DOOR E	1.9 JTDm	TRW
 147	HATCHBACK DOOR E	1.9 JTDm 16v	TRW
 147	HATCHBACK DOOR E	2.0 TS 16v	TRW

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 147	HATCHBACK DOOR E	2.0 TS 16v Selespeed	TRW
 147	HATCHBACK DOOR E	3.2 V6 GTA (02-..)	TRW
 147	KEY ENCODE	1.6 TS 16v 105cv	Marelli CODE Body Computer
 147	KEY ENCODE	1.6 TS 16v 120cv	Marelli CODE Body Computer
 147	KEY ENCODE	1.9 JTD 100cv	Marelli CODE Body Computer
 147	KEY ENCODE	1.9 JTD 116cv	Marelli CODE Body Computer
 147	KEY ENCODE	1.9 JTD 120cv	Marelli CODE Body Computer
 147	KEY ENCODE	1.9 JTD 16v	Marelli CODE Body Computer
 147	KEY ENCODE	1.9 JTDm	Marelli CODE Body Computer
 147	KEY ENCODE	1.9 JTDm 16v	Marelli CODE Body Computer
 147	KEY ENCODE	2.0 TS 16v	Marelli CODE Body Computer
 147	KEY ENCODE	2.0 TS 16v Selespeed	Marelli CODE Body Computer
 147	MAINTENANCE	1.6 TS 16v 105cv	MANNESMAN/VDO Dashboard
 147	MAINTENANCE	1.6 TS 16v 105cv (01-..)	
 147	MAINTENANCE	1.6 TS 16v 105cv (05-..)	BOSCH ABS/VDC 8
 147	MAINTENANCE	1.6 TS 16v 120cv	MANNESMAN/VDO Dashboard
 147	MAINTENANCE	1.6 TS 16v 120cv (01-..)	
 147	MAINTENANCE	1.6 TS 16v 120cv (05-..)	BOSCH ABS/VDC 8
 147	MAINTENANCE	1.9 JTD 100cv	MANNESMAN/VDO Dashboard
 147	MAINTENANCE	1.9 JTD 100cv (01-..)	
 147	MAINTENANCE	1.9 JTD 116cv	MANNESMAN/VDO Dashboard
 147	MAINTENANCE	1.9 JTD 116cv (01-..)	
 147	MAINTENANCE	1.9 JTD 120cv	BOSCH EDC 16 Common Rail
 147	MAINTENANCE	1.9 JTD 120cv	BOSCH EDC 16 Common Rail
 147	MAINTENANCE	1.9 JTD 120cv	MANNESMAN/VDO Dashboard
 147	MAINTENANCE	1.9 JTD 120cv (01-..)	
 147	MAINTENANCE	1.9 JTD 16v	MANNESMAN/VDO Dashboard
 147	MAINTENANCE	1.9 JTD 16v (01-..)	
 147	MAINTENANCE	1.9 JTD 16v (04-..)	BOSCH EDC 16 Common Rail FAP
 147	MAINTENANCE	1.9 JTD 16v (04-..)	BOSCH EDC 16 Common Rail FAP
 147	MAINTENANCE	1.9 JTD 16v (05-..)	BOSCH ABS/VDC 8
 147	MAINTENANCE	1.9 JTDm	
 147	MAINTENANCE	1.9 JTDm	MANNESMAN/VDO Dashboard
 147	MAINTENANCE	1.9 JTDm (05-..)	BOSCH ABS/VDC 8
 147	MAINTENANCE	1.9 JTDm 16v	
 147	MAINTENANCE	1.9 JTDm 16v	MANNESMAN/VDO Dashboard
 147	MAINTENANCE	1.9 JTDm 16v (05-..)	BOSCH ABS/VDC 8
 147	MAINTENANCE	2.0 TS 16v	
 147	MAINTENANCE	2.0 TS 16v	MANNESMAN/VDO Dashboard
 147	MAINTENANCE	2.0 TS 16v (05-..)	BOSCH ABS/VDC 8
 147	MAINTENANCE	2.0 TS 16v Selespeed	MANNESMAN/VDO Dashboard
 147	MAINTENANCE	2.0 TS 16v Selespeed	Marelli Selespeed CFC208F
 147	MAINTENANCE	2.0 TS 16v Selespeed	Marelli Selespeed CFC208F
 147	MAINTENANCE	2.0 TS 16v Selespeed (01-..)	
 147	MAINTENANCE	3.2 V6 GTA (02-..)	
 147	MAINTENANCE	3.2 V6 GTA (02-..)	MANNESMAN/VDO Dashboard
 147	MAINTENANCE	3.2 V6 GTA (05-..)	BOSCH ABS/VDC 8
 147	SERVICE LIGHT RES	1.6 TS 16v 105cv (01-..)	
 147	SERVICE LIGHT RES	1.6 TS 16v 120cv (01-..)	
 147	SERVICE LIGHT RES	1.9 JTD 100cv (01-..)	
 147	SERVICE LIGHT RES	1.9 JTD 116cv (01-..)	
 147	SERVICE LIGHT RES	1.9 JTD 120cv (01-..)	
 147	SERVICE LIGHT RES	1.9 JTD 16v (01-..)	
 147	SERVICE LIGHT RES	1.9 JTDm	
 147	SERVICE LIGHT RES	1.9 JTDm 16v	
 147	SERVICE LIGHT RES	2.0 TS 16v	
 147	SERVICE LIGHT RES	2.0 TS 16v Selespeed (01-..)	
 147	SERVICE LIGHT RES	3.2 V6 GTA (02-..)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 147	VISUAL./TELEMATIC	1.6 TS 16v 105cv	Marelli Connect 3
 147	VISUAL./TELEMATIC	1.6 TS 16v 120cv	Marelli Connect 3
 147	VISUAL./TELEMATIC	1.9 JTD 100cv	Marelli Connect 3
 147	VISUAL./TELEMATIC	1.9 JTD 116cv	Marelli Connect 3
 147	VISUAL./TELEMATIC	1.9 JTD 120cv	Marelli Connect 3
 147	VISUAL./TELEMATIC	1.9 JTD 16v	Marelli Connect 3
 147	VISUAL./TELEMATIC	1.9 JTDm	Marelli Connect 3
 147	VISUAL./TELEMATIC	1.9 JTDm 16v	Marelli Connect 3
 147	VISUAL./TELEMATIC	2.0 TS 16v	Marelli Connect 3
 147	VISUAL./TELEMATIC	2.0 TS 16v Selespeed	Marelli Connect 3
 147	VISUAL./TELEMATIC	3.2 V6 GTA	Marelli Connect 3
 155	ABS	1.6	BOSCH ABS 2E
 155	ABS	1.6	BOSCH ABS 5.3
 155	ABS	1.6 TS 16v	BOSCH ABS 2E
 155	ABS	1.6 TS 16v	BOSCH ABS 5.3
 155	ABS	1.7 TS	BOSCH ABS 2E
 155	ABS	1.7 TS	BOSCH ABS 5.3
 155	ABS	1.7 TS + Immob.	BOSCH ABS 2E
 155	ABS	1.7 TS + Immob.	BOSCH ABS 5.3
 155	ABS	1.8 TS	BOSCH ABS 2E
 155	ABS	1.8 TS	BOSCH ABS 5.3
 155	ABS	1.8 TS + Immob.	BOSCH ABS 2E
 155	ABS	1.8 TS + Immob.	BOSCH ABS 5.3
 155	ABS	1.8 TS 16v	BOSCH ABS 2E
 155	ABS	1.8 TS 16v	BOSCH ABS 5.3
 155	ABS	1.9 TD	BOSCH ABS 2E
 155	ABS	1.9 TD	BOSCH ABS 5.3
 155	ABS	2.0 T 16v Q4	BOSCH ABS 2E
 155	ABS	2.0 T 16v Q4	BOSCH ABS 5.3
 155	ABS	2.0 TS	BOSCH ABS 2E
 155	ABS	2.0 TS	BOSCH ABS 5.3
 155	ABS	2.0 TS 16v	BOSCH ABS 2E
 155	ABS	2.0 TS 16v	BOSCH ABS 5.3
 155	ABS	2.0 TS 16v + Immob.	BOSCH ABS 2E
 155	ABS	2.0 TS 16v + Immob.	BOSCH ABS 5.3
 155	ABS	2.5 TD	BOSCH ABS 2E
 155	ABS	2.5 TD	BOSCH ABS 5.3
 155	ABS	2.5 V6	BOSCH ABS 2E
 155	ABS	2.5 V6	BOSCH ABS 5.3
 155	ABS	2.5 V6 + Immob.	BOSCH ABS 2E
 155	ABS	2.5 V6 + Immob.	BOSCH ABS 5.3
 155	ENGINE MANAGEME	1.6	BOSCH MonoMotronic MA1.7
 155	ENGINE MANAGEME	1.6 TS 16v	BOSCH Motronic M2.10.4
 155	ENGINE MANAGEME	1.7 TS	BOSCH Motronic M1.7
 155	ENGINE MANAGEME	1.7 TS + Immob.	BOSCH Motronic M1.7
 155	ENGINE MANAGEME	1.8 TS	BOSCH Motronic M1.7
 155	ENGINE MANAGEME	1.8 TS + Immob.	BOSCH Motronic M1.7
 155	ENGINE MANAGEME	1.8 TS 16v	BOSCH Motronic M2.10.4
 155	ENGINE MANAGEME	2.0 T 16v Q4	Marelli IAW 4W6
 155	ENGINE MANAGEME	2.0 T 16v Q4	Marelli IAW 4W6
 155	ENGINE MANAGEME	2.0 T 16v Q4	Marelli IAW 4W6
 155	ENGINE MANAGEME	2.0 TS	BOSCH Motronic M1.7
 155	ENGINE MANAGEME	2.0 TS 16v	BOSCH Motronic M2.10.3
 155	ENGINE MANAGEME	2.0 TS 16v + Immob.	BOSCH Motronic M2.10.3
 155	ENGINE MANAGEME	2.5 TD	BOSCH MSA 11
 155	ENGINE MANAGEME	2.5 V6	BOSCH Motronic M1.7
 155	ENGINE MANAGEME	2.5 V6 + Immob.	BOSCH Motronic M1.7
 156	ABS	1.6 TS 16v (02-05)	BOSCH ABS 5.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 156	ABS	1.6 TS 16v (97-02)	BOSCH ABS 5.3
 156	ABS	1.8 TS 16v (97-02)	BOSCH ABS 5.3
 156	ABS	1.9 JTD (97-02)	BOSCH ABS 5.3
 156	ABS	2.0 TS 16v (97-02)	BOSCH ABS 5.3
 156	ABS	2.0 TS 16v Selespeed (97-02)	BOSCH ABS 5.3
 156	ABS	2.4 JTD (97-02)	BOSCH ABS 5.3
 156	ABS	2.5 V6 24v (97-02)	BOSCH ABS 5.3
 156	ABS	2.5 V6 24v Selespeed (97-02)	BOSCH ABS 5.3
 156	ABS + TRACT. CONT	1.6 TS 16v (02-05)	BOSCH ABS/VDC 5.7
 156	ABS + TRACT. CONT	1.8 TS 16v (02-05)	BOSCH ABS/VDC 5.7
 156	ABS + TRACT. CONT	1.9 JTD (02-05)	BOSCH ABS/VDC 5.7
 156	ABS + TRACT. CONT	1.9 JTDm 16v (02-05)	BOSCH ABS/VDC 5.7
 156	ABS + TRACT. CONT	2.0 JTS (02-05)	BOSCH ABS/VDC 5.7
 156	ABS + TRACT. CONT	2.0 JTS Selespeed (02-05)	BOSCH ABS/VDC 5.7
 156	ABS + TRACT. CONT	2.0 TS 16v Selespeed (02-05)	BOSCH ABS/VDC 5.7
 156	ABS + TRACT. CONT	2.4 JTD (02-05)	BOSCH ABS/VDC 5.7
 156	ABS + TRACT. CONT	2.4 JTDm 20v (03-05)	BOSCH ABS/VDC 5.7
 156	ABS + TRACT. CONT	2.5 V6 24v (02-05)	BOSCH ABS/VDC 5.7
 156	ABS + TRACT. CONT	2.5 V6 24v Selespeed (02-05)	BOSCH ABS/VDC 5.7
 156	ABS + TRACT. CONT	3.2 V6 GTA (02-05)	BOSCH ABS/VDC 5.7
 156	ABS + TRACT. CONT	3.2 V6 GTA Selespeed (02-05)	BOSCH ABS/VDC 5.7
 156	AIRBAG	1.6 TS 16v (02-05)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 156	AIRBAG	1.6 TS 16v (97-02)	ALLIED AirBag MY 97 (2F-2P)
 156	AIRBAG	1.6 TS 16v (97-02)	ALLIED AirBag MY 97 (2F-2P-2L-2T-I)
 156	AIRBAG	1.6 TS 16v (97-02)	ALLIED AirBag MY 97 (2F-2P-2L-I)
 156	AIRBAG	1.6 TS 16v (97-02)	ALLIED AirBag MY 97 (2F-2P-2L-I-S)
 156	AIRBAG	1.6 TS 16v (97-02)	ALLIED AirBag MY 97 (2F-2P-I)
 156	AIRBAG	1.6 TS 16v (97-02)	ALLIED AirBag MY 97 (2F-2P-I-S)
 156	AIRBAG	1.6 TS 16v (97-02)	ALLIED AirBag Signal
 156	AIRBAG	1.6 TS 16v (97-02)	ALLIED AirBag Signal 2
 156	AIRBAG	1.8 TS 16v (02-05)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 156	AIRBAG	1.8 TS 16v (97-02)	ALLIED AirBag MY 97 (2F-2P)
 156	AIRBAG	1.8 TS 16v (97-02)	ALLIED AirBag MY 97 (2F-2P-2L-2T-I)
 156	AIRBAG	1.8 TS 16v (97-02)	ALLIED AirBag MY 97 (2F-2P-2L-I)
 156	AIRBAG	1.8 TS 16v (97-02)	ALLIED AirBag MY 97 (2F-2P-2L-I-S)
 156	AIRBAG	1.8 TS 16v (97-02)	ALLIED AirBag MY 97 (2F-2P-I)
 156	AIRBAG	1.8 TS 16v (97-02)	ALLIED AirBag MY 97 (2F-2P-I-S)
 156	AIRBAG	1.8 TS 16v (97-02)	ALLIED AirBag Signal
 156	AIRBAG	1.8 TS 16v (97-02)	ALLIED AirBag Signal 2
 156	AIRBAG	1.9 JTD (02-05)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 156	AIRBAG	1.9 JTD (97-02)	ALLIED AirBag MY 97 (2F-2P)
 156	AIRBAG	1.9 JTD (97-02)	ALLIED AirBag MY 97 (2F-2P-2L-2T-I)
 156	AIRBAG	1.9 JTD (97-02)	ALLIED AirBag MY 97 (2F-2P-2L-I)
 156	AIRBAG	1.9 JTD (97-02)	ALLIED AirBag MY 97 (2F-2P-2L-I-S)
 156	AIRBAG	1.9 JTD (97-02)	ALLIED AirBag MY 97 (2F-2P-I)
 156	AIRBAG	1.9 JTD (97-02)	ALLIED AirBag MY 97 (2F-2P-I-S)
 156	AIRBAG	1.9 JTD (97-02)	ALLIED AirBag Signal
 156	AIRBAG	1.9 JTD (97-02)	ALLIED AirBag Signal 2
 156	AIRBAG	1.9 JTDm 16v (02-05)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 156	AIRBAG	2.0 JTS (02-05)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 156	AIRBAG	2.0 JTS Selespeed (02-05)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 156	AIRBAG	2.0 TS 16v (02-05)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 156	AIRBAG	2.0 TS 16v (97-02)	ALLIED AirBag MY 97 (2F-2P)
 156	AIRBAG	2.0 TS 16v (97-02)	ALLIED AirBag MY 97 (2F-2P-2L-2T-I)
 156	AIRBAG	2.0 TS 16v (97-02)	ALLIED AirBag MY 97 (2F-2P-2L-I)
 156	AIRBAG	2.0 TS 16v (97-02)	ALLIED AirBag MY 97 (2F-2P-2L-I-S)
 156	AIRBAG	2.0 TS 16v (97-02)	ALLIED AirBag MY 97 (2F-2P-I)
 156	AIRBAG	2.0 TS 16v (97-02)	ALLIED AirBag MY 97 (2F-2P-I-S)

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 156	AIRBAG	2.0 TS 16v (97-02)	ALLIED AirBag Signal
 156	AIRBAG	2.0 TS 16v (97-02)	ALLIED AirBag Signal 2
 156	AIRBAG	2.0 TS 16v Selespeed (02-05)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 156	AIRBAG	2.0 TS 16v Selespeed (97-02)	ALLIED AirBag MY 97 (2F-2P)
 156	AIRBAG	2.0 TS 16v Selespeed (97-02)	ALLIED AirBag MY 97 (2F-2P-2L-2T-I)
 156	AIRBAG	2.0 TS 16v Selespeed (97-02)	ALLIED AirBag MY 97 (2F-2P-2L-I)
 156	AIRBAG	2.0 TS 16v Selespeed (97-02)	ALLIED AirBag MY 97 (2F-2P-2L-I-S)
 156	AIRBAG	2.0 TS 16v Selespeed (97-02)	ALLIED AirBag MY 97 (2F-2P-I)
 156	AIRBAG	2.0 TS 16v Selespeed (97-02)	ALLIED AirBag MY 97 (2F-2P-I-S)
 156	AIRBAG	2.0 TS 16v Selespeed (97-02)	ALLIED AirBag Signal
 156	AIRBAG	2.0 TS 16v Selespeed (97-02)	ALLIED AirBag Signal 2
 156	AIRBAG	2.4 JTD (02-05)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 156	AIRBAG	2.4 JTD (97-02)	ALLIED AirBag MY 97 (2F-2P)
 156	AIRBAG	2.4 JTD (97-02)	ALLIED AirBag MY 97 (2F-2P-2L-2T-I)
 156	AIRBAG	2.4 JTD (97-02)	ALLIED AirBag MY 97 (2F-2P-2L-I)
 156	AIRBAG	2.4 JTD (97-02)	ALLIED AirBag MY 97 (2F-2P-2L-I-S)
 156	AIRBAG	2.4 JTD (97-02)	ALLIED AirBag MY 97 (2F-2P-I)
 156	AIRBAG	2.4 JTD (97-02)	ALLIED AirBag MY 97 (2F-2P-I-S)
 156	AIRBAG	2.4 JTD (97-02)	ALLIED AirBag Signal
 156	AIRBAG	2.4 JTD (97-02)	ALLIED AirBag Signal 2
 156	AIRBAG	2.4 JTDm 20v (03-05)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 156	AIRBAG	2.5 V6 24v (02-05)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 156	AIRBAG	2.5 V6 24v (97-02)	ALLIED AirBag MY 97 (2F-2P)
 156	AIRBAG	2.5 V6 24v (97-02)	ALLIED AirBag MY 97 (2F-2P-2L-2T-I)
 156	AIRBAG	2.5 V6 24v (97-02)	ALLIED AirBag MY 97 (2F-2P-2L-I)
 156	AIRBAG	2.5 V6 24v (97-02)	ALLIED AirBag MY 97 (2F-2P-2L-I-S)
 156	AIRBAG	2.5 V6 24v (97-02)	ALLIED AirBag MY 97 (2F-2P-I)
 156	AIRBAG	2.5 V6 24v (97-02)	ALLIED AirBag MY 97 (2F-2P-I-S)
 156	AIRBAG	2.5 V6 24v (97-02)	ALLIED AirBag Signal
 156	AIRBAG	2.5 V6 24v (97-02)	ALLIED AirBag Signal 2
 156	AIRBAG	2.5 V6 24v Selespeed (02-05)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 156	AIRBAG	2.5 V6 24v Selespeed (97-02)	ALLIED AirBag MY 97 (2F-2P)
 156	AIRBAG	2.5 V6 24v Selespeed (97-02)	ALLIED AirBag MY 97 (2F-2P-2L-2T-I)
 156	AIRBAG	2.5 V6 24v Selespeed (97-02)	ALLIED AirBag MY 97 (2F-2P-2L-I)
 156	AIRBAG	2.5 V6 24v Selespeed (97-02)	ALLIED AirBag MY 97 (2F-2P-2L-I-S)
 156	AIRBAG	2.5 V6 24v Selespeed (97-02)	ALLIED AirBag MY 97 (2F-2P-I)
 156	AIRBAG	2.5 V6 24v Selespeed (97-02)	ALLIED AirBag MY 97 (2F-2P-I-S)
 156	AIRBAG	2.5 V6 24v Selespeed (97-02)	ALLIED AirBag Signal
 156	AIRBAG	2.5 V6 24v Selespeed (97-02)	ALLIED AirBag Signal 2
 156	AIRBAG	3.2 V6 GTA (02-05)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 156	AIRBAG	3.2 V6 GTA Selespeed (02-05)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 156	CENTRAL LOCKING	1.6 TS 16v (02-05)	RF Bloccaporte/ricevitore VAS 97/3
 156	CENTRAL LOCKING	1.6 TS 16v (97-02)	RF Bloccaporte/ricevitore VAS 97/3
 156	CENTRAL LOCKING	1.8 TS 16v (02-05)	RF Bloccaporte/ricevitore VAS 97/3
 156	CENTRAL LOCKING	1.8 TS 16v (97-02)	RF Bloccaporte/ricevitore VAS 97/3
 156	CENTRAL LOCKING	1.9 JTD (02-05)	RF Bloccaporte/ricevitore VAS 97/3
 156	CENTRAL LOCKING	1.9 JTD (97-02)	RF Bloccaporte/ricevitore VAS 97/3
 156	CENTRAL LOCKING	1.9 JTDm 16v (02-05)	RF Bloccaporte/ricevitore VAS 97/3
 156	CENTRAL LOCKING	2.0 JTS (02-05)	RF Bloccaporte/ricevitore VAS 97/3
 156	CENTRAL LOCKING	2.0 JTS Selespeed (02-05)	RF Bloccaporte/ricevitore VAS 97/3
 156	CENTRAL LOCKING	2.0 TS 16v (02-05)	RF Bloccaporte/ricevitore VAS 97/3
 156	CENTRAL LOCKING	2.0 TS 16v (97-02)	RF Bloccaporte/ricevitore VAS 97/3
 156	CENTRAL LOCKING	2.0 TS 16v Selespeed (02-05)	RF Bloccaporte/ricevitore VAS 97/3
 156	CENTRAL LOCKING	2.0 TS 16v Selespeed (97-02)	RF Bloccaporte/ricevitore VAS 97/3
 156	CENTRAL LOCKING	2.4 JTD (02-05)	RF Bloccaporte/ricevitore VAS 97/3
 156	CENTRAL LOCKING	2.4 JTD (97-02)	RF Bloccaporte/ricevitore VAS 97/3
 156	CENTRAL LOCKING	2.4 JTDm 20v (03-05)	RF Bloccaporte/ricevitore VAS 97/3
 156	CENTRAL LOCKING	2.5 V6 24v (02-05)	RF Bloccaporte/ricevitore VAS 97/3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 156	CENTRAL LOCKING	2.5 V6 24v (97-02)	RF Bloccaporte/ricevitore VAS 97/3
 156	CENTRAL LOCKING	2.5 V6 24v Selespeed (02-05)	RF Bloccaporte/ricevitore VAS 97/3
 156	CENTRAL LOCKING	2.5 V6 24v Selespeed (97-02)	RF Bloccaporte/ricevitore VAS 97/3
 156	CENTRAL LOCKING	3.2 V6 GTA Selespeed (02-05)	RF Bloccaporte/ricevitore VAS 97/3
 156	CLIMA	1.6 TS 16v (02-05)	DELPHI Klima Bizone
 156	CLIMA	1.8 TS 16v (02-05)	DELPHI Klima Bizone
 156	CLIMA	1.9 JTD (02-05)	DELPHI Klima Bizone
 156	CLIMA	1.9 JTDm 16v (02-05)	DELPHI Klima Bizone
 156	CLIMA	2.0 JTS (02-05)	DELPHI Klima Bizone
 156	CLIMA	2.0 JTS Selespeed (02-05)	DELPHI Klima Bizone
 156	CLIMA	2.0 TS 16v (02-05)	DELPHI Klima Bizone
 156	CLIMA	2.0 TS 16v Selespeed (02-05)	DELPHI Klima Bizone
 156	CLIMA	2.4 JTD (02-05)	DELPHI Klima Bizone
 156	CLIMA	2.4 JTDm 20v (03-05)	DELPHI Klima Bizone
 156	CLIMA	2.5 V6 24v (02-05)	DELPHI Klima Bizone
 156	CLIMA	3.2 V6 GTA (02-05)	DELPHI Klima Bizone
 156	CLIMA	3.2 V6 GTA Selespeed (02-05)	DELPHI Klima Bizone
 156	ENGINE MANAGEME	1.6 TS 16v (01-02)	BOSCH Motronic ME7.3.1 EOBD
 156	ENGINE MANAGEME	1.6 TS 16v (03-05)	BOSCH Motronic ME7.3.1 EOBD
 156	ENGINE MANAGEME	1.6 TS 16v (97-02)	BOSCH Motronic M1.5.5
 156	ENGINE MANAGEME	1.6 TS 16v (97-02)	BOSCH Motronic M2.10.4
 156	ENGINE MANAGEME	1.8 TS 16v (01-02)	BOSCH Motronic ME7.3.1 EOBD
 156	ENGINE MANAGEME	1.8 TS 16v (03-05)	BOSCH Motronic ME7.3.1 EOBD
 156	ENGINE MANAGEME	1.8 TS 16v (97-01)	BOSCH Motronic M1.5.5
 156	ENGINE MANAGEME	1.8 TS 16v (97-98)	BOSCH Motronic M1.5.5
 156	ENGINE MANAGEME	1.9 JTD (01-02)	BOSCH EDC 15 Common Rail (JTD '99)
 156	ENGINE MANAGEME	1.9 JTD (02-05)	BOSCH EDC 15 Common Rail (JTD '99)
 156	ENGINE MANAGEME	1.9 JTD (97-98)	BOSCH EDC 15 Common Rail
 156	ENGINE MANAGEME	1.9 JTD (99-01)	BOSCH EDC 15 Common Rail (JTD '99)
 156	ENGINE MANAGEME	1.9 JTDm 16v (02-05)	BOSCH EDC 16 C39 CF4 EOBD Common
 156	ENGINE MANAGEME	1.9 JTDm 16v (02-05)	BOSCH EDC 16 CF3 Common Rail M-Jet
 156	ENGINE MANAGEME	2.0 JTS (02-05)	EOBD
 156	ENGINE MANAGEME	2.0 JTS Selespeed (02-05)	EOBD
 156	ENGINE MANAGEME	2.0 TS 16v (01-02)	BOSCH Motronic ME7.3.1 EOBD
 156	ENGINE MANAGEME	2.0 TS 16v (03-05)	BOSCH Motronic ME7.3.1 EOBD
 156	ENGINE MANAGEME	2.0 TS 16v (97-01)	BOSCH Motronic M1.5.5
 156	ENGINE MANAGEME	2.0 TS 16v (97-98)	BOSCH Motronic M1.5.5
 156	ENGINE MANAGEME	2.0 TS 16v Selespeed (01-02)	BOSCH Motronic ME7.3.1 EOBD
 156	ENGINE MANAGEME	2.0 TS 16v Selespeed (03-05)	BOSCH Motronic ME7.3.1 EOBD
 156	ENGINE MANAGEME	2.0 TS 16v Selespeed (97-01)	BOSCH Motronic M1.5.5
 156	ENGINE MANAGEME	2.0 TS 16v Selespeed (97-98)	BOSCH Motronic M1.5.5
 156	ENGINE MANAGEME	2.4 JTD (01-02)	BOSCH EDC 15 Common Rail (JTD '99)
 156	ENGINE MANAGEME	2.4 JTD (02-05)	BOSCH EDC 15 Common Rail (JTD '99)
 156	ENGINE MANAGEME	2.4 JTD (97-98)	BOSCH EDC 15 Common Rail
 156	ENGINE MANAGEME	2.4 JTD (99-02)	BOSCH EDC 15 Common Rail (JTD '99)
 156	ENGINE MANAGEME	2.4 JTDm 20v (03-05)	BOSCH EDC 16 CF3 Common Rail M-Jet
 156	ENGINE MANAGEME	2.5 V6 24v (01-02)	BOSCH Motronic ME3.1 EOBD
 156	ENGINE MANAGEME	2.5 V6 24v (02-05)	EOBD
 156	ENGINE MANAGEME	2.5 V6 24v (97-02)	BOSCH Motronic ME2.1
 156	ENGINE MANAGEME	2.5 V6 24v Selespeed (01-02)	BOSCH Motronic ME3.1 EOBD
 156	ENGINE MANAGEME	2.5 V6 24v Selespeed (02-05)	BOSCH Motronic ME3.1 EOBD
 156	ENGINE MANAGEME	2.5 V6 24v Selespeed (97-02)	BOSCH Motronic ME2.1
 156	ENGINE MANAGEME	3.2 V6 GTA (03-05)	BOSCH Motronic ME7.3.1 EOBD
 156	ENGINE MANAGEME	3.2 V6 GTA Selespeed (02-05)	BOSCH Motronic ME7.3.1 EOBD
 156	IMMOBILIZER	1.6 TS 16v (02-05)	BOSCH CODE 2
 156	IMMOBILIZER	1.6 TS 16v (97-02)	BOSCH CODE 2
 156	IMMOBILIZER	1.8 TS 16v (02-05)	BOSCH CODE 2
 156	IMMOBILIZER	1.8 TS 16v (97-02)	BOSCH CODE 2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 156	IMMOBILIZER	1.9 JTD (02-05)	BOSCH CODE 2
 156	IMMOBILIZER	1.9 JTD (97-02)	BOSCH CODE 2
 156	IMMOBILIZER	1.9 JTDm 16v (02-05)	BOSCH CODE 2
 156	IMMOBILIZER	2.0 JTS (02-05)	BOSCH CODE 2
 156	IMMOBILIZER	2.0 JTS Selespeed (02-05)	BOSCH CODE 2
 156	IMMOBILIZER	2.0 TS 16v (02-05)	BOSCH CODE 2
 156	IMMOBILIZER	2.0 TS 16v (97-02)	BOSCH CODE 2
 156	IMMOBILIZER	2.0 TS 16v Selespeed (02-05)	BOSCH CODE 2
 156	IMMOBILIZER	2.0 TS 16v Selespeed (97-02)	BOSCH CODE 2
 156	IMMOBILIZER	2.4 JTD (02-05)	BOSCH CODE 2
 156	IMMOBILIZER	2.4 JTD (97-02)	BOSCH CODE 2
 156	IMMOBILIZER	2.4 JTDm 20v (03-05)	BOSCH CODE 2
 156	IMMOBILIZER	2.5 V6 24v (02-05)	BOSCH CODE 2
 156	IMMOBILIZER	2.5 V6 24v (97-02)	BOSCH CODE 2
 156	IMMOBILIZER	2.5 V6 24v Selespeed (02-05)	BOSCH CODE 2
 156	IMMOBILIZER	2.5 V6 24v Selespeed (97-02)	BOSCH CODE 2
 156	IMMOBILIZER	3.2 V6 GTA (02-05)	BOSCH CODE 2
 156	IMMOBILIZER	3.2 V6 GTA Selespeed (02-05)	BOSCH CODE 2
 156	MAINTENANCE	1.6 TS 16v (02-05)	MANUAL
 156	MAINTENANCE	1.6 TS 16v (97-02)	MANUAL
 156	MAINTENANCE	1.8 TS 16v (02-05)	MANUAL
 156	MAINTENANCE	1.8 TS 16v (97-02)	MANUAL
 156	MAINTENANCE	1.9 JTD (02-05)	MANUAL
 156	MAINTENANCE	1.9 JTD (97-02)	MANUAL
 156	MAINTENANCE	1.9 JTDm 16v (02-05)	BOSCH EDC 16 C39 CF4 EOBD Common
 156	MAINTENANCE	1.9 JTDm 16v (02-05)	BOSCH EDC 16 C39 CF4 EOBD Common
 156	MAINTENANCE	1.9 JTDm 16v (02-05)	MANUAL
 156	MAINTENANCE	2.0 JTS (02-05)	MANUAL
 156	MAINTENANCE	2.0 JTS Selespeed (02-05)	MANUAL
 156	MAINTENANCE	2.0 TS 16v (02-05)	MANUAL
 156	MAINTENANCE	2.0 TS 16v (97-02)	MANUAL
 156	MAINTENANCE	2.0 TS 16v Selespeed (02-05)	MANUAL
 156	MAINTENANCE	2.0 TS 16v Selespeed (97-02)	MANUAL
 156	MAINTENANCE	2.4 JTD (02-05)	MANUAL
 156	MAINTENANCE	2.4 JTD (97-02)	MANUAL
 156	MAINTENANCE	2.4 JTDm 20v (03-05)	MANUAL
 156	MAINTENANCE	2.5 V6 24v (02-05)	MANUAL
 156	MAINTENANCE	2.5 V6 24v (97-02)	MANUAL
 156	MAINTENANCE	2.5 V6 24v Selespeed (02-05)	MANUAL
 156	MAINTENANCE	2.5 V6 24v Selespeed (97-02)	MANUAL
 156	MAINTENANCE	3.2 V6 GTA (02-05)	MANUAL
 156	MAINTENANCE	3.2 V6 GTA Selespeed (02-05)	MANUAL
 156	SERVICE LIGHT RES	1.6 TS 16v (02-05)	MANUAL
 156	SERVICE LIGHT RES	1.6 TS 16v (97-02)	MANUAL
 156	SERVICE LIGHT RES	1.8 TS 16v (02-05)	MANUAL
 156	SERVICE LIGHT RES	1.8 TS 16v (97-02)	MANUAL
 156	SERVICE LIGHT RES	1.9 JTD (02-05)	MANUAL
 156	SERVICE LIGHT RES	1.9 JTD (97-02)	MANUAL
 156	SERVICE LIGHT RES	1.9 JTDm 16v (02-05)	MANUAL
 156	SERVICE LIGHT RES	2.0 JTS (02-05)	MANUAL
 156	SERVICE LIGHT RES	2.0 JTS Selespeed (02-05)	MANUAL
 156	SERVICE LIGHT RES	2.0 TS 16v (02-05)	MANUAL
 156	SERVICE LIGHT RES	2.0 TS 16v (97-02)	MANUAL
 156	SERVICE LIGHT RES	2.0 TS 16v Selespeed (02-05)	MANUAL
 156	SERVICE LIGHT RES	2.0 TS 16v Selespeed (97-02)	MANUAL
 156	SERVICE LIGHT RES	2.4 JTD (02-05)	MANUAL
 156	SERVICE LIGHT RES	2.4 JTD (97-02)	MANUAL
 156	SERVICE LIGHT RES	2.4 JTDm 20v (03-05)	MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 156	SERVICE LIGHT RES	2.5 V6 24v (02-05)	MANUAL
 156	SERVICE LIGHT RES	2.5 V6 24v (97-02)	MANUAL
 156	SERVICE LIGHT RES	2.5 V6 24v Selespeed (02-05)	MANUAL
 156	SERVICE LIGHT RES	2.5 V6 24v Selespeed (97-02)	MANUAL
 156	SERVICE LIGHT RES	3.2 V6 GTA (02-05)	MANUAL
 156	SERVICE LIGHT RES	3.2 V6 GTA Selespeed (02-05)	MANUAL
 159	ABS	1.8 16v	Lucas TRW ABS
 159	ABS	1.9 JTDm	Lucas TRW ABS
 159	ABS	1.9 JTDm 16v	Lucas TRW ABS
 159	ABS	1.9 JTS	Lucas TRW ABS
 159	ABS	1750 Tbi	Lucas TRW ABS
 159	ABS	2.0 JTDm 16v	Lucas TRW ABS
 159	ABS	2.2 JTS	Lucas TRW ABS
 159	ABS	2.4 JTDm 20v	Lucas TRW ABS
 159	ABS	3.2 JTS	Lucas TRW ABS
 159	ABS + TRACT. CONT	1.8 16v	Lucas TRW ABS ESP
 159	ABS + TRACT. CONT	1.9 JTDm	Lucas TRW ABS ESP
 159	ABS + TRACT. CONT	1.9 JTDm 16v	Lucas TRW ABS ESP
 159	ABS + TRACT. CONT	1.9 JTS	Lucas TRW ABS ESP
 159	ABS + TRACT. CONT	1750 Tbi	Lucas TRW ABS ESP
 159	ABS + TRACT. CONT	2.0 JTDm 16v	Lucas TRW ABS ESP
 159	ABS + TRACT. CONT	2.2 JTS	Lucas TRW ABS ESP
 159	ABS + TRACT. CONT	2.4 JTDm 20v	Lucas TRW ABS ESP
 159	ABS + TRACT. CONT	3.2 JTS	Lucas TRW ABS ESP
 159	AIRBAG	1.8 16v	TRW AirBag MY 03 (2F-2P-2L-2T-2G-I)
 159	AIRBAG	1.9 JTDm	TRW AirBag MY 03 (2F-2P-2L-2T-2G-I)
 159	AIRBAG	1.9 JTDm 16v	TRW AirBag MY 03 (2F-2P-2L-2T-2G-I)
 159	AIRBAG	1.9 JTS	TRW AirBag MY 03 (2F-2P-2L-2T-2G-I)
 159	AIRBAG	1750 Tbi	TRW AirBag MY 03 (2F-2P-2L-2T-2G-I)
 159	AIRBAG	2.0 JTDm 16v	TRW AirBag MY 03 (2F-2P-2L-2T-2G-I)
 159	AIRBAG	2.2 JTS	TRW AirBag MY 03 (2F-2P-2L-2T-2G-I)
 159	AIRBAG	2.4 JTDm 20v	TRW AirBag MY 03 (2F-2P-2L-2T-1G-I)
 159	AIRBAG	3.2 JTS	TRW AirBag MY 03 (2F-2P-2L-2T-2G-I)
 159	AUTOM. TRANSMISSI	1.9 JTDm	Aisin Q-Tronic AF 40-6
 159	AUTOM. TRANSMISSI	1.9 JTDm 16v	Aisin Q-Tronic AF 40-6
 159	AUTOM. TRANSMISSI	2.4 JTDm 20v	Aisin Q-Tronic AF 40-6
 159	AUTOM. TRANSMISSI	3.2 JTS	Aisin Q-Tronic AF 40-6
 159	CHASSIS NETWORK	1.8 16v	Marelli Body Computer 3
 159	CHASSIS NETWORK	1.8 16v	Proxi Alignement
 159	CHASSIS NETWORK	1.9 JTDm	Marelli Body Computer 3
 159	CHASSIS NETWORK	1.9 JTDm	Proxi Alignement
 159	CHASSIS NETWORK	1.9 JTDm 16v	Marelli Body Computer 3
 159	CHASSIS NETWORK	1.9 JTDm 16v	Proxi Alignement
 159	CHASSIS NETWORK	1.9 JTS	Marelli Body Computer 3
 159	CHASSIS NETWORK	1.9 JTS	Proxi Alignement
 159	CHASSIS NETWORK	1750 Tbi	Marelli Body Computer 3
 159	CHASSIS NETWORK	1750 Tbi	Proxi Alignement
 159	CHASSIS NETWORK	2.0 JTDm 16v	Marelli Body Computer 3
 159	CHASSIS NETWORK	2.0 JTDm 16v	Proxi Alignement
 159	CHASSIS NETWORK	2.2 JTS	Marelli Body Computer 3
 159	CHASSIS NETWORK	2.2 JTS	Proxi Alignement
 159	CHASSIS NETWORK	2.4 JTDm 20v	Marelli Body Computer 3
 159	CHASSIS NETWORK	2.4 JTDm 20v	Proxi Alignement
 159	CHASSIS NETWORK	3.2 JTS	Marelli Body Computer 3
 159	CHASSIS NETWORK	3.2 JTS	Proxi Alignement
 159	CLIMA	1.8 16v	DELPHI Clima Bi-trizone
 159	CLIMA	1.8 16v	DELPHI Clima Monozone
 159	CLIMA	1.9 JTDm	DELPHI Clima Bi-trizone

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 159	CLIMA	1.9 JTDm	DELPHI Clima Monozone
 159	CLIMA	1.9 JTDm 16v	DELPHI Clima Bi-trizone
 159	CLIMA	1.9 JTDm 16v	DELPHI Clima Monozone
 159	CLIMA	1.9 JTS	DELPHI Clima Bi-trizone
 159	CLIMA	1.9 JTS	DELPHI Clima Monozone
 159	CLIMA	1750 Tbi	DELPHI Clima Bi-trizone
 159	CLIMA	1750 Tbi	DELPHI Clima Monozone
 159	CLIMA	2.0 JTDm 16v	DELPHI Clima Bi-trizone
 159	CLIMA	2.0 JTDm 16v	DELPHI Clima Monozone
 159	CLIMA	2.2 JTS	DELPHI Clima Bi-trizone
 159	CLIMA	2.2 JTS	DELPHI Clima Monozone
 159	CLIMA	2.4 JTDm 20v	DELPHI Clima Bi-trizone
 159	CLIMA	2.4 JTDm 20v	DELPHI Clima Monozone
 159	CLIMA	3.2 JTS	DELPHI Clima Bi-trizone
 159	CLIMA	3.2 JTS	DELPHI Clima Monozone
 159	DASHBOARD	1.8 16v	SIEMENS Dashboard 2
 159	DASHBOARD	1.9 JTDm	SIEMENS Dashboard 2
 159	DASHBOARD	1.9 JTDm 16v	SIEMENS Dashboard 2
 159	DASHBOARD	1.9 JTS	SIEMENS Dashboard 2
 159	DASHBOARD	1750 Tbi	SIEMENS Dashboard 2
 159	DASHBOARD	2.0 JTDm 16v	SIEMENS Dashboard 2
 159	DASHBOARD	2.2 JTS	SIEMENS Dashboard 2
 159	DASHBOARD	2.4 JTDm 20v	SIEMENS Dashboard 2
 159	DASHBOARD	3.2 JTS	SIEMENS Dashboard 2
 159	DRIVER SEAT CONT	1.8 16v	Lear 2
 159	DRIVER SEAT CONT	1.9 JTDm	Lear 2
 159	DRIVER SEAT CONT	1.9 JTDm 16v	Lear 2
 159	DRIVER SEAT CONT	1.9 JTS	Lear 2
 159	DRIVER SEAT CONT	1750 Tbi	Lear 2
 159	DRIVER SEAT CONT	2.0 JTDm 16v	Lear 2
 159	DRIVER SEAT CONT	2.2 JTS	Lear 2
 159	DRIVER SEAT CONT	2.4 JTDm 20v	Lear 2
 159	DRIVER SEAT CONT	3.2 JTS	Lear 2
 159	DRIVER SIDE DOOR	1.8 16v	G.E. PROCOND 2 DRIVER DOOR
 159	DRIVER SIDE DOOR	1.9 JTDm	G.E. PROCOND 2 DRIVER DOOR
 159	DRIVER SIDE DOOR	1.9 JTDm 16v	G.E. PROCOND 2 DRIVER DOOR
 159	DRIVER SIDE DOOR	1.9 JTS	G.E. PROCOND 2 DRIVER DOOR
 159	DRIVER SIDE DOOR	1750 Tbi	G.E. PROCOND 2 DRIVER DOOR
 159	DRIVER SIDE DOOR	2.0 JTDm 16v	G.E. PROCOND 2 DRIVER DOOR
 159	DRIVER SIDE DOOR	2.2 JTS	G.E. PROCOND 2 DRIVER DOOR
 159	DRIVER SIDE DOOR	2.4 JTDm 20v	G.E. PROCOND 2 DRIVER DOOR
 159	DRIVER SIDE DOOR	3.2 JTS	G.E. PROCOND 2 DRIVER DOOR
 159	ENGINE MANAGEME	1.8 16v	BOSCH Motronic MED 7.6.1 CF4-EOBD
 159	ENGINE MANAGEME	1.9 JTDm	BOSCH EDC 16 Common Rail
 159	ENGINE MANAGEME	1.9 JTDm 16v	BOSCH EDC 16 Common Rail
 159	ENGINE MANAGEME	1.9 JTS	BOSCH Motronic MED 7.6.1 CF4-EOBD
 159	ENGINE MANAGEME	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 159	ENGINE MANAGEME	2.0 JTDm 16v (07-..)	BOSCH EDC 16C39 CF5/EOBD
 159	ENGINE MANAGEME	2.2 JTS	BOSCH Motronic MED 7.6.1 CF4-EOBD
 159	ENGINE MANAGEME	2.4 JTDm 20v	BOSCH EDC 16 Common Rail
 159	ENGINE MANAGEME	3.2 JTS	BOSCH Motronic MED 7.6.1 CF4-EOBD
 159	FRONT DOORS	1.8 16v	G.E. PROCOND FRONT DOOR
 159	FRONT DOORS	1.9 JTDm	G.E. PROCOND FRONT DOOR
 159	FRONT DOORS	1.9 JTDm 16v	G.E. PROCOND FRONT DOOR
 159	FRONT DOORS	1.9 JTS	G.E. PROCOND FRONT DOOR
 159	FRONT DOORS	1750 Tbi	G.E. PROCOND FRONT DOOR
 159	FRONT DOORS	2.0 JTDm 16v	G.E. PROCOND FRONT DOOR
 159	FRONT DOORS	2.2 JTS	G.E. PROCOND FRONT DOOR

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 159	FRONT DOORS	2.4 JTDm 20v	G.E. PROCOND FRONT DOOR
 159	FRONT DOORS	3.2 JTS	G.E. PROCOND FRONT DOOR
 159	HATCHBACK DOOR E	1.8 16v	G.E.PROCOND TRUNK COMPARTMENT 2
 159	HATCHBACK DOOR E	1.9 JTDm	G.E.PROCOND TRUNK COMPARTMENT 2
 159	HATCHBACK DOOR E	1.9 JTDm 16v	G.E.PROCOND TRUNK COMPARTMENT 2
 159	HATCHBACK DOOR E	1.9 JTS	G.E.PROCOND TRUNK COMPARTMENT 2
 159	HATCHBACK DOOR E	1750 Tbi	G.E.PROCOND TRUNK COMPARTMENT 2
 159	HATCHBACK DOOR E	2.0 JTDm 16v	G.E.PROCOND TRUNK COMPARTMENT 2
 159	HATCHBACK DOOR E	2.2 JTS	G.E.PROCOND TRUNK COMPARTMENT 2
 159	HATCHBACK DOOR E	2.4 JTDm 20v	G.E.PROCOND TRUNK COMPARTMENT 2
 159	HATCHBACK DOOR E	3.2 JTS	G.E.PROCOND TRUNK COMPARTMENT 2
 159	KEY ENCODE	1.8 16v	TRW Teg Reader
 159	KEY ENCODE	1.9 JTDm	TRW Teg Reader
 159	KEY ENCODE	1.9 JTDm 16v	TRW Teg Reader
 159	KEY ENCODE	1.9 JTS	TRW Teg Reader
 159	KEY ENCODE	1750 Tbi	TRW Teg Reader
 159	KEY ENCODE	2.0 JTDm 16v	TRW Teg Reader
 159	KEY ENCODE	2.2 JTS	TRW Teg Reader
 159	KEY ENCODE	2.4 JTDm 20v	TRW Teg Reader
 159	KEY ENCODE	3.2 JTS	TRW Teg Reader
 159	LH RIGHT MODULATI	1.8 16v	Litronic
 159	LH RIGHT MODULATI	1.9 JTDm	Litronic
 159	LH RIGHT MODULATI	1.9 JTDm 16v	Litronic
 159	LH RIGHT MODULATI	1.9 JTS	Litronic
 159	LH RIGHT MODULATI	1750 Tbi	Litronic
 159	LH RIGHT MODULATI	2.0 JTDm 16v	Litronic
 159	LH RIGHT MODULATI	2.2 JTS	Litronic
 159	LH RIGHT MODULATI	2.4 JTDm 20v	Litronic
 159	LH RIGHT MODULATI	3.2 JTS	Litronic
 159	MAINTENANCE	1.8 16v	Litronic
 159	MAINTENANCE	1.8 16v	Litronic
 159	MAINTENANCE	1.8 16v	Lucas TRW ABS ESP
 159	MAINTENANCE	1.8 16v	SIEMENS 2
 159	MAINTENANCE	1.8 16v	SIEMENS Dashboard 2
 159	MAINTENANCE	1.9 JTDm	BOSCH EDC 16 Common Rail
 159	MAINTENANCE	1.9 JTDm	BOSCH EDC 16 Common Rail
 159	MAINTENANCE	1.9 JTDm	Litronic
 159	MAINTENANCE	1.9 JTDm	Litronic
 159	MAINTENANCE	1.9 JTDm	Lucas TRW ABS ESP
 159	MAINTENANCE	1.9 JTDm	SIEMENS 2
 159	MAINTENANCE	1.9 JTDm	SIEMENS Dashboard 2
 159	MAINTENANCE	1.9 JTDm 16v	BOSCH EDC 16 Common Rail
 159	MAINTENANCE	1.9 JTDm 16v	BOSCH EDC 16 Common Rail
 159	MAINTENANCE	1.9 JTDm 16v	Litronic
 159	MAINTENANCE	1.9 JTDm 16v	Litronic
 159	MAINTENANCE	1.9 JTDm 16v	Lucas TRW ABS ESP
 159	MAINTENANCE	1.9 JTDm 16v	SIEMENS 2
 159	MAINTENANCE	1.9 JTDm 16v	SIEMENS Dashboard 2
 159	MAINTENANCE	1.9 JTS	Litronic
 159	MAINTENANCE	1.9 JTS	Litronic
 159	MAINTENANCE	1.9 JTS	Lucas TRW ABS ESP
 159	MAINTENANCE	1.9 JTS	SIEMENS 2
 159	MAINTENANCE	1.9 JTS	SIEMENS Dashboard 2
 159	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 159	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 159	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 159	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 159	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 159	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 159	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 159	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 159	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 159	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 159	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 159	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 159	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 159	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 159	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 159	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 159	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 159	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 159	MAINTENANCE	1750 Tbi	Litronic
 159	MAINTENANCE	1750 Tbi	Litronic
 159	MAINTENANCE	1750 Tbi	Lucas TRW ABS ESP
 159	MAINTENANCE	1750 Tbi	SIEMENS 2
 159	MAINTENANCE	1750 Tbi	SIEMENS Dashboard 2
 159	MAINTENANCE	2.0 JTDm 16v	Litronic
 159	MAINTENANCE	2.0 JTDm 16v	Litronic
 159	MAINTENANCE	2.0 JTDm 16v	Lucas TRW ABS ESP
 159	MAINTENANCE	2.0 JTDm 16v	SIEMENS 2
 159	MAINTENANCE	2.0 JTDm 16v	SIEMENS Dashboard 2
 159	MAINTENANCE	2.0 JTDm 16v (07-..)	BOSCH EDC 16C39 CF5/EOBD
 159	MAINTENANCE	2.0 JTDm 16v (07-..)	BOSCH EDC 16C39 CF5/EOBD
 159	MAINTENANCE	2.2 JTS	Litronic
 159	MAINTENANCE	2.2 JTS	Litronic
 159	MAINTENANCE	2.2 JTS	Lucas TRW ABS ESP
 159	MAINTENANCE	2.2 JTS	SIEMENS 2
 159	MAINTENANCE	2.2 JTS	SIEMENS Dashboard 2
 159	MAINTENANCE	2.4 JTDm 20v	BOSCH EDC 16 Common Rail
 159	MAINTENANCE	2.4 JTDm 20v	BOSCH EDC 16 Common Rail
 159	MAINTENANCE	2.4 JTDm 20v	Litronic
 159	MAINTENANCE	2.4 JTDm 20v	Litronic
 159	MAINTENANCE	2.4 JTDm 20v	Lucas TRW ABS ESP
 159	MAINTENANCE	2.4 JTDm 20v	SIEMENS 2
 159	MAINTENANCE	2.4 JTDm 20v	SIEMENS Dashboard 2
 159	MAINTENANCE	3.2 JTS	Litronic
 159	MAINTENANCE	3.2 JTS	Litronic
 159	MAINTENANCE	3.2 JTS	Lucas TRW ABS ESP
 159	MAINTENANCE	3.2 JTS	SIEMENS 2
 159	MAINTENANCE	3.2 JTS	SIEMENS Dashboard 2
 159	PARKING HELP	1.8 16v	Valeo
 159	PARKING HELP	1.9 JTDm	Valeo
 159	PARKING HELP	1.9 JTDm 16v	Valeo
 159	PARKING HELP	1.9 JTS	Valeo
 159	PARKING HELP	1750 Tbi	Valeo
 159	PARKING HELP	2.0 JTDm 16v	Valeo
 159	PARKING HELP	2.2 JTS	Valeo
 159	PARKING HELP	2.4 JTDm 20v	Valeo
 159	PARKING HELP	3.2 JTS	Valeo
 159	PASS. SIDE DOOR	1.8 16v	G.E. PROCOND 2 PASSENGER DOOR
 159	PASS. SIDE DOOR	1.9 JTDm	G.E. PROCOND 2 PASSENGER DOOR
 159	PASS. SIDE DOOR	1.9 JTDm 16v	G.E. PROCOND 2 PASSENGER DOOR
 159	PASS. SIDE DOOR	1.9 JTS	G.E. PROCOND 2 PASSENGER DOOR
 159	PASS. SIDE DOOR	1750 Tbi	G.E. PROCOND 2 PASSENGER DOOR
 159	PASS. SIDE DOOR	2.0 JTDm 16v	G.E. PROCOND 2 PASSENGER DOOR
 159	PASS. SIDE DOOR	2.2 JTS	G.E. PROCOND 2 PASSENGER DOOR

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 159	PASS. SIDE DOOR	2.4 JTDm 20v	G.E. PROCOND 2 PASSENGER DOOR
 159	PASS. SIDE DOOR	3.2 JTS	G.E. PROCOND 2 PASSENGER DOOR
 159	PASSENGER SEAT R	1.8 16v	Lear 2
 159	PASSENGER SEAT R	1.9 JTDm	Lear 2
 159	PASSENGER SEAT R	1.9 JTDm 16v	Lear 2
 159	PASSENGER SEAT R	1.9 JTS	Lear 2
 159	PASSENGER SEAT R	1750 Tbi	Lear 2
 159	PASSENGER SEAT R	2.0 JTDm 16v	Lear 2
 159	PASSENGER SEAT R	2.2 JTS	Lear 2
 159	PASSENGER SEAT R	2.4 JTDm 20v	Lear 2
 159	PASSENGER SEAT R	3.2 JTS	Lear 2
 159	RH LIGHT MODULATI	1.8 16v	Litronic
 159	RH LIGHT MODULATI	1.9 JTDm	Litronic
 159	RH LIGHT MODULATI	1.9 JTDm 16v	Litronic
 159	RH LIGHT MODULATI	1.9 JTS	Litronic
 159	RH LIGHT MODULATI	1750 Tbi	Litronic
 159	RH LIGHT MODULATI	2.0 JTDm 16v	Litronic
 159	RH LIGHT MODULATI	2.2 JTS	Litronic
 159	RH LIGHT MODULATI	2.4 JTDm 20v	Litronic
 159	RH LIGHT MODULATI	3.2 JTS	Litronic
 159	SERVICE LIGHT RES	1.8 16v	SIEMENS 2
 159	SERVICE LIGHT RES	1.9 JTDm	SIEMENS 2
 159	SERVICE LIGHT RES	1.9 JTDm 16v	SIEMENS 2
 159	SERVICE LIGHT RES	1.9 JTS	SIEMENS 2
 159	SERVICE LIGHT RES	1750 Tbi	SIEMENS 2
 159	SERVICE LIGHT RES	2.0 JTDm 16v	SIEMENS 2
 159	SERVICE LIGHT RES	2.2 JTS	SIEMENS 2
 159	SERVICE LIGHT RES	2.4 JTDm 20v	SIEMENS 2
 159	SERVICE LIGHT RES	3.2 JTS	SIEMENS 2
 159	TIRE PRESSURE	1.8 16v	TRW 2
 159	TIRE PRESSURE	1.9 JTDm	TRW 2
 159	TIRE PRESSURE	1.9 JTDm 16v	TRW 2
 159	TIRE PRESSURE	1.9 JTS	TRW 2
 159	TIRE PRESSURE	1750 Tbi	TRW 2
 159	TIRE PRESSURE	2.0 JTDm 16v	TRW 2
 159	TIRE PRESSURE	2.2 JTS	TRW 2
 159	TIRE PRESSURE	2.4 JTDm 20v	TRW 2
 159	TIRE PRESSURE	3.2 JTS	TRW 2
 159	VISUAL./TELEMATIC	1.8 16v	Marelli Connect 3
 159	VISUAL./TELEMATIC	1.9 JTDm	Marelli Connect 3
 159	VISUAL./TELEMATIC	1.9 JTDm 16v	Marelli Connect 3
 159	VISUAL./TELEMATIC	1.9 JTS	Marelli Connect 3
 159	VISUAL./TELEMATIC	1750 Tbi	Marelli Connect 3
 159	VISUAL./TELEMATIC	2.0 JTDm 16v	Marelli Connect 3
 159	VISUAL./TELEMATIC	2.2 JTS	Marelli Connect 3
 159	VISUAL./TELEMATIC	2.4 JTDm 20v	Marelli Connect 3
 159	VISUAL./TELEMATIC	3.2 JTS	Marelli Connect 3
 164	ABS	2.0 T	BOSCH ABS 2Si
 164	ABS	2.0 T	BOSCH ABS 5.3
 164	ABS	2.0 T + Immob.	BOSCH ABS 2Si
 164	ABS	2.0 T + Immob.	BOSCH ABS 5.3
 164	ABS	2.0 TS	BOSCH ABS 2Si
 164	ABS	2.0 TS	BOSCH ABS 5.3
 164	ABS	2.0 TS + Immob.	BOSCH ABS 2Si
 164	ABS	2.0 TS + Immob.	BOSCH ABS 5.3
 164	ABS	2.0 V6 T	BOSCH ABS 2Si
 164	ABS	2.0 V6 T	BOSCH ABS 5.3
 164	ABS	2.0 V6 T Kat	BOSCH ABS 2Si

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 164	ABS	2.0 V6 T Kat	BOSCH ABS 5.3
 164	ABS	2.0 V6 T Kat + Immob.	BOSCH ABS 2Si
 164	ABS	2.0 V6 T Kat + Immob.	BOSCH ABS 5.3
 164	ABS	2.5 TD	BOSCH ABS 2Si
 164	ABS	2.5 TD	BOSCH ABS 5.3
 164	ABS	2.5 V6	BOSCH ABS 2Si
 164	ABS	2.5 V6	BOSCH ABS 5.3
 164	ABS	3.0 V6 24v Q4	BOSCH ABS 2Si
 164	ABS	3.0 V6 24v Q4	BOSCH ABS 5.3
 164	ABS	3.0 V6 12v	BOSCH ABS 2Si
 164	ABS	3.0 V6 12v	BOSCH ABS 5.3
 164	ABS	3.0 V6 12v (BRA) + Immob.	BOSCH ABS 2Si
 164	ABS	3.0 V6 12v (BRA) + Immob.	BOSCH ABS 5.3
 164	ABS	3.0 V6 12v + Immob.	BOSCH ABS 2Si
 164	ABS	3.0 V6 12v + Immob.	BOSCH ABS 5.3
 164	ABS	3.0 V6 24v	BOSCH ABS 2Si
 164	ABS	3.0 V6 24v	BOSCH ABS 5.3
 164	ABS	3.0 V6 24v (BRA) + Immob.	BOSCH ABS 2Si
 164	ABS	3.0 V6 24v (BRA) + Immob.	BOSCH ABS 5.3
 164	ABS	3.0 V6 24v EGR + Immob.	BOSCH ABS 2Si
 164	ABS	3.0 V6 24v EGR + Immob.	BOSCH ABS 5.3
 164	ABS	3.0 V6 Q4 + Immob.	BOSCH ABS 2Si
 164	ABS	3.0 V6 Q4 + Immob.	BOSCH ABS 5.3
 164	AIRBAG	2.0 T	SIEMENS AirBag 1 Airbag
 164	AIRBAG	2.0 T + Immob.	SIEMENS AirBag 1 Airbag
 164	AIRBAG	2.0 TS	SIEMENS AirBag 1 Airbag
 164	AIRBAG	2.0 TS + Immob.	SIEMENS AirBag 1 Airbag
 164	AIRBAG	2.0 V6 T	SIEMENS AirBag 1 Airbag
 164	AIRBAG	2.0 V6 T Kat	SIEMENS AirBag 1 Airbag
 164	AIRBAG	2.0 V6 T Kat + Immob.	SIEMENS AirBag 1 Airbag
 164	AIRBAG	2.5 TD	SIEMENS AirBag 1 Airbag
 164	AIRBAG	2.5 V6	SIEMENS AirBag 1 Airbag
 164	AIRBAG	3.0 V6 24v Q4	SIEMENS AirBag 1 Airbag
 164	AIRBAG	3.0 V6 12v	SIEMENS AirBag 1 Airbag
 164	AIRBAG	3.0 V6 12v (BRA) + Immob.	SIEMENS AirBag 1 Airbag
 164	AIRBAG	3.0 V6 12v + Immob.	SIEMENS AirBag 1 Airbag
 164	AIRBAG	3.0 V6 24v	SIEMENS AirBag 1 Airbag
 164	AIRBAG	3.0 V6 24v (BRA) + Immob.	SIEMENS AirBag 1 Airbag
 164	AIRBAG	3.0 V6 24v EGR + Immob.	SIEMENS AirBag 1 Airbag
 164	AIRBAG	3.0 V6 Q4 + Immob.	SIEMENS AirBag 1 Airbag
 164	ENGINE MANAGEME	2.0 TS	BOSCH Motronic M1.7
 164	ENGINE MANAGEME	2.0 TS	BOSCH Motronic ML4.1
 164	ENGINE MANAGEME	2.0 TS	BOSCH Motronic ML4.1
 164	ENGINE MANAGEME	2.0 TS + Immob.	BOSCH Motronic M1.7
 164	ENGINE MANAGEME	2.0 V6 T	BOSCH Motronic + EZ ML4.1+212K
 164	ENGINE MANAGEME	2.0 V6 T Kat	BOSCH Motronic + EZ ML4.1+212K
 164	ENGINE MANAGEME	2.0 V6 T Kat	BOSCH Motronic ML4.1+212K
 164	ENGINE MANAGEME	2.0 V6 T Kat + Immob.	BOSCH Motronic ML4.1+212K
 164	ENGINE MANAGEME	2.5 TD	BOSCH MSA 11
 164	ENGINE MANAGEME	2.5 V6	BOSCH Motronic M1.7
 164	ENGINE MANAGEME	3.0 V6 24v Q4	BOSCH Motronic M3.7
 164	ENGINE MANAGEME	3.0 V6 24v Q4	BOSCH Motronic M3.7
 164	ENGINE MANAGEME	3.0 V6 12v	BOSCH Motronic M1.7
 164	ENGINE MANAGEME	3.0 V6 12v	BOSCH Motronic M1.7
 164	ENGINE MANAGEME	3.0 V6 12v (BRA) + Immob.	BOSCH Motronic M1.7
 164	ENGINE MANAGEME	3.0 V6 12v + Immob.	BOSCH Motronic M1.7
 164	ENGINE MANAGEME	3.0 V6 24v	BOSCH Motronic M1.7
 164	ENGINE MANAGEME	3.0 V6 24v	BOSCH Motronic M1.7

Systems supported by ECUREADER / ECUDECODER (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 164	ENGINE MANAGEME	3.0 V6 24v (BRA) + Immob.	BOSCH Motronic M1.7
 164	ENGINE MANAGEME	3.0 V6 24v EGR + Immob.	BOSCH Motronic M1.7
 164	ENGINE MANAGEME	3.0 V6 Q4 + Immob.	BOSCH Motronic M3.7
 166	ABS	2.0 TS 16v	BOSCH ABS 5.3
 166	ABS	2.0 V6 TB	BOSCH ABS 5.3
 166	ABS	2.4 JTD	BOSCH ABS 5.3
 166	ABS	2.4 JTD 20v	BOSCH ABS 5.3
 166	ABS	2.5 V6 24v	BOSCH ABS 5.3
 166	ABS	3.0 V6 24v	BOSCH ABS 5.3
 166	ABS	3.2 V6 24v	BOSCH ABS 5.3
 166	ABS	3.2 V6 24v	BOSCH ABS 5.3
 166	ABS + TRACT. CONT	2.0 TS 16v (02-..)	BOSCH ABS/VDC 5.7
 166	ABS + TRACT. CONT	2.0 V6 TB (02-..)	BOSCH ABS/VDC 5.7
 166	ABS + TRACT. CONT	2.4 JTD (02-..)	BOSCH ABS/VDC 5.7
 166	ABS + TRACT. CONT	2.4 JTD 20v (02-..)	BOSCH ABS/VDC 5.7
 166	ABS + TRACT. CONT	2.5 V6 24v (02-..)	BOSCH ABS/VDC 5.7
 166	ABS + TRACT. CONT	3.0 V6 24v (02-..)	BOSCH ABS/VDC 5.7
 166	ABS + TRACT. CONT	3.2 V6 24v (02-..)	BOSCH ABS/VDC 5.7
 166	AIRBAG	2.0 TS 16v	TRW AirBag MY 97 (2F-2P-2L-I)
 166	AIRBAG	2.0 TS 16v	TRW AirBag MY 97 (2F-2P-2L-I-S)
 166	AIRBAG	2.0 TS 16v	TRW AirBag MY 97 (2F-2P-I)
 166	AIRBAG	2.0 TS 16v	TRW AirBag MY 97 (2F-2P-I-S)
 166	AIRBAG	2.0 TS 16v (03-..)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 166	AIRBAG	2.0 TS 16v (03-..)	SIEMENS AirBag MY 99 (2F-2P-2L-I)
 166	AIRBAG	2.0 V6 TB	TRW AirBag MY 97 (2F-2P-2L-I)
 166	AIRBAG	2.0 V6 TB	TRW AirBag MY 97 (2F-2P-2L-I-S)
 166	AIRBAG	2.0 V6 TB	TRW AirBag MY 97 (2F-2P-I)
 166	AIRBAG	2.0 V6 TB	TRW AirBag MY 97 (2F-2P-I-S)
 166	AIRBAG	2.0 V6 TB (03-..)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 166	AIRBAG	2.0 V6 TB (03-..)	SIEMENS AirBag MY 99 (2F-2P-2L-I)
 166	AIRBAG	2.4 JTD	TRW AirBag MY 97 (2F-2P-2L-I)
 166	AIRBAG	2.4 JTD	TRW AirBag MY 97 (2F-2P-2L-I-S)
 166	AIRBAG	2.4 JTD	TRW AirBag MY 97 (2F-2P-I)
 166	AIRBAG	2.4 JTD	TRW AirBag MY 97 (2F-2P-I-S)
 166	AIRBAG	2.4 JTD (03-..)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 166	AIRBAG	2.4 JTD (03-..)	SIEMENS AirBag MY 99 (2F-2P-2L-I)
 166	AIRBAG	2.4 JTD 20v	TRW AirBag MY 97 (2F-2P-2L-I)
 166	AIRBAG	2.4 JTD 20v	TRW AirBag MY 97 (2F-2P-2L-I-S)
 166	AIRBAG	2.4 JTD 20v	TRW AirBag MY 97 (2F-2P-I)
 166	AIRBAG	2.4 JTD 20v	TRW AirBag MY 97 (2F-2P-I-S)
 166	AIRBAG	2.4 JTD 20v (03-..)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 166	AIRBAG	2.4 JTD 20v (03-..)	SIEMENS AirBag MY 99 (2F-2P-2L-I)
 166	AIRBAG	2.5 V6 24v	TRW AirBag MY 97 (2F-2P-2L-I)
 166	AIRBAG	2.5 V6 24v	TRW AirBag MY 97 (2F-2P-2L-I-S)
 166	AIRBAG	2.5 V6 24v	TRW AirBag MY 97 (2F-2P-I)
 166	AIRBAG	2.5 V6 24v	TRW AirBag MY 97 (2F-2P-I-S)
 166	AIRBAG	2.5 V6 24v (03-..)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 166	AIRBAG	2.5 V6 24v (03-..)	SIEMENS AirBag MY 99 (2F-2P-2L-I)
 166	AIRBAG	3.0 V6 24v	TRW AirBag MY 97 (2F-2P-2L-I)
 166	AIRBAG	3.0 V6 24v	TRW AirBag MY 97 (2F-2P-2L-I-S)
 166	AIRBAG	3.0 V6 24v	TRW AirBag MY 97 (2F-2P-I)
 166	AIRBAG	3.0 V6 24v	TRW AirBag MY 97 (2F-2P-I-S)
 166	AIRBAG	3.0 V6 24v (03-..)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 166	AIRBAG	3.0 V6 24v (03-..)	SIEMENS AirBag MY 99 (2F-2P-2L-I)
 166	AIRBAG	3.2 V6 24v	TRW AirBag MY 97 (2F-2P-2L-I)
 166	AIRBAG	3.2 V6 24v	TRW AirBag MY 97 (2F-2P-2L-I)
 166	AIRBAG	3.2 V6 24v	TRW AirBag MY 97 (2F-2P-2L-I-S)
 166	AIRBAG	3.2 V6 24v	TRW AirBag MY 97 (2F-2P-2L-I-S)

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 166	AIRBAG	3.2 V6 24v	TRW AirBag MY 97 (2F-2P-I)
 166	AIRBAG	3.2 V6 24v	TRW AirBag MY 97 (2F-2P-I)
 166	AIRBAG	3.2 V6 24v	TRW AirBag MY 97 (2F-2P-I-S)
 166	AIRBAG	3.2 V6 24v	TRW AirBag MY 97 (2F-2P-I-S)
 166	AIRBAG	3.2 V6 24v (03-..)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 166	AIRBAG	3.2 V6 24v (03-..)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 166	AIRBAG	3.2 V6 24v (03-..)	SIEMENS AirBag MY 99 (2F-2P-2L-I)
 166	AIRBAG	3.2 V6 24v (03-..)	SIEMENS AirBag MY 99 (2F-2P-2L-I)
 166	CENTRAL LOCKING	2.0 TS 16v	RF Bloccaporte/ricevitore VAS 97/3
 166	CENTRAL LOCKING	2.0 V6 TB	RF Bloccaporte/ricevitore VAS 97/3
 166	CENTRAL LOCKING	2.4 JTD	RF Bloccaporte/ricevitore VAS 97/3
 166	CENTRAL LOCKING	2.5 V6 24v	RF Bloccaporte/ricevitore VAS 97/3
 166	CENTRAL LOCKING	3.0 V6 24v	RF Bloccaporte/ricevitore VAS 97/3
 166	CENTRAL LOCKING	3.2 V6 24v	RF Bloccaporte/ricevitore VAS 97/3
 166	CENTRAL LOCKING	3.2 V6 24v	RF Bloccaporte/ricevitore VAS 97/3
 166	ENGINE MANAGEME	2.0 TS 16v	BOSCH Motronic M1.5.5
 166	ENGINE MANAGEME	2.0 TS 16v (01-..)	BOSCH Motronic ME7.3.1 EOBD
 166	ENGINE MANAGEME	2.0 V6 TB	BOSCH Motronic ME2.1
 166	ENGINE MANAGEME	2.4 JTD (...98)	BOSCH EDC 15 Common Rail
 166	ENGINE MANAGEME	2.4 JTD (00-..)	BOSCH EDC 15 Common Rail (JTD '99)
 166	ENGINE MANAGEME	2.4 JTD (98-99)	BOSCH EDC 15 Common Rail (JTD '99)
 166	ENGINE MANAGEME	2.4 JTD 20v (...03)	BOSCH EDC 16 CF3 Common Rail M-Jet
 166	ENGINE MANAGEME	2.4 JTD 20v (03-..)	BOSCH EDC 16 C39 CF4/EOBD Common
 166	ENGINE MANAGEME	3.0 V6 24v	BOSCH Motronic ME2.1
 166	ENGINE MANAGEME	3.0 V6 24v (01-..)	EOBD
 166	ENGINE MANAGEME	3.2 V6 24v	BOSCH Motronic ME2.1
 166	ENGINE MANAGEME	3.2 V6 24v (01-..)	EOBD
 166	HEADLIGHT LEVEL	2.0 TS 16v (03-..)	VALEO
 166	HEADLIGHT LEVEL	2.0 V6 TB (03-..)	VALEO
 166	HEADLIGHT LEVEL	2.4 JTD (03-..)	VALEO
 166	HEADLIGHT LEVEL	2.5 V6 24v (03-..)	VALEO
 166	HEADLIGHT LEVEL	3.0 V6 24v (03-..)	VALEO
 166	HEADLIGHT LEVEL	3.2 V6 24v (03-..)	VALEO
 166	IMMOBILIZER	2.0 TS 16v	BOSCH CODE 2
 166	IMMOBILIZER	2.0 V6 TB	BOSCH CODE 2
 166	IMMOBILIZER	2.4 JTD	BOSCH CODE 2
 166	IMMOBILIZER	2.5 V6 24v	BOSCH CODE 2
 166	IMMOBILIZER	3.0 V6 24v	BOSCH CODE 2
 166	IMMOBILIZER	3.2 V6 24v	BOSCH CODE 2
 166	LH RIGHT MODULATI	2.0 TS 16v (03-..)	VALEO
 166	LH RIGHT MODULATI	2.0 V6 TB (03-..)	VALEO
 166	LH RIGHT MODULATI	2.4 JTD (03-..)	VALEO
 166	LH RIGHT MODULATI	2.5 V6 24v (03-..)	VALEO
 166	LH RIGHT MODULATI	3.0 V6 24v (03-..)	VALEO
 166	LH RIGHT MODULATI	3.2 V6 24v (03-..)	VALEO
 166	MAINTENANCE	2.4 JTD 20v (03-..)	BOSCH EDC 16 C39 CF4/EOBD Common
 166	MAINTENANCE	2.4 JTD 20v (03-..)	BOSCH EDC 16 C39 CF4/EOBD Common
 166	RH LIGHT MODULATI	2.0 TS 16v (03-..)	VALEO
 166	RH LIGHT MODULATI	2.0 V6 TB (03-..)	VALEO
 166	RH LIGHT MODULATI	2.4 JTD (03-..)	VALEO
 166	RH LIGHT MODULATI	2.5 V6 24v (03-..)	VALEO
 166	RH LIGHT MODULATI	3.0 V6 24v (03-..)	VALEO
 166	RH LIGHT MODULATI	3.2 V6 24v (03-..)	VALEO
 33	ENGINE MANAGEME	1.3 / 1.4 Kat	Marelli IAW 8F.68
 33	ENGINE MANAGEME	1.3 / 1.4 Kat	Marelli IAW 8F.68
 33	ENGINE MANAGEME	1.3 / 1.4 Kat	Marelli IAW 8F.68
 33	ENGINE MANAGEME	1.5 i.e. Kat	BOSCH Motronic MP3.1
 33	ENGINE MANAGEME	1.7 8v i.e. Kat	BOSCH Motronic MP3.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 75	ENGINE MANAGEME	1.6 Kat	BOSCH Motronic ML4.1
 75	ENGINE MANAGEME	1.8	Marelli IAW 4T5
 75	ENGINE MANAGEME	1.8 Kat	BOSCH Motronic ML4.1
 75	ENGINE MANAGEME	1.8 Kat	Marelli IAW 4U5
 75	ENGINE MANAGEME	2.0 TS	BOSCH Motronic ML4.1
 Brera	ABS + TRACT. CONT	1750 Tbi	Lucas TRW ABS ESP
 Brera	ABS + TRACT. CONT	2.0 JTDm 16v	Lucas TRW ABS ESP
 Brera	ABS + TRACT. CONT	2.2 JTS	Lucas TRW ABS ESP
 Brera	ABS + TRACT. CONT	2.4 JTDm 20v	Lucas TRW ABS ESP
 Brera	ABS + TRACT. CONT	3.2 JTS	Lucas TRW ABS ESP
 Brera	AIRBAG	1750 Tbi	TRW AirBag MY 03 (2F-2P-2L-2T-1G-I)
 Brera	AIRBAG	1750 Tbi	TRW AirBag MY 03 (2F-2P-2L-2T-2G-I)
 Brera	AIRBAG	2.0 JTDm 16v	TRW AirBag MY 03 (2F-2P-2L-2T-1G-I)
 Brera	AIRBAG	2.0 JTDm 16v	TRW AirBag MY 03 (2F-2P-2L-2T-2G-I)
 Brera	AIRBAG	2.2 JTS	TRW AirBag MY 03 (2F-2P-2L-2T-1G-I)
 Brera	AIRBAG	2.2 JTS	TRW AirBag MY 03 (2F-2P-2L-2T-2G-I)
 Brera	AIRBAG	2.4 JTDm 20v	TRW AirBag MY 03 (2F-2P-2L-2T-1G-I)
 Brera	AIRBAG	2.4 JTDm 20v	TRW AirBag MY 03 (2F-2P-2L-2T-2G-I)
 Brera	AIRBAG	3.2 JTS	TRW AirBag MY 03 (2F-2P-2L-2T-1G-I)
 Brera	AIRBAG	3.2 JTS	TRW AirBag MY 03 (2F-2P-2L-2T-2G-I)
 Brera	AUTOM. TRANSMISSI	3.2 JTS	Aisin Q-Tronic AF 40-6
 Brera	CHASSIS NETWORK	1750 Tbi	Marelli Body Computer 3
 Brera	CHASSIS NETWORK	1750 Tbi	Proxi Alignment
 Brera	CHASSIS NETWORK	2.0 JTDm 16v	Marelli Body Computer 3
 Brera	CHASSIS NETWORK	2.0 JTDm 16v	Proxi Alignment
 Brera	CHASSIS NETWORK	2.2 JTS	Marelli Body Computer 3
 Brera	CHASSIS NETWORK	2.2 JTS	Proxi Alignment
 Brera	CHASSIS NETWORK	2.4 JTDm 20v	Marelli Body Computer 3
 Brera	CHASSIS NETWORK	2.4 JTDm 20v	Proxi Alignment
 Brera	CHASSIS NETWORK	3.2 JTS	Marelli Body Computer 3
 Brera	CHASSIS NETWORK	3.2 JTS	Proxi Alignment
 Brera	CLIMA	1750 Tbi	DELPHI Clima Bi-trizone
 Brera	CLIMA	1750 Tbi	DELPHI Clima Monozone
 Brera	CLIMA	2.0 JTDm 16v	DELPHI Clima Bi-trizone
 Brera	CLIMA	2.0 JTDm 16v	DELPHI Clima Monozone
 Brera	CLIMA	2.2 JTS	DELPHI Clima Bi-trizone
 Brera	CLIMA	2.2 JTS	DELPHI Clima Monozone
 Brera	CLIMA	2.4 JTDm 20v	DELPHI Clima Bi-trizone
 Brera	CLIMA	2.4 JTDm 20v	DELPHI Clima Monozone
 Brera	CLIMA	3.2 JTS	DELPHI Clima Bi-trizone
 Brera	CLIMA	3.2 JTS	DELPHI Clima Monozone
 Brera	DASHBOARD	1750 Tbi	SIEMENS Dashboard 2
 Brera	DASHBOARD	2.0 JTDm 16v	SIEMENS Dashboard 2
 Brera	DASHBOARD	2.2 JTS	SIEMENS Dashboard 2
 Brera	DASHBOARD	2.4 JTDm 20v	SIEMENS Dashboard 2
 Brera	DASHBOARD	3.2 JTS	SIEMENS Dashboard 2
 Brera	DRIVER SEAT CONT	1750 Tbi	Lear 2
 Brera	DRIVER SEAT CONT	2.0 JTDm 16v	Lear 2
 Brera	DRIVER SEAT CONT	2.2 JTS	Lear 2
 Brera	DRIVER SEAT CONT	2.4 JTDm 20v	Lear 2
 Brera	DRIVER SEAT CONT	3.2 JTS	Lear 2
 Brera	ENGINE MANAGEME	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 Brera	ENGINE MANAGEME	2.0 JTDm 16v	BOSCH Motronic MED 7.6.1 CF4-EOBD
 Brera	ENGINE MANAGEME	2.0 JTDm 16v (09-..)	BOSCH EDC 16C39 CF5/EOBD
 Brera	ENGINE MANAGEME	2.2 JTS	BOSCH Motronic MED 7.6.1 CF4-EOBD
 Brera	ENGINE MANAGEME	2.4 JTDm 20v	BOSCH EDC 16 Common Rail
 Brera	ENGINE MANAGEME	3.2 JTS	BOSCH Motronic MED 7.6.1 CF4-EOBD
 Brera	HATCHBACK DOOR E	1750 Tbi	G.E.PROCOND TRUNK COMPARTMENT 2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Brera	HATCHBACK DOOR E	2.0 JTDm 16v	G.E.PROCOND TRUNK COMPARTMENT 2
 Brera	HATCHBACK DOOR E	2.2 JTS	G.E.PROCOND TRUNK COMPARTMENT 2
 Brera	HATCHBACK DOOR E	2.4 JTDm 20v	G.E.PROCOND TRUNK COMPARTMENT 2
 Brera	HATCHBACK DOOR E	3.2 JTS	G.E.PROCOND TRUNK COMPARTMENT 2
 Brera	KEY ENCODE	1750 Tbi	TRW Teg Reader
 Brera	KEY ENCODE	2.0 JTDm 16v	TRW Teg Reader
 Brera	KEY ENCODE	2.2 JTS	TRW Teg Reader
 Brera	KEY ENCODE	2.4 JTDm 20v	TRW Teg Reader
 Brera	KEY ENCODE	3.2 JTS	TRW Teg Reader
 Brera	LH RIGHT MODULATI	1750 Tbi	Litronic
 Brera	LH RIGHT MODULATI	2.0 JTDm 16v	Litronic
 Brera	LH RIGHT MODULATI	2.2 JTS	Litronic
 Brera	LH RIGHT MODULATI	2.4 JTDm 20v	Litronic
 Brera	LH RIGHT MODULATI	3.2 JTS	Litronic
 Brera	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 Brera	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 Brera	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 Brera	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 Brera	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 Brera	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 Brera	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 Brera	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 Brera	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 Brera	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 Brera	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 Brera	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 Brera	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 Brera	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 Brera	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 Brera	MAINTENANCE	1750 Tbi	BOSCH MeD17.3.1 CF5/EOBD
 Brera	MAINTENANCE	1750 Tbi	Litronic
 Brera	MAINTENANCE	1750 Tbi	Litronic
 Brera	MAINTENANCE	1750 Tbi	Lucas TRW ABS ESP
 Brera	MAINTENANCE	1750 Tbi	SIEMENS 2
 Brera	MAINTENANCE	1750 Tbi	SIEMENS Dashboard 2
 Brera	MAINTENANCE	2.0 JTDm 16v	Litronic
 Brera	MAINTENANCE	2.0 JTDm 16v	Litronic
 Brera	MAINTENANCE	2.0 JTDm 16v	Lucas TRW ABS ESP
 Brera	MAINTENANCE	2.0 JTDm 16v	SIEMENS 2
 Brera	MAINTENANCE	2.0 JTDm 16v	SIEMENS Dashboard 2
 Brera	MAINTENANCE	2.0 JTDm 16v (09-..)	BOSCH EDC 16C39 CF5/EOBD
 Brera	MAINTENANCE	2.0 JTDm 16v (09-..)	BOSCH EDC 16C39 CF5/EOBD
 Brera	MAINTENANCE	2.2 JTS	Litronic
 Brera	MAINTENANCE	2.2 JTS	Litronic
 Brera	MAINTENANCE	2.2 JTS	Lucas TRW ABS ESP
 Brera	MAINTENANCE	2.2 JTS	SIEMENS 2
 Brera	MAINTENANCE	2.2 JTS	SIEMENS Dashboard 2
 Brera	MAINTENANCE	2.4 JTDm 20v	BOSCH EDC 16 Common Rail
 Brera	MAINTENANCE	2.4 JTDm 20v	BOSCH EDC 16 Common Rail
 Brera	MAINTENANCE	2.4 JTDm 20v	Litronic
 Brera	MAINTENANCE	2.4 JTDm 20v	Litronic
 Brera	MAINTENANCE	2.4 JTDm 20v	Lucas TRW ABS ESP
 Brera	MAINTENANCE	2.4 JTDm 20v	SIEMENS 2
 Brera	MAINTENANCE	2.4 JTDm 20v	SIEMENS Dashboard 2
Brera	MAINTENANCE	3.2 JTS	Litronic
Brera	MAINTENANCE	3.2 JTS	Litronic

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Brera	MAINTENANCE	3.2 JTS	Lucas TRW ABS ESP
 Brera	MAINTENANCE	3.2 JTS	SIEMENS 2
 Brera	MAINTENANCE	3.2 JTS	SIEMENS Dashboard 2
 Brera	PARKING HELP	1750 Tbi	Valeo
 Brera	PARKING HELP	2.0 JTDm 16v	Valeo
 Brera	PARKING HELP	2.2 JTS	Valeo
 Brera	PARKING HELP	2.4 JTDm 20v	Valeo
 Brera	PARKING HELP	3.2 JTS	Valeo
 Brera	PASSENGER SEAT R	1750 Tbi	Lear 2
 Brera	PASSENGER SEAT R	2.0 JTDm 16v	Lear 2
 Brera	PASSENGER SEAT R	2.2 JTS	Lear 2
 Brera	PASSENGER SEAT R	2.4 JTDm 20v	Lear 2
 Brera	PASSENGER SEAT R	3.2 JTS	Lear 2
 Brera	RH LIGHT MODULATI	1750 Tbi	Litronic
 Brera	RH LIGHT MODULATI	2.0 JTDm 16v	Litronic
 Brera	RH LIGHT MODULATI	2.2 JTS	Litronic
 Brera	RH LIGHT MODULATI	2.4 JTDm 20v	Litronic
 Brera	RH LIGHT MODULATI	3.2 JTS	Litronic
 Brera	SERVICE LIGHT RES	1750 Tbi	SIEMENS 2
 Brera	SERVICE LIGHT RES	2.0 JTDm 16v	SIEMENS 2
 Brera	SERVICE LIGHT RES	2.2 JTS	SIEMENS 2
 Brera	SERVICE LIGHT RES	2.4 JTDm 20v	SIEMENS 2
 Brera	SERVICE LIGHT RES	3.2 JTS	SIEMENS 2
 Brera	TIRE PRESSURE	1750 Tbi	TRW 2
 Brera	TIRE PRESSURE	2.0 JTDm 16v	TRW 2
 Brera	TIRE PRESSURE	2.2 JTS	TRW 2
 Brera	TIRE PRESSURE	2.4 JTDm 20v	TRW 2
 Brera	VISUAL./TELEMATIC	1750 Tbi	Marelli Connect 3
 Brera	VISUAL./TELEMATIC	2.0 JTDm 16v	Marelli Connect 3
 Brera	VISUAL./TELEMATIC	2.2 JTS	Marelli Connect 3
 Brera	VISUAL./TELEMATIC	2.4 JTDm 20v	Marelli Connect 3
 Brera	VISUAL./TELEMATIC	3.2 JTS	Marelli Connect 3
 Giulietta (191)	ABS + TRACT. CONT	1.4 MultiAir Turbo 16v 170cv (10-..)	Continental MK60EC
 Giulietta (191)	ABS + TRACT. CONT	1.4 Turbobenzina 120cv (10-..)	Continental MK60EC
 Giulietta (191)	ABS + TRACT. CONT	1.6 JTDm 105cv (10-..)	Continental MK60EC
 Giulietta (191)	ABS + TRACT. CONT	1750 Tbi (10-..)	Continental MK60EC
 Giulietta (191)	ABS + TRACT. CONT	2.0 JTDm 16v 140cv (10-..)	Continental MK60EC
 Giulietta (191)	ABS + TRACT. CONT	2.0 JTDm 16v 170cv (10-..)	Continental MK60EC
 Giulietta (191)	AIRBAG	1.4 MultiAir Turbo 16v 170cv (10-..)	Bosch
 Giulietta (191)	AIRBAG	1.4 Turbobenzina 120cv (10-..)	Bosch
 Giulietta (191)	AIRBAG	1.6 JTDm 105cv (10-..)	Bosch
 Giulietta (191)	AIRBAG	1750 Tbi (10-..)	Bosch
 Giulietta (191)	AIRBAG	2.0 JTDm 16v 140cv (10-..)	Bosch
 Giulietta (191)	AIRBAG	2.0 JTDm 16v 170cv (10-..)	Bosch
 Giulietta (191)	CHASSIS NETWORK	1.4 MultiAir Turbo 16v 170cv (08-..)	DELPHI Body Computer CAN info
 Giulietta (191)	CHASSIS NETWORK	1.4 MultiAir Turbo 16v 170cv (10-..)	Marelli Body Computer 10
 Giulietta (191)	CHASSIS NETWORK	1.4 Turbobenzina 120cv (10-..)	DELPHI Body Computer CAN info
 Giulietta (191)	CHASSIS NETWORK	1.4 Turbobenzina 120cv (10-..)	Marelli Body Computer 10
 Giulietta (191)	CHASSIS NETWORK	1.6 JTDm 105cv (10-..)	DELPHI Body Computer CAN info
 Giulietta (191)	CHASSIS NETWORK	1.6 JTDm 105cv (10-..)	Marelli Body Computer 10
 Giulietta (191)	CHASSIS NETWORK	1750 Tbi (10-..)	DELPHI Body Computer CAN info
 Giulietta (191)	CHASSIS NETWORK	1750 Tbi (10-..)	Marelli Body Computer 10
 Giulietta (191)	CHASSIS NETWORK	2.0 JTDm 16v 140cv (10-..)	DELPHI Body Computer CAN info
 Giulietta (191)	CHASSIS NETWORK	2.0 JTDm 16v 140cv (10-..)	Marelli Body Computer 10
 Giulietta (191)	CHASSIS NETWORK	2.0 JTDm 16v 170cv (10-..)	DELPHI Body Computer CAN info
 Giulietta (191)	CHASSIS NETWORK	2.0 JTDm 16v 170cv (10-..)	Marelli Body Computer 10
 Giulietta (191)	CLIMA	1.4 MultiAir Turbo 16v 170cv (10-..)	Marelli Bizone
 Giulietta (191)	CLIMA	1.4 MultiAir Turbo 16v 170cv (10-..)	Marelli EP

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Giulietta (191)	CLIMA	1.4 Turbobenzina 120cv (10-..)	Marelli Bizone
 Giulietta (191)	CLIMA	1.4 Turbobenzina 120cv (10-..)	Marelli EP
 Giulietta (191)	CLIMA	1.6 JTDm 105cv (10-..)	Marelli Bizone
 Giulietta (191)	CLIMA	1.6 JTDm 105cv (10-..)	Marelli EP
 Giulietta (191)	CLIMA	1750 Tbi (10-..)	Marelli Bizone
 Giulietta (191)	CLIMA	1750 Tbi (10-..)	Marelli EP
 Giulietta (191)	CLIMA	2.0 JTDm 16v 140cv (10-..)	Marelli Bizone
 Giulietta (191)	CLIMA	2.0 JTDm 16v 140cv (10-..)	Marelli EP
 Giulietta (191)	CLIMA	2.0 JTDm 16v 170cv (10-..)	Marelli Bizone
 Giulietta (191)	CLIMA	2.0 JTDm 16v 170cv (10-..)	Marelli EP
 Giulietta (191)	DASHBOARD	1.4 MultiAir Turbo 16v 170cv (10-..)	Siemens 3
 Giulietta (191)	DASHBOARD	1.4 Turbobenzina 120cv (10-..)	Siemens 3
 Giulietta (191)	DASHBOARD	1.6 JTDm 105cv (10-..)	Siemens 3
 Giulietta (191)	DASHBOARD	1750 Tbi (10-..)	Siemens 3
 Giulietta (191)	DASHBOARD	2.0 JTDm 16v 140cv (10-..)	Siemens 3
 Giulietta (191)	DASHBOARD	2.0 JTDm 16v 170cv (10-..)	Siemens 3
 Giulietta (191)	DRIVER SEAT CONT	1.4 MultiAir Turbo 16v 170cv (10-..)	LEAR DRIVER SEAT
 Giulietta (191)	DRIVER SEAT CONT	1.4 Turbobenzina 120cv (10-..)	LEAR DRIVER SEAT
 Giulietta (191)	DRIVER SEAT CONT	1.6 JTDm 105cv (10-..)	LEAR DRIVER SEAT
 Giulietta (191)	DRIVER SEAT CONT	1750 Tbi (10-..)	LEAR DRIVER SEAT
 Giulietta (191)	DRIVER SEAT CONT	2.0 JTDm 16v 140cv (10-..)	LEAR DRIVER SEAT
 Giulietta (191)	DRIVER SEAT CONT	2.0 JTDm 16v 170cv (10-..)	LEAR DRIVER SEAT
 Giulietta (191)	ELECTRIC STEERING	1.4 MultiAir Turbo 16v 170cv (10-..)	ZF
 Giulietta (191)	ELECTRIC STEERING	1.4 Turbobenzina 120cv (10-..)	ZF
 Giulietta (191)	ELECTRIC STEERING	1.6 JTDm 105cv (10-..)	ZF
 Giulietta (191)	ELECTRIC STEERING	1750 Tbi (10-..)	ZF
 Giulietta (191)	ELECTRIC STEERING	2.0 JTDm 16v 140cv (10-..)	ZF
 Giulietta (191)	ELECTRIC STEERING	2.0 JTDm 16v 170cv (10-..)	ZF
 Giulietta (191)	ENGINE MANAGEME	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Giulietta (191)	ENGINE MANAGEME	1.4 MultiAir Turbo 16v 170cv (10-..)	EOBD
 Giulietta (191)	ENGINE MANAGEME	1.4 Turbobenzina 120cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Giulietta (191)	ENGINE MANAGEME	1.6 JTDm 105cv (10-..)	BOSCH EDC16C39 CF5/EOBD
 Giulietta (191)	ENGINE MANAGEME	1750 Tbi (10-..)	Bosch MeD17.3.1 CF5/EOBD
 Giulietta (191)	ENGINE MANAGEME	2.0 JTDm 16v 140cv (10-..)	BOSCH EDC16C39 CF5/EOBD
 Giulietta (191)	ENGINE MANAGEME	2.0 JTDm 16v 170cv (10-..)	Bosch EDC16C39 CF5/EOBD
 Giulietta (191)	HEADLIGHT LEVEL	1.4 MultiAir Turbo 16v 170cv (10-..)	Automotive Lighting
 Giulietta (191)	HEADLIGHT LEVEL	1.4 Turbobenzina 120cv (10-..)	Automotive Lighting
 Giulietta (191)	HEADLIGHT LEVEL	1.6 JTDm 105cv (10-..)	Automotive Lighting
 Giulietta (191)	HEADLIGHT LEVEL	1750 Tbi (10-..)	Automotive Lighting
 Giulietta (191)	HEADLIGHT LEVEL	2.0 JTDm 16v 140cv (10-..)	Automotive Lighting
 Giulietta (191)	HEADLIGHT LEVEL	2.0 JTDm 16v 170cv (10-..)	Automotive Lighting
 Giulietta (191)	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Giulietta (191)	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Giulietta (191)	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Giulietta (191)	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Giulietta (191)	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Giulietta (191)	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Giulietta (191)	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Giulietta (191)	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Giulietta (191)	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Giulietta (191)	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Giulietta (191)	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Giulietta (191)	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD

CARS Alfa Romeo

Page 30 of 1129

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Giulietta (191)	PARKING HELP	2.0 JTDm 16v 170cv (10-..)	Valeo
 Giulietta (191)	PASS SEAT CONTRO	1.4 MultiAir Turbo 16v 170cv (10-..)	LEAR Passenger seat
 Giulietta (191)	PASS SEAT CONTRO	1.4 Turbobenzina 120cv (10-..)	LEAR Passenger seat
 Giulietta (191)	PASS SEAT CONTRO	1.6 JTDm 105cv (10-..)	LEAR Passenger seat
 Giulietta (191)	PASS SEAT CONTRO	1750 Tbi (10-..)	LEAR Passenger seat
 Giulietta (191)	PASS SEAT CONTRO	2.0 JTDm 16v 140cv (10-..)	LEAR Passenger seat
 Giulietta (191)	PASS SEAT CONTRO	2.0 JTDm 16v 170cv (10-..)	LEAR Passenger seat
 Giulietta (191)	VISUAL./TELEMATIC	1.4 MultiAir Turbo 16v 170cv (10-..)	Marelli-Microsoft Convergence
 Giulietta (191)	VISUAL./TELEMATIC	1.4 Turbobenzina 120cv (10-..)	Marelli-Microsoft Convergence
 Giulietta (191)	VISUAL./TELEMATIC	1.6 JTDm 105cv (10-..)	Marelli-Microsoft Convergence
 Giulietta (191)	VISUAL./TELEMATIC	1750 Tbi (10-..)	Marelli-Microsoft Convergence
 Giulietta (191)	VISUAL./TELEMATIC	2.0 JTDm 16v 140cv (10-..)	Marelli-Microsoft Convergence
 Giulietta (191)	VISUAL./TELEMATIC	2.0 JTDm 16v 170cv (10-..)	Marelli-Microsoft Convergence
 GT	ABS + TRACT. CONT	1.8 TS 16v	BOSCH ABS/VDC 5.7
 GT	ABS + TRACT. CONT	1.8 TS 16v (05-..)	BOSCH ABS/VDC 8
 GT	ABS + TRACT. CONT	1.9 JTD 16v	BOSCH ABS/VDC 5.7
 GT	ABS + TRACT. CONT	1.9 JTD 16v (05-..)	BOSCH ABS/VDC 8
 GT	ABS + TRACT. CONT	1.9 JTDm 16v	BOSCH ABS/VDC 5.7
 GT	ABS + TRACT. CONT	2.0 JTS	BOSCH ABS/VDC 5.7
 GT	ABS + TRACT. CONT	2.0 JTS (05-..)	BOSCH ABS/VDC 8
 GT	ABS + TRACT. CONT	3.2 V6 24v	BOSCH ABS/VDC 5.7
 GT	ABS + TRACT. CONT	3.2 V6 24v (05-..)	BOSCH ABS/VDC 8
 GT	AIRBAG	1.8 TS 16v	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 GT	AIRBAG	1.9 JTD 16v	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 GT	AIRBAG	1.9 JTDm 16v	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 GT	AIRBAG	2.0 JTS	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 GT	AIRBAG	3.2 V6 24v	SIEMENS AirBag MY 99 (2F-2P-2L-2T-I)
 GT	AUTOM. TRANSMISSI	1.8 TS 16v	Marelli Selespeed CFC208F
 GT	AUTOM. TRANSMISSI	1.9 JTD 16v	Marelli Selespeed CFC208F
 GT	AUTOM. TRANSMISSI	1.9 JTDm 16v	Marelli Selespeed CFC208F
 GT	AUTOM. TRANSMISSI	2.0 JTD	Marelli Selespeed CFC208F
 GT	CHASSIS NETWORK	1.8 TS 16v	Alfa Romeo CAN Info
 GT	CHASSIS NETWORK	1.8 TS 16v	DELPHI/Marelli Body Computer
 GT	CHASSIS NETWORK	1.9 JTD 16v	Alfa Romeo CAN Info
 GT	CHASSIS NETWORK	1.9 JTD 16v	DELPHI/Marelli Body Computer
 GT	CHASSIS NETWORK	1.9 JTDm 16v	Alfa Romeo CAN Info
 GT	CHASSIS NETWORK	1.9 JTDm 16v	DELPHI/Marelli Body Computer
 GT	CHASSIS NETWORK	2.0 JTS	Alfa Romeo CAN Info
 GT	CHASSIS NETWORK	2.0 JTS	DELPHI/Marelli Body Computer
 GT	CHASSIS NETWORK	3.2 V6 24v	Alfa Romeo CAN Info
 GT	CHASSIS NETWORK	3.2 V6 24v	DELPHI/Marelli Body Computer
 GT	CLIMA	1.8 TS 16v	DELPHI klima Bizone
 GT	CLIMA	1.8 TS 16v	DELPHI klima Monozone
 GT	CLIMA	1.9 JTD 16v	DELPHI klima Bizone
 GT	CLIMA	1.9 JTD 16v	DELPHI klima Monozone
 GT	CLIMA	1.9 JTDm 16v	DELPHI klima Bizone
 GT	CLIMA	1.9 JTDm 16v	DELPHI klima Monozone
 GT	CLIMA	2.0 JTS	DELPHI klima Bizone
 GT	CLIMA	2.0 JTS	DELPHI klima Monozone
 GT	CLIMA	3.2 V6 24v	DELPHI klima Bizone
 GT	CLIMA	3.2 V6 24v	DELPHI klima Monozone
 GT	DASHBOARD	1.8 TS 16v	MANNESMAN/VDO Dashboard
 GT	DASHBOARD	1.9 JTD 16v	MANNESMAN/VDO Dashboard
 GT	DASHBOARD	1.9 JTDm 16v	MANNESMAN/VDO Dashboard
 GT	DASHBOARD	2.0 JTS	MANNESMAN/VDO Dashboard
 GT	DASHBOARD	3.2 V6 24v	MANNESMAN/VDO Dashboard
 GT	ENGINE MANAGEME	1.8 TS 16v	BOSCH Motronic ME7.3.1 EOBD
 GT	ENGINE MANAGEME	1.9 JTD 16v	BOSCH EDC 16 CF3 Common Rail M-Jet

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 GT	ENGINE MANAGEME	1.9 JTDm 16v	BOSCH EDC 16 Common Rail FAP
 GT	ENGINE MANAGEME	2.0 JTS	EOBD
 GT	ENGINE MANAGEME	3.2 V6 24v	EOBD
 GT	KEY ENCODE	1.8 TS 16v	Marelli CODE Body Computer
 GT	KEY ENCODE	1.9 JTD 16v	Marelli CODE Body Computer
 GT	KEY ENCODE	1.9 JTDm 16v	Marelli CODE Body Computer
 GT	KEY ENCODE	2.0 JTS	Marelli CODE Body Computer
 GT	KEY ENCODE	3.2 V6 24v	Marelli CODE Body Computer
 GT	MAINTENANCE	1.8 TS 16v	MANNESMAN/VDO Dashboard
 GT	MAINTENANCE	1.8 TS 16v	Marelli Selespeed CFC208F
 GT	MAINTENANCE	1.8 TS 16v	Marelli Selespeed CFC208F
 GT	MAINTENANCE	1.8 TS 16v (05-..)	BOSCH ABS/VDC 8
 GT	MAINTENANCE	1.9 JTD 16v	MANNESMAN/VDO Dashboard
 GT	MAINTENANCE	1.9 JTD 16v	Marelli Selespeed CFC208F
 GT	MAINTENANCE	1.9 JTD 16v	Marelli Selespeed CFC208F
 GT	MAINTENANCE	1.9 JTD 16v (05-..)	BOSCH ABS/VDC 8
 GT	MAINTENANCE	1.9 JTDm 16v	BOSCH EDC 16 Common Rail FAP
 GT	MAINTENANCE	1.9 JTDm 16v	BOSCH EDC 16 Common Rail FAP
 GT	MAINTENANCE	1.9 JTDm 16v	MANNESMAN/VDO Dashboard
 GT	MAINTENANCE	1.9 JTDm 16v	Marelli Selespeed CFC208F
 GT	MAINTENANCE	1.9 JTDm 16v	Marelli Selespeed CFC208F
 GT	MAINTENANCE	2.0 JTD	Marelli Selespeed CFC208F
 GT	MAINTENANCE	2.0 JTD	Marelli Selespeed CFC208F
 GT	MAINTENANCE	2.0 JTS	MANNESMAN/VDO Dashboard
 GT	MAINTENANCE	2.0 JTS (05-..)	BOSCH ABS/VDC 8
 GT	MAINTENANCE	3.2 V6 24v	MANNESMAN/VDO Dashboard
 GT	MAINTENANCE	3.2 V6 24v (05-..)	BOSCH ABS/VDC 8
 GT	VISUAL./TELEMATIC	1.8 TS 16v	Marelli Connect 3
 GT	VISUAL./TELEMATIC	1.9 JTD 16v	Marelli Connect 3
 GT	VISUAL./TELEMATIC	1.9 JTDm 16v	Marelli Connect 3
 GT	VISUAL./TELEMATIC	2.0 JTS	Marelli Connect 3
 GTV	ABS	1.8 TS 16v	BOSCH ABS 2Si
 GTV	ABS	1.8 TS 16v	BOSCH ABS 5.3
 GTV	ABS	2.0 JTS	BOSCH ABS 5.3
 GTV	ABS	2.0 TS 16v	BOSCH ABS 2Si
 GTV	ABS	2.0 TS 16v	BOSCH ABS 5.3
 GTV	ABS	2.0 V6 T	BOSCH ABS 2Si
 GTV	ABS	2.0 V6 T	BOSCH ABS 5.3
 GTV	ABS	3.0 V6 24v	BOSCH ABS 2Si
 GTV	ABS	3.0 V6 24v	BOSCH ABS 5.3
 GTV	AIRBAG	1.8 TS 16v	TRW AirBag MY 97 (2F-2P)
 GTV	AIRBAG	1.8 TS 16v	TRW AirBag TRW2
 GTV	AIRBAG	1.8 TS 16v	TRW-Becker AirBag no Pret.
 GTV	AIRBAG	1.8 TS 16v (98-..)	TRW AirBag MY 97 (2F-2P)
 GTV	AIRBAG	1.8 TS 16v (98-..)	TRW AirBag MY 97 (2F-2P-I)
 GTV	AIRBAG	2.0 JTS	TRW AirBag MY 97 (2F-2P)
 GTV	AIRBAG	2.0 JTS (98-..)	TRW AirBag MY 97 (2F-2P)
 GTV	AIRBAG	2.0 JTS (98-..)	TRW AirBag MY 97 (2F-2P-I)
 GTV	AIRBAG	2.0 TS 16v	TRW AirBag MY 97 (2F-2P)
 GTV	AIRBAG	2.0 TS 16v	TRW AirBag TRW2
 GTV	AIRBAG	2.0 TS 16v	TRW-Becker AirBag no Pret.
 GTV	AIRBAG	2.0 TS 16v (98-..)	TRW AirBag MY 97 (2F-2P)
 GTV	AIRBAG	2.0 TS 16v (98-..)	TRW AirBag MY 97 (2F-2P-I)
 GTV	AIRBAG	2.0 V6 T	TRW AirBag MY 97 (2F-2P)
 GTV	AIRBAG	2.0 V6 T	TRW AirBag TRW2
 GTV	AIRBAG	2.0 V6 T	TRW-Becker AirBag no Pret.
 GTV	AIRBAG	2.0 V6 T (98-..)	TRW AirBag MY 97 (2F-2P)
 GTV	AIRBAG	2.0 V6 T (98-..)	TRW AirBag MY 97 (2F-2P-I)

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 GTV	AIRBAG	3.0 V6 24v	TRW AirBag MY 97 (2F-2P)
 GTV	AIRBAG	3.0 V6 24v	TRW AirBag TRW2
 GTV	AIRBAG	3.0 V6 24v	TRW-Becker AirBag no Pret.
 GTV	AIRBAG	3.0 V6 24v (98-..)	TRW AirBag MY 97 (2F-2P)
 GTV	AIRBAG	3.0 V6 24v (98-..)	TRW AirBag MY 97 (2F-2P-I)
 GTV	ENGINE MANAGEME	1.8 TS 16v (98-..)	BOSCH Motronic M1.5.5
 GTV	ENGINE MANAGEME	2.0 JTS	EOBD
 GTV	ENGINE MANAGEME	2.0 TS 16v	BOSCH Motronic M2.10.3
 GTV	ENGINE MANAGEME	2.0 TS 16v	BOSCH Motronic M2.10.4
 GTV	ENGINE MANAGEME	2.0 TS 16v	BOSCH Motronic M2.10.4
 GTV	ENGINE MANAGEME	2.0 TS 16v (98-..)	BOSCH Motronic M1.5.5
 GTV	ENGINE MANAGEME	2.0 TS 16v (98-..)	BOSCH Motronic ME7.3.1 EOBD
 GTV	ENGINE MANAGEME	2.0 V6 T	BOSCH Motronic + EZ ML4.1+212K
 GTV	ENGINE MANAGEME	2.0 V6 T	BOSCH Motronic + EZ ML4.1+212K
 GTV	ENGINE MANAGEME	3.0 V6 24v	BOSCH Motronic M3.7.1
 GTV	ENGINE MANAGEME	3.0 V6 24v (98-..)	BOSCH Motronic ME2.1
 Mito	ABS + TRACT. CONT	1.3 MJET 16v (08-09)	BOSCH ESP EP 2
 Mito	ABS + TRACT. CONT	1.3 MJET-2 16v (09-..)	BOSCH ESP EP 2
 Mito	ABS + TRACT. CONT	1.4 78cv (08-..)	BOSCH ESP EP 2
 Mito	ABS + TRACT. CONT	1.4 MultiAir 16v 105cv (08-..)	BOSCH ESP EP 2
 Mito	ABS + TRACT. CONT	1.4 MultiAir Turbo 16v 135cv (08-..)	BOSCH ESP EP 2
 Mito	ABS + TRACT. CONT	1.4 MultiAir Turbo 16v 170cv (08-..)	BOSCH ESP EP 2
 Mito	ABS + TRACT. CONT	1.4 Turbobenzina 120cv (08-..)	BOSCH ESP EP 2
 Mito	ABS + TRACT. CONT	1.4 Turbobenzina 155cv (08-..)	BOSCH ESP EP 2
 Mito	ABS + TRACT. CONT	1.4 TurboGPL 120cv (08-..)	BOSCH ESP EP 2
 Mito	ABS + TRACT. CONT	1.6 MJET 16v (08-..)	BOSCH ESP EP 2
 Mito	AIRBAG	1.3 MJET 16v (08-09)	SIEMENS SRS EP-Proxy 2
 Mito	AIRBAG	1.3 MJET-2 16v (09-..)	SIEMENS SRS EP-Proxy 2
 Mito	AIRBAG	1.4 78cv (08-..)	SIEMENS SRS EP-Proxy 2
 Mito	AIRBAG	1.4 MultiAir 16v 105cv (08-..)	SIEMENS SRS EP-Proxy 2
 Mito	AIRBAG	1.4 MultiAir Turbo 16v 135cv (08-..)	SIEMENS SRS EP-Proxy 2
 Mito	AIRBAG	1.4 MultiAir Turbo 16v 170cv (08-..)	SIEMENS SRS EP-Proxy 2
 Mito	AIRBAG	1.4 Turbobenzina 120cv (08-..)	SIEMENS SRS EP-Proxy 2
 Mito	AIRBAG	1.4 Turbobenzina 155cv (08-..)	SIEMENS SRS EP-Proxy 2
 Mito	AIRBAG	1.4 TurboGPL 120cv (08-..)	SIEMENS SRS EP-Proxy 2
 Mito	AIRBAG	1.6 MJET 16v (08-..)	SIEMENS SRS EP-Proxy 2
 Mito	CHASSIS NETWORK	1.3 MJET 16v (08-09)	DELPHI Body Computer CAN info
 Mito	CHASSIS NETWORK	1.3 MJET 16v (08-09)	DELPHI Body Computer EP 3
 Mito	CHASSIS NETWORK	1.3 MJET 16v (08-09)	DELPHI Body Computer Proxi Alignement
 Mito	CHASSIS NETWORK	1.3 MJET-2 16v (09-..)	DELPHI Body Computer CAN info
 Mito	CHASSIS NETWORK	1.3 MJET-2 16v (09-..)	DELPHI Body Computer EP 3
 Mito	CHASSIS NETWORK	1.3 MJET-2 16v (09-..)	DELPHI Body Computer Proxi Alignement
 Mito	CHASSIS NETWORK	1.4 78cv (08-..)	DELPHI Body Computer CAN info
 Mito	CHASSIS NETWORK	1.4 78cv (08-..)	DELPHI Body Computer EP 3
 Mito	CHASSIS NETWORK	1.4 78cv (08-..)	DELPHI Body Computer Proxi Alignement
 Mito	CHASSIS NETWORK	1.4 MultiAir 16v 105cv (08-..)	DELPHI Body Computer CAN info
 Mito	CHASSIS NETWORK	1.4 MultiAir 16v 105cv (08-..)	DELPHI Body Computer EP 3
 Mito	CHASSIS NETWORK	1.4 MultiAir 16v 105cv (08-..)	DELPHI Body Computer Proxi Alignement
 Mito	CHASSIS NETWORK	1.4 MultiAir Turbo 16v 135cv (08-..)	DELPHI Body Computer CAN info
 Mito	CHASSIS NETWORK	1.4 MultiAir Turbo 16v 135cv (08-..)	DELPHI Body Computer EP 3
 Mito	CHASSIS NETWORK	1.4 MultiAir Turbo 16v 135cv (08-..)	DELPHI Body Computer Proxi Alignement
 Mito	CHASSIS NETWORK	1.4 MultiAir Turbo 16v 170cv (08-..)	DELPHI Body Computer CAN info
 Mito	CHASSIS NETWORK	1.4 MultiAir Turbo 16v 170cv (08-..)	DELPHI Body Computer EP 3
 Mito	CHASSIS NETWORK	1.4 MultiAir Turbo 16v 170cv (08-..)	DELPHI Body Computer Proxi Alignement
 Mito	CHASSIS NETWORK	1.4 Turbobenzina 120cv (08-..)	DELPHI Body Computer CAN info
 Mito	CHASSIS NETWORK	1.4 Turbobenzina 120cv (08-..)	DELPHI Body Computer EP 3
 Mito	CHASSIS NETWORK	1.4 Turbobenzina 120cv (08-..)	DELPHI Body Computer Proxi Alignement
 Mito	CHASSIS NETWORK	1.4 Turbobenzina 155cv (08-..)	DELPHI Body Computer CAN info

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Mito	CHASSIS NETWORK	1.4 Turbobenzina 155cv (08-..)	DELPHI Body Computer EP 3
 Mito	CHASSIS NETWORK	1.4 Turbobenzina 155cv (08-..)	DELPHI Body Computer Proxi Alignement
 Mito	CHASSIS NETWORK	1.4 TurboGPL 120cv (08-..)	DELPHI Body Computer CAN info
 Mito	CHASSIS NETWORK	1.4 TurboGPL 120cv (08-..)	DELPHI Body Computer EP 3
 Mito	CHASSIS NETWORK	1.4 TurboGPL 120cv (08-..)	DELPHI Body Computer Proxi Alignement
 Mito	CHASSIS NETWORK	1.6 MJET 16v (08-..)	DELPHI Body Computer CAN info
 Mito	CHASSIS NETWORK	1.6 MJET 16v (08-..)	DELPHI Body Computer EP 3
 Mito	CHASSIS NETWORK	1.6 MJET 16v (08-..)	DELPHI Body Computer Proxi Alignement
 Mito	CLIMA	1.3 MJET 16v (08-09)	DENSO EP
 Mito	CLIMA	1.3 MJET-2 16v (09-..)	DENSO EP
 Mito	CLIMA	1.4 78cv (08-..)	DENSO EP
 Mito	CLIMA	1.4 Multiair 16v 105cv (08-..)	DENSO EP
 Mito	CLIMA	1.4 MultiAir Turbo 16v 135cv (08-..)	DENSO EP
 Mito	CLIMA	1.4 MultiAir Turbo 16v 170cv (08-..)	DENSO EP
 Mito	CLIMA	1.4 Turbobenzina 120cv (08-..)	DENSO EP
 Mito	CLIMA	1.4 Turbobenzina 155cv (08-..)	DENSO EP
 Mito	CLIMA	1.4 TurboGPL 120cv (08-..)	DENSO EP
 Mito	CLIMA	1.6 MJET 16v (08-..)	DENSO EP
 Mito	DASHBOARD	1.3 MJET 16v (08-09)	SIEMENS Dashboard 3
 Mito	DASHBOARD	1.3 MJET-2 16v (09-..)	SIEMENS Dashboard 3
 Mito	DASHBOARD	1.4 78cv (08-..)	SIEMENS Dashboard 3
 Mito	DASHBOARD	1.4 Multiair 16v 105cv (08-..)	SIEMENS Dashboard 3
 Mito	DASHBOARD	1.4 MultiAir Turbo 16v 135cv (08-..)	SIEMENS Dashboard 3
 Mito	DASHBOARD	1.4 MultiAir Turbo 16v 170cv (08-..)	SIEMENS Dashboard 3
 Mito	DASHBOARD	1.4 Turbobenzina 120cv (08-..)	SIEMENS Dashboard 3
 Mito	DASHBOARD	1.4 Turbobenzina 155cv (08-..)	SIEMENS Dashboard 3
 Mito	DASHBOARD	1.4 TurboGPL 120cv (08-..)	SIEMENS Dashboard 3
 Mito	DASHBOARD	1.6 MJET 16v (08-..)	SIEMENS Dashboard 3
 Mito	ELECTRIC STEERING	1.3 MJET 16v (08-09)	DELPHI EPS EP 3
 Mito	ELECTRIC STEERING	1.3 MJET-2 16v (09-..)	DELPHI EPS EP 3
 Mito	ELECTRIC STEERING	1.4 78cv (08-..)	DELPHI EPS EP 3
 Mito	ELECTRIC STEERING	1.4 Multiair 16v 105cv (08-..)	DELPHI EPS EP 3
 Mito	ELECTRIC STEERING	1.4 MultiAir Turbo 16v 135cv (08-..)	DELPHI EPS EP 3
 Mito	ELECTRIC STEERING	1.4 MultiAir Turbo 16v 170cv (08-..)	DELPHI EPS EP 3
 Mito	ELECTRIC STEERING	1.4 Turbobenzina 120cv (08-..)	DELPHI EPS EP 3
 Mito	ELECTRIC STEERING	1.4 Turbobenzina 155cv (08-..)	DELPHI EPS EP 3
 Mito	ELECTRIC STEERING	1.4 TurboGPL 120cv (08-..)	DELPHI EPS EP 3
 Mito	ELECTRIC STEERING	1.6 MJET 16v (08-..)	DELPHI EPS EP 3
 Mito	ENGINE MANAGEME	1.3 MJET 16v (08-..)	EOBD
 Mito	ENGINE MANAGEME	1.3 MJET-2 16v (09-..)	Marelli EDC 8DF CF5
 Mito	ENGINE MANAGEME	1.3 MJET-2 16v (09-..)	Marelli EDC 8F3 CF5
 Mito	ENGINE MANAGEME	1.4 78cv (08-..)	BOSCH Motronic ME7.9.10 CF4-EOBD
 Mito	ENGINE MANAGEME	1.4 Multiair 16v 105cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Mito	ENGINE MANAGEME	1.4 MultiAir Turbo 16v 135cv (08-..)	EOBD
 Mito	ENGINE MANAGEME	1.4 MultiAir Turbo 16v 135cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Mito	ENGINE MANAGEME	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Mito	ENGINE MANAGEME	1.4 Turbobenzina 120cv (08-..)	BOSCH Motronic ME7.9.10 CF4-EOBD
 Mito	ENGINE MANAGEME	1.4 Turbobenzina 155cv (08-..)	BOSCH Motronic ME7.9.10 CF4-EOBD
 Mito	ENGINE MANAGEME	1.4 TurboGPL 120cv (08-..)	EOBD
 Mito	ENGINE MANAGEME	1.6 MJET 16v (08-..)	BOSCH EDC16C39 CF5/EOBD
 Mito	MAINTENANCE	1.3 MJET 16v (08-09)	DELPHI EPS EP 3
 Mito	MAINTENANCE	1.3 MJET 16v (08-09)	SIEMENS Dashboard 3
 Mito	MAINTENANCE	1.3 MJET 16v (08-09)	SIEMENS Dashboard 3
 Mito	MAINTENANCE	1.3 MJET-2 16v (09-..)	DELPHI EPS EP 3
 Mito	MAINTENANCE	1.3 MJET-2 16v (09-..)	Marelli EDC 8DF CF5
 Mito	MAINTENANCE	1.3 MJET-2 16v (09-..)	Marelli EDC 8DF CF5
 Mito	MAINTENANCE	1.3 MJET-2 16v (09-..)	Marelli EDC 8F3 CF5
 Mito	MAINTENANCE	1.3 MJET-2 16v (09-..)	Marelli EDC 8F3 CF5

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

[illegible]

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Mito	MAINTENANCE	1.4 MultiAir Turbo 16v 135cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Mito	MAINTENANCE	1.4 MultiAir Turbo 16v 135cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Mito	MAINTENANCE	1.4 MultiAir Turbo 16v 135cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Mito	MAINTENANCE	1.4 MultiAir Turbo 16v 135cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Mito	MAINTENANCE	1.4 MultiAir Turbo 16v 135cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Mito	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (08-..)	DELPHI EPS EP 3
 Mito	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (08-..)	SIEMENS Dashboard 3
 Mito	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (08-..)	SIEMENS Dashboard 3
 Mito	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Mito	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Mito	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Mito	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Mito	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Mito	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Mito	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Mito	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Mito	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Mito	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Mito	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Mito	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Mito	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Mito	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Mito	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Mito	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Mito	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Mito	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Mito	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Mito	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Mito	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Mito	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Mito	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Mito	MAINTENANCE	1.4 MultiAir Turbo 16v 170cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Mito	MAINTENANCE	1.4 Turbobenzina 120cv (08-..)	DELPHI EPS EP 3
 Mito	MAINTENANCE	1.4 Turbobenzina 120cv (08-..)	SIEMENS Dashboard 3
 Mito	MAINTENANCE	1.4 Turbobenzina 120cv (08-..)	SIEMENS Dashboard 3
 Mito	MAINTENANCE	1.4 Turbobenzina 155cv (08-..)	DELPHI EPS EP 3
 Mito	MAINTENANCE	1.4 Turbobenzina 155cv (08-..)	SIEMENS Dashboard 3
 Mito	MAINTENANCE	1.4 Turbobenzina 155cv (08-..)	SIEMENS Dashboard 3
 Mito	MAINTENANCE	1.4 TurboGPL 120cv (08-..)	DELPHI EPS EP 3
 Mito	MAINTENANCE	1.4 TurboGPL 120cv (08-..)	SIEMENS Dashboard 3
 Mito	MAINTENANCE	1.4 TurboGPL 120cv (08-..)	SIEMENS Dashboard 3
 Mito	MAINTENANCE	1.6 MJET 16v (08-..)	BOSCH EDC16C39 CF5/EOBD
 Mito	MAINTENANCE	1.6 MJET 16v (08-..)	DELPHI EPS EP 3
 Mito	MAINTENANCE	1.6 MJET 16v (08-..)	SIEMENS Dashboard 3
 Mito	MAINTENANCE	1.6 MJET 16v (08-..)	SIEMENS Dashboard 3
 Mito	PARKING HELP	1.3 MJET 16v (08-09)	Valeo 2
 Mito	PARKING HELP	1.3 MJET-2 16v (09-..)	Valeo 2
 Mito	PARKING HELP	1.4 78cv (08-..)	Valeo 2
 Mito	PARKING HELP	1.4 MultiAir 16v 105cv (08-..)	Valeo 2
 Mito	PARKING HELP	1.4 MultiAir Turbo 16v 135cv (08-..)	Valeo 2
 Mito	PARKING HELP	1.4 MultiAir Turbo 16v 170cv (08-..)	Valeo 2
 Mito	PARKING HELP	1.4 Turbobenzina 120cv (08-..)	Valeo 2
 Mito	PARKING HELP	1.4 Turbobenzina 155cv (08-..)	Valeo 2
 Mito	PARKING HELP	1.4 TurboGPL 120cv (08-..)	Valeo 2
 Mito	PARKING HELP	1.6 MJET 16v (08-..)	Valeo 2
 Mito	VISUAL./TELEMATIC	1.3 MJET 16v (08-09)	Marelli Convergence

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Mito	VISUAL./TELEMATIC	1.3 MJET-2 16v (09-..)	Marelli Convergence
 Mito	VISUAL./TELEMATIC	1.4 78cv (08-..)	Marelli Convergence
 Mito	VISUAL./TELEMATIC	1.4 MultiAir 16v 105cv (08-..)	Marelli Convergence
 Mito	VISUAL./TELEMATIC	1.4 MultiAir Turbo 16v 135cv (08-..)	Marelli Convergence
 Mito	VISUAL./TELEMATIC	1.4 MultiAir Turbo 16v 170cv (08-..)	Marelli Convergence
 Mito	VISUAL./TELEMATIC	1.4 Turbobenzina 120cv (08-..)	Marelli Convergence
 Mito	VISUAL./TELEMATIC	1.4 Turbobenzina 155cv (08-..)	Marelli Convergence
 Mito	VISUAL./TELEMATIC	1.4 TurboGPL 120cv (08-..)	Marelli Convergence
 Mito	VISUAL./TELEMATIC	1.6 MJET 16v (08-..)	Marelli Convergence
 Spider	ABS	1.8 TS 16v	BOSCH ABS 2Si
 Spider	ABS	1.8 TS 16v	BOSCH ABS 5.3
 Spider	ABS	2.0	BOSCH ABS 2Si
 Spider	ABS	2.0	BOSCH ABS 5.3
 Spider	ABS	2.0 Kat	BOSCH ABS 2Si
 Spider	ABS	2.0 Kat	BOSCH ABS 5.3
 Spider	ABS	2.0 TS 16v	BOSCH ABS 2Si
 Spider	ABS	2.0 TS 16v	BOSCH ABS 5.3
 Spider	ABS	2.2 JTS	BOSCH ABS 5.3
 Spider	ABS	3.0 V6 (98)	BOSCH ABS 2Si
 Spider	ABS	3.0 V6 (98)	BOSCH ABS 5.3
 Spider	ABS	3.0 V6 12v	BOSCH ABS 2Si
 Spider	ABS	3.0 V6 12v	BOSCH ABS 5.3
 Spider	ABS + TRACT. CONT	1750 Tbi (05-..)	Lucas TRW ABS ESP
 Spider	ABS + TRACT. CONT	2.0 JTDm 16v (05-..)	Lucas TRW ABS ESP
 Spider	ABS + TRACT. CONT	2.2 JTS (05-..)	Lucas TRW ABS ESP
 Spider	ABS + TRACT. CONT	2.4 JTDm 20v (05-..)	Lucas TRW ABS ESP
 Spider	ABS + TRACT. CONT	3.2 JTS (05-..)	Lucas TRW ABS ESP
 Spider	AIRBAG	1.8 TS 16v	TRW AirBag MY 97 (2F-2P)
 Spider	AIRBAG	1.8 TS 16v	TRW AirBag TRW2
 Spider	AIRBAG	1.8 TS 16v	TRW-Becker AirBag no Pret.
 Spider	AIRBAG	1.8 TS 16v (98-..)	TRW AirBag MY 97 (2F-2P)
 Spider	AIRBAG	1.8 TS 16v (98-..)	TRW AirBag MY 97 (2F-2P-I)
 Spider	AIRBAG	2.0	TRW AirBag MY 97 (2F-2P)
 Spider	AIRBAG	2.0	TRW AirBag TRW2
 Spider	AIRBAG	2.0	TRW-Becker AirBag no Pret.
 Spider	AIRBAG	2.0 (98-..)	TRW AirBag MY 97 (2F-2P)
 Spider	AIRBAG	2.0 (98-..)	TRW AirBag MY 97 (2F-2P-I)
 Spider	AIRBAG	2.0 JTS (98-..)	TRW AirBag MY 97 (2F-2P)
 Spider	AIRBAG	2.0 JTS (98-..)	TRW AirBag MY 97 (2F-2P-I)
 Spider	AIRBAG	2.0 Kat	TRW AirBag MY 97 (2F-2P)
 Spider	AIRBAG	2.0 Kat	TRW AirBag TRW2
 Spider	AIRBAG	2.0 Kat	TRW-Becker AirBag no Pret.
 Spider	AIRBAG	2.0 Kat (98-..)	TRW AirBag MY 97 (2F-2P)
 Spider	AIRBAG	2.0 Kat (98-..)	TRW AirBag MY 97 (2F-2P-I)
 Spider	AIRBAG	2.0 TS 16v	TRW AirBag MY 97 (2F-2P)
 Spider	AIRBAG	2.0 TS 16v	TRW AirBag TRW2
 Spider	AIRBAG	2.0 TS 16v	TRW-Becker AirBag no Pret.
 Spider	AIRBAG	2.0 TS 16v (98-..)	TRW AirBag MY 97 (2F-2P)
 Spider	AIRBAG	2.0 TS 16v (98-..)	TRW AirBag MY 97 (2F-2P-I)
 Spider	AIRBAG	2.0 V6 T (98-..)	TRW AirBag MY 97 (2F-2P)
 Spider	AIRBAG	2.0 V6 T (98-..)	TRW AirBag MY 97 (2F-2P-I)
 Spider	AIRBAG	3.0 V6 (98)	TRW AirBag MY 97 (2F-2P)
 Spider	AIRBAG	3.0 V6 (98)	TRW AirBag TRW2
 Spider	AIRBAG	3.0 V6 (98)	TRW-Becker AirBag no Pret.
 Spider	AIRBAG	3.0 V6 (98) (98-..)	TRW AirBag MY 97 (2F-2P)
 Spider	AIRBAG	3.0 V6 (98) (98-..)	TRW AirBag MY 97 (2F-2P-I)
 Spider	AIRBAG	3.0 V6 12v	TRW AirBag MY 97 (2F-2P)
 Spider	AIRBAG	3.0 V6 12v	TRW AirBag TRW2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Spider	AIRBAG	3.0 V6 12v	TRW-Becker AirBag no Pret.
 Spider	AIRBAG	3.0 V6 12v (98-..)	TRW AirBag MY 97 (2F-2P)
 Spider	AIRBAG	3.0 V6 12v (98-..)	TRW AirBag MY 97 (2F-2P-I)
 Spider	AIRBAG	3.2 V6 24v (98-..)	TRW AirBag MY 97 (2F-2P)
 Spider	AIRBAG	3.2 V6 24v (98-..)	TRW AirBag MY 97 (2F-2P-I)
 Spider	AUTOM. TRANSMISSI	1750 Tbi (05-..)	Aisin Q-Tronic AF 40-6
 Spider	AUTOM. TRANSMISSI	3.2 JTS (05-..)	Aisin Q-Tronic AF 40-6
 Spider	CHASSIS NETWORK	1750 Tbi (05-..)	Marelli Body Computer 3
 Spider	CHASSIS NETWORK	2.0 JTDm 16v (05-..)	Marelli Body Computer 3
 Spider	CHASSIS NETWORK	2.0 JTDm 16v (05-..)	Proxi Alignment
 Spider	CHASSIS NETWORK	2.2 JTS (05-..)	Marelli Body Computer 3
 Spider	CHASSIS NETWORK	2.2 JTS (05-..)	Proxi Alignment
 Spider	CHASSIS NETWORK	2.4 JTDm 20v (05-..)	Marelli Body Computer 3
 Spider	CHASSIS NETWORK	2.4 JTDm 20v (05-..)	Proxi Alignment
 Spider	CHASSIS NETWORK	3.2 JTS	Proxi Alignment
 Spider	CHASSIS NETWORK	3.2 JTS (05-..)	Marelli Body Computer 3
 Spider	CLIMA	1750 Tbi (05-..)	DELPHI Clima Bi-trizone
 Spider	CLIMA	2.0 JTDm 16v (05-..)	DELPHI Clima Bi-trizone
 Spider	CLIMA	2.2 JTS (05-..)	DELPHI Clima Bi-trizone
 Spider	CLIMA	2.4 JTDm 20v (05-..)	DELPHI Clima Bi-trizone
 Spider	CLIMA	3.2 JTS (05-..)	DELPHI Clima Bi-trizone
 Spider	DRIVER SEAT CONT	1750 Tbi (05-..)	Lear 2
 Spider	DRIVER SEAT CONT	2.0 JTDm 16v (05-..)	Lear 2
 Spider	DRIVER SEAT CONT	2.2 JTS (05-..)	Lear 2
 Spider	DRIVER SEAT CONT	2.4 JTDm 20v (05-..)	Lear 2
 Spider	DRIVER SEAT CONT	3.2 JTS (05-..)	Lear 2
 Spider	ENGINE MANAGEME	1.8 TS 16v (98-..)	BOSCH Motronic M1.5.5
 Spider	ENGINE MANAGEME	1750 Tbi (05-..)	BOSCH MeD17.3.1 CF5/EOBD
 Spider	ENGINE MANAGEME	2.0	BOSCH Motronic ML4.1
 Spider	ENGINE MANAGEME	2.0 JTDm 16v (05-..)	EOBD
 Spider	ENGINE MANAGEME	2.0 JTS (01-..)	EOBD
 Spider	ENGINE MANAGEME	2.0 Kat	BOSCH Motronic ML4.1
 Spider	ENGINE MANAGEME	2.0 TS 16v	BOSCH Motronic M2.10.3
 Spider	ENGINE MANAGEME	2.0 TS 16v (98-..)	BOSCH Motronic M1.5.5
 Spider	ENGINE MANAGEME	2.2 JTS (05-..)	BOSCH Motronic MED 7.6.1 CF4-EOBD
 Spider	ENGINE MANAGEME	2.4 JTDm 20v (05-..)	EOBD
 Spider	ENGINE MANAGEME	3.0 V6 (98) (98-..)	BOSCH Motronic ME2.1
 Spider	ENGINE MANAGEME	3.0 V6 12v	BOSCH Motronic M3.7.1
 Spider	ENGINE MANAGEME	3.2 JTS (05-..)	BOSCH Motronic MED 7.6.1 CF4-EOBD
 Spider	ENGINE MANAGEME	3.2 V6 24v (01-..)	EOBD
 Spider	KEY ENCODE	1750 Tbi (05-..)	TRW Teg Reader
 Spider	KEY ENCODE	2.0 JTDm 16v (05-..)	TRW Teg Reader
 Spider	KEY ENCODE	2.2 JTS (05-..)	TRW Teg Reader
 Spider	KEY ENCODE	2.4 JTDm 20v (05-..)	TRW Teg Reader
 Spider	KEY ENCODE	3.2 JTS (05-..)	TRW Teg Reader
 Spider	LH RIGHT MODULATI	1750 Tbi (05-..)	Litronic
 Spider	LH RIGHT MODULATI	2.0 JTDm 16v (05-..)	Litronic
 Spider	LH RIGHT MODULATI	2.2 JTS (05-..)	Litronic
 Spider	LH RIGHT MODULATI	2.4 JTDm 20v (05-..)	Litronic
 Spider	LH RIGHT MODULATI	3.2 JTS (05-..)	Litronic
 Spider	MAINTENANCE	1750 Tbi (05-..)	BOSCH MeD17.3.1 CF5/EOBD
 Spider	MAINTENANCE	1750 Tbi (05-..)	BOSCH MeD17.3.1 CF5/EOBD
 Spider	MAINTENANCE	1750 Tbi (05-..)	BOSCH MeD17.3.1 CF5/EOBD
 Spider	MAINTENANCE	1750 Tbi (05-..)	BOSCH MeD17.3.1 CF5/EOBD
 Spider	MAINTENANCE	1750 Tbi (05-..)	BOSCH MeD17.3.1 CF5/EOBD
 Spider	MAINTENANCE	1750 Tbi (05-..)	BOSCH MeD17.3.1 CF5/EOBD
 Spider	MAINTENANCE	1750 Tbi (05-..)	BOSCH MeD17.3.1 CF5/EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Alfa Romeo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Spider	MAINTENANCE	1750 Tbi (05-..)	BOSCH MeD17.3.1 CF5/EOBD
 Spider	MAINTENANCE	1750 Tbi (05-..)	BOSCH MeD17.3.1 CF5/EOBD
 Spider	MAINTENANCE	1750 Tbi (05-..)	BOSCH MeD17.3.1 CF5/EOBD
 Spider	MAINTENANCE	1750 Tbi (05-..)	BOSCH MeD17.3.1 CF5/EOBD
 Spider	MAINTENANCE	1750 Tbi (05-..)	BOSCH MeD17.3.1 CF5/EOBD
 Spider	MAINTENANCE	1750 Tbi (05-..)	BOSCH MeD17.3.1 CF5/EOBD
 Spider	MAINTENANCE	1750 Tbi (05-..)	BOSCH MeD17.3.1 CF5/EOBD
 Spider	MAINTENANCE	1750 Tbi (05-..)	BOSCH MeD17.3.1 CF5/EOBD
 Spider	MAINTENANCE	1750 Tbi (05-..)	BOSCH MeD17.3.1 CF5/EOBD
 Spider	MAINTENANCE	1750 Tbi (05-..)	BOSCH MeD17.3.1 CF5/EOBD
 Spider	MAINTENANCE	1750 Tbi (05-..)	Litronic
 Spider	MAINTENANCE	1750 Tbi (05-..)	Litronic
 Spider	MAINTENANCE	1750 Tbi (05-..)	Lucas TRW ABS ESP
 Spider	MAINTENANCE	2.0 JTDm 16v (05-..)	Litronic
 Spider	MAINTENANCE	2.0 JTDm 16v (05-..)	Litronic
 Spider	MAINTENANCE	2.0 JTDm 16v (05-..)	Lucas TRW ABS ESP
 Spider	MAINTENANCE	2.2 JTS (05-..)	Litronic
 Spider	MAINTENANCE	2.2 JTS (05-..)	Litronic
 Spider	MAINTENANCE	2.2 JTS (05-..)	Lucas TRW ABS ESP
 Spider	MAINTENANCE	2.4 JTDm 20v (05-..)	Litronic
 Spider	MAINTENANCE	2.4 JTDm 20v (05-..)	Litronic
 Spider	MAINTENANCE	2.4 JTDm 20v (05-..)	Lucas TRW ABS ESP
 Spider	MAINTENANCE	3.2 JTS (05-..)	Litronic
 Spider	MAINTENANCE	3.2 JTS (05-..)	Litronic
 Spider	MAINTENANCE	3.2 JTS (05-..)	Lucas TRW ABS ESP
 Spider	PARKING HELP	1750 Tbi (05-..)	Valeo
 Spider	PARKING HELP	2.0 JTDm 16v (05-..)	Valeo
 Spider	PARKING HELP	2.2 JTS (05-..)	Valeo
 Spider	PARKING HELP	2.4 JTDm 20v (05-..)	Valeo
 Spider	PARKING HELP	3.2 JTS (05-..)	Valeo
 Spider	PASSENGER SEAT R	1750 Tbi (05-..)	Lear 2
 Spider	PASSENGER SEAT R	2.0 JTDm 16v (05-..)	Lear 2
 Spider	PASSENGER SEAT R	2.2 JTS (05-..)	Lear 2
 Spider	PASSENGER SEAT R	2.4 JTDm 20v (05-..)	Lear 2
 Spider	PASSENGER SEAT R	3.2 JTS (05-..)	Lear 2
 Spider	RH LIGHT MODULATI	1750 Tbi (05-..)	Litronic
 Spider	RH LIGHT MODULATI	2.0 JTDm 16v (05-..)	Litronic
 Spider	RH LIGHT MODULATI	2.2 JTS (05-..)	Litronic
 Spider	RH LIGHT MODULATI	2.4 JTDm 20v (05-..)	Litronic
 Spider	RH LIGHT MODULATI	3.2 JTS (05-..)	Litronic
 Spider	TIRE PRESSURE	1750 Tbi	TRW 2
 Spider	TIRE PRESSURE	2.0 JTDm 16v	TRW 2
 Spider	TIRE PRESSURE	2.2 JTS	TRW 2
 Spider	TIRE PRESSURE	2.4 JTDm 20v	TRW 2
 Spider	TIRE PRESSURE	3.2 JTS	TRW 2
 Spider	VISUAL./TELEMATIC	1750 Tbi (05-..)	Marelli Connect 3
 Spider	VISUAL./TELEMATIC	2.0 JTDm 16v (05-..)	Marelli Connect 3
 Spider	VISUAL./TELEMATIC	2.2 JTS (05-..)	Marelli Connect 3
 Spider	VISUAL./TELEMATIC	2.4 JTDm 20v (05-..)	Marelli Connect 3
 Spider	VISUAL./TELEMATIC	3.2 JTS (05-..)	Marelli Connect 3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Audi

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 100 (4A) (91-94)	ABS	(91-94)	
 100 (4A) (91-94)	AIRBAG	(91-94)	
 100 (4A) (91-94)	AUTOM. TRANSMISSI	(91-94)	
 100 (4A) (91-94)	CENTRAL LOCKING	(91-94)	
 100 (4A) (91-94)	CLIMA	(91-94)	
 100 (4A) (91-94)	CONV. TOP/SUNROO	(91-94)	
 100 (4A) (91-94)	ENGINE MANAGEME	(91-94)	
 100 (4A) (91-94)	ENGINE MANAGEME	(91-94)	
 100 (4A) (91-94)	ENGINE MANAGEME	(91-94)	
 100 (4A) (91-94)	IMMOBILIZER	(91-94)	
 100 (4A) (91-94)	MAINTENANCE	(91-94)	
 100 (4A) (91-94)	MAINTENANCE	(91-94)	
 100 (4A) (91-94)	MAINTENANCE	(91-94)	
 200 (44) (88-91)	ABS	(88-91)	
 200 (44) (88-91)	AIRBAG	(88-91)	
 200 (44) (88-91)	AUTOM. TRANSMISSI	(88-91)	
 200 (44) (88-91)	CLIMA	(88-91)	
 200 (44) (88-91)	ENGINE MANAGEME	(88-91)	
 200 (44) (88-91)	MAINTENANCE	(88-91)	
 200 (44) (88-91)	MAINTENANCE	(88-91)	
 200 (44) (88-91)	MAINTENANCE	(88-91)	
 80 (8C) (92-96)	ABS	(92-96)	
 80 (8C) (92-96)	AIRBAG	(92-96)	
 80 (8C) (92-96)	AUTOM. TRANSMISSI	(92-96)	
 80 (8C) (92-96)	CENTRAL LOCKING	(92-96)	
 80 (8C) (92-96)	CLIMA	(92-96)	
 80 (8C) (92-96)	CONV. TOP/SUNROO	(92-96)	
 80 (8C) (92-96)	ENGINE MANAGEME	(92-96)	
 80 (8C) (92-96)	ENGINE MANAGEME	(92-96)	
 80 (8C) (92-96)	ENGINE MANAGEME	(92-96)	
 80 (8C) (92-96)	IMMOBILIZER	(92-96)	
 80 (8C) (92-96)	MAINTENANCE	(92-96)	
 80 (8C) (92-96)	MAINTENANCE	(92-96)	
 80 (8C) (92-96)	MAINTENANCE	(92-96)	
 90 (89) (87-92)	ABS	(87-92)	
 90 (89) (87-92)	AIRBAG	(87-92)	
 90 (89) (87-92)	AUTOM. TRANSMISSI	(87-92)	
 90 (89) (87-92)	CLIMA	(87-92)	
 90 (89) (87-92)	ENGINE MANAGEME	(87-92)	
 90 (89) (87-92)	ENGINE MANAGEME	(87-92)	
 90 (89) (87-92)	ENGINE MANAGEME	(87-92)	
 90 (89) (87-92)	MAINTENANCE	(87-92)	
 90 (89) (87-92)	MAINTENANCE	(87-92)	
 90 (89) (87-92)	MAINTENANCE	(87-92)	
 A1 (8X) (10-..)	AIRBAG	(10-..)	
 A1 (8X) (10-..)	CHASSIS NETWORK	(10-..)	Diagnostic bus interface
 A1 (8X) (10-..)	CLIMA	(10-..)	Climatic
 A1 (8X) (10-..)	DASHBOARD	(10-..)	
 A1 (8X) (10-..)	ENGINE MANAGEME	(10-..)	
 A1 (8X) (10-..)	ENGINE MANAGEME	1.4 TSI 90 Kw (10-..)	CAXA
 A1 (8X) (10-..)	MAINTENANCE	(10-..)	
 A2 (8Z) (01-05)	ABS	(01-05)	
 A2 (8Z) (01-05)	ABS	(01-05)	ATE TEVES Mk60 No ASR
 A2 (8Z) (01-05)	AIRBAG	(01-05)	
 A2 (8Z) (01-05)	AUTOM. TRANSMISSI	(01-05)	
 A2 (8Z) (01-05)	CHASSIS NETWORK	(01-05)	
 A2 (8Z) (01-05)	CLIMA	(01-05)	CLIMATIC

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Audi

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 A2 (8Z) (01-05)	CLIMA	(01-05)	CLIMATRONIC
 A2 (8Z) (01-05)	COMFORT SYSTEM	(01-05)	
 A2 (8Z) (01-05)	DASHBOARD	(01-05)	
 A2 (8Z) (01-05)	ELECTRIC STEERING	(01-05)	
 A2 (8Z) (01-05)	ENGINE MANAGEME	(01-05)	
 A2 (8Z) (01-05)	ENGINE MANAGEME	(01-05)	
 A2 (8Z) (01-05)	ENGINE MANAGEME	(01-05)	
 A2 (8Z) (01-05)	IMMOBILIZER	(01-05)	
 A2 (8Z) (01-05)	MAINTENANCE	(01-05)	
 A2 (8Z) (01-05)	MAINTENANCE	(01-05)	
 A2 (8Z) (01-05)	MAINTENANCE	(01-05)	
 A2 (8Z) (01-05)	MAINTENANCE	(01-05)	
 A2 (8Z) (01-05)	MAINTENANCE	(01-05)	
 A2 (8Z) (01-05)	NAVIGATION	(01-05)	
 A2 (8Z) (01-05)	SERVICE LIGHT RES	(01-05)	
 A3 (8L) (97-03)	4WD ELECTRONICS	(97-03)	ATE TEVES Mk60 No ASR
 A3 (8L) (97-03)	ABS	(01-03)	
 A3 (8L) (97-03)	ABS	(97-03)	
 A3 (8L) (97-03)	AIRBAG	(97-03)	
 A3 (8L) (97-03)	ANTITHEFT	(97-03)	
 A3 (8L) (97-03)	AUTOM. TRANSMISSI	(97-03)	
 A3 (8L) (97-03)	CENTRAL LOCKING	(97-03)	
 A3 (8L) (97-03)	CLIMA	(97-03)	
 A3 (8L) (97-03)	DASHBOARD	(97-03)	
 A3 (8L) (97-03)	ENGINE MANAGEME	(97-03)	
 A3 (8L) (97-03)	ENGINE MANAGEME	(97-03)	
 A3 (8L) (97-03)	HEADLIGHT LEVEL	(97-03)	
 A3 (8L) (97-03)	IMMOBILIZER	(97-03)	
 A3 (8L) (97-03)	MAINTENANCE	(..-00)	
 A3 (8L) (97-03)	MAINTENANCE	(..-00)	DIAG DIAG DIAG ATE TEVES Mk60 No ASR MANUAL
 A3 (8L) (97-03)	MAINTENANCE	(00-03)	
 A3 (8L) (97-03)	MAINTENANCE	(01-03)	
 A3 (8L) (97-03)	MAINTENANCE	(97-03)	
 A3 (8L) (97-03)	MAINTENANCE	(97-03)	
 A3 (8L) (97-03)	MAINTENANCE	(97-03)	
 A3 (8L) (97-03)	MAINTENANCE	(97-03)	
 A3 (8L) (97-03)	MAINTENANCE	(97-03)	
 A3 (8L) (97-03)	NAVIGATION	(97-03)	
 A3 (8L) (97-03)	PARKING HELP	(97-03)	
 A3 (8L) (97-03)	PASSIVE ENTRY	(97-03)	
 A3 (8L) (97-03)	RADIO / CD	(97-03)	
 A3 (8L) (97-03)	SERVICE LIGHT RES	(..-00)	
 A3 (8L) (97-03)	SERVICE LIGHT RES	(00-03)	DIAG DIAG MANUAL
 A3 (8L) (97-03)	SERVICE LIGHT RES	(97-03)	
 A3 (8L) (97-03)	STEERING WHEEL E	(97-03)	
 A3 (8P) (04-..)	4WD ELECTRONICS	(04-09)	CAN Electric central system Comfort system
 A3 (8P) (04-..)	ABS	(04-09)	
 A3 (8P) (04-..)	AIRBAG	(04-09)	
 A3 (8P) (04-..)	AUTOM. TRANSMISSI	(04-09)	
 A3 (8P) (04-..)	AUX. HEATING	(04-09)	
 A3 (8P) (04-..)	CENTRAL ELECTRIC	(04-09)	
 A3 (8P) (04-..)	CHASSIS NETWORK	(04-09)	
 A3 (8P) (04-..)	CLIMA	(04-09)	
 A3 (8P) (04-..)	COMFORT SYSTEM	(04-09)	
 A3 (8P) (04-..)	DASHBOARD	(04-09)	
 A3 (8P) (04-..)	DIGITAL RADIO TUNE	(04-09)	
 A3 (8P) (04-..)	DRIVER SEAT CONT	(04-09)	
 A3 (8P) (04-..)	DRIVER SIDE DOOR	(04-09)	
 A3 (8P) (04-..)	ELECTRIC STEERING	(04-09)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Audi

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 A3 (8P) (04-..)	ENGINE MANAGEME	(04-09)	CAN
 A3 (8P) (04-..)	ENGINE MANAGEME	2.0 TDI 125 Kw (08-10)	CBBB
 A3 (8P) (04-..)	HEADLIGHT LEVEL	(04-09)	
 A3 (8P) (04-..)	IMMOBILIZER	(04-09)	
 A3 (8P) (04-..)	LEFT REAR DOOR	(04-09)	
 A3 (8P) (04-..)	MAINTENANCE	(04-06)	DIAG
 A3 (8P) (04-..)	MAINTENANCE	(04-06)	DIAG
 A3 (8P) (04-..)	MAINTENANCE	(04-06)	DIAG
 A3 (8P) (04-..)	MAINTENANCE	(04-07)	MANUAL
 A3 (8P) (04-..)	MAINTENANCE	(04-09)	
 A3 (8P) (04-..)	MAINTENANCE	(04-09)	
 A3 (8P) (04-..)	MAINTENANCE	(04-09)	
 A3 (8P) (04-..)	MAINTENANCE	(04-09)	
 A3 (8P) (04-..)	MAINTENANCE	(04-09)	
 A3 (8P) (04-..)	MAINTENANCE	(04-09)	CAN
 A3 (8P) (04-..)	MAINTENANCE	(04-09)	CAN
 A3 (8P) (04-..)	MAINTENANCE	(06-07)	DIAG
 A3 (8P) (04-..)	MAINTENANCE	(06-07)	DIAG
 A3 (8P) (04-..)	MAINTENANCE	(06-07)	DIAG
 A3 (8P) (04-..)	MAINTENANCE	(06-07)	DIAG
 A3 (8P) (04-..)	MAINTENANCE	(06-07)	DIAG
 A3 (8P) (04-..)	MAINTENANCE	(06-07)	DIAG
 A3 (8P) (04-..)	MAINTENANCE	(08-..)	DIAG
 A3 (8P) (04-..)	MAINTENANCE	(08-..)	DIAG
 A3 (8P) (04-..)	MAINTENANCE	(08-..)	DIAG
 A3 (8P) (04-..)	MAINTENANCE	(08-..)	DIAG
 A3 (8P) (04-..)	MAINTENANCE	2.0 TDI 125 Kw (08-10)	CBBB
 A3 (8P) (04-..)	MAINTENANCE	2.0 TDI 125 Kw (08-10)	CBBB
 A3 (8P) (04-..)	MAINTENANCE	2.0 TDI 125 Kw (08-10)	CBBB
 A3 (8P) (04-..)	NAVIGATION	(04-09)	
 A3 (8P) (04-..)	PARKING HELP	(04-09)	
 A3 (8P) (04-..)	PASS. SIDE DOOR	(04-09)	
 A3 (8P) (04-..)	PHONE	(04-09)	
 A3 (8P) (04-..)	RADIO / CD	(04-09)	
 A3 (8P) (04-..)	RIGHT REAR DOOR	(04-09)	
 A3 (8P) (04-..)	SERVICE LIGHT RES	(04-06)	DIAG
 A3 (8P) (04-..)	SERVICE LIGHT RES	(04-07)	MANUAL
 A3 (8P) (04-..)	SERVICE LIGHT RES	(06-07)	DIAG
 A3 (8P) (04-..)	SERVICE LIGHT RES	(08-..)	DIAG
 A3 (8P) (04-..)	SOUND SYSTEM	(04-09)	
 A3 (8P) (04-..)	STEERING WHEEL E	(04-09)	
 A3 (8P) (04-..)	TOW FUNCTION	(04-09)	CAN Gateway
 A3 (8P) (04-..)	TRANSPORT MODALI	(04-09)	
 A3 (8P) (04-..)	TV SYSTEM	(04-09)	
 A4 (8D) (96-01)	ABS	(96-6/01)	
 A4 (8D) (96-01)	AIRBAG	(96-6/01)	
 A4 (8D) (96-01)	ANTITHEFT	(96-6/01)	
 A4 (8D) (96-01)	AUTOM. TRANSMISSI	(96-6/01)	
 A4 (8D) (96-01)	CENTRAL LOCKING	(96-6/01)	
 A4 (8D) (96-01)	CLIMA	(96-6/01)	
 A4 (8D) (96-01)	DASHBOARD	(96-6/01)	
 A4 (8D) (96-01)	ELECTRIC ACTUATIO	(96-6/01)	
 A4 (8D) (96-01)	ENGINE MANAGEME	(96-6/01)	
 A4 (8D) (96-01)	ENGINE MANAGEME	(96-6/01)	
 A4 (8D) (96-01)	ENGINE MANAGEME	(96-6/01)	
 A4 (8D) (96-01)	HEADLIGHT LEVEL	(96-6/01)	
 A4 (8D) (96-01)	IMMOBILIZER	(96-6/01)	
 A4 (8D) (96-01)	MAINTENANCE	(96-6/01)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Audi

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 A4 (8D) (96-01)	MAINTENANCE	(96-6/01)	MANUAL
 A4 (8D) (96-01)	MAINTENANCE	(96-6/01)	
 A4 (8D) (96-01)	MAINTENANCE	(96-6/01)	
 A4 (8D) (96-01)	MAINTENANCE	(96-6/98)	
 A4 (8D) (96-01)	MAINTENANCE	(96-6/98)	
 A4 (8D) (96-01)	NAVIGATION	(96-6/01)	
 A4 (8D) (96-01)	RADIO / CD	(96-6/01)	
 A4 (8D) (96-01)	SERVICE LIGHT RES	(96-6/01)	
 A4 (8D) (96-01)	SERVICE LIGHT RES	(96-6/98)	ATE TEVES Mk60 No ASR No CAN CAN No CAN CAN No CAN CAN KWP-2000 No CAN CAN KWP-2000 No CAN No CAN CAN No CAN No CAN CAN No CAN No CAN CAN KWP-2000 No CAN No CAN CAN RS4 No CAN CAN KPW-2000 ATE TEVES Mk60 No ASR No CAN No CAN No CAN No CAN KWP-2000 CAN CAN CAN CAN CAN KPW-2000 KPW-2000
 A4 (8E) (01-08)	ABS	(01-05)	
 A4 (8E) (01-08)	ABS	(01-05)	
 A4 (8E) (01-08)	ABS	(06-08)	
 A4 (8E) (01-08)	AIRBAG	(01-05)	
 A4 (8E) (01-08)	AIRBAG	(06-08)	
 A4 (8E) (01-08)	ANTITHEFT	(06-08)	
 A4 (8E) (01-08)	AUTOM. TRANSMISSI	(01-08)	
 A4 (8E) (01-08)	AUTOM. TRANSMISSI	(06-08)	
 A4 (8E) (01-08)	AUTOM. TRANSMISSI	(06-08)	
 A4 (8E) (01-08)	AUX. HEATING	(01-05)	
 A4 (8E) (01-08)	AUX. HEATING	(06-08)	
 A4 (8E) (01-08)	AUX. HEATING	(06-08)	
 A4 (8E) (01-08)	CHASSIS NETWORK	(01-05)	
 A4 (8E) (01-08)	CLIMA	(01-08)	
 A4 (8E) (01-08)	CLIMA	(06-08)	
 A4 (8E) (01-08)	COMFORT SYSTEM	(01-08)	
 A4 (8E) (01-08)	CONV. TOP/SUNROO	(01-08)	
 A4 (8E) (01-08)	CONV. TOP/SUNROO	(06-08)	
 A4 (8E) (01-08)	CONV. TOP/SUNROO	(06-08)	
 A4 (8E) (01-08)	DASHBOARD	(01-05)	
 A4 (8E) (01-08)	DASHBOARD	(06-08)	
 A4 (8E) (01-08)	DIGITAL RADIO TUNE	(06-08)	
 A4 (8E) (01-08)	DRIVER SEAT CONT	(01-05)	
 A4 (8E) (01-08)	DRIVER SEAT CONT	(06-08)	
 A4 (8E) (01-08)	ELECTRIC STEERING	(01-05)	
 A4 (8E) (01-08)	ELECTRIC STEERING	(06-08)	
 A4 (8E) (01-08)	EMERGENCY MODUL	(06-08)	
 A4 (8E) (01-08)	ENGINE MANAGEME	(01-08)	
 A4 (8E) (01-08)	ENGINE MANAGEME	(01-08)	
 A4 (8E) (01-08)	ENGINE MANAGEME	(01-08)	
 A4 (8E) (01-08)	ENGINE MANAGEME	(05-08)	
 A4 (8E) (01-08)	ENGINE MANAGEME	(06-08)	
 A4 (8E) (01-08)	HEADLIGHT LEVEL	(01-05)	
 A4 (8E) (01-08)	HEADLIGHT LEVEL	(06-08)	
 A4 (8E) (01-08)	HEADLIGHT LEVEL	(06-08)	
 A4 (8E) (01-08)	MAINTENANCE	(01-05)	
 A4 (8E) (01-08)	MAINTENANCE	(01-05)	
 A4 (8E) (01-08)	MAINTENANCE	(01-05)	
 A4 (8E) (01-08)	MAINTENANCE	(01-05)	
 A4 (8E) (01-08)	MAINTENANCE	(01-08)	
 A4 (8E) (01-08)	MAINTENANCE	(05-08)	
 A4 (8E) (01-08)	MAINTENANCE	(05-08)	
 A4 (8E) (01-08)	MAINTENANCE	(06-08)	
 A4 (8E) (01-08)	MAINTENANCE	(06-08)	
 A4 (8E) (01-08)	MAINTENANCE	(06-08)	
 A4 (8E) (01-08)	MAINTENANCE	(06-08)	
 A4 (8E) (01-08)	MAINTENANCE	(06-08)	
 A4 (8E) (01-08)	MAINTENANCE	(06-08)	
 A4 (8E) (01-08)	MAINTENANCE	(06-08)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Audi

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 A4 (8E) (01-08)	MAINTENANCE	(06-08)	KPW-2000
 A4 (8E) (01-08)	MAINTENANCE	(06-08)	KWP-2000
 A4 (8E) (01-08)	NAVIGATION	(06-08)	
 A4 (8E) (01-08)	PARKING HELP	(01-05)	
 A4 (8E) (01-08)	PHONE	(06-08)	
 A4 (8E) (01-08)	RADIO / CD	(01-08)	No CAN
 A4 (8E) (01-08)	RADIO / CD	(06-08)	CAN
 A4 (8E) (01-08)	SERVICE LIGHT RES	(01-05)	No CAN
 A4 (8E) (01-08)	SERVICE LIGHT RES	(06-08)	KWP-2000
 A4 (8E) (01-08)	STEERING WHEEL E	(01-08)	No CAN
 A4 (8E) (01-08)	STEERING WHEEL E	(06-08)	CAN
 A4 (8E) (01-08)	TIRE PRESSURE	(01-05)	No CAN
 A4 (8E) (01-08)	TIRE PRESSURE	(06-08)	KPW-2000
 A4 (8E) (01-08)	TOW FUNCTION	(06-08)	CAN
 A4 (8E) (01-08)	TV SYSTEM	(01-08)	No CAN
 A4 (8E) (01-08)	TV SYSTEM	(06-08)	KWP-2000
 A4 (8E) (01-08)	VOICE CONTROL	(01-05)	No CAN
 A4 (8E) (01-08)	VOICE CONTROL	(06-08)	KWP-2000
 A4 (8K) (08-..)	ABS + TRACT. CONT	(08-10)	
 A4 (8K) (08-..)	AIRBAG	(08-10)	
 A4 (8K) (08-..)	AUTOM. TRANSMISSI	(08-10)	0AW
 A4 (8K) (08-..)	CHANGE BRAKE PAD	(08-10)	
 A4 (8K) (08-..)	CHASSIS NETWORK	(08-10)	
 A4 (8K) (08-..)	CLIMA	(08-10)	
 A4 (8K) (08-..)	COMFORT SYSTEM	(08-10)	
 A4 (8K) (08-..)	DASHBOARD	(08-10)	
 A4 (8K) (08-..)	DRIVER SIDE DOOR	(08-10)	
 A4 (8K) (08-..)	ENGINE MANAGEME	1.8 TFSi 170Cv CDHB (08-10)	
 A4 (8K) (08-..)	ENGINE MANAGEME	2.0 TDI 105 Kw CAGA (08-10)	
 A4 (8K) (08-..)	HEADLIGHT LEVEL	(08-10)	
 A4 (8K) (08-..)	LEFT REAR DOOR	(08-10)	
 A4 (8K) (08-..)	MAINTENANCE	(08-10)	
 A4 (8K) (08-..)	MAINTENANCE	(08-10)	
 A4 (8K) (08-..)	MAINTENANCE	(08-10)	
 A4 (8K) (08-..)	MAINTENANCE	(08-10)	
 A4 (8K) (08-..)	MAINTENANCE	(08-10)	
 A4 (8K) (08-..)	MAINTENANCE	(08-10)	
 A4 (8K) (08-..)	MAINTENANCE	(08-10)	
 A4 (8K) (08-..)	MAINTENANCE	2.0 TDI 105 Kw CAGA (08-10)	
 A4 (8K) (08-..)	PARK.BRAKE	(08-10)	
 A4 (8K) (08-..)	PASS. SIDE DOOR	(08-10)	
 A4 (8K) (08-..)	RELEV/SWITCON	(08-10)	
 A4 (8K) (08-..)	RIGHT REAR DOOR	(08-10)	
 A4 (8K) (08-..)	SERVICE LIGHT RES	(08-10)	
 A4 (8K) (08-..)	SOUND SYSTEM	(08-10)	
 A4 (8K) (08-..)	STEERING WHEEL E	(08-10)	
 A4 Cabrio (8H) (02-09)	ABS	(02-09)	
 A4 Cabrio (8H) (02-09)	ABS	(02-09)	ATE TEVES Mk60 No ASR
 A4 Cabrio (8H) (02-09)	ABS	(06-09)	CAN
 A4 Cabrio (8H) (02-09)	AIRBAG	(02-09)	
 A4 Cabrio (8H) (02-09)	AIRBAG	(06-09)	CAN
 A4 Cabrio (8H) (02-09)	ANTITHEFT	(06-08)	
 A4 Cabrio (8H) (02-09)	AUTOM. TRANSMISSI	(02-09)	No CAN
 A4 Cabrio (8H) (02-09)	AUTOM. TRANSMISSI	(06-08)	KWP-2000
 A4 Cabrio (8H) (02-09)	AUTOM. TRANSMISSI	(06-09)	CAN
 A4 Cabrio (8H) (02-09)	AUX. HEATING	(02-05)	No CAN
 A4 Cabrio (8H) (02-09)	AUX. HEATING	(06-09)	CAN

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Audi

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 A4 Cabrio (8H) (02-09)	CENTRAL ELECTRIC	(06-08)	
 A4 Cabrio (8H) (02-09)	CENTRAL ELECTRIC	(06-09)	Electric central system
 A4 Cabrio (8H) (02-09)	CHASSIS NETWORK	(02-05)	
 A4 Cabrio (8H) (02-09)	CLIMA	(02-09)	No CAN
 A4 Cabrio (8H) (02-09)	CLIMA	(06-09)	CAN
 A4 Cabrio (8H) (02-09)	COMFORT SYSTEM	(06-08)	
 A4 Cabrio (8H) (02-09)	COMFORT SYSTEM	(06-09)	CAN
 A4 Cabrio (8H) (02-09)	COMFORT SYSTEM	(06-09)	No CAN
 A4 Cabrio (8H) (02-09)	CONV. TOP/SUNROO	(02-05)	No CAN
 A4 Cabrio (8H) (02-09)	CONV. TOP/SUNROO	(06-08)	CAN
 A4 Cabrio (8H) (02-09)	CONV. TOP/SUNROO	(06-08)	KWP-2000
 A4 Cabrio (8H) (02-09)	CONV. TOP/SUNROO	(06-08)	NO CAN
 A4 Cabrio (8H) (02-09)	CONV. TOP/SUNROO	(06-09)	CAN
 A4 Cabrio (8H) (02-09)	DASHBOARD	(02-05)	No CAN
 A4 Cabrio (8H) (02-09)	DASHBOARD	(06-09)	KWP-2000
 A4 Cabrio (8H) (02-09)	DIGITAL RADIO TUNE	(06-08)	
 A4 Cabrio (8H) (02-09)	DIGITAL RADIO TUNE	(06-09)	
 A4 Cabrio (8H) (02-09)	DRIVER SEAT CONT	(02-05)	
 A4 Cabrio (8H) (02-09)	DRIVER SEAT CONT	(06-08)	
 A4 Cabrio (8H) (02-09)	ELECTRIC STEERING	(02-05)	
 A4 Cabrio (8H) (02-09)	ELECTRIC STEERING	(06-09)	
 A4 Cabrio (8H) (02-09)	EMERGENCY MODUL	(06-08)	
 A4 Cabrio (8H) (02-09)	ENGINE MANAGEME	(02-09)	
 A4 Cabrio (8H) (02-09)	ENGINE MANAGEME	(02-09)	
 A4 Cabrio (8H) (02-09)	ENGINE MANAGEME	(06-09)	CAN
 A4 Cabrio (8H) (02-09)	ENGINE MANAGEME	(06-08)	RS4
 A4 Cabrio (8H) (02-09)	HEADLIGHT LEVEL	(02-05)	No CAN
 A4 Cabrio (8H) (02-09)	HEADLIGHT LEVEL	(06-08)	
 A4 Cabrio (8H) (02-09)	HEADLIGHT LEVEL	(06-09)	KWP-2000
 A4 Cabrio (8H) (02-09)	MAINTENANCE	(02-05)	
 A4 Cabrio (8H) (02-09)	MAINTENANCE	(02-09)	
 A4 Cabrio (8H) (02-09)	MAINTENANCE	(02-09)	
 A4 Cabrio (8H) (02-09)	MAINTENANCE	(02-09)	
 A4 Cabrio (8H) (02-09)	MAINTENANCE	(02-09)	ATE TEVES Mk60 No ASR
 A4 Cabrio (8H) (02-09)	MAINTENANCE	(06-09)	CAN
 A4 Cabrio (8H) (02-09)	MAINTENANCE	(06-09)	CAN
 A4 Cabrio (8H) (02-09)	MAINTENANCE	(06-09)	CAN
 A4 Cabrio (8H) (02-09)	MAINTENANCE	(06-09)	CAN
 A4 Cabrio (8H) (02-09)	MAINTENANCE	(06-09)	CAN
 A4 Cabrio (8H) (02-09)	MAINTENANCE	(06-09)	CAN
 A4 Cabrio (8H) (02-09)	MAINTENANCE	(06-09)	KWP-2000
 A4 Cabrio (8H) (02-09)	MAINTENANCE	(06-09)	KWP-2000
 A4 Cabrio (8H) (02-09)	MAINTENANCE	(06-09)	KWP-2000
 A4 Cabrio (8H) (02-09)	MAINTENANCE	(06-09)	No CAN
 A4 Cabrio (8H) (02-09)	NAVIGATION	(06-08)	
 A4 Cabrio (8H) (02-09)	PARKING HELP	(02-05)	
 A4 Cabrio (8H) (02-09)	PHONE	(06-08)	
 A4 Cabrio (8H) (02-09)	PHONE	(06-09)	
 A4 Cabrio (8H) (02-09)	RADIO / CD	(02-05)	No CAN
 A4 Cabrio (8H) (02-09)	RADIO / CD	(06-09)	CAN
 A4 Cabrio (8H) (02-09)	SERVICE LIGHT RES	(02-05)	
 A4 Cabrio (8H) (02-09)	SERVICE LIGHT RES	(06-09)	No CAN
 A4 Cabrio (8H) (02-09)	STEERING WHEEL E	(02-09)	No CAN
 A4 Cabrio (8H) (02-09)	STEERING WHEEL E	(06-09)	CAN
 A4 Cabrio (8H) (02-09)	SUPP HEATER/AUTO	(06-09)	No CAN
 A4 Cabrio (8H) (02-09)	TIRE PRESSURE	(02-05)	No CAN
 A4 Cabrio (8H) (02-09)	TIRE PRESSURE	(06-09)	
 A4 Cabrio (8H) (02-09)	TOW FUNCTION	(06-09)	CAN

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Audi

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 A4 Cabrio (8H) (02-09)	TV SYSTEM	(02-05)	No CAN
 A4 Cabrio (8H) (02-09)	TV SYSTEM	(06-08)	
 A4 Cabrio (8H) (02-09)	TV SYSTEM	(06-09)	KWP-2000
 A4 Cabrio (8H) (02-09)	VOICE CONTROL	(02-05)	No CAN
 A4 Cabrio (8H) (02-09)	VOICE CONTROL	(06-09)	KWP-2000
 A5 (8T) (08-..)	ABS + TRACT. CONT	(08-10)	
 A5 (8T) (08-..)	AIRBAG	(08-10)	
 A5 (8T) (08-..)	AUTOM. TRANSMISSI	(08-10)	0AW
 A5 (8T) (08-..)	CHANGE BRAKE PAD	(08-10)	
 A5 (8T) (08-..)	CHASSIS NETWORK	(08-10)	
 A5 (8T) (08-..)	CLIMA	(08-10)	
 A5 (8T) (08-..)	COMFORT SYSTEM	(08-10)	
 A5 (8T) (08-..)	DASHBOARD	(08-10)	
 A5 (8T) (08-..)	DRIVER SIDE DOOR	(08-10)	
 A5 (8T) (08-..)	ENGINE MANAGEME	1.8 TFSi 170Cv CDHB (08-10)	
 A5 (8T) (08-..)	ENGINE MANAGEME	2.0 TDI 105 Kw CAGA (08-10)	
 A5 (8T) (08-..)	HEADLIGHT LEVEL	(08-10)	
 A5 (8T) (08-..)	LEFT REAR DOOR	(08-10)	
 A5 (8T) (08-..)	MAINTENANCE	(08-10)	
 A5 (8T) (08-..)	MAINTENANCE	(08-10)	
 A5 (8T) (08-..)	MAINTENANCE	(08-10)	
 A5 (8T) (08-..)	MAINTENANCE	(08-10)	
 A5 (8T) (08-..)	MAINTENANCE	(08-10)	
 A5 (8T) (08-..)	MAINTENANCE	(08-10)	
 A5 (8T) (08-..)	MAINTENANCE	2.0 TDI 105 Kw CAGA (08-10)	
 A5 (8T) (08-..)	PARK.BRAKE	(08-10)	
 A5 (8T) (08-..)	PASS. SIDE DOOR	(08-10)	
 A5 (8T) (08-..)	RELEV/SWITCON	(08-10)	
 A5 (8T) (08-..)	RIGHT REAR DOOR	(08-10)	
 A5 (8T) (08-..)	SERVICE LIGHT RES	(08-10)	
 A5 (8T) (08-..)	SOUND SYSTEM	(08-10)	
 A5 (8T) (08-..)	STEERING WHEEL E	(08-10)	
 A5 Cabrio (8F) (09-..)	ABS + TRACT. CONT	(09-10)	
 A5 Cabrio (8F) (09-..)	AIRBAG	(09-10)	
 A5 Cabrio (8F) (09-..)	AUTOM. TRANSMISSI	(08-10)	0AW
 A5 Cabrio (8F) (09-..)	CHANGE BRAKE PAD	(09-10)	
 A5 Cabrio (8F) (09-..)	CHASSIS NETWORK	(09-10)	
 A5 Cabrio (8F) (09-..)	CLIMA	(09-10)	
 A5 Cabrio (8F) (09-..)	COMFORT SYSTEM	(09-10)	
 A5 Cabrio (8F) (09-..)	DASHBOARD	(09-10)	
 A5 Cabrio (8F) (09-..)	DRIVER SIDE DOOR	(09-10)	
 A5 Cabrio (8F) (09-..)	ENGINE MANAGEME	1.8 TFSi 170Cv CDHB (08-10)	
 A5 Cabrio (8F) (09-..)	ENGINE MANAGEME	2.0 TDI 105 Kw CAGA (08-10)	
 A5 Cabrio (8F) (09-..)	HEADLIGHT LEVEL	(09-10)	
 A5 Cabrio (8F) (09-..)	LEFT REAR DOOR	(08-10)	
 A5 Cabrio (8F) (09-..)	MAINTENANCE	(09-10)	
 A5 Cabrio (8F) (09-..)	MAINTENANCE	(09-10)	
 A5 Cabrio (8F) (09-..)	MAINTENANCE	(09-10)	
 A5 Cabrio (8F) (09-..)	MAINTENANCE	(09-10)	
 A5 Cabrio (8F) (09-..)	MAINTENANCE	(09-10)	
 A5 Cabrio (8F) (09-..)	MAINTENANCE	(09-10)	
 A5 Cabrio (8F) (09-..)	MAINTENANCE	2.0 TDI 105 Kw CAGA (08-10)	
 A5 Cabrio (8F) (09-..)	PARK.BRAKE	(09-10)	
 A5 Cabrio (8F) (09-..)	PASS. SIDE DOOR	(09-10)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Audi

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 A5 Cabrio (8F) (09-..)	RELEV/SWITCON	(09-10)	
 A5 Cabrio (8F) (09-..)	RIGHT REAR DOOR	(08-10)	
 A5 Cabrio (8F) (09-..)	SERVICE LIGHT RES	(09-10)	
 A5 Cabrio (8F) (09-..)	SOUND SYSTEM	(09-10)	
 A5 Cabrio (8F) (09-..)	STEERING WHEEL E	(09-10)	
 A6 (4A) (95-97)	ABS	(95-97)	
 A6 (4A) (95-97)	AIRBAG	(95-97)	
 A6 (4A) (95-97)	AUTOM. TRANSMISSI	(95-97)	
 A6 (4A) (95-97)	CLIMA	(95-97)	
 A6 (4A) (95-97)	DASHBOARD	(95-97)	
 A6 (4A) (95-97)	ENGINE MANAGEME	(95-97)	
 A6 (4A) (95-97)	ENGINE MANAGEME	(95-97)	
 A6 (4A) (95-97)	ENGINE MANAGEME	(95-97)	
 A6 (4A) (95-97)	IMMOBILIZER	(95-97)	
 A6 (4A) (95-97)	MAINTENANCE	(95-97)	
 A6 (4A) (95-97)	MAINTENANCE	(95-97)	
 A6 (4A) (95-97)	MAINTENANCE	(95-97)	
 A6 (4B) (98-04)	ABS	(98-04)	
 A6 (4B) (98-04)	ABS	(98-04)	ATE TEVES Mk60 No ASR
 A6 (4B) (98-04)	AIRBAG	(98-04)	KW-2000
 A6 (4B) (98-04)	AIRBAG	(98-04)	NON CAN
 A6 (4B) (98-04)	AUTOM. TRANSMISSI	(98-04)	
 A6 (4B) (98-04)	CENTRAL LOCKING	(98-04)	
 A6 (4B) (98-04)	CLIMA	(98-04)	
 A6 (4B) (98-04)	DASHBOARD	(98-04)	
 A6 (4B) (98-04)	DRIVER SEAT CONT	(98-04)	
 A6 (4B) (98-04)	ELECTRIC ACTUATIO	(98-04)	
 A6 (4B) (98-04)	ENGINE MANAGEME	(98-04)	
 A6 (4B) (98-04)	ENGINE MANAGEME	(98-04)	
 A6 (4B) (98-04)	HEADLIGHT LEVEL	(98-04)	
 A6 (4B) (98-04)	IMMOBILIZER	(98-04)	
 A6 (4B) (98-04)	MAINTENANCE	(..-6/98)	
 A6 (4B) (98-04)	MAINTENANCE	(..-6/98)	
 A6 (4B) (98-04)	MAINTENANCE	(98-04)	
 A6 (4B) (98-04)	MAINTENANCE	(98-04)	
 A6 (4B) (98-04)	MAINTENANCE	(98-04)	
 A6 (4B) (98-04)	MAINTENANCE	(98-04)	ATE TEVES Mk60 No ASR
 A6 (4B) (98-04)	MAINTENANCE	(98-04)	MANUAL
 A6 (4B) (98-04)	MAINTENANCE	(99-04)	
 A6 (4B) (98-04)	PARKING HELP	(98-04)	
 A6 (4B) (98-04)	PHONE	(98-04)	
 A6 (4B) (98-04)	RADIO / CD	(98-04)	
 A6 (4B) (98-04)	SERVICE LIGHT RES	(..-6/98)	
 A6 (4B) (98-04)	SERVICE LIGHT RES	(98-04)	MANUAL
 A6 (4B) (98-04)	SERVICE LIGHT RES	(99-04)	
 A6 (4B) (98-04)	STEERING WHEEL E	(98-04)	
 A6 (4B) (98-04)	SUSPENSION CONTR	(98-04)	
 A6 (4F-FB) (05-..)	ABS	(05-09)	CAN
 A6 (4F-FB) (05-..)	AIRBAG	(05-09)	CAN
 A6 (4F-FB) (05-..)	AUTOM. TRANSMISSI	(05-09)	CAN
 A6 (4F-FB) (05-..)	BATTERY REGULATI	(05-09)	CAN
 A6 (4F-FB) (05-..)	CENTRAL ELECTRIC	(05-09)	CAN
 A6 (4F-FB) (05-..)	CHANGE BRAKE PAD	(05-09)	CAN
 A6 (4F-FB) (05-..)	CHASSIS NETWORK	(05-09)	CAN Gateway
 A6 (4F-FB) (05-..)	CLIMA	(05-09)	CAN
 A6 (4F-FB) (05-..)	COLUMN/SEAT REG.	(05-09)	CAN
 A6 (4F-FB) (05-..)	COMFORT SYSTEM	(05-09)	CAN
 A6 (4F-FB) (05-..)	DASHBOARD	(05-09)	CAN

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Audi

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 A6 (4F-FB) (05-...)	DIGITAL RADIO TUNE	(05-09)	CAN
 A6 (4F-FB) (05-...)	DISTANCE REGULATI	(05-09)	CAN
 A6 (4F-FB) (05-...)	DRIVER SIDE DOOR	(05-09)	CAN
 A6 (4F-FB) (05-...)	ELECT. CENTRAL SY	(05-09)	CAN
 A6 (4F-FB) (05-...)	ELECTRONIC TRIM	(05-09)	CAN
 A6 (4F-FB) (05-...)	ENGINE MANAGEME	(05-09)	3.0 V6 BMK
 A6 (4F-FB) (05-...)	ENGINE MANAGEME	(05-09)	CAN
 A6 (4F-FB) (05-...)	ENGINE MANAGEME	(05-09)	CAN
 A6 (4F-FB) (05-...)	HATCHBACK DOOR E	(05-09)	CAN
 A6 (4F-FB) (05-...)	HEADLIGHT LEVEL	(05-09)	CAN
 A6 (4F-FB) (05-...)	LEFT REAR DOOR	(05-09)	CAN
 A6 (4F-FB) (05-...)	MAINTENANCE	(05-08)	CAN
 A6 (4F-FB) (05-...)	MAINTENANCE	(05-08)	CAN
 A6 (4F-FB) (05-...)	MAINTENANCE	(05-08)	CAN
 A6 (4F-FB) (05-...)	MAINTENANCE	(05-09)	3.0 V6 BMK
 A6 (4F-FB) (05-...)	MAINTENANCE	(05-09)	CAN
 A6 (4F-FB) (05-...)	MAINTENANCE	(05-09)	CAN
 A6 (4F-FB) (05-...)	MAINTENANCE	(05-09)	CAN
 A6 (4F-FB) (05-...)	MAINTENANCE	(05-09)	CAN
 A6 (4F-FB) (05-...)	MAINTENANCE	(05-09)	CAN
 A6 (4F-FB) (05-...)	MAINTENANCE	(05-09)	CAN
 A6 (4F-FB) (05-...)	MAINTENANCE	(05-09)	CAN
 A6 (4F-FB) (05-...)	MAINTENANCE	(05-09)	CAN
 A6 (4F-FB) (05-...)	MAINTENANCE	(05-09)	CAN
 A6 (4F-FB) (05-...)	MAINTENANCE	(05-09)	CAN
 A6 (4F-FB) (05-...)	MAINTENANCE	(05-09)	CAN
 A6 (4F-FB) (05-...)	MAINTENANCE	(05-09)	CAN
 A6 (4F-FB) (05-...)	MAINTENANCE	(05-09)	CAN
 A6 (4F-FB) (05-...)	MAINTENANCE	(08-09)	CAN
 A6 (4F-FB) (05-...)	MAINTENANCE	(08-09)	CAN
 A6 (4F-FB) (05-...)	MAINTENANCE	(08-09)	CAN
 A6 (4F-FB) (05-...)	MAINTENANCE	(08-09)	CAN
 A6 (4F-FB) (05-...)	MEDIA PLAYER POSI	(05-09)	CAN
 A6 (4F-FB) (05-...)	MEDIA PLAYER POSI	(05-09)	CAN
 A6 (4F-FB) (05-...)	NAVIGATION	(05-09)	CAN
 A6 (4F-FB) (05-...)	PARK.BRAKE	(05-09)	CAN
 A6 (4F-FB) (05-...)	PARKING HELP	(05-09)	CAN
 A6 (4F-FB) (05-...)	PASS. SIDE DOOR	(05-09)	CAN
 A6 (4F-FB) (05-...)	PASSENGER SEAT R	(05-09)	CAN
 A6 (4F-FB) (05-...)	PHONE	(05-09)	CAN
 A6 (4F-FB) (05-...)	RADIO / CD	(05-09)	CAN
 A6 (4F-FB) (05-...)	REAR CLIMA	(05-09)	CAN
 A6 (4F-FB) (05-...)	RELEV/SWITCON	(05-09)	CAN
 A6 (4F-FB) (05-...)	RIGHT REAR DOOR	(05-09)	CAN
 A6 (4F-FB) (05-...)	SERVICE LIGHT RES	(05-08)	CAN
 A6 (4F-FB) (05-...)	SERVICE LIGHT RES	(08-09)	CAN
 A6 (4F-FB) (05-...)	SOUND SYSTEM	(05-09)	CAN
 A6 (4F-FB) (05-...)	SPECIAL FUNCTION	(05-09)	CAN
 A6 (4F-FB) (05-...)	STEERING WHEEL E	(05-09)	CAN
 A6 (4F-FB) (05-...)	SUPP HEATER/AUTO	(05-09)	CAN
 A6 (4F-FB) (05-...)	SUSPENSION CONTR	(05-09)	CAN
 A6 (4F-FB) (05-...)	TIRE PRESSURE	(05-09)	CAN
 A6 (4F-FB) (05-...)	TOW FUNCTION	(05-09)	CAN
 A6 (4F-FB) (05-...)	TV SYSTEM	(05-09)	CAN
 A6 (4F-FB) (05-...)	VOICE CONTROL	(05-09)	CAN
 A8 (4D) (94-03)	ABS	(01-03)	ATE TEVES Mk60 No ASR
 A8 (4D) (94-03)	ABS	(94-03)	
 A8 (4D) (94-03)	AIRBAG	(94-03)	
 A8 (4D) (94-03)	ANTITHEFT	(94-03)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Audi

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 A8 (4D) (94-03)	AUTOM. TRANSMISSI	(94-03)	ATE TEVES Mk60 No ASR
 A8 (4D) (94-03)	AUX. HEATING	(94-03)	
 A8 (4D) (94-03)	CENTRAL LOCKING	(94-03)	
 A8 (4D) (94-03)	CLIMA	(94-03)	
 A8 (4D) (94-03)	DASHBOARD	(94-03)	
 A8 (4D) (94-03)	EMERGENCY MODUL	(94-03)	
 A8 (4D) (94-03)	ENGINE MANAGEME	(94-03)	
 A8 (4D) (94-03)	ENGINE MANAGEME	(94-03)	
 A8 (4D) (94-03)	ENGINE MANAGEME	(94-03)	
 A8 (4D) (94-03)	ENGINE MANAGEME	(94-03)	
 A8 (4D) (94-03)	HEADLIGHT LEVEL	(94-03)	
 A8 (4D) (94-03)	IMMOBILIZER	(94-03)	
 A8 (4D) (94-03)	MAINTENANCE	(..-6/98)	
 A8 (4D) (94-03)	MAINTENANCE	(..-6/98)	
 A8 (4D) (94-03)	MAINTENANCE	(01-03)	
 A8 (4D) (94-03)	MAINTENANCE	(94-03)	
 A8 (4D) (94-03)	MAINTENANCE	(94-03)	
 A8 (4D) (94-03)	MAINTENANCE	(99-03)	
 A8 (4D) (94-03)	NAVIGATION	(94-03)	
 A8 (4D) (94-03)	PARKING HELP	(94-03)	
 A8 (4D) (94-03)	PHONE	(94-03)	
 A8 (4D) (94-03)	RADIO / CD	(94-03)	
 A8 (4D) (94-03)	SERVICE LIGHT RES	(..-6/98)	
 A8 (4D) (94-03)	SERVICE LIGHT RES	(99-03)	
 A8 (4D) (94-03)	STEERING WHEEL E	(94-03)	
 A8 (4D) (94-03)	TIRE PRESSURE	(94-03)	
 A8 (4D) (94-03)	TV SYSTEM	(94-03)	
 A8 (4D) (94-03)	VOICE CONTROL	(94-03)	
 A8 (4E) (03-..)	ABS	(03-10)	CAN Gateway
 A8 (4E) (03-..)	AIRBAG	(03-10)	
 A8 (4E) (03-..)	AUTOM. TRANSMISSI	(03-10)	
 A8 (4E) (03-..)	BATTERY REGULATI	(03-10)	
 A8 (4E) (03-..)	CENTRAL ELECTRIC	(03-10)	
 A8 (4E) (03-..)	CHANGE BRAKE PAD	(03-10)	
 A8 (4E) (03-..)	CHASSIS NETWORK	(03-10)	
 A8 (4E) (03-..)	CLIMA	(03-10)	
 A8 (4E) (03-..)	COLUMN/SEAT REG.	(03-10)	
 A8 (4E) (03-..)	COMFORT SYSTEM	(03-10)	
 A8 (4E) (03-..)	CONV. TOP/SUNROO	(03-10)	
 A8 (4E) (03-..)	DASHBOARD	(03-10)	
 A8 (4E) (03-..)	DISTANCE REGULATI	(03-10)	
 A8 (4E) (03-..)	DRIVER IDENT.	(03-10)	
 A8 (4E) (03-..)	DRIVER SIDE DOOR	(03-10)	
 A8 (4E) (03-..)	ELECT. CENTRAL SY	(03-10)	
 A8 (4E) (03-..)	ELECTRONIC TRIM	(03-10)	
 A8 (4E) (03-..)	EMERGENCY MODUL	(03-10)	
 A8 (4E) (03-..)	ENGINE MANAGEME	(03-10)	
 A8 (4E) (03-..)	ENGINE MANAGEME	(03-10)	
 A8 (4E) (03-..)	HEADLIGHT LEVEL	(03-10)	
 A8 (4E) (03-..)	IDENT./COMMAND U	(03-10)	
 A8 (4E) (03-..)	IND./COMMAND UNIT	(03-10)	
 A8 (4E) (03-..)	IND./COMMAND UNIT	(03-10)	
 A8 (4E) (03-..)	LEFT REAR DOOR	(03-10)	
 A8 (4E) (03-..)	MAINTENANCE	(03-10)	
 A8 (4E) (03-..)	MAINTENANCE	(03-10)	
 A8 (4E) (03-..)	MAINTENANCE	(03-10)	
 A8 (4E) (03-..)	MAINTENANCE	(03-10)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Audi

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 A8 (4E) (03-..)	MAINTENANCE	(03-10)	
 A8 (4E) (03-..)	MAINTENANCE	(03-10)	
 A8 (4E) (03-..)	MAINTENANCE	(03-10)	
 A8 (4E) (03-..)	MAINTENANCE	(03-10)	
 A8 (4E) (03-..)	MAINTENANCE	(03-10)	
 A8 (4E) (03-..)	MAINTENANCE	(03-10)	
 A8 (4E) (03-..)	MAINTENANCE	(03-10)	
 A8 (4E) (03-..)	MAINTENANCE	(03-10)	
 A8 (4E) (03-..)	MEDIA PLAYER POSI	(03-10)	
 A8 (4E) (03-..)	MEDIA PLAYER POSI	(03-10)	
 A8 (4E) (03-..)	MEDIA PLAYER POSI	(03-10)	
 A8 (4E) (03-..)	MEDIA PLAYER POSI	(03-10)	
 A8 (4E) (03-..)	NAVIGATION	(03-10)	
 A8 (4E) (03-..)	PARKING HELP	(03-10)	
 A8 (4E) (03-..)	PASS. SIDE DOOR	(03-10)	
 A8 (4E) (03-..)	PASSENGER SEAT R	(03-10)	
 A8 (4E) (03-..)	PHONE	(03-10)	
 A8 (4E) (03-..)	RADIO / CD	(03-10)	
 A8 (4E) (03-..)	REAR CLIMA	(03-10)	
 A8 (4E) (03-..)	REAR SEAT REG.	(03-10)	
 A8 (4E) (03-..)	RELEV/SWITCON	(03-10)	
 A8 (4E) (03-..)	RIGHT REAR DOOR	(03-10)	
 A8 (4E) (03-..)	SERVICE LIGHT RES	(03-10)	
 A8 (4E) (03-..)	SOUND SYSTEM	(03-10)	
 A8 (4E) (03-..)	STEERING WHEEL E	(03-10)	
 A8 (4E) (03-..)	SUPP HEATER/AUTO	(03-10)	
 A8 (4E) (03-..)	TIRE PRESSURE	(03-10)	
 A8 (4E) (03-..)	TOW FUNCTION	(03-10)	
 A8 (4E) (03-..)	TV SYSTEM	(03-10)	
 A8 (4E) (03-..)	VOICE CONTROL	(03-10)	
 Cabrio (8G) (92-00)	ABS	(92-00)	
 Cabrio (8G) (92-00)	AIRBAG	(92-00)	
 Cabrio (8G) (92-00)	AUTOM. TRANSMISSI	(92-00)	
 Cabrio (8G) (92-00)	CLIMA	(92-00)	
 Cabrio (8G) (92-00)	CONV. TOP/SUNROO	(92-00)	
 Cabrio (8G) (92-00)	ENGINE MANAGEME	(92-00)	
 Cabrio (8G) (92-00)	ENGINE MANAGEME	(92-00)	
 Cabrio (8G) (92-00)	ENGINE MANAGEME	(92-00)	
 Cabrio (8G) (92-00)	MAINTENANCE	(92-00)	
 Cabrio (8G) (92-00)	MAINTENANCE	(92-00)	
 Cabrio (8G) (92-00)	MAINTENANCE	(92-6/98)	
 Cabrio (8G) (92-00)	MAINTENANCE	(92-6/98)	
 Cabrio (8G) (92-00)	MAINTENANCE	(99-00)	
 Cabrio (8G) (92-00)	SERVICE LIGHT RES	(92-6/98)	
 Cabrio (8G) (92-00)	SERVICE LIGHT RES	(99-00)	
 Coupe' (8B) (89-96)	ABS	(89-96)	
 Coupe' (8B) (89-96)	AIRBAG	(89-96)	
 Coupe' (8B) (89-96)	AUTOM. TRANSMISSI	(89-96)	
 Coupe' (8B) (89-96)	BATTERY REGULATI	(89-96)	
 Coupe' (8B) (89-96)	CENTRAL LOCKING	(89-96)	
 Coupe' (8B) (89-96)	CLIMA	(89-96)	
 Coupe' (8B) (89-96)	DASHBOARD	(89-96)	
 Coupe' (8B) (89-96)	DRIVER SIDE DOOR	(89-96)	
 Coupe' (8B) (89-96)	ENGINE MANAGEME	(89-96)	
 Coupe' (8B) (89-96)	ENGINE MANAGEME	(89-96)	
 Coupe' (8B) (89-96)	ENGINE MANAGEME	(89-96)	
 Coupe' (8B) (89-96)	IMMOBILIZER	(89-96)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Audi

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Coupe' (8B) (89-96)	MAINTENANCE	(89-96)	
 Coupe' (8B) (89-96)	MAINTENANCE	(89-96)	
 Coupe' (8B) (89-96)	MAINTENANCE	(89-96)	
 Coupe' (8B) (89-96)	MAINTENANCE	(89-96)	
 Coupe' (8B) (89-96)	MAINTENANCE	(89-96)	
 Coupe' (8B) (89-96)	PASS. SIDE DOOR	(89-96)	
 Coupe' (8B) (89-96)	SERVICE LIGHT RES	(89-96)	
 Q3 (8U) (11-..)	ABS	(11-..)	
 Q3 (8U) (11-..)	AIRBAG	(11-..)	
 Q3 (8U) (11-..)	CHASSIS NETWORK	(11-..)	Body Computer
 Q3 (8U) (11-..)	DASHBOARD	(11-..)	
 Q3 (8U) (11-..)	DRIVER SIDE DOOR	(11-..)	
 Q3 (8U) (11-..)	ENGINE MANAGEME	2.0 TDI (11-..)	
 Q3 (8U) (11-..)	LEFT REAR DOOR	(11-..)	
 Q3 (8U) (11-..)	MAINTENANCE	(11-..)	
 Q3 (8U) (11-..)	MAINTENANCE	(11-..)	
 Q3 (8U) (11-..)	MAINTENANCE	(11-..)	
 Q3 (8U) (11-..)	PASS. SIDE DOOR	(11-..)	
 Q3 (8U) (11-..)	RIGHT REAR DOOR	(11-..)	
 Q5 (8R) (09-..)	ABS + TRACT. CONT	(09-10)	
 Q5 (8R) (09-..)	CHANGE BRAKE PAD	(09-10)	
 Q5 (8R) (09-..)	CLIMA	(09-10)	
 Q5 (8R) (09-..)	COMFORT SYSTEM	(09-10)	
 Q5 (8R) (09-..)	DASHBOARD	(09-10)	
 Q5 (8R) (09-..)	DRIVER SIDE DOOR	(09-10)	
 Q5 (8R) (09-..)	HEADLIGHT LEVEL	(09-10)	
 Q5 (8R) (09-..)	LEFT REAR DOOR	(09-10)	
 Q5 (8R) (09-..)	MAINTENANCE	(09-10)	
 Q5 (8R) (09-..)	MAINTENANCE	(09-10)	
 Q5 (8R) (09-..)	MAINTENANCE	(09-10)	
 Q5 (8R) (09-..)	MAINTENANCE	(09-10)	
 Q5 (8R) (09-..)	MAINTENANCE	(09-10)	
 Q5 (8R) (09-..)	MAINTENANCE	(09-10)	
 Q5 (8R) (09-..)	MAINTENANCE	(09-10)	
 Q5 (8R) (09-..)	MAINTENANCE	(09-10)	
 Q5 (8R) (09-..)	MAINTENANCE	(09-10)	
 Q5 (8R) (09-..)	MAINTENANCE	(09-10)	
 Q5 (8R) (09-..)	MAINTENANCE	(09-10)	
 Q5 (8R) (09-..)	MAINTENANCE	(09-10)	
 Q5 (8R) (09-..)	PASS. SIDE DOOR	(09-10)	
 Q5 (8R) (09-..)	RADIO / CD	(09-10)	
 Q5 (8R) (09-..)	RELEV/SWITCON	(09-10)	
 Q5 (8R) (09-..)	RIGHT REAR DOOR	(09-10)	
 Q5 (8R) (09-..)	SERVICE LIGHT RES	(09-10)	
 Q5 (8R) (09-..)	STEERING WHEEL E	(09-10)	
 Q7 (4L) (07-..)	ABS	(07-10)	
 Q7 (4L) (07-..)	AIRBAG	(07-10)	
 Q7 (4L) (07-..)	AUTOM. TRANSMISSI	(07-10)	
 Q7 (4L) (07-..)	BATTERY REGULATI	(07-10)	
 Q7 (4L) (07-..)	CENTRAL ELECTRIC	(07-10)	
 Q7 (4L) (07-..)	CHANGE BRAKE PAD	(07-10)	
 Q7 (4L) (07-..)	CLIMA	(07-10)	
 Q7 (4L) (07-..)	COLUMN/SEAT REG.	(07-10)	
 Q7 (4L) (07-..)	COMFORT SYSTEM	(07-10)	
 Q7 (4L) (07-..)	DASHBOARD	(07-10)	
 Q7 (4L) (07-..)	DIGITAL RADIO TUNE	(07-10)	
 Q7 (4L) (07-..)	DISTANCE REGULATI	(07-10)	
 Q7 (4L) (07-..)	DRIVER SIDE DOOR	(07-10)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Audi

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Q7 (4L) (07-..)	ELECT. CENTRAL SY	(07-10)	
 Q7 (4L) (07-..)	ELECTRONIC TRIM	(07-10)	
 Q7 (4L) (07-..)	ENGINE MANAGEME	(07-10)	
 Q7 (4L) (07-..)	ENGINE MANAGEME	(07-10)	
 Q7 (4L) (07-..)	HATCHBACK DOOR E	(07-10)	
 Q7 (4L) (07-..)	HEADLIGHT LEVEL	(07-10)	
 Q7 (4L) (07-..)	LANE MANT. ASSYST	(07-10)	
 Q7 (4L) (07-..)	LEFT REAR DOOR	(07-10)	
 Q7 (4L) (07-..)	MAINTENANCE	(07-09)	
 Q7 (4L) (07-..)	MAINTENANCE	(07-09)	
 Q7 (4L) (07-..)	MAINTENANCE	(07-09)	
 Q7 (4L) (07-..)	MAINTENANCE	(07-10)	
 Q7 (4L) (07-..)	MAINTENANCE	(07-10)	
 Q7 (4L) (07-..)	MAINTENANCE	(07-10)	
 Q7 (4L) (07-..)	MAINTENANCE	(07-10)	
 Q7 (4L) (07-..)	MAINTENANCE	(07-10)	
 Q7 (4L) (07-..)	MAINTENANCE	(07-10)	
 Q7 (4L) (07-..)	MAINTENANCE	(07-10)	
 Q7 (4L) (07-..)	MAINTENANCE	(07-10)	
 Q7 (4L) (07-..)	MAINTENANCE	(07-10)	
 Q7 (4L) (07-..)	MAINTENANCE	(09-10)	
 Q7 (4L) (07-..)	MAINTENANCE	(09-10)	
 Q7 (4L) (07-..)	MAINTENANCE	(09-10)	
 Q7 (4L) (07-..)	MAINTENANCE	(09-10)	
 Q7 (4L) (07-..)	MEDIA PLAYER POSI	(07-10)	
 Q7 (4L) (07-..)	MEDIA PLAYER POSI	(07-10)	
 Q7 (4L) (07-..)	NAVIGATION	(07-10)	
 Q7 (4L) (07-..)	PARKING HELP	(07-10)	
 Q7 (4L) (07-..)	PASS. SIDE DOOR	(07-10)	
 Q7 (4L) (07-..)	PASSENGER SEAT R	(07-10)	
 Q7 (4L) (07-..)	PHONE	(07-10)	
 Q7 (4L) (07-..)	RADIO / CD	(07-10)	
 Q7 (4L) (07-..)	REAR CLIMA	(07-10)	
 Q7 (4L) (07-..)	RELEV/SWITCON	(07-10)	
 Q7 (4L) (07-..)	RIGHT REAR DOOR	(07-10)	
 Q7 (4L) (07-..)	SERVICE LIGHT RES	(07-09)	
 Q7 (4L) (07-..)	SERVICE LIGHT RES	(09-10)	
 Q7 (4L) (07-..)	SOUND SYSTEM	(07-10)	
 Q7 (4L) (07-..)	STEERING WHEEL E	(07-10)	
 Q7 (4L) (07-..)	SUPP HEATER/AUTO	(07-10)	
 Q7 (4L) (07-..)	TIRE PRESSURE	(07-10)	
 Q7 (4L) (07-..)	TOW FUNCTION	(07-10)	
 Q7 (4L) (07-..)	TV SYSTEM	(07-10)	
 Q7 (4L) (07-..)	VOICE CONTROL	(07-10)	
 R8 (42) (07-..)	ABS	(07-..)	
 R8 (42) (07-..)	AIRBAG	(07-..)	
 R8 (42) (07-..)	AUTOM. TRANSMISSI	(07-..)	
 R8 (42) (07-..)	BATTERY REGULATI	(07-..)	
 R8 (42) (07-..)	CENTRAL ELECTRIC	(07-..)	
 R8 (42) (07-..)	CHANGE BRAKE PAD	(07-..)	
 R8 (42) (07-..)	CHASSIS NETWORK	(07-..)	CAN Gateway
 R8 (42) (07-..)	CLIMA	(07-..)	
 R8 (42) (07-..)	COLUMN/SEAT REG.	(07-..)	
 R8 (42) (07-..)	COMFORT SYSTEM	(07-..)	
 R8 (42) (07-..)	CONV. TOP/SUNROO	(07-..)	
 R8 (42) (07-..)	DASHBOARD	(07-..)	
 R8 (42) (07-..)	DISTANCE REGULATI	(07-..)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Audi

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 R8 (42) (07-..)	DRIVER IDENT.	(07-..)	
 R8 (42) (07-..)	DRIVER SIDE DOOR	(07-..)	
 R8 (42) (07-..)	ELECT. CENTRAL SY	(07-..)	
 R8 (42) (07-..)	ELECTRONIC TRIM	(07-..)	
 R8 (42) (07-..)	EMERGENCY MODUL	(07-..)	
 R8 (42) (07-..)	ENGINE MANAGEME	(07-..)	
 R8 (42) (07-..)	HEADLIGHT LEVEL	(07-..)	
 R8 (42) (07-..)	IDENT./COMMAND U	(07-..)	
 R8 (42) (07-..)	IND./COMMAND UNIT	(07-..)	
 R8 (42) (07-..)	IND./COMMAND UNIT	(07-..)	
 R8 (42) (07-..)	LEFT REAR DOOR	(07-..)	
 R8 (42) (07-..)	MAINTENANCE	(07-..)	
 R8 (42) (07-..)	MAINTENANCE	(07-..)	
 R8 (42) (07-..)	MAINTENANCE	(07-..)	
 R8 (42) (07-..)	MAINTENANCE	(07-..)	
 R8 (42) (07-..)	MAINTENANCE	(07-..)	
 R8 (42) (07-..)	MAINTENANCE	(07-..)	
 R8 (42) (07-..)	MAINTENANCE	(07-..)	
 R8 (42) (07-..)	MAINTENANCE	(07-..)	
 R8 (42) (07-..)	MAINTENANCE	(07-..)	
 R8 (42) (07-..)	MAINTENANCE	(07-..)	
 R8 (42) (07-..)	MAINTENANCE	(07-..)	
 R8 (42) (07-..)	MAINTENANCE	(07-..)	
 R8 (42) (07-..)	MAINTENANCE	(07-..)	
 R8 (42) (07-..)	MAINTENANCE	(07-..)	
 R8 (42) (07-..)	NAVIGATION	(07-..)	
 R8 (42) (07-..)	PARK.BRAKE	(07-..)	
 R8 (42) (07-..)	PARKING HELP	(07-..)	
 R8 (42) (07-..)	PASS. SIDE DOOR	(07-..)	
 R8 (42) (07-..)	PASSENGER SEAT R	(07-..)	
 R8 (42) (07-..)	PHONE	(07-..)	
 R8 (42) (07-..)	RADIO / CD	(07-..)	
 R8 (42) (07-..)	REAR CLIMA	(07-..)	
 R8 (42) (07-..)	REAR SEAT REG.	(07-..)	
 R8 (42) (07-..)	RELEV/SWITCON	(07-..)	
 R8 (42) (07-..)	RIGHT REAR DOOR	(07-..)	
 R8 (42) (07-..)	SERVICE LIGHT RES	(07-..)	
 R8 (42) (07-..)	SOUND SYSTEM	(07-..)	
 R8 (42) (07-..)	STEERING WHEEL E	(07-..)	
 R8 (42) (07-..)	SUPP HEATER/AUTO	(07-..)	
 R8 (42) (07-..)	TIRE PRESSURE	(07-..)	
 R8 (42) (07-..)	TOW FUNCTION	(07-..)	
 R8 (42) (07-..)	TV SYSTEM	(07-..)	
 R8 (42) (07-..)	VOICE CONTROL	(07-..)	
 TT (8J) (06-..)	4WD ELECTRONICS	(06-10)	
 TT (8J) (06-..)	ABS	(06-10)	
 TT (8J) (06-..)	AIRBAG	(06-10)	
 TT (8J) (06-..)	AUTOM. TRANSMISSI	(06-10)	
 TT (8J) (06-..)	CENTRAL ELECTRIC	(06-10)	
 TT (8J) (06-..)	CHASSIS NETWORK	(06-10)	CAN Gateway
 TT (8J) (06-..)	CLIMA	(06-10)	
 TT (8J) (06-..)	COMFORT SYSTEM	(06-10)	
 TT (8J) (06-..)	DASHBOARD	(06-10)	
 TT (8J) (06-..)	DIGITAL RADIO TUNE	(06-10)	
 TT (8J) (06-..)	DRIVER SIDE DOOR	(06-10)	
 TT (8J) (06-..)	ELECTRIC STEERING	(06-10)	
 TT (8J) (06-..)	ENGINE MANAGEME	(06-10)	
 TT (8J) (06-..)	ENGINE MANAGEME	2.0 TDI 125 Kw (08-10)	CBBB

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Audi

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TT (8J) (06-..)	HEADLIGHT LEVEL	(06-10)	
 TT (8J) (06-..)	IMMOBILIZER	(06-10)	
 TT (8J) (06-..)	MAINTENANCE	(06-07)	
 TT (8J) (06-..)	MAINTENANCE	(06-07)	
 TT (8J) (06-..)	MAINTENANCE	(06-07)	
 TT (8J) (06-..)	MAINTENANCE	(06-07)	
 TT (8J) (06-..)	MAINTENANCE	(06-07)	
 TT (8J) (06-..)	MAINTENANCE	(06-10)	
 TT (8J) (06-..)	MAINTENANCE	(06-10)	
 TT (8J) (06-..)	MAINTENANCE	(06-10)	
 TT (8J) (06-..)	MAINTENANCE	(06-10)	
 TT (8J) (06-..)	MAINTENANCE	(06-10)	
 TT (8J) (06-..)	MAINTENANCE	(06-10)	
 TT (8J) (06-..)	MAINTENANCE	(06-10)	
 TT (8J) (06-..)	MAINTENANCE	(08-10)	
 TT (8J) (06-..)	MAINTENANCE	(08-10)	
 TT (8J) (06-..)	MAINTENANCE	(08-10)	
 TT (8J) (06-..)	MAINTENANCE	(08-10)	
 TT (8J) (06-..)	MAINTENANCE	2.0 TDI 125 Kw (08-10)	CBBB
 TT (8J) (06-..)	MAINTENANCE	2.0 TDI 125 Kw (08-10)	CBBB
 TT (8J) (06-..)	MAINTENANCE	2.0 TDI 125 Kw (08-10)	CBBB
 TT (8J) (06-..)	NAVIGATION	(06-10)	
 TT (8J) (06-..)	PARKING HELP	(06-10)	
 TT (8J) (06-..)	PASS. SIDE DOOR	(06-10)	
 TT (8J) (06-..)	PHONE	(06-10)	
 TT (8J) (06-..)	RADIO / CD	(06-10)	
 TT (8J) (06-..)	SERVICE LIGHT RES	(06-07)	
 TT (8J) (06-..)	SERVICE LIGHT RES	(08-10)	
 TT (8J) (06-..)	SOUND SYSTEM	(06-10)	
 TT (8J) (06-..)	STEERING WHEEL E	(06-10)	
 TT (8J) (06-..)	SUSPENSION CONTR	(06-10)	
 TT (8N) (99-06)	4WD ELECTRONICS	(99-06)	
 TT (8N) (99-06)	ABS	(99-06)	
 TT (8N) (99-06)	AIRBAG	(99-06)	
 TT (8N) (99-06)	ANTITHEFT	(99-06)	
 TT (8N) (99-06)	AUTOM. TRANSMISSI	(99-06)	
 TT (8N) (99-06)	CENTRAL LOCKING	(99-06)	
 TT (8N) (99-06)	CLIMA	(99-06)	
 TT (8N) (99-06)	DASHBOARD	(99-06)	
 TT (8N) (99-06)	DIGITAL RADIO TUNE	(99-06)	
 TT (8N) (99-06)	ENGINE MANAGEME	(99-06)	
 TT (8N) (99-06)	HEADLIGHT LEVEL	(99-06)	
 TT (8N) (99-06)	IMMOBILIZER	(99-06)	
 TT (8N) (99-06)	MAINTENANCE	(99-06)	
 TT (8N) (99-06)	MAINTENANCE	(99-06)	
 TT (8N) (99-06)	MAINTENANCE	(99-06)	
 TT (8N) (99-06)	MAINTENANCE	(99-06)	
 TT (8N) (99-06)	NAVIGATION	(99-06)	
 TT (8N) (99-06)	PARKING HELP	(99-06)	
 TT (8N) (99-06)	PHONE	(99-06)	
 TT (8N) (99-06)	RADIO / CD	(99-06)	
 TT (8N) (99-06)	SERVICE LIGHT RES	(99-06)	
 V8 (4C) (91-94)	4WD ELECTRONICS	(..-03)	
 V8 (4C) (91-94)	ABS	(..-00)	ATE TEVES ABS Mk60 No ASR
 V8 (4C) (91-94)	ABS	(..-6/98)	
 V8 (4C) (91-94)	AIRBAG	(..-6/98)	
 V8 (4C) (91-94)	AUTOM. TRANSMISSI	(..-6/98)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Audi

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 V8 (4C) (91-94)	BATTERY CHARGER	(..-00)	
 V8 (4C) (91-94)	BATTERY REGULATI	(..-00)	
 V8 (4C) (91-94)	BRAKE POWER SUP	(..-00)	
 V8 (4C) (91-94)	CENTRAL LOCKING	(..-6/98)	
 V8 (4C) (91-94)	CLIMA	(..-6/98)	
 V8 (4C) (91-94)	CONV. TOP/SUNROO	(..-6/98)	
 V8 (4C) (91-94)	DASHBOARD	(..-6/98)	
 V8 (4C) (91-94)	DRIVER FOOT BOAR	(..-00)	
 V8 (4C) (91-94)	DRIVER SIDE DOOR	(..-00)	
 V8 (4C) (91-94)	ELECTRIC ACTUATIO	(..-00)	
 V8 (4C) (91-94)	ENGINE MANAGEME	(..-6/98)	
 V8 (4C) (91-94)	IMMOBILIZER	(..-6/98)	
 V8 (4C) (91-94)	LEFT REAR DOOR	(..-00)	
 V8 (4C) (91-94)	MAINTENANCE	(..-00)	ATE TEVES ABS Mk60 No ASR
 V8 (4C) (91-94)	MAINTENANCE	(..-6/98)	
 V8 (4C) (91-94)	MAINTENANCE	(..-6/98)	
 V8 (4C) (91-94)	MAINTENANCE	(..-6/98)	
 V8 (4C) (91-94)	PASS. SIDE DOOR	(..-00)	
 V8 (4C) (91-94)	PASS.FOOT BOARD	(..-00)	
 V8 (4C) (91-94)	POWER BRAKE	(..-00)	
 V8 (4C) (91-94)	RIGHT REAR DOOR	(..-00)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Autobianchi

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Y10	ELECTRONIC INJECT	1.0 Kat	BOSCH MonoJetronic A2.2
 Y10	ELECTRONIC INJECT	1.0 Kat	BOSCH MonoJetronic A2.2
 Y10	ELECTRONIC INJECT	1.0 Kat	BOSCH MonoJetronic A2.2
 Y10	ELECTRONIC INJECT	1.0 Kat	BOSCH MonoJetronic A2.2
 Y10	ELECTRONIC INJECT	1.1	BOSCH MonoJetronic A2.2
 Y10	ELECTRONIC INJECT	1.1	BOSCH MonoJetronic A2.4
 Y10	ELECTRONIC INJECT	1.1 AT	BOSCH MonoJetronic A2.4
 Y10	ELECTRONIC INJECT	1.1 Kat	BOSCH MonoJetronic A2.2
 Y10	ELECTRONIC INJECT	1.1 Kat	BOSCH MonoJetronic A2.2
 Y10	ELECTRONIC INJECT	1.1 Kat	BOSCH MonoJetronic A2.2
 Y10	ENGINE MANAGEME	1.1 4x4 Kat	BOSCH MonoMotronic MA1.7
 Y10	ENGINE MANAGEME	1.1 AT Kat	BOSCH MonoMotronic MA1.7
 Y10	ENGINE MANAGEME	1.1 Kat	BOSCH MonoMotronic MA1.7
 Y10	ENGINE MANAGEME	1.1 Kat	BOSCH MonoMotronic MA1.7

Systems supported by ECUREADER / ECUDECODER (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 1 Series (E87-E81-E82-E88	ABS + TRACT. CONT	116d (04-07)	TEVES ABS/DSC MKxx
 1 Series (E87-E81-E82-E88	ABS + TRACT. CONT	116d (07-..)	BOSCH DSC
 1 Series (E87-E81-E82-E88	ABS + TRACT. CONT	116i (04-07)	TEVES ABS/DSC MKxx
 1 Series (E87-E81-E82-E88	ABS + TRACT. CONT	116i (07-..)	BOSCH DSC
 1 Series (E87-E81-E82-E88	ABS + TRACT. CONT	118d (04-07)	TEVES ABS/DSC MKxx
 1 Series (E87-E81-E82-E88	ABS + TRACT. CONT	118d (07-..)	BOSCH DSC
 1 Series (E87-E81-E82-E88	ABS + TRACT. CONT	118i (04-07)	TEVES ABS/DSC MKxx
 1 Series (E87-E81-E82-E88	ABS + TRACT. CONT	118i (07-..)	BOSCH DSC
 1 Series (E87-E81-E82-E88	ABS + TRACT. CONT	120d (04-07)	TEVES ABS/DSC MKxx
 1 Series (E87-E81-E82-E88	ABS + TRACT. CONT	120d (07-..)	BOSCH DSC
 1 Series (E87-E81-E82-E88	ABS + TRACT. CONT	120i (04-07)	TEVES ABS/DSC Mxxx
 1 Series (E87-E81-E82-E88	ABS + TRACT. CONT	120i (07-..)	BOSCH DSC
 1 Series (E87-E81-E82-E88	ABS + TRACT. CONT	123d (04-07)	TEVES ABS/DSC MKxx
 1 Series (E87-E81-E82-E88	ABS + TRACT. CONT	123d (07-..)	BOSCH DSC
 1 Series (E87-E81-E82-E88	ABS + TRACT. CONT	125i (04-07)	TEVES ABS/DSC MKxx
 1 Series (E87-E81-E82-E88	ABS + TRACT. CONT	125i (07-..)	BOSCH DSC
 1 Series (E87-E81-E82-E88	ABS + TRACT. CONT	130i (04-07)	TEVES ABS/DSC MKxx
 1 Series (E87-E81-E82-E88	ABS + TRACT. CONT	130i (07-..)	BOSCH DSC
 1 Series (E87-E81-E82-E88	ABS + TRACT. CONT	135i (04-07)	TEVES ABS/DSC MKxx
 1 Series (E87-E81-E82-E88	ABS + TRACT. CONT	135i (07-..)	BOSCH DSC
 1 Series (E87-E81-E82-E88	AIRBAG	116d (04-07)	BOSCH SRS MRS5
 1 Series (E87-E81-E82-E88	AIRBAG	116d (07-..)	AirBag MSR5
 1 Series (E87-E81-E82-E88	AIRBAG	116i (04-07)	BOSCH SRS MRS5
 1 Series (E87-E81-E82-E88	AIRBAG	116i (07-..)	AirBag MSR5
 1 Series (E87-E81-E82-E88	AIRBAG	118d (04-07)	BOSCH SRS MRS5
 1 Series (E87-E81-E82-E88	AIRBAG	118d (07-..)	AirBag MSR5
 1 Series (E87-E81-E82-E88	AIRBAG	118i (04-07)	BOSCH SRS MRS5
 1 Series (E87-E81-E82-E88	AIRBAG	118i (07-..)	AirBag MSR5
 1 Series (E87-E81-E82-E88	AIRBAG	120d (04-07)	BOSCH SRS MRS5
 1 Series (E87-E81-E82-E88	AIRBAG	120d (07-..)	AirBag MSR5
 1 Series (E87-E81-E82-E88	AIRBAG	120i (04-07)	BOSCH SRS MRS5
 1 Series (E87-E81-E82-E88	AIRBAG	120i (07-..)	AirBag MSR5
 1 Series (E87-E81-E82-E88	AIRBAG	123d (04-07)	BOSCH SRS MRS5
 1 Series (E87-E81-E82-E88	AIRBAG	123d (07-..)	AirBag MSR5
 1 Series (E87-E81-E82-E88	AIRBAG	125i (04-07)	BOSCH SRS MRS5
 1 Series (E87-E81-E82-E88	AIRBAG	125i (07-..)	AirBag MSR5
 1 Series (E87-E81-E82-E88	AIRBAG	130i (04-07)	BOSCH SRS MRS5
 1 Series (E87-E81-E82-E88	AIRBAG	130i (07-..)	AirBag MSR5
 1 Series (E87-E81-E82-E88	AIRBAG	135i (04-07)	BOSCH SRS MRS5
 1 Series (E87-E81-E82-E88	AIRBAG	135i (07-..)	AirBag MSR5
 1 Series (E87-E81-E82-E88	CLIMA	116d (04-07)	Siemens/VDO Riscaldamento/Clima IHKA
 1 Series (E87-E81-E82-E88	CLIMA	116d (07-..)	Klimautomatik IHKA
 1 Series (E87-E81-E82-E88	CLIMA	116i (04-07)	Siemens/VDO Riscaldamento/Clima IHKA
 1 Series (E87-E81-E82-E88	CLIMA	116i (07-..)	Klimautomatik IHKA
 1 Series (E87-E81-E82-E88	CLIMA	118d (04-07)	Siemens/VDO Riscaldamento/Clima IHKA
 1 Series (E87-E81-E82-E88	CLIMA	118d (07-..)	Klimautomatik IHKA
 1 Series (E87-E81-E82-E88	CLIMA	118i (04-07)	Siemens/VDO Riscaldamento/Clima IHKA
 1 Series (E87-E81-E82-E88	CLIMA	118i (07-..)	Klimautomatik IHKA
 1 Series (E87-E81-E82-E88	CLIMA	120d (04-07)	Siemens/VDO Riscaldamento/Clima IHKA
 1 Series (E87-E81-E82-E88	CLIMA	120d (07-..)	Klimautomatik IHKA
 1 Series (E87-E81-E82-E88	CLIMA	120i (04-07)	Siemens/VDO Riscaldamento/Clima IHKA
 1 Series (E87-E81-E82-E88	CLIMA	120i (07-..)	Klimautomatik IHKA
 1 Series (E87-E81-E82-E88	CLIMA	123d (04-07)	Siemens/VDO Riscaldamento/Clima IHKA
 1 Series (E87-E81-E82-E88	CLIMA	123d (07-..)	Klimautomatik IHKA
 1 Series (E87-E81-E82-E88	CLIMA	125i (04-07)	Siemens/VDO Riscaldamento/Clima IHKA
 1 Series (E87-E81-E82-E88	CLIMA	125i (07-..)	Klimautomatik IHKA
 1 Series (E87-E81-E82-E88	CLIMA	130i (04-07)	Siemens/VDO Riscaldamento/Clima IHKA
 1 Series (E87-E81-E82-E88	CLIMA	130i (07-..)	Klimautomatik IHKA

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 1 Series (E87-E81-E82-E88)	CLIMA	135i (04-07)	Siemens/VDO Riscaldamento/Clima IHKA
 1 Series (E87-E81-E82-E88)	CLIMA	135i (07-..)	Klimautomatik IHKA
 1 Series (E87-E81-E82-E88)	CONV. TOP/SUNROO	116d (07-..)	FZD 87 CAN
 1 Series (E87-E81-E82-E88)	CONV. TOP/SUNROO	116i (07-..)	FZD 87 CAN
 1 Series (E87-E81-E82-E88)	CONV. TOP/SUNROO	118d (07-..)	FZD 87 CAN
 1 Series (E87-E81-E82-E88)	CONV. TOP/SUNROO	118i (07-..)	FZD 87 CAN
 1 Series (E87-E81-E82-E88)	CONV. TOP/SUNROO	120d (07-..)	FZD 87 CAN
 1 Series (E87-E81-E82-E88)	CONV. TOP/SUNROO	120i (07-..)	FZD 87 CAN
 1 Series (E87-E81-E82-E88)	CONV. TOP/SUNROO	123d (07-..)	FZD 87 CAN
 1 Series (E87-E81-E82-E88)	CONV. TOP/SUNROO	125i (07-..)	FZD 87 CAN
 1 Series (E87-E81-E82-E88)	CONV. TOP/SUNROO	130i (07-..)	FZD 87 CAN
 1 Series (E87-E81-E82-E88)	CONV. TOP/SUNROO	135i (07-..)	FZD 87 CAN
 1 Series (E87-E81-E82-E88)	CRUISE CONTROL	116d (07-..)	ACC 2 CAN
 1 Series (E87-E81-E82-E88)	CRUISE CONTROL	116i (07-..)	ACC 2 CAN
 1 Series (E87-E81-E82-E88)	CRUISE CONTROL	118d (07-..)	ACC 2 CAN
 1 Series (E87-E81-E82-E88)	CRUISE CONTROL	118i (07-..)	ACC 2 CAN
 1 Series (E87-E81-E82-E88)	CRUISE CONTROL	120d (07-..)	ACC 2 CAN
 1 Series (E87-E81-E82-E88)	CRUISE CONTROL	120i (07-..)	ACC 2 CAN
 1 Series (E87-E81-E82-E88)	CRUISE CONTROL	123d (07-..)	ACC 2 CAN
 1 Series (E87-E81-E82-E88)	CRUISE CONTROL	125i (07-..)	ACC 2 CAN
 1 Series (E87-E81-E82-E88)	CRUISE CONTROL	130i (07-..)	ACC 2 CAN
 1 Series (E87-E81-E82-E88)	CRUISE CONTROL	135i (07-..)	ACC 2 CAN
 1 Series (E87-E81-E82-E88)	DASHBOARD	116d (04-07)	Siemens/VDO/Borg Kombinstrum.
 1 Series (E87-E81-E82-E88)	DASHBOARD	116d (07-..)	Kombinstrument
 1 Series (E87-E81-E82-E88)	DASHBOARD	116i (04-07)	Siemens/VDO/Borg Kombinstrum.
 1 Series (E87-E81-E82-E88)	DASHBOARD	116i (07-..)	Kombinstrument
 1 Series (E87-E81-E82-E88)	DASHBOARD	118d (04-07)	Siemens/VDO/Borg Kombinstrum.
 1 Series (E87-E81-E82-E88)	DASHBOARD	118d (07-..)	Kombinstrument
 1 Series (E87-E81-E82-E88)	DASHBOARD	118i (04-07)	Siemens/VDO/Borg Kombinstrum.
 1 Series (E87-E81-E82-E88)	DASHBOARD	118i (07-..)	Kombinstrument
 1 Series (E87-E81-E82-E88)	DASHBOARD	120d (04-07)	Siemens/VDO/Borg Kombinstrum.
 1 Series (E87-E81-E82-E88)	DASHBOARD	120d (07-..)	Kombinstrument
 1 Series (E87-E81-E82-E88)	DASHBOARD	120i (04-07)	Siemens/VDO/Borg Kombinstrum.
 1 Series (E87-E81-E82-E88)	DASHBOARD	120i (07-..)	Kombinstrument
 1 Series (E87-E81-E82-E88)	DASHBOARD	123d (04-07)	Siemens/VDO/Borg Kombinstrum.
 1 Series (E87-E81-E82-E88)	DASHBOARD	123d (07-..)	Kombinstrument
 1 Series (E87-E81-E82-E88)	DASHBOARD	125i (04-07)	Siemens/VDO/Borg Kombinstrum.
 1 Series (E87-E81-E82-E88)	DASHBOARD	125i (07-..)	Kombinstrument
 1 Series (E87-E81-E82-E88)	DASHBOARD	130i (04-07)	Siemens/VDO/Borg Kombinstrum.
 1 Series (E87-E81-E82-E88)	DASHBOARD	130i (07-..)	Kombinstrument
 1 Series (E87-E81-E82-E88)	DASHBOARD	135i (04-07)	Siemens/VDO/Borg Kombinstrum.
 1 Series (E87-E81-E82-E88)	DASHBOARD	135i (07-..)	Kombinstrument
 1 Series (E87-E81-E82-E88)	ELECTRIC STEERING	116d (07-..)	EPS 90 CAN
 1 Series (E87-E81-E82-E88)	ELECTRIC STEERING	116d Active Front Steering (07-..)	AFS 70 CAN
 1 Series (E87-E81-E82-E88)	ELECTRIC STEERING	116i (07-..)	EPS 90 CAN
 1 Series (E87-E81-E82-E88)	ELECTRIC STEERING	116i Active Front Steering (07-..)	AFS 70 CAN
 1 Series (E87-E81-E82-E88)	ELECTRIC STEERING	118d (07-..)	EPS 90 CAN
 1 Series (E87-E81-E82-E88)	ELECTRIC STEERING	118d Active Front Steering (07-..)	AFS 70 CAN
 1 Series (E87-E81-E82-E88)	ELECTRIC STEERING	118i (07-..)	EPS 90 CAN
 1 Series (E87-E81-E82-E88)	ELECTRIC STEERING	118i Active Front Steering (07-..)	AFS 70 CAN
 1 Series (E87-E81-E82-E88)	ELECTRIC STEERING	120d (07-..)	EPS 90 CAN
 1 Series (E87-E81-E82-E88)	ELECTRIC STEERING	120d Active Front Steering (07-..)	AFS 70 CAN
 1 Series (E87-E81-E82-E88)	ELECTRIC STEERING	120i (07-..)	EPS 90 CAN
 1 Series (E87-E81-E82-E88)	ELECTRIC STEERING	120i Active Front Steering (07-..)	AFS 70 CAN
 1 Series (E87-E81-E82-E88)	ELECTRIC STEERING	123d (07-..)	EPS 90 CAN
 1 Series (E87-E81-E82-E88)	ELECTRIC STEERING	123d Active Front Steering (07-..)	AFS 70 CAN
 1 Series (E87-E81-E82-E88)	ELECTRIC STEERING	125i (07-..)	EPS 90 CAN
 1 Series (E87-E81-E82-E88)	ELECTRIC STEERING	125i Active Front Steering (07-..)	AFS 70 CAN

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 1 Series (E87-E81-E82-E88	ELECTRIC STEERING	130i (07-..)	EPS 90 CAN
 1 Series (E87-E81-E82-E88	ELECTRIC STEERING	130i Active Front Steering (07-..)	AFS 70 CAN
 1 Series (E87-E81-E82-E88	ELECTRIC STEERING	135i (07-..)	EPS 90 CAN
 1 Series (E87-E81-E82-E88	ELECTRIC STEERING	135i Active Front Steering (07-..)	AFS 70 CAN
 1 Series (E87-E81-E82-E88	ENGINE MANAGEME	116d (04-..)	EOBD
 1 Series (E87-E81-E82-E88	ENGINE MANAGEME	116i (04-..)	EOBD
 1 Series (E87-E81-E82-E88	ENGINE MANAGEME	116i (07-..)	MSD 80 CAN
 1 Series (E87-E81-E82-E88	ENGINE MANAGEME	118d (04-..)	EOBD
 1 Series (E87-E81-E82-E88	ENGINE MANAGEME	118i (04-..)	EOBD
 1 Series (E87-E81-E82-E88	ENGINE MANAGEME	120d (04-..)	EOBD
 1 Series (E87-E81-E82-E88	ENGINE MANAGEME	120d N47D20A (07-..)	BOSCH EDC DDE 7
 1 Series (E87-E81-E82-E88	ENGINE MANAGEME	120i (04-..)	EOBD
 1 Series (E87-E81-E82-E88	ENGINE MANAGEME	123d (04-..)	EOBD
 1 Series (E87-E81-E82-E88	ENGINE MANAGEME	125i (04-..)	EOBD
 1 Series (E87-E81-E82-E88	ENGINE MANAGEME	130i (04-..)	EOBD
 1 Series (E87-E81-E82-E88	ENGINE MANAGEME	135i (04-..)	EOBD
 1 Series (E87-E81-E82-E88	IMMOBILIZER	116d (07-..)	CAS
 1 Series (E87-E81-E82-E88	IMMOBILIZER	116i (07-..)	CAS
 1 Series (E87-E81-E82-E88	IMMOBILIZER	118d (07-..)	CAS
 1 Series (E87-E81-E82-E88	IMMOBILIZER	118i (07-..)	CAS
 1 Series (E87-E81-E82-E88	IMMOBILIZER	120d (07-..)	CAS
 1 Series (E87-E81-E82-E88	IMMOBILIZER	120i (07-..)	CAS
 1 Series (E87-E81-E82-E88	IMMOBILIZER	123d (07-..)	CAS
 1 Series (E87-E81-E82-E88	IMMOBILIZER	125i (07-..)	CAS
 1 Series (E87-E81-E82-E88	IMMOBILIZER	130i (07-..)	CAS
 1 Series (E87-E81-E82-E88	IMMOBILIZER	135i (07-..)	CAS
 1 Series (E87-E81-E82-E88	MAINTENANCE	116d (04-07)	MANUAL
 1 Series (E87-E81-E82-E88	MAINTENANCE	116i (04-07)	MANUAL
 1 Series (E87-E81-E82-E88	MAINTENANCE	118d (04-07)	MANUAL
 1 Series (E87-E81-E82-E88	MAINTENANCE	118i (04-07)	MANUAL
 1 Series (E87-E81-E82-E88	MAINTENANCE	120d (04-07)	MANUAL
 1 Series (E87-E81-E82-E88	MAINTENANCE	120i (04-07)	MANUAL
 1 Series (E87-E81-E82-E88	MAINTENANCE	123d (04-07)	MANUAL
 1 Series (E87-E81-E82-E88	MAINTENANCE	125i (04-07)	MANUAL
 1 Series (E87-E81-E82-E88	MAINTENANCE	130i (04-07)	MANUAL
 1 Series (E87-E81-E82-E88	MAINTENANCE	135i (04-07)	MANUAL
 1 Series (E87-E81-E82-E88	PARK.BRAKE	116d (07-..)	EMF 89 CAN
 1 Series (E87-E81-E82-E88	PARK.BRAKE	116i (07-..)	EMF 89 CAN
 1 Series (E87-E81-E82-E88	PARK.BRAKE	118d (07-..)	EMF 89 CAN
 1 Series (E87-E81-E82-E88	PARK.BRAKE	118i (07-..)	EMF 89 CAN
 1 Series (E87-E81-E82-E88	PARK.BRAKE	120d (07-..)	EMF 89 CAN
 1 Series (E87-E81-E82-E88	PARK.BRAKE	120i (07-..)	EMF 89 CAN
 1 Series (E87-E81-E82-E88	PARK.BRAKE	123d (07-..)	EMF 89 CAN
 1 Series (E87-E81-E82-E88	PARK.BRAKE	125i (07-..)	EMF 89 CAN
 1 Series (E87-E81-E82-E88	PARK.BRAKE	130i (07-..)	EMF 89 CAN
 1 Series (E87-E81-E82-E88	PARK.BRAKE	135i (07-..)	EMF 89 CAN
 1 Series (E87-E81-E82-E88	RADIO / CD	116d (07-..)	DAB 60 - DIGITAL RADIO CAN
 1 Series (E87-E81-E82-E88	RADIO / CD	116i (07-..)	DAB 60 - DIGITAL RADIO CAN
 1 Series (E87-E81-E82-E88	RADIO / CD	118d (07-..)	DAB 60 - DIGITAL RADIO CAN
 1 Series (E87-E81-E82-E88	RADIO / CD	118i (07-..)	DAB 60 - DIGITAL RADIO CAN
 1 Series (E87-E81-E82-E88	RADIO / CD	120d (07-..)	DAB 60 - DIGITAL RADIO CAN
 1 Series (E87-E81-E82-E88	RADIO / CD	120i (07-..)	DAB 60 - DIGITAL RADIO CAN
 1 Series (E87-E81-E82-E88	RADIO / CD	123d (07-..)	DAB 60 - DIGITAL RADIO CAN
 1 Series (E87-E81-E82-E88	RADIO / CD	125i (07-..)	DAB 60 - DIGITAL RADIO CAN
 1 Series (E87-E81-E82-E88	RADIO / CD	130i (07-..)	DAB 60 - DIGITAL RADIO CAN
 1 Series (E87-E81-E82-E88	RADIO / CD	135i (07-..)	DAB 60 - DIGITAL RADIO CAN
 1 Series (E87-E81-E82-E88	RAIN-LUMINOSITY S	116d (07-..)	RLS 87 CAN
 1 Series (E87-E81-E82-E88	RAIN-LUMINOSITY S	116i (07-..)	RLS 87 CAN

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 1 Series (E87-E81-E82-E88)	RAIN-LUMINOSITY S	118d (07-..)	RLS 87 CAN
 1 Series (E87-E81-E82-E88)	RAIN-LUMINOSITY S	118i (07-..)	RLS 87 CAN
 1 Series (E87-E81-E82-E88)	RAIN-LUMINOSITY S	120d (07-..)	RLS 87 CAN
 1 Series (E87-E81-E82-E88)	RAIN-LUMINOSITY S	120i (07-..)	RLS 87 CAN
 1 Series (E87-E81-E82-E88)	RAIN-LUMINOSITY S	123d (07-..)	RLS 87 CAN
 1 Series (E87-E81-E82-E88)	RAIN-LUMINOSITY S	125i (07-..)	RLS 87 CAN
 1 Series (E87-E81-E82-E88)	RAIN-LUMINOSITY S	130i (07-..)	RLS 87 CAN
 1 Series (E87-E81-E82-E88)	RAIN-LUMINOSITY S	135i (07-..)	RLS 87 CAN
 1 Series (E87-E81-E82-E88)	SERVICE LIGHT RES	116d (04-07)	MANUAL
 1 Series (E87-E81-E82-E88)	SERVICE LIGHT RES	116i (04-07)	MANUAL
 1 Series (E87-E81-E82-E88)	SERVICE LIGHT RES	118d (04-07)	MANUAL
 1 Series (E87-E81-E82-E88)	SERVICE LIGHT RES	118i (04-07)	MANUAL
 1 Series (E87-E81-E82-E88)	SERVICE LIGHT RES	120d (04-07)	MANUAL
 1 Series (E87-E81-E82-E88)	SERVICE LIGHT RES	120i (04-07)	MANUAL
 1 Series (E87-E81-E82-E88)	SERVICE LIGHT RES	123d (04-07)	MANUAL
 1 Series (E87-E81-E82-E88)	SERVICE LIGHT RES	125i (04-07)	MANUAL
 1 Series (E87-E81-E82-E88)	SERVICE LIGHT RES	130i (04-07)	MANUAL
 1 Series (E87-E81-E82-E88)	SERVICE LIGHT RES	135i (04-07)	MANUAL
 1 Series (E87-E81-E82-E88)	SUSPENSION CONTR	116d (07-..)	EDCK 65 CAN
 1 Series (E87-E81-E82-E88)	SUSPENSION CONTR	116i (07-..)	EDCK 65 CAN
 1 Series (E87-E81-E82-E88)	SUSPENSION CONTR	118d (07-..)	EDCK 65 CAN
 1 Series (E87-E81-E82-E88)	SUSPENSION CONTR	118i (07-..)	EDCK 65 CAN
 1 Series (E87-E81-E82-E88)	SUSPENSION CONTR	120d (07-..)	EDCK 65 CAN
 1 Series (E87-E81-E82-E88)	SUSPENSION CONTR	120i (07-..)	EDCK 65 CAN
 1 Series (E87-E81-E82-E88)	SUSPENSION CONTR	123d (07-..)	EDCK 65 CAN
 1 Series (E87-E81-E82-E88)	SUSPENSION CONTR	125i (07-..)	EDCK 65 CAN
 1 Series (E87-E81-E82-E88)	SUSPENSION CONTR	130i (07-..)	EDCK 65 CAN
 1 Series (E87-E81-E82-E88)	SUSPENSION CONTR	135i (07-..)	EDCK 65 CAN
 1 Series (E87-E81-E82-E88)	VISUAL./TELEMATIC	116d (07-..)	Info Display CID90
 1 Series (E87-E81-E82-E88)	VISUAL./TELEMATIC	116i (07-..)	Info Display CID90
 1 Series (E87-E81-E82-E88)	VISUAL./TELEMATIC	118d (07-..)	Info Display CID90
 1 Series (E87-E81-E82-E88)	VISUAL./TELEMATIC	118i (07-..)	Info Display CID90
 1 Series (E87-E81-E82-E88)	VISUAL./TELEMATIC	120d (07-..)	Info Display CID90
 1 Series (E87-E81-E82-E88)	VISUAL./TELEMATIC	120i (07-..)	Info Display CID90
 1 Series (E87-E81-E82-E88)	VISUAL./TELEMATIC	123d (07-..)	Info Display CID90
 1 Series (E87-E81-E82-E88)	VISUAL./TELEMATIC	125i (07-..)	Info Display CID90
 1 Series (E87-E81-E82-E88)	VISUAL./TELEMATIC	130i (07-..)	Info Display CID90
 1 Series (E87-E81-E82-E88)	VISUAL./TELEMATIC	135i (07-..)	Info Display CID90
 3 Series (E30) (87-94)	ENGINE MANAGEME	316i 16 4E 1 (88-94)	BOSCH Motronic DME M1.3
 3 Series (E30) (87-94)	ENGINE MANAGEME	316i 16 4E 1 (91-94)	BOSCH Motronic DME M1.7
 3 Series (E30) (87-94)	ENGINE MANAGEME	318i 18 4E 1 (87-94)	BOSCH Motronic DME M1.3
 3 Series (E30) (87-94)	ENGINE MANAGEME	318i 18 SE 1 (89-91)	BOSCH Motronic DME M1.3
 3 Series (E30) (87-94)	ENGINE MANAGEME	320i 20 6K A (87-91)	BOSCH Motronic DME M1.1
 3 Series (E30) (87-94)	ENGINE MANAGEME	320i 20 6K A (87-93)	BOSCH Motronic DME M1.3
 3 Series (E30) (87-94)	ENGINE MANAGEME	323i 16 4E 1 (88-94)	BOSCH Motronic DME M1.3
 3 Series (E30) (87-94)	ENGINE MANAGEME	323i 16 4E 1 (91-94)	BOSCH Motronic DME M1.7
 3 Series (E30) (87-94)	ENGINE MANAGEME	323i 25 6K A (87-91)	BOSCH EDC DME M1.1
 3 Series (E30) (87-94)	ENGINE MANAGEME	324d 24 6D B (88-92)	BOSCH EDC DDE 2
 3 Series (E30) (87-94)	ENGINE MANAGEME	324td 24 6T B (87-93)	BOSCH EDC DDE 1
 3 Series (E30) (87-94)	ENGINE MANAGEME	325i 25 6K 1 (87-93)	BOSCH Motronic DME M1.3
 3 Series (E30) (87-94)	ENGINE MANAGEME	325i 25 6K 1 (88-90)	BOSCH Motronic DME M1.3
 3 Series (E30) (87-94)	ENGINE MANAGEME	325i 25 6K 1 (88-93)	BOSCH Motronic DME M1.3
 3 Series (E30) (87-94)	ENGINE MANAGEME	325i 25 6K A (87-91)	BOSCH EDC DME M1.1
 3 Series (E30) (87-94)	ENGINE MANAGEME	325xi 25 6K 1 (87-92)	BOSCH Motronic DME M1.3
 3 Series (E30) (87-94)	ENGINE MANAGEME	M3 16 4E 1 (88-94)	BOSCH Motronic DME M1.3
 3 Series (E30) (87-94)	ENGINE MANAGEME	M3 16 4E 1 (91-94)	BOSCH Motronic DME M1.7
 3 Series (E30) (87-94)	MAINTENANCE	316i (.-09/00)	Service
 3 Series (E30) (87-94)	MAINTENANCE	318i (.-09/00)	Service

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 3 Series (E30) (87-94)	MAINTENANCE	320i (...-09/00)	Service
 3 Series (E30) (87-94)	MAINTENANCE	323i (...-09/00)	Service
 3 Series (E30) (87-94)	MAINTENANCE	324d (...-09/00)	Service
 3 Series (E30) (87-94)	MAINTENANCE	324td (...-09/00)	Service
 3 Series (E30) (87-94)	MAINTENANCE	325i (...-09/00)	Service
 3 Series (E30) (87-94)	MAINTENANCE	325xi (...-09/00)	Service
 3 Series (E30) (87-94)	MAINTENANCE	M3 (...-09/00)	Service
 3 Series (E30) (87-94)	SERVICE LIGHT RES	316i (...-09/00)	Service
 3 Series (E30) (87-94)	SERVICE LIGHT RES	318i (...-09/00)	Service
 3 Series (E30) (87-94)	SERVICE LIGHT RES	320i (...-09/00)	Service
 3 Series (E30) (87-94)	SERVICE LIGHT RES	323i (...-09/00)	Service
 3 Series (E30) (87-94)	SERVICE LIGHT RES	324d (...-09/00)	Service
 3 Series (E30) (87-94)	SERVICE LIGHT RES	324td (...-09/00)	Service
 3 Series (E30) (87-94)	SERVICE LIGHT RES	325i (...-09/00)	Service
 3 Series (E30) (87-94)	SERVICE LIGHT RES	325i (...-09/00)	Service
 3 Series (E30) (87-94)	SERVICE LIGHT RES	325xi (...-09/00)	Service
 3 Series (E30) (87-94)	SERVICE LIGHT RES	M3 (...-09/00)	Service
 3 Series (E36) (90-98)	ABS	316i (92-94)	ATE-TEVES ABS MkIV/3
 3 Series (E36) (90-98)	ABS	316i (95-98)	ITT-TEVES ABS Mk20-I/ERL
 3 Series (E36) (90-98)	ABS	318i (92-94)	ATE-TEVES ABS MkIV/3
 3 Series (E36) (90-98)	ABS	318i (95-98)	ITT-TEVES ABS Mk20-I/ERL
 3 Series (E36) (90-98)	ABS	318tds (92-94)	ATE-TEVES ABS MkIV/3
 3 Series (E36) (90-98)	ABS	318tds (95-98)	ITT-TEVES ABS Mk20-I/ERL
 3 Series (E36) (90-98)	ABS	320i (92-94)	ATE-TEVES ABS MkIV/3
 3 Series (E36) (90-98)	ABS	320i (95-98)	ITT-TEVES ABS Mk20-I/ERL
 3 Series (E36) (90-98)	ABS	323i (92-94)	ATE-TEVES ABS MkIV/3
 3 Series (E36) (90-98)	ABS	323i (95-98)	ITT-TEVES ABS Mk20-I/ERL
 3 Series (E36) (90-98)	ABS	325i (92-94)	ATE-TEVES ABS MkIV/3
 3 Series (E36) (90-98)	ABS	325i (95-98)	ITT-TEVES ABS Mk20-I/ERL
 3 Series (E36) (90-98)	ABS	325td (92-94)	ATE-TEVES ABS MkIV/3
 3 Series (E36) (90-98)	ABS	325td (95-98)	ITT-TEVES ABS Mk20-I/ERL
 3 Series (E36) (90-98)	ABS	325tds (92-94)	ATE-TEVES ABS MkIV/3
 3 Series (E36) (90-98)	ABS	325tds (95-98)	ITT-TEVES ABS Mk20-I/ERL
 3 Series (E36) (90-98)	ABS	328i (92-94)	ATE-TEVES ABS MkIV/3
 3 Series (E36) (90-98)	ABS	328i (95-98)	ITT-TEVES ABS Mk20-I/ERL
 3 Series (E36) (90-98)	ABS	M3 (92-94)	ATE-TEVES ABS MkIV/3
 3 Series (E36) (90-98)	ABS	M3 (95-98)	ITT-TEVES ABS Mk20-I/ERL
 3 Series (E36) (90-98)	AIRBAG	316i (95-98)	TEMIC AirBag ZAE2
 3 Series (E36) (90-98)	AIRBAG	318i (95-98)	TEMIC AirBag ZAE2
 3 Series (E36) (90-98)	AIRBAG	318tds (95-98)	TEMIC AirBag ZAE2
 3 Series (E36) (90-98)	AIRBAG	320i (95-98)	TEMIC AirBag ZAE2
 3 Series (E36) (90-98)	AIRBAG	323i (95-98)	TEMIC AirBag ZAE2
 3 Series (E36) (90-98)	AIRBAG	325i (95-98)	TEMIC AirBag ZAE2
 3 Series (E36) (90-98)	AIRBAG	325td (95-98)	TEMIC AirBag ZAE2
 3 Series (E36) (90-98)	AIRBAG	325tds (95-98)	TEMIC AirBag ZAE2
 3 Series (E36) (90-98)	AIRBAG	328i (95-98)	TEMIC AirBag ZAE2
 3 Series (E36) (90-98)	AIRBAG	M3 (95-98)	TEMIC AirBag ZAE2
 3 Series (E36) (90-98)	ENGINE MANAGEME	316i 16 4E 2 (93-96)	BOSCH Motronic DME M1.7.2
 3 Series (E36) (90-98)	ENGINE MANAGEME	316i 16 4E 2 (95-96)	BOSCH Motronic DME M1.7.3
 3 Series (E36) (90-98)	ENGINE MANAGEME	318i 18 4E 1 (90-93)	BOSCH Motronic DME M1.7
 3 Series (E36) (90-98)	ENGINE MANAGEME	318i 18 4E 2 (93-96)	BOSCH Motronic DME M1.7.2
 3 Series (E36) (90-98)	ENGINE MANAGEME	318i 18 4E 2 (95-96)	BOSCH Motronic DME M1.7.3
 3 Series (E36) (90-98)	ENGINE MANAGEME	318i 18 4S 1 (91-93)	BOSCH Motronic DME M1.7
 3 Series (E36) (90-98)	ENGINE MANAGEME	318i 18 4S 1 (93-95)	BOSCH Motronic DME M1.7.2
 3 Series (E36) (90-98)	ENGINE MANAGEME	318i 19 4S 1 (96-98)	BOSCH Motronic DME 5.2 M44
 3 Series (E36) (90-98)	ENGINE MANAGEME	318tds 17 4T 1 (94-96)	BOSCH EDC DDE 2.1
 3 Series (E36) (90-98)	ENGINE MANAGEME	320i 20 6S 1 (90-92)	BOSCH Motronic DME M3.1
 3 Series (E36) (90-98)	ENGINE MANAGEME	320i 20 6S 2 (92-96)	SIEMENS MPI DME MS 40.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 3 Series (E36) (90-98)	ENGINE MANAGEME	320i 20 6S 3 (94-96)	SIEMENS MPI DME MS 41.0
 3 Series (E36) (90-98)	ENGINE MANAGEME	323i 20 6S 1 (90-92)	BOSCH Motronic DME M3.1
 3 Series (E36) (90-98)	ENGINE MANAGEME	323i 20 6S 2 (92-96)	SIEMENS MPI DME MS 40.1
 3 Series (E36) (90-98)	ENGINE MANAGEME	323i 20 6S 3 (94-96)	SIEMENS MPI DME MS 41.0
 3 Series (E36) (90-98)	ENGINE MANAGEME	325i 20 6S 1 (90-92)	BOSCH Motronic DME M3.1
 3 Series (E36) (90-98)	ENGINE MANAGEME	325i 25 6S 2 (92-95)	BOSCH Motronic DME M3.3.1
 3 Series (E36) (90-98)	ENGINE MANAGEME	325i 25 6S 2 (92-95)	BOSCH Motronic DME M3.3.2
 3 Series (E36) (90-98)	ENGINE MANAGEME	325i 25 6S 3 (95-96)	SIEMENS MPI DME MS 41.0
 3 Series (E36) (90-98)	ENGINE MANAGEME	325td 25 6T 1 (91-95)	BOSCH EDC DDE 2
 3 Series (E36) (90-98)	ENGINE MANAGEME	325td 25 6T 1 (93-96)	BOSCH EDC DDE 2.1
 3 Series (E36) (90-98)	ENGINE MANAGEME	325td 25 6T 1 (95-96)	BOSCH EDC DDE 2.1
 3 Series (E36) (90-98)	ENGINE MANAGEME	325td 25 6T 1 (95-96)	BOSCH EDC DDE 2.1 EG-2
 3 Series (E36) (90-98)	ENGINE MANAGEME	325td 25 6T 1 (95-96)	BOSCH EDC DDE 2.1 EG-2
 3 Series (E36) (90-98)	ENGINE MANAGEME	325tds 25 6T 1 (91-95)	BOSCH EDC DDE 2
 3 Series (E36) (90-98)	ENGINE MANAGEME	325tds 25 6T 1 (93-96)	BOSCH EDC DDE 2.1
 3 Series (E36) (90-98)	ENGINE MANAGEME	325tds 25 6T 1 (95-96)	BOSCH EDC DDE 2.1
 3 Series (E36) (90-98)	ENGINE MANAGEME	325tds 25 6T 1 (95-96)	BOSCH EDC DDE 2.1 EG-2
 3 Series (E36) (90-98)	ENGINE MANAGEME	325tds 25 6T 1 (95-96)	BOSCH EDC DDE 2.1 EG-2
 3 Series (E36) (90-98)	ENGINE MANAGEME	328i 28 6S 1 (95-96)	SIEMENS MPI DME MS 41.0
 3 Series (E36) (90-98)	ENGINE MANAGEME	M3 30 6S 1 (92-95)	BOSCH Motronic DME M3.3
 3 Series (E36) (90-98)	MAINTENANCE	316i	MANUAL
 3 Series (E36) (90-98)	MAINTENANCE	316i (...-09/00)	Service
 3 Series (E36) (90-98)	MAINTENANCE	316i (92-94)	ATE-TEVES ABS MkIV/3
 3 Series (E36) (90-98)	MAINTENANCE	318i	MANUAL
 3 Series (E36) (90-98)	MAINTENANCE	318i (...-09/00)	Service
 3 Series (E36) (90-98)	MAINTENANCE	318i (92-94)	ATE-TEVES ABS MkIV/3
 3 Series (E36) (90-98)	MAINTENANCE	318tds	MANUAL
 3 Series (E36) (90-98)	MAINTENANCE	318tds (...-09/00)	Service
 3 Series (E36) (90-98)	MAINTENANCE	318tds (92-94)	ATE-TEVES ABS MkIV/3
 3 Series (E36) (90-98)	MAINTENANCE	320i	MANUAL
 3 Series (E36) (90-98)	MAINTENANCE	320i (...-09/00)	Service
 3 Series (E36) (90-98)	MAINTENANCE	320i (92-94)	ATE-TEVES ABS MkIV/3
 3 Series (E36) (90-98)	MAINTENANCE	323i	MANUAL
 3 Series (E36) (90-98)	MAINTENANCE	323i (...-09/00)	Service
 3 Series (E36) (90-98)	MAINTENANCE	323i (92-94)	ATE-TEVES ABS MkIV/3
 3 Series (E36) (90-98)	MAINTENANCE	325i	MANUAL
 3 Series (E36) (90-98)	MAINTENANCE	325i (...-09/00)	Service
 3 Series (E36) (90-98)	MAINTENANCE	325i (92-94)	ATE-TEVES ABS MkIV/3
 3 Series (E36) (90-98)	MAINTENANCE	325td	MANUAL
 3 Series (E36) (90-98)	MAINTENANCE	325td (...-09/00)	Service
 3 Series (E36) (90-98)	MAINTENANCE	325td (92-94)	ATE-TEVES ABS MkIV/3
 3 Series (E36) (90-98)	MAINTENANCE	325tds	MANUAL
 3 Series (E36) (90-98)	MAINTENANCE	325tds (...-09/00)	Service
 3 Series (E36) (90-98)	MAINTENANCE	325tds (92-94)	ATE-TEVES ABS MkIV/3
 3 Series (E36) (90-98)	MAINTENANCE	328i	MANUAL
 3 Series (E36) (90-98)	MAINTENANCE	328i (...-09/00)	Service
 3 Series (E36) (90-98)	MAINTENANCE	328i (92-94)	ATE-TEVES ABS MkIV/3
 3 Series (E36) (90-98)	MAINTENANCE	M3	MANUAL
 3 Series (E36) (90-98)	MAINTENANCE	M3 (...-09/00)	Service
 3 Series (E36) (90-98)	MAINTENANCE	M3 (92-94)	ATE-TEVES ABS MkIV/3
 3 Series (E36) (90-98)	REMOTE CONTROL E	316i	MANUAL
 3 Series (E36) (90-98)	REMOTE CONTROL E	318i	MANUAL
 3 Series (E36) (90-98)	REMOTE CONTROL E	318tds	MANUAL
 3 Series (E36) (90-98)	REMOTE CONTROL E	320i	MANUAL
 3 Series (E36) (90-98)	REMOTE CONTROL E	323i	MANUAL
 3 Series (E36) (90-98)	REMOTE CONTROL E	325i	MANUAL
 3 Series (E36) (90-98)	REMOTE CONTROL E	325td	MANUAL
 3 Series (E36) (90-98)	REMOTE CONTROL E	325tds	MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 3 Series (E36) (90-98)	REMOTE CONTROL E	328i	MANUAL
 3 Series (E36) (90-98)	REMOTE CONTROL E	M3	MANUAL
 3 Series (E36) (90-98)	SERVICE LIGHT RES	316i (...-09/00)	Service
 3 Series (E36) (90-98)	SERVICE LIGHT RES	318i (...-09/00)	Service
 3 Series (E36) (90-98)	SERVICE LIGHT RES	318tds (...-09/00)	Service
 3 Series (E36) (90-98)	SERVICE LIGHT RES	320i (...-09/00)	Service
 3 Series (E36) (90-98)	SERVICE LIGHT RES	323i (...-09/00)	Service
 3 Series (E36) (90-98)	SERVICE LIGHT RES	325i (...-09/00)	Service
 3 Series (E36) (90-98)	SERVICE LIGHT RES	325td (...-09/00)	Service
 3 Series (E36) (90-98)	SERVICE LIGHT RES	325tds (...-09/00)	Service
 3 Series (E36) (90-98)	SERVICE LIGHT RES	328i (...-09/00)	Service
 3 Series (E36) (90-98)	SERVICE LIGHT RES	M3 (...-09/00)	Service
 3 Series (E46) (98-06)	ABS	316i (98-03)	TEVES ABS Mk60
 3 Series (E46) (98-06)	ABS	318d (98-03)	TEVES ABS Mk60
 3 Series (E46) (98-06)	ABS	318i (98-03)	TEVES ABS Mk60
 3 Series (E46) (98-06)	ABS	320d (98-03)	TEVES ABS Mk60
 3 Series (E46) (98-06)	ABS	320i (98-03)	TEVES ABS Mk60
 3 Series (E46) (98-06)	ABS	323i (98-03)	TEVES ABS Mk60
 3 Series (E46) (98-06)	ABS	325i (98-03)	TEVES ABS Mk60
 3 Series (E46) (98-06)	ABS	325xi (98-03)	TEVES ABS Mk60
 3 Series (E46) (98-06)	ABS	328i (98-03)	TEVES ABS Mk60
 3 Series (E46) (98-06)	ABS	330d (98-03)	TEVES ABS Mk60
 3 Series (E46) (98-06)	ABS	330i (98-03)	TEVES ABS Mk60
 3 Series (E46) (98-06)	ABS	330xd (98-03)	TEVES ABS Mk60
 3 Series (E46) (98-06)	ABS	330xi (98-03)	TEVES ABS Mk60
 3 Series (E46) (98-06)	ABS	M3 (98-03)	TEVES ABS Mk60
 3 Series (E46) (98-06)	AIRBAG	316i (01-03)	TEMIC AirBag MRS4
 3 Series (E46) (98-06)	AIRBAG	316i (98-01)	TEMIC AirBag MRS2/3
 3 Series (E46) (98-06)	AIRBAG	318d (01-03)	TEMIC AirBag MRS4
 3 Series (E46) (98-06)	AIRBAG	318d (98-01)	TEMIC AirBag MRS2/3
 3 Series (E46) (98-06)	AIRBAG	318i (01-03)	TEMIC AirBag MRS4
 3 Series (E46) (98-06)	AIRBAG	318i (98-01)	TEMIC AirBag MRS2/3
 3 Series (E46) (98-06)	AIRBAG	320d (01-03)	TEMIC AirBag MRS4
 3 Series (E46) (98-06)	AIRBAG	320d (98-01)	TEMIC AirBag MRS2/3
 3 Series (E46) (98-06)	AIRBAG	320i (01-03)	TEMIC AirBag MRS4
 3 Series (E46) (98-06)	AIRBAG	320i (98-01)	TEMIC AirBag MRS2/3
 3 Series (E46) (98-06)	AIRBAG	323i (01-03)	TEMIC AirBag MRS4
 3 Series (E46) (98-06)	AIRBAG	323i (98-01)	TEMIC AirBag MRS2/3
 3 Series (E46) (98-06)	AIRBAG	325i (01-03)	TEMIC AirBag MRS4
 3 Series (E46) (98-06)	AIRBAG	325i (98-01)	TEMIC AirBag MRS2/3
 3 Series (E46) (98-06)	AIRBAG	325xi (01-03)	TEMIC AirBag MRS4
 3 Series (E46) (98-06)	AIRBAG	325xi (98-01)	TEMIC AirBag MRS2/3
 3 Series (E46) (98-06)	AIRBAG	328i (01-03)	TEMIC AirBag MRS4
 3 Series (E46) (98-06)	AIRBAG	328i (98-01)	TEMIC AirBag MRS2/3
 3 Series (E46) (98-06)	AIRBAG	330d (01-03)	TEMIC AirBag MRS4
 3 Series (E46) (98-06)	AIRBAG	330d (98-01)	TEMIC AirBag MRS2/3
 3 Series (E46) (98-06)	AIRBAG	330i (01-03)	TEMIC AirBag MRS4
 3 Series (E46) (98-06)	AIRBAG	330i (98-01)	TEMIC AirBag MRS2/3
 3 Series (E46) (98-06)	AIRBAG	330xd (01-03)	TEMIC AirBag MRS4
 3 Series (E46) (98-06)	AIRBAG	330xd (98-01)	TEMIC AirBag MRS2/3
 3 Series (E46) (98-06)	AIRBAG	330xi (01-03)	TEMIC AirBag MRS4
 3 Series (E46) (98-06)	AIRBAG	330xi (98-01)	TEMIC AirBag MRS2/3
 3 Series (E46) (98-06)	AIRBAG	M3 (01-03)	TEMIC AirBag MRS4
 3 Series (E46) (98-06)	AIRBAG	M3 (98-01)	TEMIC AirBag MRS2/3
 3 Series (E46) (98-06)	AUTOM. TRANSMISSI	316i (01-03)	EGS GS20
 3 Series (E46) (98-06)	AUTOM. TRANSMISSI	318d (01-03)	EGS GS20
 3 Series (E46) (98-06)	AUTOM. TRANSMISSI	318i (01-03)	EGS GS20
 3 Series (E46) (98-06)	AUTOM. TRANSMISSI	320d (01-03)	EGS GS20

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 3 Series (E46) (98-06)	AUTOM. TRANSMISSI	320i (01-03)	EGS GS20
 3 Series (E46) (98-06)	AUTOM. TRANSMISSI	323i (01-03)	EGS GS20
 3 Series (E46) (98-06)	AUTOM. TRANSMISSI	325i (01-03)	EGS GS20
 3 Series (E46) (98-06)	AUTOM. TRANSMISSI	325xi (01-03)	EGS GS20
 3 Series (E46) (98-06)	AUTOM. TRANSMISSI	328i (01-03)	EGS GS20
 3 Series (E46) (98-06)	AUTOM. TRANSMISSI	330d (01-03)	EGS GS20
 3 Series (E46) (98-06)	AUTOM. TRANSMISSI	330i (01-03)	EGS GS20
 3 Series (E46) (98-06)	AUTOM. TRANSMISSI	330xd (01-03)	EGS GS20
 3 Series (E46) (98-06)	AUTOM. TRANSMISSI	330xi (01-03)	EGS GS20
 3 Series (E46) (98-06)	AUTOM. TRANSMISSI	M3 (01-03)	EGS GS20
 3 Series (E46) (98-06)	CHASSIS NETWORK	316i (98-04)	ZKE Body Computer
 3 Series (E46) (98-06)	CHASSIS NETWORK	318d (98-04)	ZKE Body Computer
 3 Series (E46) (98-06)	CHASSIS NETWORK	318i (98-04)	ZKE Body Computer
 3 Series (E46) (98-06)	CHASSIS NETWORK	320d (98-04)	ZKE Body Computer
 3 Series (E46) (98-06)	CHASSIS NETWORK	320i (98-04)	ZKE Body Computer
 3 Series (E46) (98-06)	CHASSIS NETWORK	323i (98-04)	ZKE Body Computer
 3 Series (E46) (98-06)	CHASSIS NETWORK	325i (98-04)	ZKE Body Computer
 3 Series (E46) (98-06)	CHASSIS NETWORK	325xi (98-04)	ZKE Body Computer
 3 Series (E46) (98-06)	CHASSIS NETWORK	328i (98-04)	ZKE Body Computer
 3 Series (E46) (98-06)	CHASSIS NETWORK	330d (98-04)	ZKE Body Computer
 3 Series (E46) (98-06)	CHASSIS NETWORK	330i (98-04)	ZKE Body Computer
 3 Series (E46) (98-06)	CHASSIS NETWORK	330xd (98-04)	ZKE Body Computer
 3 Series (E46) (98-06)	CHASSIS NETWORK	330xi (98-04)	ZKE Body Computer
 3 Series (E46) (98-06)	CHASSIS NETWORK	M3 (98-04)	ZKE Body Computer
 3 Series (E46) (98-06)	CLIMA	316i (98-04)	BEHR/HELLA Klima
 3 Series (E46) (98-06)	CLIMA	318d (98-04)	BEHR/HELLA Klima
 3 Series (E46) (98-06)	CLIMA	318i (98-04)	BEHR/HELLA Klima
 3 Series (E46) (98-06)	CLIMA	320d (98-04)	BEHR/HELLA Klima
 3 Series (E46) (98-06)	CLIMA	320i (98-04)	BEHR/HELLA Klima
 3 Series (E46) (98-06)	CLIMA	323i (98-04)	BEHR/HELLA Klima
 3 Series (E46) (98-06)	CLIMA	325i (98-04)	BEHR/HELLA Klima
 3 Series (E46) (98-06)	CLIMA	325xi (98-04)	BEHR/HELLA Klima
 3 Series (E46) (98-06)	CLIMA	328i (98-04)	BEHR/HELLA Klima
 3 Series (E46) (98-06)	CLIMA	330d (98-04)	BEHR/HELLA Klima
 3 Series (E46) (98-06)	CLIMA	330i (98-04)	BEHR/HELLA Klima
 3 Series (E46) (98-06)	CLIMA	330xd (98-04)	BEHR/HELLA Klima
 3 Series (E46) (98-06)	CLIMA	330xi (98-04)	BEHR/HELLA Klima
 3 Series (E46) (98-06)	CLIMA	M3 (98-04)	BEHR/HELLA Klima
 3 Series (E46) (98-06)	DASHBOARD	316i (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	DASHBOARD	318d (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	DASHBOARD	318i (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	DASHBOARD	320d (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	DASHBOARD	320i (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	DASHBOARD	323i (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	DASHBOARD	325i (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	DASHBOARD	325xi (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	DASHBOARD	328i (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	DASHBOARD	330d (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	DASHBOARD	330i (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	DASHBOARD	330xd (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	DASHBOARD	330xi (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	DASHBOARD	M3 (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	ENGINE MANAGEME	316i 16 4E 3 (98-04)	SIEMENS MPI DME MS46
 3 Series (E46) (98-06)	ENGINE MANAGEME	318d (04-06)	EOBD
 3 Series (E46) (98-06)	ENGINE MANAGEME	318d 20 4D 1 (00-02)	BOSCH EDC 15 M DDE 3.0
 3 Series (E46) (98-06)	ENGINE MANAGEME	318i 19 4E 1 (98-04)	SIEMENS MPI DME MS46
 3 Series (E46) (98-06)	ENGINE MANAGEME	320d (04-06)	EOBD
 3 Series (E46) (98-06)	ENGINE MANAGEME	320d 20 4D 1 (98-01)	BOSCH EDC 15 M DDE 3.0

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 3 Series (E46) (98-06)	ENGINE MANAGEME	320d 20 4D 4 (02-06)	BOSCH Motronic DDE 5.0
 3 Series (E46) (98-06)	ENGINE MANAGEME	320i (00-04)	SIEMENS MPI DME MS 43.0
 3 Series (E46) (98-06)	ENGINE MANAGEME	323i (01-06)	EOBD
 3 Series (E46) (98-06)	ENGINE MANAGEME	325i (00-04)	SIEMENS MPI DME MS 43.0
 3 Series (E46) (98-06)	ENGINE MANAGEME	325i (01-06)	EOBD
 3 Series (E46) (98-06)	ENGINE MANAGEME	325xi (01-06)	EOBD
 3 Series (E46) (98-06)	ENGINE MANAGEME	328i (01-06)	EOBD
 3 Series (E46) (98-06)	ENGINE MANAGEME	330d 30 6D 1 (98-04)	BOSCH EDC 15 C4 DDE 4.0
 3 Series (E46) (98-06)	ENGINE MANAGEME	330i (01-06)	EOBD
 3 Series (E46) (98-06)	ENGINE MANAGEME	330i 30 6S 3 (00-04)	SIEMENS MPI DME MS 43.0
 3 Series (E46) (98-06)	ENGINE MANAGEME	330xd (04-06)	EOBD
 3 Series (E46) (98-06)	ENGINE MANAGEME	330xi (01-06)	EOBD
 3 Series (E46) (98-06)	ENGINE MANAGEME	330xi 30 6S 3 (00-04)	SIEMENS MPI DME MS 43.0
 3 Series (E46) (98-06)	ENGINE MANAGEME	M3 (01-06)	EOBD
 3 Series (E46) (98-06)	HEADLIGHT LEVEL	316i (98-04)	Siemens LSZ
 3 Series (E46) (98-06)	HEADLIGHT LEVEL	318d (98-04)	Siemens LSZ
 3 Series (E46) (98-06)	HEADLIGHT LEVEL	318i (98-04)	Siemens LSZ
 3 Series (E46) (98-06)	HEADLIGHT LEVEL	320d (98-04)	Siemens LSZ
 3 Series (E46) (98-06)	HEADLIGHT LEVEL	320i (98-04)	Siemens LSZ
 3 Series (E46) (98-06)	HEADLIGHT LEVEL	323i (98-04)	Siemens LSZ
 3 Series (E46) (98-06)	HEADLIGHT LEVEL	325i (98-04)	Siemens LSZ
 3 Series (E46) (98-06)	HEADLIGHT LEVEL	325xi (98-04)	Siemens LSZ
 3 Series (E46) (98-06)	HEADLIGHT LEVEL	328i (98-04)	Siemens LSZ
 3 Series (E46) (98-06)	HEADLIGHT LEVEL	330d (98-04)	Siemens LSZ
 3 Series (E46) (98-06)	HEADLIGHT LEVEL	330i (98-04)	Siemens LSZ
 3 Series (E46) (98-06)	HEADLIGHT LEVEL	330xd (98-04)	Siemens LSZ
 3 Series (E46) (98-06)	HEADLIGHT LEVEL	330xi (98-04)	Siemens LSZ
 3 Series (E46) (98-06)	HEADLIGHT LEVEL	M3 (98-04)	Siemens LSZ
 3 Series (E46) (98-06)	IMMOBILIZER	316i (01-03)	Immobilizer EWSIII
 3 Series (E46) (98-06)	IMMOBILIZER	318d (01-03)	Immobilizer EWSIII
 3 Series (E46) (98-06)	IMMOBILIZER	318i (01-03)	Immobilizer EWSIII
 3 Series (E46) (98-06)	IMMOBILIZER	320d (01-03)	Immobilizer EWSIII
 3 Series (E46) (98-06)	IMMOBILIZER	320i (01-03)	Immobilizer EWSIII
 3 Series (E46) (98-06)	IMMOBILIZER	323i (01-03)	Immobilizer EWSIII
 3 Series (E46) (98-06)	IMMOBILIZER	325i (01-03)	Immobilizer EWSIII
 3 Series (E46) (98-06)	IMMOBILIZER	325xi (01-03)	Immobilizer EWSIII
 3 Series (E46) (98-06)	IMMOBILIZER	328i (01-03)	Immobilizer EWSIII
 3 Series (E46) (98-06)	IMMOBILIZER	330d (01-03)	Immobilizer EWSIII
 3 Series (E46) (98-06)	IMMOBILIZER	330i (01-03)	Immobilizer EWSIII
 3 Series (E46) (98-06)	IMMOBILIZER	330xd (01-03)	Immobilizer EWSIII
 3 Series (E46) (98-06)	IMMOBILIZER	330xi (01-03)	Immobilizer EWSIII
 3 Series (E46) (98-06)	IMMOBILIZER	M3 (01-03)	Immobilizer EWSIII
 3 Series (E46) (98-06)	MAINTENANCE	316i (.-09/00)	Service
 3 Series (E46) (98-06)	MAINTENANCE	316i (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	316i (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	316i (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	316i (09/00-..)	MANUAL
 3 Series (E46) (98-06)	MAINTENANCE	316i (98-04)	MANUAL
 3 Series (E46) (98-06)	MAINTENANCE	318d (.-09/00)	Service
 3 Series (E46) (98-06)	MAINTENANCE	318d (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	318d (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	318d (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	318d (09/00-..)	MANUAL
 3 Series (E46) (98-06)	MAINTENANCE	318d (98-04)	MANUAL
 3 Series (E46) (98-06)	MAINTENANCE	318i (.-09/00)	Service
 3 Series (E46) (98-06)	MAINTENANCE	318i (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	318i (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	318i (01-03)	Kombinstrum.+Service

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 3 Series (E46) (98-06)	MAINTENANCE	318i (09/00-..)	MANUAL
 3 Series (E46) (98-06)	MAINTENANCE	318i (98-04)	MANUAL
 3 Series (E46) (98-06)	MAINTENANCE	320d (...-09/00)	Service
 3 Series (E46) (98-06)	MAINTENANCE	320d (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	320d (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	320d (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	320d (09/00-..)	MANUAL
 3 Series (E46) (98-06)	MAINTENANCE	320d (98-04)	MANUAL
 3 Series (E46) (98-06)	MAINTENANCE	320d 20 4D 4 (02-06)	BOSCH Motronic DDE 5.0
 3 Series (E46) (98-06)	MAINTENANCE	320i (...-09/00)	Service
 3 Series (E46) (98-06)	MAINTENANCE	320i (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	320i (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	320i (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	320i (09/00-..)	MANUAL
 3 Series (E46) (98-06)	MAINTENANCE	320i (98-04)	MANUAL
 3 Series (E46) (98-06)	MAINTENANCE	323i (...-09/00)	Service
 3 Series (E46) (98-06)	MAINTENANCE	323i (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	323i (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	323i (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	323i (09/00-..)	MANUAL
 3 Series (E46) (98-06)	MAINTENANCE	323i (98-04)	MANUAL
 3 Series (E46) (98-06)	MAINTENANCE	325i (...-09/00)	Service
 3 Series (E46) (98-06)	MAINTENANCE	325i (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	325i (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	325i (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	325i (09/00-..)	MANUAL
 3 Series (E46) (98-06)	MAINTENANCE	325i (98-04)	MANUAL
 3 Series (E46) (98-06)	MAINTENANCE	325xi (...-09/00)	Service
 3 Series (E46) (98-06)	MAINTENANCE	325xi (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	325xi (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	325xi (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	325xi (09/00-..)	MANUAL
 3 Series (E46) (98-06)	MAINTENANCE	325xi (98-04)	MANUAL
 3 Series (E46) (98-06)	MAINTENANCE	328i (...-09/00)	Service
 3 Series (E46) (98-06)	MAINTENANCE	328i (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	328i (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	328i (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	328i (09/00-..)	MANUAL
 3 Series (E46) (98-06)	MAINTENANCE	328i (98-04)	MANUAL
 3 Series (E46) (98-06)	MAINTENANCE	330d (...-09/00)	Service
 3 Series (E46) (98-06)	MAINTENANCE	330d (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	330d (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	330d (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	330d (09/00-..)	MANUAL
 3 Series (E46) (98-06)	MAINTENANCE	330d (98-04)	MANUAL
 3 Series (E46) (98-06)	MAINTENANCE	330i (...-09/00)	Service
 3 Series (E46) (98-06)	MAINTENANCE	330i (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	330i (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	330i (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	330i (09/00-..)	MANUAL
 3 Series (E46) (98-06)	MAINTENANCE	330i (98-04)	MANUAL
 3 Series (E46) (98-06)	MAINTENANCE	330xd (...-09/00)	Service
 3 Series (E46) (98-06)	MAINTENANCE	330xd (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	330xd (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	330xd (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	330xd (09/00-..)	MANUAL
 3 Series (E46) (98-06)	MAINTENANCE	330xd (98-04)	MANUAL
 3 Series (E46) (98-06)	MAINTENANCE	330xi (...-09/00)	Service

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 3 Series (E46) (98-06)	MAINTENANCE	330xi (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	330xi (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	330xi (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	330xi (09/00-..)	MANUAL
 3 Series (E46) (98-06)	MAINTENANCE	330xi (98-04)	MANUAL
 3 Series (E46) (98-06)	MAINTENANCE	M3 (.-09/00)	Service
 3 Series (E46) (98-06)	MAINTENANCE	M3 (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	M3 (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	M3 (01-03)	Kombinstrum.+Service
 3 Series (E46) (98-06)	MAINTENANCE	M3 (09/00-..)	MANUAL
 3 Series (E46) (98-06)	MAINTENANCE	M3 (98-04)	MANUAL
 3 Series (E46) (98-06)	NAVIGATION	316i (01-04)	NAV
 3 Series (E46) (98-06)	NAVIGATION	318d (01-04)	NAV
 3 Series (E46) (98-06)	NAVIGATION	318i (01-04)	NAV
 3 Series (E46) (98-06)	NAVIGATION	320d (01-04)	NAV
 3 Series (E46) (98-06)	NAVIGATION	320i (01-04)	NAV
 3 Series (E46) (98-06)	NAVIGATION	323i (01-04)	NAV
 3 Series (E46) (98-06)	NAVIGATION	325i (01-04)	NAV
 3 Series (E46) (98-06)	NAVIGATION	325xi (01-04)	NAV
 3 Series (E46) (98-06)	NAVIGATION	328i (01-04)	NAV
 3 Series (E46) (98-06)	NAVIGATION	330d (01-04)	NAV
 3 Series (E46) (98-06)	NAVIGATION	330i (01-04)	NAV
 3 Series (E46) (98-06)	NAVIGATION	330xd (01-04)	NAV
 3 Series (E46) (98-06)	NAVIGATION	330xi (01-04)	NAV
 3 Series (E46) (98-06)	NAVIGATION	M3 (01-04)	NAV
 3 Series (E46) (98-06)	RAIN-LUMINOSITY S	316i (98-04)	RLS
 3 Series (E46) (98-06)	RAIN-LUMINOSITY S	318d (98-04)	RLS
 3 Series (E46) (98-06)	RAIN-LUMINOSITY S	318i (98-04)	RLS
 3 Series (E46) (98-06)	RAIN-LUMINOSITY S	320d (98-04)	RLS
 3 Series (E46) (98-06)	RAIN-LUMINOSITY S	320i (98-04)	RLS
 3 Series (E46) (98-06)	RAIN-LUMINOSITY S	323i (98-04)	RLS
 3 Series (E46) (98-06)	RAIN-LUMINOSITY S	325i (98-04)	RLS
 3 Series (E46) (98-06)	RAIN-LUMINOSITY S	325xi (98-04)	RLS
 3 Series (E46) (98-06)	RAIN-LUMINOSITY S	328i (98-04)	RLS
 3 Series (E46) (98-06)	RAIN-LUMINOSITY S	330d (98-04)	RLS
 3 Series (E46) (98-06)	RAIN-LUMINOSITY S	330i (98-04)	RLS
 3 Series (E46) (98-06)	RAIN-LUMINOSITY S	330xd (98-04)	RLS
 3 Series (E46) (98-06)	RAIN-LUMINOSITY S	330xi (98-04)	RLS
 3 Series (E46) (98-06)	RAIN-LUMINOSITY S	M3 (98-04)	RLS
 3 Series (E46) (98-06)	REMOTE CONTROL E	316i (98-04)	MANUAL
 3 Series (E46) (98-06)	REMOTE CONTROL E	318d (98-04)	MANUAL
 3 Series (E46) (98-06)	REMOTE CONTROL E	318i (98-04)	MANUAL
 3 Series (E46) (98-06)	REMOTE CONTROL E	320d (98-04)	MANUAL
 3 Series (E46) (98-06)	REMOTE CONTROL E	320i (98-04)	MANUAL
 3 Series (E46) (98-06)	REMOTE CONTROL E	323i (98-04)	MANUAL
 3 Series (E46) (98-06)	REMOTE CONTROL E	325i (98-04)	MANUAL
 3 Series (E46) (98-06)	REMOTE CONTROL E	325xi (98-04)	MANUAL
 3 Series (E46) (98-06)	REMOTE CONTROL E	328i (98-04)	MANUAL
 3 Series (E46) (98-06)	REMOTE CONTROL E	330d (98-04)	MANUAL
 3 Series (E46) (98-06)	REMOTE CONTROL E	330i (98-04)	MANUAL
 3 Series (E46) (98-06)	REMOTE CONTROL E	330xd (98-04)	MANUAL
 3 Series (E46) (98-06)	REMOTE CONTROL E	330xi (98-04)	MANUAL
 3 Series (E46) (98-06)	REMOTE CONTROL E	M3 (98-04)	MANUAL
 3 Series (E46) (98-06)	SERVICE LIGHT RES	316i (.-09/00)	Service
 3 Series (E46) (98-06)	SERVICE LIGHT RES	316i (09/00-..)	MANUAL
 3 Series (E46) (98-06)	SERVICE LIGHT RES	318d (.-09/00)	Service
 3 Series (E46) (98-06)	SERVICE LIGHT RES	318d (09/00-..)	MANUAL
 3 Series (E46) (98-06)	SERVICE LIGHT RES	318i (.-09/00)	Service

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 3 Series (E46) (98-06)	SERVICE LIGHT RES	318i (09/00-..)	MANUAL
 3 Series (E46) (98-06)	SERVICE LIGHT RES	320d (...-09/00)	Service
 3 Series (E46) (98-06)	SERVICE LIGHT RES	320d (09/00-..)	MANUAL
 3 Series (E46) (98-06)	SERVICE LIGHT RES	320i (...-09/00)	Service
 3 Series (E46) (98-06)	SERVICE LIGHT RES	320i (09/00-..)	MANUAL
 3 Series (E46) (98-06)	SERVICE LIGHT RES	323i (...-09/00)	Service
 3 Series (E46) (98-06)	SERVICE LIGHT RES	323i (09/00-..)	MANUAL
 3 Series (E46) (98-06)	SERVICE LIGHT RES	325i (...-09/00)	Service
 3 Series (E46) (98-06)	SERVICE LIGHT RES	325i (09/00-..)	MANUAL
 3 Series (E46) (98-06)	SERVICE LIGHT RES	325xi (...-09/00)	Service
 3 Series (E46) (98-06)	SERVICE LIGHT RES	325xi (09/00-..)	MANUAL
 3 Series (E46) (98-06)	SERVICE LIGHT RES	328i (...-09/00)	Service
 3 Series (E46) (98-06)	SERVICE LIGHT RES	328i (09/00-..)	MANUAL
 3 Series (E46) (98-06)	SERVICE LIGHT RES	330d (...-09/00)	Service
 3 Series (E46) (98-06)	SERVICE LIGHT RES	330d (09/00-..)	MANUAL
 3 Series (E46) (98-06)	SERVICE LIGHT RES	330i (...-09/00)	Service
 3 Series (E46) (98-06)	SERVICE LIGHT RES	330i (09/00-..)	MANUAL
 3 Series (E46) (98-06)	SERVICE LIGHT RES	330xd (...-09/00)	Service
 3 Series (E46) (98-06)	SERVICE LIGHT RES	330xd (09/00-..)	MANUAL
 3 Series (E46) (98-06)	SERVICE LIGHT RES	330xi (...-09/00)	Service
 3 Series (E46) (98-06)	SERVICE LIGHT RES	330xi (09/00-..)	MANUAL
 3 Series (E46) (98-06)	SERVICE LIGHT RES	M3 (...-09/00)	Service
 3 Series (E46) (98-06)	SERVICE LIGHT RES	M3 (09/00-..)	MANUAL
 3 Series (E46) (98-06)	STEERING COLUMN	316i (98-04)	KOSTAL LWS
 3 Series (E46) (98-06)	STEERING COLUMN	318d (98-04)	KOSTAL LWS
 3 Series (E46) (98-06)	STEERING COLUMN	318i (98-04)	KOSTAL LWS
 3 Series (E46) (98-06)	STEERING COLUMN	320d (98-04)	KOSTAL LWS
 3 Series (E46) (98-06)	STEERING COLUMN	320i (98-04)	KOSTAL LWS
 3 Series (E46) (98-06)	STEERING COLUMN	323i (98-04)	KOSTAL LWS
 3 Series (E46) (98-06)	STEERING COLUMN	325i (98-04)	KOSTAL LWS
 3 Series (E46) (98-06)	STEERING COLUMN	325xi (98-04)	KOSTAL LWS
 3 Series (E46) (98-06)	STEERING COLUMN	328i (98-04)	KOSTAL LWS
 3 Series (E46) (98-06)	STEERING COLUMN	330d (98-04)	KOSTAL LWS
 3 Series (E46) (98-06)	STEERING COLUMN	330i (98-04)	KOSTAL LWS
 3 Series (E46) (98-06)	STEERING COLUMN	330xd (98-04)	KOSTAL LWS
 3 Series (E46) (98-06)	STEERING COLUMN	330xi (98-04)	KOSTAL LWS
 3 Series (E46) (98-06)	STEERING COLUMN	M3 (98-04)	KOSTAL LWS
 3 Series (E46) (98-06)	STEERING WHEEL E	316i (98-04)	MFL
 3 Series (E46) (98-06)	STEERING WHEEL E	318d (98-04)	MFL
 3 Series (E46) (98-06)	STEERING WHEEL E	318i (98-04)	MFL
 3 Series (E46) (98-06)	STEERING WHEEL E	320d (98-04)	MFL
 3 Series (E46) (98-06)	STEERING WHEEL E	320i (98-04)	MFL
 3 Series (E46) (98-06)	STEERING WHEEL E	323i (98-04)	MFL
 3 Series (E46) (98-06)	STEERING WHEEL E	325i (98-04)	MFL
 3 Series (E46) (98-06)	STEERING WHEEL E	325xi (98-04)	MFL
 3 Series (E46) (98-06)	STEERING WHEEL E	328i (98-04)	MFL
 3 Series (E46) (98-06)	STEERING WHEEL E	330d (98-04)	MFL
 3 Series (E46) (98-06)	STEERING WHEEL E	330i (98-04)	MFL
 3 Series (E46) (98-06)	STEERING WHEEL E	330xd (98-04)	MFL
 3 Series (E46) (98-06)	STEERING WHEEL E	330xi (98-04)	MFL
 3 Series (E46) (98-06)	STEERING WHEEL E	M3 (98-04)	MFL
 3 Series (E46) (98-06)	VISUAL./TELEMATIC	316i (98-04)	Alpine BM
 3 Series (E46) (98-06)	VISUAL./TELEMATIC	318d (98-04)	Alpine BM
 3 Series (E46) (98-06)	VISUAL./TELEMATIC	318i (98-04)	Alpine BM
 3 Series (E46) (98-06)	VISUAL./TELEMATIC	320d (98-04)	Alpine BM
 3 Series (E46) (98-06)	VISUAL./TELEMATIC	320i (98-04)	Alpine BM
 3 Series (E46) (98-06)	VISUAL./TELEMATIC	323i (98-04)	Alpine BM
 3 Series (E46) (98-06)	VISUAL./TELEMATIC	325i (98-04)	Alpine BM

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 3 Series (E46) (98-06)	VISUAL./TELEMATIC	325xi (98-04)	Alpine BM
 3 Series (E46) (98-06)	VISUAL./TELEMATIC	328i (98-04)	Alpine BM
 3 Series (E46) (98-06)	VISUAL./TELEMATIC	330d (98-04)	Alpine BM
 3 Series (E46) (98-06)	VISUAL./TELEMATIC	330i (98-04)	Alpine BM
 3 Series (E46) (98-06)	VISUAL./TELEMATIC	330xd (98-04)	Alpine BM
 3 Series (E46) (98-06)	VISUAL./TELEMATIC	330xi (98-04)	Alpine BM
 3 Series (E46) (98-06)	VISUAL./TELEMATIC	M3 (98-04)	Alpine BM
 3 Series (E90-E91-E92-E93)	ABS + TRACT. CONT	316i (04-07)	TEVES ABS/DSC MKxx
 3 Series (E90-E91-E92-E93)	ABS + TRACT. CONT	318d (04-07)	TEVES ABS/DSC Mkxx
 3 Series (E90-E91-E92-E93)	ABS + TRACT. CONT	318i (04-07)	TEVES ABS/DSC Mkxx
 3 Series (E90-E91-E92-E93)	ABS + TRACT. CONT	320d (04-07)	TEVES ABS/DSC Mkxx
 3 Series (E90-E91-E92-E93)	ABS + TRACT. CONT	320i (04-07)	TEVES ABS/DSC Mkxx
 3 Series (E90-E91-E92-E93)	ABS + TRACT. CONT	320xd (04-07)	TEVES ABS/DSC Mkxx
 3 Series (E90-E91-E92-E93)	ABS + TRACT. CONT	323i (04-07)	TEVES ABS/DSC MKxx
 3 Series (E90-E91-E92-E93)	ABS + TRACT. CONT	325d (04-07)	TEVES ABS/DSC Mkxx
 3 Series (E90-E91-E92-E93)	ABS + TRACT. CONT	325i (04-07)	TEVES ABS/DSC Mkxx
 3 Series (E90-E91-E92-E93)	ABS + TRACT. CONT	325xi (04-07)	TEVES ABS/DSC Mkxx
 3 Series (E90-E91-E92-E93)	ABS + TRACT. CONT	330d (04-07)	TEVES ABS/DSC Mkxx
 3 Series (E90-E91-E92-E93)	ABS + TRACT. CONT	330i (04-07)	TEVES ABS/DSC MKxx
 3 Series (E90-E91-E92-E93)	ABS + TRACT. CONT	330xd (04-07)	TEVES ABS/DSC MKxx
 3 Series (E90-E91-E92-E93)	ABS + TRACT. CONT	330xi (04-07)	TEVES ABS/DSC Mkxx
 3 Series (E90-E91-E92-E93)	ABS + TRACT. CONT	335d (04-07)	TEVES ABS/DSC MKxx
 3 Series (E90-E91-E92-E93)	ABS + TRACT. CONT	335i (04-07)	TEVES ABS/DSC MKxx
 3 Series (E90-E91-E92-E93)	ABS + TRACT. CONT	335xi (04-07)	TEVES ABS/DSC MKxx
 3 Series (E90-E91-E92-E93)	ABS + TRACT. CONT	M3 (04-07)	TEVES ABS/DSC MKxx
 3 Series (E90-E91-E92-E93)	AIRBAG	316i (04-07)	BOSCH SRS MRS5
 3 Series (E90-E91-E92-E93)	AIRBAG	318d (04-07)	BOSCH SRS MRS5
 3 Series (E90-E91-E92-E93)	AIRBAG	318i (04-07)	BOSCH SRS MRS5
 3 Series (E90-E91-E92-E93)	AIRBAG	320d (04-07)	BOSCH SRS MRS5
 3 Series (E90-E91-E92-E93)	AIRBAG	320i (04-07)	BOSCH SRS MRS5
 3 Series (E90-E91-E92-E93)	AIRBAG	320xd (04-07)	BOSCH SRS MRS5
 3 Series (E90-E91-E92-E93)	AIRBAG	323i (04-07)	BOSCH SRS MRS5
 3 Series (E90-E91-E92-E93)	AIRBAG	325d (04-07)	BOSCH SRS MRS5
 3 Series (E90-E91-E92-E93)	AIRBAG	325i (04-07)	BOSCH SRS MRS5
 3 Series (E90-E91-E92-E93)	AIRBAG	325xi (04-07)	BOSCH SRS MRS5
 3 Series (E90-E91-E92-E93)	AIRBAG	330d (04-07)	BOSCH SRS MRS5
 3 Series (E90-E91-E92-E93)	AIRBAG	330i (04-07)	BOSCH SRS MRS5
 3 Series (E90-E91-E92-E93)	AIRBAG	330xd (04-07)	BOSCH SRS MRS5
 3 Series (E90-E91-E92-E93)	AIRBAG	330xi (04-07)	BOSCH SRS MRS5
 3 Series (E90-E91-E92-E93)	AIRBAG	335d (04-07)	BOSCH SRS MRS5
 3 Series (E90-E91-E92-E93)	AIRBAG	335i (04-07)	BOSCH SRS MRS5
 3 Series (E90-E91-E92-E93)	AIRBAG	335xi (04-07)	BOSCH SRS MRS5
 3 Series (E90-E91-E92-E93)	AIRBAG	M3 (04-07)	BOSCH SRS MRS5
 3 Series (E90-E91-E92-E93)	AUTOM. TRANSMISSI	316i (04-07)	EGS
 3 Series (E90-E91-E92-E93)	AUTOM. TRANSMISSI	318d (04-07)	EGS
 3 Series (E90-E91-E92-E93)	AUTOM. TRANSMISSI	318i (04-07)	EGS
 3 Series (E90-E91-E92-E93)	AUTOM. TRANSMISSI	320d (04-07)	EGS
 3 Series (E90-E91-E92-E93)	AUTOM. TRANSMISSI	320i (04-07)	EGS
 3 Series (E90-E91-E92-E93)	AUTOM. TRANSMISSI	320xd (04-07)	EGS
 3 Series (E90-E91-E92-E93)	AUTOM. TRANSMISSI	323i (04-07)	EGS
 3 Series (E90-E91-E92-E93)	AUTOM. TRANSMISSI	325d (04-07)	EGS
 3 Series (E90-E91-E92-E93)	AUTOM. TRANSMISSI	325i (04-07)	EGS
 3 Series (E90-E91-E92-E93)	AUTOM. TRANSMISSI	325xi (04-07)	EGS
 3 Series (E90-E91-E92-E93)	AUTOM. TRANSMISSI	330d (04-07)	EGS
 3 Series (E90-E91-E92-E93)	AUTOM. TRANSMISSI	330i (04-07)	EGS
 3 Series (E90-E91-E92-E93)	AUTOM. TRANSMISSI	330xd (04-07)	EGS
 3 Series (E90-E91-E92-E93)	AUTOM. TRANSMISSI	330xi (04-07)	EGS
 3 Series (E90-E91-E92-E93)	AUTOM. TRANSMISSI	335d (04-07)	EGS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 3 Series (E90-E91-E92-E93)	AUTOM. TRANSMISSI	335i (04-07)	EGS
 3 Series (E90-E91-E92-E93)	AUTOM. TRANSMISSI	335xi (04-07)	EGS
 3 Series (E90-E91-E92-E93)	AUTOM. TRANSMISSI	M3 (04-07)	EGS
 3 Series (E90-E91-E92-E93)	CHASSIS NETWORK	316i (04-07)	JBE
 3 Series (E90-E91-E92-E93)	CHASSIS NETWORK	318d (04-07)	JBE
 3 Series (E90-E91-E92-E93)	CHASSIS NETWORK	318i (04-07)	JBE
 3 Series (E90-E91-E92-E93)	CHASSIS NETWORK	320d (04-07)	JBE
 3 Series (E90-E91-E92-E93)	CHASSIS NETWORK	320i (04-07)	JBE
 3 Series (E90-E91-E92-E93)	CHASSIS NETWORK	320xd (04-07)	JBE
 3 Series (E90-E91-E92-E93)	CHASSIS NETWORK	323i (04-07)	JBE
 3 Series (E90-E91-E92-E93)	CHASSIS NETWORK	325d (04-07)	JBE
 3 Series (E90-E91-E92-E93)	CHASSIS NETWORK	325i (04-07)	JBE
 3 Series (E90-E91-E92-E93)	CHASSIS NETWORK	325xi (04-07)	JBE
 3 Series (E90-E91-E92-E93)	CHASSIS NETWORK	330d (04-07)	JBE
 3 Series (E90-E91-E92-E93)	CHASSIS NETWORK	330i (04-07)	JBE
 3 Series (E90-E91-E92-E93)	CHASSIS NETWORK	330xd (04-07)	JBE
 3 Series (E90-E91-E92-E93)	CHASSIS NETWORK	330xi (04-07)	JBE
 3 Series (E90-E91-E92-E93)	CHASSIS NETWORK	335d (04-07)	JBE
 3 Series (E90-E91-E92-E93)	CHASSIS NETWORK	335i (04-07)	JBE
 3 Series (E90-E91-E92-E93)	CHASSIS NETWORK	335xi (04-07)	JBE
 3 Series (E90-E91-E92-E93)	CHASSIS NETWORK	M3 (04-07)	JBE
 3 Series (E90-E91-E92-E93)	CLIMA	316i (04-07)	Siemens/VDO Riscaldamento/Clima IHKA
 3 Series (E90-E91-E92-E93)	CLIMA	318d (04-07)	Siemens/VDO Riscaldamento/Clima IHKA
 3 Series (E90-E91-E92-E93)	CLIMA	318i (04-07)	Siemens/VDO Riscaldamento/Clima IHKA
 3 Series (E90-E91-E92-E93)	CLIMA	320d (04-07)	Siemens/VDO Riscaldamento/Clima IHKA
 3 Series (E90-E91-E92-E93)	CLIMA	320i (04-07)	Siemens/VDO Riscaldamento/Clima IHKA
 3 Series (E90-E91-E92-E93)	CLIMA	320xd (04-07)	Siemens/VDO Riscaldamento/Clima IHKA
 3 Series (E90-E91-E92-E93)	CLIMA	323i (04-07)	Siemens/VDO Riscaldamento/Clima IHKA
 3 Series (E90-E91-E92-E93)	CLIMA	325d (04-07)	Siemens/VDO Riscaldamento/Clima IHKA
 3 Series (E90-E91-E92-E93)	CLIMA	325i (04-07)	Siemens/VDO Riscaldamento/Clima IHKA
 3 Series (E90-E91-E92-E93)	CLIMA	325xi (04-07)	Siemens/VDO Riscaldamento/Clima IHKA
 3 Series (E90-E91-E92-E93)	CLIMA	330d (04-07)	Siemens/VDO Riscaldamento/Clima IHKA
 3 Series (E90-E91-E92-E93)	CLIMA	330i (04-07)	Siemens/VDO Riscaldamento/Clima IHKA
 3 Series (E90-E91-E92-E93)	CLIMA	330xd (04-07)	Siemens/VDO Riscaldamento/Clima IHKA
 3 Series (E90-E91-E92-E93)	CLIMA	330xi (04-07)	Siemens/VDO Riscaldamento/Clima IHKA
 3 Series (E90-E91-E92-E93)	CLIMA	335d (04-07)	Siemens/VDO Riscaldamento/Clima IHKA
 3 Series (E90-E91-E92-E93)	CLIMA	335i (04-07)	Siemens/VDO Riscaldamento/Clima IHKA
 3 Series (E90-E91-E92-E93)	CLIMA	335xi (04-07)	Siemens/VDO Riscaldamento/Clima IHKA
 3 Series (E90-E91-E92-E93)	CLIMA	M3 (04-07)	Siemens/VDO Riscaldamento/Clima IHKA
 3 Series (E90-E91-E92-E93)	CONV. TOP/SUNROO	316i (07-..)	FZD 87 CAN
 3 Series (E90-E91-E92-E93)	CONV. TOP/SUNROO	318d (07-..)	FZD 87 CAN
 3 Series (E90-E91-E92-E93)	CONV. TOP/SUNROO	318i (07-..)	FZD 87 CAN
 3 Series (E90-E91-E92-E93)	CONV. TOP/SUNROO	320d (07-..)	FZD 87 CAN
 3 Series (E90-E91-E92-E93)	CONV. TOP/SUNROO	320i (07-..)	FZD 87 CAN
 3 Series (E90-E91-E92-E93)	CONV. TOP/SUNROO	320xd (07-..)	FZD 87 CAN
 3 Series (E90-E91-E92-E93)	CONV. TOP/SUNROO	323i (07-..)	FZD 87 CAN
 3 Series (E90-E91-E92-E93)	CONV. TOP/SUNROO	325d (07-..)	FZD 87 CAN
 3 Series (E90-E91-E92-E93)	CONV. TOP/SUNROO	325i (07-..)	FZD 87 CAN
 3 Series (E90-E91-E92-E93)	CONV. TOP/SUNROO	325xi (07-..)	FZD 87 CAN
 3 Series (E90-E91-E92-E93)	CONV. TOP/SUNROO	330d (07-..)	FZD 87 CAN
 3 Series (E90-E91-E92-E93)	CONV. TOP/SUNROO	330i (07-..)	FZD 87 CAN
 3 Series (E90-E91-E92-E93)	CONV. TOP/SUNROO	330xd (07-..)	FZD 87 CAN
 3 Series (E90-E91-E92-E93)	CONV. TOP/SUNROO	330xi (07-..)	FZD 87 CAN
 3 Series (E90-E91-E92-E93)	CONV. TOP/SUNROO	335d (07-..)	FZD 87 CAN
 3 Series (E90-E91-E92-E93)	CONV. TOP/SUNROO	335i (07-..)	FZD 87 CAN
 3 Series (E90-E91-E92-E93)	CONV. TOP/SUNROO	335xi (07-..)	FZD 87 CAN
 3 Series (E90-E91-E92-E93)	CONV. TOP/SUNROO	M3 (07-..)	FZD 87 CAN
 3 Series (E90-E91-E92-E93)	CRUISE CONTROL	316i (07-..)	ACC 2 CAN

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 3 Series (E90-E91-E92-E93)	CRUISE CONTROL	318d (07-..)	ACC 2 CAN
 3 Series (E90-E91-E92-E93)	CRUISE CONTROL	318i (07-..)	ACC 2 CAN
 3 Series (E90-E91-E92-E93)	CRUISE CONTROL	320d (07-..)	ACC 2 CAN
 3 Series (E90-E91-E92-E93)	CRUISE CONTROL	320i (07-..)	ACC 2 CAN
 3 Series (E90-E91-E92-E93)	CRUISE CONTROL	320xd (07-..)	ACC 2 CAN
 3 Series (E90-E91-E92-E93)	CRUISE CONTROL	323i (07-..)	ACC 2 CAN
 3 Series (E90-E91-E92-E93)	CRUISE CONTROL	325d (07-..)	ACC 2 CAN
 3 Series (E90-E91-E92-E93)	CRUISE CONTROL	325i (07-..)	ACC 2 CAN
 3 Series (E90-E91-E92-E93)	CRUISE CONTROL	325xi (07-..)	ACC 2 CAN
 3 Series (E90-E91-E92-E93)	CRUISE CONTROL	330d (07-..)	ACC 2 CAN
 3 Series (E90-E91-E92-E93)	CRUISE CONTROL	330i (07-..)	ACC 2 CAN
 3 Series (E90-E91-E92-E93)	CRUISE CONTROL	330xd (07-..)	ACC 2 CAN
 3 Series (E90-E91-E92-E93)	CRUISE CONTROL	330xi (07-..)	ACC 2 CAN
 3 Series (E90-E91-E92-E93)	CRUISE CONTROL	335d (07-..)	ACC 2 CAN
 3 Series (E90-E91-E92-E93)	CRUISE CONTROL	335i (07-..)	ACC 2 CAN
 3 Series (E90-E91-E92-E93)	CRUISE CONTROL	335xi (07-..)	ACC 2 CAN
 3 Series (E90-E91-E92-E93)	CRUISE CONTROL	M3 (07-..)	ACC 2 CAN
 3 Series (E90-E91-E92-E93)	DASHBOARD	316i (04-07)	Siemens/VDO/Borg Kombinstrum.
 3 Series (E90-E91-E92-E93)	DASHBOARD	318d (04-07)	Siemens/VDO/Borg Kombinstrum.
 3 Series (E90-E91-E92-E93)	DASHBOARD	318d (07-..)	KOMB 87 CAN
 3 Series (E90-E91-E92-E93)	DASHBOARD	318i (04-07)	Siemens/VDO/Borg Kombinstrum.
 3 Series (E90-E91-E92-E93)	DASHBOARD	318i (07-..)	KOMB 87 CAN
 3 Series (E90-E91-E92-E93)	DASHBOARD	320d (04-07)	Siemens/VDO/Borg Kombinstrum.
 3 Series (E90-E91-E92-E93)	DASHBOARD	320d (07-..)	KOMB 87 CAN
 3 Series (E90-E91-E92-E93)	DASHBOARD	320i (04-07)	Siemens/VDO/Borg Kombinstrum.
 3 Series (E90-E91-E92-E93)	DASHBOARD	320i (07-..)	KOMB 87 CAN
 3 Series (E90-E91-E92-E93)	DASHBOARD	320xd (04-07)	Siemens/VDO/Borg Kombinstrum.
 3 Series (E90-E91-E92-E93)	DASHBOARD	320xd (07-..)	KOMB 87 CAN
 3 Series (E90-E91-E92-E93)	DASHBOARD	323i (04-07)	Siemens/VDO/Borg Kombinstrum.
 3 Series (E90-E91-E92-E93)	DASHBOARD	323i (07-..)	KOMB 87 CAN
 3 Series (E90-E91-E92-E93)	DASHBOARD	325d (04-07)	Siemens/VDO/Borg Kombinstrum.
 3 Series (E90-E91-E92-E93)	DASHBOARD	325d (07-..)	KOMB 87 CAN
 3 Series (E90-E91-E92-E93)	DASHBOARD	325i (04-07)	Siemens/VDO/Borg Kombinstrum.
 3 Series (E90-E91-E92-E93)	DASHBOARD	325i (07-..)	KOMB 87 CAN
 3 Series (E90-E91-E92-E93)	DASHBOARD	325xi (04-07)	Siemens/VDO/Borg Kombinstrum.
 3 Series (E90-E91-E92-E93)	DASHBOARD	325xi (07-..)	KOMB 87 CAN
 3 Series (E90-E91-E92-E93)	DASHBOARD	330d (04-07)	Siemens/VDO/Borg Kombinstrum.
 3 Series (E90-E91-E92-E93)	DASHBOARD	330d (07-..)	KOMB 87 CAN
 3 Series (E90-E91-E92-E93)	DASHBOARD	330i (04-07)	Siemens/VDO/Borg Kombinstrum.
 3 Series (E90-E91-E92-E93)	DASHBOARD	330i (07-..)	KOMB 87 CAN
 3 Series (E90-E91-E92-E93)	DASHBOARD	330xd (04-07)	Siemens/VDO/Borg Kombinstrum.
 3 Series (E90-E91-E92-E93)	DASHBOARD	330xd (07-..)	KOMB 87 CAN
 3 Series (E90-E91-E92-E93)	DASHBOARD	330xi (04-07)	Siemens/VDO/Borg Kombinstrum.
 3 Series (E90-E91-E92-E93)	DASHBOARD	330xi (07-..)	KOMB 87 CAN
 3 Series (E90-E91-E92-E93)	DASHBOARD	335d (04-07)	Siemens/VDO/Borg Kombinstrum.
 3 Series (E90-E91-E92-E93)	DASHBOARD	335d (07-..)	KOMB 87 CAN
 3 Series (E90-E91-E92-E93)	DASHBOARD	335i (04-07)	Siemens/VDO/Borg Kombinstrum.
 3 Series (E90-E91-E92-E93)	DASHBOARD	335i (07-..)	KOMB 87 CAN
 3 Series (E90-E91-E92-E93)	DASHBOARD	335xi (04-07)	Siemens/VDO/Borg Kombinstrum.
 3 Series (E90-E91-E92-E93)	DASHBOARD	335xi (07-..)	KOMB 87 CAN
 3 Series (E90-E91-E92-E93)	DASHBOARD	M3 (04-07)	Siemens/VDO/Borg Kombinstrum.
 3 Series (E90-E91-E92-E93)	DASHBOARD	M3 (07-..)	KOMB 87 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	316i (04-07)	Megamos EPS
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	316i (07-..)	EPS 90 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	316i Active Front Steering (07-..)	AFS 70 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	318d (04-07)	Megamos EPS
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	318d (07-..)	EPS 90 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	318d Active Front Steering (07-..)	AFS 70 CAN

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	318i (04-07)	Megamos EPS
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	318i (07-..)	EPS 90 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	318i Active Front Steering (07-..)	AFS 70 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	320d (04-07)	Megamos EPS
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	320d (07-..)	EPS 90 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	320d Active Front Steering (07-..)	AFS 70 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	320i (04-07)	Megamos EPS
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	320i (07-..)	EPS 90 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	320i Active Front Steering (07-..)	AFS 70 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	320xd (04-07)	Megamos EPS
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	320xd (07-..)	EPS 90 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	320xd Active Front Steering (07-..)	AFS 70 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	323i (04-07)	Megamos EPS
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	323i (07-..)	EPS 90 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	323i Active Front Steering (07-..)	AFS 70 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	325d (04-07)	Megamos EPS
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	325d (07-..)	EPS 90 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	325d Active Front Steering (07-..)	AFS 70 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	325i (04-07)	Megamos EPS
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	325i (07-..)	EPS 90 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	325i Active Front Steering (07-..)	AFS 70 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	325xi (04-07)	Megamos EPS
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	325xi (07-..)	EPS 90 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	325xi Active Front Steering (07-..)	AFS 70 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	330d (04-07)	Megamos EPS
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	330d (07-..)	EPS 90 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	330d Active Front Steering (07-..)	AFS 70 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	330i (04-07)	Megamos EPS
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	330i (07-..)	EPS 90 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	330i Active Front Steering (07-..)	AFS 70 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	330xd (04-07)	Megamos EPS
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	330xd (07-..)	EPS 90 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	330xd Active Front Steering (07-..)	AFS 70 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	330xi (04-07)	Megamos EPS
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	330xi (07-..)	EPS 90 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	330xi Active Front Steering (07-..)	AFS 70 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	335d (04-07)	Megamos EPS
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	335d (07-..)	EPS 90 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	335d Active Front Steering (07-..)	AFS 70 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	335i (04-07)	Megamos EPS
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	335i (07-..)	EPS 90 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	335i Active Front Steering (07-..)	AFS 70 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	335xi (04-07)	Megamos EPS
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	335xi (07-..)	EPS 90 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	335xi Active Front Steering (07-..)	AFS 70 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	M3 (04-07)	Megamos EPS
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	M3 (07-..)	EPS 90 CAN
 3 Series (E90-E91-E92-E93)	ELECTRIC STEERING	M3 Active Front Steering (07-..)	AFS 70 CAN
 3 Series (E90-E91-E92-E93)	ENGINE MANAGEME	316i (04-07)	EOBD
 3 Series (E90-E91-E92-E93)	ENGINE MANAGEME	316i (07-..)	MSD 80 CAN
 3 Series (E90-E91-E92-E93)	ENGINE MANAGEME	318d 20 4D 4 (04-07)	BOSCH DDE 6.0
 3 Series (E90-E91-E92-E93)	ENGINE MANAGEME	318i (04-07)	EOBD
 3 Series (E90-E91-E92-E93)	ENGINE MANAGEME	320d 20 4D 4 (04-07)	BOSCH DDE 6.0
 3 Series (E90-E91-E92-E93)	ENGINE MANAGEME	320i (04-07)	EOBD
 3 Series (E90-E91-E92-E93)	ENGINE MANAGEME	320xd 20 4D 4 (04-07)	BOSCH DDE 6.0
 3 Series (E90-E91-E92-E93)	ENGINE MANAGEME	323i (04-07)	EOBD
 3 Series (E90-E91-E92-E93)	ENGINE MANAGEME	325d (04-07)	EOBD
 3 Series (E90-E91-E92-E93)	ENGINE MANAGEME	325i (04-07)	EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 3 Series (E90-E91-E92-E93)	ENGINE MANAGEME	325xi (04-07)	EOBD
 3 Series (E90-E91-E92-E93)	ENGINE MANAGEME	330d (04-07)	BOSCH DDE 6.0
 3 Series (E90-E91-E92-E93)	ENGINE MANAGEME	330i (04-07)	EOBD
 3 Series (E90-E91-E92-E93)	ENGINE MANAGEME	330xd (04-07)	BOSCH DDE 6.0
 3 Series (E90-E91-E92-E93)	ENGINE MANAGEME	330xi (04-07)	EOBD
 3 Series (E90-E91-E92-E93)	ENGINE MANAGEME	335d (04-07)	EOBD
 3 Series (E90-E91-E92-E93)	ENGINE MANAGEME	335i (04-07)	EOBD
 3 Series (E90-E91-E92-E93)	ENGINE MANAGEME	335xi (04-07)	EOBD
 3 Series (E90-E91-E92-E93)	ENGINE MANAGEME	M3 (04-07)	EOBD
 3 Series (E90-E91-E92-E93)	IMMOBILIZER	316i (07-..)	CAS CAN
 3 Series (E90-E91-E92-E93)	IMMOBILIZER	318d (07-..)	CAS CAN
 3 Series (E90-E91-E92-E93)	IMMOBILIZER	318i (07-..)	CAS CAN
 3 Series (E90-E91-E92-E93)	IMMOBILIZER	320d (07-..)	CAS CAN
 3 Series (E90-E91-E92-E93)	IMMOBILIZER	320i (07-..)	CAS CAN
 3 Series (E90-E91-E92-E93)	IMMOBILIZER	320xd (07-..)	CAS CAN
 3 Series (E90-E91-E92-E93)	IMMOBILIZER	323i (07-..)	CAS CAN
 3 Series (E90-E91-E92-E93)	IMMOBILIZER	325d (07-..)	CAS CAN
 3 Series (E90-E91-E92-E93)	IMMOBILIZER	325i (07-..)	CAS CAN
 3 Series (E90-E91-E92-E93)	IMMOBILIZER	325xi (07-..)	CAS CAN
 3 Series (E90-E91-E92-E93)	IMMOBILIZER	330d (07-..)	CAS CAN
 3 Series (E90-E91-E92-E93)	IMMOBILIZER	330i (07-..)	CAS CAN
 3 Series (E90-E91-E92-E93)	IMMOBILIZER	330xd (07-..)	CAS CAN
 3 Series (E90-E91-E92-E93)	IMMOBILIZER	330xi (07-..)	CAS CAN
 3 Series (E90-E91-E92-E93)	IMMOBILIZER	335d (07-..)	CAS CAN
 3 Series (E90-E91-E92-E93)	IMMOBILIZER	335i (07-..)	CAS CAN
 3 Series (E90-E91-E92-E93)	IMMOBILIZER	335xi (07-..)	CAS CAN
 3 Series (E90-E91-E92-E93)	IMMOBILIZER	M3 (07-..)	CAS CAN
 3 Series (E90-E91-E92-E93)	MAINTENANCE	316i (04-07)	MANUAL
 3 Series (E90-E91-E92-E93)	MAINTENANCE	316i (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	316i (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	316i (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	316i (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	316i (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	316i (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	316i (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	316i (04-07)	Tyre Monitor MANUAL
 3 Series (E90-E91-E92-E93)	MAINTENANCE	318d (04-07)	MANUAL
 3 Series (E90-E91-E92-E93)	MAINTENANCE	318d (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	318d (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	318d (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	318d (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	318d (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	318d (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	318d (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	318d (04-07)	Tyre Monitor MANUAL
 3 Series (E90-E91-E92-E93)	MAINTENANCE	318i (04-07)	MANUAL
 3 Series (E90-E91-E92-E93)	MAINTENANCE	318i (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	318i (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	318i (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	318i (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	318i (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	318i (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	318i (04-07)	Tyre Monitor MANUAL
 3 Series (E90-E91-E92-E93)	MAINTENANCE	320d (04-07)	MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

[illegible]

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

[illegible]

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 3 Series (E90-E91-E92-E93)	MAINTENANCE	335d (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	335d (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	335d (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	335d (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	335d (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	335d (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	335d (04-07)	Tyre Monitor MANUAL
 3 Series (E90-E91-E92-E93)	MAINTENANCE	335i (04-07)	MANUAL
 3 Series (E90-E91-E92-E93)	MAINTENANCE	335i (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	335i (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	335i (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	335i (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	335i (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	335i (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	335i (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	335i (04-07)	Tyre Monitor MANUAL
 3 Series (E90-E91-E92-E93)	MAINTENANCE	335xi (04-07)	MANUAL
 3 Series (E90-E91-E92-E93)	MAINTENANCE	335xi (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	335xi (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	335xi (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	335xi (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	335xi (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	335xi (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	335xi (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	335xi (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	335xi (04-07)	Tyre Monitor MANUAL
 3 Series (E90-E91-E92-E93)	MAINTENANCE	M3 (04-07)	MANUAL
 3 Series (E90-E91-E92-E93)	MAINTENANCE	M3 (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	M3 (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	M3 (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	M3 (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	M3 (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	M3 (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	M3 (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	MAINTENANCE	M3 (04-07)	Tyre Monitor MANUAL
 3 Series (E90-E91-E92-E93)	PARK.BRAKE	316i (07-..)	EMF 89 CAN
 3 Series (E90-E91-E92-E93)	PARK.BRAKE	318d (07-..)	EMF 89 CAN
 3 Series (E90-E91-E92-E93)	PARK.BRAKE	318i (07-..)	EMF 89 CAN
 3 Series (E90-E91-E92-E93)	PARK.BRAKE	320d (07-..)	EMF 89 CAN
 3 Series (E90-E91-E92-E93)	PARK.BRAKE	320i (07-..)	EMF 89 CAN
 3 Series (E90-E91-E92-E93)	PARK.BRAKE	320xd (07-..)	EMF 89 CAN
 3 Series (E90-E91-E92-E93)	PARK.BRAKE	323i (07-..)	EMF 89 CAN
 3 Series (E90-E91-E92-E93)	PARK.BRAKE	325d (07-..)	EMF 89 CAN
 3 Series (E90-E91-E92-E93)	PARK.BRAKE	325i (07-..)	EMF 89 CAN
 3 Series (E90-E91-E92-E93)	PARK.BRAKE	325xi (07-..)	EMF 89 CAN
 3 Series (E90-E91-E92-E93)	PARK.BRAKE	330d (07-..)	EMF 89 CAN
 3 Series (E90-E91-E92-E93)	PARK.BRAKE	330i (07-..)	EMF 89 CAN
 3 Series (E90-E91-E92-E93)	PARK.BRAKE	330xd (07-..)	EMF 89 CAN
 3 Series (E90-E91-E92-E93)	PARK.BRAKE	330xi (07-..)	EMF 89 CAN
 3 Series (E90-E91-E92-E93)	PARK.BRAKE	335d (07-..)	EMF 89 CAN
 3 Series (E90-E91-E92-E93)	PARK.BRAKE	335i (07-..)	EMF 89 CAN
 3 Series (E90-E91-E92-E93)	PARK.BRAKE	335xi (07-..)	EMF 89 CAN
 3 Series (E90-E91-E92-E93)	PARK.BRAKE	M3 (07-..)	EMF 89 CAN
 3 Series (E90-E91-E92-E93)	PARKING HELP	316i (04-07)	BOSCH PDC
 3 Series (E90-E91-E92-E93)	PARKING HELP	318d (04-07)	BOSCH PDC
 3 Series (E90-E91-E92-E93)	PARKING HELP	318i (04-07)	BOSCH PDC

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 3 Series (E90-E91-E92-E93)	PARKING HELP	320d (04-07)	BOSCH PDC
 3 Series (E90-E91-E92-E93)	PARKING HELP	320i (04-07)	BOSCH PDC
 3 Series (E90-E91-E92-E93)	PARKING HELP	320xd (04-07)	BOSCH PDC
 3 Series (E90-E91-E92-E93)	PARKING HELP	323i (04-07)	BOSCH PDC
 3 Series (E90-E91-E92-E93)	PARKING HELP	325d (04-07)	BOSCH PDC
 3 Series (E90-E91-E92-E93)	PARKING HELP	325i (04-07)	BOSCH PDC
 3 Series (E90-E91-E92-E93)	PARKING HELP	325xi (04-07)	BOSCH PDC
 3 Series (E90-E91-E92-E93)	PARKING HELP	330d (04-07)	BOSCH PDC
 3 Series (E90-E91-E92-E93)	PARKING HELP	330i (04-07)	BOSCH PDC
 3 Series (E90-E91-E92-E93)	PARKING HELP	330xd (04-07)	BOSCH PDC
 3 Series (E90-E91-E92-E93)	PARKING HELP	330xi (04-07)	BOSCH PDC
 3 Series (E90-E91-E92-E93)	PARKING HELP	335d (04-07)	BOSCH PDC
 3 Series (E90-E91-E92-E93)	PARKING HELP	335i (04-07)	BOSCH PDC
 3 Series (E90-E91-E92-E93)	PARKING HELP	335xi (04-07)	BOSCH PDC
 3 Series (E90-E91-E92-E93)	PARKING HELP	M3 (04-07)	BOSCH PDC
 3 Series (E90-E91-E92-E93)	RADIO / CD	316i (07-..)	DAB 60 - DIGITAL RADIO CAN
 3 Series (E90-E91-E92-E93)	RADIO / CD	318d (07-..)	DAB 60 - DIGITAL RADIO CAN
 3 Series (E90-E91-E92-E93)	RADIO / CD	318i (07-..)	DAB 60 - DIGITAL RADIO CAN
 3 Series (E90-E91-E92-E93)	RADIO / CD	320d (07-..)	DAB 60 - DIGITAL RADIO CAN
 3 Series (E90-E91-E92-E93)	RADIO / CD	320i (07-..)	DAB 60 - DIGITAL RADIO CAN
 3 Series (E90-E91-E92-E93)	RADIO / CD	320xd (07-..)	DAB 60 - DIGITAL RADIO CAN
 3 Series (E90-E91-E92-E93)	RADIO / CD	323i (07-..)	DAB 60 - DIGITAL RADIO CAN
 3 Series (E90-E91-E92-E93)	RADIO / CD	325d (07-..)	DAB 60 - DIGITAL RADIO CAN
 3 Series (E90-E91-E92-E93)	RADIO / CD	325i (07-..)	DAB 60 - DIGITAL RADIO CAN
 3 Series (E90-E91-E92-E93)	RADIO / CD	325xi (07-..)	DAB 60 - DIGITAL RADIO CAN
 3 Series (E90-E91-E92-E93)	RADIO / CD	330d (07-..)	DAB 60 - DIGITAL RADIO CAN
 3 Series (E90-E91-E92-E93)	RADIO / CD	330i (07-..)	DAB 60 - DIGITAL RADIO CAN
 3 Series (E90-E91-E92-E93)	RADIO / CD	330xd (07-..)	DAB 60 - DIGITAL RADIO CAN
 3 Series (E90-E91-E92-E93)	RADIO / CD	330xi (07-..)	DAB 60 - DIGITAL RADIO CAN
 3 Series (E90-E91-E92-E93)	RADIO / CD	335d (07-..)	DAB 60 - DIGITAL RADIO CAN
 3 Series (E90-E91-E92-E93)	RADIO / CD	335i (07-..)	DAB 60 - DIGITAL RADIO CAN
 3 Series (E90-E91-E92-E93)	RADIO / CD	335xi (07-..)	DAB 60 - DIGITAL RADIO CAN
 3 Series (E90-E91-E92-E93)	RADIO / CD	M3 (07-..)	DAB 60 - DIGITAL RADIO CAN
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	316i (04-07)	Kostal RLSS
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	316i (07-..)	RLS 87 CAN
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	318d (04-07)	Kostal RLSS
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	318d (07-..)	RLS 87 CAN
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	318i (04-07)	Kostal RLSS
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	318i (07-..)	RLS 87 CAN
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	320d (04-07)	Kostal RLSS
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	320d (07-..)	RLS 87 CAN
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	320i (04-07)	Kostal RLSS
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	320i (07-..)	RLS 87 CAN
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	320xd (04-07)	Kostal RLSS
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	320xd (07-..)	RLS 87 CAN
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	323i (04-07)	Kostal RLSS
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	323i (07-..)	RLS 87 CAN
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	325d (04-07)	Kostal RLSS
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	325d (07-..)	RLS 87 CAN
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	325i (04-07)	Kostal RLSS
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	325i (07-..)	RLS 87 CAN
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	325xi (04-07)	Kostal RLSS
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	325xi (07-..)	RLS 87 CAN
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	330d (04-07)	Kostal RLSS
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	330d (07-..)	RLS 87 CAN
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	330i (04-07)	Kostal RLSS
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	330i (07-..)	RLS 87 CAN
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	330xd (04-07)	Kostal RLSS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	330xd (07-..)	RLS 87 CAN
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	330xi (04-07)	Kostal RLSS
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	330xi (07-..)	RLS 87 CAN
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	335d (04-07)	Kostal RLSS
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	335d (07-..)	RLS 87 CAN
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	335i (04-07)	Kostal RLSS
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	335i (07-..)	RLS 87 CAN
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	335xi (04-07)	Kostal RLSS
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	335xi (07-..)	RLS 87 CAN
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	M3 (04-07)	Kostal RLSS
 3 Series (E90-E91-E92-E93)	RAIN-LUMINOSITY S	M3 (07-..)	RLS 87 CAN
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	316i (04-07)	MANUAL
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	316i (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	318d (04-07)	MANUAL
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	318d (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	318i (04-07)	MANUAL
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	318i (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	320d (04-07)	MANUAL
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	320d (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	320i (04-07)	MANUAL
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	320i (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	320xd (04-07)	MANUAL
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	320xd (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	323i (04-07)	MANUAL
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	323i (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	325d (04-07)	MANUAL
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	325d (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	325i (04-07)	MANUAL
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	325i (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	325xi (04-07)	MANUAL
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	325xi (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	330d (04-07)	MANUAL
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	330d (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	330i (04-07)	MANUAL
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	330i (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	330xd (04-07)	MANUAL
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	330xd (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	330xi (04-07)	MANUAL
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	330xi (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	335d (04-07)	MANUAL
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	335d (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	335i (04-07)	MANUAL
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	335i (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	335xi (04-07)	MANUAL
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	335xi (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	M3 (04-07)	MANUAL
 3 Series (E90-E91-E92-E93)	SERVICE LIGHT RES	M3 (04-07)	Service Kombi/Info Display
 3 Series (E90-E91-E92-E93)	SUSPENSION CONTR	316i (07-..)	EDCK 65 CAN
 3 Series (E90-E91-E92-E93)	SUSPENSION CONTR	318d (07-..)	EDCK 65 CAN
 3 Series (E90-E91-E92-E93)	SUSPENSION CONTR	318i (07-..)	EDCK 65 CAN
 3 Series (E90-E91-E92-E93)	SUSPENSION CONTR	320d (07-..)	EDCK 65 CAN
 3 Series (E90-E91-E92-E93)	SUSPENSION CONTR	320i (07-..)	EDCK 65 CAN
 3 Series (E90-E91-E92-E93)	SUSPENSION CONTR	320xd (07-..)	EDCK 65 CAN
 3 Series (E90-E91-E92-E93)	SUSPENSION CONTR	323i (07-..)	EDCK 65 CAN
 3 Series (E90-E91-E92-E93)	SUSPENSION CONTR	325d (07-..)	EDCK 65 CAN
 3 Series (E90-E91-E92-E93)	SUSPENSION CONTR	325i (07-..)	EDCK 65 CAN
 3 Series (E90-E91-E92-E93)	SUSPENSION CONTR	325xi (07-..)	EDCK 65 CAN
 3 Series (E90-E91-E92-E93)	SUSPENSION CONTR	330d (07-..)	EDCK 65 CAN

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 3 Series (E90-E91-E92-E93)	SUSPENSION CONTR	330i (07-..)	EDCK 65 CAN
 3 Series (E90-E91-E92-E93)	SUSPENSION CONTR	330xd (07-..)	EDCK 65 CAN
 3 Series (E90-E91-E92-E93)	SUSPENSION CONTR	330xi (07-..)	EDCK 65 CAN
 3 Series (E90-E91-E92-E93)	SUSPENSION CONTR	335d (07-..)	EDCK 65 CAN
 3 Series (E90-E91-E92-E93)	SUSPENSION CONTR	335i (07-..)	EDCK 65 CAN
 3 Series (E90-E91-E92-E93)	SUSPENSION CONTR	335xi (07-..)	EDCK 65 CAN
 3 Series (E90-E91-E92-E93)	SUSPENSION CONTR	M3 (07-..)	EDCK 65 CAN
 3 Series (E90-E91-E92-E93)	TIRE PRESSURE	316i (04-07)	Tyre Monitor MANUAL
 3 Series (E90-E91-E92-E93)	TIRE PRESSURE	318d (04-07)	Tyre Monitor MANUAL
 3 Series (E90-E91-E92-E93)	TIRE PRESSURE	318i (04-07)	Tyre Monitor MANUAL
 3 Series (E90-E91-E92-E93)	TIRE PRESSURE	320d (04-07)	Tyre Monitor MANUAL
 3 Series (E90-E91-E92-E93)	TIRE PRESSURE	320i (04-07)	Tyre Monitor MANUAL
 3 Series (E90-E91-E92-E93)	TIRE PRESSURE	320xd (04-07)	Tyre Monitor MANUAL
 3 Series (E90-E91-E92-E93)	TIRE PRESSURE	323i (04-07)	Tyre Monitor MANUAL
 3 Series (E90-E91-E92-E93)	TIRE PRESSURE	325d (04-07)	Tyre Monitor MANUAL
 3 Series (E90-E91-E92-E93)	TIRE PRESSURE	325i (04-07)	Tyre Monitor MANUAL
 3 Series (E90-E91-E92-E93)	TIRE PRESSURE	325xi (04-07)	Tyre Monitor MANUAL
 3 Series (E90-E91-E92-E93)	TIRE PRESSURE	330d (04-07)	Tyre Monitor MANUAL
 3 Series (E90-E91-E92-E93)	TIRE PRESSURE	330i (04-07)	Tyre Monitor MANUAL
 3 Series (E90-E91-E92-E93)	TIRE PRESSURE	330xd (04-07)	Tyre Monitor MANUAL
 3 Series (E90-E91-E92-E93)	TIRE PRESSURE	330xi (04-07)	Tyre Monitor MANUAL
 3 Series (E90-E91-E92-E93)	TIRE PRESSURE	335d (04-07)	Tyre Monitor MANUAL
 3 Series (E90-E91-E92-E93)	TIRE PRESSURE	335i (04-07)	Tyre Monitor MANUAL
 3 Series (E90-E91-E92-E93)	TIRE PRESSURE	335xi (04-07)	Tyre Monitor MANUAL
 3 Series (E90-E91-E92-E93)	TIRE PRESSURE	M3 (04-07)	Tyre Monitor MANUAL
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	316i (04-07)	Alpine CID
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	316i (07-..)	Info Display CID90
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	318d (04-07)	Alpine CID
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	318d (07-..)	Info Display CID90
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	318i (04-07)	Alpine CID
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	318i (07-..)	Info Display CID90
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	320d (04-07)	Alpine CID
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	320d (07-..)	Info Display CID90
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	320i (04-07)	Alpine CID
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	320i (07-..)	Info Display CID90
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	320xd (04-07)	Alpine CID
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	320xd (07-..)	Info Display CID90
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	323i (04-07)	Alpine CID
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	323i (07-..)	Info Display CID90
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	325d (04-07)	Alpine CID
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	325d (07-..)	Info Display CID90
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	325i (04-07)	Alpine CID
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	325i (07-..)	Info Display CID90
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	325xi (04-07)	Alpine CID
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	325xi (07-..)	Info Display CID90
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	330d (04-07)	Alpine CID
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	330d (07-..)	Info Display CID90
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	330i (04-07)	Alpine CID
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	330i (07-..)	Info Display CID90
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	330xd (04-07)	Alpine CID
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	330xd (07-..)	Info Display CID90
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	330xi (04-07)	Alpine CID
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	330xi (07-..)	Info Display CID90
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	335d (04-07)	Alpine CID
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	335d (07-..)	Info Display CID90
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	335i (04-07)	Alpine CID
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	335i (07-..)	Info Display CID90
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	335xi (04-07)	Alpine CID

Systems supported by ECUREADER / ECUDECODER (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	335xi (07-...)	Info Display CID90
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	M3 (04-07)	Alpine CID
 3 Series (E90-E91-E92-E93)	VISUAL./TELEMATIC	M3 (07-...)	Info Display CID90
 3 Series Compact (E36) (94)	ABS	316g (92-94)	ATE-TEVES ABS MkIV/3
 3 Series Compact (E36) (94)	ABS	316g (95-98)	ITT-TEVES ABS Mk20-I/ERL
 3 Series Compact (E36) (94)	ABS	316ti (92-94)	ATE-TEVES ABS MkIV/3
 3 Series Compact (E36) (94)	ABS	316ti (95-98)	ITT-TEVES ABS Mk20-I/ERL
 3 Series Compact (E36) (94)	ABS	318tds (92-94)	ATE-TEVES ABS MkIV/3
 3 Series Compact (E36) (94)	ABS	318tds (95-98)	ITT-TEVES ABS Mk20-I/ERL
 3 Series Compact (E36) (94)	ABS	318ti (92-94)	ATE-TEVES ABS MkIV/3
 3 Series Compact (E36) (94)	ABS	318ti (95-98)	ITT-TEVES ABS Mk20-I/ERL
 3 Series Compact (E36) (94)	ABS	323ti (92-94)	ATE-TEVES ABS MkIV/3
 3 Series Compact (E36) (94)	ABS	323ti (95-98)	ITT-TEVES ABS Mk20-I/ERL
 3 Series Compact (E36) (94)	AIRBAG	316g (95-98)	TEMIC AirBag ZAE2
 3 Series Compact (E36) (94)	AIRBAG	316ti (95-98)	TEMIC AirBag ZAE2
 3 Series Compact (E36) (94)	AIRBAG	318tds (95-98)	TEMIC AirBag ZAE2
 3 Series Compact (E36) (94)	AIRBAG	318ti (95-98)	TEMIC AirBag ZAE2
 3 Series Compact (E36) (94)	AIRBAG	323ti (95-98)	TEMIC AirBag ZAE2
 3 Series Compact (E36) (94)	ENGINE MANAGEME	316ti 16 4E 2 (93-96)	BOSCH Motronic DME M1.7.2
 3 Series Compact (E36) (94)	ENGINE MANAGEME	316ti 16 4E 2 (95-96)	BOSCH Motronic DME M1.7.3
 3 Series Compact (E36) (94)	ENGINE MANAGEME	318tds 17 4T 1 (94-96)	BOSCH EDC DDE 2.1
 3 Series Compact (E36) (94)	ENGINE MANAGEME	318ti 18 4E 1 (90-93)	BOSCH Motronic DME M1.7
 3 Series Compact (E36) (94)	ENGINE MANAGEME	318ti 18 4E 2 (93-96)	BOSCH Motronic DME M1.7.2
 3 Series Compact (E36) (94)	ENGINE MANAGEME	318ti 18 4E 2 (95-96)	BOSCH Motronic DME M1.7.3
 3 Series Compact (E36) (94)	ENGINE MANAGEME	318ti 18 4S 1 (91-93)	BOSCH Motronic DME M1.7
 3 Series Compact (E36) (94)	ENGINE MANAGEME	318ti 18 4S 1 (93-95)	BOSCH Motronic DME M1.7.2
 3 Series Compact (E36) (94)	ENGINE MANAGEME	323ti 20 6S 1 (90-92)	BOSCH Motronic DME M3.1
 3 Series Compact (E36) (94)	ENGINE MANAGEME	323ti 20 6S 2 (92-96)	SIEMENS MPI DME MS 40.1
 3 Series Compact (E36) (94)	ENGINE MANAGEME	323ti 20 6S 3 (94-96)	SIEMENS MPI DME MS 41.0
 3 Series Compact (E36) (94)	MAINTENANCE	316g	MANUAL
 3 Series Compact (E36) (94)	MAINTENANCE	316g (...-09/00)	Service
 3 Series Compact (E36) (94)	MAINTENANCE	316g (92-94)	ATE-TEVES ABS MkIV/3
 3 Series Compact (E36) (94)	MAINTENANCE	316ti	MANUAL
 3 Series Compact (E36) (94)	MAINTENANCE	316ti (...-09/00)	Service
 3 Series Compact (E36) (94)	MAINTENANCE	316ti (92-94)	ATE-TEVES ABS MkIV/3
 3 Series Compact (E36) (94)	MAINTENANCE	318tds	MANUAL
 3 Series Compact (E36) (94)	MAINTENANCE	318tds (...-09/00)	Service
 3 Series Compact (E36) (94)	MAINTENANCE	318tds (92-94)	ATE-TEVES ABS MkIV/3
 3 Series Compact (E36) (94)	MAINTENANCE	318ti	MANUAL
 3 Series Compact (E36) (94)	MAINTENANCE	318ti (...-09/00)	Service
 3 Series Compact (E36) (94)	MAINTENANCE	318ti (92-94)	ATE-TEVES ABS MkIV/3
 3 Series Compact (E36) (94)	MAINTENANCE	323ti	MANUAL
 3 Series Compact (E36) (94)	MAINTENANCE	323ti (...-09/00)	Service
 3 Series Compact (E36) (94)	MAINTENANCE	323ti (92-94)	ATE-TEVES ABS MkIV/3
 3 Series Compact (E36) (94)	REMOTE CONTROL E	316g	MANUAL
 3 Series Compact (E36) (94)	REMOTE CONTROL E	316ti	MANUAL
 3 Series Compact (E36) (94)	REMOTE CONTROL E	318tds	MANUAL
 3 Series Compact (E36) (94)	REMOTE CONTROL E	318ti	MANUAL
 3 Series Compact (E36) (94)	REMOTE CONTROL E	323ti	MANUAL
 3 Series Compact (E36) (94)	SERVICE LIGHT RES	316g (...-09/00)	Service
 3 Series Compact (E36) (94)	SERVICE LIGHT RES	316ti (...-09/00)	Service
 3 Series Compact (E36) (94)	SERVICE LIGHT RES	318tds (...-09/00)	Service
 3 Series Compact (E36) (94)	SERVICE LIGHT RES	318ti (...-09/00)	Service
 3 Series Compact (E36) (94)	SERVICE LIGHT RES	323ti (...-09/00)	Service
 3 Series Compact (E46) (00)	ABS	316ti (98-03)	TEVES ABS Mk60
 3 Series Compact (E46) (00)	ABS	318td (98-03)	TEVES ABS Mk60
 3 Series Compact (E46) (00)	ABS	318ti (98-03)	TEVES ABS Mk60
 3 Series Compact (E46) (00)	ABS	320td (98-03)	TEVES ABS Mk60

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 3 Series Compact (E46) (00	ABS	325ti (98-03)	TEVES ABS Mk60
 3 Series Compact (E46) (00	AIRBAG	316ti (01-03)	TEMIC AirBag MRS4
 3 Series Compact (E46) (00	AIRBAG	316ti (98-01)	TEMIC AirBag MRS2/3
 3 Series Compact (E46) (00	AIRBAG	318td (01-03)	TEMIC AirBag MRS4
 3 Series Compact (E46) (00	AIRBAG	318td (98-01)	TEMIC AirBag MRS2/3
 3 Series Compact (E46) (00	AIRBAG	318ti (01-03)	TEMIC AirBag MRS4
 3 Series Compact (E46) (00	AIRBAG	318ti (98-01)	TEMIC AirBag MRS2/3
 3 Series Compact (E46) (00	AIRBAG	320td (01-03)	TEMIC AirBag MRS4
 3 Series Compact (E46) (00	AIRBAG	320td (98-01)	TEMIC AirBag MRS2/3
 3 Series Compact (E46) (00	AIRBAG	325ti (01-03)	TEMIC AirBag MRS4
 3 Series Compact (E46) (00	AIRBAG	325ti (98-01)	TEMIC AirBag MRS2/3
 3 Series Compact (E46) (00	AUTOM. TRANSMISSI	316ti (01-03)	EGS GS20
 3 Series Compact (E46) (00	AUTOM. TRANSMISSI	318td (01-03)	EGS GS20
 3 Series Compact (E46) (00	AUTOM. TRANSMISSI	318ti (01-03)	EGS GS20
 3 Series Compact (E46) (00	AUTOM. TRANSMISSI	320td (01-03)	EGS GS20
 3 Series Compact (E46) (00	AUTOM. TRANSMISSI	325ti (01-03)	EGS GS20
 3 Series Compact (E46) (00	CHASSIS NETWORK	316ti (98-04)	ZKE Body Computer
 3 Series Compact (E46) (00	CHASSIS NETWORK	318td (98-04)	ZKE Body Computer
 3 Series Compact (E46) (00	CHASSIS NETWORK	318ti (98-04)	ZKE Body Computer
 3 Series Compact (E46) (00	CHASSIS NETWORK	320td (98-04)	ZKE Body Computer
 3 Series Compact (E46) (00	CHASSIS NETWORK	325ti (98-04)	ZKE Body Computer
 3 Series Compact (E46) (00	CLIMA	316ti (98-04)	BEHR/HELLA Klima
 3 Series Compact (E46) (00	CLIMA	318td (98-04)	BEHR/HELLA Klima
 3 Series Compact (E46) (00	CLIMA	318ti (98-04)	BEHR/HELLA Klima
 3 Series Compact (E46) (00	CLIMA	320td (98-04)	BEHR/HELLA Klima
 3 Series Compact (E46) (00	CLIMA	325ti (98-04)	BEHR/HELLA Klima
 3 Series Compact (E46) (00	DASHBOARD	316ti (01-03)	Kombinstrum.+Service
 3 Series Compact (E46) (00	DASHBOARD	318td (01-03)	Kombinstrum.+Service
 3 Series Compact (E46) (00	DASHBOARD	318ti (01-03)	Kombinstrum.+Service
 3 Series Compact (E46) (00	DASHBOARD	320td (01-03)	Kombinstrum.+Service
 3 Series Compact (E46) (00	DASHBOARD	325ti (01-03)	Kombinstrum.+Service
 3 Series Compact (E46) (00	ENGINE MANAGEME	316ti (01-05)	EOBD
 3 Series Compact (E46) (00	ENGINE MANAGEME	318td (03-04)	BOSCH Motronic DDE 5.0
 3 Series Compact (E46) (00	ENGINE MANAGEME	318ti (01-05)	EOBD
 3 Series Compact (E46) (00	ENGINE MANAGEME	320td 20 4D 4 (03-04)	BOSCH Motronic DDE 5.0
 3 Series Compact (E46) (00	ENGINE MANAGEME	325ti (01-05)	EOBD
 3 Series Compact (E46) (00	IMMOBILIZER	316ti (01-03)	Immobilizer EWSIII
 3 Series Compact (E46) (00	IMMOBILIZER	318td (01-03)	Immobilizer EWSIII
 3 Series Compact (E46) (00	IMMOBILIZER	318ti (01-03)	Immobilizer EWSIII
 3 Series Compact (E46) (00	IMMOBILIZER	320td (01-03)	Immobilizer EWSIII
 3 Series Compact (E46) (00	IMMOBILIZER	325ti (01-03)	Immobilizer EWSIII
 3 Series Compact (E46) (00	MAINTENANCE	316ti (...-09/00)	Service
 3 Series Compact (E46) (00	MAINTENANCE	316ti (01-03)	Kombinstrum.+Service
 3 Series Compact (E46) (00	MAINTENANCE	316ti (01-03)	Kombinstrum.+Service
 3 Series Compact (E46) (00	MAINTENANCE	316ti (01-03)	Kombinstrum.+Service
 3 Series Compact (E46) (00	MAINTENANCE	316ti (09/00-..)	MANUAL
 3 Series Compact (E46) (00	MAINTENANCE	316ti (98-04)	MANUAL
 3 Series Compact (E46) (00	MAINTENANCE	318td (...-09/00)	Service
 3 Series Compact (E46) (00	MAINTENANCE	318td (01-03)	Kombinstrum.+Service
 3 Series Compact (E46) (00	MAINTENANCE	318td (01-03)	Kombinstrum.+Service
 3 Series Compact (E46) (00	MAINTENANCE	318td (01-03)	Kombinstrum.+Service
 3 Series Compact (E46) (00	MAINTENANCE	318td (03-04)	BOSCH Motronic DDE 5.0
 3 Series Compact (E46) (00	MAINTENANCE	318td (09/00-..)	MANUAL
 3 Series Compact (E46) (00	MAINTENANCE	318td (98-04)	MANUAL
 3 Series Compact (E46) (00	MAINTENANCE	318ti (01-03)	Kombinstrum.+Service
 3 Series Compact (E46) (00	MAINTENANCE	318ti (01-03)	Kombinstrum.+Service
 3 Series Compact (E46) (00	MAINTENANCE	318ti (01-03)	Kombinstrum.+Service
 3 Series Compact (E46) (00	MAINTENANCE	318ti (98-04)	MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 3 Series Compact (E46) (00	MAINTENANCE	320td (...09/00)	Service
 3 Series Compact (E46) (00	MAINTENANCE	320td (01-03)	Kombinstrum.+Service
 3 Series Compact (E46) (00	MAINTENANCE	320td (01-03)	Kombinstrum.+Service
 3 Series Compact (E46) (00	MAINTENANCE	320td (01-03)	Kombinstrum.+Service
 3 Series Compact (E46) (00	MAINTENANCE	320td (09/00-..)	MANUAL
 3 Series Compact (E46) (00	MAINTENANCE	320td (98-04)	MANUAL
 3 Series Compact (E46) (00	MAINTENANCE	320td 20 4D 4 (03-04)	BOSCH Motronic DDE 5.0
 3 Series Compact (E46) (00	MAINTENANCE	325ti (...09/00)	Service
 3 Series Compact (E46) (00	MAINTENANCE	325ti (01-03)	Kombinstrum.+Service
 3 Series Compact (E46) (00	MAINTENANCE	325ti (01-03)	Kombinstrum.+Service
 3 Series Compact (E46) (00	MAINTENANCE	325ti (01-03)	Kombinstrum.+Service
 3 Series Compact (E46) (00	MAINTENANCE	325ti (09/00-..)	MANUAL
 3 Series Compact (E46) (00	MAINTENANCE	325ti (98-04)	MANUAL
 3 Series Compact (E46) (00	NAVIGATION	316ti (01-04)	NAV
 3 Series Compact (E46) (00	NAVIGATION	318td (01-04)	NAV
 3 Series Compact (E46) (00	NAVIGATION	318ti (01-04)	NAV
 3 Series Compact (E46) (00	NAVIGATION	320td (01-04)	NAV
 3 Series Compact (E46) (00	NAVIGATION	325ti (01-04)	NAV
 3 Series Compact (E46) (00	RAIN-LUMINOSITY S	316ti (98-04)	RLS
 3 Series Compact (E46) (00	RAIN-LUMINOSITY S	318td (98-04)	RLS
 3 Series Compact (E46) (00	RAIN-LUMINOSITY S	318ti (98-04)	RLS
 3 Series Compact (E46) (00	RAIN-LUMINOSITY S	320td (98-04)	RLS
 3 Series Compact (E46) (00	RAIN-LUMINOSITY S	325ti (98-04)	RLS
 3 Series Compact (E46) (00	REMOTE CONTROL E	316ti (98-04)	MANUAL
 3 Series Compact (E46) (00	REMOTE CONTROL E	318td (98-04)	MANUAL
 3 Series Compact (E46) (00	REMOTE CONTROL E	318ti (98-04)	MANUAL
 3 Series Compact (E46) (00	REMOTE CONTROL E	320td (98-04)	MANUAL
 3 Series Compact (E46) (00	REMOTE CONTROL E	325ti (98-04)	MANUAL
 3 Series Compact (E46) (00	SERVICE LIGHT RES	316ti (...09/00)	Service
 3 Series Compact (E46) (00	SERVICE LIGHT RES	316ti (09/00-..)	MANUAL
 3 Series Compact (E46) (00	SERVICE LIGHT RES	318td (...09/00)	Service
 3 Series Compact (E46) (00	SERVICE LIGHT RES	318td (09/00-..)	MANUAL
 3 Series Compact (E46) (00	SERVICE LIGHT RES	320td (...09/00)	Service
 3 Series Compact (E46) (00	SERVICE LIGHT RES	320td (09/00-..)	MANUAL
 3 Series Compact (E46) (00	SERVICE LIGHT RES	325ti (...09/00)	Service
 3 Series Compact (E46) (00	SERVICE LIGHT RES	325ti (09/00-..)	MANUAL
 3 Series Compact (E46) (00	STEERING COLUMN	316ti (98-04)	KOSTAL LWS
 3 Series Compact (E46) (00	STEERING COLUMN	320td (98-04)	KOSTAL LWS
 3 Series Compact (E46) (00	VISUAL./TELEMATIC	316ti (98-04)	Alpine BM
 3 Series Compact (E46) (00	VISUAL./TELEMATIC	318td (98-04)	Alpine BM
 3 Series Compact (E46) (00	VISUAL./TELEMATIC	320td (98-04)	Alpine BM
 5 Series (E28) (86-88)	ENGINE MANAGEME	525e 27 6K B (86-88)	BOSCH Motronic DME M1.1
 5 Series (E28) (86-88)	MAINTENANCE	525e (...09/00)	Service
 5 Series (E28) (86-88)	SERVICE LIGHT RES	525e (...09/00)	Service
 5 Series (E34) (88-96)	ABS	518g (89-95)	BOSCH ABS 3
 5 Series (E34) (88-96)	ABS	518i (89-95)	BOSCH ABS 3
 5 Series (E34) (88-96)	ABS	520i (89-95)	BOSCH ABS 3
 5 Series (E34) (88-96)	ABS	524td (89-95)	BOSCH ABS 3
 5 Series (E34) (88-96)	ABS	525i (89-95)	BOSCH ABS 3
 5 Series (E34) (88-96)	ABS	525ix (89-95)	BOSCH ABS 3
 5 Series (E34) (88-96)	ABS	525td (89-95)	BOSCH ABS 3
 5 Series (E34) (88-96)	ABS	525tds (89-95)	BOSCH ABS 3
 5 Series (E34) (88-96)	ABS	530i (89-95)	BOSCH ABS 3
 5 Series (E34) (88-96)	ABS	535i (89-95)	BOSCH ABS 3
 5 Series (E34) (88-96)	ABS	540i (89-95)	BOSCH ABS 3
 5 Series (E34) (88-96)	ABS	M5 (89-95)	BOSCH ABS 3
 5 Series (E34) (88-96)	AIRBAG	518g (89-95)	TEMIC AirBag BAE
 5 Series (E34) (88-96)	AIRBAG	518i (89-95)	TEMIC AirBag BAE

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 5 Series (E34) (88-96)	AIRBAG	520i (89-95)	TEMIC AirBag BAE
 5 Series (E34) (88-96)	AIRBAG	524td (89-95)	TEMIC AirBag BAE
 5 Series (E34) (88-96)	AIRBAG	525i (89-95)	TEMIC AirBag BAE
 5 Series (E34) (88-96)	AIRBAG	525ix (89-95)	TEMIC AirBag BAE
 5 Series (E34) (88-96)	AIRBAG	525td (89-95)	TEMIC AirBag BAE
 5 Series (E34) (88-96)	AIRBAG	525tds (89-95)	TEMIC AirBag BAE
 5 Series (E34) (88-96)	AIRBAG	530i (89-95)	TEMIC AirBag BAE
 5 Series (E34) (88-96)	AIRBAG	535i (89-95)	TEMIC AirBag BAE
 5 Series (E34) (88-96)	AIRBAG	540i (89-95)	TEMIC AirBag BAE
 5 Series (E34) (88-96)	AIRBAG	M5 (89-95)	TEMIC AirBag BAE
 5 Series (E34) (88-96)	ENGINE MANAGEME	518i 18 4E 1 (89-91)	BOSCH Motronic DME M1.3
 5 Series (E34) (88-96)	ENGINE MANAGEME	518i 18 4E 1 (91-94)	BOSCH Motronic DME M1.7
 5 Series (E34) (88-96)	ENGINE MANAGEME	518i 18 4E 2 (94-96)	BOSCH Motronic DME M1.7.2
 5 Series (E34) (88-96)	ENGINE MANAGEME	518i 18 4E 2 (95-96)	BOSCH Motronic DME M1.7.3
 5 Series (E34) (88-96)	ENGINE MANAGEME	520i 20 6K A (87-90)	BOSCH Motronic DME M1.3
 5 Series (E34) (88-96)	ENGINE MANAGEME	520i 20 6S 1 (89-92)	BOSCH Motronic DME M3.1
 5 Series (E34) (88-96)	ENGINE MANAGEME	520i 20 6S 1 (89-92)	BOSCH Motronic DME M3.1R
 5 Series (E34) (88-96)	ENGINE MANAGEME	520i 20 6S 2 (91-92)	SIEMENS MPI DME MS 40.0
 5 Series (E34) (88-96)	ENGINE MANAGEME	520i 20 6S 2 (92-96)	SIEMENS MPI DME MS 40.1
 5 Series (E34) (88-96)	ENGINE MANAGEME	520i 25 6S 2 (89-92)	BOSCH Motronic DME 3.1R
 5 Series (E34) (88-96)	ENGINE MANAGEME	524td 24 6T B (87-93)	BOSCH EDC DDE 1
 5 Series (E34) (88-96)	ENGINE MANAGEME	525i 20 6S 1 (88-92)	BOSCH Motronic DME M3.1
 5 Series (E34) (88-96)	ENGINE MANAGEME	525i 25 6S 2 (92-95)	BOSCH Motronic DME3.3.1/3.3.2
 5 Series (E34) (88-96)	ENGINE MANAGEME	525i 25 6S 2 (92-96)	BOSCH Motronic DME M3.3.1
 5 Series (E34) (88-96)	ENGINE MANAGEME	525ix 20 6S 1 (89-92)	BOSCH Motronic DME M3.1
 5 Series (E34) (88-96)	ENGINE MANAGEME	525ix 25 6S 2 (92-95)	BOSCH Motronic DME M3.3.1
 5 Series (E34) (88-96)	ENGINE MANAGEME	525tds 25 6T 1 (91-95)	BOSCH EDC DDE 2
 5 Series (E34) (88-96)	ENGINE MANAGEME	525tds 25 6T 1 (93-95)	BOSCH EDC DDE 2
 5 Series (E34) (88-96)	ENGINE MANAGEME	525tds 25 6T 1 (95-96)	BOSCH EDC DDE 2.1
 5 Series (E34) (88-96)	ENGINE MANAGEME	525tds 25 6T 1 (95-96)	BOSCH EDC DDE 2.1
 5 Series (E34) (88-96)	ENGINE MANAGEME	530i 30 6K A (88-88)	BOSCH Motronic DME M1.1
 5 Series (E34) (88-96)	ENGINE MANAGEME	530i 30 6K A (88-90)	BOSCH Motronic DME M1.3
 5 Series (E34) (88-96)	ENGINE MANAGEME	530i 30 8S 1 (95-96)	BOSCH Motronic DME M3.3
 5 Series (E34) (88-96)	ENGINE MANAGEME	535i 34 6K B (88-92)	BOSCH Motronic DME M1.3
 5 Series (E34) (88-96)	ENGINE MANAGEME	540i 40 8S 1 (95-96)	BOSCH Motronic DME M3.3
 5 Series (E34) (88-96)	ENGINE MANAGEME	M5 36 6S 1 (88-92)	BOSCH Motronic DME M1.2
 5 Series (E34) (88-96)	ENGINE MANAGEME	M5 38 6S 1 (92-96)	BOSCH Motronic DME M3.3
 5 Series (E34) (88-96)	MAINTENANCE	518g	MANUAL
 5 Series (E34) (88-96)	MAINTENANCE	518g (...-09/00)	Service
 5 Series (E34) (88-96)	MAINTENANCE	518i	MANUAL
 5 Series (E34) (88-96)	MAINTENANCE	518i (...-09/00)	Service
 5 Series (E34) (88-96)	MAINTENANCE	520i	MANUAL
 5 Series (E34) (88-96)	MAINTENANCE	520i (...-09/00)	Service
 5 Series (E34) (88-96)	MAINTENANCE	524td	MANUAL
 5 Series (E34) (88-96)	MAINTENANCE	524td (...-09/00)	Service
 5 Series (E34) (88-96)	MAINTENANCE	525i	MANUAL
 5 Series (E34) (88-96)	MAINTENANCE	525i (...-09/00)	Service
 5 Series (E34) (88-96)	MAINTENANCE	525ix	MANUAL
 5 Series (E34) (88-96)	MAINTENANCE	525ix (...-09/00)	Service
 5 Series (E34) (88-96)	MAINTENANCE	525td	MANUAL
 5 Series (E34) (88-96)	MAINTENANCE	525td (...-09/00)	Service
 5 Series (E34) (88-96)	MAINTENANCE	525tds	MANUAL
 5 Series (E34) (88-96)	MAINTENANCE	525tds (...-09/00)	Service
 5 Series (E34) (88-96)	MAINTENANCE	530i	MANUAL
 5 Series (E34) (88-96)	MAINTENANCE	530i (...-09/00)	Service
 5 Series (E34) (88-96)	MAINTENANCE	535i	MANUAL
 5 Series (E34) (88-96)	MAINTENANCE	535i (...-09/00)	Service
 5 Series (E34) (88-96)	MAINTENANCE	540i	MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 5 Series (E34) (88-96)	MAINTENANCE	540i (...-09/00)	Service
 5 Series (E34) (88-96)	MAINTENANCE	M5	MANUAL
 5 Series (E34) (88-96)	MAINTENANCE	M5 (...-09/00)	Service
 5 Series (E34) (88-96)	REMOTE CONTROL E	518g	MANUAL
 5 Series (E34) (88-96)	REMOTE CONTROL E	518i	MANUAL
 5 Series (E34) (88-96)	REMOTE CONTROL E	520i	MANUAL
 5 Series (E34) (88-96)	REMOTE CONTROL E	524td	MANUAL
 5 Series (E34) (88-96)	REMOTE CONTROL E	525i	MANUAL
 5 Series (E34) (88-96)	REMOTE CONTROL E	525ix	MANUAL
 5 Series (E34) (88-96)	REMOTE CONTROL E	525td	MANUAL
 5 Series (E34) (88-96)	REMOTE CONTROL E	525tds	MANUAL
 5 Series (E34) (88-96)	REMOTE CONTROL E	530i	MANUAL
 5 Series (E34) (88-96)	REMOTE CONTROL E	535i	MANUAL
 5 Series (E34) (88-96)	REMOTE CONTROL E	540i	MANUAL
 5 Series (E34) (88-96)	REMOTE CONTROL E	M5	MANUAL
 5 Series (E34) (88-96)	SERVICE LIGHT RES	518g (...-09/00)	Service
 5 Series (E34) (88-96)	SERVICE LIGHT RES	518i (...-09/00)	Service
 5 Series (E34) (88-96)	SERVICE LIGHT RES	520i (...-09/00)	Service
 5 Series (E34) (88-96)	SERVICE LIGHT RES	524td (...-09/00)	Service
 5 Series (E34) (88-96)	SERVICE LIGHT RES	525i (...-09/00)	Service
 5 Series (E34) (88-96)	SERVICE LIGHT RES	525ix (...-09/00)	Service
 5 Series (E34) (88-96)	SERVICE LIGHT RES	525td (...-09/00)	Service
 5 Series (E34) (88-96)	SERVICE LIGHT RES	525tds (...-09/00)	Service
 5 Series (E34) (88-96)	SERVICE LIGHT RES	530i (...-09/00)	Service
 5 Series (E34) (88-96)	SERVICE LIGHT RES	535i (...-09/00)	Service
 5 Series (E34) (88-96)	SERVICE LIGHT RES	540i (...-09/00)	Service
 5 Series (E34) (88-96)	SERVICE LIGHT RES	M5 (...-09/00)	Service
 5 Series (E39) (95-04)	ABS + TRACT. CONT	520d (94-99)	BOSCH ABS/ASC 5
 5 Series (E39) (95-04)	ABS + TRACT. CONT	520d (98-..)	BOSCH ABS/ASR 5.7
 5 Series (E39) (95-04)	ABS + TRACT. CONT	520d (98-..)	BOSCH ABS/DSC 5.7
 5 Series (E39) (95-04)	ABS + TRACT. CONT	520i (94-99)	BOSCH ABS/ASC 5
 5 Series (E39) (95-04)	ABS + TRACT. CONT	520i (98-..)	BOSCH ABS/ASR 5.7
 5 Series (E39) (95-04)	ABS + TRACT. CONT	520i (98-..)	BOSCH ABS/DSC 5.7
 5 Series (E39) (95-04)	ABS + TRACT. CONT	523i (94-99)	BOSCH ABS/ASC 5
 5 Series (E39) (95-04)	ABS + TRACT. CONT	523i (98-..)	BOSCH ABS/ASR 5.7
 5 Series (E39) (95-04)	ABS + TRACT. CONT	523i (98-..)	BOSCH ABS/DSC 5.7
 5 Series (E39) (95-04)	ABS + TRACT. CONT	525d (94-99)	BOSCH ABS/ASC 5
 5 Series (E39) (95-04)	ABS + TRACT. CONT	525d (98-..)	BOSCH ABS/ASR 5.7
 5 Series (E39) (95-04)	ABS + TRACT. CONT	525d (98-..)	BOSCH ABS/DSC 5.7
 5 Series (E39) (95-04)	ABS + TRACT. CONT	525i (94-99)	BOSCH ABS/ASC 5
 5 Series (E39) (95-04)	ABS + TRACT. CONT	525i (98-..)	BOSCH ABS/ASR 5.7
 5 Series (E39) (95-04)	ABS + TRACT. CONT	525i (98-..)	BOSCH ABS/DSC 5.7
 5 Series (E39) (95-04)	ABS + TRACT. CONT	525td (94-99)	BOSCH ABS/ASC 5
 5 Series (E39) (95-04)	ABS + TRACT. CONT	525td (98-..)	BOSCH ABS/ASR 5.7
 5 Series (E39) (95-04)	ABS + TRACT. CONT	525td (98-..)	BOSCH ABS/DSC 5.7
 5 Series (E39) (95-04)	ABS + TRACT. CONT	525tds (94-99)	BOSCH ABS/ASC 5
 5 Series (E39) (95-04)	ABS + TRACT. CONT	525tds (98-..)	BOSCH ABS/ASR 5.7
 5 Series (E39) (95-04)	ABS + TRACT. CONT	525tds (98-..)	BOSCH ABS/DSC 5.7
 5 Series (E39) (95-04)	ABS + TRACT. CONT	528i (94-99)	BOSCH ABS/ASC 5
 5 Series (E39) (95-04)	ABS + TRACT. CONT	528i (98-..)	BOSCH ABS/ASR 5.7
 5 Series (E39) (95-04)	ABS + TRACT. CONT	528i (98-..)	BOSCH ABS/DSC 5.7
 5 Series (E39) (95-04)	ABS + TRACT. CONT	530d (94-99)	BOSCH ABS/ASC 5
 5 Series (E39) (95-04)	ABS + TRACT. CONT	530d (98-..)	BOSCH ABS/ASR 5.7
 5 Series (E39) (95-04)	ABS + TRACT. CONT	530d (98-..)	BOSCH ABS/DSC 5.7
 5 Series (E39) (95-04)	ABS + TRACT. CONT	530i (94-99)	BOSCH ABS/ASC 5
 5 Series (E39) (95-04)	ABS + TRACT. CONT	530i (98-..)	BOSCH ABS/ASR 5.7
 5 Series (E39) (95-04)	ABS + TRACT. CONT	530i (98-..)	BOSCH ABS/DSC 5.7
5 Series (E39) (95-04)	ABS + TRACT. CONT	535i (94-99)	BOSCH ABS/ASC 5

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 5 Series (E39) (95-04)	ABS + TRACT. CONT	535i (98-..)	BOSCH ABS/ASR 5.7
 5 Series (E39) (95-04)	ABS + TRACT. CONT	535i (98-..)	BOSCH ABS/DSC 5.7
 5 Series (E39) (95-04)	ABS + TRACT. CONT	540i (94-99)	BOSCH ABS/ASC 5
 5 Series (E39) (95-04)	ABS + TRACT. CONT	540i (98-..)	BOSCH ABS/ASR 5.7
 5 Series (E39) (95-04)	ABS + TRACT. CONT	540i (98-..)	BOSCH ABS/DSC 5.7
 5 Series (E39) (95-04)	ABS + TRACT. CONT	M5 (94-99)	BOSCH ABS/ASC 5
 5 Series (E39) (95-04)	ABS + TRACT. CONT	M5 (98-..)	BOSCH ABS/ASR 5.7
 5 Series (E39) (95-04)	ABS + TRACT. CONT	M5 (98-..)	BOSCH ABS/DSC 5.7
 5 Series (E39) (95-04)	AIRBAG	520d (01-03)	TEMIC AirBag MRS4
 5 Series (E39) (95-04)	AIRBAG	520d (95-97)	TEMIC AirBag ZAE2 5999
 5 Series (E39) (95-04)	AIRBAG	520d (98-01)	TEMIC AirBag MRS2/3
 5 Series (E39) (95-04)	AIRBAG	520i (01-03)	TEMIC AirBag MRS4
 5 Series (E39) (95-04)	AIRBAG	520i (95-97)	TEMIC AirBag ZAE2 5999
 5 Series (E39) (95-04)	AIRBAG	520i (98-01)	TEMIC AirBag MRS2/3
 5 Series (E39) (95-04)	AIRBAG	523i (01-03)	TEMIC AirBag MRS4
 5 Series (E39) (95-04)	AIRBAG	523i (95-97)	TEMIC AirBag ZAE2 5999
 5 Series (E39) (95-04)	AIRBAG	523i (98-01)	TEMIC AirBag MRS2/3
 5 Series (E39) (95-04)	AIRBAG	525d (01-03)	TEMIC AirBag MRS4
 5 Series (E39) (95-04)	AIRBAG	525d (95-97)	TEMIC AirBag ZAE2 5999
 5 Series (E39) (95-04)	AIRBAG	525d (98-01)	TEMIC AirBag MRS2/3
 5 Series (E39) (95-04)	AIRBAG	525i (01-03)	TEMIC AirBag MRS4
 5 Series (E39) (95-04)	AIRBAG	525i (95-97)	TEMIC AirBag ZAE2 5999
 5 Series (E39) (95-04)	AIRBAG	525i (98-01)	TEMIC AirBag MRS2/3
 5 Series (E39) (95-04)	AIRBAG	525td (01-03)	TEMIC AirBag MRS4
 5 Series (E39) (95-04)	AIRBAG	525td (95-97)	TEMIC AirBag ZAE2 5999
 5 Series (E39) (95-04)	AIRBAG	525td (98-01)	TEMIC AirBag MRS2/3
 5 Series (E39) (95-04)	AIRBAG	525tds (01-03)	TEMIC AirBag MRS4
 5 Series (E39) (95-04)	AIRBAG	525tds (95-97)	TEMIC AirBag ZAE2 5999
 5 Series (E39) (95-04)	AIRBAG	525tds (98-01)	TEMIC AirBag MRS2/3
 5 Series (E39) (95-04)	AIRBAG	528i (01-03)	TEMIC AirBag MRS4
 5 Series (E39) (95-04)	AIRBAG	528i (95-97)	TEMIC AirBag ZAE2 5999
 5 Series (E39) (95-04)	AIRBAG	528i (98-01)	TEMIC AirBag MRS2/3
 5 Series (E39) (95-04)	AIRBAG	530d (01-03)	TEMIC AirBag MRS4
 5 Series (E39) (95-04)	AIRBAG	530d (95-97)	TEMIC AirBag ZAE2 5999
 5 Series (E39) (95-04)	AIRBAG	530d (98-01)	TEMIC AirBag MRS2/3
 5 Series (E39) (95-04)	AIRBAG	530i (01-03)	TEMIC AirBag MRS4
 5 Series (E39) (95-04)	AIRBAG	530i (95-97)	TEMIC AirBag ZAE2 5999
 5 Series (E39) (95-04)	AIRBAG	530i (98-01)	TEMIC AirBag MRS2/3
 5 Series (E39) (95-04)	AIRBAG	535i (01-03)	TEMIC AirBag MRS4
 5 Series (E39) (95-04)	AIRBAG	535i (95-97)	TEMIC AirBag ZAE2 5999
 5 Series (E39) (95-04)	AIRBAG	535i (98-01)	TEMIC AirBag MRS2/3
 5 Series (E39) (95-04)	AIRBAG	540i (01-03)	TEMIC AirBag MRS4
 5 Series (E39) (95-04)	AIRBAG	540i (95-97)	TEMIC AirBag ZAE2 5999
 5 Series (E39) (95-04)	AIRBAG	540i (98-01)	TEMIC AirBag MRS2/3
 5 Series (E39) (95-04)	AIRBAG	M5 (01-03)	TEMIC AirBag MRS4
 5 Series (E39) (95-04)	AIRBAG	M5 (95-97)	TEMIC AirBag ZAE2 5999
 5 Series (E39) (95-04)	AIRBAG	M5 (98-01)	TEMIC AirBag MRS2/3
 5 Series (E39) (95-04)	AUTOM. TRANSMISSI	520d (01-03)	EGS GS20
 5 Series (E39) (95-04)	AUTOM. TRANSMISSI	520i (01-03)	EGS GS20
 5 Series (E39) (95-04)	AUTOM. TRANSMISSI	523i (01-03)	EGS GS20
 5 Series (E39) (95-04)	AUTOM. TRANSMISSI	525d (01-03)	EGS GS20
 5 Series (E39) (95-04)	AUTOM. TRANSMISSI	525i (01-03)	EGS GS20
 5 Series (E39) (95-04)	AUTOM. TRANSMISSI	525td (01-03)	EGS GS20
 5 Series (E39) (95-04)	AUTOM. TRANSMISSI	525tds (01-03)	EGS GS20
 5 Series (E39) (95-04)	AUTOM. TRANSMISSI	528i (01-03)	EGS GS20
 5 Series (E39) (95-04)	AUTOM. TRANSMISSI	530d (01-03)	EGS GS20
 5 Series (E39) (95-04)	AUTOM. TRANSMISSI	530i (01-03)	EGS GS20
 5 Series (E39) (95-04)	AUTOM. TRANSMISSI	535i (01-03)	EGS GS20

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 5 Series (E39) (95-04)	AUTOM. TRANSMISSI	540i (01-03)	EGS GS20
 5 Series (E39) (95-04)	AUTOM. TRANSMISSI	M5 (01-03)	EGS GS20
 5 Series (E39) (95-04)	CLIMA	520d (01-03)	IHKA Klima
 5 Series (E39) (95-04)	CLIMA	520i (01-03)	IHKA Klima
 5 Series (E39) (95-04)	CLIMA	523i (01-03)	IHKA Klima
 5 Series (E39) (95-04)	CLIMA	525d (01-03)	IHKA Klima
 5 Series (E39) (95-04)	CLIMA	525i (01-03)	IHKA Klima
 5 Series (E39) (95-04)	CLIMA	525td (01-03)	IHKA Klima
 5 Series (E39) (95-04)	CLIMA	525tds (01-03)	IHKA Klima
 5 Series (E39) (95-04)	CLIMA	528i (01-03)	IHKA Klima
 5 Series (E39) (95-04)	CLIMA	530d (01-03)	IHKA Klima
 5 Series (E39) (95-04)	CLIMA	530i (01-03)	IHKA Klima
 5 Series (E39) (95-04)	CLIMA	535i (01-03)	IHKA Klima
 5 Series (E39) (95-04)	CLIMA	540i (01-03)	IHKA Klima
 5 Series (E39) (95-04)	CLIMA	M5 (01-03)	IHKA Klima
 5 Series (E39) (95-04)	ELECTRONIC TRIM	520d (01-03)	Kostal EHC
 5 Series (E39) (95-04)	ELECTRONIC TRIM	520i (01-03)	Kostal EHC
 5 Series (E39) (95-04)	ELECTRONIC TRIM	523i (01-03)	Kostal EHC
 5 Series (E39) (95-04)	ELECTRONIC TRIM	525d (01-03)	Kostal EHC
 5 Series (E39) (95-04)	ELECTRONIC TRIM	525i (01-03)	Kostal EHC
 5 Series (E39) (95-04)	ELECTRONIC TRIM	525td (01-03)	Kostal EHC
 5 Series (E39) (95-04)	ELECTRONIC TRIM	525tds (01-03)	Kostal EHC
 5 Series (E39) (95-04)	ELECTRONIC TRIM	528i (01-03)	Kostal EHC
 5 Series (E39) (95-04)	ELECTRONIC TRIM	530d (01-03)	Kostal EHC
 5 Series (E39) (95-04)	ELECTRONIC TRIM	530i (01-03)	Kostal EHC
 5 Series (E39) (95-04)	ELECTRONIC TRIM	535i (01-03)	Kostal EHC
 5 Series (E39) (95-04)	ELECTRONIC TRIM	540i (01-03)	Kostal EHC
 5 Series (E39) (95-04)	ELECTRONIC TRIM	M5 (01-03)	Kostal EHC
 5 Series (E39) (95-04)	ENGINE MANAGEME	520d 20 4D 1 (98-01)	BOSCH EDC 15 M DDE 3.0
 5 Series (E39) (95-04)	ENGINE MANAGEME	520i (00-04)	SIEMENS MPI DME MS 43.0
 5 Series (E39) (95-04)	ENGINE MANAGEME	520i (01-04)	EOBD
 5 Series (E39) (95-04)	ENGINE MANAGEME	520i 20 6S 3 (95-96)	SIEMENS MPI DME MS 41.0
 5 Series (E39) (95-04)	ENGINE MANAGEME	523i 24 6S 4 (01-04)	EOBD
 5 Series (E39) (95-04)	ENGINE MANAGEME	525d (01-..)	EOBD
 5 Series (E39) (95-04)	ENGINE MANAGEME	525i (00-04)	SIEMENS MPI DME MS 43.0
 5 Series (E39) (95-04)	ENGINE MANAGEME	525i 25 6S 3 (95-96)	SIEMENS MPI DME MS 41.0
 5 Series (E39) (95-04)	ENGINE MANAGEME	525tds 25 6D 1 (08/98-..)	BOSCH EDC 15 C4 DDE 4.0
 5 Series (E39) (95-04)	ENGINE MANAGEME	525tds 25 6T 1 (97-99)	BOSCH EDC DDE 2.2 M51
 5 Series (E39) (95-04)	ENGINE MANAGEME	525tds 25 6T 1 (97-99)	BOSCH EDC DDE 2.2 M51
 5 Series (E39) (95-04)	ENGINE MANAGEME	528i (01-04)	EOBD
 5 Series (E39) (95-04)	ENGINE MANAGEME	528i 28 6S 1 (95-96)	SIEMENS MPI DME MS 41.0
 5 Series (E39) (95-04)	ENGINE MANAGEME	530d 30 6D 1 (08/98-..)	BOSCH EDC 15 C4 DDE 4.0
 5 Series (E39) (95-04)	ENGINE MANAGEME	530i 30 6S 3 (00-04)	SIEMENS MPI DME MS 43.0
 5 Series (E39) (95-04)	ENGINE MANAGEME	535i (01-04)	EOBD
 5 Series (E39) (95-04)	ENGINE MANAGEME	540i (01-04)	EOBD
 5 Series (E39) (95-04)	ENGINE MANAGEME	M5 (01-04)	EOBD
 5 Series (E39) (95-04)	MAINTENANCE	520d	MANUAL
 5 Series (E39) (95-04)	MAINTENANCE	520d (...09/00)	Service
 5 Series (E39) (95-04)	MAINTENANCE	520d (09/00-..)	MANUAL
 5 Series (E39) (95-04)	MAINTENANCE	520i	MANUAL
 5 Series (E39) (95-04)	MAINTENANCE	520i (...09/00)	Service
 5 Series (E39) (95-04)	MAINTENANCE	520i (09/00-..)	MANUAL
 5 Series (E39) (95-04)	MAINTENANCE	523i	MANUAL
 5 Series (E39) (95-04)	MAINTENANCE	523i (09/00-..)	MANUAL
 5 Series (E39) (95-04)	MAINTENANCE	525d	MANUAL
 5 Series (E39) (95-04)	MAINTENANCE	525d (...09/00)	Service
 5 Series (E39) (95-04)	MAINTENANCE	525d (09/00-..)	MANUAL
 5 Series (E39) (95-04)	MAINTENANCE	525i	MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 5 Series (E39) (95-04)	MAINTENANCE	525i (.-09/00)	Service
 5 Series (E39) (95-04)	MAINTENANCE	525i (09/00-..)	MANUAL
 5 Series (E39) (95-04)	MAINTENANCE	525td	MANUAL
 5 Series (E39) (95-04)	MAINTENANCE	525td (.-09/00)	Service
 5 Series (E39) (95-04)	MAINTENANCE	525td (09/00-..)	MANUAL
 5 Series (E39) (95-04)	MAINTENANCE	525tds	MANUAL
 5 Series (E39) (95-04)	MAINTENANCE	525tds (.-09/00)	Service
 5 Series (E39) (95-04)	MAINTENANCE	525tds (09/00-..)	MANUAL
 5 Series (E39) (95-04)	MAINTENANCE	528i	MANUAL
 5 Series (E39) (95-04)	MAINTENANCE	528i (.-09/00)	Service
 5 Series (E39) (95-04)	MAINTENANCE	528i (09/00-..)	MANUAL
 5 Series (E39) (95-04)	MAINTENANCE	530d	MANUAL
 5 Series (E39) (95-04)	MAINTENANCE	530d (.-09/00)	Service
 5 Series (E39) (95-04)	MAINTENANCE	530d (09/00-..)	MANUAL
 5 Series (E39) (95-04)	MAINTENANCE	530i	MANUAL
 5 Series (E39) (95-04)	MAINTENANCE	530i (.-09/00)	Service
 5 Series (E39) (95-04)	MAINTENANCE	530i (09/00-..)	MANUAL
 5 Series (E39) (95-04)	MAINTENANCE	535i	MANUAL
 5 Series (E39) (95-04)	MAINTENANCE	535i (09/00-..)	MANUAL
 5 Series (E39) (95-04)	MAINTENANCE	540i	MANUAL
 5 Series (E39) (95-04)	MAINTENANCE	540i (09/00-..)	MANUAL
 5 Series (E39) (95-04)	MAINTENANCE	M5	MANUAL
 5 Series (E39) (95-04)	MAINTENANCE	M5 (09/00-..)	MANUAL
 5 Series (E39) (95-04)	REMOTE CONTROL E	520d	MANUAL
 5 Series (E39) (95-04)	REMOTE CONTROL E	520i	MANUAL
 5 Series (E39) (95-04)	REMOTE CONTROL E	523i	MANUAL
 5 Series (E39) (95-04)	REMOTE CONTROL E	525d	MANUAL
 5 Series (E39) (95-04)	REMOTE CONTROL E	525i	MANUAL
 5 Series (E39) (95-04)	REMOTE CONTROL E	525td	MANUAL
 5 Series (E39) (95-04)	REMOTE CONTROL E	525tds	MANUAL
 5 Series (E39) (95-04)	REMOTE CONTROL E	528i	MANUAL
 5 Series (E39) (95-04)	REMOTE CONTROL E	530d	MANUAL
 5 Series (E39) (95-04)	REMOTE CONTROL E	530i	MANUAL
 5 Series (E39) (95-04)	REMOTE CONTROL E	535i	MANUAL
 5 Series (E39) (95-04)	REMOTE CONTROL E	540i	MANUAL
 5 Series (E39) (95-04)	REMOTE CONTROL E	M5	MANUAL
 5 Series (E39) (95-04)	SERVICE LIGHT RES	520d (.-09/00)	Service
 5 Series (E39) (95-04)	SERVICE LIGHT RES	520d (09/00-..)	MANUAL
 5 Series (E39) (95-04)	SERVICE LIGHT RES	520i (.-09/00)	Service
 5 Series (E39) (95-04)	SERVICE LIGHT RES	520i (09/00-..)	MANUAL
 5 Series (E39) (95-04)	SERVICE LIGHT RES	523i (09/00-..)	MANUAL
 5 Series (E39) (95-04)	SERVICE LIGHT RES	525d (.-09/00)	Service
 5 Series (E39) (95-04)	SERVICE LIGHT RES	525d (09/00-..)	MANUAL
 5 Series (E39) (95-04)	SERVICE LIGHT RES	525i (.-09/00)	Service
 5 Series (E39) (95-04)	SERVICE LIGHT RES	525i (09/00-..)	MANUAL
 5 Series (E39) (95-04)	SERVICE LIGHT RES	525td (.-09/00)	Service
 5 Series (E39) (95-04)	SERVICE LIGHT RES	525td (09/00-..)	MANUAL
 5 Series (E39) (95-04)	SERVICE LIGHT RES	525tds (.-09/00)	Service
 5 Series (E39) (95-04)	SERVICE LIGHT RES	525tds (09/00-..)	MANUAL
 5 Series (E39) (95-04)	SERVICE LIGHT RES	528i (.-09/00)	Service
 5 Series (E39) (95-04)	SERVICE LIGHT RES	528i (09/00-..)	MANUAL
 5 Series (E39) (95-04)	SERVICE LIGHT RES	530d (.-09/00)	Service
 5 Series (E39) (95-04)	SERVICE LIGHT RES	530d (09/00-..)	MANUAL
 5 Series (E39) (95-04)	SERVICE LIGHT RES	530i (.-09/00)	Service
 5 Series (E39) (95-04)	SERVICE LIGHT RES	530i (09/00-..)	MANUAL
 5 Series (E39) (95-04)	SERVICE LIGHT RES	535i (09/00-..)	MANUAL
 5 Series (E39) (95-04)	SERVICE LIGHT RES	540i (09/00-..)	MANUAL
 5 Series (E39) (95-04)	SERVICE LIGHT RES	M5 (09/00-..)	MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 5 Series (E60-E61) (03-10)	ABS + TRACT. CONT	520d (03-05)	BOSCH DSC
 5 Series (E60-E61) (03-10)	ABS + TRACT. CONT	520i (03-05)	BOSCH DSC
 5 Series (E60-E61) (03-10)	ABS + TRACT. CONT	523i (03-05)	BOSCH DSC
 5 Series (E60-E61) (03-10)	ABS + TRACT. CONT	525d (03-05)	BOSCH DSC
 5 Series (E60-E61) (03-10)	ABS + TRACT. CONT	525i (03-07)	BOSCH DSC
 5 Series (E60-E61) (03-10)	ABS + TRACT. CONT	525xd (03-05)	BOSCH DSC
 5 Series (E60-E61) (03-10)	ABS + TRACT. CONT	525xi (03-05)	BOSCH DSC
 5 Series (E60-E61) (03-10)	ABS + TRACT. CONT	530d (03-05)	BOSCH DSC
 5 Series (E60-E61) (03-10)	ABS + TRACT. CONT	530i (03-05)	BOSCH DSC
 5 Series (E60-E61) (03-10)	ABS + TRACT. CONT	530xd (05-07)	BOSCH DSC
 5 Series (E60-E61) (03-10)	ABS + TRACT. CONT	530xi (03-05)	BOSCH DSC
 5 Series (E60-E61) (03-10)	ABS + TRACT. CONT	535d (03-05)	BOSCH DSC
 5 Series (E60-E61) (03-10)	ABS + TRACT. CONT	540i (03-05)	BOSCH DSC
 5 Series (E60-E61) (03-10)	ABS + TRACT. CONT	545i (03-05)	BOSCH DSC
 5 Series (E60-E61) (03-10)	ABS + TRACT. CONT	550i (03-05)	BOSCH DSC
 5 Series (E60-E61) (03-10)	ABS + TRACT. CONT	M5 (03-05)	BOSCH DSC
 5 Series (E60-E61) (03-10)	AIRBAG	520d (03-05)	Autoliv SRS SBSL (Left Side)
 5 Series (E60-E61) (03-10)	AIRBAG	520d (03-05)	Autoliv SRS SBSR (Right Side)
 5 Series (E60-E61) (03-10)	AIRBAG	520d (03-05)	DELPHI SRS SFZ Satellite Central
 5 Series (E60-E61) (03-10)	AIRBAG	520d (03-05)	SRS SGM-SIM Central
 5 Series (E60-E61) (03-10)	AIRBAG	520d (05-07)	TEMIC-Autoliv ACSM MRS5
 5 Series (E60-E61) (03-10)	AIRBAG	520i (03-05)	Autoliv SRS SBSL (Left Side)
 5 Series (E60-E61) (03-10)	AIRBAG	520i (03-05)	Autoliv SRS SBSR (Right Side)
 5 Series (E60-E61) (03-10)	AIRBAG	520i (03-05)	DELPHI SRS SFZ Satellite Central
 5 Series (E60-E61) (03-10)	AIRBAG	520i (03-05)	SRS SGM-SIM Central
 5 Series (E60-E61) (03-10)	AIRBAG	520i (05-07)	TEMIC-Autoliv ACSM MRS5
 5 Series (E60-E61) (03-10)	AIRBAG	523i (03-05)	Autoliv SRS SBSL (Left Side)
 5 Series (E60-E61) (03-10)	AIRBAG	523i (03-05)	Autoliv SRS SBSR (Right Side)
 5 Series (E60-E61) (03-10)	AIRBAG	523i (03-05)	DELPHI SRS SFZ Satellite Central
 5 Series (E60-E61) (03-10)	AIRBAG	523i (03-05)	SRS SGM-SIM Central
 5 Series (E60-E61) (03-10)	AIRBAG	523i (05-07)	TEMIC-Autoliv ACSM MRS5
 5 Series (E60-E61) (03-10)	AIRBAG	525d (03-05)	Autoliv SRS SBSL (Left Side)
 5 Series (E60-E61) (03-10)	AIRBAG	525d (03-05)	Autoliv SRS SBSR (Right Side)
 5 Series (E60-E61) (03-10)	AIRBAG	525d (03-05)	DELPHI SRS SFZ Satellite Central
 5 Series (E60-E61) (03-10)	AIRBAG	525d (03-05)	SRS SGM-SIM Central
 5 Series (E60-E61) (03-10)	AIRBAG	525d (05-07)	TEMIC-Autoliv ACSM MRS5
 5 Series (E60-E61) (03-10)	AIRBAG	525i (03-05)	Autoliv SRS SBSL (Left Side)
 5 Series (E60-E61) (03-10)	AIRBAG	525i (03-05)	Autoliv SRS SBSR (Right Side)
 5 Series (E60-E61) (03-10)	AIRBAG	525i (03-05)	DELPHI SRS SFZ Satellite Central
 5 Series (E60-E61) (03-10)	AIRBAG	525i (03-05)	SRS SGM-SIM Central
 5 Series (E60-E61) (03-10)	AIRBAG	525i (05-07)	TEMIC-Autoliv ACSM MRS5
 5 Series (E60-E61) (03-10)	AIRBAG	525xd (03-05)	Autoliv SRS SBSL (Left Side)
 5 Series (E60-E61) (03-10)	AIRBAG	525xd (03-05)	Autoliv SRS SBSR (Right Side)
 5 Series (E60-E61) (03-10)	AIRBAG	525xd (03-05)	DELPHI SRS SFZ Satellite Central
 5 Series (E60-E61) (03-10)	AIRBAG	525xd (03-05)	SRS SGM-SIM Central
 5 Series (E60-E61) (03-10)	AIRBAG	525xd (05-07)	TEMIC-Autoliv ACSM MRS5
 5 Series (E60-E61) (03-10)	AIRBAG	525xi (03-05)	Autoliv SRS SBSL (Left Side)
 5 Series (E60-E61) (03-10)	AIRBAG	525xi (03-05)	Autoliv SRS SBSR (Right Side)
 5 Series (E60-E61) (03-10)	AIRBAG	525xi (03-05)	DELPHI SRS SFZ Satellite Central
 5 Series (E60-E61) (03-10)	AIRBAG	525xi (03-05)	SRS SGM-SIM Central
 5 Series (E60-E61) (03-10)	AIRBAG	525xi (05-07)	TEMIC-Autoliv ACSM MRS5
 5 Series (E60-E61) (03-10)	AIRBAG	530d (03-05)	Autoliv SRS SBSL (Left Side)
 5 Series (E60-E61) (03-10)	AIRBAG	530d (03-05)	Autoliv SRS SBSR (Right Side)
 5 Series (E60-E61) (03-10)	AIRBAG	530d (03-05)	DELPHI SRS SFZ Satellite Central
 5 Series (E60-E61) (03-10)	AIRBAG	530d (03-05)	SRS SGM-SIM Central
 5 Series (E60-E61) (03-10)	AIRBAG	530d (05-07)	TEMIC-Autoliv ACSM MRS5
 5 Series (E60-E61) (03-10)	AIRBAG	530i (03-05)	Autoliv SRS SBSL (Left Side)
 5 Series (E60-E61) (03-10)	AIRBAG	530i (03-05)	Autoliv SRS SBSR (Right Side)

Systems supported by ECUREADER / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 5 Series (E60-E61) (03-10)	AIRBAG	530i (03-05)	DELPHI SRS SFZ Satellite Central
 5 Series (E60-E61) (03-10)	AIRBAG	530i (03-05)	SRS SGM-SIM Central
 5 Series (E60-E61) (03-10)	AIRBAG	530i (05-07)	TEMIC-Autoliv ACSM MRS5
 5 Series (E60-E61) (03-10)	AIRBAG	530xd (05-07)	Autoliv SRS SBSL (Left Side)
 5 Series (E60-E61) (03-10)	AIRBAG	530xd (05-07)	Autoliv SRS SBSR (Right Side)
 5 Series (E60-E61) (03-10)	AIRBAG	530xd (05-07)	DELPHI SRS SFZ Satellite Central
 5 Series (E60-E61) (03-10)	AIRBAG	530xd (05-07)	SRS SGM-SIM Central
 5 Series (E60-E61) (03-10)	AIRBAG	530xd (05-07)	TEMIC-Autoliv ACSM MRS5
 5 Series (E60-E61) (03-10)	AIRBAG	530xi (03-05)	Autoliv SRS SBSL (Left Side)
 5 Series (E60-E61) (03-10)	AIRBAG	530xi (03-05)	Autoliv SRS SBSR (Right Side)
 5 Series (E60-E61) (03-10)	AIRBAG	530xi (03-05)	DELPHI SRS SFZ Satellite Central
 5 Series (E60-E61) (03-10)	AIRBAG	530xi (03-05)	SRS SGM-SIM Central
 5 Series (E60-E61) (03-10)	AIRBAG	530xi (05-07)	TEMIC-Autoliv ACSM MRS5
 5 Series (E60-E61) (03-10)	AIRBAG	535d (03-05)	Autoliv SRS SBSL (Left Side)
 5 Series (E60-E61) (03-10)	AIRBAG	535d (03-05)	Autoliv SRS SBSR (Right Side)
 5 Series (E60-E61) (03-10)	AIRBAG	535d (03-05)	DELPHI SRS SFZ Satellite Central
 5 Series (E60-E61) (03-10)	AIRBAG	535d (03-05)	SRS SGM-SIM Central
 5 Series (E60-E61) (03-10)	AIRBAG	535d (05-07)	TEMIC-Autoliv ACSM MRS5
 5 Series (E60-E61) (03-10)	AIRBAG	540i (03-05)	Autoliv SRS SBSL (Left Side)
 5 Series (E60-E61) (03-10)	AIRBAG	540i (03-05)	Autoliv SRS SBSR (Right Side)
 5 Series (E60-E61) (03-10)	AIRBAG	540i (03-05)	DELPHI SRS SFZ Satellite Central
 5 Series (E60-E61) (03-10)	AIRBAG	540i (03-05)	SRS SGM-SIM Central
 5 Series (E60-E61) (03-10)	AIRBAG	540i (05-07)	TEMIC-Autoliv ACSM MRS5
 5 Series (E60-E61) (03-10)	AIRBAG	545i (03-05)	Autoliv SRS SBSL (Left Side)
 5 Series (E60-E61) (03-10)	AIRBAG	545i (03-05)	Autoliv SRS SBSR (Right Side)
 5 Series (E60-E61) (03-10)	AIRBAG	545i (03-05)	DELPHI SRS SFZ Satellite Central
 5 Series (E60-E61) (03-10)	AIRBAG	545i (03-05)	SRS SGM-SIM Central
 5 Series (E60-E61) (03-10)	AIRBAG	545i (05-07)	TEMIC-Autoliv ACSM MRS5
 5 Series (E60-E61) (03-10)	AIRBAG	550i (03-05)	Autoliv SRS SBSL (Left Side)
 5 Series (E60-E61) (03-10)	AIRBAG	550i (03-05)	Autoliv SRS SBSR (Right Side)
 5 Series (E60-E61) (03-10)	AIRBAG	550i (03-05)	DELPHI SRS SFZ Satellite Central
 5 Series (E60-E61) (03-10)	AIRBAG	550i (03-05)	SRS SGM-SIM Central
 5 Series (E60-E61) (03-10)	AIRBAG	550i (05-07)	TEMIC-Autoliv ACSM MRS5
 5 Series (E60-E61) (03-10)	AIRBAG	M5 (03-05)	Autoliv SRS SBSL (Left Side)
 5 Series (E60-E61) (03-10)	AIRBAG	M5 (03-05)	Autoliv SRS SBSR (Right Side)
 5 Series (E60-E61) (03-10)	AIRBAG	M5 (03-05)	DELPHI SRS SFZ Satellite Central
 5 Series (E60-E61) (03-10)	AIRBAG	M5 (03-05)	SRS SGM-SIM Central
 5 Series (E60-E61) (03-10)	AIRBAG	M5 (05-07)	TEMIC-Autoliv ACSM MRS5
 5 Series (E60-E61) (03-10)	ANTITHEFT	520d (05-07)	Gemel SINE
 5 Series (E60-E61) (03-10)	ANTITHEFT	520d (05-07)	Megamos DWA
 5 Series (E60-E61) (03-10)	ANTITHEFT	520i (05-07)	Gemel SINE
 5 Series (E60-E61) (03-10)	ANTITHEFT	520i (05-07)	Megamos DWA
 5 Series (E60-E61) (03-10)	ANTITHEFT	523i (05-07)	Gemel SINE
 5 Series (E60-E61) (03-10)	ANTITHEFT	523i (05-07)	Megamos DWA
 5 Series (E60-E61) (03-10)	ANTITHEFT	525d (05-07)	Gemel SINE
 5 Series (E60-E61) (03-10)	ANTITHEFT	525d (05-07)	Megamos DWA
 5 Series (E60-E61) (03-10)	ANTITHEFT	525i (05-07)	Gemel SINE
 5 Series (E60-E61) (03-10)	ANTITHEFT	525i (05-07)	Megamos DWA
 5 Series (E60-E61) (03-10)	ANTITHEFT	525xd (05-07)	Gemel SINE
 5 Series (E60-E61) (03-10)	ANTITHEFT	525xd (05-07)	Megamos DWA
 5 Series (E60-E61) (03-10)	ANTITHEFT	525xi (05-07)	Gemel SINE
 5 Series (E60-E61) (03-10)	ANTITHEFT	525xi (05-07)	Megamos DWA
 5 Series (E60-E61) (03-10)	ANTITHEFT	530d (05-07)	Gemel SINE
 5 Series (E60-E61) (03-10)	ANTITHEFT	530d (05-07)	Megamos DWA
 5 Series (E60-E61) (03-10)	ANTITHEFT	530i (05-07)	Gemel SINE
 5 Series (E60-E61) (03-10)	ANTITHEFT	530i (05-07)	Megamos DWA
 5 Series (E60-E61) (03-10)	ANTITHEFT	530xd (05-07)	Gemel SINE
 5 Series (E60-E61) (03-10)	ANTITHEFT	530xd (05-07)	Megamos DWA

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 5 Series (E60-E61) (03-10)	ANTITHEFT	530xi (05-07)	Gemel SINE
 5 Series (E60-E61) (03-10)	ANTITHEFT	530xi (05-07)	Megamos DWA
 5 Series (E60-E61) (03-10)	ANTITHEFT	535d (05-07)	Gemel SINE
 5 Series (E60-E61) (03-10)	ANTITHEFT	535d (05-07)	Megamos DWA
 5 Series (E60-E61) (03-10)	ANTITHEFT	540i (05-07)	Gemel SINE
 5 Series (E60-E61) (03-10)	ANTITHEFT	540i (05-07)	Megamos DWA
 5 Series (E60-E61) (03-10)	ANTITHEFT	545i (05-07)	Gemel SINE
 5 Series (E60-E61) (03-10)	ANTITHEFT	545i (05-07)	Megamos DWA
 5 Series (E60-E61) (03-10)	ANTITHEFT	550i (05-07)	Gemel SINE
 5 Series (E60-E61) (03-10)	ANTITHEFT	550i (05-07)	Megamos DWA
 5 Series (E60-E61) (03-10)	ANTITHEFT	M5 (05-07)	Gemel SINE
 5 Series (E60-E61) (03-10)	ANTITHEFT	M5 (05-07)	Megamos DWA
 5 Series (E60-E61) (03-10)	AUTOM. TRANSMISSI	520d (05-07)	EGS
 5 Series (E60-E61) (03-10)	AUTOM. TRANSMISSI	520i (05-07)	EGS
 5 Series (E60-E61) (03-10)	AUTOM. TRANSMISSI	523i (05-07)	EGS
 5 Series (E60-E61) (03-10)	AUTOM. TRANSMISSI	525d (05-07)	EGS
 5 Series (E60-E61) (03-10)	AUTOM. TRANSMISSI	525i (05-07)	EGS
 5 Series (E60-E61) (03-10)	AUTOM. TRANSMISSI	525xd (05-07)	EGS
 5 Series (E60-E61) (03-10)	AUTOM. TRANSMISSI	525xi (05-07)	EGS
 5 Series (E60-E61) (03-10)	AUTOM. TRANSMISSI	530d (05-07)	EGS
 5 Series (E60-E61) (03-10)	AUTOM. TRANSMISSI	530i (05-07)	EGS
 5 Series (E60-E61) (03-10)	AUTOM. TRANSMISSI	530xd (05-07)	EGS
 5 Series (E60-E61) (03-10)	AUTOM. TRANSMISSI	530xi (05-07)	EGS
 5 Series (E60-E61) (03-10)	AUTOM. TRANSMISSI	535d (05-07)	EGS
 5 Series (E60-E61) (03-10)	AUTOM. TRANSMISSI	540i (05-07)	EGS
 5 Series (E60-E61) (03-10)	AUTOM. TRANSMISSI	545i (05-07)	EGS
 5 Series (E60-E61) (03-10)	AUTOM. TRANSMISSI	550i (05-07)	EGS
 5 Series (E60-E61) (03-10)	AUTOM. TRANSMISSI	M5 (05-07)	EGS
 5 Series (E60-E61) (03-10)	BATTERY CHARGER	520d (03-05)	Gateway
 5 Series (E60-E61) (03-10)	BATTERY CHARGER	520i (03-05)	Gateway
 5 Series (E60-E61) (03-10)	BATTERY CHARGER	523i (03-05)	Gateway
 5 Series (E60-E61) (03-10)	BATTERY CHARGER	525d (03-05)	Gateway
 5 Series (E60-E61) (03-10)	BATTERY CHARGER	525i (03-05)	Gateway
 5 Series (E60-E61) (03-10)	BATTERY CHARGER	525xd (03-05)	Gateway
 5 Series (E60-E61) (03-10)	BATTERY CHARGER	525xi (03-05)	Gateway
 5 Series (E60-E61) (03-10)	BATTERY CHARGER	530d (03-05)	Gateway
 5 Series (E60-E61) (03-10)	BATTERY CHARGER	530i (03-05)	Gateway
 5 Series (E60-E61) (03-10)	BATTERY CHARGER	530xd (03-05)	Gateway
 5 Series (E60-E61) (03-10)	BATTERY CHARGER	530xi (03-05)	Gateway
 5 Series (E60-E61) (03-10)	BATTERY CHARGER	535d (03-05)	Gateway
 5 Series (E60-E61) (03-10)	BATTERY CHARGER	540i (03-05)	Gateway
 5 Series (E60-E61) (03-10)	BATTERY CHARGER	545i (03-05)	Gateway
 5 Series (E60-E61) (03-10)	BATTERY CHARGER	550i (03-05)	Gateway
 5 Series (E60-E61) (03-10)	BATTERY CHARGER	M5 (03-05)	Gateway
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	520d (03-05)	VDO CCC-GW Gateway
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	520d (05-07)	LOEWE-LEAR Chassis Gateway
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	520d (05-07)	SIEMENS Base Module
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	520i (03-05)	VDO CCC-GW Gateway
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	520i (05-07)	LOEWE-LEAR Chassis Gateway
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	520i (05-07)	SIEMENS Base Module
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	523i (03-05)	VDO CCC-GW Gateway
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	523i (05-07)	LOEWE-LEAR Chassis Gateway
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	523i (05-07)	SIEMENS Base Module
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	525d (03-05)	VDO CCC-GW Gateway
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	525d (05-07)	LOEWE-LEAR Chassis Gateway
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	525d (05-07)	SIEMENS Base Module
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	525i (03-05)	VDO CCC-GW Gateway
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	525i (05-07)	LOEWE-LEAR Chassis Gateway

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	525i (05-07)	SIEMENS Base Module
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	525xd (03-05)	VDO CCC-GW Gateway
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	525xd (05-07)	LOEWE-LEAR Chassis Gateway
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	525xd (05-07)	SIEMENS Base Module
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	525xi (03-05)	VDO CCC-GW Gateway
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	525xi (05-07)	LOEWE-LEAR Chassis Gateway
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	525xi (05-07)	SIEMENS Base Module
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	530d (03-05)	VDO CCC-GW Gateway
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	530d (05-07)	LOEWE-LEAR Chassis Gateway
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	530d (05-07)	SIEMENS Base Module
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	530i (03-05)	VDO CCC-GW Gateway
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	530i (05-07)	LOEWE-LEAR Chassis Gateway
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	530i (05-07)	SIEMENS Base Module
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	530xd (03-05)	VDO CCC-GW Gateway
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	530xd (05-07)	LOEWE-LEAR Chassis Gateway
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	530xd (05-07)	SIEMENS Base Module
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	530xi (03-05)	VDO CCC-GW Gateway
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	530xi (05-07)	LOEWE-LEAR Chassis Gateway
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	530xi (05-07)	SIEMENS Base Module
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	535d (03-05)	VDO CCC-GW Gateway
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	535d (05-07)	LOEWE-LEAR Chassis Gateway
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	535d (05-07)	SIEMENS Base Module
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	540i (03-05)	VDO CCC-GW Gateway
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	540i (05-07)	LOEWE-LEAR Chassis Gateway
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	540i (05-07)	SIEMENS Base Module
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	545i (03-05)	VDO CCC-GW Gateway
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	545i (05-07)	LOEWE-LEAR Chassis Gateway
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	545i (05-07)	SIEMENS Base Module
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	550i (03-05)	VDO CCC-GW Gateway
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	550i (05-07)	LOEWE-LEAR Chassis Gateway
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	550i (05-07)	SIEMENS Base Module
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	M5 (03-05)	VDO CCC-GW Gateway
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	M5 (05-07)	LOEWE-LEAR Chassis Gateway
 5 Series (E60-E61) (03-10)	CHASSIS NETWORK	M5 (05-07)	SIEMENS Base Module
 5 Series (E60-E61) (03-10)	CLIMA	520d (05-07)	PREH Gmbh Klimautomatik
 5 Series (E60-E61) (03-10)	CLIMA	520d (09-10)	IHKA60 2
 5 Series (E60-E61) (03-10)	CLIMA	520i (05-07)	PREH Gmbh Klimautomatik
 5 Series (E60-E61) (03-10)	CLIMA	520i (09-10)	IHKA60 2
 5 Series (E60-E61) (03-10)	CLIMA	523i (05-07)	PREH Gmbh Klimautomatik
 5 Series (E60-E61) (03-10)	CLIMA	523i (09-10)	IHKA60 2
 5 Series (E60-E61) (03-10)	CLIMA	525d (05-07)	PREH Gmbh Klimautomatik
 5 Series (E60-E61) (03-10)	CLIMA	525d (09-10)	IHKA60 2
 5 Series (E60-E61) (03-10)	CLIMA	525i (05-07)	PREH Gmbh Klimautomatik
 5 Series (E60-E61) (03-10)	CLIMA	525i (09-10)	IHKA60 2
 5 Series (E60-E61) (03-10)	CLIMA	525xd (05-07)	PREH Gmbh Klimautomatik
 5 Series (E60-E61) (03-10)	CLIMA	525xd (09-10)	IHKA60 2
 5 Series (E60-E61) (03-10)	CLIMA	525xi (05-07)	PREH Gmbh Klimautomatik
 5 Series (E60-E61) (03-10)	CLIMA	525xi (09-10)	IHKA60 2
 5 Series (E60-E61) (03-10)	CLIMA	530d (05-07)	PREH Gmbh Klimautomatik
 5 Series (E60-E61) (03-10)	CLIMA	530d (09-10)	IHKA60 2
 5 Series (E60-E61) (03-10)	CLIMA	530i (05-07)	PREH Gmbh Klimautomatik
 5 Series (E60-E61) (03-10)	CLIMA	530i (09-10)	IHKA60 2
 5 Series (E60-E61) (03-10)	CLIMA	530xd (05-07)	PREH Gmbh Klimautomatik
 5 Series (E60-E61) (03-10)	CLIMA	530xd (09-10)	IHKA60 2
 5 Series (E60-E61) (03-10)	CLIMA	530xi (05-07)	PREH Gmbh Klimautomatik
 5 Series (E60-E61) (03-10)	CLIMA	530xi (09-10)	IHKA60 2
 5 Series (E60-E61) (03-10)	CLIMA	535d (05-07)	PREH Gmbh Klimautomatik
 5 Series (E60-E61) (03-10)	CLIMA	535d (09-10)	IHKA60 2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 5 Series (E60-E61) (03-10)	CLIMA	540i (05-07)	PREH Gmbh Klimautomatik
 5 Series (E60-E61) (03-10)	CLIMA	540i (09-10)	IHKA60 2
 5 Series (E60-E61) (03-10)	CLIMA	545i (05-07)	PREH Gmbh Klimautomatik
 5 Series (E60-E61) (03-10)	CLIMA	545i (09-10)	IHKA60 2
 5 Series (E60-E61) (03-10)	CLIMA	550i (05-07)	PREH Gmbh Klimautomatik
 5 Series (E60-E61) (03-10)	CLIMA	550i (09-10)	IHKA60 2
 5 Series (E60-E61) (03-10)	CLIMA	M5 (05-07)	PREH Gmbh Klimautomatik
 5 Series (E60-E61) (03-10)	CLIMA	M5 (09-10)	IHKA60 2
 5 Series (E60-E61) (03-10)	COMFORT SYSTEM	520d (03-07)	Eaton SZM
 5 Series (E60-E61) (03-10)	COMFORT SYSTEM	520i (03-07)	Eaton SZM
 5 Series (E60-E61) (03-10)	COMFORT SYSTEM	523i (03-07)	Eaton SZM
 5 Series (E60-E61) (03-10)	COMFORT SYSTEM	525d (03-07)	Eaton SZM
 5 Series (E60-E61) (03-10)	COMFORT SYSTEM	525i (03-07)	Eaton SZM
 5 Series (E60-E61) (03-10)	COMFORT SYSTEM	525xd (03-07)	Eaton SZM
 5 Series (E60-E61) (03-10)	COMFORT SYSTEM	525xi (03-07)	Eaton SZM
 5 Series (E60-E61) (03-10)	COMFORT SYSTEM	530d (03-07)	Eaton SZM
 5 Series (E60-E61) (03-10)	COMFORT SYSTEM	530i (03-07)	Eaton SZM
 5 Series (E60-E61) (03-10)	COMFORT SYSTEM	530xd (03-07)	Eaton SZM
 5 Series (E60-E61) (03-10)	COMFORT SYSTEM	530xi (03-07)	Eaton SZM
 5 Series (E60-E61) (03-10)	COMFORT SYSTEM	535d (03-07)	Eaton SZM
 5 Series (E60-E61) (03-10)	COMFORT SYSTEM	540i (03-07)	Eaton SZM
 5 Series (E60-E61) (03-10)	COMFORT SYSTEM	545i (03-07)	Eaton SZM
 5 Series (E60-E61) (03-10)	COMFORT SYSTEM	550i (03-07)	Eaton SZM
 5 Series (E60-E61) (03-10)	COMFORT SYSTEM	M5 (03-07)	Eaton SZM
 5 Series (E60-E61) (03-10)	CONV. TOP/SUNROO	520d (05-07)	SIEMENS WideRoof
 5 Series (E60-E61) (03-10)	CONV. TOP/SUNROO	520i (05-07)	SIEMENS WideRoof
 5 Series (E60-E61) (03-10)	CONV. TOP/SUNROO	523i (05-07)	SIEMENS WideRoof
 5 Series (E60-E61) (03-10)	CONV. TOP/SUNROO	525d (05-07)	SIEMENS WideRoof
 5 Series (E60-E61) (03-10)	CONV. TOP/SUNROO	525i (05-07)	SIEMENS WideRoof
 5 Series (E60-E61) (03-10)	CONV. TOP/SUNROO	525xd (05-07)	SIEMENS WideRoof
 5 Series (E60-E61) (03-10)	CONV. TOP/SUNROO	525xi (05-07)	SIEMENS WideRoof
 5 Series (E60-E61) (03-10)	CONV. TOP/SUNROO	530d (05-07)	SIEMENS WideRoof
 5 Series (E60-E61) (03-10)	CONV. TOP/SUNROO	530i (05-07)	SIEMENS WideRoof
 5 Series (E60-E61) (03-10)	CONV. TOP/SUNROO	530xd (05-07)	SIEMENS WideRoof
 5 Series (E60-E61) (03-10)	CONV. TOP/SUNROO	530xi (05-07)	SIEMENS WideRoof
 5 Series (E60-E61) (03-10)	CONV. TOP/SUNROO	535d (05-07)	SIEMENS WideRoof
 5 Series (E60-E61) (03-10)	CONV. TOP/SUNROO	540i (05-07)	SIEMENS WideRoof
 5 Series (E60-E61) (03-10)	CONV. TOP/SUNROO	545i (05-07)	SIEMENS WideRoof
 5 Series (E60-E61) (03-10)	CONV. TOP/SUNROO	550i (05-07)	SIEMENS WideRoof
 5 Series (E60-E61) (03-10)	CONV. TOP/SUNROO	M5 (05-07)	SIEMENS WideRoof
 5 Series (E60-E61) (03-10)	DASHBOARD	520d (05-07)	VDO Kombinstrum.
 5 Series (E60-E61) (03-10)	DASHBOARD	520d (09-10)	KOMB60
 5 Series (E60-E61) (03-10)	DASHBOARD	520i (05-07)	VDO Kombinstrum.
 5 Series (E60-E61) (03-10)	DASHBOARD	520i (09-10)	KOMB60
 5 Series (E60-E61) (03-10)	DASHBOARD	523i (05-07)	VDO Kombinstrum.
 5 Series (E60-E61) (03-10)	DASHBOARD	523i (09-10)	KOMB60
 5 Series (E60-E61) (03-10)	DASHBOARD	525d (05-07)	VDO Kombinstrum.
 5 Series (E60-E61) (03-10)	DASHBOARD	525d (09-10)	KOMB60
 5 Series (E60-E61) (03-10)	DASHBOARD	525i (05-07)	VDO Kombinstrum.
 5 Series (E60-E61) (03-10)	DASHBOARD	525i (09-10)	KOMB60
 5 Series (E60-E61) (03-10)	DASHBOARD	525xd (05-07)	VDO Kombinstrum.
 5 Series (E60-E61) (03-10)	DASHBOARD	525xd (09-10)	KOMB60
 5 Series (E60-E61) (03-10)	DASHBOARD	525xi (05-07)	VDO Kombinstrum.
 5 Series (E60-E61) (03-10)	DASHBOARD	525xi (09-10)	KOMB60
 5 Series (E60-E61) (03-10)	DASHBOARD	530d (05-07)	VDO Kombinstrum.
 5 Series (E60-E61) (03-10)	DASHBOARD	530d (09-10)	KOMB60
 5 Series (E60-E61) (03-10)	DASHBOARD	530i (05-07)	VDO Kombinstrum.
 5 Series (E60-E61) (03-10)	DASHBOARD	530i (09-10)	KOMB60

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 5 Series (E60-E61) (03-10)	DASHBOARD	530xd (05-07)	VDO Kombinstrum.
 5 Series (E60-E61) (03-10)	DASHBOARD	530xd (09-10)	KOMB60
 5 Series (E60-E61) (03-10)	DASHBOARD	530xi (05-07)	VDO Kombinstrum.
 5 Series (E60-E61) (03-10)	DASHBOARD	530xi (09-10)	KOMB60
 5 Series (E60-E61) (03-10)	DASHBOARD	535d (05-07)	VDO Kombinstrum.
 5 Series (E60-E61) (03-10)	DASHBOARD	535d (09-10)	KOMB60
 5 Series (E60-E61) (03-10)	DASHBOARD	540i (05-07)	VDO Kombinstrum.
 5 Series (E60-E61) (03-10)	DASHBOARD	540i (09-10)	KOMB60
 5 Series (E60-E61) (03-10)	DASHBOARD	545i (05-07)	VDO Kombinstrum.
 5 Series (E60-E61) (03-10)	DASHBOARD	545i (09-10)	KOMB60
 5 Series (E60-E61) (03-10)	DASHBOARD	550i (05-07)	VDO Kombinstrum.
 5 Series (E60-E61) (03-10)	DASHBOARD	550i (09-10)	KOMB60
 5 Series (E60-E61) (03-10)	DASHBOARD	M5 (05-07)	VDO Kombinstrum.
 5 Series (E60-E61) (03-10)	DASHBOARD	M5 (09-10)	KOMB60
 5 Series (E60-E61) (03-10)	DIFFERENTIAL MANA	520d (09-10)	VGSG90
 5 Series (E60-E61) (03-10)	DIFFERENTIAL MANA	520i (09-10)	VGSG90
 5 Series (E60-E61) (03-10)	DIFFERENTIAL MANA	523i (09-10)	VGSG90
 5 Series (E60-E61) (03-10)	DIFFERENTIAL MANA	525d (09-10)	VGSG90
 5 Series (E60-E61) (03-10)	DIFFERENTIAL MANA	525i (09-10)	VGSG90
 5 Series (E60-E61) (03-10)	DIFFERENTIAL MANA	525xd (09-10)	VGSG90
 5 Series (E60-E61) (03-10)	DIFFERENTIAL MANA	525xi (09-10)	VGSG90
 5 Series (E60-E61) (03-10)	DIFFERENTIAL MANA	530d (09-10)	VGSG90
 5 Series (E60-E61) (03-10)	DIFFERENTIAL MANA	530i (09-10)	VGSG90
 5 Series (E60-E61) (03-10)	DIFFERENTIAL MANA	530xd (09-10)	VGSG90
 5 Series (E60-E61) (03-10)	DIFFERENTIAL MANA	530xi (09-10)	VGSG90
 5 Series (E60-E61) (03-10)	DIFFERENTIAL MANA	535d (09-10)	VGSG90
 5 Series (E60-E61) (03-10)	DIFFERENTIAL MANA	540i (09-10)	VGSG90
 5 Series (E60-E61) (03-10)	DIFFERENTIAL MANA	545i (09-10)	VGSG90
 5 Series (E60-E61) (03-10)	DIFFERENTIAL MANA	550i (09-10)	VGSG90
 5 Series (E60-E61) (03-10)	DIFFERENTIAL MANA	M5 (09-10)	VGSG90
 5 Series (E60-E61) (03-10)	DIGITAL RADIO TUNE	520d (05-07)	Megamos Audio System
 5 Series (E60-E61) (03-10)	DIGITAL RADIO TUNE	520i (05-07)	Megamos Audio System
 5 Series (E60-E61) (03-10)	DIGITAL RADIO TUNE	523i (05-07)	Megamos Audio System
 5 Series (E60-E61) (03-10)	DIGITAL RADIO TUNE	525d (05-07)	Megamos Audio System
 5 Series (E60-E61) (03-10)	DIGITAL RADIO TUNE	525i (05-07)	Megamos Audio System
 5 Series (E60-E61) (03-10)	DIGITAL RADIO TUNE	525xd (05-07)	Megamos Audio System
 5 Series (E60-E61) (03-10)	DIGITAL RADIO TUNE	525xi (05-07)	Megamos Audio System
 5 Series (E60-E61) (03-10)	DIGITAL RADIO TUNE	530d (05-07)	Megamos Audio System
 5 Series (E60-E61) (03-10)	DIGITAL RADIO TUNE	530i (05-07)	Megamos Audio System
 5 Series (E60-E61) (03-10)	DIGITAL RADIO TUNE	530xd (05-07)	Megamos Audio System
 5 Series (E60-E61) (03-10)	DIGITAL RADIO TUNE	530xi (05-07)	Megamos Audio System
 5 Series (E60-E61) (03-10)	DIGITAL RADIO TUNE	535d (05-07)	Megamos Audio System
 5 Series (E60-E61) (03-10)	DIGITAL RADIO TUNE	540i (05-07)	Megamos Audio System
 5 Series (E60-E61) (03-10)	DIGITAL RADIO TUNE	545i (05-07)	Megamos Audio System
 5 Series (E60-E61) (03-10)	DIGITAL RADIO TUNE	550i (05-07)	Megamos Audio System
 5 Series (E60-E61) (03-10)	DIGITAL RADIO TUNE	M5 (05-07)	Megamos Audio System
 5 Series (E60-E61) (03-10)	DRIVER SEAT CONT	520d (05-07)	Driver Seat
 5 Series (E60-E61) (03-10)	DRIVER SEAT CONT	520i (05-07)	Driver Seat
 5 Series (E60-E61) (03-10)	DRIVER SEAT CONT	523i (05-07)	Driver Seat
 5 Series (E60-E61) (03-10)	DRIVER SEAT CONT	525d (05-07)	Driver Seat
 5 Series (E60-E61) (03-10)	DRIVER SEAT CONT	525i (05-07)	Driver Seat
 5 Series (E60-E61) (03-10)	DRIVER SEAT CONT	525xd (05-07)	Driver Seat
 5 Series (E60-E61) (03-10)	DRIVER SEAT CONT	525xi (05-07)	Driver Seat
 5 Series (E60-E61) (03-10)	DRIVER SEAT CONT	530d (05-07)	Driver Seat
 5 Series (E60-E61) (03-10)	DRIVER SEAT CONT	530i (05-07)	Driver Seat
 5 Series (E60-E61) (03-10)	DRIVER SEAT CONT	530xd (05-07)	Driver Seat
 5 Series (E60-E61) (03-10)	DRIVER SEAT CONT	530xi (05-07)	Driver Seat
 5 Series (E60-E61) (03-10)	DRIVER SEAT CONT	535d (05-07)	Driver Seat

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 5 Series (E60-E61) (03-10)	DRIVER SEAT CONT	540i (05-07)	Driver Seat
 5 Series (E60-E61) (03-10)	DRIVER SEAT CONT	545i (05-07)	Driver Seat
 5 Series (E60-E61) (03-10)	DRIVER SEAT CONT	550i (05-07)	Driver Seat
 5 Series (E60-E61) (03-10)	DRIVER SEAT CONT	M5 (05-07)	Driver Seat
 5 Series (E60-E61) (03-10)	ENGINE MANAGEME	520d (03-10)	EOBD
 5 Series (E60-E61) (03-10)	ENGINE MANAGEME	520i (03-10)	EOBD
 5 Series (E60-E61) (03-10)	ENGINE MANAGEME	523i (03-10)	EOBD
 5 Series (E60-E61) (03-10)	ENGINE MANAGEME	525d 25 6D 3 (03-07)	BOSCH DDE 6.0
 5 Series (E60-E61) (03-10)	ENGINE MANAGEME	525i 25 6S 3 (03-07)	SIEMENS MPI DME MS 45.1
 5 Series (E60-E61) (03-10)	ENGINE MANAGEME	525xd 25 6D 3 (03-07)	BOSCH DDE 6.0
 5 Series (E60-E61) (03-10)	ENGINE MANAGEME	525xi (03-10)	EOBD
 5 Series (E60-E61) (03-10)	ENGINE MANAGEME	530d 30 6D 3 (03-07)	BOSCH DDE 6
 5 Series (E60-E61) (03-10)	ENGINE MANAGEME	530i 30 6S 3 (03-07)	SIEMENS MPI DME MS 45.1
 5 Series (E60-E61) (03-10)	ENGINE MANAGEME	530xd 30 6D 3 (03-07)	BOSCH DDE 6
 5 Series (E60-E61) (03-10)	ENGINE MANAGEME	530xi 30 6S 3 (03-07)	SIEMENS MPI DME MS 45.1
 5 Series (E60-E61) (03-10)	ENGINE MANAGEME	535d 30 6D 4 (03-07)	BOSCH DDE 6
 5 Series (E60-E61) (03-10)	ENGINE MANAGEME	540i (03-10)	EOBD
 5 Series (E60-E61) (03-10)	ENGINE MANAGEME	545i (03-10)	EOBD
 5 Series (E60-E61) (03-10)	ENGINE MANAGEME	550i (03-10)	EOBD
 5 Series (E60-E61) (03-10)	ENGINE MANAGEME	M5 (03-10)	EOBD
 5 Series (E60-E61) (03-10)	FUEL PUMP MANAGE	520d (05-07)	EKPS
 5 Series (E60-E61) (03-10)	FUEL PUMP MANAGE	520i (05-07)	EKPS
 5 Series (E60-E61) (03-10)	FUEL PUMP MANAGE	523i (05-07)	EKPS
 5 Series (E60-E61) (03-10)	FUEL PUMP MANAGE	525d (05-07)	EKPS
 5 Series (E60-E61) (03-10)	FUEL PUMP MANAGE	525i (05-07)	EKPS
 5 Series (E60-E61) (03-10)	FUEL PUMP MANAGE	525xd (05-07)	EKPS
 5 Series (E60-E61) (03-10)	FUEL PUMP MANAGE	525xi (05-07)	EKPS
 5 Series (E60-E61) (03-10)	FUEL PUMP MANAGE	530d (05-07)	EKPS
 5 Series (E60-E61) (03-10)	FUEL PUMP MANAGE	530i (05-07)	EKPS
 5 Series (E60-E61) (03-10)	FUEL PUMP MANAGE	530xd (05-07)	EKPS
 5 Series (E60-E61) (03-10)	FUEL PUMP MANAGE	530xi (05-07)	EKPS
 5 Series (E60-E61) (03-10)	FUEL PUMP MANAGE	535d (05-07)	EKPS
 5 Series (E60-E61) (03-10)	FUEL PUMP MANAGE	540i (05-07)	EKPS
 5 Series (E60-E61) (03-10)	FUEL PUMP MANAGE	545i (05-07)	EKPS
 5 Series (E60-E61) (03-10)	FUEL PUMP MANAGE	550i (05-07)	EKPS
 5 Series (E60-E61) (03-10)	FUEL PUMP MANAGE	M5 (05-07)	EKPS
 5 Series (E60-E61) (03-10)	GEARBOX MANAGEM	520d (05-07)	VTG
 5 Series (E60-E61) (03-10)	GEARBOX MANAGEM	520i (05-07)	VTG
 5 Series (E60-E61) (03-10)	GEARBOX MANAGEM	523i (05-07)	VTG
 5 Series (E60-E61) (03-10)	GEARBOX MANAGEM	525d (05-07)	VTG
 5 Series (E60-E61) (03-10)	GEARBOX MANAGEM	525i (05-07)	VTG
 5 Series (E60-E61) (03-10)	GEARBOX MANAGEM	525xd (05-07)	VTG
 5 Series (E60-E61) (03-10)	GEARBOX MANAGEM	525xi (05-07)	VTG
 5 Series (E60-E61) (03-10)	GEARBOX MANAGEM	530d (05-07)	VTG
 5 Series (E60-E61) (03-10)	GEARBOX MANAGEM	530i (05-07)	VTG
 5 Series (E60-E61) (03-10)	GEARBOX MANAGEM	530xd (05-07)	VTG
 5 Series (E60-E61) (03-10)	GEARBOX MANAGEM	530xi (05-07)	VTG
 5 Series (E60-E61) (03-10)	GEARBOX MANAGEM	535d (05-07)	VTG
 5 Series (E60-E61) (03-10)	GEARBOX MANAGEM	540i (05-07)	VTG
 5 Series (E60-E61) (03-10)	GEARBOX MANAGEM	545i (05-07)	VTG
 5 Series (E60-E61) (03-10)	GEARBOX MANAGEM	550i (05-07)	VTG
 5 Series (E60-E61) (03-10)	GEARBOX MANAGEM	M5 (05-07)	VTG
 5 Series (E60-E61) (03-10)	HEADLIGHT LEVEL	520d (05-07)	FLA
 5 Series (E60-E61) (03-10)	HEADLIGHT LEVEL	520d (05-07)	HELLA-LEAR
 5 Series (E60-E61) (03-10)	HEADLIGHT LEVEL	520i (05-07)	FLA
 5 Series (E60-E61) (03-10)	HEADLIGHT LEVEL	520i (05-07)	HELLA-LEAR
 5 Series (E60-E61) (03-10)	HEADLIGHT LEVEL	523i (05-07)	FLA
 5 Series (E60-E61) (03-10)	HEADLIGHT LEVEL	523i (05-07)	HELLA-LEAR

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 5 Series (E60-E61) (03-10)	HEADLIGHT LEVEL	525d (05-07)	FLA
 5 Series (E60-E61) (03-10)	HEADLIGHT LEVEL	525d (05-07)	HELLA-LEAR
 5 Series (E60-E61) (03-10)	HEADLIGHT LEVEL	525i (05-07)	FLA
 5 Series (E60-E61) (03-10)	HEADLIGHT LEVEL	525i (05-07)	HELLA-LEAR
 5 Series (E60-E61) (03-10)	HEADLIGHT LEVEL	525xd (05-07)	FLA
 5 Series (E60-E61) (03-10)	HEADLIGHT LEVEL	525xd (05-07)	HELLA-LEAR
 5 Series (E60-E61) (03-10)	HEADLIGHT LEVEL	525xi (05-07)	FLA
 5 Series (E60-E61) (03-10)	HEADLIGHT LEVEL	525xi (05-07)	HELLA-LEAR
 5 Series (E60-E61) (03-10)	HEADLIGHT LEVEL	530d (05-07)	FLA
 5 Series (E60-E61) (03-10)	HEADLIGHT LEVEL	530d (05-07)	HELLA-LEAR
 5 Series (E60-E61) (03-10)	HEADLIGHT LEVEL	530i (05-07)	FLA
 5 Series (E60-E61) (03-10)	HEADLIGHT LEVEL	530i (05-07)	HELLA-LEAR
 5 Series (E60-E61) (03-10)	HEADLIGHT LEVEL	530xd (05-07)	FLA
 5 Series (E60-E61) (03-10)	HEADLIGHT LEVEL	530xd (05-07)	HELLA-LEAR
 5 Series (E60-E61) (03-10)	HEADLIGHT LEVEL	530xi (05-07)	FLA
 5 Series (E60-E61) (03-10)	HEADLIGHT LEVEL	530xi (05-07)	HELLA-LEAR
 5 Series (E60-E61) (03-10)	HEADLIGHT LEVEL	535d (05-07)	FLA
 5 Series (E60-E61) (03-10)	HEADLIGHT LEVEL	535d (05-07)	HELLA-LEAR
 5 Series (E60-E61) (03-10)	HEADLIGHT LEVEL	540i (05-07)	FLA
 5 Series (E60-E61) (03-10)	HEADLIGHT LEVEL	540i (05-07)	HELLA-LEAR
 5 Series (E60-E61) (03-10)	HEADLIGHT LEVEL	545i (05-07)	FLA
 5 Series (E60-E61) (03-10)	HEADLIGHT LEVEL	545i (05-07)	HELLA-LEAR
 5 Series (E60-E61) (03-10)	HEADLIGHT LEVEL	550i (05-07)	FLA
 5 Series (E60-E61) (03-10)	HEADLIGHT LEVEL	550i (05-07)	HELLA-LEAR
 5 Series (E60-E61) (03-10)	HEADLIGHT LEVEL	M5 (05-07)	FLA
 5 Series (E60-E61) (03-10)	HEADLIGHT LEVEL	M5 (05-07)	HELLA-LEAR
 5 Series (E60-E61) (03-10)	IMMOBILIZER	520d (05-07)	Megamos Immobilizer CAS
 5 Series (E60-E61) (03-10)	IMMOBILIZER	520d (09-10)	CAS CAN
 5 Series (E60-E61) (03-10)	IMMOBILIZER	520i (05-07)	Megamos Immobilizer CAS
 5 Series (E60-E61) (03-10)	IMMOBILIZER	520i (09-10)	CAS CAN
 5 Series (E60-E61) (03-10)	IMMOBILIZER	523i (05-07)	Megamos Immobilizer CAS
 5 Series (E60-E61) (03-10)	IMMOBILIZER	523i (09-10)	CAS CAN
 5 Series (E60-E61) (03-10)	IMMOBILIZER	525d (05-07)	Megamos Immobilizer CAS
 5 Series (E60-E61) (03-10)	IMMOBILIZER	525d (09-10)	CAS CAN
 5 Series (E60-E61) (03-10)	IMMOBILIZER	525i (05-07)	Megamos Immobilizer CAS
 5 Series (E60-E61) (03-10)	IMMOBILIZER	525i (09-10)	CAS CAN
 5 Series (E60-E61) (03-10)	IMMOBILIZER	525xd (03-07)	Megamos Immobilizer CAS
 5 Series (E60-E61) (03-10)	IMMOBILIZER	525xd (09-10)	CAS CAN
 5 Series (E60-E61) (03-10)	IMMOBILIZER	525xi (05-07)	Megamos Immobilizer CAS
 5 Series (E60-E61) (03-10)	IMMOBILIZER	525xi (09-10)	CAS CAN
 5 Series (E60-E61) (03-10)	IMMOBILIZER	530d (05-07)	Megamos Immobilizer CAS
 5 Series (E60-E61) (03-10)	IMMOBILIZER	530d (09-10)	CAS CAN
 5 Series (E60-E61) (03-10)	IMMOBILIZER	530i (05-07)	Megamos Immobilizer CAS
 5 Series (E60-E61) (03-10)	IMMOBILIZER	530i (09-10)	CAS CAN
 5 Series (E60-E61) (03-10)	IMMOBILIZER	530xd (05-07)	Megamos Immobilizer CAS
 5 Series (E60-E61) (03-10)	IMMOBILIZER	530xd (09-10)	CAS CAN
 5 Series (E60-E61) (03-10)	IMMOBILIZER	530xi (05-07)	Megamos Immobilizer CAS
 5 Series (E60-E61) (03-10)	IMMOBILIZER	530xi (09-10)	CAS CAN
 5 Series (E60-E61) (03-10)	IMMOBILIZER	535d (05-07)	Megamos Immobilizer CAS
 5 Series (E60-E61) (03-10)	IMMOBILIZER	535d (09-10)	CAS CAN
 5 Series (E60-E61) (03-10)	IMMOBILIZER	540i (05-07)	Megamos Immobilizer CAS
 5 Series (E60-E61) (03-10)	IMMOBILIZER	540i (09-10)	CAS CAN
 5 Series (E60-E61) (03-10)	IMMOBILIZER	545i (05-07)	Megamos Immobilizer CAS
 5 Series (E60-E61) (03-10)	IMMOBILIZER	545i (09-10)	CAS CAN
 5 Series (E60-E61) (03-10)	IMMOBILIZER	550i (05-07)	Megamos Immobilizer CAS
 5 Series (E60-E61) (03-10)	IMMOBILIZER	550i (09-10)	CAS CAN
 5 Series (E60-E61) (03-10)	IMMOBILIZER	M5 (05-07)	Megamos Immobilizer CAS
 5 Series (E60-E61) (03-10)	IMMOBILIZER	M5 (09-10)	CAS CAN

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

[illegible]

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 5 Series (E60-E61) (03-10)	MAINTENANCE	525d (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	MAINTENANCE	525d (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	MAINTENANCE	525d (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	MAINTENANCE	525d (05-07)	HELLA-LEAR
 5 Series (E60-E61) (03-10)	MAINTENANCE	525d (06-10)	MANUAL
 5 Series (E60-E61) (03-10)	MAINTENANCE	525d 25 6D 3 (03-07)	BOSCH DDE 6.0
 5 Series (E60-E61) (03-10)	MAINTENANCE	525i (03-05)	Gateway
 5 Series (E60-E61) (03-10)	MAINTENANCE	525i (03-05)	MANUAL
 5 Series (E60-E61) (03-10)	MAINTENANCE	525i (03-05)	Tyre Monitor MANUAL
 5 Series (E60-E61) (03-10)	MAINTENANCE	525i (03-07)	BOSCH DSC
 5 Series (E60-E61) (03-10)	MAINTENANCE	525i (03-07)	BOSCH DSC
 5 Series (E60-E61) (03-10)	MAINTENANCE	525i (03-07)	BOSCH DSC
 5 Series (E60-E61) (03-10)	MAINTENANCE	525i (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	MAINTENANCE	525i (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	MAINTENANCE	525i (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	MAINTENANCE	525i (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	MAINTENANCE	525i (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	MAINTENANCE	525i (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	MAINTENANCE	525i (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	MAINTENANCE	525i (05-07)	HELLA-LEAR
 5 Series (E60-E61) (03-10)	MAINTENANCE	525i (06-10)	MANUAL
 5 Series (E60-E61) (03-10)	MAINTENANCE	525xd (03-05)	BOSCH DSC
 5 Series (E60-E61) (03-10)	MAINTENANCE	525xd (03-05)	BOSCH DSC
 5 Series (E60-E61) (03-10)	MAINTENANCE	525xd (03-05)	BOSCH DSC
 5 Series (E60-E61) (03-10)	MAINTENANCE	525xd (03-05)	Gateway
 5 Series (E60-E61) (03-10)	MAINTENANCE	525xd (03-05)	MANUAL
 5 Series (E60-E61) (03-10)	MAINTENANCE	525xd (03-05)	Tyre Monitor MANUAL
 5 Series (E60-E61) (03-10)	MAINTENANCE	525xd (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	MAINTENANCE	525xd (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	MAINTENANCE	525xd (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	MAINTENANCE	525xd (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	MAINTENANCE	525xd (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	MAINTENANCE	525xd (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	MAINTENANCE	525xd (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	MAINTENANCE	525xd (05-07)	HELLA-LEAR
 5 Series (E60-E61) (03-10)	MAINTENANCE	525xd (06-10)	MANUAL
 5 Series (E60-E61) (03-10)	MAINTENANCE	525xd 25 6D 3 (03-07)	BOSCH DDE 6.0
 5 Series (E60-E61) (03-10)	MAINTENANCE	525xi (03-05)	BOSCH DSC
 5 Series (E60-E61) (03-10)	MAINTENANCE	525xi (03-05)	BOSCH DSC
 5 Series (E60-E61) (03-10)	MAINTENANCE	525xi (03-05)	BOSCH DSC
 5 Series (E60-E61) (03-10)	MAINTENANCE	525xi (03-05)	Gateway
 5 Series (E60-E61) (03-10)	MAINTENANCE	525xi (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	MAINTENANCE	525xi (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	MAINTENANCE	525xi (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	MAINTENANCE	525xi (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	MAINTENANCE	525xi (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	MAINTENANCE	525xi (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	MAINTENANCE	525xi (05-07)	HELLA-LEAR
 5 Series (E60-E61) (03-10)	MAINTENANCE	530d (03-05)	BOSCH DSC
 5 Series (E60-E61) (03-10)	MAINTENANCE	530d (03-05)	BOSCH DSC
 5 Series (E60-E61) (03-10)	MAINTENANCE	530d (03-05)	BOSCH DSC
 5 Series (E60-E61) (03-10)	MAINTENANCE	530d (03-05)	Gateway
 5 Series (E60-E61) (03-10)	MAINTENANCE	530d (03-05)	MANUAL
 5 Series (E60-E61) (03-10)	MAINTENANCE	530d (03-05)	Tyre Monitor MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

[illegible]

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

[illegible]

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 5 Series (E60-E61) (03-10)	MAINTENANCE	M5 (03-05)	BOSCH DSC
 5 Series (E60-E61) (03-10)	MAINTENANCE	M5 (03-05)	BOSCH DSC
 5 Series (E60-E61) (03-10)	MAINTENANCE	M5 (03-05)	BOSCH DSC
 5 Series (E60-E61) (03-10)	MAINTENANCE	M5 (03-05)	Gateway
 5 Series (E60-E61) (03-10)	MAINTENANCE	M5 (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	MAINTENANCE	M5 (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	MAINTENANCE	M5 (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	MAINTENANCE	M5 (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	MAINTENANCE	M5 (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	MAINTENANCE	M5 (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	MAINTENANCE	M5 (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	MAINTENANCE	M5 (05-07)	HELLA-LEAR
 5 Series (E60-E61) (03-10)	PARKING HELP	520d (05-07)	VALEO PDC
 5 Series (E60-E61) (03-10)	PARKING HELP	520i (05-07)	VALEO PDC
 5 Series (E60-E61) (03-10)	PARKING HELP	523i (05-07)	VALEO PDC
 5 Series (E60-E61) (03-10)	PARKING HELP	525d (05-07)	VALEO PDC
 5 Series (E60-E61) (03-10)	PARKING HELP	525i (05-07)	VALEO PDC
 5 Series (E60-E61) (03-10)	PARKING HELP	525xd (03-07)	VALEO PDC
 5 Series (E60-E61) (03-10)	PARKING HELP	525xi (05-07)	VALEO PDC
 5 Series (E60-E61) (03-10)	PARKING HELP	530d (05-07)	VALEO PDC
 5 Series (E60-E61) (03-10)	PARKING HELP	530i (05-07)	VALEO PDC
 5 Series (E60-E61) (03-10)	PARKING HELP	530xd (05-07)	VALEO PDC
 5 Series (E60-E61) (03-10)	PARKING HELP	530xi (05-07)	VALEO PDC
 5 Series (E60-E61) (03-10)	PARKING HELP	535d (05-07)	VALEO PDC
 5 Series (E60-E61) (03-10)	PARKING HELP	540i (05-07)	VALEO PDC
 5 Series (E60-E61) (03-10)	PARKING HELP	545i (05-07)	VALEO PDC
 5 Series (E60-E61) (03-10)	PARKING HELP	550i (05-07)	VALEO PDC
 5 Series (E60-E61) (03-10)	PARKING HELP	M5 (05-07)	VALEO PDC
 5 Series (E60-E61) (03-10)	PASSENGER SEAT R	520d (05-07)	Passenger Seat
 5 Series (E60-E61) (03-10)	PASSENGER SEAT R	520i (05-07)	Passenger Seat
 5 Series (E60-E61) (03-10)	PASSENGER SEAT R	523i (05-07)	Passenger Seat
 5 Series (E60-E61) (03-10)	PASSENGER SEAT R	525d (05-07)	Passenger Seat
 5 Series (E60-E61) (03-10)	PASSENGER SEAT R	525i (05-07)	Passenger Seat
 5 Series (E60-E61) (03-10)	PASSENGER SEAT R	525xd (05-07)	Passenger Seat
 5 Series (E60-E61) (03-10)	PASSENGER SEAT R	525xi (05-07)	Passenger Seat
 5 Series (E60-E61) (03-10)	PASSENGER SEAT R	530d (05-07)	Passenger Seat
 5 Series (E60-E61) (03-10)	PASSENGER SEAT R	530i (05-07)	Passenger Seat
 5 Series (E60-E61) (03-10)	PASSENGER SEAT R	530xd (05-07)	Passenger Seat
 5 Series (E60-E61) (03-10)	PASSENGER SEAT R	530xi (05-07)	Passenger Seat
 5 Series (E60-E61) (03-10)	PASSENGER SEAT R	535d (05-07)	Passenger Seat
 5 Series (E60-E61) (03-10)	PASSENGER SEAT R	540i (05-07)	Passenger Seat
 5 Series (E60-E61) (03-10)	PASSENGER SEAT R	545i (05-07)	Passenger Seat
 5 Series (E60-E61) (03-10)	PASSENGER SEAT R	550i (05-07)	Passenger Seat
 5 Series (E60-E61) (03-10)	PASSENGER SEAT R	M5 (05-07)	Passenger Seat
 5 Series (E60-E61) (03-10)	RADIO / CD	520d (05-07)	CON Controller
 5 Series (E60-E61) (03-10)	RADIO / CD	520d (05-07)	VDO CarCommunicationCenter
 5 Series (E60-E61) (03-10)	RADIO / CD	520d (09-10)	CD Changer CDC_E65
 5 Series (E60-E61) (03-10)	RADIO / CD	520d (09-10)	Radio IBOC60
 5 Series (E60-E61) (03-10)	RADIO / CD	520i (05-07)	CON Controller
 5 Series (E60-E61) (03-10)	RADIO / CD	520i (05-07)	VDO CarCommunicationCenter
 5 Series (E60-E61) (03-10)	RADIO / CD	520i (09-10)	CD Changer CDC_E65
 5 Series (E60-E61) (03-10)	RADIO / CD	520i (09-10)	Radio IBOC60
 5 Series (E60-E61) (03-10)	RADIO / CD	523i (05-07)	CON Controller
 5 Series (E60-E61) (03-10)	RADIO / CD	523i (05-07)	VDO CarCommunicationCenter
 5 Series (E60-E61) (03-10)	RADIO / CD	523i (09-10)	CD Changer CDC_E65
 5 Series (E60-E61) (03-10)	RADIO / CD	523i (09-10)	Radio IBOC60
 5 Series (E60-E61) (03-10)	RADIO / CD	525d (05-07)	CON Controller

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 5 Series (E60-E61) (03-10)	RADIO / CD	525d (05-07)	VDO CarCommunicationCenter
 5 Series (E60-E61) (03-10)	RADIO / CD	525d (09-10)	CD Changer CDC_E65
 5 Series (E60-E61) (03-10)	RADIO / CD	525d (09-10)	Radio IBOC60
 5 Series (E60-E61) (03-10)	RADIO / CD	525i (05-07)	CON Controller
 5 Series (E60-E61) (03-10)	RADIO / CD	525i (05-07)	VDO CarCommunicationCenter
 5 Series (E60-E61) (03-10)	RADIO / CD	525i (09-10)	CD Changer CDC_E65
 5 Series (E60-E61) (03-10)	RADIO / CD	525i (09-10)	Radio IBOC60
 5 Series (E60-E61) (03-10)	RADIO / CD	525xd (05-07)	CON Controller
 5 Series (E60-E61) (03-10)	RADIO / CD	525xd (05-07)	VDO CarCommunicationCenter
 5 Series (E60-E61) (03-10)	RADIO / CD	525xd (09-10)	CD Changer CDC_E65
 5 Series (E60-E61) (03-10)	RADIO / CD	525xd (09-10)	Radio IBOC60
 5 Series (E60-E61) (03-10)	RADIO / CD	525xi (05-07)	CON Controller
 5 Series (E60-E61) (03-10)	RADIO / CD	525xi (05-07)	VDO CarCommunicationCenter
 5 Series (E60-E61) (03-10)	RADIO / CD	525xi (09-10)	CD Changer CDC_E65
 5 Series (E60-E61) (03-10)	RADIO / CD	525xi (09-10)	Radio IBOC60
 5 Series (E60-E61) (03-10)	RADIO / CD	530d (05-07)	CON Controller
 5 Series (E60-E61) (03-10)	RADIO / CD	530d (09-10)	VDO CarCommunicationCenter
 5 Series (E60-E61) (03-10)	RADIO / CD	530d (09-10)	CD Changer CDC_E65
 5 Series (E60-E61) (03-10)	RADIO / CD	530d (09-10)	Radio IBOC60
 5 Series (E60-E61) (03-10)	RADIO / CD	530i (05-07)	CON Controller
 5 Series (E60-E61) (03-10)	RADIO / CD	530i (05-07)	VDO CarCommunicationCenter
 5 Series (E60-E61) (03-10)	RADIO / CD	530i (09-10)	CD Changer CDC_E65
 5 Series (E60-E61) (03-10)	RADIO / CD	530i (09-10)	Radio IBOC60
 5 Series (E60-E61) (03-10)	RADIO / CD	530xd (05-07)	CON Controller
 5 Series (E60-E61) (03-10)	RADIO / CD	530xd (05-07)	VDO CarCommunicationCenter
 5 Series (E60-E61) (03-10)	RADIO / CD	530xd (09-10)	CD Changer CDC_E65
 5 Series (E60-E61) (03-10)	RADIO / CD	530xd (09-10)	Radio IBOC60
 5 Series (E60-E61) (03-10)	RADIO / CD	530xi (05-07)	CON Controller
 5 Series (E60-E61) (03-10)	RADIO / CD	530xi (05-07)	VDO CarCommunicationCenter
 5 Series (E60-E61) (03-10)	RADIO / CD	530xi (09-10)	CD Changer CDC_E65
 5 Series (E60-E61) (03-10)	RADIO / CD	530xi (09-10)	Radio IBOC60
 5 Series (E60-E61) (03-10)	RADIO / CD	535d (05-07)	CON Controller
 5 Series (E60-E61) (03-10)	RADIO / CD	535d (05-07)	VDO CarCommunicationCenter
 5 Series (E60-E61) (03-10)	RADIO / CD	535d (09-10)	CD Changer CDC_E65
 5 Series (E60-E61) (03-10)	RADIO / CD	535d (09-10)	Radio IBOC60
 5 Series (E60-E61) (03-10)	RADIO / CD	540i (05-07)	CON Controller
 5 Series (E60-E61) (03-10)	RADIO / CD	540i (05-07)	VDO CarCommunicationCenter
 5 Series (E60-E61) (03-10)	RADIO / CD	540i (09-10)	CD Changer CDC_E65
 5 Series (E60-E61) (03-10)	RADIO / CD	540i (09-10)	Radio IBOC60
 5 Series (E60-E61) (03-10)	RADIO / CD	545i (05-07)	CON Controller
 5 Series (E60-E61) (03-10)	RADIO / CD	545i (05-07)	VDO CarCommunicationCenter
 5 Series (E60-E61) (03-10)	RADIO / CD	545i (09-10)	CD Changer CDC_E65
 5 Series (E60-E61) (03-10)	RADIO / CD	545i (09-10)	Radio IBOC60
 5 Series (E60-E61) (03-10)	RADIO / CD	550i (05-07)	CON Controller
 5 Series (E60-E61) (03-10)	RADIO / CD	550i (05-07)	VDO CarCommunicationCenter
 5 Series (E60-E61) (03-10)	RADIO / CD	550i (09-10)	CD Changer CDC_E65
 5 Series (E60-E61) (03-10)	RADIO / CD	550i (09-10)	Radio IBOC60
 5 Series (E60-E61) (03-10)	RADIO / CD	M5 (05-07)	CON Controller
 5 Series (E60-E61) (03-10)	RADIO / CD	M5 (05-07)	VDO CarCommunicationCenter
 5 Series (E60-E61) (03-10)	RADIO / CD	M5 (09-10)	CD Changer CDC_E65
 5 Series (E60-E61) (03-10)	RADIO / CD	M5 (09-10)	Radio IBOC60
 5 Series (E60-E61) (03-10)	RAIN-LUMINOSITY S	520d (03-07)	Kostal RLS
 5 Series (E60-E61) (03-10)	RAIN-LUMINOSITY S	520i (03-07)	Kostal RLS
 5 Series (E60-E61) (03-10)	RAIN-LUMINOSITY S	523i (03-07)	Kostal RLS
 5 Series (E60-E61) (03-10)	RAIN-LUMINOSITY S	525d (03-07)	Kostal RLS
 5 Series (E60-E61) (03-10)	RAIN-LUMINOSITY S	525i (03-07)	Kostal RLS
 5 Series (E60-E61) (03-10)	RAIN-LUMINOSITY S	525xd (03-07)	Kostal RLS
 5 Series (E60-E61) (03-10)	RAIN-LUMINOSITY S	525xi (03-07)	Kostal RLS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 5 Series (E60-E61) (03-10)	RAIN-LUMINOSITY S	530d (03-07)	Kostal RLS
 5 Series (E60-E61) (03-10)	RAIN-LUMINOSITY S	530i (03-07)	Kostal RLS
 5 Series (E60-E61) (03-10)	RAIN-LUMINOSITY S	530xd (03-07)	Kostal RLS
 5 Series (E60-E61) (03-10)	RAIN-LUMINOSITY S	530xi (03-07)	Kostal RLS
 5 Series (E60-E61) (03-10)	RAIN-LUMINOSITY S	535d (03-07)	Kostal RLS
 5 Series (E60-E61) (03-10)	RAIN-LUMINOSITY S	540i (03-07)	Kostal RLS
 5 Series (E60-E61) (03-10)	RAIN-LUMINOSITY S	545i (03-07)	Kostal RLS
 5 Series (E60-E61) (03-10)	RAIN-LUMINOSITY S	550i (03-07)	Kostal RLS
 5 Series (E60-E61) (03-10)	RAIN-LUMINOSITY S	M5 (03-07)	Kostal RLS
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	520d (03-05)	MANUAL
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	520d (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	520d (06-10)	MANUAL
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	520i (03-05)	MANUAL
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	520i (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	520i (06-10)	MANUAL
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	523i (03-05)	MANUAL
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	523i (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	523i (06-10)	MANUAL
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	525d (03-05)	MANUAL
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	525d (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	525d (06-10)	MANUAL
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	525i (03-05)	MANUAL
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	525i (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	525i (06-10)	MANUAL
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	525xd (03-05)	MANUAL
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	525xd (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	525xd (06-10)	MANUAL
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	525xi (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	530d (03-05)	MANUAL
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	530d (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	530d (06-10)	MANUAL
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	530i (03-05)	MANUAL
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	530i (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	530i (06-10)	MANUAL
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	530xd (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	530xi (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	535d (03-05)	MANUAL
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	535d (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	535d (06-10)	MANUAL
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	540i (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	545i (03-05)	MANUAL
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	545i (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	545i (06-10)	MANUAL
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	550i (03-05)	MANUAL
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	550i (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	550i (06-10)	MANUAL
 5 Series (E60-E61) (03-10)	SERVICE LIGHT RES	M5 (05-06)	Service Kombi/Info Display
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	520d (03-05)	VDO CCC-BO Dash
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	520d (05-07)	VDO CCC-ANT
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	520d (09-10)	ASK60
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	520i (03-05)	VDO CCC-BO Dash
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	520i (05-07)	VDO CCC-ANT
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	520i (09-10)	ASK60
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	523i (03-05)	VDO CCC-BO Dash
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	523i (05-07)	VDO CCC-ANT
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	523i (09-10)	ASK60
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	525d (03-05)	VDO CCC-BO Dash
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	525d (05-07)	VDO CCC-ANT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	525d (09-10)	ASK60
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	525i (03-05)	VDO CCC-BO Dash
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	525i (05-07)	VDO CCC-ANT
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	525i (09-10)	ASK60
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	525xd (03-05)	VDO CCC-BO Dash
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	525xd (05-07)	VDO CCC-ANT
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	525xd (09-10)	ASK60
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	525xi (03-05)	VDO CCC-BO Dash
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	525xi (05-07)	VDO CCC-ANT
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	525xi (09-10)	ASK60
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	530d (03-05)	VDO CCC-BO Dash
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	530d (05-07)	VDO CCC-ANT
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	530d (09-10)	ASK60
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	530i (03-05)	VDO CCC-BO Dash
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	530i (05-07)	VDO CCC-ANT
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	530i (09-10)	ASK60
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	530xd (03-05)	VDO CCC-BO Dash
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	530xd (05-07)	VDO CCC-ANT
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	530xd (09-10)	ASK60
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	530xi (03-05)	VDO CCC-BO Dash
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	530xi (05-07)	VDO CCC-ANT
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	530xi (09-10)	ASK60
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	535d (03-05)	VDO CCC-BO Dash
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	535d (05-07)	VDO CCC-ANT
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	535d (09-10)	ASK60
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	540i (03-05)	VDO CCC-BO Dash
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	540i (05-07)	VDO CCC-ANT
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	540i (09-10)	ASK60
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	545i (03-05)	VDO CCC-BO Dash
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	545i (05-07)	VDO CCC-ANT
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	545i (09-10)	ASK60
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	550i (03-05)	VDO CCC-BO Dash
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	550i (05-07)	VDO CCC-ANT
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	550i (09-10)	ASK60
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	M5 (03-05)	VDO CCC-BO Dash
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	M5 (05-07)	VDO CCC-ANT
 5 Series (E60-E61) (03-10)	SOUND SYSTEM	M5 (09-10)	ASK60
 5 Series (E60-E61) (03-10)	STEERING COLUMN	520d (05-07)	Kostal SZL 2
 5 Series (E60-E61) (03-10)	STEERING COLUMN	520d (09-10)	SZL60
 5 Series (E60-E61) (03-10)	STEERING COLUMN	520i (05-07)	Kostal SZL 2
 5 Series (E60-E61) (03-10)	STEERING COLUMN	520i (09-10)	SZL60
 5 Series (E60-E61) (03-10)	STEERING COLUMN	523i (05-07)	Kostal SZL 2
 5 Series (E60-E61) (03-10)	STEERING COLUMN	523i (09-10)	SZL60
 5 Series (E60-E61) (03-10)	STEERING COLUMN	525d (05-07)	Kostal SZL 2
 5 Series (E60-E61) (03-10)	STEERING COLUMN	525d (09-10)	SZL60
 5 Series (E60-E61) (03-10)	STEERING COLUMN	525i (05-07)	Kostal SZL 2
 5 Series (E60-E61) (03-10)	STEERING COLUMN	525i (09-10)	SZL60
 5 Series (E60-E61) (03-10)	STEERING COLUMN	525xd (03-07)	Kostal SZL 2
 5 Series (E60-E61) (03-10)	STEERING COLUMN	525xd (09-10)	SZL60
 5 Series (E60-E61) (03-10)	STEERING COLUMN	525xi (05-07)	Kostal SZL 2
 5 Series (E60-E61) (03-10)	STEERING COLUMN	525xi (09-10)	SZL60
 5 Series (E60-E61) (03-10)	STEERING COLUMN	530d (05-07)	Kostal SZL 2
 5 Series (E60-E61) (03-10)	STEERING COLUMN	530d (09-10)	SZL60
 5 Series (E60-E61) (03-10)	STEERING COLUMN	530i (05-07)	Kostal SZL 2
 5 Series (E60-E61) (03-10)	STEERING COLUMN	530i (09-10)	SZL60
 5 Series (E60-E61) (03-10)	STEERING COLUMN	530xd (05-07)	Kostal SZL 2
 5 Series (E60-E61) (03-10)	STEERING COLUMN	530xd (09-10)	SZL60
 5 Series (E60-E61) (03-10)	STEERING COLUMN	530xi (05-07)	Kostal SZL 2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 5 Series (E60-E61) (03-10)	STEERING COLUMN	530xi (09-10)	SZL60
 5 Series (E60-E61) (03-10)	STEERING COLUMN	535d (05-07)	Kostal SZL 2
 5 Series (E60-E61) (03-10)	STEERING COLUMN	535d (09-10)	SZL60
 5 Series (E60-E61) (03-10)	STEERING COLUMN	540i (05-07)	Kostal SZL 2
 5 Series (E60-E61) (03-10)	STEERING COLUMN	540i (09-10)	SZL60
 5 Series (E60-E61) (03-10)	STEERING COLUMN	545i (05-07)	Kostal SZL 2
 5 Series (E60-E61) (03-10)	STEERING COLUMN	545i (09-10)	SZL60
 5 Series (E60-E61) (03-10)	STEERING COLUMN	550i (05-07)	Kostal SZL 2
 5 Series (E60-E61) (03-10)	STEERING COLUMN	550i (09-10)	SZL60
 5 Series (E60-E61) (03-10)	STEERING COLUMN	M5 (05-07)	Kostal SZL 2
 5 Series (E60-E61) (03-10)	STEERING COLUMN	M5 (09-10)	SZL60
 5 Series (E60-E61) (03-10)	SUSPENSION CONTR	520d (05-07)	THYSSEN KRUPP
 5 Series (E60-E61) (03-10)	SUSPENSION CONTR	520i (05-07)	THYSSEN KRUPP
 5 Series (E60-E61) (03-10)	SUSPENSION CONTR	523i (05-07)	THYSSEN KRUPP
 5 Series (E60-E61) (03-10)	SUSPENSION CONTR	525d (05-07)	THYSSEN KRUPP
 5 Series (E60-E61) (03-10)	SUSPENSION CONTR	525i (05-07)	THYSSEN KRUPP
 5 Series (E60-E61) (03-10)	SUSPENSION CONTR	525xd (05-07)	THYSSEN KRUPP
 5 Series (E60-E61) (03-10)	SUSPENSION CONTR	525xi (05-07)	THYSSEN KRUPP
 5 Series (E60-E61) (03-10)	SUSPENSION CONTR	530d (05-07)	THYSSEN KRUPP
 5 Series (E60-E61) (03-10)	SUSPENSION CONTR	530i (05-07)	THYSSEN KRUPP
 5 Series (E60-E61) (03-10)	SUSPENSION CONTR	530xd (05-07)	THYSSEN KRUPP
 5 Series (E60-E61) (03-10)	SUSPENSION CONTR	530xi (05-07)	THYSSEN KRUPP
 5 Series (E60-E61) (03-10)	SUSPENSION CONTR	535d (05-07)	THYSSEN KRUPP
 5 Series (E60-E61) (03-10)	SUSPENSION CONTR	540i (05-07)	THYSSEN KRUPP
 5 Series (E60-E61) (03-10)	SUSPENSION CONTR	545i (05-07)	THYSSEN KRUPP
 5 Series (E60-E61) (03-10)	SUSPENSION CONTR	550i (05-07)	THYSSEN KRUPP
 5 Series (E60-E61) (03-10)	SUSPENSION CONTR	M5 (05-07)	THYSSEN KRUPP
 5 Series (E60-E61) (03-10)	TIRE PRESSURE	520d (03-05)	Tyre Monitor MANUAL
 5 Series (E60-E61) (03-10)	TIRE PRESSURE	523i (03-05)	Tyre Monitor MANUAL
 5 Series (E60-E61) (03-10)	TIRE PRESSURE	525d (03-05)	Tyre Monitor MANUAL
 5 Series (E60-E61) (03-10)	TIRE PRESSURE	525i (03-05)	Tyre Monitor MANUAL
 5 Series (E60-E61) (03-10)	TIRE PRESSURE	525xd (03-05)	Tyre Monitor MANUAL
 5 Series (E60-E61) (03-10)	TIRE PRESSURE	530d (03-05)	Tyre Monitor MANUAL
 5 Series (E60-E61) (03-10)	TIRE PRESSURE	530i (03-05)	Tyre Monitor MANUAL
 5 Series (E60-E61) (03-10)	TIRE PRESSURE	535d (03-05)	Tyre Monitor MANUAL
 5 Series (E60-E61) (03-10)	TIRE PRESSURE	545i (03-05)	Tyre Monitor MANUAL
 5 Series (E60-E61) (03-10)	TIRE PRESSURE	550i (03-05)	Tyre Monitor MANUAL
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	520d (05-07)	Motorola TCU
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	520d (05-07)	VDO Central Info Display
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	520d (09-10)	FLA 65
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	520d (09-10)	Info Display CID90
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	520i (05-07)	Motorola TCU
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	520i (05-07)	VDO Central Info Display
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	520i (09-10)	FLA 65
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	520i (09-10)	Info Display CID90
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	523i (05-07)	Motorola TCU
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	523i (05-07)	VDO Central Info Display
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	523i (09-10)	FLA 65
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	523i (09-10)	Info Display CID90
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	525d (05-07)	Motorola TCU
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	525d (05-07)	VDO Central Info Display
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	525d (09-10)	FLA 65
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	525d (09-10)	Info Display CID90
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	525i (05-07)	Motorola TCU
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	525i (05-07)	VDO Central Info Display
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	525i (09-10)	FLA 65
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	525i (09-10)	Info Display CID90
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	525xd (05-07)	Motorola TCU

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	525xd (05-07)	VDO Central Info Display
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	525xd (09-10)	FLA 65
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	525xd (09-10)	Info Display CID90
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	525xi (05-07)	Motorola TCU
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	525xi (05-07)	VDO Central Info Display
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	525xi (09-10)	FLA 65
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	525xi (09-10)	Info Display CID90
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	530d (05-07)	Motorola TCU
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	530d (05-07)	VDO Central Info Display
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	530d (09-10)	FLA 65
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	530d (09-10)	Info Display CID90
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	530i (05-07)	Motorola TCU
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	530i (05-07)	VDO Central Info Display
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	530i (09-10)	FLA 65
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	530i (09-10)	Info Display CID90
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	530xd (05-07)	Motorola TCU
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	530xd (09-10)	VDO Central Info Display
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	530xd (09-10)	FLA 65
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	530xd (09-10)	Info Display CID90
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	530xi (05-07)	Motorola TCU
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	530xi (05-07)	VDO Central Info Display
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	530xi (09-10)	FLA 65
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	530xi (09-10)	Info Display CID90
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	535d (05-07)	Motorola TCU
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	535d (05-07)	VDO Central Info Display
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	535d (09-10)	FLA 65
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	535d (09-10)	Info Display CID90
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	540i (05-07)	Motorola TCU
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	540i (05-07)	VDO Central Info Display
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	540i (09-10)	FLA 65
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	540i (09-10)	Info Display CID90
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	545i (05-07)	Motorola TCU
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	545i (05-07)	VDO Central Info Display
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	545i (09-10)	FLA 65
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	545i (09-10)	Info Display CID90
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	550i (05-07)	Motorola TCU
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	550i (05-07)	VDO Central Info Display
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	550i (09-10)	FLA 65
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	550i (09-10)	Info Display CID90
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	M5 (05-07)	Motorola TCU
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	M5 (05-07)	VDO Central Info Display
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	M5 (09-10)	FLA 65
 5 Series (E60-E61) (03-10)	VISUAL./TELEMATIC	M5 (09-10)	Info Display CID90
 5 Series (F10-F11) (10-..)	VISUAL./TELEMATIC	518d (10-..)	TELE60 3
 5 Series (F10-F11) (10-..)	VISUAL./TELEMATIC	520d (10-..)	TELE60 3
 5 Series (F10-F11) (10-..)	VISUAL./TELEMATIC	520i (10-..)	TELE60 3
 5 Series (F10-F11) (10-..)	VISUAL./TELEMATIC	520xd (10-..)	TELE60 3
 5 Series (F10-F11) (10-..)	VISUAL./TELEMATIC	525d (10-..)	TELE60 3
 5 Series (F10-F11) (10-..)	VISUAL./TELEMATIC	525xd (10-..)	TELE60 3
 5 Series (F10-F11) (10-..)	VISUAL./TELEMATIC	528i (10-..)	TELE60 3
 5 Series (F10-F11) (10-..)	VISUAL./TELEMATIC	528xi (10-..)	TELE60 3
 5 Series (F10-F11) (10-..)	VISUAL./TELEMATIC	530d (10-..)	TELE60 3
 5 Series (F10-F11) (10-..)	VISUAL./TELEMATIC	530xd (10-..)	TELE60 3
 5 Series (F10-F11) (10-..)	VISUAL./TELEMATIC	535d (10-..)	TELE60 3
 5 Series (F10-F11) (10-..)	VISUAL./TELEMATIC	535i (10-..)	TELE60 3
 5 Series (F10-F11) (10-..)	VISUAL./TELEMATIC	535xd (10-..)	TELE60 3
 5 Series (F10-F11) (10-..)	VISUAL./TELEMATIC	535xi (10-..)	TELE60 3
 5 Series (F10-F11) (10-..)	VISUAL./TELEMATIC	550d (10-..)	TELE60 3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 5 Series (F10-F11) (10-..)	VISUAL./TELEMATIC	550i (10-..)	TELE60 3
 5 Series (F10-F11) (10-..)	VISUAL./TELEMATIC	550xi (10-..)	TELE60 3
 5GT Series (F07) (09-..)	CRUISE CONTROL	520d (09-10)	ACC LRR 60
 5GT Series (F07) (09-..)	CRUISE CONTROL	530d (09-10)	ACC LRR 60
 5GT Series (F07) (09-..)	CRUISE CONTROL	530xd (09-10)	ACC LRR 60
 5GT Series (F07) (09-..)	CRUISE CONTROL	535d (09-10)	ACC LRR 60
 5GT Series (F07) (09-..)	CRUISE CONTROL	535i (09-10)	ACC LRR 60
 5GT Series (F07) (09-..)	CRUISE CONTROL	535xd (09-10)	ACC LRR 60
 5GT Series (F07) (09-..)	CRUISE CONTROL	535xi (09-10)	ACC LRR 60
 5GT Series (F07) (09-..)	CRUISE CONTROL	550i (09-10)	ACC LRR 60
 6 Series (E24) (87-89)	ENGINE MANAGEME	628i 34 6K B (87-89)	BOSCH Motronic DME M1.1
 6 Series (E24) (87-89)	ENGINE MANAGEME	635i 34 6K B (87-89)	BOSCH Motronic DME M1.3
 6 Series (E24) (87-89)	ENGINE MANAGEME	M635i 34 6K B (87-89)	BOSCH Motronic DME M1.3
 6 Series (E24) (87-89)	MAINTENANCE	628i (.-09/00)	Service
 6 Series (E24) (87-89)	MAINTENANCE	635i (.-09/00)	Service
 6 Series (E24) (87-89)	MAINTENANCE	M635i (.-09/00)	Service
 6 Series (E24) (87-89)	SERVICE LIGHT RES	628i (.-09/00)	Service
 6 Series (E24) (87-89)	SERVICE LIGHT RES	635i (.-09/00)	Service
 6 Series (E24) (87-89)	SERVICE LIGHT RES	M635i (.-09/00)	Service
 6 Series (E63-E64) (03-10)	CLIMA	630i (09-10)	IHKA60 2
 6 Series (E63-E64) (03-10)	CLIMA	635d (09-10)	IHKA60 2
 6 Series (E63-E64) (03-10)	CLIMA	645 Ci (09-10)	IHKA60 2
 6 Series (E63-E64) (03-10)	CLIMA	650i (09-10)	IHKA60 2
 6 Series (E63-E64) (03-10)	CLIMA	M6 (09-10)	IHKA60 2
 6 Series (E63-E64) (03-10)	DASHBOARD	630i (09-10)	KOMB60
 6 Series (E63-E64) (03-10)	DASHBOARD	635d (09-10)	KOMB60
 6 Series (E63-E64) (03-10)	DASHBOARD	645 Ci (09-10)	KOMB60
 6 Series (E63-E64) (03-10)	DASHBOARD	650i (09-10)	KOMB60
 6 Series (E63-E64) (03-10)	DASHBOARD	M6 (09-10)	KOMB60
 6 Series (E63-E64) (03-10)	DIFFERENTIAL MANA	630i (09-10)	VGSG90
 6 Series (E63-E64) (03-10)	DIFFERENTIAL MANA	635d (09-10)	VGSG90
 6 Series (E63-E64) (03-10)	DIFFERENTIAL MANA	645 Ci (09-10)	VGSG90
 6 Series (E63-E64) (03-10)	DIFFERENTIAL MANA	650i (09-10)	VGSG90
 6 Series (E63-E64) (03-10)	DIFFERENTIAL MANA	M6 (09-10)	VGSG90
 6 Series (E63-E64) (03-10)	IMMOBILIZER	630i (09-10)	CAS
 6 Series (E63-E64) (03-10)	IMMOBILIZER	635d (09-10)	CAS
 6 Series (E63-E64) (03-10)	IMMOBILIZER	645 Ci (09-10)	CAS
 6 Series (E63-E64) (03-10)	IMMOBILIZER	650i (09-10)	CAS
 6 Series (E63-E64) (03-10)	IMMOBILIZER	M6 (09-10)	CAS
 6 Series (E63-E64) (03-10)	RADIO / CD	630i (09-10)	CD Changer CDC_E65
 6 Series (E63-E64) (03-10)	RADIO / CD	630i (09-10)	Radio IBOC60
 6 Series (E63-E64) (03-10)	RADIO / CD	635d (09-10)	CD Changer CDC_E65
 6 Series (E63-E64) (03-10)	RADIO / CD	635d (09-10)	Radio IBOC60
 6 Series (E63-E64) (03-10)	RADIO / CD	645 Ci (09-10)	CD Changer CDC_E65
 6 Series (E63-E64) (03-10)	RADIO / CD	645 Ci (09-10)	Radio IBOC60
 6 Series (E63-E64) (03-10)	RADIO / CD	650i (09-10)	CD Changer CDC_E65
 6 Series (E63-E64) (03-10)	RADIO / CD	650i (09-10)	Radio IBOC60
 6 Series (E63-E64) (03-10)	RADIO / CD	M6 (09-10)	CD Changer CDC_E65
 6 Series (E63-E64) (03-10)	RADIO / CD	M6 (09-10)	Radio IBOC60
 6 Series (E63-E64) (03-10)	SOUND SYSTEM	630i (09-10)	ASK60
 6 Series (E63-E64) (03-10)	SOUND SYSTEM	635d (09-10)	ASK60
 6 Series (E63-E64) (03-10)	SOUND SYSTEM	645 Ci (09-10)	ASK60
 6 Series (E63-E64) (03-10)	SOUND SYSTEM	650i (09-10)	ASK60
 6 Series (E63-E64) (03-10)	SOUND SYSTEM	M6 (09-10)	ASK60
 6 Series (E63-E64) (03-10)	STEERING COLUMN	630i (09-10)	SZL60
 6 Series (E63-E64) (03-10)	STEERING COLUMN	635d (09-10)	SZL60
 6 Series (E63-E64) (03-10)	STEERING COLUMN	645 Ci (09-10)	SZL60
 6 Series (E63-E64) (03-10)	STEERING COLUMN	650i (09-10)	SZL60

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 6 Series (E63-E64) (03-10)	STEERING COLUMN	M6 (09-10)	SZL60
 6 Series (E63-E64) (03-10)	VISUAL./TELEMATIC	630i (09-10)	FLA 65
 6 Series (E63-E64) (03-10)	VISUAL./TELEMATIC	630i (09-10)	Info Display CID90
 6 Series (E63-E64) (03-10)	VISUAL./TELEMATIC	635d (09-10)	FLA 65
 6 Series (E63-E64) (03-10)	VISUAL./TELEMATIC	635d (09-10)	Info Display CID90
 6 Series (E63-E64) (03-10)	VISUAL./TELEMATIC	645 Ci (09-10)	FLA 65
 6 Series (E63-E64) (03-10)	VISUAL./TELEMATIC	645 Ci (09-10)	Info Display CID90
 6 Series (E63-E64) (03-10)	VISUAL./TELEMATIC	650i (09-10)	FLA 65
 6 Series (E63-E64) (03-10)	VISUAL./TELEMATIC	650i (09-10)	Info Display CID90
 6 Series (E63-E64) (03-10)	VISUAL./TELEMATIC	M6 (09-10)	FLA 65
 6 Series (E63-E64) (03-10)	VISUAL./TELEMATIC	M6 (09-10)	Info Display CID90
 6 Series (F12-F13) (10-..)	VISUAL./TELEMATIC	640d (10-..)	TELE60 3
 6 Series (F12-F13) (10-..)	VISUAL./TELEMATIC	640xd (10-..)	TELE60 3
 6 Series (F12-F13) (10-..)	VISUAL./TELEMATIC	650i (10-..)	TELE60 3
 6 Series (F12-F13) (10-..)	VISUAL./TELEMATIC	650ix (10-..)	TELE60 3
 7 Series (E32) (86-94)	AIRBAG	730i (89-95)	TEMIC AirBag BAE
 7 Series (E32) (86-94)	AIRBAG	735i (89-95)	TEMIC AirBag BAE
 7 Series (E32) (86-94)	AIRBAG	740i (89-95)	TEMIC AirBag BAE
 7 Series (E32) (86-94)	AIRBAG	750i (89-95)	TEMIC AirBag BAE
 7 Series (E32) (86-94)	ENGINE MANAGEME	730i 30 6K A (86-92)	BOSCH Motronic DME M1.1
 7 Series (E32) (86-94)	ENGINE MANAGEME	730i 30 6K A (86-92)	BOSCH Motronic DME M1.3
 7 Series (E32) (86-94)	ENGINE MANAGEME	735i 34 6K B (86-92)	BOSCH Motronic DME M1.3
 7 Series (E32) (86-94)	ENGINE MANAGEME	740i 34 6K B (86-92)	BOSCH Motronic DME M1.3
 7 Series (E32) (86-94)	ENGINE MANAGEME	750i 50 12 A (87-90)	BOSCH Motronic DME M1.2-ECU1
 7 Series (E32) (86-94)	ENGINE MANAGEME	750i 50 12 A (87-90)	BOSCH Motronic DME M1.2-ECU2
 7 Series (E32) (86-94)	ENGINE MANAGEME	750i 50 12 A (90-94)	BOSCH Motronic DME M1.7-ECU1
 7 Series (E32) (86-94)	ENGINE MANAGEME	750i 50 12 A (90-94)	BOSCH Motronic DME M1.7-ECU2
 7 Series (E32) (86-94)	MAINTENANCE	730i (...-09/00)	Service
 7 Series (E32) (86-94)	MAINTENANCE	735i (...-09/00)	Service
 7 Series (E32) (86-94)	MAINTENANCE	740i (...-09/00)	Service
 7 Series (E32) (86-94)	MAINTENANCE	750i (...-09/00)	Service
 7 Series (E32) (86-94)	SERVICE LIGHT RES	730i (...-09/00)	Service
 7 Series (E32) (86-94)	SERVICE LIGHT RES	735i (...-09/00)	Service
 7 Series (E32) (86-94)	SERVICE LIGHT RES	740i (...-09/00)	Service
 7 Series (E32) (86-94)	SERVICE LIGHT RES	750i (...-09/00)	Service
 7 Series (E38) (95-01)	ABS + TRACT. CONT	725d (95-99)	BOSCH ABS/ASC 5
 7 Series (E38) (95-01)	ABS + TRACT. CONT	725d (98-..)	BOSCH ABS/ASR 5.7
 7 Series (E38) (95-01)	ABS + TRACT. CONT	728i (95-99)	BOSCH ABS/ASC 5
 7 Series (E38) (95-01)	ABS + TRACT. CONT	728i (98-..)	BOSCH ABS/ASR 5.7
 7 Series (E38) (95-01)	ABS + TRACT. CONT	730d (95-99)	BOSCH ABS/ASC 5
 7 Series (E38) (95-01)	ABS + TRACT. CONT	730d (98-..)	BOSCH ABS/ASR 5.7
 7 Series (E38) (95-01)	ABS + TRACT. CONT	730i (95-99)	BOSCH ABS/ASC 5
 7 Series (E38) (95-01)	ABS + TRACT. CONT	730i (98-..)	BOSCH ABS/ASR 5.7
 7 Series (E38) (95-01)	ABS + TRACT. CONT	735i (95-99)	BOSCH ABS/ASC 5
 7 Series (E38) (95-01)	ABS + TRACT. CONT	735i (98-..)	BOSCH ABS/ASR 5.7
 7 Series (E38) (95-01)	ABS + TRACT. CONT	740d (95-99)	BOSCH ABS/ASC 5
 7 Series (E38) (95-01)	ABS + TRACT. CONT	740d (98-..)	BOSCH ABS/ASR 5.7
 7 Series (E38) (95-01)	ABS + TRACT. CONT	740i (95-99)	BOSCH ABS/ASC 5
 7 Series (E38) (95-01)	ABS + TRACT. CONT	740i (98-..)	BOSCH ABS/ASR 5.7
 7 Series (E38) (95-01)	ABS + TRACT. CONT	750i (95-99)	BOSCH ABS/ASC 5
 7 Series (E38) (95-01)	ABS + TRACT. CONT	750i (98-..)	BOSCH ABS/ASR 5.7
 7 Series (E38) (95-01)	ABS + TRACT. CONT	L7 (95-99)	BOSCH ABS/ASC 5
 7 Series (E38) (95-01)	ABS + TRACT. CONT	L7 (98-..)	BOSCH ABS/ASR 5.7
 7 Series (E38) (95-01)	AIRBAG	725d (95-97)	TEMIC AirBag ZAE2 5999
 7 Series (E38) (95-01)	AIRBAG	725d (98-01)	TEMIC AirBag MRS2/3
 7 Series (E38) (95-01)	AIRBAG	728i (95-97)	TEMIC AirBag ZAE2 5999
 7 Series (E38) (95-01)	AIRBAG	728i (98-01)	TEMIC AirBag MRS2/3
 7 Series (E38) (95-01)	AIRBAG	730d (95-97)	TEMIC AirBag ZAE2 5999

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 7 Series (E38) (95-01)	AIRBAG	730d (98-01)	TEMIC AirBag MRS2/3
 7 Series (E38) (95-01)	AIRBAG	730i (95-97)	TEMIC AirBag ZAE2 5999
 7 Series (E38) (95-01)	AIRBAG	730i (98-01)	TEMIC AirBag MRS2/3
 7 Series (E38) (95-01)	AIRBAG	735i (95-97)	TEMIC AirBag ZAE2 5999
 7 Series (E38) (95-01)	AIRBAG	735i (98-01)	TEMIC AirBag MRS2/3
 7 Series (E38) (95-01)	AIRBAG	740d (95-97)	TEMIC AirBag ZAE2 5999
 7 Series (E38) (95-01)	AIRBAG	740d (98-01)	TEMIC AirBag MRS2/3
 7 Series (E38) (95-01)	AIRBAG	740i (95-97)	TEMIC AirBag ZAE2 5999
 7 Series (E38) (95-01)	AIRBAG	740i (98-01)	TEMIC AirBag MRS2/3
 7 Series (E38) (95-01)	AIRBAG	750i (95-97)	TEMIC AirBag ZAE2 5999
 7 Series (E38) (95-01)	AIRBAG	750i (98-01)	TEMIC AirBag MRS2/3
 7 Series (E38) (95-01)	AIRBAG	L7 (95-97)	TEMIC AirBag ZAE2 5999
 7 Series (E38) (95-01)	AIRBAG	L7 (98-01)	TEMIC AirBag MRS2/3
 7 Series (E38) (95-01)	ENGINE MANAGEME	725d 30 6D 1 (08/98-..)	BOSCH EDC 15 C4 DDE 4.0
 7 Series (E38) (95-01)	ENGINE MANAGEME	728i 28 6S 1 (95-96)	SIEMENS MPI DME MS 41.0
 7 Series (E38) (95-01)	ENGINE MANAGEME	730d 30 6D 1 (08/98-..)	BOSCH EDC 15 C4 DDE 4.0
 7 Series (E38) (95-01)	ENGINE MANAGEME	730i 30 8S 1 (95-96)	BOSCH Motronic DME M3.3
 7 Series (E38) (95-01)	ENGINE MANAGEME	735i 3.6 200kW (01-..)	EOBD
 7 Series (E38) (95-01)	ENGINE MANAGEME	740d 30 6D 1 (08/98-..)	BOSCH EDC 15 C4 DDE 4.0
 7 Series (E38) (95-01)	ENGINE MANAGEME	740i 40 8S 1 (95-96)	BOSCH Motronic DME M3.3
 7 Series (E38) (95-01)	ENGINE MANAGEME	750i 40 8S 1 (95-96)	BOSCH Motronic DME M3.3
 7 Series (E38) (95-01)	ENGINE MANAGEME	L7 40 8S 1 (95-96)	BOSCH Motronic DME M3.3
 7 Series (E38) (95-01)	MAINTENANCE	725d (...-09/00)	Service
 7 Series (E38) (95-01)	MAINTENANCE	725d (09/00-..)	MANUAL
 7 Series (E38) (95-01)	MAINTENANCE	728i (...-09/00)	Service
 7 Series (E38) (95-01)	MAINTENANCE	728i (09/00-..)	MANUAL
 7 Series (E38) (95-01)	MAINTENANCE	730d (...-09/00)	Service
 7 Series (E38) (95-01)	MAINTENANCE	730d (09/00-..)	MANUAL
 7 Series (E38) (95-01)	MAINTENANCE	730i (...-09/00)	Service
 7 Series (E38) (95-01)	MAINTENANCE	730i (09/00-..)	MANUAL
 7 Series (E38) (95-01)	MAINTENANCE	735i (...-09/00)	Service
 7 Series (E38) (95-01)	MAINTENANCE	735i (09/00-..)	MANUAL
 7 Series (E38) (95-01)	MAINTENANCE	740d (...-09/00)	Service
 7 Series (E38) (95-01)	MAINTENANCE	740d (09/00-..)	MANUAL
 7 Series (E38) (95-01)	MAINTENANCE	740i (...-09/00)	Service
 7 Series (E38) (95-01)	MAINTENANCE	740i (09/00-..)	MANUAL
 7 Series (E38) (95-01)	MAINTENANCE	750i (...-09/00)	Service
 7 Series (E38) (95-01)	MAINTENANCE	750i (09/00-..)	MANUAL
 7 Series (E38) (95-01)	MAINTENANCE	L7 (...-09/00)	Service
 7 Series (E38) (95-01)	MAINTENANCE	L7 (09/00-..)	MANUAL
 7 Series (E38) (95-01)	SERVICE LIGHT RES	725d (...-09/00)	Service
 7 Series (E38) (95-01)	SERVICE LIGHT RES	725d (09/00-..)	MANUAL
 7 Series (E38) (95-01)	SERVICE LIGHT RES	728i (...-09/00)	Service
 7 Series (E38) (95-01)	SERVICE LIGHT RES	728i (09/00-..)	MANUAL
 7 Series (E38) (95-01)	SERVICE LIGHT RES	730d (...-09/00)	Service
 7 Series (E38) (95-01)	SERVICE LIGHT RES	730d (09/00-..)	MANUAL
 7 Series (E38) (95-01)	SERVICE LIGHT RES	730i (...-09/00)	Service
 7 Series (E38) (95-01)	SERVICE LIGHT RES	730i (09/00-..)	MANUAL
 7 Series (E38) (95-01)	SERVICE LIGHT RES	735i (...-09/00)	Service
 7 Series (E38) (95-01)	SERVICE LIGHT RES	735i (09/00-..)	MANUAL
 7 Series (E38) (95-01)	SERVICE LIGHT RES	740d (...-09/00)	Service
 7 Series (E38) (95-01)	SERVICE LIGHT RES	740d (09/00-..)	MANUAL
 7 Series (E38) (95-01)	SERVICE LIGHT RES	740i (...-09/00)	Service
 7 Series (E38) (95-01)	SERVICE LIGHT RES	740i (09/00-..)	MANUAL
 7 Series (E38) (95-01)	SERVICE LIGHT RES	750i (...-09/00)	Service
 7 Series (E38) (95-01)	SERVICE LIGHT RES	750i (09/00-..)	MANUAL
 7 Series (E38) (95-01)	SERVICE LIGHT RES	L7 (...-09/00)	Service
 7 Series (E38) (95-01)	SERVICE LIGHT RES	L7 (09/00-..)	MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 7 Series (E65-E66) (02-08)	ABS + TRACT. CONT	730d (02-07)	BOSCH DSC
 7 Series (E65-E66) (02-08)	ABS + TRACT. CONT	730i (02-07)	BOSCH DSC
 7 Series (E65-E66) (02-08)	ABS + TRACT. CONT	735i (02-07)	BOSCH DSC
 7 Series (E65-E66) (02-08)	ABS + TRACT. CONT	740d (02-07)	BOSCH DSC
 7 Series (E65-E66) (02-08)	ABS + TRACT. CONT	740i (02-07)	BOSCH DSC
 7 Series (E65-E66) (02-08)	ABS + TRACT. CONT	745d (02-07)	BOSCH DSC
 7 Series (E65-E66) (02-08)	ABS + TRACT. CONT	745i (02-07)	BOSCH DSC
 7 Series (E65-E66) (02-08)	ABS + TRACT. CONT	750i (02-07)	BOSCH DSC
 7 Series (E65-E66) (02-08)	ABS + TRACT. CONT	760i (02-07)	BOSCH DSC
 7 Series (E65-E66) (02-08)	AIRBAG	730d (02-07)	DELPHI SRS SASL (Left Side)
 7 Series (E65-E66) (02-08)	AIRBAG	730d (02-07)	DELPHI SRS SASR (Right Side)
 7 Series (E65-E66) (02-08)	AIRBAG	730d (02-07)	DELPHI SRS SBSL (Left Side)
 7 Series (E65-E66) (02-08)	AIRBAG	730d (02-07)	DELPHI SRS SBSR (Right Side)
 7 Series (E65-E66) (02-08)	AIRBAG	730d (02-07)	DELPHI SRS SFZ Satellite Central
 7 Series (E65-E66) (02-08)	AIRBAG	730d (02-07)	DELPHI SRS SSFA (Driver Side)
 7 Series (E65-E66) (02-08)	AIRBAG	730d (02-07)	DELPHI SRS SSH (Rear Seats)
 7 Series (E65-E66) (02-08)	AIRBAG	730d (02-07)	LEAR SRS SSBF (Passenger Side)
 7 Series (E65-E66) (02-08)	AIRBAG	730d (02-07)	SIEMENS SRS STVL(Left Door)
 7 Series (E65-E66) (02-08)	AIRBAG	730d (02-07)	SIEMENS SRS STVR(Right Door)
 7 Series (E65-E66) (02-08)	AIRBAG	730i (02-07)	DELPHI SRS SASL (Left Side)
 7 Series (E65-E66) (02-08)	AIRBAG	730i (02-07)	DELPHI SRS SASR (Right Side)
 7 Series (E65-E66) (02-08)	AIRBAG	730i (02-07)	DELPHI SRS SBSL (Left Side)
 7 Series (E65-E66) (02-08)	AIRBAG	730i (02-07)	DELPHI SRS SBSR (Right Side)
 7 Series (E65-E66) (02-08)	AIRBAG	730i (02-07)	DELPHI SRS SFZ Satellite Central
 7 Series (E65-E66) (02-08)	AIRBAG	730i (02-07)	DELPHI SRS SSFA (Driver Side)
 7 Series (E65-E66) (02-08)	AIRBAG	730i (02-07)	DELPHI SRS SSH (Rear Seats)
 7 Series (E65-E66) (02-08)	AIRBAG	730i (02-07)	LEAR SRS SSBF (Passenger Side)
 7 Series (E65-E66) (02-08)	AIRBAG	730i (02-07)	SIEMENS SRS STVL(Left Door)
 7 Series (E65-E66) (02-08)	AIRBAG	730i (02-07)	SIEMENS SRS STVR(Right Door)
 7 Series (E65-E66) (02-08)	AIRBAG	735i (02-07)	DELPHI SRS SASL (Left Side)
 7 Series (E65-E66) (02-08)	AIRBAG	735i (02-07)	DELPHI SRS SASR (Right Side)
 7 Series (E65-E66) (02-08)	AIRBAG	735i (02-07)	DELPHI SRS SBSL (Left Side)
 7 Series (E65-E66) (02-08)	AIRBAG	735i (02-07)	DELPHI SRS SBSR (Right Side)
 7 Series (E65-E66) (02-08)	AIRBAG	735i (02-07)	DELPHI SRS SFZ Satellite Central
 7 Series (E65-E66) (02-08)	AIRBAG	735i (02-07)	DELPHI SRS SSFA (Driver Side)
 7 Series (E65-E66) (02-08)	AIRBAG	735i (02-07)	DELPHI SRS SSH (Rear Seats)
 7 Series (E65-E66) (02-08)	AIRBAG	735i (02-07)	LEAR SRS SSBF (Passenger Side)
 7 Series (E65-E66) (02-08)	AIRBAG	735i (02-07)	SIEMENS SRS STVL(Left Door)
 7 Series (E65-E66) (02-08)	AIRBAG	735i (02-07)	SIEMENS SRS STVR(Right Door)
 7 Series (E65-E66) (02-08)	AIRBAG	740d (02-07)	DELPHI SRS SASL (Left Side)
 7 Series (E65-E66) (02-08)	AIRBAG	740d (02-07)	DELPHI SRS SASR (Right Side)
 7 Series (E65-E66) (02-08)	AIRBAG	740d (02-07)	DELPHI SRS SBSL (Left Side)
 7 Series (E65-E66) (02-08)	AIRBAG	740d (02-07)	DELPHI SRS SBSR (Right Side)
 7 Series (E65-E66) (02-08)	AIRBAG	740d (02-07)	DELPHI SRS SFZ Satellite Central
 7 Series (E65-E66) (02-08)	AIRBAG	740d (02-07)	DELPHI SRS SSFA (Driver Side)
 7 Series (E65-E66) (02-08)	AIRBAG	740d (02-07)	DELPHI SRS SSH (Rear Seats)
 7 Series (E65-E66) (02-08)	AIRBAG	740d (02-07)	LEAR SRS SSBF (Passenger Side)
 7 Series (E65-E66) (02-08)	AIRBAG	740d (02-07)	SIEMENS SRS STVL(Left Door)
 7 Series (E65-E66) (02-08)	AIRBAG	740d (02-07)	SIEMENS SRS STVR(Right Door)
 7 Series (E65-E66) (02-08)	AIRBAG	740i (02-07)	DELPHI SRS SASL (Left Side)
 7 Series (E65-E66) (02-08)	AIRBAG	740i (02-07)	DELPHI SRS SASR (Right Side)
 7 Series (E65-E66) (02-08)	AIRBAG	740i (02-07)	DELPHI SRS SBSL (Left Side)
 7 Series (E65-E66) (02-08)	AIRBAG	740i (02-07)	DELPHI SRS SBSR (Right Side)
 7 Series (E65-E66) (02-08)	AIRBAG	740i (02-07)	DELPHI SRS SFZ Satellite Central
 7 Series (E65-E66) (02-08)	AIRBAG	740i (02-07)	DELPHI SRS SSFA (Driver Side)
 7 Series (E65-E66) (02-08)	AIRBAG	740i (02-07)	DELPHI SRS SSH (Rear Seats)
 7 Series (E65-E66) (02-08)	AIRBAG	740i (02-07)	LEAR SRS SSBF (Passenger Side)
 7 Series (E65-E66) (02-08)	AIRBAG	740i (02-07)	SIEMENS SRS STVL(Left Door)

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 7 Series (E65-E66) (02-08)	AIRBAG	740i (02-07)	SIEMENS SRS STVR(Right Door)
 7 Series (E65-E66) (02-08)	AIRBAG	745d (02-07)	DELPHI SRS SASL (Left Side)
 7 Series (E65-E66) (02-08)	AIRBAG	745d (02-07)	DELPHI SRS SASR (Right Side)
 7 Series (E65-E66) (02-08)	AIRBAG	745d (02-07)	DELPHI SRS SBSL (Left Side)
 7 Series (E65-E66) (02-08)	AIRBAG	745d (02-07)	DELPHI SRS SBSR (Right Side)
 7 Series (E65-E66) (02-08)	AIRBAG	745d (02-07)	DELPHI SRS SFZ Satellite Central
 7 Series (E65-E66) (02-08)	AIRBAG	745d (02-07)	DELPHI SRS SSFA (Driver Side)
 7 Series (E65-E66) (02-08)	AIRBAG	745d (02-07)	DELPHI SRS SSH (Rear Seats)
 7 Series (E65-E66) (02-08)	AIRBAG	745d (02-07)	LEAR SRS SSBF (Passenger Side)
 7 Series (E65-E66) (02-08)	AIRBAG	745d (02-07)	SIEMENS SRS STVL(Left Door)
 7 Series (E65-E66) (02-08)	AIRBAG	745d (02-07)	SIEMENS SRS STVR(Right Door)
 7 Series (E65-E66) (02-08)	AIRBAG	745i (02-07)	DELPHI SRS SASL (Left Side)
 7 Series (E65-E66) (02-08)	AIRBAG	745i (02-07)	DELPHI SRS SASR (Right Side)
 7 Series (E65-E66) (02-08)	AIRBAG	745i (02-07)	DELPHI SRS SBSL (Left Side)
 7 Series (E65-E66) (02-08)	AIRBAG	745i (02-07)	DELPHI SRS SBSR (Right Side)
 7 Series (E65-E66) (02-08)	AIRBAG	745i (02-07)	DELPHI SRS SFZ Satellite Central
 7 Series (E65-E66) (02-08)	AIRBAG	745i (02-07)	DELPHI SRS SSFA (Driver Side)
 7 Series (E65-E66) (02-08)	AIRBAG	745i (02-07)	DELPHI SRS SSH (Rear Seats)
 7 Series (E65-E66) (02-08)	AIRBAG	745i (02-07)	LEAR SRS SSBF (Passenger Side)
 7 Series (E65-E66) (02-08)	AIRBAG	745i (02-07)	SIEMENS SRS STVL(Left Door)
 7 Series (E65-E66) (02-08)	AIRBAG	745i (02-07)	SIEMENS SRS STVR(Right Door)
 7 Series (E65-E66) (02-08)	AIRBAG	750i (02-07)	DELPHI SRS SASL (Left Side)
 7 Series (E65-E66) (02-08)	AIRBAG	750i (02-07)	DELPHI SRS SASR (Right Side)
 7 Series (E65-E66) (02-08)	AIRBAG	750i (02-07)	DELPHI SRS SBSL (Left Side)
 7 Series (E65-E66) (02-08)	AIRBAG	750i (02-07)	DELPHI SRS SBSR (Right Side)
 7 Series (E65-E66) (02-08)	AIRBAG	750i (02-07)	DELPHI SRS SFZ Satellite Central
 7 Series (E65-E66) (02-08)	AIRBAG	750i (02-07)	DELPHI SRS SSFA (Driver Side)
 7 Series (E65-E66) (02-08)	AIRBAG	750i (02-07)	DELPHI SRS SSH (Rear Seats)
 7 Series (E65-E66) (02-08)	AIRBAG	750i (02-07)	LEAR SRS SSBF (Passenger Side)
 7 Series (E65-E66) (02-08)	AIRBAG	750i (02-07)	SIEMENS SRS STVL(Left Door)
 7 Series (E65-E66) (02-08)	AIRBAG	750i (02-07)	SIEMENS SRS STVR(Right Door)
 7 Series (E65-E66) (02-08)	AIRBAG	760i (02-07)	DELPHI SRS SASL (Left Side)
 7 Series (E65-E66) (02-08)	AIRBAG	760i (02-07)	DELPHI SRS SASR (Right Side)
 7 Series (E65-E66) (02-08)	AIRBAG	760i (02-07)	DELPHI SRS SBSL (Left Side)
 7 Series (E65-E66) (02-08)	AIRBAG	760i (02-07)	DELPHI SRS SBSR (Right Side)
 7 Series (E65-E66) (02-08)	AIRBAG	760i (02-07)	DELPHI SRS SFZ Satellite Central
 7 Series (E65-E66) (02-08)	AIRBAG	760i (02-07)	DELPHI SRS SSFA (Driver Side)
 7 Series (E65-E66) (02-08)	AIRBAG	760i (02-07)	DELPHI SRS SSH (Rear Seats)
 7 Series (E65-E66) (02-08)	AIRBAG	760i (02-07)	LEAR SRS SSBF (Passenger Side)
 7 Series (E65-E66) (02-08)	AIRBAG	760i (02-07)	SIEMENS SRS STVL(Left Door)
 7 Series (E65-E66) (02-08)	AIRBAG	760i (02-07)	SIEMENS SRS STVR(Right Door)
 7 Series (E65-E66) (02-08)	AUTOM. TRANSMISSI	730d (02-07)	EGS Steptronic
 7 Series (E65-E66) (02-08)	AUTOM. TRANSMISSI	730i (02-07)	EGS Steptronic
 7 Series (E65-E66) (02-08)	AUTOM. TRANSMISSI	735i (02-07)	EGS Steptronic
 7 Series (E65-E66) (02-08)	AUTOM. TRANSMISSI	740d (02-07)	EGS Steptronic
 7 Series (E65-E66) (02-08)	AUTOM. TRANSMISSI	740i (02-07)	EGS Steptronic
 7 Series (E65-E66) (02-08)	AUTOM. TRANSMISSI	745d (02-07)	EGS Steptronic
 7 Series (E65-E66) (02-08)	AUTOM. TRANSMISSI	745i (02-07)	EGS Steptronic
 7 Series (E65-E66) (02-08)	AUTOM. TRANSMISSI	750i (02-07)	EGS Steptronic
 7 Series (E65-E66) (02-08)	AUTOM. TRANSMISSI	760i (02-07)	EGS Steptronic
 7 Series (E65-E66) (02-08)	CLIMA	730d (02-07)	IHKA Klimautomatik
 7 Series (E65-E66) (02-08)	CLIMA	730i (02-07)	IHKA Klimautomatik
 7 Series (E65-E66) (02-08)	CLIMA	735i (02-07)	IHKA Klimautomatik
 7 Series (E65-E66) (02-08)	CLIMA	740d (02-07)	IHKA Klimautomatik
 7 Series (E65-E66) (02-08)	CLIMA	740i (02-07)	IHKA Klimautomatik
 7 Series (E65-E66) (02-08)	CLIMA	745d (02-07)	IHKA Klimautomatik
 7 Series (E65-E66) (02-08)	CLIMA	745i (02-07)	IHKA Klimautomatik
 7 Series (E65-E66) (02-08)	CLIMA	750i (02-07)	IHKA Klimautomatik

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 7 Series (E65-E66) (02-08)	CLIMA	760i (02-07)	IHKA Klimautomatik
 7 Series (E65-E66) (02-08)	DASHBOARD	730d (02-07)	Kombi
 7 Series (E65-E66) (02-08)	DASHBOARD	730i (02-07)	Kombi
 7 Series (E65-E66) (02-08)	DASHBOARD	735i (02-07)	Kombi
 7 Series (E65-E66) (02-08)	DASHBOARD	740d (02-07)	Kombi
 7 Series (E65-E66) (02-08)	DASHBOARD	740i (02-07)	Kombi
 7 Series (E65-E66) (02-08)	DASHBOARD	745d (02-07)	Kombi
 7 Series (E65-E66) (02-08)	DASHBOARD	745i (02-07)	Kombi
 7 Series (E65-E66) (02-08)	DASHBOARD	750i (02-07)	Kombi
 7 Series (E65-E66) (02-08)	DASHBOARD	760i (02-07)	Kombi
 7 Series (E65-E66) (02-08)	ELECTRIC STEERING	730d (02-07)	CIM
 7 Series (E65-E66) (02-08)	ELECTRIC STEERING	730i (02-07)	CIM
 7 Series (E65-E66) (02-08)	ELECTRIC STEERING	735i (02-07)	CIM
 7 Series (E65-E66) (02-08)	ELECTRIC STEERING	740d (02-07)	CIM
 7 Series (E65-E66) (02-08)	ELECTRIC STEERING	740i (02-07)	CIM
 7 Series (E65-E66) (02-08)	ELECTRIC STEERING	745d (02-07)	CIM
 7 Series (E65-E66) (02-08)	ELECTRIC STEERING	745i (02-07)	CIM
 7 Series (E65-E66) (02-08)	ELECTRIC STEERING	750i (02-07)	CIM
 7 Series (E65-E66) (02-08)	ELECTRIC STEERING	760i (02-07)	CIM
 7 Series (E65-E66) (02-08)	ENGINE MANAGEME	730d 30 6D 3 (02-07)	BOSCH DDE 6
 7 Series (E65-E66) (02-08)	ENGINE MANAGEME	730i (02-07)	EOBD
 7 Series (E65-E66) (02-08)	ENGINE MANAGEME	735i (02-07)	EOBD
 7 Series (E65-E66) (02-08)	ENGINE MANAGEME	740d (04-07)	EOBD
 7 Series (E65-E66) (02-08)	ENGINE MANAGEME	740i (02-07)	EOBD
 7 Series (E65-E66) (02-08)	ENGINE MANAGEME	745d (02-07)	EOBD
 7 Series (E65-E66) (02-08)	ENGINE MANAGEME	745i (02-07)	BOSCH DME ME9
 7 Series (E65-E66) (02-08)	ENGINE MANAGEME	745i (02-07)	VDO Valvetronic
 7 Series (E65-E66) (02-08)	ENGINE MANAGEME	745i (02-07)	VDO Valvetronic 2
 7 Series (E65-E66) (02-08)	ENGINE MANAGEME	750i (02-08)	EOBD
 7 Series (E65-E66) (02-08)	ENGINE MANAGEME	760i (02-08)	EOBD
 7 Series (E65-E66) (02-08)	IMMOBILIZER	730d (02-07)	SIEMENS CAS Car Access System
 7 Series (E65-E66) (02-08)	IMMOBILIZER	730i (02-07)	SIEMENS CAS Car Access System
 7 Series (E65-E66) (02-08)	IMMOBILIZER	735i (02-07)	SIEMENS CAS Car Access System
 7 Series (E65-E66) (02-08)	IMMOBILIZER	740d (02-07)	SIEMENS CAS Car Access System
 7 Series (E65-E66) (02-08)	IMMOBILIZER	740i (02-07)	SIEMENS CAS Car Access System
 7 Series (E65-E66) (02-08)	IMMOBILIZER	745d (02-07)	SIEMENS CAS Car Access System
 7 Series (E65-E66) (02-08)	IMMOBILIZER	745i (02-07)	SIEMENS CAS Car Access System
 7 Series (E65-E66) (02-08)	IMMOBILIZER	750i (02-07)	SIEMENS CAS Car Access System
 7 Series (E65-E66) (02-08)	IMMOBILIZER	760i (02-07)	SIEMENS CAS Car Access System
 7 Series (E65-E66) (02-08)	MAINTENANCE	730d (02-07)	CIM
 7 Series (E65-E66) (02-08)	MAINTENANCE	730d (02-07)	Tyre Monitor MANUAL
 7 Series (E65-E66) (02-08)	MAINTENANCE	730d (04-07)	MANUAL
 7 Series (E65-E66) (02-08)	MAINTENANCE	730d 30 6D 3 (02-07)	BOSCH DDE 6
 7 Series (E65-E66) (02-08)	MAINTENANCE	730i (02-07)	CIM
 7 Series (E65-E66) (02-08)	MAINTENANCE	730i (02-07)	Tyre Monitor MANUAL
 7 Series (E65-E66) (02-08)	MAINTENANCE	730i (04-08)	MANUAL
 7 Series (E65-E66) (02-08)	MAINTENANCE	735i (02-07)	CIM
 7 Series (E65-E66) (02-08)	MAINTENANCE	735i (04-08)	MANUAL
 7 Series (E65-E66) (02-08)	MAINTENANCE	740d (02-07)	CIM
 7 Series (E65-E66) (02-08)	MAINTENANCE	740d (02-07)	Tyre Monitor MANUAL
 7 Series (E65-E66) (02-08)	MAINTENANCE	740d (04-07)	MANUAL
 7 Series (E65-E66) (02-08)	MAINTENANCE	740i (02-07)	CIM
 7 Series (E65-E66) (02-08)	MAINTENANCE	740i (02-07)	Tyre Monitor MANUAL
 7 Series (E65-E66) (02-08)	MAINTENANCE	740i (04-07)	MANUAL
 7 Series (E65-E66) (02-08)	MAINTENANCE	745d (02-07)	CIM
 7 Series (E65-E66) (02-08)	MAINTENANCE	745d (02-07)	Tyre Monitor MANUAL
 7 Series (E65-E66) (02-08)	MAINTENANCE	745d (04-07)	MANUAL
 7 Series (E65-E66) (02-08)	MAINTENANCE	745i (02-07)	CIM

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 7 Series (E65-E66) (02-08)	MAINTENANCE	745i (04-07)	MANUAL
 7 Series (E65-E66) (02-08)	MAINTENANCE	750i (02-07)	CIM
 7 Series (E65-E66) (02-08)	MAINTENANCE	750i (02-07)	Tyre Monitor MANUAL
 7 Series (E65-E66) (02-08)	MAINTENANCE	750i (04-07)	MANUAL
 7 Series (E65-E66) (02-08)	MAINTENANCE	760i (02-07)	CIM
 7 Series (E65-E66) (02-08)	MAINTENANCE	760i (02-07)	Tyre Monitor MANUAL
 7 Series (E65-E66) (02-08)	MAINTENANCE	760i (04-07)	MANUAL
 7 Series (E65-E66) (02-08)	PARK.BRAKE	730d (02-07)	Siemens EMF
 7 Series (E65-E66) (02-08)	PARK.BRAKE	730i (02-07)	Siemens EMF
 7 Series (E65-E66) (02-08)	PARK.BRAKE	735i (02-07)	Siemens EMF
 7 Series (E65-E66) (02-08)	PARK.BRAKE	740d (02-07)	Siemens EMF
 7 Series (E65-E66) (02-08)	PARK.BRAKE	740i (02-07)	Siemens EMF
 7 Series (E65-E66) (02-08)	PARK.BRAKE	745d (02-07)	Siemens EMF
 7 Series (E65-E66) (02-08)	PARK.BRAKE	745i (02-07)	Siemens EMF
 7 Series (E65-E66) (02-08)	PARK.BRAKE	750i (02-07)	Siemens EMF
 7 Series (E65-E66) (02-08)	PARK.BRAKE	760i (02-07)	Siemens EMF
 7 Series (E65-E66) (02-08)	PARKING HELP	730d (02-07)	VALEO PDC (Park Distance Control)
 7 Series (E65-E66) (02-08)	PARKING HELP	730i (02-07)	VALEO PDC (Park Distance Control)
 7 Series (E65-E66) (02-08)	PARKING HELP	735i (02-07)	VALEO PDC (Park Distance Control)
 7 Series (E65-E66) (02-08)	PARKING HELP	740d (02-07)	VALEO PDC (Park Distance Control)
 7 Series (E65-E66) (02-08)	PARKING HELP	740i (02-07)	VALEO PDC (Park Distance Control)
 7 Series (E65-E66) (02-08)	PARKING HELP	745d (02-07)	VALEO PDC (Park Distance Control)
 7 Series (E65-E66) (02-08)	PARKING HELP	745i (02-07)	VALEO PDC (Park Distance Control)
 7 Series (E65-E66) (02-08)	PARKING HELP	750i (02-07)	VALEO PDC (Park Distance Control)
 7 Series (E65-E66) (02-08)	PARKING HELP	760i (02-07)	VALEO PDC (Park Distance Control)
 7 Series (E65-E66) (02-08)	SERVICE LIGHT RES	730d (04-07)	MANUAL
 7 Series (E65-E66) (02-08)	SERVICE LIGHT RES	730i (04-08)	MANUAL
 7 Series (E65-E66) (02-08)	SERVICE LIGHT RES	735i (04-08)	MANUAL
 7 Series (E65-E66) (02-08)	SERVICE LIGHT RES	740d (04-07)	MANUAL
 7 Series (E65-E66) (02-08)	SERVICE LIGHT RES	740i (04-07)	MANUAL
 7 Series (E65-E66) (02-08)	SERVICE LIGHT RES	745d (04-07)	MANUAL
 7 Series (E65-E66) (02-08)	SERVICE LIGHT RES	745i (04-07)	MANUAL
 7 Series (E65-E66) (02-08)	SERVICE LIGHT RES	750i (04-07)	MANUAL
 7 Series (E65-E66) (02-08)	SERVICE LIGHT RES	760i (04-07)	MANUAL
 7 Series (E65-E66) (02-08)	TIRE PRESSURE	730d (02-07)	Tyre Monitor MANUAL
 7 Series (E65-E66) (02-08)	TIRE PRESSURE	730i (02-07)	Tyre Monitor MANUAL
 7 Series (E65-E66) (02-08)	TIRE PRESSURE	740d (02-07)	Tyre Monitor MANUAL
 7 Series (E65-E66) (02-08)	TIRE PRESSURE	740i (02-07)	Tyre Monitor MANUAL
 7 Series (E65-E66) (02-08)	TIRE PRESSURE	745d (02-07)	Tyre Monitor MANUAL
 7 Series (E65-E66) (02-08)	TIRE PRESSURE	750i (02-07)	Tyre Monitor MANUAL
 7 Series (E65-E66) (02-08)	TIRE PRESSURE	760i (02-07)	Tyre Monitor MANUAL
 7 Series (F01-F02_F04) (08)	CRUISE CONTROL	730d (09-10)	ACC LRR 60
 7 Series (F01-F02_F04) (08)	CRUISE CONTROL	740d (09-10)	ACC LRR 60
 7 Series (F01-F02_F04) (08)	CRUISE CONTROL	740i (09-10)	ACC LRR 60
 7 Series (F01-F02_F04) (08)	CRUISE CONTROL	740xd (09-10)	ACC LRR 60
 7 Series (F01-F02_F04) (08)	CRUISE CONTROL	750i (09-10)	ACC LRR 60
 7 Series (F01-F02_F04) (08)	CRUISE CONTROL	750xd (09-10)	ACC LRR 60
 7 Series (F01-F02_F04) (08)	CRUISE CONTROL	750xi (09-10)	ACC LRR 60
 7 Series (F01-F02_F04) (08)	CRUISE CONTROL	760i (09-10)	ACC LRR 60
 8 Series (E31) (90-96)	ENGINE MANAGEME	840i 40 8S 1 (95-96)	BOSCH Motronic DME M3.3
 8 Series (E31) (90-96)	ENGINE MANAGEME	850i 50 12A 2 (90-94)	Motronic DMEM1.7ECU1
 8 Series (E31) (90-96)	ENGINE MANAGEME	850i 56 12 1 (92-96)	Motronic DMEM1.7.1ECU1
 8 Series (E31) (90-96)	ENGINE MANAGEME	850i 50 12A 2 (90-94)	Motronic DMEM1.7ECU2
 8 Series (E31) (90-96)	ENGINE MANAGEME	850i 56 12 1 (92-96)	Motronic DMEM1.7.1ECU2
 8 Series (E31) (90-96)	MAINTENANCE	840i (.-09/00)	Service
 8 Series (E31) (90-96)	MAINTENANCE	850i (.-09/00)	Service
 8 Series (E31) (90-96)	SERVICE LIGHT RES	840i (.-09/00)	Service
 8 Series (E31) (90-96)	SERVICE LIGHT RES	850i (.-09/00)	Service

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 X1 Series (E84) (09-..)	4WD ELECTRONICS	sDrive 18i (09-..)	LMV 84
 X1 Series (E84) (09-..)	4WD ELECTRONICS	sDrive18d (09-..)	LMV 84
 X1 Series (E84) (09-..)	4WD ELECTRONICS	sDrive20d (09-..)	LMV 84
 X1 Series (E84) (09-..)	4WD ELECTRONICS	xDrive 18d (09-..)	LMV 84
 X1 Series (E84) (09-..)	4WD ELECTRONICS	xDrive 20d (09-..)	LMV 84
 X1 Series (E84) (09-..)	4WD ELECTRONICS	xDrive 20i (09-..)	LMV 84
 X1 Series (E84) (09-..)	4WD ELECTRONICS	xDrive 23d (09-..)	LMV 84
 X1 Series (E84) (09-..)	4WD ELECTRONICS	xDrive 25i (09-..)	LMV 84
 X1 Series (E84) (09-..)	4WD ELECTRONICS	xDrive 28i (09-..)	LMV 84
 X1 Series (E84) (09-..)	ABS + TRACT. CONT	sDrive 18i (09-..)	DSC DXC8
 X1 Series (E84) (09-..)	ABS + TRACT. CONT	sDrive18d (09-..)	DSC DXC8
 X1 Series (E84) (09-..)	ABS + TRACT. CONT	sDrive20d (09-..)	DSC DXC8
 X1 Series (E84) (09-..)	ABS + TRACT. CONT	xDrive 18d (09-..)	DSC DXC8
 X1 Series (E84) (09-..)	ABS + TRACT. CONT	xDrive 20d (09-..)	DSC DXC8
 X1 Series (E84) (09-..)	ABS + TRACT. CONT	xDrive 20i (09-..)	DSC DXC8
 X1 Series (E84) (09-..)	ABS + TRACT. CONT	xDrive 23d (09-..)	DSC DXC8
 X1 Series (E84) (09-..)	ABS + TRACT. CONT	xDrive 25i (09-..)	DSC DXC8
 X1 Series (E84) (09-..)	ABS + TRACT. CONT	xDrive 28i (09-..)	DSC DXC8
 X1 Series (E84) (09-..)	AIRBAG	sDrive 18i (09-..)	MRS5
 X1 Series (E84) (09-..)	AIRBAG	sDrive18d (09-..)	MRS5
 X1 Series (E84) (09-..)	AIRBAG	sDrive20d (09-..)	MRS5
 X1 Series (E84) (09-..)	AIRBAG	xDrive 18d (09-..)	MRS5
 X1 Series (E84) (09-..)	AIRBAG	xDrive 20d (09-..)	MRS5
 X1 Series (E84) (09-..)	AIRBAG	xDrive 20i (09-..)	MRS5
 X1 Series (E84) (09-..)	AIRBAG	xDrive 23d (09-..)	MRS5
 X1 Series (E84) (09-..)	AIRBAG	xDrive 25i (09-..)	MRS5
 X1 Series (E84) (09-..)	AIRBAG	xDrive 28i (09-..)	MRS5
 X1 Series (E84) (09-..)	CONV. TOP/SUNROO	sDrive 18i (09-..)	FZD 87
 X1 Series (E84) (09-..)	CONV. TOP/SUNROO	sDrive18d (09-..)	FZD 87
 X1 Series (E84) (09-..)	CONV. TOP/SUNROO	sDrive20d (09-..)	FZD 87
 X1 Series (E84) (09-..)	CONV. TOP/SUNROO	xDrive 18d (09-..)	FZD 87
 X1 Series (E84) (09-..)	CONV. TOP/SUNROO	xDrive 20d (09-..)	FZD 87
 X1 Series (E84) (09-..)	CONV. TOP/SUNROO	xDrive 20i (09-..)	FZD 87
 X1 Series (E84) (09-..)	CONV. TOP/SUNROO	xDrive 23d (09-..)	FZD 87
 X1 Series (E84) (09-..)	CONV. TOP/SUNROO	xDrive 25i (09-..)	FZD 87
 X1 Series (E84) (09-..)	CONV. TOP/SUNROO	xDrive 28i (09-..)	FZD 87
 X1 Series (E84) (09-..)	CRUISE CONTROL	sDrive 18i (09-..)	ACC 2
 X1 Series (E84) (09-..)	CRUISE CONTROL	sDrive18d (09-..)	ACC 2
 X1 Series (E84) (09-..)	CRUISE CONTROL	sDrive20d (09-..)	ACC 2
 X1 Series (E84) (09-..)	CRUISE CONTROL	xDrive 18d (09-..)	ACC 2
 X1 Series (E84) (09-..)	CRUISE CONTROL	xDrive 20d (09-..)	ACC 2
 X1 Series (E84) (09-..)	CRUISE CONTROL	xDrive 20i (09-..)	ACC 2
 X1 Series (E84) (09-..)	CRUISE CONTROL	xDrive 23d (09-..)	ACC 2
 X1 Series (E84) (09-..)	CRUISE CONTROL	xDrive 25i (09-..)	ACC 2
 X1 Series (E84) (09-..)	CRUISE CONTROL	xDrive 28i (09-..)	ACC 2
 X1 Series (E84) (09-..)	DASHBOARD	sDrive 18i (09-..)	KOMBI PL2
 X1 Series (E84) (09-..)	DASHBOARD	sDrive18d (09-..)	KOMBI PL2
 X1 Series (E84) (09-..)	DASHBOARD	sDrive20d (09-..)	KOMBI PL2
 X1 Series (E84) (09-..)	DASHBOARD	xDrive 18d (09-..)	KOMBI PL2
 X1 Series (E84) (09-..)	DASHBOARD	xDrive 20d (09-..)	KOMBI PL2
 X1 Series (E84) (09-..)	DASHBOARD	xDrive 20i (09-..)	KOMBI PL2
 X1 Series (E84) (09-..)	DASHBOARD	xDrive 23d (09-..)	KOMBI PL2
 X1 Series (E84) (09-..)	DASHBOARD	xDrive 25i (09-..)	KOMBI PL2
 X1 Series (E84) (09-..)	DASHBOARD	xDrive 28i (09-..)	KOMBI PL2
 X1 Series (E84) (09-..)	ELECTRIC STEERING	sDrive 18i (09-..)	Active Front Steering AFS 70
 X1 Series (E84) (09-..)	ELECTRIC STEERING	sDrive 18i (09-..)	EPS 90
 X1 Series (E84) (09-..)	ELECTRIC STEERING	sDrive18d (09-..)	Active Front Steering AFS 70
 X1 Series (E84) (09-..)	ELECTRIC STEERING	sDrive18d (09-..)	EPS 90

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 X1 Series (E84) (09-..)	ELECTRIC STEERING	sDrive20d (09-..)	Active Front Steering AFS 70
 X1 Series (E84) (09-..)	ELECTRIC STEERING	sDrive20d (09-..)	EPS 90
 X1 Series (E84) (09-..)	ELECTRIC STEERING	xDrive 18d (09-..)	Active Front Steering AFS 70
 X1 Series (E84) (09-..)	ELECTRIC STEERING	xDrive 18d (09-..)	EPS 90
 X1 Series (E84) (09-..)	ELECTRIC STEERING	xDrive 20d (09-..)	Active Front Steering AFS 70
 X1 Series (E84) (09-..)	ELECTRIC STEERING	xDrive 20d (09-..)	EPS 90
 X1 Series (E84) (09-..)	ELECTRIC STEERING	xDrive 20i (09-..)	Active Front Steering AFS 70
 X1 Series (E84) (09-..)	ELECTRIC STEERING	xDrive 20i (09-..)	EPS 90
 X1 Series (E84) (09-..)	ELECTRIC STEERING	xDrive 23d (09-..)	Active Front Steering AFS 70
 X1 Series (E84) (09-..)	ELECTRIC STEERING	xDrive 23d (09-..)	EPS 90
 X1 Series (E84) (09-..)	ELECTRIC STEERING	xDrive 25i (09-..)	Active Front Steering AFS 70
 X1 Series (E84) (09-..)	ELECTRIC STEERING	xDrive 25i (09-..)	EPS 90
 X1 Series (E84) (09-..)	ELECTRIC STEERING	xDrive 28i (09-..)	Active Front Steering AFS 70
 X1 Series (E84) (09-..)	ELECTRIC STEERING	xDrive 28i (09-..)	EPS 90
 X1 Series (E84) (09-..)	ENGINE MANAGEME	sDrive 18i (09-..)	EOBD
 X1 Series (E84) (09-..)	ENGINE MANAGEME	sDrive18d (09-..)	EOBD
 X1 Series (E84) (09-..)	ENGINE MANAGEME	sDrive20d (09-..)	BOSCH DDE 7
 X1 Series (E84) (09-..)	ENGINE MANAGEME	xDrive 18d (09-..)	EOBD
 X1 Series (E84) (09-..)	ENGINE MANAGEME	xDrive 20d (09-..)	BOSCH DDE 7
 X1 Series (E84) (09-..)	ENGINE MANAGEME	xDrive 20i (09-..)	EOBD
 X1 Series (E84) (09-..)	ENGINE MANAGEME	xDrive 23d (09-..)	EOBD
 X1 Series (E84) (09-..)	ENGINE MANAGEME	xDrive 25i (09-..)	EOBD
 X1 Series (E84) (09-..)	ENGINE MANAGEME	xDrive 28i (09-..)	EOBD
 X1 Series (E84) (09-..)	IMMOBILIZER	sDrive 18i (09-..)	CAS
 X1 Series (E84) (09-..)	IMMOBILIZER	sDrive18d (09-..)	CAS
 X1 Series (E84) (09-..)	IMMOBILIZER	sDrive20d (09-..)	CAS
 X1 Series (E84) (09-..)	IMMOBILIZER	xDrive 18d (09-..)	CAS
 X1 Series (E84) (09-..)	IMMOBILIZER	xDrive 20d (09-..)	CAS
 X1 Series (E84) (09-..)	IMMOBILIZER	xDrive 20i (09-..)	CAS
 X1 Series (E84) (09-..)	IMMOBILIZER	xDrive 23d (09-..)	CAS
 X1 Series (E84) (09-..)	IMMOBILIZER	xDrive 25i (09-..)	CAS
 X1 Series (E84) (09-..)	IMMOBILIZER	xDrive 28i (09-..)	CAS
 X1 Series (E84) (09-..)	PARK.BRAKE	sDrive 18i (09-..)	EMF 89
 X1 Series (E84) (09-..)	PARK.BRAKE	sDrive18d (09-..)	EMF 89
 X1 Series (E84) (09-..)	PARK.BRAKE	sDrive20d (09-..)	EMF 89
 X1 Series (E84) (09-..)	PARK.BRAKE	xDrive 18d (09-..)	EMF 89
 X1 Series (E84) (09-..)	PARK.BRAKE	xDrive 20d (09-..)	EMF 89
 X1 Series (E84) (09-..)	PARK.BRAKE	xDrive 20i (09-..)	EMF 89
 X1 Series (E84) (09-..)	PARK.BRAKE	xDrive 23d (09-..)	EMF 89
 X1 Series (E84) (09-..)	PARK.BRAKE	xDrive 25i (09-..)	EMF 89
 X1 Series (E84) (09-..)	PARK.BRAKE	xDrive 28i (09-..)	EMF 89
 X1 Series (E84) (09-..)	RADIO / CD	sDrive 18i (09-..)	DAB 60 - DIGITAL RADIO
 X1 Series (E84) (09-..)	RADIO / CD	sDrive18d (09-..)	DAB 60 - DIGITAL RADIO
 X1 Series (E84) (09-..)	RADIO / CD	sDrive20d (09-..)	DAB 60 - DIGITAL RADIO
 X1 Series (E84) (09-..)	RADIO / CD	xDrive 18d (09-..)	DAB 60 - DIGITAL RADIO
 X1 Series (E84) (09-..)	RADIO / CD	xDrive 20d (09-..)	DAB 60 - DIGITAL RADIO
 X1 Series (E84) (09-..)	RADIO / CD	xDrive 20i (09-..)	DAB 60 - DIGITAL RADIO
 X1 Series (E84) (09-..)	RADIO / CD	xDrive 23d (09-..)	DAB 60 - DIGITAL RADIO
 X1 Series (E84) (09-..)	RADIO / CD	xDrive 25i (09-..)	DAB 60 - DIGITAL RADIO
 X1 Series (E84) (09-..)	RADIO / CD	xDrive 28i (09-..)	DAB 60 - DIGITAL RADIO
 X1 Series (E84) (09-..)	RAIN-LUMINOSITY S	sDrive 18i (09-..)	RLS 87
 X1 Series (E84) (09-..)	RAIN-LUMINOSITY S	sDrive18d (09-..)	RLS 87
 X1 Series (E84) (09-..)	RAIN-LUMINOSITY S	sDrive20d (09-..)	RLS 87
 X1 Series (E84) (09-..)	RAIN-LUMINOSITY S	xDrive 18d (09-..)	RLS 87
 X1 Series (E84) (09-..)	RAIN-LUMINOSITY S	xDrive 20d (09-..)	RLS 87
 X1 Series (E84) (09-..)	RAIN-LUMINOSITY S	xDrive 20i (09-..)	RLS 87
 X1 Series (E84) (09-..)	RAIN-LUMINOSITY S	xDrive 23d (09-..)	RLS 87
 X1 Series (E84) (09-..)	RAIN-LUMINOSITY S	xDrive 25i (09-..)	RLS 87

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 X1 Series (E84) (09-..)	RAIN-LUMINOSITY S	xDrive 28i (09-..)	RLS 87
 X1 Series (E84) (09-..)	SUSPENSION CONTR	sDrive 18i (09-..)	EDCK 65
 X1 Series (E84) (09-..)	SUSPENSION CONTR	sDrive18d (09-..)	EDCK 65
 X1 Series (E84) (09-..)	SUSPENSION CONTR	sDrive20d (09-..)	EDCK 65
 X1 Series (E84) (09-..)	SUSPENSION CONTR	xDrive 18d (09-..)	EDCK 65
 X1 Series (E84) (09-..)	SUSPENSION CONTR	xDrive 20d (09-..)	EDCK 65
 X1 Series (E84) (09-..)	SUSPENSION CONTR	xDrive 20i (09-..)	EDCK 65
 X1 Series (E84) (09-..)	SUSPENSION CONTR	xDrive 23d (09-..)	EDCK 65
 X1 Series (E84) (09-..)	SUSPENSION CONTR	xDrive 25i (09-..)	EDCK 65
 X1 Series (E84) (09-..)	SUSPENSION CONTR	xDrive 28i (09-..)	EDCK 65
 X1 Series (E84) (09-..)	TIRE PRESSURE	sDrive 18i (09-..)	RDC
 X1 Series (E84) (09-..)	TIRE PRESSURE	sDrive18d (09-..)	RDC
 X1 Series (E84) (09-..)	TIRE PRESSURE	sDrive20d (09-..)	RDC
 X1 Series (E84) (09-..)	TIRE PRESSURE	xDrive 18d (09-..)	RDC
 X1 Series (E84) (09-..)	TIRE PRESSURE	xDrive 20d (09-..)	RDC
 X1 Series (E84) (09-..)	TIRE PRESSURE	xDrive 20i (09-..)	RDC
 X1 Series (E84) (09-..)	TIRE PRESSURE	xDrive 23d (09-..)	RDC
 X1 Series (E84) (09-..)	TIRE PRESSURE	xDrive 25i (09-..)	RDC
 X1 Series (E84) (09-..)	TIRE PRESSURE	xDrive 28i (09-..)	RDC
 X3 Series (E83) (04-07)	ABS + TRACT. CONT	2.0d (04-07)	BOSCH DSC
 X3 Series (E83) (04-07)	ABS + TRACT. CONT	2.0i (05-07)	BOSCH DSC
 X3 Series (E83) (04-07)	ABS + TRACT. CONT	2.5i (04-07)	BOSCH DSC
 X3 Series (E83) (04-07)	ABS + TRACT. CONT	3.0d (05-07)	BOSCH DSC
 X3 Series (E83) (04-07)	ABS + TRACT. CONT	3.0i (04-07)	BOSCH DSC
 X3 Series (E83) (04-07)	AIRBAG	2.0d (04-07)	BOSCH MSR5
 X3 Series (E83) (04-07)	AIRBAG	2.0i (05-07)	BOSCH MSR5
 X3 Series (E83) (04-07)	AIRBAG	2.5i (04-07)	BOSCH MSR5
 X3 Series (E83) (04-07)	AIRBAG	3.0d (05-07)	BOSCH MSR5
 X3 Series (E83) (04-07)	AIRBAG	3.0i (04-07)	BOSCH MSR5
 X3 Series (E83) (04-07)	CHASSIS NETWORK	2.0d (04-07)	Reinshagen/Delphi Base Module 5
 X3 Series (E83) (04-07)	CHASSIS NETWORK	2.0i (05-07)	Reinshagen/Delphi Base Module 5
 X3 Series (E83) (04-07)	CHASSIS NETWORK	2.5i (04-07)	Reinshagen/Delphi Base Module 5
 X3 Series (E83) (04-07)	CHASSIS NETWORK	3.0d (05-07)	Reinshagen/Delphi Base Module 5
 X3 Series (E83) (04-07)	CHASSIS NETWORK	3.0i (04-07)	Reinshagen/Delphi Base Module 5
 X3 Series (E83) (04-07)	CLIMA	2.0d (04-07)	BEHR/HELLA Klima
 X3 Series (E83) (04-07)	CLIMA	2.0i (05-07)	BEHR/HELLA Klima
 X3 Series (E83) (04-07)	CLIMA	2.5i (04-07)	BEHR/HELLA Klima
 X3 Series (E83) (04-07)	CLIMA	3.0d (05-07)	BEHR/HELLA Klima
 X3 Series (E83) (04-07)	CLIMA	3.0i (04-07)	BEHR/HELLA Klima
 X3 Series (E83) (04-07)	DASHBOARD	2.0d (04-07)	Borg Instruments Kombi
 X3 Series (E83) (04-07)	DASHBOARD	2.0i (05-07)	Borg Instruments Kombi
 X3 Series (E83) (04-07)	DASHBOARD	2.5i (04-07)	Borg Instruments Kombi
 X3 Series (E83) (04-07)	DASHBOARD	3.0d (05-07)	Borg Instruments Kombi
 X3 Series (E83) (04-07)	DASHBOARD	3.0i (04-07)	Borg Instruments Kombi
 X3 Series (E83) (04-07)	ELECTRIC STEERING	2.0d (04-07)	Helbako SVT Servotronic
 X3 Series (E83) (04-07)	ELECTRIC STEERING	2.0i (05-07)	Helbako SVT Servotronic
 X3 Series (E83) (04-07)	ELECTRIC STEERING	2.5i (04-07)	Helbako SVT Servotronic
 X3 Series (E83) (04-07)	ELECTRIC STEERING	3.0d (05-07)	Helbako SVT Servotronic
 X3 Series (E83) (04-07)	ELECTRIC STEERING	3.0i (04-07)	Helbako SVT Servotronic
 X3 Series (E83) (04-07)	ENGINE MANAGEME	2.0d (04-07)	EOBD
 X3 Series (E83) (04-07)	ENGINE MANAGEME	2.0d 20 4D 2 (04-07)	BOSCH EDC DDE 6.0
 X3 Series (E83) (04-07)	ENGINE MANAGEME	2.0i (05-07)	EOBD
 X3 Series (E83) (04-07)	ENGINE MANAGEME	2.5i (04-07)	EOBD
 X3 Series (E83) (04-07)	ENGINE MANAGEME	3.0d (05-07)	EOBD
 X3 Series (E83) (04-07)	ENGINE MANAGEME	3.0i (04-07)	EOBD
 X3 Series (E83) (04-07)	IMMOBILIZER	2.0d (04-07)	UTA Immobilizer EWSIII
 X3 Series (E83) (04-07)	IMMOBILIZER	2.0i (05-07)	UTA Immobilizer EWSIII
 X3 Series (E83) (04-07)	IMMOBILIZER	2.5i (04-07)	UTA Immobilizer EWSIII

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 X3 Series (E83) (04-07)	IMMOBILIZER	3.0d (05-07)	UTA Immobilizer EWSIII
 X3 Series (E83) (04-07)	IMMOBILIZER	3.0i (04-07)	UTA Immobilizer EWSIII
 X3 Series (E83) (04-07)	MAINTENANCE	2.0d (04-07)	Borg Instruments Kombi
 X3 Series (E83) (04-07)	MAINTENANCE	2.0d (04-07)	Borg Instruments Kombi
 X3 Series (E83) (04-07)	MAINTENANCE	2.0d (04-07)	BOSCH DSC
 X3 Series (E83) (04-07)	MAINTENANCE	2.0d (04-07)	BOSCH DSC
 X3 Series (E83) (04-07)	MAINTENANCE	2.0d (04-07)	BOSCH DSC
 X3 Series (E83) (04-07)	MAINTENANCE	2.0d (04-07)	BOSCH DSC
 X3 Series (E83) (04-07)	MAINTENANCE	2.0d (04-07)	BOSCH DSC
 X3 Series (E83) (04-07)	MAINTENANCE	2.0d (04-07)	BOSCH DSC
 X3 Series (E83) (04-07)	MAINTENANCE	2.0d 20 4D 2 (04-07)	BOSCH EDC DDE 6.0
 X3 Series (E83) (04-07)	MAINTENANCE	2.0d 20 4D 2 (04-07)	BOSCH EDC DDE 6.0
 X3 Series (E83) (04-07)	MAINTENANCE	2.0d 20 4D 2 (04-07)	BOSCH EDC DDE 6.0
 X3 Series (E83) (04-07)	MAINTENANCE	2.0i (05-07)	Borg Instruments Kombi
 X3 Series (E83) (04-07)	MAINTENANCE	2.0i (05-07)	Borg Instruments Kombi
 X3 Series (E83) (04-07)	MAINTENANCE	2.0i (05-07)	BOSCH DSC
 X3 Series (E83) (04-07)	MAINTENANCE	2.0i (05-07)	BOSCH DSC
 X3 Series (E83) (04-07)	MAINTENANCE	2.0i (05-07)	BOSCH DSC
 X3 Series (E83) (04-07)	MAINTENANCE	2.0i (05-07)	BOSCH DSC
 X3 Series (E83) (04-07)	MAINTENANCE	2.0i (05-07)	BOSCH DSC
 X3 Series (E83) (04-07)	MAINTENANCE	2.0i (05-07)	BOSCH DSC
 X3 Series (E83) (04-07)	MAINTENANCE	2.0i (05-07)	VTG
 X3 Series (E83) (04-07)	MAINTENANCE	2.5i (04-07)	Borg Instruments Kombi
 X3 Series (E83) (04-07)	MAINTENANCE	2.5i (04-07)	Borg Instruments Kombi
 X3 Series (E83) (04-07)	MAINTENANCE	2.5i (04-07)	BOSCH DSC
 X3 Series (E83) (04-07)	MAINTENANCE	2.5i (04-07)	BOSCH DSC
 X3 Series (E83) (04-07)	MAINTENANCE	2.5i (04-07)	BOSCH DSC
 X3 Series (E83) (04-07)	MAINTENANCE	2.5i (04-07)	BOSCH DSC
 X3 Series (E83) (04-07)	MAINTENANCE	2.5i (04-07)	BOSCH DSC
 X3 Series (E83) (04-07)	MAINTENANCE	2.5i (04-07)	BOSCH DSC
 X3 Series (E83) (04-07)	MAINTENANCE	2.5i (04-07)	VTG
 X3 Series (E83) (04-07)	MAINTENANCE	3.0d (05-07)	Borg Instruments Kombi
 X3 Series (E83) (04-07)	MAINTENANCE	3.0d (05-07)	Borg Instruments Kombi
 X3 Series (E83) (04-07)	MAINTENANCE	3.0d (05-07)	BOSCH DSC
 X3 Series (E83) (04-07)	MAINTENANCE	3.0d (05-07)	BOSCH DSC
 X3 Series (E83) (04-07)	MAINTENANCE	3.0d (05-07)	BOSCH DSC
 X3 Series (E83) (04-07)	MAINTENANCE	3.0d (05-07)	BOSCH DSC
 X3 Series (E83) (04-07)	MAINTENANCE	3.0d (05-07)	BOSCH DSC
 X3 Series (E83) (04-07)	MAINTENANCE	3.0d (05-07)	VTG
 X3 Series (E83) (04-07)	MAINTENANCE	3.0i (04-07)	Borg Instruments Kombi
 X3 Series (E83) (04-07)	MAINTENANCE	3.0i (04-07)	Borg Instruments Kombi
 X3 Series (E83) (04-07)	MAINTENANCE	3.0i (04-07)	BOSCH DSC
 X3 Series (E83) (04-07)	MAINTENANCE	3.0i (04-07)	BOSCH DSC
 X3 Series (E83) (04-07)	MAINTENANCE	3.0i (04-07)	BOSCH DSC
 X3 Series (E83) (04-07)	MAINTENANCE	3.0i (04-07)	BOSCH DSC
 X3 Series (E83) (04-07)	MAINTENANCE	3.0i (04-07)	BOSCH DSC
 X3 Series (E83) (04-07)	MAINTENANCE	3.0i (04-07)	BOSCH DSC
 X3 Series (E83) (04-07)	MAINTENANCE	3.0i (04-07)	VTG
 X3 Series (E83) (04-07)	PARKING HELP	2.0d (04-07)	Valeo PDC
 X3 Series (E83) (04-07)	PARKING HELP	2.0i (05-07)	Valeo PDC
 X3 Series (E83) (04-07)	PARKING HELP	2.5i (04-07)	Valeo PDC
 X3 Series (E83) (04-07)	PARKING HELP	3.0d (05-07)	Valeo PDC
 X3 Series (E83) (04-07)	PARKING HELP	3.0i (04-07)	Valeo PDC
 X3 Series (E83) (04-07)	STEERING COLUMN	2.0d (04-07)	Kostal LWS
 X3 Series (E83) (04-07)	STEERING COLUMN	2.0i (05-07)	Kostal LWS
 X3 Series (E83) (04-07)	STEERING COLUMN	2.5i (04-07)	Kostal LWS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 X3 Series (E83) (04-07)	STEERING COLUMN	3.0d (05-07)	Kostal LWS
 X3 Series (E83) (04-07)	STEERING COLUMN	3.0i (04-07)	Kostal LWS
 X3 Series (E83) (04-07)	STEERING WHEEL E	2.0d (04-07)	MFL
 X3 Series (E83) (04-07)	STEERING WHEEL E	2.0i (05-07)	MFL
 X3 Series (E83) (04-07)	STEERING WHEEL E	2.5i (04-07)	MFL
 X3 Series (E83) (04-07)	STEERING WHEEL E	3.0d (05-07)	MFL
 X3 Series (E83) (04-07)	STEERING WHEEL E	3.0i (04-07)	MFL
 X3 Series (E83) (04-07)	TRACTION CONTROL	2.0d (04-07)	VTG
 X3 Series (E83) (04-07)	TRACTION CONTROL	2.0i (05-07)	VTG
 X3 Series (E83) (04-07)	TRACTION CONTROL	2.5i (04-07)	VTG
 X3 Series (E83) (04-07)	TRACTION CONTROL	3.0d (05-07)	VTG
 X3 Series (E83) (04-07)	TRACTION CONTROL	3.0i (04-07)	VTG
 X3 Series (F25) (10-..)	VISUAL./TELEMATIC	sDrive18d (10-..)	TELE60 3
 X3 Series (F25) (10-..)	VISUAL./TELEMATIC	xDrive 20d (10-..)	TELE60 3
 X3 Series (F25) (10-..)	VISUAL./TELEMATIC	xDrive 20i (10-..)	TELE60 3
 X3 Series (F25) (10-..)	VISUAL./TELEMATIC	xDrive 28i (10-..)	TELE60 3
 X3 Series (F25) (10-..)	VISUAL./TELEMATIC	xDrive 35d (10-..)	TELE60 3
 X3 Series (F25) (10-..)	VISUAL./TELEMATIC	xDrive 35i (10-..)	TELE60 3
 X5 Series (E53) (00-07)	AIRBAG	3.0d (00-05)	TEMIC AirBag MRS4
 X5 Series (E53) (00-07)	AIRBAG	3.0i (00-05)	TEMIC AirBag MRS4
 X5 Series (E53) (00-07)	AIRBAG	4.4i (00-05)	TEMIC AirBag MRS4
 X5 Series (E53) (00-07)	AIRBAG	4.6i (00-05)	TEMIC AirBag MRS4
 X5 Series (E53) (00-07)	AIRBAG	4.8i (00-05)	TEMIC AirBag MRS4
 X5 Series (E53) (00-07)	AUTOM. TRANSMISSI	3.0d (04-07)	EGS
 X5 Series (E53) (00-07)	AUTOM. TRANSMISSI	3.0i (04-07)	EGS
 X5 Series (E53) (00-07)	AUTOM. TRANSMISSI	4.4i (04-07)	EGS
 X5 Series (E53) (00-07)	AUTOM. TRANSMISSI	4.6i (04-07)	EGS
 X5 Series (E53) (00-07)	AUTOM. TRANSMISSI	4.8i (04-07)	EGS
 X5 Series (E53) (00-07)	CHASSIS NETWORK	3.0d (04-07)	Body Computer
 X5 Series (E53) (00-07)	CHASSIS NETWORK	3.0i (04-07)	Body Computer
 X5 Series (E53) (00-07)	CHASSIS NETWORK	4.4i (04-07)	Body Computer
 X5 Series (E53) (00-07)	CHASSIS NETWORK	4.6i (04-07)	Body Computer
 X5 Series (E53) (00-07)	CHASSIS NETWORK	4.8i (04-07)	Body Computer
 X5 Series (E53) (00-07)	CLIMA	3.0d (00-05)	Klimautomatik X.x
 X5 Series (E53) (00-07)	CLIMA	3.0i (00-05)	Klimautomatik X.x
 X5 Series (E53) (00-07)	CLIMA	4.4i (00-05)	Klimautomatik X.x
 X5 Series (E53) (00-07)	CLIMA	4.6i (00-05)	Klimautomatik X.x
 X5 Series (E53) (00-07)	CLIMA	4.8i (00-05)	Klimautomatik X.x
 X5 Series (E53) (00-07)	DASHBOARD	3.0d (04-07)	Kombi+Service
 X5 Series (E53) (00-07)	DASHBOARD	3.0i (04-07)	Kombi+Service
 X5 Series (E53) (00-07)	DASHBOARD	4.4i (04-07)	Kombi+Service
 X5 Series (E53) (00-07)	DASHBOARD	4.6i (04-07)	Kombi+Service
 X5 Series (E53) (00-07)	DASHBOARD	4.8i (04-07)	Kombi+Service
 X5 Series (E53) (00-07)	ELECTRIC STEERING	3.0d (04-07)	Steering angle sensor
 X5 Series (E53) (00-07)	ELECTRIC STEERING	3.0i (04-07)	Steering angle sensor
 X5 Series (E53) (00-07)	ELECTRIC STEERING	4.4i (04-07)	Steering angle sensor
 X5 Series (E53) (00-07)	ELECTRIC STEERING	4.6i (04-07)	Steering angle sensor
 X5 Series (E53) (00-07)	ELECTRIC STEERING	4.8i (04-07)	Steering angle sensor
 X5 Series (E53) (00-07)	ENGINE MANAGEME	3.0d 30 6D 1 (00-07)	BOSCH EDC 15 C4 DDE 4.0
 X5 Series (E53) (00-07)	ENGINE MANAGEME	3.0d 30 6D 2 (01-04)	BOSCH EDC 15 C4 DDE 5.0
 X5 Series (E53) (00-07)	ENGINE MANAGEME	3.0i (01-07)	EOBD
 X5 Series (E53) (00-07)	ENGINE MANAGEME	3.0i 30 6S 3 (00-03)	SIEMENS MPI DME MS 43.0
 X5 Series (E53) (00-07)	ENGINE MANAGEME	4.4i (01-06)	EOBD
 X5 Series (E53) (00-07)	ENGINE MANAGEME	4.6i (01-06)	EOBD
 X5 Series (E53) (00-07)	ENGINE MANAGEME	4.8i (01-04)	EOBD
 X5 Series (E53) (00-07)	MAINTENANCE	3.0d (00-04)	BOSCH ABS+DSC
 X5 Series (E53) (00-07)	MAINTENANCE	3.0d (00-04)	BOSCH ABS+DSC
 X5 Series (E53) (00-07)	MAINTENANCE	3.0d (04-07)	EGS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 X5 Series (E53) (00-07)	MAINTENANCE	3.0d (04-07)	EGS
 X5 Series (E53) (00-07)	MAINTENANCE	3.0d (04-07)	Kombi+Service
 X5 Series (E53) (00-07)	MAINTENANCE	3.0d (04-07)	Kombi+Service
 X5 Series (E53) (00-07)	MAINTENANCE	3.0d (04-07)	Kombi+Service
 X5 Series (E53) (00-07)	MAINTENANCE	3.0d (04-07)	VTG
 X5 Series (E53) (00-07)	MAINTENANCE	3.0d (09/00-04)	MANUAL
 X5 Series (E53) (00-07)	MAINTENANCE	3.0d 30 6D 2 (01-04)	BOSCH EDC 15 C4 DDE 5.0
 X5 Series (E53) (00-07)	MAINTENANCE	3.0i (00-04)	BOSCH ABS+DSC
 X5 Series (E53) (00-07)	MAINTENANCE	3.0i (00-04)	BOSCH ABS+DSC
 X5 Series (E53) (00-07)	MAINTENANCE	3.0i (04-07)	EGS
 X5 Series (E53) (00-07)	MAINTENANCE	3.0i (04-07)	EGS
 X5 Series (E53) (00-07)	MAINTENANCE	3.0i (04-07)	Kombi+Service
 X5 Series (E53) (00-07)	MAINTENANCE	3.0i (04-07)	Kombi+Service
 X5 Series (E53) (00-07)	MAINTENANCE	3.0i (04-07)	Kombi+Service
 X5 Series (E53) (00-07)	MAINTENANCE	3.0i (04-07)	VTG
 X5 Series (E53) (00-07)	MAINTENANCE	3.0i (09/00-04)	MANUAL
 X5 Series (E53) (00-07)	MAINTENANCE	4.4i (00-04)	BOSCH ABS+DSC
 X5 Series (E53) (00-07)	MAINTENANCE	4.4i (00-04)	BOSCH ABS+DSC
 X5 Series (E53) (00-07)	MAINTENANCE	4.4i (04-07)	EGS
 X5 Series (E53) (00-07)	MAINTENANCE	4.4i (04-07)	EGS
 X5 Series (E53) (00-07)	MAINTENANCE	4.4i (04-07)	Kombi+Service
 X5 Series (E53) (00-07)	MAINTENANCE	4.4i (04-07)	Kombi+Service
 X5 Series (E53) (00-07)	MAINTENANCE	4.4i (04-07)	Kombi+Service
 X5 Series (E53) (00-07)	MAINTENANCE	4.4i (04-07)	VTG
 X5 Series (E53) (00-07)	MAINTENANCE	4.4i (09/00-04)	MANUAL
 X5 Series (E53) (00-07)	MAINTENANCE	4.6i (00-04)	BOSCH ABS+DSC
 X5 Series (E53) (00-07)	MAINTENANCE	4.6i (00-04)	BOSCH ABS+DSC
 X5 Series (E53) (00-07)	MAINTENANCE	4.6i (04-07)	EGS
 X5 Series (E53) (00-07)	MAINTENANCE	4.6i (04-07)	EGS
 X5 Series (E53) (00-07)	MAINTENANCE	4.6i (04-07)	Kombi+Service
 X5 Series (E53) (00-07)	MAINTENANCE	4.6i (04-07)	Kombi+Service
 X5 Series (E53) (00-07)	MAINTENANCE	4.6i (04-07)	Kombi+Service
 X5 Series (E53) (00-07)	MAINTENANCE	4.6i (04-07)	VTG
 X5 Series (E53) (00-07)	MAINTENANCE	4.6i (09/00-04)	MANUAL
 X5 Series (E53) (00-07)	MAINTENANCE	4.8i (00-04)	BOSCH ABS+DSC
 X5 Series (E53) (00-07)	MAINTENANCE	4.8i (00-04)	BOSCH ABS+DSC
 X5 Series (E53) (00-07)	MAINTENANCE	4.8i (04-07)	EGS
 X5 Series (E53) (00-07)	MAINTENANCE	4.8i (04-07)	EGS
 X5 Series (E53) (00-07)	MAINTENANCE	4.8i (04-07)	Kombi+Service
 X5 Series (E53) (00-07)	MAINTENANCE	4.8i (04-07)	Kombi+Service
 X5 Series (E53) (00-07)	MAINTENANCE	4.8i (04-07)	Kombi+Service
 X5 Series (E53) (00-07)	MAINTENANCE	4.8i (04-07)	VTG
 X5 Series (E53) (00-07)	MAINTENANCE	4.8i (09/00-04)	MANUAL
 X5 Series (E53) (00-07)	PARKING HELP	3.0d (04-07)	Valeo PDC
 X5 Series (E53) (00-07)	PARKING HELP	3.0i (04-07)	Valeo PDC
 X5 Series (E53) (00-07)	PARKING HELP	4.4i (04-07)	Valeo PDC
 X5 Series (E53) (00-07)	PARKING HELP	4.6i (04-07)	Valeo PDC
 X5 Series (E53) (00-07)	PARKING HELP	4.8i (04-07)	Valeo PDC
 X5 Series (E53) (00-07)	SERVICE LIGHT RES	3.0d (09/00-04)	MANUAL
 X5 Series (E53) (00-07)	SERVICE LIGHT RES	3.0i (09/00-04)	MANUAL
 X5 Series (E53) (00-07)	SERVICE LIGHT RES	4.4i (09/00-04)	MANUAL
 X5 Series (E53) (00-07)	SERVICE LIGHT RES	4.6i (09/00-04)	MANUAL
 X5 Series (E53) (00-07)	SERVICE LIGHT RES	4.8i (09/00-04)	MANUAL
 X5 Series (E53) (00-07)	SUSPENSION CONTR	3.0d (04-07)	THYSSSEN KRUPP EHC
 X5 Series (E53) (00-07)	SUSPENSION CONTR	3.0i (04-07)	THYSSSEN KRUPP EHC
 X5 Series (E53) (00-07)	SUSPENSION CONTR	4.4i (04-07)	THYSSSEN KRUPP EHC
 X5 Series (E53) (00-07)	SUSPENSION CONTR	4.6i (04-07)	THYSSSEN KRUPP EHC
 X5 Series (E53) (00-07)	SUSPENSION CONTR	4.8i (04-07)	THYSSSEN KRUPP EHC

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 X5 Series (E53) (00-07)	TRACTION CONTROL	3.0d (00-04)	BOSCH ABS/DSC 5.7
 X5 Series (E53) (00-07)	TRACTION CONTROL	3.0d (00-04)	BOSCH ABS+DSC
 X5 Series (E53) (00-07)	TRACTION CONTROL	3.0d (04-07)	VTG
 X5 Series (E53) (00-07)	TRACTION CONTROL	3.0i (00-04)	BOSCH ABS/DSC 5.7
 X5 Series (E53) (00-07)	TRACTION CONTROL	3.0i (00-04)	BOSCH ABS+DSC
 X5 Series (E53) (00-07)	TRACTION CONTROL	3.0i (04-07)	VTG
 X5 Series (E53) (00-07)	TRACTION CONTROL	4.4i (00-04)	BOSCH ABS/DSC 5.7
 X5 Series (E53) (00-07)	TRACTION CONTROL	4.4i (00-04)	BOSCH ABS+DSC
 X5 Series (E53) (00-07)	TRACTION CONTROL	4.4i (04-07)	VTG
 X5 Series (E53) (00-07)	TRACTION CONTROL	4.6i (00-04)	BOSCH ABS/DSC 5.7
 X5 Series (E53) (00-07)	TRACTION CONTROL	4.6i (00-04)	BOSCH ABS+DSC
 X5 Series (E53) (00-07)	TRACTION CONTROL	4.6i (04-07)	VTG
 X5 Series (E53) (00-07)	TRACTION CONTROL	4.8i (00-04)	BOSCH ABS/DSC 5.7
 X5 Series (E53) (00-07)	TRACTION CONTROL	4.8i (00-04)	BOSCH ABS+DSC
 X5 Series (E53) (00-07)	TRACTION CONTROL	4.8i (04-07)	VTG
 X5 Series (E70) (07-..)	CLIMA	xDrive 30d (07-..)	IHKA70
 X5 Series (E70) (07-..)	CLIMA	xDrive 35i (07-..)	IHKA70
 X5 Series (E70) (07-..)	CLIMA	xDrive 40d (07-..)	IHKA70
 X5 Series (E70) (07-..)	CLIMA	xDrive 50i (07-..)	IHKA70
 X5 Series (E70) (07-..)	CLIMA	xDrive M 4.4i (07-..)	IHKA70
 X5 Series (E70) (07-..)	CRUISE CONTROL	xDrive 30d (07-..)	Adaptive cruise control FRR70
 X5 Series (E70) (07-..)	CRUISE CONTROL	xDrive 35i (07-..)	Adaptive cruise control FRR70
 X5 Series (E70) (07-..)	CRUISE CONTROL	xDrive 40d (07-..)	Adaptive cruise control FRR70
 X5 Series (E70) (07-..)	CRUISE CONTROL	xDrive 50i (07-..)	Adaptive cruise control FRR70
 X5 Series (E70) (07-..)	CRUISE CONTROL	xDrive M 4.4i (07-..)	Adaptive cruise control FRR70
 X5 Series (E70) (07-..)	DASHBOARD	xDrive 30d (07-..)	KOMB70
 X5 Series (E70) (07-..)	DASHBOARD	xDrive 35i (07-..)	KOMB70
 X5 Series (E70) (07-..)	DASHBOARD	xDrive 40d (07-..)	KOMB70
 X5 Series (E70) (07-..)	DASHBOARD	xDrive 50i (07-..)	KOMB70
 X5 Series (E70) (07-..)	DASHBOARD	xDrive M 4.4i (07-..)	KOMB70
 X5 Series (E70) (07-..)	ELECTRIC STEERING	xDrive 30d (07-..)	Active Front Steering AFS 70
 X5 Series (E70) (07-..)	ELECTRIC STEERING	xDrive 30d (07-..)	EPS72
 X5 Series (E70) (07-..)	ELECTRIC STEERING	xDrive 35i (07-..)	Active Front Steering AFS 70
 X5 Series (E70) (07-..)	ELECTRIC STEERING	xDrive 35i (07-..)	EPS72
 X5 Series (E70) (07-..)	ELECTRIC STEERING	xDrive 40d (07-..)	Active Front Steering AFS 70
 X5 Series (E70) (07-..)	ELECTRIC STEERING	xDrive 40d (07-..)	EPS72
 X5 Series (E70) (07-..)	ELECTRIC STEERING	xDrive 50i (07-..)	Active Front Steering AFS 70
 X5 Series (E70) (07-..)	ELECTRIC STEERING	xDrive 50i (07-..)	EPS72
 X5 Series (E70) (07-..)	ELECTRIC STEERING	xDrive M 4.4i (07-..)	Active Front Steering AFS 70
 X5 Series (E70) (07-..)	ELECTRIC STEERING	xDrive M 4.4i (07-..)	EPS72
 X5 Series (E70) (07-..)	IMMOBILIZER	xDrive 30d (07-..)	CAS
 X5 Series (E70) (07-..)	IMMOBILIZER	xDrive 35i (07-..)	CAS
 X5 Series (E70) (07-..)	IMMOBILIZER	xDrive 40d (07-..)	CAS
 X5 Series (E70) (07-..)	IMMOBILIZER	xDrive 50i (07-..)	CAS
 X5 Series (E70) (07-..)	IMMOBILIZER	xDrive M 4.4i (07-..)	CAS
 X5 Series (E70) (07-..)	REAR CLIMA	xDrive 30d (07-..)	FKA70
 X5 Series (E70) (07-..)	REAR CLIMA	xDrive 35i (07-..)	FKA70
 X5 Series (E70) (07-..)	REAR CLIMA	xDrive 40d (07-..)	FKA70
 X5 Series (E70) (07-..)	REAR CLIMA	xDrive 50i (07-..)	FKA70
 X5 Series (E70) (07-..)	REAR CLIMA	xDrive M 4.4i (07-..)	FKA70
 X5 Series (E70) (07-..)	SUSPENSION CONTR	xDrive 30d (07-..)	Front left suspension EDCSVL
 X5 Series (E70) (07-..)	SUSPENSION CONTR	xDrive 30d (07-..)	Front right suspension EDCSVR
 X5 Series (E70) (07-..)	SUSPENSION CONTR	xDrive 30d (07-..)	Rear left suspension EDCSHL
 X5 Series (E70) (07-..)	SUSPENSION CONTR	xDrive 30d (07-..)	Rear right suspension EDCSHR
 X5 Series (E70) (07-..)	SUSPENSION CONTR	xDrive 35i (07-..)	Front left suspension EDCSVL
 X5 Series (E70) (07-..)	SUSPENSION CONTR	xDrive 35i (07-..)	Front right suspension EDCSVR
 X5 Series (E70) (07-..)	SUSPENSION CONTR	xDrive 35i (07-..)	Rear left suspension EDCSHL
 X5 Series (E70) (07-..)	SUSPENSION CONTR	xDrive 35i (07-..)	Rear right suspension EDCSHR

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 X5 Series (E70) (07-..)	SUSPENSION CONTR	xDrive 40d (07-..)	Front left suspension EDCSV
 X5 Series (E70) (07-..)	SUSPENSION CONTR	xDrive 40d (07-..)	Front right suspension EDCSV
 X5 Series (E70) (07-..)	SUSPENSION CONTR	xDrive 40d (07-..)	Rear left suspension EDCHL
 X5 Series (E70) (07-..)	SUSPENSION CONTR	xDrive 40d (07-..)	Rear right suspension EDCHL
 X5 Series (E70) (07-..)	SUSPENSION CONTR	xDrive 50i (07-..)	Front left suspension EDCSV
 X5 Series (E70) (07-..)	SUSPENSION CONTR	xDrive 50i (07-..)	Front right suspension EDCSV
 X5 Series (E70) (07-..)	SUSPENSION CONTR	xDrive 50i (07-..)	Rear left suspension EDCHL
 X5 Series (E70) (07-..)	SUSPENSION CONTR	xDrive 50i (07-..)	Rear right suspension EDCHL
 X5 Series (E70) (07-..)	SUSPENSION CONTR	xDrive M 4.4i (07-..)	Front left suspension EDCSV
 X5 Series (E70) (07-..)	SUSPENSION CONTR	xDrive M 4.4i (07-..)	Front right suspension EDCSV
 X5 Series (E70) (07-..)	SUSPENSION CONTR	xDrive M 4.4i (07-..)	Rear left suspension EDCHL
 X5 Series (E70) (07-..)	SUSPENSION CONTR	xDrive M 4.4i (07-..)	Rear right suspension EDCHL
 X6 Series (E71-E72) (08-..)	CLIMA	ActiveHybrid (08-..)	IHKA70
 X6 Series (E71-E72) (08-..)	CLIMA	xDrive 30d (08-..)	IHKA70
 X6 Series (E71-E72) (08-..)	CLIMA	xDrive 35d (08-..)	IHKA70
 X6 Series (E71-E72) (08-..)	CLIMA	xDrive 35i (08-..)	IHKA70
 X6 Series (E71-E72) (08-..)	CLIMA	xDrive 40d (08-..)	IHKA70
 X6 Series (E71-E72) (08-..)	CLIMA	xDrive 50i (08-..)	IHKA70
 X6 Series (E71-E72) (08-..)	CLIMA	xDrive M 4.4i (08-..)	IHKA70
 X6 Series (E71-E72) (08-..)	CRUISE CONTROL	ActiveHybrid (08-..)	Adaptive cruise control FRR70
 X6 Series (E71-E72) (08-..)	CRUISE CONTROL	xDrive 30d (08-..)	Adaptive cruise control FRR70
 X6 Series (E71-E72) (08-..)	CRUISE CONTROL	xDrive 35d (08-..)	Adaptive cruise control FRR70
 X6 Series (E71-E72) (08-..)	CRUISE CONTROL	xDrive 35i (08-..)	Adaptive cruise control FRR70
 X6 Series (E71-E72) (08-..)	CRUISE CONTROL	xDrive 40d (08-..)	Adaptive cruise control FRR70
 X6 Series (E71-E72) (08-..)	CRUISE CONTROL	xDrive 50i (08-..)	Adaptive cruise control FRR70
 X6 Series (E71-E72) (08-..)	CRUISE CONTROL	xDrive M 4.4i (08-..)	Adaptive cruise control FRR70
 X6 Series (E71-E72) (08-..)	DASHBOARD	ActiveHybrid (08-..)	KOMB70
 X6 Series (E71-E72) (08-..)	DASHBOARD	xDrive 30d (08-..)	KOMB70
 X6 Series (E71-E72) (08-..)	DASHBOARD	xDrive 35d (08-..)	KOMB70
 X6 Series (E71-E72) (08-..)	DASHBOARD	xDrive 35i (08-..)	KOMB70
 X6 Series (E71-E72) (08-..)	DASHBOARD	xDrive 40d (08-..)	KOMB70
 X6 Series (E71-E72) (08-..)	DASHBOARD	xDrive 50i (08-..)	KOMB70
 X6 Series (E71-E72) (08-..)	DASHBOARD	xDrive M 4.4i (08-..)	KOMB70
 X6 Series (E71-E72) (08-..)	ELECTRIC STEERING	ActiveHybrid (08-..)	Active Front Steering AFS 70
 X6 Series (E71-E72) (08-..)	ELECTRIC STEERING	ActiveHybrid (08-..)	EPS72
 X6 Series (E71-E72) (08-..)	ELECTRIC STEERING	xDrive 30d (08-..)	Active Front Steering AFS 70
 X6 Series (E71-E72) (08-..)	ELECTRIC STEERING	xDrive 30d (08-..)	EPS72
 X6 Series (E71-E72) (08-..)	ELECTRIC STEERING	xDrive 35d (08-..)	Active Front Steering AFS 70
 X6 Series (E71-E72) (08-..)	ELECTRIC STEERING	xDrive 35d (08-..)	EPS72
 X6 Series (E71-E72) (08-..)	ELECTRIC STEERING	xDrive 35i (08-..)	Active Front Steering AFS 70
 X6 Series (E71-E72) (08-..)	ELECTRIC STEERING	xDrive 35i (08-..)	EPS72
 X6 Series (E71-E72) (08-..)	ELECTRIC STEERING	xDrive 40d (08-..)	Active Front Steering AFS 70
 X6 Series (E71-E72) (08-..)	ELECTRIC STEERING	xDrive 40d (08-..)	EPS72
 X6 Series (E71-E72) (08-..)	ELECTRIC STEERING	xDrive 50i (08-..)	Active Front Steering AFS 70
 X6 Series (E71-E72) (08-..)	ELECTRIC STEERING	xDrive 50i (08-..)	EPS72
 X6 Series (E71-E72) (08-..)	ELECTRIC STEERING	xDrive M 4.4i (08-..)	Active Front Steering AFS 70
 X6 Series (E71-E72) (08-..)	ELECTRIC STEERING	xDrive M 4.4i (08-..)	EPS72
 X6 Series (E71-E72) (08-..)	IMMOBILIZER	ActiveHybrid (08-..)	CAS
 X6 Series (E71-E72) (08-..)	IMMOBILIZER	xDrive 30d (08-..)	CAS
 X6 Series (E71-E72) (08-..)	IMMOBILIZER	xDrive 35d (08-..)	CAS
 X6 Series (E71-E72) (08-..)	IMMOBILIZER	xDrive 35i (08-..)	CAS
 X6 Series (E71-E72) (08-..)	IMMOBILIZER	xDrive 40d (08-..)	CAS
 X6 Series (E71-E72) (08-..)	IMMOBILIZER	xDrive 50i (08-..)	CAS
 X6 Series (E71-E72) (08-..)	IMMOBILIZER	xDrive M 4.4i (08-..)	CAS
 X6 Series (E71-E72) (08-..)	REAR CLIMA	ActiveHybrid (08-..)	FKA70
 X6 Series (E71-E72) (08-..)	REAR CLIMA	xDrive 30d (08-..)	FKA70
 X6 Series (E71-E72) (08-..)	REAR CLIMA	xDrive 35d (08-..)	FKA70
 X6 Series (E71-E72) (08-..)	REAR CLIMA	xDrive 35i (08-..)	FKA70

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 X6 Series (E71-E72) (08-..)	REAR CLIMA	xDrive 40d (08-..)	FKA70
 X6 Series (E71-E72) (08-..)	REAR CLIMA	xDrive 50i (08-..)	FKA70
 X6 Series (E71-E72) (08-..)	REAR CLIMA	xDrive M 4.4i (08-..)	FKA70
 X6 Series (E71-E72) (08-..)	SUSPENSION CONTR	ActiveHybrid (08-..)	Front left suspension EDCSVL
 X6 Series (E71-E72) (08-..)	SUSPENSION CONTR	ActiveHybrid (08-..)	Front right suspension EDCSVR
 X6 Series (E71-E72) (08-..)	SUSPENSION CONTR	ActiveHybrid (08-..)	Rear left suspension EDCSHL
 X6 Series (E71-E72) (08-..)	SUSPENSION CONTR	ActiveHybrid (08-..)	Rear right suspension EDCSHR
 X6 Series (E71-E72) (08-..)	SUSPENSION CONTR	xDrive 30d (08-..)	Front left suspension EDCSVL
 X6 Series (E71-E72) (08-..)	SUSPENSION CONTR	xDrive 30d (08-..)	Front right suspension EDCSVR
 X6 Series (E71-E72) (08-..)	SUSPENSION CONTR	xDrive 30d (08-..)	Rear left suspension EDCSHL
 X6 Series (E71-E72) (08-..)	SUSPENSION CONTR	xDrive 30d (08-..)	Rear right suspension EDCSHR
 X6 Series (E71-E72) (08-..)	SUSPENSION CONTR	xDrive 35d (08-..)	Front left suspension EDCSVL
 X6 Series (E71-E72) (08-..)	SUSPENSION CONTR	xDrive 35d (08-..)	Front right suspension EDCSVR
 X6 Series (E71-E72) (08-..)	SUSPENSION CONTR	xDrive 35d (08-..)	Rear left suspension EDCSHL
 X6 Series (E71-E72) (08-..)	SUSPENSION CONTR	xDrive 35d (08-..)	Rear right suspension EDCSHR
 X6 Series (E71-E72) (08-..)	SUSPENSION CONTR	xDrive 35i (08-..)	Front left suspension EDCSVL
 X6 Series (E71-E72) (08-..)	SUSPENSION CONTR	xDrive 35i (08-..)	Front right suspension EDCSVR
 X6 Series (E71-E72) (08-..)	SUSPENSION CONTR	xDrive 35i (08-..)	Rear left suspension EDCSHL
 X6 Series (E71-E72) (08-..)	SUSPENSION CONTR	xDrive 35i (08-..)	Rear right suspension EDCSHR
 X6 Series (E71-E72) (08-..)	SUSPENSION CONTR	xDrive 40d (08-..)	Front left suspension EDCSVL
 X6 Series (E71-E72) (08-..)	SUSPENSION CONTR	xDrive 40d (08-..)	Front right suspension EDCSVR
 X6 Series (E71-E72) (08-..)	SUSPENSION CONTR	xDrive 40d (08-..)	Rear left suspension EDCSHL
 X6 Series (E71-E72) (08-..)	SUSPENSION CONTR	xDrive 40d (08-..)	Rear right suspension EDCSHR
 X6 Series (E71-E72) (08-..)	SUSPENSION CONTR	xDrive 50i (08-..)	Front left suspension EDCSVL
 X6 Series (E71-E72) (08-..)	SUSPENSION CONTR	xDrive 50i (08-..)	Front right suspension EDCSVR
 X6 Series (E71-E72) (08-..)	SUSPENSION CONTR	xDrive 50i (08-..)	Rear left suspension EDCSHL
 X6 Series (E71-E72) (08-..)	SUSPENSION CONTR	xDrive 50i (08-..)	Rear right suspension EDCSHR
 X6 Series (E71-E72) (08-..)	SUSPENSION CONTR	xDrive M 4.4i (08-..)	Front left suspension EDCSVL
 X6 Series (E71-E72) (08-..)	SUSPENSION CONTR	xDrive M 4.4i (08-..)	Front right suspension EDCSVR
 X6 Series (E71-E72) (08-..)	SUSPENSION CONTR	xDrive M 4.4i (08-..)	Rear left suspension EDCSHL
 X6 Series (E71-E72) (08-..)	SUSPENSION CONTR	xDrive M 4.4i (08-..)	Rear right suspension EDCSHR
 Z1 (87-92)	ENGINE MANAGEME	2.5i 25 6K 1 (87-92)	BOSCH Motronic DME M1.3
 Z1 (87-92)	MAINTENANCE	2.5i (...-09/00)	Service
 Z1 (87-92)	SERVICE LIGHT RES	2.5i (...-09/00)	Service
 Z3 Series (E36-E37) (96-02)	ABS	1.8i (95-98)	ITT-TEVES ABS Mk20-I/ERL
 Z3 Series (E36-E37) (96-02)	ABS	1.9i (95-98)	ITT-TEVES ABS Mk20-I/ERL
 Z3 Series (E36-E37) (96-02)	ABS	2.0i (95-98)	ITT-TEVES ABS Mk20-I/ERL
 Z3 Series (E36-E37) (96-02)	ABS	2.2i (95-98)	ITT-TEVES ABS Mk20-I/ERL
 Z3 Series (E36-E37) (96-02)	ABS	2.8i (95-98)	ITT-TEVES ABS Mk20-I/ERL
 Z3 Series (E36-E37) (96-02)	ABS	3.0i (95-98)	ITT-TEVES ABS Mk20-I/ERL
 Z3 Series (E36-E37) (96-02)	ABS	3.2i (95-98)	ITT-TEVES ABS Mk20-I/ERL
 Z3 Series (E36-E37) (96-02)	AIRBAG	1.8i (01-03)	TEMIC AirBag MRS4
 Z3 Series (E36-E37) (96-02)	AIRBAG	1.8i (95-98)	TEMIC AirBag ZAE2
 Z3 Series (E36-E37) (96-02)	AIRBAG	1.9i (01-03)	TEMIC AirBag MRS4
 Z3 Series (E36-E37) (96-02)	AIRBAG	1.9i (95-98)	TEMIC AirBag ZAE2
 Z3 Series (E36-E37) (96-02)	AIRBAG	2.0i (01-03)	TEMIC AirBag MRS4
 Z3 Series (E36-E37) (96-02)	AIRBAG	2.0i (95-98)	TEMIC AirBag ZAE2
 Z3 Series (E36-E37) (96-02)	AIRBAG	2.2i (01-03)	TEMIC AirBag MRS4
 Z3 Series (E36-E37) (96-02)	AIRBAG	2.2i (95-98)	TEMIC AirBag ZAE2
 Z3 Series (E36-E37) (96-02)	AIRBAG	2.8i (01-03)	TEMIC AirBag MRS4
 Z3 Series (E36-E37) (96-02)	AIRBAG	2.8i (95-98)	TEMIC AirBag ZAE2
 Z3 Series (E36-E37) (96-02)	AIRBAG	3.0i (01-03)	TEMIC AirBag MRS4
 Z3 Series (E36-E37) (96-02)	AIRBAG	3.0i (95-98)	TEMIC AirBag ZAE2
 Z3 Series (E36-E37) (96-02)	AIRBAG	3.2i (01-03)	TEMIC AirBag MRS4
 Z3 Series (E36-E37) (96-02)	AIRBAG	3.2i (95-98)	TEMIC AirBag ZAE2
 Z3 Series (E36-E37) (96-02)	ENGINE MANAGEME	1.8i (01-02)	EOBD
 Z3 Series (E36-E37) (96-02)	ENGINE MANAGEME	1.8i 18 4E 2 (...-96)	BOSCH Motronic DME M1.7.3
 Z3 Series (E36-E37) (96-02)	ENGINE MANAGEME	1.9i (01-02)	EOBD

Systems supported by ECUREADER / ECUDECODER (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Z3 Series (E36-E37) (96-02)	ENGINE MANAGEMEN	1.9i 19 4S 1 (96-98)	BOSCH Motronic DME 5.2 M44
 Z3 Series (E36-E37) (96-02)	ENGINE MANAGEMEN	2.0i (01-02)	EOBD
 Z3 Series (E36-E37) (96-02)	ENGINE MANAGEMEN	2.2i (01-02)	EOBD
 Z3 Series (E36-E37) (96-02)	ENGINE MANAGEMEN	2.8i (01-02)	EOBD
 Z3 Series (E36-E37) (96-02)	ENGINE MANAGEMEN	3.0i (01-02)	EOBD
 Z3 Series (E36-E37) (96-02)	ENGINE MANAGEMEN	3.2i (01-02)	EOBD
 Z3 Series (E36-E37) (96-02)	MAINTENANCE	1.8i (...-09/00)	Service
 Z3 Series (E36-E37) (96-02)	MAINTENANCE	1.9i (...-09/00)	Service
 Z3 Series (E36-E37) (96-02)	MAINTENANCE	2.0i (09/00-...)	MANUAL
 Z3 Series (E36-E37) (96-02)	MAINTENANCE	2.2i (09/00-...)	MANUAL
 Z3 Series (E36-E37) (96-02)	MAINTENANCE	2.8i (09/00-...)	MANUAL
 Z3 Series (E36-E37) (96-02)	MAINTENANCE	3.0i (09/00-...)	MANUAL
 Z3 Series (E36-E37) (96-02)	MAINTENANCE	3.2i (09/00-...)	MANUAL
 Z3 Series (E36-E37) (96-02)	SERVICE LIGHT RES	1.8i (...-09/00)	Service
 Z3 Series (E36-E37) (96-02)	SERVICE LIGHT RES	1.9i (...-09/00)	Service
 Z3 Series (E36-E37) (96-02)	SERVICE LIGHT RES	2.0i (09/00-...)	MANUAL
 Z3 Series (E36-E37) (96-02)	SERVICE LIGHT RES	2.2i (09/00-...)	MANUAL
 Z3 Series (E36-E37) (96-02)	SERVICE LIGHT RES	2.8i (09/00-...)	MANUAL
 Z3 Series (E36-E37) (96-02)	SERVICE LIGHT RES	3.0i (09/00-...)	MANUAL
 Z3 Series (E36-E37) (96-02)	SERVICE LIGHT RES	3.2i (09/00-...)	MANUAL
 Z4 Series (E85-E86) (02-08)	ABS + TRACT. CONT	2.0i (07-08)	Continental Teves DSC
 Z4 Series (E85-E86) (02-08)	ABS + TRACT. CONT	2.2i (07-08)	Continental Teves DSC
 Z4 Series (E85-E86) (02-08)	ABS + TRACT. CONT	2.5i (07-08)	Continental Teves DSC
 Z4 Series (E85-E86) (02-08)	ABS + TRACT. CONT	3.0i (07-08)	Continental Teves DSC
 Z4 Series (E85-E86) (02-08)	ABS + TRACT. CONT	3.0si (07-08)	Continental Teves DSC
 Z4 Series (E85-E86) (02-08)	ABS + TRACT. CONT	3.2 M (07-08)	Continental Teves DSC
 Z4 Series (E85-E86) (02-08)	AIRBAG	2.0i (05-07)	Autoliv SRS SBSL (Left Side)
 Z4 Series (E85-E86) (02-08)	AIRBAG	2.0i (05-07)	Autoliv SRS SBSR (Right Side)
 Z4 Series (E85-E86) (02-08)	AIRBAG	2.0i (05-07)	DELPHI SRS SFZ Satellite Central
 Z4 Series (E85-E86) (02-08)	AIRBAG	2.0i (05-07)	SRS SGM-SIM Central
 Z4 Series (E85-E86) (02-08)	AIRBAG	2.0i (07-08)	Autoliv SRS ACSM
 Z4 Series (E85-E86) (02-08)	AIRBAG	2.2i (05-07)	Autoliv SRS SBSL (Left Side)
 Z4 Series (E85-E86) (02-08)	AIRBAG	2.2i (05-07)	Autoliv SRS SBSR (Right Side)
 Z4 Series (E85-E86) (02-08)	AIRBAG	2.2i (05-07)	DELPHI SRS SFZ Satellite Central
 Z4 Series (E85-E86) (02-08)	AIRBAG	2.2i (05-07)	SRS SGM-SIM Central
 Z4 Series (E85-E86) (02-08)	AIRBAG	2.2i (07-08)	Autoliv SRS ACSM
 Z4 Series (E85-E86) (02-08)	AIRBAG	2.5i (05-07)	Autoliv SRS SBSL (Left Side)
 Z4 Series (E85-E86) (02-08)	AIRBAG	2.5i (05-07)	Autoliv SRS SBSR (Right Side)
 Z4 Series (E85-E86) (02-08)	AIRBAG	2.5i (05-07)	DELPHI SRS SFZ Satellite Central
 Z4 Series (E85-E86) (02-08)	AIRBAG	2.5i (05-07)	SRS SGM-SIM Central
 Z4 Series (E85-E86) (02-08)	AIRBAG	2.5i (07-08)	Autoliv SRS ACSM
 Z4 Series (E85-E86) (02-08)	AIRBAG	3.0i (05-07)	Autoliv SRS SBSL (Left Side)
 Z4 Series (E85-E86) (02-08)	AIRBAG	3.0i (05-07)	Autoliv SRS SBSR (Right Side)
 Z4 Series (E85-E86) (02-08)	AIRBAG	3.0i (05-07)	DELPHI SRS SFZ Satellite Central
 Z4 Series (E85-E86) (02-08)	AIRBAG	3.0i (05-07)	SRS SGM-SIM Central
 Z4 Series (E85-E86) (02-08)	AIRBAG	3.0i (07-08)	Autoliv SRS ACSM
 Z4 Series (E85-E86) (02-08)	AIRBAG	3.0si (05-07)	Autoliv SRS SBSL (Left Side)
 Z4 Series (E85-E86) (02-08)	AIRBAG	3.0si (05-07)	Autoliv SRS SBSR (Right Side)
 Z4 Series (E85-E86) (02-08)	AIRBAG	3.0si (05-07)	DELPHI SRS SFZ Satellite Central
 Z4 Series (E85-E86) (02-08)	AIRBAG	3.0si (05-07)	SRS SGM-SIM Central
 Z4 Series (E85-E86) (02-08)	AIRBAG	3.0si (07-08)	Autoliv SRS ACSM
 Z4 Series (E85-E86) (02-08)	AIRBAG	3.2 M (05-07)	Autoliv SRS SBSL (Left Side)
 Z4 Series (E85-E86) (02-08)	AIRBAG	3.2 M (05-07)	Autoliv SRS SBSR (Right Side)
 Z4 Series (E85-E86) (02-08)	AIRBAG	3.2 M (05-07)	DELPHI SRS SFZ Satellite Central
 Z4 Series (E85-E86) (02-08)	AIRBAG	3.2 M (05-07)	SRS SGM-SIM Central
 Z4 Series (E85-E86) (02-08)	AIRBAG	3.2 M (07-08)	Autoliv SRS ACSM
 Z4 Series (E85-E86) (02-08)	CHASSIS NETWORK	2.0i (07-08)	DELPHI GM5
 Z4 Series (E85-E86) (02-08)	CHASSIS NETWORK	2.0i (07-08)	DELPHI ZKE

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Z4 Series (E85-E86) (02-08)	CHASSIS NETWORK	2.2i (07-08)	DELPHI GM5
 Z4 Series (E85-E86) (02-08)	CHASSIS NETWORK	2.2i (07-08)	DELPHI ZKE
 Z4 Series (E85-E86) (02-08)	CHASSIS NETWORK	2.5i (07-08)	DELPHI GM5
 Z4 Series (E85-E86) (02-08)	CHASSIS NETWORK	2.5i (07-08)	DELPHI ZKE
 Z4 Series (E85-E86) (02-08)	CHASSIS NETWORK	3.0i (07-08)	DELPHI GM5
 Z4 Series (E85-E86) (02-08)	CHASSIS NETWORK	3.0i (07-08)	DELPHI ZKE
 Z4 Series (E85-E86) (02-08)	CHASSIS NETWORK	3.0si (07-08)	DELPHI GM5
 Z4 Series (E85-E86) (02-08)	CHASSIS NETWORK	3.0si (07-08)	DELPHI ZKE
 Z4 Series (E85-E86) (02-08)	CHASSIS NETWORK	3.2 M (07-08)	DELPHI GM5
 Z4 Series (E85-E86) (02-08)	CHASSIS NETWORK	3.2 M (07-08)	DELPHI ZKE
 Z4 Series (E85-E86) (02-08)	CLIMA	2.0i (07-08)	IHKA
 Z4 Series (E85-E86) (02-08)	CLIMA	2.2i (07-08)	IHKA
 Z4 Series (E85-E86) (02-08)	CLIMA	2.5i (07-08)	IHKA
 Z4 Series (E85-E86) (02-08)	CLIMA	3.0i (07-08)	IHKA
 Z4 Series (E85-E86) (02-08)	CLIMA	3.0si (07-08)	IHKA
 Z4 Series (E85-E86) (02-08)	CLIMA	3.2 M (07-08)	IHKA
 Z4 Series (E85-E86) (02-08)	CONV. TOP/SUNROO	2.0i (05-07)	Helbako CVM
 Z4 Series (E85-E86) (02-08)	CONV. TOP/SUNROO	2.2i (05-07)	Helbako CVM
 Z4 Series (E85-E86) (02-08)	CONV. TOP/SUNROO	2.5i (05-07)	Helbako CVM
 Z4 Series (E85-E86) (02-08)	CONV. TOP/SUNROO	3.0i (05-07)	Helbako CVM
 Z4 Series (E85-E86) (02-08)	CONV. TOP/SUNROO	3.0si (05-07)	Helbako CVM
 Z4 Series (E85-E86) (02-08)	CONV. TOP/SUNROO	3.2 M (05-07)	Helbako CVM
 Z4 Series (E85-E86) (02-08)	DASHBOARD	2.0i (07-08)	Borg instruments KOMBI
 Z4 Series (E85-E86) (02-08)	DASHBOARD	2.2i (07-08)	Borg instruments KOMBI
 Z4 Series (E85-E86) (02-08)	DASHBOARD	2.5i (07-08)	Borg instruments KOMBI
 Z4 Series (E85-E86) (02-08)	DASHBOARD	3.0i (07-08)	Borg instruments KOMBI
 Z4 Series (E85-E86) (02-08)	DASHBOARD	3.0si (07-08)	Borg instruments KOMBI
 Z4 Series (E85-E86) (02-08)	DASHBOARD	3.2 M (07-08)	Borg instruments KOMBI
 Z4 Series (E85-E86) (02-08)	ELECTRIC STEERING	2.0i (07-08)	EPS
 Z4 Series (E85-E86) (02-08)	ELECTRIC STEERING	2.2i (07-08)	EPS
 Z4 Series (E85-E86) (02-08)	ELECTRIC STEERING	2.5i (07-08)	EPS
 Z4 Series (E85-E86) (02-08)	ELECTRIC STEERING	3.0i (07-08)	EPS
 Z4 Series (E85-E86) (02-08)	ELECTRIC STEERING	3.0si (07-08)	EPS
 Z4 Series (E85-E86) (02-08)	ELECTRIC STEERING	3.2 M (07-08)	EPS
 Z4 Series (E85-E86) (02-08)	ENGINE MANAGEME	2.0i (04-08)	EOBD
 Z4 Series (E85-E86) (02-08)	ENGINE MANAGEME	2.2i (02-08)	EOBD
 Z4 Series (E85-E86) (02-08)	ENGINE MANAGEME	2.2i (07-08)	SIEMENS DME MSS70
 Z4 Series (E85-E86) (02-08)	ENGINE MANAGEME	2.5i (02-08)	EOBD
 Z4 Series (E85-E86) (02-08)	ENGINE MANAGEME	2.5i (07-08)	SIEMENS DME MSS70
 Z4 Series (E85-E86) (02-08)	ENGINE MANAGEME	3.0i (02-08)	EOBD
 Z4 Series (E85-E86) (02-08)	ENGINE MANAGEME	3.0i (07-08)	SIEMENS DME MSS70
 Z4 Series (E85-E86) (02-08)	ENGINE MANAGEME	3.0si (07-08)	SIEMENS DME MSS70
 Z4 Series (E85-E86) (02-08)	ENGINE MANAGEME	3.2 M (02-08)	EOBD
 Z4 Series (E85-E86) (02-08)	ENGINE MANAGEME	3.2 M (07-08)	SIEMENS DME MSS70
 Z4 Series (E85-E86) (02-08)	FUEL PUMP MANAGE	2.0i (07-08)	HELBako EKPS
 Z4 Series (E85-E86) (02-08)	FUEL PUMP MANAGE	2.2i (07-08)	HELBako EKPS
 Z4 Series (E85-E86) (02-08)	FUEL PUMP MANAGE	2.5i (07-08)	HELBako EKPS
 Z4 Series (E85-E86) (02-08)	FUEL PUMP MANAGE	3.0i (07-08)	HELBako EKPS
 Z4 Series (E85-E86) (02-08)	FUEL PUMP MANAGE	3.0si (07-08)	HELBako EKPS
 Z4 Series (E85-E86) (02-08)	FUEL PUMP MANAGE	3.2 M (07-08)	HELBako EKPS
 Z4 Series (E85-E86) (02-08)	HEADLIGHT LEVEL	2.0i (05-07)	Siemens LSZ
 Z4 Series (E85-E86) (02-08)	HEADLIGHT LEVEL	2.2i (05-07)	Siemens LSZ
 Z4 Series (E85-E86) (02-08)	HEADLIGHT LEVEL	2.5i (05-07)	Siemens LSZ
 Z4 Series (E85-E86) (02-08)	HEADLIGHT LEVEL	3.0i (05-07)	Siemens LSZ
 Z4 Series (E85-E86) (02-08)	HEADLIGHT LEVEL	3.0si (05-07)	Siemens LSZ
 Z4 Series (E85-E86) (02-08)	HEADLIGHT LEVEL	3.2 M (05-07)	Siemens LSZ
 Z4 Series (E85-E86) (02-08)	IMMOBILIZER	2.0i (07-08)	Immobilizer EWS
 Z4 Series (E85-E86) (02-08)	IMMOBILIZER	2.2i (07-08)	Immobilizer EWS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Z4 Series (E85-E86) (02-08)	IMMOBILIZER	2.5i (07-08)	Immobilizer EWS
 Z4 Series (E85-E86) (02-08)	IMMOBILIZER	3.0i (07-08)	Immobilizer EWS
 Z4 Series (E85-E86) (02-08)	IMMOBILIZER	3.0si (07-08)	Immobilizer EWS
 Z4 Series (E85-E86) (02-08)	IMMOBILIZER	3.2 M (07-08)	Immobilizer EWS
 Z4 Series (E85-E86) (02-08)	MAINTENANCE	2.0i (04-08)	MANUAL
 Z4 Series (E85-E86) (02-08)	MAINTENANCE	2.2i (04-08)	MANUAL
 Z4 Series (E85-E86) (02-08)	MAINTENANCE	2.5i (04-08)	MANUAL
 Z4 Series (E85-E86) (02-08)	MAINTENANCE	3.0i (04-08)	MANUAL
 Z4 Series (E85-E86) (02-08)	MAINTENANCE	3.0si (04-08)	MANUAL
 Z4 Series (E85-E86) (02-08)	MAINTENANCE	3.2 M (04-08)	MANUAL
 Z4 Series (E85-E86) (02-08)	PARKING HELP	2.0i (06-..)	VALEO PDC
 Z4 Series (E85-E86) (02-08)	PARKING HELP	2.2i (06-..)	VALEO PDC
 Z4 Series (E85-E86) (02-08)	PARKING HELP	2.5i (06-..)	VALEO PDC
 Z4 Series (E85-E86) (02-08)	PARKING HELP	3.0i (06-..)	VALEO PDC
 Z4 Series (E85-E86) (02-08)	PARKING HELP	3.0si (06-..)	VALEO PDC
 Z4 Series (E85-E86) (02-08)	PARKING HELP	3.2 M (06-..)	VALEO PDC
 Z4 Series (E85-E86) (02-08)	RADIO / CD	2.0i (05-07)	Philips RAD
 Z4 Series (E85-E86) (02-08)	RADIO / CD	2.2i (05-07)	Philips RAD
 Z4 Series (E85-E86) (02-08)	RADIO / CD	2.5i (05-07)	Philips RAD
 Z4 Series (E85-E86) (02-08)	RADIO / CD	3.0i (05-07)	Philips RAD
 Z4 Series (E85-E86) (02-08)	RADIO / CD	3.0si (05-07)	Philips RAD
 Z4 Series (E85-E86) (02-08)	RADIO / CD	3.2 M (05-07)	Philips RAD
 Z4 Series (E85-E86) (02-08)	SERVICE LIGHT RES	2.0i (04-08)	MANUAL
 Z4 Series (E85-E86) (02-08)	SERVICE LIGHT RES	2.2i (04-08)	MANUAL
 Z4 Series (E85-E86) (02-08)	SERVICE LIGHT RES	2.5i (04-08)	MANUAL
 Z4 Series (E85-E86) (02-08)	SERVICE LIGHT RES	3.0i (04-08)	MANUAL
 Z4 Series (E85-E86) (02-08)	SERVICE LIGHT RES	3.0si (04-08)	MANUAL
 Z4 Series (E85-E86) (02-08)	SERVICE LIGHT RES	3.2 M (04-08)	MANUAL
 Z4 Series (E85-E86) (02-08)	STEERING COLUMN	2.0i (04-08)	KOSTAL LWS
 Z4 Series (E85-E86) (02-08)	STEERING COLUMN	2.2i (04-08)	KOSTAL LWS
 Z4 Series (E85-E86) (02-08)	STEERING COLUMN	2.5i (04-08)	KOSTAL LWS
 Z4 Series (E85-E86) (02-08)	STEERING COLUMN	3.0i (04-08)	KOSTAL LWS
 Z4 Series (E85-E86) (02-08)	STEERING COLUMN	3.0si (04-08)	KOSTAL LWS
 Z4 Series (E85-E86) (02-08)	STEERING COLUMN	3.2 M (04-08)	KOSTAL LWS
 Z4 Series (E85-E86) (02-08)	STEERING WHEEL E	2.0i (07-08)	MFL
 Z4 Series (E85-E86) (02-08)	STEERING WHEEL E	2.2i (07-08)	MFL
 Z4 Series (E85-E86) (02-08)	STEERING WHEEL E	2.5i (07-08)	MFL
 Z4 Series (E85-E86) (02-08)	STEERING WHEEL E	3.0i (07-08)	MFL
 Z4 Series (E85-E86) (02-08)	STEERING WHEEL E	3.0si (07-08)	MFL
 Z4 Series (E85-E86) (02-08)	STEERING WHEEL E	3.2 M (07-08)	MFL
 Z4 Series (E89) (09-..)	CONV. TOP/SUNROO	sDrive20i (09-..)	FZD 87
 Z4 Series (E89) (09-..)	CONV. TOP/SUNROO	sDrive23i (09-..)	FZD 87
 Z4 Series (E89) (09-..)	CONV. TOP/SUNROO	sDrive28i (09-..)	FZD 87
 Z4 Series (E89) (09-..)	CONV. TOP/SUNROO	sDrive30i (09-..)	FZD 87
 Z4 Series (E89) (09-..)	CONV. TOP/SUNROO	sDrive35i (09-..)	FZD 87
 Z4 Series (E89) (09-..)	CONV. TOP/SUNROO	sDrive35is (09-..)	FZD 87
 Z4 Series (E89) (09-..)	CRUISE CONTROL	sDrive20i (09-..)	ACC 2
 Z4 Series (E89) (09-..)	CRUISE CONTROL	sDrive23i (09-..)	ACC 2
 Z4 Series (E89) (09-..)	CRUISE CONTROL	sDrive28i (09-..)	ACC 2
 Z4 Series (E89) (09-..)	CRUISE CONTROL	sDrive30i (09-..)	ACC 2
 Z4 Series (E89) (09-..)	CRUISE CONTROL	sDrive35i (09-..)	ACC 2
 Z4 Series (E89) (09-..)	CRUISE CONTROL	sDrive35is (09-..)	ACC 2
 Z4 Series (E89) (09-..)	DASHBOARD	sDrive20i (09-..)	KOMB 87
 Z4 Series (E89) (09-..)	DASHBOARD	sDrive23i (09-..)	KOMB 87
 Z4 Series (E89) (09-..)	DASHBOARD	sDrive28i (09-..)	KOMB 87
 Z4 Series (E89) (09-..)	DASHBOARD	sDrive30i (09-..)	KOMB 87
 Z4 Series (E89) (09-..)	DASHBOARD	sDrive35i (09-..)	KOMB 87
 Z4 Series (E89) (09-..)	DASHBOARD	sDrive35is (09-..)	KOMB 87

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

BMW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Z4 Series (E89) (09-..)	ELECTRIC STEERING	sDrive20i (09-..)	Active Front Steering AFS 70
 Z4 Series (E89) (09-..)	ELECTRIC STEERING	sDrive20i (09-..)	EPS 90
 Z4 Series (E89) (09-..)	ELECTRIC STEERING	sDrive23i (09-..)	Active Front Steering AFS 70
 Z4 Series (E89) (09-..)	ELECTRIC STEERING	sDrive23i (09-..)	EPS 90
 Z4 Series (E89) (09-..)	ELECTRIC STEERING	sDrive28i (09-..)	Active Front Steering AFS 70
 Z4 Series (E89) (09-..)	ELECTRIC STEERING	sDrive28i (09-..)	EPS 90
 Z4 Series (E89) (09-..)	ELECTRIC STEERING	sDrive30i (09-..)	Active Front Steering AFS 70
 Z4 Series (E89) (09-..)	ELECTRIC STEERING	sDrive30i (09-..)	EPS 90
 Z4 Series (E89) (09-..)	ELECTRIC STEERING	sDrive35i (09-..)	Active Front Steering AFS 70
 Z4 Series (E89) (09-..)	ELECTRIC STEERING	sDrive35i (09-..)	EPS 90
 Z4 Series (E89) (09-..)	ELECTRIC STEERING	sDrive35is (09-..)	Active Front Steering AFS 70
 Z4 Series (E89) (09-..)	ELECTRIC STEERING	sDrive35is (09-..)	EPS 90
 Z4 Series (E89) (09-..)	ENGINE MANAGEME	sDrive20i (09-..)	EOBD
 Z4 Series (E89) (09-..)	ENGINE MANAGEME	sDrive23i (09-..)	EOBD
 Z4 Series (E89) (09-..)	ENGINE MANAGEME	sDrive28i (09-..)	EOBD
 Z4 Series (E89) (09-..)	ENGINE MANAGEME	sDrive30i (09-..)	EOBD
 Z4 Series (E89) (09-..)	ENGINE MANAGEME	sDrive35i (09-..)	EOBD
 Z4 Series (E89) (09-..)	ENGINE MANAGEME	sDrive35is (09-..)	EOBD
 Z4 Series (E89) (09-..)	IMMOBILIZER	sDrive20i (09-..)	CAS
 Z4 Series (E89) (09-..)	IMMOBILIZER	sDrive23i (09-..)	CAS
 Z4 Series (E89) (09-..)	IMMOBILIZER	sDrive28i (09-..)	CAS
 Z4 Series (E89) (09-..)	IMMOBILIZER	sDrive30i (09-..)	CAS
 Z4 Series (E89) (09-..)	IMMOBILIZER	sDrive35i (09-..)	CAS
 Z4 Series (E89) (09-..)	IMMOBILIZER	sDrive35is (09-..)	CAS
 Z4 Series (E89) (09-..)	PARK.BRAKE	sDrive20i (09-..)	EMF 89
 Z4 Series (E89) (09-..)	PARK.BRAKE	sDrive23i (09-..)	EMF 89
 Z4 Series (E89) (09-..)	PARK.BRAKE	sDrive28i (09-..)	EMF 89
 Z4 Series (E89) (09-..)	PARK.BRAKE	sDrive30i (09-..)	EMF 89
 Z4 Series (E89) (09-..)	PARK.BRAKE	sDrive35i (09-..)	EMF 89
 Z4 Series (E89) (09-..)	PARK.BRAKE	sDrive35is (09-..)	EMF 89
 Z4 Series (E89) (09-..)	RADIO / CD	sDrive20i (09-..)	DAB 60 - DIGITAL RADIO
 Z4 Series (E89) (09-..)	RADIO / CD	sDrive23i (09-..)	DAB 60 - DIGITAL RADIO
 Z4 Series (E89) (09-..)	RADIO / CD	sDrive28i (09-..)	DAB 60 - DIGITAL RADIO
 Z4 Series (E89) (09-..)	RADIO / CD	sDrive30i (09-..)	DAB 60 - DIGITAL RADIO
 Z4 Series (E89) (09-..)	RADIO / CD	sDrive35i (09-..)	DAB 60 - DIGITAL RADIO
 Z4 Series (E89) (09-..)	RADIO / CD	sDrive35is (09-..)	DAB 60 - DIGITAL RADIO
 Z4 Series (E89) (09-..)	RAIN-LUMINOSITY S	sDrive20i (09-..)	RLS 87
 Z4 Series (E89) (09-..)	RAIN-LUMINOSITY S	sDrive23i (09-..)	RLS 87
 Z4 Series (E89) (09-..)	RAIN-LUMINOSITY S	sDrive28i (09-..)	RLS 87
 Z4 Series (E89) (09-..)	RAIN-LUMINOSITY S	sDrive30i (09-..)	RLS 87
 Z4 Series (E89) (09-..)	RAIN-LUMINOSITY S	sDrive35i (09-..)	RLS 87
 Z4 Series (E89) (09-..)	RAIN-LUMINOSITY S	sDrive35is (09-..)	RLS 87
 Z4 Series (E89) (09-..)	SUSPENSION CONTR	sDrive20i (09-..)	EDCK 65
 Z4 Series (E89) (09-..)	SUSPENSION CONTR	sDrive23i (09-..)	EDCK 65
 Z4 Series (E89) (09-..)	SUSPENSION CONTR	sDrive28i (09-..)	EDCK 65
 Z4 Series (E89) (09-..)	SUSPENSION CONTR	sDrive30i (09-..)	EDCK 65
 Z4 Series (E89) (09-..)	SUSPENSION CONTR	sDrive35i (09-..)	EDCK 65
 Z4 Series (E89) (09-..)	SUSPENSION CONTR	sDrive35is (09-..)	EDCK 65
 Z8 Series (E52) (00-04)	AIRBAG	5.0i (00-04)	TEMIC AirBag MRS4
 Z8 Series (E52) (00-04)	ENGINE MANAGEME	5.0i (01-04)	EOBD
 Z8 Series (E52) (00-04)	MAINTENANCE	5.0i (00-04)	MANUAL
 Z8 Series (E52) (00-04)	SERVICE LIGHT RES	5.0i (00-04)	MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Cadillac

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 CTS	ENGINE MANAGEME	2.6 V6 136kw (01-...)	EOBD
 CTS	ENGINE MANAGEME	3.2 V6 160kw (01-...)	EOBD
 Seville	ENGINE MANAGEME	4.6 V8 Northstar (01-...)	EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Chevrolet

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Alero	ENGINE MANAGEME	2.4 104kw (01-...)	EOBD
 Blazer	ENGINE MANAGEME	4.3 V6 142kw (01-...)	EOBD
 Camaro	ENGINE MANAGEME	3.8 V6 142kw (01-...)	EOBD
 Captiva	ABS + TRACT. CONT	2.0 VCDI	TEVES ESC 0300
 Captiva	ABS + TRACT. CONT	2.4 16v	TEVES ESC 0300
 Captiva	ABS + TRACT. CONT	3.2	TEVES ESC 0300
 Captiva	AIRBAG	2.0 VCDI	SDM
 Captiva	AIRBAG	2.4 16v	SDM
 Captiva	AIRBAG	3.2	SDM
 Captiva	AUTOM. TRANSMISSI	2.0 VCDI	AISIN A/T
 Captiva	AUTOM. TRANSMISSI	2.4 16v	AISIN A/T
 Captiva	AUTOM. TRANSMISSI	3.2	AISIN A/T
 Captiva	CHASSIS NETWORK	2.0 VCDI	BCM Front
 Captiva	CHASSIS NETWORK	2.0 VCDI	XBCM Rear
 Captiva	CHASSIS NETWORK	2.4 16v	BCM Front
 Captiva	CHASSIS NETWORK	2.4 16v	XBCM Rear
 Captiva	CHASSIS NETWORK	3.2	BCM Front
 Captiva	CHASSIS NETWORK	3.2	XBCM Rear
 Captiva	CLIMA	2.0 VCDI	ECC
 Captiva	CLIMA	2.4 16v	ECC
 Captiva	CLIMA	3.2	ECC
 Captiva	DASHBOARD	2.0 VCDI	IPC
 Captiva	DASHBOARD	2.4 16v	IPC
 Captiva	DASHBOARD	3.2	IPC
 Captiva	ENGINE MANAGEME	2.0 VCDI 2.0L	BOSCH EDC 16 39 Common Rail
 Captiva	ENGINE MANAGEME	2.4 16v (06-...)	EOBD
 Captiva	ENGINE MANAGEME	3.2	EOBD
 Captiva	IMMOBILIZER	2.0 VCDI	BOSCH VTD
 Captiva	IMMOBILIZER	2.4 16v	BOSCH VTD
 Captiva	IMMOBILIZER	3.2	BOSCH VTD
 Captiva	MAINTENANCE	2.0 VCDI	IPC
 Captiva	MAINTENANCE	2.0 VCDI	Omron TPMS 0400
 Captiva	MAINTENANCE	2.4 16v	IPC
 Captiva	MAINTENANCE	2.4 16v	Omron TPMS 0400
 Captiva	MAINTENANCE	3.2	IPC
 Captiva	MAINTENANCE	3.2	Omron TPMS 0400
 Captiva	PARKING HELP	2.0 VCDI	PAS
 Captiva	PARKING HELP	2.4 16v	PAS
 Captiva	PARKING HELP	3.2	PAS
 Captiva	TIRE PRESSURE	2.0 VCDI	Omron TPMS 0400
 Captiva	TIRE PRESSURE	2.4 16v	Omron TPMS 0400
 Captiva	TIRE PRESSURE	3.2	Omron TPMS 0400
 Captiva	TRACTION CONTROL	2.0 VCDI	TCCM
 Captiva	TRACTION CONTROL	2.4 16v	TCCM
 Captiva	TRACTION CONTROL	3.2	TCCM
 Corvette	ENGINE MANAGEME	5.7 V8 (01-...)	EOBD
 Epica	ENGINE MANAGEME	2.0 (05-...)	EOBD
 Epica	ENGINE MANAGEME	2.5 (05-...)	EOBD
 Kalos	ABS	1.2 (05-...)	ABS T200
Kalos	ABS	1.4 16v (05-...)	ABS T200
Kalos	ENGINE MANAGEME	1.2 (05-...)	EOBD
Kalos	ENGINE MANAGEME	1.2 (05-...)	MPI
Kalos	ENGINE MANAGEME	1.4 16v (05-...)	EOBD
Kalos	MAINTENANCE	1.2 (05-...)	ABS T200
Kalos	MAINTENANCE	1.4 16v (05-...)	ABS T200
Lacetti	ENGINE MANAGEME	1.4 16v (05-...)	EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Chevrolet

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Matiz	ABS	0.8 (05-..)	TEVES
 Matiz	ABS	1.0 (05-..)	TEVES
 Matiz	ENGINE MANAGEME	0.8 (05-..)	EOBD
 Matiz	ENGINE MANAGEME	1.0 (05-..)	EOBD
 Matiz	ENGINE MANAGEME	1.0 (07-..)	MPI
 Matiz	MAINTENANCE	0.8 (05-..)	TEVES
 Matiz	MAINTENANCE	1.0 (05-..)	TEVES
 Nubira	ENGINE MANAGEME	1.6 (05-..)	EOBD
 S10	ENGINE MANAGEME	2.2 90kw (01-..)	EOBD
 S10	ENGINE MANAGEME	4.3 V6 142kw (01-..)	EOBD
 Tacuma	ENGINE MANAGEME	1.6 16v (05-..)	EOBD
 Tahoe	ENGINE MANAGEME	5.3 V8 201kw (01-..)	EOBD
 TrailBlazer	ENGINE MANAGEME	4.2 201kw (01-..)	EOBD
 Trans Sport	ENGINE MANAGEME	3.4 V6 138kw (01-..)	EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Chrysler

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 300C	ABS	3.0 V6 CRD DPF (05-07)	TEVES TIPMCGW
 300C	ABS	3.5 V6 24v (05-07)	TEVES TIPMCGW
 300C	ABS	5.7 V8 HEMI (05-07)	TEVES TIPMCGW
 300C	ABS	6.1 V8 HEMI (05-07)	TEVES TIPMCGW
 300C	AIRBAG	3.0 V6 CRD DPF (05-07)	SRS
 300C	AIRBAG	3.5 V6 24v (05-07)	SRS
 300C	AIRBAG	5.7 V8 HEMI (05-07)	SRS
 300C	AIRBAG	6.1 V8 HEMI (05-07)	SRS
 300C	AUTOM. TRANSMISSI	3.0 V6 CRD DPF (05-07)	A/T
 300C	AUTOM. TRANSMISSI	3.0 V6 CRD DPF (05-07)	A/T Selector Lever
 300C	AUTOM. TRANSMISSI	3.5 V6 24v (05-07)	A/T
 300C	AUTOM. TRANSMISSI	3.5 V6 24v (05-07)	A/T Selector Lever
 300C	AUTOM. TRANSMISSI	5.7 V8 HEMI (05-07)	A/T
 300C	AUTOM. TRANSMISSI	5.7 V8 HEMI (05-07)	A/T Selector Lever
 300C	AUTOM. TRANSMISSI	6.1 V8 HEMI (05-07)	A/T
 300C	AUTOM. TRANSMISSI	6.1 V8 HEMI (05-07)	A/T Selector Lever
 300C	CHASSIS NETWORK	3.0 V6 CRD DPF (05-07)	Gateway
 300C	CHASSIS NETWORK	3.5 V6 24v (05-07)	Gateway
 300C	CHASSIS NETWORK	5.7 V8 HEMI (05-07)	Gateway
 300C	CHASSIS NETWORK	6.1 V8 HEMI (05-07)	Gateway
 300C	CLIMA	3.0 V6 CRD DPF (05-07)	Climate Control
 300C	CLIMA	3.5 V6 24v (05-07)	Climate Control
 300C	CLIMA	5.7 V8 HEMI (05-07)	Climate Control
 300C	CLIMA	6.1 V8 HEMI (05-07)	Climate Control
 300C	DASHBOARD	3.0 V6 CRD DPF (05-07)	Dashboard
 300C	DASHBOARD	3.5 V6 24v (05-07)	Dashboard
 300C	DASHBOARD	5.7 V8 HEMI (05-07)	Dashboard
 300C	DASHBOARD	6.1 V8 HEMI (05-07)	Dashboard
 300C	ENGINE MANAGEME	3.0 V6 CRD DPF (05-07)	BOSCH EDC Common Rail
 300C	ENGINE MANAGEME	3.5 V6 24v (05-07)	EOBD
 300C	ENGINE MANAGEME	6.1 V8 HEMI (05-07)	EOBD
 300C	MAINTENANCE	3.0 V6 CRD DPF (05-07)	BOSCH EDC Common Rail
 300C	MAINTENANCE	3.0 V6 CRD DPF (05-07)	TEVES TIPMCGW
 300C	MAINTENANCE	3.5 V6 24v (05-07)	TEVES TIPMCGW
 300C	MAINTENANCE	5.7 V8 HEMI (05-07)	TEVES TIPMCGW
 300C	MAINTENANCE	6.1 V8 HEMI (05-07)	TEVES TIPMCGW
 300C	PARKING HELP	3.0 V6 CRD DPF (05-07)	
 300C	PARKING HELP	3.5 V6 24v (05-07)	
 300C	PARKING HELP	5.7 V8 HEMI (05-07)	
 300C	PARKING HELP	6.1 V8 HEMI (05-07)	
 300M	ENGINE MANAGEME	2.7 V6 150kw (01-..)	EOBD
 300M	ENGINE MANAGEME	3.5 V6 185kw (01-..)	EOBD
 Neon	ENGINE MANAGEME	1.6 85kw (01-..)	EOBD
 Neon	ENGINE MANAGEME	2.0 98kw (01-..)	EOBD
 PT Cruiser	ENGINE MANAGEME	1.6 85kw (01-..)	EOBD
 PT Cruiser	ENGINE MANAGEME	2.0 104kw (01-..)	EOBD
 Sebring	ENGINE MANAGEME	2.0 104kw (01-..)	EOBD
 Sebring	ENGINE MANAGEME	2.7 V6 149kw (01-..)	EOBD
 Voyager	ENGINE MANAGEME	2.4 108kw (01-..)	EOBD
 Voyager	ENGINE MANAGEME	2.5 TD Common Rail 105kw (04-..)	EOBD
 Voyager	ENGINE MANAGEME	3.3 V6 128kw (01-..)	EOBD
 Voyager	MAINTENANCE	2.4 108kw (01-..)	MANUAL
 Voyager	MAINTENANCE	2.5 TD Common Rail 105kw (04-..)	MANUAL
 Voyager	MAINTENANCE	3.3 V6 128kw (01-..)	MANUAL
 Voyager	SERVICE LIGHT RES	2.4 108kw (01-..)	MANUAL
 Voyager	SERVICE LIGHT RES	2.5 TD Common Rail 105kw (04-..)	MANUAL
 Voyager	SERVICE LIGHT RES	3.3 V6 128kw (01-..)	MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 AX	ELECTRONIC INJECT	1.1 8v 43kw HDZ	BOSCH MonoJetronic A2.2 [Slow]
 AX	ELECTRONIC INJECT	1.4 8v 55kw KDY	BOSCH MonoJetronic A2.2 [Slow]
 AX	ELECTRONIC INJECT	1.4 8v 55kw KDZ	BOSCH MonoJetronic A2.2 [Slow]
 AX	ENGINE MANAGEME	1.0 8v 33kw CDY	BOSCH MonoMotronic MA3.0 [Slow]
 AX	ENGINE MANAGEME	1.0 8v 33kw CDZ	BOSCH MonoMotronic MA3.0 [Slow]
 AX	ENGINE MANAGEME	1.1 8v 44kw HDZ	Marelli MMBA G6 [Slow]
 AX	ENGINE MANAGEME	1.4 8v 55kw K6B	BOSCH Motronic MP3.1 [Slow]
 AX	ENGINE MANAGEME	1.4 8v 55kw KDX	BOSCH MonoMotronic MA3.0 [Fast]
 AX	ENGINE MANAGEME	1.4 8v 55kw KDX	BOSCH MonoMotronic MA3.0 [Slow]
 AX	ENGINE MANAGEME	1.4 8v 70kw KFZ	BOSCH Motronic MP3.1 [Slow]
 Berlingo 1 (96-02)	ABS	1.1 8v 40kw HDY	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	ABS	1.1 8v 44kw HDZ	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	ABS	1.1 8v 44kw HFX	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	ABS	1.4 8v 55kw KFW	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	ABS	1.4 8v 55kw KFX	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	ABS	1.4 8v 55kw KFX - GPL	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	ABS	1.6 16v 82kw N6A	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	ABS	1.6 16v 82kw NFU	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	ABS	1.8 8v 66kw LFX	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	ABS	1.8 D 8v 44kw A9A	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	ABS	1.9 D 8v 50kw D9B	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	ABS	1.9 D 8v 50kw DJY	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	ABS	1.9 D 8v 52kw WJY	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	ABS	1.9 D 8v 52kw WJZ	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	ABS	2.0 HDI 8v 66kw RHY	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	AIRBAG	1.1 8v 40kw HDY (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo 1 (96-02)	AIRBAG	1.1 8v 44kw HDZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo 1 (96-02)	AIRBAG	1.1 8v 44kw HFX (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo 1 (96-02)	AIRBAG	1.4 8v 55kw KFW (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo 1 (96-02)	AIRBAG	1.4 8v 55kw KFX - GPL (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo 1 (96-02)	AIRBAG	1.4 8v 55kw KFX (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo 1 (96-02)	AIRBAG	1.6 16v 82kw N6A (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo 1 (96-02)	AIRBAG	1.6 16v 82kw NFU (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo 1 (96-02)	AIRBAG	1.8 8v 66kw LFX (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo 1 (96-02)	AIRBAG	1.8 D 8v 44kw A9A (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo 1 (96-02)	AIRBAG	1.9 D 8v 50kw D9B (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo 1 (96-02)	AIRBAG	1.9 D 8v 50kw DJY (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo 1 (96-02)	AIRBAG	1.9 D 8v 52kw WJY (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo 1 (96-02)	AIRBAG	1.9 D 8v 52kw WJZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo 1 (96-02)	AIRBAG	2.0 HDI 8v 66kw RHY (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo 1 (96-02)	CHASSIS NETWORK	1.1 8v 40kw HDY	Body Computer BSI AUTODETECT
 Berlingo 1 (96-02)	CHASSIS NETWORK	1.1 8v 40kw HDY (...01)	VALEO Body Computer
 Berlingo 1 (96-02)	CHASSIS NETWORK	1.1 8v 44kw HDZ	Body Computer BSI AUTODETECT
 Berlingo 1 (96-02)	CHASSIS NETWORK	1.1 8v 44kw HDZ (...01)	VALEO Body Computer
 Berlingo 1 (96-02)	CHASSIS NETWORK	1.1 8v 44kw HFX	Body Computer BSI AUTODETECT
 Berlingo 1 (96-02)	CHASSIS NETWORK	1.1 8v 44kw HFX (...01)	VALEO Body Computer
 Berlingo 1 (96-02)	CHASSIS NETWORK	1.4 8v 55kw KFW	Body Computer BSI AUTODETECT
 Berlingo 1 (96-02)	CHASSIS NETWORK	1.4 8v 55kw KFW (...01)	VALEO Body Computer
 Berlingo 1 (96-02)	CHASSIS NETWORK	1.4 8v 55kw KFX	Body Computer BSI AUTODETECT
 Berlingo 1 (96-02)	CHASSIS NETWORK	1.4 8v 55kw KFX - GPL	Body Computer BSI AUTODETECT
 Berlingo 1 (96-02)	CHASSIS NETWORK	1.4 8v 55kw KFX - GPL	VALEO Body Computer BSI AUTODETECT
 Berlingo 1 (96-02)	CHASSIS NETWORK	1.4 8v 55kw KFX (...01)	VALEO Body Computer
 Berlingo 1 (96-02)	CHASSIS NETWORK	1.6 16v 82kw N6A	Body Computer BSI AUTODETECT
 Berlingo 1 (96-02)	CHASSIS NETWORK	1.6 16v 82kw N6A (...01)	VALEO Body Computer
 Berlingo 1 (96-02)	CHASSIS NETWORK	1.6 16v 82kw NFU	Body Computer BSI AUTODETECT
 Berlingo 1 (96-02)	CHASSIS NETWORK	1.6 16v 82kw NFU (...01)	VALEO Body Computer
 Berlingo 1 (96-02)	CHASSIS NETWORK	1.8 8v 66kw LFX	Body Computer BSI AUTODETECT
 Berlingo 1 (96-02)	CHASSIS NETWORK	1.8 8v 66kw LFX (...01)	VALEO Body Computer

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo 1 (96-02)	CHASSIS NETWORK	1.8 D 8v 44kw A9A	Body Computer BSI AUTODETECT
 Berlingo 1 (96-02)	CHASSIS NETWORK	1.8 D 8v 44kw A9A (...-01)	VALEO Body Computer
 Berlingo 1 (96-02)	CHASSIS NETWORK	1.9 D 8v 50kw D9B	Body Computer BSI AUTODETECT
 Berlingo 1 (96-02)	CHASSIS NETWORK	1.9 D 8v 50kw D9B (...-01)	VALEO Body Computer
 Berlingo 1 (96-02)	CHASSIS NETWORK	1.9 D 8v 50kw DJY	Body Computer BSI AUTODETECT
 Berlingo 1 (96-02)	CHASSIS NETWORK	1.9 D 8v 50kw DJY (...-01)	VALEO Body Computer
 Berlingo 1 (96-02)	CHASSIS NETWORK	1.9 D 8v 52kw WJY	Body Computer BSI AUTODETECT
 Berlingo 1 (96-02)	CHASSIS NETWORK	1.9 D 8v 52kw WJY (...-01)	VALEO Body Computer
 Berlingo 1 (96-02)	CHASSIS NETWORK	1.9 D 8v 52kw WJZ	Body Computer BSI AUTODETECT
 Berlingo 1 (96-02)	CHASSIS NETWORK	1.9 D 8v 52kw WJZ (...-01)	VALEO Body Computer
 Berlingo 1 (96-02)	CHASSIS NETWORK	2.0 HDI 8v 66kw RHY	Body Computer BSI AUTODETECT
 Berlingo 1 (96-02)	CHASSIS NETWORK	2.0 HDI 8v 66kw RHY (...-01)	VALEO Body Computer
 Berlingo 1 (96-02)	DASHBOARD	1.1 8v 40kw HDY	AUTODETECT
 Berlingo 1 (96-02)	DASHBOARD	1.1 8v 44kw HDZ	AUTODETECT
 Berlingo 1 (96-02)	DASHBOARD	1.1 8v 44kw HFX	AUTODETECT
 Berlingo 1 (96-02)	DASHBOARD	1.4 8v 55kw KFW	AUTODETECT
 Berlingo 1 (96-02)	DASHBOARD	1.4 8v 55kw KFX	AUTODETECT
 Berlingo 1 (96-02)	DASHBOARD	1.4 8v 55kw KFX - GPL	AUTODETECT
 Berlingo 1 (96-02)	DASHBOARD	1.6 16v 82kw N6A	AUTODETECT
 Berlingo 1 (96-02)	DASHBOARD	1.6 16v 82kw NFU	AUTODETECT
 Berlingo 1 (96-02)	DASHBOARD	1.8 8v 66kw LFX	AUTODETECT
 Berlingo 1 (96-02)	DASHBOARD	1.8 D 8v 44kw A9A	AUTODETECT
 Berlingo 1 (96-02)	DASHBOARD	1.9 D 8v 50kw D9B	AUTODETECT
 Berlingo 1 (96-02)	DASHBOARD	1.9 D 8v 50kw DJY	AUTODETECT
 Berlingo 1 (96-02)	DASHBOARD	1.9 D 8v 52kw WJY	AUTODETECT
 Berlingo 1 (96-02)	DASHBOARD	1.9 D 8v 52kw WJZ	AUTODETECT
 Berlingo 1 (96-02)	DASHBOARD	2.0 HDI 8v 66kw RHY	AUTODETECT
 Berlingo 1 (96-02)	DIESEL MANAGEMEN	1.9 D 8v 52kw WJY	LUCAS DCN2 AUTODETECT
 Berlingo 1 (96-02)	DIESEL MANAGEMEN	1.9 D 8v 52kw WJY	LUCAS Diesel DCN2
 Berlingo 1 (96-02)	ENGINE MANAGEME	1.1 8v 40kw HDY	BOSCH MonoMotronic MA3.1
 Berlingo 1 (96-02)	ENGINE MANAGEME	1.1 8v 44kw HDZ	BOSCH MonoMotronic MA3.1
 Berlingo 1 (96-02)	ENGINE MANAGEME	1.1 8v 44kw HFX	BOSCH M7.4.4 AUTODETECT
 Berlingo 1 (96-02)	ENGINE MANAGEME	1.4 8v 55kw KFW	SAGEM S2000 AUTODETECT
 Berlingo 1 (96-02)	ENGINE MANAGEME	1.4 8v 55kw KFX	Marelli MM 1AP.40
 Berlingo 1 (96-02)	ENGINE MANAGEME	1.4 8v 55kw KFX	SAGEM SL 96
 Berlingo 1 (96-02)	ENGINE MANAGEME	1.6 16v 82kw N6A	BOSCH ME 7.4.4 AUTODETECT
 Berlingo 1 (96-02)	ENGINE MANAGEME	1.6 16v 82kw NFU	BOSCH ME 7.4.4 AUTODETECT
 Berlingo 1 (96-02)	ENGINE MANAGEME	1.8 8v 66kw LFX	BOSCH ME 7.4.4 AUTODETECT
 Berlingo 1 (96-02)	ENGINE MANAGEME	2.0 HDI 8v 66kw RHY	BOSCH EDC15 C2 Common Rail AUTODE
 Berlingo 1 (96-02)	ENGINE MANAGEME	2.0 HDI 8v 66kw RHY	SIEMENS Diesel SID 801 Common Rail
 Berlingo 1 (96-02)	ENGINE MANAGEME	2.0 HDI 8v 66kw RHY	SIEMENS SID 801 Common Rail AUTODE
 Berlingo 1 (96-02)	ENGINE MANAGEME	2.0 HDI 8v 66kw RHY (...-00)	BOSCH EDC 15 C2 Common Rail
 Berlingo 1 (96-02)	ENGINE MANAGEME	2.0 HDI 8v 66kw RHY (01-03)	BOSCH EDC 15 C2 Common Rail
 Berlingo 1 (96-02)	KEY ENCODE	1.1 8v 40kw HDY	Valeo/Siemens
 Berlingo 1 (96-02)	KEY ENCODE	1.1 8v 44kw HDZ	Valeo/Siemens
 Berlingo 1 (96-02)	KEY ENCODE	1.1 8v 44kw HFX	Valeo/Siemens
 Berlingo 1 (96-02)	KEY ENCODE	1.4 8v 55kw KFW	Valeo/Siemens
 Berlingo 1 (96-02)	KEY ENCODE	1.4 8v 55kw KFX	Valeo/Siemens
 Berlingo 1 (96-02)	KEY ENCODE	1.6 16v 82kw N6A	Valeo/Siemens
 Berlingo 1 (96-02)	KEY ENCODE	1.6 16v 82kw NFU	Valeo/Siemens
 Berlingo 1 (96-02)	KEY ENCODE	1.8 8v 66kw LFX	Valeo/Siemens
 Berlingo 1 (96-02)	KEY ENCODE	1.8 D 8v 44kw A9A	Valeo/Siemens
 Berlingo 1 (96-02)	KEY ENCODE	1.9 D 8v 50kw D9B	Valeo/Siemens
 Berlingo 1 (96-02)	KEY ENCODE	1.9 D 8v 50kw DJY	Valeo/Siemens
 Berlingo 1 (96-02)	KEY ENCODE	1.9 D 8v 52kw WJY	Valeo/Siemens
 Berlingo 1 (96-02)	KEY ENCODE	1.9 D 8v 52kw WJZ	Valeo/Siemens
 Berlingo 1 (96-02)	KEY ENCODE	2.0 HDI 8v 66kw RHY	Valeo/Siemens
 Berlingo 1 (96-02)	MAINTENANCE	1.1 8v 40kw HDY	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo 1 (96-02)	MAINTENANCE	1.1 8v 40kw HDY	AUTODETECT
 Berlingo 1 (96-02)	MAINTENANCE	1.1 8v 40kw HDY	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.1 8v 40kw HDY	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.1 8v 40kw HDY	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.1 8v 40kw HDY	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.1 8v 40kw HDY (98-00)	Sagem Manual
 Berlingo 1 (96-02)	MAINTENANCE	1.1 8v 44kw HDZ	AUTODETECT
 Berlingo 1 (96-02)	MAINTENANCE	1.1 8v 44kw HDZ	AUTODETECT
 Berlingo 1 (96-02)	MAINTENANCE	1.1 8v 44kw HDZ	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.1 8v 44kw HDZ	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.1 8v 44kw HDZ	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.1 8v 44kw HDZ	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.1 8v 44kw HDZ (98-00)	Sagem Manual
 Berlingo 1 (96-02)	MAINTENANCE	1.1 8v 44kw HFX	AUTODETECT
 Berlingo 1 (96-02)	MAINTENANCE	1.1 8v 44kw HFX	AUTODETECT
 Berlingo 1 (96-02)	MAINTENANCE	1.1 8v 44kw HFX	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.1 8v 44kw HFX	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.1 8v 44kw HFX	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.1 8v 44kw HFX	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.1 8v 44kw HFX (98-00)	Sagem Manual
 Berlingo 1 (96-02)	MAINTENANCE	1.4 8v 55kw KFW	AUTODETECT
 Berlingo 1 (96-02)	MAINTENANCE	1.4 8v 55kw KFW	AUTODETECT
 Berlingo 1 (96-02)	MAINTENANCE	1.4 8v 55kw KFW	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.4 8v 55kw KFW	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.4 8v 55kw KFW	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.4 8v 55kw KFW	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.4 8v 55kw KFW (98-00)	Sagem Manual
 Berlingo 1 (96-02)	MAINTENANCE	1.4 8v 55kw KFX	AUTODETECT
 Berlingo 1 (96-02)	MAINTENANCE	1.4 8v 55kw KFX	AUTODETECT
 Berlingo 1 (96-02)	MAINTENANCE	1.4 8v 55kw KFX	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.4 8v 55kw KFX	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.4 8v 55kw KFX	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.4 8v 55kw KFX	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.4 8v 55kw KFX - GPL	AUTODETECT
 Berlingo 1 (96-02)	MAINTENANCE	1.4 8v 55kw KFX - GPL	AUTODETECT
 Berlingo 1 (96-02)	MAINTENANCE	1.4 8v 55kw KFX - GPL	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.4 8v 55kw KFX - GPL	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.4 8v 55kw KFX - GPL	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.4 8v 55kw KFX - GPL	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.4 8v 55kw KFX - GPL (98-00)	Sagem Manual
 Berlingo 1 (96-02)	MAINTENANCE	1.4 8v 55kw KFX (98-00)	Sagem Manual
 Berlingo 1 (96-02)	MAINTENANCE	1.6 16v 82kw N6A	AUTODETECT
 Berlingo 1 (96-02)	MAINTENANCE	1.6 16v 82kw N6A	AUTODETECT
 Berlingo 1 (96-02)	MAINTENANCE	1.6 16v 82kw N6A	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.6 16v 82kw N6A	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.6 16v 82kw N6A	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.6 16v 82kw N6A	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.6 16v 82kw NFU	AUTODETECT
 Berlingo 1 (96-02)	MAINTENANCE	1.6 16v 82kw NFU	AUTODETECT
 Berlingo 1 (96-02)	MAINTENANCE	1.6 16v 82kw NFU	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.6 16v 82kw NFU	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.6 16v 82kw NFU	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.6 16v 82kw NFU	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.8 8v 66kw LFX	AUTODETECT
 Berlingo 1 (96-02)	MAINTENANCE	1.8 8v 66kw LFX	AUTODETECT
 Berlingo 1 (96-02)	MAINTENANCE	1.8 8v 66kw LFX	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.8 8v 66kw LFX	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.8 8v 66kw LFX	BOSCH ABS ABR 5.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo 1 (96-02)	MAINTENANCE	1.8 8v 66kw LFX	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.8 D 8v 44kw A9A	AUTODETECT
 Berlingo 1 (96-02)	MAINTENANCE	1.8 D 8v 44kw A9A	AUTODETECT
 Berlingo 1 (96-02)	MAINTENANCE	1.8 D 8v 44kw A9A	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.8 D 8v 44kw A9A	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.8 D 8v 44kw A9A	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.8 D 8v 44kw A9A	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.8 D 8v 44kw A9A (98-00)	Sagem Manual
 Berlingo 1 (96-02)	MAINTENANCE	1.9 D 8v 50kw D9B	AUTODETECT
 Berlingo 1 (96-02)	MAINTENANCE	1.9 D 8v 50kw D9B	AUTODETECT
 Berlingo 1 (96-02)	MAINTENANCE	1.9 D 8v 50kw D9B	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.9 D 8v 50kw D9B	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.9 D 8v 50kw D9B	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.9 D 8v 50kw D9B	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.9 D 8v 50kw D9B (98-00)	Sagem Manual
 Berlingo 1 (96-02)	MAINTENANCE	1.9 D 8v 50kw DJY	AUTODETECT
 Berlingo 1 (96-02)	MAINTENANCE	1.9 D 8v 50kw DJY	AUTODETECT
 Berlingo 1 (96-02)	MAINTENANCE	1.9 D 8v 50kw DJY	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.9 D 8v 50kw DJY	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.9 D 8v 50kw DJY	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.9 D 8v 50kw DJY	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.9 D 8v 50kw DJY (98-00)	Sagem Manual
 Berlingo 1 (96-02)	MAINTENANCE	1.9 D 8v 52kw WJY	AUTODETECT
 Berlingo 1 (96-02)	MAINTENANCE	1.9 D 8v 52kw WJY	AUTODETECT
 Berlingo 1 (96-02)	MAINTENANCE	1.9 D 8v 52kw WJY	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.9 D 8v 52kw WJY	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.9 D 8v 52kw WJY	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.9 D 8v 52kw WJY	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.9 D 8v 52kw WJY (98-00)	Sagem Manual
 Berlingo 1 (96-02)	MAINTENANCE	1.9 D 8v 52kw WJZ	AUTODETECT
 Berlingo 1 (96-02)	MAINTENANCE	1.9 D 8v 52kw WJZ	AUTODETECT
 Berlingo 1 (96-02)	MAINTENANCE	1.9 D 8v 52kw WJZ	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.9 D 8v 52kw WJZ	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.9 D 8v 52kw WJZ	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.9 D 8v 52kw WJZ	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	1.9 D 8v 52kw WJZ (98-00)	Sagem Manual
 Berlingo 1 (96-02)	MAINTENANCE	2.0 HDI 8v 66kw RHY	AUTODETECT
 Berlingo 1 (96-02)	MAINTENANCE	2.0 HDI 8v 66kw RHY	AUTODETECT
 Berlingo 1 (96-02)	MAINTENANCE	2.0 HDI 8v 66kw RHY	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	2.0 HDI 8v 66kw RHY	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	2.0 HDI 8v 66kw RHY	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	2.0 HDI 8v 66kw RHY	BOSCH ABS ABR 5.3
 Berlingo 1 (96-02)	MAINTENANCE	2.0 HDI 8v 66kw RHY	BOSCH EDC15 C2 Common Rail AUTODE
 Berlingo 1 (96-02)	MAINTENANCE	2.0 HDI 8v 66kw RHY (01-03)	BOSCH EDC 15 C2 Common Rail
 Berlingo 1 (96-02)	MAINTENANCE	2.0 HDI 8v 66kw RHY (98-00)	Sagem Manual
 Berlingo 1 (96-02)	RADIO / CD	1.1 8v 40kw HDY	AudioSystem AUTODETECT
 Berlingo 1 (96-02)	RADIO / CD	1.1 8v 40kw HDY	CD Changer AUTODETECT
 Berlingo 1 (96-02)	RADIO / CD	1.1 8v 40kw HDY	CLARION AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.1 8v 40kw HDY	PHILIPS AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.1 8v 40kw HDY	VDO AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.1 8v 44kw HDZ	AudioSystem AUTODETECT
 Berlingo 1 (96-02)	RADIO / CD	1.1 8v 44kw HDZ	CD Changer AUTODETECT
 Berlingo 1 (96-02)	RADIO / CD	1.1 8v 44kw HDZ	CLARION AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.1 8v 44kw HDZ	PHILIPS AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.1 8v 44kw HDZ	VDO AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.1 8v 44kw HFX	AudioSystem AUTODETECT
 Berlingo 1 (96-02)	RADIO / CD	1.1 8v 44kw HFX	Cd Changer AUTODETECT
 Berlingo 1 (96-02)	RADIO / CD	1.1 8v 44kw HFX	CLARION AudioSystem

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo 1 (96-02)	RADIO / CD	1.1 8v 44kw HFX	PHILIPS AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.1 8v 44kw HFX	VDO AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.4 8v 55kw KFW	AudioSystem AUTODETECT
 Berlingo 1 (96-02)	RADIO / CD	1.4 8v 55kw KFW	CD Changer AUTODETECT
 Berlingo 1 (96-02)	RADIO / CD	1.4 8v 55kw KFW	CLARION AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.4 8v 55kw KFW	PHILIPS AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.4 8v 55kw KFW	VDO AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.4 8v 55kw KFX	AudioSystem AUTODETECT
 Berlingo 1 (96-02)	RADIO / CD	1.4 8v 55kw KFX	CD Changer AUTODETECT
 Berlingo 1 (96-02)	RADIO / CD	1.4 8v 55kw KFX	CLARION AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.4 8v 55kw KFX	PHILIPS AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.4 8v 55kw KFX	VDO AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.4 8v 55kw KFX - GPL	AudioSystem AUTODETECT
 Berlingo 1 (96-02)	RADIO / CD	1.4 8v 55kw KFX - GPL	CD Changer AUTODETECT
 Berlingo 1 (96-02)	RADIO / CD	1.4 8v 55kw KFX - GPL	CLARION AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.4 8v 55kw KFX - GPL	PHILIPS AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.4 8v 55kw KFX - GPL	VDO AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.6 16v 82kw N6A	AudioSystem AUTODETECT
 Berlingo 1 (96-02)	RADIO / CD	1.6 16v 82kw N6A	CD Changer AUTODETECT
 Berlingo 1 (96-02)	RADIO / CD	1.6 16v 82kw N6A	CLARION AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.6 16v 82kw N6A	PHILIPS AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.6 16v 82kw N6A	VDO AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.6 16v 82kw NFU	AudioSystem AUTODETECT
 Berlingo 1 (96-02)	RADIO / CD	1.6 16v 82kw NFU	CD Changer AUTODETECT
 Berlingo 1 (96-02)	RADIO / CD	1.6 16v 82kw NFU	CLARION AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.6 16v 82kw NFU	PHILIPS AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.6 16v 82kw NFU	VDO AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.8 8v 66kw LFX	AudioSystem AUTODETECT
 Berlingo 1 (96-02)	RADIO / CD	1.8 8v 66kw LFX	CD Changer AUTODETECT
 Berlingo 1 (96-02)	RADIO / CD	1.8 8v 66kw LFX	CLARION AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.8 8v 66kw LFX	PHILIPS AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.8 8v 66kw LFX	VDO AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.8 D 8v 44kw A9A	AudioSystem AUTODETECT
 Berlingo 1 (96-02)	RADIO / CD	1.8 D 8v 44kw A9A	CD Changer AUTODETECT
 Berlingo 1 (96-02)	RADIO / CD	1.8 D 8v 44kw A9A	CLARION AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.8 D 8v 44kw A9A	PHILIPS AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.8 D 8v 44kw A9A	VDO AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.9 D 8v 50kw D9B	AudioSystem AUTODETECT
 Berlingo 1 (96-02)	RADIO / CD	1.9 D 8v 50kw D9B	CD Changer AUTODETECT
 Berlingo 1 (96-02)	RADIO / CD	1.9 D 8v 50kw D9B	CLARION AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.9 D 8v 50kw D9B	PHILIPS AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.9 D 8v 50kw D9B	VDO AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.9 D 8v 50kw DJY	AudioSystem AUTODETECT
 Berlingo 1 (96-02)	RADIO / CD	1.9 D 8v 50kw DJY	CD Changer AUTODETECT
 Berlingo 1 (96-02)	RADIO / CD	1.9 D 8v 50kw DJY	CLARION AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.9 D 8v 50kw DJY	PHILIPS AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.9 D 8v 50kw DJY	VDO AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.9 D 8v 52kw WJY	AudioSystem AUTODETECT
 Berlingo 1 (96-02)	RADIO / CD	1.9 D 8v 52kw WJY	CD Changer AUTODETECT
 Berlingo 1 (96-02)	RADIO / CD	1.9 D 8v 52kw WJY	CLARION AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.9 D 8v 52kw WJY	PHILIPS AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.9 D 8v 52kw WJY	VDO AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.9 D 8v 52kw WJZ	AudioSystem AUTODETECT
 Berlingo 1 (96-02)	RADIO / CD	1.9 D 8v 52kw WJZ	CD Changer AUTODETECT
 Berlingo 1 (96-02)	RADIO / CD	1.9 D 8v 52kw WJZ	CLARION AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.9 D 8v 52kw WJZ	PHILIPS AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	1.9 D 8v 52kw WJZ	VDO AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	2.0 HDI 8v 66kw RHY	AudioSystem AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo 1 (96-02)	RADIO / CD	2.0 HDI 8v 66kw RHY	CD Changer AUTODETECT
 Berlingo 1 (96-02)	RADIO / CD	2.0 HDI 8v 66kw RHY	CLARION AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	2.0 HDI 8v 66kw RHY	PHILIPS AudioSystem
 Berlingo 1 (96-02)	RADIO / CD	2.0 HDI 8v 66kw RHY	VDO AudioSystem
 Berlingo 1 (96-02)	SERVICE LIGHT RES	1.1 8v 40kw HDY (98-00)	Sagem Manual
 Berlingo 1 (96-02)	SERVICE LIGHT RES	1.1 8v 44kw HDZ (98-00)	Sagem Manual
 Berlingo 1 (96-02)	SERVICE LIGHT RES	1.1 8v 44kw HFX (98-00)	Sagem Manual
 Berlingo 1 (96-02)	SERVICE LIGHT RES	1.4 8v 55kw KFW (98-00)	Sagem Manual
 Berlingo 1 (96-02)	SERVICE LIGHT RES	1.4 8v 55kw KFX - GPL (98-00)	Sagem Manual
 Berlingo 1 (96-02)	SERVICE LIGHT RES	1.4 8v 55kw KFX (98-00)	Sagem Manual
 Berlingo 1 (96-02)	SERVICE LIGHT RES	1.8 D 8v 44kw A9A (98-00)	Sagem Manual
 Berlingo 1 (96-02)	SERVICE LIGHT RES	1.9 D 8v 50kw D9B (98-00)	Sagem Manual
 Berlingo 1 (96-02)	SERVICE LIGHT RES	1.9 D 8v 50kw DJY (98-00)	Sagem Manual
 Berlingo 1 (96-02)	SERVICE LIGHT RES	1.9 D 8v 52kw WJY (98-00)	Sagem Manual
 Berlingo 1 (96-02)	SERVICE LIGHT RES	1.9 D 8v 52kw WJZ (98-00)	Sagem Manual
 Berlingo 1 (96-02)	SERVICE LIGHT RES	2.0 HDI 8v 66kw RHY (98-00)	Sagem Manual
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.1 8v 44kw HFX	BOSCH ABS 8.0 no ESP AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.1 8v 44kw HFX	BOSCH ABS 8.1 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.1 8v 44kw HFX	BOSCH ABS/ESP 5.7
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.1 8v 44kw HFX	BOSCH ESP 5.7 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.1 8v 44kw HFX	BOSCH ESP 8.0 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.1 8v 44kw HFX	BOSCH ESP 8.1 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.4 8v 55kw KFW	BOSCH ABS 8.0 no ESP AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.4 8v 55kw KFW	BOSCH ABS 8.1 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.4 8v 55kw KFW	BOSCH ESP 5.7 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.4 8v 55kw KFW	BOSCH ESP 8.0 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.4 8v 55kw KFW	BOSCH ESP 8.1 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.4 8v 55kw KFW - GPL	BOSCH ABS 8.0 no ESP AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.4 8v 55kw KFW - GPL	BOSCH ABS 8.1 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.4 8v 55kw KFW - GPL	BOSCH ABS/ESP 5.7
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.4 8v 55kw KFW - GPL	BOSCH ABS8.0 no ESP AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.4 8v 55kw KFW - GPL	BOSCH ESP 5.7 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.4 8v 55kw KFW - GPL	BOSCH ESP 8.0 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.4 8v 55kw KFW - GPL	BOSCH ESP 8.1 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.4 8v 55kw KFW	BOSCH ABS 8.0 no ESP AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.4 8v 55kw KFW	BOSCH ABS 8.1 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.4 8v 55kw KFW	BOSCH ABS/ESP 5.7
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.4 8v 55kw KFW	BOSCH ESP 5.7 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.4 8v 55kw KFW	BOSCH ESP 8.0 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.4 8v 55kw KFW	BOSCH ESP 8.1 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.4 8v 55kw KFW - GNV	BOSCH ABS 8.1 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.4 8v 55kw KFW - GNV	BOSCH ABS/ESP 5.7
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.4 8v 55kw KFW - GNV	BOSCH ABS8.0 no ESP AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.4 8v 55kw KFW - GNV	BOSCH ESP 5.7 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.4 8v 55kw KFW - GNV	BOSCH ESP 8.0 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.4 8v 55kw KFW - GNV	BOSCH ESP 8.1 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.6 16v 82kw N6A	BOSCH ABS 8.0 no ESP AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.6 16v 82kw N6A	BOSCH ABS 8.1 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.6 16v 82kw N6A	BOSCH ESP 5.7 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.6 16v 82kw N6A	BOSCH ESP 8.0 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.6 16v 82kw N6A	BOSCH ESP 8.1 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.6 16v 82kw NFU	BOSCH ABS 8.0 no ESP AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.6 16v 82kw NFU	BOSCH ABS 8.1 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.6 16v 82kw NFU	BOSCH ABS/ESP 5.7
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.6 16v 82kw NFU	BOSCH ESP 5.7 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.6 16v 82kw NFU	BOSCH ESP 8.0 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.6 16v 82kw NFU	BOSCH ESP 8.1 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.6 HDI 16v 55kw 9HW	BOSCH ABS 8.0 no ESP AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.6 HDI 16v 55kw 9HW	BOSCH ABS 8.1 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.6 HDI 16v 55kw 9HW	BOSCH ABS/ESP 5.7
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.6 HDI 16v 55kw 9HW	BOSCH ESP 5.7 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.6 HDI 16v 55kw 9HW	BOSCH ESP 8.0 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.6 HDI 16v 55kw 9HW	BOSCH ESP 8.1 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX	BOSCH ABS 8.0 no ESP AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX	BOSCH ABS 8.1 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX	BOSCH ABS/ESP 5.7
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX	BOSCH ESP 5.7 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX	BOSCH ESP 8.0 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX	BOSCH ESP 8.1 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.9 D 8v 50kw WJY	BOSCH ABS 8.0 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.9 D 8v 50kw WJY	BOSCH ABS BOSCH 8.1 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.9 D 8v 50kw WJY	BOSCH ABS/ESP 5.7
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.9 D 8v 50kw WJY	BOSCH ESP 5.7 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.9 D 8v 50kw WJY	BOSCH ESP 8.0 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	1.9 D 8v 50kw WJY	BOSCH ESP 8.1 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	2.0 HDI 8v 66kw RHY	BOSCH ABS 8.0 no ESP AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	2.0 HDI 8v 66kw RHY	BOSCH ABS 8.1 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	2.0 HDI 8v 66kw RHY	BOSCH ABS/ESP 5.7
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	2.0 HDI 8v 66kw RHY	BOSCH ESP 5.7 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	2.0 HDI 8v 66kw RHY	BOSCH ESP 8.0 AUTODETECT
 Berlingo 1 Restyling (02-08)	ABS + TRACT. CONT	2.0 HDI 8v 66kw RHY	BOSCH ESP 8.1 AUTODETECT
 Berlingo 1 Restyling (02-08)	AIRBAG	1.1 8v 44kw HFX	Temic AirBag CENTRAL AUTODETECT
 Berlingo 1 Restyling (02-08)	AIRBAG	1.4 8v 55kw KfV	Temic AirBag CENTRAL AUTODETECT
 Berlingo 1 Restyling (02-08)	AIRBAG	1.4 8v 55kw KfV - GPL	Temic AirBag CENTRAL AUTODETECT
 Berlingo 1 Restyling (02-08)	AIRBAG	1.4 8v 55kw KfV	Temic AirBag CENTRAL AUTODETECT
 Berlingo 1 Restyling (02-08)	AIRBAG	1.4 8v 55kw KfV - GNV	Temic AirBag CENTRAL AUTODETECT
 Berlingo 1 Restyling (02-08)	AIRBAG	1.6 16v 82kw N6A	Temic AirBag CENTRAL AUTODETECT
 Berlingo 1 Restyling (02-08)	AIRBAG	1.6 16v 82kw NFU	Temic AirBag CENTRAL AUTODETECT
 Berlingo 1 Restyling (02-08)	AIRBAG	1.6 HDI 16v 55kw 9HW	Temic AirBag CENTRAL AUTODETECT
 Berlingo 1 Restyling (02-08)	AIRBAG	1.6 HDI 16v 66kw 9HX	Temic AirBag CENTRAL AUTODETECT
 Berlingo 1 Restyling (02-08)	AIRBAG	1.9 D 8v 50kw WJY	Temic AirBag CENTRAL AUTODETECT
 Berlingo 1 Restyling (02-08)	AIRBAG	2.0 HDI 8v 66kw RHY	Temic AirBag CENTRAL AUTODETECT
 Berlingo 1 Restyling (02-08)	ANTITHEFT	1.1 8v 44kw HFX	Alarm PSA2 AUTODETECT
 Berlingo 1 Restyling (02-08)	ANTITHEFT	1.4 8v 55kw KfV	Alarm PSA2 AUTODETECT
 Berlingo 1 Restyling (02-08)	ANTITHEFT	1.4 8v 55kw KfV - GPL	Alarm PSA2 AUTODETECT
 Berlingo 1 Restyling (02-08)	ANTITHEFT	1.4 8v 55kw KfV	Alarm PSA2 AUTODETECT
 Berlingo 1 Restyling (02-08)	ANTITHEFT	1.4 8v 55kw KfV - GNV	Alarm PSA2 AUTODETECT
 Berlingo 1 Restyling (02-08)	ANTITHEFT	1.6 16v 82kw N6A	Alarm PSA2 AUTODETECT
 Berlingo 1 Restyling (02-08)	ANTITHEFT	1.6 16v 82kw NFU	Alarm PSA2 AUTODETECT
 Berlingo 1 Restyling (02-08)	ANTITHEFT	1.6 HDI 16v 55kw 9HW	Alarm PSA2 AUTODETECT
 Berlingo 1 Restyling (02-08)	ANTITHEFT	1.6 HDI 16v 66kw 9HX	Alarm PSA2 AUTODETECT
 Berlingo 1 Restyling (02-08)	ANTITHEFT	1.9 D 8v 50kw WJY	Alarm PSA2 AUTODETECT
 Berlingo 1 Restyling (02-08)	ANTITHEFT	2.0 HDI 8v 66kw RHY	Alarm PSA2 AUTODETECT
 Berlingo 1 Restyling (02-08)	CHASSIS NETWORK	1.1 8v 44kw HFX	Body Computer BSI AUTODETECT
 Berlingo 1 Restyling (02-08)	CHASSIS NETWORK	1.4 8v 55kw KfV	Body Computer BSI AUTODETECT
 Berlingo 1 Restyling (02-08)	CHASSIS NETWORK	1.4 8v 55kw KfV - GPL	Body Computer BSI AUTODETECT
 Berlingo 1 Restyling (02-08)	CHASSIS NETWORK	1.4 8v 55kw KfV	Body Computer BSI AUTODETECT
 Berlingo 1 Restyling (02-08)	CHASSIS NETWORK	1.4 8v 55kw KfV - GNV	Body Computer BSI AUTODETECT
 Berlingo 1 Restyling (02-08)	CHASSIS NETWORK	1.6 16v 82kw N6A	Body Computer BSI AUTODETECT
 Berlingo 1 Restyling (02-08)	CHASSIS NETWORK	1.6 16v 82kw NFU	Body Computer BSI AUTODETECT
 Berlingo 1 Restyling (02-08)	CHASSIS NETWORK	1.6 HDI 16v 55kw 9HW	Body Computer BSI AUTODETECT
 Berlingo 1 Restyling (02-08)	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	Body Computer BSI AUTODETECT
 Berlingo 1 Restyling (02-08)	CHASSIS NETWORK	1.9 D 8v 50kw WJY	Body Computer BSI AUTODETECT
 Berlingo 1 Restyling (02-08)	CHASSIS NETWORK	2.0 HDI 8v 66kw RHY	Body Computer BSI AUTODETECT
 Berlingo 1 Restyling (02-08)	DASHBOARD	1.1 8v 44kw HFX	AUTODETECT
 Berlingo 1 Restyling (02-08)	DASHBOARD	1.4 8v 55kw KfV	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo 1 Restyling (02-08)	DASHBOARD	1.4 8v 55kw KfV - GPL	AUTODETECT
 Berlingo 1 Restyling (02-08)	DASHBOARD	1.4 8v 55kw KfV	AUTODETECT
 Berlingo 1 Restyling (02-08)	DASHBOARD	1.4 8v 55kw KfV - GNV	AUTODETECT
 Berlingo 1 Restyling (02-08)	DASHBOARD	1.6 16v 82kw N6A	AUTODETECT
 Berlingo 1 Restyling (02-08)	DASHBOARD	1.6 16v 82kw NFU	AUTODETECT
 Berlingo 1 Restyling (02-08)	DASHBOARD	1.6 HDI 16v 55kw 9HW	AUTODETECT
 Berlingo 1 Restyling (02-08)	DASHBOARD	1.6 HDI 16v 66kw 9HX	AUTODETECT
 Berlingo 1 Restyling (02-08)	DASHBOARD	1.9 D 8v 50kw WJY	AUTODETECT
 Berlingo 1 Restyling (02-08)	DASHBOARD	2.0 HDI 8v 66kw RHY	AUTODETECT
 Berlingo 1 Restyling (02-08)	DIESEL MANAGEMEN	1.9 D 8v 50kw WJY	LUCAS DCN2 AUTODETECT
 Berlingo 1 Restyling (02-08)	ENGINE MANAGEME	1.1 8v 44kw HFX	JCAE SAX500 GNV AUTODETECT
 Berlingo 1 Restyling (02-08)	ENGINE MANAGEME	1.1 8v 44kw HFX	Marelli MM48P AUTODETECT
 Berlingo 1 Restyling (02-08)	ENGINE MANAGEME	1.4 8v 55kw KfV	SAGEM J34P AUTODETECT
 Berlingo 1 Restyling (02-08)	ENGINE MANAGEME	1.4 8v 55kw KfV	SAGEM S2000 PM1 AUTODETECT
 Berlingo 1 Restyling (02-08)	ENGINE MANAGEME	1.4 8v 55kw KfV	SAGEM S2000 PM2 AUTODETECT
 Berlingo 1 Restyling (02-08)	ENGINE MANAGEME	1.4 8v 55kw KfV - GPL	JCAE SAX500 GPL AUTODETECT
 Berlingo 1 Restyling (02-08)	ENGINE MANAGEME	1.4 8v 55kw KfV	SAGEM S2000
 Berlingo 1 Restyling (02-08)	ENGINE MANAGEME	1.4 8v 55kw KfV	SAGEM S2000 PM1 AUTODETECT
 Berlingo 1 Restyling (02-08)	ENGINE MANAGEME	1.4 8v 55kw KfV	SAGEM S2000 PM2 AUTODETECT
 Berlingo 1 Restyling (02-08)	ENGINE MANAGEME	1.4 8v 55kw KfV - GNV	EOBD
 Berlingo 1 Restyling (02-08)	ENGINE MANAGEME	1.6 16v 82kw N6A	BOSCH ME 7.4.5 AUTODETECT
 Berlingo 1 Restyling (02-08)	ENGINE MANAGEME	1.6 16v 82kw NFU	BOSCH ME 7.4.4 AUTODETECT
 Berlingo 1 Restyling (02-08)	ENGINE MANAGEME	1.6 16v 82kw NFU	BOSCH ME 7.4.5 AUTODETECT
 Berlingo 1 Restyling (02-08)	ENGINE MANAGEME	1.6 16v 82kw NFU	BOSCH Motronic ME7.4.4
 Berlingo 1 Restyling (02-08)	ENGINE MANAGEME	1.6 HDI 16v 55kw 9HW	BOSCH EDC16 C34 Common Rail AUTOD
 Berlingo 1 Restyling (02-08)	ENGINE MANAGEME	1.6 HDI 16v 66kw 9HX	BOSCH EDC16 C34 Common Rail AUTOD
 Berlingo 1 Restyling (02-08)	ENGINE MANAGEME	2.0 HDI 8v 66kw RHY	BOSCH EDC 15 C2 Common Rail
 Berlingo 1 Restyling (02-08)	ENGINE MANAGEME	2.0 HDI 8v 66kw RHY	SIEMENS Diesel SID 801 Common Rail
 Berlingo 1 Restyling (02-08)	ENGINE MANAGEME	2.0 HDI 8v 66kw RHY	SIEMENS SID 801 Common rail AUTODET
 Berlingo 1 Restyling (02-08)	KEY ENCODE	1.1 8v 44kw HFX	VALEO Body Siemens
 Berlingo 1 Restyling (02-08)	KEY ENCODE	1.4 8v 55kw KfV - GPL	VALEO Body Siemens
 Berlingo 1 Restyling (02-08)	KEY ENCODE	1.4 8v 55kw KfV	VALEO Body Siemens
 Berlingo 1 Restyling (02-08)	KEY ENCODE	1.4 8v 55kw KfV - GNV	VALEO Body Siemens
 Berlingo 1 Restyling (02-08)	KEY ENCODE	1.6 16v 82kw NFU	VALEO Body Siemens
 Berlingo 1 Restyling (02-08)	KEY ENCODE	1.6 HDI 16v 55kw 9HW	VALEO Body Siemens
 Berlingo 1 Restyling (02-08)	KEY ENCODE	1.6 HDI 16v 66kw 9HX	VALEO Body Siemens
 Berlingo 1 Restyling (02-08)	KEY ENCODE	1.9 D 8v 50kw WJY	VALEO Body Siemens
 Berlingo 1 Restyling (02-08)	KEY ENCODE	2.0 HDI 8v 66kw RHY	VALEO Body Siemens
 Berlingo 1 Restyling (02-08)	MAINTENANCE	1.1 8v 44kw HFX	BOSCH ABS 8.0 no ESP AUTODETECT
 Berlingo 1 Restyling (02-08)	MAINTENANCE	1.1 8v 44kw HFX	BOSCH ABS 8.0 no ESP AUTODETECT
 Berlingo 1 Restyling (02-08)	MAINTENANCE	1.1 8v 44kw HFX	BOSCH ABS 8.1 AUTODETECT
 Berlingo 1 Restyling (02-08)	MAINTENANCE	1.1 8v 44kw HFX	BOSCH ABS/ESP 5.7
 Berlingo 1 Restyling (02-08)	MAINTENANCE	1.1 8v 44kw HFX	BOSCH ABS/ESP 5.7
 Berlingo 1 Restyling (02-08)	MAINTENANCE	1.1 8v 44kw HFX	BOSCH ABS/ESP 5.7
 Berlingo 1 Restyling (02-08)	MAINTENANCE	1.1 8v 44kw HFX	BOSCH ABS/ESP 5.7
 Berlingo 1 Restyling (02-08)	MAINTENANCE	1.1 8v 44kw HFX	BOSCH ABS/ESP 5.7
 Berlingo 1 Restyling (02-08)	MAINTENANCE	1.1 8v 44kw HFX	BOSCH ESP 5.7 AUTODETECT
 Berlingo 1 Restyling (02-08)	MAINTENANCE	1.1 8v 44kw HFX	BOSCH ESP 5.7 AUTODETECT
 Berlingo 1 Restyling (02-08)	MAINTENANCE	1.1 8v 44kw HFX	BOSCH ESP 8.1 AUTODETECT
 Berlingo 1 Restyling (02-08)	MAINTENANCE	1.1 8v 44kw HFX	BOSCH ESP 8.1 AUTODETECT
 Berlingo 1 Restyling (02-08)	MAINTENANCE	1.4 8v 55kw KfV	BOSCH ABS 8.0 no ESP AUTODETECT
 Berlingo 1 Restyling (02-08)	MAINTENANCE	1.4 8v 55kw KfV	BOSCH ABS 8.0 no ESP AUTODETECT
 Berlingo 1 Restyling (02-08)	MAINTENANCE	1.4 8v 55kw KfV	BOSCH ABS 8.1 AUTODETECT
 Berlingo 1 Restyling (02-08)	MAINTENANCE	1.4 8v 55kw KfV	BOSCH ESP 5.7 AUTODETECT
 Berlingo 1 Restyling (02-08)	MAINTENANCE	1.4 8v 55kw KfV	BOSCH ESP 5.7 AUTODETECT
 Berlingo 1 Restyling (02-08)	MAINTENANCE	1.4 8v 55kw KfV	BOSCH ESP 8.1 AUTODETECT
 Berlingo 1 Restyling (02-08)	MAINTENANCE	1.4 8v 55kw KfV	BOSCH ESP 8.1 AUTODETECT
 Berlingo 1 Restyling (02-08)	MAINTENANCE	1.4 8v 55kw KfV - GPL	BOSCH ABS 8.0 no ESP AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

[illegible]

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

[illegible]

Systems supported by ECUREADER / ECUDECODER (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo 1 Restyling (02-08)	MAINTENANCE	2.0 HDI 8v 66kw RHY	BOSCH ESP 5.7 AUTODETECT
 Berlingo 1 Restyling (02-08)	MAINTENANCE	2.0 HDI 8v 66kw RHY	BOSCH ESP 8.1 AUTODETECT
 Berlingo 1 Restyling (02-08)	MAINTENANCE	2.0 HDI 8v 66kw RHY	BOSCH ESP 8.1 AUTODETECT
 Berlingo 1 Restyling (02-08)	PARKING HELP	1.1 8v 44kw HFX	AUTODETECT
 Berlingo 1 Restyling (02-08)	PARKING HELP	1.4 8v 55kw KFV	AUTODETECT
 Berlingo 1 Restyling (02-08)	PARKING HELP	1.4 8v 55kw KFV - GPL	AUTODETECT
 Berlingo 1 Restyling (02-08)	PARKING HELP	1.4 8v 55kw KFW	AUTODETECT
 Berlingo 1 Restyling (02-08)	PARKING HELP	1.4 8v 55kw KFW - GNV	AUTODETECT
 Berlingo 1 Restyling (02-08)	PARKING HELP	1.6 16v 82kw N6A	AUTODETECT
 Berlingo 1 Restyling (02-08)	PARKING HELP	1.6 16v 82kw NFU	AUTODETECT
 Berlingo 1 Restyling (02-08)	PARKING HELP	1.6 HDI 16v 55kw 9HW	AUTODETECT
 Berlingo 1 Restyling (02-08)	PARKING HELP	1.6 HDI 16v 66kw 9HX	AUTODETECT
 Berlingo 1 Restyling (02-08)	PARKING HELP	1.9 D 8v 50kw WJY	AUTODETECT
 Berlingo 1 Restyling (02-08)	PARKING HELP	2.0 HDI 8v 66kw RHY	AUTODETECT
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.1 8v 44kw HFX	AudioSystem AUTODETECT
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.1 8v 44kw HFX	CD Changer AUTODETECT
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.1 8v 44kw HFX	CLARION AudioSystem
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.1 8v 44kw HFX	PHILIPS AudioSystem
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.1 8v 44kw HFX	VDO AudioSystem
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.4 8v 55kw KFV	AudioSystem AUTODETECT
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.4 8v 55kw KFV	CD Changer AUTODETECT
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.4 8v 55kw KFV - GPL	AudioSystem AUTODETECT
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.4 8v 55kw KFV - GPL	CD Changer AUTODETECT
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.4 8v 55kw KFV - GPL	CLARION AudioSystem
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.4 8v 55kw KFV - GPL	PHILIPS AudioSystem
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.4 8v 55kw KFV - GPL	VDO AudioSystem
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.4 8v 55kw KFW	AudioSystem AUTODETECT
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.4 8v 55kw KFW	CD Changer AUTODETECT
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.4 8v 55kw KFW	CLARION AudioSystem
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.4 8v 55kw KFW	PHILIPS AudioSystem
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.4 8v 55kw KFW	VDO AudioSystem
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.4 8v 55kw KFW - GNV	AudioSystem AUTODETECT
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.4 8v 55kw KFW - GNV	CD Changer AUTODETECT
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.4 8v 55kw KFW - GNV	CLARION AudioSystem
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.4 8v 55kw KFW - GNV	PHILIPS AudioSystem
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.4 8v 55kw KFW - GNV	VDO AudioSystem
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.6 16v 82kw N6A	AudioSystem AUTODETECT
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.6 16v 82kw N6A	CD Changer AUTODETECT
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.6 16v 82kw NFU	AudioSystem AUTODETECT
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.6 16v 82kw NFU	CD Changer AUTODETECT
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.6 16v 82kw NFU	CLARION AudioSystem
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.6 16v 82kw NFU	PHILIPS AudioSystem
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.6 16v 82kw NFU	VDO AudioSystem
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.6 HDI 16v 55kw 9HW	AudioSystem AUTODETECT
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.6 HDI 16v 55kw 9HW	CD Changer AUTODETECT
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.6 HDI 16v 55kw 9HW	CLARION AudioSystem
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.6 HDI 16v 55kw 9HW	PHILIPS AudioSystem
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.6 HDI 16v 55kw 9HW	VDO AudioSystem
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.6 HDI 16v 66kw 9HX	AudioSystem AUTODETECT
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.6 HDI 16v 66kw 9HX	CD Changer AUTODETECT
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.6 HDI 16v 66kw 9HX	CLARION AudioSystem
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.6 HDI 16v 66kw 9HX	PHILIPS AudioSystem
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.6 HDI 16v 66kw 9HX	VDO AudioSystem
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.9 D 8v 50kw WJY	AudioSystem AUTODETECT
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.9 D 8v 50kw WJY	CD Changer AUTODETECT
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.9 D 8v 50kw WJY	CLARION AudioSystem
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.9 D 8v 50kw WJY	PHILIPS AudioSystem
 Berlingo 1 Restyling (02-08)	RADIO / CD	1.9 D 8v 50kw WJY	VDO AudioSystem

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo 1 Restyling (02-08)	RADIO / CD	2.0 HDI 8v 66kw RHY	AudioSystem AUTODETECT
 Berlingo 1 Restyling (02-08)	RADIO / CD	2.0 HDI 8v 66kw RHY	Cd Changer AUTODETECT
 Berlingo 1 Restyling (02-08)	RADIO / CD	2.0 HDI 8v 66kw RHY	CLARION AudioSystem
 Berlingo 1 Restyling (02-08)	RADIO / CD	2.0 HDI 8v 66kw RHY	PHILIPS AudioSystem
 Berlingo 1 Restyling (02-08)	RADIO / CD	2.0 HDI 8v 66kw RHY	VDO AudioSystem
 Berlingo 1 Restyling (02-08)	RAIN-LUMINOSITY S	1.1 8v 44kw HFX	AUTODETECT
 Berlingo 1 Restyling (02-08)	RAIN-LUMINOSITY S	1.4 8v 55kw KfV	AUTODETECT
 Berlingo 1 Restyling (02-08)	RAIN-LUMINOSITY S	1.4 8v 55kw KfV - GPL	AUTODETECT
 Berlingo 1 Restyling (02-08)	RAIN-LUMINOSITY S	1.4 8v 55kw KfW	AUTODETECT
 Berlingo 1 Restyling (02-08)	RAIN-LUMINOSITY S	1.4 8v 55kw KfW - GNV	AUTODETECT
 Berlingo 1 Restyling (02-08)	RAIN-LUMINOSITY S	1.6 16v 82kw N6A	AUTODETECT
 Berlingo 1 Restyling (02-08)	RAIN-LUMINOSITY S	1.6 16v 82kw NFU	AUTODETECT
 Berlingo 1 Restyling (02-08)	RAIN-LUMINOSITY S	1.6 HDI 16v 55kw 9HW	AUTODETECT
 Berlingo 1 Restyling (02-08)	RAIN-LUMINOSITY S	1.6 HDI 16v 66kw 9HX	AUTODETECT
 Berlingo 1 Restyling (02-08)	RAIN-LUMINOSITY S	1.9 D 8v 50kw WJY	AUTODETECT
 Berlingo 1 Restyling (02-08)	RAIN-LUMINOSITY S	2.0 HDI 8v 66kw RHY	AUTODETECT
 Berlingo 1 Restyling (02-08)	STEERING COLUMN	1.1 8v 44kw HFX	AUTODETECT
 Berlingo 1 Restyling (02-08)	STEERING COLUMN	1.4 8v 55kw KfV	AUTODETECT
 Berlingo 1 Restyling (02-08)	STEERING COLUMN	1.4 8v 55kw KfV - GPL	AUTODETECT
 Berlingo 1 Restyling (02-08)	STEERING COLUMN	1.4 8v 55kw KfW	AUTODETECT
 Berlingo 1 Restyling (02-08)	STEERING COLUMN	1.4 8v 55kw KfW - GNV	AUTODETECT
 Berlingo 1 Restyling (02-08)	STEERING COLUMN	1.6 16v 82kw N6A	AUTODETECT
 Berlingo 1 Restyling (02-08)	STEERING COLUMN	1.6 16v 82kw NFU	AUTODETECT
 Berlingo 1 Restyling (02-08)	STEERING COLUMN	1.6 HDI 16v 55kw 9HW	AUTODETECT
 Berlingo 1 Restyling (02-08)	STEERING COLUMN	1.6 HDI 16v 66kw 9HX	AUTODETECT
 Berlingo 1 Restyling (02-08)	STEERING COLUMN	1.9 D 8v 50kw WJY	AUTODETECT
 Berlingo 1 Restyling (02-08)	STEERING COLUMN	2.0 HDI 8v 66kw RHY	AUTODETECT
 Berlingo 1 Restyling (02-08)	VISUAL./TELEMATIC	1.1 8v 44kw HFX	AUTODETECT
 Berlingo 1 Restyling (02-08)	VISUAL./TELEMATIC	1.1 8v 44kw HFX	Display AUTODETECT
 Berlingo 1 Restyling (02-08)	VISUAL./TELEMATIC	1.1 8v 44kw HFX	SAGEM JCAE
 Berlingo 1 Restyling (02-08)	VISUAL./TELEMATIC	1.4 8v 55kw KfV	AUTODETECT
 Berlingo 1 Restyling (02-08)	VISUAL./TELEMATIC	1.4 8v 55kw KfV	Display AUTODETECT
 Berlingo 1 Restyling (02-08)	VISUAL./TELEMATIC	1.4 8v 55kw KfV - GPL	AUTODETECT
 Berlingo 1 Restyling (02-08)	VISUAL./TELEMATIC	1.4 8v 55kw KfV - GPL	Display AUTODETECT
 Berlingo 1 Restyling (02-08)	VISUAL./TELEMATIC	1.4 8v 55kw KfV - GPL	SAGEM JCAE
 Berlingo 1 Restyling (02-08)	VISUAL./TELEMATIC	1.4 8v 55kw KfW	AUTODETECT
 Berlingo 1 Restyling (02-08)	VISUAL./TELEMATIC	1.4 8v 55kw KfW	Display AUTODETECT
 Berlingo 1 Restyling (02-08)	VISUAL./TELEMATIC	1.4 8v 55kw KfW	SAGEM JCAE
 Berlingo 1 Restyling (02-08)	VISUAL./TELEMATIC	1.4 8v 55kw KfW - GNV	AUTODETECT
 Berlingo 1 Restyling (02-08)	VISUAL./TELEMATIC	1.4 8v 55kw KfW - GNV	Display AUTODETECT
 Berlingo 1 Restyling (02-08)	VISUAL./TELEMATIC	1.4 8v 55kw KfW - GNV	SAGEM JCAE
 Berlingo 1 Restyling (02-08)	VISUAL./TELEMATIC	1.6 16v 82kw N6A	AUTODETECT
 Berlingo 1 Restyling (02-08)	VISUAL./TELEMATIC	1.6 16v 82kw N6A	Display AUTODETECT
 Berlingo 1 Restyling (02-08)	VISUAL./TELEMATIC	1.6 16v 82kw NFU	AUTODETECT
 Berlingo 1 Restyling (02-08)	VISUAL./TELEMATIC	1.6 16v 82kw NFU	Display AUTODETECT
 Berlingo 1 Restyling (02-08)	VISUAL./TELEMATIC	1.6 16v 82kw NFU	SAGEM JCAE
 Berlingo 1 Restyling (02-08)	VISUAL./TELEMATIC	1.6 HDI 16v 55kw 9HW	AUTODETECT
 Berlingo 1 Restyling (02-08)	VISUAL./TELEMATIC	1.6 HDI 16v 55kw 9HW	Display AUTODETECT
 Berlingo 1 Restyling (02-08)	VISUAL./TELEMATIC	1.6 HDI 16v 55kw 9HW	SAGEM JCAE
 Berlingo 1 Restyling (02-08)	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HX	AUTODETECT
 Berlingo 1 Restyling (02-08)	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HX	Display AUTODETECT
 Berlingo 1 Restyling (02-08)	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HX	SAGEM JCAE
 Berlingo 1 Restyling (02-08)	VISUAL./TELEMATIC	1.9 D 8v 50kw WJY	AUTODETECT
 Berlingo 1 Restyling (02-08)	VISUAL./TELEMATIC	1.9 D 8v 50kw WJY	Display AUTODETECT
 Berlingo 1 Restyling (02-08)	VISUAL./TELEMATIC	1.9 D 8v 50kw WJY	SAGEM JCAE
 Berlingo 1 Restyling (02-08)	VISUAL./TELEMATIC	2.0 HDI 8v 66kw RHY	AUTODETECT
 Berlingo 1 Restyling (02-08)	VISUAL./TELEMATIC	2.0 HDI 8v 66kw RHY	Display AUTODETECT
 Berlingo 1 Restyling (02-08)	VISUAL./TELEMATIC	2.0 HDI 8v 66kw RHY	SAGEM JCAE

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo 2 (08-..)	ABS	1.6 16v 66kw NFR	BOSCH ABS 8.1
 Berlingo 2 (08-..)	ABS	1.6 16v 80kw NFU	BOSCH ABS 8.1
 Berlingo 2 (08-..)	ABS	1.6 16v 80kw NFU - ETH	BOSCH ABS 8.1
 Berlingo 2 (08-..)	ABS	1.6 HDI 16v 55kw 9HT	BOSCH ABS 8.1
 Berlingo 2 (08-..)	ABS	1.6 HDI 16v 66kw 9HS-FAP	BOSCH ABS 8.1
 Berlingo 2 (08-..)	ABS	1.6 HDI 16v 66kw 9HV-FAP	BOSCH ABS 8.1
 Berlingo 2 (08-..)	ABS	1.6 HDI 16v 66kw 9HX	BOSCH ABS 8.1
 Berlingo 2 (08-..)	ABS	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ABS 8.1
 Berlingo 2 (08-..)	ABS + TRACT. CONT	1.6 16v 66kw NFR	BOSCH ABS 8.1 AUTODETECT
 Berlingo 2 (08-..)	ABS + TRACT. CONT	1.6 16v 66kw NFR	BOSCH ESP 8.1 AUTODETECT
 Berlingo 2 (08-..)	ABS + TRACT. CONT	1.6 16v 80kw NFU	BOSCH ABS 8.1 AUTODETECT
 Berlingo 2 (08-..)	ABS + TRACT. CONT	1.6 16v 80kw NFU	BOSCH ESP 8.1 AUTODETECT
 Berlingo 2 (08-..)	ABS + TRACT. CONT	1.6 16v 80kw NFU - ETH	BOSCH ABS 8.1 AUTODETECT
 Berlingo 2 (08-..)	ABS + TRACT. CONT	1.6 16v 80kw NFU - ETH	BOSCH ESP 8.1 AUTODETECT
 Berlingo 2 (08-..)	ABS + TRACT. CONT	1.6 HDI 16v 55kw 9HT	BOSCH ABS 8.1 AUTODETECT
 Berlingo 2 (08-..)	ABS + TRACT. CONT	1.6 HDI 16v 55kw 9HT	BOSCH ESP 8.1 AUTODETECT
 Berlingo 2 (08-..)	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HS-FAP	BOSCH ABS 8.1 AUTODETECT
 Berlingo 2 (08-..)	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HS-FAP	BOSCH ESP 8.1 AUTODETECT
 Berlingo 2 (08-..)	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HV-FAP	BOSCH ABS 8.1 AUTODETECT
 Berlingo 2 (08-..)	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HV-FAP	BOSCH ESP 8.1 AUTODETECT
 Berlingo 2 (08-..)	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX	BOSCH ABS 8.1 AUTODETECT
 Berlingo 2 (08-..)	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX	BOSCH ESP 8.1 AUTODETECT
 Berlingo 2 (08-..)	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ABS 8.1 AUTODETECT
 Berlingo 2 (08-..)	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ESP 8.1 AUTODETECT
 Berlingo 2 (08-..)	AIRBAG	1.6 16v 66kw NFR	AirBag CENTRAL AUTODETECT
 Berlingo 2 (08-..)	AIRBAG	1.6 16v 66kw NFR	Autoliv AirBag
 Berlingo 2 (08-..)	AIRBAG	1.6 16v 80kw NFU	AirBag CENTRAL AUTODETECT
 Berlingo 2 (08-..)	AIRBAG	1.6 16v 80kw NFU	Autoliv AirBag
 Berlingo 2 (08-..)	AIRBAG	1.6 16v 80kw NFU - ETH	AirBag CENTRAL AUTODETECT
 Berlingo 2 (08-..)	AIRBAG	1.6 16v 80kw NFU - ETH	Autoliv AirBag
 Berlingo 2 (08-..)	AIRBAG	1.6 HDI 16v 55kw 9HT	AirBag CENTRAL AUTODETECT
 Berlingo 2 (08-..)	AIRBAG	1.6 HDI 16v 55kw 9HT	Autoliv AirBag
 Berlingo 2 (08-..)	AIRBAG	1.6 HDI 16v 66kw 9HS-FAP	AirBag CENTRAL AUTODETECT
 Berlingo 2 (08-..)	AIRBAG	1.6 HDI 16v 66kw 9HS-FAP	Autoliv AirBag
 Berlingo 2 (08-..)	AIRBAG	1.6 HDI 16v 66kw 9HV-FAP	AirBag CENTRAL AUTODETECT
 Berlingo 2 (08-..)	AIRBAG	1.6 HDI 16v 66kw 9HV-FAP	Autoliv AirBag
 Berlingo 2 (08-..)	AIRBAG	1.6 HDI 16v 66kw 9HX	AirBag CENTRAL AUTODETECT
 Berlingo 2 (08-..)	AIRBAG	1.6 HDI 16v 66kw 9HX	Autoliv AirBag
 Berlingo 2 (08-..)	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL AUTODETECT
 Berlingo 2 (08-..)	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP	Autoliv AirBag
 Berlingo 2 (08-..)	ANTITHEFT	1.6 16v 66kw NFR	Alarm PSA2 AUTODETECT
 Berlingo 2 (08-..)	ANTITHEFT	1.6 16v 80kw NFU	Alarm PSA2 AUTODETECT
 Berlingo 2 (08-..)	ANTITHEFT	1.6 16v 80kw NFU - ETH	Alarm PSA2 AUTODETECT
 Berlingo 2 (08-..)	ANTITHEFT	1.6 HDI 16v 55kw 9HT	Alarm PSA2 AUTODETECT
 Berlingo 2 (08-..)	ANTITHEFT	1.6 HDI 16v 66kw 9HS-FAP	Alarm PSA2 AUTODETECT
 Berlingo 2 (08-..)	ANTITHEFT	1.6 HDI 16v 66kw 9HV-FAP	Alarm PSA2 AUTODETECT
 Berlingo 2 (08-..)	ANTITHEFT	1.6 HDI 16v 66kw 9HX	Alarm PSA2 AUTODETECT
 Berlingo 2 (08-..)	ANTITHEFT	1.6 HDI 16v 80kw 9HZ-FAP	Alarm PSA2 AUTODETECT
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 16v 66kw NFR	Body Computer BSI AUTODETECT
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 16v 66kw NFR	Body Computer BSM AUTODETECT
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 16v 66kw NFR	Body Computer BSR AUTODETECT
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 16v 66kw NFR	Body Computer Chassis AUTODETECT
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 16v 66kw NFR	DELPHI BSM
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 16v 66kw NFR	JCAE BSI 5.20
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 16v 80kw NFU	Body Computer BSI AUTODETECT
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 16v 80kw NFU	Body Computer BSM AUTODETECT
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 16v 80kw NFU	Body Computer BSR AUTODETECT
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 16v 80kw NFU	Body Computer chassis AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 16v 80kw NFU	DELPHI BSM
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 16v 80kw NFU	JCAE BSI 5.20
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 16v 80kw NFU - ETH	Body Computer BSI AUTODETECT
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 16v 80kw NFU - ETH	Body Computer BSM AUTODETECT
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 16v 80kw NFU - ETH	Body Computer BSR AUTODETECT
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 16v 80kw NFU - ETH	Body Computer chassis AUTODETECT
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 16v 80kw NFU - ETH	DELPHI BSM
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 16v 80kw NFU - ETH	JCAE BSI 5.20
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 55kw 9HT	Body Computer BSI AUTODETECT
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 55kw 9HT	Body Computer BSM AUTODETECT
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 55kw 9HT	Body Computer BSR AUTODETECT
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 55kw 9HT	Body Computer Chassis AUTODETECT
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 55kw 9HT	DELPHI BSM
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 55kw 9HT	JCAE BSI 5.20
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HS-FAP	Body Computer BSI AUTODETECT
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HS-FAP	Body Computer BSM AUTODETECT
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HS-FAP	Body Computer BSR AUTODETECT
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HS-FAP	Body Computer Chassis AUTODETECT
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HS-FAP	DELPHI BSM
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HS-FAP	JCAE BSI 5.20
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HV-FAP	Body Computer BSI AUTODETECT
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HV-FAP	Body Computer BSM AUTODETECT
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HV-FAP	Body Computer BSR AUTODETECT
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HV-FAP	Body Computer Chassis AUTODETECT
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HV-FAP	DELPHI BSM
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HV-FAP	JCAE BSI 5.20
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	Body Computer BSI AUTODETECT
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	Body Computer BSM AUTODETECT
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	Body Computer BSR AUTODETECT
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	Body Computer chassis AUTODETECT
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	DELPHI BSM
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	JCAE BSI 5.20
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSI AUTODETECT
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSM AUTODETECT
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSR AUTODETECT
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer Chassis AUTODETECT
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	DELPHI BSM
 Berlingo 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	JCAE BSI 5.20
 Berlingo 2 (08-..)	CLIMA	1.6 16v 66kw NFR	CLIMA AUTODETECT
 Berlingo 2 (08-..)	CLIMA	1.6 16v 80kw NFU	CLIMA AUTODETECT
 Berlingo 2 (08-..)	CLIMA	1.6 16v 80kw NFU - ETH	CLIMA AUTODETECT
 Berlingo 2 (08-..)	CLIMA	1.6 HDI 16v 55kw 9HT	CLIMA AUTODETECT
 Berlingo 2 (08-..)	CLIMA	1.6 HDI 16v 66kw 9HS-FAP	CLIMA AUTODETECT
 Berlingo 2 (08-..)	CLIMA	1.6 HDI 16v 66kw 9HV-FAP	CLIMA AUTODETECT
 Berlingo 2 (08-..)	CLIMA	1.6 HDI 16v 66kw 9HX	CLIMA AUTODETECT
 Berlingo 2 (08-..)	CLIMA	1.6 HDI 16v 80kw 9HZ-FAP	CLIMA AUTODETECT
 Berlingo 2 (08-..)	DASHBOARD	1.6 16v 66kw NFR	AUTODETECT
 Berlingo 2 (08-..)	DASHBOARD	1.6 16v 66kw NFR	Marelli
 Berlingo 2 (08-..)	DASHBOARD	1.6 16v 80kw NFU	AUTODETECT
 Berlingo 2 (08-..)	DASHBOARD	1.6 16v 80kw NFU	Marelli
 Berlingo 2 (08-..)	DASHBOARD	1.6 16v 80kw NFU - ETH	AUTODETECT
 Berlingo 2 (08-..)	DASHBOARD	1.6 16v 80kw NFU - ETH	Marelli
 Berlingo 2 (08-..)	DASHBOARD	1.6 HDI 16v 55kw 9HT	AUTODETECT
 Berlingo 2 (08-..)	DASHBOARD	1.6 HDI 16v 55kw 9HT	Marelli
 Berlingo 2 (08-..)	DASHBOARD	1.6 HDI 16v 66kw 9HS-FAP	AUTODETECT
 Berlingo 2 (08-..)	DASHBOARD	1.6 HDI 16v 66kw 9HS-FAP	Marelli
 Berlingo 2 (08-..)	DASHBOARD	1.6 HDI 16v 66kw 9HV-FAP	AUTODETECT
 Berlingo 2 (08-..)	DASHBOARD	1.6 HDI 16v 66kw 9HV-FAP	Marelli

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo 2 (08-..)	DASHBOARD	1.6 HDI 16v 66kw 9HX	AUTODETECT
 Berlingo 2 (08-..)	DASHBOARD	1.6 HDI 16v 66kw 9HX	Marelli
 Berlingo 2 (08-..)	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 Berlingo 2 (08-..)	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP	Marelli
 Berlingo 2 (08-..)	DIESEL ADDITION	1.6 HDI 16v 66kw 9HS-FAP	AUTODETECT
 Berlingo 2 (08-..)	DIESEL ADDITION	1.6 HDI 16v 66kw 9HV-FAP	AUTODETECT
 Berlingo 2 (08-..)	DIESEL ADDITION	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 Berlingo 2 (08-..)	ELECTRIC STEERING	1.6 16v 66kw NFR	AUTODETECT
 Berlingo 2 (08-..)	ELECTRIC STEERING	1.6 16v 80kw NFU	AUTODETECT
 Berlingo 2 (08-..)	ELECTRIC STEERING	1.6 16v 80kw NFU - ETH	AUTODETECT
 Berlingo 2 (08-..)	ELECTRIC STEERING	1.6 HDI 16v 55kw 9HT	AUTODETECT
 Berlingo 2 (08-..)	ELECTRIC STEERING	1.6 HDI 16v 66kw 9HS-FAP	AUTODETECT
 Berlingo 2 (08-..)	ELECTRIC STEERING	1.6 HDI 16v 66kw 9HV-FAP	AUTODETECT
 Berlingo 2 (08-..)	ELECTRIC STEERING	1.6 HDI 16v 66kw 9HX	AUTODETECT
 Berlingo 2 (08-..)	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 Berlingo 2 (08-..)	ENGINE MANAGEME	1.6 16v 66kw NFR	BOSCH ME 7.4.5 AUTODETECT
 Berlingo 2 (08-..)	ENGINE MANAGEME	1.6 16v 66kw NFR	BOSCH Motronic ME 7.4.5
 Berlingo 2 (08-..)	ENGINE MANAGEME	1.6 16v 80kw NFU	BOSCH ME 7.4.5 AUTODETECT
 Berlingo 2 (08-..)	ENGINE MANAGEME	1.6 16v 80kw NFU - ETH	EOBD
 Berlingo 2 (08-..)	ENGINE MANAGEME	1.6 HDI 16v 55kw 9HT	BOSCH EDC16 C34 Common Rail AUTOD
 Berlingo 2 (08-..)	ENGINE MANAGEME	1.6 HDI 16v 66kw 9HS-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 Berlingo 2 (08-..)	ENGINE MANAGEME	1.6 HDI 16v 66kw 9HV-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 Berlingo 2 (08-..)	ENGINE MANAGEME	1.6 HDI 16v 66kw 9HX	BOSCH EDC16 C34 Common Rail AUTOD
 Berlingo 2 (08-..)	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 Berlingo 2 (08-..)	MAINTENANCE	1.6 16v 66kw NFR	BOSCH ESP 8.1 AUTODETECT
 Berlingo 2 (08-..)	MAINTENANCE	1.6 16v 66kw NFR	BOSCH ESP 8.1 AUTODETECT
 Berlingo 2 (08-..)	MAINTENANCE	1.6 16v 66kw NFR	MANUAL
 Berlingo 2 (08-..)	MAINTENANCE	1.6 16v 66kw NFR	Marelli
 Berlingo 2 (08-..)	MAINTENANCE	1.6 16v 66kw NFR	Siemens-JCAE AUTODETECT
 Berlingo 2 (08-..)	MAINTENANCE	1.6 16v 66kw NFR	Siemens-JCAE AUTODETECT
 Berlingo 2 (08-..)	MAINTENANCE	1.6 16v 66kw NFR	Siemens-JCAE AUTODETECT
 Berlingo 2 (08-..)	MAINTENANCE	1.6 16v 66kw NFR	Siemens-JCAE AUTODETECT
 Berlingo 2 (08-..)	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ESP 8.1 AUTODETECT
 Berlingo 2 (08-..)	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ESP 8.1 AUTODETECT
 Berlingo 2 (08-..)	MAINTENANCE	1.6 16v 80kw NFU	MANUAL
 Berlingo 2 (08-..)	MAINTENANCE	1.6 16v 80kw NFU	Marelli
 Berlingo 2 (08-..)	MAINTENANCE	1.6 16v 80kw NFU	Siemens-JCAE AUTODETECT
 Berlingo 2 (08-..)	MAINTENANCE	1.6 16v 80kw NFU	Siemens-JCAE AUTODETECT
 Berlingo 2 (08-..)	MAINTENANCE	1.6 16v 80kw NFU	Siemens-JCAE AUTODETECT
 Berlingo 2 (08-..)	MAINTENANCE	1.6 16v 80kw NFU	Siemens-JCAE AUTODETECT
 Berlingo 2 (08-..)	MAINTENANCE	1.6 16v 80kw NFU - ETH	BOSCH ESP 8.1 AUTODETECT
 Berlingo 2 (08-..)	MAINTENANCE	1.6 16v 80kw NFU - ETH	BOSCH ESP 8.1 AUTODETECT
 Berlingo 2 (08-..)	MAINTENANCE	1.6 16v 80kw NFU - ETH	MANUAL
 Berlingo 2 (08-..)	MAINTENANCE	1.6 16v 80kw NFU - ETH	Marelli
 Berlingo 2 (08-..)	MAINTENANCE	1.6 16v 80kw NFU - ETH	Siemens-JCAE AUTODETECT
 Berlingo 2 (08-..)	MAINTENANCE	1.6 16v 80kw NFU - ETH	Siemens-JCAE AUTODETECT
 Berlingo 2 (08-..)	MAINTENANCE	1.6 16v 80kw NFU - ETH	Siemens-JCAE AUTODETECT
 Berlingo 2 (08-..)	MAINTENANCE	1.6 16v 80kw NFU - ETH	Siemens-JCAE AUTODETECT
 Berlingo 2 (08-..)	MAINTENANCE	1.6 HDI 16v 55kw 9HT	BOSCH EDC16 C34 Common Rail AUTOD
 Berlingo 2 (08-..)	MAINTENANCE	1.6 HDI 16v 55kw 9HT	BOSCH EDC16 C34 Common Rail AUTOD
 Berlingo 2 (08-..)	MAINTENANCE	1.6 HDI 16v 55kw 9HT	BOSCH EDC16 C34 Common Rail AUTOD
 Berlingo 2 (08-..)	MAINTENANCE	1.6 HDI 16v 55kw 9HT	BOSCH EDC16 C34 Common Rail AUTOD
 Berlingo 2 (08-..)	MAINTENANCE	1.6 HDI 16v 55kw 9HT	BOSCH EDC16 C34 Common Rail AUTOD
 Berlingo 2 (08-..)	MAINTENANCE	1.6 HDI 16v 55kw 9HT	BOSCH ESP 8.1 AUTODETECT
 Berlingo 2 (08-..)	MAINTENANCE	1.6 HDI 16v 55kw 9HT	BOSCH ESP 8.1 AUTODETECT
 Berlingo 2 (08-..)	MAINTENANCE	1.6 HDI 16v 55kw 9HT	MANUAL
 Berlingo 2 (08-..)	MAINTENANCE	1.6 HDI 16v 55kw 9HT	Marelli

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

[illegible]

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo 2 (08-..)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Marelli
 Berlingo 2 (08-..)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Siemens-JCAE AUTODETECT
 Berlingo 2 (08-..)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Siemens-JCAE AUTODETECT
 Berlingo 2 (08-..)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Siemens-JCAE AUTODETECT
 Berlingo 2 (08-..)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Siemens-JCAE AUTODETECT
 Berlingo 2 (08-..)	NAVIGATION	1.6 16v 66kw NFR	AUTODETECT
 Berlingo 2 (08-..)	NAVIGATION	1.6 16v 80kw NFU	AUTODETECT
 Berlingo 2 (08-..)	NAVIGATION	1.6 16v 80kw NFU - ETH	AUTODETECT
 Berlingo 2 (08-..)	NAVIGATION	1.6 HDI 16v 55kw 9HT	AUTODETECT
 Berlingo 2 (08-..)	NAVIGATION	1.6 HDI 16v 66kw 9HS-FAP	AUTODETECT
 Berlingo 2 (08-..)	NAVIGATION	1.6 HDI 16v 66kw 9HV-FAP	AUTODETECT
 Berlingo 2 (08-..)	NAVIGATION	1.6 HDI 16v 66kw 9HX	AUTODETECT
 Berlingo 2 (08-..)	NAVIGATION	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 Berlingo 2 (08-..)	PARKING HELP	1.6 16v 66kw NFR	AUTODETECT
 Berlingo 2 (08-..)	PARKING HELP	1.6 16v 80kw NFU	AUTODETECT
 Berlingo 2 (08-..)	PARKING HELP	1.6 16v 80kw NFU - ETH	AUTODETECT
 Berlingo 2 (08-..)	PARKING HELP	1.6 HDI 16v 55kw 9HT	AUTODETECT
 Berlingo 2 (08-..)	PARKING HELP	1.6 HDI 16v 66kw 9HS-FAP	AUTODETECT
 Berlingo 2 (08-..)	PARKING HELP	1.6 HDI 16v 66kw 9HV-FAP	AUTODETECT
 Berlingo 2 (08-..)	PARKING HELP	1.6 HDI 16v 66kw 9HX	AUTODETECT
 Berlingo 2 (08-..)	PARKING HELP	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 Berlingo 2 (08-..)	PHONE	1.6 16v 66kw NFR	AUTODETECT
 Berlingo 2 (08-..)	PHONE	1.6 16v 80kw NFU	AUTODETECT
 Berlingo 2 (08-..)	PHONE	1.6 16v 80kw NFU - ETH	AUTODETECT
 Berlingo 2 (08-..)	PHONE	1.6 HDI 16v 55kw 9HT	AUTODETECT
 Berlingo 2 (08-..)	PHONE	1.6 HDI 16v 66kw 9HS-FAP	AUTODETECT
 Berlingo 2 (08-..)	PHONE	1.6 HDI 16v 66kw 9HV-FAP	AUTODETECT
 Berlingo 2 (08-..)	PHONE	1.6 HDI 16v 66kw 9HX	AUTODETECT
 Berlingo 2 (08-..)	PHONE	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 Berlingo 2 (08-..)	RADIO / CD	1.6 16v 66kw NFR	AudioSystem AUTODETECT
 Berlingo 2 (08-..)	RADIO / CD	1.6 16v 66kw NFR	CD Changer AUTODETECT
 Berlingo 2 (08-..)	RADIO / CD	1.6 16v 80kw NFU	AudioSystem AUTODETECT
 Berlingo 2 (08-..)	RADIO / CD	1.6 16v 80kw NFU	CD Changer AUTODETECT
 Berlingo 2 (08-..)	RADIO / CD	1.6 16v 80kw NFU - ETH	AudioSystem AUTODETECT
 Berlingo 2 (08-..)	RADIO / CD	1.6 16v 80kw NFU - ETH	CD Changer AUTODETECT
 Berlingo 2 (08-..)	RADIO / CD	1.6 HDI 16v 55kw 9HT	AudioSystem AUTODETECT
 Berlingo 2 (08-..)	RADIO / CD	1.6 HDI 16v 55kw 9HT	CD Changer AUTODETECT
 Berlingo 2 (08-..)	RADIO / CD	1.6 HDI 16v 66kw 9HS-FAP	AudioSystem AUTODETECT
 Berlingo 2 (08-..)	RADIO / CD	1.6 HDI 16v 66kw 9HS-FAP	CD Changer AUTODETECT
 Berlingo 2 (08-..)	RADIO / CD	1.6 HDI 16v 66kw 9HV-FAP	AudioSystem AUTODETECT
 Berlingo 2 (08-..)	RADIO / CD	1.6 HDI 16v 66kw 9HV-FAP	CD Changer AUTODETECT
 Berlingo 2 (08-..)	RADIO / CD	1.6 HDI 16v 66kw 9HX	AudioSystem AUTODETECT
 Berlingo 2 (08-..)	RADIO / CD	1.6 HDI 16v 66kw 9HX	CD Changer AUTODETECT
 Berlingo 2 (08-..)	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	AudioSystem AUTODETECT
 Berlingo 2 (08-..)	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	CD Changer AUTODETECT
 Berlingo 2 (08-..)	RAIN-LUMINOSITY S	1.6 16v 66kw NFR	AUTODETECT
 Berlingo 2 (08-..)	RAIN-LUMINOSITY S	1.6 16v 80kw NFU	AUTODETECT
 Berlingo 2 (08-..)	RAIN-LUMINOSITY S	1.6 16v 80kw NFU - ETH	AUTODETECT
 Berlingo 2 (08-..)	RAIN-LUMINOSITY S	1.6 HDI 16v 55kw 9HT	AUTODETECT
 Berlingo 2 (08-..)	RAIN-LUMINOSITY S	1.6 HDI 16v 66kw 9HS-FAP	AUTODETECT
 Berlingo 2 (08-..)	RAIN-LUMINOSITY S	1.6 HDI 16v 66kw 9HV-FAP	AUTODETECT
 Berlingo 2 (08-..)	RAIN-LUMINOSITY S	1.6 HDI 16v 66kw 9HX	AUTODETECT
 Berlingo 2 (08-..)	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 Berlingo 2 (08-..)	SERVICE LIGHT RES	1.6 16v 66kw NFR	MANUAL
 Berlingo 2 (08-..)	SERVICE LIGHT RES	1.6 16v 80kw NFU	MANUAL
 Berlingo 2 (08-..)	SERVICE LIGHT RES	1.6 16v 80kw NFU - ETH	MANUAL
 Berlingo 2 (08-..)	SERVICE LIGHT RES	1.6 HDI 16v 55kw 9HT	MANUAL
 Berlingo 2 (08-..)	SERVICE LIGHT RES	1.6 HDI 16v 66kw 9HS-FAP	MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo 2 (08-..)	SERVICE LIGHT RES	1.6 HDI 16v 66kw 9HV-FAP	MANUAL
 Berlingo 2 (08-..)	SERVICE LIGHT RES	1.6 HDI 16v 66kw 9HX	MANUAL
 Berlingo 2 (08-..)	SERVICE LIGHT RES	1.6 HDI 16v 80kw 9HZ-FAP	MANUAL
 Berlingo 2 (08-..)	STEERING COLUMN	1.6 16v 66kw NFR	AUTODETECT
 Berlingo 2 (08-..)	STEERING COLUMN	1.6 16v 80kw NFU	AUTODETECT
 Berlingo 2 (08-..)	STEERING COLUMN	1.6 16v 80kw NFU - ETH	AUTODETECT
 Berlingo 2 (08-..)	STEERING COLUMN	1.6 HDI 16v 55kw 9HT	AUTODETECT
 Berlingo 2 (08-..)	STEERING COLUMN	1.6 HDI 16v 66kw 9HS-FAP	AUTODETECT
 Berlingo 2 (08-..)	STEERING COLUMN	1.6 HDI 16v 66kw 9HV-FAP	AUTODETECT
 Berlingo 2 (08-..)	STEERING COLUMN	1.6 HDI 16v 66kw 9HX	AUTODETECT
 Berlingo 2 (08-..)	STEERING COLUMN	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 Berlingo 2 (08-..)	SWITCHLIGHT MODU	1.6 16v 66kw NFR	DELPHI
 Berlingo 2 (08-..)	SWITCHLIGHT MODU	1.6 16v 80kw NFU	DELPHI
 Berlingo 2 (08-..)	SWITCHLIGHT MODU	1.6 16v 80kw NFU - ETH	DELPHI
 Berlingo 2 (08-..)	SWITCHLIGHT MODU	1.6 HDI 16v 55kw 9HT	DELPHI
 Berlingo 2 (08-..)	SWITCHLIGHT MODU	1.6 HDI 16v 66kw 9HS-FAP	DELPHI
 Berlingo 2 (08-..)	SWITCHLIGHT MODU	1.6 HDI 16v 66kw 9HV-FAP	DELPHI
 Berlingo 2 (08-..)	SWITCHLIGHT MODU	1.6 HDI 16v 66kw 9HX	DELPHI
 Berlingo 2 (08-..)	SWITCHLIGHT MODU	1.6 HDI 16v 80kw 9HZ-FAP	DELPHI
 Berlingo 2 (08-..)	TIRE PRESSURE	1.6 16v 66kw NFR	Siemens-JCAE AUTODETECT
 Berlingo 2 (08-..)	TIRE PRESSURE	1.6 16v 80kw NFU	Siemens-JCAE AUTODETECT
 Berlingo 2 (08-..)	TIRE PRESSURE	1.6 16v 80kw NFU - ETH	Siemens-JCAE AUTODETECT
 Berlingo 2 (08-..)	TIRE PRESSURE	1.6 HDI 16v 55kw 9HT	Siemens-JCAE AUTODETECT
 Berlingo 2 (08-..)	TIRE PRESSURE	1.6 HDI 16v 66kw 9HS-FAP	Siemens-JCAE AUTODETECT
 Berlingo 2 (08-..)	TIRE PRESSURE	1.6 HDI 16v 66kw 9HV-FAP	Siemens-JCAE AUTODETECT
 Berlingo 2 (08-..)	TIRE PRESSURE	1.6 HDI 16v 66kw 9HX	Siemens-JCAE AUTODETECT
 Berlingo 2 (08-..)	TIRE PRESSURE	1.6 HDI 16v 80kw 9HZ-FAP	Siemens-JCAE AUTODETECT
 Berlingo 2 (08-..)	VISUAL./TELEMATIC	1.6 16v 66kw NFR	Display A+ AUTODETECT
 Berlingo 2 (08-..)	VISUAL./TELEMATIC	1.6 16v 66kw NFR	Display C- AUTODETECT
 Berlingo 2 (08-..)	VISUAL./TELEMATIC	1.6 16v 80kw NFU	Display A+ AUTODETECT
 Berlingo 2 (08-..)	VISUAL./TELEMATIC	1.6 16v 80kw NFU	Display C- AUTODETECT
 Berlingo 2 (08-..)	VISUAL./TELEMATIC	1.6 16v 80kw NFU - ETH	Display A+ AUTODETECT
 Berlingo 2 (08-..)	VISUAL./TELEMATIC	1.6 16v 80kw NFU - ETH	Display C- AUTODETECT
 Berlingo 2 (08-..)	VISUAL./TELEMATIC	1.6 HDI 16v 55kw 9HT	Display A+ AUTODETECT
 Berlingo 2 (08-..)	VISUAL./TELEMATIC	1.6 HDI 16v 55kw 9HT	Display C- AUTODETECT
 Berlingo 2 (08-..)	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HS-FAP	Display A+ AUTODETECT
 Berlingo 2 (08-..)	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HS-FAP	Display C- AUTODETECT
 Berlingo 2 (08-..)	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HV-FAP	Display A+ AUTODETECT
 Berlingo 2 (08-..)	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HV-FAP	Display C- AUTODETECT
 Berlingo 2 (08-..)	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HX	Display A+ AUTODETECT
 Berlingo 2 (08-..)	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HX	Display C- AUTODETECT
 Berlingo 2 (08-..)	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	Display A+ AUTODETECT
 Berlingo 2 (08-..)	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	Display C- AUTODETECT
 BX	ELECTRONIC INJECT	1.4 8v 55kw KDY	BOSCH MonoJetronic A2.2 [Slow]
 BX	ELECTRONIC INJECT	1.4 8v 55kw KDZ	BOSCH MonoJetronic A2.2 [Slow]
 BX	ENGINE MANAGEME	1.6 8v 65kw BDY	Marelli MMBA G6 [Slow]
 BX	ENGINE MANAGEME	1.6 8v 65kw BDZ	Marelli MMBA G5 [Slow]
 BX	ENGINE MANAGEME	1.9 16v 109kw DFW	BOSCH Motronic M1.3 [Slow]
 BX	ENGINE MANAGEME	1.9 8v 88kw DKZ	BOSCH Motronic ML4.1 [Slow]
 BX	ENGINE MANAGEME	1.9 8v 90kw D6A	BOSCH Motronic ML4.1 [Slow]
 BX	ENGINE MANAGEME	1.9 8v 90kw D6D	BOSCH Motronic MP3.1 [Slow]
 Bx3	ABS + TRACT. CONT	1.6 66kw NFA	BOSCH ABS 8.1 AUTODETECT
 Bx3	ABS + TRACT. CONT	1.6 66kw NFA	BOSCH ESP 8.1 AUTODETECT
 Bx3	ABS + TRACT. CONT	2.0 103kw RFJ	BOSCH ABS 8.1 AUTODETECT
 Bx3	ABS + TRACT. CONT	2.0 103kw RFJ	BOSCH ESP 8.1 AUTODETECT
 Bx3	AIRBAG	1.6 66kw NFA	AirBag CENTRAL AUTODETECT
 Bx3	AIRBAG	2.0 103kw RFJ	AirBag CENTRAL AUTODETECT
 Bx3	ANTITHEFT	1.6 66kw NFA	Alarm PSA2 AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Bx3	ANTITHEFT	2.0 103kw RFJ	Alarm PSA2 AUTODETECT
 Bx3	AUTOM. TRANSMISSI	1.6 66kw NFA	A/T AL4 AUTODETECT
 Bx3	AUTOM. TRANSMISSI	2.0 103kw RFJ	A/T AL4 AUTODETECT
 Bx3	CHASSIS NETWORK	1.6 66kw NFA	Body Computer BSI AUTODETECT
 Bx3	CHASSIS NETWORK	1.6 66kw NFA	Body Computer BSM AUTODETECT
 Bx3	CHASSIS NETWORK	1.6 66kw NFA	Body Computer BSR AUTODETECT
 Bx3	CHASSIS NETWORK	2.0 103kw RFJ	Body Computer BSI AUTODETECT
 Bx3	CHASSIS NETWORK	2.0 103kw RFJ	Body Computer BSM AUTODETECT
 Bx3	CHASSIS NETWORK	2.0 103kw RFJ	Body Computer BSR AUTODETECT
 Bx3	CLIMA	1.6 66kw NFA	CLIMA AUTODETECT
 Bx3	CLIMA	2.0 103kw RFJ	CLIMA AUTODETECT
 Bx3	DASHBOARD	1.6 66kw NFA	AUTODETECT
 Bx3	DASHBOARD	2.0 103kw RFJ	AUTODETECT
 Bx3	DRIVER SEAT CONT	1.6 66kw NFA	AUTODETECT
 Bx3	DRIVER SEAT CONT	2.0 103kw RFJ	AUTODETECT
 Bx3	DRIVER SIDE DOOR	1.6 66kw NFA	AUTODETECT
 Bx3	DRIVER SIDE DOOR	2.0 103kw RFJ	AUTODETECT
 Bx3	ELECTRIC STEERING	1.6 66kw NFA	AUTODETECT
 Bx3	ELECTRIC STEERING	2.0 103kw RFJ	AUTODETECT
 Bx3	ENGINE MANAGEME	1.6 66kw NFA	BOSCH ME 7.4.5 AUTODETECT
 Bx3	ENGINE MANAGEME	2.0 103kw RFJ	Marelli MM6PLB AUTODETECT
 Bx3	MAINTENANCE	1.6 66kw NFA	A/T AL4 AUTODETECT
 Bx3	MAINTENANCE	1.6 66kw NFA	AirBag CENTRAL AUTODETECT
 Bx3	MAINTENANCE	1.6 66kw NFA	AirBag CENTRAL AUTODETECT
 Bx3	MAINTENANCE	1.6 66kw NFA	BOSCH ESP 8.1 AUTODETECT
 Bx3	MAINTENANCE	1.6 66kw NFA	BOSCH ESP 8.1 AUTODETECT
 Bx3	MAINTENANCE	2.0 103kw RFJ	A/T AL4 AUTODETECT
 Bx3	MAINTENANCE	2.0 103kw RFJ	AirBag CENTRAL AUTODETECT
 Bx3	MAINTENANCE	2.0 103kw RFJ	AirBag CENTRAL AUTODETECT
 Bx3	MAINTENANCE	2.0 103kw RFJ	BOSCH ESP 8.1 AUTODETECT
 Bx3	MAINTENANCE	2.0 103kw RFJ	BOSCH ESP 8.1 AUTODETECT
 Bx3	NAVIGATION	1.6 66kw NFA	AUTODETECT
 Bx3	NAVIGATION	2.0 103kw RFJ	AUTODETECT
 Bx3	PARKING HELP	1.6 66kw NFA	AUTODETECT
 Bx3	PARKING HELP	2.0 103kw RFJ	AUTODETECT
 Bx3	PASS. SIDE DOOR	1.6 66kw NFA	AUTODETECT
 Bx3	PASS. SIDE DOOR	2.0 103kw RFJ	AUTODETECT
 Bx3	PHONE	1.6 66kw NFA	AUTODETECT
 Bx3	PHONE	2.0 103kw RFJ	AUTODETECT
 Bx3	RADIO / CD	1.6 66kw NFA	AudioSystem AUTODETECT
 Bx3	RADIO / CD	1.6 66kw NFA	CD Changer AUTODETECT
 Bx3	RADIO / CD	2.0 103kw RFJ	AudioSystem AUTODETECT
 Bx3	RADIO / CD	2.0 103kw RFJ	CD Changer AUTODETECT
 Bx3	STEERING WHEEL E	1.6 66kw NFA	AUTODETECT
 Bx3	STEERING WHEEL E	2.0 103kw RFJ	AUTODETECT
 Bx3	VISUAL./TELEMATIC	1.6 66kw NFA	Display C- AUTODETECT
 Bx3	VISUAL./TELEMATIC	2.0 103kw RFJ	Display C- AUTODETECT
 C1	ABS	1.0 12V 50kw CFA	ABS 8.0 AUTODETECT
 C1	ABS	1.0 12V 50kw CFA	BOSCH ABS 8.0
 C1	ABS	1.4 HDI 8v 40kw 8HT	ABS 8.0 AUTODETECT
 C1	ABS	1.4 HDI 8v 40kw 8HT	BOSCH ABS 8.0
 C1	ABS + TRACT. CONT	1.0 12V 50kw CFA	ESP 8.0 AUTODETECT
 C1	ABS + TRACT. CONT	1.4 HDI 8v 40kw 8HT	ESP 8.0 AUTODETECT
 C1	AIRBAG	1.0 12V 50kw CFA	AirBag CENTRAL AUTODETECT
 C1	AIRBAG	1.0 12V 50kw CFA	TRW SAC
 C1	AIRBAG	1.4 HDI 8v 40kw 8HT	AirBag CENTRAL AUTODETECT
 C1	AIRBAG	1.4 HDI 8v 40kw 8HT	TRW SAC
 C1	ELECTRIC STEERING	1.0 12V 50kw CFA	AUTODETECT

Systems supported by ECUREADER / ECUDECODER (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C1	ELECTRIC STEERING	1.4 HDI 8v 40kw 8HT	AUTODETECT
 C1	ENGINE MANAGEME	1.0 12V 50kw CFA	BOSCH Motronic ME796
 C1	ENGINE MANAGEME	1.4 HDI 8v 40kw 8HT	SIEMENS SID 805 Common Rail AUTODE
 C1	IGNITION SWITCH	1.0 12V 50kw CFA	Ignition Key
 C1	IGNITION SWITCH	1.4 HDI 8v 40kw 8HT	Ignition Key
 C1	IMMOBILIZER	1.0 12V 50kw CFA	AUTODETECT
 C1	IMMOBILIZER	1.0 12V 50kw CFA	
 C1	IMMOBILIZER	1.4 HDI 8v 40kw 8HT	AUTODETECT
 C1	IMMOBILIZER	1.4 HDI 8v 40kw 8HT	
 C15	DIESEL MANAGEMEN	1.9 D 51kw WJY	LUCAS DCN2 AUTODETECT
 C15	DIESEL MANAGEMEN	1.9 D 51kw WJY	LUCAS Diesel DCN2
 C15	ELECTRONIC INJECT	1.1 44kw HDZ	BOSCH MonoJetronic A2.2 [Slow]
 C15	ELECTRONIC INJECT	1.4 55kw KDY	BOSCH MonoJetronic A2.2 [Slow]
 C2 China	ABS + TRACT. CONT	1.4 55kw KFV	TEVES ABS MK70 AUTODETECT
 C2 China	ABS + TRACT. CONT	1.6 16v 80kw NFU	TEVES ABS MK70 AUTODETECT
 C2 China	AIRBAG	1.4 55kw KFV	Temic AirBag CENTRAL AUTODETECT
 C2 China	AIRBAG	1.6 16v 80kw NFU	Temic AirBag CENTRAL AUTODETECT
 C2 China	AUTOM. TRANSMISSI	1.4 55kw KFV	A/T AL4 AUTODETECT
 C2 China	AUTOM. TRANSMISSI	1.6 16v 80kw NFU	A/T AL4 AUTODETECT
 C2 China	CHASSIS NETWORK	1.4 55kw KFV	Body Computer BSI AUTODETECT
 C2 China	CHASSIS NETWORK	1.6 16v 80kw NFU	Body Computer BSI AUTODETECT
 C2 China	CLIMA	1.4 55kw KFV	CLIMA AUTODETECT
 C2 China	CLIMA	1.6 16v 80kw NFU	CLIMA AUTODETECT
 C2 China	DASHBOARD	1.4 55kw KFV	AUTODETECT
 C2 China	DASHBOARD	1.6 16v 80kw NFU	AUTODETECT
 C2 China	ENGINE MANAGEME	1.4 55kw KFV	SAGEM J34P AUTODETECT
 C2 China	ENGINE MANAGEME	1.6 16v 80kw NFU	BOSCH ME 7.4.5 AUTODETECT
 C2 China	MAINTENANCE	1.4 55kw KFV	A/T AL4 AUTODETECT
 C2 China	MAINTENANCE	1.4 55kw KFV	Body Computer BSI AUTODETECT
 C2 China	MAINTENANCE	1.6 16v 80kw NFU	A/T AL4 AUTODETECT
 C2 China	MAINTENANCE	1.6 16v 80kw NFU	Body Computer BSI AUTODETECT
 C2 China	STEERING COLUMN	1.4 55kw KFV	AUTODETECT
 C2 China	STEERING COLUMN	1.6 16v 80kw NFU	AUTODETECT
 C2	ABS	1.1 8v 44kw HFX	TEVES ABS Mk60
 C2	ABS	1.1 8v 44kw HFX	TEVES ABS Mk70
 C2	ABS	1.4 16v 66kw KFU	TEVES ABS Mk60
 C2	ABS	1.4 16v 66kw KFU	TEVES ABS Mk70
 C2	ABS	1.4 8v 55kw KFV	TEVES ABS Mk60
 C2	ABS	1.4 8v 55kw KFV	TEVES ABS Mk70
 C2	ABS	1.4 HDI 8v 50kw 8HX	TEVES ABS Mk60
 C2	ABS	1.4 HDI 8v 50kw 8HX	TEVES ABS Mk70
 C2	ABS	1.4 HDI 8v 50kw 8HZ	TEVES ABS Mk70
 C2	ABS	1.6 16v 80kw NFU - ETH	TEVES ABS Mk60
 C2	ABS	1.6 16v 80kw NFU - ETH	TEVES ABS Mk70
 C2	ABS	1.6 16v 82kw NFU	TEVES ABS Mk60
 C2	ABS	1.6 16v 82kw NFU	TEVES ABS Mk70
 C2	ABS	1.6 16v 90kw VTS NFS	TEVES ABS Mk60
 C2	ABS	1.6 16v 90kw VTS NFS	TEVES ABS Mk70
 C2	ABS	1.6 HDI 16v 80kw 9HZ	TEVES ABS Mk60
 C2	ABS	1.6 HDI 16v 80kw 9HZ	TEVES ABS Mk70
 C2	ABS + TRACT. CONT	1.1 8v 44kw HFX	TEVES ABS MK70 AUTODETECT
 C2	ABS + TRACT. CONT	1.1 8v 44kw HFX	TEVES ABS MK70 New AUTODETECT
 C2	ABS + TRACT. CONT	1.1 8v 44kw HFX	TEVES ESP MK60 AUTODETECT
 C2	ABS + TRACT. CONT	1.1 8v 44kw HFX	TEVES ESP MK60 New AUTODETECT
 C2	ABS + TRACT. CONT	1.4 16v 66kw KFU	TEVES ABS MK70 AUTODETECT
 C2	ABS + TRACT. CONT	1.4 16v 66kw KFU	TEVES ABS MK70 New AUTODETECT
 C2	ABS + TRACT. CONT	1.4 16v 66kw KFU	TEVES ESP MK60 AUTODETECT
 C2	ABS + TRACT. CONT	1.4 16v 66kw KFU	TEVES ESP MK60 New AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C2	ABS + TRACT. CONT	1.4 8v 55kw KFV	TEVES ABS MK70 AUTODETECT
 C2	ABS + TRACT. CONT	1.4 8v 55kw KFV	TEVES ABS MK70 New AUTODETECT
 C2	ABS + TRACT. CONT	1.4 8v 55kw KFV	TEVES ESP MK60 AUTODETECT
 C2	ABS + TRACT. CONT	1.4 8v 55kw KFV	TEVES ESP MK60 New AUTODETECT
 C2	ABS + TRACT. CONT	1.4 HDI 8v 50kw 8HX	TEVES ABS MK70 AUTODETECT
 C2	ABS + TRACT. CONT	1.4 HDI 8v 50kw 8HX	TEVES ABS MK70 New AUTODETECT
 C2	ABS + TRACT. CONT	1.4 HDI 8v 50kw 8HX	TEVES ESP MK60 New AUTODETECT
 C2	ABS + TRACT. CONT	1.4 HDI 8v 50kw 8HX	TEVES ESP MK60 New AUTODETECT
 C2	ABS + TRACT. CONT	1.4 HDI 8v 50kw 8HZ	TEVES ABS MK70 AUTODETECT
 C2	ABS + TRACT. CONT	1.4 HDI 8v 50kw 8HZ	TEVES ABS MK70 New AUTODETECT
 C2	ABS + TRACT. CONT	1.4 HDI 8v 50kw 8HZ	TEVES ESP MK60 AUTODETECT
 C2	ABS + TRACT. CONT	1.4 HDI 8v 50kw 8HZ	TEVES ESP MK60 New AUTODETECT
 C2	ABS + TRACT. CONT	1.6 16v 80kw NFU - ETH	TEVES ABS MK70 AUTODETECT
 C2	ABS + TRACT. CONT	1.6 16v 80kw NFU - ETH	TEVES ABS MK70 New AUTODETECT
 C2	ABS + TRACT. CONT	1.6 16v 80kw NFU - ETH	TEVES ESP MK60 AUTODETECT
 C2	ABS + TRACT. CONT	1.6 16v 80kw NFU - ETH	TEVES ESP MK60 New AUTODETECT
 C2	ABS + TRACT. CONT	1.6 16v 82kw NFU	TEVES ABS MK70 AUTODETECT
 C2	ABS + TRACT. CONT	1.6 16v 82kw NFU	TEVES ABS MK70 New AUTODETECT
 C2	ABS + TRACT. CONT	1.6 16v 82kw NFU	TEVES ESP MK60 AUTODETECT
 C2	ABS + TRACT. CONT	1.6 16v 82kw NFU	TEVES ESP MK60 New AUTODETECT
 C2	ABS + TRACT. CONT	1.6 16v 90kw VTS NFS	TEVES ABS MK70 AUTODETECT
 C2	ABS + TRACT. CONT	1.6 16v 90kw VTS NFS	TEVES ABS MK70 New AUTODETECT
 C2	ABS + TRACT. CONT	1.6 16v 90kw VTS NFS	TEVES ESP MK60 AUTODETECT
 C2	ABS + TRACT. CONT	1.6 16v 90kw VTS NFS	TEVES ESP MK60 New AUTODETECT
 C2	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ	TEVES ABS MK70 AUTODETECT
 C2	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ	TEVES ABS MK70 New AUTODETECT
 C2	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ	TEVES ESP MK60 AUTODETECT
 C2	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ	TEVES ESP MK60 New AUTODETECT
 C2	AIRBAG	1.1 8v 44kw HFX	AirBag CENTRAL AUTODETECT
 C2	AIRBAG	1.1 8v 44kw HFX	TEMIC AirBag
 C2	AIRBAG	1.4 16v 66kw KFV	AirBag CENTRAL AUTODETECT
 C2	AIRBAG	1.4 8v 55kw KFV	AirBag CENTRAL AUTODETECT
 C2	AIRBAG	1.4 8v 55kw KFV	TEMIC AirBag
 C2	AIRBAG	1.4 HDI 8v 50kw 8HX	AirBag CENTRAL AUTODETECT
 C2	AIRBAG	1.4 HDI 8v 50kw 8HZ	AirBag CENTRAL AUTODETECT
 C2	AIRBAG	1.4 HDI 8v 50kw 8HZ	TEMIC AirBag
 C2	AIRBAG	1.6 16v 80kw NFU - ETH	AirBag CENTRAL AUTODETECT
 C2	AIRBAG	1.6 16v 80kw NFU - ETH	TEMIC AirBag
 C2	AIRBAG	1.6 16v 82kw NFU	AirBag CENTRAL AUTODETECT
 C2	AIRBAG	1.6 16v 82kw NFU	TEMIC AirBag
 C2	AIRBAG	1.6 16v 90kw VTS NFS	AirBag CENTRAL AUTODETECT
 C2	AIRBAG	1.6 HDI 16v 80kw 9HZ	AirBag CENTRAL AUTODETECT
 C2	ANTITHEFT	1.1 8v 44kw HFX	Alarm PSA2 AUTODETECT
 C2	ANTITHEFT	1.4 16v 66kw KFV	Alarm PSA2 AUTODETECT
 C2	ANTITHEFT	1.4 8v 55kw KFV	Alarm PSA2 AUTODETECT
 C2	ANTITHEFT	1.4 HDI 8v 50kw 8HX	Alarm PSA2 AUTODETECT
 C2	ANTITHEFT	1.4 HDI 8v 50kw 8HZ	Alarm PSA2 AUTODETECT
 C2	ANTITHEFT	1.6 16v 80kw NFU - ETH	Alarm PSA2 AUTODETECT
 C2	ANTITHEFT	1.6 16v 82kw NFU	Alarm PSA2 AUTODETECT
 C2	ANTITHEFT	1.6 16v 90kw VTS NFS	Alarm PSA2 AUTODETECT
 C2	ANTITHEFT	1.6 HDI 16v 80kw 9HZ	Alarm PSA2 AUTODETECT
 C2	AUTOM. TRANSMISSI	1.1 8v 44kw HFX	A/T Pilot Manual AUTODETECT
 C2	AUTOM. TRANSMISSI	1.4 16v 66kw KFV	A/T Manual Pilot AUTODETECT
 C2	AUTOM. TRANSMISSI	1.4 8v 55kw KFV	A/T Manual Pilot AUTODETECT
 C2	AUTOM. TRANSMISSI	1.4 HDI 8v 50kw 8HX	A/T Manual pilot AUTODETECT
 C2	AUTOM. TRANSMISSI	1.4 HDI 8v 50kw 8HZ	A/T Manual pilot AUTODETECT
 C2	AUTOM. TRANSMISSI	1.6 16v 80kw NFU - ETH	A/T Pilot manual AUTODETECT
 C2	AUTOM. TRANSMISSI	1.6 16v 82kw NFU	A/T Pilot manual AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C2	AUTOM. TRANSMISSI	1.6 16v 90kw VTS NFS	A/T Manual pilot AUTODETECT
 C2	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ	A/T Manual pilot AUTODETECT
 C2	CHASSIS NETWORK	1.1 8v 44kw HFX	Body Computer BSI AUTODETECT
 C2	CHASSIS NETWORK	1.1 8v 44kw HFX	Body Computer BSM AUTODETECT
 C2	CHASSIS NETWORK	1.1 8v 44kw HFX	Body Computer BSR AUTODETECT
 C2	CHASSIS NETWORK	1.1 8v 44kw HFX	High frequency receiver AUTODETECT
 C2	CHASSIS NETWORK	1.1 8v 44kw HFX	STOP/START System AUTODETECT
 C2	CHASSIS NETWORK	1.4 16v 66kw KFU	Body Computer BSI AUTODETECT
 C2	CHASSIS NETWORK	1.4 16v 66kw KFU	Body Computer BSM AUTODETECT
 C2	CHASSIS NETWORK	1.4 16v 66kw KFU	Body Computer BSR AUTODETECT
 C2	CHASSIS NETWORK	1.4 16v 66kw KFU	High frequency receiver AUTODETECT
 C2	CHASSIS NETWORK	1.4 16v 66kw KFU	STOP/START System AUTODETECT
 C2	CHASSIS NETWORK	1.4 8v 55kw KFV	Body Computer BSI AUTODETECT
 C2	CHASSIS NETWORK	1.4 8v 55kw KFV	Body Computer BSM AUTODETECT
 C2	CHASSIS NETWORK	1.4 8v 55kw KFV	Body Computer BSR AUTODETECT
 C2	CHASSIS NETWORK	1.4 8v 55kw KFV	High frequency receiver AUTODETECT
 C2	CHASSIS NETWORK	1.4 8v 55kw KFV	Stop/Start system AUTODETECT
 C2	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HX	Body Computer BSI AUTODETECT
 C2	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HX	Body Computer BSM AUTODETECT
 C2	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HX	Body Computer BSR AUTODETECT
 C2	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HX	High frequency receiver AUTODETECT
 C2	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HX	STOP/START System AUTODETECT
 C2	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HZ	Body Computer BSI AUTODETECT
 C2	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HZ	Body Computer BSM AUTODETECT
 C2	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HZ	Body Computer BSR AUTODETECT
 C2	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HZ	High frequency receiver AUTODETECT
 C2	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HZ	STOP/START System AUTODETECT
 C2	CHASSIS NETWORK	1.6 16v 80kw NFU - ETH	Body Computer BSI AUTODETECT
 C2	CHASSIS NETWORK	1.6 16v 80kw NFU - ETH	Body Computer BSM AUTODETECT
 C2	CHASSIS NETWORK	1.6 16v 80kw NFU - ETH	Body Computer BSR AUTODETECT
 C2	CHASSIS NETWORK	1.6 16v 80kw NFU - ETH	High frequency receiver AUTODETECT
 C2	CHASSIS NETWORK	1.6 16v 80kw NFU - ETH	STOP/START System AUTODETECT
 C2	CHASSIS NETWORK	1.6 16v 82kw NFU	Body Computer BSI AUTODETECT
 C2	CHASSIS NETWORK	1.6 16v 82kw NFU	Body Computer BSM AUTODETECT
 C2	CHASSIS NETWORK	1.6 16v 82kw NFU	Body Computer BSR AUTODETECT
 C2	CHASSIS NETWORK	1.6 16v 82kw NFU	High frequency receiver AUTODETECT
 C2	CHASSIS NETWORK	1.6 16v 82kw NFU	STOP/START System AUTODETECT
 C2	CHASSIS NETWORK	1.6 16v 90kw VTS NFS	Body Computer BSI AUTODETECT
 C2	CHASSIS NETWORK	1.6 16v 90kw VTS NFS	Body Computer BSM AUTODETECT
 C2	CHASSIS NETWORK	1.6 16v 90kw VTS NFS	Body Computer BSR AUTODETECT
 C2	CHASSIS NETWORK	1.6 16v 90kw VTS NFS	High frequency receiver AUTODETECT
 C2	CHASSIS NETWORK	1.6 16v 90kw VTS NFS	STOP/START system AUTODETECT
 C2	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ	Body Computer BSI AUTODETECT
 C2	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ	Body Computer BSM AUTODETECT
 C2	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ	Body Computer BSR AUTODETECT
 C2	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ	High frequency receiver AUTODETECT
 C2	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ	STOP/START System AUTODETECT
 C2	CLIMA	1.1 8v 44kw HFX	CLIMA AUTO AUTODETECT
 C2	CLIMA	1.1 8v 44kw HFX	CLIMA AUTODETECT
 C2	CLIMA	1.1 8v 44kw HFX	Klimautomatik x.x
 C2	CLIMA	1.4 16v 66kw KFU	CLIMA AUTO AUTODETECT
 C2	CLIMA	1.4 16v 66kw KFU	CLIMA AUTODETECT
 C2	CLIMA	1.4 8v 55kw KFV	CLIMA AUTO AUTODETECT
 C2	CLIMA	1.4 8v 55kw KFV	CLIMA AUTODETECT
 C2	CLIMA	1.4 8v 55kw KFV	Klimautomatik x.x
 C2	CLIMA	1.4 HDI 8v 50kw 8HX	CLIMA AUTO AUTODETECT
 C2	CLIMA	1.4 HDI 8v 50kw 8HX	CLIMA AUTODETECT
 C2	CLIMA	1.4 HDI 8v 50kw 8HX	Klimautomatik x.x

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C2	CLIMA	1.4 HDI 8v 50kw 8HZ	CLIMA AUTO AUTODETECT
 C2	CLIMA	1.4 HDI 8v 50kw 8HZ	CLIMA AUTODETECT
 C2	CLIMA	1.4 HDI 8v 50kw 8HZ	Klimautomatik x.x
 C2	CLIMA	1.6 16v 80kw NFU - ETH	CLIMA AUTO AUTODETECT
 C2	CLIMA	1.6 16v 80kw NFU - ETH	CLIMA AUTODETECT
 C2	CLIMA	1.6 16v 80kw NFU - ETH	Klimautomatik x.x
 C2	CLIMA	1.6 16v 82kw NFU	CLIMA AUTO AUTODETECT
 C2	CLIMA	1.6 16v 82kw NFU	CLIMA AUTODETECT
 C2	CLIMA	1.6 16v 82kw NFU	Klimautomatik x.x
 C2	CLIMA	1.6 16v 90kw VTS NFS	CLIMA AUTO AUTODETECT
 C2	CLIMA	1.6 16v 90kw VTS NFS	CLIMA AUTODETECT
 C2	CLIMA	1.6 16v 90kw VTS NFS	Klimautomatik x.x
 C2	CLIMA	1.6 HDI 16v 80kw 9HZ	CLIMA AUTO AUTODETECT
 C2	CLIMA	1.6 HDI 16v 80kw 9HZ	CLIMA AUTODETECT
 C2	CLIMA	1.6 HDI 16v 80kw 9HZ	Klimautomatik x.x
 C2	DASHBOARD	1.1 8v 44kw HFX	AUTODETECT
 C2	DASHBOARD	1.1 8v 44kw HFX	SAGEM Dashboard
 C2	DASHBOARD	1.4 16v 66kw KFV	AUTODETECT
 C2	DASHBOARD	1.4 8v 55kw KFV	AUTODETECT
 C2	DASHBOARD	1.4 8v 55kw KFV	SAGEM
 C2	DASHBOARD	1.4 HDI 8v 50kw 8HX	AUTODETECT
 C2	DASHBOARD	1.4 HDI 8v 50kw 8HZ	AUTODETECT
 C2	DASHBOARD	1.4 HDI 8v 50kw 8HZ	SAGEM Dashboard
 C2	DASHBOARD	1.6 16v 80kw NFU - ETH	AUTODETECT
 C2	DASHBOARD	1.6 16v 80kw NFU - ETH	SAGEM Dashboard
 C2	DASHBOARD	1.6 16v 82kw NFU	AUTODETECT
 C2	DASHBOARD	1.6 16v 82kw NFU	SAGEM Dashboard
 C2	DASHBOARD	1.6 16v 90kw VTS NFS	AUTODETECT
 C2	DASHBOARD	1.6 HDI 16v 80kw 9HZ	AUTODETECT
 C2	ELECTRIC STEERING	1.1 8v 44kw HFX	AUTODETECT
 C2	ELECTRIC STEERING	1.1 8v 44kw HFX	KOYO EPS
 C2	ELECTRIC STEERING	1.4 16v 66kw KFV	AUTODETECT
 C2	ELECTRIC STEERING	1.4 8v 55kw KFV	AUTODETECT
 C2	ELECTRIC STEERING	1.4 8v 55kw KFV	KOYO EPS
 C2	ELECTRIC STEERING	1.4 HDI 8v 50kw 8HX	AUTODETECT
 C2	ELECTRIC STEERING	1.4 HDI 8v 50kw 8HZ	AUTODETECT
 C2	ELECTRIC STEERING	1.4 HDI 8v 50kw 8HZ	KOYO EPS
 C2	ELECTRIC STEERING	1.6 16v 80kw NFU - ETH	AUTODETECT
 C2	ELECTRIC STEERING	1.6 16v 80kw NFU - ETH	KOYO EPS
 C2	ELECTRIC STEERING	1.6 16v 82kw NFU	AUTODETECT
 C2	ELECTRIC STEERING	1.6 16v 82kw NFU	KOYO EPS
 C2	ELECTRIC STEERING	1.6 16v 90kw VTS NFS	AUTODETECT
 C2	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ	AUTODETECT
 C2	ENGINE MANAGEME	1.1 8v 44kw HFX	Marelli 4.8P
 C2	ENGINE MANAGEME	1.1 8v 44kw HFX	Marelli MM 48P AUTODETECT
 C2	ENGINE MANAGEME	1.1 8v 44kw HFX	SAGEM J34P AUTODETECT
 C2	ENGINE MANAGEME	1.1 8v 44kw HFX (06-..)	SAGEM MPI J34P
 C2	ENGINE MANAGEME	1.4 16v 66kw KFV	Marelli MM6LP AUTODETECT
 C2	ENGINE MANAGEME	1.4 8v 55kw KFV	SAGEM J34P AUTODETECT
 C2	ENGINE MANAGEME	1.4 8v 55kw KFV	SAGEM S2000 PM1 AUTODETECT
 C2	ENGINE MANAGEME	1.4 8v 55kw KFV	SAGEM S2000 PM2 AUTODETECT
 C2	ENGINE MANAGEME	1.4 8v 55kw KFV	SAGEM S2000PM2
 C2	ENGINE MANAGEME	1.4 HDI 8v 50kw 8HX	BOSCH EDC16 C34 Common Rail AUTOD
 C2	ENGINE MANAGEME	1.4 HDI 8v 50kw 8HX	SIEMENS SID802 Common Rail AUTODET
 C2	ENGINE MANAGEME	1.4 HDI 8v 50kw 8HX	SIEMENS SID804 Common Rail AUTODET
 C2	ENGINE MANAGEME	1.4 HDI 8v 50kw 8HZ	BOSCH EDC 16 C3 Common Rail
 C2	ENGINE MANAGEME	1.4 HDI 8v 50kw 8HZ	BOSCH EDC16 C34 Common Rail AUTOD
 C2	ENGINE MANAGEME	1.4 HDI 8v 50kw 8HZ	SIEMENS Diesel SID 804 Common Rail

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C2	ENGINE MANAGEME	1.4 HDI 8v 50kw 8HZ	SIEMENS SID804 Common Rail AUTODET
 C2	ENGINE MANAGEME	1.4 HDI 8v 50kw 8HZ	SIEMENS SID806 Common Rail AUTODET
 C2	ENGINE MANAGEME	1.6 16v 80kw NFU - ETH	BOSCH ME 7.4.4 AUTODETECT
 C2	ENGINE MANAGEME	1.6 16v 80kw NFU - ETH	BOSCH ME 7.4.5 AUTODETECT
 C2	ENGINE MANAGEME	1.6 16v 80kw NFU - ETH	BOSCH Motronic ME7.4.4
 C2	ENGINE MANAGEME	1.6 16v 82kw NFU	BOSCH ME 7.4.4 AUTODETECT
 C2	ENGINE MANAGEME	1.6 16v 82kw NFU	BOSCH ME 7.4.5 AUTODETECT
 C2	ENGINE MANAGEME	1.6 16v 82kw NFU	BOSCH Motronic ME7.4.4
 C2	ENGINE MANAGEME	1.6 16v 90kw VTS NFS	BOSCH ME 7.4.4 AUTODETECT
 C2	ENGINE MANAGEME	1.6 16v 90kw VTS NFS	BOSCH ME 7.4.5 AUTODETECT
 C2	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ	BOSCH EDC16 C34 Common Rail AUTOD
 C2	KEY ENCODE	1.1 8v 44kw HFX	VALEO Body Siemens
 C2	KEY ENCODE	1.4 8v 55kw KFV	VALEO Body Siemens
 C2	KEY ENCODE	1.4 HDI 8v 50kw 8HZ	VALEO Body Siemens
 C2	KEY ENCODE	1.6 16v 80kw NFU - ETH	VALEO Body Siemens
 C2	KEY ENCODE	1.6 16v 82kw NFU	VALEO Body Siemens
 C2	MAINTENANCE	1.1 8v 44kw HFX	SAGEM Dashboard
 C2	MAINTENANCE	1.1 8v 44kw HFX	TEMIC AirBag
 C2	MAINTENANCE	1.1 8v 44kw HFX	TEVES ABS MK70 New AUTODETECT
 C2	MAINTENANCE	1.1 8v 44kw HFX	TEVES ESP MK60 AUTODETECT
 C2	MAINTENANCE	1.1 8v 44kw HFX	TEVES ESP MK60 AUTODETECT
 C2	MAINTENANCE	1.1 8v 44kw HFX	TEVES ESP MK60 New AUTODETECT
 C2	MAINTENANCE	1.1 8v 44kw HFX	TEVES ESP MK60 New AUTODETECT
 C2	MAINTENANCE	1.1 8v 44kw HFX	Valeo Body Computer MANUAL
 C2	MAINTENANCE	1.4 16v 66kw KFV	TEVES ABS MK70 New AUTODETECT
 C2	MAINTENANCE	1.4 16v 66kw KFV	TEVES ESP MK60 AUTODETECT
 C2	MAINTENANCE	1.4 16v 66kw KFV	TEVES ESP MK60 AUTODETECT
 C2	MAINTENANCE	1.4 16v 66kw KFV	TEVES ESP MK60 New AUTODETECT
 C2	MAINTENANCE	1.4 16v 66kw KFV	TEVES ESP MK60 New AUTODETECT
 C2	MAINTENANCE	1.4 8v 55kw KFV	SAGEM
 C2	MAINTENANCE	1.4 8v 55kw KFV	TEMIC AirBag
 C2	MAINTENANCE	1.4 8v 55kw KFV	TEVES ABS MK70 New AUTODETECT
 C2	MAINTENANCE	1.4 8v 55kw KFV	TEVES ESP MK60 AUTODETECT
 C2	MAINTENANCE	1.4 8v 55kw KFV	TEVES ESP MK60 AUTODETECT
 C2	MAINTENANCE	1.4 8v 55kw KFV	TEVES ESP MK60 New AUTODETECT
 C2	MAINTENANCE	1.4 8v 55kw KFV	TEVES ESP MK60 New AUTODETECT
 C2	MAINTENANCE	1.4 HDI 8v 50kw 8HX	Valeo Body Computer MANUAL
 C2	MAINTENANCE	1.4 HDI 8v 50kw 8HX	TEVES ABS MK70 New AUTODETECT
 C2	MAINTENANCE	1.4 HDI 8v 50kw 8HX	TEVES ESP MK60 New AUTODETECT
 C2	MAINTENANCE	1.4 HDI 8v 50kw 8HX	TEVES ESP MK60 New AUTODETECT
 C2	MAINTENANCE	1.4 HDI 8v 50kw 8HX	TEVES ESP MK60 New AUTODETECT
 C2	MAINTENANCE	1.4 HDI 8v 50kw 8HX	TEVES ESP MK60 New AUTODETECT
 C2	MAINTENANCE	1.4 HDI 8v 50kw 8HX	Valeo Body Computer MANUAL
 C2	MAINTENANCE	1.4 HDI 8v 50kw 8HZ	SAGEM Dashboard
 C2	MAINTENANCE	1.4 HDI 8v 50kw 8HZ	TEMIC AirBag
 C2	MAINTENANCE	1.4 HDI 8v 50kw 8HZ	TEVES ABS MK70 New AUTODETECT
 C2	MAINTENANCE	1.4 HDI 8v 50kw 8HZ	TEVES ESP MK60 AUTODETECT
 C2	MAINTENANCE	1.4 HDI 8v 50kw 8HZ	TEVES ESP MK60 AUTODETECT
 C2	MAINTENANCE	1.4 HDI 8v 50kw 8HZ	TEVES ESP MK60 New AUTODETECT
 C2	MAINTENANCE	1.4 HDI 8v 50kw 8HZ	TEVES ESP MK60 New AUTODETECT
 C2	MAINTENANCE	1.4 HDI 8v 50kw 8HZ	Valeo Body Computer MANUAL
 C2	MAINTENANCE	1.6 16v 80kw NFU - ETH	SAGEM Dashboard
 C2	MAINTENANCE	1.6 16v 80kw NFU - ETH	TEMIC AirBag
 C2	MAINTENANCE	1.6 16v 80kw NFU - ETH	TEVES ABS MK70 New AUTODETECT
 C2	MAINTENANCE	1.6 16v 80kw NFU - ETH	TEVES ESP MK60 AUTODETECT
 C2	MAINTENANCE	1.6 16v 80kw NFU - ETH	TEVES ESP MK60 AUTODETECT
 C2	MAINTENANCE	1.6 16v 80kw NFU - ETH	TEVES ESP MK60 New AUTODETECT
 C2	MAINTENANCE	1.6 16v 80kw NFU - ETH	TEVES ESP MK60 New AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C2	MAINTENANCE	1.6 16v 80kw NFU - ETH	Valeo Body Computer MANUAL
 C2	MAINTENANCE	1.6 16v 82kw NFU	SAGEM Dashboard
 C2	MAINTENANCE	1.6 16v 82kw NFU	TEMIC AirBag
 C2	MAINTENANCE	1.6 16v 82kw NFU	TEVES ABS MK70 New AUTODETECT
 C2	MAINTENANCE	1.6 16v 82kw NFU	TEVES ESP MK60 AUTODETECT
 C2	MAINTENANCE	1.6 16v 82kw NFU	TEVES ESP MK60 AUTODETECT
 C2	MAINTENANCE	1.6 16v 82kw NFU	TEVES ESP MK60 New AUTODETECT
 C2	MAINTENANCE	1.6 16v 82kw NFU	TEVES ESP MK60 New AUTODETECT
 C2	MAINTENANCE	1.6 16v 82kw NFU	Valeo Body Computer MANUAL
 C2	MAINTENANCE	1.6 16v 90kw VTS NFS	TEVES ABS MK70 New AUTODETECT
 C2	MAINTENANCE	1.6 16v 90kw VTS NFS	TEVES ESP MK60 AUTODETECT
 C2	MAINTENANCE	1.6 16v 90kw VTS NFS	TEVES ESP MK60 AUTODETECT
 C2	MAINTENANCE	1.6 16v 90kw VTS NFS	TEVES ESP MK60 New AUTODETECT
 C2	MAINTENANCE	1.6 16v 90kw VTS NFS	TEVES ESP MK60 New AUTODETECT
 C2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ	Valeo Body Computer MANUAL
 C2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ	BOSCH EDC16 C34 Common Rail AUTOD
 C2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ	BOSCH EDC16 C34 Common Rail AUTOD
 C2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ	BOSCH EDC16 C34 Common Rail AUTOD
 C2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ	BOSCH EDC16 C34 Common Rail AUTOD
 C2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ	BOSCH EDC16 C34 Common Rail AUTOD
 C2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ	TEVES ABS MK70 New AUTODETECT
 C2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ	TEVES ESP MK60 AUTODETECT
 C2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ	TEVES ESP MK60 AUTODETECT
 C2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ	TEVES ESP MK60 New AUTODETECT
 C2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ	TEVES ESP MK60 New AUTODETECT
 C2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ	Valeo Body Computer MANUAL
 C2	NAVIGATION	1.1 8v 44kw HFX	AUTODETECT
 C2	NAVIGATION	1.1 8v 44kw HFX	AUTODETECT
 C2	NAVIGATION	1.4 16v 66kw KFV	AUTODETECT
 C2	NAVIGATION	1.4 16v 66kw KFV	AUTODETECT
 C2	NAVIGATION	1.4 8v 55kw KFV	AUTODETECT
 C2	NAVIGATION	1.4 8v 55kw KFV	AUTODETECT
 C2	NAVIGATION	1.4 HDI 8v 50kw 8HX	AUTODETECT
 C2	NAVIGATION	1.4 HDI 8v 50kw 8HX	AUTODETECT
 C2	NAVIGATION	1.4 HDI 8v 50kw 8HZ	AUTODETECT
 C2	NAVIGATION	1.4 HDI 8v 50kw 8HZ	AUTODETECT
 C2	NAVIGATION	1.6 16v 80kw NFU - ETH	AUTODETECT
 C2	NAVIGATION	1.6 16v 80kw NFU - ETH	AUTODETECT
 C2	NAVIGATION	1.6 16v 82kw NFU	AUTODETECT
 C2	NAVIGATION	1.6 16v 82kw NFU	AUTODETECT
 C2	NAVIGATION	1.6 16v 90kw VTS NFS	AUTODETECT
 C2	NAVIGATION	1.6 16v 90kw VTS NFS	AUTODETECT
 C2	NAVIGATION	1.6 HDI 16v 80kw 9HZ	AUTODETECT
 C2	NAVIGATION	1.6 HDI 16v 80kw 9HZ	AUTODETECT
 C2	PARKING HELP	1.1 8v 44kw HFX	AUTODETECT
 C2	PARKING HELP	1.4 16v 66kw KFV	AUTODETECT
 C2	PARKING HELP	1.4 8v 55kw KFV	AUTODETECT
 C2	PARKING HELP	1.4 HDI 8v 50kw 8HX	AUTODETECT
 C2	PARKING HELP	1.4 HDI 8v 50kw 8HZ	AUTODETECT
 C2	PARKING HELP	1.6 16v 80kw NFU - ETH	AUTODETECT
 C2	PARKING HELP	1.6 16v 82kw NFU	AUTODETECT
 C2	PARKING HELP	1.6 16v 90kw VTS NFS	AUTODETECT
 C2	PARKING HELP	1.6 HDI 16v 80kw 9HZ	AUTODETECT
 C2	PHONE	1.1 8v 44kw HFX	KIT MAIN LIBRE AUTODETECT
 C2	PHONE	1.4 16v 66kw KFV	AUTODETECT
 C2	PHONE	1.4 8v 55kw KFV	AUTODETECT
 C2	PHONE	1.4 HDI 8v 50kw 8HX	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C2	PHONE	1.4 HDI 8v 50kw 8HZ	AUTODETECT
 C2	PHONE	1.6 16v 80kw NFU - ETH	AUTODETECT
 C2	PHONE	1.6 16v 82kw NFU	AUTODETECT
 C2	PHONE	1.6 16v 90kw VTS NFS	AUTODETECT
 C2	PHONE	1.6 HDI 16v 80kw 9HZ	AUTODETECT
 C2	RADIO / CD	1.1 8v 44kw HFX	AudioSystem AUTODETECT
 C2	RADIO / CD	1.1 8v 44kw HFX	CD Changer AUTODETECT
 C2	RADIO / CD	1.1 8v 44kw HFX	CLARION AudioSystem
 C2	RADIO / CD	1.1 8v 44kw HFX	PHILIPS AudioSystem
 C2	RADIO / CD	1.1 8v 44kw HFX	VDO AudioSystem
 C2	RADIO / CD	1.4 16v 66kw KFV	AudioSystem AUTODETECT
 C2	RADIO / CD	1.4 16v 66kw KFV	CD Changer AUTODETECT
 C2	RADIO / CD	1.4 8v 55kw KFV	AudioSystem AUTODETECT
 C2	RADIO / CD	1.4 8v 55kw KFV	CD Changer AUTODETECT
 C2	RADIO / CD	1.4 8v 55kw KFV	CLARION AudioSystem
 C2	RADIO / CD	1.4 8v 55kw KFV	PHILIPS AudioSystem
 C2	RADIO / CD	1.4 8v 55kw KFV	VDO AudioSystem
 C2	RADIO / CD	1.4 HDI 8v 50kw 8HX	AudioSystem AUTODETECT
 C2	RADIO / CD	1.4 HDI 8v 50kw 8HX	Cd Changer AUTODETECT
 C2	RADIO / CD	1.4 HDI 8v 50kw 8HZ	CD Changer AUTODETECT
 C2	RADIO / CD	1.4 HDI 8v 50kw 8HZ	CD Changer AUTODETECT
 C2	RADIO / CD	1.4 HDI 8v 50kw 8HZ	CLARION AudioSystem
 C2	RADIO / CD	1.4 HDI 8v 50kw 8HZ	PHILIPS AudioSystem
 C2	RADIO / CD	1.4 HDI 8v 50kw 8HZ	VDO AudioSystem
 C2	RADIO / CD	1.6 16v 80kw NFU - ETH	AudioSystem AUTODETECT
 C2	RADIO / CD	1.6 16v 80kw NFU - ETH	CD Changer AUTODETECT
 C2	RADIO / CD	1.6 16v 80kw NFU - ETH	CLARION AudioSystem
 C2	RADIO / CD	1.6 16v 80kw NFU - ETH	PHILIPS AudioSystem
 C2	RADIO / CD	1.6 16v 80kw NFU - ETH	VDO AudioSystem
 C2	RADIO / CD	1.6 16v 82kw NFU	AudioSystem AUTODETECT
 C2	RADIO / CD	1.6 16v 82kw NFU	CD Changer AUTODETECT
 C2	RADIO / CD	1.6 16v 82kw NFU	CLARION AudioSystem
 C2	RADIO / CD	1.6 16v 82kw NFU	PHILIPS AudioSystem
 C2	RADIO / CD	1.6 16v 82kw NFU	VDO AudioSystem
 C2	RADIO / CD	1.6 16v 90kw VTS NFS	AudioSystem AUTODETECT
 C2	RADIO / CD	1.6 16v 90kw VTS NFS	CD Changer AUTODETECT
 C2	RADIO / CD	1.6 HDI 16v 80kw 9HZ	AudioSystem AUTODETECT
 C2	RADIO / CD	1.6 HDI 16v 80kw 9HZ	CD Changer AUTODETECT
 C2	RAIN-LUMINOSITY S	1.1 8v 44kw HFX	AUTODETECT
 C2	RAIN-LUMINOSITY S	1.1 8v 44kw HFX	KOSTAL WSS
 C2	RAIN-LUMINOSITY S	1.4 16v 66kw KFV	AUTODETECT
 C2	RAIN-LUMINOSITY S	1.4 8v 55kw KFV	AUTODETECT
 C2	RAIN-LUMINOSITY S	1.4 8v 55kw KFV	KOSTAL WSS
 C2	RAIN-LUMINOSITY S	1.4 HDI 8v 50kw 8HX	AUTODETECT
 C2	RAIN-LUMINOSITY S	1.4 HDI 8v 50kw 8HZ	AUTODETECT
 C2	RAIN-LUMINOSITY S	1.4 HDI 8v 50kw 8HZ	KOSTAL WSS
 C2	RAIN-LUMINOSITY S	1.6 16v 80kw NFU - ETH	AUTODETECT
 C2	RAIN-LUMINOSITY S	1.6 16v 80kw NFU - ETH	KOSTAL WSS
 C2	RAIN-LUMINOSITY S	1.6 16v 82kw NFU	AUTODETECT
 C2	RAIN-LUMINOSITY S	1.6 16v 82kw NFU	KOSTAL WSS
 C2	RAIN-LUMINOSITY S	1.6 16v 90kw VTS NFS	AUTODETECT
 C2	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HZ	AUTODETECT
 C2	REMOTE CONTROL E	1.1 8v 44kw HFX	Valeo Body Computer MANUAL
 C2	REMOTE CONTROL E	1.4 8v 55kw KFV	Valeo Body Computer MANUAL
 C2	REMOTE CONTROL E	1.4 HDI 8v 50kw 8HX	Valeo Body Computer MANUAL
 C2	REMOTE CONTROL E	1.4 HDI 8v 50kw 8HZ	Valeo Body Computer MANUAL
 C2	REMOTE CONTROL E	1.6 16v 80kw NFU - ETH	Valeo Body Computer MANUAL
 C2	REMOTE CONTROL E	1.6 16v 82kw NFU	Valeo Body Computer MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C2	REMOTE CONTROL E	1.6 16v 90kw VTS NFS	Valeo Body Computer MANUAL
 C2	REMOTE CONTROL E	1.6 HDI 16v 80kw 9HZ	Valeo Body Computer MANUAL
 C2	STEERING COLUMN	1.1 8v 44kw HFX	AUTODETECT
 C2	STEERING COLUMN	1.4 16v 66kw KFU	AUTODETECT
 C2	STEERING COLUMN	1.4 8v 55kw KFU	AUTODETECT
 C2	STEERING COLUMN	1.4 HDI 8v 50kw 8HX	AUTODETECT
 C2	STEERING COLUMN	1.4 HDI 8v 50kw 8HZ	AUTODETECT
 C2	STEERING COLUMN	1.6 16v 80kw NFU - ETH	AUTODETECT
 C2	STEERING COLUMN	1.6 16v 82kw NFU	AUTODETECT
 C2	STEERING COLUMN	1.6 16v 90kw VTS NFS	AUTODETECT
 C2	STEERING COLUMN	1.6 HDI 16v 80kw 9HZ	AUTODETECT
 C2	SWITCHLIGHT MODU	1.1 8v 44kw HFX	EATON
 C2	SWITCHLIGHT MODU	1.4 HDI 8v 50kw 8HZ	EATON
 C2	SWITCHLIGHT MODU	1.6 16v 80kw NFU - ETH	EATON
 C2	SWITCHLIGHT MODU	1.6 16v 82kw NFU	EATON
 C2	VISUAL./TELEMATIC	1.1 8v 44kw HFX	AUTODETECT
 C2	VISUAL./TELEMATIC	1.1 8v 44kw HFX	Display A+ AUTODETECT
 C2	VISUAL./TELEMATIC	1.1 8v 44kw HFX	Display AUTODETECT
 C2	VISUAL./TELEMATIC	1.1 8v 44kw HFX	Display C- AUTODETECT
 C2	VISUAL./TELEMATIC	1.1 8v 44kw HFX	SAGEM JCAE
 C2	VISUAL./TELEMATIC	1.4 16v 66kw KFU	AUTODETECT
 C2	VISUAL./TELEMATIC	1.4 16v 66kw KFU	Display A+ AUTODETECT
 C2	VISUAL./TELEMATIC	1.4 16v 66kw KFU	Display AUTODETECT
 C2	VISUAL./TELEMATIC	1.4 16v 66kw KFU	Display C- AUTODETECT
 C2	VISUAL./TELEMATIC	1.4 8v 55kw KFU	AUTODETECT
 C2	VISUAL./TELEMATIC	1.4 8v 55kw KFU	Display A+ AUTODETECT
 C2	VISUAL./TELEMATIC	1.4 8v 55kw KFU	Display AUTODETECT
 C2	VISUAL./TELEMATIC	1.4 8v 55kw KFU	Display C- AUTODETECT
 C2	VISUAL./TELEMATIC	1.4 8v 55kw KFU	SAGEM JCAE
 C2	VISUAL./TELEMATIC	1.4 HDI 8v 50kw 8HX	AUTODETECT
 C2	VISUAL./TELEMATIC	1.4 HDI 8v 50kw 8HX	Display A+ AUTODETECT
 C2	VISUAL./TELEMATIC	1.4 HDI 8v 50kw 8HX	Display AUTODETECT
 C2	VISUAL./TELEMATIC	1.4 HDI 8v 50kw 8HX	Display C- AUTODETECT
 C2	VISUAL./TELEMATIC	1.4 HDI 8v 50kw 8HX	SAGEM
 C2	VISUAL./TELEMATIC	1.4 HDI 8v 50kw 8HX	SAGEM JCAE
 C2	VISUAL./TELEMATIC	1.4 HDI 8v 50kw 8HZ	AUTODETECT
 C2	VISUAL./TELEMATIC	1.4 HDI 8v 50kw 8HZ	Display A+ AUTODETECT
 C2	VISUAL./TELEMATIC	1.4 HDI 8v 50kw 8HZ	Display AUTODETECT
 C2	VISUAL./TELEMATIC	1.4 HDI 8v 50kw 8HZ	Display C- AUTODETECT
 C2	VISUAL./TELEMATIC	1.4 HDI 8v 50kw 8HZ	SAGEM JCAE
 C2	VISUAL./TELEMATIC	1.6 16v 80kw NFU - ETH	AUTODETECT
 C2	VISUAL./TELEMATIC	1.6 16v 80kw NFU - ETH	Display A+ AUTODETECT
 C2	VISUAL./TELEMATIC	1.6 16v 80kw NFU - ETH	Display AUTODETECT
 C2	VISUAL./TELEMATIC	1.6 16v 80kw NFU - ETH	Display C- AUTODETECT
 C2	VISUAL./TELEMATIC	1.6 16v 80kw NFU - ETH	SAGEM JCAE
 C2	VISUAL./TELEMATIC	1.6 16v 82kw NFU	AUTODETECT
 C2	VISUAL./TELEMATIC	1.6 16v 82kw NFU	Display A+ AUTODETECT
 C2	VISUAL./TELEMATIC	1.6 16v 82kw NFU	Display AUTODETECT
 C2	VISUAL./TELEMATIC	1.6 16v 82kw NFU	Display C- AUTODETECT
 C2	VISUAL./TELEMATIC	1.6 16v 82kw NFU	SAGEM JCAE
 C2	VISUAL./TELEMATIC	1.6 16v 90kw VTS NFS	AUTODETECT
 C2	VISUAL./TELEMATIC	1.6 16v 90kw VTS NFS	Display A+ AUTODETECT
 C2	VISUAL./TELEMATIC	1.6 16v 90kw VTS NFS	Display AUTODETECT
 C2	VISUAL./TELEMATIC	1.6 16v 90kw VTS NFS	Display C- AUTODETECT
 C2	VISUAL./TELEMATIC	1.6 16v 90kw VTS NFS	SAGEM JCAE
 C2	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ	AUTODETECT
 C2	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ	Display A+ AUTODETECT
 C2	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ	Display AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C2	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ	Display C- AUTODETECT
 C2	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ	SAGEM JCAE
 C3 1	ABS	1.1 8v 44kw HFX (02-08)	TEVES ABS Mk60
 C3 1	ABS	1.1 8v 44kw HFX (02-08)	TEVES ABS Mk70
 C3 1	ABS	1.1 8v 44kw HFX (06-..)	TRW ABS
 C3 1	ABS	1.4 16v 66kw KFV (06-..)	TRW ABS
 C3 1	ABS	1.4 8v 55kw KFV (06-..)	TRW ABS
 C3 1	ABS	1.4 HDI 16v 66kw 8HY (02-08)	TEVES ABS Mk60
 C3 1	ABS	1.4 HDI 16v 66kw 8HY (02-08)	TEVES ABS Mk70
 C3 1	ABS	1.4 HDI 8v 50kw 8HZ (02-08)	TEVES ABS Mk60
 C3 1	ABS	1.4 HDI 8v 50kw 8HZ (02-08)	TEVES ABS Mk70
 C3 1	ABS	1.4 HDI 8v 50kw 8HZ (06-..)	TRW ABS
 C3 1	ABS	1.6 16v 80kw NFU (02-08)	TEVES ABS Mk60
 C3 1	ABS	1.6 16v 80kw NFU (02-08)	TEVES ABS Mk70
 C3 1	ABS	1.6 16v 80kw NFU (06-..)	TRW ABS
 C3 1	ABS	1.6 HDI 16v 66kw 9HX (06-..)	TRW ABS
 C3 1	ABS	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	TRW ABS
 C3 1	ABS + TRACT. CONT	1.1 8v 44kw HFX (02-08)	TEVES ABS MK60 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.1 8v 44kw HFX (02-08)	TEVES ABS MK70 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.1 8v 44kw HFX (02-08)	TEVES ESP MK60 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.1 8v 44kw HFX (06-..)	TEVES ABS MK70 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.1 8v 44kw HFX (06-..)	TEVES ABS MK70 New AUTODETECT
 C3 1	ABS + TRACT. CONT	1.1 8v 44kw HFX (06-..)	TEVES ESP MK60 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.1 8v 44kw HFX (06-..)	TEVES ESP MK60 New AUTODETECT
 C3 1	ABS + TRACT. CONT	1.4 16v 66kw KFV (02-08)	TEVES ABS MK60 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.4 16v 66kw KFV (02-08)	TEVES ABS MK70 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.4 16v 66kw KFV (02-08)	TEVES ESP MK60 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.4 16v 66kw KFV (06-..)	TEVES ABS MK70 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.4 16v 66kw KFV (06-..)	TEVES ABS MK70 New AUTODETECT
 C3 1	ABS + TRACT. CONT	1.4 16v 66kw KFV (06-..)	TEVES ESP MK60 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.4 16v 66kw KFV (06-..)	TEVES ESP MK60 New AUTODETECT
 C3 1	ABS + TRACT. CONT	1.4 8v 55kw KFV (02-08)	TEVES ABS MK60 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.4 8v 55kw KFV (02-08)	TEVES ABS MK70 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.4 8v 55kw KFV (02-08)	TEVES ESP MK60 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.4 8v 55kw KFV (06-..)	TEVES ABS MK70 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.4 8v 55kw KFV (06-..)	TEVES ABS MK70 New AUTODETECT
 C3 1	ABS + TRACT. CONT	1.4 8v 55kw KFV (06-..)	TEVES ESP MK60 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.4 8v 55kw KFV (06-..)	TEVES ESP MK60 New AUTODETECT
 C3 1	ABS + TRACT. CONT	1.4 HDI 16v 66kw 8HY (02-08)	TEVES ABS MK60 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.4 HDI 16v 66kw 8HY (02-08)	TEVES ABS MK70 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.4 HDI 16v 66kw 8HY (02-08)	TEVES ESP MK60 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.4 HDI 8v 50kw 8HX (02-08)	TEVES ABS MK60 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.4 HDI 8v 50kw 8HX (02-08)	TEVES ABS MK70 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.4 HDI 8v 50kw 8HX (02-08)	TEVES ABS MK70 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.4 HDI 8v 50kw 8HZ (02-08)	TEVES ABS MK60 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.4 HDI 8v 50kw 8HZ (02-08)	TEVES ABS MK70 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.4 HDI 8v 50kw 8HZ (02-08)	TEVES ABS MK70 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.4 HDI 8v 50kw 8HZ (06-..)	TEVES ABS MK70 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.4 HDI 8v 50kw 8HZ (06-..)	TEVES ABS MK70 New AUTODETECT
 C3 1	ABS + TRACT. CONT	1.4 HDI 8v 50kw 8HZ (06-..)	TEVES ESP MK60 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.4 HDI 8v 50kw 8HZ (06-..)	TEVES ESP MK60 New AUTODETECT
 C3 1	ABS + TRACT. CONT	1.6 16v 80kw N6A (02-08)	TEVES ABS MK60 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.6 16v 80kw N6A (02-08)	TEVES ESP MK60 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.6 16v 80kw NFU (02-08)	TEVES ABS MK60 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.6 16v 80kw NFU (02-08)	TEVES ABS MK70 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.6 16v 80kw NFU (02-08)	TEVES ESP MK60 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.6 16v 80kw NFU (06-..)	TEVES ABS MK70 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.6 16v 80kw NFU (06-..)	TEVES ABS MK70 New AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C3 1	ABS + TRACT. CONT	1.6 16v 80kw NFU (06-..)	TEVES ESP MK60 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.6 16v 80kw NFU (06-..)	TEVES ESP MK60 New AUTODETECT
 C3 1	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX (02-08)	TEVES ABS MK60 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX (02-08)	TEVES ABS MK70 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX (02-08)	TEVES ESP MK60 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX (06-..)	TEVES ABS MK70 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX (06-..)	TEVES ABS MK70 New AUTODETECT
 C3 1	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX (06-..)	TEVES ESP MK60 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX (06-..)	TEVES ESP MK60 New AUTODETECT
 C3 1	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	TEVES ABS MK60 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	TEVES ABS MK70 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	TEVES ESP MK60 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	TEVES ABS MK70 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	TEVES ABS MK70 New AUTODETECT
 C3 1	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	TEVES ESP MK60 AUTODETECT
 C3 1	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	TEVES ESP MK60 New AUTODETECT
 C3 1	AIRBAG	1.1 8v 44kw HFX (02-08)	AirBag CENTRAL AUTODETECT
 C3 1	AIRBAG	1.1 8v 44kw HFX (02-08)	TEMIC AirBag
 C3 1	AIRBAG	1.1 8v 44kw HFX (06-..)	AirBag CENTRAL AUTODETECT
 C3 1	AIRBAG	1.1 8v 44kw HFX (06-..)	TRW Autoliv AirBag
 C3 1	AIRBAG	1.4 16v 66kw KFV (02-08)	AirBag CENTRAL AUTODETECT
 C3 1	AIRBAG	1.4 16v 66kw KFV (06-..)	AirBag CENTRAL AUTODETECT
 C3 1	AIRBAG	1.4 16v 66kw KFV (06-..)	TRW Autoliv AirBag
 C3 1	AIRBAG	1.4 8v 55kw KFV (02-08)	AirBag CENTRAL AUTODETECT
 C3 1	AIRBAG	1.4 8v 55kw KFV (02-08)	TEMIC AirBag
 C3 1	AIRBAG	1.4 8v 55kw KFV (06-..)	AirBag CENTRAL AUTODETECT
 C3 1	AIRBAG	1.4 8v 55kw KFV (06-..)	TRW Autoliv AirBag
 C3 1	AIRBAG	1.4 HDI 16v 66kw 8HY (02-08)	AirBag CENTRAL AUTODETECT
 C3 1	AIRBAG	1.4 HDI 16v 66kw 8HY (02-08)	TEMIC AirBag
 C3 1	AIRBAG	1.4 HDI 8v 50kw 8HX (02-08)	AirBag CENTRAL AUTODETECT
 C3 1	AIRBAG	1.4 HDI 8v 50kw 8HZ (02-08)	AirBag CENTRAL AUTODETECT
 C3 1	AIRBAG	1.4 HDI 8v 50kw 8HZ (02-08)	TEMIC AirBag
 C3 1	AIRBAG	1.4 HDI 8v 50kw 8HZ (06-..)	AirBag CENTRAL AUTODETECT
 C3 1	AIRBAG	1.4 HDI 8v 50kw 8HZ (06-..)	TRW Autoliv AirBag
 C3 1	AIRBAG	1.6 16v 80kw N6A (02-08)	AirBag CENTRAL AUTODETECT
 C3 1	AIRBAG	1.6 16v 80kw NFU (02-08)	AirBag CENTRAL AUTODETECT
 C3 1	AIRBAG	1.6 16v 80kw NFU (02-08)	TEMIC AirBag
 C3 1	AIRBAG	1.6 16v 80kw NFU (06-..)	AirBag CENTRAL AUTODETECT
 C3 1	AIRBAG	1.6 16v 80kw NFU (06-..)	TRW Autoliv AirBag
 C3 1	AIRBAG	1.6 HDI 16v 66kw 9HX (02-08)	AirBag CENTRAL AUTODETECT
 C3 1	AIRBAG	1.6 HDI 16v 66kw 9HX (06-..)	AirBag CENTRAL AUTODETECT
 C3 1	AIRBAG	1.6 HDI 16v 66kw 9HX (06-..)	TRW Autoliv AirBag
 C3 1	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	AirBag CENTRAL AUTODETECT
 C3 1	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	AirBag CENTRAL AUTODETECT
 C3 1	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	TRW Autoliv AirBag
 C3 1	ANTITHEFT	1.1 8v 44kw HFX (02-08)	ALARME PSA2 AUTODETECT
 C3 1	ANTITHEFT	1.1 8v 44kw HFX (06-..)	Alarm PSA2 AUTODETECT
 C3 1	ANTITHEFT	1.4 16v 66kw KFV (02-08)	Alarm PSA2 AUTODETECT
 C3 1	ANTITHEFT	1.4 16v 66kw KFV (06-..)	Alarm PSA2 AUTODETECT
 C3 1	ANTITHEFT	1.4 8v 55kw KFV (02-08)	Alarm PSA2 AUTODETECT
 C3 1	ANTITHEFT	1.4 8v 55kw KFV (06-..)	Alarm PSA2 AUTODETECT
 C3 1	ANTITHEFT	1.4 HDI 16v 66kw 8HY (02-08)	Alarm PSA2 AUTODETECT
 C3 1	ANTITHEFT	1.4 HDI 8v 50kw 8HX (02-08)	Alarm PSA2 AUTODETECT
 C3 1	ANTITHEFT	1.4 HDI 8v 50kw 8HZ (02-08)	Alarm PSA2 AUTODETECT
 C3 1	ANTITHEFT	1.4 HDI 8v 50kw 8HZ (06-..)	Alarm PSA2 AUTODETECT
 C3 1	ANTITHEFT	1.6 16v 80kw N6A (02-08)	Alarm PSA2 AUTODETECT
 C3 1	ANTITHEFT	1.6 16v 80kw NFU (02-08)	Alarm PSA2 AUTODETECT
 C3 1	ANTITHEFT	1.6 16v 80kw NFU (06-..)	Alarm PSA2 AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C3 1	ANTITHEFT	1.6 HDI 16v 66kw 9HX (02-08)	Alarm PSA2 AUTODETECT
 C3 1	ANTITHEFT	1.6 HDI 16v 66kw 9HX (06-..)	Alarm PSA2 AUTODETECT
 C3 1	ANTITHEFT	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	Alarma PSA2 AUTODETECT
 C3 1	ANTITHEFT	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	Alarm PSA2 AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.1 8v 44kw HFX (02-08)	A/T AL4 AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.1 8v 44kw HFX (02-08)	A/T Pilot manual AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.1 8v 44kw HFX (06-..)	A/T AL4 AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.1 8v 44kw HFX (06-..)	A/T Pilot Manual AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.4 16v 66kw KFU (02-08)	A/AT Manual Pilot AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.4 16v 66kw KFU (02-08)	A/T AL4 AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.4 16v 66kw KFU (06-..)	A/T AL4 AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.4 16v 66kw KFU (06-..)	A/T Manual Pilot AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.4 8v 55kw KFV (02-08)	A/T AL4 AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.4 8v 55kw KFV (02-08)	A/T Manual Pilot AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.4 8v 55kw KFV (06-..)	A/T AL4 AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.4 8v 55kw KFV (06-..)	A/T Manual Pilot AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.4 HDI 16v 66kw 8HY (02-08)	A/T AL4 AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.4 HDI 16v 66kw 8HY (02-08)	A/T Manual Pilot AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.4 HDI 8v 50kw 8HX (02-08)	A/T AL4 AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.4 HDI 8v 50kw 8HX (02-08)	A/T Manual Pilot AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.4 HDI 8v 50kw 8HZ (02-08)	A/T AL4 AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.4 HDI 8v 50kw 8HZ (02-08)	A/T Manual Pilot AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.4 HDI 8v 50kw 8HZ (06-..)	A/T AL4 AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.4 HDI 8v 50kw 8HZ (06-..)	A/T Manual Pilot AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.6 16v 80kw N6A (02-08)	A/T AL4 AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.6 16v 80kw N6A (02-08)	A/T Manual Pilot AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.6 16v 80kw NFU (02-08)	A/T AL4 AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.6 16v 80kw NFU (02-08)	A/T Manual Pilot AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.6 16v 80kw NFU (06-..)	A/T AL4 AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.6 16v 80kw NFU (06-..)	A/T manual Pilot AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.6 HDI 16v 66kw 9HX (02-08)	A/T AL4 AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.6 HDI 16v 66kw 9HX (02-08)	A/T AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.6 HDI 16v 66kw 9HX (06-..)	A/T Pilot manual AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	A/T AL4 AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	A/T Manual Pilot AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	A/T AL4 AUTODETECT
 C3 1	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	A/T Pilot manual AUTODETECT
 C3 1	CHASSIS NETWORK	1.1 8v 44kw HFX (02-08)	Body Computer BSI AUTODETECT
 C3 1	CHASSIS NETWORK	1.1 8v 44kw HFX (02-08)	SIEMENS Body Computer
 C3 1	CHASSIS NETWORK	1.1 8v 44kw HFX (02-08)	STOP/START System AUTODETECT
 C3 1	CHASSIS NETWORK	1.1 8v 44kw HFX (06-..)	Body Computer BSI AUTODETECT
 C3 1	CHASSIS NETWORK	1.1 8v 44kw HFX (06-..)	Body Computer BSM AUTODETECT
 C3 1	CHASSIS NETWORK	1.1 8v 44kw HFX (06-..)	Body Computer BSR AUTODETECT
 C3 1	CHASSIS NETWORK	1.1 8v 44kw HFX (06-..)	High frequency receiver AUTODETECT
 C3 1	CHASSIS NETWORK	1.1 8v 44kw HFX (06-..)	SIEMENS Body Computer BSI
 C3 1	CHASSIS NETWORK	1.1 8v 44kw HFX (06-..)	SIEMENS Body Computer BSM
 C3 1	CHASSIS NETWORK	1.1 8v 44kw HFX (06-..)	STOP-START System AUTODETECT
 C3 1	CHASSIS NETWORK	1.4 16v 66kw KFU (02-08)	Body Computer BSI AUTODETECT
 C3 1	CHASSIS NETWORK	1.4 16v 66kw KFU (02-08)	STOP/START System AUTODETECT
 C3 1	CHASSIS NETWORK	1.4 16v 66kw KFU (06-..)	Body Computer BSI AUTODETECT
 C3 1	CHASSIS NETWORK	1.4 16v 66kw KFU (06-..)	Body Computer BSM AUTODETECT
 C3 1	CHASSIS NETWORK	1.4 16v 66kw KFU (06-..)	Body Computer BSR AUTODETECT
 C3 1	CHASSIS NETWORK	1.4 16v 66kw KFU (06-..)	High frequency receiver AUTODETECT
 C3 1	CHASSIS NETWORK	1.4 16v 66kw KFU (06-..)	SIEMENS Body Computer BSI
 C3 1	CHASSIS NETWORK	1.4 16v 66kw KFU (06-..)	SIEMENS Body Computer BSM
 C3 1	CHASSIS NETWORK	1.4 16v 66kw KFU (06-..)	STOP/START System AUTODETECT
 C3 1	CHASSIS NETWORK	1.4 8v 55kw KFV (02-08)	Body Computer BSI AUTODETECT
 C3 1	CHASSIS NETWORK	1.4 8v 55kw KFV (02-08)	STOP/START System AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C3 1	CHASSIS NETWORK	1.4 8v 55kw KFV (06-..)	Body Computer BSI AUTODETECT
 C3 1	CHASSIS NETWORK	1.4 8v 55kw KFV (06-..)	Body Computer BSM AUTODETECT
 C3 1	CHASSIS NETWORK	1.4 8v 55kw KFV (06-..)	Body Computer BSR AUTODETECT
 C3 1	CHASSIS NETWORK	1.4 8v 55kw KFV (06-..)	High ferquency receiver AUTODETECT
 C3 1	CHASSIS NETWORK	1.4 8v 55kw KFV (06-..)	SIEMENS Body Computer BSI
 C3 1	CHASSIS NETWORK	1.4 8v 55kw KFV (06-..)	SIEMENS Body Computer BSM
 C3 1	CHASSIS NETWORK	1.4 8v 55kw KFV (06-..)	STOP-START System AUTODETECT
 C3 1	CHASSIS NETWORK	1.4 HDI 16v 66kw 8HY (02-08)	Body Computer BSI AUTODETECT
 C3 1	CHASSIS NETWORK	1.4 HDI 16v 66kw 8HY (02-08)	SIEMENS Body Computer
 C3 1	CHASSIS NETWORK	1.4 HDI 16v 66kw 8HY (02-08)	STOP-START System AUTODETECT
 C3 1	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HX (02-08)	Body Computer BSI AUTODETECT
 C3 1	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HX (02-08)	SIEMENS Body Computer
 C3 1	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HX (02-08)	STOP/START system AUTODETECT
 C3 1	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HZ (02-08)	Body Computer BSI AUTODETECT
 C3 1	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HZ (02-08)	SIEMENS Body Computer
 C3 1	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HZ (02-08)	STOP/START system AUTODETECT
 C3 1	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HZ (06-..)	Body Computer BSI AUTODETECT
 C3 1	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HZ (06-..)	Body Computer BSM AUTODETECT
 C3 1	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HZ (06-..)	Body Computer BSR AUTODETECT
 C3 1	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HZ (06-..)	High frequency receiver AUTODETECT
 C3 1	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HZ (06-..)	SIEMENS Body Computer BSI
 C3 1	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HZ (06-..)	SIEMENS Body Computer BSM
 C3 1	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HZ (06-..)	STOP/START System AUTODETECT
 C3 1	CHASSIS NETWORK	1.6 16v 80kw N6A (02-08)	Body Computer BSI AUTODETECT
 C3 1	CHASSIS NETWORK	1.6 16v 80kw N6A (02-08)	STOP/START System AUTODETECT
 C3 1	CHASSIS NETWORK	1.6 16v 80kw NFU (02-08)	Body Computer BSI AUTODETECT
 C3 1	CHASSIS NETWORK	1.6 16v 80kw NFU (02-08)	SIEMENS Body Computer
 C3 1	CHASSIS NETWORK	1.6 16v 80kw NFU (02-08)	STOP/START System AUTODETECT
 C3 1	CHASSIS NETWORK	1.6 16v 80kw NFU (06-..)	Body Computer BSI AUTODETECT
 C3 1	CHASSIS NETWORK	1.6 16v 80kw NFU (06-..)	Body Computer BSM AUTODETECT
 C3 1	CHASSIS NETWORK	1.6 16v 80kw NFU (06-..)	Body Computer BSR AUTODETECT
 C3 1	CHASSIS NETWORK	1.6 16v 80kw NFU (06-..)	High frequency receiver AUTODETECT
 C3 1	CHASSIS NETWORK	1.6 16v 80kw NFU (06-..)	SIEMENS Body Computer BSI
 C3 1	CHASSIS NETWORK	1.6 16v 80kw NFU (06-..)	SIEMENS Body Computer BSM
 C3 1	CHASSIS NETWORK	1.6 16v 80kw NFU (06-..)	STOP/START System AUTODETECT
 C3 1	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX (02-08)	Body Computer BSI AUTODETECT
 C3 1	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX (02-08)	STOP/START System AUTODETECT
 C3 1	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX (06-..)	Body Computer BSI AUTODETECT
 C3 1	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX (06-..)	Body Computer BSR AUTODETECT
 C3 1	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX (06-..)	High Frequency receiver AUTODETECT
 C3 1	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX (06-..)	SIEMENS Body Computer BSI
 C3 1	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX (06-..)	SIEMENS Body Computer BSM
 C3 1	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX (06-..)	STOP/START System AUTODETECT
 C3 1	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	Body Computer BSI AUTODETECT
 C3 1	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	STOP/START System AUTODETECT
 C3 1	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	Body Computer BSI AUTODETECT
 C3 1	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	Body Computer BSM AUTODETECT
 C3 1	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	Body Computer BSR AUTODETECT
 C3 1	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	High frequency reiciver AUTODETECT
 C3 1	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	SIEMENS Body Computer BSI
 C3 1	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	SIEMENS Body Computer BSM
 C3 1	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	STOP/START System AUTODETECT
 C3 1	CLIMA	1.1 8v 44kw HFX (02-08)	CLIMA AUTO AUTODETECT
 C3 1	CLIMA	1.1 8v 44kw HFX (02-08)	klimateumatik x.x
 C3 1	CLIMA	1.1 8v 44kw HFX (06-..)	AutoClima X.x
 C3 1	CLIMA	1.1 8v 44kw HFX (06-..)	AUTODETECT
 C3 1	CLIMA	1.4 16v 66kw KFU (02-08)	CLIMA AUTO AUTODETECT
 C3 1	CLIMA	1.4 16v 66kw KFU (06-..)	AutoClima X.x

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C3 1	CLIMA	1.4 16v 66kw KFU (06-..)	AUTODETECT
 C3 1	CLIMA	1.4 8v 55kw KFV (02-08)	CLIMA AUTO AUTODETECT
 C3 1	CLIMA	1.4 8v 55kw KFV (02-08)	klimautomatik x.x
 C3 1	CLIMA	1.4 8v 55kw KFV (06-..)	AutoClima X.x
 C3 1	CLIMA	1.4 8v 55kw KFV (06-..)	AUTODETECT
 C3 1	CLIMA	1.4 HDI 16v 66kw 8HY (02-08)	CLIMA AUTO AUTODETECT
 C3 1	CLIMA	1.4 HDI 16v 66kw 8HY (02-08)	klimautomatik x.x
 C3 1	CLIMA	1.4 HDI 8v 50kw 8HX (02-08)	CLIMA AUTO AUTODETECT
 C3 1	CLIMA	1.4 HDI 8v 50kw 8HX (02-08)	klimautomatik x.x
 C3 1	CLIMA	1.4 HDI 8v 50kw 8HZ (02-08)	CLIMA AUTO AUTODETECT
 C3 1	CLIMA	1.4 HDI 8v 50kw 8HZ (02-08)	klimautomatik x.x
 C3 1	CLIMA	1.4 HDI 8v 50kw 8HZ (06-..)	AutoClima X.x
 C3 1	CLIMA	1.4 HDI 8v 50kw 8HZ (06-..)	AUTODETECT
 C3 1	CLIMA	1.6 16v 80kw N6A (02-08)	CLIMA AUTO AUTODETECT
 C3 1	CLIMA	1.6 16v 80kw NFU (02-08)	CLIMA AUTO AUTODETECT
 C3 1	CLIMA	1.6 16v 80kw NFU (02-08)	klimautomatik x.x
 C3 1	CLIMA	1.6 16v 80kw NFU (06-..)	AutoClima X.x
 C3 1	CLIMA	1.6 16v 80kw NFU (06-..)	AUTODETECT
 C3 1	CLIMA	1.6 HDI 16v 66kw 9HX (02-08)	CLIMA AUTO AUTODETECT
 C3 1	CLIMA	1.6 HDI 16v 66kw 9HX (06-..)	AutoClima X.x
 C3 1	CLIMA	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	CLIMA AUTO AUTODETECT
 C3 1	CLIMA	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	AutoClima X.x
 C3 1	CLIMA	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	AUTODETECT
 C3 1	COMFORT SYSTEM	1.1 8v 44kw HFX (02-08)	AUTODETECT
 C3 1	COMFORT SYSTEM	1.1 8v 44kw HFX (06-..)	AUTODETECT
 C3 1	COMFORT SYSTEM	1.4 16v 66kw KFU (02-08)	School Module AUTODETECT
 C3 1	COMFORT SYSTEM	1.4 16v 66kw KFU (06-..)	School module AUTODETECT
 C3 1	COMFORT SYSTEM	1.4 8v 55kw KFV (02-08)	AUTODETECT
 C3 1	COMFORT SYSTEM	1.4 8v 55kw KFV (06-..)	School Module AUTODETECT
 C3 1	COMFORT SYSTEM	1.4 HDI 16v 66kw 8HY (02-08)	School Module AUTODETECT
 C3 1	COMFORT SYSTEM	1.4 HDI 8v 50kw 8HX (02-08)	School Module AUTODETECT
 C3 1	COMFORT SYSTEM	1.4 HDI 8v 50kw 8HZ (02-08)	School Module AUTODETECT
 C3 1	COMFORT SYSTEM	1.4 HDI 8v 50kw 8HZ (06-..)	School Module AUTODETECT
 C3 1	COMFORT SYSTEM	1.6 16v 80kw N6A (02-08)	School Module AUTODETECT
 C3 1	COMFORT SYSTEM	1.6 16v 80kw NFU (02-08)	School Module AUTODETECT
 C3 1	COMFORT SYSTEM	1.6 16v 80kw NFU (06-..)	School Module AUTODETECT
 C3 1	COMFORT SYSTEM	1.6 HDI 16v 66kw 9HX (02-08)	School Module AUTODETECT
 C3 1	COMFORT SYSTEM	1.6 HDI 16v 66kw 9HX (06-..)	School Module AUTODETECT
 C3 1	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	School Module AUTODETECT
 C3 1	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	School Module AUTODETECT
 C3 1	DASHBOARD	1.1 8v 44kw HFX (02-08)	AUTODETECT
 C3 1	DASHBOARD	1.1 8v 44kw HFX (02-08)	SAGEM Dashboard
 C3 1	DASHBOARD	1.1 8v 44kw HFX (06-..)	AUTODETECT
 C3 1	DASHBOARD	1.1 8v 44kw HFX (06-..)	SAGEM Dashboard
 C3 1	DASHBOARD	1.4 16v 66kw KFU (02-08)	AUTODETECT
 C3 1	DASHBOARD	1.4 16v 66kw KFU (06-..)	AUTODETECT
 C3 1	DASHBOARD	1.4 16v 66kw KFU (06-..)	SAGEM Dashboard
 C3 1	DASHBOARD	1.4 8v 55kw KFV (02-08)	AUTODETECT
 C3 1	DASHBOARD	1.4 8v 55kw KFV (06-..)	AUTODETECT
 C3 1	DASHBOARD	1.4 8v 55kw KFV (06-..)	SAGEM Dashboard
 C3 1	DASHBOARD	1.4 HDI 16v 66kw 8HY (02-08)	AUTODETECT
 C3 1	DASHBOARD	1.4 HDI 16v 66kw 8HY (02-08)	SAGEM Dashboard
 C3 1	DASHBOARD	1.4 HDI 8v 50kw 8HX (02-08)	AUTODETECT
 C3 1	DASHBOARD	1.4 HDI 8v 50kw 8HX (02-08)	SAGEM Dashboard
 C3 1	DASHBOARD	1.4 HDI 8v 50kw 8HZ (02-08)	AUTODETECT
 C3 1	DASHBOARD	1.4 HDI 8v 50kw 8HZ (02-08)	SAGEM Dashboard
 C3 1	DASHBOARD	1.4 HDI 8v 50kw 8HZ (06-..)	AUTODETECT
 C3 1	DASHBOARD	1.4 HDI 8v 50kw 8HZ (06-..)	SAGEM Dashboard

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C3 1	DASHBOARD	1.6 16v 80kw N6A (02-08)	AUTODETECT
 C3 1	DASHBOARD	1.6 16v 80kw NFU (02-08)	AUTODETECT
 C3 1	DASHBOARD	1.6 16v 80kw NFU (02-08)	SAGEM Dashboard
 C3 1	DASHBOARD	1.6 16v 80kw NFU (06-..)	AUTODETECT
 C3 1	DASHBOARD	1.6 16v 80kw NFU (06-..)	SAGEM Dashboard
 C3 1	DASHBOARD	1.6 HDI 16v 66kw 9HX (02-08)	AUTODETECT
 C3 1	DASHBOARD	1.6 HDI 16v 66kw 9HX (06-..)	AUTODETECT
 C3 1	DASHBOARD	1.6 HDI 16v 66kw 9HX (06-..)	SAGEM Dashboard
 C3 1	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	AUTODETECT
 C3 1	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	AUTODETECT
 C3 1	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	SAGEM Dashboard
 C3 1	DIESEL ADDITION	1.4 HDI 16v 66kw 8HY (02-08)	AUTODETECT
 C3 1	DIESEL ADDITION	1.4 HDI 8v 50kw 8HX (02-08)	AUTODETECT
 C3 1	DIESEL ADDITION	1.4 HDI 8v 50kw 8HZ (02-08)	AUTODETECT
 C3 1	DIESEL ADDITION	1.4 HDI 8v 50kw 8HZ (06-..)	AUTODETECT
 C3 1	DIESEL ADDITION	1.6 HDI 16v 66kw 9HX (02-08)	AUTODETECT
 C3 1	DIESEL ADDITION	1.6 HDI 16v 66kw 9HX (06-..)	AUTODETECT
 C3 1	DIESEL ADDITION	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	AUTODETECT
 C3 1	DIESEL ADDITION	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	AUTODETECT
 C3 1	ELECTRIC STEERING	1.1 8v 44kw HFX (02-08)	AUTODETECT
 C3 1	ELECTRIC STEERING	1.1 8v 44kw HFX (02-08)	KOYO EPS
 C3 1	ELECTRIC STEERING	1.1 8v 44kw HFX (06-..)	KOYO EPS 8401
 C3 1	ELECTRIC STEERING	1.4 16v 66kw KFU (02-08)	AUTODETECT
 C3 1	ELECTRIC STEERING	1.4 16v 66kw KFU (06-..)	AUTODETECT
 C3 1	ELECTRIC STEERING	1.4 16v 66kw KFU (06-..)	KOYO EPS 8401
 C3 1	ELECTRIC STEERING	1.4 8v 55kw KFV (02-08)	AUTODETECT
 C3 1	ELECTRIC STEERING	1.4 8v 55kw KFV (02-08)	KOYO EPS
 C3 1	ELECTRIC STEERING	1.4 8v 55kw KFV (06-..)	AUTODETECT
 C3 1	ELECTRIC STEERING	1.4 8v 55kw KFV (06-..)	KOYO EPS 8401
 C3 1	ELECTRIC STEERING	1.4 HDI 16v 66kw 8HY (02-08)	AUTODETECT
 C3 1	ELECTRIC STEERING	1.4 HDI 16v 66kw 8HY (02-08)	KOYO EPS
 C3 1	ELECTRIC STEERING	1.4 HDI 8v 50kw 8HX (02-08)	AUTODETECT
 C3 1	ELECTRIC STEERING	1.4 HDI 8v 50kw 8HX (02-08)	KOYO EPS
 C3 1	ELECTRIC STEERING	1.4 HDI 8v 50kw 8HZ (02-08)	AUTODETECT
 C3 1	ELECTRIC STEERING	1.4 HDI 8v 50kw 8HZ (02-08)	KOYO EPS
 C3 1	ELECTRIC STEERING	1.4 HDI 8v 50kw 8HZ (06-..)	AUTODETECT
 C3 1	ELECTRIC STEERING	1.4 HDI 8v 50kw 8HZ (06-..)	KOYO EPS 8401
 C3 1	ELECTRIC STEERING	1.6 16v 80kw N6A (02-08)	AUTODETECT
 C3 1	ELECTRIC STEERING	1.6 16v 80kw NFU (02-08)	AUTODETECT
 C3 1	ELECTRIC STEERING	1.6 16v 80kw NFU (02-08)	KOYO EPS
 C3 1	ELECTRIC STEERING	1.6 16v 80kw NFU (06-..)	AUTODETECT
 C3 1	ELECTRIC STEERING	1.6 16v 80kw NFU (06-..)	KOYO EPS 8401
 C3 1	ELECTRIC STEERING	1.6 HDI 16v 66kw 9HX (02-08)	AUTODETECT
 C3 1	ELECTRIC STEERING	1.6 HDI 16v 66kw 9HX (06-..)	KOYO EPS 8401
 C3 1	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	AUTODETECT
 C3 1	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	AUTODETECT
 C3 1	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	KOYO EPS 8401
 C3 1	ENGINE MANAGEME	1.1 8v 44kw HFX (02-08)	JCAE SAX500 GNV AUTODETECT
 C3 1	ENGINE MANAGEME	1.1 8v 44kw HFX (02-08)	Marelli 4.8P
 C3 1	ENGINE MANAGEME	1.1 8v 44kw HFX (02-08)	Marelli MM48P AUTODETECT
 C3 1	ENGINE MANAGEME	1.1 8v 44kw HFX (06-..)	JCAE SAX500 GNV AUTODETECT
 C3 1	ENGINE MANAGEME	1.1 8v 44kw HFX (06-..)	SAGEM J34P AUTODETECT
 C3 1	ENGINE MANAGEME	1.1 8v 44kw HFX (06-..)	SAGEM MPI J34P
 C3 1	ENGINE MANAGEME	1.4 16v 66kw KFU (02-08)	JCAE SAX500 GNV AUTODETECT
 C3 1	ENGINE MANAGEME	1.4 16v 66kw KFU (02-08)	Marelli MM6LP AUTODETECT
 C3 1	ENGINE MANAGEME	1.4 16v 66kw KFU (06-..)	JCAE SAX500 GNV AUTODETECT
 C3 1	ENGINE MANAGEME	1.4 16v 66kw KFU (06-..)	Marelli MM6LP AUTODETECT
 C3 1	ENGINE MANAGEME	1.4 8v 55kw KFV (02-08)	BOSCH ME 7.4.4 AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C3 1	ENGINE MANAGEME	1.4 8v 55kw KFV (02-08)	BOSCH ME 7.4.9 AUTODETECT
 C3 1	ENGINE MANAGEME	1.4 8v 55kw KFV (02-08)	JCAE SAX500 GNV AUTODETECT
 C3 1	ENGINE MANAGEME	1.4 8v 55kw KFV (02-08)	SAGEM S2000 PM1 AUTODETECT
 C3 1	ENGINE MANAGEME	1.4 8v 55kw KFV (02-08)	SAGEM S2000 PM2 AUTODETECT
 C3 1	ENGINE MANAGEME	1.4 8v 55kw KFV (02-08)	SAGEM S2000PM1
 C3 1	ENGINE MANAGEME	1.4 8v 55kw KFV (02-08)	SAGEM S2000PM2
 C3 1	ENGINE MANAGEME	1.4 8v 55kw KFV (06-..)	JCAE SAX500 GNV AUTODETECT
 C3 1	ENGINE MANAGEME	1.4 8v 55kw KFV (06-..)	SAGEM J34P AUTODETECT
 C3 1	ENGINE MANAGEME	1.4 8v 55kw KFV (06-..)	SAGEM S2000 PM2 AUTODETECT
 C3 1	ENGINE MANAGEME	1.4 HDI 16v 66kw 8HY (02-08)	DELPHI C6 Common Rail
 C3 1	ENGINE MANAGEME	1.4 HDI 16v 66kw 8HY (02-08)	DELPHI C6 Common Rail AUTODETECT
 C3 1	ENGINE MANAGEME	1.4 HDI 8v 50kw 8HX (02-08)	BOSCH EDC16 C34 Common rail AUTODE
 C3 1	ENGINE MANAGEME	1.4 HDI 8v 50kw 8HX (02-08)	SIEMENS Diesel SID 804 Common Rail
 C3 1	ENGINE MANAGEME	1.4 HDI 8v 50kw 8HX (02-08)	SIEMENS SID802 Common Rail AUTODET
 C3 1	ENGINE MANAGEME	1.4 HDI 8v 50kw 8HX (02-08)	SIEMENS SID804 Common Rail AUTODET
 C3 1	ENGINE MANAGEME	1.4 HDI 8v 50kw 8HZ (02-08)	BOSCH EDC 16 C3 Common Rail
 C3 1	ENGINE MANAGEME	1.4 HDI 8v 50kw 8HZ (02-08)	BOSCH EDC16 C34 Common rail AUTODE
 C3 1	ENGINE MANAGEME	1.4 HDI 8v 50kw 8HZ (02-08)	SIEMENS SID804 Common Rail AUTODET
 C3 1	ENGINE MANAGEME	1.4 HDI 8v 50kw 8HZ (06-..)	BOSCH EDC16 C34 Common Rail AUTOD
 C3 1	ENGINE MANAGEME	1.4 HDI 8v 50kw 8HZ (06-..)	JCAE SAX500 GNV AUTODETECT
 C3 1	ENGINE MANAGEME	1.4 HDI 8v 50kw 8HZ (06-..)	SIEMENS SID806 Common Rail AUTODET
 C3 1	ENGINE MANAGEME	1.6 16v 80kw N6A (02-08)	BOSCH ME 7.4.9 AUTODETECT
 C3 1	ENGINE MANAGEME	1.6 16v 80kw N6A (02-08)	BOSCH ME 7.4.9 Bioflex AUTODETECT
 C3 1	ENGINE MANAGEME	1.6 16v 80kw N6A (02-08)	JCAE SAX500 GNV AUTODETECT
 C3 1	ENGINE MANAGEME	1.6 16v 80kw NFU (02-08)	BOSCH ME 7.4.4 AUTODETECT
 C3 1	ENGINE MANAGEME	1.6 16v 80kw NFU (02-08)	BOSCH Motronic ME7.4.4
 C3 1	ENGINE MANAGEME	1.6 16v 80kw NFU (02-08)	JCAE SAX500 GNV AUTODETECT
 C3 1	ENGINE MANAGEME	1.6 16v 80kw NFU (06-..)	BOSCH ME 7.4.5 AUTODETECT
 C3 1	ENGINE MANAGEME	1.6 16v 80kw NFU (06-..)	JCAE SAX500 GNV AUTODETECT
 C3 1	ENGINE MANAGEME	1.6 HDI 16v 66kw 9HX (02-08)	BOSCH EDC16 C34 Common Rail AUTOD
 C3 1	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	BOSCH EDC16 C34 Common Rail AUTOD
 C3 1	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	BOSCH EDC16 C34 Common rail
 C3 1	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	DIESEL AUTODETECT
 C3 1	KEY ENCODE	1.1 8v 44kw HFX (02-08)	VALEO Body Siemens
 C3 1	KEY ENCODE	1.4 8v 55kw KFV (02-08)	VALEO Body Siemens
 C3 1	KEY ENCODE	1.4 HDI 16v 66kw 8HY (02-08)	VALEO Body Siemens
 C3 1	KEY ENCODE	1.4 HDI 8v 50kw 8HX (02-08)	VALEO Body Siemens
 C3 1	KEY ENCODE	1.4 HDI 8v 50kw 8HZ (02-08)	VALEO Body Siemens
 C3 1	KEY ENCODE	1.6 16v 80kw NFU (02-08)	VALEO Body Siemens
 C3 1	MAINTENANCE	1.1 8v 44kw HFX (02-08)	A/T AL4 AUTODETECT
 C3 1	MAINTENANCE	1.1 8v 44kw HFX (02-08)	Body Computer BSI AUTODETECT
 C3 1	MAINTENANCE	1.1 8v 44kw HFX (02-08)	SAGEM Dashboard
 C3 1	MAINTENANCE	1.1 8v 44kw HFX (02-08)	Sagem/xx MANUAL
 C3 1	MAINTENANCE	1.1 8v 44kw HFX (02-08)	TEMIC AirBag
 C3 1	MAINTENANCE	1.1 8v 44kw HFX (02-08)	TEVES ABS MK60 AUTODETECT
 C3 1	MAINTENANCE	1.1 8v 44kw HFX (02-08)	TEVES ESP MK60 AUTODETECT
 C3 1	MAINTENANCE	1.1 8v 44kw HFX (02-08)	TEVES ESP MK60 AUTODETECT
 C3 1	MAINTENANCE	1.1 8v 44kw HFX (02-08)	Valeo Body Computer MANUAL
 C3 1	MAINTENANCE	1.1 8v 44kw HFX (06-..)	A/T AL4 AUTODETECT
 C3 1	MAINTENANCE	1.1 8v 44kw HFX (06-..)	AirBag CENTRAL AUTODETECT
 C3 1	MAINTENANCE	1.1 8v 44kw HFX (06-..)	AirBag CENTRAL AUTODETECT
 C3 1	MAINTENANCE	1.1 8v 44kw HFX (06-..)	SAGEM Dashboard
 C3 1	MAINTENANCE	1.1 8v 44kw HFX (06-..)	SIEMENS Body Computer BSI
 C3 1	MAINTENANCE	1.1 8v 44kw HFX (06-..)	TEVES ABS MK70 New AUTODETECT
 C3 1	MAINTENANCE	1.1 8v 44kw HFX (06-..)	TEVES ESP MK60 AUTODETECT
 C3 1	MAINTENANCE	1.1 8v 44kw HFX (06-..)	TEVES ESP MK60 AUTODETECT
 C3 1	MAINTENANCE	1.1 8v 44kw HFX (06-..)	TEVES ESP MK60 New AUTODETECT
 C3 1	MAINTENANCE	1.1 8v 44kw HFX (06-..)	TEVES ESP MK60 New AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C3 1	MAINTENANCE	1.4 16v 66kw KFU (02-08)	A/T AL4 AUTODETECT
 C3 1	MAINTENANCE	1.4 16v 66kw KFU (02-08)	Body Computer BSI AUTODETECT
 C3 1	MAINTENANCE	1.4 16v 66kw KFU (02-08)	TEVES ABS MK60 AUTODETECT
 C3 1	MAINTENANCE	1.4 16v 66kw KFU (02-08)	TEVES ESP MK60 AUTODETECT
 C3 1	MAINTENANCE	1.4 16v 66kw KFU (02-08)	TEVES ESP MK60 AUTODETECT
 C3 1	MAINTENANCE	1.4 16v 66kw KFU (06-..)	A/T AL4 AUTODETECT
 C3 1	MAINTENANCE	1.4 16v 66kw KFU (06-..)	AirBag CENTRAL AUTODETECT
 C3 1	MAINTENANCE	1.4 16v 66kw KFU (06-..)	AirBag CENTRAL AUTODETECT
 C3 1	MAINTENANCE	1.4 16v 66kw KFU (06-..)	SAGEM Dashboard
 C3 1	MAINTENANCE	1.4 16v 66kw KFU (06-..)	SIEMENS Body Computer BSI
 C3 1	MAINTENANCE	1.4 16v 66kw KFU (06-..)	TEVES ABS MK70 New AUTODETECT
 C3 1	MAINTENANCE	1.4 16v 66kw KFU (06-..)	TEVES ESP MK60 AUTODETECT
 C3 1	MAINTENANCE	1.4 16v 66kw KFU (06-..)	TEVES ESP MK60 AUTODETECT
 C3 1	MAINTENANCE	1.4 16v 66kw KFU (06-..)	TEVES ESP MK60 New AUTODETECT
 C3 1	MAINTENANCE	1.4 16v 66kw KFU (06-..)	TEVES ESP MK60 New AUTODETECT
 C3 1	MAINTENANCE	1.4 8v 55kw KFV (02-08)	A/T AL4 AUTODETECT
 C3 1	MAINTENANCE	1.4 8v 55kw KFV (02-08)	Body Computer BSI AUTODETECT
 C3 1	MAINTENANCE	1.4 8v 55kw KFV (02-08)	Sagem/xx MANUAL
 C3 1	MAINTENANCE	1.4 8v 55kw KFV (02-08)	TEMIC AirBag
 C3 1	MAINTENANCE	1.4 8v 55kw KFV (02-08)	TEVES ABS MK60 AUTODETECT
 C3 1	MAINTENANCE	1.4 8v 55kw KFV (02-08)	TEVES ESP MK60 AUTODETECT
 C3 1	MAINTENANCE	1.4 8v 55kw KFV (02-08)	TEVES ESP MK60 AUTODETECT
 C3 1	MAINTENANCE	1.4 8v 55kw KFV (02-08)	Valeo Body Computer MANUAL
 C3 1	MAINTENANCE	1.4 8v 55kw KFV (06-..)	A/T AL4 AUTODETECT
 C3 1	MAINTENANCE	1.4 8v 55kw KFV (06-..)	AirBag CENTRAL AUTODETECT
 C3 1	MAINTENANCE	1.4 8v 55kw KFV (06-..)	AirBag CENTRAL AUTODETECT
 C3 1	MAINTENANCE	1.4 8v 55kw KFV (06-..)	SAGEM Dashboard
 C3 1	MAINTENANCE	1.4 8v 55kw KFV (06-..)	SIEMENS Body Computer BSI
 C3 1	MAINTENANCE	1.4 8v 55kw KFV (06-..)	TEVES ABS MK70 New AUTODETECT
 C3 1	MAINTENANCE	1.4 8v 55kw KFV (06-..)	TEVES ESP MK60 AUTODETECT
 C3 1	MAINTENANCE	1.4 8v 55kw KFV (06-..)	TEVES ESP MK60 AUTODETECT
 C3 1	MAINTENANCE	1.4 8v 55kw KFV (06-..)	TEVES ESP MK60 New AUTODETECT
 C3 1	MAINTENANCE	1.4 8v 55kw KFV (06-..)	TEVES ESP MK60 New AUTODETECT
 C3 1	MAINTENANCE	1.4 HDI 16v 66kw 8HY (02-08)	A/T AL4 AUTODETECT
 C3 1	MAINTENANCE	1.4 HDI 16v 66kw 8HY (02-08)	Body Computer BSI AUTODETECT
 C3 1	MAINTENANCE	1.4 HDI 16v 66kw 8HY (02-08)	SAGEM Dashboard
 C3 1	MAINTENANCE	1.4 HDI 16v 66kw 8HY (02-08)	Sagem/xx MANUAL
 C3 1	MAINTENANCE	1.4 HDI 16v 66kw 8HY (02-08)	TEMIC AirBag
 C3 1	MAINTENANCE	1.4 HDI 16v 66kw 8HY (02-08)	TEVES ABS MK60 AUTODETECT
 C3 1	MAINTENANCE	1.4 HDI 16v 66kw 8HY (02-08)	TEVES ESP MK60 AUTODETECT
 C3 1	MAINTENANCE	1.4 HDI 16v 66kw 8HY (02-08)	TEVES ESP MK60 AUTODETECT
 C3 1	MAINTENANCE	1.4 HDI 16v 66kw 8HY (02-08)	Valeo Body Computer MANUAL
 C3 1	MAINTENANCE	1.4 HDI 8v 50kw 8HX (02-08)	A/T AL4 AUTODETECT
 C3 1	MAINTENANCE	1.4 HDI 8v 50kw 8HX (02-08)	Body Computer BSI AUTODETECT
 C3 1	MAINTENANCE	1.4 HDI 8v 50kw 8HX (02-08)	SAGEM Dashboard
 C3 1	MAINTENANCE	1.4 HDI 8v 50kw 8HX (02-08)	Sagem/xx MANUAL
 C3 1	MAINTENANCE	1.4 HDI 8v 50kw 8HX (02-08)	TEVES ABS MK60 AUTODETECT
 C3 1	MAINTENANCE	1.4 HDI 8v 50kw 8HX (02-08)	TEVES ABS MK70 AUTODETECT
 C3 1	MAINTENANCE	1.4 HDI 8v 50kw 8HX (02-08)	TEVES ABS MK70 AUTODETECT
 C3 1	MAINTENANCE	1.4 HDI 8v 50kw 8HX (02-08)	Valeo Body Computer MANUAL
 C3 1	MAINTENANCE	1.4 HDI 8v 50kw 8HZ (02-08)	A/T AL4 AUTODETECT
 C3 1	MAINTENANCE	1.4 HDI 8v 50kw 8HZ (02-08)	Body Computer BSI AUTODETECT
 C3 1	MAINTENANCE	1.4 HDI 8v 50kw 8HZ (02-08)	SAGEM Dashboard
 C3 1	MAINTENANCE	1.4 HDI 8v 50kw 8HZ (02-08)	Sagem/xx MANUAL
 C3 1	MAINTENANCE	1.4 HDI 8v 50kw 8HZ (02-08)	TEMIC AirBag
 C3 1	MAINTENANCE	1.4 HDI 8v 50kw 8HZ (02-08)	TEVES ABS MK60 AUTODETECT
 C3 1	MAINTENANCE	1.4 HDI 8v 50kw 8HZ (02-08)	TEVES ABS MK70 AUTODETECT
 C3 1	MAINTENANCE	1.4 HDI 8v 50kw 8HZ (02-08)	TEVES ABS MK70 AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C3 1	MAINTENANCE	1.4 HDI 8v 50kw 8HZ (02-08)	Valeo Body Computer MANUAL
 C3 1	MAINTENANCE	1.4 HDI 8v 50kw 8HZ (06-..)	A/T AL4 AUTODETECT
 C3 1	MAINTENANCE	1.4 HDI 8v 50kw 8HZ (06-..)	AirBag CENTRAL AUTODETECT
 C3 1	MAINTENANCE	1.4 HDI 8v 50kw 8HZ (06-..)	AirBag CENTRAL AUTODETECT
 C3 1	MAINTENANCE	1.4 HDI 8v 50kw 8HZ (06-..)	AUTODETECT
 C3 1	MAINTENANCE	1.4 HDI 8v 50kw 8HZ (06-..)	SAGEM Dashboard
 C3 1	MAINTENANCE	1.4 HDI 8v 50kw 8HZ (06-..)	SIEMENS Body Computer BSI
 C3 1	MAINTENANCE	1.4 HDI 8v 50kw 8HZ (06-..)	TEVES ABS MK70 New AUTODETECT
 C3 1	MAINTENANCE	1.4 HDI 8v 50kw 8HZ (06-..)	TEVES ESP MK60 AUTODETECT
 C3 1	MAINTENANCE	1.4 HDI 8v 50kw 8HZ (06-..)	TEVES ESP MK60 AUTODETECT
 C3 1	MAINTENANCE	1.4 HDI 8v 50kw 8HZ (06-..)	TEVES ESP MK60 New AUTODETECT
 C3 1	MAINTENANCE	1.4 HDI 8v 50kw 8HZ (06-..)	TEVES ESP MK60 New AUTODETECT
 C3 1	MAINTENANCE	1.6 16v 80kw N6A (02-08)	A/T AL4 AUTODETECT
 C3 1	MAINTENANCE	1.6 16v 80kw N6A (02-08)	Body Computer BSI AUTODETECT
 C3 1	MAINTENANCE	1.6 16v 80kw N6A (02-08)	TEVES ABS MK60 AUTODETECT
 C3 1	MAINTENANCE	1.6 16v 80kw N6A (02-08)	TEVES ESP MK60 AUTODETECT
 C3 1	MAINTENANCE	1.6 16v 80kw N6A (02-08)	TEVES ESP MK60 AUTODETECT
 C3 1	MAINTENANCE	1.6 16v 80kw NFU (02-08)	A/T AL4 AUTODETECT
 C3 1	MAINTENANCE	1.6 16v 80kw NFU (02-08)	Body Computer BSI AUTODETECT
 C3 1	MAINTENANCE	1.6 16v 80kw NFU (02-08)	SAGEM Dashboard
 C3 1	MAINTENANCE	1.6 16v 80kw NFU (02-08)	Sagem/xx MANUAL
 C3 1	MAINTENANCE	1.6 16v 80kw NFU (02-08)	TEMIC AirBag
 C3 1	MAINTENANCE	1.6 16v 80kw NFU (02-08)	TEVES ABS MK60 AUTODETECT
 C3 1	MAINTENANCE	1.6 16v 80kw NFU (02-08)	TEVES ESP MK60 AUTODETECT
 C3 1	MAINTENANCE	1.6 16v 80kw NFU (02-08)	TEVES ESP MK60 AUTODETECT
 C3 1	MAINTENANCE	1.6 16v 80kw NFU (02-08)	Valeo Body Computer MANUAL
 C3 1	MAINTENANCE	1.6 16v 80kw NFU (06-..)	A/T AL4 AUTODETECT
 C3 1	MAINTENANCE	1.6 16v 80kw NFU (06-..)	AirBag CENTRAL AUTODETECT
 C3 1	MAINTENANCE	1.6 16v 80kw NFU (06-..)	AirBag CENTRAL AUTODETECT
 C3 1	MAINTENANCE	1.6 16v 80kw NFU (06-..)	SAGEM Dashboard
 C3 1	MAINTENANCE	1.6 16v 80kw NFU (06-..)	SIEMENS Body Computer BSI
 C3 1	MAINTENANCE	1.6 16v 80kw NFU (06-..)	TEVES ABS MK70 New AUTODETECT
 C3 1	MAINTENANCE	1.6 16v 80kw NFU (06-..)	TEVES ESP MK60 AUTODETECT
 C3 1	MAINTENANCE	1.6 16v 80kw NFU (06-..)	TEVES ESP MK60 AUTODETECT
 C3 1	MAINTENANCE	1.6 16v 80kw NFU (06-..)	TEVES ESP MK60 New AUTODETECT
 C3 1	MAINTENANCE	1.6 16v 80kw NFU (06-..)	TEVES ESP MK60 New AUTODETECT
 C3 1	MAINTENANCE	1.6 HDI 16v 66kw 9HX (02-08)	A/T AL4 AUTODETECT
 C3 1	MAINTENANCE	1.6 HDI 16v 66kw 9HX (02-08)	Body Computer BSI AUTODETECT
 C3 1	MAINTENANCE	1.6 HDI 16v 66kw 9HX (02-08)	BOSCH EDC16 C34 Common Rail AUTOD
 C3 1	MAINTENANCE	1.6 HDI 16v 66kw 9HX (02-08)	BOSCH EDC16 C34 Common Rail AUTOD
 C3 1	MAINTENANCE	1.6 HDI 16v 66kw 9HX (02-08)	BOSCH EDC16 C34 Common Rail AUTOD
 C3 1	MAINTENANCE	1.6 HDI 16v 66kw 9HX (02-08)	BOSCH EDC16 C34 Common Rail AUTOD
 C3 1	MAINTENANCE	1.6 HDI 16v 66kw 9HX (02-08)	BOSCH EDC16 C34 Common Rail AUTOD
 C3 1	MAINTENANCE	1.6 HDI 16v 66kw 9HX (02-08)	BOSCH EDC16 C34 Common Rail AUTOD
 C3 1	MAINTENANCE	1.6 HDI 16v 66kw 9HX (02-08)	BOSCH EDC16 C34 Common Rail AUTOD
 C3 1	MAINTENANCE	1.6 HDI 16v 66kw 9HX (02-08)	TEVES ABS MK60 AUTODETECT
 C3 1	MAINTENANCE	1.6 HDI 16v 66kw 9HX (02-08)	TEVES ESP MK60 AUTODETECT
 C3 1	MAINTENANCE	1.6 HDI 16v 66kw 9HX (02-08)	TEVES ESP MK60 AUTODETECT
 C3 1	MAINTENANCE	1.6 HDI 16v 66kw 9HX (06-..)	AirBag CENTRAL AUTODETECT
 C3 1	MAINTENANCE	1.6 HDI 16v 66kw 9HX (06-..)	AirBag CENTRAL AUTODETECT
 C3 1	MAINTENANCE	1.6 HDI 16v 66kw 9HX (06-..)	AUTODETECT
 C3 1	MAINTENANCE	1.6 HDI 16v 66kw 9HX (06-..)	SAGEM Dashboard
 C3 1	MAINTENANCE	1.6 HDI 16v 66kw 9HX (06-..)	SIEMENS Body Computer BSI
 C3 1	MAINTENANCE	1.6 HDI 16v 66kw 9HX (06-..)	TEVES ABS MK70 New AUTODETECT
 C3 1	MAINTENANCE	1.6 HDI 16v 66kw 9HX (06-..)	TEVES ESP MK60 AUTODETECT
 C3 1	MAINTENANCE	1.6 HDI 16v 66kw 9HX (06-..)	TEVES ESP MK60 AUTODETECT
 C3 1	MAINTENANCE	1.6 HDI 16v 66kw 9HX (06-..)	TEVES ESP MK60 New AUTODETECT
 C3 1	MAINTENANCE	1.6 HDI 16v 66kw 9HX (06-..)	TEVES ESP MK60 New AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C3 1	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	A/T AL4 AUTODETECT
 C3 1	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	Body Computer BSI AUTODETECT
 C3 1	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	BOSCH EDC16 C34 Common Rail AUTOD
 C3 1	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	BOSCH EDC16 C34 Common Rail AUTOD
 C3 1	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	BOSCH EDC16 C34 Common Rail AUTOD
 C3 1	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	BOSCH EDC16 C34 Common Rail AUTOD
 C3 1	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	BOSCH EDC16 C34 Common Rail AUTOD
 C3 1	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	BOSCH EDC16 C34 Common Rail AUTOD
 C3 1	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	TEVES ABS MK60 AUTODETECT
 C3 1	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	TEVES ESP MK60 AUTODETECT
 C3 1	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	TEVES ESP MK60 AUTODETECT
 C3 1	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	A/T AL4 AUTODETECT
 C3 1	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	AirBag CENTRAL AUTODETECT
 C3 1	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	AirBag CENTRAL AUTODETECT
 C3 1	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	AUTODETECT
 C3 1	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	DIESEL AUTODETECT
 C3 1	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	DIESEL AUTODETECT
 C3 1	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	DIESEL AUTODETECT
 C3 1	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	DIESEL AUTODETECT
 C3 1	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	DIESEL AUTODETECT
 C3 1	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	DIESEL AUTODETECT
 C3 1	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	SAGEM Dashboard
 C3 1	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	SIEMENS Body Computer BSI
 C3 1	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	TEVES ABS MK70 New AUTODETECT
 C3 1	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	TEVES ESP MK60 AUTODETECT
 C3 1	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	TEVES ESP MK60 AUTODETECT
 C3 1	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	TEVES ESP MK60 New AUTODETECT
 C3 1	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	TEVES ESP MK60 New AUTODETECT
 C3 1	NAVIGATION	1.1 8v 44kw HFX (02-08)	AUTODETECT
 C3 1	NAVIGATION	1.1 8v 44kw HFX (06-..)	AUTODETECT
 C3 1	NAVIGATION	1.4 16v 66kw KFU (02-08)	AUTODETECT
 C3 1	NAVIGATION	1.4 16v 66kw KFU (06-..)	AUTODETECT
 C3 1	NAVIGATION	1.4 8v 55kw KFV (02-08)	AUTODETECT
 C3 1	NAVIGATION	1.4 8v 55kw KFV (06-..)	AUTODETECT
 C3 1	NAVIGATION	1.4 HDI 16v 66kw 8HY (02-08)	AUTODETECT
 C3 1	NAVIGATION	1.4 HDI 8v 50kw 8HX (02-08)	AUTODETECT
 C3 1	NAVIGATION	1.4 HDI 8v 50kw 8HZ (02-08)	AUTODETECT
 C3 1	NAVIGATION	1.4 HDI 8v 50kw 8HZ (06-..)	AUTODETECT
 C3 1	NAVIGATION	1.6 16v 80kw N6A (02-08)	AUTODETECT
 C3 1	NAVIGATION	1.6 16v 80kw NFU (02-08)	AUTODETECT
 C3 1	NAVIGATION	1.6 16v 80kw NFU (06-..)	AUTODETECT
 C3 1	NAVIGATION	1.6 HDI 16v 66kw 9HX (02-08)	AUTODETECT
 C3 1	NAVIGATION	1.6 HDI 16v 66kw 9HX (06-..)	AUTODETECT
 C3 1	NAVIGATION	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	AUTODETECT
 C3 1	NAVIGATION	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	AUTODETECT
 C3 1	PARKING HELP	1.1 8v 44kw HFX (02-08)	AUTODETECT
 C3 1	PARKING HELP	1.1 8v 44kw HFX (06-..)	AUTODETECT
 C3 1	PARKING HELP	1.4 16v 66kw KFU (02-08)	AUTODETECT
 C3 1	PARKING HELP	1.4 16v 66kw KFU (06-..)	AUTODETECT
 C3 1	PARKING HELP	1.4 8v 55kw KFV (02-08)	AUTODETECT
 C3 1	PARKING HELP	1.4 8v 55kw KFV (06-..)	AUTODETECT
 C3 1	PARKING HELP	1.4 HDI 16v 66kw 8HY (02-08)	AUTODETECT
 C3 1	PARKING HELP	1.4 HDI 8v 50kw 8HX (02-08)	AUTODETECT
 C3 1	PARKING HELP	1.4 HDI 8v 50kw 8HZ (02-08)	AUTODETECT
 C3 1	PARKING HELP	1.4 HDI 8v 50kw 8HZ (06-..)	AUTODETECT
 C3 1	PARKING HELP	1.6 16v 80kw N6A (02-08)	AUTODETECT
 C3 1	PARKING HELP	1.6 16v 80kw NFU (02-08)	AUTODETECT

Systems supported by ECUREADER / ECUDECODER (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C3 1	PARKING HELP	1.6 16v 80kw NFU (06-..)	AUTODETECT
 C3 1	PARKING HELP	1.6 HDI 16v 66kw 9HX (02-08)	AUTODETECT
 C3 1	PARKING HELP	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	AUTODETECT
 C3 1	PARKING HELP	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	AUTODETECT
 C3 1	PHONE	1.1 8v 44kw HFX (06-..)	AUTODETECT
 C3 1	PHONE	1.4 16v 66kw KFU (06-..)	AUTODETECT
 C3 1	PHONE	1.4 8v 55kw KFV (06-..)	AUTODETECT
 C3 1	PHONE	1.4 HDI 8v 50kw 8HZ (06-..)	AUTODETECT
 C3 1	PHONE	1.6 16v 80kw NFU (06-..)	AUTODETECT
 C3 1	PHONE	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	AUTODETECT
 C3 1	RADIO / CD	1.1 8v 44kw HFX (02-08)	AudioSystem AUTODETECT
 C3 1	RADIO / CD	1.1 8v 44kw HFX (02-08)	CD Changer AUTODETECT
 C3 1	RADIO / CD	1.1 8v 44kw HFX (02-08)	CLARION AudioSystem
 C3 1	RADIO / CD	1.1 8v 44kw HFX (02-08)	PHILIPS AudioSystem
 C3 1	RADIO / CD	1.1 8v 44kw HFX (02-08)	VDO AudioSystem
 C3 1	RADIO / CD	1.1 8v 44kw HFX (06-..)	AudioSystem AUTODETECT
 C3 1	RADIO / CD	1.1 8v 44kw HFX (06-..)	CD Changer AUTODETECT
 C3 1	RADIO / CD	1.4 16v 66kw KFU (02-08)	AudioSystem AUTODETECT
 C3 1	RADIO / CD	1.4 16v 66kw KFU (02-08)	CD Changer AUTODETECT
 C3 1	RADIO / CD	1.4 16v 66kw KFU (06-..)	AudioSystem AUTODETECT
 C3 1	RADIO / CD	1.4 16v 66kw KFU (06-..)	CD Changer AUTODETECT
 C3 1	RADIO / CD	1.4 8v 55kw KFV (02-08)	AudioSystem AUTODETECT
 C3 1	RADIO / CD	1.4 8v 55kw KFV (02-08)	CD Changer AUTODETECT
 C3 1	RADIO / CD	1.4 8v 55kw KFV (02-08)	CLARION AudioSystem
 C3 1	RADIO / CD	1.4 8v 55kw KFV (02-08)	PHILIPS AudioSystem
 C3 1	RADIO / CD	1.4 8v 55kw KFV (02-08)	VDO AudioSystem
 C3 1	RADIO / CD	1.4 8v 55kw KFV (06-..)	AudioSystem AUTODETECT
 C3 1	RADIO / CD	1.4 8v 55kw KFV (06-..)	CD Changer AUTODETECT
 C3 1	RADIO / CD	1.4 HDI 16v 66kw 8HY (02-08)	AudioSystem AUTODETECT
 C3 1	RADIO / CD	1.4 HDI 16v 66kw 8HY (02-08)	CD Changer AUTODETECT
 C3 1	RADIO / CD	1.4 HDI 16v 66kw 8HY (02-08)	CLARION AudioSystem
 C3 1	RADIO / CD	1.4 HDI 16v 66kw 8HY (02-08)	PHILIPS AudioSystem
 C3 1	RADIO / CD	1.4 HDI 16v 66kw 8HY (02-08)	VDO AudioSystem
 C3 1	RADIO / CD	1.4 HDI 8v 50kw 8HX (02-08)	AudioSystem AUTODETECT
 C3 1	RADIO / CD	1.4 HDI 8v 50kw 8HX (02-08)	CD Changer AUTODETECT
 C3 1	RADIO / CD	1.4 HDI 8v 50kw 8HX (02-08)	CLARION AudioSystem
 C3 1	RADIO / CD	1.4 HDI 8v 50kw 8HX (02-08)	PHILIPS AudioSystem
 C3 1	RADIO / CD	1.4 HDI 8v 50kw 8HX (02-08)	VDO AudioSystem
 C3 1	RADIO / CD	1.4 HDI 8v 50kw 8HZ (02-08)	AudioSystem AUTODETECT
 C3 1	RADIO / CD	1.4 HDI 8v 50kw 8HZ (02-08)	CD Changer AUTODETECT
 C3 1	RADIO / CD	1.4 HDI 8v 50kw 8HZ (02-08)	CLARION AudioSystem
 C3 1	RADIO / CD	1.4 HDI 8v 50kw 8HZ (02-08)	PHILIPS AudioSystem
 C3 1	RADIO / CD	1.4 HDI 8v 50kw 8HZ (02-08)	VDO AudioSystem
 C3 1	RADIO / CD	1.4 HDI 8v 50kw 8HZ (06-..)	AudioSystem AUTODETECT
 C3 1	RADIO / CD	1.4 HDI 8v 50kw 8HZ (06-..)	CD Changer AUTODETECT
 C3 1	RADIO / CD	1.6 16v 80kw N6A (02-08)	AudioSystem AUTODETECT
 C3 1	RADIO / CD	1.6 16v 80kw N6A (02-08)	CD Changer AUTODETECT
 C3 1	RADIO / CD	1.6 16v 80kw NFU (02-08)	AudioSystem AUTODETECT
 C3 1	RADIO / CD	1.6 16v 80kw NFU (02-08)	CD Changer AUTODETECT
 C3 1	RADIO / CD	1.6 16v 80kw NFU (02-08)	CLARION AudioSystem
 C3 1	RADIO / CD	1.6 16v 80kw NFU (02-08)	PHILIPS AudioSystem
 C3 1	RADIO / CD	1.6 16v 80kw NFU (02-08)	VDO AudioSystem
 C3 1	RADIO / CD	1.6 16v 80kw NFU (06-..)	AudioSystem AUTODETECT
 C3 1	RADIO / CD	1.6 16v 80kw NFU (06-..)	CD Changer AUTODETECT
 C3 1	RADIO / CD	1.6 HDI 16v 66kw 9HX (02-08)	AudioSystem AUTODETECT
 C3 1	RADIO / CD	1.6 HDI 16v 66kw 9HX (02-08)	CD Changer AUTODETECT
 C3 1	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	AudioSystem AUTODETECT
 C3 1	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	CD Changer AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C3 1	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	AudioSystem AUTODETECT
 C3 1	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	CD Changer AUTODETECT
 C3 1	RAIN-LUMINOSITY S	1.1 8v 44kw HFX (02-08)	AUTODETECT
 C3 1	RAIN-LUMINOSITY S	1.1 8v 44kw HFX (02-08)	KOSTAL WSS
 C3 1	RAIN-LUMINOSITY S	1.1 8v 44kw HFX (06-..)	AUTODETECT
 C3 1	RAIN-LUMINOSITY S	1.4 16v 66kw KFU (02-08)	AUTODETECT
 C3 1	RAIN-LUMINOSITY S	1.4 16v 66kw KFU (06-..)	AUTODETECT
 C3 1	RAIN-LUMINOSITY S	1.4 8v 55kw KFV (02-08)	AUTODETECT
 C3 1	RAIN-LUMINOSITY S	1.4 8v 55kw KFV (02-08)	KOSTAL WSS
 C3 1	RAIN-LUMINOSITY S	1.4 8v 55kw KFV (06-..)	AUTODETECT
 C3 1	RAIN-LUMINOSITY S	1.4 HDI 16v 66kw 8HY (02-08)	AUTODETECT
 C3 1	RAIN-LUMINOSITY S	1.4 HDI 16v 66kw 8HY (02-08)	KOSTAL WSS
 C3 1	RAIN-LUMINOSITY S	1.4 HDI 8v 50kw 8HX (02-08)	AUTODETECT
 C3 1	RAIN-LUMINOSITY S	1.4 HDI 8v 50kw 8HX (02-08)	KOSTAL WSS
 C3 1	RAIN-LUMINOSITY S	1.4 HDI 8v 50kw 8HZ (02-08)	AUTODETECT
 C3 1	RAIN-LUMINOSITY S	1.4 HDI 8v 50kw 8HZ (02-08)	KOSTAL WSS
 C3 1	RAIN-LUMINOSITY S	1.4 HDI 8v 50kw 8HZ (06-..)	AUTODETECT
 C3 1	RAIN-LUMINOSITY S	1.6 16v 80kw N6A (02-08)	AUTODETECT
 C3 1	RAIN-LUMINOSITY S	1.6 16v 80kw NFU (02-08)	AUTODETECT
 C3 1	RAIN-LUMINOSITY S	1.6 16v 80kw NFU (02-08)	KOSTAL WSS
 C3 1	RAIN-LUMINOSITY S	1.6 16v 80kw NFU (06-..)	AUTODETECT
 C3 1	RAIN-LUMINOSITY S	1.6 HDI 16v 66kw 9HX (02-08)	AUTODETECT
 C3 1	RAIN-LUMINOSITY S	1.6 HDI 16v 66kw 9HX (06-..)	AUTODETECT
 C3 1	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	AUTODETECT
 C3 1	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	AUTODETECT
 C3 1	REMOTE CONTROL E	1.1 8v 44kw HFX (02-08)	Valeo Body Computer MANUAL
 C3 1	REMOTE CONTROL E	1.4 8v 55kw KFV (02-08)	Valeo Body Computer MANUAL
 C3 1	REMOTE CONTROL E	1.4 HDI 16v 66kw 8HY (02-08)	Valeo Body Computer MANUAL
 C3 1	REMOTE CONTROL E	1.4 HDI 8v 50kw 8HX (02-08)	Valeo Body Computer MANUAL
 C3 1	REMOTE CONTROL E	1.4 HDI 8v 50kw 8HZ (02-08)	Valeo Body Computer MANUAL
 C3 1	REMOTE CONTROL E	1.6 16v 80kw NFU (02-08)	Valeo Body Computer MANUAL
 C3 1	SERVICE LIGHT RES	1.1 8v 44kw HFX (02-08)	Sagem/xx MANUAL
 C3 1	SERVICE LIGHT RES	1.4 8v 55kw KFV (02-08)	Sagem/xx MANUAL
 C3 1	SERVICE LIGHT RES	1.4 HDI 16v 66kw 8HY (02-08)	Sagem/xx MANUAL
 C3 1	SERVICE LIGHT RES	1.4 HDI 8v 50kw 8HX (02-08)	Sagem/xx MANUAL
 C3 1	SERVICE LIGHT RES	1.4 HDI 8v 50kw 8HZ (02-08)	Sagem/xx MANUAL
 C3 1	SERVICE LIGHT RES	1.6 16v 80kw NFU (02-08)	Sagem/xx MANUAL
 C3 1	STEERING COLUMN	1.1 8v 44kw HFX (02-08)	AUTODETECT
 C3 1	STEERING COLUMN	1.1 8v 44kw HFX (06-..)	AUTODETECT
 C3 1	STEERING COLUMN	1.4 16v 66kw KFU (02-08)	AUTODETECT
 C3 1	STEERING COLUMN	1.4 16v 66kw KFU (06-..)	AUTODETECT
 C3 1	STEERING COLUMN	1.4 8v 55kw KFV (02-08)	AUTODETECT
 C3 1	STEERING COLUMN	1.4 8v 55kw KFV (06-..)	AUTODETECT
 C3 1	STEERING COLUMN	1.4 HDI 16v 66kw 8HY (02-08)	AUTODETECT
 C3 1	STEERING COLUMN	1.4 HDI 8v 50kw 8HX (02-08)	AUTODETECT
 C3 1	STEERING COLUMN	1.4 HDI 8v 50kw 8HZ (02-08)	AUTODETECT
 C3 1	STEERING COLUMN	1.4 HDI 8v 50kw 8HZ (06-..)	AUTODETECT
 C3 1	STEERING COLUMN	1.6 16v 80kw N6A (02-08)	AUTODETECT
 C3 1	STEERING COLUMN	1.6 16v 80kw NFU (02-08)	AUTODETECT
 C3 1	STEERING COLUMN	1.6 16v 80kw NFU (06-..)	AUTODETECT
 C3 1	STEERING COLUMN	1.6 HDI 16v 66kw 9HX (02-08)	AUTODETECT
 C3 1	STEERING COLUMN	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	AUTODETECT
 C3 1	STEERING COLUMN	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	AUTODETECT
 C3 1	SWITCHLIGHT MODU	1.1 8v 44kw HFX (02-08)	EATON
 C3 1	SWITCHLIGHT MODU	1.1 8v 44kw HFX (06-..)	DELPHI 4.00
 C3 1	SWITCHLIGHT MODU	1.4 16v 66kw KFU (06-..)	DELPHI 4.00
 C3 1	SWITCHLIGHT MODU	1.4 8v 55kw KFV (02-08)	EATON
 C3 1	SWITCHLIGHT MODU	1.4 8v 55kw KFV (06-..)	DELPHI 4.00

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C3 1	SWITCHLIGHT MODU	1.4 HDI 16v 66kw 8HY (02-08)	EATON
 C3 1	SWITCHLIGHT MODU	1.4 HDI 8v 50kw 8HX (02-08)	EATON
 C3 1	SWITCHLIGHT MODU	1.4 HDI 8v 50kw 8HZ (02-08)	EATON
 C3 1	SWITCHLIGHT MODU	1.4 HDI 8v 50kw 8HZ (06-..)	DELPHI 4.00
 C3 1	SWITCHLIGHT MODU	1.6 16v 80kw NFU (02-08)	EATON
 C3 1	SWITCHLIGHT MODU	1.6 16v 80kw NFU (06-..)	DELPHI 4.00
 C3 1	SWITCHLIGHT MODU	1.6 HDI 16v 66kw 9HX (06-..)	DELPHI 4.00
 C3 1	SWITCHLIGHT MODU	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	DELPHI 4.00
 C3 1	VISUAL./TELEMATIC	1.1 8v 44kw HFX (02-08)	AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.1 8v 44kw HFX (02-08)	Display AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.1 8v 44kw HFX (02-08)	SAGEM JCAE
 C3 1	VISUAL./TELEMATIC	1.1 8v 44kw HFX (06-..)	Display A+ AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.1 8v 44kw HFX (06-..)	Display C- AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.4 16v 66kw KFU (02-08)	AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.4 16v 66kw KFU (02-08)	Display AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.4 16v 66kw KFU (06-..)	Display A+ AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.4 16v 66kw KFU (06-..)	Display C- AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.4 8v 55kw KFV (02-08)	AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.4 8v 55kw KFV (02-08)	Display AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.4 8v 55kw KFV (02-08)	SAGEM JCAE
 C3 1	VISUAL./TELEMATIC	1.4 8v 55kw KFV (06-..)	Display A+ AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.4 8v 55kw KFV (06-..)	Display C- AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.4 HDI 16v 66kw 8HY (02-08)	AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.4 HDI 16v 66kw 8HY (02-08)	Display AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.4 HDI 16v 66kw 8HY (02-08)	SAGEM JCAE
 C3 1	VISUAL./TELEMATIC	1.4 HDI 8v 50kw 8HX (02-08)	AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.4 HDI 8v 50kw 8HX (02-08)	Display AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.4 HDI 8v 50kw 8HX (02-08)	SAGEM JCAE
 C3 1	VISUAL./TELEMATIC	1.4 HDI 8v 50kw 8HZ (02-08)	AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.4 HDI 8v 50kw 8HZ (02-08)	Display AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.4 HDI 8v 50kw 8HZ (02-08)	SAGEM JCAE
 C3 1	VISUAL./TELEMATIC	1.4 HDI 8v 50kw 8HZ (06-..)	Display C- AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.4 HDI 8v 50kw 8HZ (06-..)	Display A+ AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.6 16v 80kw N6A (02-08)	AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.6 16v 80kw N6A (02-08)	Display AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.6 16v 80kw NFU (02-08)	AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.6 16v 80kw NFU (02-08)	Display AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.6 16v 80kw NFU (02-08)	SAGEM JCAE
 C3 1	VISUAL./TELEMATIC	1.6 16v 80kw NFU (06-..)	Display A+ AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.6 16v 80kw NFU (06-..)	Display C- AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HX (02-08)	AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HX (02-08)	Display AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HX (06-..)	Display A+ AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HX (06-..)	Display C- AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP (02-08)	Display AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	Display A+ AUTODETECT
 C3 1	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP (06-..)	Display C- AUTODETECT
 C3 A51	ABS + TRACT. CONT	1.4 16v 70kw 8FP (10-..)	TEVES MK60
 C3 A51	ABS + TRACT. CONT	1.4 16v 72kw Vti 8FR (10-..)	TEVES MK60
 C3 A51	ABS + TRACT. CONT	1.4 54kw KFT (10-..)	TEVES MK60
 C3 A51	ABS + TRACT. CONT	1.4 HDI 8v 50kw 8HZ (10-..)	TEVES MK60
 C3 A51	ABS + TRACT. CONT	1.6 16v 88kw 5FS (10-..)	TEVES MK60
 C3 A51	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX (10-..)	TEVES MK60
 C3 A51	ABS + TRACT. CONT	1.6 HDI 82kw 9HP-FAP (10-..)	TEVES MK60
 C3 A51	AIRBAG	1.1 44kw HFV (10-..)	AirBag CENTRAL AUTODETECT
 C3 A51	AIRBAG	1.4 16v 70kw 8FP (10-..)	AirBag CENTRAL AUTODETECT
 C3 A51	AIRBAG	1.4 16v 72kw Vti 8FR (10-..)	AirBag CENTRAL AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C3 A51	AIRBAG	1.4 54kw KFT (10-..)	AirBag CENTRAL AUTODETECT
 C3 A51	AIRBAG	1.4 HDI 8v 50kw 8HZ (10-..)	AirBag CENTRAL AUTODETECT
 C3 A51	AIRBAG	1.6 16v 88kw 5FS (10-..)	AirBag CENTRAL AUTODETECT
 C3 A51	AIRBAG	1.6 HDI 16v 66kw 9HX (10-..)	AirBag CENTRAL AUTODETECT
 C3 A51	AIRBAG	1.6 HDI 82kw 9HP-FAP (10-..)	AirBag CENTRAL AUTODETECT
 C3 A51	CLIMA	1.1 44kw HFV (10-..)	CLIMA AUTODETECT
 C3 A51	CLIMA	1.4 16v 70kw 8FP (10-..)	CLIMA AUTODETECT
 C3 A51	CLIMA	1.4 16v 72kw Vti 8FR (10-..)	CLIMA AUTODETECT
 C3 A51	CLIMA	1.4 54kw KFT (10-..)	CLIMA AUTODETECT
 C3 A51	CLIMA	1.4 HDI 8v 50kw 8HZ (10-..)	CLIMA AUTODETECT
 C3 A51	CLIMA	1.6 16v 88kw 5FS (10-..)	CLIMA AUTODETECT
 C3 A51	CLIMA	1.6 HDI 16v 66kw 9HX (10-..)	CLIMA AUTODETECT
 C3 A51	CLIMA	1.6 HDI 82kw 9HP-FAP (10-..)	CLIMA AUTODETECT
 C3 A51	ENGINE MANAGEME	1.1 44kw HFV (10-..)	EOBD
 C3 A51	ENGINE MANAGEME	1.4 16v 70kw 8FP (10-..)	EOBD
 C3 A51	ENGINE MANAGEME	1.4 16v 72kw Vti 8FR (10-..)	EOBD
 C3 A51	ENGINE MANAGEME	1.4 54kw KFT (10-..)	EOBD
 C3 A51	ENGINE MANAGEME	1.4 HDI 8v 50kw 8HZ (10-..)	EOBD
 C3 A51	ENGINE MANAGEME	1.6 16v 88kw 5FS (10-..)	EOBD
 C3 A51	ENGINE MANAGEME	1.6 HDI 16v 66kw 9HX (10-..)	EOBD
 C3 A51	ENGINE MANAGEME	1.6 HDI 82kw 9HP-FAP (10-..)	BOSCH EDC 17 C1 0 Common Rail
 C3 A51	PARKING HELP	1.1 44kw HFV (10-..)	
 C3 A51	PARKING HELP	1.4 16v 70kw 8FP (10-..)	
 C3 A51	PARKING HELP	1.4 16v 72kw Vti 8FR (10-..)	
 C3 A51	PARKING HELP	1.4 54kw KFT (10-..)	
 C3 A51	PARKING HELP	1.4 HDI 8v 50kw 8HZ (10-..)	
 C3 A51	PARKING HELP	1.6 16v 88kw 5FS (10-..)	
 C3 A51	PARKING HELP	1.6 HDI 16v 66kw 9HX (10-..)	
 C3 A51	PARKING HELP	1.6 HDI 82kw 9HP-FAP (10-..)	
 C3 Picasso	ABS + TRACT. CONT	1.4 16v 70kw 8FS	TEVES ABS MK 70.2 AUTODETECT
 C3 Picasso	ABS + TRACT. CONT	1.4 16v 70kw 8FS	TEVES ESP MK60 AUTODETECT
 C3 Picasso	ABS + TRACT. CONT	1.6 16v 88kw 5FW	TEVES ABS MK 70.2 AUTODETECT
 C3 Picasso	ABS + TRACT. CONT	1.6 16v 88kw 5FW	TEVES ESP MK60 AUTODETECT
 C3 Picasso	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX	TEVES ABS MK 70.2 AUTODETECT
 C3 Picasso	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX	TEVES ESP MK60 AUTODETECT
 C3 Picasso	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	TEVES ABS MK 70.2 AUTODETECT
 C3 Picasso	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	TEVES ESP MK60 AUTODETECT
 C3 Picasso	AIRBAG	1.4 16v 70kw 8FS	AirBag CENTRAL AUTODETECT
 C3 Picasso	AIRBAG	1.6 16v 88kw 5FW	AirBag CENTRAL AUTODETECT
 C3 Picasso	AIRBAG	1.6 HDI 16v 66kw 9HX	AirBag CENTRAL AUTODETECT
 C3 Picasso	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL AUTODETECT
 C3 Picasso	ANTITHEFT	1.4 16v 70kw 8FS	ALARME PSA2 AUTODETECT
 C3 Picasso	ANTITHEFT	1.6 16v 88kw 5FW	Alarm PSA2 AUTODETECT
 C3 Picasso	ANTITHEFT	1.6 HDI 16v 66kw 9HX	Alarm PSA2 AUTODETECT
 C3 Picasso	ANTITHEFT	1.6 HDI 16v 80kw 9HZ-FAP	Alarm PSA2 AUTODETECT
 C3 Picasso	CHASSIS NETWORK	1.4 16v 70kw 8FS	Body Computer BSI AUTODETECT
 C3 Picasso	CHASSIS NETWORK	1.4 16v 70kw 8FS	Body Computer BSM AUTODETECT
 C3 Picasso	CHASSIS NETWORK	1.4 16v 70kw 8FS	Body Computer BSR AUTODETECT
 C3 Picasso	CHASSIS NETWORK	1.6 16v 88kw 5FW	Body Computer BSI AUTODETECT
 C3 Picasso	CHASSIS NETWORK	1.6 16v 88kw 5FW	Body Computer BSM AUTODETECT
 C3 Picasso	CHASSIS NETWORK	1.6 16v 88kw 5FW	Body Computer BSR AUTODETECT
 C3 Picasso	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	Body Computer BSI AUTODETECT
 C3 Picasso	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	Body Computer BSM AUTODETECT
 C3 Picasso	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	Body Computer BSR AUTODETECT
 C3 Picasso	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSI AUTODETECT
 C3 Picasso	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSM AUTODETECT
 C3 Picasso	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSR AUTODETECT
 C3 Picasso	CLIMA	1.4 16v 70kw 8FS	CLIMA AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C3 Picasso	CLIMA	1.6 16v 88kw 5FW	CLIMA AUTODETECT
 C3 Picasso	CLIMA	1.6 HDI 16v 66kw 9HX	CLIMA AUTODETECT
 C3 Picasso	CLIMA	1.6 HDI 16v 80kw 9HZ-FAP	CLIMA AUTODETECT
 C3 Picasso	DASHBOARD	1.4 16v 70kw 8FS	AUTODETECT
 C3 Picasso	DASHBOARD	1.6 16v 88kw 5FW	AUTODETECT
 C3 Picasso	DASHBOARD	1.6 HDI 16v 66kw 9HX	AUTODETECT
 C3 Picasso	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C3 Picasso	DIESEL ADDITION	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C3 Picasso	DRIVER SIDE DOOR	1.4 16v 70kw 8FS	AUTODETECT
 C3 Picasso	DRIVER SIDE DOOR	1.6 16v 88kw 5FW	AUTODETECT
 C3 Picasso	DRIVER SIDE DOOR	1.6 HDI 16v 66kw 9HX	AUTODETECT
 C3 Picasso	DRIVER SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C3 Picasso	ELECTRIC STEERING	1.4 16v 70kw 8FS	AUTODETECT
 C3 Picasso	ELECTRIC STEERING	1.6 16v 88kw 5FW	AUTODETECT
 C3 Picasso	ELECTRIC STEERING	1.6 HDI 16v 66kw 9HX	AUTODETECT
 C3 Picasso	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C3 Picasso	ENGINE MANAGEME	1.4 16v 70kw 8FS	BOSCH MEV 17.4 AUTODETECT
 C3 Picasso	ENGINE MANAGEME	1.6 16v 88kw 5FW	BOSCH MEV 17.4 AUTODETECT
 C3 Picasso	ENGINE MANAGEME	1.6 HDI 16v 66kw 9HX	BOSCH EDC16 C34 Common Rail AUTOD
 C3 Picasso	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 C3 Picasso	MAINTENANCE	1.4 16v 70kw 8FS	TEVES ESP MK60 AUTODETECT
 C3 Picasso	MAINTENANCE	1.4 16v 70kw 8FS	TEVES ESP MK60 AUTODETECT
 C3 Picasso	MAINTENANCE	1.6 16v 88kw 5FW	TEVES ESP MK60 AUTODETECT
 C3 Picasso	MAINTENANCE	1.6 16v 88kw 5FW	TEVES ESP MK60 AUTODETECT
 C3 Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC16 C34 Common Rail AUTOD
 C3 Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC16 C34 Common Rail AUTOD
 C3 Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC16 C34 Common Rail AUTOD
 C3 Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC16 C34 Common Rail AUTOD
 C3 Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC16 C34 Common Rail AUTOD
 C3 Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC16 C34 Common Rail AUTOD
 C3 Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX	TEVES ESP MK60 AUTODETECT
 C3 Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX	TEVES ESP MK60 AUTODETECT
 C3 Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C3 Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 C3 Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 C3 Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 C3 Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 C3 Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 C3 Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	TEVES ESP MK60 AUTODETECT
 C3 Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	TEVES ESP MK60 AUTODETECT
 C3 Picasso	NAVIGATION	1.4 16v 70kw 8FS	AUTODETECT
 C3 Picasso	NAVIGATION	1.6 16v 88kw 5FW	AUTODETECT
 C3 Picasso	NAVIGATION	1.6 HDI 16v 66kw 9HX	AUTODETECT
 C3 Picasso	NAVIGATION	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C3 Picasso	PARKING HELP	1.4 16v 70kw 8FS	AUTODETECT
 C3 Picasso	PARKING HELP	1.6 16v 88kw 5FW	AUTODETECT
 C3 Picasso	PARKING HELP	1.6 HDI 16v 66kw 9HX	AUTODETECT
 C3 Picasso	PARKING HELP	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C3 Picasso	PHONE	1.4 16v 70kw 8FS	AUTODETECT
 C3 Picasso	PHONE	1.4 16v 70kw 8FS	AUTODETECT
 C3 Picasso	PHONE	1.6 16v 88kw 5FW	AUTODETECT
 C3 Picasso	PHONE	1.6 16v 88kw 5FW	AUTODETECT
 C3 Picasso	PHONE	1.6 HDI 16v 66kw 9HX	AUTODETECT
 C3 Picasso	PHONE	1.6 HDI 16v 66kw 9HX	AUTODETECT
 C3 Picasso	PHONE	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C3 Picasso	PHONE	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C3 Picasso	RADIO / CD	1.4 16v 70kw 8FS	AudioSystem AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C3 Picasso	RADIO / CD	1.6 16v 88kw 5FW	AudioSystem AUTODETECT
 C3 Picasso	RADIO / CD	1.6 HDI 16v 66kw 9HX	AudioSystem AUTODETECT
 C3 Picasso	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	AudioSystem AUTODETECT
 C3 Picasso	RAIN-LUMINOSITY S	1.4 16v 70kw 8FS	AUTODETECT
 C3 Picasso	RAIN-LUMINOSITY S	1.6 16v 88kw 5FW	AUTODETECT
 C3 Picasso	RAIN-LUMINOSITY S	1.6 HDI 16v 66kw 9HX	AUTODETECT
 C3 Picasso	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C3 Picasso	STEERING COLUMN	1.4 16v 70kw 8FS	AUTODETECT
 C3 Picasso	STEERING COLUMN	1.6 16v 88kw 5FW	AUTODETECT
 C3 Picasso	STEERING COLUMN	1.6 HDI 16v 66kw 9HX	AUTODETECT
 C3 Picasso	STEERING COLUMN	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C3 Picasso	VISUAL./TELEMATIC	1.4 16v 70kw 8FS	Display A+ AUTODETECT
 C3 Picasso	VISUAL./TELEMATIC	1.4 16v 70kw 8FS	Display C- AUTODETECT
 C3 Picasso	VISUAL./TELEMATIC	1.6 16v 88kw 5FW	Display A+ AUTODETECT
 C3 Picasso	VISUAL./TELEMATIC	1.6 16v 88kw 5FW	Display C- AUTODETECT
 C3 Picasso	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HX	Display A+ AUTODETECT
 C3 Picasso	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HX	Display C- AUTODETECT
 C3 Picasso	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	Display A+ AUTODETECT
 C3 Picasso	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	Display C- AUTODETECT
 C3 Pluriel	ABS	1.4 8v 55kw KFV	TEVES ABS Mk60
 C3 Pluriel	ABS	1.4 8v 55kw KFV	TEVES ABS Mk70
 C3 Pluriel	ABS	1.4 HDI 8v 50kw 8HX	TEVES ABS Mk60
 C3 Pluriel	ABS	1.4 HDI 8v 50kw 8HX	TEVES ABS Mk70
 C3 Pluriel	ABS	1.4 HDI 8v 50kw 8HZ	TEVES ABS Mk60
 C3 Pluriel	ABS	1.4 HDI 8v 50kw 8HZ	TEVES ABS Mk70
 C3 Pluriel	ABS	1.6 16v 82kw NFU	TEVES ABS Mk60
 C3 Pluriel	ABS	1.6 16v 82kw NFU	TEVES ABS Mk70
 C3 Pluriel	ABS + TRACT. CONT	1.4 8v 55kw KFV	TEVES ABS MK70 AUTODETECT
 C3 Pluriel	ABS + TRACT. CONT	1.4 8v 55kw KFV	TEVES ABS MK70 New AUTODETECT
 C3 Pluriel	ABS + TRACT. CONT	1.4 8v 55kw KFV	TEVES ESP MK60 AUTODETECT
 C3 Pluriel	ABS + TRACT. CONT	1.4 8v 55kw KFV	TEVES ESP MK60 New AUTODETECT
 C3 Pluriel	ABS + TRACT. CONT	1.4 HDI 8v 50kw 8HX	TEVES ABS MK70 AUTODETECT
 C3 Pluriel	ABS + TRACT. CONT	1.4 HDI 8v 50kw 8HX	TEVES ABS MK70 New AUTODETECT
 C3 Pluriel	ABS + TRACT. CONT	1.4 HDI 8v 50kw 8HX	TEVES ESP MK60 AUTODETECT
 C3 Pluriel	ABS + TRACT. CONT	1.4 HDI 8v 50kw 8HX	TEVES ESP MK60 New AUTODETECT
 C3 Pluriel	ABS + TRACT. CONT	1.4 HDI 8v 50kw 8HZ	TEVES ABS MK70 AUTODETECT
 C3 Pluriel	ABS + TRACT. CONT	1.4 HDI 8v 50kw 8HZ	TEVES ABS MK70 New AUTODETECT
 C3 Pluriel	ABS + TRACT. CONT	1.4 HDI 8v 50kw 8HZ	TEVES ESP MK60 AUTODETECT
 C3 Pluriel	ABS + TRACT. CONT	1.4 HDI 8v 50kw 8HZ	TEVES ESP MK60 New AUTODETECT
 C3 Pluriel	ABS + TRACT. CONT	1.6 16v 82kw NFU	TEVES ABS MK70 AUTODETECT
 C3 Pluriel	ABS + TRACT. CONT	1.6 16v 82kw NFU	TEVES ABS MK70 New AUTODETECT
 C3 Pluriel	ABS + TRACT. CONT	1.6 16v 82kw NFU	TEVES ESP MK60 AUTODETECT
 C3 Pluriel	ABS + TRACT. CONT	1.6 16v 82kw NFU	TEVES ESP MK60 New AUTODETECT
 C3 Pluriel	AIRBAG	1.4 8v 55kw KFV	AirBag CENTRAL AUTODETECT
 C3 Pluriel	AIRBAG	1.4 8v 55kw KFV	TEMIC AirBag
 C3 Pluriel	AIRBAG	1.4 HDI 8v 50kw 8HX	AirBag CENTRAL AUTODETECT
 C3 Pluriel	AIRBAG	1.4 HDI 8v 50kw 8HX	TEMIC AirBag
 C3 Pluriel	AIRBAG	1.4 HDI 8v 50kw 8HZ	AirBag CENTRAL AUTODETECT
 C3 Pluriel	AIRBAG	1.4 HDI 8v 50kw 8HZ	TEMIC AirBag
 C3 Pluriel	AIRBAG	1.6 16v 82kw NFU	AirBag CENTRAL AUTODETECT
 C3 Pluriel	AIRBAG	1.6 16v 82kw NFU	TEMIC AirBag
 C3 Pluriel	ANTITHEFT	1.4 8v 55kw KFV	Alarm PSA2 AUTODETECT
 C3 Pluriel	ANTITHEFT	1.4 HDI 8v 50kw 8HX	Alarm PSA2 AUTODETECT
 C3 Pluriel	ANTITHEFT	1.4 HDI 8v 50kw 8HZ	Alarm PSA2 AUTODETECT
 C3 Pluriel	ANTITHEFT	1.6 16v 82kw NFU	Alarm PSA2 AUTODETECT
 C3 Pluriel	AUTOM. TRANSMISSI	1.4 8v 55kw KFV	A/T Manual Pilot AUTODETECT
 C3 Pluriel	AUTOM. TRANSMISSI	1.4 HDI 8v 50kw 8HX	A/T Manual Pilot AUTODETECT
 C3 Pluriel	AUTOM. TRANSMISSI	1.4 HDI 8v 50kw 8HZ	A/T Manual Pilot AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C3 Pluriel	AUTOM. TRANSMISSI	1.6 16v 82kw NFU	A/T Manual Pilot AUTODETECT
 C3 Pluriel	CHASSIS NETWORK	1.4 8v 55kw KFV	Body Computer BSI AUTODETECT
 C3 Pluriel	CHASSIS NETWORK	1.4 8v 55kw KFV	Body Computer BSM AUTODETECT
 C3 Pluriel	CHASSIS NETWORK	1.4 8v 55kw KFV	Body Computer BSR AUTODETECT
 C3 Pluriel	CHASSIS NETWORK	1.4 8v 55kw KFV	High frequency receiver AUTODETECT
 C3 Pluriel	CHASSIS NETWORK	1.4 8v 55kw KFV	SIEMENS Body Computer
 C3 Pluriel	CHASSIS NETWORK	1.4 8v 55kw KFV	STOP/START System AUTODETECT
 C3 Pluriel	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HX	Body Computer BSI AUTODETECT
 C3 Pluriel	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HX	Body Computer BSM AUTODETECT
 C3 Pluriel	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HX	Body Computer BSR AUTODETECT
 C3 Pluriel	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HX	High frequency receiver AUTODETECT
 C3 Pluriel	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HX	SIEMENS Body Computer
 C3 Pluriel	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HX	STOP/START System AUTODETECT
 C3 Pluriel	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HZ	Body Computer BSI AUTODETECT
 C3 Pluriel	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HZ	Body Computer BSM AUTODETECT
 C3 Pluriel	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HZ	Body Computer BSR AUTODETECT
 C3 Pluriel	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HZ	High frequency receiver AUTODETECT
 C3 Pluriel	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HZ	SIEMENS Body Computer
 C3 Pluriel	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HZ	STOP/START System AUTODETECT
 C3 Pluriel	CHASSIS NETWORK	1.6 16v 82kw NFU	Body Computer BSI AUTODETECT
 C3 Pluriel	CHASSIS NETWORK	1.6 16v 82kw NFU	Body Computer BSM AUTODETECT
 C3 Pluriel	CHASSIS NETWORK	1.6 16v 82kw NFU	Body Computer BSR AUTODETECT
 C3 Pluriel	CHASSIS NETWORK	1.6 16v 82kw NFU	High Frequency receiver AUTODETECT
 C3 Pluriel	CHASSIS NETWORK	1.6 16v 82kw NFU	SIEMENS Body Computer
 C3 Pluriel	CHASSIS NETWORK	1.6 16v 82kw NFU	STOP/START System AUTODETECT
 C3 Pluriel	CLIMA	1.4 8v 55kw KFV	CLIMA AUTO AUTODETECT
 C3 Pluriel	CLIMA	1.4 8v 55kw KFV	CLIMA AUTODETECT
 C3 Pluriel	CLIMA	1.4 8v 55kw KFV	klimautomatik x.x
 C3 Pluriel	CLIMA	1.4 HDI 8v 50kw 8HX	CLIMA AUTO AUTODETECT
 C3 Pluriel	CLIMA	1.4 HDI 8v 50kw 8HX	CLIMA AUTODETECT
 C3 Pluriel	CLIMA	1.4 HDI 8v 50kw 8HX	klimautomatik x.x
 C3 Pluriel	CLIMA	1.4 HDI 8v 50kw 8HZ	CLIMA AUTO AUTODETECT
 C3 Pluriel	CLIMA	1.4 HDI 8v 50kw 8HZ	CLIMA AUTODETECT
 C3 Pluriel	CLIMA	1.4 HDI 8v 50kw 8HZ	klimautomatik x.x
 C3 Pluriel	CLIMA	1.6 16v 82kw NFU	CLIMA AUTO AUTODETECT
 C3 Pluriel	CLIMA	1.6 16v 82kw NFU	CLIMA AUTODETECT
 C3 Pluriel	CLIMA	1.6 16v 82kw NFU	klimautomatik x.x
 C3 Pluriel	CONV. TOP/SUNROO	1.4 8v 55kw KFV	AUTODETECT
 C3 Pluriel	CONV. TOP/SUNROO	1.4 8v 55kw KFV	INALFA Roof
 C3 Pluriel	CONV. TOP/SUNROO	1.4 HDI 8v 50kw 8HX	AUTODETECT
 C3 Pluriel	CONV. TOP/SUNROO	1.4 HDI 8v 50kw 8HX	INALFA Roof
 C3 Pluriel	CONV. TOP/SUNROO	1.4 HDI 8v 50kw 8HZ	AUTODETECT
 C3 Pluriel	CONV. TOP/SUNROO	1.4 HDI 8v 50kw 8HZ	INALFA Roof
 C3 Pluriel	CONV. TOP/SUNROO	1.6 16v 82kw NFU	AUTODETECT
 C3 Pluriel	CONV. TOP/SUNROO	1.6 16v 82kw NFU	INALFA Roof
 C3 Pluriel	DASHBOARD	1.4 8v 55kw KFV	AUTODETECT
 C3 Pluriel	DASHBOARD	1.4 8v 55kw KFV	SAGEM Dashboard
 C3 Pluriel	DASHBOARD	1.4 HDI 8v 50kw 8HX	AUTODETECT
 C3 Pluriel	DASHBOARD	1.4 HDI 8v 50kw 8HX	SAGEM Dashboard
 C3 Pluriel	DASHBOARD	1.4 HDI 8v 50kw 8HZ	AUTODETECT
 C3 Pluriel	DASHBOARD	1.4 HDI 8v 50kw 8HZ	SAGEM Dashboard
 C3 Pluriel	DASHBOARD	1.6 16v 82kw NFU	AUTODETECT
 C3 Pluriel	DASHBOARD	1.6 16v 82kw NFU	SAGEM Dashboard
 C3 Pluriel	ELECTRIC STEERING	1.4 8v 55kw KFV	AUTODETECT
 C3 Pluriel	ELECTRIC STEERING	1.4 8v 55kw KFV	KOYO EPS
 C3 Pluriel	ELECTRIC STEERING	1.4 HDI 8v 50kw 8HX	AUTODETECT
 C3 Pluriel	ELECTRIC STEERING	1.4 HDI 8v 50kw 8HX	KOYO EPS
 C3 Pluriel	ELECTRIC STEERING	1.4 HDI 8v 50kw 8HZ	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C3 Pluriel	ELECTRIC STEERING	1.4 HDI 8v 50kw 8HZ	KOYO EPS
 C3 Pluriel	ELECTRIC STEERING	1.6 16v 82kw NFU	AUTODETECT
 C3 Pluriel	ELECTRIC STEERING	1.6 16v 82kw NFU	KOYO EPS
 C3 Pluriel	ENGINE MANAGEME	1.4 8v 55kw KfV	SAGEM J34P AUTODETECT
 C3 Pluriel	ENGINE MANAGEME	1.4 8v 55kw KfV	SAGEM S2000 PM1 AUTODETECT
 C3 Pluriel	ENGINE MANAGEME	1.4 8v 55kw KfV	SAGEM S2000 PM2 AUTODETECT
 C3 Pluriel	ENGINE MANAGEME	1.4 8v 55kw KfV	SAGEM S2000PM2
 C3 Pluriel	ENGINE MANAGEME	1.4 HDI 8v 50kw 8HX	SIEMENS Diesel SID 804 Common Rail
 C3 Pluriel	ENGINE MANAGEME	1.4 HDI 8v 50kw 8HX	SIEMENS SID804 Common Rail AUTODET
 C3 Pluriel	ENGINE MANAGEME	1.4 HDI 8v 50kw 8HZ	BOSCH EDC 16 C34 Common Rail AUTOD
 C3 Pluriel	ENGINE MANAGEME	1.4 HDI 8v 50kw 8HZ	SIEMENS SID804 Common Rail AUTODET
 C3 Pluriel	ENGINE MANAGEME	1.4 HDI 8v 50kw 8HZ	SIEMENS SID806 Common Rail AUTODET
 C3 Pluriel	ENGINE MANAGEME	1.4 HDI 8v 50kw 8HZ (02-..)	BOSCH EDC 16 C3 Common Rail
 C3 Pluriel	ENGINE MANAGEME	1.6 16v 82kw NFU	BOSCH ME 7.4.4 AUTODETECT
 C3 Pluriel	ENGINE MANAGEME	1.6 16v 82kw NFU	BOSCH ME 7.4.5 AUTODETECT
 C3 Pluriel	ENGINE MANAGEME	1.6 16v 82kw NFU	BOSCH Motronic ME7.4.4
 C3 Pluriel	KEY ENCODE	1.4 8v 55kw KfV	VALEO Body Siemens
 C3 Pluriel	KEY ENCODE	1.4 HDI 8v 50kw 8HX	VALEO Body Siemens
 C3 Pluriel	KEY ENCODE	1.4 HDI 8v 50kw 8HZ	VALEO Body Siemens
 C3 Pluriel	KEY ENCODE	1.6 16v 82kw NFU	VALEO Body Siemens
 C3 Pluriel	MAINTENANCE	1.4 8v 55kw KfV	SAGEM Dashboard
 C3 Pluriel	MAINTENANCE	1.4 8v 55kw KfV	TEMIC AirBag
 C3 Pluriel	MAINTENANCE	1.4 8v 55kw KfV	TEVES ABS MK70 New AUTODETECT
 C3 Pluriel	MAINTENANCE	1.4 8v 55kw KfV	TEVES ESP MK60 AUTODETECT
 C3 Pluriel	MAINTENANCE	1.4 8v 55kw KfV	TEVES ESP MK60 AUTODETECT
 C3 Pluriel	MAINTENANCE	1.4 8v 55kw KfV	TEVES ESP MK60 New AUTODETECT
 C3 Pluriel	MAINTENANCE	1.4 8v 55kw KfV	TEVES ESP MK60 New AUTODETECT
 C3 Pluriel	MAINTENANCE	1.4 8v 55kw KfV (01-..)	Sagem/xx MANUAL
 C3 Pluriel	MAINTENANCE	1.4 8v 55kw KfV (02-..)	VALEO Body Computer MANUAL
 C3 Pluriel	MAINTENANCE	1.4 HDI 8v 50kw 8HX	SAGEM Dashboard
 C3 Pluriel	MAINTENANCE	1.4 HDI 8v 50kw 8HX	TEMIC AirBag
 C3 Pluriel	MAINTENANCE	1.4 HDI 8v 50kw 8HX	TEVES ABS MK70 New AUTODETECT
 C3 Pluriel	MAINTENANCE	1.4 HDI 8v 50kw 8HX	TEVES ESP MK60 AUTODETECT
 C3 Pluriel	MAINTENANCE	1.4 HDI 8v 50kw 8HX	TEVES ESP MK60 AUTODETECT
 C3 Pluriel	MAINTENANCE	1.4 HDI 8v 50kw 8HX	TEVES ESP MK60 New AUTODETECT
 C3 Pluriel	MAINTENANCE	1.4 HDI 8v 50kw 8HX	TEVES ESP MK60 New AUTODETECT
 C3 Pluriel	MAINTENANCE	1.4 HDI 8v 50kw 8HX (01-..)	Sagem/xx MANUAL
 C3 Pluriel	MAINTENANCE	1.4 HDI 8v 50kw 8HX (02-..)	VALEO Body Computer MANUAL
 C3 Pluriel	MAINTENANCE	1.4 HDI 8v 50kw 8HZ	SAGEM Dashboard
 C3 Pluriel	MAINTENANCE	1.4 HDI 8v 50kw 8HZ	TEMIC AirBag
 C3 Pluriel	MAINTENANCE	1.4 HDI 8v 50kw 8HZ	TEVES ABS MK70 New AUTODETECT
 C3 Pluriel	MAINTENANCE	1.4 HDI 8v 50kw 8HZ	TEVES ESP MK60 AUTODETECT
 C3 Pluriel	MAINTENANCE	1.4 HDI 8v 50kw 8HZ	TEVES ESP MK60 AUTODETECT
 C3 Pluriel	MAINTENANCE	1.4 HDI 8v 50kw 8HZ	TEVES ESP MK60 New AUTODETECT
 C3 Pluriel	MAINTENANCE	1.4 HDI 8v 50kw 8HZ	TEVES ESP MK60 New AUTODETECT
 C3 Pluriel	MAINTENANCE	1.4 HDI 8v 50kw 8HZ (01-..)	Sagem/xx MANUAL
 C3 Pluriel	MAINTENANCE	1.4 HDI 8v 50kw 8HZ (02-..)	VALEO Body Computer MANUAL
 C3 Pluriel	MAINTENANCE	1.6 16v 82kw NFU	SAGEM Dashboard
 C3 Pluriel	MAINTENANCE	1.6 16v 82kw NFU	TEMIC AirBag
 C3 Pluriel	MAINTENANCE	1.6 16v 82kw NFU	TEVES ABS MK70 New AUTODETECT
 C3 Pluriel	MAINTENANCE	1.6 16v 82kw NFU	TEVES ESP MK60 AUTODETECT
 C3 Pluriel	MAINTENANCE	1.6 16v 82kw NFU	TEVES ESP MK60 AUTODETECT
 C3 Pluriel	MAINTENANCE	1.6 16v 82kw NFU	TEVES ESP MK60 New AUTODETECT
 C3 Pluriel	MAINTENANCE	1.6 16v 82kw NFU	TEVES ESP MK60 New AUTODETECT
 C3 Pluriel	MAINTENANCE	1.6 16v 82kw NFU (01-..)	Sagem/xx MANUAL
 C3 Pluriel	MAINTENANCE	1.6 16v 82kw NFU (02-..)	VALEO Body Computer MANUAL
 C3 Pluriel	NAVIGATION	1.4 8v 55kw KfV	AUTODETECT
 C3 Pluriel	NAVIGATION	1.4 8v 55kw KfV	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C3 Pluriel	NAVIGATION	1.4 HDI 8v 50kw 8HX	AUTODETECT
 C3 Pluriel	NAVIGATION	1.4 HDI 8v 50kw 8HX	AUTODETECT
 C3 Pluriel	NAVIGATION	1.4 HDI 8v 50kw 8HZ	AUTODETECT
 C3 Pluriel	NAVIGATION	1.4 HDI 8v 50kw 8HZ	AUTODETECT
 C3 Pluriel	NAVIGATION	1.6 16v 82kw NFU	AUTODETECT
 C3 Pluriel	NAVIGATION	1.6 16v 82kw NFU	AUTODETECT
 C3 Pluriel	PARKING HELP	1.4 8v 55kw KFV	AUTODETECT
 C3 Pluriel	PARKING HELP	1.4 HDI 8v 50kw 8HX	AUTODETECT
 C3 Pluriel	PARKING HELP	1.4 HDI 8v 50kw 8HZ	AUTODETECT
 C3 Pluriel	PARKING HELP	1.6 16v 82kw NFU	AUTODETECT
 C3 Pluriel	PHONE	1.4 8v 55kw KFV	AUTODETECT
 C3 Pluriel	PHONE	1.4 HDI 8v 50kw 8HX	AUTODETECT
 C3 Pluriel	PHONE	1.4 HDI 8v 50kw 8HZ	AUTODETECT
 C3 Pluriel	PHONE	1.6 16v 82kw NFU	AUTODETECT
 C3 Pluriel	RADIO / CD	1.4 8v 55kw KFV	AudioSystem AUTODETECT
 C3 Pluriel	RADIO / CD	1.4 8v 55kw KFV	CD Changer AUTODETECT
 C3 Pluriel	RADIO / CD	1.4 8v 55kw KFV	CLARION AudioSystem
 C3 Pluriel	RADIO / CD	1.4 8v 55kw KFV	PHILIPS AudioSystem
 C3 Pluriel	RADIO / CD	1.4 8v 55kw KFV	VDO AudioSystem
 C3 Pluriel	RADIO / CD	1.4 HDI 8v 50kw 8HX	AudioSystem AUTODETECT
 C3 Pluriel	RADIO / CD	1.4 HDI 8v 50kw 8HX	CD Changer AUTODETECT
 C3 Pluriel	RADIO / CD	1.4 HDI 8v 50kw 8HX	CLARION AudioSystem
 C3 Pluriel	RADIO / CD	1.4 HDI 8v 50kw 8HX	PHILIPS AudioSystem
 C3 Pluriel	RADIO / CD	1.4 HDI 8v 50kw 8HX	VDO AudioSystem
 C3 Pluriel	RADIO / CD	1.4 HDI 8v 50kw 8HZ	AudioSystem AUTODETECT
 C3 Pluriel	RADIO / CD	1.4 HDI 8v 50kw 8HZ	CD Changer AUTODETECT
 C3 Pluriel	RADIO / CD	1.4 HDI 8v 50kw 8HZ	CLARION AudioSystem
 C3 Pluriel	RADIO / CD	1.4 HDI 8v 50kw 8HZ	PHILIPS AudioSystem
 C3 Pluriel	RADIO / CD	1.4 HDI 8v 50kw 8HZ	VDO AudioSystem
 C3 Pluriel	RADIO / CD	1.6 16v 82kw NFU	AudioSystem AUTODETECT
 C3 Pluriel	RADIO / CD	1.6 16v 82kw NFU	CD Changer AUTODETECT
 C3 Pluriel	RADIO / CD	1.6 16v 82kw NFU	CLARION AudioSystem
 C3 Pluriel	RADIO / CD	1.6 16v 82kw NFU	PHILIPS AudioSystem
 C3 Pluriel	RADIO / CD	1.6 16v 82kw NFU	VDO AudioSystem
 C3 Pluriel	RAIN-LUMINOSITY S	1.4 8v 55kw KFV	AUTODETECT
 C3 Pluriel	RAIN-LUMINOSITY S	1.4 8v 55kw KFV	KOSTAL WSS
 C3 Pluriel	RAIN-LUMINOSITY S	1.4 HDI 8v 50kw 8HX	AUTODETECT
 C3 Pluriel	RAIN-LUMINOSITY S	1.4 HDI 8v 50kw 8HX	KOSTAL WSS
 C3 Pluriel	RAIN-LUMINOSITY S	1.4 HDI 8v 50kw 8HZ	AUTODETECT
 C3 Pluriel	RAIN-LUMINOSITY S	1.4 HDI 8v 50kw 8HZ	KOSTAL WSS
 C3 Pluriel	RAIN-LUMINOSITY S	1.6 16v 82kw NFU	AUTODETECT
 C3 Pluriel	RAIN-LUMINOSITY S	1.6 16v 82kw NFU	KOSTAL WSS
 C3 Pluriel	REMOTE CONTROL E	1.4 8v 55kw KFV (02-..)	VALEO Body Computer MANUAL
 C3 Pluriel	REMOTE CONTROL E	1.4 HDI 8v 50kw 8HX (02-..)	VALEO Body Computer MANUAL
 C3 Pluriel	REMOTE CONTROL E	1.4 HDI 8v 50kw 8HZ (02-..)	VALEO Body Computer MANUAL
 C3 Pluriel	REMOTE CONTROL E	1.6 16v 82kw NFU (02-..)	VALEO Body Computer MANUAL
 C3 Pluriel	SERVICE LIGHT RES	1.4 8v 55kw KFV (01-..)	Sagem/xx MANUAL
 C3 Pluriel	SERVICE LIGHT RES	1.4 HDI 8v 50kw 8HX (01-..)	Sagem/xx MANUAL
 C3 Pluriel	SERVICE LIGHT RES	1.4 HDI 8v 50kw 8HZ (01-..)	Sagem/xx MANUAL
 C3 Pluriel	SERVICE LIGHT RES	1.6 16v 82kw NFU (01-..)	Sagem/xx MANUAL
 C3 Pluriel	STEERING COLUMN	1.4 8v 55kw KFV	AUTODETECT
 C3 Pluriel	STEERING COLUMN	1.4 HDI 8v 50kw 8HX	AUTODETECT
 C3 Pluriel	STEERING COLUMN	1.4 HDI 8v 50kw 8HZ	AUTODETECT
 C3 Pluriel	STEERING COLUMN	1.6 16v 82kw NFU	AUTODETECT
 C3 Pluriel	SWITCHLIGHT MODU	1.4 8v 55kw KFV	EATON
 C3 Pluriel	SWITCHLIGHT MODU	1.4 HDI 8v 50kw 8HX	EATON
 C3 Pluriel	SWITCHLIGHT MODU	1.4 HDI 8v 50kw 8HZ	EATON
 C3 Pluriel	SWITCHLIGHT MODU	1.6 16v 82kw NFU	EATON

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C3 Pluriel	VISUAL./TELEMATIC	1.4 8v 55kw KFV	AUTODETECT
 C3 Pluriel	VISUAL./TELEMATIC	1.4 8v 55kw KFV	Display A+ AUTODETECT
 C3 Pluriel	VISUAL./TELEMATIC	1.4 8v 55kw KFV	Display AUTODETECT
 C3 Pluriel	VISUAL./TELEMATIC	1.4 8v 55kw KFV	Display C- AUTODETECT
 C3 Pluriel	VISUAL./TELEMATIC	1.4 8v 55kw KFV	SAGEM JCAE
 C3 Pluriel	VISUAL./TELEMATIC	1.4 HDI 8v 50kw 8HX	AUTODETECT
 C3 Pluriel	VISUAL./TELEMATIC	1.4 HDI 8v 50kw 8HX	Display A+ AUTODETECT
 C3 Pluriel	VISUAL./TELEMATIC	1.4 HDI 8v 50kw 8HX	Display AUTODETECT
 C3 Pluriel	VISUAL./TELEMATIC	1.4 HDI 8v 50kw 8HX	Display C- AUTODETECT
 C3 Pluriel	VISUAL./TELEMATIC	1.4 HDI 8v 50kw 8HX	SAGEM JCAE
 C3 Pluriel	VISUAL./TELEMATIC	1.4 HDI 8v 50kw 8HZ	AUTODETECT
 C3 Pluriel	VISUAL./TELEMATIC	1.4 HDI 8v 50kw 8HZ	Display A+ AUTODETECT
 C3 Pluriel	VISUAL./TELEMATIC	1.4 HDI 8v 50kw 8HZ	Display AUTODETECT
 C3 Pluriel	VISUAL./TELEMATIC	1.4 HDI 8v 50kw 8HZ	Display C- AUTODETECT
 C3 Pluriel	VISUAL./TELEMATIC	1.4 HDI 8v 50kw 8HZ	SAGEM JCAE
 C3 Pluriel	VISUAL./TELEMATIC	1.6 16v 82kw NFU	AUTODETECT
 C3 Pluriel	VISUAL./TELEMATIC	1.6 16v 82kw NFU	Display A+ AUTODETECT
 C3 Pluriel	VISUAL./TELEMATIC	1.6 16v 82kw NFU	Display AUTODETECT
 C3 Pluriel	VISUAL./TELEMATIC	1.6 16v 82kw NFU	Display C- AUTODETECT
 C3 Pluriel	VISUAL./TELEMATIC	1.6 16v 82kw NFU	SAGEM JCAE
 C4 09	ABS + TRACT. CONT	1.4 16v 66kw KFU	BOSCH ABS 8.0 AUTODETECT
 C4 09	ABS + TRACT. CONT	1.4 16v 66kw KFU	BOSCH ESP 8.0 AUTODETECT
 C4 09	ABS + TRACT. CONT	1.6 16v 103kw 5FT	BOSCH ABS 8.0 AUTODETECT
 C4 09	ABS + TRACT. CONT	1.6 16v 103kw 5FT	BOSCH ESP 8.0 AUTODETECT
 C4 09	ABS + TRACT. CONT	1.6 16v 110kw 5FX	BOSCH ABS 8.0 AUTODETECT
 C4 09	ABS + TRACT. CONT	1.6 16v 110kw 5FX	BOSCH ESP 8.0 AUTODETECT
 C4 09	ABS + TRACT. CONT	1.6 16v 88kw 5FW	BOSCH ABS 8.0 AUTODETECT
 C4 09	ABS + TRACT. CONT	1.6 16v 88kw 5FW	BOSCH ESP 8.0 AUTODETECT
 C4 09	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HV	BOSCH ABS 8.0 AUTODETECT
 C4 09	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HV	BOSCH ESP 8.0 AUTODETECT
 C4 09	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX	BOSCH ABS 8.0 AUTODETECT
 C4 09	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX	BOSCH ESP 8.0 AUTODETECT
 C4 09	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HY	BOSCH ABS 8.0 AUTODETECT
 C4 09	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HY	BOSCH ESP 8.0 AUTODETECT
 C4 09	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ABS 8.0 AUTODETECT
 C4 09	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ESP 8.0 AUTODETECT
 C4 09	ABS + TRACT. CONT	2.0 16v 103kw RFJ	BOSCH ABS 8.0 AUTODETECT
 C4 09	ABS + TRACT. CONT	2.0 16v 103kw RFJ	BOSCH ESP 8.0 AUTODETECT
 C4 09	ABS + TRACT. CONT	2.0 HDI 16v 103kw RHF	BOSCH ABS 8.0 AUTODETECT
 C4 09	ABS + TRACT. CONT	2.0 HDI 16v 103kw RHF	BOSCH ESP 8.0 AUTODETECT
 C4 09	AIRBAG	1.4 16v 66kw KFU	AirBag CENTRAL AUTODETECT
 C4 09	AIRBAG	1.4 16v 66kw KFU	Autoliv AirBag
 C4 09	AIRBAG	1.6 16v 103kw 5FT	AirBag CENTRAL AUTODETECT
 C4 09	AIRBAG	1.6 16v 103kw 5FT	Autoliv AirBag
 C4 09	AIRBAG	1.6 16v 110kw 5FX	AirBag CENTRAL AUTODETECT
 C4 09	AIRBAG	1.6 16v 110kw 5FX	Autoliv AirBag
 C4 09	AIRBAG	1.6 16v 88kw 5FW	AirBag CENTRAL AUTODETECT
 C4 09	AIRBAG	1.6 16v 88kw 5FW	Autoliv AirBag
 C4 09	AIRBAG	1.6 HDI 16v 66kw 9HV	AirBag CENTRAL AUTODETECT
 C4 09	AIRBAG	1.6 HDI 16v 66kw 9HV	Autoliv AirBag
 C4 09	AIRBAG	1.6 HDI 16v 66kw 9HX	AirBag CENTRAL AUTODETECT
 C4 09	AIRBAG	1.6 HDI 16v 66kw 9HX	Autoliv AirBag
 C4 09	AIRBAG	1.6 HDI 16v 80kw 9HY	AirBag CENTRAL AUTODETECT
 C4 09	AIRBAG	1.6 HDI 16v 80kw 9HY	Autoliv AirBag
 C4 09	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL AUTODETECT
 C4 09	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP	Autoliv AirBag
 C4 09	AIRBAG	2.0 16v 103kw RFJ	AirBag CENTRAL AUTODETECT
 C4 09	AIRBAG	2.0 16v 103kw RFJ	Autoliv AirBag

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4 09	AIRBAG	2.0 HDI 16v 103kw RHF	AirBag CENTRAL AUTODETECT
 C4 09	AIRBAG	2.0 HDI 16v 103kw RHF	Autoliv AirBag
 C4 09	CHASSIS NETWORK	1.4 16v 66kw KFU	Body Computer BSI AUTODETECT
 C4 09	CHASSIS NETWORK	1.6 16v 103kw 5FT	Body Computer BSI AUTODETECT
 C4 09	CHASSIS NETWORK	1.6 16v 110kw F5X	Body Computer BSI AUTODETECT
 C4 09	CHASSIS NETWORK	1.6 16v 88kw 5FW	Body Computer BSI AUTODETECT
 C4 09	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HV	Body Computer BSI AUTODETECT
 C4 09	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	Body Computer BSI AUTODETECT
 C4 09	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY	Body Computer BSI AUTODETECT
 C4 09	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSI AUTODETECT
 C4 09	CHASSIS NETWORK	2.0 16v 103kw RFJ	Body Computer BSI AUTODETECT
 C4 09	CHASSIS NETWORK	2.0 HDI 16v 103kw RHF-FAP	Body Computer BSI AUTODETECT
 C4 09	DASHBOARD	1.4 16v 66kw KFU	AUTODETECT
 C4 09	DASHBOARD	1.6 16v 103kw 5FT	AUTODETECT
 C4 09	DASHBOARD	1.6 16v 110kw F5X	AUTODETECT
 C4 09	DASHBOARD	1.6 16v 88kw 5FW	AUTODETECT
 C4 09	DASHBOARD	1.6 HDI 16v 66kw 9HV	AUTODETECT
 C4 09	DASHBOARD	1.6 HDI 16v 66kw 9HX	AUTODETECT
 C4 09	DASHBOARD	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C4 09	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4 09	DASHBOARD	2.0 16v 103kw RFJ	AUTODETECT
 C4 09	DASHBOARD	2.0 HDI 16v 103kw RHF-FAP	AUTODETECT
 C4 09	DRIVER SIDE DOOR	1.4 16v 66kw KFU	AUTODETECT
 C4 09	DRIVER SIDE DOOR	1.6 16v 103kw 5FT	AUTODETECT
 C4 09	DRIVER SIDE DOOR	1.6 16v 110kw F5X	AUTODETECT
 C4 09	DRIVER SIDE DOOR	1.6 16v 88kw 5FW	AUTODETECT
 C4 09	DRIVER SIDE DOOR	1.6 HDI 16v 66kw 9HV	AUTODETECT
 C4 09	DRIVER SIDE DOOR	1.6 HDI 16v 66kw 9HX	AUTODETECT
 C4 09	DRIVER SIDE DOOR	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C4 09	DRIVER SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4 09	DRIVER SIDE DOOR	2.0 16v 103kw RFJ	AUTODETECT
 C4 09	DRIVER SIDE DOOR	2.0 HDI 16v 103kw RHF-FAP	AUTODETECT
 C4 09	ELECTRIC STEERING	1.4 16v 66kw KFU	AUTODETECT
 C4 09	ELECTRIC STEERING	1.4 16v 66kw KFU	HPI GEP
 C4 09	ELECTRIC STEERING	1.6 16v 103kw 5FT	AUTODETECT
 C4 09	ELECTRIC STEERING	1.6 16v 103kw 5FT	HPI GEP
 C4 09	ELECTRIC STEERING	1.6 16v 110kw 5FX	AUTODETECT
 C4 09	ELECTRIC STEERING	1.6 16v 110kw 5FX	HPI GEP
 C4 09	ELECTRIC STEERING	1.6 16v 88kw 5FW	AUTODETECT
 C4 09	ELECTRIC STEERING	1.6 16v 88kw 5FW	HPI GEP
 C4 09	ELECTRIC STEERING	1.6 HDI 16v 66kw 9HV	AUTODETECT
 C4 09	ELECTRIC STEERING	1.6 HDI 16v 66kw 9HV	HPI GEP
 C4 09	ELECTRIC STEERING	1.6 HDI 16v 66kw 9HX	AUTODETECT
 C4 09	ELECTRIC STEERING	1.6 HDI 16v 66kw 9HX	HPI GEP
 C4 09	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C4 09	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HY	HPI GEP
 C4 09	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4 09	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	HPI GEP
 C4 09	ELECTRIC STEERING	2.0 16v 103kw RFJ	AUTODETECT
 C4 09	ELECTRIC STEERING	2.0 16v 103kw RFJ	HPI GEP
 C4 09	ELECTRIC STEERING	2.0 HDI 16v 103kw RHF	AUTODETECT
 C4 09	ELECTRIC STEERING	2.0 HDI 16v 103kw RHF	HPI GEP
 C4 09	ENGINE MANAGEME	1.4 16v 66kw KFU	EOBD
 C4 09	ENGINE MANAGEME	1.6 16v 103kw 5FT	EOBD
 C4 09	ENGINE MANAGEME	1.6 16v 110kw F5X	EOBD
 C4 09	ENGINE MANAGEME	1.6 16v 88kw 5FW	EOBD
 C4 09	ENGINE MANAGEME	1.6 HDI 16v 66kw 9HV	EOBD
 C4 09	ENGINE MANAGEME	1.6 HDI 16v 66kw 9HX	EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4 09	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HY	EOBD
 C4 09	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16C 34 Common Rail
 C4 09	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 AUTODETECT
 C4 09	ENGINE MANAGEME	2.0 16v 103kw RFJ	EOBD
 C4 09	ENGINE MANAGEME	2.0 HDI 16v 103kw RHF-FAP	EOBD
 C4 09	KEY ENCODE	1.4 16v 66kw KFU	JCAE Body Computer
 C4 09	KEY ENCODE	1.6 16v 103kw 5FT	JCAE Body Computer
 C4 09	KEY ENCODE	1.6 16v 110kw F5X	JCAE Body Computer
 C4 09	KEY ENCODE	1.6 16v 88kw 5FW	JCAE Body Computer
 C4 09	KEY ENCODE	1.6 HDI 16v 66kw 9HV	JCAE Body Computer
 C4 09	KEY ENCODE	1.6 HDI 16v 66kw 9HX	JCAE Body Computer
 C4 09	KEY ENCODE	1.6 HDI 16v 80kw 9HY	JCAE Body Computer
 C4 09	KEY ENCODE	1.6 HDI 16v 80kw 9HZ-FAP	JCAE Body Computer
 C4 09	KEY ENCODE	2.0 16v 103kw RFJ	JCAE Body Computer
 C4 09	KEY ENCODE	2.0 HDI 16v 103kw RHF-FAP	JCAE Body Computer
 C4 09	MAINTENANCE	1.4 16v 66kw KFU	AirBag CENTRAL AUTODETECT
 C4 09	MAINTENANCE	1.4 16v 66kw KFU	AirBag CENTRAL AUTODETECT
 C4 09	MAINTENANCE	1.4 16v 66kw KFU	BOSCH ABS 8.0 AUTODETECT
 C4 09	MAINTENANCE	1.4 16v 66kw KFU	BOSCH ABS 8.0 AUTODETECT
 C4 09	MAINTENANCE	1.4 16v 66kw KFU	BOSCH ESP 8.0 AUTODETECT
 C4 09	MAINTENANCE	1.4 16v 66kw KFU	BOSCH ESP 8.0 AUTODETECT
 C4 09	MAINTENANCE	1.6 16v 103kw 5FT	AirBag CENTRAL AUTODETECT
 C4 09	MAINTENANCE	1.6 16v 103kw 5FT	AirBag CENTRAL AUTODETECT
 C4 09	MAINTENANCE	1.6 16v 103kw 5FT	BOSCH ABS 8.0 AUTODETECT
 C4 09	MAINTENANCE	1.6 16v 103kw 5FT	BOSCH ABS 8.0 AUTODETECT
 C4 09	MAINTENANCE	1.6 16v 103kw 5FT	BOSCH ESP 8.0 AUTODETECT
 C4 09	MAINTENANCE	1.6 16v 103kw 5FT	BOSCH ESP 8.0 AUTODETECT
 C4 09	MAINTENANCE	1.6 16v 110kw 5FX	AirBag CENTRAL AUTODETECT
 C4 09	MAINTENANCE	1.6 16v 110kw 5FX	AirBag CENTRAL AUTODETECT
 C4 09	MAINTENANCE	1.6 16v 110kw 5FX	BOSCH ABS 8.0 AUTODETECT
 C4 09	MAINTENANCE	1.6 16v 110kw 5FX	BOSCH ABS 8.0 AUTODETECT
 C4 09	MAINTENANCE	1.6 16v 110kw 5FX	BOSCH ESP 8.0 AUTODETECT
 C4 09	MAINTENANCE	1.6 16v 110kw 5FX	BOSCH ESP 8.0 AUTODETECT
 C4 09	MAINTENANCE	1.6 16v 88kw 5FW	AirBag CENTRAL AUTODETECT
 C4 09	MAINTENANCE	1.6 16v 88kw 5FW	AirBag CENTRAL AUTODETECT
 C4 09	MAINTENANCE	1.6 16v 88kw 5FW	BOSCH ABS 8.0 AUTODETECT
 C4 09	MAINTENANCE	1.6 16v 88kw 5FW	BOSCH ABS 8.0 AUTODETECT
 C4 09	MAINTENANCE	1.6 16v 88kw 5FW	BOSCH ESP 8.0 AUTODETECT
 C4 09	MAINTENANCE	1.6 16v 88kw 5FW	BOSCH ESP 8.0 AUTODETECT
 C4 09	MAINTENANCE	1.6 HDI 16v 66kw 9HV	AirBag CENTRAL AUTODETECT
 C4 09	MAINTENANCE	1.6 HDI 16v 66kw 9HV	AirBag CENTRAL AUTODETECT
 C4 09	MAINTENANCE	1.6 HDI 16v 66kw 9HV	BOSCH ABS 8.0 AUTODETECT
 C4 09	MAINTENANCE	1.6 HDI 16v 66kw 9HV	BOSCH ABS 8.0 AUTODETECT
 C4 09	MAINTENANCE	1.6 HDI 16v 66kw 9HV	BOSCH ESP 8.0 AUTODETECT
 C4 09	MAINTENANCE	1.6 HDI 16v 66kw 9HV	BOSCH ESP 8.0 AUTODETECT
 C4 09	MAINTENANCE	1.6 HDI 16v 66kw 9HX	AirBag CENTRAL AUTODETECT
 C4 09	MAINTENANCE	1.6 HDI 16v 66kw 9HX	AirBag CENTRAL AUTODETECT
 C4 09	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH ABS 8.0 AUTODETECT
 C4 09	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH ABS 8.0 AUTODETECT
 C4 09	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH ESP 8.0 AUTODETECT
 C4 09	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH ESP 8.0 AUTODETECT
 C4 09	MAINTENANCE	1.6 HDI 16v 80kw 9HY	AirBag CENTRAL AUTODETECT
 C4 09	MAINTENANCE	1.6 HDI 16v 80kw 9HY	AirBag CENTRAL AUTODETECT
 C4 09	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH ABS 8.0 AUTODETECT
 C4 09	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH ABS 8.0 AUTODETECT
 C4 09	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH ESP 8.0 AUTODETECT
 C4 09	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH ESP 8.0 AUTODETECT
 C4 09	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4 09	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL AUTODETECT
 C4 09	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ABS 8.0 AUTODETECT
 C4 09	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ABS 8.0 AUTODETECT
 C4 09	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 AUTODETECT
 C4 09	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 AUTODETECT
 C4 09	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 AUTODETECT
 C4 09	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 AUTODETECT
 C4 09	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 AUTODETECT
 C4 09	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 AUTODETECT
 C4 09	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ESP 8.0 AUTODETECT
 C4 09	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ESP 8.0 AUTODETECT
 C4 09	MAINTENANCE	2.0 16v 103kw RFJ	AirBag CENTRAL AUTODETECT
 C4 09	MAINTENANCE	2.0 16v 103kw RFJ	AirBag CENTRAL AUTODETECT
 C4 09	MAINTENANCE	2.0 16v 103kw RFJ	BOSCH ABS 8.0 AUTODETECT
 C4 09	MAINTENANCE	2.0 16v 103kw RFJ	BOSCH ABS 8.0 AUTODETECT
 C4 09	MAINTENANCE	2.0 16v 103kw RFJ	BOSCH ESP 8.0 AUTODETECT
 C4 09	MAINTENANCE	2.0 16v 103kw RFJ	BOSCH ESP 8.0 AUTODETECT
 C4 09	MAINTENANCE	2.0 HDI 16v 103kw RHF	AirBag CENTRAL AUTODETECT
 C4 09	MAINTENANCE	2.0 HDI 16v 103kw RHF	AirBag CENTRAL AUTODETECT
 C4 09	MAINTENANCE	2.0 HDI 16v 103kw RHF	BOSCH ABS 8.0 AUTODETECT
 C4 09	MAINTENANCE	2.0 HDI 16v 103kw RHF	BOSCH ABS 8.0 AUTODETECT
 C4 09	MAINTENANCE	2.0 HDI 16v 103kw RHF	BOSCH ESP 8.0 AUTODETECT
 C4 09	MAINTENANCE	2.0 HDI 16v 103kw RHF	BOSCH ESP 8.0 AUTODETECT
 C4 09	PARKING HELP	1.4 16v 66kw KFJ	AUTODETECT
 C4 09	PARKING HELP	1.4 16v 66kw KFJ	VALEO
 C4 09	PARKING HELP	1.6 16v 103kw 5FT	AUTODETECT
 C4 09	PARKING HELP	1.6 16v 103kw 5FT	VALEO
 C4 09	PARKING HELP	1.6 16v 110kw 5FX	AUTODETECT
 C4 09	PARKING HELP	1.6 16v 110kw 5FX	VALEO
 C4 09	PARKING HELP	1.6 16v 88kw 5FW	AUTODETECT
 C4 09	PARKING HELP	1.6 16v 88kw 5FW	VALEO
 C4 09	PARKING HELP	1.6 HDI 16v 66kw 9HV	AUTODETECT
 C4 09	PARKING HELP	1.6 HDI 16v 66kw 9HV	VALEO
 C4 09	PARKING HELP	1.6 HDI 16v 66kw 9HX	AUTODETECT
 C4 09	PARKING HELP	1.6 HDI 16v 66kw 9HX	VALEO
 C4 09	PARKING HELP	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C4 09	PARKING HELP	1.6 HDI 16v 80kw 9HY	VALEO
 C4 09	PARKING HELP	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4 09	PARKING HELP	1.6 HDI 16v 80kw 9HZ-FAP	VALEO
 C4 09	PARKING HELP	2.0 16v 103kw RFJ	AUTODETECT
 C4 09	PARKING HELP	2.0 16v 103kw RFJ	VALEO
 C4 09	PARKING HELP	2.0 HDI 16v 103kw RHF	AUTODETECT
 C4 09	PARKING HELP	2.0 HDI 16v 103kw RHF	VALEO
 C4 09	PASS. SIDE DOOR	1.4 16v 66kw KFJ	AUTODETECT
 C4 09	PASS. SIDE DOOR	1.6 16v 103kw 5FT	AUTODETECT
 C4 09	PASS. SIDE DOOR	1.6 16v 110kw F5X	AUTODETECT
 C4 09	PASS. SIDE DOOR	1.6 16v 88kw 5FW	AUTODETECT
 C4 09	PASS. SIDE DOOR	1.6 HDI 16v 66kw 9HV	AUTODETECT
 C4 09	PASS. SIDE DOOR	1.6 HDI 16v 66kw 9HX	AUTODETECT
 C4 09	PASS. SIDE DOOR	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C4 09	PASS. SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4 09	PASS. SIDE DOOR	2.0 16v 103kw RFJ	AUTODETECT
 C4 09	PASS. SIDE DOOR	2.0 HDI 16v 103kw RHF-FAP	AUTODETECT
 C4 09	STEERING WHEEL E	1.4 16v 66kw KFJ	AUTODETECT
 C4 09	STEERING WHEEL E	1.6 16v 103kw 5FT	AUTODETECT
 C4 09	STEERING WHEEL E	1.6 16v 110kw F5X	AUTODETECT
 C4 09	STEERING WHEEL E	1.6 16v 88kw 5FW	AUTODETECT
 C4 09	STEERING WHEEL E	1.6 HDI 16v 66kw 9HV	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4 09	STEERING WHEEL E	1.6 HDI 16v 66kw 9HX	AUTODETECT
 C4 09	STEERING WHEEL E	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C4 09	STEERING WHEEL E	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4 09	STEERING WHEEL E	2.0 16v 103kw RFJ	AUTODETECT
 C4 09	STEERING WHEEL E	2.0 HDI 16v 103kw RHF-FAP	AUTODETECT
 C4 09	SWITCHLIGHT MODU	1.4 16v 66kw KFU	EATON/DELPHI
 C4 09	SWITCHLIGHT MODU	1.6 16v 103kw 5FT	EATON/DELPHI
 C4 09	SWITCHLIGHT MODU	1.6 16v 110kw F5X	EATON/DELPHI
 C4 09	SWITCHLIGHT MODU	1.6 16v 88kw 5FW	EATON/DELPHI
 C4 09	SWITCHLIGHT MODU	1.6 HDI 16v 66kw 9HV	EATON/DELPHI
 C4 09	SWITCHLIGHT MODU	1.6 HDI 16v 66kw 9HX	EATON/DELPHI
 C4 09	SWITCHLIGHT MODU	1.6 HDI 16v 80kw 9HY	EATON/DELPHI
 C4 09	SWITCHLIGHT MODU	1.6 HDI 16v 80kw 9HZ-FAP	EATON/DELPHI
 C4 09	SWITCHLIGHT MODU	2.0 16v 103kw RFJ	EATON/DELPHI
 C4 09	SWITCHLIGHT MODU	2.0 HDI 16v 103kw RHF-FAP	EATON/DELPHI
 C4 09	VISUAL./TELEMATIC	1.4 16v 66kw KFU	Display C- AUTODETECT
 C4 09	VISUAL./TELEMATIC	1.6 16v 103kw 5FT	Display C- AUTODETECT
 C4 09	VISUAL./TELEMATIC	1.6 16v 110kw F5X	Display C- AUTODETECT
 C4 09	VISUAL./TELEMATIC	1.6 16v 88kw 5FW	Display C- AUTODETECT
 C4 09	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HV	Display C- AUTODETECT
 C4 09	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HX	Display C- AUTODETECT
 C4 09	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HY	Display C- AUTODETECT
 C4 09	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	Display C- AUTODETECT
 C4 09	VISUAL./TELEMATIC	2.0 16v 103kw RFJ	Display C- AUTODETECT
 C4 09	VISUAL./TELEMATIC	2.0 HDI 16v 103kw RHF-FAP	Display C- AUTODETECT
 C4 Picasso	ABS + TRACT. CONT	1.6 16v 103kw 5FT	BOSCH ABS
 C4 Picasso	ABS + TRACT. CONT	1.6 16v 103kw 5FT	BOSCH ESP 8.1 AUTODETECT
 C4 Picasso	ABS + TRACT. CONT	1.6 16v 110kw 5FX	BOSCH ABS
 C4 Picasso	ABS + TRACT. CONT	1.6 16v 110kw 5FX	BOSCH ESP 8.1 AUTODETECT
 C4 Picasso	ABS + TRACT. CONT	1.6 16v 88kw 5FW	BOSCH ABS
 C4 Picasso	ABS + TRACT. CONT	1.6 16v 88kw 5FW	BOSCH ESP 8.1 AUTODETECT
 C4 Picasso	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ABS
 C4 Picasso	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ESP 8.1 AUTODETECT
 C4 Picasso	ABS + TRACT. CONT	1.8 16v 92kw 6FY	BOSCH ABS
 C4 Picasso	ABS + TRACT. CONT	1.8 16v 92kw 6FY	BOSCH ESP 8.1 AUTODETECT
 C4 Picasso	ABS + TRACT. CONT	2.0 16v 103kw RFJ	BOSCH ABS
 C4 Picasso	ABS + TRACT. CONT	2.0 16v 103kw RFJ	BOSCH ESP 8.1 AUTODETECT
 C4 Picasso	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHJ-FAP	BOSCH ESP 8.1 AUTODETECT
 C4 Picasso	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP	BOSCH ABS
 C4 Picasso	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP	BOSCH ESP 8.1 AUTODETECT
 C4 Picasso	ABS + TRACT. CONT	2.0 HDI 16v 110kw RHE	BOSCH ABS
 C4 Picasso	ABS + TRACT. CONT	2.0 HDI 16v 110kw RHE	BOSCH ESP 8.1 AUTODETECT
 C4 Picasso	AIRBAG	1.6 16v 103kw 5FT	AirBag CENTRAL AUTODETECT
 C4 Picasso	AIRBAG	1.6 16v 103kw 5FT	TRW Autoliv AirBag
 C4 Picasso	AIRBAG	1.6 16v 110kw 5FX	AirBag CENTRAL AUTODETECT
 C4 Picasso	AIRBAG	1.6 16v 110kw 5FX	TRW Autoliv AirBag
 C4 Picasso	AIRBAG	1.6 16v 88kw 5FW	AirBag CENTRAL AUTODETECT
 C4 Picasso	AIRBAG	1.6 16v 88kw 5FW	TRW Autoliv AirBag
 C4 Picasso	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL AUTODETECT
 C4 Picasso	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP	TRW Autoliv AirBag
 C4 Picasso	AIRBAG	1.8 16v 92kw 6FY	AirBag CENTRAL AUTODETECT
 C4 Picasso	AIRBAG	1.8 16v 92kw 6FY	TRW Autoliv AirBag
 C4 Picasso	AIRBAG	2.0 16v 103kw RFJ	AirBag CENTRAL AUTODETECT
 C4 Picasso	AIRBAG	2.0 16v 103kw RFJ	TRW Autoliv AirBag
 C4 Picasso	AIRBAG	2.0 HDI 16v 100kw RHJ-FAP	AirBag CENTRAL AUTODETECT
 C4 Picasso	AIRBAG	2.0 HDI 16v 100kw RHJ-FAP	TRW Autoliv AirBag
 C4 Picasso	AIRBAG	2.0 HDI 16v 100kw RHR-FAP	AirBag CENTRAL AUTODETECT
 C4 Picasso	AIRBAG	2.0 HDI 16v 100kw RHR-FAP	TRW Autoliv AirBag

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4 Picasso	AIRBAG	2.0 HDI 16v 110kw RHE	AirBag CENTRAL AUTODETECT
 C4 Picasso	AIRBAG	2.0 HDI 16v 110kw RHE	TRW Autoliv AirBag
 C4 Picasso	ANTITHEFT	1.6 16v 103kw 5FT	Alarm PSA2 AUTODETECT
 C4 Picasso	ANTITHEFT	1.6 16v 110kw 5FX	Alarm PSA2 AUTODETECT
 C4 Picasso	ANTITHEFT	1.6 16v 88kw 5FW	Alarm PSA2 AUTODETECT
 C4 Picasso	ANTITHEFT	1.6 HDI 16v 80kw 9HZ-FAP	Alarm PSA2 AUTODETECT
 C4 Picasso	ANTITHEFT	1.8 16v 92kw 6FY	Alarm PSA2 AUTODETECT
 C4 Picasso	ANTITHEFT	2.0 16v 103kw RFJ	Alarm PSA2 AUTODETECT
 C4 Picasso	ANTITHEFT	2.0 HDI 16v 100kw RHJ-FAP	Alarm PSA2 AUTODETECT
 C4 Picasso	ANTITHEFT	2.0 HDI 16v 100kw RHR-FAP	Alarm PSA2 AUTODETECT
 C4 Picasso	ANTITHEFT	2.0 HDI 16v 110kw RHE	Alarm PSA2 AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	1.6 16v 103kw 5FT	A/T AL4 AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	1.6 16v 103kw 5FT	A/T AM6 AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	1.6 16v 103kw 5FT	A/T MCP AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	1.6 16v 103kw 5FT	COMELBVA AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	1.6 16v 110kw 5FX	A/T AL4 AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	1.6 16v 110kw 5FX	A/T AM6 AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	1.6 16v 110kw 5FX	A/T MCP AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	1.6 16v 110kw 5FX	COMELBVA AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	1.6 16v 88kw 5FW	A/T AL4 AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	1.6 16v 88kw 5FW	A/T AM6 AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	1.6 16v 88kw 5FW	A/T MCP AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	1.6 16v 88kw 5FW	COMELBVA AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP	A/T AL4 AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP	A/T AM6 AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP	A/T MCP AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP	COMELBVA AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	1.8 16v 92kw 6FY	A/T AL4 AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	1.8 16v 92kw 6FY	A/T AM6 AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	1.8 16v 92kw 6FY	A/T MCP AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	1.8 16v 92kw 6FY	COMELBVA AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ	A/T AL4 AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ	A/T AM6 AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ	A/T MCP AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ	COMELBVA AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHJ-FAP	A/T AL4 AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHJ-FAP	A/T AM6 AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHJ-FAP	A/T MCP AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHJ-FAP	COMELBVA AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP	A/T AL4 AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP	A/T AM6 AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP	A/T MCP AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP	COMELBVA AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	2.0 HDI 16v 110kw RHE	A/T AL4 AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	2.0 HDI 16v 110kw RHE	A/T AM6 AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	2.0 HDI 16v 110kw RHE	A/T MCP AUTODETECT
 C4 Picasso	AUTOM. TRANSMISSI	2.0 HDI 16v 110kw RHE	COMELBVA AUTODETECT
 C4 Picasso	CHASSIS NETWORK	1.6 16v 103kw 5FT	Body Computer BSI AUTODETECT
 C4 Picasso	CHASSIS NETWORK	1.6 16v 103kw 5FT	Body Computer BSM AUTODETECT
 C4 Picasso	CHASSIS NETWORK	1.6 16v 103kw 5FT	Body Computer BSR AUTODETECT
 C4 Picasso	CHASSIS NETWORK	1.6 16v 103kw 5FT	DELPHI Body Computer BSM
 C4 Picasso	CHASSIS NETWORK	1.6 16v 103kw 5FT	High frequency receiver AUTODETECT
 C4 Picasso	CHASSIS NETWORK	1.6 16v 103kw 5FT	JCAE Body Computer BSI 17.00
 C4 Picasso	CHASSIS NETWORK	1.6 16v 110kw 5FX	Body Computer BSI AUTODETECT
 C4 Picasso	CHASSIS NETWORK	1.6 16v 110kw 5FX	Body Computer BSM AUTODETECT
 C4 Picasso	CHASSIS NETWORK	1.6 16v 110kw 5FX	Body Computer BSR AUTODETECT
 C4 Picasso	CHASSIS NETWORK	1.6 16v 110kw 5FX	DELPHI Body Computer BSM
 C4 Picasso	CHASSIS NETWORK	1.6 16v 110kw 5FX	High frequency receiver AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4 Picasso	CHASSIS NETWORK	1.6 16v 110kw 5FX	JCAE Body Computer BSI 17.00
 C4 Picasso	CHASSIS NETWORK	1.6 16v 88kw 5FW	Body Computer BSI AUTODETECT
 C4 Picasso	CHASSIS NETWORK	1.6 16v 88kw 5FW	Body Computer BSM AUTODETECT
 C4 Picasso	CHASSIS NETWORK	1.6 16v 88kw 5FW	Body Computer BSR AUTODETECT
 C4 Picasso	CHASSIS NETWORK	1.6 16v 88kw 5FW	DELPHI Body Computer BSM
 C4 Picasso	CHASSIS NETWORK	1.6 16v 88kw 5FW	High frequency receiver AUTODETECT
 C4 Picasso	CHASSIS NETWORK	1.6 16v 88kw 5FW	JCAE Body Computer BSI 17.00
 C4 Picasso	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSI AUTODETECT
 C4 Picasso	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSM AUTODETECT
 C4 Picasso	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSR AUTODETECT
 C4 Picasso	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	DELPHI Body Computer BSM
 C4 Picasso	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	High frequency receiver AUTODETECT
 C4 Picasso	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	JCAE Body Computer BSI 17.00
 C4 Picasso	CHASSIS NETWORK	1.8 16v 92kw 6FY	Body Computer BSI AUTODETECT
 C4 Picasso	CHASSIS NETWORK	1.8 16v 92kw 6FY	Body Computer BSM AUTODETECT
 C4 Picasso	CHASSIS NETWORK	1.8 16v 92kw 6FY	Body Computer BSR AUTODETECT
 C4 Picasso	CHASSIS NETWORK	1.8 16v 92kw 6FY	DELPHI Body Computer BSM
 C4 Picasso	CHASSIS NETWORK	1.8 16v 92kw 6FY	High frequency receiver AUTODETECT
 C4 Picasso	CHASSIS NETWORK	1.8 16v 92kw 6FY	JCAE Body Computer BSI 17.00
 C4 Picasso	CHASSIS NETWORK	2.0 16v 103kw RFJ	Body Computer BSI AUTODETECT
 C4 Picasso	CHASSIS NETWORK	2.0 16v 103kw RFJ	Body Computer BSM AUTODETECT
 C4 Picasso	CHASSIS NETWORK	2.0 16v 103kw RFJ	Body Computer BSR AUTODETECT
 C4 Picasso	CHASSIS NETWORK	2.0 16v 103kw RFJ	DELPHI Body Computer BSM
 C4 Picasso	CHASSIS NETWORK	2.0 16v 103kw RFJ	High frequency receiver AUTODETECT
 C4 Picasso	CHASSIS NETWORK	2.0 16v 103kw RFJ	JCAE Body Computer BSI 17.00
 C4 Picasso	CHASSIS NETWORK	2.0 HDI 16v 100kw RHJ-FAP	Body Computer BSI AUTODETECT
 C4 Picasso	CHASSIS NETWORK	2.0 HDI 16v 100kw RHJ-FAP	Body Computer BSM AUTODETECT
 C4 Picasso	CHASSIS NETWORK	2.0 HDI 16v 100kw RHJ-FAP	Body Computer BSR AUTODETECT
 C4 Picasso	CHASSIS NETWORK	2.0 HDI 16v 100kw RHJ-FAP	DELPHI Body Computer BSM
 C4 Picasso	CHASSIS NETWORK	2.0 HDI 16v 100kw RHJ-FAP	High frequency receiver AUTODETECT
 C4 Picasso	CHASSIS NETWORK	2.0 HDI 16v 100kw RHJ-FAP	JCAE Body Computer BSI 17.00
 C4 Picasso	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	Body Computer BSI AUTODETECT
 C4 Picasso	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	Body Computer BSM AUTODETECT
 C4 Picasso	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	Body Computer BSR AUTODETECT
 C4 Picasso	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	DELPHI Body Computer BSM
 C4 Picasso	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	High frequency receiver AUTODETECT
 C4 Picasso	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	JCAE Body Computer BSI 17.00
 C4 Picasso	CHASSIS NETWORK	2.0 HDI 16v 110kw RHE	Body Computer BSI AUTODETECT
 C4 Picasso	CHASSIS NETWORK	2.0 HDI 16v 110kw RHE	Body Computer BSM AUTODETECT
 C4 Picasso	CHASSIS NETWORK	2.0 HDI 16v 110kw RHE	Body Computer BSR AUTODETECT
 C4 Picasso	CHASSIS NETWORK	2.0 HDI 16v 110kw RHE	DELPHI Body Computer BSM
 C4 Picasso	CHASSIS NETWORK	2.0 HDI 16v 110kw RHE	High frequency receiver AUTODETECT
 C4 Picasso	CHASSIS NETWORK	2.0 HDI 16v 110kw RHE	JCAE Body Computer BSI 17.00
 C4 Picasso	CLIMA	1.6 16v 103kw 5FT	CLIMA AUTODETECT
 C4 Picasso	CLIMA	1.6 16v 103kw 5FT	DENSO AutoClima
 C4 Picasso	CLIMA	1.6 16v 110kw 5FX	CLIMA AUTODETECT
 C4 Picasso	CLIMA	1.6 16v 110kw 5FX	DENSO AutoClima
 C4 Picasso	CLIMA	1.6 16v 88kw 5FW	CLIMA AUTODETECT
 C4 Picasso	CLIMA	1.6 16v 88kw 5FW	DENSO AutoClima
 C4 Picasso	CLIMA	1.6 HDI 16v 80kw 9HZ-FAP	CLIMA AUTODETECT
 C4 Picasso	CLIMA	1.6 HDI 16v 80kw 9HZ-FAP	DENSO AutoClima
 C4 Picasso	CLIMA	1.8 16v 92kw 6FY	CLIMA AUTODETECT
 C4 Picasso	CLIMA	1.8 16v 92kw 6FY	DENSO AutoClima
 C4 Picasso	CLIMA	2.0 16v 103kw RFJ	CLIMA AUTODETECT
 C4 Picasso	CLIMA	2.0 16v 103kw RFJ	DENSO AutoClima
 C4 Picasso	CLIMA	2.0 HDI 16v 100kw RHJ-FAP	CLIMA AUTODETECT
 C4 Picasso	CLIMA	2.0 HDI 16v 100kw RHJ-FAP	DENSO AutoClima
 C4 Picasso	CLIMA	2.0 HDI 16v 100kw RHR-FAP	CLIMA AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4 Picasso	CLIMA	2.0 HDI 16v 100kw RHR-FAP	DENSO AutoClima
 C4 Picasso	CLIMA	2.0 HDI 16v 110kw RHE	CLIMA AUTODETECT
 C4 Picasso	CLIMA	2.0 HDI 16v 110kw RHE	DENSO AutoClima
 C4 Picasso	COMFORT SYSTEM	1.6 16v 103kw 5FT	AUTODETECT
 C4 Picasso	COMFORT SYSTEM	1.6 16v 103kw 5FT	AUTODETECT
 C4 Picasso	COMFORT SYSTEM	1.6 16v 110kw 5FX	AUTODETECT
 C4 Picasso	COMFORT SYSTEM	1.6 16v 110kw 5FX	AUTODETECT
 C4 Picasso	COMFORT SYSTEM	1.6 16v 88kw 5FW	AUTODETECT
 C4 Picasso	COMFORT SYSTEM	1.6 16v 88kw 5FW	AUTODETECT
 C4 Picasso	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4 Picasso	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4 Picasso	COMFORT SYSTEM	1.8 16v 92kw 6FY	AUTODETECT
 C4 Picasso	COMFORT SYSTEM	1.8 16v 92kw 6FY	AUTODETECT
 C4 Picasso	COMFORT SYSTEM	2.0 16v 103kw RFJ	AUTODETECT
 C4 Picasso	COMFORT SYSTEM	2.0 16v 103kw RFJ	AUTODETECT
 C4 Picasso	COMFORT SYSTEM	2.0 HDI 16v 100kw RHJ-FAP	AUTODETECT
 C4 Picasso	COMFORT SYSTEM	2.0 HDI 16v 100kw RHJ-FAP	AUTODETECT
 C4 Picasso	COMFORT SYSTEM	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C4 Picasso	COMFORT SYSTEM	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C4 Picasso	COMFORT SYSTEM	2.0 HDI 16v 110kw RHE	AUTODETECT
 C4 Picasso	COMFORT SYSTEM	2.0 HDI 16v 110kw RHE	AUTODETECT
 C4 Picasso	DASHBOARD	1.6 16v 103kw 5FT	AUTODETECT
 C4 Picasso	DASHBOARD	1.6 16v 103kw 5FT	JCAE Dashboard 8.16
 C4 Picasso	DASHBOARD	1.6 16v 110kw 5FX	AUTODETECT
 C4 Picasso	DASHBOARD	1.6 16v 110kw 5FX	JCAE Dashboard 8.16
 C4 Picasso	DASHBOARD	1.6 16v 88kw 5FW	AUTODETECT
 C4 Picasso	DASHBOARD	1.6 16v 88kw 5FW	JCAE Dashboard 8.16
 C4 Picasso	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP	COMBINE AUTODETECT
 C4 Picasso	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP	JCAE Dashboard 8.16
 C4 Picasso	DASHBOARD	1.8 16v 92kw 6FY	COMBINE AUTODETECT
 C4 Picasso	DASHBOARD	1.8 16v 92kw 6FY	JCAE Dashboard 8.16
 C4 Picasso	DASHBOARD	2.0 16v 103kw RFJ	COMBINE AUTODETECT
 C4 Picasso	DASHBOARD	2.0 16v 103kw RFJ	JCAE Dashboard 8.16
 C4 Picasso	DASHBOARD	2.0 HDI 16v 100kw RHJ-FAP	COMBINE AUTODETECT
 C4 Picasso	DASHBOARD	2.0 HDI 16v 100kw RHJ-FAP	JCAE Dashboard 8.16
 C4 Picasso	DASHBOARD	2.0 HDI 16v 100kw RHR-FAP	COMBINE AUTODETECT
 C4 Picasso	DASHBOARD	2.0 HDI 16v 100kw RHR-FAP	JCAE Dashboard 8.16
 C4 Picasso	DASHBOARD	2.0 HDI 16v 110kw RHE	COMBINE AUTODETECT
 C4 Picasso	DASHBOARD	2.0 HDI 16v 110kw RHE	JCAE Dashboard 8.16
 C4 Picasso	DIESEL ADDITION	1.6 HDI 16v 80kw 9HZ-FAP	Diesel pump add. AUTODETECT
 C4 Picasso	DIESEL ADDITION	2.0 HDI 16v 100kw RHJ-FAP	Diesel pump add. AUTODETECT
 C4 Picasso	DIESEL ADDITION	2.0 HDI 16v 100kw RHR-FAP	Diesel pump add. AUTODETECT
 C4 Picasso	DRIVER SEAT CONT	1.6 16v 103kw 5FT	AUTODETECT
 C4 Picasso	DRIVER SEAT CONT	1.6 16v 110kw 5FX	AUTODETECT
 C4 Picasso	DRIVER SEAT CONT	1.6 16v 88kw 5FW	AUTODETECT
 C4 Picasso	DRIVER SEAT CONT	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4 Picasso	DRIVER SEAT CONT	1.8 16v 92kw 6FY	AUTODETECT
 C4 Picasso	DRIVER SEAT CONT	2.0 16v 103kw RFJ	AUTODETECT
 C4 Picasso	DRIVER SEAT CONT	2.0 HDI 16v 100kw RHJ-FAP	AUTODETECT
 C4 Picasso	DRIVER SEAT CONT	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C4 Picasso	DRIVER SEAT CONT	2.0 HDI 16v 110kw RHE	AUTODETECT
 C4 Picasso	DRIVER SIDE DOOR	1.6 16v 103kw 5FT	ArvinMeritor DriverDoor
 C4 Picasso	DRIVER SIDE DOOR	1.6 16v 103kw 5FT	AUTODETECT
 C4 Picasso	DRIVER SIDE DOOR	1.6 16v 110kw 5FX	ArvinMeritor DriverDoor
 C4 Picasso	DRIVER SIDE DOOR	1.6 16v 110kw 5FX	AUTODETECT
 C4 Picasso	DRIVER SIDE DOOR	1.6 16v 88kw 5FW	ArvinMeritor DriverDoor
 C4 Picasso	DRIVER SIDE DOOR	1.6 16v 88kw 5FW	AUTODETECT
 C4 Picasso	DRIVER SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	ArvinMeritor DriverDoor

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4 Picasso	DRIVER SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4 Picasso	DRIVER SIDE DOOR	1.8 16v 92kw 6FY	ArvinMeritor DriverDoor
 C4 Picasso	DRIVER SIDE DOOR	1.8 16v 92kw 6FY	AUTODETECT
 C4 Picasso	DRIVER SIDE DOOR	2.0 16v 103kw RFJ	ArvinMeritor DriverDoor
 C4 Picasso	DRIVER SIDE DOOR	2.0 16v 103kw RFJ	AUTODETECT
 C4 Picasso	DRIVER SIDE DOOR	2.0 HDI 16v 100kw RHJ-FAP	ArvinMeritor DriverDoor
 C4 Picasso	DRIVER SIDE DOOR	2.0 HDI 16v 100kw RHJ-FAP	AUTODETECT
 C4 Picasso	DRIVER SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	ArvinMeritor DriverDoor
 C4 Picasso	DRIVER SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C4 Picasso	DRIVER SIDE DOOR	2.0 HDI 16v 110kw RHE	ArvinMeritor DriverDoor
 C4 Picasso	DRIVER SIDE DOOR	2.0 HDI 16v 110kw RHE	AUTODETECT
 C4 Picasso	ELECTRIC STEERING	1.6 16v 103kw 5FT	TRW GEP 255.5
 C4 Picasso	ELECTRIC STEERING	1.6 16v 110kw 5FX	AUTODETECT
 C4 Picasso	ELECTRIC STEERING	1.6 16v 110kw 5FX	TRW GEP 255.5
 C4 Picasso	ELECTRIC STEERING	1.6 16v 88kw 5FW	AUTODETECT
 C4 Picasso	ELECTRIC STEERING	1.6 16v 88kw 5FW	TRW GEP 255.5
 C4 Picasso	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4 Picasso	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	TRW GEP 255.5
 C4 Picasso	ELECTRIC STEERING	1.8 16v 92kw 6FY	AUTODETECT
 C4 Picasso	ELECTRIC STEERING	1.8 16v 92kw 6FY	TRW GEP 255.5
 C4 Picasso	ELECTRIC STEERING	2.0 16v 103kw RFJ	AUTODETECT
 C4 Picasso	ELECTRIC STEERING	2.0 16v 103kw RFJ	TRW GEP 255.5
 C4 Picasso	ELECTRIC STEERING	2.0 HDI 16v 100kw RHJ-FAP	AUTODETECT
 C4 Picasso	ELECTRIC STEERING	2.0 HDI 16v 100kw RHJ-FAP	TRW GEP 255.5
 C4 Picasso	ELECTRIC STEERING	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C4 Picasso	ELECTRIC STEERING	2.0 HDI 16v 100kw RHR-FAP	TRW GEP 255.5
 C4 Picasso	ELECTRIC STEERING	2.0 HDI 16v 110kw RHE	AUTODETECT
 C4 Picasso	ELECTRIC STEERING	2.0 HDI 16v 110kw RHE	TRW GEP 255.5
 C4 Picasso	ENGINE MANAGEME	1.6 16v 103kw 5FT	BOSCH MED 17.4 AUTODETECT
 C4 Picasso	ENGINE MANAGEME	1.6 16v 110kw 5FX	BOSCH MED 17.4 AUTODETECT
 C4 Picasso	ENGINE MANAGEME	1.6 16v 88kw 5FW	BOSCH MEV 17.4 AUTODETECT
 C4 Picasso	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 C4 Picasso	ENGINE MANAGEME	1.8 16v 92kw 6FY	Marelli MM6LPB AUTODETECT
 C4 Picasso	ENGINE MANAGEME	1.8 16v 92kw 6FY	Marelli MPI MM6LPB
 C4 Picasso	ENGINE MANAGEME	2.0 16v 103kw RFJ	BOSCH MM6PLB AUTODETECT
 C4 Picasso	ENGINE MANAGEME	2.0 HDI 16v 100kw RHJ-FAP	Marelli MPI MM6LPB
 C4 Picasso	ENGINE MANAGEME	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803A Common Rail AUTOD
 C4 Picasso	ENGINE MANAGEME	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803A Common Rail AUTOD
 C4 Picasso	ENGINE MANAGEME	2.0 HDI 16v 110kw RHE	EOBD
 C4 Picasso	LANE CHANGE ASSY	1.6 16v 103kw 5FT	AUTODETECT
 C4 Picasso	LANE CHANGE ASSY	1.6 16v 110kw 5FX	AUTODETECT
 C4 Picasso	LANE CHANGE ASSY	1.6 16v 88kw 5FW	AUTODETECT
 C4 Picasso	LANE CHANGE ASSY	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4 Picasso	LANE CHANGE ASSY	1.8 16v 92kw 6FY	AUTODETECT
 C4 Picasso	LANE CHANGE ASSY	2.0 16v 103kw RFJ	AUTODETECT
 C4 Picasso	LANE CHANGE ASSY	2.0 HDI 16v 100kw RHJ-FAP	AUTODETECT
 C4 Picasso	LANE CHANGE ASSY	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C4 Picasso	LANE CHANGE ASSY	2.0 HDI 16v 110kw RHE	AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 103kw 5FT	A/T AL4 AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 103kw 5FT	A/T AM6 AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 103kw 5FT	A/T AM6 AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 103kw 5FT	AirBag CENTRAL AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 103kw 5FT	AirBag CENTRAL AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 103kw 5FT	BOSCH ESP 8.1 AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 103kw 5FT	BOSCH ESP 8.1 AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 103kw 5FT	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 103kw 5FT	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 103kw 5FT	Siemens-JCAE AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4 Picasso	MAINTENANCE	1.6 16v 103kw 5FT	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 103kw 5FT	Wiper
 C4 Picasso	MAINTENANCE	1.6 16v 110kw 5FX	A/T AL4 AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 110kw 5FX	A/T AM6 AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 110kw 5FX	A/T AM6 AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 110kw 5FX	AirBag CENTRAL AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 110kw 5FX	AirBag CENTRAL AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 110kw 5FX	BOSCH ESP 8.1 AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 110kw 5FX	BOSCH ESP 8.1 AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 110kw 5FX	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 110kw 5FX	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 110kw 5FX	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 110kw 5FX	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 110kw 5FX	Wiper
 C4 Picasso	MAINTENANCE	1.6 16v 88kw 5FW	A/T AL4 AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 88kw 5FW	A/T AM6 AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 88kw 5FW	A/T AM6 AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 88kw 5FW	AirBag CENTRAL AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 88kw 5FW	AirBag CENTRAL AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 88kw 5FW	BOSCH ESP 8.1 AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 88kw 5FW	BOSCH ESP 8.1 AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 88kw 5FW	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 88kw 5FW	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 88kw 5FW	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 88kw 5FW	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 88kw 5FW	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 16v 88kw 5FW	Wiper
 C4 Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	A/T AL4 AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	A/T AM6 AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	A/T AM6 AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 C4 Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 C4 Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 C4 Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 C4 Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 C4 Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 C4 Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ESP 8.1 AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ESP 8.1 AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Diesel pump add. AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Wiper
 C4 Picasso	MAINTENANCE	1.8 16v 92kw 6FY	A/T AL4 AUTODETECT
 C4 Picasso	MAINTENANCE	1.8 16v 92kw 6FY	A/T AM6 AUTODETECT
 C4 Picasso	MAINTENANCE	1.8 16v 92kw 6FY	A/T AM6 AUTODETECT
 C4 Picasso	MAINTENANCE	1.8 16v 92kw 6FY	AirBag CENTRAL AUTODETECT
 C4 Picasso	MAINTENANCE	1.8 16v 92kw 6FY	AirBag CENTRAL AUTODETECT
 C4 Picasso	MAINTENANCE	1.8 16v 92kw 6FY	BOSCH ESP 8.1 AUTODETECT
 C4 Picasso	MAINTENANCE	1.8 16v 92kw 6FY	BOSCH ESP 8.1 AUTODETECT
 C4 Picasso	MAINTENANCE	1.8 16v 92kw 6FY	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	1.8 16v 92kw 6FY	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	1.8 16v 92kw 6FY	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	1.8 16v 92kw 6FY	Wiper
 C4 Picasso	MAINTENANCE	2.0 16v 103kw RFJ	A/T AL4 AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4 Picasso	MAINTENANCE	2.0 16v 103kw RFJ	A/T AM6 AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 16v 103kw RFJ	A/T AM6 AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 16v 103kw RFJ	AirBag CENTRAL AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 16v 103kw RFJ	AirBag CENTRAL AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 16v 103kw RFJ	BOSCH ESP 8.1 AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 16v 103kw RFJ	BOSCH ESP 8.1 AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 16v 103kw RFJ	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 16v 103kw RFJ	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 16v 103kw RFJ	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 16v 103kw RFJ	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 16v 103kw RFJ	Wiper
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 100kw RHJ-FAP	A/T AL4 AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 100kw RHJ-FAP	A/T AM6 AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 100kw RHJ-FAP	A/T AM6 AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 100kw RHJ-FAP	AirBag CENTRAL AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 100kw RHJ-FAP	AirBag CENTRAL AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 100kw RHJ-FAP	BOSCH ESP 8.1 AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 100kw RHJ-FAP	BOSCH ESP 8.1 AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 100kw RHJ-FAP	Diesel pump add. AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 100kw RHJ-FAP	SIEMENS SID 803A Common Rail AUTOD
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 100kw RHJ-FAP	SIEMENS SID 803A Common Rail AUTOD
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 100kw RHJ-FAP	SIEMENS SID 803A Common Rail AUTOD
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 100kw RHJ-FAP	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 100kw RHJ-FAP	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 100kw RHJ-FAP	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 100kw RHJ-FAP	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 100kw RHJ-FAP	Wiper
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	A/T AL4 AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	A/T AM6 AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	A/T AM6 AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	AirBag CENTRAL AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	AirBag CENTRAL AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	BOSCH ESP 8.1 AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	BOSCH ESP 8.1 AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Diesel pump add. AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803A Common Rail AUTOD
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803A Common Rail AUTOD
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803A Common Rail AUTOD
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Wiper
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 110kw RHE	A/T AL4 AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 110kw RHE	A/T AM6 AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 110kw RHE	A/T AM6 AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 110kw RHE	AirBag CENTRAL AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 110kw RHE	AirBag CENTRAL AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 110kw RHE	BOSCH ESP 8.1 AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 110kw RHE	BOSCH ESP 8.1 AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 110kw RHE	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 110kw RHE	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 110kw RHE	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 110kw RHE	Siemens-JCAE AUTODETECT
 C4 Picasso	MAINTENANCE	2.0 HDI 16v 110kw RHE	Wiper
 C4 Picasso	NAVIGATION	1.6 16v 103kw 5FT	AUTODETECT
 C4 Picasso	NAVIGATION	1.6 16v 103kw 5FT	AUTODETECT
 C4 Picasso	NAVIGATION	1.6 16v 110kw 5FX	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4 Picasso	NAVIGATION	1.6 16v 110kw 5FX	AUTODETECT
 C4 Picasso	NAVIGATION	1.6 16v 88kw 5FW	AUTODETECT
 C4 Picasso	NAVIGATION	1.6 16v 88kw 5FW	AUTODETECT
 C4 Picasso	NAVIGATION	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4 Picasso	NAVIGATION	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4 Picasso	NAVIGATION	1.8 16v 92kw 6FY	AUTODETECT
 C4 Picasso	NAVIGATION	1.8 16v 92kw 6FY	AUTODETECT
 C4 Picasso	NAVIGATION	2.0 16v 103kw RFJ	AUTODETECT
 C4 Picasso	NAVIGATION	2.0 16v 103kw RFJ	AUTODETECT
 C4 Picasso	NAVIGATION	2.0 HDI 16v 100kw RHJ-FAP	AUTODETECT
 C4 Picasso	NAVIGATION	2.0 HDI 16v 100kw RHJ-FAP	AUTODETECT
 C4 Picasso	NAVIGATION	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C4 Picasso	NAVIGATION	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C4 Picasso	NAVIGATION	2.0 HDI 16v 110kw RHE	AUTODETECT
 C4 Picasso	NAVIGATION	2.0 HDI 16v 110kw RHE	AUTODETECT
 C4 Picasso	PARK.BRAKE	1.6 16v 103kw 5FT	BOSCH Electrobrake 01
 C4 Picasso	PARK.BRAKE	1.6 16v 103kw 5FT	Electrobrake AUTODETECT
 C4 Picasso	PARK.BRAKE	1.6 16v 110kw 5FX	BOSCH Electrobrake 01
 C4 Picasso	PARK.BRAKE	1.6 16v 110kw 5FX	Electrobrake AUTODETECT
 C4 Picasso	PARK.BRAKE	1.6 16v 88kw 5FW	BOSCH Electrobrake 01
 C4 Picasso	PARK.BRAKE	1.6 16v 88kw 5FW	Electrobrake AUTODETECT
 C4 Picasso	PARK.BRAKE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH Electrobrake 01
 C4 Picasso	PARK.BRAKE	1.6 HDI 16v 80kw 9HZ-FAP	Electrobrake AUTODETECT
 C4 Picasso	PARK.BRAKE	1.8 16v 92kw 6FY	BOSCH Electrobrake 01
 C4 Picasso	PARK.BRAKE	1.8 16v 92kw 6FY	Electrobrake AUTODETECT
 C4 Picasso	PARK.BRAKE	2.0 16v 103kw RFJ	BOSCH Electrobrake 01
 C4 Picasso	PARK.BRAKE	2.0 16v 103kw RFJ	Electrobrake AUTODETECT
 C4 Picasso	PARK.BRAKE	2.0 HDI 16v 100kw RHJ-FAP	BOSCH Electrobrake 01
 C4 Picasso	PARK.BRAKE	2.0 HDI 16v 100kw RHJ-FAP	Electrobrake AUTODETECT
 C4 Picasso	PARK.BRAKE	2.0 HDI 16v 100kw RHR-FAP	BOSCH Electrobrake 01
 C4 Picasso	PARK.BRAKE	2.0 HDI 16v 100kw RHR-FAP	Electrobrake AUTODETECT
 C4 Picasso	PARK.BRAKE	2.0 HDI 16v 110kw RHE	BOSCH Electrobrake 01
 C4 Picasso	PARK.BRAKE	2.0 HDI 16v 110kw RHE	Electric Brake AUTODETECT
 C4 Picasso	PARKING HELP	1.6 16v 103kw 5FT	AUTODETECT
 C4 Picasso	PARKING HELP	1.6 16v 103kw 5FT	BOSCH PDC 1.44
 C4 Picasso	PARKING HELP	1.6 16v 110kw 5FX	AUTODETECT
 C4 Picasso	PARKING HELP	1.6 16v 110kw 5FX	BOSCH PDC 1.44
 C4 Picasso	PARKING HELP	1.6 16v 88kw 5FW	AUTODETECT
 C4 Picasso	PARKING HELP	1.6 16v 88kw 5FW	BOSCH PDC 1.44
 C4 Picasso	PARKING HELP	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4 Picasso	PARKING HELP	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH PDC 1.44
 C4 Picasso	PARKING HELP	1.8 16v 92kw 6FY	AUTODETECT
 C4 Picasso	PARKING HELP	1.8 16v 92kw 6FY	BOSCH PDC 1.44
 C4 Picasso	PARKING HELP	2.0 16v 103kw RFJ	AUTODETECT
 C4 Picasso	PARKING HELP	2.0 16v 103kw RFJ	BOSCH PDC 1.44
 C4 Picasso	PARKING HELP	2.0 HDI 16v 100kw RHJ-FAP	AUTODETECT
 C4 Picasso	PARKING HELP	2.0 HDI 16v 100kw RHJ-FAP	BOSCH PDC 1.44
 C4 Picasso	PARKING HELP	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C4 Picasso	PARKING HELP	2.0 HDI 16v 100kw RHR-FAP	BOSCH PDC 1.44
 C4 Picasso	PARKING HELP	2.0 HDI 16v 110kw RHE	AUTODETECT
 C4 Picasso	PARKING HELP	2.0 HDI 16v 110kw RHE	BOSCH PDC 1.44
 C4 Picasso	PASS. SIDE DOOR	1.6 16v 103kw 5FT	ArvinMeritor PassengerDoor
 C4 Picasso	PASS. SIDE DOOR	1.6 16v 103kw 5FT	AUTODETECT
 C4 Picasso	PASS. SIDE DOOR	1.6 16v 110kw 5FX	ArvinMeritor PassengerDoor
 C4 Picasso	PASS. SIDE DOOR	1.6 16v 110kw 5FX	AUTODETECT
 C4 Picasso	PASS. SIDE DOOR	1.6 16v 88kw 5FW	ArvinMeritor PassengerDoor
 C4 Picasso	PASS. SIDE DOOR	1.6 16v 88kw 5FW	AUTODETECT
 C4 Picasso	PASS. SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	ArvinMeritor PassengerDoor

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4 Picasso	PASS. SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4 Picasso	PASS. SIDE DOOR	1.8 16v 92kw 6FY	ArvinMeritor PassengerDoor
 C4 Picasso	PASS. SIDE DOOR	1.8 16v 92kw 6FY	AUTODETECT
 C4 Picasso	PASS. SIDE DOOR	2.0 16v 103kw RFJ	ArvinMeritor PassengerDoor
 C4 Picasso	PASS. SIDE DOOR	2.0 16v 103kw RFJ	AUTODETECT
 C4 Picasso	PASS. SIDE DOOR	2.0 HDI 16v 100kw RHJ-FAP	ArvinMeritor PassengerDoor
 C4 Picasso	PASS. SIDE DOOR	2.0 HDI 16v 100kw RHJ-FAP	AUTODETECT
 C4 Picasso	PASS. SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	ArvinMeritor PassengerDoor
 C4 Picasso	PASS. SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C4 Picasso	PASS. SIDE DOOR	2.0 HDI 16v 110kw RHE	ArvinMeritor PassengerDoor
 C4 Picasso	PASS. SIDE DOOR	2.0 HDI 16v 110kw RHE	AUTODETECT
 C4 Picasso	PHONE	1.6 16v 110kw 5FX	AUTODETECT
 C4 Picasso	PHONE	1.6 16v 110kw 5FX	Mobile Phone Kit AUTODETECT
 C4 Picasso	PHONE	1.6 16v 88kw 5FW	AUTODETECT
 C4 Picasso	PHONE	1.6 16v 88kw 5FW	Mobile Phone Kit AUTODETECT
 C4 Picasso	PHONE	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4 Picasso	PHONE	1.6 HDI 16v 80kw 9HZ-FAP	Mobile Phone Kit AUTODETECT
 C4 Picasso	PHONE	1.8 16v 92kw 6FY	AUTODETECT
 C4 Picasso	PHONE	1.8 16v 92kw 6FY	Mobile Phone Kit AUTODETECT
 C4 Picasso	PHONE	2.0 16v 103kw RFJ	AUTODETECT
 C4 Picasso	PHONE	2.0 16v 103kw RFJ	Mobile Phone Kit AUTODETECT
 C4 Picasso	PHONE	2.0 HDI 16v 100kw RHJ-FAP	AUTODETECT
 C4 Picasso	PHONE	2.0 HDI 16v 100kw RHJ-FAP	Mobile Phone Kit AUTODETECT
 C4 Picasso	PHONE	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C4 Picasso	PHONE	2.0 HDI 16v 100kw RHR-FAP	Mobile Phone Kit AUTODETECT
 C4 Picasso	PHONE	2.0 HDI 16v 110kw RHE	AUTODETECT
 C4 Picasso	PHONE	2.0 HDI 16v 110kw RHE	Mobile Phone Kit AUTODETECT
 C4 Picasso	RADIO / CD	1.6 16v 103kw 5FT	Ampli Audio AUTODETECT
 C4 Picasso	RADIO / CD	1.6 16v 103kw 5FT	AudioSystem AUTODETECT
 C4 Picasso	RADIO / CD	1.6 16v 103kw 5FT	BLAUPUNKT Audio System 18.10
 C4 Picasso	RADIO / CD	1.6 16v 103kw 5FT	CD Changer AUTODETECT
 C4 Picasso	RADIO / CD	1.6 16v 110kw 5FX	Ampli Audio AUTODETECT
 C4 Picasso	RADIO / CD	1.6 16v 110kw 5FX	AudioSystem AUTODETECT
 C4 Picasso	RADIO / CD	1.6 16v 110kw 5FX	BLAUPUNKT Audio System 18.10
 C4 Picasso	RADIO / CD	1.6 16v 110kw 5FX	CD Changer AUTODETECT
 C4 Picasso	RADIO / CD	1.6 16v 88kw 5FW	Ampli Audio AUTODETECT
 C4 Picasso	RADIO / CD	1.6 16v 88kw 5FW	AudioSystem AUTODETECT
 C4 Picasso	RADIO / CD	1.6 16v 88kw 5FW	BLAUPUNKT Audio System 18.10
 C4 Picasso	RADIO / CD	1.6 16v 88kw 5FW	CD Changer AUTODETECT
 C4 Picasso	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Ampli Audio AUTODETECT
 C4 Picasso	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	AudioSystem AUTODETECT
 C4 Picasso	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	BLAUPUNKT Audio System 18.10
 C4 Picasso	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	CD Changer AUTODETECT
 C4 Picasso	RADIO / CD	1.8 16v 92kw 6FY	Ampli Audio AUTODETECT
 C4 Picasso	RADIO / CD	1.8 16v 92kw 6FY	AudioSystem AUTODETECT
 C4 Picasso	RADIO / CD	1.8 16v 92kw 6FY	BLAUPUNKT Audio System 18.10
 C4 Picasso	RADIO / CD	1.8 16v 92kw 6FY	CD Changer AUTODETECT
 C4 Picasso	RADIO / CD	2.0 16v 103kw RFJ	Ampli Audio AUTODETECT
 C4 Picasso	RADIO / CD	2.0 16v 103kw RFJ	AudioSystem AUTODETECT
 C4 Picasso	RADIO / CD	2.0 16v 103kw RFJ	BLAUPUNKT Audio System 18.10
 C4 Picasso	RADIO / CD	2.0 16v 103kw RFJ	CD Changer AUTODETECT
 C4 Picasso	RADIO / CD	2.0 HDI 16v 100kw RHJ-FAP	Ampli Audio AUTODETECT
 C4 Picasso	RADIO / CD	2.0 HDI 16v 100kw RHJ-FAP	AudioSystem AUTODETECT
 C4 Picasso	RADIO / CD	2.0 HDI 16v 100kw RHJ-FAP	BLAUPUNKT Audio System 18.10
 C4 Picasso	RADIO / CD	2.0 HDI 16v 100kw RHJ-FAP	CD Changer AUTODETECT
 C4 Picasso	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP	Ampli Audio AUTODETECT
 C4 Picasso	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP	AudioSystem AUTODETECT
 C4 Picasso	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP	BLAUPUNKT Audio System 18.10

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4 Picasso	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP	CD Changer AUTODETECT
 C4 Picasso	RADIO / CD	2.0 HDI 16v 110kw RHE	Ampli Audio AUTODETECT
 C4 Picasso	RADIO / CD	2.0 HDI 16v 110kw RHE	AudioSystem AUTODETECT
 C4 Picasso	RADIO / CD	2.0 HDI 16v 110kw RHE	BLAUPUNKT Audio System 18.10
 C4 Picasso	RADIO / CD	2.0 HDI 16v 110kw RHE	CD Changer AUTODETECT
 C4 Picasso	RAIN-LUMINOSITY S	1.6 16v 103kw 5FT	AUTODETECT
 C4 Picasso	RAIN-LUMINOSITY S	1.6 16v 103kw 5FT	BOSCH WSS
 C4 Picasso	RAIN-LUMINOSITY S	1.6 16v 110kw 5FX	AUTODETECT
 C4 Picasso	RAIN-LUMINOSITY S	1.6 16v 110kw 5FX	BOSCH WSS
 C4 Picasso	RAIN-LUMINOSITY S	1.6 16v 88kw 5FW	AUTODETECT
 C4 Picasso	RAIN-LUMINOSITY S	1.6 16v 88kw 5FW	BOSCH WSS
 C4 Picasso	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4 Picasso	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH WSS
 C4 Picasso	RAIN-LUMINOSITY S	1.8 16v 92kw 6FY	AUTODETECT
 C4 Picasso	RAIN-LUMINOSITY S	1.8 16v 92kw 6FY	BOSCH WSS
 C4 Picasso	RAIN-LUMINOSITY S	2.0 16v 103kw RFJ	AUTODETECT
 C4 Picasso	RAIN-LUMINOSITY S	2.0 16v 103kw RFJ	BOSCH WSS
 C4 Picasso	RAIN-LUMINOSITY S	2.0 HDI 16v 100kw RHJ-FAP	AUTODETECT
 C4 Picasso	RAIN-LUMINOSITY S	2.0 HDI 16v 100kw RHJ-FAP	BOSCH WSS
 C4 Picasso	RAIN-LUMINOSITY S	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C4 Picasso	RAIN-LUMINOSITY S	2.0 HDI 16v 100kw RHR-FAP	BOSCH WSS
 C4 Picasso	RAIN-LUMINOSITY S	2.0 HDI 16v 110kw RHE	AUTODETECT
 C4 Picasso	RAIN-LUMINOSITY S	2.0 HDI 16v 110kw RHE	BOSCH WSS
 C4 Picasso	STEERING WHEEL E	1.6 16v 103kw 5FT	AUTODETECT
 C4 Picasso	STEERING WHEEL E	1.6 16v 103kw 5FT	VALEO 04.96
 C4 Picasso	STEERING WHEEL E	1.6 16v 110kw 5FX	AUTODETECT
 C4 Picasso	STEERING WHEEL E	1.6 16v 110kw 5FX	VALEO 04.96
 C4 Picasso	STEERING WHEEL E	1.6 16v 88kw 5FW	AUTODETECT
 C4 Picasso	STEERING WHEEL E	1.6 16v 88kw 5FW	VALEO 04.96
 C4 Picasso	STEERING WHEEL E	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4 Picasso	STEERING WHEEL E	1.6 HDI 16v 80kw 9HZ-FAP	VALEO 04.96
 C4 Picasso	STEERING WHEEL E	1.8 16v 92kw 6FY	AUTODETECT
 C4 Picasso	STEERING WHEEL E	1.8 16v 92kw 6FY	VALEO 04.96
 C4 Picasso	STEERING WHEEL E	2.0 16v 103kw RFJ	AUTODETECT
 C4 Picasso	STEERING WHEEL E	2.0 16v 103kw RFJ	VALEO 04.96
 C4 Picasso	STEERING WHEEL E	2.0 HDI 16v 100kw RHJ-FAP	AUTODETECT
 C4 Picasso	STEERING WHEEL E	2.0 HDI 16v 100kw RHJ-FAP	VALEO 04.96
 C4 Picasso	STEERING WHEEL E	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C4 Picasso	STEERING WHEEL E	2.0 HDI 16v 100kw RHR-FAP	VALEO 04.96
 C4 Picasso	STEERING WHEEL E	2.0 HDI 16v 110kw RHE	AUTODETECT
 C4 Picasso	STEERING WHEEL E	2.0 HDI 16v 110kw RHE	VALEO 04.96
 C4 Picasso	SUSPENSION CONTR	1.6 16v 103kw 5FT	AUTODETECT
 C4 Picasso	SUSPENSION CONTR	1.6 16v 110kw 5FX	AUTODETECT
 C4 Picasso	SUSPENSION CONTR	1.6 16v 88kw 5FW	AUTODETECT
 C4 Picasso	SUSPENSION CONTR	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4 Picasso	SUSPENSION CONTR	1.8 16v 92kw 6FY	AUTODETECT
 C4 Picasso	SUSPENSION CONTR	2.0 16v 103kw RFJ	AUTODETECT
 C4 Picasso	SUSPENSION CONTR	2.0 HDI 16v 100kw RHJ-FAP	AUTODETECT
 C4 Picasso	SUSPENSION CONTR	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C4 Picasso	SUSPENSION CONTR	2.0 HDI 16v 110kw RHE	AUTODETECT
 C4 Picasso	TIRE PRESSURE	1.6 16v 103kw 5FT	Siemens-JCAE AUTODETECT
 C4 Picasso	TIRE PRESSURE	1.6 16v 110kw 5FX	Siemens-JCAE AUTODETECT
 C4 Picasso	TIRE PRESSURE	1.6 16v 88kw 5FW	Siemens-JCAE AUTODETECT
 C4 Picasso	TIRE PRESSURE	1.6 HDI 16v 80kw 9HZ-FAP	Siemens-JCAE AUTODETECT
 C4 Picasso	TIRE PRESSURE	1.8 16v 92kw 6FY	Siemens-JCAE AUTODETECT
 C4 Picasso	TIRE PRESSURE	2.0 16v 103kw RFJ	Siemens-JCAE AUTODETECT
 C4 Picasso	TIRE PRESSURE	2.0 HDI 16v 100kw RHJ-FAP	Siemens-JCAE AUTODETECT
 C4 Picasso	TIRE PRESSURE	2.0 HDI 16v 100kw RHR-FAP	Siemens-JCAE AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4 Picasso	TIRE PRESSURE	2.0 HDI 16v 110kw RHE	Siemens-JCAE AUTODETECT
 C4 Picasso	WIPERS	1.6 16v 103kw 5FT	Wiper
 C4 Picasso	WIPERS	1.6 16v 110kw 5FX	Wiper
 C4 Picasso	WIPERS	1.6 16v 88kw 5FW	Wiper
 C4 Picasso	WIPERS	1.6 HDI 16v 80kw 9HZ-FAP	Wiper
 C4 Picasso	WIPERS	1.8 16v 92kw 6FY	Wiper
 C4 Picasso	WIPERS	2.0 16v 103kw RFJ	Wiper
 C4 Picasso	WIPERS	2.0 HDI 16v 100kw RHJ-FAP	Wiper
 C4 Picasso	WIPERS	2.0 HDI 16v 100kw RHR-FAP	Wiper
 C4 Picasso	WIPERS	2.0 HDI 16v 110kw RHE	Wiper
 C4	ABS	1.4 16v 66kw KFU	BOSCH ABS 8
 C4	ABS	1.6 16v 103kw 5FT	BOSCH ABS 8
 C4	ABS	1.6 16v 110kw 5FX	BOSCH ABS 8
 C4	ABS	1.6 16v 80kw N6A	BOSCH ABS 8
 C4	ABS	1.6 16v 80kw NFU	BOSCH ABS 8
 C4	ABS	1.6 16v 88kw 5FW	BOSCH ABS 8
 C4	ABS	1.6 HDI 16v 66kw 9HV	BOSCH ABS 8
 C4	ABS	1.6 HDI 16v 66kw 9HX	BOSCH ABS 8
 C4	ABS	1.6 HDI 16v 80kw 9HY	BOSCH ABS 8
 C4	ABS	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ABS 8
 C4	ABS	2.0 16v 100kw RFN	BOSCH ABS 8
 C4	ABS	2.0 16v 103kw RFJ	BOSCH ABS 8
 C4	ABS	2.0 16v 130kw RFK	BOSCH ABS 8
 C4	ABS	2.0 HDI 16v 100kw RHR-FAP	BOSCH ABS 8
 C4	ABS	2.0 HDI 16v 103kw RHF-FAP	BOSCH ABS 8
 C4	ABS	2.0 HDI 8v 80kw RHZ	BOSCH ABS 8
 C4	ABS + TRACT. CONT	1.4 16v 66kw KFU	BOSCH ABS 8.0 AUTODETECT
 C4	ABS + TRACT. CONT	1.4 16v 66kw KFU	BOSCH ABS 8.1 AUTODETECT
 C4	ABS + TRACT. CONT	1.4 16v 66kw KFU	BOSCH ESP 8.0 AUTODETECT
 C4	ABS + TRACT. CONT	1.4 16v 66kw KFU	BOSCH ESP 8.1 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 16v 103kw 5FT	BOSCH ABS 8.0 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 16v 103kw 5FT	BOSCH ABS 8.1 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 16v 103kw 5FT	BOSCH ESP 8.0 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 16v 103kw 5FT	BOSCH ESP 8.1 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 16v 110kw 5FX	BOSCH ABS 8.0 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 16v 110kw 5FX	BOSCH ABS 8.1 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 16v 110kw 5FX	BOSCH ESP 8.0 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 16v 110kw 5FX	BOSCH ESP 8.1 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 16v 80kw N6A	BOSCH ABS 8.0 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 16v 80kw N6A	BOSCH ABS 8.1 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 16v 80kw N6A	BOSCH ESP 8.0 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 16v 80kw N6A	BOSCH ESP 8.1 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 16v 80kw NFU	BOSCH ABS 8.0 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 16v 80kw NFU	BOSCH ABS 8.1 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 16v 80kw NFU	BOSCH ESP 8.0 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 16v 80kw NFU	BOSCH ESP 8.1 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 16v 88kw 5FW	BOSCH ABS 8.0 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 16v 88kw 5FW	BOSCH ABS 8.1 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 16v 88kw 5FW	BOSCH ESP 8.0 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 16v 88kw 5FW	BOSCH ESP 8.1 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HV	BOSCH ABS 8.0 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HV	BOSCH ABS 8.1 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HV	BOSCH ESP 8.0 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HV	BOSCH ESP 8.1 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX	BOSCH ABS 8.0 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX	BOSCH ABS 8.1 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX	BOSCH ESP 8.0 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX	BOSCH ESP 8.1 AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HY	BOSCH ABS 8.0 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HY	BOSCH ABS 8.1 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HY	BOSCH ESP 8.0 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HY	BOSCH ESP 8.1 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ABS 8.0 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ABS 8.1 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ESP 8.0 AUTODETECT
 C4	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ESP 8.1 AUTODETECT
 C4	ABS + TRACT. CONT	2.0 16v 100kw RFN	BOSCH ABS 8.0 AUTODETECT
 C4	ABS + TRACT. CONT	2.0 16v 100kw RFN	BOSCH ABS 8.1 AUTODETECT
 C4	ABS + TRACT. CONT	2.0 16v 100kw RFN	BOSCH ESP 8.0 AUTODETECT
 C4	ABS + TRACT. CONT	2.0 16v 100kw RFN	BOSCH ESP 8.1 AUTODETECT
 C4	ABS + TRACT. CONT	2.0 16v 103kw RFJ	BOSCH ABS 8.0 AUTODETECT
 C4	ABS + TRACT. CONT	2.0 16v 103kw RFJ	BOSCH ABS 8.1 AUTODETECT
 C4	ABS + TRACT. CONT	2.0 16v 103kw RFJ	BOSCH ESP 8.0 AUTODETECT
 C4	ABS + TRACT. CONT	2.0 16v 103kw RFJ	BOSCH ESP 8.1 AUTODETECT
 C4	ABS + TRACT. CONT	2.0 16v 130kw RFK	BOSCH ABS 8.0 AUTODETECT
 C4	ABS + TRACT. CONT	2.0 16v 130kw RFK	BOSCH ABS 8.1 AUTODETECT
 C4	ABS + TRACT. CONT	2.0 16v 130kw RFK	BOSCH ESP 8.0 AUTODETECT
 C4	ABS + TRACT. CONT	2.0 16v 130kw RFK	BOSCH ESP 8.1 AUTODETECT
 C4	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP	BOSCH ABS 8.0 AUTODETECT
 C4	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP	BOSCH ABS 8.1 AUTODETECT
 C4	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP	BOSCH ESP 8.0 AUTODETECT
 C4	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP	BOSCH ESP 8.1 AUTODETECT
 C4	ABS + TRACT. CONT	2.0 HDI 16v 103kw RHF-FAP	BOSCH ABS 8.0 AUTODETECT
 C4	ABS + TRACT. CONT	2.0 HDI 16v 103kw RHF-FAP	BOSCH ABS 8.1 AUTODETECT
 C4	ABS + TRACT. CONT	2.0 HDI 16v 103kw RHF-FAP	BOSCH ESP 8.0 AUTODETECT
 C4	ABS + TRACT. CONT	2.0 HDI 16v 103kw RHF-FAP	BOSCH ESP 8.1 AUTODETECT
 C4	ABS + TRACT. CONT	2.0 HDI 8v 80kw RHZ	BOSCH ABS 8.0 AUTODETECT
 C4	ABS + TRACT. CONT	2.0 HDI 8v 80kw RHZ	BOSCH ABS 8.1 AUTODETECT
 C4	ABS + TRACT. CONT	2.0 HDI 8v 80kw RHZ	BOSCH ESP 8.0 AUTODETECT
 C4	ABS + TRACT. CONT	2.0 HDI 8v 80kw RHZ	BOSCH ESP 8.1 AUTODETECT
 C4	AIRBAG	1.4 16v 66kw KFU	AirBag CENTRAL AUTODETECT
 C4	AIRBAG	1.4 16v 66kw KFU	Autoliv AirBag
 C4	AIRBAG	1.6 16v 103kw 5FT	AirBag CENTRAL AUTODETECT
 C4	AIRBAG	1.6 16v 103kw 5FT	Autoliv AirBag
 C4	AIRBAG	1.6 16v 110kw 5FX	AirBag CENTRAL AUTODETECT
 C4	AIRBAG	1.6 16v 110kw 5FX	Autoliv AirBag
 C4	AIRBAG	1.6 16v 80kw N6A	AirBag CENTRAL AUTODETECT
 C4	AIRBAG	1.6 16v 80kw N6A	Autoliv AirBag
 C4	AIRBAG	1.6 16v 80kw NFU	AirBag CENTRAL AUTODETECT
 C4	AIRBAG	1.6 16v 80kw NFU	Autoliv AirBag
 C4	AIRBAG	1.6 16v 88kw 5FW	AirBag CENTRAL AUTODETECT
 C4	AIRBAG	1.6 16v 88kw 5FW	Autoliv AirBag
 C4	AIRBAG	1.6 HDI 16v 66kw 9HV	AirBag CENTRAL AUTODETECT
 C4	AIRBAG	1.6 HDI 16v 66kw 9HV	Autoliv AirBag
 C4	AIRBAG	1.6 HDI 16v 66kw 9HX	AirBag CENTRAL AUTODETECT
 C4	AIRBAG	1.6 HDI 16v 66kw 9HX	Autoliv AirBag
 C4	AIRBAG	1.6 HDI 16v 80kw 9HY	AirBag CENTRAL AUTODETECT
 C4	AIRBAG	1.6 HDI 16v 80kw 9HY	Autoliv AirBag
 C4	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL AUTODETECT
 C4	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP	Autoliv AirBag
 C4	AIRBAG	2.0 16v 100kw RFN	AirBag CENTRAL AUTODETECT
 C4	AIRBAG	2.0 16v 100kw RFN	Autoliv AirBag
 C4	AIRBAG	2.0 16v 103kw RFJ	AirBag CENTRAL AUTODETECT
 C4	AIRBAG	2.0 16v 103kw RFJ	Autoliv AirBag
 C4	AIRBAG	2.0 16v 130kw RFK	AirBag CENTRAL AUTODETECT
 C4	AIRBAG	2.0 16v 130kw RFK	Autoliv AirBag

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4	AIRBAG	2.0 HDI 16v 100kw RHR-FAP	AirBag CENTRAL AUTODETECT
 C4	AIRBAG	2.0 HDI 16v 100kw RHR-FAP	Autoliv AirBag
 C4	AIRBAG	2.0 HDI 16v 103kw RHF-FAP	AirBag CENTRAL AUTODETECT
 C4	AIRBAG	2.0 HDI 16v 103kw RHF-FAP	Autoliv AirBag
 C4	AIRBAG	2.0 HDI 8v 80kw RHZ	AirBag CENTRAL AUTODETECT
 C4	AIRBAG	2.0 HDI 8v 80kw RHZ	Autoliv AirBag
 C4	ANTITHEFT	1.4 16v 66kw KFU	Alarm PSA2 AUTODETECT
 C4	ANTITHEFT	1.6 16v 103kw 5FT	Alarm PSA2 AUTODETECT
 C4	ANTITHEFT	1.6 16v 110kw 5FX	Alarm PSA2 AUTODETECT
 C4	ANTITHEFT	1.6 16v 80kw N6A	Alarm PSA2 AUTODETECT
 C4	ANTITHEFT	1.6 16v 80kw NFU	Alarm PSA2 AUTODETECT
 C4	ANTITHEFT	1.6 16v 88kw 5FW	Alarm PSA2 AUTODETECT
 C4	ANTITHEFT	1.6 HDI 16v 66kw 9HV	Alarm PSA2 AUTODETECT
 C4	ANTITHEFT	1.6 HDI 16v 66kw 9HX	Alarm PSA2 AUTODETECT
 C4	ANTITHEFT	1.6 HDI 16v 80kw 9HY	Alarm PSA2 AUTODETECT
 C4	ANTITHEFT	1.6 HDI 16v 80kw 9HZ-FAP	Alarm PSA2 AUTODETECT
 C4	ANTITHEFT	2.0 16v 100kw RFN	Alarm PSA2 AUTODETECT
 C4	ANTITHEFT	2.0 16v 103kw RFJ	Alarm PSA2 AUTODETECT
 C4	ANTITHEFT	2.0 16v 130kw RFK	Alarm PSA2 AUTODETECT
 C4	ANTITHEFT	2.0 HDI 16v 100kw RHR-FAP	Alarm PSA2 AUTODETECT
 C4	ANTITHEFT	2.0 HDI 16v 103kw RHF-FAP	Alarm PSA2 AUTODETECT
 C4	ANTITHEFT	2.0 HDI 8v 80kw RHZ	Alarm PSA2 AUTODETECT
 C4	AUTOM. TRANSMISSI	1.4 16v 66kw KFU	A/T AL4 AUTODETECT
 C4	AUTOM. TRANSMISSI	1.4 16v 66kw KFU	A/T AM6 AUTODETECT
 C4	AUTOM. TRANSMISSI	1.4 16v 66kw KFU	A/T MCP AUTODETECT
 C4	AUTOM. TRANSMISSI	1.6 16v 103kw 5FT	A/T AL4 AUTODETECT
 C4	AUTOM. TRANSMISSI	1.6 16v 103kw 5FT	A/T AM6 AUTODETECT
 C4	AUTOM. TRANSMISSI	1.6 16v 110kw 5FX	A/T AL4 AUTODETECT
 C4	AUTOM. TRANSMISSI	1.6 16v 110kw 5FX	A/T AM6 AUTODETECT
 C4	AUTOM. TRANSMISSI	1.6 16v 110kw 5FX	A/T MCP AUTODETECT
 C4	AUTOM. TRANSMISSI	1.6 16v 80kw N6A	A/T AL4 AUTODETECT
 C4	AUTOM. TRANSMISSI	1.6 16v 80kw N6A	A/T AM6 AUTODETECT
 C4	AUTOM. TRANSMISSI	1.6 16v 80kw NFU	A/T AL4 AUTODETECT
 C4	AUTOM. TRANSMISSI	1.6 16v 80kw NFU	A/T AM6 AUTODETECT
 C4	AUTOM. TRANSMISSI	1.6 16v 88kw 5FW	A/T AL4 AUTODETECT
 C4	AUTOM. TRANSMISSI	1.6 16v 88kw 5FW	A/T MCP AUTODETECT
 C4	AUTOM. TRANSMISSI	1.6 HDI 16v 66kw 9HV	A/T AL4 AUTODETECT
 C4	AUTOM. TRANSMISSI	1.6 HDI 16v 66kw 9HV	A/T AM6 AUTODETECT
 C4	AUTOM. TRANSMISSI	1.6 HDI 16v 66kw 9HV	A/T MCP AUTODETECT
 C4	AUTOM. TRANSMISSI	1.6 HDI 16v 66kw 9HX	A/T AL4 AUTODETECT
 C4	AUTOM. TRANSMISSI	1.6 HDI 16v 66kw 9HX	A/T AM6 AUTODETECT
 C4	AUTOM. TRANSMISSI	1.6 HDI 16v 66kw 9HX	A/T MCP AUTODETECT
 C4	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HY	A/T AL4 AUTODETECT
 C4	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HY	A/T AM6 AUTODETECT
 C4	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HY	A/T MCP AUTODETECT
 C4	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP	A/T AL4 AUTODETECT
 C4	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP	A/T AM6 AUTODETECT
 C4	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP	A/T MCP AUTODETECT
 C4	AUTOM. TRANSMISSI	2.0 16v 100kw RFN	A/T AL4 AUTODETECT
 C4	AUTOM. TRANSMISSI	2.0 16v 100kw RFN	A/T AM6 AUTODETECT
 C4	AUTOM. TRANSMISSI	2.0 16v 100kw RFN	A/T MCP AUTODETECT
 C4	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ	A/T AL4 AUTODETECT
 C4	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ	A/T AM6 AUTODETECT
 C4	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ	A/T MCP AUTODETECT
 C4	AUTOM. TRANSMISSI	2.0 16v 130kw RFK	A/T AL4 AUTODETECT
 C4	AUTOM. TRANSMISSI	2.0 16v 130kw RFK	A/T AM6 AUTODETECT
 C4	AUTOM. TRANSMISSI	2.0 16v 130kw RFK	A/T MCP AUTODETECT
 C4	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP	A/T AL4 AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP	A/T AM6 AUTODETECT
 C4	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP	A/T MCP AUTODETECT
 C4	AUTOM. TRANSMISSI	2.0 HDI 16v 103kw RHF-FAP	A/T AL4 AUTODETECT
 C4	AUTOM. TRANSMISSI	2.0 HDI 16v 103kw RHF-FAP	A/T AM6 AUTODETECT
 C4	AUTOM. TRANSMISSI	2.0 HDI 16v 103kw RHF-FAP	A/T MCP AUTODETECT
 C4	AUTOM. TRANSMISSI	2.0 HDI 8v 80kw RHZ	A/T AL4 AUTODETECT
 C4	AUTOM. TRANSMISSI	2.0 HDI 8v 80kw RHZ	A/T AM6 AUTODETECT
 C4	AUTOM. TRANSMISSI	2.0 HDI 8v 80kw RHZ	A/T MCP AUTODETECT
 C4	CHASSIS NETWORK	1.4 16v 66kw KFU	Body Computer BSI AUTODETECT
 C4	CHASSIS NETWORK	1.4 16v 66kw KFU	Body Computer BSM AUTODETECT
 C4	CHASSIS NETWORK	1.4 16v 66kw KFU	Body Computer BSR AUTODETECT
 C4	CHASSIS NETWORK	1.4 16v 66kw KFU	High frequency receiver AUTODETECT
 C4	CHASSIS NETWORK	1.4 16v 66kw KFU	JCAE Body Computer BSI+Service
 C4	CHASSIS NETWORK	1.6 16v 103kw 5FT	Body Computer BSI AUTODETECT
 C4	CHASSIS NETWORK	1.6 16v 103kw 5FT	Body Computer BSM AUTODETECT
 C4	CHASSIS NETWORK	1.6 16v 103kw 5FT	Body Computer BSR AUTODETECT
 C4	CHASSIS NETWORK	1.6 16v 103kw 5FT	High frequency receiver AUTODETECT
 C4	CHASSIS NETWORK	1.6 16v 103kw 5FT	JCAE Body Computer BSI+Service
 C4	CHASSIS NETWORK	1.6 16v 110kw 5FX	Body Computer BSI AUTODETECT
 C4	CHASSIS NETWORK	1.6 16v 110kw 5FX	Body Computer BSM AUTODETECT
 C4	CHASSIS NETWORK	1.6 16v 110kw 5FX	Body Computer BSR AUTODETECT
 C4	CHASSIS NETWORK	1.6 16v 110kw 5FX	High frequency receiver AUTODETECT
 C4	CHASSIS NETWORK	1.6 16v 110kw 5FX	JCAE Body Computer BSI+Service
 C4	CHASSIS NETWORK	1.6 16v 80kw N6A	Body Computer BSI AUTODETECT
 C4	CHASSIS NETWORK	1.6 16v 80kw N6A	Body Computer BSM AUTODETECT
 C4	CHASSIS NETWORK	1.6 16v 80kw N6A	Body Computer BSR AUTODETECT
 C4	CHASSIS NETWORK	1.6 16v 80kw N6A	High frequency receiver AUTODETECT
 C4	CHASSIS NETWORK	1.6 16v 80kw N6A	JCAE Body Computer BSI+Service
 C4	CHASSIS NETWORK	1.6 16v 80kw NFU	Body Computer BSI AUTODETECT
 C4	CHASSIS NETWORK	1.6 16v 80kw NFU	Body Computer BSM AUTODETECT
 C4	CHASSIS NETWORK	1.6 16v 80kw NFU	Body Computer BSR AUTODETECT
 C4	CHASSIS NETWORK	1.6 16v 80kw NFU	High frequency receiver AUTODETECT
 C4	CHASSIS NETWORK	1.6 16v 80kw NFU	JCAE Body Computer BSI+Service
 C4	CHASSIS NETWORK	1.6 16v 88kw 5FW	Body Computer BSI AUTODETECT
 C4	CHASSIS NETWORK	1.6 16v 88kw 5FW	Body Computer BSM AUTODETECT
 C4	CHASSIS NETWORK	1.6 16v 88kw 5FW	Body Computer BSR AUTODETECT
 C4	CHASSIS NETWORK	1.6 16v 88kw 5FW	High frequency receiver AUTODETECT
 C4	CHASSIS NETWORK	1.6 16v 88kw 5FW	JCAE Body Computer BSI+Service
 C4	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HV	Body Computer BSI AUTODETECT
 C4	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HV	Body Computer BSM AUTODETECT
 C4	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HV	Body Computer BSR AUTODETECT
 C4	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HV	High frequency receiver AUTODETECT
 C4	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HV	JCAE Body Computer BSI+Service
 C4	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	Body Computer BSI AUTODETECT
 C4	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	Body Computer BSM AUTODETECT
 C4	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	Body Computer BSR AUTODETECT
 C4	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	High frequency receiver AUTODETECT
 C4	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	JCAE Body Computer BSI+Service
 C4	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY	Body Computer BSI AUTODETECT
 C4	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY	Body Computer BSM AUTODETECT
 C4	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY	Body Computer BSR AUTODETECT
 C4	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY	JCAE Body Computer BSI+Service
 C4	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSI AUTODETECT
 C4	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSM AUTODETECT
 C4	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSR AUTODETECT
 C4	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	High frequency receiver AUTODETECT
 C4	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	JCAE Body Computer BSI+Service
 C4	CHASSIS NETWORK	2.0 16v 100kw RFN	Body Computer BSI AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4	CHASSIS NETWORK	2.0 16v 100kw RFN	Body Computer BSM AUTODETECT
 C4	CHASSIS NETWORK	2.0 16v 100kw RFN	Body Computer BSR AUTODETECT
 C4	CHASSIS NETWORK	2.0 16v 100kw RFN	High frequency receiver AUTODETECT
 C4	CHASSIS NETWORK	2.0 16v 100kw RFN	JCAE Body Computer BSI+Service
 C4	CHASSIS NETWORK	2.0 16v 103kw RFJ	Body Computer BSI AUTODETECT
 C4	CHASSIS NETWORK	2.0 16v 103kw RFJ	Body Computer BSM AUTODETECT
 C4	CHASSIS NETWORK	2.0 16v 103kw RFJ	Body Computer BSR AUTODETECT
 C4	CHASSIS NETWORK	2.0 16v 103kw RFJ	High frequency receiver AUTODETECT
 C4	CHASSIS NETWORK	2.0 16v 103kw RFJ	JCAE Body Computer BSI+Service
 C4	CHASSIS NETWORK	2.0 16v 130kw RFK	Body Computer BSI AUTODETECT
 C4	CHASSIS NETWORK	2.0 16v 130kw RFK	Body Computer BSM AUTODETECT
 C4	CHASSIS NETWORK	2.0 16v 130kw RFK	Body Computer BSR AUTODETECT
 C4	CHASSIS NETWORK	2.0 16v 130kw RFK	High frequency receiver AUTODETECT
 C4	CHASSIS NETWORK	2.0 16v 130kw RFK	JCAE Body Computer BSI+Service
 C4	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	Body Computer BSI AUTODETECT
 C4	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	Body Computer BSM AUTODETECT
 C4	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	Body Computer BSR AUTODETECT
 C4	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	High frequency receiver AUTODETECT
 C4	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	JCAE Body Computer BSI+Service
 C4	CHASSIS NETWORK	2.0 HDI 16v 103kw RHF-FAP	Body Computer BSI AUTODETECT
 C4	CHASSIS NETWORK	2.0 HDI 16v 103kw RHF-FAP	Body Computer BSM AUTODETECT
 C4	CHASSIS NETWORK	2.0 HDI 16v 103kw RHF-FAP	Body Computer BSR AUTODETECT
 C4	CHASSIS NETWORK	2.0 HDI 16v 103kw RHF-FAP	High frequency receiver AUTODETECT
 C4	CHASSIS NETWORK	2.0 HDI 16v 103kw RHF-FAP	JCAE Body Computer BSI+Service
 C4	CHASSIS NETWORK	2.0 HDI 8v 80kw RHZ	Body Computer BSI AUTODETECT
 C4	CHASSIS NETWORK	2.0 HDI 8v 80kw RHZ	Body Computer BSM AUTODETECT
 C4	CHASSIS NETWORK	2.0 HDI 8v 80kw RHZ	Body Computer BSR AUTODETECT
 C4	CHASSIS NETWORK	2.0 HDI 8v 80kw RHZ	High frequency receiver AUTODETECT
 C4	CHASSIS NETWORK	2.0 HDI 8v 80kw RHZ	JCAE Body Computer BSI+Service
 C4	CLIMA	1.4 16v 66kw KFU	CLIMA AUTODETECT
 C4	CLIMA	1.6 16v 103kw 5FT	CLIMA AUTODETECT
 C4	CLIMA	1.6 16v 110kw 5FX	CLIMA AUTODETECT
 C4	CLIMA	1.6 16v 80kw N6A	CLIMA AUTODETECT
 C4	CLIMA	1.6 16v 80kw NFU	CLIMA AUTODETECT
 C4	CLIMA	1.6 16v 88kw 5FW	CLIMA AUTODETECT
 C4	CLIMA	1.6 HDI 16v 66kw 9HV	CLIMA AUTODETECT
 C4	CLIMA	1.6 HDI 16v 66kw 9HX	CLIMA AUTODETECT
 C4	CLIMA	1.6 HDI 16v 80kw 9HY	CLIMA AUTODETECT
 C4	CLIMA	1.6 HDI 16v 80kw 9HZ-FAP	CLIMA AUTODETECT
 C4	CLIMA	2.0 16v 100kw RFN	CLIMA AUTODETECT
 C4	CLIMA	2.0 16v 103kw RFJ	CLIMA AUTODETECT
 C4	CLIMA	2.0 16v 130kw RFK	CLIMA AUTODETECT
 C4	CLIMA	2.0 HDI 16v 100kw RHR-FAP	CLIMA AUTODETECT
 C4	CLIMA	2.0 HDI 16v 103kw RHF-FAP	CLIMA AUTODETECT
 C4	CLIMA	2.0 HDI 8v 80kw RHZ	CLIMA AUTODETECT
 C4	COMFORT SYSTEM	1.4 16v 66kw KFU	AUTODETECT
 C4	COMFORT SYSTEM	1.4 16v 66kw KFU	School Module AUTODETECT
 C4	COMFORT SYSTEM	1.6 16v 103kw 5FT	AUTODETECT
 C4	COMFORT SYSTEM	1.6 16v 103kw 5FT	School Module AUTODETECT
 C4	COMFORT SYSTEM	1.6 16v 110kw 5FX	AUTODETECT
 C4	COMFORT SYSTEM	1.6 16v 110kw 5FX	School Module AUTODETECT
 C4	COMFORT SYSTEM	1.6 16v 80kw N6A	AUTODETECT
 C4	COMFORT SYSTEM	1.6 16v 80kw N6A	School Module AUTODETECT
 C4	COMFORT SYSTEM	1.6 16v 80kw NFU	AUTODETECT
 C4	COMFORT SYSTEM	1.6 16v 80kw NFU	School Module AUTODETECT
 C4	COMFORT SYSTEM	1.6 16v 88kw 5FW	AUTODETECT
 C4	COMFORT SYSTEM	1.6 16v 88kw 5FW	School Module AUTODETECT
 C4	COMFORT SYSTEM	1.6 HDI 16v 66kw 9HV	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4	COMFORT SYSTEM	1.6 HDI 16v 66kw 9HV	School Module AUTODETECT
 C4	COMFORT SYSTEM	1.6 HDI 16v 66kw 9HX	AUTODETECT
 C4	COMFORT SYSTEM	1.6 HDI 16v 66kw 9HX	School Module AUTODETECT
 C4	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C4	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HY	School Module AUTODETECT
 C4	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HZ-FAP	School Module AUTODETECT
 C4	COMFORT SYSTEM	2.0 16v 100kw RFN	AUTODETECT
 C4	COMFORT SYSTEM	2.0 16v 100kw RFN	School Module AUTODETECT
 C4	COMFORT SYSTEM	2.0 16v 103kw RFJ	AUTODETECT
 C4	COMFORT SYSTEM	2.0 16v 103kw RFJ	School Module AUTODETECT
 C4	COMFORT SYSTEM	2.0 16v 130kw RFK	AUTODETECT
 C4	COMFORT SYSTEM	2.0 16v 130kw RFK	School Module AUTODETECT
 C4	COMFORT SYSTEM	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C4	COMFORT SYSTEM	2.0 HDI 16v 100kw RHR-FAP	School Module AUTODETECT
 C4	COMFORT SYSTEM	2.0 HDI 16v 103kw RHF-FAP	AUTODETECT
 C4	COMFORT SYSTEM	2.0 HDI 16v 103kw RHF-FAP	School Module AUTODETECT
 C4	COMFORT SYSTEM	2.0 HDI 8v 80kw RHZ	AUTODETECT
 C4	COMFORT SYSTEM	2.0 HDI 8v 80kw RHZ	School Module AUTODETECT
 C4	DASH LAMPS	1.4 16v 66kw KFU	AUTODETECT
 C4	DASH LAMPS	1.4 16v 66kw KFU	Compte-Tours
 C4	DASH LAMPS	1.6 16v 103kw 5FT	AUTODETECT
 C4	DASH LAMPS	1.6 16v 103kw 5FT	Compte-Tours
 C4	DASH LAMPS	1.6 16v 110kw 5FX	AUTODETECT
 C4	DASH LAMPS	1.6 16v 110kw 5FX	Compte-Tours
 C4	DASH LAMPS	1.6 16v 80kw N6A	AUTODETECT
 C4	DASH LAMPS	1.6 16v 80kw N6A	Compte-Tours
 C4	DASH LAMPS	1.6 16v 80kw NFU	AUTODETECT
 C4	DASH LAMPS	1.6 16v 80kw NFU	Compte-Tours
 C4	DASH LAMPS	1.6 16v 88kw 5FW	AUTODETECT
 C4	DASH LAMPS	1.6 16v 88kw 5FW	Compte-Tours
 C4	DASH LAMPS	1.6 HDI 16v 66kw 9HV	AUTODETECT
 C4	DASH LAMPS	1.6 HDI 16v 66kw 9HV	Compte-Tours
 C4	DASH LAMPS	1.6 HDI 16v 66kw 9HX	AUTODETECT
 C4	DASH LAMPS	1.6 HDI 16v 66kw 9HX	Compte-Tours
 C4	DASH LAMPS	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C4	DASH LAMPS	1.6 HDI 16v 80kw 9HY	Compte-Tours
 C4	DASH LAMPS	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4	DASH LAMPS	1.6 HDI 16v 80kw 9HZ-FAP	Compte-Tours
 C4	DASH LAMPS	2.0 16v 100kw RFN	AUTODETECT
 C4	DASH LAMPS	2.0 16v 100kw RFN	Compte-Tours
 C4	DASH LAMPS	2.0 16v 103kw RFJ	AUTODETECT
 C4	DASH LAMPS	2.0 16v 103kw RFJ	Compte-Tours
 C4	DASH LAMPS	2.0 16v 130kw RFK	AUTODETECT
 C4	DASH LAMPS	2.0 16v 130kw RFK	AUTODETECT
 C4	DASH LAMPS	2.0 16v 130kw RFK	Compte-Tours
 C4	DASH LAMPS	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C4	DASH LAMPS	2.0 HDI 16v 100kw RHR-FAP	Compte-Tours
 C4	DASH LAMPS	2.0 HDI 16v 103kw RHF-FAP	AUTODETECT
 C4	DASH LAMPS	2.0 HDI 16v 103kw RHF-FAP	Compte-Tours
 C4	DASH LAMPS	2.0 HDI 8v 80kw RHZ	AUTODETECT
 C4	DASH LAMPS	2.0 HDI 8v 80kw RHZ	Compte-Tours
 C4	DASHBOARD	1.4 16v 66kw KFU	AUTODETECT
 C4	DASHBOARD	1.4 16v 66kw KFU	JCAE Dashboard
 C4	DASHBOARD	1.6 16v 103kw 5FT	AUTODETECT
 C4	DASHBOARD	1.6 16v 103kw 5FT	JCAE Dashboard
 C4	DASHBOARD	1.6 16v 110kw 5FX	AUTODETECT
 C4	DASHBOARD	1.6 16v 110kw 5FX	JCAE Dashboard

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4	DASHBOARD	1.6 16v 80kw N6A	AUTODETECT
 C4	DASHBOARD	1.6 16v 80kw N6A	JCAE Dashboard
 C4	DASHBOARD	1.6 16v 80kw NFU	AUTODETECT
 C4	DASHBOARD	1.6 16v 80kw NFU	JCAE Dashboard
 C4	DASHBOARD	1.6 16v 88kw 5FW	AUTODETECT
 C4	DASHBOARD	1.6 16v 88kw 5FW	JCAE Dashboard
 C4	DASHBOARD	1.6 HDI 16v 66kw 9HV	AUTODETECT
 C4	DASHBOARD	1.6 HDI 16v 66kw 9HV	JCAE Dashboard
 C4	DASHBOARD	1.6 HDI 16v 66kw 9HX	AUTODETECT
 C4	DASHBOARD	1.6 HDI 16v 66kw 9HX	JCAE Dashboard
 C4	DASHBOARD	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C4	DASHBOARD	1.6 HDI 16v 80kw 9HY	JCAE Dashboard
 C4	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP	JCAE Dashboard
 C4	DASHBOARD	2.0 16v 100kw RFN	AUTODETECT
 C4	DASHBOARD	2.0 16v 100kw RFN	JCAE Dashboard
 C4	DASHBOARD	2.0 16v 103kw RFJ	AUTODETECT
 C4	DASHBOARD	2.0 16v 103kw RFJ	JCAE Dashboard
 C4	DASHBOARD	2.0 16v 130kw RFK	AUTODETECT
 C4	DASHBOARD	2.0 16v 130kw RFK	JCAE Dashboard
 C4	DASHBOARD	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C4	DASHBOARD	2.0 HDI 16v 100kw RHR-FAP	JCAE Dashboard
 C4	DASHBOARD	2.0 HDI 16v 103kw RHF-FAP	AUTODETECT
 C4	DASHBOARD	2.0 HDI 16v 103kw RHF-FAP	JCAE Dashboard
 C4	DASHBOARD	2.0 HDI 8v 80kw RHZ	AUTODETECT
 C4	DASHBOARD	2.0 HDI 8v 80kw RHZ	JCAE Dashboard
 C4	DIESEL ADDITION	1.6 HDI 16v 66kw 9HV	AUTODETECT
 C4	DIESEL ADDITION	1.6 HDI 16v 66kw 9HV	Diesel pump add. AUTODETECT
 C4	DIESEL ADDITION	1.6 HDI 16v 66kw 9HX	AUTODETECT
 C4	DIESEL ADDITION	1.6 HDI 16v 66kw 9HX	Diesel pump add. AUTODETECT
 C4	DIESEL ADDITION	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C4	DIESEL ADDITION	1.6 HDI 16v 80kw 9HY	Diesel pump add. AUTODETECT
 C4	DIESEL ADDITION	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4	DIESEL ADDITION	1.6 HDI 16v 80kw 9HZ-FAP	Diesel pump add. AUTODETECT
 C4	DIESEL ADDITION	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C4	DIESEL ADDITION	2.0 HDI 16v 100kw RHR-FAP	Diesel pump add. AUTODETECT
 C4	DIESEL ADDITION	2.0 HDI 8v 80kw RHZ	AUTODETECT
 C4	DRIVER SEAT CONT	1.4 16v 66kw KFU	AUTODETECT
 C4	DRIVER SEAT CONT	1.6 16v 103kw 5FT	AUTODETECT
 C4	DRIVER SEAT CONT	1.6 16v 110kw 5FX	AUTODETECT
 C4	DRIVER SEAT CONT	1.6 16v 80kw N6A	AUTODETECT
 C4	DRIVER SEAT CONT	1.6 16v 80kw NFU	AUTODETECT
 C4	DRIVER SEAT CONT	1.6 16v 88kw 5FW	AUTODETECT
 C4	DRIVER SEAT CONT	1.6 HDI 16v 66kw 9HV	AUTODETECT
 C4	DRIVER SEAT CONT	1.6 HDI 16v 66kw 9HX	AUTODETECT
 C4	DRIVER SEAT CONT	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C4	DRIVER SEAT CONT	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4	DRIVER SEAT CONT	2.0 16v 100kw RFN	AUTODETECT
 C4	DRIVER SEAT CONT	2.0 16v 103kw RFJ	AUTODETECT
 C4	DRIVER SEAT CONT	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C4	DRIVER SEAT CONT	2.0 HDI 16v 103kw RHF-FAP	AUTODETECT
 C4	DRIVER SEAT CONT	2.0 HDI 8v 80kw RHZ	AUTODETECT
 C4	DRIVER SIDE DOOR	1.4 16v 66kw KFU	AUTODETECT
 C4	DRIVER SIDE DOOR	1.6 16v 103kw 5FT	AUTODETECT
 C4	DRIVER SIDE DOOR	1.6 16v 110kw 5FX	AUTODETECT
 C4	DRIVER SIDE DOOR	1.6 16v 80kw N6A	AUTODETECT
 C4	DRIVER SIDE DOOR	1.6 16v 80kw NFU	AUTODETECT
 C4	DRIVER SIDE DOOR	1.6 16v 88kw 5FW	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4	DRIVER SIDE DOOR	1.6 HDI 16v 66kw 9HV	AUTODETECT
 C4	DRIVER SIDE DOOR	1.6 HDI 16v 66kw 9HX	AUTODETECT
 C4	DRIVER SIDE DOOR	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C4	DRIVER SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4	DRIVER SIDE DOOR	2.0 16v 100kw RFN	AUTODETECT
 C4	DRIVER SIDE DOOR	2.0 16v 103kw RFJ	AUTODETECT
 C4	DRIVER SIDE DOOR	2.0 16v 130kw RFK	AUTODETECT
 C4	DRIVER SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C4	DRIVER SIDE DOOR	2.0 HDI 16v 103kw RHF-FAP	AUTODETECT
 C4	DRIVER SIDE DOOR	2.0 HDI 8v 80kw RHZ	AUTODETECT
 C4	ELECTRIC STEERING	1.4 16v 66kw KFU	AUTODETECT
 C4	ELECTRIC STEERING	1.4 16v 66kw KFU	HPI GEP
 C4	ELECTRIC STEERING	1.6 16v 103kw 5FT	AUTODETECT
 C4	ELECTRIC STEERING	1.6 16v 103kw 5FT	HPI GEP
 C4	ELECTRIC STEERING	1.6 16v 110kw 5FX	AUTODETECT
 C4	ELECTRIC STEERING	1.6 16v 110kw 5FX	HPI GEP
 C4	ELECTRIC STEERING	1.6 16v 80kw N6A	AUTODETECT
 C4	ELECTRIC STEERING	1.6 16v 80kw N6A	HPI GEP
 C4	ELECTRIC STEERING	1.6 16v 80kw NFU	AUTODETECT
 C4	ELECTRIC STEERING	1.6 16v 80kw NFU	HPI GEP
 C4	ELECTRIC STEERING	1.6 16v 88kw 5FW	AUTODETECT
 C4	ELECTRIC STEERING	1.6 16v 88kw 5FW	HPI GEP
 C4	ELECTRIC STEERING	1.6 HDI 16v 66kw 9HV	AUTODETECT
 C4	ELECTRIC STEERING	1.6 HDI 16v 66kw 9HV	HPI GEP
 C4	ELECTRIC STEERING	1.6 HDI 16v 66kw 9HX	AUTODETECT
 C4	ELECTRIC STEERING	1.6 HDI 16v 66kw 9HX	HPI GEP
 C4	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C4	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HY	HPI GEP
 C4	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	HPI GEP
 C4	ELECTRIC STEERING	2.0 16v 100kw RFN	AUTODETECT
 C4	ELECTRIC STEERING	2.0 16v 100kw RFN	HPI GEP
 C4	ELECTRIC STEERING	2.0 16v 103kw RFJ	AUTODETECT
 C4	ELECTRIC STEERING	2.0 16v 103kw RFJ	HPI GEP
 C4	ELECTRIC STEERING	2.0 16v 130kw RFK	AUTODETECT
 C4	ELECTRIC STEERING	2.0 16v 130kw RFK	HPI GEP
 C4	ELECTRIC STEERING	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C4	ELECTRIC STEERING	2.0 HDI 16v 100kw RHR-FAP	HPI GEP
 C4	ELECTRIC STEERING	2.0 HDI 16v 103kw RHF-FAP	AUTODETECT
 C4	ELECTRIC STEERING	2.0 HDI 16v 103kw RHF-FAP	HPI GEP
 C4	ELECTRIC STEERING	2.0 HDI 8v 80kw RHZ	AUTODETECT
 C4	ELECTRIC STEERING	2.0 HDI 8v 80kw RHZ	HPI GEP
 C4	ENGINE MANAGEME	1.4 16v 66kw KFU	Marelli MM6LP AUTODETECT
 C4	ENGINE MANAGEME	1.6 16v 103kw 5FT	BOSCH MED 17.4 AUTODETECT
 C4	ENGINE MANAGEME	1.6 16v 110kw 5FX	BOSCH MED 17.4 AUTODETECT
 C4	ENGINE MANAGEME	1.6 16v 80kw N6A	BOSCH ME 7.4.5 AUTODETECT
 C4	ENGINE MANAGEME	1.6 16v 80kw NFU	BOSCH ME 7.4.5 AUTODETECT
 C4	ENGINE MANAGEME	1.6 16v 88kw 5FW	BOSCH MEV 17.4 AUTODETECT
 C4	ENGINE MANAGEME	1.6 HDI 16v 66kw 9HV	BOSCH EDC16 C34 Common Rail AUTOD
 C4	ENGINE MANAGEME	1.6 HDI 16v 66kw 9HX	BOSCH EDC 16C 34 Common Rail
 C4	ENGINE MANAGEME	1.6 HDI 16v 66kw 9HX	BOSCH EDC16 C34 AUTODETECT
 C4	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HY	BOSCH EDC16 C34 AUTODETECT
 C4	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16C 34 Common Rail
 C4	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 AUTODETECT
 C4	ENGINE MANAGEME	2.0 16v 100kw RFN	Marelli MM6LP AUTODETECT
 C4	ENGINE MANAGEME	2.0 16v 103kw RFJ	Marelli MM6KP BioFlex AUTODETECT
 C4	ENGINE MANAGEME	2.0 16v 103kw RFJ	Marelli MM6LPB AUTODETECT
 C4	ENGINE MANAGEME	2.0 16v 103kw RFJ	Marelli MPI MM6LPB

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4	ENGINE MANAGEME	2.0 16v 130kw RFK	Marelli MM6LP AUTODETECT
 C4	ENGINE MANAGEME	2.0 HDI 16v 100kw RHR-FAP	DELPHI DCM 3.4 Common Rail AUTODET
 C4	ENGINE MANAGEME	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803 Common Rail AUTODE
 C4	ENGINE MANAGEME	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803A Common Rail AUTOD
 C4	ENGINE MANAGEME	2.0 HDI 16v 103kw RHF-FAP	EOBD
 C4	ENGINE MANAGEME	2.0 HDI 8v 80kw RHZ	BOSCH EDC 15C2 Common Rail AUTODE
 C4	KEY ENCODE	1.4 16v 66kw KFU	JCAE Body Computer
 C4	KEY ENCODE	1.6 16v 103kw 5FT	JCAE Body Computer
 C4	KEY ENCODE	1.6 16v 110kw 5FX	JCAE Body Computer
 C4	KEY ENCODE	1.6 16v 80kw N6A	JCAE Body Computer
 C4	KEY ENCODE	1.6 16v 80kw NFU	JCAE Body Computer
 C4	KEY ENCODE	1.6 16v 88kw 5FW	JCAE Body Computer
 C4	KEY ENCODE	1.6 HDI 16v 66kw 9HV	JCAE Body Computer
 C4	KEY ENCODE	1.6 HDI 16v 66kw 9HX	JCAE Body Computer
 C4	KEY ENCODE	1.6 HDI 16v 80kw 9HY	JCAE Body Computer
 C4	KEY ENCODE	1.6 HDI 16v 80kw 9HZ-FAP	JCAE Body Computer
 C4	KEY ENCODE	2.0 16v 100kw RFN	JCAE Body Computer
 C4	KEY ENCODE	2.0 16v 103kw RFJ	JCAE Body Computer
 C4	KEY ENCODE	2.0 16v 130kw RFK	JCAE Body Computer
 C4	KEY ENCODE	2.0 HDI 16v 100kw RHR-FAP	JCAE Body Computer
 C4	KEY ENCODE	2.0 HDI 16v 103kw RHF-FAP	JCAE Body Computer
 C4	KEY ENCODE	2.0 HDI 8v 80kw RHZ	JCAE Body Computer
 C4	LANE CHANGE ASSY	1.4 16v 66kw KFU	AUTODETECT
 C4	LANE CHANGE ASSY	1.6 16v 103kw 5FT	AUTODETECT
 C4	LANE CHANGE ASSY	1.6 16v 110kw 5FX	AUTODETECT
 C4	LANE CHANGE ASSY	1.6 16v 80kw N6A	AUTODETECT
 C4	LANE CHANGE ASSY	1.6 16v 80kw NFU	AUTODETECT
 C4	LANE CHANGE ASSY	1.6 16v 88kw 5FW	AUTODETECT
 C4	LANE CHANGE ASSY	1.6 HDI 16v 66kw 9HV	AUTODETECT
 C4	LANE CHANGE ASSY	1.6 HDI 16v 66kw 9HX	AUTODETECT
 C4	LANE CHANGE ASSY	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C4	LANE CHANGE ASSY	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4	LANE CHANGE ASSY	2.0 16v 100kw RFN	AUTODETECT
 C4	LANE CHANGE ASSY	2.0 16v 103kw RFJ	AUTODETECT
 C4	LANE CHANGE ASSY	2.0 16v 130kw RFK	AUTODETECT
 C4	LANE CHANGE ASSY	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C4	LANE CHANGE ASSY	2.0 HDI 16v 103kw RHF-FAP	AUTODETECT
 C4	LANE CHANGE ASSY	2.0 HDI 8v 80kw RHZ	AUTODETECT
 C4	MAINTENANCE	1.4 16v 66kw KFU	A/T AL4 AUTODETECT
 C4	MAINTENANCE	1.4 16v 66kw KFU	A/T AM6 AUTODETECT
 C4	MAINTENANCE	1.4 16v 66kw KFU	A/T AM6 AUTODETECT
 C4	MAINTENANCE	1.4 16v 66kw KFU	AirBag CENTRAL AUTODETECT
 C4	MAINTENANCE	1.4 16v 66kw KFU	AirBag CENTRAL AUTODETECT
 C4	MAINTENANCE	1.4 16v 66kw KFU	BOSCH ABS 8
 C4	MAINTENANCE	1.4 16v 66kw KFU	BOSCH ABS 8.0 AUTODETECT
 C4	MAINTENANCE	1.4 16v 66kw KFU	BOSCH ABS 8.0 AUTODETECT
 C4	MAINTENANCE	1.4 16v 66kw KFU	BOSCH ESP 8.0 AUTODETECT
 C4	MAINTENANCE	1.4 16v 66kw KFU	BOSCH ESP 8.0 AUTODETECT
 C4	MAINTENANCE	1.4 16v 66kw KFU	BOSCH ESP 8.1 AUTODETECT
 C4	MAINTENANCE	1.4 16v 66kw KFU	BOSCH ESP 8.1 AUTODETECT
 C4	MAINTENANCE	1.4 16v 66kw KFU	JCAE Body Computer BSI+Service
 C4	MAINTENANCE	1.4 16v 66kw KFU	JCAE Body Computer MANUAL
 C4	MAINTENANCE	1.4 16v 66kw KFU	JCAE Dashboard
 C4	MAINTENANCE	1.4 16v 66kw KFU	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.4 16v 66kw KFU	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.4 16v 66kw KFU	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.4 16v 66kw KFU	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 16v 103kw 5FT	A/T AL4 AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4	MAINTENANCE	1.6 16v 103kw 5FT	A/T AM6 AUTODETECT
 C4	MAINTENANCE	1.6 16v 103kw 5FT	A/T AM6 AUTODETECT
 C4	MAINTENANCE	1.6 16v 103kw 5FT	AirBag CENTRAL AUTODETECT
 C4	MAINTENANCE	1.6 16v 103kw 5FT	AirBag CENTRAL AUTODETECT
 C4	MAINTENANCE	1.6 16v 103kw 5FT	BOSCH ABS 8
 C4	MAINTENANCE	1.6 16v 103kw 5FT	BOSCH ABS 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 16v 103kw 5FT	BOSCH ABS 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 16v 103kw 5FT	BOSCH ESP 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 16v 103kw 5FT	BOSCH ESP 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 16v 103kw 5FT	BOSCH ESP 8.1 AUTODETECT
 C4	MAINTENANCE	1.6 16v 103kw 5FT	BOSCH ESP 8.1 AUTODETECT
 C4	MAINTENANCE	1.6 16v 103kw 5FT	JCAE Body Computer BSI+Service
 C4	MAINTENANCE	1.6 16v 103kw 5FT	JCAE Body Computer MANUAL
 C4	MAINTENANCE	1.6 16v 103kw 5FT	JCAE Dashboard
 C4	MAINTENANCE	1.6 16v 103kw 5FT	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 16v 103kw 5FT	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 16v 103kw 5FT	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 16v 103kw 5FT	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 16v 110kw 5FX	A/T AL4 AUTODETECT
 C4	MAINTENANCE	1.6 16v 110kw 5FX	A/T AM6 AUTODETECT
 C4	MAINTENANCE	1.6 16v 110kw 5FX	A/T AM6 AUTODETECT
 C4	MAINTENANCE	1.6 16v 110kw 5FX	AirBag CENTRAL AUTODETECT
 C4	MAINTENANCE	1.6 16v 110kw 5FX	AirBag CENTRAL AUTODETECT
 C4	MAINTENANCE	1.6 16v 110kw 5FX	BOSCH ABS 8
 C4	MAINTENANCE	1.6 16v 110kw 5FX	BOSCH ABS 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 16v 110kw 5FX	BOSCH ABS 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 16v 110kw 5FX	BOSCH ESP 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 16v 110kw 5FX	BOSCH ESP 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 16v 110kw 5FX	BOSCH ESP 8.1 AUTODETECT
 C4	MAINTENANCE	1.6 16v 110kw 5FX	BOSCH ESP 8.1 AUTODETECT
 C4	MAINTENANCE	1.6 16v 110kw 5FX	JCAE Body Computer BSI+Service
 C4	MAINTENANCE	1.6 16v 110kw 5FX	JCAE Body Computer MANUAL
 C4	MAINTENANCE	1.6 16v 110kw 5FX	JCAE Dashboard
 C4	MAINTENANCE	1.6 16v 110kw 5FX	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 16v 110kw 5FX	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 16v 110kw 5FX	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 16v 110kw 5FX	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 16v 80kw N6A	A/T AL4 AUTODETECT
 C4	MAINTENANCE	1.6 16v 80kw N6A	A/T AM6 AUTODETECT
 C4	MAINTENANCE	1.6 16v 80kw N6A	A/T AM6 AUTODETECT
 C4	MAINTENANCE	1.6 16v 80kw N6A	AirBag CENTRAL AUTODETECT
 C4	MAINTENANCE	1.6 16v 80kw N6A	AirBag CENTRAL AUTODETECT
 C4	MAINTENANCE	1.6 16v 80kw N6A	BOSCH ABS 8
 C4	MAINTENANCE	1.6 16v 80kw N6A	BOSCH ABS 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 16v 80kw N6A	BOSCH ABS 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 16v 80kw N6A	BOSCH ESP 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 16v 80kw N6A	BOSCH ESP 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 16v 80kw N6A	BOSCH ESP 8.1 AUTODETECT
 C4	MAINTENANCE	1.6 16v 80kw N6A	BOSCH ESP 8.1 AUTODETECT
 C4	MAINTENANCE	1.6 16v 80kw N6A	JCAE Body Computer BSI+Service
 C4	MAINTENANCE	1.6 16v 80kw N6A	JCAE Body Computer MANUAL
 C4	MAINTENANCE	1.6 16v 80kw N6A	JCAE Dashboard
 C4	MAINTENANCE	1.6 16v 80kw N6A	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 16v 80kw N6A	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 16v 80kw N6A	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 16v 80kw N6A	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 16v 80kw NFU	A/T AL4 AUTODETECT
 C4	MAINTENANCE	1.6 16v 80kw NFU	A/T AM6 AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4	MAINTENANCE	1.6 16v 80kw NFU	A/T AM6 AUTODETECT
 C4	MAINTENANCE	1.6 16v 80kw NFU	AirBag CENTRAL AUTODETECT
 C4	MAINTENANCE	1.6 16v 80kw NFU	AirBag CENTRAL AUTODETECT
 C4	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ABS 8
 C4	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ABS 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ABS 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ESP 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ESP 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ESP 8.1 AUTODETECT
 C4	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ESP 8.1 AUTODETECT
 C4	MAINTENANCE	1.6 16v 80kw NFU	JCAE Body Computer BSI+Service
 C4	MAINTENANCE	1.6 16v 80kw NFU	JCAE Body Computer MANUAL
 C4	MAINTENANCE	1.6 16v 80kw NFU	JCAE Dashboard
 C4	MAINTENANCE	1.6 16v 80kw NFU	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 16v 80kw NFU	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 16v 80kw NFU	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 16v 80kw NFU	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 16v 88kw 5FW	A/T AL4 AUTODETECT
 C4	MAINTENANCE	1.6 16v 88kw 5FW	AirBag CENTRAL AUTODETECT
 C4	MAINTENANCE	1.6 16v 88kw 5FW	AirBag CENTRAL AUTODETECT
 C4	MAINTENANCE	1.6 16v 88kw 5FW	BOSCH ABS 8
 C4	MAINTENANCE	1.6 16v 88kw 5FW	BOSCH ABS 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 16v 88kw 5FW	BOSCH ABS 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 16v 88kw 5FW	BOSCH ESP 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 16v 88kw 5FW	BOSCH ESP 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 16v 88kw 5FW	BOSCH ESP 8.1 AUTODETECT
 C4	MAINTENANCE	1.6 16v 88kw 5FW	BOSCH ESP 8.1 AUTODETECT
 C4	MAINTENANCE	1.6 16v 88kw 5FW	JCAE Body Computer BSI+Service
 C4	MAINTENANCE	1.6 16v 88kw 5FW	JCAE Body Computer MANUAL
 C4	MAINTENANCE	1.6 16v 88kw 5FW	JCAE Dashboard
 C4	MAINTENANCE	1.6 16v 88kw 5FW	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 16v 88kw 5FW	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 16v 88kw 5FW	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 16v 88kw 5FW	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HV	A/T AL4 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HV	A/T AM6 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HV	A/T AM6 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HV	AirBag CENTRAL AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HV	AirBag CENTRAL AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HV	BOSCH ABS 8
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HV	BOSCH ABS 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HV	BOSCH ABS 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HV	BOSCH EDC16 C34 Common Rail AUTOD
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HV	BOSCH EDC16 C34 Common Rail AUTOD
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HV	BOSCH EDC16 C34 Common Rail AUTOD
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HV	BOSCH EDC16 C34 Common Rail AUTOD
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HV	BOSCH EDC16 C34 Common Rail AUTOD
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HV	BOSCH ESP 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HV	BOSCH ESP 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HV	BOSCH ESP 8.1 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HV	BOSCH ESP 8.1 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HV	Diesel pump add. AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HV	JCAE Body Computer BSI+Service
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HV	JCAE Body Computer MANUAL
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HV	JCAE Dashboard
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HV	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HV	Siemens-JCAE AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HV	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HV	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HX	A/T AL4 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HX	A/T AM6 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HX	A/T AM6 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HX	AirBag CENTRAL AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HX	AirBag CENTRAL AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH ABS 8
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH ABS 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH ABS 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC16 C34 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC16 C34 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC16 C34 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC16 C34 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC16 C34 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC16 C34 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH ESP 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH ESP 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH ESP 8.1 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH ESP 8.1 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Diesel pump add. AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HX	JCAE Body Computer BSI+Service
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HX	JCAE Body Computer MANUAL
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HX	JCAE Dashboard
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HY	A/T AL4 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HY	A/T AM6 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HY	A/T AM6 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HY	AirBag CENTRAL AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HY	AirBag CENTRAL AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH ABS 8
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH ABS 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH ABS 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC16 C34 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC16 C34 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC16 C34 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC16 C34 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC16 C34 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC16 C34 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC16 C34 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH ESP 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH ESP 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH ESP 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH ESP 8.1 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH ESP 8.1 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Diesel pump add. AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HY	JCAE Body Computer BSI+Service
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HY	JCAE Body Computer MANUAL
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HY	JCAE Dashboard
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	A/T AL4 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	A/T AM6 AUTODETECT
C4	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	A/T AM6 AUTODETECT
C4	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ABS 8
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ABS 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ABS 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ESP 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ESP 8.0 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ESP 8.1 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ESP 8.1 AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Diesel pump add. AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	JCAE Body Computer BSI+Service
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	JCAE Body Computer MANUAL
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	JCAE Dashboard
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	2.0 16v 100kw RFN	A/T AL4 AUTODETECT
 C4	MAINTENANCE	2.0 16v 100kw RFN	A/T AM6 AUTODETECT
 C4	MAINTENANCE	2.0 16v 100kw RFN	A/T AM6 AUTODETECT
 C4	MAINTENANCE	2.0 16v 100kw RFN	AirBag CENTRAL AUTODETECT
 C4	MAINTENANCE	2.0 16v 100kw RFN	AirBag CENTRAL AUTODETECT
 C4	MAINTENANCE	2.0 16v 100kw RFN	BOSCH ABS 8
 C4	MAINTENANCE	2.0 16v 100kw RFN	BOSCH ABS 8.0 AUTODETECT
 C4	MAINTENANCE	2.0 16v 100kw RFN	BOSCH ABS 8.0 AUTODETECT
 C4	MAINTENANCE	2.0 16v 100kw RFN	BOSCH ESP 8.0 AUTODETECT
 C4	MAINTENANCE	2.0 16v 100kw RFN	BOSCH ESP 8.0 AUTODETECT
 C4	MAINTENANCE	2.0 16v 100kw RFN	BOSCH ESP 8.1 AUTODETECT
 C4	MAINTENANCE	2.0 16v 100kw RFN	BOSCH ESP 8.1 AUTODETECT
 C4	MAINTENANCE	2.0 16v 100kw RFN	JCAE Body Computer BSI+Service
 C4	MAINTENANCE	2.0 16v 100kw RFN	JCAE Body Computer MANUAL
 C4	MAINTENANCE	2.0 16v 100kw RFN	JCAE Dashboard
 C4	MAINTENANCE	2.0 16v 100kw RFN	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	2.0 16v 100kw RFN	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	2.0 16v 100kw RFN	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	2.0 16v 100kw RFN	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	2.0 16v 103kw RFJ	A/T AL4 AUTODETECT
 C4	MAINTENANCE	2.0 16v 103kw RFJ	A/T AM6 AUTODETECT
 C4	MAINTENANCE	2.0 16v 103kw RFJ	A/T AM6 AUTODETECT
 C4	MAINTENANCE	2.0 16v 103kw RFJ	AirBag CENTRAL AUTODETECT
 C4	MAINTENANCE	2.0 16v 103kw RFJ	AirBag CENTRAL AUTODETECT
 C4	MAINTENANCE	2.0 16v 103kw RFJ	BOSCH ABS 8
 C4	MAINTENANCE	2.0 16v 103kw RFJ	BOSCH ABS 8.0 AUTODETECT
 C4	MAINTENANCE	2.0 16v 103kw RFJ	BOSCH ABS 8.0 AUTODETECT
 C4	MAINTENANCE	2.0 16v 103kw RFJ	BOSCH ESP 8.0 AUTODETECT
 C4	MAINTENANCE	2.0 16v 103kw RFJ	BOSCH ESP 8.0 AUTODETECT
 C4	MAINTENANCE	2.0 16v 103kw RFJ	BOSCH ESP 8.1 AUTODETECT
 C4	MAINTENANCE	2.0 16v 103kw RFJ	BOSCH ESP 8.1 AUTODETECT
 C4	MAINTENANCE	2.0 16v 103kw RFJ	JCAE Body Computer BSI+Service
 C4	MAINTENANCE	2.0 16v 103kw RFJ	JCAE Body Computer MANUAL
 C4	MAINTENANCE	2.0 16v 103kw RFJ	JCAE Dashboard
 C4	MAINTENANCE	2.0 16v 103kw RFJ	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	2.0 16v 103kw RFJ	Siemens-JCAE AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4	MAINTENANCE	2.0 16v 103kw RFJ	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	2.0 16v 103kw RFJ	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	2.0 16v 130kw RFK	A/T AL4 AUTODETECT
 C4	MAINTENANCE	2.0 16v 130kw RFK	A/T AM6 AUTODETECT
 C4	MAINTENANCE	2.0 16v 130kw RFK	A/T AM6 AUTODETECT
 C4	MAINTENANCE	2.0 16v 130kw RFK	AirBag CENTRAL AUTODETECT
 C4	MAINTENANCE	2.0 16v 130kw RFK	AirBag CENTRAL AUTODETECT
 C4	MAINTENANCE	2.0 16v 130kw RFK	BOSCH ABS 8
 C4	MAINTENANCE	2.0 16v 130kw RFK	BOSCH ABS 8.0 AUTODETECT
 C4	MAINTENANCE	2.0 16v 130kw RFK	BOSCH ABS 8.0 AUTODETECT
 C4	MAINTENANCE	2.0 16v 130kw RFK	BOSCH ESP 8.0 AUTODETECT
 C4	MAINTENANCE	2.0 16v 130kw RFK	BOSCH ESP 8.0 AUTODETECT
 C4	MAINTENANCE	2.0 16v 130kw RFK	BOSCH ESP 8.1 AUTODETECT
 C4	MAINTENANCE	2.0 16v 130kw RFK	BOSCH ESP 8.1 AUTODETECT
 C4	MAINTENANCE	2.0 16v 130kw RFK	JCAE Body Computer BSI+Service
 C4	MAINTENANCE	2.0 16v 130kw RFK	JCAE Body Computer MANUAL
 C4	MAINTENANCE	2.0 16v 130kw RFK	JCAE Dashboard
 C4	MAINTENANCE	2.0 16v 130kw RFK	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	2.0 16v 130kw RFK	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	2.0 16v 130kw RFK	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	2.0 16v 130kw RFK	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	A/T AL4 AUTODETECT
 C4	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	A/T AM6 AUTODETECT
 C4	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	A/T AM6 AUTODETECT
 C4	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	AirBag CENTRAL AUTODETECT
 C4	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	AirBag CENTRAL AUTODETECT
 C4	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	BOSCH ABS 8
 C4	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	BOSCH ABS 8.0 AUTODETECT
 C4	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	BOSCH ABS 8.0 AUTODETECT
 C4	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	BOSCH ESP 8.0 AUTODETECT
 C4	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	BOSCH ESP 8.0 AUTODETECT
 C4	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	BOSCH ESP 8.1 AUTODETECT
 C4	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	BOSCH ESP 8.1 AUTODETECT
 C4	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	DELPHI DCM 3.4 Common Rail AUTODET
 C4	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Diesel pump add. AUTODETECT
 C4	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	JCAE Body Computer BSI+Service
 C4	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	JCAE Body Computer MANUAL
 C4	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	JCAE Dashboard
 C4	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803 Common Rail AUTODE
 C4	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803 Common Rail AUTODE
 C4	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803 Common Rail AUTODE
 C4	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803A Common Rail AUTOD
 C4	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803A Common Rail AUTOD
 C4	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803A Common Rail AUTOD
 C4	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	A/T AL4 AUTODETECT
 C4	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	A/T AM6 AUTODETECT
 C4	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	A/T AM6 AUTODETECT
 C4	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	AirBag CENTRAL AUTODETECT
 C4	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	AirBag CENTRAL AUTODETECT
 C4	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	BOSCH ABS 8
 C4	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	BOSCH ABS 8.0 AUTODETECT
 C4	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	BOSCH ABS 8.0 AUTODETECT
 C4	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	BOSCH ESP 8.0 AUTODETECT
 C4	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	BOSCH ESP 8.0 AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	BOSCH ESP 8.1 AUTODETECT
 C4	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	BOSCH ESP 8.1 AUTODETECT
 C4	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	JCAE Body Computer BSI+Service
 C4	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	JCAE Body Computer MANUAL
 C4	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	JCAE Dashboard
 C4	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	2.0 HDI 8v 80kw RHZ	A/T AL4 AUTODETECT
 C4	MAINTENANCE	2.0 HDI 8v 80kw RHZ	A/T AM6 AUTODETECT
 C4	MAINTENANCE	2.0 HDI 8v 80kw RHZ	A/T AM6 AUTODETECT
 C4	MAINTENANCE	2.0 HDI 8v 80kw RHZ	AirBag CENTRAL AUTODETECT
 C4	MAINTENANCE	2.0 HDI 8v 80kw RHZ	AirBag CENTRAL AUTODETECT
 C4	MAINTENANCE	2.0 HDI 8v 80kw RHZ	BOSCH ABS 8
 C4	MAINTENANCE	2.0 HDI 8v 80kw RHZ	BOSCH ABS 8.0 AUTODETECT
 C4	MAINTENANCE	2.0 HDI 8v 80kw RHZ	BOSCH EDC 15C2 Common Rail AUTODE
 C4	MAINTENANCE	2.0 HDI 8v 80kw RHZ	BOSCH ESP 8.0 AUTODETECT
 C4	MAINTENANCE	2.0 HDI 8v 80kw RHZ	BOSCH ESP 8.0 AUTODETECT
 C4	MAINTENANCE	2.0 HDI 8v 80kw RHZ	BOSCH ESP 8.1 AUTODETECT
 C4	MAINTENANCE	2.0 HDI 8v 80kw RHZ	BOSCH ESP 8.1 AUTODETECT
 C4	MAINTENANCE	2.0 HDI 8v 80kw RHZ	JCAE Body Computer BSI+Service
 C4	MAINTENANCE	2.0 HDI 8v 80kw RHZ	JCAE Body Computer MANUAL
 C4	MAINTENANCE	2.0 HDI 8v 80kw RHZ	JCAE Dashboard
 C4	MAINTENANCE	2.0 HDI 8v 80kw RHZ	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	2.0 HDI 8v 80kw RHZ	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	2.0 HDI 8v 80kw RHZ	Siemens-JCAE AUTODETECT
 C4	MAINTENANCE	2.0 HDI 8v 80kw RHZ	Siemens-JCAE AUTODETECT
 C4	NAVIGATION	1.4 16v 66kw KFJ	AUTODETECT
 C4	NAVIGATION	1.4 16v 66kw KFJ	AUTODETECT
 C4	NAVIGATION	1.6 16v 103kw 5FT	AUTODETECT
 C4	NAVIGATION	1.6 16v 103kw 5FT	AUTODETECT
 C4	NAVIGATION	1.6 16v 110kw 5FX	AUTODETECT
 C4	NAVIGATION	1.6 16v 110kw 5FX	AUTODETECT
 C4	NAVIGATION	1.6 16v 80kw N6A	AUTODETECT
 C4	NAVIGATION	1.6 16v 80kw N6A	AUTODETECT
 C4	NAVIGATION	1.6 16v 80kw NFU	AUTODETECT
 C4	NAVIGATION	1.6 16v 80kw NFU	AUTODETECT
 C4	NAVIGATION	1.6 16v 88kw 5FW	AUTODETECT
 C4	NAVIGATION	1.6 16v 88kw 5FW	AUTODETECT
 C4	NAVIGATION	1.6 HDI 16v 66kw 9HV	AUTODETECT
 C4	NAVIGATION	1.6 HDI 16v 66kw 9HV	AUTODETECT
 C4	NAVIGATION	1.6 HDI 16v 66kw 9HX	AUTODETECT
 C4	NAVIGATION	1.6 HDI 16v 66kw 9HX	AUTODETECT
 C4	NAVIGATION	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C4	NAVIGATION	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C4	NAVIGATION	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4	NAVIGATION	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4	NAVIGATION	2.0 16v 100kw RFN	AUTODETECT
 C4	NAVIGATION	2.0 16v 100kw RFN	AUTODETECT
 C4	NAVIGATION	2.0 16v 103kw RFJ	AUTODETECT
 C4	NAVIGATION	2.0 16v 103kw RFJ	AUTODETECT
 C4	NAVIGATION	2.0 16v 130kw RFK	AUTODETECT
 C4	NAVIGATION	2.0 16v 130kw RFK	AUTODETECT
 C4	NAVIGATION	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C4	NAVIGATION	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C4	NAVIGATION	2.0 HDI 16v 103kw RHF-FAP	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4	NAVIGATION	2.0 HDI 16v 103kw RHF-FAP	AUTODETECT
 C4	NAVIGATION	2.0 HDI 8v 80kw RHZ	AUTODETECT
 C4	NAVIGATION	2.0 HDI 8v 80kw RHZ	AUTODETECT
 C4	PARKING HELP	1.4 16v 66kw KFU	AUTODETECT
 C4	PARKING HELP	1.4 16v 66kw KFU	VALEO
 C4	PARKING HELP	1.6 16v 103kw 5FT	AUTODETECT
 C4	PARKING HELP	1.6 16v 103kw 5FT	VALEO
 C4	PARKING HELP	1.6 16v 110kw 5FX	AUTODETECT
 C4	PARKING HELP	1.6 16v 110kw 5FX	VALEO
 C4	PARKING HELP	1.6 16v 80kw N6A	AUTODETECT
 C4	PARKING HELP	1.6 16v 80kw N6A	VALEO
 C4	PARKING HELP	1.6 16v 80kw NFU	AUTODETECT
 C4	PARKING HELP	1.6 16v 80kw NFU	VALEO
 C4	PARKING HELP	1.6 16v 88kw 5FW	AUTODETECT
 C4	PARKING HELP	1.6 16v 88kw 5FW	VALEO
 C4	PARKING HELP	1.6 HDI 16v 66kw 9HV	AUTODETECT
 C4	PARKING HELP	1.6 HDI 16v 66kw 9HV	VALEO
 C4	PARKING HELP	1.6 HDI 16v 66kw 9HX	AUTODETECT
 C4	PARKING HELP	1.6 HDI 16v 66kw 9HX	VALEO
 C4	PARKING HELP	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C4	PARKING HELP	1.6 HDI 16v 80kw 9HY	VALEO
 C4	PARKING HELP	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4	PARKING HELP	1.6 HDI 16v 80kw 9HZ-FAP	VALEO
 C4	PARKING HELP	2.0 16v 100kw RFN	AUTODETECT
 C4	PARKING HELP	2.0 16v 100kw RFN	VALEO
 C4	PARKING HELP	2.0 16v 103kw RFJ	AUTODETECT
 C4	PARKING HELP	2.0 16v 103kw RFJ	VALEO
 C4	PARKING HELP	2.0 16v 130kw RFK	AUTODETECT
 C4	PARKING HELP	2.0 16v 130kw RFK	VALEO
 C4	PARKING HELP	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C4	PARKING HELP	2.0 HDI 16v 100kw RHR-FAP	VALEO
 C4	PARKING HELP	2.0 HDI 16v 103kw RHF-FAP	AUTODETECT
 C4	PARKING HELP	2.0 HDI 16v 103kw RHF-FAP	VALEO
 C4	PARKING HELP	2.0 HDI 8v 80kw RHZ	AUTODETECT
 C4	PASS. SIDE DOOR	1.4 16v 66kw KFU	AUTODETECT
 C4	PASS. SIDE DOOR	1.6 16v 103kw 5FT	AUTODETECT
 C4	PASS. SIDE DOOR	1.6 16v 110kw 5FX	AUTODETECT
 C4	PASS. SIDE DOOR	1.6 16v 80kw N6A	AUTODETECT
 C4	PASS. SIDE DOOR	1.6 16v 80kw NFU	AUTODETECT
 C4	PASS. SIDE DOOR	1.6 16v 88kw 5FW	AUTODETECT
 C4	PASS. SIDE DOOR	1.6 HDI 16v 66kw 9HV	AUTODETECT
 C4	PASS. SIDE DOOR	1.6 HDI 16v 66kw 9HX	AUTODETECT
 C4	PASS. SIDE DOOR	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C4	PASS. SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4	PASS. SIDE DOOR	2.0 16v 100kw RFN	AUTODETECT
 C4	PASS. SIDE DOOR	2.0 16v 103kw RFJ	AUTODETECT
 C4	PASS. SIDE DOOR	2.0 16v 130kw RFK	AUTODETECT
 C4	PASS. SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C4	PASS. SIDE DOOR	2.0 HDI 16v 103kw RHF-FAP	AUTODETECT
 C4	PASS. SIDE DOOR	2.0 HDI 8v 80kw RHZ	AUTODETECT
 C4	PHONE	1.4 16v 66kw KFU	AUTODETECT
 C4	PHONE	1.4 16v 66kw KFU	Mobile phone kit AUTODETECT
 C4	PHONE	1.6 16v 103kw 5FT	AUTODETECT
 C4	PHONE	1.6 16v 103kw 5FT	Mobile phone kit AUTODETECT
 C4	PHONE	1.6 16v 110kw 5FX	AUTODETECT
 C4	PHONE	1.6 16v 110kw 5FX	Mobile phone kit AUTODETECT
 C4	PHONE	1.6 16v 80kw N6A	AUTODETECT
 C4	PHONE	1.6 16v 80kw N6A	Mobile phone kit AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4	PHONE	1.6 16v 80kw NFU	AUTODETECT
 C4	PHONE	1.6 16v 80kw NFU	Mobile phone kit AUTODETECT
 C4	PHONE	1.6 16v 88kw 5FW	AUTODETECT
 C4	PHONE	1.6 16v 88kw 5FW	Mobile phone kit AUTODETECT
 C4	PHONE	1.6 HDI 16v 66kw 9HV	AUTODETECT
 C4	PHONE	1.6 HDI 16v 66kw 9HV	Mobile phone kit AUTODETECT
 C4	PHONE	1.6 HDI 16v 66kw 9HX	AUTODETECT
 C4	PHONE	1.6 HDI 16v 66kw 9HX	Mobile phone kit AUTODETECT
 C4	PHONE	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C4	PHONE	1.6 HDI 16v 80kw 9HY	Mobile phone kit AUTODETECT
 C4	PHONE	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4	PHONE	1.6 HDI 16v 80kw 9HZ-FAP	Mobile phone kit AUTODETECT
 C4	PHONE	2.0 16v 100kw RFN	AUTODETECT
 C4	PHONE	2.0 16v 100kw RFN	Mobile phone kit AUTODETECT
 C4	PHONE	2.0 16v 103kw RFJ	AUTODETECT
 C4	PHONE	2.0 16v 103kw RFJ	Mobile phone kit AUTODETECT
 C4	PHONE	2.0 16v 130kw RFK	AUTODETECT
 C4	PHONE	2.0 16v 130kw RFK	Mobile phone kit AUTODETECT
 C4	PHONE	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C4	PHONE	2.0 HDI 16v 100kw RHR-FAP	Mobile phone kit AUTODETECT
 C4	PHONE	2.0 HDI 16v 103kw RHF-FAP	AUTODETECT
 C4	PHONE	2.0 HDI 16v 103kw RHF-FAP	Mobile phone kit AUTODETECT
 C4	PHONE	2.0 HDI 8v 80kw RHZ	AUTODETECT
 C4	PHONE	2.0 HDI 8v 80kw RHZ	Mobile phone kit AUTODETECT
 C4	RADIO / CD	1.4 16v 66kw KFU	Ampli audio AUTODETECT
 C4	RADIO / CD	1.4 16v 66kw KFU	AudioSystem AUTODETECT
 C4	RADIO / CD	1.4 16v 66kw KFU	CD Changer AUTODETECT
 C4	RADIO / CD	1.6 16v 103kw 5FT	Ampli Audio AUTODETECT
 C4	RADIO / CD	1.6 16v 103kw 5FT	AudioSystem AUTODETECT
 C4	RADIO / CD	1.6 16v 103kw 5FT	CD Changer AUTODETECT
 C4	RADIO / CD	1.6 16v 110kw 5FX	Ampli Audio AUTODETECT
 C4	RADIO / CD	1.6 16v 110kw 5FX	AudioSystem AUTODETECT
 C4	RADIO / CD	1.6 16v 110kw 5FX	CD Changer AUTODETECT
 C4	RADIO / CD	1.6 16v 80kw N6A	Ampli Audio AUTODETECT
 C4	RADIO / CD	1.6 16v 80kw N6A	AudioSystem AUTODETECT
 C4	RADIO / CD	1.6 16v 80kw N6A	CD Changer AUTODETECT
 C4	RADIO / CD	1.6 16v 80kw NFU	Ampli Audio AUTODETECT
 C4	RADIO / CD	1.6 16v 80kw NFU	AudioSystem AUTODETECT
 C4	RADIO / CD	1.6 16v 80kw NFU	CD Changer AUTODETECT
 C4	RADIO / CD	1.6 16v 88kw 5FW	Ampli Audio AUTODETECT
 C4	RADIO / CD	1.6 16v 88kw 5FW	AudioSystem AUTODETECT
 C4	RADIO / CD	1.6 16v 88kw 5FW	CD Changer AUTODETECT
 C4	RADIO / CD	1.6 HDI 16v 66kw 9HV	Ampli Audio AUTODETECT
 C4	RADIO / CD	1.6 HDI 16v 66kw 9HV	AudioSystem AUTODETECT
 C4	RADIO / CD	1.6 HDI 16v 66kw 9HV	CD Changer AUTODETECT
 C4	RADIO / CD	1.6 HDI 16v 66kw 9HX	Ampli Audio AUTODETECT
 C4	RADIO / CD	1.6 HDI 16v 66kw 9HX	AudioSystem AUTODETECT
 C4	RADIO / CD	1.6 HDI 16v 66kw 9HX	CD Changer AUTODETECT
 C4	RADIO / CD	1.6 HDI 16v 80kw 9HY	Ampli Audio AUTODETECT
 C4	RADIO / CD	1.6 HDI 16v 80kw 9HY	AudioSystem AUTODETECT
 C4	RADIO / CD	1.6 HDI 16v 80kw 9HY	CD Changer AUTODETECT
 C4	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Ampli Audio AUTODETECT
 C4	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	AudioSystem AUTODETECT
 C4	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	CD Changer AUTODETECT
 C4	RADIO / CD	2.0 16v 100kw RFN	Ampli Audio AUTODETECT
 C4	RADIO / CD	2.0 16v 100kw RFN	AudioSystem AUTODETECT
 C4	RADIO / CD	2.0 16v 100kw RFN	CD Changer AUTODETECT
 C4	RADIO / CD	2.0 16v 103kw RFJ	Ampli Audio AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4	RADIO / CD	2.0 16v 103kw RFJ	AudioSystem AUTODETECT
 C4	RADIO / CD	2.0 16v 103kw RFJ	CD Changer AUTODETECT
 C4	RADIO / CD	2.0 16v 130kw RFK	Ampli Audio AUTODETECT
 C4	RADIO / CD	2.0 16v 130kw RFK	AudioSystem AUTODETECT
 C4	RADIO / CD	2.0 16v 130kw RFK	CD Changer AUTODETECT
 C4	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP	Ampli Audio AUTODETECT
 C4	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP	AudioSystem AUTODETECT
 C4	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP	CD Changer AUTODETECT
 C4	RADIO / CD	2.0 HDI 16v 103kw RHF-FAP	Ampli Audio AUTODETECT
 C4	RADIO / CD	2.0 HDI 16v 103kw RHF-FAP	AudioSystem AUTODETECT
 C4	RADIO / CD	2.0 HDI 16v 103kw RHF-FAP	CD Changer AUTODETECT
 C4	RADIO / CD	2.0 HDI 8v 80kw RHZ	Ampli Audio AUTODETECT
 C4	RADIO / CD	2.0 HDI 8v 80kw RHZ	AudioSystem AUTODETECT
 C4	RADIO / CD	2.0 HDI 8v 80kw RHZ	CD Changer AUTODETECT
 C4	RAIN-LUMINOSITY S	1.4 16v 66kw KFU	AUTODETECT
 C4	RAIN-LUMINOSITY S	1.6 16v 103kw 5FT	AUTODETECT
 C4	RAIN-LUMINOSITY S	1.6 16v 110kw 5FX	AUTODETECT
 C4	RAIN-LUMINOSITY S	1.6 16v 80kw N6A	AUTODETECT
 C4	RAIN-LUMINOSITY S	1.6 16v 80kw NFU	AUTODETECT
 C4	RAIN-LUMINOSITY S	1.6 16v 88kw 5FW	AUTODETECT
 C4	RAIN-LUMINOSITY S	1.6 HDI 16v 66kw 9HV	AUTODETECT
 C4	RAIN-LUMINOSITY S	1.6 HDI 16v 66kw 9HX	AUTODETECT
 C4	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C4	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4	RAIN-LUMINOSITY S	2.0 16v 100kw RFN	AUTODETECT
 C4	RAIN-LUMINOSITY S	2.0 16v 103kw RFJ	AUTODETECT
 C4	RAIN-LUMINOSITY S	2.0 16v 130kw RFK	AUTODETECT
 C4	RAIN-LUMINOSITY S	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C4	RAIN-LUMINOSITY S	2.0 HDI 16v 103kw RHF-FAP	AUTODETECT
 C4	RAIN-LUMINOSITY S	2.0 HDI 8v 80kw RHZ	AUTODETECT
 C4	REMOTE CONTROL E	1.4 16v 66kw KFU	JCAE Body Computer MANUAL
 C4	REMOTE CONTROL E	1.6 16v 103kw 5FT	JCAE Body Computer MANUAL
 C4	REMOTE CONTROL E	1.6 16v 110kw 5FX	JCAE Body Computer MANUAL
 C4	REMOTE CONTROL E	1.6 16v 80kw N6A	JCAE Body Computer MANUAL
 C4	REMOTE CONTROL E	1.6 16v 80kw NFU	JCAE Body Computer MANUAL
 C4	REMOTE CONTROL E	1.6 16v 88kw 5FW	JCAE Body Computer MANUAL
 C4	REMOTE CONTROL E	1.6 HDI 16v 66kw 9HV	JCAE Body Computer MANUAL
 C4	REMOTE CONTROL E	1.6 HDI 16v 66kw 9HX	JCAE Body Computer MANUAL
 C4	REMOTE CONTROL E	1.6 HDI 16v 80kw 9HY	JCAE Body Computer MANUAL
 C4	REMOTE CONTROL E	1.6 HDI 16v 80kw 9HZ-FAP	JCAE Body Computer MANUAL
 C4	REMOTE CONTROL E	2.0 16v 100kw RFN	JCAE Body Computer MANUAL
 C4	REMOTE CONTROL E	2.0 16v 103kw RFJ	JCAE Body Computer MANUAL
 C4	REMOTE CONTROL E	2.0 16v 130kw RFK	JCAE Body Computer MANUAL
 C4	REMOTE CONTROL E	2.0 HDI 16v 100kw RHR-FAP	JCAE Body Computer MANUAL
 C4	REMOTE CONTROL E	2.0 HDI 16v 103kw RHF-FAP	JCAE Body Computer MANUAL
 C4	REMOTE CONTROL E	2.0 HDI 8v 80kw RHZ	JCAE Body Computer MANUAL
 C4	STEERING WHEEL E	1.4 16v 66kw KFU	AUTODETECT
 C4	STEERING WHEEL E	1.6 16v 103kw 5FT	AUTODETECT
 C4	STEERING WHEEL E	1.6 16v 110kw 5FX	AUTODETECT
 C4	STEERING WHEEL E	1.6 16v 80kw N6A	AUTODETECT
 C4	STEERING WHEEL E	1.6 16v 80kw NFU	AUTODETECT
 C4	STEERING WHEEL E	1.6 16v 88kw 5FW	AUTODETECT
 C4	STEERING WHEEL E	1.6 HDI 16v 66kw 9HV	AUTODETECT
 C4	STEERING WHEEL E	1.6 HDI 16v 66kw 9HX	AUTODETECT
 C4	STEERING WHEEL E	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C4	STEERING WHEEL E	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C4	STEERING WHEEL E	2.0 16v 100kw RFN	AUTODETECT
 C4	STEERING WHEEL E	2.0 16v 103kw RFJ	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4	STEERING WHEEL E	2.0 16v 130kw RFK	AUTODETECT
 C4	STEERING WHEEL E	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C4	STEERING WHEEL E	2.0 HDI 16v 103kw RHF-FAP	AUTODETECT
 C4	STEERING WHEEL E	2.0 HDI 8v 80kw RHZ	AUTODETECT
 C4	SWITCHLIGHT MODU	1.4 16v 66kw KFU	EATON/DELPHI
 C4	SWITCHLIGHT MODU	1.6 16v 103kw 5FT	EATON/DELPHI
 C4	SWITCHLIGHT MODU	1.6 16v 110kw 5FX	EATON/DELPHI
 C4	SWITCHLIGHT MODU	1.6 16v 80kw N6A	EATON/DELPHI
 C4	SWITCHLIGHT MODU	1.6 16v 80kw NFU	EATON/DELPHI
 C4	SWITCHLIGHT MODU	1.6 16v 88kw 5FW	EATON/DELPHI
 C4	SWITCHLIGHT MODU	1.6 HDI 16v 66kw 9HV	EATON/DELPHI
 C4	SWITCHLIGHT MODU	1.6 HDI 16v 66kw 9HX	EATON/DELPHI
 C4	SWITCHLIGHT MODU	1.6 HDI 16v 80kw 9HY	EATON/DELPHI
 C4	SWITCHLIGHT MODU	1.6 HDI 16v 80kw 9HZ-FAP	EATON/DELPHI
 C4	SWITCHLIGHT MODU	2.0 16v 100kw RFN	EATON/DELPHI
 C4	SWITCHLIGHT MODU	2.0 16v 103kw RFJ	EATON/DELPHI
 C4	SWITCHLIGHT MODU	2.0 16v 130kw RFK	EATON/DELPHI
 C4	SWITCHLIGHT MODU	2.0 HDI 16v 100kw RHR-FAP	EATON/DELPHI
 C4	SWITCHLIGHT MODU	2.0 HDI 16v 103kw RHF-FAP	EATON/DELPHI
 C4	SWITCHLIGHT MODU	2.0 HDI 8v 80kw RHZ	EATON/DELPHI
 C4	TIRE PRESSURE	1.4 16v 66kw KFU	Siemens-JCAE AUTODETECT
 C4	TIRE PRESSURE	1.6 16v 103kw 5FT	Siemens-JCAE AUTODETECT
 C4	TIRE PRESSURE	1.6 16v 110kw 5FX	Siemens-JCAE AUTODETECT
 C4	TIRE PRESSURE	1.6 16v 80kw N6A	Siemens-JCAE AUTODETECT
 C4	TIRE PRESSURE	1.6 16v 80kw NFU	Siemens-JCAE AUTODETECT
 C4	TIRE PRESSURE	1.6 16v 88kw 5FW	Siemens-JCAE AUTODETECT
 C4	TIRE PRESSURE	1.6 HDI 16v 66kw 9HV	Siemens-JCAE AUTODETECT
 C4	TIRE PRESSURE	1.6 HDI 16v 66kw 9HX	Siemens-JCAE AUTODETECT
 C4	TIRE PRESSURE	1.6 HDI 16v 80kw 9HY	Siemens-JCAE AUTODETECT
 C4	TIRE PRESSURE	1.6 HDI 16v 80kw 9HZ-FAP	Siemens-JCAE AUTODETECT
 C4	TIRE PRESSURE	2.0 16v 100kw RFN	Siemens-JCAE AUTODETECT
 C4	TIRE PRESSURE	2.0 16v 103kw RFJ	Siemens-JCAE AUTODETECT
 C4	TIRE PRESSURE	2.0 16v 130kw RFK	Siemens-JCAE AUTODETECT
 C4	TIRE PRESSURE	2.0 HDI 16v 100kw RHR-FAP	Siemens-JCAE AUTODETECT
 C4	TIRE PRESSURE	2.0 HDI 16v 103kw RHF-FAP	Siemens-JCAE AUTODETECT
 C4	TIRE PRESSURE	2.0 HDI 8v 80kw RHZ	Siemens-JCAE AUTODETECT
 C4	VISUAL./TELEMATIC	1.4 16v 66kw KFU	Display A+ AUTODETECT
 C4	VISUAL./TELEMATIC	1.4 16v 66kw KFU	Display C- AUTODETECT
 C4	VISUAL./TELEMATIC	1.4 16v 66kw KFU	JCAE DIS
 C4	VISUAL./TELEMATIC	1.6 16v 103kw 5FT	Display A+ AUTODETECT
 C4	VISUAL./TELEMATIC	1.6 16v 103kw 5FT	Display C- AUTODETECT
 C4	VISUAL./TELEMATIC	1.6 16v 103kw 5FT	JCAE DIS
 C4	VISUAL./TELEMATIC	1.6 16v 110kw 5FX	Display A+ AUTODETECT
 C4	VISUAL./TELEMATIC	1.6 16v 110kw 5FX	Display C- AUTODETECT
 C4	VISUAL./TELEMATIC	1.6 16v 110kw 5FX	JCAE DIS
 C4	VISUAL./TELEMATIC	1.6 16v 80kw N6A	Display A+ AUTODETECT
 C4	VISUAL./TELEMATIC	1.6 16v 80kw N6A	Display C- AUTODETECT
 C4	VISUAL./TELEMATIC	1.6 16v 80kw N6A	JCAE DIS
 C4	VISUAL./TELEMATIC	1.6 16v 80kw NFU	Display A+ AUTODETECT
 C4	VISUAL./TELEMATIC	1.6 16v 80kw NFU	Display C- AUTODETECT
 C4	VISUAL./TELEMATIC	1.6 16v 80kw NFU	JCAE DIS
 C4	VISUAL./TELEMATIC	1.6 16v 88kw 5FW	Display A+ AUTODETECT
 C4	VISUAL./TELEMATIC	1.6 16v 88kw 5FW	Display C- AUTODETECT
 C4	VISUAL./TELEMATIC	1.6 16v 88kw 5FW	JCAE DIS
 C4	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HV	Display A+ AUTODETECT
 C4	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HV	Display C- AUTODETECT
 C4	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HV	JCAE DIS
 C4	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HX	Display A+ AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C4	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HX	JCAE DIS
 C4	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HY	Display A+ AUTODETECT
 C4	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HY	Display C- AUTODETECT
 C4	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HY	JCAE DIS
 C4	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	Display A+ AUTODETECT
 C4	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	Display C- AUTODETECT
 C4	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	JCAE DIS
 C4	VISUAL./TELEMATIC	2.0 16v 100kw RFN	Display A+ AUTODETECT
 C4	VISUAL./TELEMATIC	2.0 16v 100kw RFN	Display C- AUTODETECT
 C4	VISUAL./TELEMATIC	2.0 16v 100kw RFN	JCAE DIS
 C4	VISUAL./TELEMATIC	2.0 16v 103kw RFJ	Display A+ AUTODETECT
 C4	VISUAL./TELEMATIC	2.0 16v 103kw RFJ	Display C- AUTODETECT
 C4	VISUAL./TELEMATIC	2.0 16v 103kw RFJ	JCAE DIS
 C4	VISUAL./TELEMATIC	2.0 16v 130kw RFK	Display A+ AUTODETECT
 C4	VISUAL./TELEMATIC	2.0 16v 130kw RFK	Display C- AUTODETECT
 C4	VISUAL./TELEMATIC	2.0 16v 130kw RFK	JCAE DIS
 C4	VISUAL./TELEMATIC	2.0 HDI 16v 100kw RHR-FAP	Display A+ AUTODETECT
 C4	VISUAL./TELEMATIC	2.0 HDI 16v 100kw RHR-FAP	Display C- AUTODETECT
 C4	VISUAL./TELEMATIC	2.0 HDI 16v 100kw RHR-FAP	JCAE DIS
 C4	VISUAL./TELEMATIC	2.0 HDI 16v 103kw RHF-FAP	Display A+ AUTODETECT
 C4	VISUAL./TELEMATIC	2.0 HDI 16v 103kw RHF-FAP	Display C- AUTODETECT
 C4	VISUAL./TELEMATIC	2.0 HDI 16v 103kw RHF-FAP	JCAE DIS
 C4	VISUAL./TELEMATIC	2.0 HDI 8v 80kw RHZ	Display A+ AUTODETECT
 C4	VISUAL./TELEMATIC	2.0 HDI 8v 80kw RHZ	Display C- AUTODETECT
 C4	VISUAL./TELEMATIC	2.0 HDI 8v 80kw RHZ	JCAE DIS
 C5 1 (01-04)	ABS	1.8 16v 86kw 6FZ	TEVES ABS Mk60
 C5 1 (01-04)	ABS	2.0 16v 100kw RFN	TEVES ABS Mk60
 C5 1 (01-04)	ABS	2.0 16v 105kw RLZ	TEVES ABS Mk60
 C5 1 (01-04)	ABS	2.0 HDI 16v 79kw RHS	TEVES ABS Mk60
 C5 1 (01-04)	ABS	2.0 HDI 8v 66kw RHY	TEVES ABS Mk60
 C5 1 (01-04)	ABS	2.0 HDI 8v 81kw RHZ	TEVES ABS Mk60
 C5 1 (01-04)	ABS	2.2 HDI 16v 98kw 4HX	TEVES ABS Mk60
 C5 1 (01-04)	ABS	3.0 V6 24v 152kw XFX	TEVES ABS Mk60
 C5 1 (01-04)	ABS + TRACT. CONT	1.8 16v 86kw 6FZ	TEVES ABS MK60 AUTODETECT
 C5 1 (01-04)	ABS + TRACT. CONT	1.8 16v 86kw 6FZ	TEVES ESP MK60 AUTODETECT
 C5 1 (01-04)	ABS + TRACT. CONT	2.0 16v 100kw RFN	TEVES ABS MK60 AUTODETECT
 C5 1 (01-04)	ABS + TRACT. CONT	2.0 16v 100kw RFN	TEVES ESP MK60 AUTODETECT
 C5 1 (01-04)	ABS + TRACT. CONT	2.0 16v 105kw RLZ	TEVES ABS MK60 AUTODETECT
 C5 1 (01-04)	ABS + TRACT. CONT	2.0 16v 105kw RLZ	TEVES ESP MK60 AUTODETECT
 C5 1 (01-04)	ABS + TRACT. CONT	2.0 HDI 16v 79kw RHS	TEVES ABS MK60 AUTODETECT
 C5 1 (01-04)	ABS + TRACT. CONT	2.0 HDI 16v 79kw RHS	TEVES ESP MK60 AUTODETECT
 C5 1 (01-04)	ABS + TRACT. CONT	2.0 HDI 8v 66kw RHY	TEVES ABS MK60 AUTODETECT
 C5 1 (01-04)	ABS + TRACT. CONT	2.0 HDI 8v 66kw RHY	TEVES ESP MK60 AUTODETECT
 C5 1 (01-04)	ABS + TRACT. CONT	2.0 HDI 8v 81kw RHZ	TEVES ABS MK60 AUTODETECT
 C5 1 (01-04)	ABS + TRACT. CONT	2.0 HDI 8v 81kw RHZ	TEVES ESP MK60 AUTODETECT
 C5 1 (01-04)	ABS + TRACT. CONT	2.2 HDI 16v 98kw 4HX	TEVES ABS MK60 AUTODETECT
 C5 1 (01-04)	ABS + TRACT. CONT	2.2 HDI 16v 98kw 4HX	TEVES ESP MK60 AUTODETECT
 C5 1 (01-04)	ABS + TRACT. CONT	3.0 V6 24v 152kw XFX	TEVES ABS MK60 AUTODETECT
 C5 1 (01-04)	ABS + TRACT. CONT	3.0 V6 24v 152kw XFX	TEVES ESP MK60 AUTODETECT
 C5 1 (01-04)	AIRBAG	1.8 16v 86kw 6FZ	AirBag CENTRAL AUTODETECT
 C5 1 (01-04)	AIRBAG	2.0 HDI 16v 79kw RHS	AirBag CENTRAL AUTODETECT
 C5 1 (01-04)	AIRBAG	2.0 HDI 8v 81kw RHZ	AirBag CENTRAL AUTODETECT
 C5 1 (01-04)	AIRBAG	2.2 HDI 16v 98kw 4HX	AirBag CENTRAL AUTODETECT
 C5 1 (01-04)	ANTITHEFT	1.8 16v 86kw 6FZ	Alarm PSA2 AUTODETECT
 C5 1 (01-04)	ANTITHEFT	2.0 16v 100kw RFN	Alarm PSA2 AUTODETECT
 C5 1 (01-04)	ANTITHEFT	2.0 16v 105kw RLZ	Alarm PSA2 AUTODETECT
 C5 1 (01-04)	ANTITHEFT	2.0 HDI 16v 79kw RHS	Alarm PSA2 AUTODETECT
 C5 1 (01-04)	ANTITHEFT	2.0 HDI 8v 66kw RHY	Alarm PSA2 AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C5 1 (01-04)	ANTITHEFT	2.0 HDI 8v 81kw RHZ	Alarm PSA2 AUTODETECT
 C5 1 (01-04)	ANTITHEFT	2.2 HDI 16v 98kw 4HX	Alarm PSA2 AUTODETECT
 C5 1 (01-04)	ANTITHEFT	3.0 V6 24v 152kw XFX	Alarm PSA2 AUTODETECT
 C5 1 (01-04)	AUTOM. TRANSMISSI	1.8 16v 86kw 6FZ	A/T 4HP20 AUTODETECT
 C5 1 (01-04)	AUTOM. TRANSMISSI	1.8 16v 86kw 6FZ	A/T AL4 AUTODETECT
 C5 1 (01-04)	AUTOM. TRANSMISSI	2.0 16v 100kw RFN	A/T 4HP20 AUTODETECT
 C5 1 (01-04)	AUTOM. TRANSMISSI	2.0 16v 100kw RFN	A/T AL4 AUTODETECT
 C5 1 (01-04)	AUTOM. TRANSMISSI	2.0 16v 105kw RLZ	A/T 4HP20 AUTODETECT
 C5 1 (01-04)	AUTOM. TRANSMISSI	2.0 16v 105kw RLZ	A/T AL4 AUTODETECT
 C5 1 (01-04)	AUTOM. TRANSMISSI	2.0 HDI 16v 79kw RHS	A/T 4HP20 AUTODETECT
 C5 1 (01-04)	AUTOM. TRANSMISSI	2.0 HDI 16v 79kw RHS	A/T AL4 AUTODETECT
 C5 1 (01-04)	AUTOM. TRANSMISSI	2.0 HDI 8v 66kw RHY	A/T 4HP20 AUTODETECT
 C5 1 (01-04)	AUTOM. TRANSMISSI	2.0 HDI 8v 66kw RHY	A/T AL4 AUTODETECT
 C5 1 (01-04)	AUTOM. TRANSMISSI	2.0 HDI 8v 81kw RHZ	A/T 4HP20 AUTODETECT
 C5 1 (01-04)	AUTOM. TRANSMISSI	2.0 HDI 8v 81kw RHZ	A/T AL4 AUTODETECT
 C5 1 (01-04)	AUTOM. TRANSMISSI	2.2 HDI 16v 98kw 4HX	A/T 4HP20 AUTODETECT
 C5 1 (01-04)	AUTOM. TRANSMISSI	2.2 HDI 16v 98kw 4HX	A/T AL4 AUTODETECT
 C5 1 (01-04)	AUTOM. TRANSMISSI	3.0 V6 24v 152kw XFX	A/T 4HP20 AUTODETECT
 C5 1 (01-04)	AUTOM. TRANSMISSI	3.0 V6 24v 152kw XFX	A/T AL4 AUTODETECT
 C5 1 (01-04)	CHASSIS NETWORK	1.8 16v 86kw 6FZ	Body Computer BSI AUTODETECT
 C5 1 (01-04)	CHASSIS NETWORK	2.0 16v 100kw RFN	Body Computer BSI AUTODETECT
 C5 1 (01-04)	CHASSIS NETWORK	2.0 16v 105kw RLZ	Body Computer BSI AUTODETECT
 C5 1 (01-04)	CHASSIS NETWORK	2.0 HDI 16v 79kw RHS	Body Computer BSI AUTODETECT
 C5 1 (01-04)	CHASSIS NETWORK	2.0 HDI 8v 66kw RHY	Body Computer BSI AUTODETECT
 C5 1 (01-04)	CHASSIS NETWORK	2.0 HDI 8v 81kw RHZ	Body Computer BSI AUTODETECT
 C5 1 (01-04)	CHASSIS NETWORK	2.2 HDI 16v 98kw 4HX	Body Computer BSI AUTODETECT
 C5 1 (01-04)	CHASSIS NETWORK	3.0 V6 24v 152kw XFX	Body Computer BSI AUTODETECT
 C5 1 (01-04)	CLIMA	1.8 16v 86kw 6FZ	CLIMA AUTO AUTODETECT
 C5 1 (01-04)	CLIMA	2.0 16v 100kw RFN	CLIMA AUTO AUTODETECT
 C5 1 (01-04)	CLIMA	2.0 16v 105kw RLZ	CLIMA AUTO AUTODETECT
 C5 1 (01-04)	CLIMA	2.0 HDI 16v 79kw RHS	CLIMA AUTO AUTODETECT
 C5 1 (01-04)	CLIMA	2.0 HDI 8v 66kw RHY	CLIMA AUTO AUTODETECT
 C5 1 (01-04)	CLIMA	2.0 HDI 8v 81kw RHZ	CLIMA AUTO AUTODETECT
 C5 1 (01-04)	CLIMA	2.2 HDI 16v 98kw 4HX	CLIMA AUTO AUTODETECT
 C5 1 (01-04)	CLIMA	3.0 V6 24v 152kw XFX	CLIMA AUTO AUTODETECT
 C5 1 (01-04)	COMFORT SYSTEM	1.8 16v 86kw 6FZ	AUTODETECT
 C5 1 (01-04)	COMFORT SYSTEM	2.0 16v 100kw RFN	AUTODETECT
 C5 1 (01-04)	COMFORT SYSTEM	2.0 16v 100kw RFN	AUTODETECT
 C5 1 (01-04)	COMFORT SYSTEM	2.0 16v 105kw RLZ	AUTODETECT
 C5 1 (01-04)	COMFORT SYSTEM	2.0 16v 105kw RLZ	AUTODETECT
 C5 1 (01-04)	COMFORT SYSTEM	2.0 HDI 16v 79kw RHS	AUTODETECT
 C5 1 (01-04)	COMFORT SYSTEM	2.0 HDI 16v 79kw RHS	AUTODETECT
 C5 1 (01-04)	COMFORT SYSTEM	2.0 HDI 8v 66kw RHY	AUTODETECT
 C5 1 (01-04)	COMFORT SYSTEM	2.0 HDI 8v 66kw RHY	AUTODETECT
 C5 1 (01-04)	COMFORT SYSTEM	2.0 HDI 8v 81kw RHZ	AUTODETECT
 C5 1 (01-04)	COMFORT SYSTEM	2.0 HDI 8v 81kw RHZ	AUTODETECT
 C5 1 (01-04)	COMFORT SYSTEM	2.2 HDI 16v 98kw 4HX	AUTODETECT
 C5 1 (01-04)	COMFORT SYSTEM	2.2 HDI 16v 98kw 4HX	AUTODETECT
 C5 1 (01-04)	COMFORT SYSTEM	3.0 V6 24v 152kw XFX	AUTODETECT
 C5 1 (01-04)	COMFORT SYSTEM	3.0 V6 24v 152kw XFX	AUTODETECT
 C5 1 (01-04)	CONV. TOP/SUNROO	1.8 16v 86kw 6FZ	AUTODETECT
 C5 1 (01-04)	CONV. TOP/SUNROO	2.0 16v 100kw RFN	AUTODETECT
 C5 1 (01-04)	CONV. TOP/SUNROO	2.0 16v 105kw RLZ	AUTODETECT
 C5 1 (01-04)	CONV. TOP/SUNROO	2.0 HDI 16v 79kw RHS	AUTODETECT
 C5 1 (01-04)	CONV. TOP/SUNROO	2.0 HDI 8v 66kw RHY	AUTODETECT
 C5 1 (01-04)	CONV. TOP/SUNROO	2.0 HDI 8v 81kw RHZ	AUTODETECT
 C5 1 (01-04)	CONV. TOP/SUNROO	2.2 HDI 16v 98kw 4HX	AUTODETECT
 C5 1 (01-04)	CONV. TOP/SUNROO	3.0 V6 24v 152kw XFX	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C5 1 (01-04)	DASHBOARD	1.8 16v 86kw 6FZ	AUTODETECT
 C5 1 (01-04)	DASHBOARD	2.0 16v 100kw RFN	AUTODETECT
 C5 1 (01-04)	DASHBOARD	2.0 16v 105kw RLZ	AUTODETECT
 C5 1 (01-04)	DASHBOARD	2.0 HDI 16v 79kw RHS	AUTODETECT
 C5 1 (01-04)	DASHBOARD	2.0 HDI 8v 66kw RHY	AUTODETECT
 C5 1 (01-04)	DASHBOARD	2.0 HDI 8v 81kw RHZ	AUTODETECT
 C5 1 (01-04)	DASHBOARD	2.2 HDI 16v 98kw 4HX	AUTODETECT
 C5 1 (01-04)	DASHBOARD	3.0 V6 24v 152kw XFX	AUTODETECT
 C5 1 (01-04)	DIESEL ADDITION	2.0 HDI 16v 79kw RHS	AUTODETECT
 C5 1 (01-04)	DIESEL ADDITION	2.0 HDI 8v 66kw RHY	AUTODETECT
 C5 1 (01-04)	DIESEL ADDITION	2.0 HDI 8v 81kw RHZ	AUTODETECT
 C5 1 (01-04)	DRIVER SIDE DOOR	1.8 16v 86kw 6FZ	AUTODETECT
 C5 1 (01-04)	DRIVER SIDE DOOR	1.8 16v 86kw 6FZ	Marelli MTP CONDUCT
 C5 1 (01-04)	DRIVER SIDE DOOR	2.0 16v 100kw RFN	AUTODETECT
 C5 1 (01-04)	DRIVER SIDE DOOR	2.0 16v 100kw RFN	Marelli MTP CONDUCT
 C5 1 (01-04)	DRIVER SIDE DOOR	2.0 16v 105kw RLZ	AUTODETECT
 C5 1 (01-04)	DRIVER SIDE DOOR	2.0 16v 105kw RLZ	Marelli MTP CONDUCT
 C5 1 (01-04)	DRIVER SIDE DOOR	2.0 HDI 16v 79kw RHS	AUTODETECT
 C5 1 (01-04)	DRIVER SIDE DOOR	2.0 HDI 16v 79kw RHS	Marelli MTP CONDUCT
 C5 1 (01-04)	DRIVER SIDE DOOR	2.0 HDI 8v 66kw RHY	AUTODETECT
 C5 1 (01-04)	DRIVER SIDE DOOR	2.0 HDI 8v 66kw RHY	Marelli MTP CONDUCT
 C5 1 (01-04)	DRIVER SIDE DOOR	2.0 HDI 8v 81kw RHZ	AUTODETECT
 C5 1 (01-04)	DRIVER SIDE DOOR	2.0 HDI 8v 81kw RHZ	Marelli MTP CONDUCT
 C5 1 (01-04)	DRIVER SIDE DOOR	2.2 HDI 16v 98kw 4HX	AUTODETECT
 C5 1 (01-04)	DRIVER SIDE DOOR	2.2 HDI 16v 98kw 4HX	Marelli MTP CONDUCT
 C5 1 (01-04)	DRIVER SIDE DOOR	3.0 V6 24v 152kw XFX	AUTODETECT
 C5 1 (01-04)	DRIVER SIDE DOOR	3.0 V6 24v 152kw XFX	Marelli MTP CONDUCT
 C5 1 (01-04)	ENGINE MANAGEME	1.8 16v 86kw 6FZ	SAGEM S2000 AUTODETECT
 C5 1 (01-04)	ENGINE MANAGEME	1.8 16v 86kw 6FZ	SAGEM S2000 PM1 AUTODETECT
 C5 1 (01-04)	ENGINE MANAGEME	2.0 16v 100kw RFN	Marelli MM48P AUTODETECT
 C5 1 (01-04)	ENGINE MANAGEME	2.0 16v 100kw RFN	Marelli MM6LP AUTODETECT
 C5 1 (01-04)	ENGINE MANAGEME	2.0 16v 105kw RLZ	SIEMENS SIRIUS 81 AUTODETECT
 C5 1 (01-04)	ENGINE MANAGEME	2.0 HDI 16v 79kw RHS	BOSCH EDC15 C2 Common Rail AUTODE
 C5 1 (01-04)	ENGINE MANAGEME	2.0 HDI 16v 79kw RHS (01-04)	BOSCH EDC 15 C2 Common Rail
 C5 1 (01-04)	ENGINE MANAGEME	2.0 HDI 8v 66kw RHY	BOSCH EDC 15 C2 Common Rail
 C5 1 (01-04)	ENGINE MANAGEME	2.0 HDI 8v 66kw RHY	SIEMENS Diesel SID 801 Common Rail
 C5 1 (01-04)	ENGINE MANAGEME	2.0 HDI 8v 66kw RHY	SIEMENS SID 801 Common Rail AUTODE
 C5 1 (01-04)	ENGINE MANAGEME	2.0 HDI 8v 81kw RHZ	BOSCH EDC 15 C2 Common Rail
 C5 1 (01-04)	ENGINE MANAGEME	2.0 HDI 8v 81kw RHZ	BOSCH EDC15 C2 Common Rail AUTODE
 C5 1 (01-04)	ENGINE MANAGEME	2.2 HDI 16v 98kw 4HX	BOSCH EDC 15 C2 Common Rail
 C5 1 (01-04)	ENGINE MANAGEME	2.2 HDI 16v 98kw 4HX	BOSCH EDC15 C2 Common Rail AUTODE
 C5 1 (01-04)	ENGINE MANAGEME	3.0 V6 24v 152kw XFX	BOSCH ME 7.4.6 AUTODETECT
 C5 1 (01-04)	MAINTENANCE	1.8 16v 86kw 6FZ	A/T AL4 AUTODETECT
 C5 1 (01-04)	MAINTENANCE	1.8 16v 86kw 6FZ	TEVES ABS MK60 AUTODETECT
 C5 1 (01-04)	MAINTENANCE	1.8 16v 86kw 6FZ	TEVES ESP MK60 AUTODETECT
 C5 1 (01-04)	MAINTENANCE	1.8 16v 86kw 6FZ	TEVES ESP MK60 AUTODETECT
 C5 1 (01-04)	MAINTENANCE	2.0 16v 100kw RFN	A/T AL4 AUTODETECT
 C5 1 (01-04)	MAINTENANCE	2.0 16v 100kw RFN	TEVES ABS MK60 AUTODETECT
 C5 1 (01-04)	MAINTENANCE	2.0 16v 100kw RFN	TEVES ESP MK60 AUTODETECT
 C5 1 (01-04)	MAINTENANCE	2.0 16v 100kw RFN	TEVES ESP MK60 AUTODETECT
 C5 1 (01-04)	MAINTENANCE	2.0 16v 105kw RLZ	A/T AL4 AUTODETECT
 C5 1 (01-04)	MAINTENANCE	2.0 16v 105kw RLZ	TEVES ABS MK60 AUTODETECT
 C5 1 (01-04)	MAINTENANCE	2.0 16v 105kw RLZ	TEVES ESP MK60 AUTODETECT
 C5 1 (01-04)	MAINTENANCE	2.0 16v 105kw RLZ	TEVES ESP MK60 AUTODETECT
 C5 1 (01-04)	MAINTENANCE	2.0 HDI 16v 79kw RHS	A/T AL4 AUTODETECT
 C5 1 (01-04)	MAINTENANCE	2.0 HDI 16v 79kw RHS	BOSCH EDC15 C2 Common Rail AUTODE
 C5 1 (01-04)	MAINTENANCE	2.0 HDI 16v 79kw RHS	TEVES ABS MK60 AUTODETECT
 C5 1 (01-04)	MAINTENANCE	2.0 HDI 16v 79kw RHS	TEVES ESP MK60 AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C5 1 (01-04)	MAINTENANCE	2.0 HDI 16v 79kw RHS	TEVES ESP MK60 AUTODETECT
 C5 1 (01-04)	MAINTENANCE	2.0 HDI 16v 79kw RHS (01-04)	BOSCH EDC 15 C2 Common Rail
 C5 1 (01-04)	MAINTENANCE	2.0 HDI 8v 66kw RHY	A/T AL4 AUTODETECT
 C5 1 (01-04)	MAINTENANCE	2.0 HDI 8v 66kw RHY	BOSCH EDC 15 C2 Common Rail
 C5 1 (01-04)	MAINTENANCE	2.0 HDI 8v 66kw RHY	TEVES ABS MK60 AUTODETECT
 C5 1 (01-04)	MAINTENANCE	2.0 HDI 8v 66kw RHY	TEVES ESP MK60 AUTODETECT
 C5 1 (01-04)	MAINTENANCE	2.0 HDI 8v 66kw RHY	TEVES ESP MK60 AUTODETECT
 C5 1 (01-04)	MAINTENANCE	2.0 HDI 8v 81kw RHZ	A/T AL4 AUTODETECT
 C5 1 (01-04)	MAINTENANCE	2.0 HDI 8v 81kw RHZ	BOSCH EDC 15 C2 Common Rail
 C5 1 (01-04)	MAINTENANCE	2.0 HDI 8v 81kw RHZ	BOSCH EDC15 C2 Common Rail AUTODE
 C5 1 (01-04)	MAINTENANCE	2.0 HDI 8v 81kw RHZ	TEVES ABS MK60 AUTODETECT
 C5 1 (01-04)	MAINTENANCE	2.0 HDI 8v 81kw RHZ	TEVES ESP MK60 AUTODETECT
 C5 1 (01-04)	MAINTENANCE	2.0 HDI 8v 81kw RHZ	TEVES ESP MK60 AUTODETECT
 C5 1 (01-04)	MAINTENANCE	2.2 HDI 16v 98kw 4HX	A/T AL4 AUTODETECT
 C5 1 (01-04)	MAINTENANCE	2.2 HDI 16v 98kw 4HX	BOSCH EDC 15 C2 Common Rail
 C5 1 (01-04)	MAINTENANCE	2.2 HDI 16v 98kw 4HX	BOSCH EDC15 C2 Common Rail AUTODE
 C5 1 (01-04)	MAINTENANCE	2.2 HDI 16v 98kw 4HX	TEVES ABS MK60 AUTODETECT
 C5 1 (01-04)	MAINTENANCE	2.2 HDI 16v 98kw 4HX	TEVES ESP MK60 AUTODETECT
 C5 1 (01-04)	MAINTENANCE	2.2 HDI 16v 98kw 4HX	TEVES ESP MK60 AUTODETECT
 C5 1 (01-04)	MAINTENANCE	3.0 V6 24v 152kw XFX	A/T AL4 AUTODETECT
 C5 1 (01-04)	MAINTENANCE	3.0 V6 24v 152kw XFX	TEVES ABS MK60 AUTODETECT
 C5 1 (01-04)	MAINTENANCE	3.0 V6 24v 152kw XFX	TEVES ESP MK60 AUTODETECT
 C5 1 (01-04)	MAINTENANCE	3.0 V6 24v 152kw XFX	TEVES ESP MK60 AUTODETECT
 C5 1 (01-04)	NAVIGATION	1.8 16v 86kw 6FZ	AUTODETECT
 C5 1 (01-04)	NAVIGATION	1.8 16v 86kw 6FZ	Color Navi AUTODETECT
 C5 1 (01-04)	NAVIGATION	2.0 16v 100kw RFN	AUTODETECT
 C5 1 (01-04)	NAVIGATION	2.0 16v 100kw RFN	Color Navi AUTODETECT
 C5 1 (01-04)	NAVIGATION	2.0 16v 105kw RLZ	AUTODETECT
 C5 1 (01-04)	NAVIGATION	2.0 16v 105kw RLZ	Color Navi AUTODETECT
 C5 1 (01-04)	NAVIGATION	2.0 HDI 16v 79kw RHS	AUTODETECT
 C5 1 (01-04)	NAVIGATION	2.0 HDI 16v 79kw RHS	Color Navi AUTODETECT
 C5 1 (01-04)	NAVIGATION	2.0 HDI 8v 66kw RHY	AUTODETECT
 C5 1 (01-04)	NAVIGATION	2.0 HDI 8v 66kw RHY	Color Navi AUTODETECT
 C5 1 (01-04)	NAVIGATION	2.0 HDI 8v 81kw RHZ	AUTODETECT
 C5 1 (01-04)	NAVIGATION	2.0 HDI 8v 81kw RHZ	Color Navi AUTODETECT
 C5 1 (01-04)	NAVIGATION	2.2 HDI 16v 98kw 4HX	AUTODETECT
 C5 1 (01-04)	NAVIGATION	2.2 HDI 16v 98kw 4HX	Color Navi AUTODETECT
 C5 1 (01-04)	NAVIGATION	3.0 V6 24v 152kw XFX	AUTODETECT
 C5 1 (01-04)	NAVIGATION	3.0 V6 24v 152kw XFX	Color Navi AUTODETECT
 C5 1 (01-04)	PARKING HELP	1.8 16v 86kw 6FZ	AUTODETECT
 C5 1 (01-04)	PARKING HELP	2.0 16v 100kw RFN	AUTODETECT
 C5 1 (01-04)	PARKING HELP	2.0 16v 105kw RLZ	AUTODETECT
 C5 1 (01-04)	PARKING HELP	2.0 HDI 16v 79kw RHS	AUTODETECT
 C5 1 (01-04)	PARKING HELP	2.0 HDI 8v 66kw RHY	AUTODETECT
 C5 1 (01-04)	PARKING HELP	2.0 HDI 8v 81kw RHZ	AUTODETECT
 C5 1 (01-04)	PARKING HELP	2.2 HDI 16v 98kw 4HX	AUTODETECT
 C5 1 (01-04)	PARKING HELP	3.0 V6 24v 152kw XFX	AUTODETECT
 C5 1 (01-04)	PASS. SIDE DOOR	1.8 16v 86kw 6FZ	AUTODETECT
 C5 1 (01-04)	PASS. SIDE DOOR	1.8 16v 86kw 6FZ	Marelli MTP PASS
 C5 1 (01-04)	PASS. SIDE DOOR	2.0 16v 100kw RFN	AUTODETECT
 C5 1 (01-04)	PASS. SIDE DOOR	2.0 16v 100kw RFN	Marelli MTP PASS
 C5 1 (01-04)	PASS. SIDE DOOR	2.0 16v 105kw RLZ	AUTODETECT
 C5 1 (01-04)	PASS. SIDE DOOR	2.0 16v 105kw RLZ	Marelli MTP PASS
 C5 1 (01-04)	PASS. SIDE DOOR	2.0 HDI 16v 79kw RHS	AUTODETECT
 C5 1 (01-04)	PASS. SIDE DOOR	2.0 HDI 16v 79kw RHS	Marelli MTP PASS
 C5 1 (01-04)	PASS. SIDE DOOR	2.0 HDI 8v 66kw RHY	AUTODETECT
 C5 1 (01-04)	PASS. SIDE DOOR	2.0 HDI 8v 66kw RHY	Marelli MTP PASS
 C5 1 (01-04)	PASS. SIDE DOOR	2.0 HDI 8v 81kw RHZ	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C5 1 (01-04)	PASS. SIDE DOOR	2.0 HDI 8v 81kw RHZ	Marelli MTP PASS
 C5 1 (01-04)	PASS. SIDE DOOR	2.2 HDI 16v 98kw 4HX	AUTODETECT
 C5 1 (01-04)	PASS. SIDE DOOR	2.2 HDI 16v 98kw 4HX	Marelli MTP PASS
 C5 1 (01-04)	PASS. SIDE DOOR	3.0 V6 24v 152kw XFX	AUTODETECT
 C5 1 (01-04)	PASS. SIDE DOOR	3.0 V6 24v 152kw XFX	Marelli MTP PASS
 C5 1 (01-04)	RADIO / CD	1.8 16v 86kw 6FZ	AudioSystem AUTODETECT
 C5 1 (01-04)	RADIO / CD	1.8 16v 86kw 6FZ	CD CHanger AUTODETECT
 C5 1 (01-04)	RADIO / CD	1.8 16v 86kw 6FZ	CLARION AudioSystem
 C5 1 (01-04)	RADIO / CD	1.8 16v 86kw 6FZ	PHILIPS AudioSystem
 C5 1 (01-04)	RADIO / CD	1.8 16v 86kw 6FZ	VDO AudioSystem
 C5 1 (01-04)	RADIO / CD	2.0 16v 100kw RFN	AudioSystem AUTODETECT
 C5 1 (01-04)	RADIO / CD	2.0 16v 100kw RFN	CD CHanger AUTODETECT
 C5 1 (01-04)	RADIO / CD	2.0 16v 100kw RFN	CLARION AudioSystem
 C5 1 (01-04)	RADIO / CD	2.0 16v 100kw RFN	PHILIPS AudioSystem
 C5 1 (01-04)	RADIO / CD	2.0 16v 100kw RFN	VDO AudioSystem
 C5 1 (01-04)	RADIO / CD	2.0 16v 105kw RLZ	AudioSystem AUTODETECT
 C5 1 (01-04)	RADIO / CD	2.0 16v 105kw RLZ	CD CHanger AUTODETECT
 C5 1 (01-04)	RADIO / CD	2.0 16v 105kw RLZ	CLARION AudioSystem
 C5 1 (01-04)	RADIO / CD	2.0 16v 105kw RLZ	PHILIPS AudioSystem
 C5 1 (01-04)	RADIO / CD	2.0 16v 105kw RLZ	VDO AudioSystem
 C5 1 (01-04)	RADIO / CD	2.0 HDI 16v 79kw RHS	AudioSystem AUTODETECT
 C5 1 (01-04)	RADIO / CD	2.0 HDI 16v 79kw RHS	CD CHanger AUTODETECT
 C5 1 (01-04)	RADIO / CD	2.0 HDI 16v 79kw RHS	CLARION AudioSystem
 C5 1 (01-04)	RADIO / CD	2.0 HDI 16v 79kw RHS	PHILIPS AudioSystem
 C5 1 (01-04)	RADIO / CD	2.0 HDI 16v 79kw RHS	VDO AudioSystem
 C5 1 (01-04)	RADIO / CD	2.0 HDI 8v 66kw RHY	AudioSystem AUTODETECT
 C5 1 (01-04)	RADIO / CD	2.0 HDI 8v 66kw RHY	CD CHanger AUTODETECT
 C5 1 (01-04)	RADIO / CD	2.0 HDI 8v 66kw RHY	CLARION AudioSystem
 C5 1 (01-04)	RADIO / CD	2.0 HDI 8v 66kw RHY	PHILIPS AudioSystem
 C5 1 (01-04)	RADIO / CD	2.0 HDI 8v 66kw RHY	VDO AudioSystem
 C5 1 (01-04)	RADIO / CD	2.0 HDI 8v 81kw RHZ	AudioSystem AUTODETECT
 C5 1 (01-04)	RADIO / CD	2.0 HDI 8v 81kw RHZ	CD CHanger AUTODETECT
 C5 1 (01-04)	RADIO / CD	2.0 HDI 8v 81kw RHZ	CLARION AudioSystem
 C5 1 (01-04)	RADIO / CD	2.0 HDI 8v 81kw RHZ	PHILIPS AudioSystem
 C5 1 (01-04)	RADIO / CD	2.0 HDI 8v 81kw RHZ	VDO AudioSystem
 C5 1 (01-04)	RADIO / CD	2.2 HDI 16v 98kw 4HX	AudioSystem AUTODETECT
 C5 1 (01-04)	RADIO / CD	2.2 HDI 16v 98kw 4HX	CD CHanger AUTODETECT
 C5 1 (01-04)	RADIO / CD	2.2 HDI 16v 98kw 4HX	CLARION AudioSystem
 C5 1 (01-04)	RADIO / CD	2.2 HDI 16v 98kw 4HX	PHILIPS AudioSystem
 C5 1 (01-04)	RADIO / CD	2.2 HDI 16v 98kw 4HX	VDO AudioSystem
 C5 1 (01-04)	RADIO / CD	3.0 V6 24v 152kw XFX	AudioSystem AUTODETECT
 C5 1 (01-04)	RADIO / CD	3.0 V6 24v 152kw XFX	CD CHanger AUTODETECT
 C5 1 (01-04)	RADIO / CD	3.0 V6 24v 152kw XFX	CLARION AudioSystem
 C5 1 (01-04)	RADIO / CD	3.0 V6 24v 152kw XFX	PHILIPS AudioSystem
 C5 1 (01-04)	RADIO / CD	3.0 V6 24v 152kw XFX	VDO AudioSystem
 C5 1 (01-04)	RAIN-LUMINOSITY S	1.8 16v 86kw 6FZ	AUTODETECT
 C5 1 (01-04)	RAIN-LUMINOSITY S	1.8 16v 86kw 6FZ	KOSTAL WSS
 C5 1 (01-04)	RAIN-LUMINOSITY S	2.0 16v 100kw RFN	AUTODETECT
 C5 1 (01-04)	RAIN-LUMINOSITY S	2.0 16v 100kw RFN	KOSTAL WSS
 C5 1 (01-04)	RAIN-LUMINOSITY S	2.0 16v 105kw RLZ	AUTODETECT
 C5 1 (01-04)	RAIN-LUMINOSITY S	2.0 16v 105kw RLZ	KOSTAL WSS
 C5 1 (01-04)	RAIN-LUMINOSITY S	2.0 HDI 16v 79kw RHS	AUTODETECT
 C5 1 (01-04)	RAIN-LUMINOSITY S	2.0 HDI 16v 79kw RHS	KOSTAL WSS
 C5 1 (01-04)	RAIN-LUMINOSITY S	2.0 HDI 8v 66kw RHY	AUTODETECT
 C5 1 (01-04)	RAIN-LUMINOSITY S	2.0 HDI 8v 66kw RHY	KOSTAL WSS
 C5 1 (01-04)	RAIN-LUMINOSITY S	2.0 HDI 8v 81kw RHZ	AUTODETECT
 C5 1 (01-04)	RAIN-LUMINOSITY S	2.0 HDI 8v 81kw RHZ	KOSTAL WSS
 C5 1 (01-04)	RAIN-LUMINOSITY S	2.2 HDI 16v 98kw 4HX	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C5 1 (01-04)	RAIN-LUMINOSITY S	2.2 HDI 16v 98kw 4HX	KOSTAL WSS
 C5 1 (01-04)	RAIN-LUMINOSITY S	3.0 V6 24v 152kw XFX	AUTODETECT
 C5 1 (01-04)	RAIN-LUMINOSITY S	3.0 V6 24v 152kw XFX	KOSTAL WSS
 C5 1 (01-04)	STEERING COLUMN	1.8 16v 86kw 6FZ	AUTODETECT
 C5 1 (01-04)	STEERING COLUMN	2.0 16v 100kw RFN	AUTODETECT
 C5 1 (01-04)	STEERING COLUMN	2.0 16v 105kw RLZ	AUTODETECT
 C5 1 (01-04)	STEERING COLUMN	2.0 HDI 16v 79kw RHS	AUTODETECT
 C5 1 (01-04)	STEERING COLUMN	2.0 HDI 8v 66kw RHY	AUTODETECT
 C5 1 (01-04)	STEERING COLUMN	2.0 HDI 8v 81kw RHZ	AUTODETECT
 C5 1 (01-04)	STEERING COLUMN	2.2 HDI 16v 98kw 4HX	AUTODETECT
 C5 1 (01-04)	STEERING COLUMN	3.0 V6 24v 152kw XFX	AUTODETECT
 C5 1 (01-04)	SUSPENSION CONTR	1.8 16v 86kw 6FZ	AUTODETECT
 C5 1 (01-04)	SUSPENSION CONTR	2.0 16v 100kw RFN	AUTODETECT
 C5 1 (01-04)	SUSPENSION CONTR	2.0 16v 105kw RLZ	AUTODETECT
 C5 1 (01-04)	SUSPENSION CONTR	2.0 HDI 16v 79kw RHS	AUTODETECT
 C5 1 (01-04)	SUSPENSION CONTR	2.0 HDI 8v 66kw RHY	AUTODETECT
 C5 1 (01-04)	SUSPENSION CONTR	2.0 HDI 8v 81kw RHZ	AUTODETECT
 C5 1 (01-04)	SUSPENSION CONTR	2.2 HDI 16v 98kw 4HX	AUTODETECT
 C5 1 (01-04)	SUSPENSION CONTR	3.0 V6 24v 152kw XFX	AUTODETECT
 C5 1 (01-04)	SWITCHLIGHT MODU	1.8 16v 86kw 6FZ	EATON
 C5 1 (01-04)	SWITCHLIGHT MODU	2.0 16v 100kw RFN	EATON
 C5 1 (01-04)	SWITCHLIGHT MODU	2.0 16v 105kw RLZ	EATON
 C5 1 (01-04)	SWITCHLIGHT MODU	2.0 HDI 16v 79kw RHS	EATON
 C5 1 (01-04)	SWITCHLIGHT MODU	2.0 HDI 8v 66kw RHY	EATON
 C5 1 (01-04)	SWITCHLIGHT MODU	2.0 HDI 8v 81kw RHZ	EATON
 C5 1 (01-04)	SWITCHLIGHT MODU	2.2 HDI 16v 98kw 4HX	EATON
 C5 1 (01-04)	SWITCHLIGHT MODU	3.0 V6 24v 152kw XFX	EATON
 C5 1 (01-04)	VISUAL./TELEMATIC	1.8 16v 86kw 6FZ	AUTODETECT
 C5 1 (01-04)	VISUAL./TELEMATIC	1.8 16v 86kw 6FZ	AUTODETECT
 C5 1 (01-04)	VISUAL./TELEMATIC	1.8 16v 86kw 6FZ	AUTODETECT
 C5 1 (01-04)	VISUAL./TELEMATIC	1.8 16v 86kw 6FZ	SAGEM
 C5 1 (01-04)	VISUAL./TELEMATIC	2.0 16v 100kw RFN	AUTODETECT
 C5 1 (01-04)	VISUAL./TELEMATIC	2.0 16v 100kw RFN	AUTODETECT
 C5 1 (01-04)	VISUAL./TELEMATIC	2.0 16v 100kw RFN	AUTODETECT
 C5 1 (01-04)	VISUAL./TELEMATIC	2.0 16v 100kw RFN	SAGEM
 C5 1 (01-04)	VISUAL./TELEMATIC	2.0 16v 105kw RLZ	AUTODETECT
 C5 1 (01-04)	VISUAL./TELEMATIC	2.0 16v 105kw RLZ	AUTODETECT
 C5 1 (01-04)	VISUAL./TELEMATIC	2.0 16v 105kw RLZ	SAGEM
 C5 1 (01-04)	VISUAL./TELEMATIC	2.0 HDI 16v 79kw RHS	AUTODETECT
 C5 1 (01-04)	VISUAL./TELEMATIC	2.0 HDI 16v 79kw RHS	AUTODETECT
 C5 1 (01-04)	VISUAL./TELEMATIC	2.0 HDI 16v 79kw RHS	AUTODETECT
 C5 1 (01-04)	VISUAL./TELEMATIC	2.0 HDI 16v 79kw RHS	SAGEM
 C5 1 (01-04)	VISUAL./TELEMATIC	2.0 HDI 8v 66kw RHY	AUTODETECT
 C5 1 (01-04)	VISUAL./TELEMATIC	2.0 HDI 8v 66kw RHY	AUTODETECT
 C5 1 (01-04)	VISUAL./TELEMATIC	2.0 HDI 8v 66kw RHY	AUTODETECT
 C5 1 (01-04)	VISUAL./TELEMATIC	2.0 HDI 8v 66kw RHY	SAGEM
 C5 1 (01-04)	VISUAL./TELEMATIC	2.0 HDI 8v 81kw RHZ	AUTODETECT
 C5 1 (01-04)	VISUAL./TELEMATIC	2.0 HDI 8v 81kw RHZ	AUTODETECT
 C5 1 (01-04)	VISUAL./TELEMATIC	2.0 HDI 8v 81kw RHZ	AUTODETECT
 C5 1 (01-04)	VISUAL./TELEMATIC	2.0 HDI 8v 81kw RHZ	SAGEM
 C5 1 (01-04)	VISUAL./TELEMATIC	2.2 HDI 16v 98kw 4HX	AUTODETECT
 C5 1 (01-04)	VISUAL./TELEMATIC	2.2 HDI 16v 98kw 4HX	AUTODETECT
 C5 1 (01-04)	VISUAL./TELEMATIC	2.2 HDI 16v 98kw 4HX	AUTODETECT
 C5 1 (01-04)	VISUAL./TELEMATIC	2.2 HDI 16v 98kw 4HX	SAGEM
 C5 1 (01-04)	VISUAL./TELEMATIC	3.0 V6 24v 152kw XFX	AUTODETECT
 C5 1 (01-04)	VISUAL./TELEMATIC	3.0 V6 24v 152kw XFX	AUTODETECT
 C5 1 (01-04)	VISUAL./TELEMATIC	3.0 V6 24v 152kw XFX	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C5 1 (01-04)	VISUAL./TELEMATIC	3.0 V6 24v 152kw XFX	SAGEM
 C5 1 Restyling (04-08)	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HY	ESP MK60 AUTODETECT
 C5 1 Restyling (04-08)	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HY	TEVES ABS Mk60
 C5 1 Restyling (04-08)	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	ESP MK60 AUTODETECT
 C5 1 Restyling (04-08)	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	TEVES ABS Mk60
 C5 1 Restyling (04-08)	ABS + TRACT. CONT	1.8 16v 86kw 6FZ	ESP MK60 AUTODETECT
 C5 1 Restyling (04-08)	ABS + TRACT. CONT	1.8 16v 86kw 6FZ	TEVES ABS Mk60
 C5 1 Restyling (04-08)	ABS + TRACT. CONT	1.8 16v 92kw 6FY	ESP MK60 AUTODETECT
 C5 1 Restyling (04-08)	ABS + TRACT. CONT	1.8 16v 92kw 6FY	TEVES ABS Mk60
 C5 1 Restyling (04-08)	ABS + TRACT. CONT	2.0 16v 103kw RFJ	ESP MK60 AUTODETECT
 C5 1 Restyling (04-08)	ABS + TRACT. CONT	2.0 16v 103kw RFJ	TEVES ABS Mk60
 C5 1 Restyling (04-08)	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP	ESP MK60 AUTODETECT
 C5 1 Restyling (04-08)	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP	TEVES ABS Mk60
 C5 1 Restyling (04-08)	ABS + TRACT. CONT	2.0 HDI 16v 103kw RHF	ESP MK60 AUTODETECT
 C5 1 Restyling (04-08)	ABS + TRACT. CONT	2.0 HDI 16v 103kw RHF	TEVES ABS Mk60
 C5 1 Restyling (04-08)	ABS + TRACT. CONT	2.0 HDI 16v 93kw RHL-FAP	ESP MK60 AUTODETECT
 C5 1 Restyling (04-08)	ABS + TRACT. CONT	2.0 HDI 16v 93kw RHL-FAP	TEVES ABS Mk60
 C5 1 Restyling (04-08)	ABS + TRACT. CONT	2.2 HDI 16v 120kw 4HP-FAP	ESP MK60 AUTODETECT
 C5 1 Restyling (04-08)	ABS + TRACT. CONT	2.2 HDI 16v 120kw 4HP-FAP	TEVES ABS Mk60
 C5 1 Restyling (04-08)	ABS + TRACT. CONT	2.2 HDI 16v 120kw 4HR-FAP	ESP MK60 AUTODETECT
 C5 1 Restyling (04-08)	ABS + TRACT. CONT	2.2 HDI 16v 120kw 4HR-FAP	TEVES ABS Mk60
 C5 1 Restyling (04-08)	ABS + TRACT. CONT	2.2 HDI 16v 125kw 4HS-FAP	ESP MK60 AUTODETECT
 C5 1 Restyling (04-08)	ABS + TRACT. CONT	2.2 HDI 16v 125kw 4HS-FAP	TEVES ABS Mk60
 C5 1 Restyling (04-08)	ABS + TRACT. CONT	2.2 HDI 16v 125kw 4HT-FAP	ESP MK60 AUTODETECT
 C5 1 Restyling (04-08)	ABS + TRACT. CONT	2.2 HDI 16v 125kw 4HT-FAP	TEVES ABS Mk60
 C5 1 Restyling (04-08)	ABS + TRACT. CONT	2.2 HDI 16v 98kw 4HX-FAP	ESP MK60 AUTODETECT
 C5 1 Restyling (04-08)	ABS + TRACT. CONT	2.2 HDI 16v 98kw 4HX-FAP	TEVES ABS Mk60
 C5 1 Restyling (04-08)	ABS + TRACT. CONT	3.0 V6 24v 152kw XFU	ESP MK60 AUTODETECT
 C5 1 Restyling (04-08)	ABS + TRACT. CONT	3.0 V6 24v 152kw XFU	TEVES ABS Mk60
 C5 1 Restyling (04-08)	AIRBAG	1.6 HDI 16v 80kw 9HY	AirBag CENTRAL AUTODETECT
 C5 1 Restyling (04-08)	AIRBAG	1.6 HDI 16v 80kw 9HY	TRW Autoliv AirBag
 C5 1 Restyling (04-08)	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL AUTODETECT
 C5 1 Restyling (04-08)	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP	TRW Autoliv AirBag
 C5 1 Restyling (04-08)	AIRBAG	1.8 16v 86kw 6FZ	AirBag CENTRAL AUTODETECT
 C5 1 Restyling (04-08)	AIRBAG	1.8 16v 86kw 6FZ	TRW Autoliv AirBag
 C5 1 Restyling (04-08)	AIRBAG	1.8 16v 92kw 6FY	AirBag CENTRAL AUTODETECT
 C5 1 Restyling (04-08)	AIRBAG	1.8 16v 92kw 6FY	TRW Autoliv AirBag
 C5 1 Restyling (04-08)	AIRBAG	2.0 16v 103kw RFJ	AirBag CENTRAL AUTODETECT
 C5 1 Restyling (04-08)	AIRBAG	2.0 16v 103kw RFJ	TRW Autoliv AirBag
 C5 1 Restyling (04-08)	AIRBAG	2.0 HDI 16v 100kw RHR-FAP	AirBag CENTRAL AUTODETECT
 C5 1 Restyling (04-08)	AIRBAG	2.0 HDI 16v 100kw RHR-FAP	TRW Autoliv AirBag
 C5 1 Restyling (04-08)	AIRBAG	2.0 HDI 16v 103kw RHF	AirBag CENTRAL AUTODETECT
 C5 1 Restyling (04-08)	AIRBAG	2.0 HDI 16v 103kw RHF	TRW Autoliv AirBag
 C5 1 Restyling (04-08)	AIRBAG	2.0 HDI 16v 93kw RHL-FAP	AirBag CENTRAL AUTODETECT
 C5 1 Restyling (04-08)	AIRBAG	2.0 HDI 16v 93kw RHL-FAP	TRW Autoliv AirBag
 C5 1 Restyling (04-08)	AIRBAG	2.2 HDI 16v 120kw 4HP-FAP	AirBag CENTRAL AUTODETECT
 C5 1 Restyling (04-08)	AIRBAG	2.2 HDI 16v 120kw 4HP-FAP	TRW Autoliv AirBag
 C5 1 Restyling (04-08)	AIRBAG	2.2 HDI 16v 120kw 4HR-FAP	AirBag CENTRAL AUTODETECT
 C5 1 Restyling (04-08)	AIRBAG	2.2 HDI 16v 120kw 4HR-FAP	TRW Autoliv AirBag
 C5 1 Restyling (04-08)	AIRBAG	2.2 HDI 16v 125kw 4HS-FAP	AirBag CENTRAL AUTODETECT
 C5 1 Restyling (04-08)	AIRBAG	2.2 HDI 16v 125kw 4HS-FAP	TRW Autoliv AirBag
 C5 1 Restyling (04-08)	AIRBAG	2.2 HDI 16v 125kw 4HT-FAP	AirBag CENTRAL AUTODETECT
C5 1 Restyling (04-08)	AIRBAG	2.2 HDI 16v 125kw 4HT-FAP	TRW Autoliv AirBag
C5 1 Restyling (04-08)	AIRBAG	2.2 HDI 16v 98kw 4HX-FAP	AirBag CENTRAL AUTODETECT
C5 1 Restyling (04-08)	AIRBAG	2.2 HDI 16v 98kw 4HX-FAP	TRW Autoliv AirBag
C5 1 Restyling (04-08)	AIRBAG	3.0 V6 24v 152kw XFU	AirBag CENTRAL AUTODETECT
C5 1 Restyling (04-08)	AIRBAG	3.0 V6 24v 152kw XFU	TRW Autoliv AirBag
C5 1 Restyling (04-08)	ANTITHEFT	1.6 HDI 16v 80kw 9HY	Alarm PSA2 AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C5 1 Restyling (04-08)	ANTITHEFT	1.6 HDI 16v 80kw 9HZ-FAP	Alarm PSA2 AUTODETECT
 C5 1 Restyling (04-08)	ANTITHEFT	1.8 16v 86kw 6FZ	Alarm PSA2 AUTODETECT
 C5 1 Restyling (04-08)	ANTITHEFT	1.8 16v 92kw 6FY	Alarm PSA2 AUTODETECT
 C5 1 Restyling (04-08)	ANTITHEFT	2.0 16v 103kw RFJ	Alarm PSA2 AUTODETECT
 C5 1 Restyling (04-08)	ANTITHEFT	2.0 HDI 16v 100kw RHR-FAP	Alarm PSA2 AUTODETECT
 C5 1 Restyling (04-08)	ANTITHEFT	2.0 HDI 16v 103kw RHF	Alarm PSA2 AUTODETECT
 C5 1 Restyling (04-08)	ANTITHEFT	2.0 HDI 16v 93kw RHL-FAP	Alarm PSA2 AUTODETECT
 C5 1 Restyling (04-08)	ANTITHEFT	2.2 HDI 16v 120kw 4HP-FAP	Alarm PSA2 AUTODETECT
 C5 1 Restyling (04-08)	ANTITHEFT	2.2 HDI 16v 120kw 4HR-FAP	Alarm PSA2 AUTODETECT
 C5 1 Restyling (04-08)	ANTITHEFT	2.2 HDI 16v 125kw 4HS-FAP	Alarm PSA2 AUTODETECT
 C5 1 Restyling (04-08)	ANTITHEFT	2.2 HDI 16v 125kw 4HT-FAP	Alarm PSA2 AUTODETECT
 C5 1 Restyling (04-08)	ANTITHEFT	2.2 HDI 16v 98kw 4HX-FAP	Alarm PSA2 AUTODETECT
 C5 1 Restyling (04-08)	ANTITHEFT	3.0 V6 24v 152kw XFU	Alarm PSA2 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HY	A/T 4HP20 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HY	A/T AL4 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HY	A/T AM6 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP	A/T 4HP20 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP	A/T AL4 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP	A/T AM6 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	1.8 16v 86kw 6FZ	A/T 4HP20 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	1.8 16v 86kw 6FZ	A/T AL4 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	1.8 16v 86kw 6FZ	A/T AM6 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	1.8 16v 92kw 6FY	A/T 4HP20 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	1.8 16v 92kw 6FY	A/T AL4 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	1.8 16v 92kw 6FY	A/T AM6 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ	A/T 4HP20 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ	A/T AL4 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ	A/T AM6 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP	A/T 4HP20 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP	A/T AL4 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP	A/T AM6 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	2.0 HDI 16v 103kw RHF	A/T 4HP20 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	2.0 HDI 16v 103kw RHF	A/T AL4 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	2.0 HDI 16v 103kw RHF	A/T AM6 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	2.0 HDI 16v 93kw RHL-FAP	A/T 4HP20 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	2.0 HDI 16v 93kw RHL-FAP	A/T AL4 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	2.0 HDI 16v 93kw RHL-FAP	A/T AM6 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HP-FAP	A/T 4HP20 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HP-FAP	A/T AL4 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HP-FAP	A/T AM6 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HR-FAP	A/T 4HP20 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HR-FAP	A/T AL4 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HR-FAP	A/T AM6 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HS-FAP	A/T 4HP20 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HS-FAP	A/T AL4 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HS-FAP	A/T AM6 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HT-FAP	A/T 4HP20 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HT-FAP	A/T AL4 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HT-FAP	A/T AM6 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	2.2 HDI 16v 98kw 4HX-FAP	A/T 4HP20 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	2.2 HDI 16v 98kw 4HX-FAP	A/T AL4 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	2.2 HDI 16v 98kw 4HX-FAP	A/T AM6 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	3.0 V6 24v 152kw XFU	A/T 4HP20 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	3.0 V6 24v 152kw XFU	A/T AL4 AUTODETECT
 C5 1 Restyling (04-08)	AUTOM. TRANSMISSI	3.0 V6 24v 152kw XFU	A/T AM6 AUTODETECT
 C5 1 Restyling (04-08)	AUX. HEATING	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C5 1 Restyling (04-08)	AUX. HEATING	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C5 1 Restyling (04-08)	AUX. HEATING	1.8 16v 86kw 6FZ	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C5 1 Restyling (04-08)	AUX. HEATING	1.8 16v 92kw 6FY	AUTODETECT
 C5 1 Restyling (04-08)	AUX. HEATING	2.0 16v 103kw RFJ	AUTODETECT
 C5 1 Restyling (04-08)	AUX. HEATING	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C5 1 Restyling (04-08)	AUX. HEATING	2.0 HDI 16v 103kw RHF	AUTODETECT
 C5 1 Restyling (04-08)	AUX. HEATING	2.0 HDI 16v 93kw RHL-FAP	AUTODETECT
 C5 1 Restyling (04-08)	AUX. HEATING	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C5 1 Restyling (04-08)	AUX. HEATING	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C5 1 Restyling (04-08)	AUX. HEATING	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C5 1 Restyling (04-08)	AUX. HEATING	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C5 1 Restyling (04-08)	AUX. HEATING	2.2 HDI 16v 98kw 4HX-FAP	AUTODETECT
 C5 1 Restyling (04-08)	AUX. HEATING	3.0 V6 24v 152kw XFU	AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY	Body Computer BSI AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY	Body Computer BSM AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY	Body Computer BSR AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY	DELPHI Body Computer BSM
 C5 1 Restyling (04-08)	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY	JCAE Body Computer BSI
 C5 1 Restyling (04-08)	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSI AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSM AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSR AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	DELPHI Body Computer BSM
 C5 1 Restyling (04-08)	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	JCAE Body Computer BSI
 C5 1 Restyling (04-08)	CHASSIS NETWORK	1.8 16v 86kw 6FZ	Body Computer BSI AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	1.8 16v 86kw 6FZ	Body Computer BSM AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	1.8 16v 86kw 6FZ	Body Computer BSR AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	1.8 16v 86kw 6FZ	DELPHI Body Computer BSM
 C5 1 Restyling (04-08)	CHASSIS NETWORK	1.8 16v 86kw 6FZ	JCAE Body Computer BSI
 C5 1 Restyling (04-08)	CHASSIS NETWORK	1.8 16v 92kw 6FY	Body Computer BSI AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	1.8 16v 92kw 6FY	Body Computer BSM AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	1.8 16v 92kw 6FY	Body Computer BSR AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	1.8 16v 92kw 6FY	DELPHI Body Computer BSM
 C5 1 Restyling (04-08)	CHASSIS NETWORK	1.8 16v 92kw 6FY	JCAE Body Computer BSI
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.0 16v 103kw RFJ	Body Computer BSI AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.0 16v 103kw RFJ	Body Computer BSM AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.0 16v 103kw RFJ	Body Computer BSR AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.0 16v 103kw RFJ	DELPHI Body Computer BSM
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.0 16v 103kw RFJ	JCAE Body Computer BSI
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	Body Computer BSI AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	Body Computer BSM AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	Body Computer BSR AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	DELPHI Body Computer BSM
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	JCAE Body Computer BSI
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.0 HDI 16v 103kw RHF	Body Computer BSI AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.0 HDI 16v 103kw RHF	Body Computer BSM AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.0 HDI 16v 103kw RHF	Body Computer BSR AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.0 HDI 16v 103kw RHF	DELPHI Body Computer BSM
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.0 HDI 16v 103kw RHF	JCAE Body Computer BSI
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.0 HDI 16v 93kw RHL-FAP	Body Computer BSI AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.0 HDI 16v 93kw RHL-FAP	Body Computer BSM AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.0 HDI 16v 93kw RHL-FAP	Body Computer BSR AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.0 HDI 16v 93kw RHL-FAP	DELPHI Body Computer BSM
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.0 HDI 16v 93kw RHL-FAP	JCAE Body Computer BSI
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP-FAP	Body Computer BSI AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP-FAP	Body Computer BSM AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP-FAP	Body Computer BSR AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP-FAP	DELPHI Body Computer BSM
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP-FAP	JCAE Body Computer BSI
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HR-FAP	Body Computer BSI AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HR-FAP	Body Computer BSM AUTODETECT

Systems supported by ECUREADER / ECUDECODER (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HR-FAP	Body Computer BSR AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HR-FAP	DELPHI Body Computer BSM
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HR-FAP	JCAE Body Computer BSI
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HS-FAP	Body Computer BSI AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HS-FAP	Body Computer BSM AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HS-FAP	Body Computer BSR AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HS-FAP	DELPHI Body Computer BSM
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HS-FAP	JCAE Body Computer BSI
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP	Body Computer BSI AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP	Body Computer BSM AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP	Body Computer BSR AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP	DELPHI Body Computer BSM
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP	JCAE Body Computer BSI
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.2 HDI 16v 98kw 4HX-FAP	Body Computer BSI AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.2 HDI 16v 98kw 4HX-FAP	Body Computer BSM AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.2 HDI 16v 98kw 4HX-FAP	Body Computer BSR AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.2 HDI 16v 98kw 4HX-FAP	DELPHI Body Computer BSM
 C5 1 Restyling (04-08)	CHASSIS NETWORK	2.2 HDI 16v 98kw 4HX-FAP	JCAE Body Computer BSI
 C5 1 Restyling (04-08)	CHASSIS NETWORK	3.0 V6 24v 152kw XFU	Body Computer BSI AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	3.0 V6 24v 152kw XFU	Body Computer BSM AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	3.0 V6 24v 152kw XFU	Body Computer BSR AUTODETECT
 C5 1 Restyling (04-08)	CHASSIS NETWORK	3.0 V6 24v 152kw XFU	DELPHI Body Computer BSM
 C5 1 Restyling (04-08)	CHASSIS NETWORK	3.0 V6 24v 152kw XFU	JCAE Body Computer BSI
 C5 1 Restyling (04-08)	CLIMA	1.6 HDI 16v 80kw 9HY	CLIMA AUTODETECT
 C5 1 Restyling (04-08)	CLIMA	1.6 HDI 16v 80kw 9HY	VISTEON SAC Monozone
 C5 1 Restyling (04-08)	CLIMA	1.6 HDI 16v 80kw 9HZ-FAP	CLIMA AUTODETECT
 C5 1 Restyling (04-08)	CLIMA	1.6 HDI 16v 80kw 9HZ-FAP	VISTEON SAC Monozone
 C5 1 Restyling (04-08)	CLIMA	1.8 16v 86kw 6FZ	CLIMA AUTODETECT
 C5 1 Restyling (04-08)	CLIMA	1.8 16v 86kw 6FZ	VISTEON SAC Monozone
 C5 1 Restyling (04-08)	CLIMA	1.8 16v 92kw 6FY	CLIMA AUTODETECT
 C5 1 Restyling (04-08)	CLIMA	1.8 16v 92kw 6FY	VISTEON SAC Monozone
 C5 1 Restyling (04-08)	CLIMA	2.0 16v 103kw RFJ	CLIMA AUTODETECT
 C5 1 Restyling (04-08)	CLIMA	2.0 16v 103kw RFJ	VISTEON SAC Monozone
 C5 1 Restyling (04-08)	CLIMA	2.0 HDI 16v 100kw RHR-FAP	CLIMA AUTODETECT
 C5 1 Restyling (04-08)	CLIMA	2.0 HDI 16v 100kw RHR-FAP	VISTEON SAC Monozone
 C5 1 Restyling (04-08)	CLIMA	2.0 HDI 16v 103kw RHF	CLIMA AUTODETECT
 C5 1 Restyling (04-08)	CLIMA	2.0 HDI 16v 103kw RHF	VISTEON SAC Monozone
 C5 1 Restyling (04-08)	CLIMA	2.0 HDI 16v 93kw RHL-FAP	CLIMA AUTODETECT
 C5 1 Restyling (04-08)	CLIMA	2.0 HDI 16v 93kw RHL-FAP	VISTEON SAC Monozone
 C5 1 Restyling (04-08)	CLIMA	2.2 HDI 16v 120kw 4HP-FAP	CLIMA AUTODETECT
 C5 1 Restyling (04-08)	CLIMA	2.2 HDI 16v 120kw 4HP-FAP	VISTEON SAC Monozone
 C5 1 Restyling (04-08)	CLIMA	2.2 HDI 16v 120kw 4HR-FAP	CLIMA AUTODETECT
 C5 1 Restyling (04-08)	CLIMA	2.2 HDI 16v 120kw 4HR-FAP	VISTEON SAC Monozone
 C5 1 Restyling (04-08)	CLIMA	2.2 HDI 16v 125kw 4HS-FAP	CLIMA AUTODETECT
 C5 1 Restyling (04-08)	CLIMA	2.2 HDI 16v 125kw 4HS-FAP	VISTEON SAC Monozone
 C5 1 Restyling (04-08)	CLIMA	2.2 HDI 16v 125kw 4HT-FAP	CLIMA AUTODETECT
 C5 1 Restyling (04-08)	CLIMA	2.2 HDI 16v 125kw 4HT-FAP	VISTEON SAC Monozone
 C5 1 Restyling (04-08)	CLIMA	2.2 HDI 16v 98kw 4HX-FAP	CLIMA AUTODETECT
 C5 1 Restyling (04-08)	CLIMA	3.0 V6 24v 152kw XFU	CLIMA AUTODETECT
 C5 1 Restyling (04-08)	CLIMA	3.0 V6 24v 152kw XFU	VISTEON SAC Monozone
 C5 1 Restyling (04-08)	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C5 1 Restyling (04-08)	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C5 1 Restyling (04-08)	COMFORT SYSTEM	1.8 16v 86kw 6FZ	AUTODETECT
 C5 1 Restyling (04-08)	COMFORT SYSTEM	1.8 16v 92kw 6FY	AUTODETECT
 C5 1 Restyling (04-08)	COMFORT SYSTEM	2.0 16v 103kw RFJ	AUTODETECT
 C5 1 Restyling (04-08)	COMFORT SYSTEM	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C5 1 Restyling (04-08)	COMFORT SYSTEM	2.0 HDI 16v 103kw RHF	AUTODETECT
 C5 1 Restyling (04-08)	COMFORT SYSTEM	2.0 HDI 16v 93kw RHL-FAP	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C5 1 Restyling (04-08)	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C5 1 Restyling (04-08)	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C5 1 Restyling (04-08)	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C5 1 Restyling (04-08)	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C5 1 Restyling (04-08)	COMFORT SYSTEM	2.2 HDI 16v 98kw 4HX-FAP	AUTODETECT
 C5 1 Restyling (04-08)	COMFORT SYSTEM	3.0 V6 24v 152kw XFU	AUTODETECT
 C5 1 Restyling (04-08)	CONV. TOP/SUNROO	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C5 1 Restyling (04-08)	CONV. TOP/SUNROO	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C5 1 Restyling (04-08)	CONV. TOP/SUNROO	1.8 16v 86kw 6FZ	AUTODETECT
 C5 1 Restyling (04-08)	CONV. TOP/SUNROO	1.8 16v 92kw 6FY	AUTODETECT
 C5 1 Restyling (04-08)	CONV. TOP/SUNROO	2.0 16v 103kw RFJ	AUTODETECT
 C5 1 Restyling (04-08)	CONV. TOP/SUNROO	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C5 1 Restyling (04-08)	CONV. TOP/SUNROO	2.0 HDI 16v 103kw RHF	AUTODETECT
 C5 1 Restyling (04-08)	CONV. TOP/SUNROO	2.0 HDI 16v 93kw RHL-FAP	AUTODETECT
 C5 1 Restyling (04-08)	CONV. TOP/SUNROO	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C5 1 Restyling (04-08)	CONV. TOP/SUNROO	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C5 1 Restyling (04-08)	CONV. TOP/SUNROO	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C5 1 Restyling (04-08)	CONV. TOP/SUNROO	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C5 1 Restyling (04-08)	CONV. TOP/SUNROO	2.2 HDI 16v 98kw 4HX-FAP	AUTODETECT
 C5 1 Restyling (04-08)	CONV. TOP/SUNROO	3.0 V6 24v 152kw XFU	AUTODETECT
 C5 1 Restyling (04-08)	DASHBOARD	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C5 1 Restyling (04-08)	DASHBOARD	1.6 HDI 16v 80kw 9HY	Marelli IPC 03.00
 C5 1 Restyling (04-08)	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C5 1 Restyling (04-08)	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP	Marelli IPC 03.00
 C5 1 Restyling (04-08)	DASHBOARD	1.8 16v 86kw 6FZ	AUTODETECT
 C5 1 Restyling (04-08)	DASHBOARD	1.8 16v 86kw 6FZ	Marelli IPC 03.00
 C5 1 Restyling (04-08)	DASHBOARD	1.8 16v 92kw 6FY	AUTODETECT
 C5 1 Restyling (04-08)	DASHBOARD	1.8 16v 92kw 6FY	Marelli IPC 03.00
 C5 1 Restyling (04-08)	DASHBOARD	2.0 16v 103kw RFJ	AUTODETECT
 C5 1 Restyling (04-08)	DASHBOARD	2.0 16v 103kw RFJ	Marelli IPC 03.00
 C5 1 Restyling (04-08)	DASHBOARD	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C5 1 Restyling (04-08)	DASHBOARD	2.0 HDI 16v 100kw RHR-FAP	Marelli IPC 03.00
 C5 1 Restyling (04-08)	DASHBOARD	2.0 HDI 16v 103kw RHF	AUTODETECT
 C5 1 Restyling (04-08)	DASHBOARD	2.0 HDI 16v 103kw RHF	Marelli IPC 03.00
 C5 1 Restyling (04-08)	DASHBOARD	2.0 HDI 16v 93kw RHL-FAP	AUTODETECT
 C5 1 Restyling (04-08)	DASHBOARD	2.0 HDI 16v 93kw RHL-FAP	Marelli IPC 03.00
 C5 1 Restyling (04-08)	DASHBOARD	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C5 1 Restyling (04-08)	DASHBOARD	2.2 HDI 16v 120kw 4HP-FAP	Marelli IPC 03.00
 C5 1 Restyling (04-08)	DASHBOARD	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C5 1 Restyling (04-08)	DASHBOARD	2.2 HDI 16v 120kw 4HR-FAP	Marelli IPC 03.00
 C5 1 Restyling (04-08)	DASHBOARD	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C5 1 Restyling (04-08)	DASHBOARD	2.2 HDI 16v 125kw 4HS-FAP	Marelli IPC 03.00
 C5 1 Restyling (04-08)	DASHBOARD	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C5 1 Restyling (04-08)	DASHBOARD	2.2 HDI 16v 125kw 4HT-FAP	Marelli IPC 03.00
 C5 1 Restyling (04-08)	DASHBOARD	2.2 HDI 16v 98kw 4HX-FAP	AUTODETECT
 C5 1 Restyling (04-08)	DASHBOARD	2.2 HDI 16v 98kw 4HX-FAP	Marelli IPC 03.00
 C5 1 Restyling (04-08)	DASHBOARD	3.0 V6 24v 152kw XFU	AUTODETECT
 C5 1 Restyling (04-08)	DASHBOARD	3.0 V6 24v 152kw XFU	Marelli IPC 03.00
 C5 1 Restyling (04-08)	DIESEL ADDITION	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C5 1 Restyling (04-08)	DIESEL ADDITION	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C5 1 Restyling (04-08)	DIESEL ADDITION	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C5 1 Restyling (04-08)	DIESEL ADDITION	2.0 HDI 16v 93kw RHL-FAP	AUTODETECT
 C5 1 Restyling (04-08)	DIESEL ADDITION	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C5 1 Restyling (04-08)	DIESEL ADDITION	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C5 1 Restyling (04-08)	DIESEL ADDITION	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C5 1 Restyling (04-08)	DIESEL ADDITION	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C5 1 Restyling (04-08)	DIESEL ADDITION	2.2 HDI 16v 98kw 4HX-FAP	AUTODETECT
 C5 1 Restyling (04-08)	DIGITAL RADIO TUNE	1.6 HDI 16v 80kw 9HY	BLAUPUNKT Audio System 18.10

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C5 1 Restyling (04-08)	DIGITAL RADIO TUNE	1.6 HDI 16v 80kw 9HZ-FAP	BLAUPUNKT Audio System 18.10
 C5 1 Restyling (04-08)	DIGITAL RADIO TUNE	1.8 16v 86kw 6FZ	BLAUPUNKT Audio System 18.10
 C5 1 Restyling (04-08)	DIGITAL RADIO TUNE	1.8 16v 92kw 6FY	BLAUPUNKT Audio System 18.10
 C5 1 Restyling (04-08)	DIGITAL RADIO TUNE	2.0 16v 103kw RFJ	BLAUPUNKT Audio System 18.10
 C5 1 Restyling (04-08)	DIGITAL RADIO TUNE	2.0 HDI 16v 100kw RHR-FAP	BLAUPUNKT Audio System 18.10
 C5 1 Restyling (04-08)	DIGITAL RADIO TUNE	2.0 HDI 16v 103kw RHF	BLAUPUNKT Audio System 18.10
 C5 1 Restyling (04-08)	DIGITAL RADIO TUNE	2.0 HDI 16v 93kw RHL-FAP	BLAUPUNKT Audio System 18.10
 C5 1 Restyling (04-08)	DIGITAL RADIO TUNE	2.2 HDI 16v 120kw 4HP-FAP	BLAUPUNKT Audio System 18.10
 C5 1 Restyling (04-08)	DIGITAL RADIO TUNE	2.2 HDI 16v 120kw 4HR-FAP	BLAUPUNKT Audio System 18.10
 C5 1 Restyling (04-08)	DIGITAL RADIO TUNE	2.2 HDI 16v 125kw 4HS-FAP	BLAUPUNKT Audio System 18.10
 C5 1 Restyling (04-08)	DIGITAL RADIO TUNE	2.2 HDI 16v 125kw 4HT-FAP	BLAUPUNKT Audio System 18.10
 C5 1 Restyling (04-08)	DIGITAL RADIO TUNE	2.2 HDI 16v 98kw 4HX-FAP	BLAUPUNKT Audio System 18.10
 C5 1 Restyling (04-08)	DIGITAL RADIO TUNE	3.0 V6 24v 152kw XFU	BLAUPUNKT Audio System 18.10
 C5 1 Restyling (04-08)	DRIVER SIDE DOOR	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C5 1 Restyling (04-08)	DRIVER SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C5 1 Restyling (04-08)	DRIVER SIDE DOOR	1.8 16v 86kw 6FZ	AUTODETECT
 C5 1 Restyling (04-08)	DRIVER SIDE DOOR	1.8 16v 92kw 6FY	AUTODETECT
 C5 1 Restyling (04-08)	DRIVER SIDE DOOR	2.0 16v 103kw RFJ	AUTODETECT
 C5 1 Restyling (04-08)	DRIVER SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C5 1 Restyling (04-08)	DRIVER SIDE DOOR	2.0 HDI 16v 103kw RHF	AUTODETECT
 C5 1 Restyling (04-08)	DRIVER SIDE DOOR	2.0 HDI 16v 93kw RHL-FAP	AUTODETECT
 C5 1 Restyling (04-08)	DRIVER SIDE DOOR	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C5 1 Restyling (04-08)	DRIVER SIDE DOOR	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C5 1 Restyling (04-08)	DRIVER SIDE DOOR	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C5 1 Restyling (04-08)	DRIVER SIDE DOOR	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C5 1 Restyling (04-08)	DRIVER SIDE DOOR	2.2 HDI 16v 98kw 4HX-FAP	AUTODETECT
 C5 1 Restyling (04-08)	DRIVER SIDE DOOR	3.0 V6 24v 152kw XFU	AUTODETECT
 C5 1 Restyling (04-08)	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C5 1 Restyling (04-08)	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C5 1 Restyling (04-08)	ELECTRIC STEERING	1.8 16v 86kw 6FZ	AUTODETECT
 C5 1 Restyling (04-08)	ELECTRIC STEERING	1.8 16v 92kw 6FY	AUTODETECT
 C5 1 Restyling (04-08)	ELECTRIC STEERING	2.0 16v 103kw RFJ	AUTODETECT
 C5 1 Restyling (04-08)	ELECTRIC STEERING	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C5 1 Restyling (04-08)	ELECTRIC STEERING	2.0 HDI 16v 103kw RHF	AUTODETECT
 C5 1 Restyling (04-08)	ELECTRIC STEERING	2.0 HDI 16v 93kw RHL-FAP	AUTODETECT
 C5 1 Restyling (04-08)	ELECTRIC STEERING	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C5 1 Restyling (04-08)	ELECTRIC STEERING	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C5 1 Restyling (04-08)	ELECTRIC STEERING	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C5 1 Restyling (04-08)	ELECTRIC STEERING	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C5 1 Restyling (04-08)	ELECTRIC STEERING	2.2 HDI 16v 98kw 4HX-FAP	AUTODETECT
 C5 1 Restyling (04-08)	ELECTRIC STEERING	3.0 V6 24v 152kw XFU	AUTODETECT
 C5 1 Restyling (04-08)	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HY	BOSCH EDC16 C34 Common Rail AUTOD
 C5 1 Restyling (04-08)	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 C5 1 Restyling (04-08)	ENGINE MANAGEME	1.8 16v 86kw 6FZ	SAGEM S2000 AUTODETECT
 C5 1 Restyling (04-08)	ENGINE MANAGEME	1.8 16v 92kw 6FY	Marelli MM6LP AUTODETECT
 C5 1 Restyling (04-08)	ENGINE MANAGEME	1.8 16v 92kw 6FY	Marelli MPI MM6LPB
 C5 1 Restyling (04-08)	ENGINE MANAGEME	2.0 16v 103kw RFJ	Marelli MM6LP AUTODETECT
 C5 1 Restyling (04-08)	ENGINE MANAGEME	2.0 16v 103kw RFJ	Marelli MPI MM6LPB
 C5 1 Restyling (04-08)	ENGINE MANAGEME	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803 Common Rail AUTODE
 C5 1 Restyling (04-08)	ENGINE MANAGEME	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803 Common Rail AUTODE
 C5 1 Restyling (04-08)	ENGINE MANAGEME	2.0 HDI 16v 103kw RHF	EOBD
 C5 1 Restyling (04-08)	ENGINE MANAGEME	2.0 HDI 16v 93kw RHL-FAP	SIEMENS SID 803 Common Rail AUTODE
 C5 1 Restyling (04-08)	ENGINE MANAGEME	2.0 HDI 16v 93kw RHL-FAP	SIEMENS SID 803 Common Rail AUTODE
 C5 1 Restyling (04-08)	ENGINE MANAGEME	2.2 HDI 16v 120kw 4HP-FAP	BOSCH EDC16 CP39 Common Rail AUTO
 C5 1 Restyling (04-08)	ENGINE MANAGEME	2.2 HDI 16v 120kw 4HR-FAP	DIESEL AUTODETECT
 C5 1 Restyling (04-08)	ENGINE MANAGEME	2.2 HDI 16v 125kw 4HS-FAP	DIESEL AUTODETECT
 C5 1 Restyling (04-08)	ENGINE MANAGEME	2.2 HDI 16v 125kw 4HT-FAP	DIESEL AUTODETECT
 C5 1 Restyling (04-08)	ENGINE MANAGEME	2.2 HDI 16v 98kw 4HX-FAP	BOSCH EDC15 C2 Common Rail AUTODE

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C5 1 Restyling (04-08)	ENGINE MANAGEME	3.0 V6 24v 152kw XFU	BOSCH ME 7.4.7 AUTODETECT
 C5 1 Restyling (04-08)	LANE CHANGE ASSY	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C5 1 Restyling (04-08)	LANE CHANGE ASSY	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C5 1 Restyling (04-08)	LANE CHANGE ASSY	1.8 16v 86kw 6FZ	AUTODETECT
 C5 1 Restyling (04-08)	LANE CHANGE ASSY	1.8 16v 92kw 6FY	AUTODETECT
 C5 1 Restyling (04-08)	LANE CHANGE ASSY	2.0 16v 103kw RFJ	AUTODETECT
 C5 1 Restyling (04-08)	LANE CHANGE ASSY	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C5 1 Restyling (04-08)	LANE CHANGE ASSY	2.0 HDI 16v 103kw RHF	AUTODETECT
 C5 1 Restyling (04-08)	LANE CHANGE ASSY	2.0 HDI 16v 93kw RHL-FAP	AUTODETECT
 C5 1 Restyling (04-08)	LANE CHANGE ASSY	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C5 1 Restyling (04-08)	LANE CHANGE ASSY	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C5 1 Restyling (04-08)	LANE CHANGE ASSY	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C5 1 Restyling (04-08)	LANE CHANGE ASSY	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C5 1 Restyling (04-08)	LANE CHANGE ASSY	2.2 HDI 16v 98kw 4HX-FAP	AUTODETECT
 C5 1 Restyling (04-08)	LANE CHANGE ASSY	3.0 V6 24v 152kw XFU	AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HY	A/T AL4 AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HY	A/T AM6 AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HY	A/T AM6 AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HY	AirBag CENTRAL AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HY	AirBag CENTRAL AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC16 C34 Common Rail AUTOD
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC16 C34 Common Rail AUTOD
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC16 C34 Common Rail AUTOD
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC16 C34 Common Rail AUTOD
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC16 C34 Common Rail AUTOD
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC16 C34 Common Rail AUTOD
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC16 C34 Common Rail AUTOD
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HY	ESP MK60 AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HY	ESP MK60 AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Siemens-JCAE AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Siemens-JCAE AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Siemens-JCAE AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Siemens-JCAE AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	A/T AL4 AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	A/T AM6 AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	A/T AM6 AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	ESP MK60 AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	ESP MK60 AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Siemens-JCAE AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Siemens-JCAE AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Siemens-JCAE AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Siemens-JCAE AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	1.8 16v 86kw 6FZ	A/T AL4 AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	1.8 16v 86kw 6FZ	A/T AM6 AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	1.8 16v 86kw 6FZ	A/T AM6 AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	1.8 16v 86kw 6FZ	AirBag CENTRAL AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	1.8 16v 86kw 6FZ	AirBag CENTRAL AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	1.8 16v 86kw 6FZ	ESP MK60 AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	1.8 16v 86kw 6FZ	ESP MK60 AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	1.8 16v 86kw 6FZ	Siemens-JCAE AUTODETECT
C5 1 Restyling (04-08)	MAINTENANCE	1.8 16v 86kw 6FZ	Siemens-JCAE AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

[illegible]

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

[illegible]

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C5 1 Restyling (04-08)	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	Siemens-JCAE AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	A/T AL4 AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	A/T AM6 AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	A/T AM6 AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	AirBag CENTRAL AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	AirBag CENTRAL AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	BOSCH EDC15 C2 Common Rail AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	ESP MK60 AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	ESP MK60 AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	Siemens-JCAE AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	Siemens-JCAE AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	Siemens-JCAE AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	Siemens-JCAE AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	3.0 V6 24v 152kw XFU	A/T AL4 AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	3.0 V6 24v 152kw XFU	A/T AM6 AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	3.0 V6 24v 152kw XFU	A/T AM6 AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	3.0 V6 24v 152kw XFU	AirBag CENTRAL AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	3.0 V6 24v 152kw XFU	AirBag CENTRAL AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	3.0 V6 24v 152kw XFU	ESP MK60 AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	3.0 V6 24v 152kw XFU	ESP MK60 AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	3.0 V6 24v 152kw XFU	Siemens-JCAE AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	3.0 V6 24v 152kw XFU	Siemens-JCAE AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	3.0 V6 24v 152kw XFU	Siemens-JCAE AUTODETECT
 C5 1 Restyling (04-08)	MAINTENANCE	3.0 V6 24v 152kw XFU	Siemens-JCAE AUTODETECT
 C5 1 Restyling (04-08)	NAVIGATION	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C5 1 Restyling (04-08)	NAVIGATION	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C5 1 Restyling (04-08)	NAVIGATION	1.8 16v 86kw 6FZ	AUTODETECT
 C5 1 Restyling (04-08)	NAVIGATION	1.8 16v 92kw 6FY	AUTODETECT
 C5 1 Restyling (04-08)	NAVIGATION	2.0 16v 103kw RFJ	AUTODETECT
 C5 1 Restyling (04-08)	NAVIGATION	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C5 1 Restyling (04-08)	NAVIGATION	2.0 HDI 16v 103kw RHF	AUTODETECT
 C5 1 Restyling (04-08)	NAVIGATION	2.0 HDI 16v 93kw RHL-FAP	AUTODETECT
 C5 1 Restyling (04-08)	NAVIGATION	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C5 1 Restyling (04-08)	NAVIGATION	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C5 1 Restyling (04-08)	NAVIGATION	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C5 1 Restyling (04-08)	NAVIGATION	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C5 1 Restyling (04-08)	NAVIGATION	2.2 HDI 16v 98kw 4HX-FAP	AUTODETECT
 C5 1 Restyling (04-08)	NAVIGATION	3.0 V6 24v 152kw XFU	AUTODETECT
 C5 1 Restyling (04-08)	PARKING HELP	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C5 1 Restyling (04-08)	PARKING HELP	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C5 1 Restyling (04-08)	PARKING HELP	1.8 16v 86kw 6FZ	AUTODETECT
 C5 1 Restyling (04-08)	PARKING HELP	1.8 16v 92kw 6FY	AUTODETECT
 C5 1 Restyling (04-08)	PARKING HELP	2.0 16v 103kw RFJ	AUTODETECT
 C5 1 Restyling (04-08)	PARKING HELP	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C5 1 Restyling (04-08)	PARKING HELP	2.0 HDI 16v 103kw RHF	AUTODETECT
 C5 1 Restyling (04-08)	PARKING HELP	2.0 HDI 16v 93kw RHL-FAP	AUTODETECT
 C5 1 Restyling (04-08)	PARKING HELP	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C5 1 Restyling (04-08)	PARKING HELP	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C5 1 Restyling (04-08)	PARKING HELP	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C5 1 Restyling (04-08)	PARKING HELP	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C5 1 Restyling (04-08)	PARKING HELP	2.2 HDI 16v 98kw 4HX-FAP	AUTODETECT
 C5 1 Restyling (04-08)	PASS. SIDE DOOR	3.0 V6 24v 152kw XFU	AUTODETECT
 C5 1 Restyling (04-08)	PASS. SIDE DOOR	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C5 1 Restyling (04-08)	PASS. SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C5 1 Restyling (04-08)	PASS. SIDE DOOR	1.8 16v 86kw 6FZ	AUTODETECT
 C5 1 Restyling (04-08)	PASS. SIDE DOOR	1.8 16v 92kw 6FY	AUTODETECT
 C5 1 Restyling (04-08)	PASS. SIDE DOOR	2.0 16v 103kw RFJ	AUTODETECT
 C5 1 Restyling (04-08)	PASS. SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C5 1 Restyling (04-08)	PASS. SIDE DOOR	2.0 HDI 16v 103kw RHF	AUTODETECT
 C5 1 Restyling (04-08)	PASS. SIDE DOOR	2.0 HDI 16v 93kw RHL-FAP	AUTODETECT
 C5 1 Restyling (04-08)	PASS. SIDE DOOR	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C5 1 Restyling (04-08)	PASS. SIDE DOOR	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C5 1 Restyling (04-08)	PASS. SIDE DOOR	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C5 1 Restyling (04-08)	PASS. SIDE DOOR	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C5 1 Restyling (04-08)	PASS. SIDE DOOR	2.2 HDI 16v 98kw 4HX-FAP	AUTODETECT
 C5 1 Restyling (04-08)	PASS. SIDE DOOR	3.0 V6 24v 152kw XFU	AUTODETECT
 C5 1 Restyling (04-08)	PHONE	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C5 1 Restyling (04-08)	PHONE	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C5 1 Restyling (04-08)	PHONE	1.8 16v 86kw 6FZ	AUTODETECT
 C5 1 Restyling (04-08)	PHONE	1.8 16v 92kw 6FY	AUTODETECT
 C5 1 Restyling (04-08)	PHONE	2.0 16v 103kw RFJ	AUTODETECT
 C5 1 Restyling (04-08)	PHONE	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C5 1 Restyling (04-08)	PHONE	2.0 HDI 16v 103kw RHF	AUTODETECT
 C5 1 Restyling (04-08)	PHONE	2.0 HDI 16v 93kw RHL-FAP	AUTODETECT
 C5 1 Restyling (04-08)	PHONE	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C5 1 Restyling (04-08)	PHONE	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C5 1 Restyling (04-08)	PHONE	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C5 1 Restyling (04-08)	PHONE	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C5 1 Restyling (04-08)	PHONE	2.2 HDI 16v 98kw 4HX-FAP	AUTODETECT
 C5 1 Restyling (04-08)	PHONE	3.0 V6 24v 152kw XFU	AUTODETECT
 C5 1 Restyling (04-08)	RADIO / CD	1.6 HDI 16v 80kw 9HY	AudioSystem AUTODETECT
 C5 1 Restyling (04-08)	RADIO / CD	1.6 HDI 16v 80kw 9HY	CD Changer AUTODETECT
 C5 1 Restyling (04-08)	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	AudioSystem AUTODETECT
 C5 1 Restyling (04-08)	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	CD Changer AUTODETECT
 C5 1 Restyling (04-08)	RADIO / CD	1.8 16v 86kw 6FZ	AudioSystem AUTODETECT
 C5 1 Restyling (04-08)	RADIO / CD	1.8 16v 86kw 6FZ	CD Changer AUTODETECT
 C5 1 Restyling (04-08)	RADIO / CD	1.8 16v 92kw 6FY	AudioSystem AUTODETECT
 C5 1 Restyling (04-08)	RADIO / CD	1.8 16v 92kw 6FY	CD Changer AUTODETECT
 C5 1 Restyling (04-08)	RADIO / CD	2.0 16v 103kw RFJ	AudioSystem AUTODETECT
 C5 1 Restyling (04-08)	RADIO / CD	2.0 16v 103kw RFJ	CD Changer AUTODETECT
 C5 1 Restyling (04-08)	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP	AudioSystem AUTODETECT
 C5 1 Restyling (04-08)	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP	CD Changer AUTODETECT
 C5 1 Restyling (04-08)	RADIO / CD	2.0 HDI 16v 103kw RHF	AudioSystem AUTODETECT
 C5 1 Restyling (04-08)	RADIO / CD	2.0 HDI 16v 103kw RHF	CD Changer AUTODETECT
 C5 1 Restyling (04-08)	RADIO / CD	2.0 HDI 16v 93kw RHL-FAP	AudioSystem AUTODETECT
 C5 1 Restyling (04-08)	RADIO / CD	2.0 HDI 16v 93kw RHL-FAP	CD Changer AUTODETECT
 C5 1 Restyling (04-08)	RADIO / CD	2.2 HDI 16v 120kw 4HP-FAP	AudioSystem AUTODETECT
 C5 1 Restyling (04-08)	RADIO / CD	2.2 HDI 16v 120kw 4HP-FAP	CD Changer AUTODETECT
 C5 1 Restyling (04-08)	RADIO / CD	2.2 HDI 16v 120kw 4HR-FAP	AudioSystem AUTODETECT
 C5 1 Restyling (04-08)	RADIO / CD	2.2 HDI 16v 120kw 4HR-FAP	CD Changer AUTODETECT
 C5 1 Restyling (04-08)	RADIO / CD	2.2 HDI 16v 125kw 4HS-FAP	AudioSystem AUTODETECT
 C5 1 Restyling (04-08)	RADIO / CD	2.2 HDI 16v 125kw 4HS-FAP	CD Changer AUTODETECT
 C5 1 Restyling (04-08)	RADIO / CD	2.2 HDI 16v 125kw 4HT-FAP	AudioSystem AUTODETECT
 C5 1 Restyling (04-08)	RADIO / CD	2.2 HDI 16v 125kw 4HT-FAP	CD Changer AUTODETECT
 C5 1 Restyling (04-08)	RADIO / CD	2.2 HDI 16v 98kw 4HX-FAP	AudioSystem AUTODETECT
 C5 1 Restyling (04-08)	RADIO / CD	2.2 HDI 16v 98kw 4HX-FAP	CD Changer AUTODETECT
 C5 1 Restyling (04-08)	RADIO / CD	3.0 V6 24v 152kw XFU	AudioSystem AUTODETECT
 C5 1 Restyling (04-08)	RADIO / CD	3.0 V6 24v 152kw XFU	CD Changer AUTODETECT
 C5 1 Restyling (04-08)	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C5 1 Restyling (04-08)	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HY	BOSCH WSS
 C5 1 Restyling (04-08)	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C5 1 Restyling (04-08)	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH WSS
 C5 1 Restyling (04-08)	RAIN-LUMINOSITY S	1.8 16v 86kw 6FZ	AUTODETECT
 C5 1 Restyling (04-08)	RAIN-LUMINOSITY S	1.8 16v 86kw 6FZ	BOSCH WSS
 C5 1 Restyling (04-08)	RAIN-LUMINOSITY S	1.8 16v 92kw 6FY	AUTODETECT
 C5 1 Restyling (04-08)	RAIN-LUMINOSITY S	1.8 16v 92kw 6FY	BOSCH WSS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C5 1 Restyling (04-08)	RAIN-LUMINOSITY S	2.0 16v 103kw RFJ	AUTODETECT
 C5 1 Restyling (04-08)	RAIN-LUMINOSITY S	2.0 16v 103kw RFJ	BOSCH WSS
 C5 1 Restyling (04-08)	RAIN-LUMINOSITY S	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C5 1 Restyling (04-08)	RAIN-LUMINOSITY S	2.0 HDI 16v 100kw RHR-FAP	BOSCH WSS
 C5 1 Restyling (04-08)	RAIN-LUMINOSITY S	2.0 HDI 16v 103kw RHF	AUTODETECT
 C5 1 Restyling (04-08)	RAIN-LUMINOSITY S	2.0 HDI 16v 103kw RHF	BOSCH WSS
 C5 1 Restyling (04-08)	RAIN-LUMINOSITY S	2.0 HDI 16v 93kw RHL-FAP	AUTODETECT
 C5 1 Restyling (04-08)	RAIN-LUMINOSITY S	2.0 HDI 16v 93kw RHL-FAP	BOSCH WSS
 C5 1 Restyling (04-08)	RAIN-LUMINOSITY S	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C5 1 Restyling (04-08)	RAIN-LUMINOSITY S	2.2 HDI 16v 120kw 4HP-FAP	BOSCH WSS
 C5 1 Restyling (04-08)	RAIN-LUMINOSITY S	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C5 1 Restyling (04-08)	RAIN-LUMINOSITY S	2.2 HDI 16v 120kw 4HR-FAP	BOSCH WSS
 C5 1 Restyling (04-08)	RAIN-LUMINOSITY S	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C5 1 Restyling (04-08)	RAIN-LUMINOSITY S	2.2 HDI 16v 125kw 4HS-FAP	BOSCH WSS
 C5 1 Restyling (04-08)	RAIN-LUMINOSITY S	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C5 1 Restyling (04-08)	RAIN-LUMINOSITY S	2.2 HDI 16v 125kw 4HT-FAP	BOSCH WSS
 C5 1 Restyling (04-08)	RAIN-LUMINOSITY S	2.2 HDI 16v 98kw 4HX-FAP	AUTODETECT
 C5 1 Restyling (04-08)	RAIN-LUMINOSITY S	2.2 HDI 16v 98kw 4HX-FAP	BOSCH WSS
 C5 1 Restyling (04-08)	RAIN-LUMINOSITY S	3.0 V6 24v 152kw XFU	AUTODETECT
 C5 1 Restyling (04-08)	RAIN-LUMINOSITY S	3.0 V6 24v 152kw XFU	BOSCH WSS
 C5 1 Restyling (04-08)	STEERING COLUMN	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C5 1 Restyling (04-08)	STEERING COLUMN	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C5 1 Restyling (04-08)	STEERING COLUMN	1.8 16v 86kw 6FZ	AUTODETECT
 C5 1 Restyling (04-08)	STEERING COLUMN	1.8 16v 92kw 6FY	AUTODETECT
 C5 1 Restyling (04-08)	STEERING COLUMN	2.0 16v 103kw RFJ	AUTODETECT
 C5 1 Restyling (04-08)	STEERING COLUMN	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C5 1 Restyling (04-08)	STEERING COLUMN	2.0 HDI 16v 103kw RHF	AUTODETECT
 C5 1 Restyling (04-08)	STEERING COLUMN	2.0 HDI 16v 93kw RHL-FAP	AUTODETECT
 C5 1 Restyling (04-08)	STEERING COLUMN	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C5 1 Restyling (04-08)	STEERING COLUMN	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C5 1 Restyling (04-08)	STEERING COLUMN	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C5 1 Restyling (04-08)	STEERING COLUMN	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C5 1 Restyling (04-08)	STEERING COLUMN	2.2 HDI 16v 98kw 4HX-FAP	AUTODETECT
 C5 1 Restyling (04-08)	STEERING COLUMN	3.0 V6 24v 152kw XFU	AUTODETECT
 C5 1 Restyling (04-08)	SUSPENSION CONTR	1.6 HDI 16v 80kw 9HY	AUTODETECT
 C5 1 Restyling (04-08)	SUSPENSION CONTR	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C5 1 Restyling (04-08)	SUSPENSION CONTR	1.8 16v 86kw 6FZ	AUTODETECT
 C5 1 Restyling (04-08)	SUSPENSION CONTR	1.8 16v 92kw 6FY	AUTODETECT
 C5 1 Restyling (04-08)	SUSPENSION CONTR	2.0 16v 103kw RFJ	AUTODETECT
 C5 1 Restyling (04-08)	SUSPENSION CONTR	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C5 1 Restyling (04-08)	SUSPENSION CONTR	2.0 HDI 16v 103kw RHF	AUTODETECT
 C5 1 Restyling (04-08)	SUSPENSION CONTR	2.0 HDI 16v 93kw RHL-FAP	AUTODETECT
 C5 1 Restyling (04-08)	SUSPENSION CONTR	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C5 1 Restyling (04-08)	SUSPENSION CONTR	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C5 1 Restyling (04-08)	SUSPENSION CONTR	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C5 1 Restyling (04-08)	SUSPENSION CONTR	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C5 1 Restyling (04-08)	SUSPENSION CONTR	2.2 HDI 16v 98kw 4HX-FAP	AUTODETECT
 C5 1 Restyling (04-08)	SUSPENSION CONTR	3.0 V6 24v 152kw XFU	AUTODETECT
 C5 1 Restyling (04-08)	TIRE PRESSURE	1.6 HDI 16v 80kw 9HY	Siemens-JCAE AUTODETECT
 C5 1 Restyling (04-08)	TIRE PRESSURE	1.6 HDI 16v 80kw 9HZ-FAP	Siemens-JCAE AUTODETECT
 C5 1 Restyling (04-08)	TIRE PRESSURE	1.8 16v 86kw 6FZ	Siemens-JCAE AUTODETECT
 C5 1 Restyling (04-08)	TIRE PRESSURE	1.8 16v 92kw 6FY	Siemens-JCAE AUTODETECT
 C5 1 Restyling (04-08)	TIRE PRESSURE	2.0 16v 103kw RFJ	Siemens-JCAE AUTODETECT
 C5 1 Restyling (04-08)	TIRE PRESSURE	2.0 HDI 16v 100kw RHR-FAP	Siemens-JCAE AUTODETECT
 C5 1 Restyling (04-08)	TIRE PRESSURE	2.0 HDI 16v 103kw RHF	Siemens-JCAE AUTODETECT
 C5 1 Restyling (04-08)	TIRE PRESSURE	2.0 HDI 16v 93kw RHL-FAP	Siemens-JCAE AUTODETECT
 C5 1 Restyling (04-08)	TIRE PRESSURE	2.2 HDI 16v 120kw 4HP-FAP	Siemens-JCAE AUTODETECT
 C5 1 Restyling (04-08)	TIRE PRESSURE	2.2 HDI 16v 120kw 4HR-FAP	Siemens-JCAE AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C5 1 Restyling (04-08)	TIRE PRESSURE	2.2 HDI 16v 125kw 4HS-FAP	Siemens-JCAE AUTODETECT
 C5 1 Restyling (04-08)	TIRE PRESSURE	2.2 HDI 16v 125kw 4HT-FAP	Siemens-JCAE AUTODETECT
 C5 1 Restyling (04-08)	TIRE PRESSURE	2.2 HDI 16v 98kw 4HX-FAP	Siemens-JCAE AUTODETECT
 C5 1 Restyling (04-08)	TIRE PRESSURE	3.0 V6 24v 152kw XFU	Siemens-JCAE AUTODETECT
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HY	Display A+ AUTODETECT
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HY	Display C- AUTODETECT
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HY	JCAE DIS
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	Display A+ AUTODETECT
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	Display C- AUTODETECT
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	JCAE DIS
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	1.8 16v 86kw 6FZ	Display A+ AUTODETECT
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	1.8 16v 86kw 6FZ	Display C- AUTODETECT
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	1.8 16v 86kw 6FZ	JCAE DIS
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	1.8 16v 92kw 6FY	Display A+ AUTODETECT
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	1.8 16v 92kw 6FY	Display C- AUTODETECT
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	1.8 16v 92kw 6FY	JCAE DIS
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	2.0 16v 103kw RFJ	Display A+ AUTODETECT
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	2.0 16v 103kw RFJ	Display C- AUTODETECT
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	2.0 16v 103kw RFJ	JCAE DIS
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	2.0 HDI 16v 100kw RHR-FAP	Display A+ AUTODETECT
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	2.0 HDI 16v 100kw RHR-FAP	Display C- AUTODETECT
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	2.0 HDI 16v 100kw RHR-FAP	JCAE DIS
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	2.0 HDI 16v 103kw RHF	Display A+ AUTODETECT
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	2.0 HDI 16v 103kw RHF	Display C- AUTODETECT
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	2.0 HDI 16v 103kw RHF	JCAE DIS
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	2.0 HDI 16v 93kw RHL-FAP	Display A+ AUTODETECT
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	2.0 HDI 16v 93kw RHL-FAP	Display C- AUTODETECT
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	2.0 HDI 16v 93kw RHL-FAP	JCAE DIS
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	2.2 HDI 16v 120kw 4HP-FAP	Display A+ AUTODETECT
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	2.2 HDI 16v 120kw 4HP-FAP	Display C- AUTODETECT
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	2.2 HDI 16v 120kw 4HP-FAP	JCAE DIS
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	2.2 HDI 16v 120kw 4HR-FAP	Display A+ AUTODETECT
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	2.2 HDI 16v 120kw 4HR-FAP	Display C- AUTODETECT
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	2.2 HDI 16v 120kw 4HR-FAP	JCAE DIS
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	2.2 HDI 16v 125kw 4HS-FAP	Display A+ AUTODETECT
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	2.2 HDI 16v 125kw 4HS-FAP	Display C- AUTODETECT
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	2.2 HDI 16v 125kw 4HS-FAP	JCAE DIS
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	2.2 HDI 16v 125kw 4HT-FAP	Display A+ AUTODETECT
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	2.2 HDI 16v 125kw 4HT-FAP	Display C- AUTODETECT
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	2.2 HDI 16v 125kw 4HT-FAP	JCAE DIS
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	2.2 HDI 16v 98kw 4HX-FAP	Display A+ AUTODETECT
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	2.2 HDI 16v 98kw 4HX-FAP	Display C- AUTODETECT
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	2.2 HDI 16v 98kw 4HX-FAP	JCAE DIS
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	3.0 V6 24v 152kw XFU	Display A+ AUTODETECT
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	3.0 V6 24v 152kw XFU	Display C- AUTODETECT
 C5 1 Restyling (04-08)	VISUAL./TELEMATIC	3.0 V6 24v 152kw XFU	JCAE DIS
 C5 2 (08-..)	ABS + TRACT. CONT	1.6 16v 110kw 5FN	ESP 8.1 AUTODETECT
 C5 2 (08-..)	ABS + TRACT. CONT	1.6 16v 115kw 5FV	ESP 8.1 AUTODETECT
 C5 2 (08-..)	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	ESP 8.1 AUTODETECT
 C5 2 (08-..)	ABS + TRACT. CONT	1.8 16v 92kw 6FY	ESP 8.1 AUTODETECT
 C5 2 (08-..)	ABS + TRACT. CONT	2.0 16v 103kw RFJ	ESP 8.1 AUTODETECT
 C5 2 (08-..)	ABS + TRACT. CONT	2.0 16v 103kw RFJ - Bio Flex	ESP 8.1 AUTODETECT
 C5 2 (08-..)	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP	ESP 8.1 AUTODETECT
 C5 2 (08-..)	ABS + TRACT. CONT	2.0 HDI 16v 103kw RHF-FAP	ESP 8.1 AUTODETECT
 C5 2 (08-..)	ABS + TRACT. CONT	2.0 HDI 16v 110kw RHE	ESP 8.1 AUTODETECT
 C5 2 (08-..)	ABS + TRACT. CONT	2.0 HDI 16v 120kw RHH	ESP 8.1 AUTODETECT
 C5 2 (08-..)	ABS + TRACT. CONT	2.2 HDI 16v 120kw 4HP-FAP	ESP 8.1 AUTODETECT
 C5 2 (08-..)	ABS + TRACT. CONT	2.2 HDI 16v 120kw 4HR-FAP	ESP 8.1 AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C5 2 (08-..)	ABS + TRACT. CONT	2.2 HDI 16v 120kw 4HS-FAP	ESP 8.1 AUTODETECT
 C5 2 (08-..)	ABS + TRACT. CONT	2.2 HDI 16v 125kw 4HT-FAP	ESP 8.1 AUTODETECT
 C5 2 (08-..)	ABS + TRACT. CONT	2.7 HDI V6 24v 150kw UHZ-FAP	ESP 8.1 AUTODETECT
 C5 2 (08-..)	ABS + TRACT. CONT	3.0 HDI V6 24V 177kw X8Z	ESP 8.1 AUTODETECT
 C5 2 (08-..)	ABS + TRACT. CONT	3.0 V6 16v 155kw XFV	ESP 8.1 AUTODETECT
 C5 2 (08-..)	AIRBAG	1.6 16v 110kw 5FN	AirBag CENTRAL AUTODETECT
 C5 2 (08-..)	AIRBAG	1.6 16v 115kw 5FV	AirBag CENTRAL AUTODETECT
 C5 2 (08-..)	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL AUTODETECT
 C5 2 (08-..)	AIRBAG	1.8 16v 92kw 6FY	AirBag CENTRAL AUTODETECT
 C5 2 (08-..)	AIRBAG	2.0 16v 103kw RFJ	AirBag CENTRAL AUTODETECT
 C5 2 (08-..)	AIRBAG	2.0 16v 103kw RFJ - Bio Flex	AirBag CENTRAL AUTODETECT
 C5 2 (08-..)	AIRBAG	2.0 HDI 16v 100kw RHR-FAP	AirBag CENTRAL AUTODETECT
 C5 2 (08-..)	AIRBAG	2.0 HDI 16v 103kw RHF-FAP	AirBag CENTRAL AUTODETECT
 C5 2 (08-..)	AIRBAG	2.0 HDI 16v 110kw RHE	AirBag CENTRAL AUTODETECT
 C5 2 (08-..)	AIRBAG	2.0 HDI 16v 120kw RHH	AirBag CENTRAL AUTODETECT
 C5 2 (08-..)	AIRBAG	2.2 HDI 16v 120kw 4HP-FAP	AirBag CENTRAL AUTODETECT
 C5 2 (08-..)	AIRBAG	2.2 HDI 16v 120kw 4HR-FAP	AirBag CENTRAL AUTODETECT
 C5 2 (08-..)	AIRBAG	2.2 HDI 16v 120kw 4HS-FAP	AirBag CENTRAL AUTODETECT
 C5 2 (08-..)	AIRBAG	2.2 HDI 16v 125kw 4HT-FAP	AirBag CENTRAL AUTODETECT
 C5 2 (08-..)	AIRBAG	2.7 HDI V6 24v 150kw UHZ-FAP	AirBag CENTRAL AUTODETECT
 C5 2 (08-..)	AIRBAG	3.0 HDI V6 24V 177kw X8Z	AirBag CENTRAL AUTODETECT
 C5 2 (08-..)	AIRBAG	3.0 V6 16v 155kw XFV	AirBag CENTRAL AUTODETECT
 C5 2 (08-..)	ANTITHEFT	1.6 16v 110kw 5FN	Alarm PAS2 AUTODETECT
 C5 2 (08-..)	ANTITHEFT	1.6 16v 115kw 5FV	Alarm PAS2 AUTODETECT
 C5 2 (08-..)	ANTITHEFT	1.6 HDI 16v 80kw 9HZ-FAP	Alarm PAS2 AUTODETECT
 C5 2 (08-..)	ANTITHEFT	1.8 16v 92kw 6FY	Alarm PAS2 AUTODETECT
 C5 2 (08-..)	ANTITHEFT	2.0 16v 103kw RFJ	Alarm PAS2 AUTODETECT
 C5 2 (08-..)	ANTITHEFT	2.0 16v 103kw RFJ - Bio Flex	Alarm PAS2 AUTODETECT
 C5 2 (08-..)	ANTITHEFT	2.0 HDI 16v 100kw RHR-FAP	Alarm PAS2 AUTODETECT
 C5 2 (08-..)	ANTITHEFT	2.0 HDI 16v 103kw RHF-FAP	Alarm PAS2 AUTODETECT
 C5 2 (08-..)	ANTITHEFT	2.0 HDI 16v 110kw RHE	Alarm PAS2 AUTODETECT
 C5 2 (08-..)	ANTITHEFT	2.0 HDI 16v 120kw RHH	Alarm PAS2 AUTODETECT
 C5 2 (08-..)	ANTITHEFT	2.2 HDI 16v 120kw 4HP-FAP	Alarm PAS2 AUTODETECT
 C5 2 (08-..)	ANTITHEFT	2.2 HDI 16v 120kw 4HR-FAP	Alarm PAS2 AUTODETECT
 C5 2 (08-..)	ANTITHEFT	2.2 HDI 16v 120kw 4HS-FAP	Alarm PAS2 AUTODETECT
 C5 2 (08-..)	ANTITHEFT	2.2 HDI 16v 125kw 4HT-FAP	Alarm PAS2 AUTODETECT
 C5 2 (08-..)	ANTITHEFT	2.7 HDI V6 24v 150kw UHZ-FAP	Alarm PAS2 AUTODETECT
 C5 2 (08-..)	ANTITHEFT	3.0 HDI V6 24V 177kw X8Z	Alarm PAS2 AUTODETECT
 C5 2 (08-..)	ANTITHEFT	3.0 V6 16v 155kw XFV	Alarm PAS2 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	1.6 16v 110kw 5FN	A/T AL4 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	1.6 16v 110kw 5FN	A/T AM6 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	1.6 16v 115kw 5FV	A/T AL4 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	1.6 16v 115kw 5FV	A/T AM6 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP	A/T AL4 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP	A/T AM6 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	1.8 16v 92kw 6FY	A/T AL4 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	1.8 16v 92kw 6FY	A/T AM6 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ	A/T AL4 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ	A/T AM6 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ - Bio Flex	A/T AL4 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ - Bio Flex	A/T AM6 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP	A/T AL4 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP	A/T AM6 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	2.0 HDI 16v 103kw RHF-FAP	A/T AL4 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	2.0 HDI 16v 103kw RHF-FAP	A/T AM6 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	2.0 HDI 16v 110kw RHE	A/T AL4 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	2.0 HDI 16v 110kw RHE	A/T AM6 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	2.0 HDI 16v 120kw RHH	A/T AL4 AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C5 2 (08-..)	AUTOM. TRANSMISSI	2.0 HDI 16v 120kw RHH	A/T AM6 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HP-FAP	A/T AL4 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HP-FAP	A/T AM6 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HR-FAP	A/T AL4 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HR-FAP	A/T AM6 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HS-FAP	A/T AL4 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HS-FAP	A/T AM6 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HT-FAP	A/T AL4 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HT-FAP	A/T AM6 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	2.7 HDI V6 24v 150kw UHZ-FAP	A/T AL4 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	2.7 HDI V6 24v 150kw UHZ-FAP	A/T AM6 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	3.0 HDI V6 24V 177kw X8Z	A/T AL4 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	3.0 HDI V6 24V 177kw X8Z	A/T AM6 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	3.0 V6 16v 155kw XFV	A/T AL4 AUTODETECT
 C5 2 (08-..)	AUTOM. TRANSMISSI	3.0 V6 16v 155kw XFV	A/T AM6 AUTODETECT
 C5 2 (08-..)	AUX. HEATING	1.6 16v 110kw 5FN	AUTODETECT
 C5 2 (08-..)	AUX. HEATING	1.6 16v 115kw 5FV	AUTODETECT
 C5 2 (08-..)	AUX. HEATING	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C5 2 (08-..)	AUX. HEATING	1.8 16v 92kw 6FY	AUTODETECT
 C5 2 (08-..)	AUX. HEATING	2.0 16v 103kw RFJ	AUTODETECT
 C5 2 (08-..)	AUX. HEATING	2.0 16v 103kw RFJ - Bio Flex	AUTODETECT
 C5 2 (08-..)	AUX. HEATING	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C5 2 (08-..)	AUX. HEATING	2.0 HDI 16v 103kw RHF-FAP	AUTODETECT
 C5 2 (08-..)	AUX. HEATING	2.0 HDI 16v 110kw RHE	AUTODETECT
 C5 2 (08-..)	AUX. HEATING	2.0 HDI 16v 120kw RHH	AUTODETECT
 C5 2 (08-..)	AUX. HEATING	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C5 2 (08-..)	AUX. HEATING	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C5 2 (08-..)	AUX. HEATING	2.2 HDI 16v 120kw 4HS-FAP	AUTODETECT
 C5 2 (08-..)	AUX. HEATING	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C5 2 (08-..)	AUX. HEATING	2.7 HDI V6 24v 150kw UHZ-FAP	AUTODETECT
 C5 2 (08-..)	AUX. HEATING	3.0 HDI V6 24V 177kw X8Z	AUTODETECT
 C5 2 (08-..)	AUX. HEATING	3.0 V6 16v 155kw XFV	AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	1.6 16v 110kw 5FN	Body Computer BSI AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	1.6 16v 110kw 5FN	Body Computer BSM AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	1.6 16v 110kw 5FN	Body Computer BSR AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	1.6 16v 115kw 5FV	Body Computer BSI AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	1.6 16v 115kw 5FV	Body Computer BSM AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	1.6 16v 115kw 5FV	Body Computer BSR AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSI AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSM AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSR AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	1.8 16v 92kw 6FY	Body Computer BSI AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	1.8 16v 92kw 6FY	Body Computer BSM AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	1.8 16v 92kw 6FY	Body Computer BSR AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	2.0 16v 103kw RFJ	AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	2.0 16v 103kw RFJ	Body Computer BSI AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	2.0 16v 103kw RFJ	Body Computer BSM AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	2.0 16v 103kw RFJ	Body Computer BSR AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	2.0 16v 103kw RFJ - Bio Flex	Body Computer BSI AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	2.0 16v 103kw RFJ - Bio Flex	Body Computer BSM AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	2.0 16v 103kw RFJ - Bio Flex	Body Computer BSR AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	Body Computer BSI AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	Body Computer BSM AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	2.0 HDI 16v 103kw RHF-FAP	Body Computer BSI AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	2.0 HDI 16v 103kw RHF-FAP	Body Computer BSM AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	2.0 HDI 16v 103kw RHF-FAP	Body Computer BSR AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C5 2 (08-..)	CHASSIS NETWORK	2.0 HDI 16v 110kw RHE	Body Computer BSI AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	2.0 HDI 16v 110kw RHE	Body Computer BSM AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	2.0 HDI 16v 110kw RHE	Body Computer BSR AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	2.0 HDI 16v 120kw RHH	Body Computer BSI AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	2.0 HDI 16v 120kw RHH	Body Computer BSM AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	2.0 HDI 16v 120kw RHH	Body Computer BSR AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP-FAP	Body Computer BSI AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP-FAP	Body Computer BSM AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP-FAP	Body Computer BSR AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HR-FAP	Body Computer BSI AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HR-FAP	Body Computer BSM AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HR-FAP	Body Computer BSR AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HS-FAP	Body Computer BSI AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HS-FAP	Body Computer BSM AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HS-FAP	Body Computer BSR AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP	Body Computer BSI AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP	Body Computer BSM AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP	Body Computer BSR AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	2.7 HDI V6 24v 150kw UHZ-FAP	Body Computer BSI AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	2.7 HDI V6 24v 150kw UHZ-FAP	Body Computer BSM AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	2.7 HDI V6 24v 150kw UHZ-FAP	Body Computer BSR AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	3.0 HDI V6 24V 177kw X8Z	Body Computer BSI AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	3.0 HDI V6 24V 177kw X8Z	Body Computer BSM AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	3.0 HDI V6 24V 177kw X8Z	Body Computer BSR AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	3.0 V6 16v 155kw XFV	Body Computer BSI AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	3.0 V6 16v 155kw XFV	Body Computer BSM AUTODETECT
 C5 2 (08-..)	CHASSIS NETWORK	3.0 V6 16v 155kw XFV	Body Computer BSR AUTODETECT
 C5 2 (08-..)	CLIMA	1.6 16v 110kw 5FN	CLIMA AUTODETECT
 C5 2 (08-..)	CLIMA	1.6 16v 115kw 5FV	CLIMA AUTODETECT
 C5 2 (08-..)	CLIMA	1.6 HDI 16v 80kw 9HZ-FAP	CLIMA AUTODETECT
 C5 2 (08-..)	CLIMA	1.8 16v 92kw 6FY	CLIMA AUTODETECT
 C5 2 (08-..)	CLIMA	2.0 16v 103kw RFJ	CLIMA AUTODETECT
 C5 2 (08-..)	CLIMA	2.0 16v 103kw RFJ - Bio Flex	CLIMA AUTODETECT
 C5 2 (08-..)	CLIMA	2.0 HDI 16v 100kw RHR-FAP	CLIMA AUTODETECT
 C5 2 (08-..)	CLIMA	2.0 HDI 16v 103kw RHF-FAP	CLIMA AUTODETECT
 C5 2 (08-..)	CLIMA	2.0 HDI 16v 110kw RHE	CLIMA AUTODETECT
 C5 2 (08-..)	CLIMA	2.0 HDI 16v 120kw RHH	CLIMA AUTODETECT
 C5 2 (08-..)	CLIMA	2.2 HDI 16v 120kw 4HP-FAP	CLIMA AUTODETECT
 C5 2 (08-..)	CLIMA	2.2 HDI 16v 120kw 4HR-FAP	CLIMA AUTODETECT
 C5 2 (08-..)	CLIMA	2.2 HDI 16v 120kw 4HS-FAP	CLIMA AUTODETECT
 C5 2 (08-..)	CLIMA	2.2 HDI 16v 125kw 4HT-FAP	CLIMA AUTODETECT
 C5 2 (08-..)	CLIMA	2.7 HDI V6 24v 150kw UHZ-FAP	CLIMA AUTODETECT
 C5 2 (08-..)	CLIMA	3.0 HDI V6 24V 177kw X8Z	CLIMA AUTODETECT
 C5 2 (08-..)	CLIMA	3.0 V6 16v 155kw XFV	CLIMA AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	1.6 16v 110kw 5FN	AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	1.6 16v 110kw 5FN	AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	1.6 16v 115kw 5FV	AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	1.6 16v 115kw 5FV	AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	1.8 16v 92kw 6FY	AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	1.8 16v 92kw 6FY	AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	2.0 16v 103kw RFJ	AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	2.0 16v 103kw RFJ	AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	2.0 16v 103kw RFJ - Bio Flex	AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	2.0 16v 103kw RFJ - Bio Flex	AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C5 2 (08-..)	COMFORT SYSTEM	2.0 HDI 16v 103kw RHF-FAP	AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	2.0 HDI 16v 103kw RHF-FAP	AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	2.0 HDI 16v 110kw RHE	AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	2.0 HDI 16v 110kw RHE	AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	2.0 HDI 16v 120kw RHH	AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	2.0 HDI 16v 120kw RHH	AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HS-FAP	AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HS-FAP	AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	2.7 HDI V6 24v 150kw UHZ-FAP	AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	2.7 HDI V6 24v 150kw UHZ-FAP	AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	3.0 HDI V6 24V 177kw X8Z	AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	3.0 HDI V6 24V 177kw X8Z	AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	3.0 V6 16v 155kw XFV	AUTODETECT
 C5 2 (08-..)	COMFORT SYSTEM	3.0 V6 16v 155kw XFV	AUTODETECT
 C5 2 (08-..)	DRIVER SEAT CONT	1.6 16v 110kw 5FN	AUTODETECT
 C5 2 (08-..)	DRIVER SEAT CONT	1.6 16v 115kw 5FV	AUTODETECT
 C5 2 (08-..)	DRIVER SEAT CONT	1.8 16v 92kw 6FY	AUTODETECT
 C5 2 (08-..)	DRIVER SEAT CONT	2.0 16v 103kw RFJ - Bio Flex	AUTODETECT
 C5 2 (08-..)	DRIVER SEAT CONT	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C5 2 (08-..)	DRIVER SEAT CONT	2.0 HDI 16v 103kw RHF-FAP	AUTODETECT
 C5 2 (08-..)	DRIVER SEAT CONT	2.0 HDI 16v 110kw RHE	AUTODETECT
 C5 2 (08-..)	DRIVER SEAT CONT	2.0 HDI 16v 120kw RHH	AUTODETECT
 C5 2 (08-..)	DRIVER SEAT CONT	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C5 2 (08-..)	DRIVER SEAT CONT	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C5 2 (08-..)	DRIVER SEAT CONT	2.2 HDI 16v 120kw 4HS-FAP	AUTODETECT
 C5 2 (08-..)	DRIVER SEAT CONT	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C5 2 (08-..)	DRIVER SEAT CONT	2.7 HDI V6 24v 150kw UHZ-FAP	AUTODETECT
 C5 2 (08-..)	DRIVER SEAT CONT	3.0 HDI V6 24V 177kw X8Z	AUTODETECT
 C5 2 (08-..)	DRIVER SEAT CONT	3.0 V6 16v 155kw XFV	AUTODETECT
 C5 2 (08-..)	DRIVER SIDE DOOR	1.6 16v 110kw 5FN	AUTODETECT
 C5 2 (08-..)	DRIVER SIDE DOOR	1.6 16v 115kw 5FV	AUTODETECT
 C5 2 (08-..)	DRIVER SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C5 2 (08-..)	DRIVER SIDE DOOR	1.8 16v 92kw 6FY	AUTODETECT
 C5 2 (08-..)	DRIVER SIDE DOOR	2.0 16v 103kw RFJ	AUTODETECT
 C5 2 (08-..)	DRIVER SIDE DOOR	2.0 16v 103kw RFJ - Bio Flex	AUTODETECT
 C5 2 (08-..)	DRIVER SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C5 2 (08-..)	DRIVER SIDE DOOR	2.0 HDI 16v 103kw RHF-FAP	AUTODETECT
 C5 2 (08-..)	DRIVER SIDE DOOR	2.0 HDI 16v 110kw RHE	AUTODETECT
 C5 2 (08-..)	DRIVER SIDE DOOR	2.0 HDI 16v 120kw RHH	AUTODETECT
 C5 2 (08-..)	DRIVER SIDE DOOR	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C5 2 (08-..)	DRIVER SIDE DOOR	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C5 2 (08-..)	DRIVER SIDE DOOR	2.2 HDI 16v 120kw 4HS-FAP	AUTODETECT
 C5 2 (08-..)	DRIVER SIDE DOOR	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C5 2 (08-..)	DRIVER SIDE DOOR	2.7 HDI V6 24v 150kw UHZ-FAP	AUTODETECT
 C5 2 (08-..)	DRIVER SIDE DOOR	3.0 HDI V6 24V 177kw X8Z	AUTODETECT
 C5 2 (08-..)	DRIVER SIDE DOOR	3.0 V6 16v 155kw XFV	AUTODETECT
 C5 2 (08-..)	ELECTRIC STEERING	1.6 16v 110kw 5FN	AUTODETECT
 C5 2 (08-..)	ELECTRIC STEERING	1.6 16v 115kw 5FV	AUTODETECT
 C5 2 (08-..)	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C5 2 (08-..)	ELECTRIC STEERING	1.8 16v 92kw 6FY	AUTODETECT
 C5 2 (08-..)	ELECTRIC STEERING	2.0 16v 103kw RFJ	AUTODETECT
 C5 2 (08-..)	ELECTRIC STEERING	2.0 16v 103kw RFJ - Bio Flex	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C5 2 (08-..)	ELECTRIC STEERING	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C5 2 (08-..)	ELECTRIC STEERING	2.0 HDI 16v 103kw RHF-FAP	AUTODETECT
 C5 2 (08-..)	ELECTRIC STEERING	2.0 HDI 16v 110kw RHE	AUTODETECT
 C5 2 (08-..)	ELECTRIC STEERING	2.0 HDI 16v 120kw RHH	AUTODETECT
 C5 2 (08-..)	ELECTRIC STEERING	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C5 2 (08-..)	ELECTRIC STEERING	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C5 2 (08-..)	ELECTRIC STEERING	2.2 HDI 16v 120kw 4HS-FAP	AUTODETECT
 C5 2 (08-..)	ELECTRIC STEERING	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C5 2 (08-..)	ELECTRIC STEERING	2.7 HDI V6 24v 150kw UHZ-FAP	AUTODETECT
 C5 2 (08-..)	ELECTRIC STEERING	3.0 HDI V6 24V 177kw X8Z	AUTODETECT
 C5 2 (08-..)	ELECTRIC STEERING	3.0 V6 16v 155kw XFV	AUTODETECT
 C5 2 (08-..)	ENGINE MANAGEME	1.6 16v 110kw 5FN	EOBD
 C5 2 (08-..)	ENGINE MANAGEME	1.6 16v 115kw 5FV	EOBD
 C5 2 (08-..)	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 C5 2 (08-..)	ENGINE MANAGEME	1.8 16v 92kw 6FY	Marelli MM6KP AUTODETECT
 C5 2 (08-..)	ENGINE MANAGEME	2.0 16v 103kw RFJ	Marelli MM6KP AUTODETECT
 C5 2 (08-..)	ENGINE MANAGEME	2.0 16v 103kw RFJ - Bio Flex	Marelli MM6KP Bio Flex AUTODETECT
 C5 2 (08-..)	ENGINE MANAGEME	2.0 HDI 16v 100kw RHR-FAP	DELPHI DCM 3.4 Common Rail AUTODET
 C5 2 (08-..)	ENGINE MANAGEME	2.0 HDI 16v 103kw RHF-FAP	EOBD
 C5 2 (08-..)	ENGINE MANAGEME	2.0 HDI 16v 110kw RHE	EOBD
 C5 2 (08-..)	ENGINE MANAGEME	2.0 HDI 16v 120kw RHH	EOBD
 C5 2 (08-..)	ENGINE MANAGEME	2.2 HDI 16v 120kw 4HP-FAP	BOSCH EDC16 CP39 Common Rail AUTO
 C5 2 (08-..)	ENGINE MANAGEME	2.2 HDI 16v 120kw 4HR-FAP	BOSCH EDC16 CP39 Common Rail AUTO
 C5 2 (08-..)	ENGINE MANAGEME	2.2 HDI 16v 120kw 4HS-FAP	BOSCH EDC16 CP39 Common Rail AUTO
 C5 2 (08-..)	ENGINE MANAGEME	2.2 HDI 16v 125kw 4HT-FAP	BOSCH EDC16 CP39 Common Rail AUTO
 C5 2 (08-..)	ENGINE MANAGEME	2.7 HDI V6 24v 150kw UHZ-FAP	SIEMENS SID201 Common Rail AUTODET
 C5 2 (08-..)	ENGINE MANAGEME	3.0 HDI V6 24V 177kw X8Z	EOBD
 C5 2 (08-..)	ENGINE MANAGEME	3.0 V6 16v 155kw XFV	EOBD
 C5 2 (08-..)	LANE CHANGE ASSY	1.6 16v 110kw 5FN	AUTODETECT
 C5 2 (08-..)	LANE CHANGE ASSY	1.6 16v 115kw 5FV	AUTODETECT
 C5 2 (08-..)	LANE CHANGE ASSY	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C5 2 (08-..)	LANE CHANGE ASSY	1.8 16v 92kw 6FY	AUTODETECT
 C5 2 (08-..)	LANE CHANGE ASSY	2.0 16v 103kw RFJ	AUTODETECT
 C5 2 (08-..)	LANE CHANGE ASSY	2.0 16v 103kw RFJ - Bio Flex	AUTODETECT
 C5 2 (08-..)	LANE CHANGE ASSY	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C5 2 (08-..)	LANE CHANGE ASSY	2.0 HDI 16v 103kw RHF-FAP	AUTODETECT
 C5 2 (08-..)	LANE CHANGE ASSY	2.0 HDI 16v 110kw RHE	AUTODETECT
 C5 2 (08-..)	LANE CHANGE ASSY	2.0 HDI 16v 120kw RHH	AUTODETECT
 C5 2 (08-..)	LANE CHANGE ASSY	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C5 2 (08-..)	LANE CHANGE ASSY	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C5 2 (08-..)	LANE CHANGE ASSY	2.2 HDI 16v 120kw 4HS-FAP	AUTODETECT
 C5 2 (08-..)	LANE CHANGE ASSY	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C5 2 (08-..)	LANE CHANGE ASSY	2.7 HDI V6 24v 150kw UHZ-FAP	AUTODETECT
 C5 2 (08-..)	LANE CHANGE ASSY	3.0 HDI V6 24V 177kw X8Z	AUTODETECT
 C5 2 (08-..)	LANE CHANGE ASSY	3.0 V6 16v 155kw XFV	AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.6 16v 110kw 5FN	A/T AL4 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.6 16v 110kw 5FN	A/T AM6 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.6 16v 110kw 5FN	A/T AM6 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.6 16v 110kw 5FN	ESP 8.1 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.6 16v 110kw 5FN	ESP 8.1 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.6 16v 110kw 5FN	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.6 16v 110kw 5FN	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.6 16v 110kw 5FN	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.6 16v 110kw 5FN	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.6 16v 110kw 5FN	Variable shock absorber AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.6 16v 110kw 5FN	Variable shock absorber AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.6 16v 115kw 5FV	A/T AL4 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.6 16v 115kw 5FV	A/T AM6 AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C5 2 (08-..)	MAINTENANCE	1.6 16v 115kw 5FV	A/T AM6 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.6 16v 115kw 5FV	ESP 8.1 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.6 16v 115kw 5FV	ESP 8.1 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.6 16v 115kw 5FV	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.6 16v 115kw 5FV	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.6 16v 115kw 5FV	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.6 16v 115kw 5FV	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.6 16v 115kw 5FV	Variable shock absorber AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.6 16v 115kw 5FV	Variable shock absorber AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	A/T AL4 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	A/T AM6 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	A/T AM6 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 C5 2 (08-..)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 C5 2 (08-..)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 C5 2 (08-..)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 C5 2 (08-..)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 C5 2 (08-..)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	ESP 8.1 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	ESP 8.1 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Variable shock absorber AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Variable shock absorber AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.8 16v 92kw 6FY	A/T AL4 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.8 16v 92kw 6FY	A/T AM6 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.8 16v 92kw 6FY	A/T AM6 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.8 16v 92kw 6FY	ESP 8.1 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.8 16v 92kw 6FY	ESP 8.1 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.8 16v 92kw 6FY	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.8 16v 92kw 6FY	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.8 16v 92kw 6FY	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.8 16v 92kw 6FY	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.8 16v 92kw 6FY	Variable shock absorber AUTODETECT
 C5 2 (08-..)	MAINTENANCE	1.8 16v 92kw 6FY	Variable shock absorber AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 16v 103kw RFJ	A/T AL4 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 16v 103kw RFJ	A/T AM6 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 16v 103kw RFJ	A/T AM6 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 16v 103kw RFJ	ESP 8.1 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 16v 103kw RFJ	ESP 8.1 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 16v 103kw RFJ	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 16v 103kw RFJ	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 16v 103kw RFJ	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 16v 103kw RFJ	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 16v 103kw RFJ	Variable shock absorber AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 16v 103kw RFJ	Variable shock absorber AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 16v 103kw RFJ - Bio Flex	A/T AL4 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 16v 103kw RFJ - Bio Flex	A/T AM6 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 16v 103kw RFJ - Bio Flex	A/T AM6 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 16v 103kw RFJ - Bio Flex	ESP 8.1 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 16v 103kw RFJ - Bio Flex	ESP 8.1 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 16v 103kw RFJ - Bio Flex	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 16v 103kw RFJ - Bio Flex	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 16v 103kw RFJ - Bio Flex	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 16v 103kw RFJ - Bio Flex	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 16v 103kw RFJ - Bio Flex	Variable shock absorber AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C5 2 (08-..)	MAINTENANCE	2.0 16v 103kw RFJ - Bio Flex	Variable shock absorber AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	A/T AL4 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	A/T AM6 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	A/T AM6 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	DELPHI DCM 3.4 Common Rail AUTODET
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	ESP 8.1 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	ESP 8.1 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Variable shock absorber AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Variable shock absorber AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	A/T AL4 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	A/T AM6 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	A/T AM6 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	ESP 8.1 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	ESP 8.1 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	Variable shock absorber AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	Variable shock absorber AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 110kw RHE	A/T AL4 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 110kw RHE	A/T AM6 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 110kw RHE	A/T AM6 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 110kw RHE	ESP 8.1 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 110kw RHE	ESP 8.1 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 110kw RHE	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 110kw RHE	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 110kw RHE	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 110kw RHE	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 110kw RHE	Variable shock absorber AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 110kw RHE	Variable shock absorber AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 120kw RHH	A/T AL4 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 120kw RHH	A/T AM6 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 120kw RHH	A/T AM6 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 120kw RHH	ESP 8.1 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 120kw RHH	ESP 8.1 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 120kw RHH	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 120kw RHH	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 120kw RHH	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 120kw RHH	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 120kw RHH	Variable shock absorber AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.0 HDI 16v 120kw RHH	Variable shock absorber AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HP-FAP	A/T AL4 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HP-FAP	A/T AM6 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HP-FAP	A/T AM6 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HP-FAP	BOSCH EDC16 CP39 Common Rail AUTO
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HP-FAP	ESP 8.1 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HP-FAP	ESP 8.1 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HP-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HP-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HP-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HP-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HP-FAP	Variable shock absorber AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HP-FAP	Variable shock absorber AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HR-FAP	A/T AL4 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HR-FAP	A/T AM6 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HR-FAP	A/T AM6 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HR-FAP	BOSCH EDC16 CP39 Common Rail AUTO
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HR-FAP	ESP 8.1 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HR-FAP	ESP 8.1 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HR-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HR-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HR-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HR-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HR-FAP	Variable shock absorber AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HR-FAP	Variable shock absorber AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HS-FAP	A/T AL4 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HS-FAP	A/T AM6 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HS-FAP	A/T AM6 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HS-FAP	BOSCH EDC16 CP39 Common Rail AUTO
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HS-FAP	ESP 8.1 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HS-FAP	ESP 8.1 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HS-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HS-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HS-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HS-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HS-FAP	Variable shock absorber AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 120kw 4HS-FAP	Variable shock absorber AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	A/T AL4 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	A/T AM6 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	A/T AM6 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	BOSCH EDC16 CP39 Common Rail AUTO
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	ESP 8.1 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	ESP 8.1 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	Variable shock absorber AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	Variable shock absorber AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	A/T AL4 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	A/T AM6 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	A/T AM6 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	ESP 8.1 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	ESP 8.1 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	SIEMENS SID201 Common Rail AUTODET
 C5 2 (08-..)	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	SIEMENS SID201 Common Rail AUTODET
 C5 2 (08-..)	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	SIEMENS SID201 Common Rail AUTODET
 C5 2 (08-..)	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	SIEMENS SID201 Common Rail AUTODET
 C5 2 (08-..)	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	SIEMENS SID201 Common Rail AUTODET
 C5 2 (08-..)	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Variable shock absorber AUTODETECT
 C5 2 (08-..)	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Variable shock absorber AUTODETECT
 C5 2 (08-..)	MAINTENANCE	3.0 HDI V6 24V 177kw X8Z	A/T AL4 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	3.0 HDI V6 24V 177kw X8Z	A/T AM6 AUTODETECT
C5 2 (08-..)	MAINTENANCE	3.0 HDI V6 24V 177kw X8Z	A/T AM6 AUTODETECT
C5 2 (08-..)	MAINTENANCE	3.0 HDI V6 24V 177kw X8Z	ESP 8.1 AUTODETECT
C5 2 (08-..)	MAINTENANCE	3.0 HDI V6 24V 177kw X8Z	ESP 8.1 AUTODETECT
C5 2 (08-..)	MAINTENANCE	3.0 HDI V6 24V 177kw X8Z	Siemens-JCAE AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C5 2 (08-..)	MAINTENANCE	3.0 HDI V6 24V 177kw X8Z	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	3.0 HDI V6 24V 177kw X8Z	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	3.0 HDI V6 24V 177kw X8Z	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	3.0 HDI V6 24V 177kw X8Z	Variable shock absorber AUTODETECT
 C5 2 (08-..)	MAINTENANCE	3.0 HDI V6 24V 177kw X8Z	Variable shock absorber AUTODETECT
 C5 2 (08-..)	MAINTENANCE	3.0 V6 16v 155kw XFV	A/T AL4 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	3.0 V6 16v 155kw XFV	A/T AM6 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	3.0 V6 16v 155kw XFV	A/T AM6 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	3.0 V6 16v 155kw XFV	ESP 8.1 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	3.0 V6 16v 155kw XFV	ESP 8.1 AUTODETECT
 C5 2 (08-..)	MAINTENANCE	3.0 V6 16v 155kw XFV	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	3.0 V6 16v 155kw XFV	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	3.0 V6 16v 155kw XFV	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	3.0 V6 16v 155kw XFV	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	MAINTENANCE	3.0 V6 16v 155kw XFV	Variable shock absorber AUTODETECT
 C5 2 (08-..)	MAINTENANCE	3.0 V6 16v 155kw XFV	Variable shock absorber AUTODETECT
 C5 2 (08-..)	NAVIGATION	1.6 16v 110kw 5FN	AUTODETECT
 C5 2 (08-..)	NAVIGATION	1.6 16v 110kw 5FN	AUTODETECT
 C5 2 (08-..)	NAVIGATION	1.6 16v 115kw 5FV	AUTODETECT
 C5 2 (08-..)	NAVIGATION	1.6 16v 115kw 5FV	AUTODETECT
 C5 2 (08-..)	NAVIGATION	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C5 2 (08-..)	NAVIGATION	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C5 2 (08-..)	NAVIGATION	1.8 16v 92kw 6FY	AUTODETECT
 C5 2 (08-..)	NAVIGATION	1.8 16v 92kw 6FY	AUTODETECT
 C5 2 (08-..)	NAVIGATION	2.0 16v 103kw RFJ	AUTODETECT
 C5 2 (08-..)	NAVIGATION	2.0 16v 103kw RFJ	AUTODETECT
 C5 2 (08-..)	NAVIGATION	2.0 16v 103kw RFJ - Bio Flex	AUTODETECT
 C5 2 (08-..)	NAVIGATION	2.0 16v 103kw RFJ - Bio Flex	AUTODETECT
 C5 2 (08-..)	NAVIGATION	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C5 2 (08-..)	NAVIGATION	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C5 2 (08-..)	NAVIGATION	2.0 HDI 16v 103kw RHF-FAP	AUTODETECT
 C5 2 (08-..)	NAVIGATION	2.0 HDI 16v 103kw RHF-FAP	AUTODETECT
 C5 2 (08-..)	NAVIGATION	2.0 HDI 16v 110kw RHE	AUTODETECT
 C5 2 (08-..)	NAVIGATION	2.0 HDI 16v 110kw RHE	AUTODETECT
 C5 2 (08-..)	NAVIGATION	2.0 HDI 16v 120kw RHH	AUTODETECT
 C5 2 (08-..)	NAVIGATION	2.0 HDI 16v 120kw RHH	AUTODETECT
 C5 2 (08-..)	NAVIGATION	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C5 2 (08-..)	NAVIGATION	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C5 2 (08-..)	NAVIGATION	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C5 2 (08-..)	NAVIGATION	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C5 2 (08-..)	NAVIGATION	2.2 HDI 16v 120kw 4HS-FAP	AUTODETECT
 C5 2 (08-..)	NAVIGATION	2.2 HDI 16v 120kw 4HS-FAP	AUTODETECT
 C5 2 (08-..)	NAVIGATION	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C5 2 (08-..)	NAVIGATION	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C5 2 (08-..)	NAVIGATION	2.7 HDI V6 24v 150kw UHZ-FAP	AUTODETECT
 C5 2 (08-..)	NAVIGATION	2.7 HDI V6 24v 150kw UHZ-FAP	AUTODETECT
 C5 2 (08-..)	NAVIGATION	3.0 HDI V6 24V 177kw X8Z	AUTODETECT
 C5 2 (08-..)	NAVIGATION	3.0 HDI V6 24V 177kw X8Z	AUTODETECT
 C5 2 (08-..)	NAVIGATION	3.0 V6 16v 155kw XFV	AUTODETECT
 C5 2 (08-..)	NAVIGATION	3.0 V6 16v 155kw XFV	AUTODETECT
 C5 2 (08-..)	PARK.BRAKE	1.6 16v 110kw 5FN	Electrobrake AUTODETECT
 C5 2 (08-..)	PARK.BRAKE	1.6 16v 115kw 5FV	Electrobrake AUTODETECT
 C5 2 (08-..)	PARK.BRAKE	1.6 HDI 16v 80kw 9HZ-FAP	Electrobrake AUTODETECT
 C5 2 (08-..)	PARK.BRAKE	1.8 16v 92kw 6FY	Electrobrake AUTODETECT
 C5 2 (08-..)	PARK.BRAKE	2.0 16v 103kw RFJ	Electrobrake AUTODETECT
 C5 2 (08-..)	PARK.BRAKE	2.0 16v 103kw RFJ - Bio Flex	Electrobrake AUTODETECT
 C5 2 (08-..)	PARK.BRAKE	2.0 HDI 16v 100kw RHR-FAP	Electrobrake AUTODETECT
 C5 2 (08-..)	PARK.BRAKE	2.0 HDI 16v 103kw RHF-FAP	Electrobrake AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C5 2 (08-..)	PARK.BRAKE	2.0 HDI 16v 110kw RHE	Electrobrake AUTODETECT
 C5 2 (08-..)	PARK.BRAKE	2.0 HDI 16v 120kw RHH	Electrobrake AUTODETECT
 C5 2 (08-..)	PARK.BRAKE	2.2 HDI 16v 120kw 4HP-FAP	Electrobrake AUTODETECT
 C5 2 (08-..)	PARK.BRAKE	2.2 HDI 16v 120kw 4HR-FAP	Electrobrake AUTODETECT
 C5 2 (08-..)	PARK.BRAKE	2.2 HDI 16v 120kw 4HS-FAP	Electrobrake AUTODETECT
 C5 2 (08-..)	PARK.BRAKE	2.2 HDI 16v 125kw 4HT-FAP	Electrobrake AUTODETECT
 C5 2 (08-..)	PARK.BRAKE	2.7 HDI V6 24v 150kw UHZ-FAP	Electrobrake AUTODETECT
 C5 2 (08-..)	PARK.BRAKE	3.0 HDI V6 24V 177kw X8Z	Electrobrake AUTODETECT
 C5 2 (08-..)	PARK.BRAKE	3.0 V6 16v 155kw XFV	Electrobrake AUTODETECT
 C5 2 (08-..)	PARKING HELP	1.6 16v 110kw 5FN	AUTODETECT
 C5 2 (08-..)	PARKING HELP	1.6 16v 115kw 5FV	AUTODETECT
 C5 2 (08-..)	PARKING HELP	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C5 2 (08-..)	PARKING HELP	1.8 16v 92kw 6FY	AUTODETECT
 C5 2 (08-..)	PARKING HELP	2.0 16v 103kw RFJ	AUTODETECT
 C5 2 (08-..)	PARKING HELP	2.0 16v 103kw RFJ - Bio Flex	AUTODETECT
 C5 2 (08-..)	PARKING HELP	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C5 2 (08-..)	PARKING HELP	2.0 HDI 16v 103kw RHF-FAP	AUTODETECT
 C5 2 (08-..)	PARKING HELP	2.0 HDI 16v 110kw RHE	AUTODETECT
 C5 2 (08-..)	PARKING HELP	2.0 HDI 16v 120kw RHH	AUTODETECT
 C5 2 (08-..)	PARKING HELP	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C5 2 (08-..)	PARKING HELP	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C5 2 (08-..)	PARKING HELP	2.2 HDI 16v 120kw 4HS-FAP	AUTODETECT
 C5 2 (08-..)	PARKING HELP	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C5 2 (08-..)	PARKING HELP	2.7 HDI V6 24v 150kw UHZ-FAP	AUTODETECT
 C5 2 (08-..)	PARKING HELP	3.0 HDI V6 24V 177kw X8Z	AUTODETECT
 C5 2 (08-..)	PARKING HELP	3.0 V6 16v 155kw XFV	AUTODETECT
 C5 2 (08-..)	PHONE	1.6 16v 110kw 5FN	AUTODETECT
 C5 2 (08-..)	PHONE	1.6 16v 115kw 5FV	AUTODETECT
 C5 2 (08-..)	PHONE	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C5 2 (08-..)	PHONE	1.8 16v 92kw 6FY	AUTODETECT
 C5 2 (08-..)	PHONE	2.0 16v 103kw RFJ	AUTODETECT
 C5 2 (08-..)	PHONE	2.0 16v 103kw RFJ - Bio Flex	AUTODETECT
 C5 2 (08-..)	PHONE	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C5 2 (08-..)	PHONE	2.0 HDI 16v 103kw RHF-FAP	AUTODETECT
 C5 2 (08-..)	PHONE	2.0 HDI 16v 110kw RHE	AUTODETECT
 C5 2 (08-..)	PHONE	2.0 HDI 16v 120kw RHH	AUTODETECT
 C5 2 (08-..)	PHONE	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C5 2 (08-..)	PHONE	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C5 2 (08-..)	PHONE	2.2 HDI 16v 120kw 4HS-FAP	AUTODETECT
 C5 2 (08-..)	PHONE	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C5 2 (08-..)	PHONE	2.7 HDI V6 24v 150kw UHZ-FAP	AUTODETECT
 C5 2 (08-..)	PHONE	3.0 HDI V6 24V 177kw X8Z	AUTODETECT
 C5 2 (08-..)	PHONE	3.0 V6 16v 155kw XFV	AUTODETECT
 C5 2 (08-..)	RADIO / CD	1.6 16v 110kw 5FN	Ampli AUDIO AUTODETECT
 C5 2 (08-..)	RADIO / CD	1.6 16v 110kw 5FN	AudioSystem AUTODETECT
 C5 2 (08-..)	RADIO / CD	1.6 16v 110kw 5FN	CD Changer AUTODETECT
 C5 2 (08-..)	RADIO / CD	1.6 16v 115kw 5FV	Ampli AUDIO AUTODETECT
 C5 2 (08-..)	RADIO / CD	1.6 16v 115kw 5FV	AudioSystem AUTODETECT
 C5 2 (08-..)	RADIO / CD	1.6 16v 115kw 5FV	CD Changer AUTODETECT
 C5 2 (08-..)	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Ampli AUDIO AUTODETECT
 C5 2 (08-..)	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	AudioSystem AUTODETECT
 C5 2 (08-..)	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	CD Changer AUTODETECT
 C5 2 (08-..)	RADIO / CD	1.8 16v 92kw 6FY	Ampli AUDIO AUTODETECT
 C5 2 (08-..)	RADIO / CD	1.8 16v 92kw 6FY	AudioSystem AUTODETECT
 C5 2 (08-..)	RADIO / CD	1.8 16v 92kw 6FY	CD Changer AUTODETECT
 C5 2 (08-..)	RADIO / CD	2.0 16v 103kw RFJ	Ampli AUDIO AUTODETECT
 C5 2 (08-..)	RADIO / CD	2.0 16v 103kw RFJ	AudioSystem AUTODETECT
 C5 2 (08-..)	RADIO / CD	2.0 16v 103kw RFJ	CD Changer AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C5 2 (08-..)	RADIO / CD	2.0 16v 103kw RFJ - Bio Flex	Ampli AUDIO AUTODETECT
 C5 2 (08-..)	RADIO / CD	2.0 16v 103kw RFJ - Bio Flex	AudioSystem AUTODETECT
 C5 2 (08-..)	RADIO / CD	2.0 16v 103kw RFJ - Bio Flex	CD Changer AUTODETECT
 C5 2 (08-..)	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP	Ampli AUDIO AUTODETECT
 C5 2 (08-..)	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP	AudioSystem AUTODETECT
 C5 2 (08-..)	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP	CD Changer AUTODETECT
 C5 2 (08-..)	RADIO / CD	2.0 HDI 16v 103kw RHF-FAP	Ampli AUDIO AUTODETECT
 C5 2 (08-..)	RADIO / CD	2.0 HDI 16v 103kw RHF-FAP	AudioSystem AUTODETECT
 C5 2 (08-..)	RADIO / CD	2.0 HDI 16v 103kw RHF-FAP	CD Changer AUTODETECT
 C5 2 (08-..)	RADIO / CD	2.0 HDI 16v 110kw RHE	Ampli AUDIO AUTODETECT
 C5 2 (08-..)	RADIO / CD	2.0 HDI 16v 110kw RHE	AudioSystem AUTODETECT
 C5 2 (08-..)	RADIO / CD	2.0 HDI 16v 110kw RHE	CD Changer AUTODETECT
 C5 2 (08-..)	RADIO / CD	2.0 HDI 16v 120kw RHH	Ampli AUDIO AUTODETECT
 C5 2 (08-..)	RADIO / CD	2.0 HDI 16v 120kw RHH	AudioSystem AUTODETECT
 C5 2 (08-..)	RADIO / CD	2.0 HDI 16v 120kw RHH	CD Changer AUTODETECT
 C5 2 (08-..)	RADIO / CD	2.2 HDI 16v 120kw 4HP-FAP	Ampli AUDIO AUTODETECT
 C5 2 (08-..)	RADIO / CD	2.2 HDI 16v 120kw 4HP-FAP	AudioSystem AUTODETECT
 C5 2 (08-..)	RADIO / CD	2.2 HDI 16v 120kw 4HP-FAP	CD Changer AUTODETECT
 C5 2 (08-..)	RADIO / CD	2.2 HDI 16v 120kw 4HR-FAP	Ampli AUDIO AUTODETECT
 C5 2 (08-..)	RADIO / CD	2.2 HDI 16v 120kw 4HR-FAP	AudioSystem AUTODETECT
 C5 2 (08-..)	RADIO / CD	2.2 HDI 16v 120kw 4HR-FAP	CD Changer AUTODETECT
 C5 2 (08-..)	RADIO / CD	2.2 HDI 16v 120kw 4HS-FAP	Ampli AUDIO AUTODETECT
 C5 2 (08-..)	RADIO / CD	2.2 HDI 16v 120kw 4HS-FAP	AudioSystem AUTODETECT
 C5 2 (08-..)	RADIO / CD	2.2 HDI 16v 120kw 4HS-FAP	CD Changer AUTODETECT
 C5 2 (08-..)	RADIO / CD	2.2 HDI 16v 125kw 4HT-FAP	Ampli AUDIO AUTODETECT
 C5 2 (08-..)	RADIO / CD	2.2 HDI 16v 125kw 4HT-FAP	AudioSystem AUTODETECT
 C5 2 (08-..)	RADIO / CD	2.2 HDI 16v 125kw 4HT-FAP	CD Changer AUTODETECT
 C5 2 (08-..)	RADIO / CD	2.7 HDI V6 24v 150kw UHZ-FAP	Ampli AUDIO AUTODETECT
 C5 2 (08-..)	RADIO / CD	2.7 HDI V6 24v 150kw UHZ-FAP	AudioSystem AUTODETECT
 C5 2 (08-..)	RADIO / CD	2.7 HDI V6 24v 150kw UHZ-FAP	CD Changer AUTODETECT
 C5 2 (08-..)	RADIO / CD	3.0 HDI V6 24V 177kw X8Z	Ampli AUDIO AUTODETECT
 C5 2 (08-..)	RADIO / CD	3.0 HDI V6 24V 177kw X8Z	AudioSystem AUTODETECT
 C5 2 (08-..)	RADIO / CD	3.0 HDI V6 24V 177kw X8Z	CD Changer AUTODETECT
 C5 2 (08-..)	RADIO / CD	3.0 V6 16v 155kw XFV	Ampli AUDIO AUTODETECT
 C5 2 (08-..)	RADIO / CD	3.0 V6 16v 155kw XFV	AudioSystem AUTODETECT
 C5 2 (08-..)	RADIO / CD	3.0 V6 16v 155kw XFV	CD Changer AUTODETECT
 C5 2 (08-..)	RAIN-LUMINOSITY S	1.6 16v 110kw 5FN	AUTODETECT
 C5 2 (08-..)	RAIN-LUMINOSITY S	1.6 16v 115kw 5FV	AUTODETECT
 C5 2 (08-..)	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C5 2 (08-..)	RAIN-LUMINOSITY S	1.8 16v 92kw 6FY	AUTODETECT
 C5 2 (08-..)	RAIN-LUMINOSITY S	2.0 16v 103kw RFJ	AUTODETECT
 C5 2 (08-..)	RAIN-LUMINOSITY S	2.0 16v 103kw RFJ - Bio Flex	AUTODETECT
 C5 2 (08-..)	RAIN-LUMINOSITY S	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C5 2 (08-..)	RAIN-LUMINOSITY S	2.0 HDI 16v 103kw RHF-FAP	AUTODETECT
 C5 2 (08-..)	RAIN-LUMINOSITY S	2.0 HDI 16v 110kw RHE	AUTODETECT
 C5 2 (08-..)	RAIN-LUMINOSITY S	2.0 HDI 16v 120kw RHH	AUTODETECT
 C5 2 (08-..)	RAIN-LUMINOSITY S	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C5 2 (08-..)	RAIN-LUMINOSITY S	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C5 2 (08-..)	RAIN-LUMINOSITY S	2.2 HDI 16v 120kw 4HS-FAP	AUTODETECT
 C5 2 (08-..)	RAIN-LUMINOSITY S	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C5 2 (08-..)	RAIN-LUMINOSITY S	2.7 HDI V6 24v 150kw UHZ-FAP	AUTODETECT
 C5 2 (08-..)	RAIN-LUMINOSITY S	3.0 HDI V6 24V 177kw X8Z	AUTODETECT
 C5 2 (08-..)	RAIN-LUMINOSITY S	3.0 V6 16v 155kw XFV	AUTODETECT
 C5 2 (08-..)	STEERING WHEEL E	1.6 16v 110kw 5FN	AUTODETECT
 C5 2 (08-..)	STEERING WHEEL E	1.6 16v 115kw 5FV	AUTODETECT
 C5 2 (08-..)	STEERING WHEEL E	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 C5 2 (08-..)	STEERING WHEEL E	1.8 16v 92kw 6FY	AUTODETECT
 C5 2 (08-..)	STEERING WHEEL E	2.0 16v 103kw RFJ	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C5 2 (08-..)	STEERING WHEEL E	2.0 16v 103kw RFJ - Bio Flex	AUTODETECT
 C5 2 (08-..)	STEERING WHEEL E	2.0 HDI 16v 100kw RHR-FAP	AUTODETECT
 C5 2 (08-..)	STEERING WHEEL E	2.0 HDI 16v 103kw RHF-FAP	AUTODETECT
 C5 2 (08-..)	STEERING WHEEL E	2.0 HDI 16v 110kw RHE	AUTODETECT
 C5 2 (08-..)	STEERING WHEEL E	2.0 HDI 16v 120kw RHH	AUTODETECT
 C5 2 (08-..)	STEERING WHEEL E	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C5 2 (08-..)	STEERING WHEEL E	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C5 2 (08-..)	STEERING WHEEL E	2.2 HDI 16v 120kw 4HS-FAP	AUTODETECT
 C5 2 (08-..)	STEERING WHEEL E	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C5 2 (08-..)	STEERING WHEEL E	2.7 HDI V6 24v 150kw UHZ-FAP	AUTODETECT
 C5 2 (08-..)	STEERING WHEEL E	3.0 HDI V6 24V 177kw X8Z	AUTODETECT
 C5 2 (08-..)	STEERING WHEEL E	3.0 V6 16v 155kw XFV	AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	1.6 16v 110kw 5FN	HYDRACTIVE AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	1.6 16v 110kw 5FN	Variable shock absorber AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	1.6 16v 115kw 5FV	HYDRACTIVE AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	1.6 16v 115kw 5FV	Variable shock absorber AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	1.6 HDI 16v 80kw 9HZ-FAP	HYDRACTIVE AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	1.6 HDI 16v 80kw 9HZ-FAP	Variable shock absorber AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	1.8 16v 92kw 6FY	HYDRACTIVE AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	1.8 16v 92kw 6FY	Variable shock absorber AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	2.0 16v 103kw RFJ	HYDRACTIVE AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	2.0 16v 103kw RFJ	Variable shock absorber AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	2.0 16v 103kw RFJ - Bio Flex	HYDRACTIVE AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	2.0 16v 103kw RFJ - Bio Flex	Variable shock absorber AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	2.0 HDI 16v 100kw RHR-FAP	HYDRACTIVE AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	2.0 HDI 16v 100kw RHR-FAP	Variable shock absorber AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	2.0 HDI 16v 103kw RHF-FAP	HYDRACTIVE AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	2.0 HDI 16v 103kw RHF-FAP	Variable shock absorber AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	2.0 HDI 16v 110kw RHE	HYDRACTIVE AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	2.0 HDI 16v 110kw RHE	Variable shock absorber AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	2.0 HDI 16v 120kw RHH	HYDRACTIVE AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	2.0 HDI 16v 120kw RHH	Variable shock absorber AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	2.2 HDI 16v 120kw 4HP-FAP	HYDRACTIVE AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	2.2 HDI 16v 120kw 4HP-FAP	Variable shock absorber AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	2.2 HDI 16v 120kw 4HR-FAP	HYDRACTIVE AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	2.2 HDI 16v 120kw 4HR-FAP	Variable shock absorber AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	2.2 HDI 16v 120kw 4HS-FAP	HYDRACTIVE AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	2.2 HDI 16v 120kw 4HS-FAP	Variable shock absorber AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	2.2 HDI 16v 125kw 4HT-FAP	HYDRACTIVE AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	2.2 HDI 16v 125kw 4HT-FAP	Variable shock absorber AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	2.7 HDI V6 24v 150kw UHZ-FAP	HYDRACTIVE AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	2.7 HDI V6 24v 150kw UHZ-FAP	Variable shock absorber AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	3.0 HDI V6 24V 177kw X8Z	HYDRACTIVE AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	3.0 HDI V6 24V 177kw X8Z	Variable shock absorber AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	3.0 V6 16v 155kw XFV	HYDRACTIVE AUTODETECT
 C5 2 (08-..)	SUSPENSION CONTR	3.0 V6 16v 155kw XFV	Variable shock absorber AUTODETECT
 C5 2 (08-..)	TIRE PRESSURE	1.6 16v 110kw 5FN	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	TIRE PRESSURE	1.6 16v 115kw 5FV	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	TIRE PRESSURE	1.6 HDI 16v 80kw 9HZ-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	TIRE PRESSURE	1.8 16v 92kw 6FY	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	TIRE PRESSURE	2.0 16v 103kw RFJ	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	TIRE PRESSURE	2.0 16v 103kw RFJ - Bio Flex	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	TIRE PRESSURE	2.0 HDI 16v 100kw RHR-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	TIRE PRESSURE	2.0 HDI 16v 103kw RHF-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	TIRE PRESSURE	2.0 HDI 16v 110kw RHE	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	TIRE PRESSURE	2.0 HDI 16v 120kw RHH	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	TIRE PRESSURE	2.2 HDI 16v 120kw 4HP-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	TIRE PRESSURE	2.2 HDI 16v 120kw 4HR-FAP	Siemens-JCAE AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C5 2 (08-..)	TIRE PRESSURE	2.2 HDI 16v 120kw 4HS-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	TIRE PRESSURE	2.2 HDI 16v 125kw 4HT-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	TIRE PRESSURE	2.7 HDI V6 24v 150kw UHZ-FAP	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	TIRE PRESSURE	3.0 HDI V6 24V 177kw X8Z	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	TIRE PRESSURE	3.0 V6 16v 155kw XFV	Siemens-JCAE AUTODETECT
 C5 2 (08-..)	VISUAL/TELEMATIC	1.6 16v 110kw 5FN	Display C- AUTODETECT
 C5 2 (08-..)	VISUAL/TELEMATIC	1.6 16v 115kw 5FV	Display C- AUTODETECT
 C5 2 (08-..)	VISUAL/TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	Display C- AUTODETECT
 C5 2 (08-..)	VISUAL/TELEMATIC	1.8 16v 92kw 6FY	Display C- AUTODETECT
 C5 2 (08-..)	VISUAL/TELEMATIC	2.0 16v 103kw RFJ	Display C- AUTODETECT
 C5 2 (08-..)	VISUAL/TELEMATIC	2.0 16v 103kw RFJ - Bio Flex	Display C- AUTODETECT
 C5 2 (08-..)	VISUAL/TELEMATIC	2.0 HDI 16v 100kw RHR-FAP	Display C- AUTODETECT
 C5 2 (08-..)	VISUAL/TELEMATIC	2.0 HDI 16v 103kw RHF-FAP	Display C- AUTODETECT
 C5 2 (08-..)	VISUAL/TELEMATIC	2.0 HDI 16v 110kw RHE	Display C- AUTODETECT
 C5 2 (08-..)	VISUAL/TELEMATIC	2.0 HDI 16v 120kw RHH	Display C- AUTODETECT
 C5 2 (08-..)	VISUAL/TELEMATIC	2.2 HDI 16v 120kw 4HP-FAP	Display C- AUTODETECT
 C5 2 (08-..)	VISUAL/TELEMATIC	2.2 HDI 16v 120kw 4HR-FAP	Display C- AUTODETECT
 C5 2 (08-..)	VISUAL/TELEMATIC	2.2 HDI 16v 120kw 4HS-FAP	Display C- AUTODETECT
 C5 2 (08-..)	VISUAL/TELEMATIC	2.2 HDI 16v 125kw 4HT-FAP	Display C- AUTODETECT
 C5 2 (08-..)	VISUAL/TELEMATIC	2.7 HDI V6 24v 150kw UHZ-FAP	Display C- AUTODETECT
 C5 2 (08-..)	VISUAL/TELEMATIC	3.0 HDI V6 24V 177kw X8Z	Display C- AUTODETECT
 C5 2 (08-..)	VISUAL/TELEMATIC	3.0 V6 16v 155kw XFV	Display C- AUTODETECT
 C6	ABS + TRACT. CONT	2.2 HDI 16v 120kw 4HP-FAP	ESP 8.1 AUTODETECT
 C6	ABS + TRACT. CONT	2.2 HDI 16v 120kw 4HP-FAP	ESP AUTODETECT
 C6	ABS + TRACT. CONT	2.2 HDI 16v 120kw 4HR-FAP	ESP 8.1 AUTODETECT
 C6	ABS + TRACT. CONT	2.2 HDI 16v 120kw 4HR-FAP	ESP AUTODETECT
 C6	ABS + TRACT. CONT	2.2 HDI 16v 125kw 4HS-FAP	ESP 8.1 AUTODETECT
 C6	ABS + TRACT. CONT	2.2 HDI 16v 125kw 4HS-FAP	ESP AUTODETECT
 C6	ABS + TRACT. CONT	2.2 HDI 16v 125kw 4HT-FAP	ESP 8.1 AUTODETECT
 C6	ABS + TRACT. CONT	2.2 HDI 16v 125kw 4HT-FAP	ESP AUTODETECT
 C6	ABS + TRACT. CONT	2.7 HDI V6 24v 150kw UHZ-FAP	ESP 8.1 AUTODETECT
 C6	ABS + TRACT. CONT	2.7 HDI V6 24v 150kw UHZ-FAP	ESP AUTODETECT
 C6	ABS + TRACT. CONT	3.0 HDI V6 24V 177kw X8Z	ESP 8.1 AUTODETECT
 C6	ABS + TRACT. CONT	3.0 HDI V6 24V 177kw X8Z	ESP AUTODETECT
 C6	ABS + TRACT. CONT	3.0 V6 24v 155kw XFV	ESP 8.1 AUTODETECT
 C6	ABS + TRACT. CONT	3.0 V6 24v 155kw XFV	ESP AUTODETECT
 C6	AIRBAG	2.2 HDI 16v 120kw 4HP-FAP	AirBag CENTRAL AUTODETECT
 C6	AIRBAG	2.2 HDI 16v 120kw 4HP-FAP	Pieton Shock Detection AUTODETECT
 C6	AIRBAG	2.2 HDI 16v 120kw 4HR-FAP	AirBag CENTRAL AUTODETECT
 C6	AIRBAG	2.2 HDI 16v 120kw 4HR-FAP	Pieton Shock Detection AUTODETECT
 C6	AIRBAG	2.2 HDI 16v 125kw 4HS-FAP	AirBag CENTRAL AUTODETECT
 C6	AIRBAG	2.2 HDI 16v 125kw 4HS-FAP	Pieton Shock Detection AUTODETECT
 C6	AIRBAG	2.2 HDI 16v 125kw 4HT-FAP	AirBag CENTRAL AUTODETECT
 C6	AIRBAG	2.2 HDI 16v 125kw 4HT-FAP	Pieton Shock Detection AUTODETECT
 C6	AIRBAG	2.7 HDI V6 24v 150kw UHZ-FAP	AirBag CENTRAL AUTODETECT
 C6	AIRBAG	2.7 HDI V6 24v 150kw UHZ-FAP	Pieton Shock Detection AUTODETECT
 C6	AIRBAG	3.0 HDI V6 24V 177kw X8Z	AirBag CENTRAL AUTODETECT
 C6	AIRBAG	3.0 HDI V6 24V 177kw X8Z	Pieton Shock Detection AUTODETECT
 C6	AIRBAG	3.0 V6 24v 155kw XFV	AirBag CENTRAL AUTODETECT
 C6	AIRBAG	3.0 V6 24v 155kw XFV	Pieton Shock Detection AUTODETECT
 C6	ANTITHEFT	2.2 HDI 16v 120kw 4HP-FAP	Alarm PSA2 AUTODETECT
 C6	ANTITHEFT	2.2 HDI 16v 120kw 4HR-FAP	Alarm PSA2 AUTODETECT
 C6	ANTITHEFT	2.2 HDI 16v 125kw 4HS-FAP	Alarm PSA2 AUTODETECT
 C6	ANTITHEFT	2.2 HDI 16v 125kw 4HT-FAP	Alarm PSA2 AUTODETECT
 C6	ANTITHEFT	2.7 HDI V6 24v 150kw UHZ-FAP	Alarm PSA2 AUTODETECT
 C6	ANTITHEFT	3.0 HDI V6 24V 177kw X8Z	Alarm PSA2 AUTODETECT
 C6	ANTITHEFT	3.0 V6 24v 155kw XFV	Alarm PSA2 AUTODETECT
 C6	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HP-FAP	A/T AM6 AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C6	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HR-FAP	A/T AM6 AUTODETECT
 C6	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HS-FAP	A/T AM6 AUTODETECT
 C6	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HT-FAP	A/T AM6 AUTODETECT
 C6	AUTOM. TRANSMISSI	2.7 HDI V6 24v 150kw UHZ-FAP	A/T AM6 AUTODETECT
 C6	AUTOM. TRANSMISSI	3.0 HDI V6 24V 177kw X8Z	A/T AM6 AUTODETECT
 C6	AUTOM. TRANSMISSI	3.0 V6 24v 155kw XFV	A/T AM6 AUTODETECT
 C6	AUX. HEATING	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C6	AUX. HEATING	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C6	AUX. HEATING	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C6	AUX. HEATING	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C6	AUX. HEATING	2.7 HDI V6 24v 150kw UHZ-FAP	AUTODETECT
 C6	AUX. HEATING	3.0 HDI V6 24V 177kw X8Z	AUTODETECT
 C6	AUX. HEATING	3.0 V6 24v 155kw XFV	AUTODETECT
 C6	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP-FAP	Body Computer BSC AUTODETECT
 C6	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP-FAP	Body Computer BSI AUTODETECT
 C6	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP-FAP	Body Computer BSM AUTODETECT
 C6	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP-FAP	Body Computer BSR AUTODETECT
 C6	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP-FAP	Rear Body Computer AUTODETECT
 C6	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HR-FAP	Body Computer BSC AUTODETECT
 C6	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HR-FAP	Body Computer BSI AUTODETECT
 C6	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HR-FAP	Body Computer BSM AUTODETECT
 C6	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HR-FAP	Body Computer BSR AUTODETECT
 C6	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HR-FAP	Rear Body Computer AUTODETECT
 C6	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HS-FAP	Body Computer BSC AUTODETECT
 C6	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HS-FAP	Body Computer BSI AUTODETECT
 C6	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HS-FAP	Body Computer BSM AUTODETECT
 C6	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HS-FAP	Body Computer BSR AUTODETECT
 C6	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HS-FAP	Rear Body Computer AUTODETECT
 C6	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP	Body Computer BSC AUTODETECT
 C6	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP	Body Computer BSI AUTODETECT
 C6	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP	Body Computer BSM AUTODETECT
 C6	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP	Body Computer BSR AUTODETECT
 C6	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP	Rear Body Computer AUTODETECT
 C6	CHASSIS NETWORK	2.7 HDI V6 24v 150kw UHZ-FAP	Body Computer BSC AUTODETECT
 C6	CHASSIS NETWORK	2.7 HDI V6 24v 150kw UHZ-FAP	Body Computer BSI AUTODETECT
 C6	CHASSIS NETWORK	2.7 HDI V6 24v 150kw UHZ-FAP	Body Computer BSM AUTODETECT
 C6	CHASSIS NETWORK	2.7 HDI V6 24v 150kw UHZ-FAP	Body Computer BSR AUTODETECT
 C6	CHASSIS NETWORK	2.7 HDI V6 24v 150kw UHZ-FAP	Rear Body Computer AUTODETECT
 C6	CHASSIS NETWORK	3.0 HDI V6 24V 177kw X8Z	Body Computer BSC AUTODETECT
 C6	CHASSIS NETWORK	3.0 HDI V6 24V 177kw X8Z	Body Computer BSI AUTODETECT
 C6	CHASSIS NETWORK	3.0 HDI V6 24V 177kw X8Z	Body Computer BSM AUTODETECT
 C6	CHASSIS NETWORK	3.0 HDI V6 24V 177kw X8Z	Body Computer BSR AUTODETECT
 C6	CHASSIS NETWORK	3.0 HDI V6 24V 177kw X8Z	Rear Body Computer AUTODETECT
 C6	CHASSIS NETWORK	3.0 V6 24v 155kw XFV	Body Computer BSC AUTODETECT
 C6	CHASSIS NETWORK	3.0 V6 24v 155kw XFV	Body Computer BSI AUTODETECT
 C6	CHASSIS NETWORK	3.0 V6 24v 155kw XFV	Body Computer BSM AUTODETECT
 C6	CHASSIS NETWORK	3.0 V6 24v 155kw XFV	Body Computer BSR AUTODETECT
 C6	CHASSIS NETWORK	3.0 V6 24v 155kw XFV	Rear Body Computer AUTODETECT
 C6	CLIMA	2.2 HDI 16v 120kw 4HP-FAP	CLIMA AUTODETECT
 C6	CLIMA	2.2 HDI 16v 120kw 4HR-FAP	CLIMA AUTODETECT
 C6	CLIMA	2.2 HDI 16v 125kw 4HS-FAP	CLIMA AUTODETECT
 C6	CLIMA	2.2 HDI 16v 125kw 4HT-FAP	CLIMA AUTODETECT
 C6	CLIMA	2.7 HDI V6 24v 150kw UHZ-FAP	CLIMA AUTODETECT
 C6	CLIMA	3.0 HDI V6 24V 177kw X8Z	CLIMA AUTODETECT
 C6	CLIMA	3.0 V6 24v 155kw XFV	CLIMA AUTODETECT
 C6	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C6	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C6	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HP-FAP	Left Seat Keyboard AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C6	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HP-FAP	Right Seat Keyboard AUTODETECT
 C6	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HP-FAP	Winshield projector AUTODETECT
 C6	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C6	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C6	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HR-FAP	Left Seat Keyboard AUTODETECT
 C6	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HR-FAP	Right Seat Keyboard AUTODETECT
 C6	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HR-FAP	Winshield projector AUTODETECT
 C6	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C6	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C6	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HS-FAP	Left Seat Keyboard AUTODETECT
 C6	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HS-FAP	Right Seat Keyboard AUTODETECT
 C6	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HS-FAP	Winshield projector AUTODETECT
 C6	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C6	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C6	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HT-FAP	Left Seat Keyboard AUTODETECT
 C6	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HT-FAP	Right Seat Keyboard AUTODETECT
 C6	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HT-FAP	Winshield projector AUTODETECT
 C6	COMFORT SYSTEM	2.7 HDI V6 24v 150kw UHZ-FAP	AUTODETECT
 C6	COMFORT SYSTEM	2.7 HDI V6 24v 150kw UHZ-FAP	AUTODETECT
 C6	COMFORT SYSTEM	2.7 HDI V6 24v 150kw UHZ-FAP	Left Seat Keyboard AUTODETECT
 C6	COMFORT SYSTEM	2.7 HDI V6 24v 150kw UHZ-FAP	Right Seat Keyboard AUTODETECT
 C6	COMFORT SYSTEM	2.7 HDI V6 24v 150kw UHZ-FAP	Winshield projector AUTODETECT
 C6	COMFORT SYSTEM	3.0 HDI V6 24V 177kw X8Z	AUTODETECT
 C6	COMFORT SYSTEM	3.0 HDI V6 24V 177kw X8Z	AUTODETECT
 C6	COMFORT SYSTEM	3.0 HDI V6 24V 177kw X8Z	Left Seat Keyboard AUTODETECT
 C6	COMFORT SYSTEM	3.0 HDI V6 24V 177kw X8Z	Right Seat Keyboard AUTODETECT
 C6	COMFORT SYSTEM	3.0 HDI V6 24V 177kw X8Z	Winshield projector AUTODETECT
 C6	COMFORT SYSTEM	3.0 V6 24v 155kw XFV	AUTODETECT
 C6	COMFORT SYSTEM	3.0 V6 24v 155kw XFV	COMFORT AUTODETECT
 C6	COMFORT SYSTEM	3.0 V6 24v 155kw XFV	Left Seat Keyboard AUTODETECT
 C6	COMFORT SYSTEM	3.0 V6 24v 155kw XFV	Right Seat Keyboard AUTODETECT
 C6	COMFORT SYSTEM	3.0 V6 24v 155kw XFV	Winshield projector AUTODETECT
 C6	DASHBOARD	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C6	DASHBOARD	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C6	DASHBOARD	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C6	DASHBOARD	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C6	DASHBOARD	2.7 HDI V6 24v 150kw UHZ-FAP	AUTODETECT
 C6	DASHBOARD	3.0 HDI V6 24V 177kw X8Z	AUTODETECT
 C6	DASHBOARD	3.0 V6 24v 155kw XFV	AUTODETECT
 C6	DRIVER SEAT CONT	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C6	DRIVER SEAT CONT	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C6	DRIVER SEAT CONT	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C6	DRIVER SEAT CONT	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C6	DRIVER SEAT CONT	2.7 HDI V6 24v 150kw UHZ-FAP	AUTODETECT
 C6	DRIVER SEAT CONT	3.0 HDI V6 24V 177kw X8Z	AUTODETECT
 C6	DRIVER SEAT CONT	3.0 V6 24v 155kw XFV	AUTODETECT
 C6	DRIVER SIDE DOOR	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C6	DRIVER SIDE DOOR	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C6	DRIVER SIDE DOOR	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C6	DRIVER SIDE DOOR	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C6	DRIVER SIDE DOOR	2.7 HDI V6 24v 150kw UHZ-FAP	AUTODETECT
 C6	DRIVER SIDE DOOR	3.0 HDI V6 24V 177kw X8Z	AUTODETECT
 C6	DRIVER SIDE DOOR	3.0 V6 24v 155kw XFV	AUTODETECT
 C6	ELECTRIC STEERING	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C6	ELECTRIC STEERING	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C6	ELECTRIC STEERING	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C6	ELECTRIC STEERING	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C6	ELECTRIC STEERING	2.7 HDI V6 24v 150kw UHZ-FAP	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C6	ELECTRIC STEERING	3.0 HDI V6 24V 177kw X8Z	AUTODETECT
 C6	ELECTRIC STEERING	3.0 V6 24v 155kw XFV	AUTODETECT
 C6	ENGINE MANAGEME	2.2 HDI 16v 120kw 4HP-FAP	BOSCH EDC16 CP39 Common Rail AUTO
 C6	ENGINE MANAGEME	2.2 HDI 16v 120kw 4HR-FAP	BOSCH EDC16 CP39 Common Rail AUTO
 C6	ENGINE MANAGEME	2.2 HDI 16v 125kw 4HS-FAP	BOSCH EDC16 CP39 Common Rail AUTO
 C6	ENGINE MANAGEME	2.2 HDI 16v 125kw 4HT-FAP	BOSCH EDC16 CP39 Common Rail AUTO
 C6	ENGINE MANAGEME	2.7 HDI V6 24v 150kw UHZ-FAP	SIEMENS SID 201 Common Rail AUTODE
 C6	ENGINE MANAGEME	3.0 HDI V6 24V 177kw X8Z	EOBD
 C6	ENGINE MANAGEME	3.0 V6 24v 155kw XFV	BOSCH ME 7.4.7 AUTODETECT
 C6	LANE CHANGE ASSY	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C6	LANE CHANGE ASSY	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C6	LANE CHANGE ASSY	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C6	LANE CHANGE ASSY	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C6	LANE CHANGE ASSY	2.7 HDI V6 24v 150kw UHZ-FAP	AUTODETECT
 C6	LANE CHANGE ASSY	3.0 HDI V6 24V 177kw X8Z	AUTODETECT
 C6	LANE CHANGE ASSY	3.0 V6 24v 155kw XFV	AUTODETECT
 C6	LH RIGHT MODULATI	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C6	LH RIGHT MODULATI	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C6	LH RIGHT MODULATI	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C6	LH RIGHT MODULATI	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C6	LH RIGHT MODULATI	2.7 HDI V6 24v 150kw UHZ-FAP	AUTODETECT
 C6	LH RIGHT MODULATI	3.0 HDI V6 24V 177kw X8Z	AUTODETECT
 C6	LH RIGHT MODULATI	3.0 V6 24v 155kw XFV	AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 120kw 4HP-FAP	A/T AM6 AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 120kw 4HP-FAP	A/T AM6 AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 120kw 4HP-FAP	AirBag CENTRAL AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 120kw 4HP-FAP	AirBag CENTRAL AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 120kw 4HP-FAP	BOSCH EDC16 CP39 Common Rail AUTO
 C6	MAINTENANCE	2.2 HDI 16v 120kw 4HP-FAP	ESP 8.1 AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 120kw 4HP-FAP	ESP 8.1 AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 120kw 4HP-FAP	ESP AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 120kw 4HP-FAP	ESP AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 120kw 4HP-FAP	Siemens-JCAE AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 120kw 4HP-FAP	Siemens-JCAE AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 120kw 4HP-FAP	Siemens-JCAE AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 120kw 4HP-FAP	Siemens-JCAE AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 120kw 4HP-FAP	Variable shock absorber AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 120kw 4HP-FAP	Variable shock absorber AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 120kw 4HR-FAP	A/T AM6 AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 120kw 4HR-FAP	A/T AM6 AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 120kw 4HR-FAP	AirBag CENTRAL AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 120kw 4HR-FAP	AirBag CENTRAL AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 120kw 4HR-FAP	BOSCH EDC16 CP39 Common Rail AUTO
 C6	MAINTENANCE	2.2 HDI 16v 120kw 4HR-FAP	ESP 8.1 AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 120kw 4HR-FAP	ESP 8.1 AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 120kw 4HR-FAP	ESP AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 120kw 4HR-FAP	ESP AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 120kw 4HR-FAP	Siemens-JCAE AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 120kw 4HR-FAP	Siemens-JCAE AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 120kw 4HR-FAP	Siemens-JCAE AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 120kw 4HR-FAP	Siemens-JCAE AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 120kw 4HR-FAP	Variable shock absorber AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 120kw 4HR-FAP	Variable shock absorber AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP	A/T AM6 AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP	A/T AM6 AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP	AirBag CENTRAL AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP	AirBag CENTRAL AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP	BOSCH EDC16 CP39 Common Rail AUTO

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C6	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP	ESP 8.1 AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP	ESP 8.1 AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP	ESP AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP	ESP AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP	Siemens-JCAE AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP	Siemens-JCAE AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP	Siemens-JCAE AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP	Siemens-JCAE AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP	Variable shock absorber AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP	Variable shock absorber AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	A/T AM6 AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	A/T AM6 AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	AirBag CENTRAL AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	AirBag CENTRAL AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	BOSCH EDC16 CP39 Common Rail AUTO
 C6	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	ESP 8.1 AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	ESP 8.1 AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	ESP AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	ESP AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	Siemens-JCAE AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	Siemens-JCAE AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	Siemens-JCAE AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	Siemens-JCAE AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	Variable shock absorber AUTODETECT
 C6	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	Variable shock absorber AUTODETECT
 C6	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	A/T AM6 AUTODETECT
 C6	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	A/T AM6 AUTODETECT
 C6	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	AirBag CENTRAL AUTODETECT
 C6	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	AirBag CENTRAL AUTODETECT
 C6	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	ESP 8.1 AUTODETECT
 C6	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	ESP 8.1 AUTODETECT
 C6	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	ESP AUTODETECT
 C6	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	ESP AUTODETECT
 C6	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	SIEMENS SID 201 Common Rail AUTODE
 C6	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	SIEMENS SID 201 Common Rail AUTODE
 C6	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	SIEMENS SID 201 Common Rail AUTODE
 C6	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	SIEMENS SID 201 Common Rail AUTODE
 C6	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	SIEMENS SID 201 Common Rail AUTODE
 C6	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Siemens-JCAE AUTODETECT
 C6	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Siemens-JCAE AUTODETECT
 C6	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Siemens-JCAE AUTODETECT
 C6	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Siemens-JCAE AUTODETECT
 C6	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Variable shock absorber AUTODETECT
 C6	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Variable shock absorber AUTODETECT
 C6	MAINTENANCE	3.0 HDI V6 24V 177kw X8Z	A/T AM6 AUTODETECT
 C6	MAINTENANCE	3.0 HDI V6 24V 177kw X8Z	A/T AM6 AUTODETECT
 C6	MAINTENANCE	3.0 HDI V6 24V 177kw X8Z	AirBag CENTRAL AUTODETECT
 C6	MAINTENANCE	3.0 HDI V6 24V 177kw X8Z	AirBag CENTRAL AUTODETECT
 C6	MAINTENANCE	3.0 HDI V6 24V 177kw X8Z	ESP 8.1 AUTODETECT
 C6	MAINTENANCE	3.0 HDI V6 24V 177kw X8Z	ESP 8.1 AUTODETECT
 C6	MAINTENANCE	3.0 HDI V6 24V 177kw X8Z	ESP AUTODETECT
 C6	MAINTENANCE	3.0 HDI V6 24V 177kw X8Z	ESP AUTODETECT
 C6	MAINTENANCE	3.0 HDI V6 24V 177kw X8Z	Siemens-JCAE AUTODETECT
 C6	MAINTENANCE	3.0 HDI V6 24V 177kw X8Z	Siemens-JCAE AUTODETECT
 C6	MAINTENANCE	3.0 HDI V6 24V 177kw X8Z	Siemens-JCAE AUTODETECT
 C6	MAINTENANCE	3.0 HDI V6 24V 177kw X8Z	Siemens-JCAE AUTODETECT
 C6	MAINTENANCE	3.0 HDI V6 24V 177kw X8Z	Variable shock absorber AUTODETECT
 C6	MAINTENANCE	3.0 HDI V6 24V 177kw X8Z	Variable shock absorber AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C6	MAINTENANCE	3.0 V6 24v 155kw XFV	A/T AM6 AUTODETECT
 C6	MAINTENANCE	3.0 V6 24v 155kw XFV	A/T AM6 AUTODETECT
 C6	MAINTENANCE	3.0 V6 24v 155kw XFV	AirBag CENTRAL AUTODETECT
 C6	MAINTENANCE	3.0 V6 24v 155kw XFV	AirBag CENTRAL AUTODETECT
 C6	MAINTENANCE	3.0 V6 24v 155kw XFV	ESP 8.1 AUTODETECT
 C6	MAINTENANCE	3.0 V6 24v 155kw XFV	ESP 8.1 AUTODETECT
 C6	MAINTENANCE	3.0 V6 24v 155kw XFV	ESP AUTODETECT
 C6	MAINTENANCE	3.0 V6 24v 155kw XFV	ESP AUTODETECT
 C6	MAINTENANCE	3.0 V6 24v 155kw XFV	Siemens-JCAE AUTODETECT
 C6	MAINTENANCE	3.0 V6 24v 155kw XFV	Siemens-JCAE AUTODETECT
 C6	MAINTENANCE	3.0 V6 24v 155kw XFV	Siemens-JCAE AUTODETECT
 C6	MAINTENANCE	3.0 V6 24v 155kw XFV	Siemens-JCAE AUTODETECT
 C6	MAINTENANCE	3.0 V6 24v 155kw XFV	Variable shock absorber AUTODETECT
 C6	MAINTENANCE	3.0 V6 24v 155kw XFV	Variable shock absorber AUTODETECT
 C6	NAVIGATION	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C6	NAVIGATION	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C6	NAVIGATION	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C6	NAVIGATION	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C6	NAVIGATION	2.7 HDI V6 24v 150kw UHZ-FAP	AUTODETECT
 C6	NAVIGATION	3.0 HDI V6 24V 177kw X8Z	AUTODETECT
 C6	NAVIGATION	3.0 V6 24v 155kw XFV	AUTODETECT
 C6	PARK.BRAKE	2.2 HDI 16v 120kw 4HP-FAP	Electrobrake AUTODETECT
 C6	PARK.BRAKE	2.2 HDI 16v 120kw 4HR-FAP	Electrobrake AUTODETECT
 C6	PARK.BRAKE	2.2 HDI 16v 125kw 4HS-FAP	Electrobrake AUTODETECT
 C6	PARK.BRAKE	2.2 HDI 16v 125kw 4HT-FAP	Electrobrake AUTODETECT
 C6	PARK.BRAKE	2.7 HDI V6 24v 150kw UHZ-FAP	Electrobrake AUTODETECT
 C6	PARK.BRAKE	3.0 HDI V6 24V 177kw X8Z	Electrobrake AUTODETECT
 C6	PARK.BRAKE	3.0 V6 24v 155kw XFV	Electrobrake AUTODETECT
 C6	PARKING HELP	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C6	PARKING HELP	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C6	PARKING HELP	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C6	PARKING HELP	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C6	PARKING HELP	2.7 HDI V6 24v 150kw UHZ-FAP	AUTODETECT
 C6	PARKING HELP	3.0 HDI V6 24V 177kw X8Z	AUTODETECT
 C6	PARKING HELP	3.0 V6 24v 155kw XFV	AUTODETECT
 C6	PASS. SIDE DOOR	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C6	PASS. SIDE DOOR	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C6	PASS. SIDE DOOR	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C6	PASS. SIDE DOOR	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C6	PASS. SIDE DOOR	2.7 HDI V6 24v 150kw UHZ-FAP	AUTODETECT
 C6	PASS. SIDE DOOR	3.0 HDI V6 24V 177kw X8Z	AUTODETECT
 C6	PASS. SIDE DOOR	3.0 V6 24v 155kw XFV	AUTODETECT
 C6	PASSENGER SEAT R	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C6	PASSENGER SEAT R	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C6	PASSENGER SEAT R	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C6	PASSENGER SEAT R	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C6	PASSENGER SEAT R	2.7 HDI V6 24v 150kw UHZ-FAP	AUTODETECT
 C6	PASSENGER SEAT R	3.0 HDI V6 24V 177kw X8Z	AUTODETECT
 C6	PASSENGER SEAT R	3.0 V6 24v 155kw XFV	AUTODETECT
 C6	PHONE	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C6	PHONE	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C6	PHONE	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C6	PHONE	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C6	PHONE	2.7 HDI V6 24v 150kw UHZ-FAP	AUTODETECT
 C6	PHONE	3.0 HDI V6 24V 177kw X8Z	AUTODETECT
 C6	PHONE	3.0 V6 24v 155kw XFV	AUTODETECT
 C6	RADIO / CD	2.2 HDI 16v 120kw 4HP-FAP	AudioSystem AUTODETECT
 C6	RADIO / CD	2.2 HDI 16v 120kw 4HP-FAP	CD Changer AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C6	RADIO / CD	2.2 HDI 16v 120kw 4HR-FAP	AudioSystem AUTODETECT
 C6	RADIO / CD	2.2 HDI 16v 120kw 4HR-FAP	CD Changer AUTODETECT
 C6	RADIO / CD	2.2 HDI 16v 125kw 4HS-FAP	AudioSystem AUTODETECT
 C6	RADIO / CD	2.2 HDI 16v 125kw 4HS-FAP	CD Changer AUTODETECT
 C6	RADIO / CD	2.2 HDI 16v 125kw 4HT-FAP	AudioSystem AUTODETECT
 C6	RADIO / CD	2.2 HDI 16v 125kw 4HT-FAP	CD Changer AUTODETECT
 C6	RADIO / CD	2.7 HDI V6 24v 150kw UHZ-FAP	AudioSystem AUTODETECT
 C6	RADIO / CD	2.7 HDI V6 24v 150kw UHZ-FAP	CD Changer AUTODETECT
 C6	RADIO / CD	3.0 HDI V6 24V 177kw X8Z	AudioSystem AUTODETECT
 C6	RADIO / CD	3.0 HDI V6 24V 177kw X8Z	CD Changer AUTODETECT
 C6	RADIO / CD	3.0 V6 24v 155kw XFV	AudioSystem AUTODETECT
 C6	RADIO / CD	3.0 V6 24v 155kw XFV	CD Changer AUTODETECT
 C6	RAIN-LUMINOSITY S	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C6	RAIN-LUMINOSITY S	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C6	RAIN-LUMINOSITY S	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C6	RAIN-LUMINOSITY S	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C6	RAIN-LUMINOSITY S	2.7 HDI V6 24v 150kw UHZ-FAP	AUTODETECT
 C6	RAIN-LUMINOSITY S	3.0 HDI V6 24V 177kw X8Z	AUTODETECT
 C6	RAIN-LUMINOSITY S	3.0 V6 24v 155kw XFV	AUTODETECT
 C6	REAR CLIMA	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C6	REAR CLIMA	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C6	REAR CLIMA	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C6	REAR CLIMA	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C6	REAR CLIMA	2.7 HDI V6 24v 150kw UHZ-FAP	AUTODETECT
 C6	REAR CLIMA	3.0 HDI V6 24V 177kw X8Z	AUTODETECT
 C6	REAR CLIMA	3.0 V6 24v 155kw XFV	AUTODETECT
 C6	RH LIGHT MODULATI	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C6	RH LIGHT MODULATI	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C6	RH LIGHT MODULATI	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C6	RH LIGHT MODULATI	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C6	RH LIGHT MODULATI	2.7 HDI V6 24v 150kw UHZ-FAP	AUTODETECT
 C6	RH LIGHT MODULATI	3.0 HDI V6 24V 177kw X8Z	AUTODETECT
 C6	RH LIGHT MODULATI	3.0 V6 24v 155kw XFV	AUTODETECT
 C6	SPOILER CONTROL	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C6	SPOILER CONTROL	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C6	SPOILER CONTROL	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C6	SPOILER CONTROL	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C6	SPOILER CONTROL	2.7 HDI V6 24v 150kw UHZ-FAP	AUTODETECT
 C6	SPOILER CONTROL	3.0 HDI V6 24V 177kw X8Z	AUTODETECT
 C6	SPOILER CONTROL	3.0 V6 24v 155kw XFV	AUTODETECT
 C6	STEERING COLUMN	2.2 HDI 16v 120kw 4HP-FAP	AUTODETECT
 C6	STEERING COLUMN	2.2 HDI 16v 120kw 4HR-FAP	AUTODETECT
 C6	STEERING COLUMN	2.2 HDI 16v 125kw 4HS-FAP	AUTODETECT
 C6	STEERING COLUMN	2.2 HDI 16v 125kw 4HT-FAP	AUTODETECT
 C6	STEERING COLUMN	2.7 HDI V6 24v 150kw UHZ-FAP	AUTODETECT
 C6	STEERING COLUMN	3.0 HDI V6 24V 177kw X8Z	AUTODETECT
 C6	STEERING COLUMN	3.0 V6 24v 155kw XFV	AUTODETECT
 C6	SUSPENSION CONTR	2.2 HDI 16v 120kw 4HP-FAP	HYDRACTIVE AUTODETECT
 C6	SUSPENSION CONTR	2.2 HDI 16v 120kw 4HP-FAP	Variable shock absorber AUTODETECT
 C6	SUSPENSION CONTR	2.2 HDI 16v 120kw 4HR-FAP	HYDRACTIVE AUTODETECT
 C6	SUSPENSION CONTR	2.2 HDI 16v 120kw 4HR-FAP	Variable shock absorber AUTODETECT
 C6	SUSPENSION CONTR	2.2 HDI 16v 125kw 4HS-FAP	HYDRACTIVE AUTODETECT
 C6	SUSPENSION CONTR	2.2 HDI 16v 125kw 4HS-FAP	Variable shock absorber AUTODETECT
 C6	SUSPENSION CONTR	2.2 HDI 16v 125kw 4HT-FAP	HYDRACTIVE AUTODETECT
 C6	SUSPENSION CONTR	2.2 HDI 16v 125kw 4HT-FAP	Variable shock absorber AUTODETECT
 C6	SUSPENSION CONTR	2.7 HDI V6 24v 150kw UHZ-FAP	HYDRACTIVE AUTODETECT
 C6	SUSPENSION CONTR	2.7 HDI V6 24v 150kw UHZ-FAP	Variable shock absorber AUTODETECT
 C6	SUSPENSION CONTR	3.0 HDI V6 24V 177kw X8Z	HYDRACTIVE AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C6	SUSPENSION CONTR	3.0 HDI V6 24V 177kw X8Z	Variable shock absorber AUTODETECT
 C6	SUSPENSION CONTR	3.0 V6 24v 155kw XFV	HYDRACTIVE AUTODETECT
 C6	SUSPENSION CONTR	3.0 V6 24v 155kw XFV	Variable shock absorber AUTODETECT
 C6	TIRE PRESSURE	2.2 HDI 16v 120kw 4HP-FAP	Siemens-JCAE AUTODETECT
 C6	TIRE PRESSURE	2.2 HDI 16v 120kw 4HR-FAP	Siemens-JCAE AUTODETECT
 C6	TIRE PRESSURE	2.2 HDI 16v 125kw 4HS-FAP	Siemens-JCAE AUTODETECT
 C6	TIRE PRESSURE	2.2 HDI 16v 125kw 4HT-FAP	Siemens-JCAE AUTODETECT
 C6	TIRE PRESSURE	2.7 HDI V6 24v 150kw UHZ-FAP	Siemens-JCAE AUTODETECT
 C6	TIRE PRESSURE	3.0 HDI V6 24V 177kw X8Z	Siemens-JCAE AUTODETECT
 C6	TIRE PRESSURE	3.0 V6 24v 155kw XFV	Siemens-JCAE AUTODETECT
 C6	VISUAL./TELEMATIC	2.2 HDI 16v 120kw 4HP-FAP	Color Display C- Color AUTODETECT
 C6	VISUAL./TELEMATIC	2.2 HDI 16v 120kw 4HR-FAP	Color Display C- Color AUTODETECT
 C6	VISUAL./TELEMATIC	2.2 HDI 16v 125kw 4HS-FAP	Color Display C- Color AUTODETECT
 C6	VISUAL./TELEMATIC	2.2 HDI 16v 125kw 4HT-FAP	Color Display C- Color AUTODETECT
 C6	VISUAL./TELEMATIC	2.7 HDI V6 24v 150kw UHZ-FAP	Color Display C- Color AUTODETECT
 C6	VISUAL./TELEMATIC	3.0 HDI V6 24V 177kw X8Z	Color Display C- Color AUTODETECT
 C6	VISUAL./TELEMATIC	3.0 V6 24v 155kw XFV	Color Display C- Color AUTODETECT
 C8	ABS	2.0 16v 100kw RFN (...06)	BOSCH ABS ABR 5.7
 C8	ABS	2.0 16v 103kw RFJ (06-..)	BOSCH ABS/ESP 8.0
 C8	ABS	2.0 HDI 16v 100kw RHR-FAP (06-..)	BOSCH ABS/ESP 8.0
 C8	ABS	2.0 HDI 16v 120kw 4HP (06-..)	BOSCH ABS/ESP 8.0
 C8	ABS	2.0 HDI 16v 120kw 4HR (06-..)	BOSCH ABS/ESP 8.0
 C8	ABS	2.0 HDI 16v 79kw RHM-FAP (...06)	BOSCH ABS ABR 5.7
 C8	ABS	2.0 HDI 16v 79kw RHT-FAP (...06)	BOSCH ABS ABR 5.7
 C8	ABS	2.0 HDI 16v 80kw RHW (...06)	BOSCH ABS ABR 5.7
 C8	ABS	2.0 HDI 16v 88kw RHK (06-..)	BOSCH ABS/ESP 8.0
 C8	ABS	2.2 16v 116kw 3FZ (...06)	BOSCH ABS ABR 5.7
 C8	ABS	2.2 HDI 16v 125kw 4HS (06-..)	BOSCH ABS/ESP 8.0
 C8	ABS	2.2 HDI 16v 125kw 4HT-FAP (06-..)	BOSCH ABS/ESP 8.0
 C8	ABS	2.2 HDI 16v 94kw 4HW-FAP (...06)	BOSCH ABS ABR 5.7
 C8	ABS	3.0 V6 24v 150kw XFW (...06)	BOSCH ABS ABR 5.7
 C8	ABS + TRACT. CONT	2.0 16v 100kw RFN (...06)	BOSCH ABS/ESP 5.7
 C8	ABS + TRACT. CONT	2.0 16v 100kw RFN (...06)	BOSCH ESP 5.7 AUTODETECT
 C8	ABS + TRACT. CONT	2.0 16v 100kw RFN (...06)	BOSCH ESP 8.0 AUTODETECT
 C8	ABS + TRACT. CONT	2.0 16v 100kw RFN (...06)	BOSCH ESP 8.1 AUTODETECT
 C8	ABS + TRACT. CONT	2.0 16v 103kw RFJ (06-..)	BOSCH ESP 5.7 AUTODETECT
 C8	ABS + TRACT. CONT	2.0 16v 103kw RFJ (06-..)	BOSCH ESP 8.0 AUTODETECT
 C8	ABS + TRACT. CONT	2.0 16v 103kw RFJ (06-..)	BOSCH ESP 8.1 AUTODETECT
 C8	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP (06-..)	BOSCH ESP 5.7 AUTODETECT
 C8	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP (06-..)	BOSCH ESP 8.0 AUTODETECT
 C8	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP (06-..)	BOSCH ESP 8.1 AUTODETECT
 C8	ABS + TRACT. CONT	2.0 HDI 16v 79kw RHM-FAP (...06)	BOSCH ABS/ESP 5.7
 C8	ABS + TRACT. CONT	2.0 HDI 16v 79kw RHM-FAP (...06)	BOSCH ESP 5.7 AUTODETECT
 C8	ABS + TRACT. CONT	2.0 HDI 16v 79kw RHM-FAP (...06)	BOSCH ESP 8.0 AUTODETECT
 C8	ABS + TRACT. CONT	2.0 HDI 16v 79kw RHM-FAP (...06)	BOSCH ESP 8.1 AUTODETECT
 C8	ABS + TRACT. CONT	2.0 HDI 16v 79kw RHT-FAP (...06)	BOSCH ABS/ESP 5.7
 C8	ABS + TRACT. CONT	2.0 HDI 16v 79kw RHT-FAP (...06)	BOSCH ESP 5.7 AUTODETECT
 C8	ABS + TRACT. CONT	2.0 HDI 16v 79kw RHT-FAP (...06)	BOSCH ESP 8.0 AUTODETECT
 C8	ABS + TRACT. CONT	2.0 HDI 16v 79kw RHT-FAP (...06)	BOSCH ESP 8.1 AUTODETECT
 C8	ABS + TRACT. CONT	2.0 HDI 16v 80kw RHW (...06)	BOSCH ABS/ESP 5.7
 C8	ABS + TRACT. CONT	2.0 HDI 16v 80kw RHW (...06)	BOSCH ESP 5.7 AUTODETECT
 C8	ABS + TRACT. CONT	2.0 HDI 16v 80kw RHW (...06)	BOSCH ESP 8.0 AUTODETECT
 C8	ABS + TRACT. CONT	2.0 HDI 16v 80kw RHW (...06)	BOSCH ESP 8.1 AUTODETECT
 C8	ABS + TRACT. CONT	2.0 HDI 16v 88kw RHK (06-..)	BOSCH ESP 5.7 AUTODETECT
 C8	ABS + TRACT. CONT	2.0 HDI 16v 88kw RHK (06-..)	BOSCH ESP 8.0 AUTODETECT
 C8	ABS + TRACT. CONT	2.0 HDI 16v 88kw RHK (06-..)	BOSCH ESP 8.1 AUTODETECT
 C8	ABS + TRACT. CONT	2.2 16v 116kw 3FZ (...06)	BOSCH ABS/ESP 5.7
 C8	ABS + TRACT. CONT	2.2 16v 116kw 3FZ (...06)	BOSCH ESP 5.7 AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C8	ABS + TRACT. CONT	2.2 16v 116kw 3FZ (...-06)	BOSCH ESP 8.0 AUTODETECT
 C8	ABS + TRACT. CONT	2.2 16v 116kw 3FZ (...-06)	BOSCH ESP 8.1 AUTODETECT
 C8	ABS + TRACT. CONT	2.2 HDI 16v 120kw 4HP (06-..)	BOSCH ESP 5.7 AUTODETECT
 C8	ABS + TRACT. CONT	2.2 HDI 16v 120kw 4HP (06-..)	BOSCH ESP 8.0 AUTODETECT
 C8	ABS + TRACT. CONT	2.2 HDI 16v 120kw 4HP (06-..)	BOSCH ESP 8.1 AUTODETECT
 C8	ABS + TRACT. CONT	2.2 HDI 16v 120kw 4HR (06-..)	BOSCH ESP 5.7 AUTODETECT
 C8	ABS + TRACT. CONT	2.2 HDI 16v 120kw 4HR (06-..)	BOSCH ESP 8.0 AUTODETECT
 C8	ABS + TRACT. CONT	2.2 HDI 16v 120kw 4HR (06-..)	BOSCH ESP 8.1 AUTODETECT
 C8	ABS + TRACT. CONT	2.2 HDI 16v 125kw 4HS (06-..)	BOSCH ESP 5.7 AUTODETECT
 C8	ABS + TRACT. CONT	2.2 HDI 16v 125kw 4HS (06-..)	BOSCH ESP 8.0 AUTODETECT
 C8	ABS + TRACT. CONT	2.2 HDI 16v 125kw 4HS (06-..)	BOSCH ESP 8.1 AUTODETECT
 C8	ABS + TRACT. CONT	2.2 HDI 16v 125kw 4HT-FAP (06-..)	BOSCH ESP 5.7 AUTODETECT
 C8	ABS + TRACT. CONT	2.2 HDI 16v 125kw 4HT-FAP (06-..)	BOSCH ESP 8.0 AUTODETECT
 C8	ABS + TRACT. CONT	2.2 HDI 16v 125kw 4HT-FAP (06-..)	BOSCH ESP 8.1 AUTODETECT
 C8	ABS + TRACT. CONT	2.2 HDI 16v 94kw 4HW-FAP (...-06)	BOSCH ABS/ESP 5.7
 C8	ABS + TRACT. CONT	2.2 HDI 16v 94kw 4HW-FAP (...-06)	BOSCH ESP 5.7 AUTODETECT
 C8	ABS + TRACT. CONT	2.2 HDI 16v 94kw 4HW-FAP (...-06)	BOSCH ESP 8.0 AUTODETECT
 C8	ABS + TRACT. CONT	2.2 HDI 16v 94kw 4HW-FAP (...-06)	BOSCH ESP 8.1 AUTODETECT
 C8	ABS + TRACT. CONT	3.0 V6 24v 150kw XFW (...-06)	BOSCH ABS/ESP 5.7
 C8	ABS + TRACT. CONT	3.0 V6 24v 150kw XFW (...-06)	BOSCH ESP 5.7 AUTODETECT
 C8	ABS + TRACT. CONT	3.0 V6 24v 150kw XFW (...-06)	BOSCH ESP 8.0 AUTODETECT
 C8	ABS + TRACT. CONT	3.0 V6 24v 150kw XFW (...-06)	BOSCH ESP 8.1 AUTODETECT
 C8	AIRBAG	2.0 16v 100kw RFN (...-06)	AirBag CENTRAL AUTODETECT
 C8	AIRBAG	2.0 16v 100kw RFN (...-06)	TEMIC AirBag
 C8	AIRBAG	2.0 16v 103kw RFJ (06-..)	AirBag CENTRAL AUTODETECT
 C8	AIRBAG	2.0 16v 103kw RFJ (06-..)	TEMIC AirBag
 C8	AIRBAG	2.0 HDI 16v 100kw RHR-FAP (06-..)	AirBag CENTRAL AUTODETECT
 C8	AIRBAG	2.0 HDI 16v 100kw RHR-FAP (06-..)	TEMIC AirBag
 C8	AIRBAG	2.0 HDI 16v 120kw 4HP (06-..)	TEMIC AirBag
 C8	AIRBAG	2.0 HDI 16v 120kw 4HR (06-..)	TEMIC AirBag
 C8	AIRBAG	2.0 HDI 16v 79kw RHM-FAP (...-06)	AirBag CENTRAL AUTODETECT
 C8	AIRBAG	2.0 HDI 16v 79kw RHM-FAP (...-06)	TEMIC AirBag
 C8	AIRBAG	2.0 HDI 16v 79kw RHT-FAP (...-06)	AirBag CENTRAL AUTODETECT
 C8	AIRBAG	2.0 HDI 16v 79kw RHT-FAP (...-06)	TEMIC AirBag
 C8	AIRBAG	2.0 HDI 16v 80kw RHW (...-06)	AirBag CENTRAL AUTODETECT
 C8	AIRBAG	2.0 HDI 16v 80kw RHW (...-06)	TEMIC AirBag
 C8	AIRBAG	2.0 HDI 16v 88kw RHK (06-..)	AirBag CENTRAL AUTODETECT
 C8	AIRBAG	2.0 HDI 16v 88kw RHK (06-..)	TEMIC AirBag
 C8	AIRBAG	2.2 16v 116kw 3FZ (...-06)	AirBag CENTRAL AUTODETECT
 C8	AIRBAG	2.2 16v 116kw 3FZ (...-06)	TEMIC AirBag
 C8	AIRBAG	2.2 HDI 16v 120kw 4HP (06-..)	AirBag CENTRAL AUTODETECT
 C8	AIRBAG	2.2 HDI 16v 120kw 4HR (06-..)	AirBag CENTRAL AUTODETECT
 C8	AIRBAG	2.2 HDI 16v 125kw 4HS (06-..)	AirBag CENTRAL AUTODETECT
 C8	AIRBAG	2.2 HDI 16v 125kw 4HS (06-..)	TEMIC AirBag
 C8	AIRBAG	2.2 HDI 16v 125kw 4HT-FAP (06-..)	AirBag CENTRAL AUTODETECT
 C8	AIRBAG	2.2 HDI 16v 125kw 4HT-FAP (06-..)	TEMIC AirBag
 C8	AIRBAG	2.2 HDI 16v 94kw 4HW-FAP (...-06)	AirBag CENTRAL AUTODETECT
 C8	AIRBAG	2.2 HDI 16v 94kw 4HW-FAP (...-06)	TEMIC AirBag
 C8	AIRBAG	3.0 V6 24v 150kw XFW (...-06)	AirBag CENTRAL AUTODETECT
 C8	AIRBAG	3.0 V6 24v 150kw XFW (...-06)	TEMIC AirBag
 C8	ANTITHEFT	2.0 16v 100kw RFN (...-06)	Alarm PSA2 AUTODETECT
 C8	ANTITHEFT	2.0 HDI 16v 100kw RHR-FAP (06-..)	Alarm PSA2 AUTODETECT
 C8	ANTITHEFT	2.0 HDI 16v 79kw RHM-FAP (...-06)	Alarm PSA2 AUTODETECT
 C8	ANTITHEFT	2.0 HDI 16v 79kw RHT-FAP (...-06)	Alarm PSA2 AUTODETECT
 C8	ANTITHEFT	2.0 HDI 16v 80kw RHW (...-06)	Alarm PSA2 AUTODETECT
 C8	ANTITHEFT	2.0 HDI 16v 88kw RHK (06-..)	Alarm PSA2 AUTODETECT
 C8	ANTITHEFT	2.2 16v 116kw 3FZ (...-06)	Alarm PSA2 AUTODETECT
 C8	ANTITHEFT	2.2 HDI 16v 120kw 4HP (06-..)	Alarm PSA2 AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C8	ANTITHEFT	2.2 HDI 16v 120kw 4HR (06-..)	Alarm PSA2 AUTODETECT
 C8	ANTITHEFT	2.2 HDI 16v 125kw 4HS (06-..)	Alarm PSA2 AUTODETECT
 C8	ANTITHEFT	2.2 HDI 16v 125kw 4HT-FAP (06-..)	Alarm PSA2 AUTODETECT
 C8	ANTITHEFT	2.2 HDI 16v 94kw 4HW-FAP (...06)	Alarm PSA2 AUTODETECT
 C8	ANTITHEFT	3.0 V6 24v 150kw XFW (...06)	Alarm PSA2 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.0 16v 100kw RFN (...06)	A/T 4HP20 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.0 16v 100kw RFN (...06)	A/T AL4 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.0 16v 100kw RFN (...06)	A/T AM6 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ (06-..)	A/T 4HP20 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ (06-..)	A/T AL4 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ (06-..)	A/T AM6 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP (06-..)	A/T 4HP20 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP (06-..)	A/T AL4 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP (06-..)	A/T AM6 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.0 HDI 16v 79kw RHM-FAP (...06)	A/T 4HP20 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.0 HDI 16v 79kw RHM-FAP (...06)	A/T AL4 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.0 HDI 16v 79kw RHM-FAP (...06)	A/T AM6 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.0 HDI 16v 79kw RHT-FAP (...06)	A/T 4HP20 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.0 HDI 16v 79kw RHT-FAP (...06)	A/T AL4 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.0 HDI 16v 79kw RHT-FAP (...06)	A/T AM6 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.0 HDI 16v 80kw RHW (...06)	A/T 4HP20 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.0 HDI 16v 80kw RHW (...06)	A/T AL4 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.0 HDI 16v 80kw RHW (...06)	A/T AM6 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.0 HDI 16v 88kw RHK (06-..)	A/T 4HP20 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.0 HDI 16v 88kw RHK (06-..)	A/T AL4 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.0 HDI 16v 88kw RHK (06-..)	A/T AM6 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.2 16v 116kw 3FZ (...06)	A/T 4HP20 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.2 16v 116kw 3FZ (...06)	A/T AL4 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.2 16v 116kw 3FZ (...06)	A/T AM6 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HP (06-..)	A/T 4HP20 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HP (06-..)	A/T AL4 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HP (06-..)	A/T AM6 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HR (06-..)	A/T 4HP20 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HR (06-..)	A/T AL4 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HR (06-..)	A/T AM6 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HS (06-..)	A/T 4HP20 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HS (06-..)	A/T AL4 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HS (06-..)	A/T AM6 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HT-FAP (06-..)	A/T 4HP20 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HT-FAP (06-..)	A/T AL4 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HT-FAP (06-..)	A/T AM6 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.2 HDI 16v 94kw 4HW-FAP (...06)	A/T 4HP20 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.2 HDI 16v 94kw 4HW-FAP (...06)	A/T AL4 AUTODETECT
 C8	AUTOM. TRANSMISSI	2.2 HDI 16v 94kw 4HW-FAP (...06)	A/T AM6 AUTODETECT
 C8	AUTOM. TRANSMISSI	3.0 V6 24v 150kw XFW (...06)	A/T 4HP20 AUTODETECT
 C8	AUTOM. TRANSMISSI	3.0 V6 24v 150kw XFW (...06)	A/T AL4 AUTODETECT
 C8	AUTOM. TRANSMISSI	3.0 V6 24v 150kw XFW (...06)	A/T AM6 AUTODETECT
 C8	AUX. HEATING	2.0 16v 100kw RFN (...06)	AUTODETECT
 C8	AUX. HEATING	2.0 16v 103kw RFJ (06-..)	AUTODETECT
 C8	AUX. HEATING	2.0 HDI 16v 100kw RHR-FAP (06-..)	AUTODETECT
 C8	AUX. HEATING	2.0 HDI 16v 79kw RHM-FAP (...06)	AUTODETECT
 C8	AUX. HEATING	2.0 HDI 16v 79kw RHT-FAP (...06)	AUTODETECT
 C8	AUX. HEATING	2.0 HDI 16v 80kw RHW (...06)	AUTODETECT
 C8	AUX. HEATING	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 C8	AUX. HEATING	2.2 16v 116kw 3FZ (...06)	AUTODETECT
 C8	AUX. HEATING	2.2 HDI 16v 120kw 4HP (06-..)	AUTODETECT
 C8	AUX. HEATING	2.2 HDI 16v 120kw 4HR (06-..)	AUTODETECT
 C8	AUX. HEATING	2.2 HDI 16v 125kw 4HS (06-..)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C8	AUX. HEATING	2.2 HDI 16v 125kw 4HT-FAP (06-..)	AUTODETECT
 C8	AUX. HEATING	2.2 HDI 16v 94kw 4HW-FAP (...06)	AUTODETECT
 C8	AUX. HEATING	3.0 V6 24v 150kw XFW (...06)	AUTODETECT
 C8	CHASSIS NETWORK	2.0 16v 100kw RFN (...06)	Body Computer AUTODETECT
 C8	CHASSIS NETWORK	2.0 16v 100kw RFN (...06)	Body Computer BSI AUTODETECT
 C8	CHASSIS NETWORK	2.0 16v 100kw RFN (...06)	Body Computer BSM AUTODETECT
 C8	CHASSIS NETWORK	2.0 16v 100kw RFN (...06)	Body Computer BSR AUTODETECT
 C8	CHASSIS NETWORK	2.0 16v 100kw RFN (...06)	SAGEM Body Computer
 C8	CHASSIS NETWORK	2.0 16v 103kw RFJ (06-..)	Body Computer AUTODETECT
 C8	CHASSIS NETWORK	2.0 16v 103kw RFJ (06-..)	Body Computer BSI AUTODETECT
 C8	CHASSIS NETWORK	2.0 16v 103kw RFJ (06-..)	Body Computer BSM AUTODETECT
 C8	CHASSIS NETWORK	2.0 16v 103kw RFJ (06-..)	Body Computer BSR AUTODETECT
 C8	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP (06-..)	Body Computer AUTODETECT
 C8	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP (06-..)	Body Computer BSI AUTODETECT
 C8	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP (06-..)	Body Computer BSM AUTODETECT
 C8	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP (06-..)	Body Computer BSR AUTODETECT
 C8	CHASSIS NETWORK	2.0 HDI 16v 79kw RHM-FAP (...06)	Body Computer AUTODETECT
 C8	CHASSIS NETWORK	2.0 HDI 16v 79kw RHM-FAP (...06)	Body Computer BSI AUTODETECT
 C8	CHASSIS NETWORK	2.0 HDI 16v 79kw RHM-FAP (...06)	Body Computer BSM AUTODETECT
 C8	CHASSIS NETWORK	2.0 HDI 16v 79kw RHM-FAP (...06)	Body Computer BSR AUTODETECT
 C8	CHASSIS NETWORK	2.0 HDI 16v 79kw RHM-FAP (...06)	SAGEM Body Computer
 C8	CHASSIS NETWORK	2.0 HDI 16v 79kw RHT-FAP (...06)	Body Computer AUTODETECT
 C8	CHASSIS NETWORK	2.0 HDI 16v 79kw RHT-FAP (...06)	Body Computer BSI AUTODETECT
 C8	CHASSIS NETWORK	2.0 HDI 16v 79kw RHT-FAP (...06)	Body Computer BSM AUTODETECT
 C8	CHASSIS NETWORK	2.0 HDI 16v 79kw RHT-FAP (...06)	Body Computer BSR AUTODETECT
 C8	CHASSIS NETWORK	2.0 HDI 16v 79kw RHT-FAP (...06)	SAGEM Body Computer
 C8	CHASSIS NETWORK	2.0 HDI 16v 80kw RHW (...06)	Body Computer AUTODETECT
 C8	CHASSIS NETWORK	2.0 HDI 16v 80kw RHW (...06)	Body Computer BSI AUTODETECT
 C8	CHASSIS NETWORK	2.0 HDI 16v 80kw RHW (...06)	Body Computer BSM AUTODETECT
 C8	CHASSIS NETWORK	2.0 HDI 16v 80kw RHW (...06)	Body Computer BSR AUTODETECT
 C8	CHASSIS NETWORK	2.0 HDI 16v 80kw RHW (...06)	SAGEM Body Computer
 C8	CHASSIS NETWORK	2.0 HDI 16v 88kw RHK (06-..)	Body Computer AUTODETECT
 C8	CHASSIS NETWORK	2.0 HDI 16v 88kw RHK (06-..)	Body Computer BSI AUTODETECT
 C8	CHASSIS NETWORK	2.0 HDI 16v 88kw RHK (06-..)	Body Computer BSM AUTODETECT
 C8	CHASSIS NETWORK	2.0 HDI 16v 88kw RHK (06-..)	Body Computer BSR AUTODETECT
 C8	CHASSIS NETWORK	2.2 16v 116kw 3FZ (...06)	Body Computer AUTODETECT
 C8	CHASSIS NETWORK	2.2 16v 116kw 3FZ (...06)	Body Computer BSI AUTODETECT
 C8	CHASSIS NETWORK	2.2 16v 116kw 3FZ (...06)	Body Computer BSM AUTODETECT
 C8	CHASSIS NETWORK	2.2 16v 116kw 3FZ (...06)	Body Computer BSR AUTODETECT
 C8	CHASSIS NETWORK	2.2 16v 116kw 3FZ (...06)	SAGEM Body Computer
 C8	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP (06-..)	Body Computer AUTODETECT
 C8	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP (06-..)	Body Computer BSI AUTODETECT
 C8	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP (06-..)	Body Computer BSM AUTODETECT
 C8	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP (06-..)	Body Computer BSR AUTODETECT
 C8	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HR (06-..)	Body Computer AUTODETECT
 C8	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HR (06-..)	Body Computer BSI AUTODETECT
 C8	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HR (06-..)	Body Computer BSM AUTODETECT
 C8	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HR (06-..)	Body Computer BSR AUTODETECT
 C8	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HS (06-..)	Body Computer AUTODETECT
 C8	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HS (06-..)	Body Computer BSI AUTODETECT
 C8	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HS (06-..)	Body Computer BSM AUTODETECT
 C8	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HS (06-..)	Body Computer BSR AUTODETECT
 C8	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP (06-..)	Body Computer AUTODETECT
 C8	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP (06-..)	Body Computer BSI AUTODETECT
 C8	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP (06-..)	Body Computer BSM AUTODETECT
 C8	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP (06-..)	Body Computer BSR AUTODETECT
 C8	CHASSIS NETWORK	2.2 HDI 16v 94kw 4HW-FAP (...06)	Body Computer AUTODETECT
 C8	CHASSIS NETWORK	2.2 HDI 16v 94kw 4HW-FAP (...06)	Body Computer BSI AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C8	CHASSIS NETWORK	2.2 HDI 16v 94kw 4HW-FAP (...-06)	Body Computer BSM AUTODETECT
 C8	CHASSIS NETWORK	2.2 HDI 16v 94kw 4HW-FAP (...-06)	Body Computer BSR AUTODETECT
 C8	CHASSIS NETWORK	2.2 HDI 16v 94kw 4HW-FAP (...-06)	SAGEM Body Computer
 C8	CHASSIS NETWORK	3.0 V6 24v 150kw XFW (...-06)	AUTODETECT
 C8	CHASSIS NETWORK	3.0 V6 24v 150kw XFW (...-06)	Body Computer AUTODETECT
 C8	CHASSIS NETWORK	3.0 V6 24v 150kw XFW (...-06)	Body Computer BSI AUTODETECT
 C8	CHASSIS NETWORK	3.0 V6 24v 150kw XFW (...-06)	Body Computer BSM AUTODETECT
 C8	CHASSIS NETWORK	3.0 V6 24v 150kw XFW (...-06)	Body Computer BSR AUTODETECT
 C8	CHASSIS NETWORK	3.0 V6 24v 150kw XFW (...-06)	SAGEM Body Computer
 C8	CLIMA	2.0 16v 100kw RFN (...-06)	CLIMA AUTO AUTODETECT
 C8	CLIMA	2.0 16v 100kw RFN (...-06)	CLIMA AUTODETECT
 C8	CLIMA	2.0 16v 100kw RFN (...-06)	Marelli Klima
 C8	CLIMA	2.0 16v 103kw RFJ (06-..)	CLIMA AUTO AUTODETECT
 C8	CLIMA	2.0 16v 103kw RFJ (06-..)	CLIMA AUTODETECT
 C8	CLIMA	2.0 HDI 16v 100kw RHR-FAP (06-..)	CLIMA AUTO AUTODETECT
 C8	CLIMA	2.0 HDI 16v 100kw RHR-FAP (06-..)	CLIMA AUTODETECT
 C8	CLIMA	2.0 HDI 16v 79kw RHM-FAP (...-06)	CLIMA AUTO AUTODETECT
 C8	CLIMA	2.0 HDI 16v 79kw RHM-FAP (...-06)	CLIMA AUTODETECT
 C8	CLIMA	2.0 HDI 16v 79kw RHM-FAP (...-06)	Marelli Klima
 C8	CLIMA	2.0 HDI 16v 79kw RHT-FAP (...-06)	CLIMA AUTO AUTODETECT
 C8	CLIMA	2.0 HDI 16v 79kw RHT-FAP (...-06)	CLIMA AUTODETECT
 C8	CLIMA	2.0 HDI 16v 79kw RHT-FAP (...-06)	Marelli Klima
 C8	CLIMA	2.0 HDI 16v 80kw RHW (...-06)	CLIMA AUTO AUTODETECT
 C8	CLIMA	2.0 HDI 16v 80kw RHW (...-06)	CLIMA AUTODETECT
 C8	CLIMA	2.0 HDI 16v 80kw RHW (...-06)	Marelli Klima
 C8	CLIMA	2.0 HDI 16v 88kw RHK (06-..)	CLIMA AUTO AUTODETECT
 C8	CLIMA	2.0 HDI 16v 88kw RHK (06-..)	CLIMA AUTODETECT
 C8	CLIMA	2.2 16v 116kw 3FZ (...-06)	CLIMA AUTO AUTODETECT
 C8	CLIMA	2.2 16v 116kw 3FZ (...-06)	CLIMA AUTODETECT
 C8	CLIMA	2.2 16v 116kw 3FZ (...-06)	Marelli Klima
 C8	CLIMA	2.2 HDI 16v 120kw 4HP (06-..)	CLIMA AUTO AUTODETECT
 C8	CLIMA	2.2 HDI 16v 120kw 4HP (06-..)	CLIMA AUTODETECT
 C8	CLIMA	2.2 HDI 16v 120kw 4HR (06-..)	CLIMA AUTO AUTODETECT
 C8	CLIMA	2.2 HDI 16v 120kw 4HR (06-..)	CLIMA AUTODETECT
 C8	CLIMA	2.2 HDI 16v 125kw 4HS (06-..)	CLIMA AUTO AUTODETECT
 C8	CLIMA	2.2 HDI 16v 125kw 4HS (06-..)	CLIMA AUTODETECT
 C8	CLIMA	2.2 HDI 16v 125kw 4HT-FAP (06-..)	CLIMA AUTO AUTODETECT
 C8	CLIMA	2.2 HDI 16v 125kw 4HT-FAP (06-..)	CLIMA AUTODETECT
 C8	CLIMA	2.2 HDI 16v 94kw 4HW-FAP (...-06)	CLIMA AUTO AUTODETECT
 C8	CLIMA	2.2 HDI 16v 94kw 4HW-FAP (...-06)	CLIMA AUTODETECT
 C8	CLIMA	2.2 HDI 16v 94kw 4HW-FAP (...-06)	Marelli Klima
 C8	CLIMA	3.0 V6 24v 150kw XFW (...-06)	CLIMA AUTO AUTODETECT
 C8	CLIMA	3.0 V6 24v 150kw XFW (...-06)	CLIMA AUTODETECT
 C8	CLIMA	3.0 V6 24v 150kw XFW (...-06)	Marelli Klima
 C8	COMFORT SYSTEM	2.0 16v 100kw RFN (...-06)	Sliding side doors AUTODETECT
 C8	COMFORT SYSTEM	2.0 16v 103kw RFJ (06-..)	Sliding side doors AUTODETECT
 C8	COMFORT SYSTEM	2.0 HDI 16v 100kw RHR-FAP (06-..)	Sliding side doors AUTODETECT
 C8	COMFORT SYSTEM	2.0 HDI 16v 79kw RHM-FAP (...-06)	Sliding side doors AUTODETECT
 C8	COMFORT SYSTEM	2.0 HDI 16v 79kw RHT-FAP (...-06)	Sliding side doors AUTODETECT
 C8	COMFORT SYSTEM	2.0 HDI 16v 80kw RHW (...-06)	Sliding side doors AUTODETECT
 C8	COMFORT SYSTEM	2.0 HDI 16v 88kw RHK (06-..)	Sliding side doors AUTODETECT
 C8	COMFORT SYSTEM	2.2 16v 116kw 3FZ (...-06)	Sliding side doors AUTODETECT
 C8	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HP (06-..)	Sliding side doors AUTODETECT
 C8	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HR (06-..)	Sliding side doors AUTODETECT
 C8	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HS (06-..)	Sliding side doors AUTODETECT
 C8	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HT-FAP (06-..)	Sliding side doors AUTODETECT
 C8	COMFORT SYSTEM	2.2 HDI 16v 94kw 4HW-FAP (...-06)	Sliding side doors AUTODETECT
 C8	COMFORT SYSTEM	3.0 V6 24v 150kw XFW (...-06)	Sliding side doors AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C8	CONV. TOP/SUNROO	2.0 16v 100kw RFN (...06)	Central sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.0 16v 100kw RFN (...06)	Front sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.0 16v 100kw RFN (...06)	Rear sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.0 16v 103kw RFJ (06-..)	Central sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.0 16v 103kw RFJ (06-..)	Front sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.0 16v 103kw RFJ (06-..)	Rear sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.0 HDI 16v 100kw RHR-FAP (06-..)	Central sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.0 HDI 16v 100kw RHR-FAP (06-..)	Front sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.0 HDI 16v 100kw RHR-FAP (06-..)	Rear sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.0 HDI 16v 79kw RHM-FAP (...06)	Central sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.0 HDI 16v 79kw RHM-FAP (...06)	Front sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.0 HDI 16v 79kw RHM-FAP (...06)	Rear sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.0 HDI 16v 79kw RHT-FAP (...06)	Central sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.0 HDI 16v 79kw RHT-FAP (...06)	Front sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.0 HDI 16v 79kw RHT-FAP (...06)	Rear sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.0 HDI 16v 80kw RHW (...06)	Central sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.0 HDI 16v 80kw RHW (...06)	Front sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.0 HDI 16v 80kw RHW (...06)	Rear sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.0 HDI 16v 88kw RHK (06-..)	Central sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.0 HDI 16v 88kw RHK (06-..)	Front sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.0 HDI 16v 88kw RHK (06-..)	Rear sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.2 16v 116kw 3FZ (...06)	Central sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.2 16v 116kw 3FZ (...06)	Front sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.2 16v 116kw 3FZ (...06)	Rear sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.2 HDI 16v 120kw 4HP (06-..)	Central sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.2 HDI 16v 120kw 4HP (06-..)	Front sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.2 HDI 16v 120kw 4HP (06-..)	Rear sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.2 HDI 16v 120kw 4HR (06-..)	Central sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.2 HDI 16v 120kw 4HR (06-..)	Front sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.2 HDI 16v 120kw 4HR (06-..)	Rear sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.2 HDI 16v 125kw 4HS (06-..)	Central sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.2 HDI 16v 125kw 4HS (06-..)	Front sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.2 HDI 16v 125kw 4HS (06-..)	Rear sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.2 HDI 16v 125kw 4HT-FAP (06-..)	Central sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.2 HDI 16v 125kw 4HT-FAP (06-..)	Front sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.2 HDI 16v 125kw 4HT-FAP (06-..)	Rear sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.2 HDI 16v 94kw 4HW-FAP (...06)	Central sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.2 HDI 16v 94kw 4HW-FAP (...06)	Front sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	2.2 HDI 16v 94kw 4HW-FAP (...06)	Rear sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	3.0 V6 24v 150kw XFW (...06)	Central sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	3.0 V6 24v 150kw XFW (...06)	Front sunruf AUTODETECT
 C8	CONV. TOP/SUNROO	3.0 V6 24v 150kw XFW (...06)	Rear sunruf AUTODETECT
 C8	DASH LAMPS	2.0 16v 100kw RFN (...06)	AUTODETECT
 C8	DASH LAMPS	2.0 16v 100kw RFN (...06)	BTO_MM
 C8	DASH LAMPS	2.0 16v 103kw RFJ (06-..)	AUTODETECT
 C8	DASH LAMPS	2.0 16v 103kw RFJ (06-..)	Marelli
 C8	DASH LAMPS	2.0 HDI 16v 100kw RHR-FAP (06-..)	AUTODETECT
 C8	DASH LAMPS	2.0 HDI 16v 100kw RHR-FAP (06-..)	Marelli
 C8	DASH LAMPS	2.0 HDI 16v 120kw 4HP (06-..)	Marelli
 C8	DASH LAMPS	2.0 HDI 16v 79kw RHM-FAP (...06)	AUTODETECT
 C8	DASH LAMPS	2.0 HDI 16v 79kw RHM-FAP (...06)	BTO_MM
 C8	DASH LAMPS	2.0 HDI 16v 79kw RHT-FAP (...06)	AUTODETECT
 C8	DASH LAMPS	2.0 HDI 16v 79kw RHT-FAP (...06)	BTO_MM
 C8	DASH LAMPS	2.0 HDI 16v 80kw RHW (...06)	AUTODETECT
 C8	DASH LAMPS	2.0 HDI 16v 80kw RHW (...06)	BTO_MM
 C8	DASH LAMPS	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 C8	DASH LAMPS	2.0 HDI 16v 88kw RHK (06-..)	Marelli
 C8	DASH LAMPS	2.2 16v 116kw 3FZ (...06)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C8	DASH LAMPS	2.2 16v 116kw 3FZ (...06)	BTO_MM
 C8	DASH LAMPS	2.2 HDI 16v 120kw 4HP (06-..)	AUTODETECT
 C8	DASH LAMPS	2.2 HDI 16v 120kw 4HR (06-..)	AUTODETECT
 C8	DASH LAMPS	2.2 HDI 16v 120kw 4HR (06-..)	Marelli
 C8	DASH LAMPS	2.2 HDI 16v 125kw 4HS (06-..)	AUTODETECT
 C8	DASH LAMPS	2.2 HDI 16v 125kw 4HS (06-..)	Marelli
 C8	DASH LAMPS	2.2 HDI 16v 125kw 4HT-FAP (06-..)	AUTODETECT
 C8	DASH LAMPS	2.2 HDI 16v 125kw 4HT-FAP (06-..)	Marelli
 C8	DASH LAMPS	2.2 HDI 16v 94kw 4HW-FAP (...06)	AUTODETECT
 C8	DASH LAMPS	2.2 HDI 16v 94kw 4HW-FAP (...06)	BTO_MM
 C8	DASH LAMPS	3.0 V6 24v 150kw XFW (...06)	BTO_MM
 C8	DASHBOARD	2.0 16v 100kw RFN (...06)	AUTODETECT
 C8	DASHBOARD	2.0 16v 100kw RFN (...06)	Marelli Dashboard
 C8	DASHBOARD	2.0 16v 103kw RFJ (06-..)	AUTODETECT
 C8	DASHBOARD	2.0 16v 103kw RFJ (06-..)	Marelli Dashboard
 C8	DASHBOARD	2.0 HDI 16v 100kw RHR-FAP (06-..)	AUTODETECT
 C8	DASHBOARD	2.0 HDI 16v 100kw RHR-FAP (06-..)	Marelli Dashboard
 C8	DASHBOARD	2.0 HDI 16v 120kw 4HP (06-..)	Marelli Dashboard
 C8	DASHBOARD	2.0 HDI 16v 79kw RHM-FAP (...06)	AUTODETECT
 C8	DASHBOARD	2.0 HDI 16v 79kw RHM-FAP (...06)	Marelli Dashboard
 C8	DASHBOARD	2.0 HDI 16v 79kw RHT-FAP (...06)	AUTODETECT
 C8	DASHBOARD	2.0 HDI 16v 79kw RHT-FAP (...06)	Marelli Dashboard
 C8	DASHBOARD	2.0 HDI 16v 80kw RHW (...06)	AUTODETECT
 C8	DASHBOARD	2.0 HDI 16v 80kw RHW (...06)	Marelli Dashboard
 C8	DASHBOARD	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 C8	DASHBOARD	2.0 HDI 16v 88kw RHK (06-..)	Marelli Dashboard
 C8	DASHBOARD	2.2 16v 116kw 3FZ (...06)	AUTODETECT
 C8	DASHBOARD	2.2 16v 116kw 3FZ (...06)	Marelli Dashboard
 C8	DASHBOARD	2.2 HDI 16v 120kw 4HP (06-..)	AUTODETECT
 C8	DASHBOARD	2.2 HDI 16v 120kw 4HR (06-..)	AUTODETECT
 C8	DASHBOARD	2.2 HDI 16v 120kw 4HR (06-..)	Marelli Dashboard
 C8	DASHBOARD	2.2 HDI 16v 125kw 4HS (06-..)	AUTODETECT
 C8	DASHBOARD	2.2 HDI 16v 125kw 4HS (06-..)	Marelli Dashboard
 C8	DASHBOARD	2.2 HDI 16v 125kw 4HT-FAP (06-..)	AUTODETECT
 C8	DASHBOARD	2.2 HDI 16v 125kw 4HT-FAP (06-..)	Marelli Dashboard
 C8	DASHBOARD	2.2 HDI 16v 94kw 4HW-FAP (...06)	AUTODETECT
 C8	DASHBOARD	2.2 HDI 16v 94kw 4HW-FAP (...06)	Marelli Dashboard
 C8	DASHBOARD	3.0 V6 24v 150kw XFW (...06)	AUTODETECT
 C8	DASHBOARD	3.0 V6 24v 150kw XFW (...06)	Marelli Dashboard
 C8	DIESEL ADDITION	2.0 HDI 16v 100kw RHR-FAP (06-..)	AUTODETECT
 C8	DIESEL ADDITION	2.0 HDI 16v 79kw RHT-FAP (...06)	AUTODETECT
 C8	DIESEL ADDITION	2.0 HDI 16v 80kw RHW (...06)	AUTODETECT
 C8	DIESEL ADDITION	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 C8	DIESEL ADDITION	2.2 HDI 16v 120kw 4HR (06-..)	AUTODETECT
 C8	DIESEL ADDITION	2.2 HDI 16v 125kw 4HT-FAP (06-..)	AUTODETECT
 C8	DIESEL ADDITION	2.2 HDI 16v 94kw 4HW-FAP (...06)	AUTODETECT
 C8	DRIVER SEAT CONT	2.0 16v 100kw RFN (...06)	AUTODETECT
 C8	DRIVER SEAT CONT	2.0 16v 103kw RFJ (06-..)	AUTODETECT
 C8	DRIVER SEAT CONT	2.0 HDI 16v 100kw RHR-FAP (06-..)	AUTODETECT
 C8	DRIVER SEAT CONT	2.0 HDI 16v 79kw RHM-FAP (...06)	AUTODETECT
 C8	DRIVER SEAT CONT	2.0 HDI 16v 79kw RHT-FAP (...06)	AUTODETECT
 C8	DRIVER SEAT CONT	2.0 HDI 16v 80kw RHW (...06)	AUTODETECT
 C8	DRIVER SEAT CONT	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 C8	DRIVER SEAT CONT	2.2 16v 116kw 3FZ (...06)	AUTODETECT
 C8	DRIVER SEAT CONT	2.2 HDI 16v 120kw 4HP (06-..)	AUTODETECT
 C8	DRIVER SEAT CONT	2.2 HDI 16v 120kw 4HR (06-..)	AUTODETECT
 C8	DRIVER SEAT CONT	2.2 HDI 16v 125kw 4HS (06-..)	AUTODETECT
 C8	DRIVER SEAT CONT	2.2 HDI 16v 125kw 4HT-FAP (06-..)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C8	DRIVER SEAT CONT	2.2 HDI 16v 94kw 4HW-FAP (...-06)	AUTODETECT
 C8	DRIVER SEAT CONT	3.0 V6 24v 150kw XFW (...-06)	AUTODETECT
 C8	DRIVER SIDE DOOR	2.0 16v 100kw RFN (...-06)	AUTODETECT
 C8	DRIVER SIDE DOOR	2.0 16v 100kw RFN (...-06)	Marelli MTP CONDUCT
 C8	DRIVER SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP (06-..)	AUTODETECT
 C8	DRIVER SIDE DOOR	2.0 HDI 16v 79kw RHM-FAP (...-06)	AUTODETECT
 C8	DRIVER SIDE DOOR	2.0 HDI 16v 79kw RHM-FAP (...-06)	Marelli MTP CONDUCT
 C8	DRIVER SIDE DOOR	2.0 HDI 16v 79kw RHT-FAP (...-06)	AUTODETECT
 C8	DRIVER SIDE DOOR	2.0 HDI 16v 79kw RHT-FAP (...-06)	Marelli MTP CONDUCT
 C8	DRIVER SIDE DOOR	2.0 HDI 16v 80kw RHW (...-06)	AUTODETECT
 C8	DRIVER SIDE DOOR	2.0 HDI 16v 80kw RHW (...-06)	Marelli MTP CONDUCT
 C8	DRIVER SIDE DOOR	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 C8	DRIVER SIDE DOOR	2.2 16v 116kw 3FZ (...-06)	AUTODETECT
 C8	DRIVER SIDE DOOR	2.2 16v 116kw 3FZ (...-06)	Marelli MTP CONDUCT
 C8	DRIVER SIDE DOOR	2.2 HDI 16v 120kw 4HP (06-..)	AUTODETECT
 C8	DRIVER SIDE DOOR	2.2 HDI 16v 120kw 4HR (06-..)	AUTODETECT
 C8	DRIVER SIDE DOOR	2.2 HDI 16v 125kw 4HS (06-..)	AUTODETECT
 C8	DRIVER SIDE DOOR	2.2 HDI 16v 125kw 4HT-FAP (06-..)	AUTODETECT
 C8	DRIVER SIDE DOOR	2.2 HDI 16v 94kw 4HW-FAP (...-06)	AUTODETECT
 C8	DRIVER SIDE DOOR	2.2 HDI 16v 94kw 4HW-FAP (...-06)	Marelli MTP CONDUCT
 C8	DRIVER SIDE DOOR	3.0 V6 24v 150kw XFW (...-06)	AUTODETECT
 C8	DRIVER SIDE DOOR	3.0 V6 24v 150kw XFW (...-06)	Marelli MTP CONDUCT
 C8	ELECTRIC STEERING	2.0 16v 100kw RFN (...-06)	AUTODETECT
 C8	ELECTRIC STEERING	2.0 16v 103kw RFJ (06-..)	AUTODETECT
 C8	ELECTRIC STEERING	2.0 16v 103kw RFJ (06-..)	HPI EPS GEP
 C8	ELECTRIC STEERING	2.0 HDI 16v 100kw RHR-FAP (06-..)	AUTODETECT
 C8	ELECTRIC STEERING	2.0 HDI 16v 100kw RHR-FAP (06-..)	HPI EPS GEP
 C8	ELECTRIC STEERING	2.0 HDI 16v 120kw 4HP (06-..)	HPI EPS GEP
 C8	ELECTRIC STEERING	2.0 HDI 16v 79kw RHM-FAP (...-06)	AUTODETECT
 C8	ELECTRIC STEERING	2.0 HDI 16v 79kw RHT-FAP (...-06)	AUTODETECT
 C8	ELECTRIC STEERING	2.0 HDI 16v 80kw RHW (...-06)	AUTODETECT
 C8	ELECTRIC STEERING	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 C8	ELECTRIC STEERING	2.0 HDI 16v 88kw RHK (06-..)	HPI EPS GEP
 C8	ELECTRIC STEERING	2.2 16v 116kw 3FZ (...-06)	AUTODETECT
 C8	ELECTRIC STEERING	2.2 HDI 16v 120kw 4HP (06-..)	AUTODETECT
 C8	ELECTRIC STEERING	2.2 HDI 16v 120kw 4HR (06-..)	AUTODETECT
 C8	ELECTRIC STEERING	2.2 HDI 16v 120kw 4HR (06-..)	HPI EPS GEP
 C8	ELECTRIC STEERING	2.2 HDI 16v 125kw 4HS (06-..)	AUTODETECT
 C8	ELECTRIC STEERING	2.2 HDI 16v 125kw 4HS (06-..)	HPI EPS GEP
 C8	ELECTRIC STEERING	2.2 HDI 16v 125kw 4HT-FAP (06-..)	AUTODETECT
 C8	ELECTRIC STEERING	2.2 HDI 16v 125kw 4HT-FAP (06-..)	HPI EPS GEP
 C8	ELECTRIC STEERING	2.2 HDI 16v 94kw 4HW-FAP (...-06)	AUTODETECT
 C8	ELECTRIC STEERING	3.0 V6 24v 150kw XFW (...-06)	AUTODETECT
 C8	ENGINE MANAGEME	2.0 16v 100kw RFN (...-06)	Marelli MM4 MP2 AUTODETECT
 C8	ENGINE MANAGEME	2.0 16v 100kw RFN (...-06)	Marelli MM48P AUTODETECT
 C8	ENGINE MANAGEME	2.0 16v 100kw RFN (...-06)	Marelli MM6LP AUTODETECT
 C8	ENGINE MANAGEME	2.0 16v 103kw RFJ (06-..)	Marelli MM6LPB AUTODETECT
 C8	ENGINE MANAGEME	2.0 16v 103kw RFJ (06-..)	Marelli MPI MM6LPB
 C8	ENGINE MANAGEME	2.0 HDI 16v 100kw RHR-FAP (06-..)	SIEMENS EDC SID 803A Common Rail
 C8	ENGINE MANAGEME	2.0 HDI 16v 100kw RHR-FAP (06-..)	SIEMENS SID 803A Common Rail AUTOD
 C8	ENGINE MANAGEME	2.0 HDI 16v 79kw RHM-FAP (...-06)	EOBD
 C8	ENGINE MANAGEME	2.0 HDI 16v 79kw RHT-FAP (...-06)	BOSCH EDC 15 C2 Common Rail
 C8	ENGINE MANAGEME	2.0 HDI 16v 79kw RHT-FAP (...-06)	BOSCH EDC15 C2 Common Rail AUTODE
 C8	ENGINE MANAGEME	2.0 HDI 16v 80kw RHW (...-06)	BOSCH EDC15 C2 Common Rail AUTODE
 C8	ENGINE MANAGEME	2.0 HDI 16v 88kw RHK (06-..)	SIEMENS SID 803A Common Rail AUTOD
 C8	ENGINE MANAGEME	2.2 16v 116kw 3FZ (...-06)	Marelli MM4MP2 AUTODETECT
 C8	ENGINE MANAGEME	2.2 16v 116kw 3FZ (...-06)	Marelli MM6LP AUTODETECT
 C8	ENGINE MANAGEME	2.2 HDI 16v 120kw 4HP (06-..)	BOSCH EDC16 CP39 Common Rail AUTO

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C8	ENGINE MANAGEME	2.2 HDI 16v 120kw 4HR (06-..)	BOSCH EDC16 CP39 Common Rail AUTO
 C8	ENGINE MANAGEME	2.2 HDI 16v 125kw 4HS (06-..)	BOSCH EDC16 CP39 Common Rail AUTO
 C8	ENGINE MANAGEME	2.2 HDI 16v 125kw 4HT-FAP (06-..)	BOSCH EDC16 CP39 Common Rail AUTO
 C8	ENGINE MANAGEME	2.2 HDI 16v 94kw 4HW-FAP (...06)	BOSCH EDC 15 C2 Common Rail
 C8	ENGINE MANAGEME	2.2 HDI 16v 94kw 4HW-FAP (...06)	BOSCH EDC15 C2 Common Rail AUTODE
 C8	ENGINE MANAGEME	3.0 V6 24v 150kw XFW (...06)	BOSCH ME 7.4.6 AUTODETECT
 C8	LH RIGHT MODULATI	2.0 16v 100kw RFN (...06)	AUTODETECT
 C8	LH RIGHT MODULATI	2.0 16v 103kw RFJ (06-..)	AUTODETECT
 C8	LH RIGHT MODULATI	2.0 HDI 16v 100kw RHR-FAP (06-..)	AUTODETECT
 C8	LH RIGHT MODULATI	2.0 HDI 16v 79kw RHM-FAP (...06)	AUTODETECT
 C8	LH RIGHT MODULATI	2.0 HDI 16v 79kw RHT-FAP (...06)	AUTODETECT
 C8	LH RIGHT MODULATI	2.0 HDI 16v 80kw RHW (...06)	AUTODETECT
 C8	LH RIGHT MODULATI	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 C8	LH RIGHT MODULATI	2.2 16v 116kw 3FZ (...06)	AUTODETECT
 C8	LH RIGHT MODULATI	2.2 HDI 16v 120kw 4HP (06-..)	AUTODETECT
 C8	LH RIGHT MODULATI	2.2 HDI 16v 120kw 4HR (06-..)	AUTODETECT
 C8	LH RIGHT MODULATI	2.2 HDI 16v 125kw 4HS (06-..)	AUTODETECT
 C8	LH RIGHT MODULATI	2.2 HDI 16v 125kw 4HT-FAP (06-..)	AUTODETECT
 C8	LH RIGHT MODULATI	2.2 HDI 16v 94kw 4HW-FAP (...06)	AUTODETECT
 C8	LH RIGHT MODULATI	3.0 V6 24v 150kw XFW (...06)	AUTODETECT
 C8	MAINTENANCE	2.0 16v 100kw RFN (...06)	A/T AM6 AUTODETECT
 C8	MAINTENANCE	2.0 16v 100kw RFN (...06)	A/T AM6 AUTODETECT
 C8	MAINTENANCE	2.0 16v 100kw RFN (...06)	AUTODETECT
 C8	MAINTENANCE	2.0 16v 100kw RFN (...06)	AUTODETECT
 C8	MAINTENANCE	2.0 16v 100kw RFN (...06)	BOSCH ABS/ESP 5.7
 C8	MAINTENANCE	2.0 16v 100kw RFN (...06)	BOSCH ABS/ESP 5.7
 C8	MAINTENANCE	2.0 16v 100kw RFN (...06)	BOSCH ABS/ESP 5.7
 C8	MAINTENANCE	2.0 16v 100kw RFN (...06)	BOSCH ABS/ESP 5.7
 C8	MAINTENANCE	2.0 16v 100kw RFN (...06)	BOSCH ESP 5.7 AUTODETECT
 C8	MAINTENANCE	2.0 16v 100kw RFN (...06)	BOSCH ESP 5.7 AUTODETECT
 C8	MAINTENANCE	2.0 16v 100kw RFN (...06)	BOSCH ESP 8.1 AUTODETECT
 C8	MAINTENANCE	2.0 16v 100kw RFN (...06)	BOSCH ESP 8.1 AUTODETECT
 C8	MAINTENANCE	2.0 16v 100kw RFN (...06)	BTO_MM
 C8	MAINTENANCE	2.0 16v 100kw RFN (...06)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.0 16v 100kw RFN (...06)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.0 16v 100kw RFN (...06)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.0 16v 100kw RFN (...06)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.0 16v 103kw RFJ (06-..)	A/T AM6 AUTODETECT
 C8	MAINTENANCE	2.0 16v 103kw RFJ (06-..)	A/T AM6 AUTODETECT
 C8	MAINTENANCE	2.0 16v 103kw RFJ (06-..)	AUTODETECT
 C8	MAINTENANCE	2.0 16v 103kw RFJ (06-..)	AUTODETECT
 C8	MAINTENANCE	2.0 16v 103kw RFJ (06-..)	BOSCH ESP 5.7 AUTODETECT
 C8	MAINTENANCE	2.0 16v 103kw RFJ (06-..)	BOSCH ESP 5.7 AUTODETECT
 C8	MAINTENANCE	2.0 16v 103kw RFJ (06-..)	BOSCH ESP 8.1 AUTODETECT
 C8	MAINTENANCE	2.0 16v 103kw RFJ (06-..)	BOSCH ESP 8.1 AUTODETECT
 C8	MAINTENANCE	2.0 16v 103kw RFJ (06-..)	Marelli
 C8	MAINTENANCE	2.0 16v 103kw RFJ (06-..)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.0 16v 103kw RFJ (06-..)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.0 16v 103kw RFJ (06-..)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.0 16v 103kw RFJ (06-..)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (06-..)	A/T AM6 AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (06-..)	A/T AM6 AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (06-..)	AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (06-..)	AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (06-..)	BOSCH ESP 5.7 AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (06-..)	BOSCH ESP 5.7 AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (06-..)	BOSCH ESP 8.1 AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C8	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (06-..)	BOSCH ESP 8.1 AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (06-..)	Marelli
 C8	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (06-..)	SIEMENS SID 803A Common Rail AUTOD
 C8	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (06-..)	SIEMENS SID 803A Common Rail AUTOD
 C8	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (06-..)	SIEMENS SID 803A Common Rail AUTOD
 C8	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (06-..)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (06-..)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (06-..)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (06-..)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 120kw 4HP (06-..)	Marelli
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHM-FAP (...-06)	A/T AM6 AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHM-FAP (...-06)	A/T AM6 AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHM-FAP (...-06)	AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHM-FAP (...-06)	AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHM-FAP (...-06)	BOSCH ABS/ESP 5.7
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHM-FAP (...-06)	BOSCH ABS/ESP 5.7
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHM-FAP (...-06)	BOSCH ABS/ESP 5.7
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHM-FAP (...-06)	BOSCH ABS/ESP 5.7
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHM-FAP (...-06)	BOSCH ESP 5.7 AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHM-FAP (...-06)	BOSCH ESP 5.7 AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHM-FAP (...-06)	BOSCH ESP 8.1 AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHM-FAP (...-06)	BOSCH ESP 8.1 AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHM-FAP (...-06)	BTO_MM
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHM-FAP (...-06)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHM-FAP (...-06)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHM-FAP (...-06)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHM-FAP (...-06)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...-06)	A/T AM6 AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...-06)	A/T AM6 AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...-06)	AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...-06)	AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...-06)	BOSCH ABS/ESP 5.7
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...-06)	BOSCH ABS/ESP 5.7
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...-06)	BOSCH ABS/ESP 5.7
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...-06)	BOSCH ABS/ESP 5.7
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...-06)	BOSCH EDC 15 C2 Common Rail
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...-06)	BOSCH EDC15 C2 Common Rail AUTODE
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...-06)	BOSCH ESP 5.7 AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...-06)	BOSCH ESP 5.7 AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...-06)	BOSCH ESP 8.1 AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...-06)	BOSCH ESP 8.1 AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...-06)	BTO_MM
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...-06)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...-06)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...-06)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...-06)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 80kw RHW (...-06)	A/T AM6 AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 80kw RHW (...-06)	A/T AM6 AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 80kw RHW (...-06)	AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 80kw RHW (...-06)	AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 80kw RHW (...-06)	BOSCH ABS/ESP 5.7
 C8	MAINTENANCE	2.0 HDI 16v 80kw RHW (...-06)	BOSCH ABS/ESP 5.7
 C8	MAINTENANCE	2.0 HDI 16v 80kw RHW (...-06)	BOSCH ABS/ESP 5.7
 C8	MAINTENANCE	2.0 HDI 16v 80kw RHW (...-06)	BOSCH ABS/ESP 5.7
 C8	MAINTENANCE	2.0 HDI 16v 80kw RHW (...-06)	BOSCH EDC15 C2 Common Rail AUTODE

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C8	MAINTENANCE	2.0 HDI 16v 80kw RHW (...-06)	BOSCH ESP 5.7 AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 80kw RHW (...-06)	BOSCH ESP 5.7 AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 80kw RHW (...-06)	BOSCH ESP 8.1 AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 80kw RHW (...-06)	BOSCH ESP 8.1 AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 80kw RHW (...-06)	BTO_MM
 C8	MAINTENANCE	2.0 HDI 16v 80kw RHW (...-06)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 80kw RHW (...-06)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 80kw RHW (...-06)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 80kw RHW (...-06)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 88kw RHK (06-..)	A/T AM6 AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 88kw RHK (06-..)	A/T AM6 AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 88kw RHK (06-..)	BOSCH ESP 5.7 AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 88kw RHK (06-..)	BOSCH ESP 5.7 AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 88kw RHK (06-..)	BOSCH ESP 8.1 AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 88kw RHK (06-..)	BOSCH ESP 8.1 AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 88kw RHK (06-..)	Marelli
 C8	MAINTENANCE	2.0 HDI 16v 88kw RHK (06-..)	SIEMENS SID 803A Common Rail AUTOD
 C8	MAINTENANCE	2.0 HDI 16v 88kw RHK (06-..)	SIEMENS SID 803A Common Rail AUTOD
 C8	MAINTENANCE	2.0 HDI 16v 88kw RHK (06-..)	SIEMENS SID 803A Common Rail AUTOD
 C8	MAINTENANCE	2.0 HDI 16v 88kw RHK (06-..)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 88kw RHK (06-..)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 88kw RHK (06-..)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.0 HDI 16v 88kw RHK (06-..)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.2 16v 116kw 3FZ (...-06)	A/T AM6 AUTODETECT
 C8	MAINTENANCE	2.2 16v 116kw 3FZ (...-06)	A/T AM6 AUTODETECT
 C8	MAINTENANCE	2.2 16v 116kw 3FZ (...-06)	AUTODETECT
 C8	MAINTENANCE	2.2 16v 116kw 3FZ (...-06)	AUTODETECT
 C8	MAINTENANCE	2.2 16v 116kw 3FZ (...-06)	BOSCH ABS/ESP 5.7
 C8	MAINTENANCE	2.2 16v 116kw 3FZ (...-06)	BOSCH ABS/ESP 5.7
 C8	MAINTENANCE	2.2 16v 116kw 3FZ (...-06)	BOSCH ABS/ESP 5.7
 C8	MAINTENANCE	2.2 16v 116kw 3FZ (...-06)	BOSCH ABS/ESP 5.7
 C8	MAINTENANCE	2.2 16v 116kw 3FZ (...-06)	BOSCH ABS/ESP 5.7
 C8	MAINTENANCE	2.2 16v 116kw 3FZ (...-06)	BOSCH ESP 5.7 AUTODETECT
 C8	MAINTENANCE	2.2 16v 116kw 3FZ (...-06)	BOSCH ESP 5.7 AUTODETECT
 C8	MAINTENANCE	2.2 16v 116kw 3FZ (...-06)	BOSCH ESP 8.1 AUTODETECT
 C8	MAINTENANCE	2.2 16v 116kw 3FZ (...-06)	BOSCH ESP 8.1 AUTODETECT
 C8	MAINTENANCE	2.2 16v 116kw 3FZ (...-06)	BTO_MM
 C8	MAINTENANCE	2.2 16v 116kw 3FZ (...-06)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.2 16v 116kw 3FZ (...-06)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.2 16v 116kw 3FZ (...-06)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.2 16v 116kw 3FZ (...-06)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 120kw 4HP (06-..)	A/T AM6 AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 120kw 4HP (06-..)	A/T AM6 AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 120kw 4HP (06-..)	AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 120kw 4HP (06-..)	AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 120kw 4HP (06-..)	BOSCH EDC16 CP39 Common Rail AUTO
 C8	MAINTENANCE	2.2 HDI 16v 120kw 4HP (06-..)	BOSCH ESP 5.7 AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 120kw 4HP (06-..)	BOSCH ESP 5.7 AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 120kw 4HP (06-..)	BOSCH ESP 8.1 AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 120kw 4HP (06-..)	BOSCH ESP 8.1 AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 120kw 4HP (06-..)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 120kw 4HP (06-..)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 120kw 4HP (06-..)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 120kw 4HP (06-..)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 120kw 4HR (06-..)	A/T AM6 AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 120kw 4HR (06-..)	A/T AM6 AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C8	MAINTENANCE	2.2 HDI 16v 120kw 4HR (06-..)	AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 120kw 4HR (06-..)	AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 120kw 4HR (06-..)	BOSCH EDC16 CP39 Common Rail AUTO
 C8	MAINTENANCE	2.2 HDI 16v 120kw 4HR (06-..)	BOSCH ESP 5.7 AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 120kw 4HR (06-..)	BOSCH ESP 5.7 AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 120kw 4HR (06-..)	BOSCH ESP 8.1 AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 120kw 4HR (06-..)	BOSCH ESP 8.1 AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 120kw 4HR (06-..)	Marelli
 C8	MAINTENANCE	2.2 HDI 16v 120kw 4HR (06-..)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 120kw 4HR (06-..)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 120kw 4HR (06-..)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 120kw 4HR (06-..)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HS (06-..)	A/T AM6 AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HS (06-..)	A/T AM6 AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HS (06-..)	AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HS (06-..)	AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HS (06-..)	BOSCH EDC16 CP39 Common Rail AUTO
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HS (06-..)	BOSCH ESP 5.7 AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HS (06-..)	BOSCH ESP 5.7 AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HS (06-..)	BOSCH ESP 8.1 AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HS (06-..)	BOSCH ESP 8.1 AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HS (06-..)	Marelli
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HS (06-..)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HS (06-..)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HS (06-..)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HS (06-..)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	A/T AM6 AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	A/T AM6 AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	BOSCH EDC16 CP39 Common Rail AUTO
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	BOSCH ESP 5.7 AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	BOSCH ESP 5.7 AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	BOSCH ESP 8.1 AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	BOSCH ESP 8.1 AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	Marelli
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	A/T AM6 AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	A/T AM6 AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	BOSCH ABS/ESP 5.7
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	BOSCH ABS/ESP 5.7
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	BOSCH ABS/ESP 5.7
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	BOSCH ABS/ESP 5.7
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	BOSCH ABS/ESP 5.7
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	BOSCH EDC 15 C2 Common Rail
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	BOSCH EDC15 C2 Common Rail AUTODE
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	BOSCH ESP 5.7 AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	BOSCH ESP 5.7 AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	BOSCH ESP 8.1 AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	BOSCH ESP 8.1 AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	BTO_MM
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	Siemens-JCAE AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C8	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (...-06)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (...-06)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	3.0 V6 24v 150kw XFW (...-06)	A/T AM6 AUTODETECT
 C8	MAINTENANCE	3.0 V6 24v 150kw XFW (...-06)	A/T AM6 AUTODETECT
 C8	MAINTENANCE	3.0 V6 24v 150kw XFW (...-06)	AUTODETECT
 C8	MAINTENANCE	3.0 V6 24v 150kw XFW (...-06)	AUTODETECT
 C8	MAINTENANCE	3.0 V6 24v 150kw XFW (...-06)	BOSCH ABS/ESP 5.7
 C8	MAINTENANCE	3.0 V6 24v 150kw XFW (...-06)	BOSCH ABS/ESP 5.7
 C8	MAINTENANCE	3.0 V6 24v 150kw XFW (...-06)	BOSCH ABS/ESP 5.7
 C8	MAINTENANCE	3.0 V6 24v 150kw XFW (...-06)	BOSCH ABS/ESP 5.7
 C8	MAINTENANCE	3.0 V6 24v 150kw XFW (...-06)	BOSCH ESP 5.7 AUTODETECT
 C8	MAINTENANCE	3.0 V6 24v 150kw XFW (...-06)	BOSCH ESP 5.7 AUTODETECT
 C8	MAINTENANCE	3.0 V6 24v 150kw XFW (...-06)	BOSCH ESP 8.1 AUTODETECT
 C8	MAINTENANCE	3.0 V6 24v 150kw XFW (...-06)	BOSCH ESP 8.1 AUTODETECT
 C8	MAINTENANCE	3.0 V6 24v 150kw XFW (...-06)	BTO_MM
 C8	MAINTENANCE	3.0 V6 24v 150kw XFW (...-06)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	3.0 V6 24v 150kw XFW (...-06)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	3.0 V6 24v 150kw XFW (...-06)	Siemens-JCAE AUTODETECT
 C8	MAINTENANCE	3.0 V6 24v 150kw XFW (...-06)	Siemens-JCAE AUTODETECT
 C8	NAVIGATION	2.0 16v 100kw RFN (...-06)	AUTODETECT
 C8	NAVIGATION	2.0 16v 100kw RFN (...-06)	AUTODETECT
 C8	NAVIGATION	2.0 16v 103kw RFJ (06-..)	AUTODETECT
 C8	NAVIGATION	2.0 16v 103kw RFJ (06-..)	AUTODETECT
 C8	NAVIGATION	2.0 HDI 16v 100kw RHR-FAP (06-..)	AUTODETECT
 C8	NAVIGATION	2.0 HDI 16v 100kw RHR-FAP (06-..)	AUTODETECT
 C8	NAVIGATION	2.0 HDI 16v 79kw RHM-FAP (...-06)	AUTODETECT
 C8	NAVIGATION	2.0 HDI 16v 79kw RHM-FAP (...-06)	AUTODETECT
 C8	NAVIGATION	2.0 HDI 16v 79kw RHT-FAP (...-06)	AUTODETECT
 C8	NAVIGATION	2.0 HDI 16v 79kw RHT-FAP (...-06)	AUTODETECT
 C8	NAVIGATION	2.0 HDI 16v 80kw RHW (...-06)	AUTODETECT
 C8	NAVIGATION	2.0 HDI 16v 80kw RHW (...-06)	AUTODETECT
 C8	NAVIGATION	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 C8	NAVIGATION	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 C8	NAVIGATION	2.2 16v 116kw 3FZ (...-06)	AUTODETECT
 C8	NAVIGATION	2.2 HDI 16v 120kw 4HP (06-..)	AUTODETECT
 C8	NAVIGATION	2.2 HDI 16v 120kw 4HP (06-..)	AUTODETECT
 C8	NAVIGATION	2.2 HDI 16v 120kw 4HR (06-..)	AUTODETECT
 C8	NAVIGATION	2.2 HDI 16v 120kw 4HR (06-..)	AUTODETECT
 C8	NAVIGATION	2.2 HDI 16v 125kw 4HS (06-..)	AUTODETECT
 C8	NAVIGATION	2.2 HDI 16v 125kw 4HS (06-..)	AUTODETECT
 C8	NAVIGATION	2.2 HDI 16v 125kw 4HT-FAP (06-..)	AUTODETECT
 C8	NAVIGATION	2.2 HDI 16v 125kw 4HT-FAP (06-..)	AUTODETECT
 C8	NAVIGATION	2.2 HDI 16v 94kw 4HW-FAP (...-06)	AUTODETECT
 C8	NAVIGATION	2.2 HDI 16v 94kw 4HW-FAP (...-06)	AUTODETECT
 C8	NAVIGATION	3.0 V6 24v 150kw XFW (...-06)	AUTODETECT
 C8	NAVIGATION	3.0 V6 24v 150kw XFW (...-06)	AUTODETECT
 C8	PARKING HELP	2.0 16v 100kw RFN (...-06)	AUTODETECT
 C8	PARKING HELP	2.0 16v 100kw RFN (...-06)	VALEO
 C8	PARKING HELP	2.0 HDI 16v 100kw RHR-FAP (06-..)	AUTODETECT
 C8	PARKING HELP	2.0 HDI 16v 79kw RHM-FAP (...-06)	AUTODETECT
 C8	PARKING HELP	2.0 HDI 16v 79kw RHM-FAP (...-06)	VALEO
 C8	PARKING HELP	2.0 HDI 16v 79kw RHT-FAP (...-06)	AUTODETECT
 C8	PARKING HELP	2.0 HDI 16v 79kw RHT-FAP (...-06)	VALEO
 C8	PARKING HELP	2.0 HDI 16v 80kw RHW (...-06)	AUTODETECT
 C8	PARKING HELP	2.0 HDI 16v 80kw RHW (...-06)	VALEO
 C8	PARKING HELP	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 C8	PARKING HELP	2.2 16v 116kw 3FZ (...-06)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C8	PARKING HELP	2.2 16v 116kw 3FZ (...06)	VALEO
 C8	PARKING HELP	2.2 HDI 16v 120kw 4HP (06-..)	AUTODETECT
 C8	PARKING HELP	2.2 HDI 16v 120kw 4HR (06-..)	AUTODETECT
 C8	PARKING HELP	2.2 HDI 16v 125kw 4HS (06-..)	AUTODETECT
 C8	PARKING HELP	2.2 HDI 16v 125kw 4HT-FAP (06-..)	AUTODETECT
 C8	PARKING HELP	2.2 HDI 16v 94kw 4HW-FAP (...06)	AUTODETECT
 C8	PARKING HELP	2.2 HDI 16v 94kw 4HW-FAP (...06)	VALEO
 C8	PARKING HELP	3.0 V6 24v 150kw XFW (...06)	AUTODETECT
 C8	PARKING HELP	3.0 V6 24v 150kw XFW (...06)	VALEO
 C8	PASS. SIDE DOOR	2.0 16v 100kw RFN (...06)	AUTODETECT
 C8	PASS. SIDE DOOR	2.0 16v 100kw RFN (...06)	Marelli MTP PASS
 C8	PASS. SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP (06-..)	AUTODETECT
 C8	PASS. SIDE DOOR	2.0 HDI 16v 79kw RHM-FAP (...06)	AUTODETECT
 C8	PASS. SIDE DOOR	2.0 HDI 16v 79kw RHM-FAP (...06)	Marelli MTP PASS
 C8	PASS. SIDE DOOR	2.0 HDI 16v 79kw RHT-FAP (...06)	AUTODETECT
 C8	PASS. SIDE DOOR	2.0 HDI 16v 79kw RHT-FAP (...06)	Marelli MTP PASS
 C8	PASS. SIDE DOOR	2.0 HDI 16v 80kw RHW (...06)	AUTODETECT
 C8	PASS. SIDE DOOR	2.0 HDI 16v 80kw RHW (...06)	Marelli MTP PASS
 C8	PASS. SIDE DOOR	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 C8	PASS. SIDE DOOR	2.2 16v 116kw 3FZ (...06)	AUTODETECT
 C8	PASS. SIDE DOOR	2.2 16v 116kw 3FZ (...06)	Marelli MTP PASS
 C8	PASS. SIDE DOOR	2.2 HDI 16v 120kw 4HP (06-..)	AUTODETECT
 C8	PASS. SIDE DOOR	2.2 HDI 16v 120kw 4HR (06-..)	AUTODETECT
 C8	PASS. SIDE DOOR	2.2 HDI 16v 125kw 4HS (06-..)	AUTODETECT
 C8	PASS. SIDE DOOR	2.2 HDI 16v 125kw 4HT-FAP (06-..)	AUTODETECT
 C8	PASS. SIDE DOOR	2.2 HDI 16v 94kw 4HW-FAP (...06)	AUTODETECT
 C8	PASS. SIDE DOOR	2.2 HDI 16v 94kw 4HW-FAP (...06)	Marelli MTP PASS
 C8	PASS. SIDE DOOR	3.0 V6 24v 150kw XFW (...06)	AUTODETECT
 C8	PASS. SIDE DOOR	3.0 V6 24v 150kw XFW (...06)	Marelli MTP PASS
 C8	PHONE	2.0 16v 100kw RFN (...06)	Cell. Phone Kit AUTODETECT
 C8	PHONE	2.0 16v 100kw RFN (...06)	Phone AUTODETECT
 C8	PHONE	2.0 16v 103kw RFJ (06-..)	Cell. Phone Kit AUTODETECT
 C8	PHONE	2.0 16v 103kw RFJ (06-..)	Phone AUTODETECT
 C8	PHONE	2.0 HDI 16v 100kw RHR-FAP (06-..)	Cell. Phone Kit AUTODETECT
 C8	PHONE	2.0 HDI 16v 100kw RHR-FAP (06-..)	Phone AUTODETECT
 C8	PHONE	2.0 HDI 16v 79kw RHM-FAP (...06)	Cell. Phone Kit AUTODETECT
 C8	PHONE	2.0 HDI 16v 79kw RHM-FAP (...06)	Phone AUTODETECT
 C8	PHONE	2.0 HDI 16v 79kw RHT-FAP (...06)	Cell. Phone Kit AUTODETECT
 C8	PHONE	2.0 HDI 16v 79kw RHT-FAP (...06)	Phone AUTODETECT
 C8	PHONE	2.0 HDI 16v 80kw RHW (...06)	Cell. Phone Kit AUTODETECT
 C8	PHONE	2.0 HDI 16v 80kw RHW (...06)	Phone AUTODETECT
 C8	PHONE	2.0 HDI 16v 88kw RHK (06-..)	Cell. Phone Kit AUTODETECT
 C8	PHONE	2.0 HDI 16v 88kw RHK (06-..)	Phone AUTODETECT
 C8	PHONE	2.2 16v 116kw 3FZ (...06)	Cell. Phone Kit AUTODETECT
 C8	PHONE	2.2 16v 116kw 3FZ (...06)	Phone AUTODETECT
 C8	PHONE	2.2 HDI 16v 120kw 4HP (06-..)	Cell. Phone Kit AUTODETECT
 C8	PHONE	2.2 HDI 16v 120kw 4HP (06-..)	Phone AUTODETECT
 C8	PHONE	2.2 HDI 16v 120kw 4HR (06-..)	Cell. Phone Kit AUTODETECT
 C8	PHONE	2.2 HDI 16v 120kw 4HR (06-..)	Phone AUTODETECT
 C8	PHONE	2.2 HDI 16v 125kw 4HS (06-..)	Cell. Phone Kit AUTODETECT
 C8	PHONE	2.2 HDI 16v 125kw 4HS (06-..)	Phone AUTODETECT
 C8	PHONE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	Cell. Phone Kit AUTODETECT
 C8	PHONE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	Phone AUTODETECT
 C8	PHONE	2.2 HDI 16v 94kw 4HW-FAP (...06)	Cell. Phone Kit AUTODETECT
 C8	PHONE	2.2 HDI 16v 94kw 4HW-FAP (...06)	Phone AUTODETECT
 C8	PHONE	3.0 V6 24v 150kw XFW (...06)	Cell. Phone Kit AUTODETECT
 C8	PHONE	3.0 V6 24v 150kw XFW (...06)	Phone AUTODETECT
 C8	RADIO / CD	2.0 16v 100kw RFN (...06)	AudioSystem AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C8	RADIO / CD	2.0 16v 100kw RFN (...06)	CD Changer AUTODETECT
 C8	RADIO / CD	2.0 16v 100kw RFN (...06)	CLARION AudioSystem
 C8	RADIO / CD	2.0 16v 100kw RFN (...06)	PHILIPS AudioSystem
 C8	RADIO / CD	2.0 16v 100kw RFN (...06)	Telematic receiver command AUTODETEC
 C8	RADIO / CD	2.0 16v 100kw RFN (...06)	VDO AudioSystem
 C8	RADIO / CD	2.0 16v 103kw RFJ (06-..)	AudioSystem AUTODETECT
 C8	RADIO / CD	2.0 16v 103kw RFJ (06-..)	CD Changer AUTODETECT
 C8	RADIO / CD	2.0 16v 103kw RFJ (06-..)	Telematic receiver command AUTODETEC
 C8	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP (06-..)	AudioSystem AUTODETECT
 C8	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP (06-..)	CD Changer AUTODETECT
 C8	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP (06-..)	Telematic receiver command AUTODETEC
 C8	RADIO / CD	2.0 HDI 16v 79kw RHM-FAP (...06)	AudioSystem AUTODETECT
 C8	RADIO / CD	2.0 HDI 16v 79kw RHM-FAP (...06)	CD Changer AUTODETECT
 C8	RADIO / CD	2.0 HDI 16v 79kw RHM-FAP (...06)	CLARION AudioSystem
 C8	RADIO / CD	2.0 HDI 16v 79kw RHM-FAP (...06)	PHILIPS AudioSystem
 C8	RADIO / CD	2.0 HDI 16v 79kw RHM-FAP (...06)	Telematic receiver command AUTODETEC
 C8	RADIO / CD	2.0 HDI 16v 79kw RHM-FAP (...06)	VDO AudioSystem
 C8	RADIO / CD	2.0 HDI 16v 79kw RHT-FAP (...06)	AudioSystem AUTODETECT
 C8	RADIO / CD	2.0 HDI 16v 79kw RHT-FAP (...06)	CD Changer AUTODETECT
 C8	RADIO / CD	2.0 HDI 16v 79kw RHT-FAP (...06)	CLARION AudioSystem
 C8	RADIO / CD	2.0 HDI 16v 79kw RHT-FAP (...06)	PHILIPS AudioSystem
 C8	RADIO / CD	2.0 HDI 16v 79kw RHT-FAP (...06)	Telematic receiver command AUTODETEC
 C8	RADIO / CD	2.0 HDI 16v 79kw RHT-FAP (...06)	VDO AudioSystem
 C8	RADIO / CD	2.0 HDI 16v 80kw RHW (...06)	AudioSystem AUTODETECT
 C8	RADIO / CD	2.0 HDI 16v 80kw RHW (...06)	CD Changer AUTODETECT
 C8	RADIO / CD	2.0 HDI 16v 80kw RHW (...06)	CLARION AudioSystem
 C8	RADIO / CD	2.0 HDI 16v 80kw RHW (...06)	PHILIPS AudioSystem
 C8	RADIO / CD	2.0 HDI 16v 80kw RHW (...06)	Telematic receiver command AUTODETEC
 C8	RADIO / CD	2.0 HDI 16v 80kw RHW (...06)	VDO AudioSystem
 C8	RADIO / CD	2.0 HDI 16v 88kw RHK (06-..)	AudioSystem AUTODETECT
 C8	RADIO / CD	2.0 HDI 16v 88kw RHK (06-..)	CD Changer AUTODETECT
 C8	RADIO / CD	2.0 HDI 16v 88kw RHK (06-..)	Telematic receiver command AUTODETEC
 C8	RADIO / CD	2.2 16v 116kw 3FZ (...06)	AudioSystem AUTODETECT
 C8	RADIO / CD	2.2 16v 116kw 3FZ (...06)	CD Changer AUTODETECT
 C8	RADIO / CD	2.2 16v 116kw 3FZ (...06)	CLARION AudioSystem
 C8	RADIO / CD	2.2 16v 116kw 3FZ (...06)	PHILIPS AudioSystem
 C8	RADIO / CD	2.2 16v 116kw 3FZ (...06)	Telematic receiver command AUTODETEC
 C8	RADIO / CD	2.2 16v 116kw 3FZ (...06)	VDO AudioSystem
 C8	RADIO / CD	2.2 HDI 16v 120kw 4HP (06-..)	AudioSystem AUTODETECT
 C8	RADIO / CD	2.2 HDI 16v 120kw 4HP (06-..)	CD Changer AUTODETECT
 C8	RADIO / CD	2.2 HDI 16v 120kw 4HP (06-..)	Telematic receiver command AUTODETEC
 C8	RADIO / CD	2.2 HDI 16v 120kw 4HR (06-..)	AudioSystem AUTODETECT
 C8	RADIO / CD	2.2 HDI 16v 120kw 4HR (06-..)	CD Changer AUTODETECT
 C8	RADIO / CD	2.2 HDI 16v 120kw 4HR (06-..)	Telematic receiver command AUTODETEC
 C8	RADIO / CD	2.2 HDI 16v 125kw 4HS (06-..)	AudioSystem AUTODETECT
 C8	RADIO / CD	2.2 HDI 16v 125kw 4HS (06-..)	CD Changer AUTODETECT
 C8	RADIO / CD	2.2 HDI 16v 125kw 4HS (06-..)	Telematic receiver command AUTODETEC
 C8	RADIO / CD	2.2 HDI 16v 125kw 4HT-FAP (06-..)	AudioSystem AUTODETECT
 C8	RADIO / CD	2.2 HDI 16v 125kw 4HT-FAP (06-..)	CD Changer AUTODETECT
 C8	RADIO / CD	2.2 HDI 16v 125kw 4HT-FAP (06-..)	Telematic receiver command AUTODETEC
 C8	RADIO / CD	2.2 HDI 16v 94kw 4HW-FAP (...06)	AudioSystem AUTODETECT
 C8	RADIO / CD	2.2 HDI 16v 94kw 4HW-FAP (...06)	CD Changer AUTODETECT
 C8	RADIO / CD	2.2 HDI 16v 94kw 4HW-FAP (...06)	CLARION AudioSystem
 C8	RADIO / CD	2.2 HDI 16v 94kw 4HW-FAP (...06)	PHILIPS AudioSystem
 C8	RADIO / CD	2.2 HDI 16v 94kw 4HW-FAP (...06)	Telematic receiver command AUTODETEC
 C8	RADIO / CD	2.2 HDI 16v 94kw 4HW-FAP (...06)	VDO AudioSystem
 C8	RADIO / CD	3.0 V6 24v 150kw XFW (...06)	AudioSystem AUTODETECT
 C8	RADIO / CD	3.0 V6 24v 150kw XFW (...06)	CD Changer AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C8	RADIO / CD	3.0 V6 24v 150kw XFW (...06)	CLARION AudioSystem
 C8	RADIO / CD	3.0 V6 24v 150kw XFW (...06)	PHILIPS AudioSystem
 C8	RADIO / CD	3.0 V6 24v 150kw XFW (...06)	Telematic receiver command AUTODETECT
 C8	RADIO / CD	3.0 V6 24v 150kw XFW (...06)	VDO AudioSystem
 C8	RAIN-LUMINOSITY S	2.0 16v 100kw RFN (...06)	AUTODETECT
 C8	RAIN-LUMINOSITY S	2.0 HDI 16v 100kw RHR-FAP (06-..)	AUTODETECT
 C8	RAIN-LUMINOSITY S	2.0 HDI 16v 79kw RHM-FAP (...06)	AUTODETECT
 C8	RAIN-LUMINOSITY S	2.0 HDI 16v 79kw RHT-FAP (...06)	AUTODETECT
 C8	RAIN-LUMINOSITY S	2.0 HDI 16v 80kw RHW (...06)	AUTODETECT
 C8	RAIN-LUMINOSITY S	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 C8	RAIN-LUMINOSITY S	2.2 16v 116kw 3FZ (...06)	AUTODETECT
 C8	RAIN-LUMINOSITY S	2.2 HDI 16v 120kw 4HP (06-..)	AUTODETECT
 C8	RAIN-LUMINOSITY S	2.2 HDI 16v 120kw 4HR (06-..)	AUTODETECT
 C8	RAIN-LUMINOSITY S	2.2 HDI 16v 125kw 4HS (06-..)	AUTODETECT
 C8	RAIN-LUMINOSITY S	2.2 HDI 16v 125kw 4HT-FAP (06-..)	AUTODETECT
 C8	RAIN-LUMINOSITY S	2.2 HDI 16v 94kw 4HW-FAP (...06)	AUTODETECT
 C8	RAIN-LUMINOSITY S	3.0 V6 24v 150kw XFW (...06)	AUTODETECT
 C8	RH LIGHT MODULATI	2.0 16v 100kw RFN (...06)	AUTODETECT
 C8	RH LIGHT MODULATI	2.0 16v 103kw RFJ (06-..)	AUTODETECT
 C8	RH LIGHT MODULATI	2.0 HDI 16v 100kw RHR-FAP (06-..)	AUTODETECT
 C8	RH LIGHT MODULATI	2.0 HDI 16v 79kw RHM-FAP (...06)	AUTODETECT
 C8	RH LIGHT MODULATI	2.0 HDI 16v 79kw RHT-FAP (...06)	AUTODETECT
 C8	RH LIGHT MODULATI	2.0 HDI 16v 80kw RHW (...06)	AUTODETECT
 C8	RH LIGHT MODULATI	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 C8	RH LIGHT MODULATI	2.2 16v 116kw 3FZ (...06)	AUTODETECT
 C8	RH LIGHT MODULATI	2.2 HDI 16v 120kw 4HP (06-..)	AUTODETECT
 C8	RH LIGHT MODULATI	2.2 HDI 16v 120kw 4HR (06-..)	AUTODETECT
 C8	RH LIGHT MODULATI	2.2 HDI 16v 125kw 4HS (06-..)	AUTODETECT
 C8	RH LIGHT MODULATI	2.2 HDI 16v 125kw 4HT-FAP (06-..)	AUTODETECT
 C8	RH LIGHT MODULATI	2.2 HDI 16v 94kw 4HW-FAP (...06)	AUTODETECT
 C8	RH LIGHT MODULATI	3.0 V6 24v 150kw XFW (...06)	AUTODETECT
 C8	STEERING COLUMN	2.0 16v 100kw RFN (...06)	AUTODETECT
 C8	STEERING COLUMN	2.0 16v 103kw RFJ (06-..)	AUTODETECT
 C8	STEERING COLUMN	2.0 HDI 16v 100kw RHR-FAP (06-..)	AUTODETECT
 C8	STEERING COLUMN	2.0 HDI 16v 79kw RHM-FAP (...06)	AUTODETECT
 C8	STEERING COLUMN	2.0 HDI 16v 79kw RHT-FAP (...06)	AUTODETECT
 C8	STEERING COLUMN	2.0 HDI 16v 80kw RHW (...06)	AUTODETECT
 C8	STEERING COLUMN	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 C8	STEERING COLUMN	2.2 16v 116kw 3FZ (...06)	AUTODETECT
 C8	STEERING COLUMN	2.2 HDI 16v 120kw 4HP (06-..)	AUTODETECT
 C8	STEERING COLUMN	2.2 HDI 16v 120kw 4HR (06-..)	AUTODETECT
 C8	STEERING COLUMN	2.2 HDI 16v 125kw 4HS (06-..)	AUTODETECT
 C8	STEERING COLUMN	2.2 HDI 16v 125kw 4HT-FAP (06-..)	AUTODETECT
 C8	STEERING COLUMN	2.2 HDI 16v 94kw 4HW-FAP (...06)	AUTODETECT
 C8	STEERING COLUMN	3.0 V6 24v 150kw XFW (...06)	AUTODETECT
 C8	SWITCHLIGHT MODU	2.0 16v 100kw RFN (...06)	EATON COM 2000
 C8	SWITCHLIGHT MODU	2.0 HDI 16v 79kw RHM-FAP (...06)	EATON COM 2000
 C8	SWITCHLIGHT MODU	2.0 HDI 16v 79kw RHT-FAP (...06)	EATON COM 2000
 C8	SWITCHLIGHT MODU	2.0 HDI 16v 80kw RHW (...06)	EATON COM 2000
 C8	SWITCHLIGHT MODU	2.2 16v 116kw 3FZ (...06)	EATON COM 2000
 C8	SWITCHLIGHT MODU	2.2 HDI 16v 94kw 4HW-FAP (...06)	EATON COM 2000
 C8	SWITCHLIGHT MODU	3.0 V6 24v 150kw XFW (...06)	EATON COM 2000
 C8	TIRE PRESSURE	2.0 16v 100kw RFN (...06)	Siemens-JCAE AUTODETECT
 C8	TIRE PRESSURE	2.0 16v 103kw RFJ (06-..)	Siemens-JCAE AUTODETECT
 C8	TIRE PRESSURE	2.0 HDI 16v 100kw RHR-FAP (06-..)	Siemens-JCAE AUTODETECT
 C8	TIRE PRESSURE	2.0 HDI 16v 79kw RHM-FAP (...06)	Siemens-JCAE AUTODETECT
 C8	TIRE PRESSURE	2.0 HDI 16v 79kw RHT-FAP (...06)	Siemens-JCAE AUTODETECT
 C8	TIRE PRESSURE	2.0 HDI 16v 80kw RHW (...06)	Siemens-JCAE AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C8	TIRE PRESSURE	2.0 HDI 16v 88kw RHK (06-..)	Siemens-JCAE AUTODETECT
 C8	TIRE PRESSURE	2.2 16v 116kw 3FZ (..-06)	Siemens-JCAE AUTODETECT
 C8	TIRE PRESSURE	2.2 HDI 16v 120kw 4HP (06-..)	Siemens-JCAE AUTODETECT
 C8	TIRE PRESSURE	2.2 HDI 16v 120kw 4HR (06-..)	Siemens-JCAE AUTODETECT
 C8	TIRE PRESSURE	2.2 HDI 16v 125kw 4HS (06-..)	Siemens-JCAE AUTODETECT
 C8	TIRE PRESSURE	2.2 HDI 16v 125kw 4HT-FAP (06-..)	Siemens-JCAE AUTODETECT
 C8	TIRE PRESSURE	2.2 HDI 16v 94kw 4HW-FAP (..-06)	Siemens-JCAE AUTODETECT
 C8	TIRE PRESSURE	3.0 V6 24v 150kw XFW (..-06)	Siemens-JCAE AUTODETECT
 C8	VISUAL./TELEMATIC	2.0 16v 100kw RFN (..-06)	AUTODETECT
 C8	VISUAL./TELEMATIC	2.0 16v 100kw RFN (..-06)	Display AUTODETECT
 C8	VISUAL./TELEMATIC	2.0 16v 100kw RFN (..-06)	Display C- AUTODETECT
 C8	VISUAL./TELEMATIC	2.0 16v 103kw RFJ (06-..)	AUTODETECT
 C8	VISUAL./TELEMATIC	2.0 16v 103kw RFJ (06-..)	Display AUTODETECT
 C8	VISUAL./TELEMATIC	2.0 16v 103kw RFJ (06-..)	Display C- AUTODETECT
 C8	VISUAL./TELEMATIC	2.0 HDI 16v 100kw RHR-FAP (06-..)	AUTODETECT
 C8	VISUAL./TELEMATIC	2.0 HDI 16v 100kw RHR-FAP (06-..)	Display AUTODETECT
 C8	VISUAL./TELEMATIC	2.0 HDI 16v 100kw RHR-FAP (06-..)	Display C- AUTODETECT
 C8	VISUAL./TELEMATIC	2.0 HDI 16v 79kw RHM-FAP (..-06)	AUTODETECT
 C8	VISUAL./TELEMATIC	2.0 HDI 16v 79kw RHM-FAP (..-06)	Display AUTODETECT
 C8	VISUAL./TELEMATIC	2.0 HDI 16v 79kw RHM-FAP (..-06)	Display C- AUTODETECT
 C8	VISUAL./TELEMATIC	2.0 HDI 16v 79kw RHT-FAP (..-06)	AUTODETECT
 C8	VISUAL./TELEMATIC	2.0 HDI 16v 79kw RHT-FAP (..-06)	Display AUTODETECT
 C8	VISUAL./TELEMATIC	2.0 HDI 16v 79kw RHT-FAP (..-06)	Display C- AUTODETECT
 C8	VISUAL./TELEMATIC	2.0 HDI 16v 80kw RHW (..-06)	AUTODETECT
 C8	VISUAL./TELEMATIC	2.0 HDI 16v 80kw RHW (..-06)	Display AUTODETECT
 C8	VISUAL./TELEMATIC	2.0 HDI 16v 80kw RHW (..-06)	Display C- AUTODETECT
 C8	VISUAL./TELEMATIC	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 C8	VISUAL./TELEMATIC	2.0 HDI 16v 88kw RHK (06-..)	Display AUTODETECT
 C8	VISUAL./TELEMATIC	2.0 HDI 16v 88kw RHK (06-..)	Display C- AUTODETECT
 C8	VISUAL./TELEMATIC	2.2 16v 116kw 3FZ (..-06)	AUTODETECT
 C8	VISUAL./TELEMATIC	2.2 16v 116kw 3FZ (..-06)	Display AUTODETECT
 C8	VISUAL./TELEMATIC	2.2 16v 116kw 3FZ (..-06)	Display C- AUTODETECT
 C8	VISUAL./TELEMATIC	2.2 HDI 16v 120kw 4HP (06-..)	AUTODETECT
 C8	VISUAL./TELEMATIC	2.2 HDI 16v 120kw 4HP (06-..)	Display AUTODETECT
 C8	VISUAL./TELEMATIC	2.2 HDI 16v 120kw 4HP (06-..)	Display C- AUTODETECT
 C8	VISUAL./TELEMATIC	2.2 HDI 16v 120kw 4HR (06-..)	AUTODETECT
 C8	VISUAL./TELEMATIC	2.2 HDI 16v 120kw 4HR (06-..)	Display AUTODETECT
 C8	VISUAL./TELEMATIC	2.2 HDI 16v 120kw 4HR (06-..)	Display C- AUTODETECT
 C8	VISUAL./TELEMATIC	2.2 HDI 16v 125kw 4HS (06-..)	AUTODETECT
 C8	VISUAL./TELEMATIC	2.2 HDI 16v 125kw 4HS (06-..)	Display AUTODETECT
 C8	VISUAL./TELEMATIC	2.2 HDI 16v 125kw 4HS (06-..)	Display C- AUTODETECT
 C8	VISUAL./TELEMATIC	2.2 HDI 16v 125kw 4HT-FAP (06-..)	AUTODETECT
 C8	VISUAL./TELEMATIC	2.2 HDI 16v 125kw 4HT-FAP (06-..)	Display AUTODETECT
 C8	VISUAL./TELEMATIC	2.2 HDI 16v 125kw 4HT-FAP (06-..)	Display C- AUTODETECT
 C8	VISUAL./TELEMATIC	2.2 HDI 16v 94kw 4HW-FAP (..-06)	AUTODETECT
 C8	VISUAL./TELEMATIC	2.2 HDI 16v 94kw 4HW-FAP (..-06)	Display AUTODETECT
 C8	VISUAL./TELEMATIC	2.2 HDI 16v 94kw 4HW-FAP (..-06)	Display C- AUTODETECT
 C8	VISUAL./TELEMATIC	3.0 V6 24v 150kw XFW (..-06)	AUTODETECT
 C8	VISUAL./TELEMATIC	3.0 V6 24v 150kw XFW (..-06)	Display AUTODETECT
 C8	VISUAL./TELEMATIC	3.0 V6 24v 150kw XFW (..-06)	Display C- AUTODETECT
 C-Crosser	4WD ELECTRONICS	2.2 HDI 16v 115kw 4HN-FAP	Transmission AUTODETECT
 C-Crosser	4WD ELECTRONICS	2.4 8v 124kw SFZ	Transmission AUTODETECT
 C-Crosser	ABS	2.2 HDI 16v 115kw 4HN-FAP	TEVES ABS/ESP AUTODETECT
 C-Crosser	ABS	2.4 8v 124kw SFZ	TEVES ABS/ESP AUTODETECT
 C-Crosser	ABS + TRACT. CONT	2.2 HDI 16v 115kw 4HN-FAP	TEVES ABS/ESP 0801
 C-Crosser	ABS + TRACT. CONT	2.2 HDI 16v 115kw 4HN-FAP	TEVES ESP AUTODETECT
 C-Crosser	ABS + TRACT. CONT	2.4 8v 124kw SFZ	TEVES ABS/ESP 0801
 C-Crosser	ABS + TRACT. CONT	2.4 8v 124kw SFZ	TEVES ESP AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C-Crosser	AIRBAG	2.2 HDI 16v 115kw 4HN-FAP	AirBag CENTRAL AUTODETECT
 C-Crosser	AIRBAG	2.2 HDI 16v 115kw 4HN-FAP	TRW AirBag 4148
 C-Crosser	AIRBAG	2.4 8v 124kw SFZ	AirBag CENTRAL AUTODETECT
 C-Crosser	AIRBAG	2.4 8v 124kw SFZ	TRW AirBag 4148
 C-Crosser	AUTOM. TRANSMISSI	2.2 HDI 16v 115kw 4HN-FAP	A/T CVT AUTODETECT
 C-Crosser	AUTOM. TRANSMISSI	2.4 8v 124kw SFZ	A/T CVT AUTODETECT
 C-Crosser	CHASSIS NETWORK	2.2 HDI 16v 115kw 4HN-FAP	Body Computer BSI AUTODETECT
 C-Crosser	CHASSIS NETWORK	2.4 8v 124kw SFZ	Body Computer BSI AUTODETECT
 C-Crosser	CLIMA	2.2 HDI 16v 115kw 4HN-FAP	CLIMA AUTODETECT
 C-Crosser	CLIMA	2.2 HDI 16v 115kw 4HN-FAP	MITSUBISHI Clima 00.01
 C-Crosser	CLIMA	2.4 8v 124kw SFZ	CLIMA AUTODETECT
 C-Crosser	CLIMA	2.4 8v 124kw SFZ	MITSUBISHI Clima 00.01
 C-Crosser	CONV. TOP/SUNROO	2.2 HDI 16v 115kw 4HN-FAP	AUTODETECT
 C-Crosser	CONV. TOP/SUNROO	2.4 8v 124kw SFZ	AUTODETECT
 C-Crosser	DASHBOARD	2.2 HDI 16v 115kw 4HN-FAP	AUTODETECT
 C-Crosser	DASHBOARD	2.2 HDI 16v 115kw 4HN-FAP	YASAKI Dashboard 0201
 C-Crosser	DASHBOARD	2.4 8v 124kw SFZ	AUTODETECT
 C-Crosser	DASHBOARD	2.4 8v 124kw SFZ	YASAKI Dashboard 0201
 C-Crosser	DRIVER SIDE DOOR	2.2 HDI 16v 115kw 4HN-FAP	AUTODETECT
 C-Crosser	DRIVER SIDE DOOR	2.4 8v 124kw SFZ	AUTODETECT
 C-Crosser	ENGINE MANAGEME	2.2 HDI 16v 115kw 4HN-FAP	BOSCH EDC Common Rail
 C-Crosser	ENGINE MANAGEME	2.2 HDI 16v 115kw 4HN-FAP	BOSCH EDC16 CP39 Common Rail AUTO
 C-Crosser	ENGINE MANAGEME	2.4 8v 124kw SFZ	MITSUBISHI 4B12-MIVEC AUTODETECT
 C-Crosser	IMMOBILIZER	2.2 HDI 16v 115kw 4HN-FAP	AUTODETECT
 C-Crosser	IMMOBILIZER	2.4 8v 124kw SFZ	AUTODETECT
 C-Crosser	LEFT REAR DOOR	2.2 HDI 16v 115kw 4HN-FAP	AUTODETECT
 C-Crosser	LEFT REAR DOOR	2.4 8v 124kw SFZ	AUTODETECT
 C-Crosser	MAINTENANCE	2.2 HDI 16v 115kw 4HN-FAP	AUTODETECT
 C-Crosser	MAINTENANCE	2.2 HDI 16v 115kw 4HN-FAP	AUTODETECT
 C-Crosser	MAINTENANCE	2.2 HDI 16v 115kw 4HN-FAP	TEVES ABS/ESP 0801
 C-Crosser	MAINTENANCE	2.2 HDI 16v 115kw 4HN-FAP	TEVES ABS/ESP AUTODETECT
 C-Crosser	MAINTENANCE	2.2 HDI 16v 115kw 4HN-FAP	TEVES ESP AUTODETECT
 C-Crosser	MAINTENANCE	2.2 HDI 16v 115kw 4HN-FAP	TEVES ESP AUTODETECT
 C-Crosser	MAINTENANCE	2.2 HDI 16v 115kw 4HN-FAP	YASAKI Dashboard 0201
 C-Crosser	MAINTENANCE	2.4 8v 124kw SFZ	AUTODETECT
 C-Crosser	MAINTENANCE	2.4 8v 124kw SFZ	AUTODETECT
 C-Crosser	MAINTENANCE	2.4 8v 124kw SFZ	TEVES ABS/ESP 0801
 C-Crosser	MAINTENANCE	2.4 8v 124kw SFZ	TEVES ABS/ESP AUTODETECT
 C-Crosser	MAINTENANCE	2.4 8v 124kw SFZ	TEVES ESP AUTODETECT
 C-Crosser	MAINTENANCE	2.4 8v 124kw SFZ	TEVES ESP AUTODETECT
 C-Crosser	MAINTENANCE	2.4 8v 124kw SFZ	YASAKI Dashboard 0201
 C-Crosser	NAVIGATION	2.2 HDI 16v 115kw 4HN-FAP	Display I4 AUTODETECT
 C-Crosser	NAVIGATION	2.4 8v 124kw SFZ	Display I4 AUTODETECT
 C-Crosser	PASS. SIDE DOOR	2.2 HDI 16v 115kw 4HN-FAP	AUTODETECT
 C-Crosser	PASS. SIDE DOOR	2.4 8v 124kw SFZ	AUTODETECT
 C-Crosser	PHONE	2.2 HDI 16v 115kw 4HN-FAP	AUTODETECT
 C-Crosser	PHONE	2.4 8v 124kw SFZ	AUTODETECT
 C-Crosser	RADIO / CD	2.2 HDI 16v 115kw 4HN-FAP	AudioSystem AUTODETECT
 C-Crosser	RADIO / CD	2.4 8v 124kw SFZ	AudioSystem AUTODETECT
 C-Crosser	RIGHT REAR DOOR	2.2 HDI 16v 115kw 4HN-FAP	AUTODETECT
 C-Crosser	RIGHT REAR DOOR	2.4 8v 124kw SFZ	AUTODETECT
 C-Crosser	STEERING COLUMN	2.2 HDI 16v 115kw 4HN-FAP	AUTODETECT
 C-Crosser	STEERING COLUMN	2.4 8v 124kw SFZ	AUTODETECT
 C-Elysee (4p - 5p)	ABS + TRACT. CONT	1.6 16v 80kw N6A	BOSCH ABS 8.1 AUTODETECT
 C-Elysee (4p - 5p)	AIRBAG	1.6 16v 80kw N6A	SIEMENS AirBag CENTRAL AUTODETEC
 C-Elysee (4p - 5p)	AUTOM. TRANSMISSI	1.6 16v 80kw N6A	A/T AL4 AUTODETECT
 C-Elysee (4p - 5p)	CENTRAL LOCKING	1.6 16v 80kw N6A	AUTODETECT
 C-Elysee (4p - 5p)	ENGINE MANAGEME	1.6 16v 80kw N6A	BOSCH ME7.4.4 AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C-Elysee (4p - 5p)	MAINTENANCE	1.6 16v 80kw N6A	BOSCH ABS 8.1 AUTODETECT
 C-Quatre (china)	ABS	1.6 16v 80kw NFA	BOSCH ABS 8
 C-Quatre (china)	ABS + TRACT. CONT	1.6 16v 80kw NFA	BOSCH ABS 8.0 AUTODETECT
 C-Quatre (china)	ABS + TRACT. CONT	1.6 16v 80kw NFA	BOSCH ABS 8.1 AUTODETECT
 C-Quatre (china)	ABS + TRACT. CONT	1.6 16v 80kw NFA	BOSCH ESP 8.0 AUTODETECT
 C-Quatre (china)	ABS + TRACT. CONT	1.6 16v 80kw NFA	BOSCH ESP 8.1 AUTODETECT
 C-Quatre (china)	AIRBAG	1.6 16v 80kw NFA	AirBag CENTRAL AUTODETECT
 C-Quatre (china)	AIRBAG	1.6 16v 80kw NFA	Autoliv AirBag
 C-Quatre (china)	ANTITHEFT	1.6 16v 80kw NFA	Alarm PSA2 AUTODETECT
 C-Quatre (china)	AUTOM. TRANSMISSI	1.6 16v 80kw NFA	A/T AL4 AUTODETECT
 C-Quatre (china)	AUTOM. TRANSMISSI	1.6 16v 80kw NFA	A/T MCP AUTODETECT
 C-Quatre (china)	CHASSIS NETWORK	1.6 16v 80kw NFA	Body Computer BSI AUTODETECT
 C-Quatre (china)	CHASSIS NETWORK	1.6 16v 80kw NFA	Body Computer BSM AUTODETECT
 C-Quatre (china)	CHASSIS NETWORK	1.6 16v 80kw NFA	Body Computer BSR AUTODETECT
 C-Quatre (china)	CHASSIS NETWORK	1.6 16v 80kw NFA	High frequency receiver AUTODETECT
 C-Quatre (china)	CHASSIS NETWORK	1.6 16v 80kw NFA	JCAE Body Computer BSI+Service
 C-Quatre (china)	CLIMA	1.6 16v 80kw NFA	CLIMA AUTODETECT
 C-Quatre (china)	COMFORT SYSTEM	1.6 16v 80kw NFA	AUTODETECT
 C-Quatre (china)	COMFORT SYSTEM	1.6 16v 80kw NFA	School Module AUTODETECT
 C-Quatre (china)	DASH LAMPS	1.6 16v 80kw NFA	AUTODETECT
 C-Quatre (china)	DASH LAMPS	1.6 16v 80kw NFA	Compte-Tours
 C-Quatre (china)	DASHBOARD	1.6 16v 80kw NFA	AUTODETECT
 C-Quatre (china)	DASHBOARD	1.6 16v 80kw NFA	JCAE Dashboard
 C-Quatre (china)	DRIVER SEAT CONT	1.6 16v 80kw NFA	AUTODETECT
 C-Quatre (china)	DRIVER SIDE DOOR	1.6 16v 80kw NFA	AUTODETECT
 C-Quatre (china)	ELECTRIC STEERING	1.6 16v 80kw NFA	AUTODETECT
 C-Quatre (china)	ELECTRIC STEERING	1.6 16v 80kw NFA	HPI GEP
 C-Quatre (china)	ENGINE MANAGEME	1.6 16v 80kw NFA	BOSCH ME 7.4.5 AUTODETECT
 C-Quatre (china)	KEY ENCODE	1.6 16v 80kw NFA	JCAE Body Computer
 C-Quatre (china)	LANE CHANGE ASSY	1.6 16v 80kw NFA	AUTODETECT
 C-Quatre (china)	MAINTENANCE	1.6 16v 80kw NFA	A/T AL4 AUTODETECT
 C-Quatre (china)	MAINTENANCE	1.6 16v 80kw NFA	AirBag CENTRAL AUTODETECT
 C-Quatre (china)	MAINTENANCE	1.6 16v 80kw NFA	AirBag CENTRAL AUTODETECT
 C-Quatre (china)	MAINTENANCE	1.6 16v 80kw NFA	BOSCH ABS 8
 C-Quatre (china)	MAINTENANCE	1.6 16v 80kw NFA	BOSCH ABS 8.0 AUTODETECT
 C-Quatre (china)	MAINTENANCE	1.6 16v 80kw NFA	BOSCH ABS 8.0 AUTODETECT
 C-Quatre (china)	MAINTENANCE	1.6 16v 80kw NFA	BOSCH ESP 8.0 AUTODETECT
 C-Quatre (china)	MAINTENANCE	1.6 16v 80kw NFA	BOSCH ESP 8.0 AUTODETECT
 C-Quatre (china)	MAINTENANCE	1.6 16v 80kw NFA	BOSCH ESP 8.1 AUTODETECT
 C-Quatre (china)	MAINTENANCE	1.6 16v 80kw NFA	BOSCH ESP 8.1 AUTODETECT
 C-Quatre (china)	MAINTENANCE	1.6 16v 80kw NFA	JCAE Body Computer BSI+Service
 C-Quatre (china)	MAINTENANCE	1.6 16v 80kw NFA	JCAE Body Computer MANUAL
 C-Quatre (china)	MAINTENANCE	1.6 16v 80kw NFA	JCAE Dashboard
 C-Quatre (china)	MAINTENANCE	1.6 16v 80kw NFA	Siemens-JCAE AUTODETECT
 C-Quatre (china)	MAINTENANCE	1.6 16v 80kw NFA	Siemens-JCAE AUTODETECT
 C-Quatre (china)	MAINTENANCE	1.6 16v 80kw NFA	Siemens-JCAE AUTODETECT
 C-Quatre (china)	MAINTENANCE	1.6 16v 80kw NFA	Siemens-JCAE AUTODETECT
 C-Quatre (china)	NAVIGATION	1.6 16v 80kw NFA	AUTODETECT
 C-Quatre (china)	NAVIGATION	1.6 16v 80kw NFA	AUTODETECT
 C-Quatre (china)	PARKING HELP	1.6 16v 80kw NFA	AUTODETECT
 C-Quatre (china)	PARKING HELP	1.6 16v 80kw NFA	VALEO
C-Quatre (china)	PASS. SIDE DOOR	1.6 16v 80kw NFA	AUTODETECT
C-Quatre (china)	PHONE	1.6 16v 80kw NFA	AUTODETECT
C-Quatre (china)	PHONE	1.6 16v 80kw NFA	Mobile phone kit AUTODETECT
C-Quatre (china)	RADIO / CD	1.6 16v 80kw NFA	Ampli Audio AUTODETECT
C-Quatre (china)	RADIO / CD	1.6 16v 80kw NFA	AudioSystem AUTODETECT
C-Quatre (china)	RADIO / CD	1.6 16v 80kw NFA	CD Changer AUTODETECT
C-Quatre (china)	RAIN-LUMINOSITY S	1.6 16v 80kw NFA	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C-Quatre (china)	REMOTE CONTROL E	1.6 16v 80kw NFA	JCAE Body Computer MANUAL
 C-Quatre (china)	STEERING WHEEL E	1.6 16v 80kw NFA	AUTODETECT
 C-Quatre (china)	SWITCHLIGHT MODU	1.6 16v 80kw NFA	EATON/DELPHI
 C-Quatre (china)	TIRE PRESSURE	1.6 16v 80kw NFA	Siemens-JCAE AUTODETECT
 C-Quatre (china)	VISUAL./TELEMATIC	1.6 16v 80kw NFA	Display A+ AUTODETECT
 C-Quatre (china)	VISUAL./TELEMATIC	1.6 16v 80kw NFA	Display C- AUTODETECT
 C-Quatre (china)	VISUAL./TELEMATIC	1.6 16v 80kw NFA	JCAE DIS
 C-triomphe	ABS + TRACT. CONT	2.0 16v 103kw RFJ	BOSCH ABS 8 AUTODETECT
 C-triomphe	ABS + TRACT. CONT	2.0 16v 103kw RFJ	BOSCH ABS 8.1 AUTODETECT
 C-triomphe	ABS + TRACT. CONT	2.0 16v 103kw RFJ	BOSCH ESP 8 AUTODETECT
 C-triomphe	ABS + TRACT. CONT	2.0 16v 103kw RFJ	BOSCH ESP 8.1 AUTODETECT
 C-triomphe	AIRBAG	2.0 16v 103kw RFJ	AirBag CENTRAL AUTODETECT
 C-triomphe	ANTITHEFT	2.0 16v 103kw RFJ	Alarm PSA2 AUTODETECT
 C-triomphe	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ	A/T AL4 AUTODETECT
 C-triomphe	CHASSIS NETWORK	2.0 16v 103kw RFJ	Body Computer BSM AUTODETECT
 C-triomphe	CHASSIS NETWORK	2.0 16v 103kw RFJ	Body Computer BSR AUTODETECT
 C-triomphe	CHASSIS NETWORK	2.0 16v 103kw RFJ	Bosdy Computer BSI AUTODETECT
 C-triomphe	CLIMA	2.0 16v 103kw RFJ	CLIMA AUTODETECT
 C-triomphe	COMFORT SYSTEM	2.0 16v 103kw RFJ	AUTODETECT
 C-triomphe	DASH LAMPS	2.0 16v 103kw RFJ	AUTODETECT
 C-triomphe	DASHBOARD	2.0 16v 103kw RFJ	AUTODETECT
 C-triomphe	DRIVER SEAT CONT	2.0 16v 103kw RFJ	AUTODETECT
 C-triomphe	DRIVER SIDE DOOR	2.0 16v 103kw RFJ	AUTODETECT
 C-triomphe	ELECTRIC STEERING	2.0 16v 103kw RFJ	AUTODETECT
 C-triomphe	ENGINE MANAGEME	2.0 16v 103kw RFJ	Marelli MM6LPB AUTODETECT
 C-triomphe	MAINTENANCE	2.0 16v 103kw RFJ	A/T AL4 AUTODETECT
 C-triomphe	MAINTENANCE	2.0 16v 103kw RFJ	AirBag CENTRAL AUTODETECT
 C-triomphe	MAINTENANCE	2.0 16v 103kw RFJ	AirBag CENTRAL AUTODETECT
 C-triomphe	MAINTENANCE	2.0 16v 103kw RFJ	BOSCH ABS 8 AUTODETECT
 C-triomphe	MAINTENANCE	2.0 16v 103kw RFJ	BOSCH ABS 8 AUTODETECT
 C-triomphe	MAINTENANCE	2.0 16v 103kw RFJ	BOSCH ESP 8 AUTODETECT
 C-triomphe	MAINTENANCE	2.0 16v 103kw RFJ	BOSCH ESP 8 AUTODETECT
 C-triomphe	MAINTENANCE	2.0 16v 103kw RFJ	BOSCH ESP 8.1 AUTODETECT
 C-triomphe	MAINTENANCE	2.0 16v 103kw RFJ	BOSCH ESP 8.1 AUTODETECT
 C-triomphe	NAVIGATION	2.0 16v 103kw RFJ	AUTODETECT
 C-triomphe	PARKING HELP	2.0 16v 103kw RFJ	AUTODETECT
 C-triomphe	PASS. SIDE DOOR	2.0 16v 103kw RFJ	AUTODETECT
 C-triomphe	PHONE	2.0 16v 103kw RFJ	AUTODETECT
 C-triomphe	RADIO / CD	2.0 16v 103kw RFJ	AudioSystem AUTODETECT
 C-triomphe	RADIO / CD	2.0 16v 103kw RFJ	CD Changer AUTODETECT
 C-triomphe	RAIN-LUMINOSITY S	2.0 16v 103kw RFJ	AUTODETECT
 C-triomphe	STEERING WHEEL E	2.0 16v 103kw RFJ	AUTODETECT
 C-triomphe	VISUAL./TELEMATIC	2.0 16v 103kw RFJ	Display A+ AUTODETECT
 C-triomphe	VISUAL./TELEMATIC	2.0 16v 103kw RFJ	Display C- AUTODETECT
 DS3	ABS + TRACT. CONT	1.1 44kw HFV (10-..)	TEVES MK60
 DS3	ABS + TRACT. CONT	1.4 16v 72kw Vti 8FR (10-..)	TEVES MK60
 DS3	ABS + TRACT. CONT	1.6 16v 110kw THP 5FX (10-..)	TEVES MK60
 DS3	ABS + TRACT. CONT	1.6 16v 115kw 8FR (10-..)	TEVES MK60
 DS3	ABS + TRACT. CONT	1.6 16v 88kw 8FR (10-..)	TEVES MK60
 DS3	ABS + TRACT. CONT	1.6 HDI 16v 68kw 8FR (10-..)	TEVES MK60
 DS3	ABS + TRACT. CONT	1.6 HDI 82kw 9HP-FAP (10-..)	TEVES MK60
 DS3	ENGINE MANAGEME	1.4 16v 72kw Vti 8FR (10-..)	EOBD
 DS3	ENGINE MANAGEME	1.6 16v 110kw THP 5FX (10-..)	EOBD
 DS3	ENGINE MANAGEME	1.6 16v 115kw 8FR (10-..)	EOBD
 DS3	ENGINE MANAGEME	1.6 16v 88kw 8FR (10-..)	EOBD
 DS3	ENGINE MANAGEME	1.6 HDI 16v 68kw 8FR (10-..)	EOBD
 DS3	ENGINE MANAGEME	1.6 HDI 82kw 9HP-FAP (10-..)	BOSCH EDC 17 C1 0 Common Rail
 DS3	PARKING HELP	1.4 16v 72kw Vti 8FR (10-..)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 DS3	PARKING HELP	1.6 16v 110kw THP 5FX (10-..)	
 DS3	PARKING HELP	1.6 16v 115kw 8FR (10-..)	
 DS3	PARKING HELP	1.6 16v 88kw 8FR (10-..)	
 DS3	PARKING HELP	1.6 HDI 16v 68kw 8FR (10-..)	
 DS3	PARKING HELP	1.6 HDI 82kw 9HP-FAP (10-..)	
 Elysee	AIRBAG	1.6 16v 80kw NFU	SIEMENS AirBag CENTRAL AUTODETEC
 Elysee	AUTOM. TRANSMISSI	1.6 16v 80kw NFU	A/T AL4 TA2000 AUTODETECT
 Elysee	ENGINE MANAGEME	1.6 16v 80kw NFU	BOSCH ME 7.4.4 AUTODETECT
 Elysee	MAINTENANCE	1.6 16v 80kw NFU	A/T AL4 TA2000 AUTODETECT
 Evasion	ABS	1.8 8v 73kw LFW (98-..)	BOSCH ABS ABR 5.3
 Evasion	ABS	1.9 TD 8v 66kw D8B (98-..)	BOSCH ABS ABR 5.3
 Evasion	ABS	1.9 TD 8v 66kw DHX (98-..)	BOSCH ABS ABR 5.3
 Evasion	ABS	2.0 16v 100kw RFN (98-..)	BOSCH ABS ABR 5.3
 Evasion	ABS	2.0 16v 97kw RFV (98-..)	BOSCH ABS ABR 5.3
 Evasion	ABS	2.0 8v 89kw RFU (98-..)	BOSCH ABS ABR 5.3
 Evasion	ABS	2.0 HDI 16v 81kw RHZ (98-..)	BOSCH ABS ABR 5.3
 Evasion	ABS	2.0 T 8v 108kw RGX (98-..)	BOSCH ABS ABR 5.3
 Evasion	ABS	2.1 TD 12v 81kw P8C (98-..)	BOSCH ABS ABR 5.3
 Evasion	AUTOM. TRANSMISSI	1.8 8v 73kw LFW	A/T AL4 AUTODETECT
 Evasion	AUTOM. TRANSMISSI	1.9 TD 8v 66kw D8B	A/T AL4 AUTODETECT
 Evasion	AUTOM. TRANSMISSI	1.9 TD 8v 66kw DHX	A/T AL4 AUTODETECT
 Evasion	AUTOM. TRANSMISSI	2.0 16v 100kw RFN	A/T AL4 AUTODETECT
 Evasion	AUTOM. TRANSMISSI	2.0 16v 97kw RFV	A/T AL4 AUTODETECT
 Evasion	AUTOM. TRANSMISSI	2.0 8v 89kw RFU	A/T AL4 AUTODETECT
 Evasion	AUTOM. TRANSMISSI	2.0 HDI 16v 80kw RHW	A/T AL4 AUTODETECT
 Evasion	AUTOM. TRANSMISSI	2.0 HDI 16v 81kw RHZ	A/T AL4 AUTODETECT
 Evasion	AUTOM. TRANSMISSI	2.0 T 8v 108kw RGX	A/T AL4 AUTODETECT
 Evasion	AUTOM. TRANSMISSI	2.1 TD 12v 81kw P8C	A/T AL4 AUTODETECT
 Evasion	DIESEL MANAGEMEN	1.9 TD 8v 66kw D8B	BOSCH AS3 VP20
 Evasion	DIESEL MANAGEMEN	1.9 TD 8v 66kw DHX	BOSCH AS3 VP20
 Evasion	ENGINE MANAGEME	1.8 8v 73kw LFW 01>	EOBD
 Evasion	ENGINE MANAGEME	2.0 16v 100kw RFN	Marelli MM48P AUTODETECT
 Evasion	ENGINE MANAGEME	2.0 16v 97kw RFV (01-..)	EOBD
 Evasion	ENGINE MANAGEME	2.0 8v 89kw RFU	Marelli MM 8P.22 [Fast]
 Evasion	ENGINE MANAGEME	2.0 HDI 16v 80kw RHW	BOSCH EDC15 C2 Common Rail AUTODE
 Evasion	ENGINE MANAGEME	2.0 HDI 16v 81kw RHZ (...00)	BOSCH EDC 15 C2 Common Rail
 Evasion	ENGINE MANAGEME	2.0 T 8v 108kw RGX	BOSCH Motronic MP3.2 [Fast]
 Evasion	ENGINE MANAGEME	2.1 TD 12v 81kw P8C	LUCAS Diesel EPIC
 Evasion	MAINTENANCE	1.8 8v 73kw LFW	A/T AL4 AUTODETECT
 Evasion	MAINTENANCE	1.8 8v 73kw LFW (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	1.8 8v 73kw LFW (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	1.8 8v 73kw LFW (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	1.8 8v 73kw LFW (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	1.8 8v 73kw LFW (98-..)	MANUAL
 Evasion	MAINTENANCE	1.9 TD 8v 66kw D8B	A/T AL4 AUTODETECT
 Evasion	MAINTENANCE	1.9 TD 8v 66kw D8B (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	1.9 TD 8v 66kw D8B (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	1.9 TD 8v 66kw D8B (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	1.9 TD 8v 66kw D8B (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	1.9 TD 8v 66kw D8B (98-..)	MANUAL
 Evasion	MAINTENANCE	1.9 TD 8v 66kw DHX	A/T AL4 AUTODETECT
 Evasion	MAINTENANCE	1.9 TD 8v 66kw DHX (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	1.9 TD 8v 66kw DHX (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	1.9 TD 8v 66kw DHX (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	1.9 TD 8v 66kw DHX (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	1.9 TD 8v 66kw DHX (98-..)	MANUAL
 Evasion	MAINTENANCE	2.0 16v 100kw RFN	A/T AL4 AUTODETECT
 Evasion	MAINTENANCE	2.0 16v 100kw RFN (98-..)	BOSCH ABS ABR 5.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Evasion	MAINTENANCE	2.0 16v 100kw RFN (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	2.0 16v 100kw RFN (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	2.0 16v 100kw RFN (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	2.0 16v 100kw RFN (98-..)	MANUAL
 Evasion	MAINTENANCE	2.0 16v 97kw RFV	A/T AL4 AUTODETECT
 Evasion	MAINTENANCE	2.0 16v 97kw RFV (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	2.0 16v 97kw RFV (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	2.0 16v 97kw RFV (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	2.0 16v 97kw RFV (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	2.0 16v 97kw RFV (98-..)	MANUAL
 Evasion	MAINTENANCE	2.0 8v 89kw RFU	A/T AL4 AUTODETECT
 Evasion	MAINTENANCE	2.0 8v 89kw RFU (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	2.0 8v 89kw RFU (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	2.0 8v 89kw RFU (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	2.0 8v 89kw RFU (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	2.0 8v 89kw RFU (98-..)	MANUAL
 Evasion	MAINTENANCE	2.0 HDI 16v 80kw RHW	A/T AL4 AUTODETECT
 Evasion	MAINTENANCE	2.0 HDI 16v 80kw RHW	BOSCH EDC15 C2 Common Rail AUTODE
 Evasion	MAINTENANCE	2.0 HDI 16v 80kw RHW (98-..)	MANUAL
 Evasion	MAINTENANCE	2.0 HDI 16v 81kw RHZ	A/T AL4 AUTODETECT
 Evasion	MAINTENANCE	2.0 HDI 16v 81kw RHZ (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	2.0 HDI 16v 81kw RHZ (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	2.0 HDI 16v 81kw RHZ (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	2.0 HDI 16v 81kw RHZ (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	2.0 HDI 16v 81kw RHZ (98-..)	MANUAL
 Evasion	MAINTENANCE	2.0 T 8v 108kw RGX	A/T AL4 AUTODETECT
 Evasion	MAINTENANCE	2.0 T 8v 108kw RGX (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	2.0 T 8v 108kw RGX (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	2.0 T 8v 108kw RGX (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	2.0 T 8v 108kw RGX (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	2.0 T 8v 108kw RGX (98-..)	MANUAL
 Evasion	MAINTENANCE	2.1 TD 12v 81kw P8C	A/T AL4 AUTODETECT
 Evasion	MAINTENANCE	2.1 TD 12v 81kw P8C (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	2.1 TD 12v 81kw P8C (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	2.1 TD 12v 81kw P8C (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	2.1 TD 12v 81kw P8C (98-..)	BOSCH ABS ABR 5.3
 Evasion	MAINTENANCE	2.1 TD 12v 81kw P8C (98-..)	MANUAL
 Evasion	SERVICE LIGHT RES	1.8 8v 73kw LFW (98-..)	MANUAL
 Evasion	SERVICE LIGHT RES	1.9 TD 8v 66kw D8B (98-..)	MANUAL
 Evasion	SERVICE LIGHT RES	1.9 TD 8v 66kw DHX (98-..)	MANUAL
 Evasion	SERVICE LIGHT RES	2.0 16v 100kw RFN (98-..)	MANUAL
 Evasion	SERVICE LIGHT RES	2.0 16v 97kw RFV (98-..)	MANUAL
 Evasion	SERVICE LIGHT RES	2.0 8v 89kw RFU (98-..)	MANUAL
 Evasion	SERVICE LIGHT RES	2.0 HDI 16v 80kw RHW (98-..)	MANUAL
 Evasion	SERVICE LIGHT RES	2.0 HDI 16v 81kw RHZ (98-..)	MANUAL
 Evasion	SERVICE LIGHT RES	2.0 T 8v 108kw RGX (98-..)	MANUAL
 Evasion	SERVICE LIGHT RES	2.1 TD 12v 81kw P8C (98-..)	MANUAL
 Jumper 1	ABS	1.9 D 68kw D9B (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	ABS	1.9 D 8v 52kw D9B (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	ABS	1.9 D 8v 52kw DJY (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	ABS	1.9 TD 8v 66kw D8C (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	ABS	1.9 TD 8v 66kw DHX (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	ABS	2.0 8v 80kw RFL (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	ABS	2.0 8v 80kw RFW (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	ABS	2.0 8v 81kw RFL (02-06)	BOSCH ABS 8
 Jumper 1	ABS	2.0 8v 81kw RFL (02-06)	BOSCH ABS ABR 5.3
 Jumper 1	ABS	2.0 HDI 8v 63kw RHV (02-06)	BOSCH ABS 8
 Jumper 1	ABS	2.0 HDI 8v 63kw RHV (02-06)	BOSCH ABS ABR 5.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Jumper 1	ABS	2.0 HDI 8v 63kw RHV (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	ABS	2.2 HDI 8v 74kw 4HY (02-06)	BOSCH ABS 8
 Jumper 1	ABS	2.2 HDI 8v 74kw 4HY (02-06)	BOSCH ABS ABR 5.3
 Jumper 1	ABS	2.3 HDI 16v 81kw F1AE0481C (02-0	BOSCH ABS 8
 Jumper 1	ABS	2.3 HDI 16v 81kw F1AE0481C (02-0	BOSCH ABS ABR 5.3
 Jumper 1	ABS	2.5 D 8v 63kw T9A (02-06)	BOSCH ABS 8
 Jumper 1	ABS	2.5 D 8v 63kw T9A (02-06)	BOSCH ABS ABR 5.3
 Jumper 1	ABS	2.5 D 8v 63kw T9A (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	ABS	2.5 TD 12V 76kw T8A (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	ABS	2.5 TD 12V 76kw THZ (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	ABS	2.5 TDI 12v 79kw THX (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	ABS	2.8 D 8v 64kw 8140.63 (02-06)	BOSCH ABS 8
 Jumper 1	ABS	2.8 D 8v 64kw 8140.63 (02-06)	BOSCH ABS ABR 5.3
 Jumper 1	ABS	2.8 D 8v 64kw 8140.63 (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	ABS	2.8 HDI 8v 108kw 43N (02-06)	BOSCH ABS 8
 Jumper 1	ABS	2.8 HDI 8v 108kw 43N (02-06)	BOSCH ABS ABR 5.3
 Jumper 1	ABS	2.8 HDI 8v 93kw 43S (02-06)	BOSCH ABS 8
 Jumper 1	ABS	2.8 HDI 8v 93kw 43S (02-06)	BOSCH ABS ABR 5.3
 Jumper 1	ABS	2.8 HDI 8v 93kw 43S (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	AIRBAG	2.0 8v 81kw RFL (02-06)	SIEMENS AirBag
 Jumper 1	AIRBAG	2.0 8v 81kw RFL (02-06)	TRW SRS 1
 Jumper 1	AIRBAG	2.0 HDI 8v 63kw RHV (02-06)	SIEMENS AirBag
 Jumper 1	AIRBAG	2.0 HDI 8v 63kw RHV (02-06)	TRW SRS 1
 Jumper 1	AIRBAG	2.2 HDI 8v 74kw 4HY (02-06)	SIEMENS AirBag
 Jumper 1	AIRBAG	2.2 HDI 8v 74kw 4HY (02-06)	TRW SRS 1
 Jumper 1	AIRBAG	2.3 HDI 16v 81kw F1AE0481C (02-0	SIEMENS AirBag
 Jumper 1	AIRBAG	2.3 HDI 16v 81kw F1AE0481C (02-0	TRW SRS 1
 Jumper 1	AIRBAG	2.5 D 8v 63kw T9A (02-06)	SIEMENS AirBag
 Jumper 1	AIRBAG	2.5 D 8v 63kw T9A (02-06)	TRW SRS 1
 Jumper 1	AIRBAG	2.8 D 8v 64kw 8140.63 (02-06)	SIEMENS AirBag
 Jumper 1	AIRBAG	2.8 D 8v 64kw 8140.63 (02-06)	TRW SRS 1
 Jumper 1	AIRBAG	2.8 HDI 8v 108kw 43N (02-06)	SIEMENS AirBag
 Jumper 1	AIRBAG	2.8 HDI 8v 108kw 43N (02-06)	TRW SRS 1
 Jumper 1	AIRBAG	2.8 HDI 8v 93kw 43S (02-06)	SIEMENS AirBag
 Jumper 1	AIRBAG	2.8 HDI 8v 93kw 43S (02-06)	TRW SRS 1
 Jumper 1	AUTOM. TRANSMISSI	2.0 8v 81kw RFL (02-06)	A/T 4HP20 AUTODETECT
 Jumper 1	AUTOM. TRANSMISSI	2.0 HDI 8v 63kw RHV (02-06)	A/T 4HP20 AUTODETECT
 Jumper 1	AUTOM. TRANSMISSI	2.2 HDI 8v 74kw 4HY (02-06)	A/T 4HP20 AUTODETECT
 Jumper 1	AUTOM. TRANSMISSI	2.3 HDI 16v 81kw F1AE0481C (02-0	A/T 4HP20 AUTODETECT
 Jumper 1	AUTOM. TRANSMISSI	2.5 D 8v 63kw T9A (02-06)	A/T 4HP20 AUTODETECT
 Jumper 1	AUTOM. TRANSMISSI	2.8 D 8v 64kw 8140.63 (02-06)	A/T 4HP20 AUTODETECT
 Jumper 1	AUTOM. TRANSMISSI	2.8 HDI 8v 108kw 43N (02-06)	A/T 4HP20 AUTODETECT
 Jumper 1	AUTOM. TRANSMISSI	2.8 HDI 8v 93kw 43S (02-06)	A/T 4HP20 AUTODETECT
 Jumper 1	AUX. HEATING	2.0 8v 81kw RFL (02-06)	AUTODETECT
 Jumper 1	AUX. HEATING	2.0 HDI 8v 63kw RHV (02-06)	AUTODETECT
 Jumper 1	AUX. HEATING	2.2 HDI 8v 74kw 4HY (02-06)	AUTODETECT
 Jumper 1	AUX. HEATING	2.3 HDI 16v 81kw F1AE0481C (02-0	AUTODETECT
 Jumper 1	AUX. HEATING	2.5 D 8v 63kw T9A (02-06)	AUTODETECT
 Jumper 1	AUX. HEATING	2.8 D 8v 64kw 8140.63 (02-06)	AUTODETECT
 Jumper 1	AUX. HEATING	2.8 HDI 8v 108kw 43N (02-06)	AUTODETECT
 Jumper 1	AUX. HEATING	2.8 HDI 8v 93kw 43S (02-06)	AUTODETECT
 Jumper 1	CHASSIS NETWORK	2.0 8v 81kw RFL (02-06)	Marelli Body Computer 6
 Jumper 1	CHASSIS NETWORK	2.0 HDI 8v 63kw RHV (02-06)	Marelli Body Computer 6
 Jumper 1	CHASSIS NETWORK	2.2 HDI 8v 74kw 4HY (02-06)	Marelli Body Computer 6
 Jumper 1	CHASSIS NETWORK	2.3 HDI 16v 81kw F1AE0481C (02-0	Marelli Body Computer 6
 Jumper 1	CHASSIS NETWORK	2.5 D 8v 63kw T9A (02-06)	Marelli Body Computer 6
 Jumper 1	CHASSIS NETWORK	2.8 D 8v 64kw 8140.63 (02-06)	Marelli Body Computer 6
 Jumper 1	CHASSIS NETWORK	2.8 HDI 8v 108kw 43N (02-06)	Marelli Body Computer 6

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Jumper 1	CHASSIS NETWORK	2.8 HDI 8v 93kw 43S (02-06)	Marelli Body Computer 6
 Jumper 1	DASHBOARD	2.0 8v 81kw RFL (02-06)	Marelli Dashboard
 Jumper 1	DASHBOARD	2.0 HDI 8v 63kw RHV (02-06)	Marelli Dashboard
 Jumper 1	DASHBOARD	2.2 HDI 8v 74kw 4HY (02-06)	Marelli Dashboard
 Jumper 1	DASHBOARD	2.3 HDI 16v 81kw F1AE0481C (02-0	Marelli Dashboard
 Jumper 1	DASHBOARD	2.5 D 8v 63kw T9A (02-06)	Marelli Dashboard
 Jumper 1	DASHBOARD	2.8 D 8v 64kw 8140.63 (02-06)	Marelli Dashboard
 Jumper 1	DASHBOARD	2.8 HDI 8v 108kw 43N (02-06)	Marelli Dashboard
 Jumper 1	DASHBOARD	2.8 HDI 8v 93kw 43S (02-06)	Marelli Dashboard
 Jumper 1	ENGINE MANAGEME	2.0 8v 80kw RFL (94-02)	Marelli MM48P AUTODETECT
 Jumper 1	ENGINE MANAGEME	2.0 8v 80kw RFW (01-02)	EOBD
 Jumper 1	ENGINE MANAGEME	2.0 8v 81kw RFL (02-06)	Marelli MM48P AUTODETECT
 Jumper 1	ENGINE MANAGEME	2.0 HDI 8v 63kw RHV (02-06)	DIESEL AUTODETECT
 Jumper 1	ENGINE MANAGEME	2.0 HDI 8v 63kw RHV (94-02)	DIESEL AUTODETECT
 Jumper 1	ENGINE MANAGEME	2.2 HDI 8v 74kw 4HY (02-06)	BOSCH EDC 15 Common Rail (JTD '99)
 Jumper 1	ENGINE MANAGEME	2.2 HDI 8v 74kw 4HY (02-06)	BOSCH EDC 16 Common Rail
 Jumper 1	ENGINE MANAGEME	2.3 HDI 16v 81kw F1AE0481C (02-0	EOBD
 Jumper 1	ENGINE MANAGEME	2.5 D 8v 63kw T9A (02-06)	EOBD
 Jumper 1	ENGINE MANAGEME	2.8 D 8v 64kw 8140.63 (02-06)	EOBD
 Jumper 1	ENGINE MANAGEME	2.8 HDI 8v 108kw 43N (02-06)	BOSCH EDC 15 Common Rail (JTD '99)
 Jumper 1	ENGINE MANAGEME	2.8 HDI 8v 108kw 43N (02-06)	DIESEL AUTODETECT
 Jumper 1	ENGINE MANAGEME	2.8 HDI 8v 93kw 43S (02-06)	BOSCH EDC 15 Common Rail (JTD '99)
 Jumper 1	ENGINE MANAGEME	2.8 HDI 8v 93kw 43S (02-06)	DIESEL AUTODETECT
 Jumper 1	ENGINE MANAGEME	2.8 HDI 8v 93kw 43S (94-02)	DIESEL AUTODETECT
 Jumper 1	MAINTENANCE	1.9 D 68kw D9B (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	1.9 D 68kw D9B (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	1.9 D 68kw D9B (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	1.9 D 68kw D9B (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	1.9 D 8v 52kw D9B (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	1.9 D 8v 52kw D9B (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	1.9 D 8v 52kw D9B (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	1.9 D 8v 52kw DJY (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	1.9 D 8v 52kw DJY (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	1.9 D 8v 52kw DJY (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	1.9 D 8v 52kw DJY (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	1.9 TD 8v 66kw D8C (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	1.9 TD 8v 66kw D8C (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	1.9 TD 8v 66kw D8C (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	1.9 TD 8v 66kw DHX (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	1.9 TD 8v 66kw DHX (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	1.9 TD 8v 66kw DHX (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	1.9 TD 8v 66kw DHX (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	1.9 TD 8v 66kw DHX (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.0 8v 80kw RFL (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.0 8v 80kw RFL (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.0 8v 80kw RFL (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.0 8v 80kw RFL (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.0 8v 80kw RFW (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.0 8v 80kw RFW (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.0 8v 80kw RFW (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.0 8v 80kw RFW (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.0 8v 81kw RFL (02-06)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.0 8v 81kw RFL (02-06)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.0 8v 81kw RFL (02-06)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.0 8v 81kw RFL (02-06)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.0 8v 81kw RFL (02-06)	Marelli Dashboard
 Jumper 1	MAINTENANCE	2.0 8v 81kw RFL (02-06)	Marelli Dashboard

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Jumper 1	MAINTENANCE	2.0 8v 81kw RFL (02-06)	Marelli Dashboard
 Jumper 1	MAINTENANCE	2.0 8v 81kw RFL (02-06)	Marelli Dashboard
 Jumper 1	MAINTENANCE	2.0 HDI 8v 63kw RHV (02-06)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.0 HDI 8v 63kw RHV (02-06)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.0 HDI 8v 63kw RHV (02-06)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.0 HDI 8v 63kw RHV (02-06)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.0 HDI 8v 63kw RHV (02-06)	Marelli Dashboard
 Jumper 1	MAINTENANCE	2.0 HDI 8v 63kw RHV (02-06)	Marelli Dashboard
 Jumper 1	MAINTENANCE	2.0 HDI 8v 63kw RHV (02-06)	Marelli Dashboard
 Jumper 1	MAINTENANCE	2.0 HDI 8v 63kw RHV (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.0 HDI 8v 63kw RHV (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.0 HDI 8v 63kw RHV (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.0 HDI 8v 63kw RHV (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.2 HDI 8v 74kw 4HY (02-06)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.2 HDI 8v 74kw 4HY (02-06)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.2 HDI 8v 74kw 4HY (02-06)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.2 HDI 8v 74kw 4HY (02-06)	BOSCH EDC 16 Common Rail
 Jumper 1	MAINTENANCE	2.2 HDI 8v 74kw 4HY (02-06)	Marelli Dashboard
 Jumper 1	MAINTENANCE	2.2 HDI 8v 74kw 4HY (02-06)	Marelli Dashboard
 Jumper 1	MAINTENANCE	2.2 HDI 8v 74kw 4HY (02-06)	Marelli Dashboard
 Jumper 1	MAINTENANCE	2.2 HDI 8v 74kw 4HY (02-06)	Marelli Dashboard
 Jumper 1	MAINTENANCE	2.3 HDI 16v 81kw F1AE0481C (02-0	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.3 HDI 16v 81kw F1AE0481C (02-0	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.3 HDI 16v 81kw F1AE0481C (02-0	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.3 HDI 16v 81kw F1AE0481C (02-0	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.3 HDI 16v 81kw F1AE0481C (02-0	Marelli Dashboard
 Jumper 1	MAINTENANCE	2.3 HDI 16v 81kw F1AE0481C (02-0	Marelli Dashboard
 Jumper 1	MAINTENANCE	2.3 HDI 16v 81kw F1AE0481C (02-0	Marelli Dashboard
 Jumper 1	MAINTENANCE	2.3 HDI 16v 81kw F1AE0481C (02-0	Marelli Dashboard
 Jumper 1	MAINTENANCE	2.5 D 8v 63kw T9A (02-06)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.5 D 8v 63kw T9A (02-06)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.5 D 8v 63kw T9A (02-06)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.5 D 8v 63kw T9A (02-06)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.5 D 8v 63kw T9A (02-06)	Marelli Dashboard
 Jumper 1	MAINTENANCE	2.5 D 8v 63kw T9A (02-06)	Marelli Dashboard
 Jumper 1	MAINTENANCE	2.5 D 8v 63kw T9A (02-06)	Marelli Dashboard
 Jumper 1	MAINTENANCE	2.5 D 8v 63kw T9A (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.5 D 8v 63kw T9A (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.5 D 8v 63kw T9A (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.5 D 8v 63kw T9A (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.5 TD 12V 76kw T8A (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.5 TD 12V 76kw T8A (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.5 TD 12V 76kw T8A (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.5 TD 12V 76kw T8A (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.5 TD 12V 76kw THZ (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.5 TD 12V 76kw THZ (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.5 TD 12V 76kw THZ (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.5 TD 12V 76kw THZ (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.5 TDI 12v 79kw THX (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.5 TDI 12v 79kw THX (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.5 TDI 12v 79kw THX (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.5 TDI 12v 79kw THX (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.8 D 8v 64kw 8140.63 (02-06)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.8 D 8v 64kw 8140.63 (02-06)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.8 D 8v 64kw 8140.63 (02-06)	BOSCH ABS ABR 5.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Jumper 1	MAINTENANCE	2.8 D 8v 64kw 8140.63 (02-06)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.8 D 8v 64kw 8140.63 (02-06)	Marelli Dashboard
 Jumper 1	MAINTENANCE	2.8 D 8v 64kw 8140.63 (02-06)	Marelli Dashboard
 Jumper 1	MAINTENANCE	2.8 D 8v 64kw 8140.63 (02-06)	Marelli Dashboard
 Jumper 1	MAINTENANCE	2.8 D 8v 64kw 8140.63 (02-06)	Marelli Dashboard
 Jumper 1	MAINTENANCE	2.8 D 8v 64kw 8140.63 (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.8 D 8v 64kw 8140.63 (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.8 D 8v 64kw 8140.63 (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.8 D 8v 64kw 8140.63 (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.8 HDI 8v 108kw 43N (02-06)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.8 HDI 8v 108kw 43N (02-06)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.8 HDI 8v 108kw 43N (02-06)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.8 HDI 8v 108kw 43N (02-06)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.8 HDI 8v 108kw 43N (02-06)	Marelli Dashboard
 Jumper 1	MAINTENANCE	2.8 HDI 8v 108kw 43N (02-06)	Marelli Dashboard
 Jumper 1	MAINTENANCE	2.8 HDI 8v 108kw 43N (02-06)	Marelli Dashboard
 Jumper 1	MAINTENANCE	2.8 HDI 8v 108kw 43N (02-06)	Marelli Dashboard
 Jumper 1	MAINTENANCE	2.8 HDI 8v 93kw 43S (02-06)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.8 HDI 8v 93kw 43S (02-06)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.8 HDI 8v 93kw 43S (02-06)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.8 HDI 8v 93kw 43S (02-06)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.8 HDI 8v 93kw 43S (02-06)	Marelli Dashboard
 Jumper 1	MAINTENANCE	2.8 HDI 8v 93kw 43S (02-06)	Marelli Dashboard
 Jumper 1	MAINTENANCE	2.8 HDI 8v 93kw 43S (02-06)	Marelli Dashboard
 Jumper 1	MAINTENANCE	2.8 HDI 8v 93kw 43S (02-06)	Marelli Dashboard
 Jumper 1	MAINTENANCE	2.8 HDI 8v 93kw 43S (02-06)	Marelli Dashboard
 Jumper 1	MAINTENANCE	2.8 HDI 8v 93kw 43S (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.8 HDI 8v 93kw 43S (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.8 HDI 8v 93kw 43S (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	MAINTENANCE	2.8 HDI 8v 93kw 43S (94-02)	BOSCH ABS ABR 5.3
 Jumper 1	SERVICE LIGHT RES	2.0 8v 81kw RFL (02-06)	Marelli Dashboard
 Jumper 1	SERVICE LIGHT RES	2.0 HDI 8v 63kw RHV (02-06)	Marelli Dashboard
 Jumper 1	SERVICE LIGHT RES	2.2 HDI 8v 74kw 4HY (02-06)	Marelli Dashboard
 Jumper 1	SERVICE LIGHT RES	2.3 HDI 16v 81kw F1AE0481C (02-0	Marelli Dashboard
 Jumper 1	SERVICE LIGHT RES	2.5 D 8v 63kw T9A (02-06)	Marelli Dashboard
 Jumper 1	SERVICE LIGHT RES	2.8 D 8v 64kw 8140.63 (02-06)	Marelli Dashboard
 Jumper 1	SERVICE LIGHT RES	2.8 HDI 8v 108kw 43N (02-06)	Marelli Dashboard
 Jumper 1	SERVICE LIGHT RES	2.8 HDI 8v 93kw 43S (02-06)	Marelli Dashboard
 Jumper 2	ABS	1.6 HDI 16v 66kw 9HU (06-..)	BOSCH ABS 8.0 AUTODETECT
 Jumper 2	ABS	2.0 16v 103kw RFH (06-..)	BOSCH ABS 8.0 AUTODETECT
 Jumper 2	ABS	2.0 HDI 16v 100kw RHR (06-..)	BOSCH ABS 8.0 AUTODETECT
 Jumper 2	ABS	2.0 HDI 16v 88kw RHG (06-..)	BOSCH ABS 8.0 AUTODETECT
 Jumper 2	ABS	2.0 HDI 16v 88kw RHK (06-..)	BOSCH ABS 8.0 AUTODETECT
 Jumper 2	ABS	2.2 HDI 16v 74kw 4HV (06-..)	BOSCH ABS 8.0 AUTODETECT
 Jumper 2	ABS	2.2 HDI 16v 88kw 4HU (06-..)	BOSCH ABS 8.0 AUTODETECT
 Jumper 2	ABS	2.3 HDI 16v 88kw F1AE0481D (06-..)	BOSCH ABS 8.0 AUTODETECT
 Jumper 2	ABS	2.3 HDI 16v 95kw F1AE0481N (06-..)	BOSCH ABS 8.0 AUTODETECT
 Jumper 2	ABS	3.0 HDI 16v 115kw F1CE0481D (06-..)	BOSCH ABS 8.0 AUTODETECT
 Jumper 2	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HU (06-..)	ABS+TC AUTODETECT
 Jumper 2	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HU (06-..)	BOSCH ESP AUTODETECT
 Jumper 2	ABS + TRACT. CONT	2.0 16v 103kw RFH (06-..)	ABS+TC AUTODETECT
 Jumper 2	ABS + TRACT. CONT	2.0 16v 103kw RFH (06-..)	BOSCH ESP AUTODETECT
 Jumper 2	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR (06-..)	ABS+TC AUTODETECT
 Jumper 2	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR (06-..)	BOSCH ESP AUTODETECT
 Jumper 2	ABS + TRACT. CONT	2.0 HDI 16v 88kw RHG (06-..)	ABS+TC AUTODETECT
 Jumper 2	ABS + TRACT. CONT	2.0 HDI 16v 88kw RHG (06-..)	BOSCH ESP AUTODETECT
 Jumper 2	ABS + TRACT. CONT	2.0 HDI 16v 88kw RHK (06-..)	ABS+TC AUTODETECT
 Jumper 2	ABS + TRACT. CONT	2.0 HDI 16v 88kw RHK (06-..)	BOSCH ESP AUTODETECT
 Jumper 2	ABS + TRACT. CONT	2.2 HDI 16v 74kw 4HV (06-..)	ABS+TC AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Jumper 2	ABS + TRACT. CONT	2.2 HDI 16v 74kw 4HV (06-..)	ESP AUTODETECT
 Jumper 2	ABS + TRACT. CONT	2.2 HDI 16v 88kw 4HU (06-..)	ABS+TC AUTODETECT
 Jumper 2	ABS + TRACT. CONT	2.2 HDI 16v 88kw 4HU (06-..)	BOSCH ESP AUTODETECT
 Jumper 2	ABS + TRACT. CONT	2.3 HDI 16v 88kw F1AE0481D (06-..)	ABS+TC AUTODETECT
 Jumper 2	ABS + TRACT. CONT	2.3 HDI 16v 88kw F1AE0481D (06-..)	BOSCH ESP AUTODETECT
 Jumper 2	ABS + TRACT. CONT	2.3 HDI 16v 95kw F1AE0481N (06-..)	ABS+TC AUTODETECT
 Jumper 2	ABS + TRACT. CONT	2.3 HDI 16v 95kw F1AE0481N (06-..)	BOSCH ESP AUTODETECT
 Jumper 2	ABS + TRACT. CONT	3.0 HDI 16v 115kw F1CE0481D (06-..)	ABS+TC AUTODETECT
 Jumper 2	ABS + TRACT. CONT	3.0 HDI 16v 115kw F1CE0481D (06-..)	BOSCH ESP AUTODETECT
 Jumper 2	AIRBAG	1.6 HDI 16v 66kw 9HU (06-..)	AirBag CENTRAL AUTODETECT
 Jumper 2	AIRBAG	2.0 16v 103kw RFH (06-..)	AirBag CENTRAL AUTODETECT
 Jumper 2	AIRBAG	2.0 HDI 16v 100kw RHR (06-..)	AirBag CENTRAL AUTODETECT
 Jumper 2	AIRBAG	2.0 HDI 16v 88kw RHG (06-..)	AirBag CENTRAL AUTODETECT
 Jumper 2	AIRBAG	2.0 HDI 16v 88kw RHK (06-..)	AirBag CENTRAL AUTODETECT
 Jumper 2	AIRBAG	2.2 HDI 16v 74kw 4HV (06-..)	AirBag CENTRAL AUTODETECT
 Jumper 2	AIRBAG	2.2 HDI 16v 88kw 4HU (06-..)	AirBag CENTRAL AUTODETECT
 Jumper 2	AIRBAG	2.3 HDI 16v 88kw F1AE0481D (06-..)	AirBag CENTRAL AUTODETECT
 Jumper 2	AIRBAG	2.3 HDI 16v 95kw F1AE0481N (06-..)	AirBag CENTRAL AUTODETECT
 Jumper 2	AIRBAG	3.0 HDI 16v 115kw F1CE0481D (06-..)	AirBag CENTRAL AUTODETECT
 Jumper 2	AUX. HEATING	1.6 HDI 16v 66kw 9HU (06-..)	AUTODETECT
 Jumper 2	AUX. HEATING	2.0 16v 103kw RFH (06-..)	AUTODETECT
 Jumper 2	AUX. HEATING	2.0 HDI 16v 100kw RHR (06-..)	AUTODETECT
 Jumper 2	AUX. HEATING	2.0 HDI 16v 88kw RHG (06-..)	AUTODETECT
 Jumper 2	AUX. HEATING	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 Jumper 2	AUX. HEATING	2.2 HDI 16v 74kw 4HV (06-..)	AUTODETECT
 Jumper 2	AUX. HEATING	2.2 HDI 16v 88kw 4HU (06-..)	AUTODETECT
 Jumper 2	AUX. HEATING	2.3 HDI 16v 88kw F1AE0481D (06-..)	AUTODETECT
 Jumper 2	AUX. HEATING	2.3 HDI 16v 95kw F1AE0481N (06-..)	AUTODETECT
 Jumper 2	AUX. HEATING	3.0 HDI 16v 115kw F1CE0481D (06-..)	AUTODETECT
 Jumper 2	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HU (06-..)	Body Computer BSI AUTODETECT
 Jumper 2	CHASSIS NETWORK	2.0 16v 103kw RFH (06-..)	Body Computer BSI AUTODETECT
 Jumper 2	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR (06-..)	Body Computer BSI AUTODETECT
 Jumper 2	CHASSIS NETWORK	2.0 HDI 16v 88kw RHG (06-..)	Body Computer BSI AUTODETECT
 Jumper 2	CHASSIS NETWORK	2.0 HDI 16v 88kw RHK (06-..)	Body Computer BSI AUTODETECT
 Jumper 2	CHASSIS NETWORK	2.2 HDI 16v 74kw 4HV (06-..)	Body Computer BSI AUTODETECT
 Jumper 2	CHASSIS NETWORK	2.2 HDI 16v 88kw 4HU (06-..)	Body Computer BSI AUTODETECT
 Jumper 2	CHASSIS NETWORK	2.3 HDI 16v 88kw F1AE0481D (06-..)	Body Computer BSI AUTODETECT
 Jumper 2	CHASSIS NETWORK	2.3 HDI 16v 95kw F1AE0481N (06-..)	Body Computer BSI AUTODETECT
 Jumper 2	CHASSIS NETWORK	3.0 HDI 16v 115kw F1CE0481D (06-..)	Body Computer BSI AUTODETECT
 Jumper 2	CHRONOTACHOGRA	1.6 HDI 16v 66kw 9HU (06-..)	AUTODETECT
 Jumper 2	CHRONOTACHOGRA	2.0 16v 103kw RFH (06-..)	AUTODETECT
 Jumper 2	CHRONOTACHOGRA	2.0 HDI 16v 100kw RHR (06-..)	AUTODETECT
 Jumper 2	CHRONOTACHOGRA	2.0 HDI 16v 88kw RHG (06-..)	AUTODETECT
 Jumper 2	CHRONOTACHOGRA	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 Jumper 2	CHRONOTACHOGRA	2.2 HDI 16v 74kw 4HV (06-..)	AUTODETECT
 Jumper 2	CHRONOTACHOGRA	2.2 HDI 16v 88kw 4HU (06-..)	AUTODETECT
 Jumper 2	CHRONOTACHOGRA	2.3 HDI 16v 88kw F1AE0481D (06-..)	AUTODETECT
 Jumper 2	CHRONOTACHOGRA	2.3 HDI 16v 95kw F1AE0481N (06-..)	AUTODETECT
 Jumper 2	CHRONOTACHOGRA	3.0 HDI 16v 115kw F1CE0481D (06-..)	AUTODETECT
 Jumper 2	CLIMA	1.6 HDI 16v 66kw 9HU (06-..)	CLIMA AUTODETECT
 Jumper 2	CLIMA	2.0 16v 103kw RFH (06-..)	CLIMA AUTODETECT
 Jumper 2	CLIMA	2.0 HDI 16v 100kw RHR (06-..)	CLIMA AUTODETECT
 Jumper 2	CLIMA	2.0 HDI 16v 88kw RHG (06-..)	CLIMA AUTODETECT
 Jumper 2	CLIMA	2.0 HDI 16v 88kw RHK (06-..)	CLIMA AUTODETECT
 Jumper 2	CLIMA	2.2 HDI 16v 74kw 4HV (06-..)	CLIMA AUTODETECT
 Jumper 2	CLIMA	2.2 HDI 16v 88kw 4HU (06-..)	CLIMA AUTODETECT
 Jumper 2	CLIMA	2.3 HDI 16v 88kw F1AE0481D (06-..)	CLIMA AUTODETECT
 Jumper 2	CLIMA	2.3 HDI 16v 95kw F1AE0481N (06-..)	CLIMA AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Jumper 2	CLIMA	3.0 HDI 16v 115kw F1CE0481D (06-..)	CLIMA AUTODETECT
 Jumper 2	DASHBOARD	1.6 HDI 16v 66kw 9HU (06-..)	AUTODETECT
 Jumper 2	DASHBOARD	2.0 16v 103kw RFH (06-..)	AUTODETECT
 Jumper 2	DASHBOARD	2.0 HDI 16v 100kw RHR (06-..)	AUTODETECT
 Jumper 2	DASHBOARD	2.0 HDI 16v 88kw RHG (06-..)	AUTODETECT
 Jumper 2	DASHBOARD	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 Jumper 2	DASHBOARD	2.2 HDI 16v 74kw 4HV (06-..)	AUTODETECT
 Jumper 2	DASHBOARD	2.2 HDI 16v 88kw 4HU (06-..)	AUTODETECT
 Jumper 2	DASHBOARD	2.3 HDI 16v 88kw F1AE0481D (06-..)	AUTODETECT
 Jumper 2	DASHBOARD	2.3 HDI 16v 95kw F1AE0481N (06-..)	AUTODETECT
 Jumper 2	DASHBOARD	3.0 HDI 16v 115kw F1CE0481D (06-..)	AUTODETECT
 Jumper 2	ELECTRIC STEERING	1.6 HDI 16v 66kw 9HU (06-..)	AUTODETECT
 Jumper 2	ELECTRIC STEERING	2.0 16v 103kw RFH (06-..)	AUTODETECT
 Jumper 2	ELECTRIC STEERING	2.0 HDI 16v 100kw RHR (06-..)	AUTODETECT
 Jumper 2	ELECTRIC STEERING	2.0 HDI 16v 88kw RHG (06-..)	AUTODETECT
 Jumper 2	ELECTRIC STEERING	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 Jumper 2	ELECTRIC STEERING	2.2 HDI 16v 74kw 4HV (06-..)	AUTODETECT
 Jumper 2	ELECTRIC STEERING	2.2 HDI 16v 88kw 4HU (06-..)	AUTODETECT
 Jumper 2	ELECTRIC STEERING	2.3 HDI 16v 88kw F1AE0481D (06-..)	AUTODETECT
 Jumper 2	ELECTRIC STEERING	2.3 HDI 16v 95kw F1AE0481N (06-..)	AUTODETECT
 Jumper 2	ELECTRIC STEERING	3.0 HDI 16v 115kw F1CE0481D (06-..)	AUTODETECT
 Jumper 2	ENGINE MANAGEME	1.6 HDI 16v 66kw 9HU (06-..)	EOBD
 Jumper 2	ENGINE MANAGEME	2.0 16v 103kw RFH (06-..)	EOBD
 Jumper 2	ENGINE MANAGEME	2.0 HDI 16v 100kw RHR (06-..)	EOBD
 Jumper 2	ENGINE MANAGEME	2.0 HDI 16v 88kw RHG (06-..)	EOBD
 Jumper 2	ENGINE MANAGEME	2.0 HDI 16v 88kw RHK (06-..)	EOBD
 Jumper 2	ENGINE MANAGEME	2.2 HDI 16v 74kw 4HV (06-..)	VISTEON PUMA AUTODETECT
 Jumper 2	ENGINE MANAGEME	2.2 HDI 16v 88kw 4HU (06-..)	VISTEON PUMA AUTODETECT
 Jumper 2	ENGINE MANAGEME	2.3 HDI 16v 88kw F1AE0481D (06-..)	EOBD
 Jumper 2	ENGINE MANAGEME	2.3 HDI 16v 95kw F1AE0481N (06-..)	EOBD
 Jumper 2	ENGINE MANAGEME	3.0 HDI 16v 115kw F1CE0481D (06-..)	BOSCH EDC16 C39 Common Rail AUTOD
 Jumper 2	MAINTENANCE	1.6 HDI 16v 66kw 9HU (06-..)	AUTODETECT
 Jumper 2	MAINTENANCE	1.6 HDI 16v 66kw 9HU (06-..)	BOSCH ESP AUTODETECT
 Jumper 2	MAINTENANCE	1.6 HDI 16v 66kw 9HU (06-..)	BOSCH ESP AUTODETECT
 Jumper 2	MAINTENANCE	2.0 16v 103kw RFH (06-..)	AUTODETECT
 Jumper 2	MAINTENANCE	2.0 16v 103kw RFH (06-..)	BOSCH ESP AUTODETECT
 Jumper 2	MAINTENANCE	2.0 16v 103kw RFH (06-..)	BOSCH ESP AUTODETECT
 Jumper 2	MAINTENANCE	2.0 HDI 16v 100kw RHR (06-..)	AUTODETECT
 Jumper 2	MAINTENANCE	2.0 HDI 16v 100kw RHR (06-..)	BOSCH ESP AUTODETECT
 Jumper 2	MAINTENANCE	2.0 HDI 16v 100kw RHR (06-..)	BOSCH ESP AUTODETECT
 Jumper 2	MAINTENANCE	2.0 HDI 16v 88kw RHG (06-..)	AUTODETECT
 Jumper 2	MAINTENANCE	2.0 HDI 16v 88kw RHG (06-..)	BOSCH ESP AUTODETECT
 Jumper 2	MAINTENANCE	2.0 HDI 16v 88kw RHG (06-..)	BOSCH ESP AUTODETECT
 Jumper 2	MAINTENANCE	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 Jumper 2	MAINTENANCE	2.0 HDI 16v 88kw RHK (06-..)	BOSCH ESP AUTODETECT
 Jumper 2	MAINTENANCE	2.0 HDI 16v 88kw RHK (06-..)	BOSCH ESP AUTODETECT
 Jumper 2	MAINTENANCE	2.2 HDI 16v 74kw 4HV (06-..)	AUTODETECT
 Jumper 2	MAINTENANCE	2.2 HDI 16v 74kw 4HV (06-..)	ESP AUTODETECT
 Jumper 2	MAINTENANCE	2.2 HDI 16v 74kw 4HV (06-..)	ESP AUTODETECT
 Jumper 2	MAINTENANCE	2.2 HDI 16v 74kw 4HV (06-..)	VISTEON PUMA AUTODETECT
 Jumper 2	MAINTENANCE	2.2 HDI 16v 88kw 4HU (06-..)	AUTODETECT
 Jumper 2	MAINTENANCE	2.2 HDI 16v 88kw 4HU (06-..)	BOSCH ESP AUTODETECT
 Jumper 2	MAINTENANCE	2.2 HDI 16v 88kw 4HU (06-..)	BOSCH ESP AUTODETECT
 Jumper 2	MAINTENANCE	2.2 HDI 16v 88kw 4HU (06-..)	VISTEON PUMA AUTODETECT
 Jumper 2	MAINTENANCE	2.3 HDI 16v 88kw F1AE0481D (06-..)	AUTODETECT
 Jumper 2	MAINTENANCE	2.3 HDI 16v 88kw F1AE0481D (06-..)	BOSCH ESP AUTODETECT
 Jumper 2	MAINTENANCE	2.3 HDI 16v 88kw F1AE0481D (06-..)	BOSCH ESP AUTODETECT
 Jumper 2	MAINTENANCE	2.3 HDI 16v 88kw F1AE0481D (06-..)	BOSCH ESP AUTODETECT
 Jumper 2	MAINTENANCE	2.3 HDI 16v 95kw F1AE0481N (06-..)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Jumper 2	MAINTENANCE	2.3 HDI 16v 95kw F1AE0481N (06-..)	BOSCH ESP AUTODETECT
 Jumper 2	MAINTENANCE	2.3 HDI 16v 95kw F1AE0481N (06-..)	BOSCH ESP AUTODETECT
 Jumper 2	MAINTENANCE	3.0 HDI 16v 115kw F1CE0481D (06-..)	AUTODETECT
 Jumper 2	MAINTENANCE	3.0 HDI 16v 115kw F1CE0481D (06-..)	BOSCH EDC16 C39 Common Rail AUTOD
 Jumper 2	MAINTENANCE	3.0 HDI 16v 115kw F1CE0481D (06-..)	BOSCH ESP AUTODETECT
 Jumper 2	MAINTENANCE	3.0 HDI 16v 115kw F1CE0481D (06-..)	BOSCH ESP AUTODETECT
 Jumper 2	NAVIGATION	1.6 HDI 16v 66kw 9HU (06-..)	AUTODETECT
 Jumper 2	NAVIGATION	2.0 16v 103kw RFH (06-..)	AUTODETECT
 Jumper 2	NAVIGATION	2.0 HDI 16v 100kw RHR (06-..)	AUTODETECT
 Jumper 2	NAVIGATION	2.0 HDI 16v 88kw RHG (06-..)	AUTODETECT
 Jumper 2	NAVIGATION	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 Jumper 2	NAVIGATION	2.2 HDI 16v 74kw 4HV (06-..)	AUTODETECT
 Jumper 2	NAVIGATION	2.2 HDI 16v 88kw 4HU (06-..)	AUTODETECT
 Jumper 2	NAVIGATION	2.3 HDI 16v 88kw F1AE0481D (06-..)	AUTODETECT
 Jumper 2	NAVIGATION	2.3 HDI 16v 95kw F1AE0481N (06-..)	AUTODETECT
 Jumper 2	NAVIGATION	3.0 HDI 16v 115kw F1CE0481D (06-..)	AUTODETECT
 Jumper 2	PARKING HELP	1.6 HDI 16v 66kw 9HU (06-..)	AUTODETECT
 Jumper 2	PARKING HELP	2.0 16v 103kw RFH (06-..)	AUTODETECT
 Jumper 2	PARKING HELP	2.0 HDI 16v 100kw RHR (06-..)	AUTODETECT
 Jumper 2	PARKING HELP	2.0 HDI 16v 88kw RHG (06-..)	AUTODETECT
 Jumper 2	PARKING HELP	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 Jumper 2	PARKING HELP	2.2 HDI 16v 74kw 4HV (06-..)	AUTODETECT
 Jumper 2	PARKING HELP	2.2 HDI 16v 88kw 4HU (06-..)	AUTODETECT
 Jumper 2	PARKING HELP	2.3 HDI 16v 88kw F1AE0481D (06-..)	AUTODETECT
 Jumper 2	PARKING HELP	2.3 HDI 16v 95kw F1AE0481N (06-..)	AUTODETECT
 Jumper 2	PARKING HELP	3.0 HDI 16v 115kw F1CE0481D (06-..)	AUTODETECT
 Jumper 2	SUSPENSION CONTR	1.6 HDI 16v 66kw 9HU (06-..)	AUTODETECT
 Jumper 2	SUSPENSION CONTR	2.0 16v 103kw RFH (06-..)	AUTODETECT
 Jumper 2	SUSPENSION CONTR	2.0 HDI 16v 100kw RHR (06-..)	AUTODETECT
 Jumper 2	SUSPENSION CONTR	2.0 HDI 16v 88kw RHG (06-..)	AUTODETECT
 Jumper 2	SUSPENSION CONTR	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 Jumper 2	SUSPENSION CONTR	2.2 HDI 16v 74kw 4HV (06-..)	AUTODETECT
 Jumper 2	SUSPENSION CONTR	2.2 HDI 16v 88kw 4HU (06-..)	AUTODETECT
 Jumper 2	SUSPENSION CONTR	2.3 HDI 16v 88kw F1AE0481D (06-..)	AUTODETECT
 Jumper 2	SUSPENSION CONTR	2.3 HDI 16v 95kw F1AE0481N (06-..)	AUTODETECT
 Jumper 2	SUSPENSION CONTR	3.0 HDI 16v 115kw F1CE0481D (06-..)	AUTODETECT
 Jumpy 1	ABS	1.6 8v 58kw 220A2 (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	ABS	1.9 D 8v 52kw D9B (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	ABS	1.9 D 8v 52kw WJY (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	ABS	1.9 D 8v 52kw WJZ (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	ABS	1.9 TD 8v 66kw D8B (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	ABS	1.9 TD 8v 66kw DHX (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	ABS	2.0 8v 89kw RFU (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	ABS	2.0 16v 100kw RFN (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	ABS	2.0 HDI 16v 80kw RHW (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	ABS	2.0 HDI 8v 70kw RHX (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	ABS	2.0 HDI 8v 81kw RHZ (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	ABS	2.0T 8v 108kw RGX (01-03)	EOBD
 Jumpy 1	ABS	2.0T 8v 108kw RGX (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	ABS	2.1 TD 12v 81kw P8C (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	AIRBAG	1.6 8v 58kw 220A2 (95-03)	AUTOLIV AirBag CENTRAL ACU AUTODE
 Jumpy 1	AIRBAG	1.9 D 8v 52kw D9B (95-03)	AUTOLIV AirBag CENTRAL ACU AUTODE
 Jumpy 1	AIRBAG	1.9 D 8v 52kw WJY (04-06)	AirBag CENTRAL AUTODETECT
 Jumpy 1	AIRBAG	1.9 D 8v 52kw WJY (95-03)	AUTOLIV AirBag CENTRAL ACU AUTODE
 Jumpy 1	AIRBAG	1.9 D 8v 52kw WJZ (95-03)	AUTOLIV AirBag CENTRAL ACU AUTODE
 Jumpy 1	AIRBAG	1.9 TD 8v 66kw D8B (95-03)	AUTOLIV AirBag CENTRAL ACU AUTODE
 Jumpy 1	AIRBAG	1.9 TD 8v 66kw DHX (95-03)	AUTOLIV AirBag CENTRAL ACU AUTODE
 Jumpy 1	AIRBAG	2.0 8v 89kw RFU (95-03)	AUTOLIV AirBag CENTRAL ACU AUTODE

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Jumpy 1	AIRBAG	2.0 16v 100kw RFN (04-06)	AirBag CENTRAL AUTODETECT
 Jumpy 1	AIRBAG	2.0 16v 100kw RFN (95-03)	AUTOLIV AirBag CENTRAL ACU AUTODE
 Jumpy 1	AIRBAG	2.0 HDI 16v 80kw RHW (04-06)	AirBag CENTRAL AUTODETECT
 Jumpy 1	AIRBAG	2.0 HDI 16v 80kw RHW (95-03)	AUTOLIV Airbag CENTRAL ACU AUTODE
 Jumpy 1	AIRBAG	2.0 HDI 8v 70kw RHX (04-06)	AirBag CENTRAL AUTODETECT
 Jumpy 1	AIRBAG	2.0 HDI 8v 70kw RHX (95-03)	AUTOLIV AirBag CENTRAL ACU AUTODE
 Jumpy 1	AIRBAG	2.0 HDI 8v 81kw RHZ (04-06)	AirBag CENTRAL AUTODETECT
 Jumpy 1	AIRBAG	2.0 HDI 8v 81kw RHZ (95-03)	AUTOLIV AirBag CENTRAL ACU AUTODE
 Jumpy 1	AIRBAG	2.0T 8v 108kw RGX (95-03)	AUTOLIV AirBag CENTRAL ACU AUTODE
 Jumpy 1	AIRBAG	2.1 TD 12v 81kw P8C (95-03)	AUTOLIV AirBag CENTRAL ACU AUTODE
 Jumpy 1	AUTOM. TRANSMISSI	1.6 8v 58kw 220A2 (95-03)	A/T AL4 AUTODETECT
 Jumpy 1	AUTOM. TRANSMISSI	1.9 D 8v 52kw D9B (95-03)	A/T AL4 AUTODETECT
 Jumpy 1	AUTOM. TRANSMISSI	1.9 D 8v 52kw WJY (04-06)	A/T AL4 AUTODETECT
 Jumpy 1	AUTOM. TRANSMISSI	1.9 D 8v 52kw WJY (95-03)	A/T AL4 AUTODETECT
 Jumpy 1	AUTOM. TRANSMISSI	1.9 D 8v 52kw WJZ (95-03)	A/T AL4 AUTODETECT
 Jumpy 1	AUTOM. TRANSMISSI	1.9 TD 8v 66kw D8B (95-03)	A/T AL4 AUTODETECT
 Jumpy 1	AUTOM. TRANSMISSI	1.9 TD 8v 66kw DHX (95-03)	A/T AL4 AUTODETECT
 Jumpy 1	AUTOM. TRANSMISSI	2.0 8v 89kw RFU (95-03)	A/T AL4 AUTODETECT
 Jumpy 1	AUTOM. TRANSMISSI	2.0 16v 100kw RFN (04-06)	A/T AL4 AUTODETECT
 Jumpy 1	AUTOM. TRANSMISSI	2.0 16v 100kw RFN (95-03)	A/T AL4 AUTODETECT
 Jumpy 1	AUTOM. TRANSMISSI	2.0 HDI 16v 80kw RHW (04-06)	A/T AL4 AUTODETECT
 Jumpy 1	AUTOM. TRANSMISSI	2.0 HDI 16v 80kw RHW (95-03)	A/T AL4 AUTODETECT
 Jumpy 1	AUTOM. TRANSMISSI	2.0 HDI 8v 70kw RHX (04-06)	A/T AL4 AUTODETECT
 Jumpy 1	AUTOM. TRANSMISSI	2.0 HDI 8v 70kw RHX (95-03)	A/T AL4 AUTODETECT
 Jumpy 1	AUTOM. TRANSMISSI	2.0 HDI 8v 81kw RHZ (04-06)	A/T AL4 AUTODETECT
 Jumpy 1	AUTOM. TRANSMISSI	2.0 HDI 8v 81kw RHZ (95-03)	A/T AL4 AUTODETECT
 Jumpy 1	AUTOM. TRANSMISSI	2.0T 8v 108kw RGX (95-03)	A/T AL4 AUTODETECT
 Jumpy 1	AUTOM. TRANSMISSI	2.1 TD 12v 81kw P8C (95-03)	A/T AL4 AUTODETECT
 Jumpy 1	DIESEL MANAGEMEN	1.9 D 8v 52kw WJY (04-06)	LUCAS DCN2 AUTODETECT
 Jumpy 1	DIESEL MANAGEMEN	1.9 D 8v 52kw WJY (04-06)	LUCAS Diesel DCN2
 Jumpy 1	DIESEL MANAGEMEN	1.9 D 8v 52kw WJY (95-03)	LUCAS DCN2 AUTODETECT
 Jumpy 1	DIESEL MANAGEMEN	1.9 D 8v 52kw WJY (95-03)	LUCAS Diesel DCN2
 Jumpy 1	DIESEL MANAGEMEN	1.9 TD 8v 66kw DHX (95-03)	BOSCH AS3 VP20
 Jumpy 1	ENGINE MANAGEME	1.6 8v 58kw 220A2 (01-03)	EOBD
 Jumpy 1	ENGINE MANAGEME	2.0 8v 89kw RFU (01-03)	EOBD
 Jumpy 1	ENGINE MANAGEME	2.0 16v 100kw RFN (04-06)	Marelli MM48P AUTODETECT
 Jumpy 1	ENGINE MANAGEME	2.0 16v 100kw RFN (95-03)	Marelli MM48P AUTODETECT
 Jumpy 1	ENGINE MANAGEME	2.0 HDI 16v 80kw RHW (04-06)	BOSCH EDC15 C2 Common Rail AUTODE
 Jumpy 1	ENGINE MANAGEME	2.0 HDI 16v 80kw RHW (95-03)	BOSCH EDC15 C2 Common Rail AUTODE
 Jumpy 1	ENGINE MANAGEME	2.0 HDI 8v 70kw RHX (04-06)	BOSCH EDC15 C2 Common Rail AUTODE
 Jumpy 1	ENGINE MANAGEME	2.0 HDI 8v 70kw RHX (95-03)	BOSCH EDC15 C2 Common Rail AUTODE
 Jumpy 1	ENGINE MANAGEME	2.0 HDI 8v 81kw RHZ (04-06)	BOSCH EDC15 C2 Common Rail AUTODE
 Jumpy 1	ENGINE MANAGEME	2.0 HDI 8v 81kw RHZ (95-03)	BOSCH EDC 15 C2 Common Rail
 Jumpy 1	ENGINE MANAGEME	2.0 HDI 8v 81kw RHZ (95-03)	BOSCH EDC15 C2 Common Rail AUTODE
 Jumpy 1	MAINTENANCE	1.6 8v 58kw 220A2 (95-03)	A/T AL4 AUTODETECT
 Jumpy 1	MAINTENANCE	1.6 8v 58kw 220A2 (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	1.6 8v 58kw 220A2 (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	1.6 8v 58kw 220A2 (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	1.6 8v 58kw 220A2 (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	1.9 D 8v 52kw D9B (95-03)	A/T AL4 AUTODETECT
 Jumpy 1	MAINTENANCE	1.9 D 8v 52kw D9B (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	1.9 D 8v 52kw D9B (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	1.9 D 8v 52kw D9B (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	1.9 D 8v 52kw D9B (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	1.9 D 8v 52kw WJY (04-06)	A/T AL4 AUTODETECT
 Jumpy 1	MAINTENANCE	1.9 D 8v 52kw WJY (04-06)	AirBag CENTRAL AUTODETECT
 Jumpy 1	MAINTENANCE	1.9 D 8v 52kw WJY (04-06)	AirBag CENTRAL AUTODETECT
 Jumpy 1	MAINTENANCE	1.9 D 8v 52kw WJY (95-03)	A/T AL4 AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Jumpy 1	MAINTENANCE	1.9 D 8v 52kw WJY (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	1.9 D 8v 52kw WJY (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	1.9 D 8v 52kw WJY (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	1.9 D 8v 52kw WJY (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	1.9 D 8v 52kw WJZ (95-03)	A/T AL4 AUTODETECT
 Jumpy 1	MAINTENANCE	1.9 D 8v 52kw WJZ (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	1.9 D 8v 52kw WJZ (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	1.9 D 8v 52kw WJZ (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	1.9 D 8v 52kw WJZ (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	1.9 TD 8v 66kw D8B (95-03)	A/T AL4 AUTODETECT
 Jumpy 1	MAINTENANCE	1.9 TD 8v 66kw D8B (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	1.9 TD 8v 66kw D8B (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	1.9 TD 8v 66kw D8B (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	1.9 TD 8v 66kw D8B (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	1.9 TD 8v 66kw DHX (95-03)	A/T AL4 AUTODETECT
 Jumpy 1	MAINTENANCE	1.9 TD 8v 66kw DHX (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	1.9 TD 8v 66kw DHX (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	1.9 TD 8v 66kw DHX (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	1.9 TD 8v 66kw DHX (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	2.0 8v 89kw RFU (95-03)	A/T AL4 AUTODETECT
 Jumpy 1	MAINTENANCE	2.0 8v 89kw RFU (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	2.0 8v 89kw RFU (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	2.0 8v 89kw RFU (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	2.0 8v 89kw RFU (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	2.0 16v 100kw RFN (04-06)	A/T AL4 AUTODETECT
 Jumpy 1	MAINTENANCE	2.0 16v 100kw RFN (04-06)	AirBag CENTRAL AUTODETECT
 Jumpy 1	MAINTENANCE	2.0 16v 100kw RFN (04-06)	AirBag CENTRAL AUTODETECT
 Jumpy 1	MAINTENANCE	2.0 16v 100kw RFN (95-03)	A/T AL4 AUTODETECT
 Jumpy 1	MAINTENANCE	2.0 16v 100kw RFN (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	2.0 16v 100kw RFN (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	2.0 16v 100kw RFN (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	2.0 16v 100kw RFN (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	2.0 HDI 16v 80kw RHW (04-06)	A/T AL4 AUTODETECT
 Jumpy 1	MAINTENANCE	2.0 HDI 16v 80kw RHW (04-06)	AirBag CENTRAL AUTODETECT
 Jumpy 1	MAINTENANCE	2.0 HDI 16v 80kw RHW (04-06)	AirBag CENTRAL AUTODETECT
 Jumpy 1	MAINTENANCE	2.0 HDI 16v 80kw RHW (04-06)	BOSCH EDC15 C2 Common Rail AUTODE
 Jumpy 1	MAINTENANCE	2.0 HDI 16v 80kw RHW (95-03)	A/T AL4 AUTODETECT
 Jumpy 1	MAINTENANCE	2.0 HDI 16v 80kw RHW (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	2.0 HDI 16v 80kw RHW (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	2.0 HDI 16v 80kw RHW (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	2.0 HDI 16v 80kw RHW (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	2.0 HDI 16v 80kw RHW (95-03)	BOSCH EDC15 C2 Common Rail AUTODE
 Jumpy 1	MAINTENANCE	2.0 HDI 8v 70kw RHX (04-06)	A/T AL4 AUTODETECT
 Jumpy 1	MAINTENANCE	2.0 HDI 8v 70kw RHX (04-06)	AirBag CENTRAL AUTODETECT
 Jumpy 1	MAINTENANCE	2.0 HDI 8v 70kw RHX (04-06)	AirBag CENTRAL AUTODETECT
 Jumpy 1	MAINTENANCE	2.0 HDI 8v 70kw RHX (04-06)	BOSCH EDC15 C2 Common Rail AUTODE
 Jumpy 1	MAINTENANCE	2.0 HDI 8v 70kw RHX (95-03)	A/T AL4 AUTODETECT
 Jumpy 1	MAINTENANCE	2.0 HDI 8v 70kw RHX (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	2.0 HDI 8v 70kw RHX (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	2.0 HDI 8v 70kw RHX (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	2.0 HDI 8v 70kw RHX (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	2.0 HDI 8v 70kw RHX (95-03)	BOSCH EDC15 C2 Common Rail AUTODE
 Jumpy 1	MAINTENANCE	2.0 HDI 8v 81kw RHZ (04-06)	A/T AL4 AUTODETECT
 Jumpy 1	MAINTENANCE	2.0 HDI 8v 81kw RHZ (04-06)	AirBag CENTRAL AUTODETECT
 Jumpy 1	MAINTENANCE	2.0 HDI 8v 81kw RHZ (04-06)	AirBag CENTRAL AUTODETECT
 Jumpy 1	MAINTENANCE	2.0 HDI 8v 81kw RHZ (04-06)	BOSCH EDC15 C2 Common Rail AUTODE
 Jumpy 1	MAINTENANCE	2.0 HDI 8v 81kw RHZ (95-03)	A/T AL4 AUTODETECT
 Jumpy 1	MAINTENANCE	2.0 HDI 8v 81kw RHZ (95-03)	BOSCH ABS ABR 5.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Jumpy 1	MAINTENANCE	2.0 HDI 8v 81kw RHZ (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	2.0 HDI 8v 81kw RHZ (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	2.0 HDI 8v 81kw RHZ (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	2.0 HDI 8v 81kw RHZ (95-03)	BOSCH EDC15 C2 Common Rail AUTODE
 Jumpy 1	MAINTENANCE	2.0T 8v 108kw RGX (95-03)	A/T AL4 AUTODETECT
 Jumpy 1	MAINTENANCE	2.0T 8v 108kw RGX (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	2.0T 8v 108kw RGX (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	2.0T 8v 108kw RGX (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	2.0T 8v 108kw RGX (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	2.1 TD 12v 81kw P8C (95-03)	A/T AL4 AUTODETECT
 Jumpy 1	MAINTENANCE	2.1 TD 12v 81kw P8C (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	2.1 TD 12v 81kw P8C (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	2.1 TD 12v 81kw P8C (95-03)	BOSCH ABS ABR 5.3
 Jumpy 1	MAINTENANCE	2.1 TD 12v 81kw P8C (95-03)	BOSCH ABS ABR 5.3
 Jumpy 2	ABS	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH ABS 8
 Jumpy 2	ABS	2.0 16v 103kw RFH (07-..)	BOSCH ABS 8
 Jumpy 2	ABS	2.0 HDI 16v 100kw RHR-FAP (07-..)	BOSCH ABS 8
 Jumpy 2	ABS	2.0 HDI 16v 88kw RHG (07-..)	BOSCH ABS 8
 Jumpy 2	ABS	2.0 HDI 16v 88kw RHK (07-..)	BOSCH ABS 8
 Jumpy 2	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH ABS 8.0 AUTODETECT
 Jumpy 2	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH ABS 8.1 AUTODETECT
 Jumpy 2	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH ESP 8.0 AUTODETECT
 Jumpy 2	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH ESP 8.1 AUTODETECT
 Jumpy 2	ABS + TRACT. CONT	2.0 16v 103kw RFH (07-..)	BOSCH ABS 8.0 AUTODETECT
 Jumpy 2	ABS + TRACT. CONT	2.0 16v 103kw RFH (07-..)	BOSCH ABS 8.1 AUTODETECT
 Jumpy 2	ABS + TRACT. CONT	2.0 16v 103kw RFH (07-..)	BOSCH ESP 8.0 AUTODETECT
 Jumpy 2	ABS + TRACT. CONT	2.0 16v 103kw RFH (07-..)	BOSCH ESP 8.1 AUTODETECT
 Jumpy 2	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP (07-..)	BOSCH ABS 8.0 AUTODETECT
 Jumpy 2	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP (07-..)	BOSCH ABS 8.1 AUTODETECT
 Jumpy 2	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP (07-..)	BOSCH ESP 8.0 AUTODETECT
 Jumpy 2	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP (07-..)	BOSCH ESP 8.1 AUTODETECT
 Jumpy 2	ABS + TRACT. CONT	2.0 HDI 16v 88kw RHG (07-..)	BOSCH ABS 8.0 AUTODETECT
 Jumpy 2	ABS + TRACT. CONT	2.0 HDI 16v 88kw RHG (07-..)	BOSCH ABS 8.1 AUTODETECT
 Jumpy 2	ABS + TRACT. CONT	2.0 HDI 16v 88kw RHG (07-..)	BOSCH ESP 8.0 AUTODETECT
 Jumpy 2	ABS + TRACT. CONT	2.0 HDI 16v 88kw RHG (07-..)	BOSCH ESP 8.1 AUTODETECT
 Jumpy 2	ABS + TRACT. CONT	2.0 HDI 16v 88kw RHK (07-..)	BOSCH ABS 8.0 AUTODETECT
 Jumpy 2	ABS + TRACT. CONT	2.0 HDI 16v 88kw RHK (07-..)	BOSCH ABS 8.1 AUTODETECT
 Jumpy 2	ABS + TRACT. CONT	2.0 HDI 16v 88kw RHK (07-..)	BOSCH ESP 8.0 AUTODETECT
 Jumpy 2	ABS + TRACT. CONT	2.0 HDI 16v 88kw RHK (07-..)	BOSCH ESP 8.1 AUTODETECT
 Jumpy 2	AIRBAG	1.6 HDI 16v 66kw 9HU (07-..)	AirBag CENTRAL AUTODETECT
 Jumpy 2	AIRBAG	1.6 HDI 16v 66kw 9HU (07-..)	Temic SRS
 Jumpy 2	AIRBAG	2.0 16v 103kw RFH (07-..)	AirBag CENTRAL AUTODETECT
 Jumpy 2	AIRBAG	2.0 16v 103kw RFH (07-..)	Temic SRS
 Jumpy 2	AIRBAG	2.0 HDI 16v 100kw RHR-FAP (07-..)	AirBag CENTRAL AUTODETECT
 Jumpy 2	AIRBAG	2.0 HDI 16v 100kw RHR-FAP (07-..)	Temic SRS
 Jumpy 2	AIRBAG	2.0 HDI 16v 88kw RHG (07-..)	AirBag CENTRAL AUTODETECT
 Jumpy 2	AIRBAG	2.0 HDI 16v 88kw RHG (07-..)	Temic SRS
 Jumpy 2	AIRBAG	2.0 HDI 16v 88kw RHK (07-..)	AirBag CENTRAL AUTODETECT
 Jumpy 2	AIRBAG	2.0 HDI 16v 88kw RHK (07-..)	Temic SRS
 Jumpy 2	ANTITHEFT	1.6 HDI 16v 66kw 9HU (07-..)	Alarm PSA2 AUTODETECT
 Jumpy 2	ANTITHEFT	2.0 16v 103kw RFH (07-..)	Alarm PSA2 AUTODETECT
 Jumpy 2	ANTITHEFT	2.0 HDI 16v 100kw RHR-FAP (07-..)	Alarm PSA2 AUTODETECT
 Jumpy 2	ANTITHEFT	2.0 HDI 16v 88kw RHG (07-..)	Alarm PSA2 AUTODETECT
 Jumpy 2	ANTITHEFT	2.0 HDI 16v 88kw RHK (07-..)	Alarm PSA2 AUTODETECT
 Jumpy 2	AUX. HEATING	1.6 HDI 16v 66kw 9HU (07-..)	AUTODETECT
 Jumpy 2	AUX. HEATING	2.0 16v 103kw RFH (07-..)	AUTODETECT
 Jumpy 2	AUX. HEATING	2.0 HDI 16v 100kw RHR-FAP (07-..)	AUTODETECT
 Jumpy 2	AUX. HEATING	2.0 HDI 16v 88kw RHG (07-..)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Jumpy 2	AUX. HEATING	2.0 HDI 16v 88kw RHK (07-..)	AUTODETECT
 Jumpy 2	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HU (07-..)	Body Computer BSI AUTODETECT
 Jumpy 2	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HU (07-..)	Body Computer BSM AUTODETECT
 Jumpy 2	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HU (07-..)	Body Computer BSR AUTODETECT
 Jumpy 2	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HU (07-..)	Body Computer Chassis AUTODETECT
 Jumpy 2	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HU (07-..)	Valeo 2 1/2
 Jumpy 2	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HU (07-..)	Valeo 2 2/2
 Jumpy 2	CHASSIS NETWORK	2.0 16v 103kw RFH (07-..)	Body Computer BSI AUTODETECT
 Jumpy 2	CHASSIS NETWORK	2.0 16v 103kw RFH (07-..)	Body Computer BSM AUTODETECT
 Jumpy 2	CHASSIS NETWORK	2.0 16v 103kw RFH (07-..)	Body Computer BSR AUTODETECT
 Jumpy 2	CHASSIS NETWORK	2.0 16v 103kw RFH (07-..)	Body Computer Chassis AUTODETECT
 Jumpy 2	CHASSIS NETWORK	2.0 16v 103kw RFH (07-..)	Valeo 2 1/2
 Jumpy 2	CHASSIS NETWORK	2.0 16v 103kw RFH (07-..)	Valeo 2 2/2
 Jumpy 2	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP (07-..)	Body Computer BSI AUTODETECT
 Jumpy 2	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP (07-..)	Body Computer BSM AUTODETECT
 Jumpy 2	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP (07-..)	Body Computer BSR AUTODETECT
 Jumpy 2	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP (07-..)	Body Computer Chassis AUTODETECT
 Jumpy 2	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP (07-..)	Valeo 2 1/2
 Jumpy 2	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP (07-..)	Valeo 2 2/2
 Jumpy 2	CHASSIS NETWORK	2.0 HDI 16v 88kw RHG (07-..)	Body Computer BSI AUTODETECT
 Jumpy 2	CHASSIS NETWORK	2.0 HDI 16v 88kw RHG (07-..)	Body Computer BSM AUTODETECT
 Jumpy 2	CHASSIS NETWORK	2.0 HDI 16v 88kw RHG (07-..)	Body Computer BSR AUTODETECT
 Jumpy 2	CHASSIS NETWORK	2.0 HDI 16v 88kw RHG (07-..)	Body Computer Chassis AUTODETECT
 Jumpy 2	CHASSIS NETWORK	2.0 HDI 16v 88kw RHG (07-..)	Valeo 2 1/2
 Jumpy 2	CHASSIS NETWORK	2.0 HDI 16v 88kw RHG (07-..)	Valeo 2 2/2
 Jumpy 2	CHASSIS NETWORK	2.0 HDI 16v 88kw RHK (07-..)	Body Computer BSI AUTODETECT
 Jumpy 2	CHASSIS NETWORK	2.0 HDI 16v 88kw RHK (07-..)	Body Computer BSM AUTODETECT
 Jumpy 2	CHASSIS NETWORK	2.0 HDI 16v 88kw RHK (07-..)	Body Computer BSR AUTODETECT
 Jumpy 2	CHASSIS NETWORK	2.0 HDI 16v 88kw RHK (07-..)	Body Computer Chassis AUTODETECT
 Jumpy 2	CHASSIS NETWORK	2.0 HDI 16v 88kw RHK (07-..)	Valeo 2 1/2
 Jumpy 2	CHASSIS NETWORK	2.0 HDI 16v 88kw RHK (07-..)	Valeo 2 2/2
 Jumpy 2	CLIMA	1.6 HDI 16v 66kw 9HU (07-..)	CLIMA AUTODETECT
 Jumpy 2	CLIMA	2.0 16v 103kw RFH (07-..)	CLIMA AUTODETECT
 Jumpy 2	CLIMA	2.0 HDI 16v 100kw RHR-FAP (07-..)	CLIMA AUTODETECT
 Jumpy 2	CLIMA	2.0 HDI 16v 88kw RHG (07-..)	CLIMA AUTODETECT
 Jumpy 2	CLIMA	2.0 HDI 16v 88kw RHK (07-..)	CLIMA AUTODETECT
 Jumpy 2	DASHBOARD	1.6 HDI 16v 66kw 9HU (07-..)	AUTODETECT
 Jumpy 2	DASHBOARD	1.6 HDI 16v 66kw 9HU (07-..)	Marelli Dashboard PSA
 Jumpy 2	DASHBOARD	2.0 16v 103kw RFH (07-..)	AUTODETECT
 Jumpy 2	DASHBOARD	2.0 16v 103kw RFH (07-..)	Marelli Dashboard PSA
 Jumpy 2	DASHBOARD	2.0 HDI 16v 100kw RHR-FAP (07-..)	AUTODETECT
 Jumpy 2	DASHBOARD	2.0 HDI 16v 100kw RHR-FAP (07-..)	Marelli Dashboard PSA
 Jumpy 2	DASHBOARD	2.0 HDI 16v 88kw RHG (07-..)	AUTODETECT
 Jumpy 2	DASHBOARD	2.0 HDI 16v 88kw RHG (07-..)	Marelli Dashboard PSA
 Jumpy 2	DASHBOARD	2.0 HDI 16v 88kw RHK (07-..)	AUTODETECT
 Jumpy 2	DASHBOARD	2.0 HDI 16v 88kw RHK (07-..)	Marelli Dashboard PSA
 Jumpy 2	ELECTRIC STEERING	1.6 HDI 16v 66kw 9HU (07-..)	AUTODETECT
 Jumpy 2	ELECTRIC STEERING	2.0 16v 103kw RFH (07-..)	AUTODETECT
 Jumpy 2	ELECTRIC STEERING	2.0 HDI 16v 100kw RHR-FAP (07-..)	AUTODETECT
 Jumpy 2	ELECTRIC STEERING	2.0 HDI 16v 88kw RHG (07-..)	AUTODETECT
 Jumpy 2	ELECTRIC STEERING	2.0 HDI 16v 88kw RHK (07-..)	AUTODETECT
 Jumpy 2	ENGINE MANAGEME	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH EDC16 C34 Common Rail AUTOD
 Jumpy 2	ENGINE MANAGEME	2.0 16v 103kw RFH (07-..)	Marelli MM6KP AUTODETECT
 Jumpy 2	ENGINE MANAGEME	2.0 HDI 16v 100kw RHR-FAP (07-..)	SIEMENS SID 803A Common Rail AUTOD
 Jumpy 2	ENGINE MANAGEME	2.0 HDI 16v 88kw RHG (07-..)	SIEMENS SID 803A Common Rail AUTOD
 Jumpy 2	ENGINE MANAGEME	2.0 HDI 16v 88kw RHK (07-..)	SIEMENS SID 803A Common Rail AUTOD
 Jumpy 2	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	AirBag CENTRAL AUTODETECT
 Jumpy 2	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	AirBag CENTRAL AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Jumpy 2	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH ABS 8.0 AUTODETECT
 Jumpy 2	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH ABS 8.0 AUTODETECT
 Jumpy 2	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH EDC16 C34 Common Rail AUTOD
 Jumpy 2	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH EDC16 C34 Common Rail AUTOD
 Jumpy 2	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH EDC16 C34 Common Rail AUTOD
 Jumpy 2	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH EDC16 C34 Common Rail AUTOD
 Jumpy 2	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH EDC16 C34 Common Rail AUTOD
 Jumpy 2	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH EDC16 C34 Common Rail AUTOD
 Jumpy 2	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH ESP 8.0 AUTODETECT
 Jumpy 2	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH ESP 8.0 AUTODETECT
 Jumpy 2	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH ESP 8.1 AUTODETECT
 Jumpy 2	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH ESP 8.1 AUTODETECT
 Jumpy 2	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	MANUAL
 Jumpy 2	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	Marelli Dashboard PSA
 Jumpy 2	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	Valeo 2 1/2
 Jumpy 2	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	Valeo 2 1/2
 Jumpy 2	MAINTENANCE	2.0 16v 103kw RFH (07-..)	AirBag CENTRAL AUTODETECT
 Jumpy 2	MAINTENANCE	2.0 16v 103kw RFH (07-..)	AirBag CENTRAL AUTODETECT
 Jumpy 2	MAINTENANCE	2.0 16v 103kw RFH (07-..)	BOSCH ABS 8.0 AUTODETECT
 Jumpy 2	MAINTENANCE	2.0 16v 103kw RFH (07-..)	BOSCH ABS 8.0 AUTODETECT
 Jumpy 2	MAINTENANCE	2.0 16v 103kw RFH (07-..)	BOSCH ESP 8.0 AUTODETECT
 Jumpy 2	MAINTENANCE	2.0 16v 103kw RFH (07-..)	BOSCH ESP 8.0 AUTODETECT
 Jumpy 2	MAINTENANCE	2.0 16v 103kw RFH (07-..)	BOSCH ESP 8.1 AUTODETECT
 Jumpy 2	MAINTENANCE	2.0 16v 103kw RFH (07-..)	BOSCH ESP 8.1 AUTODETECT
 Jumpy 2	MAINTENANCE	2.0 16v 103kw RFH (07-..)	MANUAL
 Jumpy 2	MAINTENANCE	2.0 16v 103kw RFH (07-..)	Marelli Dashboard PSA
 Jumpy 2	MAINTENANCE	2.0 16v 103kw RFH (07-..)	Valeo 2 1/2
 Jumpy 2	MAINTENANCE	2.0 16v 103kw RFH (07-..)	Valeo 2 1/2
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	AirBag CENTRAL AUTODETECT
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	AirBag CENTRAL AUTODETECT
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	BOSCH ABS 8.0 AUTODETECT
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	BOSCH ABS 8.0 AUTODETECT
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	BOSCH ESP 8.0 AUTODETECT
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	BOSCH ESP 8.0 AUTODETECT
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	BOSCH ESP 8.1 AUTODETECT
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	BOSCH ESP 8.1 AUTODETECT
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	MANUAL
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	Marelli Dashboard PSA
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	SIEMENS SID 803A Common Rail AUTOD
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	SIEMENS SID 803A Common Rail AUTOD
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	SIEMENS SID 803A Common Rail AUTOD
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	Valeo 2 1/2
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	Valeo 2 1/2
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	AirBag CENTRAL AUTODETECT
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	AirBag CENTRAL AUTODETECT
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	BOSCH ABS 8.0 AUTODETECT
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	BOSCH ABS 8.0 AUTODETECT
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	BOSCH ESP 8.0 AUTODETECT
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	BOSCH ESP 8.0 AUTODETECT
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	BOSCH ESP 8.1 AUTODETECT
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	BOSCH ESP 8.1 AUTODETECT
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	MANUAL
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	Marelli Dashboard PSA
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	SIEMENS SID 803A Common Rail AUTOD
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	SIEMENS SID 803A Common Rail AUTOD
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	SIEMENS SID 803A Common Rail AUTOD
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	Valeo 2 1/2
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	Valeo 2 1/2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	AirBag CENTRAL AUTODETECT
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	AirBag CENTRAL AUTODETECT
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	BOSCH ABS 8.0 AUTODETECT
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	BOSCH ABS 8.0 AUTODETECT
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	BOSCH ESP 8.0 AUTODETECT
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	BOSCH ESP 8.0 AUTODETECT
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	BOSCH ESP 8.1 AUTODETECT
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	BOSCH ESP 8.1 AUTODETECT
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	MANUAL
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	Marelli Dashboard PSA
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	SIEMENS SID 803A Common Rail AUTOD
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	SIEMENS SID 803A Common Rail AUTOD
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	SIEMENS SID 803A Common Rail AUTOD
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	Valeo 2 1/2
 Jumpy 2	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	Valeo 2 1/2
 Jumpy 2	NAVIGATION	1.6 HDI 16v 66kw 9HU (07-..)	AUTODETECT
 Jumpy 2	NAVIGATION	1.6 HDI 16v 66kw 9HU (07-..)	AUTODETECT
 Jumpy 2	NAVIGATION	2.0 16v 103kw RFH (07-..)	AUTODETECT
 Jumpy 2	NAVIGATION	2.0 16v 103kw RFH (07-..)	AUTODETECT
 Jumpy 2	NAVIGATION	2.0 HDI 16v 100kw RHR-FAP (07-..)	AUTODETECT
 Jumpy 2	NAVIGATION	2.0 HDI 16v 100kw RHR-FAP (07-..)	AUTODETECT
 Jumpy 2	NAVIGATION	2.0 HDI 16v 88kw RHG (07-..)	AUTODETECT
 Jumpy 2	NAVIGATION	2.0 HDI 16v 88kw RHG (07-..)	AUTODETECT
 Jumpy 2	NAVIGATION	2.0 HDI 16v 88kw RHK (07-..)	AUTODETECT
 Jumpy 2	NAVIGATION	2.0 HDI 16v 88kw RHK (07-..)	AUTODETECT
 Jumpy 2	PARKING HELP	1.6 HDI 16v 66kw 9HU (07-..)	AUTODETECT
 Jumpy 2	PARKING HELP	2.0 16v 103kw RFH (07-..)	AUTODETECT
 Jumpy 2	PARKING HELP	2.0 HDI 16v 100kw RHR-FAP (07-..)	AUTODETECT
 Jumpy 2	PARKING HELP	2.0 HDI 16v 88kw RHG (07-..)	AUTODETECT
 Jumpy 2	PARKING HELP	2.0 HDI 16v 88kw RHK (07-..)	AUTODETECT
 Jumpy 2	PHONE	1.6 HDI 16v 66kw 9HU (07-..)	AUTODETECT
 Jumpy 2	PHONE	2.0 16v 103kw RFH (07-..)	AUTODETECT
 Jumpy 2	PHONE	2.0 HDI 16v 100kw RHR-FAP (07-..)	AUTODETECT
 Jumpy 2	PHONE	2.0 HDI 16v 88kw RHG (07-..)	AUTODETECT
 Jumpy 2	PHONE	2.0 HDI 16v 88kw RHK (07-..)	AUTODETECT
 Jumpy 2	RADIO / CD	1.6 HDI 16v 66kw 9HU (07-..)	AudioSystem AUTODETECT
 Jumpy 2	RADIO / CD	1.6 HDI 16v 66kw 9HU (07-..)	Blaupunkt AudioSystem
 Jumpy 2	RADIO / CD	1.6 HDI 16v 66kw 9HU (07-..)	CD Changer AUTODETECT
 Jumpy 2	RADIO / CD	2.0 16v 103kw RFH (07-..)	AudioSystem AUTODETECT
 Jumpy 2	RADIO / CD	2.0 16v 103kw RFH (07-..)	Blaupunkt AudioSystem
 Jumpy 2	RADIO / CD	2.0 16v 103kw RFH (07-..)	CD Changer AUTODETECT
 Jumpy 2	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP (07-..)	AudioSystem AUTODETECT
 Jumpy 2	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP (07-..)	Blaupunkt AudioSystem
 Jumpy 2	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP (07-..)	CD Changer AUTODETECT
 Jumpy 2	RADIO / CD	2.0 HDI 16v 88kw RHG (07-..)	AudioSystem AUTODETECT
 Jumpy 2	RADIO / CD	2.0 HDI 16v 88kw RHG (07-..)	Blaupunkt AudioSystem
 Jumpy 2	RADIO / CD	2.0 HDI 16v 88kw RHG (07-..)	CD Changer AUTODETECT
 Jumpy 2	RADIO / CD	2.0 HDI 16v 88kw RHK (07-..)	AudioSystem AUTODETECT
 Jumpy 2	RADIO / CD	2.0 HDI 16v 88kw RHK (07-..)	Blaupunkt AudioSystem
 Jumpy 2	RADIO / CD	2.0 HDI 16v 88kw RHK (07-..)	CD Changer AUTODETECT
 Jumpy 2	RAIN-LUMINOSITY S	1.6 HDI 16v 66kw 9HU (07-..)	AUTODETECT
 Jumpy 2	RAIN-LUMINOSITY S	2.0 16v 103kw RFH (07-..)	AUTODETECT
 Jumpy 2	RAIN-LUMINOSITY S	2.0 HDI 16v 100kw RHR-FAP (07-..)	AUTODETECT
 Jumpy 2	RAIN-LUMINOSITY S	2.0 HDI 16v 88kw RHG (07-..)	AUTODETECT
 Jumpy 2	RAIN-LUMINOSITY S	2.0 HDI 16v 88kw RHK (07-..)	AUTODETECT
 Jumpy 2	REAR CLIMA	1.6 HDI 16v 66kw 9HU (07-..)	AUTODETECT
 Jumpy 2	REAR CLIMA	2.0 16v 103kw RFH (07-..)	AUTODETECT
 Jumpy 2	REAR CLIMA	2.0 HDI 16v 100kw RHR-FAP (07-..)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Jumpy 2	REAR CLIMA	2.0 HDI 16v 88kw RHG (07-..)	AUTODETECT
 Jumpy 2	REAR CLIMA	2.0 HDI 16v 88kw RHK (07-..)	AUTODETECT
 Jumpy 2	SERVICE LIGHT RES	1.6 HDI 16v 66kw 9HU (07-..)	MANUAL
 Jumpy 2	SERVICE LIGHT RES	2.0 16v 103kw RFH (07-..)	MANUAL
 Jumpy 2	SERVICE LIGHT RES	2.0 HDI 16v 100kw RHR-FAP (07-..)	MANUAL
 Jumpy 2	SERVICE LIGHT RES	2.0 HDI 16v 88kw RHG (07-..)	MANUAL
 Jumpy 2	SERVICE LIGHT RES	2.0 HDI 16v 88kw RHK (07-..)	MANUAL
 Jumpy 2	STEERING COLUMN	1.6 HDI 16v 66kw 9HU (07-..)	AUTODETECT
 Jumpy 2	STEERING COLUMN	2.0 16v 103kw RFH (07-..)	AUTODETECT
 Jumpy 2	STEERING COLUMN	2.0 HDI 16v 100kw RHR-FAP (07-..)	AUTODETECT
 Jumpy 2	STEERING COLUMN	2.0 HDI 16v 88kw RHG (07-..)	AUTODETECT
 Jumpy 2	STEERING COLUMN	2.0 HDI 16v 88kw RHK (07-..)	AUTODETECT
 Jumpy 2	SUSPENSION CONTR	1.6 HDI 16v 66kw 9HU (07-..)	AUTODETECT
 Jumpy 2	SUSPENSION CONTR	2.0 16v 103kw RFH (07-..)	AUTODETECT
 Jumpy 2	SUSPENSION CONTR	2.0 HDI 16v 100kw RHR-FAP (07-..)	AUTODETECT
 Jumpy 2	SUSPENSION CONTR	2.0 HDI 16v 88kw RHG (07-..)	AUTODETECT
 Jumpy 2	SUSPENSION CONTR	2.0 HDI 16v 88kw RHK (07-..)	AUTODETECT
 Jumpy 2	SWITCHLIGHT MODU	1.6 HDI 16v 66kw 9HU (07-..)	DELPHI
 Jumpy 2	SWITCHLIGHT MODU	2.0 16v 103kw RFH (07-..)	DELPHI
 Jumpy 2	SWITCHLIGHT MODU	2.0 HDI 16v 100kw RHR-FAP (07-..)	DELPHI
 Jumpy 2	SWITCHLIGHT MODU	2.0 HDI 16v 88kw RHG (07-..)	DELPHI
 Jumpy 2	SWITCHLIGHT MODU	2.0 HDI 16v 88kw RHK (07-..)	DELPHI
 Jumpy 2	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HU (07-..)	Display A+ AUTODETECT
 Jumpy 2	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HU (07-..)	Display C- AUTODETECT
 Jumpy 2	VISUAL./TELEMATIC	2.0 16v 103kw RFH (07-..)	Display A+ AUTODETECT
 Jumpy 2	VISUAL./TELEMATIC	2.0 16v 103kw RFH (07-..)	Display C- AUTODETECT
 Jumpy 2	VISUAL./TELEMATIC	2.0 HDI 16v 100kw RHR-FAP (07-..)	Display A+ AUTODETECT
 Jumpy 2	VISUAL./TELEMATIC	2.0 HDI 16v 100kw RHR-FAP (07-..)	Display C- AUTODETECT
 Jumpy 2	VISUAL./TELEMATIC	2.0 HDI 16v 88kw RHG (07-..)	Display A+ AUTODETECT
 Jumpy 2	VISUAL./TELEMATIC	2.0 HDI 16v 88kw RHG (07-..)	Display C- AUTODETECT
 Jumpy 2	VISUAL./TELEMATIC	2.0 HDI 16v 88kw RHK (07-..)	Display A+ AUTODETECT
 Jumpy 2	VISUAL./TELEMATIC	2.0 HDI 16v 88kw RHK (07-..)	Display C- AUTODETECT
 Nemo	ABS + TRACT. CONT	1.4 8v 55kw KfV	BOSCH ABS 8.1 AUTODETECT
 Nemo	ABS + TRACT. CONT	1.4 8v 55kw KfV	BOSCH ESP 8
 Nemo	ABS + TRACT. CONT	1.4 HDI 8v 50kw 8HS	ABS BOSCH 8.1 AUTODETECT
 Nemo	ABS + TRACT. CONT	1.4 HDI 8v 50kw 8HS	BOSCH ESP 8
 Nemo	AIRBAG	1.4 8v 55kw KfV	AUTOLIV AirBag CENTRAL AUTODETECT
 Nemo	AIRBAG	1.4 8v 55kw KfV	TRW SRS EP
 Nemo	AIRBAG	1.4 HDI 8v 50kw 8HS	AUTOLIV AirBag CENTRAL AUTODETECT
 Nemo	AIRBAG	1.4 HDI 8v 50kw 8HS	TRW SRS EP
 Nemo	AUTOM. TRANSMISSI	1.4 8v 55kw KfV	Selespeed AUTODETECT
 Nemo	AUTOM. TRANSMISSI	1.4 HDI 8v 50kw 8HS	Selespeed AUTODETECT
 Nemo	CHASSIS NETWORK	1.4 8v 55kw KfV	Body Computer BSI AUTODETECT
 Nemo	CHASSIS NETWORK	1.4 8v 55kw KfV	DELPHI Body Computer
 Nemo	CHASSIS NETWORK	1.4 8v 55kw KfV	DELPHI Body Computer CAN Info
 Nemo	CHASSIS NETWORK	1.4 8v 55kw KfV	DELPHI EP
 Nemo	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HS	Body Computer BSI AUTODETECT
 Nemo	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HS	DELPHI Body Computer
 Nemo	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HS	DELPHI Body Computer CAN Info
 Nemo	CHASSIS NETWORK	1.4 HDI 8v 50kw 8HS	DELPHI EP
 Nemo	DASHBOARD	1.4 8v 55kw (08-..)	Marelli Dashboard Comfort
 Nemo	DASHBOARD	1.4 8v 55kw (09-..)	Marelli Service reset
 Nemo	DASHBOARD	1.4 8v 55kw KfV	AUTODETECT
 Nemo	DASHBOARD	1.4 8v 55kw KfV	Marelli Dashboard Modale
 Nemo	DASHBOARD	1.4 HDI 8v 50kw (08-..)	Marelli Dashboard Comfort
 Nemo	DASHBOARD	1.4 HDI 8v 50kw (09-..)	Marelli Service reset
 Nemo	DASHBOARD	1.4 HDI 8v 50kw 8HS	AUTODETECT
 Nemo	DASHBOARD	1.4 HDI 8v 50kw 8HS	Marelli Dashboard Modale

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Nemo	ENGINE MANAGEME	1.4 8v 55kw KFV	V34P AUTODETECT
 Nemo	ENGINE MANAGEME	1.4 HDI 8v 50kw 8HS	AUTODETECT
 Nemo	ENGINE MANAGEME	1.4 HDI 8v 50kw 8HS	Marelli EDC 6F3
 Nemo	FAP OIL PARAMETER	1.4 HDI 8v 50kw 8HS (08-..)	Marelli
 Nemo	MAINTENANCE	1.4 8v 55kw (08-..)	Marelli Dashboard
 Nemo	MAINTENANCE	1.4 8v 55kw (08-..)	Marelli Dashboard Comfort
 Nemo	MAINTENANCE	1.4 8v 55kw (08-..)	Marelli Dashboard Comfort
 Nemo	MAINTENANCE	1.4 8v 55kw (08-..)	Marelli Dashboard Comfort
 Nemo	MAINTENANCE	1.4 8v 55kw (09-..)	Marelli Dashboard
 Nemo	MAINTENANCE	1.4 8v 55kw (09-..)	Marelli Service reset
 Nemo	MAINTENANCE	1.4 8v 55kw (09-..)	Marelli Service reset
 Nemo	MAINTENANCE	1.4 8v 55kw (09-..)	Marelli Service reset
 Nemo	MAINTENANCE	1.4 8v 55kw KFV	BOSCH ESP 8
 Nemo	MAINTENANCE	1.4 8v 55kw KFV	Marelli Dashboard Modale
 Nemo	MAINTENANCE	1.4 8v 55kw KFV	Marelli Dashboard Modale
 Nemo	MAINTENANCE	1.4 HDI 8v 50kw (08-..)	Marelli Dashboard
 Nemo	MAINTENANCE	1.4 HDI 8v 50kw (08-..)	Marelli Dashboard Comfort
 Nemo	MAINTENANCE	1.4 HDI 8v 50kw (08-..)	Marelli Dashboard Comfort
 Nemo	MAINTENANCE	1.4 HDI 8v 50kw (08-..)	Marelli Dashboard Comfort
 Nemo	MAINTENANCE	1.4 HDI 8v 50kw (09-..)	Marelli Dashboard
 Nemo	MAINTENANCE	1.4 HDI 8v 50kw (09-..)	Marelli Service reset
 Nemo	MAINTENANCE	1.4 HDI 8v 50kw (09-..)	Marelli Service reset
 Nemo	MAINTENANCE	1.4 HDI 8v 50kw (09-..)	Marelli Service reset
 Nemo	MAINTENANCE	1.4 HDI 8v 50kw 8HS	BOSCH ESP 8
 Nemo	MAINTENANCE	1.4 HDI 8v 50kw 8HS	Marelli Dashboard Modale
 Nemo	MAINTENANCE	1.4 HDI 8v 50kw 8HS	Marelli Dashboard Modale
 Nemo	MAINTENANCE	1.4 HDI 8v 50kw 8HS	Marelli EDC 6F3
 Nemo	MAINTENANCE	1.4 HDI 8v 50kw 8HS (08-..)	Marelli
 Nemo	PARKING HELP	1.4 8v 55kw KFV	AUTODETECT
 Nemo	PARKING HELP	1.4 HDI 8v 50kw 8HS	AUTODETECT
 Nemo	SERVICE LIGHT RES	1.4 8v 55kw (08-..)	Marelli Dashboard
 Nemo	SERVICE LIGHT RES	1.4 8v 55kw (09-..)	Marelli Dashboard
 Nemo	SERVICE LIGHT RES	1.4 HDI 8v 50kw (08-..)	Marelli Dashboard
 Nemo	SERVICE LIGHT RES	1.4 HDI 8v 50kw (09-..)	Marelli Dashboard
 Relay 1	ABS	1.9 D 68kw D9B (94-02)	BOSCH ABS ABR 5.3
 Relay 1	ABS	1.9 D 8v 52kw D9B (94-02)	BOSCH ABS ABR 5.3
 Relay 1	ABS	1.9 D 8v 52kw DJY (94-02)	BOSCH ABS ABR 5.3
 Relay 1	ABS	1.9 TD 8v 66kw D8C (94-02)	BOSCH ABS ABR 5.3
 Relay 1	ABS	1.9 TD 8v 66kw DHX (94-02)	BOSCH ABS ABR 5.3
 Relay 1	ABS	2.0 8v 80kw RFL (94-02)	BOSCH ABS ABR 5.3
 Relay 1	ABS	2.0 8v 80kw RFW (94-02)	BOSCH ABS ABR 5.3
 Relay 1	ABS	2.0 8v 81kw RFL (02-06)	BOSCH ABS 8
 Relay 1	ABS	2.0 8v 81kw RFL (02-06)	BOSCH ABS ABR 5.3
 Relay 1	ABS	2.0 HDI 8v 63kw RHV (02-06)	BOSCH ABS 8
 Relay 1	ABS	2.0 HDI 8v 63kw RHV (02-06)	BOSCH ABS ABR 5.3
 Relay 1	ABS	2.0 HDI 8v 63kw RHV (94-02)	BOSCH ABS ABR 5.3
 Relay 1	ABS	2.2 HDI 8v 74kw 4HY (02-06)	BOSCH ABS 8
 Relay 1	ABS	2.2 HDI 8v 74kw 4HY (02-06)	BOSCH ABS ABR 5.3
 Relay 1	ABS	2.3 HDI 16v 81kw F1AE0481C (02-0	BOSCH ABS 8
 Relay 1	ABS	2.3 HDI 16v 81kw F1AE0481C (02-0	BOSCH ABS ABR 5.3
 Relay 1	ABS	2.5 D 8v 63kw T9A (02-06)	BOSCH ABS 8
 Relay 1	ABS	2.5 D 8v 63kw T9A (02-06)	BOSCH ABS ABR 5.3
 Relay 1	ABS	2.5 D 8v 63kw T9A (94-02)	BOSCH ABS ABR 5.3
 Relay 1	ABS	2.5 TD 12V 76kw T8A (94-02)	BOSCH ABS ABR 5.3
 Relay 1	ABS	2.5 TD 12V 76kw THZ (94-02)	BOSCH ABS ABR 5.3
 Relay 1	ABS	2.5 TDI 12v 79kw THX (94-02)	BOSCH ABS ABR 5.3
 Relay 1	ABS	2.8 D 8v 64kw 8140.63 (02-06)	BOSCH ABS 8
 Relay 1	ABS	2.8 D 8v 64kw 8140.63 (02-06)	BOSCH ABS ABR 5.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Relay 1	ABS	2.8 D 8v 64kw 8140.63 (94-02)	BOSCH ABS ABR 5.3
 Relay 1	ABS	2.8 HDI 8v 108kw 43N (02-06)	BOSCH ABS 8
 Relay 1	ABS	2.8 HDI 8v 108kw 43N (02-06)	BOSCH ABS ABR 5.3
 Relay 1	ABS	2.8 HDI 8v 93kw 43S (02-06)	BOSCH ABS 8
 Relay 1	ABS	2.8 HDI 8v 93kw 43S (02-06)	BOSCH ABS ABR 5.3
 Relay 1	ABS	2.8 HDI 8v 93kw 43S (94-02)	BOSCH ABS ABR 5.3
 Relay 1	AIRBAG	2.0 8v 81kw RFL (02-06)	SIEMENS AirBag
 Relay 1	AIRBAG	2.0 8v 81kw RFL (02-06)	TRW SRS 1
 Relay 1	AIRBAG	2.0 HDI 8v 63kw RHV (02-06)	SIEMENS AirBag
 Relay 1	AIRBAG	2.0 HDI 8v 63kw RHV (02-06)	TRW SRS 1
 Relay 1	AIRBAG	2.2 HDI 8v 74kw 4HY (02-06)	SIEMENS AirBag
 Relay 1	AIRBAG	2.2 HDI 8v 74kw 4HY (02-06)	TRW SRS 1
 Relay 1	AIRBAG	2.3 HDI 16v 81kw F1AE0481C (02-0	SIEMENS AirBag
 Relay 1	AIRBAG	2.3 HDI 16v 81kw F1AE0481C (02-0	TRW SRS 1
 Relay 1	AIRBAG	2.5 D 8v 63kw T9A (02-06)	SIEMENS AirBag
 Relay 1	AIRBAG	2.5 D 8v 63kw T9A (02-06)	TRW SRS 1
 Relay 1	AIRBAG	2.8 D 8v 64kw 8140.63 (02-06)	SIEMENS AirBag
 Relay 1	AIRBAG	2.8 D 8v 64kw 8140.63 (02-06)	TRW SRS 1
 Relay 1	AIRBAG	2.8 HDI 8v 108kw 43N (02-06)	SIEMENS AirBag
 Relay 1	AIRBAG	2.8 HDI 8v 108kw 43N (02-06)	TRW SRS 1
 Relay 1	AIRBAG	2.8 HDI 8v 93kw 43S (02-06)	SIEMENS AirBag
 Relay 1	AIRBAG	2.8 HDI 8v 93kw 43S (02-06)	TRW SRS 1
 Relay 1	AUTOM. TRANSMISSI	2.0 8v 81kw RFL (02-06)	A/T 4HP20 AUTODETECT
 Relay 1	AUTOM. TRANSMISSI	2.0 HDI 8v 63kw RHV (02-06)	A/T 4HP20 AUTODETECT
 Relay 1	AUTOM. TRANSMISSI	2.2 HDI 8v 74kw 4HY (02-06)	A/T 4HP20 AUTODETECT
 Relay 1	AUTOM. TRANSMISSI	2.3 HDI 16v 81kw F1AE0481C (02-0	A/T 4HP20 AUTODETECT
 Relay 1	AUTOM. TRANSMISSI	2.5 D 8v 63kw T9A (02-06)	A/T 4HP20 AUTODETECT
 Relay 1	AUTOM. TRANSMISSI	2.8 D 8v 64kw 8140.63 (02-06)	A/T 4HP20 AUTODETECT
 Relay 1	AUTOM. TRANSMISSI	2.8 HDI 8v 108kw 43N (02-06)	A/T 4HP20 AUTODETECT
 Relay 1	AUTOM. TRANSMISSI	2.8 HDI 8v 93kw 43S (02-06)	A/T 4HP20 AUTODETECT
 Relay 1	AUX. HEATING	2.0 8v 81kw RFL (02-06)	AUTODETECT
 Relay 1	AUX. HEATING	2.0 HDI 8v 63kw RHV (02-06)	AUTODETECT
 Relay 1	AUX. HEATING	2.2 HDI 8v 74kw 4HY (02-06)	AUTODETECT
 Relay 1	AUX. HEATING	2.3 HDI 16v 81kw F1AE0481C (02-0	AUTODETECT
 Relay 1	AUX. HEATING	2.5 D 8v 63kw T9A (02-06)	AUTODETECT
 Relay 1	AUX. HEATING	2.8 D 8v 64kw 8140.63 (02-06)	AUTODETECT
 Relay 1	AUX. HEATING	2.8 HDI 8v 108kw 43N (02-06)	AUTODETECT
 Relay 1	AUX. HEATING	2.8 HDI 8v 93kw 43S (02-06)	AUTODETECT
 Relay 1	CHASSIS NETWORK	2.0 8v 81kw RFL (02-06)	Marelli Body Computer 6
 Relay 1	CHASSIS NETWORK	2.0 HDI 8v 63kw RHV (02-06)	Marelli Body Computer 6
 Relay 1	CHASSIS NETWORK	2.2 HDI 8v 74kw 4HY (02-06)	Marelli Body Computer 6
 Relay 1	CHASSIS NETWORK	2.3 HDI 16v 81kw F1AE0481C (02-0	Marelli Body Computer 6
 Relay 1	CHASSIS NETWORK	2.5 D 8v 63kw T9A (02-06)	Marelli Body Computer 6
 Relay 1	CHASSIS NETWORK	2.8 D 8v 64kw 8140.63 (02-06)	Marelli Body Computer 6
 Relay 1	CHASSIS NETWORK	2.8 HDI 8v 108kw 43N (02-06)	Marelli Body Computer 6
 Relay 1	CHASSIS NETWORK	2.8 HDI 8v 93kw 43S (02-06)	Marelli Body Computer 6
 Relay 1	DASHBOARD	2.0 8v 81kw RFL (02-06)	Marelli Dashboard
 Relay 1	DASHBOARD	2.0 HDI 8v 63kw RHV (02-06)	Marelli Dashboard
 Relay 1	DASHBOARD	2.2 HDI 8v 74kw 4HY (02-06)	Marelli Dashboard
 Relay 1	DASHBOARD	2.3 HDI 16v 81kw F1AE0481C (02-0	Marelli Dashboard
 Relay 1	DASHBOARD	2.5 D 8v 63kw T9A (02-06)	Marelli Dashboard
 Relay 1	DASHBOARD	2.8 D 8v 64kw 8140.63 (02-06)	Marelli Dashboard
 Relay 1	DASHBOARD	2.8 HDI 8v 108kw 43N (02-06)	Marelli Dashboard
 Relay 1	DASHBOARD	2.8 HDI 8v 93kw 43S (02-06)	Marelli Dashboard
 Relay 1	ENGINE MANAGEME	2.0 8v 80kw RFL (94-02)	Marelli MM48P AUTODETECT
 Relay 1	ENGINE MANAGEME	2.0 8v 80kw RFW (01-02)	EOBD
 Relay 1	ENGINE MANAGEME	2.0 8v 81kw RFL (02-06)	Marelli MM48P AUTODETECT
 Relay 1	ENGINE MANAGEME	2.0 HDI 8v 63kw RHV (02-06)	DIESEL AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Relay 1	ENGINE MANAGEME	2.0 HDI 8v 63kw RHV (94-02)	DIESEL AUTODETECT
 Relay 1	ENGINE MANAGEME	2.2 HDI 8v 74kw 4HY (02-06)	BOSCH EDC 15 Common Rail (JTD '99)
 Relay 1	ENGINE MANAGEME	2.2 HDI 8v 74kw 4HY (02-06)	BOSCH EDC 16 Common Rail
 Relay 1	ENGINE MANAGEME	2.3 HDI 16v 81kw F1AE0481C (02-0	EOBD
 Relay 1	ENGINE MANAGEME	2.5 D 8v 63kw T9A (02-06)	EOBD
 Relay 1	ENGINE MANAGEME	2.8 D 8v 64kw 8140.63 (02-06)	EOBD
 Relay 1	ENGINE MANAGEME	2.8 HDI 8v 108kw 43N (02-06)	BOSCH EDC 15 Common Rail (JTD '99)
 Relay 1	ENGINE MANAGEME	2.8 HDI 8v 108kw 43N (02-06)	DIESEL AUTODETECT
 Relay 1	ENGINE MANAGEME	2.8 HDI 8v 93kw 43S (02-06)	BOSCH EDC 15 Common Rail (JTD '99)
 Relay 1	ENGINE MANAGEME	2.8 HDI 8v 93kw 43S (02-06)	DIESEL AUTODETECT
 Relay 1	ENGINE MANAGEME	2.8 HDI 8v 93kw 43S (94-02)	DIESEL AUTODETECT
 Relay 1	MAINTENANCE	1.9 D 68kw D9B (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	1.9 D 68kw D9B (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	1.9 D 68kw D9B (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	1.9 D 68kw D9B (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	1.9 D 8v 52kw D9B (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	1.9 D 8v 52kw D9B (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	1.9 D 8v 52kw D9B (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	1.9 D 8v 52kw DJY (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	1.9 D 8v 52kw DJY (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	1.9 D 8v 52kw DJY (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	1.9 D 8v 52kw DJY (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	1.9 TD 8v 66kw D8C (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	1.9 TD 8v 66kw D8C (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	1.9 TD 8v 66kw D8C (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	1.9 TD 8v 66kw D8C (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	1.9 TD 8v 66kw DHX (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	1.9 TD 8v 66kw DHX (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	1.9 TD 8v 66kw DHX (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	1.9 TD 8v 66kw DHX (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.0 8v 80kw RFL (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.0 8v 80kw RFL (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.0 8v 80kw RFL (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.0 8v 80kw RFL (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.0 8v 80kw RFW (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.0 8v 80kw RFW (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.0 8v 80kw RFW (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.0 8v 81kw RFL (02-06)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.0 8v 81kw RFL (02-06)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.0 8v 81kw RFL (02-06)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.0 8v 81kw RFL (02-06)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.0 8v 81kw RFL (02-06)	Marelli Dashboard
 Relay 1	MAINTENANCE	2.0 8v 81kw RFL (02-06)	Marelli Dashboard
 Relay 1	MAINTENANCE	2.0 8v 81kw RFL (02-06)	Marelli Dashboard
 Relay 1	MAINTENANCE	2.0 8v 81kw RFL (02-06)	Marelli Dashboard
 Relay 1	MAINTENANCE	2.0 HDI 8v 63kw RHV (02-06)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.0 HDI 8v 63kw RHV (02-06)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.0 HDI 8v 63kw RHV (02-06)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.0 HDI 8v 63kw RHV (02-06)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.0 HDI 8v 63kw RHV (02-06)	Marelli Dashboard
 Relay 1	MAINTENANCE	2.0 HDI 8v 63kw RHV (02-06)	Marelli Dashboard
 Relay 1	MAINTENANCE	2.0 HDI 8v 63kw RHV (02-06)	Marelli Dashboard
 Relay 1	MAINTENANCE	2.0 HDI 8v 63kw RHV (02-06)	Marelli Dashboard
 Relay 1	MAINTENANCE	2.0 HDI 8v 63kw RHV (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.0 HDI 8v 63kw RHV (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.0 HDI 8v 63kw RHV (94-02)	BOSCH ABS ABR 5.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Relay 1	MAINTENANCE	2.0 HDI 8v 63kw RHV (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.2 HDI 8v 74kw 4HY (02-06)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.2 HDI 8v 74kw 4HY (02-06)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.2 HDI 8v 74kw 4HY (02-06)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.2 HDI 8v 74kw 4HY (02-06)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.2 HDI 8v 74kw 4HY (02-06)	BOSCH EDC 16 Common Rail
 Relay 1	MAINTENANCE	2.2 HDI 8v 74kw 4HY (02-06)	Marelli Dashboard
 Relay 1	MAINTENANCE	2.2 HDI 8v 74kw 4HY (02-06)	Marelli Dashboard
 Relay 1	MAINTENANCE	2.2 HDI 8v 74kw 4HY (02-06)	Marelli Dashboard
 Relay 1	MAINTENANCE	2.2 HDI 8v 74kw 4HY (02-06)	Marelli Dashboard
 Relay 1	MAINTENANCE	2.3 HDI 16v 81kw F1AE0481C (02-0	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.3 HDI 16v 81kw F1AE0481C (02-0	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.3 HDI 16v 81kw F1AE0481C (02-0	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.3 HDI 16v 81kw F1AE0481C (02-0	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.3 HDI 16v 81kw F1AE0481C (02-0	Marelli Dashboard
 Relay 1	MAINTENANCE	2.3 HDI 16v 81kw F1AE0481C (02-0	Marelli Dashboard
 Relay 1	MAINTENANCE	2.3 HDI 16v 81kw F1AE0481C (02-0	Marelli Dashboard
 Relay 1	MAINTENANCE	2.3 HDI 16v 81kw F1AE0481C (02-0	Marelli Dashboard
 Relay 1	MAINTENANCE	2.5 D 8v 63kw T9A (02-06)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.5 D 8v 63kw T9A (02-06)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.5 D 8v 63kw T9A (02-06)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.5 D 8v 63kw T9A (02-06)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.5 D 8v 63kw T9A (02-06)	Marelli Dashboard
 Relay 1	MAINTENANCE	2.5 D 8v 63kw T9A (02-06)	Marelli Dashboard
 Relay 1	MAINTENANCE	2.5 D 8v 63kw T9A (02-06)	Marelli Dashboard
 Relay 1	MAINTENANCE	2.5 D 8v 63kw T9A (02-06)	Marelli Dashboard
 Relay 1	MAINTENANCE	2.5 D 8v 63kw T9A (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.5 D 8v 63kw T9A (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.5 D 8v 63kw T9A (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.5 TD 12V 76kw T8A (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.5 TD 12V 76kw T8A (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.5 TD 12V 76kw T8A (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.5 TD 12V 76kw T8A (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.5 TD 12V 76kw THZ (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.5 TD 12V 76kw THZ (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.5 TD 12V 76kw THZ (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.5 TDI 12v 79kw THX (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.5 TDI 12v 79kw THX (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.5 TDI 12v 79kw THX (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.5 TDI 12v 79kw THX (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.8 D 8v 64kw 8140.63 (02-06)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.8 D 8v 64kw 8140.63 (02-06)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.8 D 8v 64kw 8140.63 (02-06)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.8 D 8v 64kw 8140.63 (02-06)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.8 D 8v 64kw 8140.63 (02-06)	Marelli Dashboard
 Relay 1	MAINTENANCE	2.8 D 8v 64kw 8140.63 (02-06)	Marelli Dashboard
 Relay 1	MAINTENANCE	2.8 D 8v 64kw 8140.63 (02-06)	Marelli Dashboard
 Relay 1	MAINTENANCE	2.8 D 8v 64kw 8140.63 (02-06)	Marelli Dashboard
 Relay 1	MAINTENANCE	2.8 D 8v 64kw 8140.63 (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.8 D 8v 64kw 8140.63 (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.8 D 8v 64kw 8140.63 (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.8 D 8v 64kw 8140.63 (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.8 HDI 8v 108kw 43N (02-06)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.8 HDI 8v 108kw 43N (02-06)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.8 HDI 8v 108kw 43N (02-06)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.8 HDI 8v 108kw 43N (02-06)	BOSCH ABS ABR 5.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Relay 1	MAINTENANCE	2.8 HDI 8v 108kw 43N (02-06)	Marelli Dashboard
 Relay 1	MAINTENANCE	2.8 HDI 8v 108kw 43N (02-06)	Marelli Dashboard
 Relay 1	MAINTENANCE	2.8 HDI 8v 108kw 43N (02-06)	Marelli Dashboard
 Relay 1	MAINTENANCE	2.8 HDI 8v 108kw 43N (02-06)	Marelli Dashboard
 Relay 1	MAINTENANCE	2.8 HDI 8v 93kw 43S (02-06)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.8 HDI 8v 93kw 43S (02-06)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.8 HDI 8v 93kw 43S (02-06)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.8 HDI 8v 93kw 43S (02-06)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.8 HDI 8v 93kw 43S (02-06)	Marelli Dashboard
 Relay 1	MAINTENANCE	2.8 HDI 8v 93kw 43S (02-06)	Marelli Dashboard
 Relay 1	MAINTENANCE	2.8 HDI 8v 93kw 43S (02-06)	Marelli Dashboard
 Relay 1	MAINTENANCE	2.8 HDI 8v 93kw 43S (02-06)	Marelli Dashboard
 Relay 1	MAINTENANCE	2.8 HDI 8v 93kw 43S (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.8 HDI 8v 93kw 43S (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.8 HDI 8v 93kw 43S (94-02)	BOSCH ABS ABR 5.3
 Relay 1	MAINTENANCE	2.8 HDI 8v 93kw 43S (94-02)	BOSCH ABS ABR 5.3
 Relay 1	SERVICE LIGHT RES	2.0 8v 81kw RFL (02-06)	Marelli Dashboard
 Relay 1	SERVICE LIGHT RES	2.0 HDI 8v 63kw RHV (02-06)	Marelli Dashboard
 Relay 1	SERVICE LIGHT RES	2.2 HDI 8v 74kw 4HY (02-06)	Marelli Dashboard
 Relay 1	SERVICE LIGHT RES	2.3 HDI 16v 81kw F1AE0481C (02-0	Marelli Dashboard
 Relay 1	SERVICE LIGHT RES	2.5 D 8v 63kw T9A (02-06)	Marelli Dashboard
 Relay 1	SERVICE LIGHT RES	2.8 D 8v 64kw 8140.63 (02-06)	Marelli Dashboard
 Relay 1	SERVICE LIGHT RES	2.8 HDI 8v 108kw 43N (02-06)	Marelli Dashboard
 Relay 1	SERVICE LIGHT RES	2.8 HDI 8v 93kw 43S (02-06)	Marelli Dashboard
 Relay 2	ABS	1.6 HDI 16v 66kw 9HU (06-..)	BOSCH ABS 8.0 AUTODETECT
 Relay 2	ABS	2.0 16v 103kw RFH (06-..)	BOSCH ABS 8.0 AUTODETECT
 Relay 2	ABS	2.0 HDI 16v 100kw RHR (06-..)	BOSCH ABS 8.0 AUTODETECT
 Relay 2	ABS	2.0 HDI 16v 88kw RHG (06-..)	BOSCH ABS 8.0 AUTODETECT
 Relay 2	ABS	2.0 HDI 16v 88kw RHK (06-..)	BOSCH ABS 8.0 AUTODETECT
 Relay 2	ABS	2.2 HDI 16v 74kw 4HV (06-..)	BOSCH ABS 8.0 AUTODETECT
 Relay 2	ABS	2.2 HDI 16v 88kw 4HU (06-..)	BOSCH ABS 8.0 AUTODETECT
 Relay 2	ABS	2.3 HDI 16v 88kw F1AE0481D (06-..)	BOSCH ABS 8.0 AUTODETECT
 Relay 2	ABS	2.3 HDI 16v 95kw F1AE0481N (06-..)	BOSCH ABS 8.0 AUTODETECT
 Relay 2	ABS	3.0 HDI 16v 115kw F1CE0481D (06-..)	BOSCH ABS 8.0 AUTODETECT
 Relay 2	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HU (06-..)	ABS+TC AUTODETECT
 Relay 2	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HU (06-..)	BOSCH ESP AUTODETECT
 Relay 2	ABS + TRACT. CONT	2.0 16v 103kw RFH (06-..)	ABS+TC AUTODETECT
 Relay 2	ABS + TRACT. CONT	2.0 16v 103kw RFH (06-..)	BOSCH ESP AUTODETECT
 Relay 2	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR (06-..)	ABS+TC AUTODETECT
 Relay 2	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR (06-..)	BOSCH ESP AUTODETECT
 Relay 2	ABS + TRACT. CONT	2.0 HDI 16v 88kw RHG (06-..)	ABS+TC AUTODETECT
 Relay 2	ABS + TRACT. CONT	2.0 HDI 16v 88kw RHG (06-..)	BOSCH ESP AUTODETECT
 Relay 2	ABS + TRACT. CONT	2.0 HDI 16v 88kw RHK (06-..)	ABS+TC AUTODETECT
 Relay 2	ABS + TRACT. CONT	2.0 HDI 16v 88kw RHK (06-..)	BOSCH ESP AUTODETECT
 Relay 2	ABS + TRACT. CONT	2.2 HDI 16v 74kw 4HV (06-..)	ABS+TC AUTODETECT
 Relay 2	ABS + TRACT. CONT	2.2 HDI 16v 74kw 4HV (06-..)	ESP AUTODETECT
 Relay 2	ABS + TRACT. CONT	2.2 HDI 16v 88kw 4HU (06-..)	ABS+TC AUTODETECT
 Relay 2	ABS + TRACT. CONT	2.2 HDI 16v 88kw 4HU (06-..)	BOSCH ESP AUTODETECT
 Relay 2	ABS + TRACT. CONT	2.3 HDI 16v 88kw F1AE0481D (06-..)	ABS+TC AUTODETECT
 Relay 2	ABS + TRACT. CONT	2.3 HDI 16v 88kw F1AE0481D (06-..)	BOSCH ESP AUTODETECT
 Relay 2	ABS + TRACT. CONT	2.3 HDI 16v 95kw F1AE0481N (06-..)	ABS+TC AUTODETECT
 Relay 2	ABS + TRACT. CONT	2.3 HDI 16v 95kw F1AE0481N (06-..)	BOSCH ESP AUTODETECT
 Relay 2	ABS + TRACT. CONT	3.0 HDI 16v 115kw F1CE0481D (06-..)	ABS+TC AUTODETECT
 Relay 2	ABS + TRACT. CONT	3.0 HDI 16v 115kw F1CE0481D (06-..)	BOSCH ESP AUTODETECT
 Relay 2	AIRBAG	1.6 HDI 16v 66kw 9HU (06-..)	AirBag CENTRAL AUTODETECT
 Relay 2	AIRBAG	2.0 16v 103kw RFH (06-..)	AirBag CENTRAL AUTODETECT
 Relay 2	AIRBAG	2.0 HDI 16v 100kw RHR (06-..)	AirBag CENTRAL AUTODETECT
 Relay 2	AIRBAG	2.0 HDI 16v 88kw RHG (06-..)	AirBag CENTRAL AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Relay 2	AIRBAG	2.0 HDI 16v 88kw RHK (06-..)	AirBag CENTRAL AUTODETECT
 Relay 2	AIRBAG	2.2 HDI 16v 74kw 4HV (06-..)	AirBag CENTRAL AUTODETECT
 Relay 2	AIRBAG	2.2 HDI 16v 88kw 4HU (06-..)	AirBag CENTRAL AUTODETECT
 Relay 2	AIRBAG	2.3 HDI 16v 88kw F1AE0481D (06-..)	AirBag CENTRAL AUTODETECT
 Relay 2	AIRBAG	2.3 HDI 16v 95kw F1AE0481N (06-..)	AirBag CENTRAL AUTODETECT
 Relay 2	AIRBAG	3.0 HDI 16v 115kw F1CE0481D (06-..)	AirBag CENTRAL AUTODETECT
 Relay 2	AUX. HEATING	1.6 HDI 16v 66kw 9HU (06-..)	AUTODETECT
 Relay 2	AUX. HEATING	2.0 16v 103kw RFH (06-..)	AUTODETECT
 Relay 2	AUX. HEATING	2.0 HDI 16v 100kw RHR (06-..)	AUTODETECT
 Relay 2	AUX. HEATING	2.0 HDI 16v 88kw RHG (06-..)	AUTODETECT
 Relay 2	AUX. HEATING	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 Relay 2	AUX. HEATING	2.2 HDI 16v 74kw 4HV (06-..)	AUTODETECT
 Relay 2	AUX. HEATING	2.2 HDI 16v 88kw 4HU (06-..)	AUTODETECT
 Relay 2	AUX. HEATING	2.3 HDI 16v 88kw F1AE0481D (06-..)	AUTODETECT
 Relay 2	AUX. HEATING	2.3 HDI 16v 95kw F1AE0481N (06-..)	AUTODETECT
 Relay 2	AUX. HEATING	3.0 HDI 16v 115kw F1CE0481D (06-..)	AUTODETECT
 Relay 2	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HU (06-..)	Body Computer BSI AUTODETECT
 Relay 2	CHASSIS NETWORK	2.0 16v 103kw RFH (06-..)	Body Computer BSI AUTODETECT
 Relay 2	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR (06-..)	Body Computer BSI AUTODETECT
 Relay 2	CHASSIS NETWORK	2.0 HDI 16v 88kw RHG (06-..)	Body Computer BSI AUTODETECT
 Relay 2	CHASSIS NETWORK	2.0 HDI 16v 88kw RHK (06-..)	Body Computer BSI AUTODETECT
 Relay 2	CHASSIS NETWORK	2.2 HDI 16v 74kw 4HV (06-..)	Body Computer BSI AUTODETECT
 Relay 2	CHASSIS NETWORK	2.2 HDI 16v 88kw 4HU (06-..)	Body Computer BSI AUTODETECT
 Relay 2	CHASSIS NETWORK	2.3 HDI 16v 88kw F1AE0481D (06-..)	Body Computer BSI AUTODETECT
 Relay 2	CHASSIS NETWORK	2.3 HDI 16v 95kw F1AE0481N (06-..)	Body Computer BSI AUTODETECT
 Relay 2	CHASSIS NETWORK	3.0 HDI 16v 115kw F1CE0481D (06-..)	Body Computer BSI AUTODETECT
 Relay 2	CHRONOTACHOGRA	1.6 HDI 16v 66kw 9HU (06-..)	AUTODETECT
 Relay 2	CHRONOTACHOGRA	2.0 16v 103kw RFH (06-..)	AUTODETECT
 Relay 2	CHRONOTACHOGRA	2.0 HDI 16v 100kw RHR (06-..)	AUTODETECT
 Relay 2	CHRONOTACHOGRA	2.0 HDI 16v 88kw RHG (06-..)	AUTODETECT
 Relay 2	CHRONOTACHOGRA	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 Relay 2	CHRONOTACHOGRA	2.2 HDI 16v 74kw 4HV (06-..)	AUTODETECT
 Relay 2	CHRONOTACHOGRA	2.2 HDI 16v 88kw 4HU (06-..)	AUTODETECT
 Relay 2	CHRONOTACHOGRA	2.3 HDI 16v 88kw F1AE0481D (06-..)	AUTODETECT
 Relay 2	CHRONOTACHOGRA	2.3 HDI 16v 95kw F1AE0481N (06-..)	AUTODETECT
 Relay 2	CHRONOTACHOGRA	3.0 HDI 16v 115kw F1CE0481D (06-..)	AUTODETECT
 Relay 2	CLIMA	1.6 HDI 16v 66kw 9HU (06-..)	CLIMA AUTODETECT
 Relay 2	CLIMA	2.0 16v 103kw RFH (06-..)	CLIMA AUTODETECT
 Relay 2	CLIMA	2.0 HDI 16v 100kw RHR (06-..)	CLIMA AUTODETECT
 Relay 2	CLIMA	2.0 HDI 16v 88kw RHG (06-..)	CLIMA AUTODETECT
 Relay 2	CLIMA	2.0 HDI 16v 88kw RHK (06-..)	CLIMA AUTODETECT
 Relay 2	CLIMA	2.2 HDI 16v 74kw 4HV (06-..)	CLIMA AUTODETECT
 Relay 2	CLIMA	2.2 HDI 16v 88kw 4HU (06-..)	CLIMA AUTODETECT
 Relay 2	CLIMA	2.3 HDI 16v 88kw F1AE0481D (06-..)	CLIMA AUTODETECT
 Relay 2	CLIMA	2.3 HDI 16v 95kw F1AE0481N (06-..)	CLIMA AUTODETECT
 Relay 2	CLIMA	3.0 HDI 16v 115kw F1CE0481D (06-..)	CLIMA AUTODETECT
 Relay 2	DASHBOARD	1.6 HDI 16v 66kw 9HU (06-..)	AUTODETECT
 Relay 2	DASHBOARD	2.0 16v 103kw RFH (06-..)	AUTODETECT
 Relay 2	DASHBOARD	2.0 HDI 16v 100kw RHR (06-..)	AUTODETECT
 Relay 2	DASHBOARD	2.0 HDI 16v 88kw RHG (06-..)	AUTODETECT
 Relay 2	DASHBOARD	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 Relay 2	DASHBOARD	2.2 HDI 16v 74kw 4HV (06-..)	AUTODETECT
 Relay 2	DASHBOARD	2.2 HDI 16v 88kw 4HU (06-..)	AUTODETECT
 Relay 2	DASHBOARD	2.3 HDI 16v 88kw F1AE0481D (06-..)	AUTODETECT
 Relay 2	DASHBOARD	2.3 HDI 16v 95kw F1AE0481N (06-..)	AUTODETECT
 Relay 2	DASHBOARD	3.0 HDI 16v 115kw F1CE0481D (06-..)	AUTODETECT
 Relay 2	ELECTRIC STEERING	1.6 HDI 16v 66kw 9HU (06-..)	AUTODETECT
 Relay 2	ELECTRIC STEERING	2.0 16v 103kw RFH (06-..)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Relay 2	ELECTRIC STEERING	2.0 HDI 16v 100kw RHR (06-..)	AUTODETECT
 Relay 2	ELECTRIC STEERING	2.0 HDI 16v 88kw RHG (06-..)	AUTODETECT
 Relay 2	ELECTRIC STEERING	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 Relay 2	ELECTRIC STEERING	2.2 HDI 16v 74kw 4HV (06-..)	AUTODETECT
 Relay 2	ELECTRIC STEERING	2.2 HDI 16v 88kw 4HU (06-..)	AUTODETECT
 Relay 2	ELECTRIC STEERING	2.3 HDI 16v 88kw F1AE0481D (06-..)	AUTODETECT
 Relay 2	ELECTRIC STEERING	2.3 HDI 16v 95kw F1AE0481N (06-..)	AUTODETECT
 Relay 2	ELECTRIC STEERING	3.0 HDI 16v 115kw F1CE0481D (06-..)	AUTODETECT
 Relay 2	ENGINE MANAGEME	1.6 HDI 16v 66kw 9HU (06-..)	EOBD
 Relay 2	ENGINE MANAGEME	2.0 16v 103kw RFH (06-..)	EOBD
 Relay 2	ENGINE MANAGEME	2.0 HDI 16v 100kw RHR (06-..)	EOBD
 Relay 2	ENGINE MANAGEME	2.0 HDI 16v 88kw RHG (06-..)	EOBD
 Relay 2	ENGINE MANAGEME	2.0 HDI 16v 88kw RHK (06-..)	EOBD
 Relay 2	ENGINE MANAGEME	2.2 HDI 16v 74kw 4HV (06-..)	VISTEON PUMA AUTODETECT
 Relay 2	ENGINE MANAGEME	2.2 HDI 16v 88kw 4HU (06-..)	VISTEON PUMA AUTODETECT
 Relay 2	ENGINE MANAGEME	2.3 HDI 16v 88kw F1AE0481D (06-..)	EOBD
 Relay 2	ENGINE MANAGEME	2.3 HDI 16v 95kw F1AE0481N (06-..)	EOBD
 Relay 2	ENGINE MANAGEME	3.0 HDI 16v 115kw F1CE0481D (06-..)	BOSCH EDC16 C39 Common Rail AUTOD
 Relay 2	MAINTENANCE	1.6 HDI 16v 66kw 9HU (06-..)	AUTODETECT
 Relay 2	MAINTENANCE	1.6 HDI 16v 66kw 9HU (06-..)	BOSCH ESP AUTODETECT
 Relay 2	MAINTENANCE	1.6 HDI 16v 66kw 9HU (06-..)	BOSCH ESP AUTODETECT
 Relay 2	MAINTENANCE	2.0 16v 103kw RFH (06-..)	AUTODETECT
 Relay 2	MAINTENANCE	2.0 16v 103kw RFH (06-..)	BOSCH ESP AUTODETECT
 Relay 2	MAINTENANCE	2.0 16v 103kw RFH (06-..)	BOSCH ESP AUTODETECT
 Relay 2	MAINTENANCE	2.0 HDI 16v 100kw RHR (06-..)	AUTODETECT
 Relay 2	MAINTENANCE	2.0 HDI 16v 100kw RHR (06-..)	BOSCH ESP AUTODETECT
 Relay 2	MAINTENANCE	2.0 HDI 16v 100kw RHR (06-..)	BOSCH ESP AUTODETECT
 Relay 2	MAINTENANCE	2.0 HDI 16v 88kw RHG (06-..)	AUTODETECT
 Relay 2	MAINTENANCE	2.0 HDI 16v 88kw RHG (06-..)	BOSCH ESP AUTODETECT
 Relay 2	MAINTENANCE	2.0 HDI 16v 88kw RHG (06-..)	BOSCH ESP AUTODETECT
 Relay 2	MAINTENANCE	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 Relay 2	MAINTENANCE	2.0 HDI 16v 88kw RHK (06-..)	BOSCH ESP AUTODETECT
 Relay 2	MAINTENANCE	2.0 HDI 16v 88kw RHK (06-..)	BOSCH ESP AUTODETECT
 Relay 2	MAINTENANCE	2.2 HDI 16v 74kw 4HV (06-..)	AUTODETECT
 Relay 2	MAINTENANCE	2.2 HDI 16v 74kw 4HV (06-..)	ESP AUTODETECT
 Relay 2	MAINTENANCE	2.2 HDI 16v 74kw 4HV (06-..)	ESP AUTODETECT
 Relay 2	MAINTENANCE	2.2 HDI 16v 74kw 4HV (06-..)	VISTEON PUMA AUTODETECT
 Relay 2	MAINTENANCE	2.2 HDI 16v 88kw 4HU (06-..)	AUTODETECT
 Relay 2	MAINTENANCE	2.2 HDI 16v 88kw 4HU (06-..)	BOSCH ESP AUTODETECT
 Relay 2	MAINTENANCE	2.2 HDI 16v 88kw 4HU (06-..)	BOSCH ESP AUTODETECT
 Relay 2	MAINTENANCE	2.2 HDI 16v 88kw 4HU (06-..)	VISTEON PUMA AUTODETECT
 Relay 2	MAINTENANCE	2.3 HDI 16v 88kw F1AE0481D (06-..)	AUTODETECT
 Relay 2	MAINTENANCE	2.3 HDI 16v 88kw F1AE0481D (06-..)	BOSCH ESP AUTODETECT
 Relay 2	MAINTENANCE	2.3 HDI 16v 88kw F1AE0481D (06-..)	BOSCH ESP AUTODETECT
 Relay 2	MAINTENANCE	2.3 HDI 16v 95kw F1AE0481N (06-..)	AUTODETECT
 Relay 2	MAINTENANCE	2.3 HDI 16v 95kw F1AE0481N (06-..)	BOSCH ESP AUTODETECT
 Relay 2	MAINTENANCE	2.3 HDI 16v 95kw F1AE0481N (06-..)	BOSCH ESP AUTODETECT
 Relay 2	MAINTENANCE	3.0 HDI 16v 115kw F1CE0481D (06-..)	AUTODETECT
 Relay 2	MAINTENANCE	3.0 HDI 16v 115kw F1CE0481D (06-..)	BOSCH EDC16 C39 Common Rail AUTOD
 Relay 2	MAINTENANCE	3.0 HDI 16v 115kw F1CE0481D (06-..)	BOSCH ESP AUTODETECT
 Relay 2	MAINTENANCE	3.0 HDI 16v 115kw F1CE0481D (06-..)	BOSCH ESP AUTODETECT
 Relay 2	NAVIGATION	1.6 HDI 16v 66kw 9HU (06-..)	AUTODETECT
 Relay 2	NAVIGATION	2.0 16v 103kw RFH (06-..)	AUTODETECT
 Relay 2	NAVIGATION	2.0 HDI 16v 100kw RHR (06-..)	AUTODETECT
 Relay 2	NAVIGATION	2.0 HDI 16v 88kw RHG (06-..)	AUTODETECT
 Relay 2	NAVIGATION	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 Relay 2	NAVIGATION	2.2 HDI 16v 74kw 4HV (06-..)	AUTODETECT
 Relay 2	NAVIGATION	2.2 HDI 16v 88kw 4HU (06-..)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Relay 2	NAVIGATION	2.3 HDI 16v 88kw F1AE0481D (06-..)	AUTODETECT
 Relay 2	NAVIGATION	2.3 HDI 16v 95kw F1AE0481N (06-..)	AUTODETECT
 Relay 2	NAVIGATION	3.0 HDI 16v 115kw F1CE0481D (06-..)	AUTODETECT
 Relay 2	PARKING HELP	1.6 HDI 16v 66kw 9HU (06-..)	AUTODETECT
 Relay 2	PARKING HELP	2.0 16v 103kw RFH (06-..)	AUTODETECT
 Relay 2	PARKING HELP	2.0 HDI 16v 100kw RHR (06-..)	AUTODETECT
 Relay 2	PARKING HELP	2.0 HDI 16v 88kw RHG (06-..)	AUTODETECT
 Relay 2	PARKING HELP	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 Relay 2	PARKING HELP	2.2 HDI 16v 74kw 4HV (06-..)	AUTODETECT
 Relay 2	PARKING HELP	2.2 HDI 16v 88kw 4HU (06-..)	AUTODETECT
 Relay 2	PARKING HELP	2.3 HDI 16v 88kw F1AE0481D (06-..)	AUTODETECT
 Relay 2	PARKING HELP	2.3 HDI 16v 95kw F1AE0481N (06-..)	AUTODETECT
 Relay 2	PARKING HELP	3.0 HDI 16v 115kw F1CE0481D (06-..)	AUTODETECT
 Relay 2	SUSPENSION CONTR	1.6 HDI 16v 66kw 9HU (06-..)	AUTODETECT
 Relay 2	SUSPENSION CONTR	2.0 16v 103kw RFH (06-..)	AUTODETECT
 Relay 2	SUSPENSION CONTR	2.0 HDI 16v 100kw RHR (06-..)	AUTODETECT
 Relay 2	SUSPENSION CONTR	2.0 HDI 16v 88kw RHG (06-..)	AUTODETECT
 Relay 2	SUSPENSION CONTR	2.0 HDI 16v 88kw RHK (06-..)	AUTODETECT
 Relay 2	SUSPENSION CONTR	2.2 HDI 16v 74kw 4HV (06-..)	AUTODETECT
 Relay 2	SUSPENSION CONTR	2.2 HDI 16v 88kw 4HU (06-..)	AUTODETECT
 Relay 2	SUSPENSION CONTR	2.3 HDI 16v 88kw F1AE0481D (06-..)	AUTODETECT
 Relay 2	SUSPENSION CONTR	2.3 HDI 16v 95kw F1AE0481N (06-..)	AUTODETECT
 Relay 2	SUSPENSION CONTR	3.0 HDI 16v 115kw F1CE0481D (06-..)	AUTODETECT
 Saxo	ABS	1.0 8v 33 kw CDY	ATE Teves ABS Mk20 E
 Saxo	ABS	1.0 8v 33 kw CDZ	ATE Teves ABS Mk20 E
 Saxo	ABS	1.1 8v 40kw HDY	ATE Teves ABS Mk20 E
 Saxo	ABS	1.1 8v 43kw HDZ	ATE Teves ABS Mk20 E
 Saxo	ABS	1.1 8v 44kw HFX	ATE Teves ABS Mk20 E
 Saxo	ABS	1.4 8v 55kw KFW	ATE Teves ABS Mk20 E
 Saxo	ABS	1.4 8v 55kw KFX	ATE Teves ABS Mk20 E
 Saxo	ABS	1.6 16v 88kw NFX	ATE Teves ABS Mk20 E
 Saxo	ABS	1.6 8v 66kw NFZ	ATE Teves ABS Mk20 E
 Saxo	ABS	1.6 8v 74kw NFT	ATE Teves ABS Mk20 E
 Saxo	AIRBAG	1.0 8v 33 kw CDY (97-00)	AKF- Autoliv AirBag no SIDE AB
 Saxo	AIRBAG	1.0 8v 33 kw CDZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 Saxo	AIRBAG	1.1 8v 40kw HDY (97-00)	AKF- Autoliv AirBag no SIDE AB
 Saxo	AIRBAG	1.1 8v 43kw HDZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 Saxo	AIRBAG	1.1 8v 44kw HFX (97-00)	AKF- Autoliv AirBag no SIDE AB
 Saxo	AIRBAG	1.4 8v 55kw KFW (97-00)	AKF- Autoliv AirBag no SIDE AB
 Saxo	AIRBAG	1.4 8v 55kw KFX (97-00)	AKF- Autoliv AirBag no SIDE AB
 Saxo	AIRBAG	1.6 16v 88kw NFX (97-00)	AKF- Autoliv AirBag no SIDE AB
 Saxo	AIRBAG	1.6 8v 66kw NFZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 Saxo	ENGINE MANAGEME	1.0 8v 33 kw CDZ	BOSCH MonoMotronic MA3.1
 Saxo	ENGINE MANAGEME	1.1 8v 40kw HDY	BOSCH MonoMotronic MA3.1
 Saxo	ENGINE MANAGEME	1.1 8v 43kw HDZ	BOSCH MonoMotronic MA3.1
 Saxo	ENGINE MANAGEME	1.1 8v 44kw HFX	BOSCH M 7.4.4 AUTODETECT
 Saxo	ENGINE MANAGEME	1.4 8v 55kw KFW	SAGEM S2000 AUTODETECT
 Saxo	ENGINE MANAGEME	1.4 8v 55kw KFX	Marelli MM 1AP.40
 Saxo	ENGINE MANAGEME	1.5 D 8v 43kw VJX	BOSCH EDC VP20
 Saxo	ENGINE MANAGEME	1.5 D 8v 43kw VJY	BOSCH EDC VP20
 Saxo	ENGINE MANAGEME	1.5 D 8v 43kw VJZ	BOSCH EDC VP20
 Saxo	ENGINE MANAGEME	1.6 16v 88kw NFX	Marelli MM 1AP.41
 Saxo	ENGINE MANAGEME	1.6 16v 88kw NFX	Marelli MM48P AUTODETECT
 Saxo	ENGINE MANAGEME	1.6 8v 66kw NFZ	BOSCH Motronic MP5.2
 Saxo	ENGINE MANAGEME	1.6 8v 66kw NFZ	BOSCH Motronic MP7.2
 Saxo	ENGINE MANAGEME	1.6 8v 74kw NFT	BOSCH M 7.4.4 AUTODETECT
 Saxo	MAINTENANCE	1.0 8v 33 kw CDY (98-00)	Sagem MANUAL
 Saxo	MAINTENANCE	1.1 8v 40kw HDY (98-00)	Sagem MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Saxo	MAINTENANCE	1.1 8v 43kw HDZ (98-00)	Sagem MANUAL
 Saxo	MAINTENANCE	1.1 8v 44kw HFX (98-00)	Sagem MANUAL
 Saxo	MAINTENANCE	1.4 8v 55kw KFW (98-00)	Sagem MANUAL
 Saxo	MAINTENANCE	1.4 8v 55kw KFX (98-00)	Sagem MANUAL
 Saxo	MAINTENANCE	1.5 D 8v 43kw VJX (98-00)	Sagem MANUAL
 Saxo	MAINTENANCE	1.5 D 8v 43kw VJY (98-00)	Sagem MANUAL
 Saxo	MAINTENANCE	1.5 D 8v 43kw VJZ (98-00)	Sagem MANUAL
 Saxo	MAINTENANCE	1.6 16v 88kw NFX (98-00)	Sagem MANUAL
 Saxo	MAINTENANCE	1.6 8v 66kw NFZ (98-00)	Sagem MANUAL
 Saxo	SERVICE LIGHT RES	1.0 8v 33 kw CDY (98-00)	Sagem MANUAL
 Saxo	SERVICE LIGHT RES	1.1 8v 40kw HDY (98-00)	Sagem MANUAL
 Saxo	SERVICE LIGHT RES	1.1 8v 43kw HDZ (98-00)	Sagem MANUAL
 Saxo	SERVICE LIGHT RES	1.1 8v 44kw HFX (98-00)	Sagem MANUAL
 Saxo	SERVICE LIGHT RES	1.4 8v 55kw KFW (98-00)	Sagem MANUAL
 Saxo	SERVICE LIGHT RES	1.4 8v 55kw KFX (98-00)	Sagem MANUAL
 Saxo	SERVICE LIGHT RES	1.5 D 8v 43kw VJX (98-00)	Sagem MANUAL
 Saxo	SERVICE LIGHT RES	1.5 D 8v 43kw VJY (98-00)	Sagem MANUAL
 Saxo	SERVICE LIGHT RES	1.5 D 8v 43kw VJZ (98-00)	Sagem MANUAL
 Saxo	SERVICE LIGHT RES	1.6 16v 88kw NFX (98-00)	Sagem MANUAL
 Saxo	SERVICE LIGHT RES	1.6 8v 66kw NFZ (98-00)	Sagem MANUAL
 Xantia (93-98)	ABS	1.6 8v 65kw BFZ	ATE Teves ABS Mk20 E
 Xantia (93-98)	ABS	1.8 8v 74kw L6A	ATE Teves ABS Mk20 E
 Xantia (93-98)	ABS	1.8 8v 74kw LFZ	ATE Teves ABS Mk20 E
 Xantia (93-98)	ABS	1.9 TD 8v 66kw D8B	ATE Teves ABS Mk20 E
 Xantia (93-98)	ABS	1.9 TD 8v 66kw DHX	ATE Teves ABS Mk20 E
 Xantia (93-98)	ABS	1.9D 8v 50kw DJY	ATE Teves Mk20 E
 Xantia (93-98)	ABS	1.9D 8v 52kw D9B	ATE Teves Mk20 E
 Xantia (93-98)	ABS	2.0 16v 110kw RFT	ATE Teves Mk20 E
 Xantia (93-98)	ABS	2.0 16v 111kw RFY	ATE Teves Mk20 E
 Xantia (93-98)	ABS	2.0 16v 97kw RFV	ATE Teves Mk20 E
 Xantia (93-98)	ABS	2.0 8v 90kw RFX	ATE Teves Mk20 E
 Xantia (93-98)	ABS	2.0T 8v 108kw RGX	ATE Teves ABS Mk20 E
 Xantia (93-98)	ABS	2.1 TD 12v 81kw P8C	ATE Teves ABS Mk20 E
 Xantia (93-98)	AIRBAG	1.6 8v 65kw BFZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xantia (93-98)	AIRBAG	1.8 8v 74kw L6A (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xantia (93-98)	AIRBAG	1.8 8v 74kw LFZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xantia (93-98)	AIRBAG	1.9 TD 8v 66kw D8B (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xantia (93-98)	AIRBAG	1.9 TD 8v 66kw DHX (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xantia (93-98)	AIRBAG	1.9D 8v 50kw DJY (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xantia (93-98)	AIRBAG	1.9D 8v 52kw D9B (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xantia (93-98)	AIRBAG	2.0 16v 110kw RFT (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xantia (93-98)	AIRBAG	2.0 16v 111kw RFY (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xantia (93-98)	AIRBAG	2.0 16v 97kw RFV (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xantia (93-98)	AIRBAG	2.0 8v 90kw RFX (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xantia (93-98)	AIRBAG	2.0T 8v 108kw RGX (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xantia (93-98)	AIRBAG	2.1 TD 12v 81kw P8C (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xantia (93-98)	DIESEL MANAGEME	1.9 TD 8v 66kw D8B	BOSCH AS3 VP20
 Xantia (93-98)	DIESEL MANAGEME	1.9 TD 8v 66kw DHX	BOSCH AS3 VP20
 Xantia (93-98)	ENGINE MANAGEME	1.6 8v 65kw BFZ	Marelli MM 8P [Slow]
 Xantia (93-98)	ENGINE MANAGEME	1.6 8v 65kw BFZ	Marelli MM 8P.13 [Fast]
 Xantia (93-98)	ENGINE MANAGEME	1.8 8v 74kw L6A	Marelli MM 8P [Fast]
 Xantia (93-98)	ENGINE MANAGEME	1.8 8v 74kw LFZ	BOSCH Motronic MP5.1 [Slow]
 Xantia (93-98)	ENGINE MANAGEME	1.8 8v 74kw LFZ	Marelli MM 8P.10 [Fast]
 Xantia (93-98)	ENGINE MANAGEME	2.0 16v 110kw RFT	BOSCH Motronic MP3.2 [Slow]
 Xantia (93-98)	ENGINE MANAGEME	2.0 16v 111kw RFY	BOSCH Motronic MP3.2 [Slow]
 Xantia (93-98)	ENGINE MANAGEME	2.0 16v 97kw RFV	BOSCH Motronic MP5.1.1 [Fast]
 Xantia (93-98)	ENGINE MANAGEME	2.0 8v 90kw RFX	Marelli MM 8P [Slow]
 Xantia (93-98)	ENGINE MANAGEME	2.0 8v 90kw RFX	Marelli MM 8P.20 [Fast]

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Xantia (93-98)	ENGINE MANAGEME	2.0T 8v 108kw RGX	BOSCH Motronic MP3.2 [Fast]
 Xantia (93-98)	ENGINE MANAGEME	2.0T 8v 108kw RGX	BOSCH Motronic MP3.2 [Slow]
 Xantia (93-98)	ENGINE MANAGEME	2.1 TD 12v 81kw P8C	LUCAS Diesel EPIC
 Xantia Restyling (97-01)	ABS	1.6 8v 65kw BFZ	ATE Teves ABS Mk20 E
 Xantia Restyling (97-01)	ABS	1.8 16v 81kw LFY	ATE Teves ABS Mk20 E
 Xantia Restyling (97-01)	ABS	1.9 TD 8v 55kw DHW	ATE Teves ABS Mk20 E
 Xantia Restyling (97-01)	ABS	1.9 TD 8v 66kw DHX	ATE Teves ABS Mk20 E
 Xantia Restyling (97-01)	ABS	2.0 16v 97kw RFV	ATE Teves ABS Mk20 E
 Xantia Restyling (97-01)	ABS	2.0 8v 90kw RFX	ATE Teves ABS Mk20 E
 Xantia Restyling (97-01)	ABS	2.0 HDI 8v 66kw RHY	ATE Teves ABS Mk20 E
 Xantia Restyling (97-01)	ABS	2.0 HDI 8v 81kw RHZ	ATE Teves ABS Mk20 E
 Xantia Restyling (97-01)	ABS	2.0T 8v 108kw RGX	ATE Teves ABS Mk20 E
 Xantia Restyling (97-01)	ABS	2.1 TD 12v 81kw P8C	ATE Teves ABS Mk20 E
 Xantia Restyling (97-01)	ABS	3.0 V6 24v 143kw XFZ	ATE Teves ABS Mk20 E
 Xantia Restyling (97-01)	AIRBAG	1.6 8v 65kw BFZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xantia Restyling (97-01)	AIRBAG	1.8 16v 81kw LFY (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xantia Restyling (97-01)	AIRBAG	1.9 TD 8v 55kw DHW (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xantia Restyling (97-01)	AIRBAG	1.9 TD 8v 66kw DHX (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xantia Restyling (97-01)	AIRBAG	2.0 16v 97kw RFV (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xantia Restyling (97-01)	AIRBAG	2.0 8v 90kw RFX (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xantia Restyling (97-01)	AIRBAG	2.0 HDI 8v 66kw RHY (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xantia Restyling (97-01)	AIRBAG	2.0 HDI 8v 81kw RHZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xantia Restyling (97-01)	AIRBAG	2.0T 8v 108kw RGX (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xantia Restyling (97-01)	AIRBAG	2.1 TD 12v 81kw P8C (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xantia Restyling (97-01)	AIRBAG	3.0 V6 24v 143kw XFZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xantia Restyling (97-01)	AUX. HEATING	1.6 8v 65kw BFZ	AUTODETECT
 Xantia Restyling (97-01)	AUX. HEATING	1.8 16v 81kw LFY	AUTODETECT
 Xantia Restyling (97-01)	AUX. HEATING	1.9 TD 8v 55kw DHW	AUTODETECT
 Xantia Restyling (97-01)	AUX. HEATING	1.9 TD 8v 66kw DHX	AUTODETECT
 Xantia Restyling (97-01)	AUX. HEATING	2.0 16v 97kw RFV	AUTODETECT
 Xantia Restyling (97-01)	AUX. HEATING	2.0 8v 90kw RFX	AUTODETECT
 Xantia Restyling (97-01)	AUX. HEATING	2.0 HDI 8v 66kw RHY	AUTODETECT
 Xantia Restyling (97-01)	AUX. HEATING	2.0 HDI 8v 81kw RHZ	AUTODETECT
 Xantia Restyling (97-01)	AUX. HEATING	2.0T 8v 108kw RGX	AUTODETECT
 Xantia Restyling (97-01)	AUX. HEATING	2.1 TD 12v 81kw P8C	AUTODETECT
 Xantia Restyling (97-01)	AUX. HEATING	3.0 V6 24v 143kw XFZ	AUTODETECT
 Xantia Restyling (97-01)	ENGINE MANAGEME	1.6 8v 65kw BFZ	EOBD
 Xantia Restyling (97-01)	ENGINE MANAGEME	1.8 16v 81kw LFY	BOSCH Motronic MP5.1.1 [Fast]
 Xantia Restyling (97-01)	ENGINE MANAGEME	1.8 16v 81kw LFY	BOSCH Motronic MP5.1.1 [Slow]
 Xantia Restyling (97-01)	ENGINE MANAGEME	1.8 16v 81kw LFY	SAGEM SL 96
 Xantia Restyling (97-01)	ENGINE MANAGEME	2.0 16v 97kw RFV	EOBD
 Xantia Restyling (97-01)	ENGINE MANAGEME	2.0 8v 90kw RFX	EOBD
 Xantia Restyling (97-01)	ENGINE MANAGEME	2.0 HDI 8v 66kw RHY	BOSCH EDC15 C2 Common Rail AUTODE
 Xantia Restyling (97-01)	ENGINE MANAGEME	2.0 HDI 8v 66kw RHY (...00)	BOSCH EDC 15 C2 Common Rail
 Xantia Restyling (97-01)	ENGINE MANAGEME	2.0 HDI 8v 81kw RHZ	BOSCH EDC15 C2 Common Rail AUTODE
 Xantia Restyling (97-01)	ENGINE MANAGEME	2.0 HDI 8v 81kw RHZ (...00)	BOSCH EDC 15 C2 Common Rail
 Xantia Restyling (97-01)	ENGINE MANAGEME	2.0T 8v 108kw RGX	EOBD
 Xantia Restyling (97-01)	MAINTENANCE	2.0 HDI 8v 66kw RHY	BOSCH EDC15 C2 Common Rail AUTODE
 Xantia Restyling (97-01)	MAINTENANCE	2.0 HDI 8v 81kw RHZ	BOSCH EDC15 C2 Common Rail AUTODE
 XM	ABS	2.0 16v 97kw RFV (...00)	ATE Teves ABS Mk20 E
 XM	ABS	2.0 8v 82kw RDZ (...00)	ATE Teves ABS Mk20 E
 XM	ABS	2.0 8v 85kw R2A (...00)	ATE Teves ABS Mk20 E
 XM	ABS	2.0 8v 90kw RFZ (...00)	ATE Teves ABS Mk20 E
 XM	ABS	2.0 8v 94kw R6A (...00)	ATE Teves ABS Mk20 E
 XM	ABS	2.0T 8v 107kw RGY (...00)	ATE Teves ABS Mk20 E
 XM	ABS	2.0T 8v 108kw RGX (...00)	ATE Teves ABS Mk20 E
 XM	ABS	2.1 D 12V 61kw P9A (...00)	ATE Teves ABS Mk20 E
 XM	ABS	2.1 D 12V 61kw PJZ (...00)	ATE Teves ABS Mk20 E

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 XM	ABS	2.1 TD 12V 80kw PHZ (...00)	ATE Teves ABS Mk20 E
 XM	ABS	2.1 TD 12v 81kw P8A (...00)	ATE Teves ABS Mk20 E
 XM	ABS	2.1 TD 12v 81kw P8B (...00)	ATE Teves ABS Mk20 E
 XM	ABS	2.1 TD 12v 81kw P8C (...00)	ATE Teves ABS Mk20 E
 XM	ABS	2.1 TD 12v 81kw PHZ (...00)	ATE Teves ABS Mk20 E
 XM	ABS	2.5 TD 12v 94kw THY (...00)	ATE Teves ABS Mk20 E
 XM	ABS	3.0 V6 12v 123kw S6A (...00)	ATE Teves ABS Mk20 E
 XM	ABS	3.0 V6 12v 123kw SFZ (...00)	ATE Teves ABS Mk20 E
 XM	ABS	3.0 V6 12v 123kw UFZ (...00)	ATE Teves ABS Mk20 E
 XM	ABS	3.0 V6 24v 143kw XFZ (...00)	ATE Teves ABS Mk20 E
 XM	ABS	3.0 V6 24v 147kw SKZ (...00)	ATE Teves ABS Mk20 E
 XM	ABS	3.0 V6 24v 147kw UKZ (...00)	ATE Teves ABS Mk20 E
 XM	DIESEL MANAGEMEN	2.5 TD 12v 94kw THY (94-..)	BOSCH MSA11 VP36
 XM	ENGINE MANAGEME	2.0 16v 97kw RFV (94-..)	BOSCH Motronic MP5.1.1 [Fast]
 XM	ENGINE MANAGEME	2.0 16v 97kw RFV (94-..)	BOSCH Motronic MP5.2
 XM	ENGINE MANAGEME	2.0 8v 90kw RFZ (...93)	BOSCH Motronic MP3.1 [Slow]
 XM	ENGINE MANAGEME	2.0 8v 94kw R6A (...93)	Marelli MMBA G5 [Slow]
 XM	ENGINE MANAGEME	2.0T 8v 107kw RGY (...93)	BOSCH Motronic MP3.2 [Slow]
 XM	ENGINE MANAGEME	2.0T 8v 107kw RGY (94-..)	BOSCH Motronic MP3.2 [Fast]
 XM	ENGINE MANAGEME	2.0T 8v 108kw RGX (94-..)	BOSCH Motronic MP3.2 [Fast]
 XM	ENGINE MANAGEME	2.1 TD 12v 81kw P8C (94-..)	LUCAS Diesel EPIC
 XM	ENGINE MANAGEME	3.0 V6 12v 123kw SFZ (...93)	BENDIX FENIX 3B [Slow]
 XM	ENGINE MANAGEME	3.0 V6 24v 147kw SKZ (...93)	BENDIX FENIX 4 [Slow]
 XM	MAINTENANCE	2.5 TD 12v 94kw THY (94-..)	BOSCH MSA11 VP36
 Xsara Picasso China	ABS + TRACT. CONT	1.6 16v 80kw N6A	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso China	ABS + TRACT. CONT	1.6 16v 80kw N6A	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso China	ABS + TRACT. CONT	1.6 16v 80kw N6A	BOSCH ESP 8.0 AUTODETECT
 Xsara Picasso China	ABS + TRACT. CONT	1.6 16v 80kw NFU	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso China	ABS + TRACT. CONT	1.6 16v 80kw NFU	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso China	ABS + TRACT. CONT	1.6 16v 80kw NFU	BOSCH ESP 8.0 AUTODETECT
 Xsara Picasso China	ABS + TRACT. CONT	1.6 8v 70kw NFV	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso China	ABS + TRACT. CONT	1.6 8v 70kw NFV	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso China	ABS + TRACT. CONT	1.6 8v 70kw NFV	BOSCH ESP 8.0 AUTODETECT
 Xsara Picasso China	ABS + TRACT. CONT	1.8 16v 86kw 6FZ	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso China	ABS + TRACT. CONT	1.8 16v 86kw 6FZ	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso China	ABS + TRACT. CONT	1.8 16v 86kw 6FZ	BOSCH ESP 8.0 AUTODETECT
 Xsara Picasso China	ABS + TRACT. CONT	2.0 16v 101kw RFN	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso China	ABS + TRACT. CONT	2.0 16v 101kw RFN	BOSCH ESP 8.0 AUTODETECT
 Xsara Picasso China	AIRBAG	1.6 16v 80kw N6A	Temic AirBag CENTRAL AUTODETECT
 Xsara Picasso China	AIRBAG	1.6 16v 80kw NFU	Temic AirBag CENTRAL AUTODETECT
 Xsara Picasso China	AIRBAG	1.6 8v 70kw NFV	Temic AirBag CENTRAL AUTODETECT
 Xsara Picasso China	AIRBAG	1.8 16v 86kw 6FZ	Temic AirBag CENTRAL AUTODETECT
 Xsara Picasso China	AIRBAG	2.0 16v 101kw RFN	Temic AirBag CENTRAL AUTODETECT
 Xsara Picasso China	ANTITHEFT	1.6 16v 80kw N6A	Alarm PSA2 AUTODETECT
 Xsara Picasso China	ANTITHEFT	1.6 16v 80kw NFU	Alarm PSA2 AUTODETECT
 Xsara Picasso China	ANTITHEFT	1.6 8v 70kw NFV	Alarm PSA2 AUTODETECT
 Xsara Picasso China	ANTITHEFT	1.8 16v 86kw 6FZ	Alarm PSA2 AUTODETECT
 Xsara Picasso China	ANTITHEFT	2.0 16v 101kw RFN	Alarm PSA2 AUTODETECT
 Xsara Picasso China	AUTOM. TRANSMISSI	1.6 16v 80kw N6A	A/T AL4 AUTODETECT
 Xsara Picasso China	AUTOM. TRANSMISSI	1.6 16v 80kw NFU	A/T AL4 AUTODETECT
 Xsara Picasso China	AUTOM. TRANSMISSI	1.6 8v 70kw NFV	A/T AL4 AUTODETECT
 Xsara Picasso China	AUTOM. TRANSMISSI	1.8 16v 86kw 6FZ	A/T AL4 AUTODETECT
 Xsara Picasso China	AUTOM. TRANSMISSI	2.0 16v 101kw RFN	A/T AL4 AUTODETECT
 Xsara Picasso China	CHASSIS NETWORK	1.6 16v 80kw N6A	Body Computer BSI AUTODETECT
 Xsara Picasso China	CHASSIS NETWORK	1.6 16v 80kw NFU	Body Computer BSI AUTODETECT
 Xsara Picasso China	CHASSIS NETWORK	1.6 8v 70kw NFV	Body Computer BSI AUTODETECT
 Xsara Picasso China	CHASSIS NETWORK	1.8 16v 86kw 6FZ	Body Computer BSI AUTODETECT
 Xsara Picasso China	CHASSIS NETWORK	2.0 16v 101kw RFN	Body Computer BSI AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Xsara Picasso China	CLIMA	1.6 16v 80kw N6A	CLIMA AUTODETECT
 Xsara Picasso China	CLIMA	1.6 16v 80kw NFU	CLIMA AUTODETECT
 Xsara Picasso China	CLIMA	1.6 8v 70kw NFV	CLIMA AUTODETECT
 Xsara Picasso China	CLIMA	1.8 16v 86kw 6FZ	CLIMA AUTODETECT
 Xsara Picasso China	CLIMA	2.0 16v 101kw RFN	CLIMA AUTODETECT
 Xsara Picasso China	DASHBOARD	1.6 16v 80kw N6A	AUTODETECT
 Xsara Picasso China	DASHBOARD	1.6 16v 80kw NFU	AUTODETECT
 Xsara Picasso China	DASHBOARD	1.6 8v 70kw NFV	AUTODETECT
 Xsara Picasso China	DASHBOARD	1.8 16v 86kw 6FZ	AUTODETECT
 Xsara Picasso China	DASHBOARD	2.0 16v 101kw RFN	AUTODETECT
 Xsara Picasso China	ENGINE MANAGEME	1.6 16v 80kw N6A	BOSCH ME 7.4.5 AUTODETECT
 Xsara Picasso China	ENGINE MANAGEME	1.6 16v 80kw N6A	BOSCH ME 7.4.9 AUTODETECT
 Xsara Picasso China	ENGINE MANAGEME	1.6 16v 80kw NFU	BOSCH ME 7.4.5 AUTODETECT
 Xsara Picasso China	ENGINE MANAGEME	1.6 8v 70kw NFV	BOSCH M 7.4.4 AUTODETECT
 Xsara Picasso China	ENGINE MANAGEME	1.8 16v 86kw 6FZ	SAGEM S2000 AUTODETECT
 Xsara Picasso China	ENGINE MANAGEME	2.0 16v 101kw RFN	Marelli MM6LP AUTODETECT
 Xsara Picasso China	MAINTENANCE	1.6 16v 80kw N6A	A/T AL4 AUTODETECT
 Xsara Picasso China	MAINTENANCE	1.6 16v 80kw N6A	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso China	MAINTENANCE	1.6 16v 80kw N6A	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso China	MAINTENANCE	1.6 16v 80kw N6A	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso China	MAINTENANCE	1.6 16v 80kw N6A	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso China	MAINTENANCE	1.6 16v 80kw NFU	A/T AL4 AUTODETECT
 Xsara Picasso China	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso China	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso China	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso China	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso China	MAINTENANCE	1.6 8v 70kw NFV	A/T AL4 AUTODETECT
 Xsara Picasso China	MAINTENANCE	1.6 8v 70kw NFV	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso China	MAINTENANCE	1.6 8v 70kw NFV	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso China	MAINTENANCE	1.6 8v 70kw NFV	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso China	MAINTENANCE	1.6 8v 70kw NFV	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso China	MAINTENANCE	1.8 16v 86kw 6FZ	A/T AL4 AUTODETECT
 Xsara Picasso China	MAINTENANCE	1.8 16v 86kw 6FZ	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso China	MAINTENANCE	1.8 16v 86kw 6FZ	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso China	MAINTENANCE	1.8 16v 86kw 6FZ	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso China	MAINTENANCE	1.8 16v 86kw 6FZ	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso China	MAINTENANCE	2.0 16v 101kw RFN	A/T AL4 AUTODETECT
 Xsara Picasso China	MAINTENANCE	2.0 16v 101kw RFN	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso China	MAINTENANCE	2.0 16v 101kw RFN	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso China	NAVIGATION	1.6 16v 80kw N6A	AUTODETECT
 Xsara Picasso China	NAVIGATION	1.6 16v 80kw NFU	AUTODETECT
 Xsara Picasso China	NAVIGATION	1.6 8v 70kw NFV	AUTODETECT
 Xsara Picasso China	NAVIGATION	1.8 16v 86kw 6FZ	AUTODETECT
 Xsara Picasso China	NAVIGATION	2.0 16v 101kw RFN	AUTODETECT
 Xsara Picasso China	PARKING HELP	1.6 16v 80kw N6A	AUTODETECT
 Xsara Picasso China	PARKING HELP	1.6 16v 80kw NFU	AUTODETECT
 Xsara Picasso China	PARKING HELP	1.6 8v 70kw NFV	AUTODETECT
 Xsara Picasso China	PARKING HELP	1.8 16v 86kw 6FZ	AUTODETECT
 Xsara Picasso China	PARKING HELP	2.0 16v 101kw RFN	AUTODETECT
 Xsara Picasso China	RADIO / CD	1.6 16v 80kw N6A	AudioSystem AUTODETECT
 Xsara Picasso China	RADIO / CD	1.6 16v 80kw N6A	CD Changer AUTODETECT
 Xsara Picasso China	RADIO / CD	1.6 16v 80kw NFU	AudioSystem AUTODETECT
 Xsara Picasso China	RADIO / CD	1.6 16v 80kw NFU	CD Changer AUTODETECT
 Xsara Picasso China	RADIO / CD	1.6 8v 70kw NFV	AudioSystem AUTODETECT
 Xsara Picasso China	RADIO / CD	1.6 8v 70kw NFV	CD Changer AUTODETECT
 Xsara Picasso China	RADIO / CD	1.8 16v 86kw 6FZ	AudioSystem AUTODETECT
 Xsara Picasso China	RADIO / CD	1.8 16v 86kw 6FZ	CD Changer AUTODETECT
 Xsara Picasso China	RADIO / CD	2.0 16v 101kw RFN	AudioSystem AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Xsara Picasso China	RADIO / CD	2.0 16v 101kw RFN	CD Changer AUTODETECT
 Xsara Picasso China	RAIN-LUMINOSITY S	1.6 16v 80kw N6A	AUTODETECT
 Xsara Picasso China	RAIN-LUMINOSITY S	1.6 16v 80kw NFU	AUTODETECT
 Xsara Picasso China	RAIN-LUMINOSITY S	1.6 8v 70kw NFV	AUTODETECT
 Xsara Picasso China	RAIN-LUMINOSITY S	1.8 16v 82kw 6FZ	AUTODETECT
 Xsara Picasso China	RAIN-LUMINOSITY S	2.0 16v 101kw RFN	AUTODETECT
 Xsara Picasso China	STEERING COLUMN	1.6 16v 80kw N6A	AUTODETECT
 Xsara Picasso China	STEERING COLUMN	1.6 16v 80kw NFU	AUTODETECT
 Xsara Picasso China	STEERING COLUMN	1.6 8v 70kw NFV	AUTODETECT
 Xsara Picasso China	STEERING COLUMN	1.8 16v 86kw 6FZ	AUTODETECT
 Xsara Picasso China	STEERING COLUMN	2.0 16v 101kw RFN	AUTODETECT
 Xsara Picasso China	VISUAL./TELEMATIC	1.6 16v 80kw N6A	Display AUTODETECT
 Xsara Picasso China	VISUAL./TELEMATIC	1.6 16v 80kw NFU	Display AUTODETECT
 Xsara Picasso China	VISUAL./TELEMATIC	1.6 8v 70kw NFV	Display AUTODETECT
 Xsara Picasso China	VISUAL./TELEMATIC	1.8 16v 86kw 6FZ	Display AUTODETECT
 Xsara Picasso China	VISUAL./TELEMATIC	2.0 16v 101kw RFN	Display AUTODETECT
 Xsara Picasso	ABS	1.6 16v 80kw N6A	BOSCH ABS ABR 5.3
 Xsara Picasso	ABS	1.6 16v 80kw NFU	BOSCH ABS ABR 5.3
 Xsara Picasso	ABS	1.6 8v 66kw NFZ	BOSCH ABS ABR 5.3
 Xsara Picasso	ABS	1.6 8v 70kw NFV	BOSCH ABS ABR 5.3
 Xsara Picasso	ABS	1.6 HDI 16v 66kw 9HX	BOSCH ABS ABR 5.3
 Xsara Picasso	ABS	1.6 HDI 16v 80kw 9HY	BOSCH ABS ABR 5.3
 Xsara Picasso	ABS	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ABS ABR 5.3
 Xsara Picasso	ABS	1.8 16v 86kw 6FZ	BOSCH ABS ABR 5.3
 Xsara Picasso	ABS	2.0 16v 101kw RFN	BOSCH ABS ABR 5.3
 Xsara Picasso	ABS	2.0 16v 85kw RFM	BOSCH ABS ABR 5.3
 Xsara Picasso	ABS	2.0 HDI 8v 66kw RHY	BOSCH ABS ABR 5.3
 Xsara Picasso	ABS + TRACT. CONT	1.6 16v 80kw N6A	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 16v 80kw N6A	BOSCH ABS 8.1 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 16v 80kw N6A	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 16v 80kw N6A	BOSCH ESP 8.0 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 16v 80kw N6A	BOSCH ESP 8.1 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 16v 80kw NFU	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 16v 80kw NFU	BOSCH ABS 8.1 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 16v 80kw NFU	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 16v 80kw NFU	BOSCH ESP 8.0 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 16v 80kw NFU	BOSCH ESP 8.1 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 16v 80kw NFU (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	ABS + TRACT. CONT	1.6 8v 66kw NFZ	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 8v 66kw NFZ	BOSCH ABS 8.1 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 8v 66kw NFZ	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 8v 66kw NFZ	BOSCH ESP 8.0 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 8v 66kw NFZ	BOSCH ESP 8.1 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 8v 70kw NFV	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 8v 70kw NFV	BOSCH ABS 8.1 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 8v 70kw NFV	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 8v 70kw NFV	BOSCH ESP 8.0 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 8v 70kw NFV	BOSCH ESP 8.1 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX	BOSCH ABS 8.1 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX	BOSCH ESP 8.0 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX	BOSCH ESP 8.1 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HY	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HY	BOSCH ABS 8.1 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HY	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HY	BOSCH ESP 8.0 AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Xsara Picasso	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HY	BOSCH ESP 8.1 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HY (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ABS 8.1 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ESP 8.0 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ESP 8.1 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	ABS + TRACT. CONT	1.8 16v 82kw 6FZ	ESP 5.7 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.8 16v 86kw 6FZ	ABS 8.0 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.8 16v 86kw 6FZ	ABS 8.1 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.8 16v 86kw 6FZ	ESP 8.0 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.8 16v 86kw 6FZ	ESP 8.1 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	1.8 16v 86kw 6FZ (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	ABS + TRACT. CONT	2.0 16v 101kw RFN	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	2.0 16v 101kw RFN	BOSCH ABS 8.1 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	2.0 16v 101kw RFN	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	2.0 16v 101kw RFN	BOSCH ESP 8.0 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	2.0 16v 101kw RFN	BOSCH ESP 8.1 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	2.0 16v 85kw RFM	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	2.0 16v 85kw RFM	BOSCH ABS 8.1 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	2.0 16v 85kw RFM	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	2.0 16v 85kw RFM	BOSCH ESP 8.0 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	2.0 16v 85kw RFM	BOSCH ESP 8.1 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	2.0 HDI 8v 66kw RHY	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	2.0 HDI 8v 66kw RHY	BOSCH ABS 8.1 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	2.0 HDI 8v 66kw RHY	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	2.0 HDI 8v 66kw RHY	BOSCH ESP 8.0 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	2.0 HDI 8v 66kw RHY	BOSCH ESP 8.1 AUTODETECT
 Xsara Picasso	ABS + TRACT. CONT	2.0 HDI 8v 66kw RHY (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	AIRBAG	1.6 16v 80kw N6A	AUTOLIV AirBag CENTRAL ACU AUTODE
 Xsara Picasso	AIRBAG	1.6 16v 80kw N6A	Temic AirBag CENTRAL AUTODETECT
 Xsara Picasso	AIRBAG	1.6 16v 80kw N6A (03-..)	AKF- Autoliv AirBag ACU3
 Xsara Picasso	AIRBAG	1.6 16v 80kw N6A (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xsara Picasso	AIRBAG	1.6 16v 80kw NFU	AUTOLIV AirBag CENTRAL ACU AUTODE
 Xsara Picasso	AIRBAG	1.6 16v 80kw NFU	Temic AirBag CENTRAL AUTODETECT
 Xsara Picasso	AIRBAG	1.6 16v 80kw NFU (03-..)	AKF- Autoliv AirBag ACU3
 Xsara Picasso	AIRBAG	1.6 16v 80kw NFU (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xsara Picasso	AIRBAG	1.6 8v 66kw NFZ	AUTOLIV AirBag CENTRAL ACU AUTODE
 Xsara Picasso	AIRBAG	1.6 8v 66kw NFZ	Temic AirBag CENTRAL AUTODETECT
 Xsara Picasso	AIRBAG	1.6 8v 66kw NFZ (03-..)	AKF- Autoliv AirBag ACU3
 Xsara Picasso	AIRBAG	1.6 8v 66kw NFZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xsara Picasso	AIRBAG	1.6 8v 70kw NFV	AUTOLIV AirBag CENTRAL ACU AUTODE
 Xsara Picasso	AIRBAG	1.6 8v 70kw NFV	Temic AirBag CENTRAL AUTODETECT
 Xsara Picasso	AIRBAG	1.6 8v 70kw NFV (03-..)	AKF- Autoliv AirBag ACU3
 Xsara Picasso	AIRBAG	1.6 8v 70kw NFV (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xsara Picasso	AIRBAG	1.6 HDI 16v 66kw 9HX	AUTOLIV AirBag CENTRAL ACU AUTODE
 Xsara Picasso	AIRBAG	1.6 HDI 16v 66kw 9HX	Temic AirBag CENTRAL AUTODETECT
 Xsara Picasso	AIRBAG	1.6 HDI 16v 66kw 9HX (03-..)	AKF- Autoliv AirBag ACU3
 Xsara Picasso	AIRBAG	1.6 HDI 16v 66kw 9HX (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xsara Picasso	AIRBAG	1.6 HDI 16v 80kw 9HY	AUTOLIV AirBag CENTRAL ACU AUTODE
 Xsara Picasso	AIRBAG	1.6 HDI 16v 80kw 9HY	Temic AirBag CENTRAL AUTODETECT
 Xsara Picasso	AIRBAG	1.6 HDI 16v 80kw 9HY (03-..)	AKF- Autoliv AirBag ACU3
 Xsara Picasso	AIRBAG	1.6 HDI 16v 80kw 9HY (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xsara Picasso	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP	AUTOLIV AirBag CENTRAL ACU AUTODE
 Xsara Picasso	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP	Temic AirBag CENTRAL AUTODETECT
 Xsara Picasso	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP (03-..)	AKF- Autoliv AirBag ACU3
 Xsara Picasso	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP (97-00)	AKF- Autoliv AirBag no SIDE AB

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Xsara Picasso	AIRBAG	1.8 16v 86kw 6FZ	AUTOLIV AirBag CENTRAL ACU AUTODE
 Xsara Picasso	AIRBAG	1.8 16v 86kw 6FZ	Temic AirBag CENTRAL AUTODETECT
 Xsara Picasso	AIRBAG	1.8 16v 86kw 6FZ (03-..)	AKF- Autoliv AirBag ACU3
 Xsara Picasso	AIRBAG	1.8 16v 86kw 6FZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xsara Picasso	AIRBAG	2.0 16v 101kw RFN	AUTOLIV AirBag CENTRAL ACU AUTODE
 Xsara Picasso	AIRBAG	2.0 16v 101kw RFN	Temic AirBag CENTRAL AUTODETECT
 Xsara Picasso	AIRBAG	2.0 16v 101kw RFN (03-..)	AKF- Autoliv AirBag ACU3
 Xsara Picasso	AIRBAG	2.0 16v 101kw RFN (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xsara Picasso	AIRBAG	2.0 16v 85kw RFM	AUTOLIV AirBag CENTRAL ACU AUTODE
 Xsara Picasso	AIRBAG	2.0 16v 85kw RFM	Temic AirBag CENTRAL AUTODETECT
 Xsara Picasso	AIRBAG	2.0 16v 85kw RFM (03-..)	AKF- Autoliv AirBag ACU3
 Xsara Picasso	AIRBAG	2.0 16v 85kw RFM (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xsara Picasso	AIRBAG	2.0 HDI 8v 66kw RHY	AUTOLIV AirBag CENTRAL ACU AUTODE
 Xsara Picasso	AIRBAG	2.0 HDI 8v 66kw RHY	Temic AirBag CENTRAL AUTODETECT
 Xsara Picasso	AIRBAG	2.0 HDI 8v 66kw RHY (01-02)	AKF- Autoliv AirBag
 Xsara Picasso	AIRBAG	2.0 HDI 8v 66kw RHY (03-..)	AKF- Autoliv AirBag ACU3
 Xsara Picasso	AIRBAG	2.0 HDI 8v 66kw RHY (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xsara Picasso	ANTITHEFT	1.6 16v 80kw N6A	Alarm PSA2 AUTODETECT
 Xsara Picasso	ANTITHEFT	1.6 16v 80kw NFU	Alarm PSA2 AUTODETECT
 Xsara Picasso	ANTITHEFT	1.6 8v 66kw NFZ	Alarm PSA2 AUTODETECT
 Xsara Picasso	ANTITHEFT	1.6 8v 70kw NFV	Alarm PSA2 AUTODETECT
 Xsara Picasso	ANTITHEFT	1.6 HDI 16v 66kw 9HX	Alarm PSA2 AUTODETECT
 Xsara Picasso	ANTITHEFT	1.6 HDI 16v 80kw 9HY	Alarm PSA2 AUTODETECT
 Xsara Picasso	ANTITHEFT	1.6 HDI 16v 80kw 9HZ-FAP	Alarm PSA2 AUTODETECT
 Xsara Picasso	ANTITHEFT	1.8 16v 86kw 6FZ	Alarm PSA2 AUTODETECT
 Xsara Picasso	ANTITHEFT	2.0 16v 101kw RFN	Alarm PSA2 AUTODETECT
 Xsara Picasso	ANTITHEFT	2.0 16v 85kw RFM	Alarm PSA2 AUTODETECT
 Xsara Picasso	ANTITHEFT	2.0 HDI 8v 66kw RHY	Alarm PSA2 AUTODETECT
 Xsara Picasso	AUTOM. TRANSMISSI	1.6 16v 80kw N6A	A/T AL4 AUTODETECT
 Xsara Picasso	AUTOM. TRANSMISSI	1.6 16v 80kw NFU	A/T AL4 AUTODETECT
 Xsara Picasso	AUTOM. TRANSMISSI	1.6 8v 66kw NFZ	A/T AL4 AUTODETECT
 Xsara Picasso	AUTOM. TRANSMISSI	1.6 8v 70kw NFV	A/T AL4 AUTODETECT
 Xsara Picasso	AUTOM. TRANSMISSI	1.6 HDI 16v 66kw 9HX	A/T AL4 AUTODETECT
 Xsara Picasso	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HY	A/T AL4 AUTODETECT
 Xsara Picasso	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP	A/T AL4 AUTODETECT
 Xsara Picasso	AUTOM. TRANSMISSI	1.8 16v 86kw 6FZ	A/T AL4 AUTODETECT
 Xsara Picasso	AUTOM. TRANSMISSI	2.0 16v 101kw RFN	A/T AL4 AUTODETECT
 Xsara Picasso	AUTOM. TRANSMISSI	2.0 16v 85kw RFM	A/T AL4 AUTODETECT
 Xsara Picasso	AUTOM. TRANSMISSI	2.0 HDI 8v 66kw RHY	A/T AL4 AUTODETECT
 Xsara Picasso	CHASSIS NETWORK	1.6 16v 80kw N6A	Body Computer BSI AUTODETECT
 Xsara Picasso	CHASSIS NETWORK	1.6 16v 80kw NFU	Body Computer BSI AUTODETECT
 Xsara Picasso	CHASSIS NETWORK	1.6 16v 80kw NFU (02-..)	VALEO Body Computer
 Xsara Picasso	CHASSIS NETWORK	1.6 8v 66kw NFZ	Body Computer BSI AUTODETECT
 Xsara Picasso	CHASSIS NETWORK	1.6 8v 66kw NFZ (02-..)	VALEO Body Computer
 Xsara Picasso	CHASSIS NETWORK	1.6 8v 70kw NFV	Body Computer BSI AUTODETECT
 Xsara Picasso	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	Body Computer BSI AUTODETECT
 Xsara Picasso	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY	Body Computer BSI AUTODETECT
 Xsara Picasso	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSI AUTODETECT
 Xsara Picasso	CHASSIS NETWORK	1.8 16v 86kw 6FZ	Body Computer BSI AUTODETECT
 Xsara Picasso	CHASSIS NETWORK	1.8 16v 86kw 6FZ (02-..)	VALEO Body Computer
 Xsara Picasso	CHASSIS NETWORK	2.0 16v 101kw RFN	Body Computer BSI AUTODETECT
 Xsara Picasso	CHASSIS NETWORK	2.0 16v 85kw RFM	Body Computer BSI AUTODETECT
 Xsara Picasso	CHASSIS NETWORK	2.0 HDI 8v 66kw RHY	Body Computer BSI AUTODETECT
 Xsara Picasso	CHASSIS NETWORK	2.0 HDI 8v 66kw RHY (02-..)	VALEO Body Computer
 Xsara Picasso	CLIMA	1.6 16v 80kw N6A	CLIMA AUTODETECT
 Xsara Picasso	CLIMA	1.6 16v 80kw NFU	Clim. Regulee
 Xsara Picasso	CLIMA	1.6 16v 80kw NFU	CLIMA AUTODETECT
 Xsara Picasso	CLIMA	1.6 8v 66kw NFZ	CLIMA AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Xsara Picasso	CLIMA	1.6 8v 70kw NFV	CLIMA AUTODETECT
 Xsara Picasso	CLIMA	1.6 HDI 16v 66kw 9HX	Clim. Regulee
 Xsara Picasso	CLIMA	1.6 HDI 16v 66kw 9HX	CLIMA AUTODETECT
 Xsara Picasso	CLIMA	1.6 HDI 16v 80kw 9HY	Clim. Regulee
 Xsara Picasso	CLIMA	1.6 HDI 16v 80kw 9HY	CLIMA AUTODETECT
 Xsara Picasso	CLIMA	1.6 HDI 16v 80kw 9HZ-FAP	Clim. Regulee
 Xsara Picasso	CLIMA	1.6 HDI 16v 80kw 9HZ-FAP	CLIMA AUTODETECT
 Xsara Picasso	CLIMA	1.8 16v 86kw 6FZ	Clim. Regulee
 Xsara Picasso	CLIMA	1.8 16v 86kw 6FZ	CLIMA AUTODETECT
 Xsara Picasso	CLIMA	2.0 16v 101kw RFN	CLIMA AUTODETECT
 Xsara Picasso	CLIMA	2.0 16v 85kw RFM	CLIMA AUTODETECT
 Xsara Picasso	CLIMA	2.0 HDI 8v 66kw RHY	Clim. Regulee
 Xsara Picasso	CLIMA	2.0 HDI 8v 66kw RHY	CLIMA AUTODETECT
 Xsara Picasso	DASHBOARD	1.6 16v 80kw N6A	AUTODETECT
 Xsara Picasso	DASHBOARD	1.6 16v 80kw NFU	AUTODETECT
 Xsara Picasso	DASHBOARD	1.6 16v 80kw NFU	SAGEM Dashboard
 Xsara Picasso	DASHBOARD	1.6 8v 66kw NFZ	AUTODETECT
 Xsara Picasso	DASHBOARD	1.6 8v 70kw NFV	AUTODETECT
 Xsara Picasso	DASHBOARD	1.6 HDI 16v 66kw 9HX	AUTODETECT
 Xsara Picasso	DASHBOARD	1.6 HDI 16v 66kw 9HX	SAGEM Dashboard
 Xsara Picasso	DASHBOARD	1.6 HDI 16v 80kw 9HY	COMBINE AUTODETECT
 Xsara Picasso	DASHBOARD	1.6 HDI 16v 80kw 9HY	SAGEM Dashboard
 Xsara Picasso	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 Xsara Picasso	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP	SAGEM Dashboard
 Xsara Picasso	DASHBOARD	1.8 16v 86kw 6FZ	AUTODETECT
 Xsara Picasso	DASHBOARD	1.8 16v 86kw 6FZ	SAGEM Dashboard
 Xsara Picasso	DASHBOARD	2.0 16v 101kw RFN	AUTODETECT
 Xsara Picasso	DASHBOARD	2.0 16v 85kw RFM	AUTODETECT
 Xsara Picasso	DASHBOARD	2.0 HDI 8v 66kw RHY	AUTODETECT
 Xsara Picasso	DASHBOARD	2.0 HDI 8v 66kw RHY	SAGEM Dashboard
 Xsara Picasso	DIESEL ADDITION	1.6 HDI 16v 80kw 9HY	AUTODETECT
 Xsara Picasso	DIESEL ADDITION	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 Xsara Picasso	DIESEL ADDITION	2.0 HDI 8v 66kw RHY	AUTODETECT
 Xsara Picasso	ENGINE MANAGEME	1.6 16v 80kw N6A	BOSCH ME 7.4.5 AUTODETECT
 Xsara Picasso	ENGINE MANAGEME	1.6 16v 80kw N6A	BOSCH ME 7.4.9 AUTODETECT
 Xsara Picasso	ENGINE MANAGEME	1.6 16v 80kw NFU	BOSCH ME 7.4.5 AUTODETECT
 Xsara Picasso	ENGINE MANAGEME	1.6 16v 80kw NFU	BOSCH Motronic ME7.4.4
 Xsara Picasso	ENGINE MANAGEME	1.6 8v 66kw NFZ	BOSCH Motronic MP7.2
 Xsara Picasso	ENGINE MANAGEME	1.6 8v 70kw NFV	BOSCH ME 7.4.4 AUTODETECT
 Xsara Picasso	ENGINE MANAGEME	1.6 HDI 16v 66kw 9HX	BOSCH EDC16 C34 Common Rail AUTOD
 Xsara Picasso	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HY	BOSCH EDC16 C3 Common Rail AUTODE
 Xsara Picasso	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HY	BOSCH EDC16 C34 Common Rail AUTOD
 Xsara Picasso	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 Xsara Picasso	ENGINE MANAGEME	1.8 16v 86kw 6FZ	SAGEM MPI S2000P
 Xsara Picasso	ENGINE MANAGEME	1.8 16v 86kw 6FZ	SAGEM S2000 AUTODETECT
 Xsara Picasso	ENGINE MANAGEME	1.8 16v 86kw 6FZ	SAGEM S2000 PM1 AUTODETECT
 Xsara Picasso	ENGINE MANAGEME	1.8 16v 86kw 6FZ	SAGEM S2000 PM2 AUTODETECT
 Xsara Picasso	ENGINE MANAGEME	2.0 16v 101kw RFN	Marelli MM6LP AUTODETECT
 Xsara Picasso	ENGINE MANAGEME	2.0 16v 85kw RFM	Marelli MM48P AUTODETECT
 Xsara Picasso	ENGINE MANAGEME	2.0 HDI 8v 66kw RHY	DIESEL AUTODETECT
 Xsara Picasso	ENGINE MANAGEME	2.0 HDI 8v 66kw RHY	SIEMENS Diesel SID 801 Common Rail
 Xsara Picasso	ENGINE MANAGEME	2.0 HDI 8v 66kw RHY (03-06)	BOSCH EDC 15 C2 Common Rail
 Xsara Picasso	ENGINE MANAGEME	2.0 HDI 8v 66kw RHY (99-02)	BOSCH EDC 15 C2 Common Rail
 Xsara Picasso	KEY ENCODE	1.6 16v 80kw NFU	VALEO Body Siemens
 Xsara Picasso	KEY ENCODE	1.6 8v 66kw NFZ	VALEO Body Siemens
 Xsara Picasso	KEY ENCODE	1.6 HDI 16v 66kw 9HX	VALEO Body Siemens
 Xsara Picasso	KEY ENCODE	1.6 HDI 16v 80kw 9HY	VALEO Body Siemens
 Xsara Picasso	KEY ENCODE	1.6 HDI 16v 80kw 9HZ-FAP	VALEO Body Siemens

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Xsara Picasso	KEY ENCODE	1.8 16v 86kw 6FZ	VALEO Body Siemens
 Xsara Picasso	KEY ENCODE	2.0 16v 101kw RFN	VALEO Body Siemens
 Xsara Picasso	KEY ENCODE	2.0 HDI 8v 66kw RHY	VALEO Body Siemens
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw N6A	A/T AL4 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw N6A	AUTOLIV AirBag CENTRAL ACU AUTODE
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw N6A	AUTOLIV AirBag CENTRAL ACU AUTODE
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw N6A	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw N6A	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw N6A	BOSCH ABS 8.1 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw N6A	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw N6A	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw N6A	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw N6A	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw N6A	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw N6A	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw N6A	BOSCH ESP 8.1 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw N6A	BOSCH ESP 8.1 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw N6A (03-..)	AKF- Autoliv AirBag ACU3
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw NFU	A/T AL4 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw NFU	AUTOLIV AirBag CENTRAL ACU AUTODE
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw NFU	AUTOLIV AirBag CENTRAL ACU AUTODE
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ABS 8.1 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ESP 8.1 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ESP 8.1 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw NFU	SAGEM Dashboard
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw NFU (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw NFU (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw NFU (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw NFU (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw NFU (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw NFU (03-..)	AKF- Autoliv AirBag ACU3
 Xsara Picasso	MAINTENANCE	1.6 16v 80kw NFU (98-06)	Sagem MANUAL
 Xsara Picasso	MAINTENANCE	1.6 8v 66kw NFZ	A/T AL4 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 8v 66kw NFZ	AUTOLIV AirBag CENTRAL ACU AUTODE
 Xsara Picasso	MAINTENANCE	1.6 8v 66kw NFZ	AUTOLIV AirBag CENTRAL ACU AUTODE
 Xsara Picasso	MAINTENANCE	1.6 8v 66kw NFZ	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 8v 66kw NFZ	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 8v 66kw NFZ	BOSCH ABS 8.1 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 8v 66kw NFZ	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	1.6 8v 66kw NFZ	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	1.6 8v 66kw NFZ	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	1.6 8v 66kw NFZ	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 8v 66kw NFZ	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 8v 66kw NFZ	BOSCH ESP 8.1 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 8v 66kw NFZ	BOSCH ESP 8.1 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 8v 66kw NFZ (03-..)	AKF- Autoliv AirBag ACU3
 Xsara Picasso	MAINTENANCE	1.6 8v 66kw NFZ (98-06)	Sagem MANUAL
 Xsara Picasso	MAINTENANCE	1.6 8v 70kw NFV	A/T AL4 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 8v 70kw NFV	AUTOLIV AirBag CENTRAL ACU AUTODE

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Xsara Picasso	MAINTENANCE	1.6 8v 70kw NFV	AUTOLIV AirBag CENTRAL ACU AUTODE
 Xsara Picasso	MAINTENANCE	1.6 8v 70kw NFV	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 8v 70kw NFV	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 8v 70kw NFV	BOSCH ABS 8.1 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 8v 70kw NFV	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	1.6 8v 70kw NFV	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	1.6 8v 70kw NFV	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	1.6 8v 70kw NFV	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	1.6 8v 70kw NFV	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 8v 70kw NFV	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 8v 70kw NFV	BOSCH ESP 8.1 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 8v 70kw NFV	BOSCH ESP 8.1 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 8v 70kw NFV (03-..)	AKF- Autoliv AirBag ACU3
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX	A/T AL4 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX	AUTOLIV AirBag CENTRAL ACU AUTODE
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX	AUTOLIV AirBag CENTRAL ACU AUTODE
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH ABS 8.1 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC16 C34 Common Rail AUTOD
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC16 C34 Common Rail AUTOD
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC16 C34 Common Rail AUTOD
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC16 C34 Common Rail AUTOD
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC16 C34 Common Rail AUTOD
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC16 C34 Common Rail AUTOD
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH ESP 8.1 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH ESP 8.1 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH ESP 8.1 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX	SAGEM Dashboard
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Sagem MANUAL
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 66kw 9HX (03-..)	AKF- Autoliv AirBag ACU3
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HY	A/T AL4 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HY	AUTOLIV AirBag CENTRAL ACU AUTODE
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HY	AUTOLIV AirBag CENTRAL ACU AUTODE
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH ABS 8.1 AUTODETECT
Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH ABS ABR 5.

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC16 C3 Common Rail AUTODE
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC16 C34 Common Rail AUTOD
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC16 C34 Common Rail AUTOD
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC16 C34 Common Rail AUTOD
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC16 C34 Common Rail AUTOD
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC16 C34 Common Rail AUTOD
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC16 C34 Common Rail AUTOD
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC16 C34 Common Rail AUTOD
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH ESP 8.1 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH ESP 8.1 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HY	SAGEM Dashboard
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Sagem MANUAL
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HY (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HY (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HY (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HY (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HY (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HY (03-..)	AKF- Autoliv AirBag ACU3
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	A/T AL4 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	AUTOLIV AirBag CENTRAL ACU AUTODE
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	AUTOLIV AirBag CENTRAL ACU AUTODE
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ABS 8.1 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC16 C34 Common Rail AUTOD
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ESP 8.1 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ESP 8.1 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	SAGEM Dashboard
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Sagem MANUAL
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (03-..)	AKF- Autoliv AirBag ACU3
 Xsara Picasso	MAINTENANCE	1.8 16v 82kw 6FZ	ESP 5.7 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.8 16v 82kw 6FZ	ESP 5.7 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.8 16v 86kw 6FZ	A/T AL4 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.8 16v 86kw 6FZ	ABS 8.0 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.8 16v 86kw 6FZ	ABS 8.0 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.8 16v 86kw 6FZ	ABS 8.1 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.8 16v 86kw 6FZ	AUTOLIV AirBag CENTRAL ACU AUTODE
 Xsara Picasso	MAINTENANCE	1.8 16v 86kw 6FZ	AUTOLIV AirBag CENTRAL ACU AUTODE
 Xsara Picasso	MAINTENANCE	1.8 16v 86kw 6FZ	BOSCH ABS ABR 5.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Xsara Picasso	MAINTENANCE	1.8 16v 86kw 6FZ	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	1.8 16v 86kw 6FZ	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	1.8 16v 86kw 6FZ	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	1.8 16v 86kw 6FZ	ESP 8.1 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.8 16v 86kw 6FZ	ESP 8.1 AUTODETECT
 Xsara Picasso	MAINTENANCE	1.8 16v 86kw 6FZ	SAGEM Dashboard
 Xsara Picasso	MAINTENANCE	1.8 16v 86kw 6FZ (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	MAINTENANCE	1.8 16v 86kw 6FZ (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	MAINTENANCE	1.8 16v 86kw 6FZ (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	MAINTENANCE	1.8 16v 86kw 6FZ (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	MAINTENANCE	1.8 16v 86kw 6FZ (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	MAINTENANCE	1.8 16v 86kw 6FZ (03-..)	AKF- Autoliv AirBag ACU3
 Xsara Picasso	MAINTENANCE	1.8 16v 86kw 6FZ (98-06)	Sagem MANUAL
 Xsara Picasso	MAINTENANCE	2.0 16v 101kw RFN	A/T AL4 AUTODETECT
 Xsara Picasso	MAINTENANCE	2.0 16v 101kw RFN	AUTOLIV AirBag CENTRAL ACU AUTODE
 Xsara Picasso	MAINTENANCE	2.0 16v 101kw RFN	AUTOLIV AirBag CENTRAL ACU AUTODE
 Xsara Picasso	MAINTENANCE	2.0 16v 101kw RFN	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso	MAINTENANCE	2.0 16v 101kw RFN	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso	MAINTENANCE	2.0 16v 101kw RFN	BOSCH ABS 8.1 AUTODETECT
 Xsara Picasso	MAINTENANCE	2.0 16v 101kw RFN	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	2.0 16v 101kw RFN	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	2.0 16v 101kw RFN	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	2.0 16v 101kw RFN	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	2.0 16v 101kw RFN	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso	MAINTENANCE	2.0 16v 101kw RFN	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso	MAINTENANCE	2.0 16v 101kw RFN	BOSCH ESP 8.1 AUTODETECT
 Xsara Picasso	MAINTENANCE	2.0 16v 101kw RFN	BOSCH ESP 8.1 AUTODETECT
 Xsara Picasso	MAINTENANCE	2.0 16v 101kw RFN (03-..)	AKF- Autoliv AirBag ACU3
 Xsara Picasso	MAINTENANCE	2.0 16v 101kw RFN (98-06)	Sagem MANUAL
 Xsara Picasso	MAINTENANCE	2.0 16v 85kw RFM	A/T AL4 AUTODETECT
 Xsara Picasso	MAINTENANCE	2.0 16v 85kw RFM	AUTOLIV AirBag CENTRAL ACU AUTODE
 Xsara Picasso	MAINTENANCE	2.0 16v 85kw RFM	AUTOLIV AirBag CENTRAL ACU AUTODE
 Xsara Picasso	MAINTENANCE	2.0 16v 85kw RFM	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso	MAINTENANCE	2.0 16v 85kw RFM	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso	MAINTENANCE	2.0 16v 85kw RFM	BOSCH ABS 8.1 AUTODETECT
 Xsara Picasso	MAINTENANCE	2.0 16v 85kw RFM	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	2.0 16v 85kw RFM	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	2.0 16v 85kw RFM	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	2.0 16v 85kw RFM	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso	MAINTENANCE	2.0 16v 85kw RFM	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso	MAINTENANCE	2.0 16v 85kw RFM	BOSCH ESP 8.1 AUTODETECT
 Xsara Picasso	MAINTENANCE	2.0 16v 85kw RFM	BOSCH ESP 8.1 AUTODETECT
 Xsara Picasso	MAINTENANCE	2.0 16v 85kw RFM (03-..)	AKF- Autoliv AirBag ACU3
 Xsara Picasso	MAINTENANCE	2.0 HDI 8v 66kw RHY	A/T AL4 AUTODETECT
 Xsara Picasso	MAINTENANCE	2.0 HDI 8v 66kw RHY	AUTOLIV AirBag CENTRAL ACU AUTODE
 Xsara Picasso	MAINTENANCE	2.0 HDI 8v 66kw RHY	AUTOLIV AirBag CENTRAL ACU AUTODE
 Xsara Picasso	MAINTENANCE	2.0 HDI 8v 66kw RHY	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso	MAINTENANCE	2.0 HDI 8v 66kw RHY	BOSCH ABS 8.0 AUTODETECT
 Xsara Picasso	MAINTENANCE	2.0 HDI 8v 66kw RHY	BOSCH ABS 8.1 AUTODETECT
 Xsara Picasso	MAINTENANCE	2.0 HDI 8v 66kw RHY	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	2.0 HDI 8v 66kw RHY	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	2.0 HDI 8v 66kw RHY	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	2.0 HDI 8v 66kw RHY	BOSCH ABS ABR 5.3
 Xsara Picasso	MAINTENANCE	2.0 HDI 8v 66kw RHY	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso	MAINTENANCE	2.0 HDI 8v 66kw RHY	BOSCH ESP 5.7 AUTODETECT
 Xsara Picasso	MAINTENANCE	2.0 HDI 8v 66kw RHY	BOSCH ESP 8.1 AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Xsara Picasso	MAINTENANCE	2.0 HDI 8v 66kw RHY	BOSCH ESP 8.1 AUTODETECT
 Xsara Picasso	MAINTENANCE	2.0 HDI 8v 66kw RHY	DIESEL AUTODETECT
 Xsara Picasso	MAINTENANCE	2.0 HDI 8v 66kw RHY	SAGEM Dashboard
 Xsara Picasso	MAINTENANCE	2.0 HDI 8v 66kw RHY (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	MAINTENANCE	2.0 HDI 8v 66kw RHY (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	MAINTENANCE	2.0 HDI 8v 66kw RHY (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	MAINTENANCE	2.0 HDI 8v 66kw RHY (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	MAINTENANCE	2.0 HDI 8v 66kw RHY (02-..)	BOSCH ABS/ESP 5.7
 Xsara Picasso	MAINTENANCE	2.0 HDI 8v 66kw RHY (03-..)	AKF- Autoliv AirBag ACU3
 Xsara Picasso	MAINTENANCE	2.0 HDI 8v 66kw RHY (03-06)	BOSCH EDC 15 C2 Common Rail
 Xsara Picasso	MAINTENANCE	2.0 HDI 8v 66kw RHY (98-06)	Sagem MANUAL
 Xsara Picasso	NAVIGATION	1.6 16v 80kw N6A	AUTODETECT
 Xsara Picasso	NAVIGATION	1.6 16v 80kw NFU	AUTODETECT
 Xsara Picasso	NAVIGATION	1.6 8v 66kw NFZ	AUTODETECT
 Xsara Picasso	NAVIGATION	1.6 8v 70kw NFV	AUTODETECT
 Xsara Picasso	NAVIGATION	1.6 HDI 16v 66kw 9HX	AUTODETECT
 Xsara Picasso	NAVIGATION	1.6 HDI 16v 80kw 9HY	AUTODETECT
 Xsara Picasso	NAVIGATION	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 Xsara Picasso	NAVIGATION	1.8 16v 86kw 6FZ	AUTODETECT
 Xsara Picasso	NAVIGATION	2.0 16v 101kw RFN	AUTODETECT
 Xsara Picasso	NAVIGATION	2.0 16v 85kw RFM	AUTODETECT
 Xsara Picasso	NAVIGATION	2.0 HDI 8v 66kw RHY	AUTODETECT
 Xsara Picasso	PARKING HELP	1.6 16v 80kw N6A	AUTODETECT
 Xsara Picasso	PARKING HELP	1.6 16v 80kw NFU	AUTODETECT
 Xsara Picasso	PARKING HELP	1.6 8v 66kw NFZ	AUTODETECT
 Xsara Picasso	PARKING HELP	1.6 8v 70kw NFV	AUTODETECT
 Xsara Picasso	PARKING HELP	1.6 HDI 16v 66kw 9HX	AUTODETECT
 Xsara Picasso	PARKING HELP	1.6 HDI 16v 80kw 9HY	AUTODETECT
 Xsara Picasso	PARKING HELP	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 Xsara Picasso	PARKING HELP	1.8 16v 86kw 6FZ	AUTODETECT
 Xsara Picasso	PARKING HELP	2.0 16v 101kw RFN	AUTODETECT
 Xsara Picasso	PARKING HELP	2.0 16v 85kw RFM	AUTODETECT
 Xsara Picasso	PARKING HELP	2.0 HDI 8v 66kw RHY	AUTODETECT
 Xsara Picasso	RADIO / CD	1.6 16v 80kw N6A	AudioSystem AUTODETECT
 Xsara Picasso	RADIO / CD	1.6 16v 80kw N6A	CD Changer AUTODETECT
 Xsara Picasso	RADIO / CD	1.6 16v 80kw NFU	AudioSystem AUTODETECT
 Xsara Picasso	RADIO / CD	1.6 16v 80kw NFU	CD Changer AUTODETECT
 Xsara Picasso	RADIO / CD	1.6 16v 80kw NFU	CLARION AudioSystem
 Xsara Picasso	RADIO / CD	1.6 16v 80kw NFU	PHILIPS AudioSystem
 Xsara Picasso	RADIO / CD	1.6 16v 80kw NFU	VDO AudioSystem
 Xsara Picasso	RADIO / CD	1.6 8v 66kw NFZ	AudioSystem AUTODETECT
 Xsara Picasso	RADIO / CD	1.6 8v 66kw NFZ	CD Changer AUTODETECT
 Xsara Picasso	RADIO / CD	1.6 8v 70kw NFV	AudioSystem AUTODETECT
 Xsara Picasso	RADIO / CD	1.6 8v 70kw NFV	CD Changer AUTODETECT
 Xsara Picasso	RADIO / CD	1.6 HDI 16v 66kw 9HX	AudioSystem AUTODETECT
 Xsara Picasso	RADIO / CD	1.6 HDI 16v 66kw 9HX	CD Changer AUTODETECT
 Xsara Picasso	RADIO / CD	1.6 HDI 16v 66kw 9HX	CLARION AudioSystem
 Xsara Picasso	RADIO / CD	1.6 HDI 16v 66kw 9HX	PHILIPS AudioSystem
 Xsara Picasso	RADIO / CD	1.6 HDI 16v 66kw 9HX	VDO AudioSystem
 Xsara Picasso	RADIO / CD	1.6 HDI 16v 80kw 9HY	AudioSystem AUTODETECT
 Xsara Picasso	RADIO / CD	1.6 HDI 16v 80kw 9HY	CD Changer AUTODETECT
 Xsara Picasso	RADIO / CD	1.6 HDI 16v 80kw 9HY	CLARION AudioSystem
 Xsara Picasso	RADIO / CD	1.6 HDI 16v 80kw 9HY	PHILIPS AudioSystem
 Xsara Picasso	RADIO / CD	1.6 HDI 16v 80kw 9HY	VDO
 Xsara Picasso	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	AudioSystem AUTODETECT
 Xsara Picasso	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	CD Changer AUTODETECT
 Xsara Picasso	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	CLARION AudioSystem
 Xsara Picasso	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	PHILIPS AudioSystem

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Xsara Picasso	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	VDO
 Xsara Picasso	RADIO / CD	1.8 16v 86kw 6FZ	AudioSystem AUTODETECT
 Xsara Picasso	RADIO / CD	1.8 16v 86kw 6FZ	CD Changer AUTODETECT
 Xsara Picasso	RADIO / CD	1.8 16v 86kw 6FZ	CLARION AudioSystem
 Xsara Picasso	RADIO / CD	1.8 16v 86kw 6FZ	PHILIPS AudioSystem
 Xsara Picasso	RADIO / CD	1.8 16v 86kw 6FZ	VDO AudioSystem
 Xsara Picasso	RADIO / CD	2.0 16v 101kw RFN	AudioSystem AUTODETECT
 Xsara Picasso	RADIO / CD	2.0 16v 101kw RFN	CD Changer AUTODETECT
 Xsara Picasso	RADIO / CD	2.0 16v 85kw RFM	AudioSystem AUTODETECT
 Xsara Picasso	RADIO / CD	2.0 16v 85kw RFM	CD Changer AUTODETECT
 Xsara Picasso	RADIO / CD	2.0 HDI 8v 66kw RHY	AudioSystem AUTODETECT
 Xsara Picasso	RADIO / CD	2.0 HDI 8v 66kw RHY	CD Changer AUTODETECT
 Xsara Picasso	RADIO / CD	2.0 HDI 8v 66kw RHY	CLARION AudioSystem
 Xsara Picasso	RADIO / CD	2.0 HDI 8v 66kw RHY	PHILIPS AudioSystem
 Xsara Picasso	RADIO / CD	2.0 HDI 8v 66kw RHY	VDO AudioSystem
 Xsara Picasso	RAIN-LUMINOSITY S	1.6 16v 80kw N6A	AUTODETECT
 Xsara Picasso	RAIN-LUMINOSITY S	1.6 16v 80kw NFU	AUTODETECT
 Xsara Picasso	RAIN-LUMINOSITY S	1.6 8v 66kw NFZ	AUTODETECT
 Xsara Picasso	RAIN-LUMINOSITY S	1.6 8v 70kw NFV	AUTODETECT
 Xsara Picasso	RAIN-LUMINOSITY S	1.6 HDI 16v 66kw 9HX	AUTODETECT
 Xsara Picasso	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HY	AUTODETECT
 Xsara Picasso	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 Xsara Picasso	RAIN-LUMINOSITY S	1.8 16v 86kw 6FZ	AUTODETECT
 Xsara Picasso	RAIN-LUMINOSITY S	2.0 16v 101kw RFN	AUTODETECT
 Xsara Picasso	RAIN-LUMINOSITY S	2.0 16v 85kw RFM	AUTODETECT
 Xsara Picasso	RAIN-LUMINOSITY S	2.0 HDI 8v 66kw RHY	AUTODETECT
 Xsara Picasso	SERVICE LIGHT RES	1.6 16v 80kw NFU (98-06)	Sagem MANUAL
 Xsara Picasso	SERVICE LIGHT RES	1.6 8v 66kw NFZ (98-06)	Sagem MANUAL
 Xsara Picasso	SERVICE LIGHT RES	1.6 HDI 16v 66kw 9HX	Sagem MANUAL
 Xsara Picasso	SERVICE LIGHT RES	1.6 HDI 16v 80kw 9HY	Sagem MANUAL
 Xsara Picasso	SERVICE LIGHT RES	1.6 HDI 16v 80kw 9HZ-FAP	Sagem MANUAL
 Xsara Picasso	SERVICE LIGHT RES	1.8 16v 86kw 6FZ (98-06)	Sagem MANUAL
 Xsara Picasso	SERVICE LIGHT RES	2.0 16v 101kw RFN (98-06)	Sagem MANUAL
 Xsara Picasso	SERVICE LIGHT RES	2.0 HDI 8v 66kw RHY (98-06)	Sagem MANUAL
 Xsara Picasso	STEERING COLUMN	1.6 16v 80kw N6A	AUTODETECT
 Xsara Picasso	STEERING COLUMN	1.6 16v 80kw NFU	AUTODETECT
 Xsara Picasso	STEERING COLUMN	1.6 8v 66kw NFZ	AUTODETECT
 Xsara Picasso	STEERING COLUMN	1.6 8v 70kw NFV	AUTODETECT
 Xsara Picasso	STEERING COLUMN	1.6 HDI 16v 66kw 9HX	AUTODETECT
 Xsara Picasso	STEERING COLUMN	1.6 HDI 16v 80kw 9HY	AUTODETECT
 Xsara Picasso	STEERING COLUMN	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 Xsara Picasso	STEERING COLUMN	1.8 16v 86kw 6FZ	AUTODETECT
 Xsara Picasso	STEERING COLUMN	2.0 16v 101kw RFN	AUTODETECT
 Xsara Picasso	STEERING COLUMN	2.0 16v 85kw RFM	AUTODETECT
 Xsara Picasso	STEERING COLUMN	2.0 HDI 8v 66kw RHY	AUTODETECT
 Xsara Picasso	SWITCHLIGHT MODU	1.6 16v 80kw NFU	EATON/DELPHI
 Xsara Picasso	SWITCHLIGHT MODU	1.8 16v 86kw 6FZ	EATON/DELPHI
 Xsara Picasso	SWITCHLIGHT MODU	2.0 16v 101kw RFN	EATON/DELPHI
 Xsara Picasso	SWITCHLIGHT MODU	2.0 HDI 8v 66kw RHY	EATON/DELPHI
 Xsara Picasso	VISUAL./TELEMATIC	1.6 16v 80kw N6A	Display AUTODETECT
 Xsara Picasso	VISUAL./TELEMATIC	1.6 16v 80kw NFU	Display AUTODETECT
 Xsara Picasso	VISUAL./TELEMATIC	1.6 16v 80kw NFU	SAGEM
 Xsara Picasso	VISUAL./TELEMATIC	1.6 8v 66kw NFZ	Display AUTODETECT
 Xsara Picasso	VISUAL./TELEMATIC	1.6 8v 70kw NFV	Display AUTODETECT
 Xsara Picasso	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HX	Display AUTODETECT
 Xsara Picasso	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HX	SAGEM
 Xsara Picasso	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HY	Display AUTODETECT
 Xsara Picasso	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HY	SAGEM

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Xsara Picasso	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	Display AUTODETECT
 Xsara Picasso	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	SAGEM
 Xsara Picasso	VISUAL./TELEMATIC	1.8 16v 86kw 6FZ	Display AUTODETECT
 Xsara Picasso	VISUAL./TELEMATIC	1.8 16v 86kw 6FZ	SAGEM
 Xsara Picasso	VISUAL./TELEMATIC	2.0 16v 101kw RFN	Display AUTODETECT
 Xsara Picasso	VISUAL./TELEMATIC	2.0 16v 85kw RFM	Display AUTODETECT
 Xsara Picasso	VISUAL./TELEMATIC	2.0 HDI 8v 66kw RHY	SAGEM
 Xsara Picasso	VISUAL./TELEMATIC	2.0 HDI 8v 66kw RHY	SAGEM Display AUTODETECT
 Xsara	ABS	1.4 8v 55kw KFX (97-00)	BOSCH ABS ABR 5.3
 Xsara	ABS	1.5 D 8v 40kw VJY (97-00)	BOSCH ABS ABR 5.3
 Xsara	ABS	1.5 D 8v 42kw VJZ (97-00)	BOSCH ABS ABR 5.3
 Xsara	ABS	1.6 8v 66kw NFZ (97-00)	BOSCH ABS ABR 5.3
 Xsara	ABS	1.8 16v 82kw LFY (97-00)	BOSCH ABS ABR 5.3
 Xsara	ABS	1.8 8v 66kw LFX (97-00)	BOSCH ABS ABR 5.3
 Xsara	ABS	1.8 8v 74kw LFZ (97-00)	BOSCH ABS ABR 5.3
 Xsara	ABS	1.8 D 8v 44kw A9A (97-00)	BOSCH ABS ABR 5.3
 Xsara	ABS	1.9 D 8v 50kw DJY (97-00)	BOSCH ABS ABR 5.3
 Xsara	ABS	1.9 D 8v 50kw WJZ (97-00)	BOSCH ABS ABR 5.3
 Xsara	ABS	1.9 D 8v 55kw DHV (97-00)	BOSCH ABS ABR 5.3
 Xsara	ABS	1.9 D 8v 55kw DHV (97-00)	BOSCH ABS ABR 5.3
 Xsara	ABS	1.9 TD 8v 66kw DHY (97-00)	BOSCH ABS ABR 5.3
 Xsara	ABS	2.0 16v 123kw RFS (97-00)	BOSCH ABS ABR 5.3
 Xsara	ABS	2.0 16v 97kw RFV (97-00)	BOSCH ABS ABR 5.3
 Xsara	ABS	2.0 HDI 8v 66kw RHY (97-00)	BOSCH ABS ABR 5.3
 Xsara	ABS + TRACT. CONT	1.4 8v 55kw KFV (00-05)	BOSCH ESP 5.7 AUTODETECT
 Xsara	ABS + TRACT. CONT	1.4 8v 55kw KFV (02-05)	BOSCH ABS/ESP 5.7
 Xsara	ABS + TRACT. CONT	1.4 8v 55kw KFW (00-05)	BOSCH ESP 5.7 AUTODETECT
 Xsara	ABS + TRACT. CONT	1.4 8v 55kw KFW (02-05)	BOSCH ABS/ESP 5.7
 Xsara	ABS + TRACT. CONT	1.4 8v 55kw KFX (00-05)	BOSCH ESP 5.7 AUTODETECT
 Xsara	ABS + TRACT. CONT	1.4 8v 55kw KFX (02-05)	BOSCH ABS/ESP 5.7
 Xsara	ABS + TRACT. CONT	1.4 HDI 8v 52kw 8HZ (00-05)	BOSCH ESP 5.7 AUTODETECT
 Xsara	ABS + TRACT. CONT	1.4 HDI 8v 52kw 8HZ (02-05)	BOSCH ABS/ESP 5.7
 Xsara	ABS + TRACT. CONT	1.6 16v 80kw N6A (02-05)	BOSCH ABS/ESP 5.7
 Xsara	ABS + TRACT. CONT	1.6 16v 80kw NFU (00-05)	BOSCH ESP 5.7 AUTODETECT
 Xsara	ABS + TRACT. CONT	1.6 16v 80kw NFU (02-05)	BOSCH ABS/ESP 5.7
 Xsara	ABS + TRACT. CONT	1.6 16v 82kw N6A (00-05)	BOSCH ESP 5.7 AUTODETECT
 Xsara	ABS + TRACT. CONT	1.9 D 8v 52kw WJY (00-05)	BOSCH ESP 5.7 AUTODETECT
 Xsara	ABS + TRACT. CONT	1.9 D 8v 52kw WJY (02-05)	BOSCH ABS/ESP 5.7
 Xsara	ABS + TRACT. CONT	2.0 16v 101kw RFN (00-05)	ESP 5.7 AUTODETECT
 Xsara	ABS + TRACT. CONT	2.0 16v 101kw RFN (02-05)	BOSCH ABS/ESP 5.7
 Xsara	ABS + TRACT. CONT	2.0 16v 123kw RFS (00-05)	BOSCH ESP 5.7 AUTODETECT
 Xsara	ABS + TRACT. CONT	2.0 16v 123kw RFS (02-05)	BOSCH ABS/ESP 5.7
 Xsara	ABS + TRACT. CONT	2.0 HDI 8v 66kw RHY (00-05)	BOSCH ESP 5.7 AUTODETECT
 Xsara	ABS + TRACT. CONT	2.0 HDI 8v 66kw RHY (02-05)	BOSCH ABS/ESP 5.7
 Xsara	ABS + TRACT. CONT	2.0 HDI 8v 81kw RHZ (00-05)	BOSCH ESP 5.7 AUTODETECT
 Xsara	ABS + TRACT. CONT	2.0 HDI 8v 81kw RHZ (02-05)	BOSCH ABS/ESP 5.7
 Xsara	AIRBAG	1.4 8v 55kw KFV (00-03)	AKF- Autoliv AirBag ACUxx
 Xsara	AIRBAG	1.4 8v 55kw KFV (00-05)	AirBag CENTRAL AUTODETECT
 Xsara	AIRBAG	1.4 8v 55kw KFV (03-05)	AKF- Autoliv AirBag ACU3
 Xsara	AIRBAG	1.4 8v 55kw KFV (03-05)	TEMIC AirBag
 Xsara	AIRBAG	1.4 8v 55kw KFW (00-03)	AKF- Autoliv AirBag ACUxx
 Xsara	AIRBAG	1.4 8v 55kw KFW (00-05)	AirBag CENTRAL AUTODETECT
 Xsara	AIRBAG	1.4 8v 55kw KFW (03-05)	AKF- Autoliv AirBag ACU3
 Xsara	AIRBAG	1.4 8v 55kw KFW (03-05)	TEMIC AirBag
 Xsara	AIRBAG	1.4 8v 55kw KFX (00-03)	AKF- Autoliv AirBag ACUxx
 Xsara	AIRBAG	1.4 8v 55kw KFX (00-05)	AirBag CENTRAL AUTODETECT
 Xsara	AIRBAG	1.4 8v 55kw KFX (03-05)	AKF- Autoliv AirBag ACU3
 Xsara	AIRBAG	1.4 8v 55kw KFX (03-05)	TEMIC AirBag

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Xsara	AIRBAG	1.4 8v 55kw KFX (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xsara	AIRBAG	1.4 8v 55kw KFX (97-00)	AKF- Autoliv Side Airbag Left Side
 Xsara	AIRBAG	1.4 8v 55kw KFX (97-00)	AKF- Autoliv Side Airbag Right Side
 Xsara	AIRBAG	1.4 HDI 8v 52kw 8HZ (00-03)	AKF- Autoliv AirBag ACUxx
 Xsara	AIRBAG	1.4 HDI 8v 52kw 8HZ (00-05)	AirBag CENTRAL AUTODETECT
 Xsara	AIRBAG	1.5 D 8v 40kw VJY (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xsara	AIRBAG	1.5 D 8v 40kw VJY (97-00)	AKF- Autoliv Side Airbag Left Side
 Xsara	AIRBAG	1.5 D 8v 40kw VJY (97-00)	AKF- Autoliv Side Airbag Right Side
 Xsara	AIRBAG	1.5 D 8v 42kw VJZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xsara	AIRBAG	1.5 D 8v 42kw VJZ (97-00)	AKF- Autoliv Side Airbag Left Side
 Xsara	AIRBAG	1.5 D 8v 42kw VJZ (97-00)	AKF- Autoliv Side Airbag Right Side
 Xsara	AIRBAG	1.6 16v 80kw N6A (00-03)	AKF- Autoliv AirBag ACUxx
 Xsara	AIRBAG	1.6 16v 80kw N6A (00-05)	AirBag CENTRAL AUTODETECT
 Xsara	AIRBAG	1.6 16v 80kw N6A (03-05)	AKF- Autoliv AirBag ACU3
 Xsara	AIRBAG	1.6 16v 80kw N6A (03-05)	TEMIC AirBag
 Xsara	AIRBAG	1.6 16v 80kw NFU (00-03)	AKF- Autoliv AirBag ACUxx
 Xsara	AIRBAG	1.6 16v 80kw NFU (00-05)	AirBag CENTRAL AUTODETECT
 Xsara	AIRBAG	1.6 16v 80kw NFU (03-05)	AKF- Autoliv AirBag ACU3
 Xsara	AIRBAG	1.6 16v 80kw NFU (03-05)	TEMIC AirBag
 Xsara	AIRBAG	1.6 8v 66kw NFZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xsara	AIRBAG	1.6 8v 66kw NFZ (97-00)	AKF- Autoliv Side Airbag Left Side
 Xsara	AIRBAG	1.6 8v 66kw NFZ (97-00)	AKF- Autoliv Side Airbag Right Side
 Xsara	AIRBAG	1.8 16v 82kw LFX (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xsara	AIRBAG	1.8 16v 82kw LFX (97-00)	AKF- Autoliv Side Airbag Left Side
 Xsara	AIRBAG	1.8 16v 82kw LFX (97-00)	AKF- Autoliv Side Airbag Right Side
 Xsara	AIRBAG	1.8 8v 66kw LFX (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xsara	AIRBAG	1.8 8v 66kw LFX (97-00)	AKF- Autoliv Side Airbag Left Side
 Xsara	AIRBAG	1.8 8v 66kw LFX (97-00)	AKF- Autoliv Side Airbag Right Side
 Xsara	AIRBAG	1.8 8v 74kw LFZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xsara	AIRBAG	1.8 8v 74kw LFZ (97-00)	AKF- Autoliv Side Airbag Left Side
 Xsara	AIRBAG	1.8 8v 74kw LFZ (97-00)	AKF- Autoliv Side Airbag Right Side
 Xsara	AIRBAG	1.8 D 8v 44kw A9A (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xsara	AIRBAG	1.8 D 8v 44kw A9A (97-00)	AKF- Autoliv Side Airbag Left Side
 Xsara	AIRBAG	1.8 D 8v 44kw A9A (97-00)	AKF- Autoliv Side Airbag Right Side
 Xsara	AIRBAG	1.9 D 8v 50kw DJY (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xsara	AIRBAG	1.9 D 8v 50kw DJY (97-00)	AKF- Autoliv Side Airbag Left Side
 Xsara	AIRBAG	1.9 D 8v 50kw DJY (97-00)	AKF- Autoliv Side Airbag Right Side
 Xsara	AIRBAG	1.9 D 8v 50kw WJZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xsara	AIRBAG	1.9 D 8v 50kw WJZ (97-00)	AKF- Autoliv Side Airbag Left Side
 Xsara	AIRBAG	1.9 D 8v 50kw WJZ (97-00)	AKF- Autoliv Side Airbag Right Side
 Xsara	AIRBAG	1.9 D 8v 52kw WJY (00-03)	AKF- Autoliv AirBag ACUxx
 Xsara	AIRBAG	1.9 D 8v 52kw WJY (00-05)	AirBag CENTRAL AUTODETECT
 Xsara	AIRBAG	1.9 D 8v 52kw WJY (03-05)	AKF- Autoliv AirBag ACU3
 Xsara	AIRBAG	1.9 D 8v 52kw WJY (03-05)	TEMIC AirBag
 Xsara	AIRBAG	1.9 D 8v 55kw DHV (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xsara	AIRBAG	1.9 D 8v 55kw DHV (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xsara	AIRBAG	1.9 D 8v 55kw DHV (97-00)	AKF- Autoliv Side Airbag Left Side
 Xsara	AIRBAG	1.9 D 8v 55kw DHV (97-00)	AKF- Autoliv Side Airbag Left Side
 Xsara	AIRBAG	1.9 D 8v 55kw DHV (97-00)	AKF- Autoliv Side Airbag Right Side
 Xsara	AIRBAG	1.9 D 8v 55kw DHV (97-00)	AKF- Autoliv Side Airbag Right Side
 Xsara	AIRBAG	1.9 TD 8v 66kw DHY (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xsara	AIRBAG	1.9 TD 8v 66kw DHY (97-00)	AKF- Autoliv Side Airbag Left Side
 Xsara	AIRBAG	1.9 TD 8v 66kw DHY (97-00)	AKF- Autoliv Side Airbag Right Side
 Xsara	AIRBAG	2.0 16v 101kw RFN (00-03)	AKF- Autoliv AirBag ACUxx
 Xsara	AIRBAG	2.0 16v 101kw RFN (00-05)	AirBag CENTRAL AUTODETECT
 Xsara	AIRBAG	2.0 16v 101kw RFN (03-05)	AKF- Autoliv AirBag ACU3
 Xsara	AIRBAG	2.0 16v 101kw RFN (03-05)	TEMIC AirBag
 Xsara	AIRBAG	2.0 16v 123kw RFS (00-03)	AKF- Autoliv AirBag ACUxx

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Xsara	AIRBAG	2.0 16v 123kw RFS (00-05)	AirBag CENTRAL AUTODETECT
 Xsara	AIRBAG	2.0 16v 123kw RFS (03-05)	AKF- Autoliv AirBag ACU3
 Xsara	AIRBAG	2.0 16v 123kw RFS (03-05)	TEMIC AirBag
 Xsara	AIRBAG	2.0 16v 123kw RFS (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xsara	AIRBAG	2.0 16v 123kw RFS (97-00)	AKF- Autoliv Side Airbag Left Side
 Xsara	AIRBAG	2.0 16v 123kw RFS (97-00)	AKF- Autoliv Side Airbag Right Side
 Xsara	AIRBAG	2.0 16v 97kw RFV (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xsara	AIRBAG	2.0 16v 97kw RFV (97-00)	AKF- Autoliv Side Airbag Left Side
 Xsara	AIRBAG	2.0 16v 97kw RFV (97-00)	AKF- Autoliv Side Airbag Right Side
 Xsara	AIRBAG	2.0 HDI 8v 66kw RHY (00-03)	AKF- Autoliv AirBag ACUxx
 Xsara	AIRBAG	2.0 HDI 8v 66kw RHY (00-05)	AirBag CENTRAL AUTODETECT
 Xsara	AIRBAG	2.0 HDI 8v 66kw RHY (03-05)	AKF- Autoliv AirBag ACU3
 Xsara	AIRBAG	2.0 HDI 8v 66kw RHY (03-05)	TEMIC AirBag
 Xsara	AIRBAG	2.0 HDI 8v 66kw RHY (97-00)	AKF- Autoliv AirBag no SIDE AB
 Xsara	AIRBAG	2.0 HDI 8v 66kw RHY (97-00)	AKF- Autoliv Side Airbag Left Side
 Xsara	AIRBAG	2.0 HDI 8v 66kw RHY (97-00)	AKF- Autoliv Side Airbag Right Side
 Xsara	AIRBAG	2.0 HDI 8v 81kw RHZ (00-03)	AKF- Autoliv AirBag ACUxx
 Xsara	AIRBAG	2.0 HDI 8v 81kw RHZ (00-05)	AirBag CENTRAL AUTODETECT
 Xsara	AIRBAG	2.0 HDI 8v 81kw RHZ (03-05)	AKF- Autoliv AirBag ACU3
 Xsara	AIRBAG	2.0 HDI 8v 81kw RHZ (03-05)	TEMIC AirBag
 Xsara	ANTITHEFT	1.4 8v 55kw KfV (00-05)	Alarm PSA2 AUTODETECT
 Xsara	ANTITHEFT	1.4 8v 55kw KfW (00-05)	Alarm PSA2 AUTODETECT
 Xsara	ANTITHEFT	1.4 8v 55kw KfX (00-05)	Alarm PSA2 AUTODETECT
 Xsara	ANTITHEFT	1.4 HDI 8v 52kw 8HZ (00-05)	Alarm PSA2 AUTODETECT
 Xsara	ANTITHEFT	1.6 16v 80kw N6A (00-05)	Alarm PSA2 AUTODETECT
 Xsara	ANTITHEFT	1.6 16v 80kw NFU (00-05)	Alarm PSA2 AUTODETECT
 Xsara	ANTITHEFT	1.9 D 8v 52kw WJY (00-05)	Alarm PSA2 AUTODETECT
 Xsara	ANTITHEFT	2.0 16v 101kw RFN (00-05)	Alarm PSA2 AUTODETECT
 Xsara	ANTITHEFT	2.0 16v 123kw RFS (00-05)	Alarm PSA2 AUTODETECT
 Xsara	ANTITHEFT	2.0 HDI 8v 66kw RHY (00-05)	Alarm PSA2 AUTODETECT
 Xsara	ANTITHEFT	2.0 HDI 8v 81kw RHZ (00-05)	Alarm PSA2 AUTODETECT
 Xsara	AUTOM. TRANSMISSI	1.4 8v 55kw KfV (00-05)	A/T AL4 AUTODETECT
 Xsara	AUTOM. TRANSMISSI	1.4 8v 55kw KfW (00-05)	A/T AL4 AUTODETECT
 Xsara	AUTOM. TRANSMISSI	1.4 8v 55kw KfX (00-05)	A/T AL4 AUTODETECT
 Xsara	AUTOM. TRANSMISSI	1.4 HDI 8v 52kw 8HZ (00-05)	A/T AL4 AUTODETECT
 Xsara	AUTOM. TRANSMISSI	1.6 16v 80kw N6A (00-05)	A/T AL4 AUTODETECT
 Xsara	AUTOM. TRANSMISSI	1.6 16v 80kw NFU (00-05)	A/T AL4 AUTODETECT
 Xsara	AUTOM. TRANSMISSI	1.9 D 8v 52kw WJY (00-05)	A/T AL4 AUTODETECT
 Xsara	AUTOM. TRANSMISSI	2.0 16v 101kw RFN (00-05)	A/T AL4 AUTODETECT
 Xsara	AUTOM. TRANSMISSI	2.0 16v 123kw RFS (00-05)	A/T AL4 AUTODETECT
 Xsara	AUTOM. TRANSMISSI	2.0 HDI 8v 66kw RHY (00-05)	A/T AL4 AUTODETECT
 Xsara	AUTOM. TRANSMISSI	2.0 HDI 8v 81kw RHZ (00-05)	A/T AL4 AUTODETECT
 Xsara	AUX. HEATING	1.4 8v 55kw KfV (00-05)	AUTODETECT
 Xsara	AUX. HEATING	1.4 8v 55kw KfW (00-05)	AUTODETECT
 Xsara	AUX. HEATING	1.4 8v 55kw KfX (00-05)	AUTODETECT
 Xsara	AUX. HEATING	1.4 HDI 8v 52kw 8HZ (00-05)	AUTODETECT
 Xsara	AUX. HEATING	1.6 16v 80kw N6A (00-05)	AUTODETECT
 Xsara	AUX. HEATING	1.6 16v 80kw NFU (00-05)	AUTODETECT
 Xsara	AUX. HEATING	1.9 D 8v 52kw WJY (00-05)	AUTODETECT
 Xsara	AUX. HEATING	2.0 16v 101kw RFN (00-05)	AUTODETECT
 Xsara	AUX. HEATING	2.0 16v 123kw RFS (00-05)	AUTODETECT
 Xsara	AUX. HEATING	2.0 HDI 8v 66kw RHY (00-05)	AUTODETECT
 Xsara	AUX. HEATING	2.0 HDI 8v 81kw RHZ (00-05)	AUTODETECT
 Xsara	CHASSIS NETWORK	1.4 8v 55kw KfV (00-05)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	1.4 8v 55kw KfW (00-05)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	1.4 8v 55kw KfX (00-05)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	1.4 8v 55kw KfW (00-05)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	1.4 8v 55kw KfX (00-05)	Body Computer BSI AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Xsara	CHASSIS NETWORK	1.4 8v 55kw KFX (00-05)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	1.4 8v 55kw KFX (97-00)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	1.4 8v 55kw KFX (97-00)	VALEO Body Computer
 Xsara	CHASSIS NETWORK	1.4 HDI 8v 52kw 8HZ (00-05)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	1.4 HDI 8v 52kw 8HZ (00-05)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	1.5 D 8v 40kw VJY (97-00)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	1.5 D 8v 40kw VJY (97-00)	VALEO Body Computer
 Xsara	CHASSIS NETWORK	1.5 D 8v 42kw VJZ (97-00)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	1.5 D 8v 42kw VJZ (97-00)	VALEO Body Computer
 Xsara	CHASSIS NETWORK	1.6 16v 80kw N6A (00-05)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	1.6 16v 80kw N6A (00-05)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	1.6 16v 80kw NFU (00-05)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	1.6 16v 80kw NFU (00-05)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	1.6 8v 66kw NFZ (97-00)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	1.6 8v 66kw NFZ (97-00)	VALEO Body Computer
 Xsara	CHASSIS NETWORK	1.8 16v 82kw LFY (97-00)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	1.8 16v 82kw LFY (97-00)	VALEO Body Computer
 Xsara	CHASSIS NETWORK	1.8 8v 66kw LFX (97-00)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	1.8 8v 66kw LFX (97-00)	VALEO Body Computer
 Xsara	CHASSIS NETWORK	1.8 8v 74kw LFZ (97-00)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	1.8 8v 74kw LFZ (97-00)	VALEO Body Computer
 Xsara	CHASSIS NETWORK	1.8 D 8v 44kw A9A (97-00)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	1.8 D 8v 44kw A9A (97-00)	VALEO Body Computer
 Xsara	CHASSIS NETWORK	1.9 D 8v 50kw DJY (97-00)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	1.9 D 8v 50kw DJY (97-00)	VALEO Body Computer
 Xsara	CHASSIS NETWORK	1.9 D 8v 50kw WJZ (97-00)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	1.9 D 8v 50kw WJZ (97-00)	VALEO Body Computer
 Xsara	CHASSIS NETWORK	1.9 D 8v 52kw WJY (00-05)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	1.9 D 8v 52kw WJY (00-05)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	1.9 D 8v 55kw DHV (97-00)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	1.9 D 8v 55kw DHV (97-00)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	1.9 D 8v 55kw DHV (97-00)	VALEO Body Computer
 Xsara	CHASSIS NETWORK	1.9 D 8v 55kw DHV (97-00)	VALEO Body Computer
 Xsara	CHASSIS NETWORK	1.9 TD 8v 66kw DHY (97-00)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	1.9 TD 8v 66kw DHY (97-00)	VALEO Body Computer
 Xsara	CHASSIS NETWORK	2.0 16v 101kw RFN (00-05)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	2.0 16v 101kw RFN (00-05)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	2.0 16v 123kw RFS (00-05)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	2.0 16v 123kw RFS (00-05)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	2.0 16v 123kw RFS (97-00)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	2.0 16v 123kw RFS (97-00)	VALEO Body Computer
 Xsara	CHASSIS NETWORK	2.0 16v 97kw RFV (97-00)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	2.0 16v 97kw RFV (97-00)	VALEO Body Computer
 Xsara	CHASSIS NETWORK	2.0 HDI 8v 66kw RHY (00-05)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	2.0 HDI 8v 66kw RHY (00-05)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	2.0 HDI 8v 66kw RHY (97-00)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	2.0 HDI 8v 66kw RHY (97-00)	VALEO Body Computer
 Xsara	CHASSIS NETWORK	2.0 HDI 8v 81kw RHZ (00-05)	Body Computer BSI AUTODETECT
 Xsara	CHASSIS NETWORK	2.0 HDI 8v 81kw RHZ (00-05)	Body Computer BSI AUTODETECT
 Xsara	CLIMA	1.4 8v 55kw KFX (00-05)	CLIMA AUTO AUTODETECT
 Xsara	CLIMA	1.4 8v 55kw KFX (00-05)	CLIMA AUTO AUTODETECT
 Xsara	CLIMA	1.4 8v 55kw KFX (00-05)	CLIMA AUTO AUTODETECT
 Xsara	CLIMA	1.4 HDI 8v 52kw 8HZ (00-05)	CLIMA AUTO AUTODETECT
 Xsara	CLIMA	1.6 16v 80kw N6A (00-05)	CLIMA AUTO AUTODETECT
 Xsara	CLIMA	1.6 16v 80kw NFU (00-05)	CLIMA AUTO AUTODETECT
 Xsara	CLIMA	1.9 D 8v 52kw WJY (00-05)	CLIMA AUTO AUTODETECT
 Xsara	CLIMA	2.0 16v 101kw RFN (00-05)	CLIMA AUTO AUTODETECT
 Xsara	CLIMA	2.0 16v 123kw RFS (00-05)	CLIMA AUTO AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Xsara	CLIMA	2.0 HDI 8v 66kw RHY (00-05)	CLIMA AUTO AUTODETECT
 Xsara	CLIMA	2.0 HDI 8v 81kw RHZ (00-05)	CLIMA AUTO AUTODETECT
 Xsara	COMFORT SYSTEM	1.4 8v 55kw KFV (00-05)	AUTODETECT
 Xsara	COMFORT SYSTEM	1.4 8v 55kw KFV (00-05)	AUTODETECT
 Xsara	COMFORT SYSTEM	1.4 8v 55kw KFV (00-05)	School Module AUTODETECT
 Xsara	COMFORT SYSTEM	1.4 8v 55kw KFW (00-05)	AUTODETECT
 Xsara	COMFORT SYSTEM	1.4 8v 55kw KFW (00-05)	AUTODETECT
 Xsara	COMFORT SYSTEM	1.4 8v 55kw KFW (00-05)	School Module AUTODETECT
 Xsara	COMFORT SYSTEM	1.4 8v 55kw KFX (00-05)	AUTODETECT
 Xsara	COMFORT SYSTEM	1.4 8v 55kw KFX (00-05)	AUTODETECT
 Xsara	COMFORT SYSTEM	1.4 8v 55kw KFX (00-05)	School Module AUTODETECT
 Xsara	COMFORT SYSTEM	1.4 HDI 8v 52kw 8HZ (00-05)	AUTODETECT
 Xsara	COMFORT SYSTEM	1.4 HDI 8v 52kw 8HZ (00-05)	AUTODETECT
 Xsara	COMFORT SYSTEM	1.4 HDI 8v 52kw 8HZ (00-05)	School Module AUTODETECT
 Xsara	COMFORT SYSTEM	1.6 16v 80kw N6A (00-05)	AUTODETECT
 Xsara	COMFORT SYSTEM	1.6 16v 80kw N6A (00-05)	AUTODETECT
 Xsara	COMFORT SYSTEM	1.6 16v 80kw N6A (00-05)	School Module AUTODETECT
 Xsara	COMFORT SYSTEM	1.6 16v 80kw NFU (00-05)	AUTODETECT
 Xsara	COMFORT SYSTEM	1.6 16v 80kw NFU (00-05)	AUTODETECT
 Xsara	COMFORT SYSTEM	1.6 16v 80kw NFU (00-05)	School Module AUTODETECT
 Xsara	COMFORT SYSTEM	1.9 D 8v 52kw WJY (00-05)	AUTODETECT
 Xsara	COMFORT SYSTEM	1.9 D 8v 52kw WJY (00-05)	AUTODETECT
 Xsara	COMFORT SYSTEM	1.9 D 8v 52kw WJY (00-05)	School Module AUTODETECT
 Xsara	COMFORT SYSTEM	2.0 16v 101kw RFN (00-05)	AUTODETECT
 Xsara	COMFORT SYSTEM	2.0 16v 101kw RFN (00-05)	AUTODETECT
 Xsara	COMFORT SYSTEM	2.0 16v 101kw RFN (00-05)	School Module AUTODETECT
 Xsara	COMFORT SYSTEM	2.0 16v 123kw RFS (00-05)	AUTODETECT
 Xsara	COMFORT SYSTEM	2.0 16v 123kw RFS (00-05)	AUTODETECT
 Xsara	COMFORT SYSTEM	2.0 16v 123kw RFS (00-05)	School Module AUTODETECT
 Xsara	COMFORT SYSTEM	2.0 HDI 8v 66kw RHY (00-05)	AUTODETECT
 Xsara	COMFORT SYSTEM	2.0 HDI 8v 66kw RHY (00-05)	AUTODETECT
 Xsara	COMFORT SYSTEM	2.0 HDI 8v 66kw RHY (00-05)	School Module AUTODETECT
 Xsara	COMFORT SYSTEM	2.0 HDI 8v 81kw RHZ (00-05)	AUTODETECT
 Xsara	COMFORT SYSTEM	2.0 HDI 8v 81kw RHZ (00-05)	AUTODETECT
 Xsara	COMFORT SYSTEM	2.0 HDI 8v 81kw RHZ (00-05)	School Module AUTODETECT
 Xsara	DASHBOARD	1.4 8v 55kw KFV (00-05)	AUTODETECT
 Xsara	DASHBOARD	1.4 8v 55kw KFW (00-05)	AUTODETECT
 Xsara	DASHBOARD	1.4 8v 55kw KFX (00-05)	AUTODETECT
 Xsara	DASHBOARD	1.4 8v 55kw KFX (97-00)	AUTODETECT
 Xsara	DASHBOARD	1.4 HDI 8v 52kw 8HZ (00-05)	AUTODETECT
 Xsara	DASHBOARD	1.5 D 8v 40kw VJY (97-00)	AUTODETECT
 Xsara	DASHBOARD	1.5 D 8v 42kw VJZ (97-00)	AUTODETECT
 Xsara	DASHBOARD	1.6 16v 80kw N6A (00-05)	AUTODETECT
 Xsara	DASHBOARD	1.6 16v 80kw NFU (00-05)	AUTODETECT
 Xsara	DASHBOARD	1.6 8v 66kw NFZ (97-00)	AUTODETECT
 Xsara	DASHBOARD	1.8 16v 82kw LFY (97-00)	AUTODETECT
 Xsara	DASHBOARD	1.8 8v 66kw LFX (97-00)	AUTODETECT
 Xsara	DASHBOARD	1.8 8v 74kw LFZ (97-00)	AUTODETECT
 Xsara	DASHBOARD	1.8 D 8v 44kw A9A (97-00)	AUTODETECT
 Xsara	DASHBOARD	1.9 D 8v 50kw DJY (97-00)	AUTODETECT
 Xsara	DASHBOARD	1.9 D 8v 50kw WJZ (97-00)	AUTODETECT
 Xsara	DASHBOARD	1.9 D 8v 52kw WJY (00-05)	AUTODETECT
 Xsara	DASHBOARD	1.9 D 8v 55kw DHV (97-00)	AUTODETECT
 Xsara	DASHBOARD	1.9 D 8v 55kw DHV (97-00)	AUTODETECT
 Xsara	DASHBOARD	1.9 TD 8v 66kw DHY (97-00)	AUTODETECT
 Xsara	DASHBOARD	2.0 16v 101kw RFN (00-05)	AUTODETECT
 Xsara	DASHBOARD	2.0 16v 123kw RFS (00-05)	AUTODETECT
 Xsara	DASHBOARD	2.0 16v 123kw RFS (97-00)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Xsara	DASHBOARD	2.0 16v 97kw RFV (97-00)	AUTODETECT
 Xsara	DASHBOARD	2.0 HDI 8v 66kw RHY (00-05)	AUTODETECT
 Xsara	DASHBOARD	2.0 HDI 8v 81kw RHZ (00-05)	AUTODETECT
 Xsara	DIESEL ADDITION	2.0 HDI 8v 66kw RHY (00-05)	AUTODETECT
 Xsara	DIESEL ADDITION	2.0 HDI 8v 81kw RHZ (00-05)	AUTODETECT
 Xsara	DIESEL MANAGEMEN	1.9 D 8v 52kw WJY (00-05)	LUCAS DCN2 AUTODETECT
 Xsara	DIESEL MANAGEMEN	1.9 D 8v 55kw DHV (97-00)	BOSCH AS3 VP20
 Xsara	ENGINE MANAGEME	1.4 8v 55kw KfV (00-05)	SAGEM S2000
 Xsara	ENGINE MANAGEME	1.4 8v 55kw KfV (00-05)	SAGEM S2000 AUTODETECT
 Xsara	ENGINE MANAGEME	1.4 8v 55kw KfV (00-05)	SAGEM S2000
 Xsara	ENGINE MANAGEME	1.4 8v 55kw KfV (00-05)	SAGEM S2000 AUTODETECT
 Xsara	ENGINE MANAGEME	1.4 8v 55kw KfV (00-05)	SAGEM S2000
 Xsara	ENGINE MANAGEME	1.4 8v 55kw KfV (00-05)	SAGEM S2000 AUTODETECT
 Xsara	ENGINE MANAGEME	1.4 8v 55kw KfV (97-00)	Marelli MM 1AP.40
 Xsara	ENGINE MANAGEME	1.4 8v 55kw KfV (97-00)	SAGEM SL 96
 Xsara	ENGINE MANAGEME	1.4 HDI 8v 52kw 8HZ (00-05)	BOSCH EDC16 C3 Common Rail AUTODE
 Xsara	ENGINE MANAGEME	1.4 HDI 8v 52kw 8HZ (02-05)	BOSCH EDC 16 C3 Common Rail
 Xsara	ENGINE MANAGEME	1.6 16v 80kw N6A (00-05)	BOSCH ME 7.4.4 AUTODETECT
 Xsara	ENGINE MANAGEME	1.6 16v 80kw NFU (00-05)	BOSCH ME 7.4.4 AUTODETECT
 Xsara	ENGINE MANAGEME	1.6 16v 80kw NFU (00-05)	BOSCH Motronic ME7.4.4
 Xsara	ENGINE MANAGEME	1.6 8v 66kw NFZ (97-00)	BOSCH Motronic MP5.2
 Xsara	ENGINE MANAGEME	1.6 8v 66kw NFZ (97-00)	BOSCH Motronic MP7.2
 Xsara	ENGINE MANAGEME	1.8 16v 82kw LFY (97-00)	SAGEM SL 96
 Xsara	ENGINE MANAGEME	2.0 16v 101kw RFN (00-05)	Marelli MM48P AUTODETECT
 Xsara	ENGINE MANAGEME	2.0 16v 101kw RFN (00-05)	Marelli MM4MP2 AUTODETECT
 Xsara	ENGINE MANAGEME	2.0 16v 101kw RFN (00-05)	Marelli MM6LP AUTODETECT
 Xsara	ENGINE MANAGEME	2.0 16v 123kw RFS (00-05)	Souspapes AUTODETECT
 Xsara	ENGINE MANAGEME	2.0 HDI 8v 66kw RHY (00-05)	BOSCH EDC 15 C2 Common Rail
 Xsara	ENGINE MANAGEME	2.0 HDI 8v 66kw RHY (00-05)	BOSCH EDC15 C2 Common Rail AUTODE
 Xsara	ENGINE MANAGEME	2.0 HDI 8v 66kw RHY (00-05)	SIEMENS Diesel SID 801 Common Rail
 Xsara	ENGINE MANAGEME	2.0 HDI 8v 66kw RHY (00-05)	SIEMENS SID 801 Common Rail AUTODE
 Xsara	ENGINE MANAGEME	2.0 HDI 8v 66kw RHY (03-05)	BOSCH EDC 15 C2 Common Rail
 Xsara	ENGINE MANAGEME	2.0 HDI 8v 66kw RHY (97-00)	BOSCH EDC 15 C2 Common Rail
 Xsara	ENGINE MANAGEME	2.0 HDI 8v 66kw RHY (97-00)	BOSCH EDC15 C2 Common Rail AUTODE
 Xsara	ENGINE MANAGEME	2.0 HDI 8v 66kw RHY (97-00)	SIEMENS Diesel SID 801 Common Rail
 Xsara	ENGINE MANAGEME	2.0 HDI 8v 81kw RHZ (00-05)	BOSCH EDC 15 C2 Common Rail
 Xsara	ENGINE MANAGEME	2.0 HDI 8v 81kw RHZ (00-05)	BOSCH EDC15 C2 Common Rail AUTODE
 Xsara	KEY ENCODE	1.4 8v 55kw KfV (00-05)	VALEO Body Siemens
 Xsara	KEY ENCODE	1.4 8v 55kw KfV (00-05)	VALEO Body Siemens
 Xsara	KEY ENCODE	1.4 8v 55kw KfV (00-05)	VALEO Body Siemens
 Xsara	KEY ENCODE	1.4 HDI 8v 52kw 8HZ (00-05)	VALEO Body Siemens
 Xsara	KEY ENCODE	1.6 16v 80kw N6A (00-05)	VALEO Body Siemens
 Xsara	KEY ENCODE	1.6 16v 80kw NFU (00-05)	VALEO Body Siemens
 Xsara	KEY ENCODE	1.9 D 8v 52kw WJY (00-05)	VALEO Body Siemens
 Xsara	KEY ENCODE	2.0 16v 101kw RFN (00-05)	VALEO Body Siemens
 Xsara	KEY ENCODE	2.0 16v 123kw RFS (00-05)	VALEO Body Siemens
 Xsara	KEY ENCODE	2.0 HDI 8v 66kw RHY (00-05)	VALEO Body Siemens
 Xsara	KEY ENCODE	2.0 HDI 8v 81kw RHZ (00-05)	VALEO Body Siemens
 Xsara	MAINTENANCE	1.4 8v 55kw KfV (00-05)	A/T AL4 AUTODETECT
 Xsara	MAINTENANCE	1.4 8v 55kw KfV (00-05)	Body Computer BSI AUTODETECT
 Xsara	MAINTENANCE	1.4 8v 55kw KfV (00-05)	Body Computer BSI AUTODETECT
 Xsara	MAINTENANCE	1.4 8v 55kw KfV (00-05)	BOSCH ESP 5.7 AUTODETECT
 Xsara	MAINTENANCE	1.4 8v 55kw KfV (00-05)	BOSCH ESP 5.7 AUTODETECT
 Xsara	MAINTENANCE	1.4 8v 55kw KfV (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.4 8v 55kw KfV (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.4 8v 55kw KfV (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.4 8v 55kw KfV (02-05)	BOSCH ABS/ESP 5.7

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Xsara	MAINTENANCE	1.4 8v 55kw KFV (02-05)	Valeo Body Computer MANUAL
 Xsara	MAINTENANCE	1.4 8v 55kw KFV (03-05)	AKF- Autoliv AirBag ACU3
 Xsara	MAINTENANCE	1.4 8v 55kw KFV (03-05)	TEMIC AirBag
 Xsara	MAINTENANCE	1.4 8v 55kw KFW (00-05)	A/T AL4 AUTODETECT
 Xsara	MAINTENANCE	1.4 8v 55kw KFW (00-05)	Body Computer BSI AUTODETECT
 Xsara	MAINTENANCE	1.4 8v 55kw KFW (00-05)	Body Computer BSI AUTODETECT
 Xsara	MAINTENANCE	1.4 8v 55kw KFW (00-05)	BOSCH ESP 5.7 AUTODETECT
 Xsara	MAINTENANCE	1.4 8v 55kw KFW (00-05)	BOSCH ESP 5.7 AUTODETECT
 Xsara	MAINTENANCE	1.4 8v 55kw KFW (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.4 8v 55kw KFW (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.4 8v 55kw KFW (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.4 8v 55kw KFW (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.4 8v 55kw KFW (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.4 8v 55kw KFW (02-05)	Valeo Body Computer MANUAL
 Xsara	MAINTENANCE	1.4 8v 55kw KFW (03-05)	AKF- Autoliv AirBag ACU3
 Xsara	MAINTENANCE	1.4 8v 55kw KFW (03-05)	TEMIC AirBag
 Xsara	MAINTENANCE	1.4 8v 55kw KFX (00-05)	A/T AL4 AUTODETECT
 Xsara	MAINTENANCE	1.4 8v 55kw KFX (00-05)	Body Computer BSI AUTODETECT
 Xsara	MAINTENANCE	1.4 8v 55kw KFX (00-05)	Body Computer BSI AUTODETECT
 Xsara	MAINTENANCE	1.4 8v 55kw KFX (00-05)	BOSCH ESP 5.7 AUTODETECT
 Xsara	MAINTENANCE	1.4 8v 55kw KFX (00-05)	BOSCH ESP 5.7 AUTODETECT
 Xsara	MAINTENANCE	1.4 8v 55kw KFX (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.4 8v 55kw KFX (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.4 8v 55kw KFX (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.4 8v 55kw KFX (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.4 8v 55kw KFX (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.4 8v 55kw KFX (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.4 8v 55kw KFX (02-05)	Valeo Body Computer MANUAL
 Xsara	MAINTENANCE	1.4 8v 55kw KFX (03-05)	AKF- Autoliv AirBag ACU3
 Xsara	MAINTENANCE	1.4 8v 55kw KFX (03-05)	TEMIC AirBag
 Xsara	MAINTENANCE	1.4 8v 55kw KFX (97-00)	AUTODETECT
 Xsara	MAINTENANCE	1.4 8v 55kw KFX (97-00)	AUTODETECT
 Xsara	MAINTENANCE	1.4 8v 55kw KFX (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.4 8v 55kw KFX (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.4 8v 55kw KFX (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.4 8v 55kw KFX (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.4 8v 55kw KFX (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.4 8v 55kw KFX (98-00)	Sagem MANUAL
 Xsara	MAINTENANCE	1.4 HDI 8v 52kw 8HZ (00-05)	A/T AL4 AUTODETECT
 Xsara	MAINTENANCE	1.4 HDI 8v 52kw 8HZ (00-05)	Body Computer BSI AUTODETECT
 Xsara	MAINTENANCE	1.4 HDI 8v 52kw 8HZ (00-05)	Body Computer BSI AUTODETECT
 Xsara	MAINTENANCE	1.4 HDI 8v 52kw 8HZ (00-05)	BOSCH ESP 5.7 AUTODETECT
 Xsara	MAINTENANCE	1.4 HDI 8v 52kw 8HZ (00-05)	BOSCH ESP 5.7 AUTODETECT
 Xsara	MAINTENANCE	1.4 HDI 8v 52kw 8HZ (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.4 HDI 8v 52kw 8HZ (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.4 HDI 8v 52kw 8HZ (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.4 HDI 8v 52kw 8HZ (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.4 HDI 8v 52kw 8HZ (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.4 HDI 8v 52kw 8HZ (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.4 HDI 8v 52kw 8HZ (02-05)	Valeo Body Computer MANUAL
 Xsara	MAINTENANCE	1.5 D 8v 40kw VJY (97-00)	AUTODETECT
 Xsara	MAINTENANCE	1.5 D 8v 40kw VJY (97-00)	AUTODETECT
 Xsara	MAINTENANCE	1.5 D 8v 40kw VJY (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.5 D 8v 40kw VJY (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.5 D 8v 40kw VJY (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.5 D 8v 40kw VJY (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.5 D 8v 40kw VJY (98-00)	Sagem MANUAL
 Xsara	MAINTENANCE	1.5 D 8v 42kw VJZ (97-00)	AUTODETECT
Xsara	MAINTENANCE	1.5 D 8v 42kw VJZ (97-00)	AUTODETECT
Xsara	MAINTENANCE	1.5 D 8v 42kw VJZ (97-00)	BOSCH ABS ABR 5.3
Xsara	MAINTENANCE	1.5 D 8v 42kw VJZ (97-00)	BOSCH ABS ABR 5.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Xsara	MAINTENANCE	1.5 D 8v 42kw VJZ (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.5 D 8v 42kw VJZ (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.5 D 8v 42kw VJZ (98-00)	Sagem MANUAL
 Xsara	MAINTENANCE	1.6 16v 80kw N6A (00-05)	A/T AL4 AUTODETECT
 Xsara	MAINTENANCE	1.6 16v 80kw N6A (00-05)	Body Computer BSI AUTODETECT
 Xsara	MAINTENANCE	1.6 16v 80kw N6A (00-05)	Body Computer BSI AUTODETECT
 Xsara	MAINTENANCE	1.6 16v 80kw N6A (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.6 16v 80kw N6A (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.6 16v 80kw N6A (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.6 16v 80kw N6A (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.6 16v 80kw N6A (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.6 16v 80kw N6A (03-05)	Valeo Body Computer MANUAL
 Xsara	MAINTENANCE	1.6 16v 80kw N6A (03-05)	AKF- Autoliv AirBag ACU3
 Xsara	MAINTENANCE	1.6 16v 80kw N6A (03-05)	TEMIC AirBag
 Xsara	MAINTENANCE	1.6 16v 80kw NFU (00-05)	A/T AL4 AUTODETECT
 Xsara	MAINTENANCE	1.6 16v 80kw NFU (00-05)	Body Computer BSI AUTODETECT
 Xsara	MAINTENANCE	1.6 16v 80kw NFU (00-05)	Body Computer BSI AUTODETECT
 Xsara	MAINTENANCE	1.6 16v 80kw NFU (00-05)	BOSCH ESP 5.7 AUTODETECT
 Xsara	MAINTENANCE	1.6 16v 80kw NFU (00-05)	BOSCH ESP 5.7 AUTODETECT
 Xsara	MAINTENANCE	1.6 16v 80kw NFU (00-05)	BOSCH ESP 5.7 AUTODETECT
 Xsara	MAINTENANCE	1.6 16v 80kw NFU (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.6 16v 80kw NFU (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.6 16v 80kw NFU (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.6 16v 80kw NFU (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.6 16v 80kw NFU (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.6 16v 80kw NFU (02-05)	Valeo Body Computer MANUAL
 Xsara	MAINTENANCE	1.6 16v 80kw NFU (03-05)	AKF- Autoliv AirBag ACU3
 Xsara	MAINTENANCE	1.6 16v 80kw NFU (03-05)	TEMIC AirBag
 Xsara	MAINTENANCE	1.6 16v 82kw N6A (00-05)	BOSCH ESP 5.7 AUTODETECT
 Xsara	MAINTENANCE	1.6 16v 82kw N6A (00-05)	BOSCH ESP 5.7 AUTODETECT
 Xsara	MAINTENANCE	1.6 8v 66kw NFZ (97-00)	AUTODETECT
 Xsara	MAINTENANCE	1.6 8v 66kw NFZ (97-00)	AUTODETECT
 Xsara	MAINTENANCE	1.6 8v 66kw NFZ (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.6 8v 66kw NFZ (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.6 8v 66kw NFZ (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.6 8v 66kw NFZ (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.6 8v 66kw NFZ (98-00)	Sagem MANUAL
 Xsara	MAINTENANCE	1.8 16v 82kw LFY (97-00)	AUTODETECT
 Xsara	MAINTENANCE	1.8 16v 82kw LFY (97-00)	AUTODETECT
 Xsara	MAINTENANCE	1.8 16v 82kw LFY (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.8 16v 82kw LFY (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.8 16v 82kw LFY (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.8 16v 82kw LFY (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.8 16v 82kw LFY (98-00)	Sagem MANUAL
 Xsara	MAINTENANCE	1.8 8v 66kw LFX (97-00)	AUTODETECT
 Xsara	MAINTENANCE	1.8 8v 66kw LFX (97-00)	AUTODETECT
 Xsara	MAINTENANCE	1.8 8v 66kw LFX (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.8 8v 66kw LFX (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.8 8v 66kw LFX (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.8 8v 66kw LFX (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.8 8v 66kw LFX (98-00)	Sagem MANUAL
 Xsara	MAINTENANCE	1.8 8v 74kw LFZ (97-00)	AUTODETECT
 Xsara	MAINTENANCE	1.8 8v 74kw LFZ (97-00)	AUTODETECT
 Xsara	MAINTENANCE	1.8 8v 74kw LFZ (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.8 8v 74kw LFZ (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.8 8v 74kw LFZ (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.8 8v 74kw LFZ (98-00)	Sagem MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Xsara	MAINTENANCE	1.8 D 8v 44kw A9A (97-00)	AUTODETECT
 Xsara	MAINTENANCE	1.8 D 8v 44kw A9A (97-00)	AUTODETECT
 Xsara	MAINTENANCE	1.8 D 8v 44kw A9A (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.8 D 8v 44kw A9A (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.8 D 8v 44kw A9A (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.8 D 8v 44kw A9A (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.8 D 8v 44kw A9A (98-00)	Sagem MANUAL
 Xsara	MAINTENANCE	1.9 D 8v 50kw DJY (97-00)	AUTODETECT
 Xsara	MAINTENANCE	1.9 D 8v 50kw DJY (97-00)	AUTODETECT
 Xsara	MAINTENANCE	1.9 D 8v 50kw DJY (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.9 D 8v 50kw DJY (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.9 D 8v 50kw DJY (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.9 D 8v 50kw DJY (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.9 D 8v 50kw DJY (98-00)	Sagem MANUAL
 Xsara	MAINTENANCE	1.9 D 8v 50kw WJZ (97-00)	AUTODETECT
 Xsara	MAINTENANCE	1.9 D 8v 50kw WJZ (97-00)	AUTODETECT
 Xsara	MAINTENANCE	1.9 D 8v 50kw WJZ (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.9 D 8v 50kw WJZ (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.9 D 8v 50kw WJZ (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.9 D 8v 50kw WJZ (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.9 D 8v 50kw WJZ (98-00)	Sagem MANUAL
 Xsara	MAINTENANCE	1.9 D 8v 52kw WJY (00-05)	A/T AL4 AUTODETECT
 Xsara	MAINTENANCE	1.9 D 8v 52kw WJY (00-05)	Body Computer BSI AUTODETECT
 Xsara	MAINTENANCE	1.9 D 8v 52kw WJY (00-05)	Body Computer BSI AUTODETECT
 Xsara	MAINTENANCE	1.9 D 8v 52kw WJY (00-05)	BOSCH ESP 5.7 AUTODETECT
 Xsara	MAINTENANCE	1.9 D 8v 52kw WJY (00-05)	BOSCH ESP 5.7 AUTODETECT
 Xsara	MAINTENANCE	1.9 D 8v 52kw WJY (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.9 D 8v 52kw WJY (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.9 D 8v 52kw WJY (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.9 D 8v 52kw WJY (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.9 D 8v 52kw WJY (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	1.9 D 8v 52kw WJY (02-05)	Valeo Body Computer MANUAL
 Xsara	MAINTENANCE	1.9 D 8v 52kw WJY (03-05)	AKF- Autoliv AirBag ACU3
 Xsara	MAINTENANCE	1.9 D 8v 52kw WJY (03-05)	TEMIC AirBag
 Xsara	MAINTENANCE	1.9 D 8v 55kw DHV (97-00)	AUTODETECT
 Xsara	MAINTENANCE	1.9 D 8v 55kw DHV (97-00)	AUTODETECT
 Xsara	MAINTENANCE	1.9 D 8v 55kw DHV (97-00)	AUTODETECT
 Xsara	MAINTENANCE	1.9 D 8v 55kw DHV (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.9 D 8v 55kw DHV (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.9 D 8v 55kw DHV (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.9 D 8v 55kw DHV (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.9 D 8v 55kw DHV (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.9 D 8v 55kw DHV (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.9 D 8v 55kw DHV (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.9 D 8v 55kw DHV (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.9 D 8v 55kw DHV (98-00)	Sagem MANUAL
 Xsara	MAINTENANCE	1.9 TD 8v 66kw DHY (97-00)	AUTODETECT
 Xsara	MAINTENANCE	1.9 TD 8v 66kw DHY (97-00)	AUTODETECT
 Xsara	MAINTENANCE	1.9 TD 8v 66kw DHY (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.9 TD 8v 66kw DHY (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.9 TD 8v 66kw DHY (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.9 TD 8v 66kw DHY (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	1.9 TD 8v 66kw DHY (98-00)	Sagem MANUAL
 Xsara	MAINTENANCE	2.0 16v 101kw RFN (00-05)	A/T AL4 AUTODETECT
 Xsara	MAINTENANCE	2.0 16v 101kw RFN (00-05)	Body Computer BSI AUTODETECT
 Xsara	MAINTENANCE	2.0 16v 101kw RFN (00-05)	Body Computer BSI AUTODETECT
 Xsara	MAINTENANCE	2.0 16v 101kw RFN (00-05)	ESP 5.7 AUTODETECT
 Xsara	MAINTENANCE	2.0 16v 101kw RFN (00-05)	ESP 5.7 AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Xsara	MAINTENANCE	2.0 16v 101kw RFN (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	2.0 16v 101kw RFN (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	2.0 16v 101kw RFN (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	2.0 16v 101kw RFN (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	2.0 16v 101kw RFN (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	2.0 16v 101kw RFN (02-05)	Valeo Body Computer MANUAL
 Xsara	MAINTENANCE	2.0 16v 101kw RFN (03-05)	AKF- Autoliv AirBag ACU3
 Xsara	MAINTENANCE	2.0 16v 101kw RFN (03-05)	TEMIC AirBag
 Xsara	MAINTENANCE	2.0 16v 123kw RFS (00-05)	A/T AL4 AUTODETECT
 Xsara	MAINTENANCE	2.0 16v 123kw RFS (00-05)	Body Computer BSI AUTODETECT
 Xsara	MAINTENANCE	2.0 16v 123kw RFS (00-05)	Body Computer BSI AUTODETECT
 Xsara	MAINTENANCE	2.0 16v 123kw RFS (00-05)	BOSCH ESP 5.7 AUTODETECT
 Xsara	MAINTENANCE	2.0 16v 123kw RFS (00-05)	BOSCH ESP 5.7 AUTODETECT
 Xsara	MAINTENANCE	2.0 16v 123kw RFS (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	2.0 16v 123kw RFS (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	2.0 16v 123kw RFS (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	2.0 16v 123kw RFS (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	2.0 16v 123kw RFS (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	2.0 16v 123kw RFS (02-05)	Valeo Body Computer MANUAL
 Xsara	MAINTENANCE	2.0 16v 123kw RFS (03-05)	AKF- Autoliv AirBag ACU3
 Xsara	MAINTENANCE	2.0 16v 123kw RFS (03-05)	TEMIC AirBag
 Xsara	MAINTENANCE	2.0 16v 123kw RFS (97-00)	AUTODETECT
 Xsara	MAINTENANCE	2.0 16v 123kw RFS (97-00)	AUTODETECT
 Xsara	MAINTENANCE	2.0 16v 123kw RFS (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	2.0 16v 123kw RFS (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	2.0 16v 123kw RFS (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	2.0 16v 123kw RFS (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	2.0 16v 123kw RFS (97-00)	Sagem MANUAL
 Xsara	MAINTENANCE	2.0 16v 97kw RFV (97-00)	AUTODETECT
 Xsara	MAINTENANCE	2.0 16v 97kw RFV (97-00)	AUTODETECT
 Xsara	MAINTENANCE	2.0 16v 97kw RFV (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	2.0 16v 97kw RFV (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	2.0 16v 97kw RFV (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	2.0 16v 97kw RFV (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	2.0 16v 97kw RFV (98-00)	Sagem MANUAL
 Xsara	MAINTENANCE	2.0 HDI 8v 66kw RHY (00-05)	A/T AL4 AUTODETECT
 Xsara	MAINTENANCE	2.0 HDI 8v 66kw RHY (00-05)	Body Computer BSI AUTODETECT
 Xsara	MAINTENANCE	2.0 HDI 8v 66kw RHY (00-05)	Body Computer BSI AUTODETECT
 Xsara	MAINTENANCE	2.0 HDI 8v 66kw RHY (00-05)	BOSCH EDC15 C2 Common Rail AUTODE
 Xsara	MAINTENANCE	2.0 HDI 8v 66kw RHY (00-05)	BOSCH ESP 5.7 AUTODETECT
 Xsara	MAINTENANCE	2.0 HDI 8v 66kw RHY (00-05)	BOSCH ESP 5.7 AUTODETECT
 Xsara	MAINTENANCE	2.0 HDI 8v 66kw RHY (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	2.0 HDI 8v 66kw RHY (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	2.0 HDI 8v 66kw RHY (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	2.0 HDI 8v 66kw RHY (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	2.0 HDI 8v 66kw RHY (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	2.0 HDI 8v 66kw RHY (02-05)	Valeo Body Computer MANUAL
 Xsara	MAINTENANCE	2.0 HDI 8v 66kw RHY (03-05)	AKF- Autoliv AirBag ACU3
 Xsara	MAINTENANCE	2.0 HDI 8v 66kw RHY (03-05)	BOSCH EDC 15 C2 Common Rail
 Xsara	MAINTENANCE	2.0 HDI 8v 66kw RHY (03-05)	TEMIC AirBag
 Xsara	MAINTENANCE	2.0 HDI 8v 66kw RHY (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	2.0 HDI 8v 66kw RHY (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	2.0 HDI 8v 66kw RHY (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	2.0 HDI 8v 66kw RHY (97-00)	BOSCH ABS ABR 5.3
 Xsara	MAINTENANCE	2.0 HDI 8v 66kw RHY (97-00)	BOSCH EDC15 C2 Common Rail AUTODE
 Xsara	MAINTENANCE	2.0 HDI 8v 66kw RHY (98-00)	Sagem MANUAL
 Xsara	MAINTENANCE	2.0 HDI 8v 81kw RHZ (00-05)	A/T AL4 AUTODETECT
 Xsara	MAINTENANCE	2.0 HDI 8v 81kw RHZ (00-05)	Body Computer BSI AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Xsara	MAINTENANCE	2.0 HDI 8v 81kw RHZ (00-05)	Body Computer BSI AUTODETECT
 Xsara	MAINTENANCE	2.0 HDI 8v 81kw RHZ (00-05)	BOSCH EDC 15 C2 Common Rail
 Xsara	MAINTENANCE	2.0 HDI 8v 81kw RHZ (00-05)	BOSCH EDC15 C2 Common Rail AUTODETECT
 Xsara	MAINTENANCE	2.0 HDI 8v 81kw RHZ (00-05)	BOSCH ESP 5.7 AUTODETECT
 Xsara	MAINTENANCE	2.0 HDI 8v 81kw RHZ (00-05)	BOSCH ESP 5.7 AUTODETECT
 Xsara	MAINTENANCE	2.0 HDI 8v 81kw RHZ (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	2.0 HDI 8v 81kw RHZ (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	2.0 HDI 8v 81kw RHZ (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	2.0 HDI 8v 81kw RHZ (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	2.0 HDI 8v 81kw RHZ (02-05)	BOSCH ABS/ESP 5.7
 Xsara	MAINTENANCE	2.0 HDI 8v 81kw RHZ (03-05)	Valeo Body Computer MANUAL
 Xsara	MAINTENANCE	2.0 HDI 8v 81kw RHZ (03-05)	AKF- Autoliv AirBag ACU3
 Xsara	MAINTENANCE	2.0 HDI 8v 81kw RHZ (03-05)	TEMIC AirBag
 Xsara	NAVIGATION	1.4 8v 55kw KFV (00-05)	AUTODETECT
 Xsara	NAVIGATION	1.4 8v 55kw KFW (00-05)	AUTODETECT
 Xsara	NAVIGATION	1.4 8v 55kw KFX (00-05)	AUTODETECT
 Xsara	NAVIGATION	1.4 HDI 8v 52kw 8HZ (00-05)	AUTODETECT
 Xsara	NAVIGATION	1.6 16v 80kw N6A (00-05)	AUTODETECT
 Xsara	NAVIGATION	1.6 16v 80kw NFU (00-05)	AUTODETECT
 Xsara	NAVIGATION	1.9 D 8v 52kw WJY (00-05)	AUTODETECT
 Xsara	NAVIGATION	2.0 16v 101kw RFN (00-05)	AUTODETECT
 Xsara	NAVIGATION	2.0 16v 123kw RFS (00-05)	AUTODETECT
 Xsara	NAVIGATION	2.0 HDI 8v 66kw RHY (00-05)	AUTODETECT
 Xsara	NAVIGATION	2.0 HDI 8v 81kw RHZ (00-05)	AUTODETECT
 Xsara	PARKING HELP	1.4 8v 55kw KFV (00-05)	AUTODETECT
 Xsara	PARKING HELP	1.4 8v 55kw KFW (00-05)	AUTODETECT
 Xsara	PARKING HELP	1.4 8v 55kw KFX (00-05)	AUTODETECT
 Xsara	PARKING HELP	1.4 HDI 8v 52kw 8HZ (00-05)	AUTODETECT
 Xsara	PARKING HELP	1.6 16v 80kw N6A (00-05)	AUTODETECT
 Xsara	PARKING HELP	1.6 16v 80kw NFU (00-05)	AUTODETECT
 Xsara	PARKING HELP	1.9 D 8v 52kw WJY (00-05)	AUTODETECT
 Xsara	PARKING HELP	2.0 16v 101kw RFN (00-05)	AUTODETECT
 Xsara	PARKING HELP	2.0 16v 123kw RFS (00-05)	AUTODETECT
 Xsara	PARKING HELP	2.0 HDI 8v 66kw RHY (00-05)	AUTODETECT
 Xsara	PARKING HELP	2.0 HDI 8v 81kw RHZ (00-05)	AUTODETECT
 Xsara	RADIO / CD	1.4 8v 55kw KFV (00-05)	AudioSystem AUTODETECT
 Xsara	RADIO / CD	1.4 8v 55kw KFV (00-05)	CD Changer AUTODETECT
 Xsara	RADIO / CD	1.4 8v 55kw KFV (00-05)	CLARION AudioSystem
 Xsara	RADIO / CD	1.4 8v 55kw KFV (00-05)	PHILIPS AudioSystem
 Xsara	RADIO / CD	1.4 8v 55kw KFV (00-05)	VDO AudioSystem
 Xsara	RADIO / CD	1.4 8v 55kw KFW (00-05)	AudioSystem AUTODETECT
 Xsara	RADIO / CD	1.4 8v 55kw KFW (00-05)	CD Changer AUTODETECT
 Xsara	RADIO / CD	1.4 8v 55kw KFW (00-05)	CLARION AudioSystem
 Xsara	RADIO / CD	1.4 8v 55kw KFW (00-05)	PHILIPS AudioSystem
 Xsara	RADIO / CD	1.4 8v 55kw KFW (00-05)	VDO AudioSystem
 Xsara	RADIO / CD	1.4 8v 55kw KFX (00-05)	AudioSystem AUTODETECT
 Xsara	RADIO / CD	1.4 8v 55kw KFX (00-05)	CD Changer AUTODETECT
 Xsara	RADIO / CD	1.4 8v 55kw KFX (00-05)	CLARION AudioSystem
 Xsara	RADIO / CD	1.4 8v 55kw KFX (00-05)	PHILIPS AudioSystem
 Xsara	RADIO / CD	1.4 8v 55kw KFX (00-05)	VDO AudioSystem
 Xsara	RADIO / CD	1.4 8v 55kw KFX (97-00)	AudioSystem AUTODETECT
 Xsara	RADIO / CD	1.4 8v 55kw KFX (97-00)	Cd Changer AUTODETECT
 Xsara	RADIO / CD	1.4 HDI 8v 52kw 8HZ (00-05)	AudioSystem AUTODETECT
 Xsara	RADIO / CD	1.4 HDI 8v 52kw 8HZ (00-05)	CD Changer AUTODETECT
 Xsara	RADIO / CD	1.4 HDI 8v 52kw 8HZ (00-05)	CLARION AudioSystem
 Xsara	RADIO / CD	1.4 HDI 8v 52kw 8HZ (00-05)	PHILIPS AudioSystem
 Xsara	RADIO / CD	1.4 HDI 8v 52kw 8HZ (00-05)	VDO AudioSystem
 Xsara	RADIO / CD	1.5 D 8v 40kw VJY (97-00)	AudioSystem AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Xsara	RADIO / CD	1.5 D 8v 40kw VJY (97-00)	Cd Changer AUTODETECT
 Xsara	RADIO / CD	1.5 D 8v 42kw VJZ (97-00)	AudioSystem AUTODETECT
 Xsara	RADIO / CD	1.5 D 8v 42kw VJZ (97-00)	Cd Changer AUTODETECT
 Xsara	RADIO / CD	1.6 16v 80kw N6A (00-05)	AudioSystem AUTODETECT
 Xsara	RADIO / CD	1.6 16v 80kw N6A (00-05)	CD Changer AUTODETECT
 Xsara	RADIO / CD	1.6 16v 80kw N6A (00-05)	CLARION AudioSystem
 Xsara	RADIO / CD	1.6 16v 80kw N6A (00-05)	PHILIPS AudioSystem
 Xsara	RADIO / CD	1.6 16v 80kw N6A (00-05)	VDO AudioSystem
 Xsara	RADIO / CD	1.6 16v 80kw NFU (00-05)	AudioSystem AUTODETECT
 Xsara	RADIO / CD	1.6 16v 80kw NFU (00-05)	CD Changer AUTODETECT
 Xsara	RADIO / CD	1.6 16v 80kw NFU (00-05)	CLARION AudioSystem
 Xsara	RADIO / CD	1.6 16v 80kw NFU (00-05)	PHILIPS AudioSystem
 Xsara	RADIO / CD	1.6 16v 80kw NFU (00-05)	VDO AudioSystem
 Xsara	RADIO / CD	1.6 8v 66kw NFZ (97-00)	AudioSystem AUTODETECT
 Xsara	RADIO / CD	1.6 8v 66kw NFZ (97-00)	Cd Changer AUTODETECT
 Xsara	RADIO / CD	1.8 16v 82kw LFY (97-00)	AudioSystem AUTODETECT
 Xsara	RADIO / CD	1.8 16v 82kw LFY (97-00)	Cd Changer AUTODETECT
 Xsara	RADIO / CD	1.8 8v 66kw LFX (97-00)	AudioSystem AUTODETECT
 Xsara	RADIO / CD	1.8 8v 66kw LFX (97-00)	Cd Changer AUTODETECT
 Xsara	RADIO / CD	1.8 8v 74kw LFZ (97-00)	AudioSystem AUTODETECT
 Xsara	RADIO / CD	1.8 8v 74kw LFZ (97-00)	Cd Changer AUTODETECT
 Xsara	RADIO / CD	1.8 D 8v 44kw A9A (97-00)	AudioSystem AUTODETECT
 Xsara	RADIO / CD	1.8 D 8v 44kw A9A (97-00)	Cd Changer AUTODETECT
 Xsara	RADIO / CD	1.9 D 8v 50kw DJY (97-00)	AudioSystem AUTODETECT
 Xsara	RADIO / CD	1.9 D 8v 50kw DJY (97-00)	Cd Changer AUTODETECT
 Xsara	RADIO / CD	1.9 D 8v 50kw WJZ (97-00)	AudioSystem AUTODETECT
 Xsara	RADIO / CD	1.9 D 8v 50kw WJZ (97-00)	Cd Changer AUTODETECT
 Xsara	RADIO / CD	1.9 D 8v 52kw WJY (00-05)	AudioSystem AUTODETECT
 Xsara	RADIO / CD	1.9 D 8v 52kw WJY (00-05)	CD Changer AUTODETECT
 Xsara	RADIO / CD	1.9 D 8v 52kw WJY (00-05)	CLARION AudioSystem
 Xsara	RADIO / CD	1.9 D 8v 52kw WJY (00-05)	PHILIPS AudioSystem
 Xsara	RADIO / CD	1.9 D 8v 52kw WJY (00-05)	VDO AudioSystem
 Xsara	RADIO / CD	1.9 D 8v 55kw DHV (97-00)	AudioSystem AUTODETECT
 Xsara	RADIO / CD	1.9 D 8v 55kw DHV (97-00)	AudioSystem AUTODETECT
 Xsara	RADIO / CD	1.9 D 8v 55kw DHV (97-00)	Cd Changer AUTODETECT
 Xsara	RADIO / CD	1.9 D 8v 55kw DHV (97-00)	Cd Changer AUTODETECT
 Xsara	RADIO / CD	1.9 TD 8v 66kw DHY (97-00)	AudioSystem AUTODETECT
 Xsara	RADIO / CD	1.9 TD 8v 66kw DHY (97-00)	Cd Changer AUTODETECT
 Xsara	RADIO / CD	2.0 16v 101kw RFN (00-05)	AudioSystem AUTODETECT
 Xsara	RADIO / CD	2.0 16v 101kw RFN (00-05)	CD Changer AUTODETECT
 Xsara	RADIO / CD	2.0 16v 101kw RFN (00-05)	CLARION AudioSystem
 Xsara	RADIO / CD	2.0 16v 101kw RFN (00-05)	PHILIPS AudioSystem
 Xsara	RADIO / CD	2.0 16v 101kw RFN (00-05)	VDO AudioSystem
 Xsara	RADIO / CD	2.0 16v 123kw RFS (00-05)	AudioSystem AUTODETECT
 Xsara	RADIO / CD	2.0 16v 123kw RFS (00-05)	CD Changer AUTODETECT
 Xsara	RADIO / CD	2.0 16v 123kw RFS (00-05)	CLARION AudioSystem
 Xsara	RADIO / CD	2.0 16v 123kw RFS (00-05)	PHILIPS AudioSystem
 Xsara	RADIO / CD	2.0 16v 123kw RFS (00-05)	VDO AudioSystem
 Xsara	RADIO / CD	2.0 16v 123kw RFS (97-00)	AudioSystem AUTODETECT
 Xsara	RADIO / CD	2.0 16v 123kw RFS (97-00)	Cd Changer AUTODETECT
 Xsara	RADIO / CD	2.0 16v 97kw RFV (97-00)	AudioSystem AUTODETECT
 Xsara	RADIO / CD	2.0 16v 97kw RFV (97-00)	Cd Changer AUTODETECT
 Xsara	RADIO / CD	2.0 HDI 8v 66kw RHY (00-05)	AudioSystem AUTODETECT
 Xsara	RADIO / CD	2.0 HDI 8v 66kw RHY (00-05)	CD Changer AUTODETECT
 Xsara	RADIO / CD	2.0 HDI 8v 66kw RHY (00-05)	CLARION AudioSystem
 Xsara	RADIO / CD	2.0 HDI 8v 66kw RHY (00-05)	PHILIPS AudioSystem
 Xsara	RADIO / CD	2.0 HDI 8v 66kw RHY (00-05)	VDO AudioSystem
 Xsara	RADIO / CD	2.0 HDI 8v 66kw RHY (97-00)	AudioSystem AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Xsara	RADIO / CD	2.0 HDI 8v 66kw RHY (97-00)	Cd Changer AUTODETECT
 Xsara	RADIO / CD	2.0 HDI 8v 81kw RHZ (00-05)	AudioSystem AUTODETECT
 Xsara	RADIO / CD	2.0 HDI 8v 81kw RHZ (00-05)	CD Changer AUTODETECT
 Xsara	RADIO / CD	2.0 HDI 8v 81kw RHZ (00-05)	CLARION AudioSystem
 Xsara	RADIO / CD	2.0 HDI 8v 81kw RHZ (00-05)	PHILIPS AudioSystem
 Xsara	RADIO / CD	2.0 HDI 8v 81kw RHZ (00-05)	VDO AudioSystem
 Xsara	RAIN-LUMINOSITY S	1.4 8v 55kw KFV (00-05)	AUTODETECT
 Xsara	RAIN-LUMINOSITY S	1.4 8v 55kw KFV (00-05)	KOSTAL WSS
 Xsara	RAIN-LUMINOSITY S	1.4 8v 55kw KFW (00-05)	AUTODETECT
 Xsara	RAIN-LUMINOSITY S	1.4 8v 55kw KFW (00-05)	KOSTAL WSS
 Xsara	RAIN-LUMINOSITY S	1.4 8v 55kw KFX (00-05)	AUTODETECT
 Xsara	RAIN-LUMINOSITY S	1.4 8v 55kw KFX (00-05)	KOSTAL WSS
 Xsara	RAIN-LUMINOSITY S	1.4 HDI 8v 52kw 8HZ (00-05)	AUTODETECT
 Xsara	RAIN-LUMINOSITY S	1.4 HDI 8v 52kw 8HZ (00-05)	KOSTAL WSS
 Xsara	RAIN-LUMINOSITY S	1.6 16v 80kw N6A (00-05)	AUTODETECT
 Xsara	RAIN-LUMINOSITY S	1.6 16v 80kw N6A (00-05)	KOSTAL WSS
 Xsara	RAIN-LUMINOSITY S	1.6 16v 80kw NFU (00-05)	AUTODETECT
 Xsara	RAIN-LUMINOSITY S	1.6 16v 80kw NFU (00-05)	KOSTAL WSS
 Xsara	RAIN-LUMINOSITY S	1.9 D 8v 52kw WJY (00-05)	AUTODETECT
 Xsara	RAIN-LUMINOSITY S	1.9 D 8v 52kw WJY (00-05)	KOSTAL WSS
 Xsara	RAIN-LUMINOSITY S	2.0 16v 101kw RFN (00-05)	AUTODETECT
 Xsara	RAIN-LUMINOSITY S	2.0 16v 101kw RFN (00-05)	KOSTAL WSS
 Xsara	RAIN-LUMINOSITY S	2.0 16v 123kw RFS (00-05)	AUTODETECT
 Xsara	RAIN-LUMINOSITY S	2.0 16v 123kw RFS (00-05)	KOSTAL WSS
 Xsara	RAIN-LUMINOSITY S	2.0 HDI 8v 66kw RHY (00-05)	AUTODETECT
 Xsara	RAIN-LUMINOSITY S	2.0 HDI 8v 66kw RHY (00-05)	KOSTAL WSS
 Xsara	RAIN-LUMINOSITY S	2.0 HDI 8v 81kw RHZ (00-05)	AUTODETECT
 Xsara	RAIN-LUMINOSITY S	2.0 HDI 8v 81kw RHZ (00-05)	KOSTAL WSS
 Xsara	REMOTE CONTROL E	1.4 8v 55kw KFV (02-05)	Valeo Body Computer MANUAL
 Xsara	REMOTE CONTROL E	1.4 8v 55kw KFW (02-05)	Valeo Body Computer MANUAL
 Xsara	REMOTE CONTROL E	1.4 8v 55kw KFX (02-05)	Valeo Body Computer MANUAL
 Xsara	REMOTE CONTROL E	1.4 HDI 8v 52kw 8HZ (02-05)	Valeo Body Computer MANUAL
 Xsara	REMOTE CONTROL E	1.6 16v 80kw N6A (02-05)	Valeo Body Computer MANUAL
 Xsara	REMOTE CONTROL E	1.6 16v 80kw NFU (02-05)	Valeo Body Computer MANUAL
 Xsara	REMOTE CONTROL E	1.9 D 8v 52kw WJY (02-05)	Valeo Body Computer MANUAL
 Xsara	REMOTE CONTROL E	2.0 16v 101kw RFN (02-05)	Valeo Body Computer MANUAL
 Xsara	REMOTE CONTROL E	2.0 16v 123kw RFS (02-05)	Valeo Body Computer MANUAL
 Xsara	REMOTE CONTROL E	2.0 HDI 8v 66kw RHY (02-05)	Valeo Body Computer MANUAL
 Xsara	REMOTE CONTROL E	2.0 HDI 8v 81kw RHZ (02-05)	Valeo Body Computer MANUAL
 Xsara	SERVICE LIGHT RES	1.4 8v 55kw KFX (98-00)	Sagem MANUAL
 Xsara	SERVICE LIGHT RES	1.5 D 8v 40kw VJY (98-00)	Sagem MANUAL
 Xsara	SERVICE LIGHT RES	1.5 D 8v 42kw VJZ (98-00)	Sagem MANUAL
 Xsara	SERVICE LIGHT RES	1.6 8v 66kw NFZ (98-00)	Sagem MANUAL
 Xsara	SERVICE LIGHT RES	1.8 16v 82kw LFX (98-00)	Sagem MANUAL
 Xsara	SERVICE LIGHT RES	1.8 8v 66kw LFX (98-00)	Sagem MANUAL
 Xsara	SERVICE LIGHT RES	1.8 8v 74kw LFZ (98-00)	Sagem MANUAL
 Xsara	SERVICE LIGHT RES	1.8 D 8v 44kw A9A (98-00)	Sagem MANUAL
 Xsara	SERVICE LIGHT RES	1.9 D 8v 50kw DJY (98-00)	Sagem MANUAL
 Xsara	SERVICE LIGHT RES	1.9 D 8v 50kw WJZ (98-00)	Sagem MANUAL
 Xsara	SERVICE LIGHT RES	1.9 D 8v 55kw DHV (98-00)	Sagem MANUAL
 Xsara	SERVICE LIGHT RES	1.9 D 8v 55kw DHV (98-00)	Sagem MANUAL
 Xsara	SERVICE LIGHT RES	1.9 TD 8v 66kw DHY (98-00)	Sagem MANUAL
 Xsara	SERVICE LIGHT RES	2.0 16v 123kw RFS (97-00)	Sagem MANUAL
 Xsara	SERVICE LIGHT RES	2.0 16v 97kw RFV (98-00)	Sagem MANUAL
 Xsara	SERVICE LIGHT RES	2.0 HDI 8v 66kw RHY (98-00)	Sagem MANUAL
 Xsara	STEERING COLUMN	1.4 8v 55kw KFV (00-05)	AUTODETECT
 Xsara	STEERING COLUMN	1.4 8v 55kw KFW (00-05)	AUTODETECT
 Xsara	STEERING COLUMN	1.4 8v 55kw KFX (00-05)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Xsara	STEERING COLUMN	1.4 HDI 8v 52kw 8HZ (00-05)	AUTODETECT
 Xsara	STEERING COLUMN	1.6 16v 80kw N6A (00-05)	AUTODETECT
 Xsara	STEERING COLUMN	1.6 16v 80kw NFU (00-05)	AUTODETECT
 Xsara	STEERING COLUMN	1.9 D 8v 52kw WJY (00-05)	AUTODETECT
 Xsara	STEERING COLUMN	2.0 16v 101kw RFN (00-05)	AUTODETECT
 Xsara	STEERING COLUMN	2.0 16v 123kw RFS (00-05)	AUTODETECT
 Xsara	STEERING COLUMN	2.0 HDI 8v 66kw RHY (00-05)	AUTODETECT
 Xsara	STEERING COLUMN	2.0 HDI 8v 81kw RHZ (00-05)	AUTODETECT
 Xsara	SWITCHLIGHT MODU	1.4 8v 55kw KFV (00-05)	EATON/DELPHI
 Xsara	SWITCHLIGHT MODU	1.4 8v 55kw KFW (00-05)	EATON/DELPHI
 Xsara	SWITCHLIGHT MODU	1.4 8v 55kw KFX (00-05)	EATON/DELPHI
 Xsara	SWITCHLIGHT MODU	1.4 HDI 8v 52kw 8HZ (00-05)	EATON/DELPHI
 Xsara	SWITCHLIGHT MODU	1.6 16v 80kw N6A (00-05)	EATON/DELPHI
 Xsara	SWITCHLIGHT MODU	1.6 16v 80kw NFU (00-05)	EATON/DELPHI
 Xsara	SWITCHLIGHT MODU	1.9 D 8v 52kw WJY (00-05)	EATON/DELPHI
 Xsara	SWITCHLIGHT MODU	2.0 16v 101kw RFN (00-05)	EATON/DELPHI
 Xsara	SWITCHLIGHT MODU	2.0 16v 123kw RFS (00-05)	EATON/DELPHI
 Xsara	SWITCHLIGHT MODU	2.0 HDI 8v 66kw RHY (00-05)	EATON/DELPHI
 Xsara	SWITCHLIGHT MODU	2.0 HDI 8v 81kw RHZ (00-05)	EATON/DELPHI
 Xsara	VISUAL./TELEMATIC	1.4 8v 55kw KFV (00-05)	AUTOPC AUTODETECT
 Xsara	VISUAL./TELEMATIC	1.4 8v 55kw KFV (00-05)	Display AUTODETECT
 Xsara	VISUAL./TELEMATIC	1.4 8v 55kw KFW (00-05)	AUTOPC AUTODETECT
 Xsara	VISUAL./TELEMATIC	1.4 8v 55kw KFW (00-05)	Display AUTODETECT
 Xsara	VISUAL./TELEMATIC	1.4 8v 55kw KFX (00-05)	AUTOPC AUTODETECT
 Xsara	VISUAL./TELEMATIC	1.4 8v 55kw KFX (00-05)	Display AUTODETECT
 Xsara	VISUAL./TELEMATIC	1.4 HDI 8v 52kw 8HZ (00-05)	AUTOPC AUTODETECT
 Xsara	VISUAL./TELEMATIC	1.4 HDI 8v 52kw 8HZ (00-05)	Display AUTODETECT
 Xsara	VISUAL./TELEMATIC	1.6 16v 80kw N6A (00-05)	AUTOPC AUTODETECT
 Xsara	VISUAL./TELEMATIC	1.6 16v 80kw N6A (00-05)	Display AUTODETECT
 Xsara	VISUAL./TELEMATIC	1.6 16v 80kw NFU (00-05)	AUTOPC AUTODETECT
 Xsara	VISUAL./TELEMATIC	1.6 16v 80kw NFU (00-05)	Display AUTODETECT
 Xsara	VISUAL./TELEMATIC	1.9 D 8v 52kw WJY (00-05)	AUTOPC AUTODETECT
 Xsara	VISUAL./TELEMATIC	1.9 D 8v 52kw WJY (00-05)	Display AUTODETECT
 Xsara	VISUAL./TELEMATIC	2.0 16v 101kw RFN (00-05)	AUTOPC AUTODETECT
 Xsara	VISUAL./TELEMATIC	2.0 16v 101kw RFN (00-05)	Display AUTODETECT
 Xsara	VISUAL./TELEMATIC	2.0 16v 123kw RFS (00-05)	AUTOPC AUTODETECT
 Xsara	VISUAL./TELEMATIC	2.0 16v 123kw RFS (00-05)	Display AUTODETECT
 Xsara	VISUAL./TELEMATIC	2.0 HDI 8v 66kw RHY (00-05)	AUTOPC AUTODETECT
 Xsara	VISUAL./TELEMATIC	2.0 HDI 8v 66kw RHY (00-05)	Display AUTODETECT
 Xsara	VISUAL./TELEMATIC	2.0 HDI 8v 81kw RHZ (00-05)	AUTOPC AUTODETECT
 Xsara	VISUAL./TELEMATIC	2.0 HDI 8v 81kw RHZ (00-05)	Display AUTODETECT
 ZX	ABS	1.1 8v 44kw H1A	BOSCH ABS 8.1 AUTODETECT
 ZX	ABS	1.1 8v 44kw H1A	BOSCH ABS ABR 5.3
 ZX	ABS	1.1 8v 44kw HDY	BOSCH ABS 8.1 AUTODETECT
 ZX	ABS	1.1 8v 44kw HDY	BOSCH ABS ABR 5.3
 ZX	ABS	1.1 8v 44kw HDZ	BOSCH ABS 8.1 AUTODETECT
 ZX	ABS	1.1 8v 44kw HDZ	BOSCH ABS ABR 5.3
 ZX	ABS	1.4 8v 55kw K2D	BOSCH ABS 8.1 AUTODETECT
 ZX	ABS	1.4 8v 55kw K2D	BOSCH ABS ABR 5.3
 ZX	ABS	1.4 8v 55kw KDX	BOSCH ABS 8.1 AUTODETECT
 ZX	ABS	1.4 8v 55kw KDX	BOSCH ABS ABR 5.3
 ZX	ABS	1.4 8v 55kw KDY	BOSCH ABS 8.1 AUTODETECT
 ZX	ABS	1.4 8v 55kw KDY	BOSCH ABS ABR 5.3
 ZX	ABS	1.4 8v 55kw KFX	BOSCH ABS 8.1 AUTODETECT
 ZX	ABS	1.4 8v 55kw KFX	BOSCH ABS ABR 5.3
 ZX	ABS	1.5 8v 42kw VJZ	BOSCH ABS 8.1 AUTODETECT
 ZX	ABS	1.5 8v 42kw VJZ	BOSCH ABS ABR 5.3
 ZX	ABS	1.6 8v 65kw B4A	BOSCH ABS 8.1 AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 ZX	ABS	1.6 8v 65kw B4A	BOSCH ABS ABR 5.3
 ZX	ABS	1.6 8v 65kw BDY	BOSCH ABS 8.1 AUTODETECT
 ZX	ABS	1.6 8v 65kw BDY	BOSCH ABS ABR 5.3
 ZX	ABS	1.6 8v 65kw BFZ	BOSCH ABS 8.1 AUTODETECT
 ZX	ABS	1.6 8v 65kw BFZ	BOSCH ABS ABR 5.3
 ZX	ABS	1.6 8v 65kw NFZ	ABS 8.1 AUTODETECT
 ZX	ABS	1.6 8v 65kw NFZ	BOSCH ABS ABR 5.3
 ZX	ABS	1.8 16v 82kw LFY	BOSCH ABS 8.1 AUTODETECT
 ZX	ABS	1.8 16v 82kw LFY	BOSCH ABS ABR 5.3
 ZX	ABS	1.8 8v 74kw LFZ	BOSCH ABS 8.1 AUTODETECT
 ZX	ABS	1.8 8v 74kw LFZ	BOSCH ABS ABR 5.3
 ZX	ABS	1.8 D 8v 44kw VJZ	BOSCH ABS 8.1 AUTODETECT
 ZX	ABS	1.8 D 8v 44kw VJZ	BOSCH ABS ABR 5.3
 ZX	ABS	1.9 8v 88kw D6E	BOSCH ABS 8.1 AUTODETECT
 ZX	ABS	1.9 8v 88kw DKZ	BOSCH ABS 8.1 AUTODETECT
 ZX	ABS	1.9 8v 88kw DKZ	BOSCH ABS ABR 5.3
 ZX	ABS	1.9 8v 93kw D6E	BOSCH ABS ABR 5.3
 ZX	ABS	1.9 D 8v 47kw DJZ	BOSCH ABS 8.1 AUTODETECT
 ZX	ABS	1.9 D 8v 47kw DJZ	BOSCH ABS ABR 5.3
 ZX	ABS	1.9 D 8v 50kw DJY	BOSCH ABS 8.1 AUTODETECT
 ZX	ABS	1.9 D 8v 50kw DJY	BOSCH ABS ABR 5.3
 ZX	ABS	1.9 D 8v 52kw D9B	BOSCH ABS 8.1 AUTODETECT
 ZX	ABS	1.9 D 8v 52kw D9B	BOSCH ABS ABR 5.3
 ZX	ABS	1.9 TD 8v 66kw D8A	BOSCH ABS 8.1 AUTODETECT
 ZX	ABS	1.9 TD 8v 66kw D8A	BOSCH ABS ABR 5.3
 ZX	ABS	1.9 TD 8v 66kw DHY	BOSCH ABS 8.1 AUTODETECT
 ZX	ABS	1.9 TD 8v 66kw DHY	BOSCH ABS ABR 5.3
 ZX	ABS	2.0 16v 110kw RFT	BOSCH ABS 8.1 AUTODETECT
 ZX	ABS	2.0 16v 110kw RFT	BOSCH ABS ABR 5.3
 ZX	ABS	2.0 16v 112kw RFY	BOSCH ABS 8.1 AUTODETECT
 ZX	ABS	2.0 16v 112kw RFY	BOSCH ABS ABR 5.3
 ZX	ABS	2.0 16v 123kw RFS	BOSCH ABS ABR 5.3
 ZX	ABS	2.0 16v 123kw RFS	Marelli ABS 8.1 AUTODETECT
 ZX	ABS	2.0 8v 90kw RFX	BOSCH ABS 8.1 AUTODETECT
 ZX	ABS	2.0 8v 90kw RFX	BOSCH ABS ABR 5.3
 ZX	AUTOM. TRANSMISSI	1.1 8v 44kw H1A	A/T AL4 TA2000 AUTODETECT
 ZX	AUTOM. TRANSMISSI	1.1 8v 44kw HDY	A/T AL4 TA2000 AUTODETECT
 ZX	AUTOM. TRANSMISSI	1.1 8v 44kw HDZ	A/T AL4 TA2000 AUTODETECT
 ZX	AUTOM. TRANSMISSI	1.4 8v 55kw K2D	A/T AL4 TA2000 AUTODETECT
 ZX	AUTOM. TRANSMISSI	1.4 8v 55kw KDX	A/T AL4 TA2000 AUTODETECT
 ZX	AUTOM. TRANSMISSI	1.4 8v 55kw KDY	A/T AL4 TA2000 AUTODETECT
 ZX	AUTOM. TRANSMISSI	1.4 8v 55kw KFX	A/T AL4 TA2000 AUTODETECT
 ZX	AUTOM. TRANSMISSI	1.5 8v 42kw VJZ	A/T AL4 TA2000 AUTODETECT
 ZX	AUTOM. TRANSMISSI	1.6 8v 65kw B4A	A/T AL4 TA2000 AUTODETECT
 ZX	AUTOM. TRANSMISSI	1.6 8v 65kw BDY	A/T AL4 TA2000 AUTODETECT
 ZX	AUTOM. TRANSMISSI	1.6 8v 65kw BFZ	A/T AL4 TA2000 AUTODETECT
 ZX	AUTOM. TRANSMISSI	1.6 8v 65kw NFZ	A/T AL4 TA2000 AUTODETECT
 ZX	AUTOM. TRANSMISSI	1.8 16v 82kw LFY	A/T AL4 TA2000 AUTODETECT
 ZX	AUTOM. TRANSMISSI	1.8 8v 74kw LFZ	A/T AL4 TA2000 AUTODETECT
 ZX	AUTOM. TRANSMISSI	1.8 D 8v 44kw VJZ	A/T AL4 TA2000 AUTODETECT
 ZX	AUTOM. TRANSMISSI	1.9 8v 88kw DKZ	A/T AL4 TA2000 AUTODETECT
 ZX	AUTOM. TRANSMISSI	1.9 8v 93kw D6E	A/T AL4 TA2000 AUTODETECT
 ZX	AUTOM. TRANSMISSI	1.9 D 8v 47kw DJZ	A/T AL4 TA2000 AUTODETECT
 ZX	AUTOM. TRANSMISSI	1.9 D 8v 50kw DJY	A/T AL4 TA2000 AUTODETECT
 ZX	AUTOM. TRANSMISSI	1.9 D 8v 52kw D9B	A/T AL4 TA2000 AUTODETECT
 ZX	AUTOM. TRANSMISSI	1.9 TD 8v 66kw D8A	A/T AL4 TA2000 AUTODETECT
 ZX	AUTOM. TRANSMISSI	1.9 TD 8v 66kw DHY	A/T AL4 TA2000 AUTODETECT
 ZX	AUTOM. TRANSMISSI	2.0 16v 110kw RFT	A/T AL4 TA2000 AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 ZX	AUTOM. TRANSMISSI	2.0 16v 112kw RFY	A/T AL4 TA2000 AUTODETECT
 ZX	AUTOM. TRANSMISSI	2.0 16v 123kw RFS	A/T AL4 TA2000 AUTODETECT
 ZX	AUTOM. TRANSMISSI	2.0 8v 90kw RFX	A/T AL4 TA2000 AUTODETECT
 ZX	ELECTRONIC INJECT	1.1 8v 44kw HDZ	BOSCH MonoJetronic A2.2 [Slow]
 ZX	ELECTRONIC INJECT	1.4 8v 55kw KDY	BOSCH MonoJetronic A2.2 [Slow]
 ZX	ENGINE MANAGEME	1.1 8v 44kw H1A	BOSCH MonoMotronic MA3.1
 ZX	ENGINE MANAGEME	1.1 8v 44kw HDY	BOSCH MonoMotronic MA3.1
 ZX	ENGINE MANAGEME	1.1 8v 44kw HDZ	BOSCH MonoMotronic MA3.0 [Slow]
 ZX	ENGINE MANAGEME	1.1 8v 44kw HDZ	BOSCH MonoMotronic MA3.1
 ZX	ENGINE MANAGEME	1.4 8v 55kw K2D	BOSCH MonoMotronic MA3.0 [Fast]
 ZX	ENGINE MANAGEME	1.4 8v 55kw K2D	BOSCH MonoMotronic MA3.0 [Slow]
 ZX	ENGINE MANAGEME	1.4 8v 55kw KDX	BOSCH MonoMotronic MA3.0 [Fast]
 ZX	ENGINE MANAGEME	1.4 8v 55kw KDX	BOSCH MonoMotronic MA3.0 [Slow]
 ZX	ENGINE MANAGEME	1.4 8v 55kw KFX	Marelli MM 1AP.40
 ZX	ENGINE MANAGEME	1.6 8v 65kw B4A	Marelli MMBA G5 [Slow]
 ZX	ENGINE MANAGEME	1.6 8v 65kw B4A	Marelli MMBA G6 [Slow]
 ZX	ENGINE MANAGEME	1.6 8v 65kw BDY	Marelli MMBA G6 [Slow]
 ZX	ENGINE MANAGEME	1.6 8v 65kw BFZ	Marelli MM 8P.13 [Fast]
 ZX	ENGINE MANAGEME	1.6 8v 65kw NFZ	BOSCH Motronic MP5.2
 ZX	ENGINE MANAGEME	1.8 8v 74kw LFZ	BOSCH Motronic MP5.1 [Slow]
 ZX	ENGINE MANAGEME	1.8 8v 74kw LFZ	Marelli MM 1AP.10
 ZX	ENGINE MANAGEME	1.8 8v 74kw LFZ	Marelli MM 8P.10 [Fast]
 ZX	ENGINE MANAGEME	1.9 8v 88kw DKZ	BOSCH Motronic M1.3 [Slow]
 ZX	ENGINE MANAGEME	1.9 8v 88kw DKZ	Marelli MM 1AP.10
 ZX	ENGINE MANAGEME	1.9 8v 93kw D6E	BOSCH Motronic MP3.1 [Slow]
 ZX	ENGINE MANAGEME	1.9 8v 93kw D6E	Marelli MM 1AP.10
 ZX	ENGINE MANAGEME	2.0 16v 112kw RFY	BOSCH Motronic MP3.2 [Fast]
 ZX	ENGINE MANAGEME	2.0 16v 112kw RFY	BOSCH Motronic MP3.2 [Slow]
 ZX	ENGINE MANAGEME	2.0 16v 112kw RFY	Marelli MM 1AP.10
 ZX	ENGINE MANAGEME	2.0 16v 123kw RFS	Marelli MM 1AP.10
 ZX	ENGINE MANAGEME	2.0 8v 90kw RFX	Marelli MM 1AP.10
 ZX	ENGINE MANAGEME	2.0 8v 90kw RFX	Marelli MM 8P [Slow]
 ZX	ENGINE MANAGEME	2.0 8v 90kw RFX	Marelli MM 8P.20 [Fast]
 ZX	MAINTENANCE	1.1 8v 44kw H1A	A/T AL4 TA2000 AUTODETECT
 ZX	MAINTENANCE	1.1 8v 44kw H1A	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.1 8v 44kw H1A	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.1 8v 44kw H1A	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.1 8v 44kw H1A	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.1 8v 44kw HDY	A/T AL4 TA2000 AUTODETECT
 ZX	MAINTENANCE	1.1 8v 44kw HDY	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.1 8v 44kw HDY	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.1 8v 44kw HDY	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.1 8v 44kw HDY	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.1 8v 44kw HDY	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.1 8v 44kw HDZ	A/T AL4 TA2000 AUTODETECT
 ZX	MAINTENANCE	1.1 8v 44kw HDZ	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.1 8v 44kw HDZ	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.1 8v 44kw HDZ	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.1 8v 44kw HDZ	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.4 8v 55kw K2D	A/T AL4 TA2000 AUTODETECT
 ZX	MAINTENANCE	1.4 8v 55kw K2D	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.4 8v 55kw K2D	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.4 8v 55kw K2D	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.4 8v 55kw K2D	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.4 8v 55kw KDX	A/T AL4 TA2000 AUTODETECT
 ZX	MAINTENANCE	1.4 8v 55kw KDX	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.4 8v 55kw KDX	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.4 8v 55kw KDX	BOSCH ABS ABR 5.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 ZX	MAINTENANCE	1.4 8v 55kw KDY	A/T AL4 TA2000 AUTODETECT
 ZX	MAINTENANCE	1.4 8v 55kw KDY	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.4 8v 55kw KDY	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.4 8v 55kw KDY	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.4 8v 55kw KDY	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.4 8v 55kw KFX	A/T AL4 TA2000 AUTODETECT
 ZX	MAINTENANCE	1.4 8v 55kw KFX	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.4 8v 55kw KFX	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.4 8v 55kw KFX	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.4 8v 55kw KFX	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.5 8v 42kw VJZ	A/T AL4 TA2000 AUTODETECT
 ZX	MAINTENANCE	1.5 8v 42kw VJZ	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.5 8v 42kw VJZ	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.5 8v 42kw VJZ	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.5 8v 42kw VJZ	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.6 8v 65kw B4A	A/T AL4 TA2000 AUTODETECT
 ZX	MAINTENANCE	1.6 8v 65kw B4A	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.6 8v 65kw B4A	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.6 8v 65kw B4A	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.6 8v 65kw B4A	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.6 8v 65kw BDY	A/T AL4 TA2000 AUTODETECT
 ZX	MAINTENANCE	1.6 8v 65kw BDY	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.6 8v 65kw BDY	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.6 8v 65kw BDY	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.6 8v 65kw BDY	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.6 8v 65kw BFZ	A/T AL4 TA2000 AUTODETECT
 ZX	MAINTENANCE	1.6 8v 65kw BFZ	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.6 8v 65kw BFZ	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.6 8v 65kw BFZ	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.6 8v 65kw NFZ	A/T AL4 TA2000 AUTODETECT
 ZX	MAINTENANCE	1.6 8v 65kw NFZ	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.6 8v 65kw NFZ	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.6 8v 65kw NFZ	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.6 8v 65kw NFZ	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.8 16v 82kw LFY	A/T AL4 TA2000 AUTODETECT
 ZX	MAINTENANCE	1.8 16v 82kw LFY	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.8 16v 82kw LFY	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.8 16v 82kw LFY	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.8 16v 82kw LFY	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.8 8v 74kw LFZ	A/T AL4 TA2000 AUTODETECT
 ZX	MAINTENANCE	1.8 8v 74kw LFZ	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.8 8v 74kw LFZ	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.8 8v 74kw LFZ	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.8 8v 74kw LFZ	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.8 D 8v 44kw VJZ	A/T AL4 TA2000 AUTODETECT
 ZX	MAINTENANCE	1.8 D 8v 44kw VJZ	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.8 D 8v 44kw VJZ	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.8 D 8v 44kw VJZ	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.8 D 8v 44kw VJZ	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.9 8v 88kw DKZ	A/T AL4 TA2000 AUTODETECT
 ZX	MAINTENANCE	1.9 8v 88kw DKZ	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.9 8v 88kw DKZ	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.9 8v 88kw DKZ	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.9 8v 93kw D6E	A/T AL4 TA2000 AUTODETECT
 ZX	MAINTENANCE	1.9 8v 93kw D6E	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.9 8v 93kw D6E	BOSCH ABS ABR 5.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 ZX	MAINTENANCE	1.9 8v 93kw D6E	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.9 8v 93kw D6E	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.9 D 8v 47kw DJZ	A/T AL4 TA2000 AUTODETECT
 ZX	MAINTENANCE	1.9 D 8v 47kw DJZ	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.9 D 8v 47kw DJZ	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.9 D 8v 47kw DJZ	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.9 D 8v 47kw DJZ	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.9 D 8v 50kw DJY	A/T AL4 TA2000 AUTODETECT
 ZX	MAINTENANCE	1.9 D 8v 50kw DJY	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.9 D 8v 50kw DJY	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.9 D 8v 50kw DJY	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.9 D 8v 52kw D9B	A/T AL4 TA2000 AUTODETECT
 ZX	MAINTENANCE	1.9 D 8v 52kw D9B	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.9 D 8v 52kw D9B	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.9 D 8v 52kw D9B	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.9 TD 8v 66kw D8A	A/T AL4 TA2000 AUTODETECT
 ZX	MAINTENANCE	1.9 TD 8v 66kw D8A	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.9 TD 8v 66kw D8A	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.9 TD 8v 66kw D8A	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.9 TD 8v 66kw D8A	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.9 TD 8v 66kw DHY	A/T AL4 TA2000 AUTODETECT
 ZX	MAINTENANCE	1.9 TD 8v 66kw DHY	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.9 TD 8v 66kw DHY	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.9 TD 8v 66kw DHY	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	1.9 TD 8v 66kw DHY	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	2.0 16v 110kw RFT	A/T AL4 TA2000 AUTODETECT
 ZX	MAINTENANCE	2.0 16v 110kw RFT	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	2.0 16v 110kw RFT	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	2.0 16v 110kw RFT	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	2.0 16v 110kw RFT	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	2.0 16v 112kw RFY	A/T AL4 TA2000 AUTODETECT
 ZX	MAINTENANCE	2.0 16v 112kw RFY	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	2.0 16v 112kw RFY	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	2.0 16v 112kw RFY	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	2.0 16v 112kw RFY	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	2.0 16v 123kw RFS	A/T AL4 TA2000 AUTODETECT
 ZX	MAINTENANCE	2.0 16v 123kw RFS	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	2.0 16v 123kw RFS	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	2.0 16v 123kw RFS	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	2.0 16v 123kw RFS	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	2.0 8v 90kw RFX	A/T AL4 TA2000 AUTODETECT
 ZX	MAINTENANCE	2.0 8v 90kw RFX	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	2.0 8v 90kw RFX	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	2.0 8v 90kw RFX	BOSCH ABS ABR 5.3
 ZX	MAINTENANCE	2.0 8v 90kw RFX	BOSCH ABS ABR 5.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Dacia

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Duster	ENGINE MANAGEME	1.5 dCi 66kw	AUTODETECT
 Duster	ENGINE MANAGEME	1.5 dCi FAP 81kw	AUTODETECT
 Duster	ENGINE MANAGEME	1.6 77kw	AUTODETECT
 Duster	ENGINE MANAGEME	1.6 GPL 79kw	AUTODETECT
 Duster	RADIO / CD	1.5 dCi 66kw	AUTODETECT
 Duster	RADIO / CD	1.5 dCi FAP 81kw	AUTODETECT
 Duster	RADIO / CD	1.6 77kw	AUTODETECT
 Duster	RADIO / CD	1.6 GPL 79kw	AUTODETECT
 Logan	ABS	1.4 MPI	BOSCH ABS 8.0
 Logan	ABS	1.5 dCi	BOSCH ABS 8.0
 Logan	ABS	1.6 MPI	BOSCH ABS 8.0
 Logan	AIRBAG	1.4 MPI	BOSCH AirBag AB8 (No CAN)
 Logan	AIRBAG	1.4 MPI 75cv (07-..)	AMR Airbag
 Logan	AIRBAG	1.5 dCi	BOSCH AirBag AB8 (No CAN)
 Logan	AIRBAG	1.5 dCi (07-..)	AMR Airbag
 Logan	AIRBAG	1.6 MPI	BOSCH AirBag AB8 (No CAN)
 Logan	AIRBAG	1.6 mpi 90cv (07-..)	AMR Airbag
 Logan	CHASSIS NETWORK	1.4 MPI	UCH AUTODETECT
 Logan	CHASSIS NETWORK	1.4 MPI 75cv	UCH AUTODETECT
 Logan	CHASSIS NETWORK	1.4 MPI 75cv (07-..)	UCH
 Logan	CHASSIS NETWORK	1.5 dCi	UCH AUTODETECT
 Logan	CHASSIS NETWORK	1.5 dCi (07-..)	UCH
 Logan	CHASSIS NETWORK	1.6 MPI	UCH AUTODETECT
 Logan	CHASSIS NETWORK	1.6 mpi 90cv	UCH AUTODETECT
 Logan	CHASSIS NETWORK	1.6 mpi 90cv (07-..)	UCH
 Logan	ELECTRIC STEERING	1.4 MPI 75cv (07-..)	EPS
 Logan	ELECTRIC STEERING	1.5 dCi (07-..)	EPS
 Logan	ELECTRIC STEERING	1.6 mpi 90cv (07-..)	EPS
 Logan	ENGINE MANAGEME	1.4 MPI	AUTODETECT
 Logan	ENGINE MANAGEME	1.4 MPI 75cv	AUTODETECT
 Logan	ENGINE MANAGEME	1.4 MPI K7J	SIEMENS Sirius 32
 Logan	ENGINE MANAGEME	1.5 dCi	AUTODETECT
 Logan	ENGINE MANAGEME	1.5 dCi K9K	DELPHI LUCAS LVCR Common Rail
 Logan	ENGINE MANAGEME	1.5 dCi K9K (07-..)	DELPHI LUCAS LVCR Common Rail
 Logan	ENGINE MANAGEME	1.6 MPI	AUTODETECT
 Logan	ENGINE MANAGEME	1.6 mpi 90cv	AUTODETECT
 Logan	ENGINE MANAGEME	1.6 MPI K7M	SIEMENS Sirius 32
 Logan	IMMOBILIZER	1.4 MPI	Immobilizer Body Computer
 Logan	IMMOBILIZER	1.5 dCi	Immobilizer Body Computer
 Logan	IMMOBILIZER	1.6 MPI	Immobilizer Body Computer
 Logan	MAINTENANCE	1.4 MPI	BOSCH ABS 8.0
 Logan	MAINTENANCE	1.4 MPI	BOSCH ABS 8.0
 Logan	MAINTENANCE	1.4 MPI	BOSCH ABS 8.0
 Logan	MAINTENANCE	1.4 MPI	BOSCH ABS 8.0
 Logan	MAINTENANCE	1.5 dCi	BOSCH ABS 8.0
 Logan	MAINTENANCE	1.5 dCi	BOSCH ABS 8.0
 Logan	MAINTENANCE	1.5 dCi	BOSCH ABS 8.0
 Logan	MAINTENANCE	1.5 dCi	BOSCH ABS 8.0
 Logan	MAINTENANCE	1.5 dCi K9K (07-..)	DELPHI LUCAS LVCR Common Rail
 Logan	MAINTENANCE	1.6 MPI	BOSCH ABS 8.0
 Logan	MAINTENANCE	1.6 MPI	BOSCH ABS 8.0
 Logan	MAINTENANCE	1.6 MPI	BOSCH ABS 8.0
 Logan	MAINTENANCE	1.6 MPI	BOSCH ABS 8.0
 Sandero	ABS	1.4 MPI (07-12)	AUTODETECT
 Sandero	ABS	1.4 MPI (07-12)	BOSCH ABS 8.0
 Sandero	ABS	1.4 MPI (07-12)	GAS AUTODETECT
 Sandero	ABS	1.5 dCi 70cv (07-12)	AUTODETECT
 Sandero	ABS	1.5 dCi 70cv (07-12)	BOSCH ABS 8.0

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Dacia

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sandero	ABS	1.5 dCi 85cv (07-12)	AUTODETECT
 Sandero	ABS	1.5 dCi 85cv (07-12)	BOSCH ABS 8.0
 Sandero	ABS	1.6 MPI (07-12)	AUTODETECT
 Sandero	ABS	1.6 MPI (07-12)	BOSCH ABS 8.0
 Sandero	ABS	1.6 MPI (07-12)	GAS AUTODETECT
 Sandero	AIRBAG	1.4 MPI (07-12)	AUTODETECT
 Sandero	AIRBAG	1.4 MPI (07-12)	BOSCH AirBag AB8.2.E (CAN)
 Sandero	AIRBAG	1.4 MPI (07-12)	GAS AUTODETECT
 Sandero	AIRBAG	1.5 dCi 70cv (07-12)	AUTODETECT
 Sandero	AIRBAG	1.5 dCi 70cv (07-12)	BOSCH AirBag AB8.2.E (CAN)
 Sandero	AIRBAG	1.5 dCi 85cv (07-12)	AUTODETECT
 Sandero	AIRBAG	1.5 dCi 85cv (07-12)	BOSCH AirBag AB8.2.E (CAN)
 Sandero	AIRBAG	1.6 MPI (07-12)	AUTODETECT
 Sandero	AIRBAG	1.6 MPI (07-12)	BOSCH AirBag AB8.2.E (CAN)
 Sandero	AIRBAG	1.6 MPI (07-12)	GAS AUTODETECT
 Sandero	CHASSIS NETWORK	1.4 MPI (07-12)	UCH AUTODETECT
 Sandero	CHASSIS NETWORK	1.5 dCi 70cv (07-12)	UCH AUTODETECT
 Sandero	CHASSIS NETWORK	1.5 dCi 85cv (07-12)	UCH AUTODETECT
 Sandero	CHASSIS NETWORK	1.6 MPI (07-12)	UCH AUTODETECT
 Sandero	ELECTRIC STEERING	1.4 MPI (07-12)	AUTODETECT
 Sandero	ELECTRIC STEERING	1.4 MPI (07-12)	GAS AUTODETECT
 Sandero	ELECTRIC STEERING	1.5 dCi 70cv (07-12)	AUTODETECT
 Sandero	ELECTRIC STEERING	1.5 dCi 85cv (07-12)	AUTODETECT
 Sandero	ELECTRIC STEERING	1.6 MPI (07-12)	AUTODETECT
 Sandero	ELECTRIC STEERING	1.6 MPI (07-12)	GAS AUTODETECT
 Sandero	ENGINE MANAGEME	1.4 MPI (07-12)	AUTODETECT
 Sandero	ENGINE MANAGEME	1.4 MPI (07-12)	GAS AUTODETECT
 Sandero	ENGINE MANAGEME	1.4 MPI K7J (07-12)	SIEMENS Sirius 32
 Sandero	ENGINE MANAGEME	1.5 dCi 70cv (07-12)	AUTODETECT
 Sandero	ENGINE MANAGEME	1.5 dCi 85cv (07-12)	AUTODETECT
 Sandero	ENGINE MANAGEME	1.6 MPI (07-12)	AUTODETECT
 Sandero	ENGINE MANAGEME	1.6 MPI (07-12)	GAS AUTODETECT
 Sandero	IMMOBILIZER	1.4 MPI (07-12)	Immobilizer Body Computer
 Sandero	IMMOBILIZER	1.5 dCi 70cv (07-12)	Immobilizer Body Computer
 Sandero	IMMOBILIZER	1.5 dCi 85cv (07-12)	Immobilizer Body Computer
 Sandero	IMMOBILIZER	1.6 MPI (07-12)	Immobilizer Body Computer
 Sandero	MAINTENANCE	1.4 MPI (07-12)	BOSCH ABS 8.0
 Sandero	MAINTENANCE	1.4 MPI (07-12)	BOSCH ABS 8.0
 Sandero	MAINTENANCE	1.4 MPI (07-12)	BOSCH ABS 8.0
 Sandero	MAINTENANCE	1.5 dCi 70cv (07-12)	BOSCH ABS 8.0
 Sandero	MAINTENANCE	1.5 dCi 70cv (07-12)	BOSCH ABS 8.0
 Sandero	MAINTENANCE	1.5 dCi 70cv (07-12)	BOSCH ABS 8.0
 Sandero	MAINTENANCE	1.5 dCi 70cv (07-12)	BOSCH ABS 8.0
 Sandero	MAINTENANCE	1.5 dCi 70cv (07-12)	BOSCH ABS 8.0
 Sandero	MAINTENANCE	1.5 dCi 85cv (07-12)	BOSCH ABS 8.0
 Sandero	MAINTENANCE	1.5 dCi 85cv (07-12)	BOSCH ABS 8.0
 Sandero	MAINTENANCE	1.5 dCi 85cv (07-12)	BOSCH ABS 8.0
 Sandero	MAINTENANCE	1.5 dCi 85cv (07-12)	BOSCH ABS 8.0
 Sandero	MAINTENANCE	1.6 MPI (07-12)	BOSCH ABS 8.0
 Sandero	MAINTENANCE	1.6 MPI (07-12)	BOSCH ABS 8.0
 Sandero	MAINTENANCE	1.6 MPI (07-12)	BOSCH ABS 8.0
 Sandero	MAINTENANCE	1.6 MPI (07-12)	BOSCH ABS 8.0
 Sandero	RADIO / CD	1.4 MPI (07-12)	AUTODETECT
 Sandero	RADIO / CD	1.4 MPI (07-12)	GAS AUTODETECT
 Sandero	RADIO / CD	1.5 dCi 70cv (07-12)	AUTODETECT
 Sandero	RADIO / CD	1.5 dCi 85cv (07-12)	AUTODETECT
 Sandero	RADIO / CD	1.6 MPI (07-12)	AUTODETECT
 Sandero	RADIO / CD	1.6 MPI (07-12)	GAS AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Dacia

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Solenza	ENGINE MANAGEME	1.4 MPI K7J	SIEMENS Sirius 32
 Solenza	ENGINE MANAGEME	1.9 D F8Q	LUCAS Diesel DCU3R

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Daewoo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Cielo	AIRBAG	(..-00)	SIEMENS AirBag SRS
 Cielo	AIRBAG	(01-..)	DPI AirBag SRS
 Espero	AIRBAG	1.5 16v (..-00)	SIEMENS AirBag SRS
 Espero	AIRBAG	1.5 16v (01-..)	DPI AirBag SRS
 Espero	AIRBAG	1.8 (..-00)	SIEMENS AirBag SRS
 Espero	AIRBAG	1.8 (01-..)	DPI AirBag SRS
 Espero	AIRBAG	2.0 (..-00)	SIEMENS AirBag SRS
 Espero	AIRBAG	2.0 (01-..)	DPI AirBag SRS
 Espero	ENGINE MANAGEME	1.5 16v A15MF (95-98)	DWMC MFI-i MANUAL
 Espero	ENGINE MANAGEME	1.8 C18LE (95-98)	DWMC MFI-i MANUAL
 Espero	ENGINE MANAGEME	2.0 C20LE (95-98)	DWMC MFI-i MANUAL
 Espero	MAINTENANCE	1.5 16v A15MF (95-98)	DWMC MFI-i MANUAL
 Espero	MAINTENANCE	1.8 C18LE (95-98)	DWMC MFI-i MANUAL
 Espero	MAINTENANCE	2.0 C20LE (95-98)	DWMC MFI-i MANUAL
 Lanos	AIRBAG	1.3 (..-00)	SIEMENS AirBag SRS
 Lanos	AIRBAG	1.3 (01-..)	DPI AirBag SRS
 Lanos	AIRBAG	1.4 SE (..-00)	SIEMENS AirBag SRS
 Lanos	AIRBAG	1.4 SE (01-..)	DPI AirBag SRS
 Lanos	AIRBAG	1.5 SE (..-00)	SIEMENS AirBag SRS
 Lanos	AIRBAG	1.5 SE (01-..)	DPI AirBag SRS
 Lanos	AIRBAG	1.5 SX (..-00)	SIEMENS AirBag SRS
 Lanos	AIRBAG	1.5 SX (01-..)	DPI AirBag SRS
 Lanos	AIRBAG	1.6 16v (..-00)	SIEMENS AirBag SRS
 Lanos	AIRBAG	1.6 16v (01-..)	DPI AirBag SRS
 Lanos	AIRBAG	1.6 SX (..-00)	SIEMENS AirBag SRS
 Lanos	AIRBAG	1.6 SX (01-..)	DPI AirBag SRS
 Lanos	ENGINE MANAGEME	1.3 (..-99)	Daewoo-GM Multec MPI
 Lanos	ENGINE MANAGEME	1.3 A13DM (97-00)	GM MFI-i MANUAL ITMS-6F
 Lanos	ENGINE MANAGEME	1.4 SE (01-..)	EOBD
 Lanos	ENGINE MANAGEME	1.5 SE A15SMS (01-..)	EOBD
 Lanos	ENGINE MANAGEME	1.5 SX (01-..)	EOBD
 Lanos	ENGINE MANAGEME	1.6 16v A16DM (..-00)	Daewoo-GM Multec MPI (Fast)
 Lanos	ENGINE MANAGEME	1.6 16v A16DM (97-00)	GM MFI-i MANUAL IEFI-6
 Lanos	ENGINE MANAGEME	1.6 SX (01-..)	EOBD
 Lanos	MAINTENANCE	1.3 A13DM (97-00)	GM MFI-i MANUAL ITMS-6F
 Lanos	MAINTENANCE	1.6 16v A16DM (97-00)	GM MFI-i MANUAL IEFI-6
 Leganza	ENGINE MANAGEME	2.0 16v X20SED (97-00)	GM MFI-i MANUAL ITMS-6F
 Leganza	MAINTENANCE	2.0 16v X20SED (97-00)	GM MFI-i MANUAL ITMS-6F
 Matiz 2	ABS	800 (01-..)	Bosch-kelsey Hayes EBC 430
 Matiz 2	AIRBAG	800 (03-..)	DPI AirBag SRS
 Matiz 2	IMMOBILIZER	800 (00-..)	DTL
 Matiz	ABS	800 (..-00)	Bosch-kelsey Hayes EBC 430
 Matiz	ABS	800 (00-..)	Bosch-kelsey Hayes EBC 430
 Matiz	AIRBAG	800 (..-00)	SIEMENS AirBag SRS
 Matiz	AIRBAG	800 (01-..)	DPI AirBag SRS
 Matiz	ENGINE MANAGEME	800 (01-..)	EOBD
 Matiz	ENGINE MANAGEME	800 (01-..)	Kemsco D3 1AFM
 Matiz	ENGINE MANAGEME	800 F8CV (..-00)	Siemens Fenix MPI EX5-M (Fast)
 Matiz	ENGINE MANAGEME	800 F8CV (98-00)	Siemens Fenix MANUAL 5M
 Matiz	IMMOBILIZER	800 (..-00)	DPI
 Matiz	IMMOBILIZER	800 (00-..)	DTL
 Matiz	MAINTENANCE	800 F8CV (98-00)	Siemens Fenix MANUAL 5M
 Nexia	AIRBAG	1.5	DPI AirBag SRS
 Nexia	AIRBAG	1.5 16v (97-00)	SIEMENS AirBag SRS
 Nexia	ENGINE MANAGEME	1.5 16v A15MF (95-98)	DWMC MFI-i MANUAL Multec
 Nexia	ENGINE MANAGEME	1.5 G15MF (95-98)	DWMC MFI-i MANUAL Multec
 Nexia	MAINTENANCE	1.5 16v A15MF (95-98)	DWMC MFI-i MANUAL Multec

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Daewoo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Nexia	MAINTENANCE	1.5 G15MF (95-98)	DWMC MFI-i MANUAL Multec
 Nubira	ENGINE MANAGEME	1.6 16v A16DM (97-00)	GM MFI-i MANUAL ITMS-6F
 Nubira	ENGINE MANAGEME	1.6 16v A16DMB (..-00)	Daewoo-GM Multec MPI (Fast)
 Nubira	ENGINE MANAGEME	1.6 SE (01-..)	EOBD
 Nubira	ENGINE MANAGEME	2.0 16v C20SE (97-00)	GM MFI-i MANUAL ITMS-6F
 Nubira	ENGINE MANAGEME	2.0 16v X20SED (97-00)	GM MFI-i MANUAL ITMS-6F
 Nubira	ENGINE MANAGEME	2.0 i CDX (01-..)	EOBD
 Nubira	MAINTENANCE	1.6 16v A16DM (97-00)	GM MFI-i MANUAL ITMS-6F
 Nubira	MAINTENANCE	2.0 16v C20SE (97-00)	GM MFI-i MANUAL ITMS-6F
 Nubira	MAINTENANCE	2.0 16v X20SED (97-00)	GM MFI-i MANUAL ITMS-6F
 Rezzo/Tacuma	ENGINE MANAGEME	2.0 CDX (01-..)	EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS			Daihatsu
MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Cuore	ENGINE MANAGEME	1.0 (01-..)	EOBD
 Gran Move	ENGINE MANAGEME	1.6 (01-..)	EOBD
 Hijet	ENGINE MANAGEME	(01-..)	EOBD
 Move	ENGINE MANAGEME	1.0 (01-..)	EOBD
 Sirion	ENGINE MANAGEME	1.0 (01-..)	EOBD
 Sirion	ENGINE MANAGEME	1.3 (01-..)	EOBD
 Terios	ENGINE MANAGEME	1.3 (01-..)	EOBD
 YRV	ENGINE MANAGEME	1.3 (01-..)	EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS			Daimler
MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Super V8	ENGINE MANAGEME	4.0 V8 276kw (01-...)	EOBD
 V8	ENGINE MANAGEME	4.0 V8 216kw (01-...)	EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 500	ABS + TRACT. CONT	0.9 TwinAir Turbo 85cv (09-..)	BOSCH ABS 8 ESP
 500	ABS + TRACT. CONT	1.2 8v 69cv	BOSCH ABS 8 ESP
 500	ABS + TRACT. CONT	1.3 Multijet 16v 75cv	BOSCH ABS 8 ESP
 500	ABS + TRACT. CONT	1.3 Multijet 16v 95cv	BOSCH ABS 8 ESP
 500	ABS + TRACT. CONT	1.4 16v 100cv	BOSCH ABS 8 ESP
 500	AIRBAG	0.9 TwinAir Turbo 85cv (09-..)	Continental AirBag
 500	AIRBAG	0.9 TwinAir Turbo 85cv (09-..)	SIEMENS AirBag
 500	AIRBAG	1.2 8v 69cv	SIEMENS AirBag
 500	AIRBAG	1.2 8v 69cv (09-..)	Continental AirBag
 500	AIRBAG	1.3 Multijet 16v 75cv	SIEMENS AirBag
 500	AIRBAG	1.3 Multijet 16v 75cv (09-..)	Continental AirBag
 500	AIRBAG	1.3 Multijet 16v 95cv	SIEMENS AirBag
 500	AIRBAG	1.3 Multijet 16v 95cv (09-..)	Continental AirBag
 500	AIRBAG	1.4 16v 100cv	SIEMENS AirBag
 500	AIRBAG	1.4 16v 100cv (09-..)	Continental AirBag
 500	AUTOM. TRANSMISSI	0.9 TwinAir Turbo 85cv (09-..)	Marelli Selespeed CFC328 - 2
 500	AUTOM. TRANSMISSI	1.2 8v 69cv (09-..)	Marelli Selespeed CFC328 - 2
 500	AUTOM. TRANSMISSI	1.3 Multijet 16v 75cv (09-..)	Marelli Selespeed CFC328 - 2
 500	AUTOM. TRANSMISSI	1.3 Multijet 16v 95cv (09-..)	Marelli Selespeed CFC328 - 2
 500	AUTOM. TRANSMISSI	1.4 16v 100cv (09-..)	Marelli Selespeed CFC328 - 2
 500	CHASSIS NETWORK	0.9 TwinAir Turbo 85cv (09-..)	DELPHI Body Computer 2
 500	CHASSIS NETWORK	0.9 TwinAir Turbo 85cv (09-..)	DELPHI Body Computer Proxi Alignement
 500	CHASSIS NETWORK	1.2 8v 69cv	DELPHI Body Computer 2
 500	CHASSIS NETWORK	1.2 8v 69cv	DELPHI Body Computer Proxi Alignement
 500	CHASSIS NETWORK	1.3 Multijet 16v 75cv	DELPHI Body Computer 2
 500	CHASSIS NETWORK	1.3 Multijet 16v 75cv	DELPHI Body Computer Proxi Alignement
 500	CHASSIS NETWORK	1.3 Multijet 16v 95cv	DELPHI Body Computer 2
 500	CHASSIS NETWORK	1.3 Multijet 16v 95cv	DELPHI Body Computer Proxi Alignement
 500	CHASSIS NETWORK	1.4 16v 100cv	DELPHI Body Computer 2
 500	CHASSIS NETWORK	1.4 16v 100cv	DELPHI Body Computer Proxi Alignement
 500	CLIMA	0.9 TwinAir Turbo 85cv (09-..)	DENSO CLIMA Monozona
 500	CLIMA	1.2 8v 69cv	DENSO CLIMA Monozona
 500	CLIMA	1.3 Multijet 16v 75cv	DENSO CLIMA Monozona
 500	CLIMA	1.3 Multijet 16v 95cv	DENSO CLIMA Monozona
 500	CLIMA	1.4 16v 100cv	DENSO CLIMA Monozona
 500	DASHBOARD	0.9 TwinAir Turbo 85cv (09-..)	Marelli 2
 500	DASHBOARD	1.2 8v 69cv	Marelli 2
 500	DASHBOARD	1.3 Multijet 16v 75cv	Marelli 2
 500	DASHBOARD	1.3 Multijet 16v 95cv	Marelli 2
 500	DASHBOARD	1.4 16v 100cv	Marelli 2
 500	ELECTRIC STEERING	0.9 TwinAir Turbo 85cv (09-..)	DELPHI 2
 500	ELECTRIC STEERING	1.2 8v 69cv	DELPHI 2
 500	ELECTRIC STEERING	1.3 Multijet 16v 75cv	DELPHI 2
 500	ELECTRIC STEERING	1.3 Multijet 16v 95cv	DELPHI 2
 500	ELECTRIC STEERING	1.4 16v 100cv	DELPHI 2
 500	ENGINE MANAGEME	0.9 TwinAir Turbo 85cv (10-..)	Marelli IAW 8GSF CF5/EOBD
 500	ENGINE MANAGEME	1.2 8v 69cv	Marelli IAW 5SF3
 500	ENGINE MANAGEME	1.2 8v 69cv	Marelli IAW 5SF8 CF5/EOBD
 500	ENGINE MANAGEME	1.3 Multijet 16v 75cv	Marelli 6F3 EOBD CAN 2
 500	ENGINE MANAGEME	1.3 Multijet 16v 75cv (09-..)	Marelli EDC 8DF CF5
 500	ENGINE MANAGEME	1.3 Multijet 16v 95cv (09-..)	Marelli EDC 8DF CF5
 500	ENGINE MANAGEME	1.4 16v 100cv	BOSCH Motronic ME7.9.10 CF4-EOBD
 500	KEY ENCODE	0.9 TwinAir Turbo 85cv (09-..)	DELPHI Body Computer
 500	KEY ENCODE	1.2 8v 69cv	DELPHI Body Computer
 500	KEY ENCODE	1.3 Multijet 16v 75cv	DELPHI Body Computer
 500	KEY ENCODE	1.3 Multijet 16v 95cv	DELPHI Body Computer
 500	KEY ENCODE	1.4 16v 100cv	DELPHI Body Computer
 500	LH RIGHT MODULATI	0.9 TwinAir Turbo 85cv (09-..)	Litronic

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 500	LH RIGHT MODULATI	1.2 8v 69cv	Litronic
 500	LH RIGHT MODULATI	1.3 Multijet 16v 75cv	Litronic
 500	LH RIGHT MODULATI	1.3 Multijet 16v 95cv	Litronic
 500	LH RIGHT MODULATI	1.4 16v 100cv	Litronic
 500	MAINTENANCE	0.9 TwinAir Turbo 85cv (09-..)	DELPHI 2
 500	MAINTENANCE	0.9 TwinAir Turbo 85cv (09-..)	Litronic
 500	MAINTENANCE	0.9 TwinAir Turbo 85cv (09-..)	Litronic
 500	MAINTENANCE	0.9 TwinAir Turbo 85cv (09-..)	Marelli 2
 500	MAINTENANCE	0.9 TwinAir Turbo 85cv (09-..)	Marelli 2
 500	MAINTENANCE	0.9 TwinAir Turbo 85cv (10-..)	Marelli IAW 8GSF CF5/EOBD
 500	MAINTENANCE	0.9 TwinAir Turbo 85cv (10-..)	Marelli IAW 8GSF CF5/EOBD
 500	MAINTENANCE	0.9 TwinAir Turbo 85cv (10-..)	Marelli IAW 8GSF CF5/EOBD
 500	MAINTENANCE	0.9 TwinAir Turbo 85cv (10-..)	Marelli IAW 8GSF CF5/EOBD
 500	MAINTENANCE	0.9 TwinAir Turbo 85cv (10-..)	Marelli IAW 8GSF CF5/EOBD
 500	MAINTENANCE	0.9 TwinAir Turbo 85cv (10-..)	Marelli IAW 8GSF CF5/EOBD
 500	MAINTENANCE	0.9 TwinAir Turbo 85cv (10-..)	Marelli IAW 8GSF CF5/EOBD
 500	MAINTENANCE	0.9 TwinAir Turbo 85cv (10-..)	Marelli IAW 8GSF CF5/EOBD
 500	MAINTENANCE	0.9 TwinAir Turbo 85cv (10-..)	Marelli IAW 8GSF CF5/EOBD
 500	MAINTENANCE	0.9 TwinAir Turbo 85cv (10-..)	Marelli IAW 8GSF CF5/EOBD
 500	MAINTENANCE	0.9 TwinAir Turbo 85cv (10-..)	Marelli IAW 8GSF CF5/EOBD
 500	MAINTENANCE	0.9 TwinAir Turbo 85cv (10-..)	Marelli IAW 8GSF CF5/EOBD
 500	MAINTENANCE	0.9 TwinAir Turbo 85cv (10-..)	Marelli IAW 8GSF CF5/EOBD
 500	MAINTENANCE	0.9 TwinAir Turbo 85cv (10-..)	Marelli IAW 8GSF CF5/EOBD
 500	MAINTENANCE	0.9 TwinAir Turbo 85cv (10-..)	Marelli IAW 8GSF CF5/EOBD
 500	MAINTENANCE	0.9 TwinAir Turbo 85cv (10-..)	Marelli IAW 8GSF CF5/EOBD
 500	MAINTENANCE	0.9 TwinAir Turbo 85cv (10-..)	Marelli IAW 8GSF CF5/EOBD
 500	MAINTENANCE	0.9 TwinAir Turbo 85cv (10-..)	Marelli IAW 8GSF CF5/EOBD
 500	MAINTENANCE	0.9 TwinAir Turbo 85cv (10-..)	Marelli IAW 8GSF CF5/EOBD
 500	MAINTENANCE	1.2 8v 69cv	DELPHI 2
 500	MAINTENANCE	1.2 8v 69cv	Litronic
 500	MAINTENANCE	1.2 8v 69cv	Litronic
 500	MAINTENANCE	1.2 8v 69cv	Marelli 2
 500	MAINTENANCE	1.2 8v 69cv	Marelli 2
 500	MAINTENANCE	1.2 8v 69cv	Marelli IAW 5SF3
 500	MAINTENANCE	1.3 Multijet 16v 75cv	DELPHI 2
 500	MAINTENANCE	1.3 Multijet 16v 75cv	Litronic
 500	MAINTENANCE	1.3 Multijet 16v 75cv	Litronic
 500	MAINTENANCE	1.3 Multijet 16v 75cv	Marelli 2
 500	MAINTENANCE	1.3 Multijet 16v 75cv	Marelli 2
 500	MAINTENANCE	1.3 Multijet 16v 75cv	Marelli 6F3 EOBD CAN 2
 500	MAINTENANCE	1.3 Multijet 16v 75cv	Marelli 6F3 EOBD CAN 2
 500	MAINTENANCE	1.3 Multijet 16v 75cv	Marelli 6F3 EOBD CAN 2
 500	MAINTENANCE	1.3 Multijet 16v 75cv	Marelli 6F3 EOBD CAN 2
 500	MAINTENANCE	1.3 Multijet 16v 75cv (09-..)	Marelli EDC 8DF CF5
 500	MAINTENANCE	1.3 Multijet 16v 75cv (09-..)	Marelli EDC 8DF CF5
 500	MAINTENANCE	1.3 Multijet 16v 95cv	DELPHI 2
 500	MAINTENANCE	1.3 Multijet 16v 95cv	Litronic
 500	MAINTENANCE	1.3 Multijet 16v 95cv	Litronic
 500	MAINTENANCE	1.3 Multijet 16v 95cv	Marelli 2
 500	MAINTENANCE	1.3 Multijet 16v 95cv	Marelli 2
 500	MAINTENANCE	1.3 Multijet 16v 95cv (09-..)	Marelli EDC 8DF CF5
 500	MAINTENANCE	1.3 Multijet 16v 95cv (09-..)	Marelli EDC 8DF CF5
 500	MAINTENANCE	1.4 16v 100cv	DELPHI 2
 500	MAINTENANCE	1.4 16v 100cv	Litronic
 500	MAINTENANCE	1.4 16v 100cv	Litronic
 500	MAINTENANCE	1.4 16v 100cv	Marelli 2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 500	MAINTENANCE	1.4 16v 100cv	Marelli 2
 500	PARKING HELP	0.9 TwinAir Turbo 85cv (09-..)	Valeo 2
 500	PARKING HELP	1.2 8v 69cv	Valeo 2
 500	PARKING HELP	1.3 Multijet 16v 75cv	Valeo 2
 500	PARKING HELP	1.3 Multijet 16v 95cv	Valeo 2
 500	PARKING HELP	1.4 16v 100cv	Valeo 2
 500	RH LIGHT MODULATI	0.9 TwinAir Turbo 85cv (09-..)	Litronic
 500	RH LIGHT MODULATI	1.2 8v 69cv	Litronic
 500	RH LIGHT MODULATI	1.3 Multijet 16v 75cv	Litronic
 500	RH LIGHT MODULATI	1.3 Multijet 16v 95cv	Litronic
 500	RH LIGHT MODULATI	1.4 16v 100cv	Litronic
 500	VISUAL./TELEMATIC	0.9 TwinAir Turbo 85cv (09-..)	Convergence Lauberhorn
 500	VISUAL./TELEMATIC	0.9 TwinAir Turbo 85cv (09-..)	Convergence Marelli/Microsoft
 500	VISUAL./TELEMATIC	1.2 8v 69cv	Convergence Marelli/Microsoft
 500	VISUAL./TELEMATIC	1.2 8v 69cv (09-..)	Convergence Lauberhorn
 500	VISUAL./TELEMATIC	1.3 Multijet 16v 75cv	Convergence Marelli/Microsoft
 500	VISUAL./TELEMATIC	1.3 Multijet 16v 75cv (09-..)	Convergence Lauberhorn
 500	VISUAL./TELEMATIC	1.3 Multijet 16v 95cv	Convergence Marelli/Microsoft
 500	VISUAL./TELEMATIC	1.3 Multijet 16v 95cv (09-..)	Convergence Lauberhorn
 500	VISUAL./TELEMATIC	1.4 16v 100cv	Convergence Marelli/Microsoft
 500	VISUAL./TELEMATIC	1.4 16v 100cv (09-..)	Convergence Lauberhorn
 Barchetta	ABS	1.8 16v	BOSCH ABS 5.3
 Barchetta	AIRBAG	1.8 16v	TRW AirBag MY 97 (2F-2P)
 Barchetta	AIRBAG	1.8 16v	TRW AirBag MY 97 (2F-2P-I)
 Barchetta	AIRBAG	1.8 16v	TRW AirBag TRW2
 Barchetta	AIRBAG	1.8 16v	TRW-Becker AirBag no Pret.
 Barchetta	ENGINE MANAGEME	1.8 16v	HITACHI MPI MFI
 Barchetta	ENGINE MANAGEME	1.8 16v	HITACHI MPI MFI '98
 Brava	ABS	1.4 12v	ATE TEVES ABS Mk20
 Brava	ABS	1.4 12v	LUCAS ABS EBC 430
 Brava	ABS	1.6 16v	ATE TEVES ABS Mk20
 Brava	ABS	1.6 16v	LUCAS ABS EBC 430
 Brava	ABS	1.8 16v	ATE TEVES ABS Mk20
 Brava	ABS	1.8 16v	LUCAS ABS EBC 430
 Brava	ABS	1.9 D	ATE TEVES ABS Mk20
 Brava	ABS	1.9 D	LUCAS ABS EBC 430
 Brava	ABS	1.9 TD 75	ATE TEVES ABS Mk20
 Brava	ABS	1.9 TD 75	LUCAS ABS EBC 430
 Brava	ABS	100 1.6 16v	LUCAS ABS EBC 430
 Brava	ABS	100 1.6 16v (01-..)	ATE TEVES ABS Mk20
 Brava	ABS	100 1.6 16v (99-..)	ATE TEVES ABS Mk20
 Brava	ABS	100 1.6 16v CF3	LUCAS ABS EBC 430
 Brava	ABS	100 1.9 JTD	LUCAS ABS EBC 430
 Brava	ABS	100 1.9 JTD (01-..)	ATE TEVES ABS Mk20
 Brava	ABS	100 1.9 TD	ATE TEVES ABS Mk20
 Brava	ABS	100 1.9 TD	LUCAS ABS EBC 430
 Brava	ABS	105 1.9 JTD	LUCAS ABS EBC 430
 Brava	ABS	105 1.9 JTD (99-..)	ATE TEVES ABS Mk20
 Brava	ABS	110 1.9 JTD	LUCAS ABS EBC 430
 Brava	ABS	115 1.8 16v	LUCAS ABS EBC 430
 Brava	ABS	115 1.8 16v (01-..)	ATE TEVES ABS Mk20
 Brava	ABS	115 1.8 16v (99-..)	ATE TEVES ABS Mk20
 Brava	ABS	155 2.0 16v	LUCAS ABS EBC 430
 Brava	ABS	155 2.0 16v (99-..)	ATE TEVES ABS Mk20
 Brava	ABS	155 2.0 20v	LUCAS ABS EBC 430
 Brava	ABS	2.0 20v	ATE TEVES ABS Mk20
 Brava	ABS	2.0 20v	LUCAS ABS EBC 430
 Brava	ABS	80 1.2 16v	LUCAS ABS EBC 430

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Brava	ABS	80 1.2 16v (01-..)	ATE TEVES ABS Mk20
 Brava	ABS	80 1.2 16v (99-..)	ATE TEVES ABS Mk20
 Brava	AIRBAG	1.4 12v	BREED AirBag MY 95
 Brava	AIRBAG	1.4 12v	BREED AirBag MY 97 (2F)
 Brava	AIRBAG	1.4 12v	BREED AirBag MY 97 (2F-2L)
 Brava	AIRBAG	1.4 12v	BREED AirBag MY 97 (2F-2L-S)
 Brava	AIRBAG	1.4 12v	BREED AirBag MY 97 (2F-S)
 Brava	AIRBAG	1.4 12v (99-..)	BREED AirBag MY 97 (2F-2L)
 Brava	AIRBAG	1.4 12v (99-..)	BREED AirBag MY 97 (2F-2L-S)
 Brava	AIRBAG	1.4 12v (99-..)	BREED AirBag MY 97 (2F-S)
 Brava	AIRBAG	1.4 12v (99-..)	SIEMENS AirBag MY 97 (2F)
 Brava	AIRBAG	1.6 16v	BREED AirBag MY 95
 Brava	AIRBAG	1.6 16v	BREED AirBag MY 97 (2F)
 Brava	AIRBAG	1.6 16v	BREED AirBag MY 97 (2F-2L)
 Brava	AIRBAG	1.6 16v	BREED AirBag MY 97 (2F-2L-S)
 Brava	AIRBAG	1.6 16v	BREED AirBag MY 97 (2F-S)
 Brava	AIRBAG	1.6 16v (99-..)	BREED AirBag MY 97 (2F-2L)
 Brava	AIRBAG	1.6 16v (99-..)	BREED AirBag MY 97 (2F-2L-S)
 Brava	AIRBAG	1.6 16v (99-..)	BREED AirBag MY 97 (2F-S)
 Brava	AIRBAG	1.6 16v (99-..)	SIEMENS AirBag MY 97 (2F)
 Brava	AIRBAG	1.8 16v	BREED AirBag MY 95
 Brava	AIRBAG	1.8 16v	BREED AirBag MY 97 (2F)
 Brava	AIRBAG	1.8 16v	BREED AirBag MY 97 (2F-2L)
 Brava	AIRBAG	1.8 16v	BREED AirBag MY 97 (2F-2L-S)
 Brava	AIRBAG	1.8 16v	BREED AirBag MY 97 (2F-S)
 Brava	AIRBAG	1.8 16v (99-..)	BREED AirBag MY 97 (2F-2L)
 Brava	AIRBAG	1.8 16v (99-..)	BREED AirBag MY 97 (2F-2L-S)
 Brava	AIRBAG	1.8 16v (99-..)	BREED AirBag MY 97 (2F-S)
 Brava	AIRBAG	1.8 16v (99-..)	SIEMENS AirBag MY 97 (2F)
 Brava	AIRBAG	1.9 D	BREED AirBag MY 95
 Brava	AIRBAG	1.9 D	BREED AirBag MY 97 (2F)
 Brava	AIRBAG	1.9 D	BREED AirBag MY 97 (2F-2L)
 Brava	AIRBAG	1.9 D	BREED AirBag MY 97 (2F-2L-S)
 Brava	AIRBAG	1.9 D	BREED AirBag MY 97 (2F-S)
 Brava	AIRBAG	1.9 D (99-..)	BREED AirBag MY 97 (2F-2L)
 Brava	AIRBAG	1.9 D (99-..)	BREED AirBag MY 97 (2F-2L-S)
 Brava	AIRBAG	1.9 D (99-..)	BREED AirBag MY 97 (2F-S)
 Brava	AIRBAG	1.9 D (99-..)	SIEMENS AirBag MY 97 (2F)
 Brava	AIRBAG	1.9 TD 75	BREED AirBag MY 95
 Brava	AIRBAG	1.9 TD 75	BREED AirBag MY 97 (2F)
 Brava	AIRBAG	1.9 TD 75	BREED AirBag MY 97 (2F-2L)
 Brava	AIRBAG	1.9 TD 75	BREED AirBag MY 97 (2F-2L-S)
 Brava	AIRBAG	1.9 TD 75	BREED AirBag MY 97 (2F-S)
 Brava	AIRBAG	1.9 TD 75 (99-..)	BREED AirBag MY 97 (2F-2L)
 Brava	AIRBAG	1.9 TD 75 (99-..)	BREED AirBag MY 97 (2F-2L-S)
 Brava	AIRBAG	1.9 TD 75 (99-..)	BREED AirBag MY 97 (2F-S)
 Brava	AIRBAG	1.9 TD 75 (99-..)	SIEMENS AirBag MY 97 (2F)
 Brava	AIRBAG	100 1.6 16v	BREED AirBag MY 95
 Brava	AIRBAG	100 1.6 16v	BREED AirBag MY 97 (2F)
 Brava	AIRBAG	100 1.6 16v	BREED AirBag MY 97 (2F-2L)
 Brava	AIRBAG	100 1.6 16v	BREED AirBag MY 97 (2F-2L-S)
 Brava	AIRBAG	100 1.6 16v	BREED AirBag MY 97 (2F-S)
 Brava	AIRBAG	100 1.6 16v (99-..)	BREED AirBag MY 97 (2F-2L)
 Brava	AIRBAG	100 1.6 16v (99-..)	BREED AirBag MY 97 (2F-2L-S)
 Brava	AIRBAG	100 1.6 16v (99-..)	BREED AirBag MY 97 (2F-S)
 Brava	AIRBAG	100 1.6 16v (99-..)	SIEMENS AirBag MY 97 (2F)
 Brava	AIRBAG	100 1.6 16v CF3	BREED AirBag MY 95
 Brava	AIRBAG	100 1.6 16v CF3	BREED AirBag MY 97 (2F)

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Brava	AIRBAG	100 1.6 16v CF3	BREED AirBag MY 97 (2F-2L)
 Brava	AIRBAG	100 1.6 16v CF3	BREED AirBag MY 97 (2F-2L-S)
 Brava	AIRBAG	100 1.6 16v CF3	BREED AirBag MY 97 (2F-S)
 Brava	AIRBAG	100 1.6 16v CF3 (99-..)	BREED AirBag MY 97 (2F-2L)
 Brava	AIRBAG	100 1.6 16v CF3 (99-..)	BREED AirBag MY 97 (2F-2L-S)
 Brava	AIRBAG	100 1.6 16v CF3 (99-..)	BREED AirBag MY 97 (2F-S)
 Brava	AIRBAG	100 1.6 16v CF3 (99-..)	SIEMENS AirBag MY 97 (2F)
 Brava	AIRBAG	100 1.9 JTD	BREED AirBag MY 95
 Brava	AIRBAG	100 1.9 JTD	BREED AirBag MY 97 (2F)
 Brava	AIRBAG	100 1.9 JTD	BREED AirBag MY 97 (2F-2L)
 Brava	AIRBAG	100 1.9 JTD	BREED AirBag MY 97 (2F-2L-S)
 Brava	AIRBAG	100 1.9 JTD	BREED AirBag MY 97 (2F-S)
 Brava	AIRBAG	100 1.9 JTD (99-..)	BREED AirBag MY 97 (2F-2L)
 Brava	AIRBAG	100 1.9 JTD (99-..)	BREED AirBag MY 97 (2F-2L-S)
 Brava	AIRBAG	100 1.9 JTD (99-..)	BREED AirBag MY 97 (2F-S)
 Brava	AIRBAG	100 1.9 JTD (99-..)	SIEMENS AirBag MY 97 (2F)
 Brava	AIRBAG	100 1.9 TD	BREED AirBag MY 95
 Brava	AIRBAG	100 1.9 TD	BREED AirBag MY 97 (2F)
 Brava	AIRBAG	100 1.9 TD	BREED AirBag MY 97 (2F-2L)
 Brava	AIRBAG	100 1.9 TD	BREED AirBag MY 97 (2F-2L-S)
 Brava	AIRBAG	100 1.9 TD	BREED AirBag MY 97 (2F-S)
 Brava	AIRBAG	100 1.9 TD (99-..)	BREED AirBag MY 97 (2F-2L)
 Brava	AIRBAG	100 1.9 TD (99-..)	BREED AirBag MY 97 (2F-2L-S)
 Brava	AIRBAG	100 1.9 TD (99-..)	BREED AirBag MY 97 (2F-S)
 Brava	AIRBAG	100 1.9 TD (99-..)	SIEMENS AirBag MY 97 (2F)
 Brava	AIRBAG	105 1.9 JTD	BREED AirBag MY 95
 Brava	AIRBAG	105 1.9 JTD	BREED AirBag MY 97 (2F)
 Brava	AIRBAG	105 1.9 JTD	BREED AirBag MY 97 (2F-2L)
 Brava	AIRBAG	105 1.9 JTD	BREED AirBag MY 97 (2F-2L-S)
 Brava	AIRBAG	105 1.9 JTD	BREED AirBag MY 97 (2F-S)
 Brava	AIRBAG	105 1.9 JTD (99-..)	BREED AirBag MY 97 (2F-2L)
 Brava	AIRBAG	105 1.9 JTD (99-..)	BREED AirBag MY 97 (2F-2L-S)
 Brava	AIRBAG	105 1.9 JTD (99-..)	BREED AirBag MY 97 (2F-S)
 Brava	AIRBAG	105 1.9 JTD (99-..)	SIEMENS AirBag MY 97 (2F)
 Brava	AIRBAG	110 1.9 JTD	BREED AirBag MY 95
 Brava	AIRBAG	110 1.9 JTD	BREED AirBag MY 97 (2F)
 Brava	AIRBAG	110 1.9 JTD	BREED AirBag MY 97 (2F-2L)
 Brava	AIRBAG	110 1.9 JTD	BREED AirBag MY 97 (2F-2L-S)
 Brava	AIRBAG	110 1.9 JTD	BREED AirBag MY 97 (2F-S)
 Brava	AIRBAG	110 1.9 JTD (99-..)	BREED AirBag MY 97 (2F-2L)
 Brava	AIRBAG	110 1.9 JTD (99-..)	BREED AirBag MY 97 (2F-2L-S)
 Brava	AIRBAG	110 1.9 JTD (99-..)	BREED AirBag MY 97 (2F-S)
 Brava	AIRBAG	110 1.9 JTD (99-..)	SIEMENS AirBag MY 97 (2F)
 Brava	AIRBAG	115 1.8 16v	BREED AirBag MY 95
 Brava	AIRBAG	115 1.8 16v	BREED AirBag MY 97 (2F)
 Brava	AIRBAG	115 1.8 16v	BREED AirBag MY 97 (2F-2L)
 Brava	AIRBAG	115 1.8 16v	BREED AirBag MY 97 (2F-2L-S)
 Brava	AIRBAG	115 1.8 16v	BREED AirBag MY 97 (2F-S)
 Brava	AIRBAG	115 1.8 16v (99-..)	BREED AirBag MY 97 (2F-2L)
 Brava	AIRBAG	115 1.8 16v (99-..)	BREED AirBag MY 97 (2F-2L-S)
 Brava	AIRBAG	115 1.8 16v (99-..)	BREED AirBag MY 97 (2F-S)
 Brava	AIRBAG	115 1.8 16v (99-..)	SIEMENS AirBag MY 97 (2F)
 Brava	AIRBAG	155 2.0 16v	BREED AirBag MY 95
 Brava	AIRBAG	155 2.0 16v	BREED AirBag MY 97 (2F)
 Brava	AIRBAG	155 2.0 16v	BREED AirBag MY 97 (2F-2L)
 Brava	AIRBAG	155 2.0 16v	BREED AirBag MY 97 (2F-2L-S)
 Brava	AIRBAG	155 2.0 16v	BREED AirBag MY 97 (2F-S)
 Brava	AIRBAG	155 2.0 16v (99-..)	BREED AirBag MY 97 (2F-2L)

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Brava	AIRBAG	155 2.0 16v (99-..)	BREED AirBag MY 97 (2F-2L-S)
 Brava	AIRBAG	155 2.0 16v (99-..)	BREED AirBag MY 97 (2F-S)
 Brava	AIRBAG	155 2.0 16v (99-..)	SIEMENS AirBag MY 97 (2F)
 Brava	AIRBAG	155 2.0 20v	BREED AirBag MY 95
 Brava	AIRBAG	155 2.0 20v	BREED AirBag MY 97 (2F)
 Brava	AIRBAG	155 2.0 20v	BREED AirBag MY 97 (2F-2L)
 Brava	AIRBAG	155 2.0 20v	BREED AirBag MY 97 (2F-2L-S)
 Brava	AIRBAG	155 2.0 20v	BREED AirBag MY 97 (2F-S)
 Brava	AIRBAG	155 2.0 20v (99-..)	BREED AirBag MY 97 (2F-2L)
 Brava	AIRBAG	155 2.0 20v (99-..)	BREED AirBag MY 97 (2F-2L-S)
 Brava	AIRBAG	155 2.0 20v (99-..)	BREED AirBag MY 97 (2F-S)
 Brava	AIRBAG	155 2.0 20v (99-..)	SIEMENS AirBag MY 97 (2F)
 Brava	AIRBAG	2.0 20v	BREED AirBag MY 95
 Brava	AIRBAG	2.0 20v	BREED AirBag MY 97 (2F)
 Brava	AIRBAG	2.0 20v	BREED AirBag MY 97 (2F-2L)
 Brava	AIRBAG	2.0 20v	BREED AirBag MY 97 (2F-2L-S)
 Brava	AIRBAG	2.0 20v	BREED AirBag MY 97 (2F-S)
 Brava	AIRBAG	2.0 20v (99-..)	BREED AirBag MY 97 (2F-2L)
 Brava	AIRBAG	2.0 20v (99-..)	BREED AirBag MY 97 (2F-2L-S)
 Brava	AIRBAG	2.0 20v (99-..)	BREED AirBag MY 97 (2F-S)
 Brava	AIRBAG	2.0 20v (99-..)	SIEMENS AirBag MY 97 (2F)
 Brava	AIRBAG	80 1.2 16v	BREED AirBag MY 95
 Brava	AIRBAG	80 1.2 16v	BREED AirBag MY 97 (2F)
 Brava	AIRBAG	80 1.2 16v	BREED AirBag MY 97 (2F-2L)
 Brava	AIRBAG	80 1.2 16v	BREED AirBag MY 97 (2F-2L-S)
 Brava	AIRBAG	80 1.2 16v	BREED AirBag MY 97 (2F-S)
 Brava	AIRBAG	80 1.2 16v (99-..)	BREED AirBag MY 97 (2F-2L)
 Brava	AIRBAG	80 1.2 16v (99-..)	BREED AirBag MY 97 (2F-2L-S)
 Brava	AIRBAG	80 1.2 16v (99-..)	BREED AirBag MY 97 (2F-S)
 Brava	AIRBAG	80 1.2 16v (99-..)	SIEMENS AirBag MY 97 (2F)
 Brava	CLIMA	1.4 12v	Borletti Klima MANUAL
 Brava	CLIMA	1.6 16v	Borletti Klima MANUAL
 Brava	CLIMA	1.8 16v	Borletti Klima MANUAL
 Brava	CLIMA	1.9 D	Borletti Klima MANUAL
 Brava	CLIMA	1.9 TD 75	Borletti Klima MANUAL
 Brava	CLIMA	100 1.6 16v	Borletti Klima MANUAL
 Brava	CLIMA	100 1.6 16v CF3	Borletti Klima MANUAL
 Brava	CLIMA	100 1.9 JTD	Borletti Klima MANUAL
 Brava	CLIMA	100 1.9 TD	Borletti Klima MANUAL
 Brava	CLIMA	105 1.9 JTD	Borletti Klima MANUAL
 Brava	CLIMA	110 1.9 JTD	Borletti Klima MANUAL
 Brava	CLIMA	115 1.8 16v	Borletti Klima MANUAL
 Brava	CLIMA	155 2.0 16v	Borletti Klima MANUAL
 Brava	CLIMA	155 2.0 20v	Borletti Klima MANUAL
 Brava	CLIMA	2.0 20v	Borletti Klima MANUAL
 Brava	CLIMA	80 1.2 16v	Borletti Klima MANUAL
 Brava	DIESEL MANAGEME	100 1.9 TD	LUCAS Diesel DCN
 Brava	ENGINE MANAGEME	1.4 12v	BOSCH MonoMotronic MA1.7.3
 Brava	ENGINE MANAGEME	1.4 12v	BOSCH MonoMotronic MA1.7.3
 Brava	ENGINE MANAGEME	1.4 12v	BOSCH MonoMotronic MA1.7.3
 Brava	ENGINE MANAGEME	1.4 12v	BOSCH MonoMotronic MA1.7.3
 Brava	ENGINE MANAGEME	1.6 16v	Marelli IAW 1AF.13
 Brava	ENGINE MANAGEME	1.6 16v	Marelli IAW 1AF.13
 Brava	ENGINE MANAGEME	1.6 16v	Marelli IAW 1AF.13
 Brava	ENGINE MANAGEME	1.6 16v	Marelli IAW 1AF.13
 Brava	ENGINE MANAGEME	1.6 16v	Marelli IAW 1AF.16
 Brava	ENGINE MANAGEME	1.6 16v	Marelli IAW 1AF.16
 Brava	ENGINE MANAGEME	1.6 16v	Marelli IAW 1AF.17

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Brava	ENGINE MANAGEME	1.8 16v	HITACHI MPI MFI
 Brava	ENGINE MANAGEME	100 1.6 16v (99-..)	Marelli IAW 49F
 Brava	ENGINE MANAGEME	100 1.6 16v CF3 (01-..)	Marelli IAW 49F/59F EOBD
 Brava	ENGINE MANAGEME	100 1.9 JTD (01-..)	BOSCH EDC 15 Common Rail (JTD '99)
 Brava	ENGINE MANAGEME	105 1.9 JTD (...98)	BOSCH EDC 15 Common Rail
 Brava	ENGINE MANAGEME	110 1.9 JTD (99-..)	BOSCH EDC 15 Common Rail (JTD '99)
 Brava	ENGINE MANAGEME	115 1.8 16v (99-..)	HITACHI MPI MFI '98
 Brava	ENGINE MANAGEME	155 2.0 20v (99-..)	BOSCH Motronic ME3.1
 Brava	ENGINE MANAGEME	2.0 20v	BOSCH Motronic M2.10.4
 Brava	ENGINE MANAGEME	2.0 20v	BOSCH Motronic M2.10.4
 Brava	ENGINE MANAGEME	80 1.2 16v (01-..)	BOSCH Motronic ME7.3 H4
 Brava	ENGINE MANAGEME	80 1.2 16v (99-..)	BOSCH Motronic M1.5.5
 Brava	KEY ENCODE	1.4 12v	BOSCH CODE MANUAL
 Brava	KEY ENCODE	1.6 16v	BOSCH CODE MANUAL
 Brava	KEY ENCODE	1.8 16v	BOSCH CODE MANUAL
 Brava	KEY ENCODE	1.9 D	BOSCH CODE MANUAL
 Brava	KEY ENCODE	1.9 TD 75	BOSCH CODE MANUAL
 Brava	KEY ENCODE	100 1.6 16v	BOSCH CODE MANUAL
 Brava	KEY ENCODE	100 1.6 16v CF3	BOSCH CODE MANUAL
 Brava	KEY ENCODE	100 1.9 JTD	BOSCH CODE MANUAL
 Brava	KEY ENCODE	100 1.9 TD	BOSCH CODE MANUAL
 Brava	KEY ENCODE	105 1.9 JTD	BOSCH CODE MANUAL
 Brava	KEY ENCODE	110 1.9 JTD	BOSCH CODE MANUAL
 Brava	KEY ENCODE	115 1.8 16v	BOSCH CODE MANUAL
 Brava	KEY ENCODE	155 2.0 16v	BOSCH CODE MANUAL
 Brava	KEY ENCODE	155 2.0 20v	BOSCH CODE MANUAL
 Brava	KEY ENCODE	2.0 20v	BOSCH CODE MANUAL
 Brava	KEY ENCODE	80 1.2 16v	BOSCH CODE MANUAL
 Brava	MAINTENANCE	1.4 12v	Borletti Klima MANUAL
 Brava	MAINTENANCE	1.4 12v	BOSCH CODE MANUAL
 Brava	MAINTENANCE	1.6 16v	Borletti Klima MANUAL
 Brava	MAINTENANCE	1.6 16v	BOSCH CODE MANUAL
 Brava	MAINTENANCE	1.8 16v	Borletti Klima MANUAL
 Brava	MAINTENANCE	1.8 16v	BOSCH CODE MANUAL
 Brava	MAINTENANCE	1.9 D	Borletti Klima MANUAL
 Brava	MAINTENANCE	1.9 D	BOSCH CODE MANUAL
 Brava	MAINTENANCE	1.9 TD 75	Borletti Klima MANUAL
 Brava	MAINTENANCE	1.9 TD 75	BOSCH CODE MANUAL
 Brava	MAINTENANCE	100 1.6 16v	Borletti Klima MANUAL
 Brava	MAINTENANCE	100 1.6 16v	BOSCH CODE MANUAL
 Brava	MAINTENANCE	100 1.6 16v CF3	Borletti Klima MANUAL
 Brava	MAINTENANCE	100 1.6 16v CF3	BOSCH CODE MANUAL
 Brava	MAINTENANCE	100 1.9 JTD	Borletti Klima MANUAL
 Brava	MAINTENANCE	100 1.9 JTD	BOSCH CODE MANUAL
 Brava	MAINTENANCE	100 1.9 TD	Borletti Klima MANUAL
 Brava	MAINTENANCE	100 1.9 TD	BOSCH CODE MANUAL
 Brava	MAINTENANCE	105 1.9 JTD	Borletti Klima MANUAL
 Brava	MAINTENANCE	105 1.9 JTD	BOSCH CODE MANUAL
 Brava	MAINTENANCE	110 1.9 JTD	Borletti Klima MANUAL
 Brava	MAINTENANCE	110 1.9 JTD	BOSCH CODE MANUAL
 Brava	MAINTENANCE	115 1.8 16v	Borletti Klima MANUAL
 Brava	MAINTENANCE	115 1.8 16v	BOSCH CODE MANUAL
 Brava	MAINTENANCE	155 2.0 16v	Borletti Klima MANUAL
 Brava	MAINTENANCE	155 2.0 16v	BOSCH CODE MANUAL
 Brava	MAINTENANCE	155 2.0 20v	Borletti Klima MANUAL
 Brava	MAINTENANCE	155 2.0 20v	BOSCH CODE MANUAL
 Brava	MAINTENANCE	2.0 20v	Borletti Klima MANUAL
 Brava	MAINTENANCE	2.0 20v	BOSCH CODE MANUAL

Systems supported by ECUREADER / ECUDECODER (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Brava	MAINTENANCE	80 1.2 16v	Borletti Klima MANUAL
 Brava	MAINTENANCE	80 1.2 16v	BOSCH CODE MANUAL
 Bravo (198)	ABS + TRACT. CONT	1.4 16v	BOSCH ABS/VDC 8
 Bravo (198)	ABS + TRACT. CONT	1.4 16v T-JET	BOSCH ABS/VDC 8
 Bravo (198)	ABS + TRACT. CONT	1.4 Turbo Multiair 16v	BOSCH ABS/VDC 8
 Bravo (198)	ABS + TRACT. CONT	1.6 MJET 16v	BOSCH ABS/VDC 8
 Bravo (198)	ABS + TRACT. CONT	1.9 Multijet 16v	BOSCH ABS/VDC 8
 Bravo (198)	ABS + TRACT. CONT	1.9 Multijet 8v	BOSCH ABS/VDC 8
 Bravo (198)	ABS + TRACT. CONT	2.0 MJET 16v	BOSCH ABS/VDC 8
 Bravo (198)	AIRBAG	1.4 16v	SIEMENS AirBag 1
 Bravo (198)	AIRBAG	1.4 16v T-JET	SIEMENS AirBag 1
 Bravo (198)	AIRBAG	1.4 Turbo Multiair 16v	SIEMENS AirBag 1
 Bravo (198)	AIRBAG	1.6 MJET 16v	SIEMENS AirBag 1
 Bravo (198)	AIRBAG	1.9 Multijet 16v	SIEMENS AirBag 1
 Bravo (198)	AIRBAG	1.9 Multijet 8v	SIEMENS AirBag 1
 Bravo (198)	AIRBAG	2.0 MJET 16v	SIEMENS AirBag 1
 Bravo (198)	CHASSIS NETWORK	1.4 16v	Fiat Proxi Alignement
 Bravo (198)	CHASSIS NETWORK	1.4 16v	Marelli Body Comp.+Key Encoding 8
 Bravo (198)	CHASSIS NETWORK	1.4 16v	Marelli CAN info
 Bravo (198)	CHASSIS NETWORK	1.4 16v T-JET	Fiat Proxi Alignement
 Bravo (198)	CHASSIS NETWORK	1.4 16v T-JET	Marelli Body Comp.+Key Encoding 8
 Bravo (198)	CHASSIS NETWORK	1.4 16v T-JET	Marelli CAN info
 Bravo (198)	CHASSIS NETWORK	1.4 Turbo Multiair 16v	Fiat Proxi Alignement
 Bravo (198)	CHASSIS NETWORK	1.4 Turbo Multiair 16v	Marelli Body Comp.+Key Encoding 8
 Bravo (198)	CHASSIS NETWORK	1.4 Turbo Multiair 16v	Marelli CAN info
 Bravo (198)	CHASSIS NETWORK	1.6 MJET 16v	Fiat Proxi Alignement
 Bravo (198)	CHASSIS NETWORK	1.6 MJET 16v	Marelli Body Comp.+Key Encoding 8
 Bravo (198)	CHASSIS NETWORK	1.6 MJET 16v	Marelli CAN info
 Bravo (198)	CHASSIS NETWORK	1.9 Multijet 16v	Fiat Proxi Alignement
 Bravo (198)	CHASSIS NETWORK	1.9 Multijet 16v	Marelli Body Comp.+Key Encoding 8
 Bravo (198)	CHASSIS NETWORK	1.9 Multijet 16v	Marelli CAN info
 Bravo (198)	CHASSIS NETWORK	1.9 Multijet 8v	Fiat Proxi Alignement
 Bravo (198)	CHASSIS NETWORK	1.9 Multijet 8v	Marelli Body Comp.+Key Encoding 8
 Bravo (198)	CHASSIS NETWORK	1.9 Multijet 8v	Marelli CAN info
 Bravo (198)	CHASSIS NETWORK	2.0 MJET 16v	Fiat Proxi Alignement
 Bravo (198)	CHASSIS NETWORK	2.0 MJET 16v	Marelli Body Comp.+Key Encoding 8
 Bravo (198)	CHASSIS NETWORK	2.0 MJET 16v	Marelli CAN info
 Bravo (198)	CLIMA	1.4 16v	Marelli Klima
 Bravo (198)	CLIMA	1.4 16v T-JET	Marelli Klima
 Bravo (198)	CLIMA	1.4 Turbo Multiair 16v	Marelli Klima
 Bravo (198)	CLIMA	1.6 MJET 16v	Marelli Klima
 Bravo (198)	CLIMA	1.9 Multijet 16v	Marelli Klima
 Bravo (198)	CLIMA	1.9 Multijet 8v	Marelli Klima
 Bravo (198)	CLIMA	2.0 MJET 16v	Marelli Klima
 Bravo (198)	DASHBOARD	1.4 16v	Marelli
 Bravo (198)	DASHBOARD	1.4 16v T-JET	Marelli
 Bravo (198)	DASHBOARD	1.4 Turbo Multiair 16v	Marelli
 Bravo (198)	DASHBOARD	1.6 MJET 16v	Marelli
 Bravo (198)	DASHBOARD	1.9 Multijet 16v	Marelli
 Bravo (198)	DASHBOARD	1.9 Multijet 8v	Marelli
 Bravo (198)	DASHBOARD	2.0 MJET 16v	Marelli
 Bravo (198)	DRIVER SEAT CONT	1.4 16v	LEAR 3 DRIVER SEAT
 Bravo (198)	DRIVER SEAT CONT	1.4 16v T-JET	LEAR 3 DRIVER SEAT
 Bravo (198)	DRIVER SEAT CONT	1.4 Turbo Multiair 16v	LEAR 3 DRIVER SEAT
 Bravo (198)	DRIVER SEAT CONT	1.6 MJET 16v	LEAR 3 DRIVER SEAT
 Bravo (198)	DRIVER SEAT CONT	1.9 Multijet 16v	LEAR 3 DRIVER SEAT
 Bravo (198)	DRIVER SEAT CONT	1.9 Multijet 8v	LEAR 3 DRIVER SEAT
 Bravo (198)	DRIVER SEAT CONT	2.0 MJET 16v	LEAR 3 DRIVER SEAT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Bravo (198)	ELECTRIC STEERING	1.4 16v	TRW EPS 3
 Bravo (198)	ELECTRIC STEERING	1.4 16v T-JET	TRW EPS 3
 Bravo (198)	ELECTRIC STEERING	1.4 Turbo Multiair 16v	TRW EPS 3
 Bravo (198)	ELECTRIC STEERING	1.6 MJET 16v	TRW EPS 3
 Bravo (198)	ELECTRIC STEERING	1.9 Multijet 16v	TRW EPS 3
 Bravo (198)	ELECTRIC STEERING	1.9 Multijet 8v	TRW EPS 3
 Bravo (198)	ELECTRIC STEERING	2.0 MJET 16v	TRW EPS 3
 Bravo (198)	ENGINE MANAGEME	1.4 16v	BOSCH Motronic ME7.3H4M EOBD
 Bravo (198)	ENGINE MANAGEME	1.4 Turbo Multiair 16v (10-..)	Marelli IAW 8GMF CF5/EOBD
 Bravo (198)	ENGINE MANAGEME	1.6 MJET 16v (07-..)	BOSCH EDC 16C39 CF5/EOBD
 Bravo (198)	ENGINE MANAGEME	1.9 Multijet 16v	BOSCH EDC 16 Common Rail
 Bravo (198)	ENGINE MANAGEME	1.9 Multijet 8v	BOSCH EDC 16 Common Rail
 Bravo (198)	ENGINE MANAGEME	2.0 MJET 16v (07-..)	BOSCH EDC 16C39 CF5/EOBD
 Bravo (198)	LH RIGHT MODULATI	1.4 16v	Litronic
 Bravo (198)	LH RIGHT MODULATI	1.4 16v T-JET	Litronic
 Bravo (198)	LH RIGHT MODULATI	1.4 Turbo Multiair 16v	Litronic
 Bravo (198)	LH RIGHT MODULATI	1.6 MJET 16v	Litronic
 Bravo (198)	LH RIGHT MODULATI	1.9 Multijet 16v	Litronic
 Bravo (198)	LH RIGHT MODULATI	1.9 Multijet 8v	Litronic
 Bravo (198)	LH RIGHT MODULATI	2.0 MJET 16v	Litronic
 Bravo (198)	MAINTENANCE	1.4 16v	BOSCH ABS/VDC 8
 Bravo (198)	MAINTENANCE	1.4 16v	Litronic
 Bravo (198)	MAINTENANCE	1.4 16v	Litronic
 Bravo (198)	MAINTENANCE	1.4 16v	Marelli
 Bravo (198)	MAINTENANCE	1.4 16v T-JET	BOSCH ABS/VDC 8
 Bravo (198)	MAINTENANCE	1.4 16v T-JET	Litronic
 Bravo (198)	MAINTENANCE	1.4 16v T-JET	Litronic
 Bravo (198)	MAINTENANCE	1.4 16v T-JET	Marelli
 Bravo (198)	MAINTENANCE	1.4 Turbo Multiair 16v	BOSCH ABS/VDC 8
 Bravo (198)	MAINTENANCE	1.4 Turbo Multiair 16v	Litronic
 Bravo (198)	MAINTENANCE	1.4 Turbo Multiair 16v	Litronic
 Bravo (198)	MAINTENANCE	1.4 Turbo Multiair 16v	Marelli
 Bravo (198)	MAINTENANCE	1.4 Turbo Multiair 16v (10-..)	Marelli IAW 8GMF CF5/EOBD
 Bravo (198)	MAINTENANCE	1.4 Turbo Multiair 16v (10-..)	Marelli IAW 8GMF CF5/EOBD
 Bravo (198)	MAINTENANCE	1.4 Turbo Multiair 16v (10-..)	Marelli IAW 8GMF CF5/EOBD
 Bravo (198)	MAINTENANCE	1.4 Turbo Multiair 16v (10-..)	Marelli IAW 8GMF CF5/EOBD
 Bravo (198)	MAINTENANCE	1.4 Turbo Multiair 16v (10-..)	Marelli IAW 8GMF CF5/EOBD
 Bravo (198)	MAINTENANCE	1.4 Turbo Multiair 16v (10-..)	Marelli IAW 8GMF CF5/EOBD
 Bravo (198)	MAINTENANCE	1.4 Turbo Multiair 16v (10-..)	Marelli IAW 8GMF CF5/EOBD
 Bravo (198)	MAINTENANCE	1.4 Turbo Multiair 16v (10-..)	Marelli IAW 8GMF CF5/EOBD
 Bravo (198)	MAINTENANCE	1.4 Turbo Multiair 16v (10-..)	Marelli IAW 8GMF CF5/EOBD
 Bravo (198)	MAINTENANCE	1.4 Turbo Multiair 16v (10-..)	Marelli IAW 8GMF CF5/EOBD
 Bravo (198)	MAINTENANCE	1.4 Turbo Multiair 16v (10-..)	Marelli IAW 8GMF CF5/EOBD
 Bravo (198)	MAINTENANCE	1.4 Turbo Multiair 16v (10-..)	Marelli IAW 8GMF CF5/EOBD
 Bravo (198)	MAINTENANCE	1.4 Turbo Multiair 16v (10-..)	Marelli IAW 8GMF CF5/EOBD
 Bravo (198)	MAINTENANCE	1.4 Turbo Multiair 16v (10-..)	Marelli IAW 8GMF CF5/EOBD
 Bravo (198)	MAINTENANCE	1.4 Turbo Multiair 16v (10-..)	Marelli IAW 8GMF CF5/EOBD
 Bravo (198)	MAINTENANCE	1.4 Turbo Multiair 16v (10-..)	Marelli IAW 8GMF CF5/EOBD
 Bravo (198)	MAINTENANCE	1.4 Turbo Multiair 16v (10-..)	Marelli IAW 8GMF CF5/EOBD
 Bravo (198)	MAINTENANCE	1.4 Turbo Multiair 16v (10-..)	Marelli IAW 8GMF CF5/EOBD
 Bravo (198)	MAINTENANCE	1.4 Turbo Multiair 16v (10-..)	Marelli IAW 8GMF CF5/EOBD
 Bravo (198)	MAINTENANCE	1.4 Turbo Multiair 16v (10-..)	Marelli IAW 8GMF CF5/EOBD
 Bravo (198)	MAINTENANCE	1.4 Turbo Multiair 16v (10-..)	Marelli IAW 8GMF CF5/EOBD
 Bravo (198)	MAINTENANCE	1.4 Turbo Multiair 16v (10-..)	Marelli IAW 8GMF CF5/EOBD
 Bravo (198)	MAINTENANCE	1.4 Turbo Multiair 16v (10-..)	Marelli IAW 8GMF CF5/EOBD
 Bravo (198)	MAINTENANCE	1.4 Turbo Multiair 16v (10-..)	Marelli IAW 8GMF CF5/EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Bravo (198)	MAINTENANCE	1.6 MJET 16v	BOSCH ABS/VDC 8
 Bravo (198)	MAINTENANCE	1.6 MJET 16v	Litronic
 Bravo (198)	MAINTENANCE	1.6 MJET 16v	Litronic
 Bravo (198)	MAINTENANCE	1.6 MJET 16v	Marelli
 Bravo (198)	MAINTENANCE	1.6 MJET 16v (07-..)	BOSCH EDC 16C39 CF5/EOBD
 Bravo (198)	MAINTENANCE	1.6 MJET 16v (07-..)	BOSCH EDC 16C39 CF5/EOBD
 Bravo (198)	MAINTENANCE	1.9 Multijet 16v	BOSCH ABS/VDC 8
 Bravo (198)	MAINTENANCE	1.9 Multijet 16v	BOSCH EDC 16 Common Rail
 Bravo (198)	MAINTENANCE	1.9 Multijet 16v	BOSCH EDC 16 Common Rail
 Bravo (198)	MAINTENANCE	1.9 Multijet 16v	Litronic
 Bravo (198)	MAINTENANCE	1.9 Multijet 16v	Litronic
 Bravo (198)	MAINTENANCE	1.9 Multijet 16v	Marelli
 Bravo (198)	MAINTENANCE	1.9 Multijet 8v	BOSCH ABS/VDC 8
 Bravo (198)	MAINTENANCE	1.9 Multijet 8v	BOSCH EDC 16 Common Rail
 Bravo (198)	MAINTENANCE	1.9 Multijet 8v	BOSCH EDC 16 Common Rail
 Bravo (198)	MAINTENANCE	1.9 Multijet 8v	Litronic
 Bravo (198)	MAINTENANCE	1.9 Multijet 8v	Litronic
 Bravo (198)	MAINTENANCE	1.9 Multijet 8v	Marelli
 Bravo (198)	MAINTENANCE	2.0 MJET 16v	BOSCH ABS/VDC 8
 Bravo (198)	MAINTENANCE	2.0 MJET 16v	Litronic
 Bravo (198)	MAINTENANCE	2.0 MJET 16v	Litronic
 Bravo (198)	MAINTENANCE	2.0 MJET 16v	Marelli
 Bravo (198)	MAINTENANCE	2.0 MJET 16v (07-..)	BOSCH EDC 16C39 CF5/EOBD
 Bravo (198)	MAINTENANCE	2.0 MJET 16v (07-..)	BOSCH EDC 16C39 CF5/EOBD
 Bravo (198)	PARKING HELP	1.4 16v	Valeo PDC
 Bravo (198)	PARKING HELP	1.4 16v T-JET	Valeo PDC
 Bravo (198)	PARKING HELP	1.4 Turbo Multiair 16v	Valeo PDC
 Bravo (198)	PARKING HELP	1.6 MJET 16v	Valeo PDC
 Bravo (198)	PARKING HELP	1.9 Multijet 16v	Valeo PDC
 Bravo (198)	PARKING HELP	1.9 Multijet 8v	Valeo PDC
 Bravo (198)	PARKING HELP	2.0 MJET 16v	Valeo PDC
 Bravo (198)	PASS SEAT CONTRO	1.4 16v	LEAR 3 PASSENGER SEAT
 Bravo (198)	PASS SEAT CONTRO	1.4 16v T-JET	LEAR 3 PASSENGER SEAT
 Bravo (198)	PASS SEAT CONTRO	1.4 Turbo Multiair 16v	LEAR 3 PASSENGER SEAT
 Bravo (198)	PASS SEAT CONTRO	1.6 MJET 16v	LEAR 3 PASSENGER SEAT
 Bravo (198)	PASS SEAT CONTRO	1.9 Multijet 16v	LEAR 3 PASSENGER SEAT
 Bravo (198)	PASS SEAT CONTRO	1.9 Multijet 8v	LEAR 3 PASSENGER SEAT
 Bravo (198)	RH LIGHT MODULATI	1.4 16v	Litronic
 Bravo (198)	RH LIGHT MODULATI	1.4 16v T-JET	Litronic
 Bravo (198)	RH LIGHT MODULATI	1.4 Turbo Multiair 16v	Litronic
 Bravo (198)	RH LIGHT MODULATI	1.6 MJET 16v	Litronic
 Bravo (198)	RH LIGHT MODULATI	1.9 Multijet 16v	Litronic
 Bravo (198)	RH LIGHT MODULATI	1.9 Multijet 8v	Litronic
 Bravo (198)	RH LIGHT MODULATI	2.0 MJET 16v	Litronic
 Bravo (198)	VISUAL./TELEMATIC	1.4 16v	Marelli Connect 3
 Bravo (198)	VISUAL./TELEMATIC	1.4 16v T-JET	Marelli Connect 3
 Bravo (198)	VISUAL./TELEMATIC	1.4 Turbo Multiair 16v	Marelli Connect 3
 Bravo (198)	VISUAL./TELEMATIC	1.6 MJET 16v	Marelli Connect 3
 Bravo (198)	VISUAL./TELEMATIC	1.9 Multijet 16v	Marelli Connect 3
 Bravo (198)	VISUAL./TELEMATIC	1.9 Multijet 8v	Marelli Connect 3
 Bravo (198)	VISUAL./TELEMATIC	2.0 MJET 16v	Marelli Connect 3
 Bravo	ABS	1.4 12v	ATE TEVES ABS Mk20
 Bravo	ABS	1.4 12v	LUCAS ABS EBC 430
 Bravo	ABS	1.6 16v	ATE TEVES ABS Mk20
 Bravo	ABS	1.6 16v	LUCAS ABS EBC 430
 Bravo	ABS	1.8 16v	ATE TEVES ABS Mk20
 Bravo	ABS	1.8 16v	LUCAS ABS EBC 430
 Bravo	ABS	1.9 D	ATE TEVES ABS Mk20

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Bravo	ABS	1.9 D	LUCAS ABS EBC 430
 Bravo	ABS	1.9 TD 75	ATE TEVES ABS Mk20
 Bravo	ABS	1.9 TD 75	LUCAS ABS EBC 430
 Bravo	ABS	100 1.6 16v	LUCAS ABS EBC 430
 Bravo	ABS	100 1.6 16v (01-..)	ATE TEVES ABS Mk20
 Bravo	ABS	100 1.6 16v (99-..)	ATE TEVES ABS Mk20
 Bravo	ABS	100 1.6 16v CF3	LUCAS ABS EBC 430
 Bravo	ABS	100 1.9 JTD	LUCAS ABS EBC 430
 Bravo	ABS	100 1.9 JTD (01-..)	ATE TEVES ABS Mk20
 Bravo	ABS	100 1.9 TD	ATE TEVES ABS Mk20
 Bravo	ABS	100 1.9 TD	LUCAS ABS EBC 430
 Bravo	ABS	105 1.9 JTD	LUCAS ABS EBC 430
 Bravo	ABS	105 1.9 JTD (99-..)	ATE TEVES ABS Mk20
 Bravo	ABS	110 1.9 JTD	LUCAS ABS EBC 430
 Bravo	ABS	115 1.8 16v	LUCAS ABS EBC 430
 Bravo	ABS	115 1.8 16v (01-..)	ATE TEVES ABS Mk20
 Bravo	ABS	115 1.8 16v (99-..)	ATE TEVES ABS Mk20
 Bravo	ABS	155 2.0 16v	LUCAS ABS EBC 430
 Bravo	ABS	155 2.0 16v (99-..)	ATE TEVES ABS Mk20
 Bravo	ABS	155 2.0 20v	LUCAS ABS EBC 430
 Bravo	ABS	2.0 20v	ATE TEVES ABS Mk20
 Bravo	ABS	2.0 20v	LUCAS ABS EBC 430
 Bravo	ABS	80 1.2 16v	LUCAS ABS EBC 430
 Bravo	ABS	80 1.2 16v (01-..)	ATE TEVES ABS Mk20
 Bravo	ABS	80 1.2 16v (99-..)	ATE TEVES ABS Mk20
 Bravo	AIRBAG	1.4 12v	BREED AirBag MY 95
 Bravo	AIRBAG	1.4 12v	BREED AirBag MY 97 (2F)
 Bravo	AIRBAG	1.4 12v	BREED AirBag MY 97 (2F-2L)
 Bravo	AIRBAG	1.4 12v	BREED AirBag MY 97 (2F-2L-S)
 Bravo	AIRBAG	1.4 12v	BREED AirBag MY 97 (2F-S)
 Bravo	AIRBAG	1.4 12v (99-..)	BREED AirBag MY 97 (2F-2L)
 Bravo	AIRBAG	1.4 12v (99-..)	BREED AirBag MY 97 (2F-2L-S)
 Bravo	AIRBAG	1.4 12v (99-..)	BREED AirBag MY 97 (2F-S)
 Bravo	AIRBAG	1.4 12v (99-..)	SIEMENS AirBag MY 97 (2F)
 Bravo	AIRBAG	1.6 16v	BREED AirBag MY 95
 Bravo	AIRBAG	1.6 16v	BREED AirBag MY 97 (2F)
 Bravo	AIRBAG	1.6 16v	BREED AirBag MY 97 (2F-2L)
 Bravo	AIRBAG	1.6 16v	BREED AirBag MY 97 (2F-2L-S)
 Bravo	AIRBAG	1.6 16v	BREED AirBag MY 97 (2F-S)
 Bravo	AIRBAG	1.6 16v (99-..)	BREED AirBag MY 97 (2F-2L)
 Bravo	AIRBAG	1.6 16v (99-..)	BREED AirBag MY 97 (2F-2L-S)
 Bravo	AIRBAG	1.6 16v (99-..)	BREED AirBag MY 97 (2F-S)
 Bravo	AIRBAG	1.6 16v (99-..)	SIEMENS AirBag MY 97 (2F)
 Bravo	AIRBAG	1.8 16v	BREED AirBag MY 95
 Bravo	AIRBAG	1.8 16v	BREED AirBag MY 97 (2F)
 Bravo	AIRBAG	1.8 16v	BREED AirBag MY 97 (2F-2L)
 Bravo	AIRBAG	1.8 16v	BREED AirBag MY 97 (2F-2L-S)
 Bravo	AIRBAG	1.8 16v	BREED AirBag MY 97 (2F-S)
 Bravo	AIRBAG	1.8 16v (99-..)	BREED AirBag MY 97 (2F-2L)
 Bravo	AIRBAG	1.8 16v (99-..)	BREED AirBag MY 97 (2F-2L-S)
 Bravo	AIRBAG	1.8 16v (99-..)	BREED AirBag MY 97 (2F-S)
 Bravo	AIRBAG	1.8 16v (99-..)	SIEMENS AirBag MY 97 (2F)
 Bravo	AIRBAG	1.9 D	BREED AirBag MY 95
 Bravo	AIRBAG	1.9 D	BREED AirBag MY 97 (2F)
 Bravo	AIRBAG	1.9 D	BREED AirBag MY 97 (2F-2L)
 Bravo	AIRBAG	1.9 D	BREED AirBag MY 97 (2F-2L-S)
 Bravo	AIRBAG	1.9 D	BREED AirBag MY 97 (2F-S)
 Bravo	AIRBAG	1.9 D (99-..)	BREED AirBag MY 97 (2F-2L)

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Bravo	AIRBAG	1.9 D (99-..)	BREED AirBag MY 97 (2F-2L-S)
 Bravo	AIRBAG	1.9 D (99-..)	BREED AirBag MY 97 (2F-S)
 Bravo	AIRBAG	1.9 D (99-..)	SIEMENS AirBag MY 97 (2F)
 Bravo	AIRBAG	1.9 TD 75	BREED AirBag MY 95
 Bravo	AIRBAG	1.9 TD 75	BREED AirBag MY 97 (2F)
 Bravo	AIRBAG	1.9 TD 75	BREED AirBag MY 97 (2F-2L)
 Bravo	AIRBAG	1.9 TD 75	BREED AirBag MY 97 (2F-2L-S)
 Bravo	AIRBAG	1.9 TD 75	BREED AirBag MY 97 (2F-S)
 Bravo	AIRBAG	1.9 TD 75 (99-..)	BREED AirBag MY 97 (2F-2L)
 Bravo	AIRBAG	1.9 TD 75 (99-..)	BREED AirBag MY 97 (2F-2L-S)
 Bravo	AIRBAG	1.9 TD 75 (99-..)	BREED AirBag MY 97 (2F-S)
 Bravo	AIRBAG	1.9 TD 75 (99-..)	SIEMENS AirBag MY 97 (2F)
 Bravo	AIRBAG	100 1.6 16v	BREED AirBag MY 95
 Bravo	AIRBAG	100 1.6 16v	BREED AirBag MY 97 (2F)
 Bravo	AIRBAG	100 1.6 16v	BREED AirBag MY 97 (2F-2L)
 Bravo	AIRBAG	100 1.6 16v	BREED AirBag MY 97 (2F-2L-S)
 Bravo	AIRBAG	100 1.6 16v	BREED AirBag MY 97 (2F-S)
 Bravo	AIRBAG	100 1.6 16v (99-..)	BREED AirBag MY 97 (2F-2L)
 Bravo	AIRBAG	100 1.6 16v (99-..)	BREED AirBag MY 97 (2F-2L-S)
 Bravo	AIRBAG	100 1.6 16v (99-..)	BREED AirBag MY 97 (2F-S)
 Bravo	AIRBAG	100 1.6 16v (99-..)	SIEMENS AirBag MY 97 (2F)
 Bravo	AIRBAG	100 1.6 16v CF3	BREED AirBag MY 95
 Bravo	AIRBAG	100 1.6 16v CF3	BREED AirBag MY 97 (2F)
 Bravo	AIRBAG	100 1.6 16v CF3	BREED AirBag MY 97 (2F-2L)
 Bravo	AIRBAG	100 1.6 16v CF3	BREED AirBag MY 97 (2F-2L-S)
 Bravo	AIRBAG	100 1.6 16v CF3	BREED AirBag MY 97 (2F-S)
 Bravo	AIRBAG	100 1.6 16v CF3 (99-..)	BREED AirBag MY 97 (2F-2L)
 Bravo	AIRBAG	100 1.6 16v CF3 (99-..)	BREED AirBag MY 97 (2F-2L-S)
 Bravo	AIRBAG	100 1.6 16v CF3 (99-..)	BREED AirBag MY 97 (2F-S)
 Bravo	AIRBAG	100 1.6 16v CF3 (99-..)	SIEMENS AirBag MY 97 (2F)
 Bravo	AIRBAG	100 1.9 JTD	BREED AirBag MY 95
 Bravo	AIRBAG	100 1.9 JTD	BREED AirBag MY 97 (2F)
 Bravo	AIRBAG	100 1.9 JTD	BREED AirBag MY 97 (2F-2L)
 Bravo	AIRBAG	100 1.9 JTD	BREED AirBag MY 97 (2F-2L-S)
 Bravo	AIRBAG	100 1.9 JTD	BREED AirBag MY 97 (2F-S)
 Bravo	AIRBAG	100 1.9 JTD (99-..)	BREED AirBag MY 97 (2F-2L)
 Bravo	AIRBAG	100 1.9 JTD (99-..)	BREED AirBag MY 97 (2F-2L-S)
 Bravo	AIRBAG	100 1.9 JTD (99-..)	BREED AirBag MY 97 (2F-S)
 Bravo	AIRBAG	100 1.9 JTD (99-..)	SIEMENS AirBag MY 97 (2F)
 Bravo	AIRBAG	100 1.9 TD	BREED AirBag MY 95
 Bravo	AIRBAG	100 1.9 TD	BREED AirBag MY 97 (2F)
 Bravo	AIRBAG	100 1.9 TD	BREED AirBag MY 97 (2F-2L)
 Bravo	AIRBAG	100 1.9 TD	BREED AirBag MY 97 (2F-2L-S)
 Bravo	AIRBAG	100 1.9 TD	BREED AirBag MY 97 (2F-S)
 Bravo	AIRBAG	100 1.9 TD (99-..)	BREED AirBag MY 97 (2F-2L)
 Bravo	AIRBAG	100 1.9 TD (99-..)	BREED AirBag MY 97 (2F-2L-S)
 Bravo	AIRBAG	100 1.9 TD (99-..)	BREED AirBag MY 97 (2F-S)
 Bravo	AIRBAG	100 1.9 TD (99-..)	SIEMENS AirBag MY 97 (2F)
 Bravo	AIRBAG	105 1.9 JTD	BREED AirBag MY 95
 Bravo	AIRBAG	105 1.9 JTD	BREED AirBag MY 97 (2F)
 Bravo	AIRBAG	105 1.9 JTD	BREED AirBag MY 97 (2F-2L)
 Bravo	AIRBAG	105 1.9 JTD	BREED AirBag MY 97 (2F-2L-S)
 Bravo	AIRBAG	105 1.9 JTD	BREED AirBag MY 97 (2F-S)
 Bravo	AIRBAG	105 1.9 JTD (99-..)	BREED AirBag MY 97 (2F-2L)
 Bravo	AIRBAG	105 1.9 JTD (99-..)	BREED AirBag MY 97 (2F-2L-S)
 Bravo	AIRBAG	105 1.9 JTD (99-..)	BREED AirBag MY 97 (2F-S)
 Bravo	AIRBAG	105 1.9 JTD (99-..)	SIEMENS AirBag MY 97 (2F)
 Bravo	AIRBAG	110 1.9 JTD	BREED AirBag MY 95

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Bravo	AIRBAG	110 1.9 JTD	BREED AirBag MY 97 (2F)
 Bravo	AIRBAG	110 1.9 JTD	BREED AirBag MY 97 (2F-2L)
 Bravo	AIRBAG	110 1.9 JTD	BREED AirBag MY 97 (2F-2L-S)
 Bravo	AIRBAG	110 1.9 JTD	BREED AirBag MY 97 (2F-S)
 Bravo	AIRBAG	110 1.9 JTD (99-..)	BREED AirBag MY 97 (2F-2L)
 Bravo	AIRBAG	110 1.9 JTD (99-..)	BREED AirBag MY 97 (2F-2L-S)
 Bravo	AIRBAG	110 1.9 JTD (99-..)	BREED AirBag MY 97 (2F-S)
 Bravo	AIRBAG	110 1.9 JTD (99-..)	SIEMENS AirBag MY 97 (2F)
 Bravo	AIRBAG	115 1.8 16v	BREED AirBag MY 95
 Bravo	AIRBAG	115 1.8 16v	BREED AirBag MY 97 (2F)
 Bravo	AIRBAG	115 1.8 16v	BREED AirBag MY 97 (2F-2L)
 Bravo	AIRBAG	115 1.8 16v	BREED AirBag MY 97 (2F-2L-S)
 Bravo	AIRBAG	115 1.8 16v	BREED AirBag MY 97 (2F-S)
 Bravo	AIRBAG	115 1.8 16v (99-..)	BREED AirBag MY 97 (2F-2L)
 Bravo	AIRBAG	115 1.8 16v (99-..)	BREED AirBag MY 97 (2F-2L-S)
 Bravo	AIRBAG	115 1.8 16v (99-..)	BREED AirBag MY 97 (2F-S)
 Bravo	AIRBAG	115 1.8 16v (99-..)	SIEMENS AirBag MY 97 (2F)
 Bravo	AIRBAG	155 2.0 16v	BREED AirBag MY 95
 Bravo	AIRBAG	155 2.0 16v	BREED AirBag MY 97 (2F)
 Bravo	AIRBAG	155 2.0 16v	BREED AirBag MY 97 (2F-2L)
 Bravo	AIRBAG	155 2.0 16v	BREED AirBag MY 97 (2F-2L-S)
 Bravo	AIRBAG	155 2.0 16v	BREED AirBag MY 97 (2F-S)
 Bravo	AIRBAG	155 2.0 16v (99-..)	BREED AirBag MY 97 (2F-2L)
 Bravo	AIRBAG	155 2.0 16v (99-..)	BREED AirBag MY 97 (2F-2L-S)
 Bravo	AIRBAG	155 2.0 16v (99-..)	BREED AirBag MY 97 (2F-S)
 Bravo	AIRBAG	155 2.0 16v (99-..)	SIEMENS AirBag MY 97 (2F)
 Bravo	AIRBAG	155 2.0 20v	BREED AirBag MY 95
 Bravo	AIRBAG	155 2.0 20v	BREED AirBag MY 97 (2F)
 Bravo	AIRBAG	155 2.0 20v	BREED AirBag MY 97 (2F-2L)
 Bravo	AIRBAG	155 2.0 20v	BREED AirBag MY 97 (2F-2L-S)
 Bravo	AIRBAG	155 2.0 20v	BREED AirBag MY 97 (2F-S)
 Bravo	AIRBAG	155 2.0 20v (99-..)	BREED AirBag MY 97 (2F-2L)
 Bravo	AIRBAG	155 2.0 20v (99-..)	BREED AirBag MY 97 (2F-2L-S)
 Bravo	AIRBAG	155 2.0 20v (99-..)	BREED AirBag MY 97 (2F-S)
 Bravo	AIRBAG	155 2.0 20v (99-..)	SIEMENS AirBag MY 97 (2F)
 Bravo	AIRBAG	2.0 20v	BREED AirBag MY 95
 Bravo	AIRBAG	2.0 20v	BREED AirBag MY 97 (2F)
 Bravo	AIRBAG	2.0 20v	BREED AirBag MY 97 (2F-2L)
 Bravo	AIRBAG	2.0 20v	BREED AirBag MY 97 (2F-2L-S)
 Bravo	AIRBAG	2.0 20v	BREED AirBag MY 97 (2F-S)
 Bravo	AIRBAG	2.0 20v (99-..)	BREED AirBag MY 97 (2F-2L)
 Bravo	AIRBAG	2.0 20v (99-..)	BREED AirBag MY 97 (2F-2L-S)
 Bravo	AIRBAG	2.0 20v (99-..)	BREED AirBag MY 97 (2F-S)
 Bravo	AIRBAG	2.0 20v (99-..)	SIEMENS AirBag MY 97 (2F)
 Bravo	AIRBAG	80 1.2 16v	BREED AirBag MY 95
 Bravo	AIRBAG	80 1.2 16v	BREED AirBag MY 97 (2F)
 Bravo	AIRBAG	80 1.2 16v	BREED AirBag MY 97 (2F-2L)
 Bravo	AIRBAG	80 1.2 16v	BREED AirBag MY 97 (2F-2L-S)
 Bravo	AIRBAG	80 1.2 16v	BREED AirBag MY 97 (2F-S)
 Bravo	AIRBAG	80 1.2 16v (99-..)	BREED AirBag MY 97 (2F-2L)
 Bravo	AIRBAG	80 1.2 16v (99-..)	BREED AirBag MY 97 (2F-2L-S)
 Bravo	AIRBAG	80 1.2 16v (99-..)	BREED AirBag MY 97 (2F-S)
 Bravo	AIRBAG	80 1.2 16v (99-..)	SIEMENS AirBag MY 97 (2F)
 Bravo	CLIMA	1.4 12v	Borletti Klima MANUAL
 Bravo	CLIMA	1.6 16v	Borletti Klima MANUAL
 Bravo	CLIMA	1.8 16v	Borletti Klima MANUAL
 Bravo	CLIMA	1.9 D	Borletti Klima MANUAL
 Bravo	CLIMA	1.9 TD 75	Borletti Klima MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Bravo	CLIMA	100 1.6 16v	Borletti Klima MANUAL
 Bravo	CLIMA	100 1.6 16v CF3	Borletti Klima MANUAL
 Bravo	CLIMA	100 1.9 JTD	Borletti Klima MANUAL
 Bravo	CLIMA	100 1.9 TD	Borletti Klima MANUAL
 Bravo	CLIMA	105 1.9 JTD	Borletti Klima MANUAL
 Bravo	CLIMA	110 1.9 JTD	Borletti Klima MANUAL
 Bravo	CLIMA	115 1.8 16v	Borletti Klima MANUAL
 Bravo	CLIMA	155 2.0 16v	Borletti Klima MANUAL
 Bravo	CLIMA	155 2.0 20v	Borletti Klima MANUAL
 Bravo	CLIMA	2.0 20v	Borletti Klima MANUAL
 Bravo	CLIMA	80 1.2 16v	Borletti Klima MANUAL
 Bravo	DIESEL MANAGEMEN	100 1.9 TD	LUCAS Diesel DCN
 Bravo	ENGINE MANAGEME	1.4 12v	BOSCH MonoMotronic MA1.7.3
 Bravo	ENGINE MANAGEME	1.4 12v	BOSCH MonoMotronic MA1.7.3
 Bravo	ENGINE MANAGEME	1.4 12v	BOSCH MonoMotronic MA1.7.3
 Bravo	ENGINE MANAGEME	1.4 12v	BOSCH MonoMotronic MA1.7.3
 Bravo	ENGINE MANAGEME	1.6 16v	Marelli IAW 1AF.13
 Bravo	ENGINE MANAGEME	1.6 16v	Marelli IAW 1AF.13
 Bravo	ENGINE MANAGEME	1.6 16v	Marelli IAW 1AF.13
 Bravo	ENGINE MANAGEME	1.6 16v	Marelli IAW 1AF.15
 Bravo	ENGINE MANAGEME	1.6 16v	Marelli IAW 1AF.16
 Bravo	ENGINE MANAGEME	1.6 16v	Marelli IAW 1AF.16
 Bravo	ENGINE MANAGEME	1.6 16v	Marelli IAW 1AF.17
 Bravo	ENGINE MANAGEME	1.8 16v	HITACHI MPI MFI
 Bravo	ENGINE MANAGEME	100 1.6 16v (99-..)	Marelli IAW 49F
 Bravo	ENGINE MANAGEME	100 1.6 16v CF3 (01-..)	Marelli IAW 49F/59F EOBD
 Bravo	ENGINE MANAGEME	100 1.9 JTD (01-..)	BOSCH EDC 15 Common Rail (JTD '99)
 Bravo	ENGINE MANAGEME	105 1.9 JTD (..-98)	BOSCH EDC 15 Common Rail
 Bravo	ENGINE MANAGEME	110 1.9 JTD (99-..)	BOSCH EDC 15 Common Rail (JTD '99)
 Bravo	ENGINE MANAGEME	115 1.8 16v (99-..)	HITACHI MPI MFI '98
 Bravo	ENGINE MANAGEME	155 2.0 20v (99-..)	BOSCH Motronic ME3.1
 Bravo	ENGINE MANAGEME	2.0 20v	BOSCH Motronic M2.10.4
 Bravo	ENGINE MANAGEME	2.0 20v	BOSCH Motronic M2.10.4
 Bravo	ENGINE MANAGEME	80 1.2 16v (01-..)	BOSCH Motronic ME7.3 H4
 Bravo	ENGINE MANAGEME	80 1.2 16v (99-..)	BOSCH Motronic M1.5.5
 Bravo	KEY ENCODE	1.4 12v	BOSCH CODE MANUAL
 Bravo	KEY ENCODE	1.6 16v	BOSCH CODE MANUAL
 Bravo	KEY ENCODE	1.8 16v	BOSCH CODE MANUAL
 Bravo	KEY ENCODE	1.9 D	BOSCH CODE MANUAL
 Bravo	KEY ENCODE	1.9 TD 75	BOSCH CODE MANUAL
 Bravo	KEY ENCODE	100 1.6 16v	BOSCH CODE MANUAL
 Bravo	KEY ENCODE	100 1.6 16v CF3	BOSCH CODE MANUAL
 Bravo	KEY ENCODE	100 1.9 JTD	BOSCH CODE MANUAL
 Bravo	KEY ENCODE	100 1.9 TD	BOSCH CODE MANUAL
 Bravo	KEY ENCODE	105 1.9 JTD	BOSCH CODE MANUAL
 Bravo	KEY ENCODE	110 1.9 JTD	BOSCH CODE MANUAL
 Bravo	KEY ENCODE	115 1.8 16v	BOSCH CODE MANUAL
 Bravo	KEY ENCODE	155 2.0 16v	BOSCH CODE MANUAL
 Bravo	KEY ENCODE	155 2.0 20v	BOSCH CODE MANUAL
 Bravo	KEY ENCODE	2.0 20v	BOSCH CODE MANUAL
 Bravo	KEY ENCODE	80 1.2 16v	BOSCH CODE MANUAL
 Bravo	MAINTENANCE	1.4 12v	Borletti Klima MANUAL
 Bravo	MAINTENANCE	1.4 12v	BOSCH CODE MANUAL
 Bravo	MAINTENANCE	1.6 16v	Borletti Klima MANUAL
 Bravo	MAINTENANCE	1.6 16v	BOSCH CODE MANUAL
 Bravo	MAINTENANCE	1.8 16v	Borletti Klima MANUAL
 Bravo	MAINTENANCE	1.8 16v	BOSCH CODE MANUAL
 Bravo	MAINTENANCE	1.9 D	Borletti Klima MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Bravo	MAINTENANCE	1.9 D	BOSCH CODE MANUAL
 Bravo	MAINTENANCE	1.9 TD 75	Borletti Klima MANUAL
 Bravo	MAINTENANCE	1.9 TD 75	BOSCH CODE MANUAL
 Bravo	MAINTENANCE	100 1.6 16v	Borletti Klima MANUAL
 Bravo	MAINTENANCE	100 1.6 16v	BOSCH CODE MANUAL
 Bravo	MAINTENANCE	100 1.6 16v CF3	Borletti Klima MANUAL
 Bravo	MAINTENANCE	100 1.6 16v CF3	BOSCH CODE MANUAL
 Bravo	MAINTENANCE	100 1.9 JTD	Borletti Klima MANUAL
 Bravo	MAINTENANCE	100 1.9 JTD	BOSCH CODE MANUAL
 Bravo	MAINTENANCE	100 1.9 TD	Borletti Klima MANUAL
 Bravo	MAINTENANCE	100 1.9 TD	BOSCH CODE MANUAL
 Bravo	MAINTENANCE	105 1.9 JTD	Borletti Klima MANUAL
 Bravo	MAINTENANCE	105 1.9 JTD	BOSCH CODE MANUAL
 Bravo	MAINTENANCE	110 1.9 JTD	Borletti Klima MANUAL
 Bravo	MAINTENANCE	110 1.9 JTD	BOSCH CODE MANUAL
 Bravo	MAINTENANCE	115 1.8 16v	Borletti Klima MANUAL
 Bravo	MAINTENANCE	115 1.8 16v	BOSCH CODE MANUAL
 Bravo	MAINTENANCE	155 2.0 16v	Borletti Klima MANUAL
 Bravo	MAINTENANCE	155 2.0 16v	BOSCH CODE MANUAL
 Bravo	MAINTENANCE	155 2.0 20v	Borletti Klima MANUAL
 Bravo	MAINTENANCE	155 2.0 20v	BOSCH CODE MANUAL
 Bravo	MAINTENANCE	2.0 20v	Borletti Klima MANUAL
 Bravo	MAINTENANCE	2.0 20v	BOSCH CODE MANUAL
 Bravo	MAINTENANCE	80 1.2 16v	Borletti Klima MANUAL
 Bravo	MAINTENANCE	80 1.2 16v	BOSCH CODE MANUAL
 Cinquecento	ENGINE MANAGEME	903 Kat	Marelli IAW 16F.E0
 Cinquecento	ENGINE MANAGEME	903 Kat	Marelli IAW 16F.E0
 Cinquecento	ENGINE MANAGEME	903 Kat	Marelli IAW 16F.E0
 Cinquecento	ENGINE MANAGEME	903 Kat	Marelli IAW 6F.S0
 Cinquecento	ENGINE MANAGEME	903 Kat	Marelli IAW 6F.S0
 Cinquecento	ENGINE MANAGEME	903 Kat	Marelli IAW 6F.S0
 Cinquecento	ENGINE MANAGEME	903 Kat	Marelli IAW 6F.S0
 Cinquecento	ENGINE MANAGEME	903 Kat	Marelli IAW 6F.S0
 Cinquecento	ENGINE MANAGEME	903 Kat	Marelli IAW 6F.S0
 Cinquecento	ENGINE MANAGEME	903 Kat	Marelli IAW 6F.S0
 Cinquecento	ENGINE MANAGEME	903 Kat + A/C	Marelli IAW 6F.S0
 Cinquecento	ENGINE MANAGEME	Sporting	Marelli IAW 16F.ER
 Cinquecento	KEY ENCODE	903 Kat	BOSCH CODE MANUAL
 Cinquecento	KEY ENCODE	903 Kat + A/C	BOSCH CODE MANUAL
 Cinquecento	KEY ENCODE	Sporting	BOSCH CODE MANUAL
 Cinquecento	MAINTENANCE	903 Kat	BOSCH CODE MANUAL
 Cinquecento	MAINTENANCE	903 Kat + A/C	BOSCH CODE MANUAL
 Cinquecento	MAINTENANCE	Sporting	BOSCH CODE MANUAL
 Coupe'	ABS	1.8 16v (96-98)	BOSCH ABS 5.3
 Coupe'	ABS	2.0 16v (96-98)	BOSCH ABS 5.3
 Coupe'	ABS	2.0 20v (96-98)	BOSCH ABS 5.3
 Coupe'	ABS	2.0 T 16v (96-98)	BOSCH ABS 5.3
 Coupe'	ABS	2.0 T 20v (96-98)	BOSCH ABS 5.3
 Coupe'	AIRBAG	1.8 16v	TRW AirBag MY 97 (2F)
 Coupe'	AIRBAG	1.8 16v	TRW-Becker AirBag no Pret.
 Coupe'	AIRBAG	1.8 16v (96-..)	TRW AirBag TRW2
 Coupe'	AIRBAG	1.8 16v (96-..)	TRW-Becker AirBag no Pret.
 Coupe'	AIRBAG	1.8 16v (98-..)	TRW AirBag MY 97 (2F)
Coupe'	AIRBAG	1.8 16v (98-..)	TRW AirBag MY 97 (2F-I)
Coupe'	AIRBAG	2.0 16v	TRW AirBag MY 97 (2F)
Coupe'	AIRBAG	2.0 16v	TRW-Becker AirBag no Pret.
Coupe'	AIRBAG	2.0 16v (96-..)	TRW AirBag TRW2

Systems supported by ECUREADER / ECUDECODER (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Coupé'	AIRBAG	2.0 16v (96-..)	TRW-Becker AirBag no Pret.
 Coupé'	AIRBAG	2.0 16v (98-..)	TRW AirBag MY 97 (2F)
 Coupé'	AIRBAG	2.0 16v (98-..)	TRW AirBag MY 97 (2F-I)
 Coupé'	AIRBAG	2.0 20v	TRW AirBag MY 97 (2F)
 Coupé'	AIRBAG	2.0 20v	TRW-Becker AirBag no Pret.
 Coupé'	AIRBAG	2.0 20v (96-..)	TRW AirBag TRW2
 Coupé'	AIRBAG	2.0 20v (96-..)	TRW-Becker AirBag no Pret.
 Coupé'	AIRBAG	2.0 20v (98-..)	TRW AirBag MY 97 (2F)
 Coupé'	AIRBAG	2.0 20v (98-..)	TRW AirBag MY 97 (2F-I)
 Coupé'	AIRBAG	2.0 T 16v	TRW AirBag MY 97 (2F)
 Coupé'	AIRBAG	2.0 T 16v	TRW-Becker AirBag no Pret.
 Coupé'	AIRBAG	2.0 T 16v (96-..)	TRW AirBag TRW2
 Coupé'	AIRBAG	2.0 T 16v (96-..)	TRW-Becker AirBag no Pret.
 Coupé'	AIRBAG	2.0 T 16v (98-..)	TRW AirBag MY 97 (2F)
 Coupé'	AIRBAG	2.0 T 16v (98-..)	TRW AirBag MY 97 (2F-I)
 Coupé'	AIRBAG	2.0 T 20v	TRW AirBag MY 97 (2F)
 Coupé'	AIRBAG	2.0 T 20v	TRW-Becker AirBag no Pret.
 Coupé'	AIRBAG	2.0 T 20v (96-..)	TRW AirBag TRW2
 Coupé'	AIRBAG	2.0 T 20v (96-..)	TRW-Becker AirBag no Pret.
 Coupé'	AIRBAG	2.0 T 20v (98-..)	TRW AirBag MY 97 (2F)
 Coupé'	AIRBAG	2.0 T 20v (98-..)	TRW AirBag MY 97 (2F-I)
 Coupé'	ENGINE MANAGEME	1.8 16v	HITACHI MPI MFI
 Coupé'	ENGINE MANAGEME	1.8 16v (98-..)	HITACHI MPI MFI '98
 Coupé'	ENGINE MANAGEME	2.0 16v	Marelli IAW 4Q4
 Coupé'	ENGINE MANAGEME	2.0 16v	Marelli IAW 4Q4
 Coupé'	ENGINE MANAGEME	2.0 20v	BOSCH Motronic M2.10.4
 Coupé'	ENGINE MANAGEME	2.0 20v (98-..)	BOSCH Motronic ME3.1
 Coupé'	ENGINE MANAGEME	2.0 20v (98-..)	BOSCH Motronic ME3.1 EOBD
 Coupé'	ENGINE MANAGEME	2.0 T 16v	Marelli IAW 4WF
 Coupé'	ENGINE MANAGEME	2.0 T 16v	Marelli IAW 4WF
 Coupé'	ENGINE MANAGEME	2.0 T 16v	Marelli IAW 4WF
 Coupé'	ENGINE MANAGEME	2.0 T 20v	BOSCH Motronic M2.10.4
 Coupé'	KEY ENCODE	1.8 16v	BOSCH CODE MANUAL
 Coupé'	KEY ENCODE	2.0 16v	BOSCH CODE MANUAL
 Coupé'	KEY ENCODE	2.0 20v	BOSCH CODE MANUAL
 Coupé'	KEY ENCODE	2.0 T 16v	BOSCH CODE MANUAL
 Coupé'	KEY ENCODE	2.0 T 20v	BOSCH CODE MANUAL
 Coupé'	MAINTENANCE	1.8 16v	BOSCH CODE MANUAL
 Coupé'	MAINTENANCE	2.0 16v	BOSCH CODE MANUAL
 Coupé'	MAINTENANCE	2.0 20v	BOSCH CODE MANUAL
 Coupé'	MAINTENANCE	2.0 T 16v	BOSCH CODE MANUAL
 Coupé'	MAINTENANCE	2.0 T 20v	BOSCH CODE MANUAL
 Croma (154)	ABS	2.0	BOSCH ABS 2E
 Croma (154)	ABS	2.0	BOSCH ABS 5
 Croma (154)	ABS	2.0 16v	BOSCH ABS 2E
 Croma (154)	ABS	2.0 16v	BOSCH ABS 5
 Croma (154)	ABS	2.0 AT	BOSCH ABS 2E
 Croma (154)	ABS	2.0 AT	BOSCH ABS 5
 Croma (154)	ABS	2.5 V6	BOSCH ABS 2E
 Croma (154)	ABS	2.5 V6	BOSCH ABS 5
 Croma (154)	ENGINE MANAGEME	2.0	Marelli IAW 026.03
 Croma (154)	ENGINE MANAGEME	2.0	Marelli IAW 026.04
 Croma (154)	ENGINE MANAGEME	2.0	Marelli IAW 046.01
 Croma (154)	ENGINE MANAGEME	2.0	Marelli IAW 046.01
 Croma (154)	ENGINE MANAGEME	2.0	Marelli IAW 046.04
 Croma (154)	ENGINE MANAGEME	2.0	Marelli IAW 046.07
 Croma (154)	ENGINE MANAGEME	2.0 16v	BOSCH Motronic M1.7
 Croma (154)	ENGINE MANAGEME	2.0 16v	BOSCH Motronic M1.7

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Croma (154)	ENGINE MANAGEME	2.0 AT	Marelli IAW 026.03
 Croma (154)	ENGINE MANAGEME	2.0 AT	Marelli IAW 026.03
 Croma (154)	ENGINE MANAGEME	2.0 AT	Marelli IAW 026.04
 Croma (154)	ENGINE MANAGEME	2.0 AT	Marelli IAW 046.07
 Croma (154)	ENGINE MANAGEME	2.5 V6	BOSCH Motronic M1.7
 Croma (154)	ENGINE MANAGEME	2.5 V6	BOSCH Motronic M1.7
 Croma (194)	ABS	1.8 16v	Lucas TRW ABS
 Croma (194)	ABS	1.9 Multijet 16v	Lucas TRW ABS
 Croma (194)	ABS	1.9 Multijet 8v	Lucas TRW ABS
 Croma (194)	ABS	2.2 16v	Lucas TRW ABS
 Croma (194)	ABS	2.4 Multijet 20v	Lucas TRW ABS
 Croma (194)	ABS + TRACT. CONT	1.8 16v	Lucas TRW ABS ESP
 Croma (194)	ABS + TRACT. CONT	1.9 Multijet 16v	Lucas TRW ABS ESP
 Croma (194)	ABS + TRACT. CONT	1.9 Multijet 8v	Lucas TRW ABS ESP
 Croma (194)	ABS + TRACT. CONT	2.2 16v	Lucas TRW ABS ESP
 Croma (194)	ABS + TRACT. CONT	2.4 Multijet 20v	Lucas TRW ABS ESP
 Croma (194)	AIRBAG	1.8 16v	TRW AirBag MY 03 (2F-2P-2L-2T-1G-I)
 Croma (194)	AIRBAG	1.8 16v	TRW AirBag MY 03 (2F-2P-2T- I)
 Croma (194)	AIRBAG	1.8 16v	TRW AirBag MY 03 (2F-2P-I)
 Croma (194)	AIRBAG	1.8 16v	TRW AirBag MY 03 (2F4P-4L-2T-1G-I)
 Croma (194)	AIRBAG	1.9 Multijet 16v	TRW AirBag MY 03 (2F-2P-2L-2T-1G-I)
 Croma (194)	AIRBAG	1.9 Multijet 16v	TRW AirBag MY 03 (2F-2P-2T- I)
 Croma (194)	AIRBAG	1.9 Multijet 16v	TRW AirBag MY 03 (2F-2P-I)
 Croma (194)	AIRBAG	1.9 Multijet 16v	TRW AirBag MY 03 (2F4P-4L-2T-1G-I)
 Croma (194)	AIRBAG	1.9 Multijet 8v	TRW AirBag MY 03 (2F-2P-2L-2T-1G-I)
 Croma (194)	AIRBAG	1.9 Multijet 8v	TRW AirBag MY 03 (2F-2P-2T- I)
 Croma (194)	AIRBAG	1.9 Multijet 8v	TRW AirBag MY 03 (2F-2P-I)
 Croma (194)	AIRBAG	1.9 Multijet 8v	TRW AirBag MY 03 (2F4P-4L-2T-1G-I)
 Croma (194)	AIRBAG	2.2 16v	TRW AirBag MY 03 (2F-2P-2L-2T-1G-I)
 Croma (194)	AIRBAG	2.2 16v	TRW AirBag MY 03 (2F-2P-2T- I)
 Croma (194)	AIRBAG	2.2 16v	TRW AirBag MY 03 (2F-2P-I)
 Croma (194)	AIRBAG	2.2 16v	TRW AirBag MY 03 (2F4P-4L-2T-1G-I)
 Croma (194)	AIRBAG	2.4 Multijet 20v	TRW AirBag MY 03 (2F-2P-2L-2T-1G-I)
 Croma (194)	AIRBAG	2.4 Multijet 20v	TRW AirBag MY 03 (2F-2P-2T- I)
 Croma (194)	AIRBAG	2.4 Multijet 20v	TRW AirBag MY 03 (2F-2P-I)
 Croma (194)	AIRBAG	2.4 Multijet 20v	TRW AirBag MY 03 (2F4P-4L-2T-1G-I)
 Croma (194)	CHASSIS NETWORK	1.8 16v	Fiat Proxi Alignement
 Croma (194)	CHASSIS NETWORK	1.8 16v	Marelli Body Computer 3
 Croma (194)	CHASSIS NETWORK	1.9 Multijet 16v	Fiat Proxi Alignement
 Croma (194)	CHASSIS NETWORK	1.9 Multijet 16v	Marelli Body Computer 3
 Croma (194)	CHASSIS NETWORK	1.9 Multijet 8v	Fiat Proxi Alignement
 Croma (194)	CHASSIS NETWORK	1.9 Multijet 8v	Marelli Body Computer 3
 Croma (194)	CHASSIS NETWORK	2.2 16v	Fiat Proxi Alignement
 Croma (194)	CHASSIS NETWORK	2.2 16v	Marelli Body Computer 3
 Croma (194)	CHASSIS NETWORK	2.4 Multijet 20v	Fiat Proxi Alignement
 Croma (194)	CHASSIS NETWORK	2.4 Multijet 20v	Marelli Body Computer 3
 Croma (194)	DASHBOARD	1.8 16v	Marelli Dashboard 2
 Croma (194)	DASHBOARD	1.9 Multijet 16v	Marelli Dashboard 2
 Croma (194)	DASHBOARD	1.9 Multijet 8v	Marelli Dashboard 2
 Croma (194)	DASHBOARD	2.2 16v	Marelli Dashboard 2
 Croma (194)	DASHBOARD	2.4 Multijet 20v	Marelli Dashboard 2
 Croma (194)	DRIVER SEAT CONT	1.8 16v	Lear 2
 Croma (194)	DRIVER SEAT CONT	1.9 Multijet 16v	Lear 2
 Croma (194)	DRIVER SEAT CONT	1.9 Multijet 8v	Lear 2
 Croma (194)	DRIVER SEAT CONT	2.2 16v	Lear 2
 Croma (194)	DRIVER SEAT CONT	2.4 Multijet 20v	Lear 2
 Croma (194)	DRIVER SIDE DOOR	1.8 16v	PROCOND 3 DRIVER DOOR
 Croma (194)	DRIVER SIDE DOOR	1.9 Multijet 16v	PROCOND 3 DRIVER DOOR

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Croma (194)	DRIVER SIDE DOOR	1.9 Multijet 8v	PROCOND 3 DRIVER DOOR
 Croma (194)	DRIVER SIDE DOOR	2.2 16v	PROCOND 3 DRIVER DOOR
 Croma (194)	DRIVER SIDE DOOR	2.4 Multijet 20v	PROCOND 3 DRIVER DOOR
 Croma (194)	ELECTRIC STEERING	1.8 16v	TRW NGE 2
 Croma (194)	ELECTRIC STEERING	1.9 Multijet 16v	TRW NGE 2
 Croma (194)	ELECTRIC STEERING	1.9 Multijet 8v	TRW NGE 2
 Croma (194)	ELECTRIC STEERING	2.2 16v	TRW NGE 2
 Croma (194)	ELECTRIC STEERING	2.4 Multijet 20v	TRW NGE 2
 Croma (194)	ENGINE MANAGEME	1.8 16v	BOSCH Motronic MED 7.6.1 CF4-EOBD
 Croma (194)	ENGINE MANAGEME	1.9 Multijet 16v	BOSCH EDC 16 Common Rail
 Croma (194)	ENGINE MANAGEME	1.9 Multijet 8v	BOSCH EDC 16 Common Rail
 Croma (194)	ENGINE MANAGEME	2.2 16v	BOSCH Motronic MED 7.6.1 CF4-EOBD
 Croma (194)	ENGINE MANAGEME	2.4 Multijet 20v	BOSCH EDC 16 Common Rail
 Croma (194)	HATCHBACK DOOR E	1.8 16v	PROCOND 3 TRUNK COMPARTMENT
 Croma (194)	HATCHBACK DOOR E	1.9 Multijet 16v	PROCOND 3 TRUNK COMPARTMENT
 Croma (194)	HATCHBACK DOOR E	1.9 Multijet 8v	PROCOND 3 TRUNK COMPARTMENT
 Croma (194)	HATCHBACK DOOR E	2.2 16v	PROCOND 3 TRUNK COMPARTMENT
 Croma (194)	HATCHBACK DOOR E	2.4 Multijet 20v	PROCOND 3 TRUNK COMPARTMENT
 Croma (194)	KEY ENCODE	1.8 16v	TRW Teg Reader
 Croma (194)	KEY ENCODE	1.9 Multijet 16v	TRW Teg Reader
 Croma (194)	KEY ENCODE	1.9 Multijet 8v	TRW Teg Reader
 Croma (194)	KEY ENCODE	2.2 16v	TRW Teg Reader
 Croma (194)	KEY ENCODE	2.4 Multijet 20v	TRW Teg Reader
 Croma (194)	LH RIGHT MODULATI	1.8 16v	Litronic
 Croma (194)	LH RIGHT MODULATI	1.9 Multijet 16v	Litronic
 Croma (194)	LH RIGHT MODULATI	1.9 Multijet 8v	Litronic
 Croma (194)	LH RIGHT MODULATI	2.2 16v	Litronic
 Croma (194)	LH RIGHT MODULATI	2.4 Multijet 20v	Litronic
 Croma (194)	MAINTENANCE	1.8 16v	Litronic
 Croma (194)	MAINTENANCE	1.8 16v	Litronic
 Croma (194)	MAINTENANCE	1.8 16v	Lucas TRW ABS ESP
 Croma (194)	MAINTENANCE	1.8 16v	Marelli 2
 Croma (194)	MAINTENANCE	1.8 16v	Marelli Dashboard 2
 Croma (194)	MAINTENANCE	1.9 Multijet 16v	BOSCH EDC 16 Common Rail
 Croma (194)	MAINTENANCE	1.9 Multijet 16v	BOSCH EDC 16 Common Rail
 Croma (194)	MAINTENANCE	1.9 Multijet 16v	Litronic
 Croma (194)	MAINTENANCE	1.9 Multijet 16v	Litronic
 Croma (194)	MAINTENANCE	1.9 Multijet 16v	Lucas TRW ABS ESP
 Croma (194)	MAINTENANCE	1.9 Multijet 16v	Marelli 2
 Croma (194)	MAINTENANCE	1.9 Multijet 16v	Marelli Dashboard 2
 Croma (194)	MAINTENANCE	1.9 Multijet 8v	BOSCH EDC 16 Common Rail
 Croma (194)	MAINTENANCE	1.9 Multijet 8v	BOSCH EDC 16 Common Rail
 Croma (194)	MAINTENANCE	1.9 Multijet 8v	Litronic
 Croma (194)	MAINTENANCE	1.9 Multijet 8v	Litronic
 Croma (194)	MAINTENANCE	1.9 Multijet 8v	Lucas TRW ABS ESP
 Croma (194)	MAINTENANCE	1.9 Multijet 8v	Marelli 2
 Croma (194)	MAINTENANCE	1.9 Multijet 8v	Marelli Dashboard 2
 Croma (194)	MAINTENANCE	2.2 16v	Litronic
 Croma (194)	MAINTENANCE	2.2 16v	Litronic
 Croma (194)	MAINTENANCE	2.2 16v	Lucas TRW ABS ESP
 Croma (194)	MAINTENANCE	2.2 16v	Marelli 2
 Croma (194)	MAINTENANCE	2.2 16v	Marelli Dashboard 2
 Croma (194)	MAINTENANCE	2.4 Multijet 20v	BOSCH EDC 16 Common Rail
 Croma (194)	MAINTENANCE	2.4 Multijet 20v	BOSCH EDC 16 Common Rail
 Croma (194)	MAINTENANCE	2.4 Multijet 20v	Litronic
 Croma (194)	MAINTENANCE	2.4 Multijet 20v	Litronic
 Croma (194)	MAINTENANCE	2.4 Multijet 20v	Lucas TRW ABS ESP
 Croma (194)	MAINTENANCE	2.4 Multijet 20v	Marelli 2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Croma (194)	MAINTENANCE	2.4 Multijet 20v	Marelli Dashboard 2
 Croma (194)	PARKING HELP	1.8 16v	Valeo
 Croma (194)	PARKING HELP	1.9 Multijet 16v	Valeo
 Croma (194)	PARKING HELP	1.9 Multijet 8v	Valeo
 Croma (194)	PARKING HELP	2.2 16v	Valeo
 Croma (194)	PARKING HELP	2.4 Multijet 20v	Valeo
 Croma (194)	PASS. SIDE DOOR	1.8 16v	PROCOND 3 PASSENGER DOOR
 Croma (194)	PASS. SIDE DOOR	1.9 Multijet 16v	PROCOND 3 PASSENGER DOOR
 Croma (194)	PASS. SIDE DOOR	1.9 Multijet 8v	PROCOND 3 PASSENGER DOOR
 Croma (194)	PASS. SIDE DOOR	2.2 16v	PROCOND 3 PASSENGER DOOR
 Croma (194)	PASS. SIDE DOOR	2.4 Multijet 20v	PROCOND 3 PASSENGER DOOR
 Croma (194)	PASSENGER SEAT R	1.8 16v	Lear 2
 Croma (194)	PASSENGER SEAT R	1.9 Multijet 16v	Lear 2
 Croma (194)	PASSENGER SEAT R	1.9 Multijet 8v	Lear 2
 Croma (194)	PASSENGER SEAT R	2.2 16v	Lear 2
 Croma (194)	PASSENGER SEAT R	2.4 Multijet 20v	Lear 2
 Croma (194)	RH LIGHT MODULATI	1.8 16v	Litronic
 Croma (194)	RH LIGHT MODULATI	1.9 Multijet 16v	Litronic
 Croma (194)	RH LIGHT MODULATI	1.9 Multijet 8v	Litronic
 Croma (194)	RH LIGHT MODULATI	2.2 16v	Litronic
 Croma (194)	RH LIGHT MODULATI	2.4 Multijet 20v	Litronic
 Croma (194)	SERVICE LIGHT RES	1.8 16v	Marelli 2
 Croma (194)	SERVICE LIGHT RES	1.9 Multijet 16v	Marelli 2
 Croma (194)	SERVICE LIGHT RES	1.9 Multijet 8v	Marelli 2
 Croma (194)	SERVICE LIGHT RES	2.2 16v	Marelli 2
 Croma (194)	SERVICE LIGHT RES	2.4 Multijet 20v	Marelli 2
 Croma (194)	VISUAL./TELEMATIC	1.8 16v	Marelli Connect 3
 Croma (194)	VISUAL./TELEMATIC	1.9 Multijet 16v	Marelli Connect 3
 Croma (194)	VISUAL./TELEMATIC	1.9 Multijet 8v	Marelli Connect 3
 Croma (194)	VISUAL./TELEMATIC	2.2 16v	Marelli Connect 3
 Croma (194)	VISUAL./TELEMATIC	2.4 Multijet 20v	Marelli Connect 3
 Doblo' (119)	ABS	1.2 16v	ATE TEVES ABS Mk20
 Doblo' (119)	ABS	1.2 8v	ATE TEVES ABS Mk20
 Doblo' (119)	ABS	1.2 8v Bipower	ATE TEVES ABS Mk20
 Doblo' (119)	ABS	1.3 Multijet	ATE TEVES ABS Mk20
 Doblo' (119)	ABS	1.3 Multijet FAP (03-..)	ATE TEVES ABS Mk20
 Doblo' (119)	ABS	1.4 8v	ATE TEVES ABS Mk20
 Doblo' (119)	ABS	1.6 16v	ATE TEVES ABS Mk20
 Doblo' (119)	ABS	1.6 16v Bipower (03-..)	ATE TEVES ABS Mk20
 Doblo' (119)	ABS	1.9 D	ATE TEVES ABS Mk20
 Doblo' (119)	ABS	1.9 DS	ATE TEVES ABS Mk20
 Doblo' (119)	ABS	1.9 JTD	ATE TEVES ABS Mk20
 Doblo' (119)	ABS	100 1.9 JTD	ATE TEVES ABS Mk20
 Doblo' (119)	ABS	120 1.9 JTD (03-..)	ATE TEVES ABS Mk20
 Doblo' (119)	ABS	80 1.9 JTD	ATE TEVES ABS Mk20
 Doblo' (119)	AIRBAG	1.2 16v	Autoliv AirBag MY 99 (1F-2P)
 Doblo' (119)	AIRBAG	1.2 16v	Autoliv AirBag MY 99 (2F-2P-2L-I)
 Doblo' (119)	AIRBAG	1.2 16v	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo' (119)	AIRBAG	1.2 16v	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo' (119)	AIRBAG	1.2 16v	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo' (119)	AIRBAG	1.2 16v	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo' (119)	AIRBAG	1.2 8v	Autoliv AirBag MY 99 (1F-2P)
 Doblo' (119)	AIRBAG	1.2 8v	Autoliv AirBag MY 99 (2F-2P-2L-I)
 Doblo' (119)	AIRBAG	1.2 8v	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo' (119)	AIRBAG	1.2 8v	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo' (119)	AIRBAG	1.2 8v	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo' (119)	AIRBAG	1.2 8v	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
Doblo' (119)	AIRBAG	1.2 8v Bipower	AUTOLIV AirBag MY 99 (1F-2P)

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Doblo' (119)	AIRBAG	1.2 8v Bipower	AUTOLIV AirBag MY 99 (2F-2P-2L-I)
 Doblo' (119)	AIRBAG	1.2 8v Bipower	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo' (119)	AIRBAG	1.2 8v Bipower	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo' (119)	AIRBAG	1.2 8v Bipower	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo' (119)	AIRBAG	1.2 8v Bipower	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo' (119)	AIRBAG	1.3 Multijet	AUTOLIV AirBag MY 99 (1F-2P)
 Doblo' (119)	AIRBAG	1.3 Multijet	AUTOLIV AirBag MY 99 (2F-2P-2L-I)
 Doblo' (119)	AIRBAG	1.3 Multijet	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo' (119)	AIRBAG	1.3 Multijet	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo' (119)	AIRBAG	1.3 Multijet	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo' (119)	AIRBAG	1.3 Multijet	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo' (119)	AIRBAG	1.3 Multijet FAP (03-..)	Autoliv AirBag MY 99 (1F-2P)
 Doblo' (119)	AIRBAG	1.3 Multijet FAP (03-..)	Autoliv AirBag MY 99 (2F-2P-2L-I)
 Doblo' (119)	AIRBAG	1.3 Multijet FAP (03-..)	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo' (119)	AIRBAG	1.3 Multijet FAP (03-..)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo' (119)	AIRBAG	1.3 Multijet FAP (03-..)	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo' (119)	AIRBAG	1.3 Multijet FAP (03-..)	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo' (119)	AIRBAG	1.4 8v	Autoliv AirBag MY 99 (1F-2P)
 Doblo' (119)	AIRBAG	1.4 8v	Autoliv AirBag MY 99 (2F-2P-2L-I)
 Doblo' (119)	AIRBAG	1.4 8v	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo' (119)	AIRBAG	1.4 8v	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo' (119)	AIRBAG	1.4 8v	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo' (119)	AIRBAG	1.4 8v	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo' (119)	AIRBAG	1.6 16v	AUTOLIV AirBag MY 99 (1F-2P)
 Doblo' (119)	AIRBAG	1.6 16v	AUTOLIV AirBag MY 99 (2F-2P-2L-I)
 Doblo' (119)	AIRBAG	1.6 16v	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo' (119)	AIRBAG	1.6 16v	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo' (119)	AIRBAG	1.6 16v	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo' (119)	AIRBAG	1.6 16v	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo' (119)	AIRBAG	1.6 16v Bipower (03-..)	Autoliv AirBag MY 99 (1F-2P)
 Doblo' (119)	AIRBAG	1.6 16v Bipower (03-..)	Autoliv AirBag MY 99 (2F-2P-2L-I)
 Doblo' (119)	AIRBAG	1.6 16v Bipower (03-..)	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo' (119)	AIRBAG	1.6 16v Bipower (03-..)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo' (119)	AIRBAG	1.6 16v Bipower (03-..)	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo' (119)	AIRBAG	1.6 16v Bipower (03-..)	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo' (119)	AIRBAG	1.9 D	AUTOLIV AirBag MY 99 (1F-2P)
 Doblo' (119)	AIRBAG	1.9 D	AUTOLIV AirBag MY 99 (2F-2P-2L-I)
 Doblo' (119)	AIRBAG	1.9 D	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo' (119)	AIRBAG	1.9 D	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo' (119)	AIRBAG	1.9 D	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo' (119)	AIRBAG	1.9 D	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo' (119)	AIRBAG	1.9 DS	Autoliv AirBag MY 99 (1F-2P)
 Doblo' (119)	AIRBAG	1.9 DS	Autoliv AirBag MY 99 (2F-2P-2L-I)
 Doblo' (119)	AIRBAG	1.9 DS	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo' (119)	AIRBAG	1.9 DS	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo' (119)	AIRBAG	1.9 DS	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo' (119)	AIRBAG	1.9 DS	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo' (119)	AIRBAG	1.9 JTD	Autoliv AirBag MY 99 (1F-2P)
 Doblo' (119)	AIRBAG	1.9 JTD	Autoliv AirBag MY 99 (2F-2P-2L-I)
 Doblo' (119)	AIRBAG	1.9 JTD	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo' (119)	AIRBAG	1.9 JTD	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo' (119)	AIRBAG	1.9 JTD	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo' (119)	AIRBAG	1.9 JTD	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo' (119)	AIRBAG	100 1.9 JTD	Autoliv AirBag MY 99 (1F-2P)
 Doblo' (119)	AIRBAG	100 1.9 JTD	Autoliv AirBag MY 99 (2F-2P-2L-I)
 Doblo' (119)	AIRBAG	100 1.9 JTD	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo' (119)	AIRBAG	100 1.9 JTD	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo' (119)	AIRBAG	100 1.9 JTD	SIEMENS AirBag MY 99 (2F-2P-I-S)

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Doblo' (119)	AIRBAG	100 1.9 JTD	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo' (119)	AIRBAG	120 1.9 JTD (03-..)	Autoliv AirBag MY 99 (1F-2P)
 Doblo' (119)	AIRBAG	120 1.9 JTD (03-..)	Autoliv AirBag MY 99 (2F-2P-2L-I)
 Doblo' (119)	AIRBAG	120 1.9 JTD (03-..)	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo' (119)	AIRBAG	120 1.9 JTD (03-..)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo' (119)	AIRBAG	120 1.9 JTD (03-..)	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo' (119)	AIRBAG	120 1.9 JTD (03-..)	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo' (119)	AIRBAG	80 1.9 JTD	Autoliv AirBag MY 99 (1F-2P)
 Doblo' (119)	AIRBAG	80 1.9 JTD	Autoliv AirBag MY 99 (2F-2P-2L-I)
 Doblo' (119)	AIRBAG	80 1.9 JTD	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo' (119)	AIRBAG	80 1.9 JTD	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo' (119)	AIRBAG	80 1.9 JTD	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo' (119)	AIRBAG	80 1.9 JTD	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo' (119)	AUTOM. TRANSMISSI	1.2 16v (01-..)	Marelli Selespeed CFC300 (EP)
 Doblo' (119)	AUTOM. TRANSMISSI	1.2 8v	Marelli Selespeed CFC300 (EP)
 Doblo' (119)	AUTOM. TRANSMISSI	1.2 8v (01-..)	Marelli Selespeed CFC300 (EP)
 Doblo' (119)	AUTOM. TRANSMISSI	1.2 8v Bipower (01-..)	Marelli Selespeed CFC300 (EP)
 Doblo' (119)	AUTOM. TRANSMISSI	1.3 Multijet	Marelli Selespeed CFC300 (EP)
 Doblo' (119)	AUTOM. TRANSMISSI	1.3 Multijet FAP (03-..)	Marelli Selespeed CFC300 (EP)
 Doblo' (119)	AUTOM. TRANSMISSI	1.4 8v (01-..)	Marelli Selespeed CFC300 (EP)
 Doblo' (119)	AUTOM. TRANSMISSI	1.6 16v (01-..)	Marelli Selespeed CFC300 (EP)
 Doblo' (119)	AUTOM. TRANSMISSI	1.6 16v Bipower (03-..)	Marelli Selespeed CFC300 (EP)
 Doblo' (119)	AUTOM. TRANSMISSI	1.9 JTD (03-..)	Marelli Selespeed CFC300 (EP)
 Doblo' (119)	AUTOM. TRANSMISSI	100 1.9 JTD (02-..)	Marelli Selespeed CFC300 (EP)
 Doblo' (119)	AUTOM. TRANSMISSI	120 1.9 JTD (03-..)	Marelli Selespeed CFC300 (EP)
 Doblo' (119)	AUTOM. TRANSMISSI	80 1.9 JTD	Marelli Selespeed CFC300 (EP)
 Doblo' (119)	CHASSIS NETWORK	1.2 16v	DELPHI/Marelli Body Computer
 Doblo' (119)	CHASSIS NETWORK	1.2 16v	Fiat CAN Info
 Doblo' (119)	CHASSIS NETWORK	1.2 16v	Fiat Proxi Alignement
 Doblo' (119)	CHASSIS NETWORK	1.2 16v (03-..)	DELPHI/Marelli Body Computer
 Doblo' (119)	CHASSIS NETWORK	1.2 16v (03-..)	Fiat Proxi Alignement
 Doblo' (119)	CHASSIS NETWORK	1.2 8v	DELPHI/Marelli Body Computer
 Doblo' (119)	CHASSIS NETWORK	1.2 8v	Fiat CAN Info
 Doblo' (119)	CHASSIS NETWORK	1.2 8v	Fiat Proxi Alignement
 Doblo' (119)	CHASSIS NETWORK	1.2 8v (03-..)	DELPHI/Marelli Body Computer
 Doblo' (119)	CHASSIS NETWORK	1.2 8v (03-..)	Fiat Proxi Alignement
 Doblo' (119)	CHASSIS NETWORK	1.2 8v Bipower	DELPHI/Marelli Body Computer
 Doblo' (119)	CHASSIS NETWORK	1.2 8v Bipower	Fiat CAN Info
 Doblo' (119)	CHASSIS NETWORK	1.2 8v Bipower	Fiat Proxi Alignement
 Doblo' (119)	CHASSIS NETWORK	1.2 8v Bipower (03-..)	DELPHI/Marelli Body Computer
 Doblo' (119)	CHASSIS NETWORK	1.2 8v Bipower (03-..)	Fiat Proxi Alignement
 Doblo' (119)	CHASSIS NETWORK	1.3 Multijet	DELPHI/Marelli Body Computer
 Doblo' (119)	CHASSIS NETWORK	1.3 Multijet	Fiat CAN Info
 Doblo' (119)	CHASSIS NETWORK	1.3 Multijet	Fiat Proxi Alignement
 Doblo' (119)	CHASSIS NETWORK	1.3 Multijet (03-..)	DELPHI/Marelli Body Computer
 Doblo' (119)	CHASSIS NETWORK	1.3 Multijet (03-..)	Fiat Proxi Alignement
 Doblo' (119)	CHASSIS NETWORK	1.3 Multijet FAP	DELPHI/Marelli Body Computer
 Doblo' (119)	CHASSIS NETWORK	1.3 Multijet FAP	Fiat CAN Info
 Doblo' (119)	CHASSIS NETWORK	1.3 Multijet FAP	Fiat Proxi Alignement
 Doblo' (119)	CHASSIS NETWORK	1.3 Multijet FAP (03-..)	DELPHI/Marelli Body Computer
 Doblo' (119)	CHASSIS NETWORK	1.3 Multijet FAP (03-..)	Fiat Proxi Alignement
 Doblo' (119)	CHASSIS NETWORK	1.4 8v	DELPHI/Marelli Body Computer
 Doblo' (119)	CHASSIS NETWORK	1.4 8v	Fiat CAN Info
 Doblo' (119)	CHASSIS NETWORK	1.4 8v	Fiat Proxi Alignement
 Doblo' (119)	CHASSIS NETWORK	1.4 8v (03-..)	DELPHI/Marelli Body Computer
 Doblo' (119)	CHASSIS NETWORK	1.4 8v (03-..)	Fiat Proxi Alignement
 Doblo' (119)	CHASSIS NETWORK	1.6 16v	DELPHI/Marelli Body Computer
 Doblo' (119)	CHASSIS NETWORK	1.6 16v	Fiat CAN Info

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Doblo' (119)	CHASSIS NETWORK	1.6 16v	Fiat Proxi Alignement
 Doblo' (119)	CHASSIS NETWORK	1.6 16v (03-..)	DELPHI/Marelli Body Computer
 Doblo' (119)	CHASSIS NETWORK	1.6 16v (03-..)	Fiat Proxi Alignement
 Doblo' (119)	CHASSIS NETWORK	1.6 16v Bipower	DELPHI/Marelli Body Computer
 Doblo' (119)	CHASSIS NETWORK	1.6 16v Bipower	Fiat CAN Info
 Doblo' (119)	CHASSIS NETWORK	1.6 16v Bipower	Fiat Proxi Alignement
 Doblo' (119)	CHASSIS NETWORK	1.6 16v Bipower (03-..)	DELPHI/Marelli Body Computer
 Doblo' (119)	CHASSIS NETWORK	1.6 16v Bipower (03-..)	Fiat Proxi Alignement
 Doblo' (119)	CHASSIS NETWORK	1.9 D	DELPHI/Marelli Body Computer
 Doblo' (119)	CHASSIS NETWORK	1.9 D	Fiat CAN Info
 Doblo' (119)	CHASSIS NETWORK	1.9 D	Fiat Proxi Alignement
 Doblo' (119)	CHASSIS NETWORK	1.9 D (03-..)	DELPHI/Marelli Body Computer
 Doblo' (119)	CHASSIS NETWORK	1.9 D (03-..)	Fiat Proxi Alignement
 Doblo' (119)	CHASSIS NETWORK	1.9 DS	DELPHI/Marelli Body Computer
 Doblo' (119)	CHASSIS NETWORK	1.9 DS	Fiat CAN Info
 Doblo' (119)	CHASSIS NETWORK	1.9 DS	Fiat Proxi Alignement
 Doblo' (119)	CHASSIS NETWORK	1.9 DS (03-..)	DELPHI/Marelli Body Computer
 Doblo' (119)	CHASSIS NETWORK	1.9 DS (03-..)	Fiat Proxi Alignement
 Doblo' (119)	CHASSIS NETWORK	1.9 JTD	DELPHI/Marelli Body Computer
 Doblo' (119)	CHASSIS NETWORK	1.9 JTD	Fiat CAN Info
 Doblo' (119)	CHASSIS NETWORK	1.9 JTD	Fiat Proxi Alignement
 Doblo' (119)	CHASSIS NETWORK	1.9 JTD (03-..)	DELPHI/Marelli Body Computer
 Doblo' (119)	CHASSIS NETWORK	1.9 JTD (03-..)	Fiat Proxi Alignement
 Doblo' (119)	CHASSIS NETWORK	100 1.9 JTD	DELPHI/Marelli Body Computer
 Doblo' (119)	CHASSIS NETWORK	100 1.9 JTD	Fiat CAN Info
 Doblo' (119)	CHASSIS NETWORK	100 1.9 JTD	Fiat Proxi Alignement
 Doblo' (119)	CHASSIS NETWORK	100 1.9 JTD (03-..)	DELPHI/Marelli Body Computer
 Doblo' (119)	CHASSIS NETWORK	100 1.9 JTD (03-..)	Fiat Proxi Alignement
 Doblo' (119)	CHASSIS NETWORK	120 1.9 JTD	DELPHI/Marelli Body Computer
 Doblo' (119)	CHASSIS NETWORK	120 1.9 JTD	Fiat CAN Info
 Doblo' (119)	CHASSIS NETWORK	120 1.9 JTD	Fiat Proxi Alignement
 Doblo' (119)	CHASSIS NETWORK	120 1.9 JTD (03-..)	DELPHI/Marelli Body Computer
 Doblo' (119)	CHASSIS NETWORK	120 1.9 JTD (03-..)	Fiat Proxi Alignement
 Doblo' (119)	CHASSIS NETWORK	80 1.9 JTD	DELPHI/Marelli Body Computer
 Doblo' (119)	CHASSIS NETWORK	80 1.9 JTD	Fiat CAN Info
 Doblo' (119)	CHASSIS NETWORK	80 1.9 JTD	Fiat Proxi Alignement
 Doblo' (119)	CHASSIS NETWORK	80 1.9 JTD (03-..)	DELPHI/Marelli Body Computer
 Doblo' (119)	CHASSIS NETWORK	80 1.9 JTD (03-..)	Fiat Proxi Alignement
 Doblo' (119)	DASHBOARD	1.2 16v	VEGLIA/Marelli Dashboard
 Doblo' (119)	DASHBOARD	1.2 16v (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	DASHBOARD	1.2 16v (03-..)	Marelli Dashboard Strip/Modale
 Doblo' (119)	DASHBOARD	1.2 8v	VEGLIA/Marelli Dashboard
 Doblo' (119)	DASHBOARD	1.2 8v (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	DASHBOARD	1.2 8v (03-..)	Marelli Dashboard Strip/Modale
 Doblo' (119)	DASHBOARD	1.2 8v Bipower	VEGLIA/Marelli Dashboard
 Doblo' (119)	DASHBOARD	1.2 8v Bipower (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	DASHBOARD	1.2 8v Bipower (03-..)	Marelli Dashboard Strip/Modale
 Doblo' (119)	DASHBOARD	1.3 Multijet	VEGLIA/Marelli Dashboard
 Doblo' (119)	DASHBOARD	1.3 Multijet (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	DASHBOARD	1.3 Multijet (03-..)	Marelli Dashboard Strip/Modale
 Doblo' (119)	DASHBOARD	1.3 Multijet FAP	VEGLIA/Marelli Dashboard
 Doblo' (119)	DASHBOARD	1.3 Multijet FAP (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	DASHBOARD	1.3 Multijet FAP (03-..)	Marelli Dashboard Strip/Modale
 Doblo' (119)	DASHBOARD	1.4 8v	VEGLIA/Marelli Dashboard
 Doblo' (119)	DASHBOARD	1.4 8v (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	DASHBOARD	1.4 8v (03-..)	Marelli Dashboard Strip/Modale
 Doblo' (119)	DASHBOARD	1.6 16v	VEGLIA/Marelli Dashboard
 Doblo' (119)	DASHBOARD	1.6 16v (03-..)	Marelli Dashboard Comfort

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Doblo' (119)	DASHBOARD	1.6 16v (03-..)	Marelli Dashboard Strip/Modale
 Doblo' (119)	DASHBOARD	1.6 16v Bipower	VEGLIA/Marelli Dashboard
 Doblo' (119)	DASHBOARD	1.6 16v Bipower (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	DASHBOARD	1.6 16v Bipower (03-..)	Marelli Dashboard Strip/Modale
 Doblo' (119)	DASHBOARD	1.9 D	VEGLIA/Marelli Dashboard
 Doblo' (119)	DASHBOARD	1.9 D (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	DASHBOARD	1.9 D (03-..)	Marelli Dashboard Strip/Modale
 Doblo' (119)	DASHBOARD	1.9 DS	VEGLIA/Marelli Dashboard
 Doblo' (119)	DASHBOARD	1.9 DS (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	DASHBOARD	1.9 DS (03-..)	Marelli Dashboard Strip/Modale
 Doblo' (119)	DASHBOARD	1.9 JTD	VEGLIA/Marelli Dashboard
 Doblo' (119)	DASHBOARD	1.9 JTD (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	DASHBOARD	1.9 JTD (03-..)	Marelli Dashboard Strip/Modale
 Doblo' (119)	DASHBOARD	100 1.9 JTD	VEGLIA/Marelli Dashboard
 Doblo' (119)	DASHBOARD	100 1.9 JTD (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	DASHBOARD	100 1.9 JTD (03-..)	Marelli Dashboard Strip/Modale
 Doblo' (119)	DASHBOARD	120 1.9 JTD	VEGLIA/Marelli Dashboard
 Doblo' (119)	DASHBOARD	120 1.9 JTD (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	DASHBOARD	120 1.9 JTD (03-..)	Marelli Dashboard Strip/Modale
 Doblo' (119)	DASHBOARD	80 1.9 JTD	VEGLIA/Marelli Dashboard
 Doblo' (119)	DASHBOARD	80 1.9 JTD (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	DASHBOARD	80 1.9 JTD (03-..)	Marelli Dashboard Strip/Modale
 Doblo' (119)	DIESEL MANAGEMEN	1.9 D	LUCAS EPIC DCU3F
 Doblo' (119)	ENGINE MANAGEME	1.2 16v (01-..)	EOBD
 Doblo' (119)	ENGINE MANAGEME	1.2 8v	Marelli IAW 49F/59F EOBD
 Doblo' (119)	ENGINE MANAGEME	1.2 8v	Marelli IAW 59F
 Doblo' (119)	ENGINE MANAGEME	1.2 8v	Marelli IAW 5AF
 Doblo' (119)	ENGINE MANAGEME	1.2 8v (01-..)	EOBD
 Doblo' (119)	ENGINE MANAGEME	1.2 8v Bipower (01-..)	EOBD
 Doblo' (119)	ENGINE MANAGEME	1.3 Multijet	Marelli 6JF CF3 Common Rail
 Doblo' (119)	ENGINE MANAGEME	1.3 Multijet FAP (03-..)	Marelli 6F3 CF3 Common Rail
 Doblo' (119)	ENGINE MANAGEME	1.3 Multijet FAP (03-..)	Marelli 6JF CF3 Common Rail
 Doblo' (119)	ENGINE MANAGEME	1.4 8v (01-..)	EOBD
 Doblo' (119)	ENGINE MANAGEME	1.6 16v (01-..)	EOBD
 Doblo' (119)	ENGINE MANAGEME	1.6 16v Bipower (03-..)	Marelli IAW 49F/59F EOBD
 Doblo' (119)	ENGINE MANAGEME	1.9 JTD (03-..)	BOSCH EDC 15 Common Rail (JTD '99)
 Doblo' (119)	ENGINE MANAGEME	100 1.9 JTD (02-..)	BOSCH EDC 15 Common Rail (JTD '99)
 Doblo' (119)	ENGINE MANAGEME	120 1.9 JTD (03-..)	BOSCH EDC 16C39 CF4/EOBD Common
 Doblo' (119)	ENGINE MANAGEME	80 1.9 JTD	BOSCH EDC 15 Common Rail (JTD '99)
 Doblo' (119)	ENGINE MANAGEME	1.6 16v Bipower (03-..)	METATRON 6A0 EOBD
 Doblo' (119)	KEY ENCODE	1.2 16v	DELPHI/Marelli CODE Body Computer
 Doblo' (119)	KEY ENCODE	1.2 8v	DELPHI/Marelli CODE Body Computer
 Doblo' (119)	KEY ENCODE	1.2 8v Bipower	DELPHI/Marelli CODE Body Computer
 Doblo' (119)	KEY ENCODE	1.3 Multijet	DELPHI/Marelli CODE Body Computer
 Doblo' (119)	KEY ENCODE	1.3 Multijet FAP (03-..)	DELPHI/Marelli CODE Body Computer
 Doblo' (119)	KEY ENCODE	1.4 8v	DELPHI/Marelli CODE Body Computer
 Doblo' (119)	KEY ENCODE	1.6 16v	DELPHI/Marelli CODE Body Computer
 Doblo' (119)	KEY ENCODE	1.6 16v Bipower (03-..)	DELPHI/Marelli CODE Body Computer
 Doblo' (119)	KEY ENCODE	1.9 D	DELPHI/Marelli CODE Body Computer
 Doblo' (119)	KEY ENCODE	1.9 DS	DELPHI/Marelli CODE Body Computer
 Doblo' (119)	KEY ENCODE	1.9 JTD	DELPHI/Marelli CODE Body Computer
 Doblo' (119)	KEY ENCODE	100 1.9 JTD	DELPHI/Marelli CODE Body Computer
 Doblo' (119)	KEY ENCODE	120 1.9 JTD (03-..)	DELPHI/Marelli CODE Body Computer
 Doblo' (119)	KEY ENCODE	80 1.9 JTD	DELPHI/Marelli CODE Body Computer
 Doblo' (119)	MAINTENANCE	1.2 16v (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	MAINTENANCE	1.2 16v (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	MAINTENANCE	1.2 16v (03-..)	Marelli Dashboard Strip/Modale
 Doblo' (119)	MAINTENANCE	1.2 8v	Marelli IAW 5AF

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Doblo' (119)	MAINTENANCE	1.2 8v (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	MAINTENANCE	1.2 8v (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	MAINTENANCE	1.2 8v (03-..)	Marelli Dashboard Strip/Modale
 Doblo' (119)	MAINTENANCE	1.2 8v Bipower (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	MAINTENANCE	1.2 8v Bipower (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	MAINTENANCE	1.2 8v Bipower (03-..)	Marelli Dashboard Strip/Modale
 Doblo' (119)	MAINTENANCE	1.3 Multijet (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	MAINTENANCE	1.3 Multijet (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	MAINTENANCE	1.3 Multijet (03-..)	Marelli Dashboard Strip/Modale
 Doblo' (119)	MAINTENANCE	1.3 Multijet FAP (03-..)	Marelli 6F3 CF3 Common Rail
 Doblo' (119)	MAINTENANCE	1.3 Multijet FAP (03-..)	Marelli 6F3 CF3 Common Rail
 Doblo' (119)	MAINTENANCE	1.3 Multijet FAP (03-..)	Marelli 6F3 CF3 Common Rail
 Doblo' (119)	MAINTENANCE	1.3 Multijet FAP (03-..)	Marelli 6F3 CF3 Common Rail
 Doblo' (119)	MAINTENANCE	1.3 Multijet FAP (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	MAINTENANCE	1.3 Multijet FAP (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	MAINTENANCE	1.3 Multijet FAP (03-..)	Marelli Dashboard Strip/Modale
 Doblo' (119)	MAINTENANCE	1.4 8v (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	MAINTENANCE	1.4 8v (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	MAINTENANCE	1.4 8v (03-..)	Marelli Dashboard Strip/Modale
 Doblo' (119)	MAINTENANCE	1.6 16v (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	MAINTENANCE	1.6 16v (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	MAINTENANCE	1.6 16v (03-..)	Marelli Dashboard Strip/Modale
 Doblo' (119)	MAINTENANCE	1.6 16v Bipower (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	MAINTENANCE	1.6 16v Bipower (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	MAINTENANCE	1.6 16v Bipower (03-..)	Marelli Dashboard Strip/Modale
 Doblo' (119)	MAINTENANCE	1.9 D (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	MAINTENANCE	1.9 D (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	MAINTENANCE	1.9 D (03-..)	Marelli Dashboard Strip/Modale
 Doblo' (119)	MAINTENANCE	1.9 DS (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	MAINTENANCE	1.9 DS (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	MAINTENANCE	1.9 DS (03-..)	Marelli Dashboard Strip/Modale
 Doblo' (119)	MAINTENANCE	1.9 JTD (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	MAINTENANCE	1.9 JTD (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	MAINTENANCE	1.9 JTD (03-..)	Marelli Dashboard Strip/Modale
 Doblo' (119)	MAINTENANCE	100 1.9 JTD (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	MAINTENANCE	100 1.9 JTD (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	MAINTENANCE	100 1.9 JTD (03-..)	Marelli Dashboard Strip/Modale
 Doblo' (119)	MAINTENANCE	120 1.9 JTD (03-..)	BOSCH EDC 16C39 CF4/EOBD Common
 Doblo' (119)	MAINTENANCE	120 1.9 JTD (03-..)	BOSCH EDC 16C39 CF4/EOBD Common
 Doblo' (119)	MAINTENANCE	120 1.9 JTD (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	MAINTENANCE	120 1.9 JTD (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	MAINTENANCE	120 1.9 JTD (03-..)	Marelli Dashboard Strip/Modale
 Doblo' (119)	MAINTENANCE	80 1.9 JTD (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	MAINTENANCE	80 1.9 JTD (03-..)	Marelli Dashboard Comfort
 Doblo' (119)	MAINTENANCE	80 1.9 JTD (03-..)	Marelli Dashboard Strip/Modale
 Doblo' (263)	ABS + TRACT. CONT	1.3 MJET 16v	Continental MK60EC
 Doblo' (263)	ABS + TRACT. CONT	1.4 16v	Continental MK60EC
 Doblo' (263)	ABS + TRACT. CONT	1.6 MJET 16v	Continental MK60EC
 Doblo' (263)	ABS + TRACT. CONT	2.0 MJET 16v	Continental MK60EC
 Doblo' (263)	ABS + TRACT. CONT	Natural Power	Continental MK60EC
 Doblo' (263)	AIRBAG	1.3 MJET 16v	Bosch
 Doblo' (263)	AIRBAG	1.4 16v	Bosch
 Doblo' (263)	AIRBAG	1.6 MJET 16v	Bosch
 Doblo' (263)	AIRBAG	2.0 MJET 16v	Bosch
 Doblo' (263)	AIRBAG	Natural Power	Bosch
 Doblo' (263)	AUTOM. TRANSMISSI	1.3 MJET 16v	Marelli Selespeed CFC300 (EP)
 Doblo' (263)	AUTOM. TRANSMISSI	1.4 16v	Marelli Selespeed CFC300 (EP)
 Doblo' (263)	AUTOM. TRANSMISSI	1.6 MJET 16v	Marelli Selespeed CFC300 (EP)

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Doblo' (263)	AUTOM. TRANSMISSI	2.0 MJET 16v	Marelli Selespeed CFC300 (EP)
 Doblo' (263)	AUTOM. TRANSMISSI	Natural Power	Marelli Selespeed CFC300 (EP)
 Doblo' (263)	CHASSIS NETWORK	1.3 MJET 16v	CAN info
 Doblo' (263)	CHASSIS NETWORK	1.3 MJET 16v	DELPHI Body Computer
 Doblo' (263)	CHASSIS NETWORK	1.3 MJET 16v	Fiat Proxi Alignement
 Doblo' (263)	CHASSIS NETWORK	1.4 16v	CAN info
 Doblo' (263)	CHASSIS NETWORK	1.4 16v	DELPHI Body Computer
 Doblo' (263)	CHASSIS NETWORK	1.4 16v	Fiat Proxi Alignement
 Doblo' (263)	CHASSIS NETWORK	1.6 MJET 16v	CAN info
 Doblo' (263)	CHASSIS NETWORK	1.6 MJET 16v	DELPHI Body Computer
 Doblo' (263)	CHASSIS NETWORK	1.6 MJET 16v	Fiat Proxi Alignement
 Doblo' (263)	CHASSIS NETWORK	2.0 MJET 16v	CAN info
 Doblo' (263)	CHASSIS NETWORK	2.0 MJET 16v	DELPHI Body Computer
 Doblo' (263)	CHASSIS NETWORK	2.0 MJET 16v	Fiat Proxi Alignement
 Doblo' (263)	CHASSIS NETWORK	Natural Power	CAN info
 Doblo' (263)	CHASSIS NETWORK	Natural Power	DELPHI Body Computer
 Doblo' (263)	CHASSIS NETWORK	Natural Power	Fiat Proxi Alignement
 Doblo' (263)	CLIMA	1.3 MJET 16v	Denso Monozone 3
 Doblo' (263)	CLIMA	1.4 16v	Denso Monozone 3
 Doblo' (263)	CLIMA	1.6 MJET 16v	Denso Monozone 3
 Doblo' (263)	CLIMA	2.0 MJET 16v	Denso Monozone 3
 Doblo' (263)	CLIMA	Natural Power	Denso Monozone 3
 Doblo' (263)	DASHBOARD	1.3 MJET 16v	Marelli Dashboard
 Doblo' (263)	DASHBOARD	1.3 MJET 16v	Marelli Dashboard 3
 Doblo' (263)	DASHBOARD	1.4 16v	Marelli Dashboard
 Doblo' (263)	DASHBOARD	1.4 16v	Marelli Dashboard 3
 Doblo' (263)	DASHBOARD	1.6 MJET 16v	Marelli Dashboard
 Doblo' (263)	DASHBOARD	1.6 MJET 16v	Marelli Dashboard 3
 Doblo' (263)	DASHBOARD	2.0 MJET 16v	Marelli Dashboard
 Doblo' (263)	DASHBOARD	2.0 MJET 16v	Marelli Dashboard 3
 Doblo' (263)	DASHBOARD	Natural Power	Marelli Dashboard
 Doblo' (263)	DASHBOARD	Natural Power	Marelli Dashboard 3
 Doblo' (263)	ENGINE MANAGEME	1.3 MJET 16v	Marelli EDC 8DF CF5
 Doblo' (263)	ENGINE MANAGEME	1.3 MJET 16v	Marelli EDC 8F3 CF5
 Doblo' (263)	ENGINE MANAGEME	1.3 MJET 16v (05-09)	Marelli EDC 6F3 (D.P.F.)
 Doblo' (263)	ENGINE MANAGEME	1.4 16v	BOSCH Motronic ME 7.9.10
 Doblo' (263)	ENGINE MANAGEME	1.4 16v	BOSCH Motronic ME7.9.10 CF4-EOBD
 Doblo' (263)	ENGINE MANAGEME	1.6 MJET 16v	BOSCH EDC16C39 CF5/EOBD
 Doblo' (263)	ENGINE MANAGEME	1.6 MJET 16v (09-..)	BOSCH EDC16C39 CF5/EOBD
 Doblo' (263)	ENGINE MANAGEME	2.0 MJET 16v	BOSCH EDC16C39 CF5/EOBD
 Doblo' (263)	ENGINE MANAGEME	2.0 MJET 16v (09-..)	BOSCH EDC16C39 CF5/EOBD
 Doblo' (263)	ENGINE MANAGEME	Natural Power	Marelli IAW 5SF8
 Doblo' (263)	MAINTENANCE	1.3 MJET 16v	Marelli Dashboard
 Doblo' (263)	MAINTENANCE	1.3 MJET 16v	Marelli Dashboard
 Doblo' (263)	MAINTENANCE	1.3 MJET 16v	Marelli Dashboard
 Doblo' (263)	MAINTENANCE	1.3 MJET 16v	Marelli Dashboard 3
 Doblo' (263)	MAINTENANCE	1.3 MJET 16v	Marelli Dashboard 3
 Doblo' (263)	MAINTENANCE	1.3 MJET 16v	Marelli EDC 8DF CF5
 Doblo' (263)	MAINTENANCE	1.3 MJET 16v	Marelli EDC 8DF CF5
 Doblo' (263)	MAINTENANCE	1.3 MJET 16v	Marelli EDC 8F3 CF5
 Doblo' (263)	MAINTENANCE	1.3 MJET 16v	Marelli EDC 8F3 CF5
 Doblo' (263)	MAINTENANCE	1.3 MJET 16v (05-09)	Marelli EDC 6F3 (D.P.F.)
 Doblo' (263)	MAINTENANCE	1.3 MJET 16v (05-09)	Marelli EDC 6F3 (D.P.F.)
 Doblo' (263)	MAINTENANCE	1.3 MJET 16v (05-09)	Marelli EDC 6F3 (D.P.F.)
 Doblo' (263)	MAINTENANCE	1.3 MJET 16v (05-09)	Marelli EDC 6F3 (D.P.F.)
 Doblo' (263)	MAINTENANCE	1.4 16v	Marelli Dashboard
 Doblo' (263)	MAINTENANCE	1.4 16v	Marelli Dashboard
 Doblo' (263)	MAINTENANCE	1.4 16v	Marelli Dashboard

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Doblo' (263)	MAINTENANCE	1.4 16v	Marelli Dashboard 3
 Doblo' (263)	MAINTENANCE	1.4 16v	Marelli Dashboard 3
 Doblo' (263)	MAINTENANCE	1.6 MJET 16v	BOSCH EDC16C39 CF5/EOBD
 Doblo' (263)	MAINTENANCE	1.6 MJET 16v	Marelli Dashboard
 Doblo' (263)	MAINTENANCE	1.6 MJET 16v	Marelli Dashboard
 Doblo' (263)	MAINTENANCE	1.6 MJET 16v	Marelli Dashboard
 Doblo' (263)	MAINTENANCE	1.6 MJET 16v	Marelli Dashboard 3
 Doblo' (263)	MAINTENANCE	1.6 MJET 16v	Marelli Dashboard 3
 Doblo' (263)	MAINTENANCE	1.6 MJET 16v (09-..)	BOSCH EDC16C39 CF5/EOBD
 Doblo' (263)	MAINTENANCE	2.0 MJET 16v	BOSCH EDC16C39 CF5/EOBD
 Doblo' (263)	MAINTENANCE	2.0 MJET 16v	Marelli Dashboard
 Doblo' (263)	MAINTENANCE	2.0 MJET 16v	Marelli Dashboard
 Doblo' (263)	MAINTENANCE	2.0 MJET 16v	Marelli Dashboard
 Doblo' (263)	MAINTENANCE	2.0 MJET 16v	Marelli Dashboard 3
 Doblo' (263)	MAINTENANCE	2.0 MJET 16v	Marelli Dashboard 3
 Doblo' (263)	MAINTENANCE	2.0 MJET 16v (09-..)	BOSCH EDC16C39 CF5/EOBD
 Doblo' (263)	MAINTENANCE	Natural Power	Marelli Dashboard
 Doblo' (263)	MAINTENANCE	Natural Power	Marelli Dashboard
 Doblo' (263)	MAINTENANCE	Natural Power	Marelli Dashboard
 Doblo' (263)	MAINTENANCE	Natural Power	Marelli Dashboard 3
 Doblo' (263)	MAINTENANCE	Natural Power	Marelli Dashboard 3
 Doblo' (263)	MAINTENANCE	Natural Power	Marelli IAW 5SF8
 Doblo' (263)	PARKING HELP	1.4 16v	
 Doblo' (263)	PARKING HELP	1.6 MJET 16v	
 Doblo' (263)	PARKING HELP	2.0 MJET 16v	
 Doblo' (263)	PARKING HELP	Natural Power	
 Doblo' (263)	SUPP HEATER/AUTO	1.3 MJET 16v	Denso
 Doblo' (263)	SUPP HEATER/AUTO	1.4 16v	Denso
 Doblo' (263)	SUPP HEATER/AUTO	1.6 MJET 16v	Denso
 Doblo' (263)	SUPP HEATER/AUTO	2.0 MJET 16v	Denso
 Doblo' (263)	SUPP HEATER/AUTO	Natural Power	Denso
 Doblo' (263)	VISUAL./TELEMATIC	1.3 MJET 16v	Lauberhorn Convergence
 Doblo' (263)	VISUAL./TELEMATIC	1.3 MJET 16v	Marelli Convergence
 Doblo' (263)	VISUAL./TELEMATIC	1.4 16v	Lauberhorn Convergence
 Doblo' (263)	VISUAL./TELEMATIC	1.4 16v	Marelli Convergence
 Doblo' (263)	VISUAL./TELEMATIC	1.6 MJET 16v	Lauberhorn Convergence
 Doblo' (263)	VISUAL./TELEMATIC	1.6 MJET 16v	Marelli Convergence
 Doblo' (263)	VISUAL./TELEMATIC	2.0 MJET 16v	Lauberhorn Convergence
 Doblo' (263)	VISUAL./TELEMATIC	2.0 MJET 16v	Marelli Convergence
 Doblo' (263)	VISUAL./TELEMATIC	Natural Power	Lauberhorn Convergence
 Doblo' (263)	VISUAL./TELEMATIC	Natural Power	Marelli Convergence
 Doblo' Cargo (223)	ABS	1.3 Multijet	ATE TEVES ABS Mk20
 Doblo' Cargo (223)	ABS	1.4 8v	ATE TEVES ABS Mk20
 Doblo' Cargo (223)	ABS	1.9 JTD	ATE TEVES ABS Mk20
 Doblo' Cargo (223)	ABS	120 1.9 JTD	ATE TEVES ABS Mk20
 Doblo' Cargo (223)	AIRBAG	1.3 Multijet	Autoliv AirBag MY 99 (1F-2P)
 Doblo' Cargo (223)	AIRBAG	1.3 Multijet	Autoliv AirBag MY 99 (2F-2P-2L-I)
 Doblo' Cargo (223)	AIRBAG	1.3 Multijet	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo' Cargo (223)	AIRBAG	1.3 Multijet	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo' Cargo (223)	AIRBAG	1.3 Multijet	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo' Cargo (223)	AIRBAG	1.3 Multijet	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo' Cargo (223)	AIRBAG	1.4 8v	Autoliv AirBag MY 99 (1F-2P)
 Doblo' Cargo (223)	AIRBAG	1.4 8v	Autoliv AirBag MY 99 (2F-2P-2L-I)
 Doblo' Cargo (223)	AIRBAG	1.4 8v	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo' Cargo (223)	AIRBAG	1.4 8v	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo' Cargo (223)	AIRBAG	1.4 8v	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo' Cargo (223)	AIRBAG	1.4 8v	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo' Cargo (223)	AIRBAG	1.9 JTD	Autoliv AirBag MY 99 (1F-2P)

Systems supported by ECUREADER / ECUDECODER (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Doblo' Cargo (223)	AIRBAG	1.9 JTD	Autoliv AirBag MY 99 (2F-2P-2L-I)
 Doblo' Cargo (223)	AIRBAG	1.9 JTD	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo' Cargo (223)	AIRBAG	1.9 JTD	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo' Cargo (223)	AIRBAG	1.9 JTD	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo' Cargo (223)	AIRBAG	1.9 JTD	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo' Cargo (223)	AIRBAG	120 1.9 JTD	Autoliv AirBag MY 99 (1F-2P)
 Doblo' Cargo (223)	AIRBAG	120 1.9 JTD	Autoliv AirBag MY 99 (2F-2P-2L-I)
 Doblo' Cargo (223)	AIRBAG	120 1.9 JTD	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo' Cargo (223)	AIRBAG	120 1.9 JTD	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo' Cargo (223)	AIRBAG	120 1.9 JTD	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo' Cargo (223)	AIRBAG	120 1.9 JTD	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo' Cargo (223)	CHASSIS NETWORK	1.3 Multijet	DELPHI/Marelli Body Computer
 Doblo' Cargo (223)	CHASSIS NETWORK	1.3 Multijet	Fiat CAN Info
 Doblo' Cargo (223)	CHASSIS NETWORK	1.3 Multijet	Fiat Proxi Alignement
 Doblo' Cargo (223)	CHASSIS NETWORK	1.3 Multijet (03-..)	DELPHI/Marelli Body Computer
 Doblo' Cargo (223)	CHASSIS NETWORK	1.3 Multijet (03-..)	Fiat Proxi Alignement
 Doblo' Cargo (223)	CHASSIS NETWORK	1.4 8v	DELPHI/Marelli Body Computer
 Doblo' Cargo (223)	CHASSIS NETWORK	1.4 8v	Fiat CAN Info
 Doblo' Cargo (223)	CHASSIS NETWORK	1.4 8v	Fiat Proxi Alignement
 Doblo' Cargo (223)	CHASSIS NETWORK	1.4 8v (03-..)	DELPHI/Marelli Body Computer
 Doblo' Cargo (223)	CHASSIS NETWORK	1.4 8v (03-..)	Fiat Proxi Alignement
 Doblo' Cargo (223)	CHASSIS NETWORK	1.9 JTD	DELPHI/Marelli Body Computer
 Doblo' Cargo (223)	CHASSIS NETWORK	1.9 JTD	Fiat CAN Info
 Doblo' Cargo (223)	CHASSIS NETWORK	1.9 JTD	Fiat Proxi Alignement
 Doblo' Cargo (223)	CHASSIS NETWORK	1.9 JTD (03-..)	DELPHI/Marelli Body Computer
 Doblo' Cargo (223)	CHASSIS NETWORK	1.9 JTD (03-..)	Fiat Proxi Alignement
 Doblo' Cargo (223)	CHASSIS NETWORK	120 1.9 JTD	DELPHI/Marelli Body Computer
 Doblo' Cargo (223)	CHASSIS NETWORK	120 1.9 JTD	Fiat CAN Info
 Doblo' Cargo (223)	CHASSIS NETWORK	120 1.9 JTD	Fiat Proxi Alignement
 Doblo' Cargo (223)	CHASSIS NETWORK	120 1.9 JTD (03-..)	DELPHI/Marelli Body Computer
 Doblo' Cargo (223)	CHASSIS NETWORK	120 1.9 JTD (03-..)	Fiat Proxi Alignement
 Doblo' Cargo (223)	DASHBOARD	1.3 Multijet	VEGLIA/Marelli Dashboard
 Doblo' Cargo (223)	DASHBOARD	1.3 Multijet (03-..)	Marelli Dashboard Comfort
 Doblo' Cargo (223)	DASHBOARD	1.3 Multijet (03-..)	Marelli Dashboard Strip/Modale
 Doblo' Cargo (223)	DASHBOARD	1.4 8v	VEGLIA/Marelli Dashboard
 Doblo' Cargo (223)	DASHBOARD	1.4 8v (03-..)	Marelli Dashboard Comfort
 Doblo' Cargo (223)	DASHBOARD	1.4 8v (03-..)	Marelli Dashboard Strip/Modale
 Doblo' Cargo (223)	DASHBOARD	1.9 JTD	VEGLIA/Marelli Dashboard
 Doblo' Cargo (223)	DASHBOARD	1.9 JTD (03-..)	Marelli Dashboard Comfort
 Doblo' Cargo (223)	DASHBOARD	1.9 JTD (03-..)	Marelli Dashboard Strip/Modale
 Doblo' Cargo (223)	DASHBOARD	120 1.9 JTD	VEGLIA/Marelli Dashboard
 Doblo' Cargo (223)	DASHBOARD	120 1.9 JTD (03-..)	Marelli Dashboard Comfort
 Doblo' Cargo (223)	DASHBOARD	120 1.9 JTD (03-..)	Marelli Dashboard Strip/Modale
 Doblo' Cargo (223)	ENGINE MANAGEME	1.3 Multijet (04-..)	Marelli 6F3 (D.P.F.) CF3 Common Rail
 Doblo' Cargo (223)	ENGINE MANAGEME	1.3 Multijet (08-..)	Marelli EDC 6F3
 Doblo' Cargo (223)	ENGINE MANAGEME	1.9 JTD (03-..)	BOSCH EDC 15 Common Rail (JTD '99)
 Doblo' Cargo (223)	ENGINE MANAGEME	120 1.9 JTD (03-..)	BOSCH EDC 16 C39 CF4/EOBD Common
 Doblo' Cargo (223)	KEY ENCODE	1.3 Multijet	DELPHI/Marelli CODE Body Computer
 Doblo' Cargo (223)	KEY ENCODE	1.4 8v	DELPHI/Marelli CODE Body Computer
 Doblo' Cargo (223)	KEY ENCODE	1.9 JTD	DELPHI/Marelli CODE Body Computer
 Doblo' Cargo (223)	KEY ENCODE	120 1.9 JTD	DELPHI/Marelli CODE Body Computer
 Doblo' Cargo (223)	MAINTENANCE	1.3 Multijet (03-..)	Marelli Dashboard Comfort
 Doblo' Cargo (223)	MAINTENANCE	1.3 Multijet (03-..)	Marelli Dashboard Comfort
 Doblo' Cargo (223)	MAINTENANCE	1.3 Multijet (03-..)	Marelli Dashboard Strip/Modale
 Doblo' Cargo (223)	MAINTENANCE	1.3 Multijet (04-..)	Marelli 6F3 (D.P.F.) CF3 Common Rail
 Doblo' Cargo (223)	MAINTENANCE	1.3 Multijet (04-..)	Marelli 6F3 (D.P.F.) CF3 Common Rail
 Doblo' Cargo (223)	MAINTENANCE	1.3 Multijet (04-..)	Marelli 6F3 (D.P.F.) CF3 Common Rail
 Doblo' Cargo (223)	MAINTENANCE	1.3 Multijet (04-..)	Marelli 6F3 (D.P.F.) CF3 Common Rail

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Doblo' Cargo (223)	MAINTENANCE	1.3 Multijet (08-..)	Marelli EDC 6F3
 Doblo' Cargo (223)	MAINTENANCE	1.4 8v (03-..)	Marelli Dashboard Comfort
 Doblo' Cargo (223)	MAINTENANCE	1.4 8v (03-..)	Marelli Dashboard Comfort
 Doblo' Cargo (223)	MAINTENANCE	1.4 8v (03-..)	Marelli Dashboard Strip/Modale
 Doblo' Cargo (223)	MAINTENANCE	1.9 JTD (03-..)	Marelli Dashboard Comfort
 Doblo' Cargo (223)	MAINTENANCE	1.9 JTD (03-..)	Marelli Dashboard Comfort
 Doblo' Cargo (223)	MAINTENANCE	1.9 JTD (03-..)	Marelli Dashboard Strip/Modale
 Doblo' Cargo (223)	MAINTENANCE	120 1.9 JTD (03-..)	BOSCH EDC 16 C39 CF4/EOBD Common
 Doblo' Cargo (223)	MAINTENANCE	120 1.9 JTD (03-..)	BOSCH EDC 16 C39 CF4/EOBD Common
 Doblo' Cargo (223)	MAINTENANCE	120 1.9 JTD (03-..)	Marelli Dashboard Comfort
 Doblo' Cargo (223)	MAINTENANCE	120 1.9 JTD (03-..)	Marelli Dashboard Comfort
 Doblo' Cargo (223)	MAINTENANCE	120 1.9 JTD (03-..)	Marelli Dashboard Strip/Modale
 Doblo' Cargo (263)	ABS + TRACT. CONT	1.3 MJET 16v	Continental MK60EC
 Doblo' Cargo (263)	ABS + TRACT. CONT	1.4 16v	Continental MK60EC
 Doblo' Cargo (263)	ABS + TRACT. CONT	1.6 MJET 16v	Continental MK60EC
 Doblo' Cargo (263)	ABS + TRACT. CONT	2.0 MJET 16v	Continental MK60EC
 Doblo' Cargo (263)	ABS + TRACT. CONT	Natural Power	Continental MK60EC
 Doblo' Cargo (263)	AIRBAG	1.3 MJET 16v	Bosch
 Doblo' Cargo (263)	AIRBAG	1.4 16v	Bosch
 Doblo' Cargo (263)	AIRBAG	1.6 MJET 16v	Bosch
 Doblo' Cargo (263)	AIRBAG	2.0 MJET 16v	Bosch
 Doblo' Cargo (263)	AIRBAG	Natural Power	Bosch
 Doblo' Cargo (263)	AUTOM. TRANSMISSI	1.3 MJET 16v	Marelli Selespeed CFC300 (EP)
 Doblo' Cargo (263)	AUTOM. TRANSMISSI	1.4 16v	Marelli Selespeed CFC300 (EP)
 Doblo' Cargo (263)	AUTOM. TRANSMISSI	1.6 16v	Marelli Selespeed CFC300 (EP)
 Doblo' Cargo (263)	AUTOM. TRANSMISSI	2.0 MJET 16v	Marelli Selespeed CFC300 (EP)
 Doblo' Cargo (263)	AUTOM. TRANSMISSI	Natural Power	Marelli Selespeed CFC300 (EP)
 Doblo' Cargo (263)	CHASSIS NETWORK	1.3 MJET 16v	CAN info
 Doblo' Cargo (263)	CHASSIS NETWORK	1.3 MJET 16v	DELPHI Body Computer
 Doblo' Cargo (263)	CHASSIS NETWORK	1.3 MJET 16v	Fiat Proxi Alignement
 Doblo' Cargo (263)	CHASSIS NETWORK	1.4 16v	CAN info
 Doblo' Cargo (263)	CHASSIS NETWORK	1.4 16v	DELPHI Body Computer
 Doblo' Cargo (263)	CHASSIS NETWORK	1.4 16v	Fiat Proxi Alignement
 Doblo' Cargo (263)	CHASSIS NETWORK	1.6 MJET 16v	CAN info
 Doblo' Cargo (263)	CHASSIS NETWORK	1.6 MJET 16v	DELPHI Body Computer
 Doblo' Cargo (263)	CHASSIS NETWORK	1.6 MJET 16v	Fiat Proxi Alignement
 Doblo' Cargo (263)	CHASSIS NETWORK	2.0 MJET 16v	CAN info
 Doblo' Cargo (263)	CHASSIS NETWORK	2.0 MJET 16v	DELPHI Body Computer
 Doblo' Cargo (263)	CHASSIS NETWORK	2.0 MJET 16v	Fiat Proxi Alignement
 Doblo' Cargo (263)	CHASSIS NETWORK	Natural Power	CAN info
 Doblo' Cargo (263)	CHASSIS NETWORK	Natural Power	DELPHI Body Computer
 Doblo' Cargo (263)	CHASSIS NETWORK	Natural Power	Fiat Proxi Alignement
 Doblo' Cargo (263)	CLIMA	1.3 MJET 16v	Denso Monozone 3
 Doblo' Cargo (263)	CLIMA	1.4 16v	Denso Monozone 3
 Doblo' Cargo (263)	CLIMA	1.6 MJET 16v	Denso Monozone 3
 Doblo' Cargo (263)	CLIMA	2.0 MJET 16v	Denso Monozone 3
 Doblo' Cargo (263)	CLIMA	Natural Power	Denso Monozone 3
 Doblo' Cargo (263)	DASHBOARD	1.3 MJET 16v	Marelli Dashboard
 Doblo' Cargo (263)	DASHBOARD	1.3 MJET 16v	Marelli Dashboard 3
 Doblo' Cargo (263)	DASHBOARD	1.4 16v	Marelli Dashboard
 Doblo' Cargo (263)	DASHBOARD	1.4 16v	Marelli Dashboard 3
 Doblo' Cargo (263)	DASHBOARD	1.6 MJET 16v	Marelli Dashboard
 Doblo' Cargo (263)	DASHBOARD	1.6 MJET 16v	Marelli Dashboard 3
 Doblo' Cargo (263)	DASHBOARD	2.0 MJET 16v	Marelli Dashboard
 Doblo' Cargo (263)	DASHBOARD	2.0 MJET 16v	Marelli Dashboard 3
 Doblo' Cargo (263)	DASHBOARD	Natural Power	Marelli Dashboard
 Doblo' Cargo (263)	DASHBOARD	Natural Power	Marelli Dashboard 3
 Doblo' Cargo (263)	ENGINE MANAGEME	1.3 MJET 16v	Marelli EDC 8DF CF5

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Doblo' Cargo (263)	ENGINE MANAGEME	1.3 MJET 16v	Marelli EDC 8F3 CF5
 Doblo' Cargo (263)	ENGINE MANAGEME	1.3 MJET 16v (05-09)	Marelli EDC 6F3 (D.P.F.)
 Doblo' Cargo (263)	ENGINE MANAGEME	1.4 16v	BOSCH Motronic ME 7.9.10
 Doblo' Cargo (263)	ENGINE MANAGEME	1.4 16v	BOSCH Motronic ME7.9.10 CF4-EOBD
 Doblo' Cargo (263)	ENGINE MANAGEME	1.6 MJET 16v	BOSCH EDC16C39 CF5/EOBD
 Doblo' Cargo (263)	ENGINE MANAGEME	1.6 MJET 16v (09-..)	BOSCH EDC16C39 CF5/EOBD
 Doblo' Cargo (263)	ENGINE MANAGEME	2.0 MJET 16v	BOSCH EDC16C39 CF5/EOBD
 Doblo' Cargo (263)	ENGINE MANAGEME	2.0 MJET 16v (09-..)	BOSCH EDC16C39 CF5/EOBD
 Doblo' Cargo (263)	ENGINE MANAGEME	Natural Power	Marelli IAW 5SF8
 Doblo' Cargo (263)	MAINTENANCE	1.3 MJET 16v	Marelli Dashboard
 Doblo' Cargo (263)	MAINTENANCE	1.3 MJET 16v	Marelli Dashboard
 Doblo' Cargo (263)	MAINTENANCE	1.3 MJET 16v	Marelli Dashboard
 Doblo' Cargo (263)	MAINTENANCE	1.3 MJET 16v	Marelli Dashboard 3
 Doblo' Cargo (263)	MAINTENANCE	1.3 MJET 16v	Marelli Dashboard 3
 Doblo' Cargo (263)	MAINTENANCE	1.3 MJET 16v	Marelli EDC 8DF CF5
 Doblo' Cargo (263)	MAINTENANCE	1.3 MJET 16v	Marelli EDC 8DF CF5
 Doblo' Cargo (263)	MAINTENANCE	1.3 MJET 16v	Marelli EDC 8F3 CF5
 Doblo' Cargo (263)	MAINTENANCE	1.3 MJET 16v (05-09)	Marelli EDC 6F3 (D.P.F.)
 Doblo' Cargo (263)	MAINTENANCE	1.3 MJET 16v (05-09)	Marelli EDC 6F3 (D.P.F.)
 Doblo' Cargo (263)	MAINTENANCE	1.3 MJET 16v (05-09)	Marelli EDC 6F3 (D.P.F.)
 Doblo' Cargo (263)	MAINTENANCE	1.3 MJET 16v (05-09)	Marelli EDC 6F3 (D.P.F.)
 Doblo' Cargo (263)	MAINTENANCE	1.4 16v	Marelli Dashboard
 Doblo' Cargo (263)	MAINTENANCE	1.4 16v	Marelli Dashboard
 Doblo' Cargo (263)	MAINTENANCE	1.4 16v	Marelli Dashboard
 Doblo' Cargo (263)	MAINTENANCE	1.4 16v	Marelli Dashboard 3
 Doblo' Cargo (263)	MAINTENANCE	1.4 16v	Marelli Dashboard 3
 Doblo' Cargo (263)	MAINTENANCE	1.6 MJET 16v	BOSCH EDC16C39 CF5/EOBD
 Doblo' Cargo (263)	MAINTENANCE	1.6 MJET 16v	Marelli Dashboard
 Doblo' Cargo (263)	MAINTENANCE	1.6 MJET 16v	Marelli Dashboard
 Doblo' Cargo (263)	MAINTENANCE	1.6 MJET 16v	Marelli Dashboard
 Doblo' Cargo (263)	MAINTENANCE	1.6 MJET 16v	Marelli Dashboard 3
 Doblo' Cargo (263)	MAINTENANCE	1.6 MJET 16v	Marelli Dashboard 3
 Doblo' Cargo (263)	MAINTENANCE	1.6 MJET 16v (09-..)	BOSCH EDC16C39 CF5/EOBD
 Doblo' Cargo (263)	MAINTENANCE	2.0 MJET 16v	BOSCH EDC16C39 CF5/EOBD
 Doblo' Cargo (263)	MAINTENANCE	2.0 MJET 16v	Marelli Dashboard
 Doblo' Cargo (263)	MAINTENANCE	2.0 MJET 16v	Marelli Dashboard
 Doblo' Cargo (263)	MAINTENANCE	2.0 MJET 16v	Marelli Dashboard
 Doblo' Cargo (263)	MAINTENANCE	2.0 MJET 16v	Marelli Dashboard 3
 Doblo' Cargo (263)	MAINTENANCE	2.0 MJET 16v	Marelli Dashboard 3
 Doblo' Cargo (263)	MAINTENANCE	2.0 MJET 16v (09-..)	BOSCH EDC16C39 CF5/EOBD
 Doblo' Cargo (263)	MAINTENANCE	Natural Power	Marelli Dashboard
 Doblo' Cargo (263)	MAINTENANCE	Natural Power	Marelli Dashboard
 Doblo' Cargo (263)	MAINTENANCE	Natural Power	Marelli Dashboard
 Doblo' Cargo (263)	MAINTENANCE	Natural Power	Marelli Dashboard 3
 Doblo' Cargo (263)	MAINTENANCE	Natural Power	Marelli Dashboard 3
 Doblo' Cargo (263)	MAINTENANCE	Natural Power	Marelli IAW 5SF8
 Doblo' Cargo (263)	PARKING HELP	1.4 16v	
 Doblo' Cargo (263)	PARKING HELP	1.6 MJET 16v	
 Doblo' Cargo (263)	PARKING HELP	2.0 MJET 16v	
 Doblo' Cargo (263)	PARKING HELP	Natural Power	
 Doblo' Cargo (263)	SUPP HEATER/AUTO	1.3 MJET 16v	Denso
 Doblo' Cargo (263)	SUPP HEATER/AUTO	1.4 16v	Denso
 Doblo' Cargo (263)	SUPP HEATER/AUTO	1.6 MJET 16v	Denso
 Doblo' Cargo (263)	SUPP HEATER/AUTO	2.0 MJET 16v	Denso
 Doblo' Cargo (263)	SUPP HEATER/AUTO	Natural Power	Denso
 Doblo' Cargo (263)	VISUAL./TELEMATIC	1.3 MJET 16v	Lauberhorn Convergence
 Doblo' Cargo (263)	VISUAL./TELEMATIC	1.3 MJET 16v	Marelli Convergence

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Doblo' Cargo (263)	VISUAL./TELEMATIC	1.4 16v	Lauberhorn Convergence
 Doblo' Cargo (263)	VISUAL./TELEMATIC	1.4 16v	Marelli Convergence
 Doblo' Cargo (263)	VISUAL./TELEMATIC	1.6 MJET 16v	Lauberhorn Convergence
 Doblo' Cargo (263)	VISUAL./TELEMATIC	1.6 MJET 16v	Marelli Convergence
 Doblo' Cargo (263)	VISUAL./TELEMATIC	2.0 MJET 16v	Lauberhorn Convergence
 Doblo' Cargo (263)	VISUAL./TELEMATIC	2.0 MJET 16v	Marelli Convergence
 Doblo' Cargo (263)	VISUAL./TELEMATIC	Natural Power	Lauberhorn Convergence
 Doblo' Cargo (263)	VISUAL./TELEMATIC	Natural Power	Marelli Convergence
 Ducato (230)	ABS		BOSCH ABS 5.3
 Ducato (230)	AIRBAG		BREED AirBag + Pret.
 Ducato (230)	AIRBAG		BREED AirBag MY 97 (1F-2P)
 Ducato (244)	ABS	2.0 (98-05)	BOSCH ABS 5.3
 Ducato (244)	ABS	2.0 JTD (98-05)	BOSCH ABS 5.3
 Ducato (244)	ABS	2.3 JTD (98-05)	BOSCH ABS 5.3
 Ducato (244)	ABS	2.8 JTD (98-05)	BOSCH ABS 5.3
 Ducato (244)	ABS	Bipower-Gpower (98-05)	BOSCH ABS 5.3
 Ducato (244)	AIRBAG	2.0 (98-05)	SIEMENS AirBag MY 99 (1F-2P)
 Ducato (244)	AIRBAG	2.0 (98-05)	SIEMENS AirBag MY 99 (1F-3P)
 Ducato (244)	AIRBAG	2.0 (98-05)	SIEMENS AirBag MY 99 (2F-2P-2L-I)
 Ducato (244)	AIRBAG	2.0 (98-05)	SIEMENS AirBag MY 99 (2F-2P-I)
 Ducato (244)	AIRBAG	2.0 (98-05)	SIEMENS AirBag MY 99 (2F-3P-I)
 Ducato (244)	AIRBAG	2.0 JTD (98-05)	SIEMENS AirBag MY 99 (1F-2P)
 Ducato (244)	AIRBAG	2.0 JTD (98-05)	SIEMENS AirBag MY 99 (1F-3P)
 Ducato (244)	AIRBAG	2.0 JTD (98-05)	SIEMENS AirBag MY 99 (2F-2P-2L-I)
 Ducato (244)	AIRBAG	2.0 JTD (98-05)	SIEMENS AirBag MY 99 (2F-2P-I)
 Ducato (244)	AIRBAG	2.0 JTD (98-05)	SIEMENS AirBag MY 99 (2F-3P-I)
 Ducato (244)	AIRBAG	2.3 JTD (98-05)	SIEMENS AirBag MY 99 (1F-2P)
 Ducato (244)	AIRBAG	2.3 JTD (98-05)	SIEMENS AirBag MY 99 (1F-3P)
 Ducato (244)	AIRBAG	2.3 JTD (98-05)	SIEMENS AirBag MY 99 (2F-2P-2L-I)
 Ducato (244)	AIRBAG	2.3 JTD (98-05)	SIEMENS AirBag MY 99 (2F-2P-I)
 Ducato (244)	AIRBAG	2.3 JTD (98-05)	SIEMENS AirBag MY 99 (2F-3P-I)
 Ducato (244)	AIRBAG	2.8 JTD (98-05)	SIEMENS AirBag MY 99 (1F-2P)
 Ducato (244)	AIRBAG	2.8 JTD (98-05)	SIEMENS AirBag MY 99 (1F-3P)
 Ducato (244)	AIRBAG	2.8 JTD (98-05)	SIEMENS AirBag MY 99 (2F-2P-2L-I)
 Ducato (244)	AIRBAG	2.8 JTD (98-05)	SIEMENS AirBag MY 99 (2F-2P-I)
 Ducato (244)	AIRBAG	2.8 JTD (98-05)	SIEMENS AirBag MY 99 (2F-3P-I)
 Ducato (244)	AIRBAG	Bipower-Gpower (98-05)	SIEMENS AirBag MY 99 (1F-2P)
 Ducato (244)	AIRBAG	Bipower-Gpower (98-05)	SIEMENS AirBag MY 99 (1F-3P)
 Ducato (244)	AIRBAG	Bipower-Gpower (98-05)	SIEMENS AirBag MY 99 (2F-2P-2L-I)
 Ducato (244)	AIRBAG	Bipower-Gpower (98-05)	SIEMENS AirBag MY 99 (2F-2P-I)
 Ducato (244)	AIRBAG	Bipower-Gpower (98-05)	SIEMENS AirBag MY 99 (2F-3P-I)
 Ducato (244)	CENTRAL LOCKING	2.0 (98-05)	RF Bloccaporte/ricevitore VAS 97/3
 Ducato (244)	CENTRAL LOCKING	2.0 JTD (98-05)	RF Bloccaporte/ricevitore VAS 97/3
 Ducato (244)	CENTRAL LOCKING	2.3 JTD (98-05)	RF Bloccaporte/ricevitore VAS 97/3
 Ducato (244)	CENTRAL LOCKING	2.8 JTD (98-05)	RF Bloccaporte/ricevitore VAS 97/3
 Ducato (244)	CENTRAL LOCKING	Bipower-Gpower (98-05)	RF Bloccaporte/ricevitore VAS 97/3
 Ducato (244)	ENGINE MANAGEME	2.0 JTD (98-05)	BOSCH EDC 15 Common Rail (JTD '99)
 Ducato (244)	ENGINE MANAGEME	2.3 JTD (98-05)	BOSCH EDC 15 Common Rail (JTD '99)
 Ducato (244)	ENGINE MANAGEME	2.8 JTD (98-05)	BOSCH EDC 15 Common Rail (JTD '99)
 Ducato (244)	ENGINE MANAGEME	Bipower-Gpower (01-...)	EOBD
 Ducato (244)	IMMOBILIZER	2.0 (98-05)	DELPHI CODE 2
 Ducato (244)	IMMOBILIZER	2.0 JTD (98-05)	DELPHI CODE 2
 Ducato (244)	IMMOBILIZER	2.3 JTD (98-05)	DELPHI CODE 2
 Ducato (244)	IMMOBILIZER	2.8 JTD (98-05)	DELPHI CODE 2
 Ducato (244)	IMMOBILIZER	Bipower-Gpower (98-05)	DELPHI CODE 2
 Ducato (244)	MAINTENANCE	2.0 (03-05)	MANUAL
 Ducato (244)	MAINTENANCE	2.0 (98-02)	MANUAL
 Ducato (244)	MAINTENANCE	2.0 JTD (03-05)	MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Ducato (244)	MAINTENANCE	2.0 JTD (98-02)	MANUAL
 Ducato (244)	MAINTENANCE	2.3 JTD (03-05)	MANUAL
 Ducato (244)	MAINTENANCE	2.3 JTD (98-05)	MANUAL
 Ducato (244)	MAINTENANCE	2.8 JTD (03-05)	MANUAL
 Ducato (244)	MAINTENANCE	2.8 JTD (98-02)	MANUAL
 Ducato (244)	MAINTENANCE	Bipower-Gpower (03-05)	MANUAL
 Ducato (244)	MAINTENANCE	Bipower-Gpower (98-02)	MANUAL
 Ducato (244)	SERVICE LIGHT RES	2.0 (03-05)	MANUAL
 Ducato (244)	SERVICE LIGHT RES	2.0 (98-02)	MANUAL
 Ducato (244)	SERVICE LIGHT RES	2.0 JTD (03-05)	MANUAL
 Ducato (244)	SERVICE LIGHT RES	2.0 JTD (98-02)	MANUAL
 Ducato (244)	SERVICE LIGHT RES	2.3 JTD (03-05)	MANUAL
 Ducato (244)	SERVICE LIGHT RES	2.3 JTD (98-05)	MANUAL
 Ducato (244)	SERVICE LIGHT RES	2.8 JTD (03-05)	MANUAL
 Ducato (244)	SERVICE LIGHT RES	2.8 JTD (98-02)	MANUAL
 Ducato (244)	SERVICE LIGHT RES	Bipower-Gpower (03-05)	MANUAL
 Ducato (244)	SERVICE LIGHT RES	Bipower-Gpower (98-02)	MANUAL
 Ducato (250)	ABS	2.2 JTD (06-..)	BOSCH ABS 8
 Ducato (250)	ABS	2.3 JTD (06-..)	BOSCH ABS 8
 Ducato (250)	ABS	3.0 JTD (06-..)	BOSCH ABS 8
 Ducato (250)	AIRBAG	2.2 JTD (06-..)	TRW SRS 1
 Ducato (250)	AIRBAG	2.3 JTD (06-..)	TRW SRS 1
 Ducato (250)	AIRBAG	3.0 JTD (06-..)	TRW SRS 1
 Ducato (250)	AUTOM. TRANSMISSI	2.2 JTD (06-..)	Marelli Selespeed CFC348
 Ducato (250)	AUTOM. TRANSMISSI	2.3 JTD (06-..)	Marelli Selespeed CFC348
 Ducato (250)	AUTOM. TRANSMISSI	3.0 JTD (06-..)	Marelli Selespeed CFC348
 Ducato (250)	CHASSIS NETWORK	2.2 JTD (06-..)	Marelli Body Computer 6
 Ducato (250)	CHASSIS NETWORK	2.3 JTD (06-..)	Marelli Body Computer 6
 Ducato (250)	CHASSIS NETWORK	3.0 JTD (06-..)	Marelli Body Computer 6
 Ducato (250)	CHRONOTACHOGRA	2.2 JTD (06-..)	Actia
 Ducato (250)	CHRONOTACHOGRA	2.3 JTD (06-..)	Actia
 Ducato (250)	CHRONOTACHOGRA	3.0 JTD (06-..)	Actia
 Ducato (250)	CLIMA	2.2 JTD (06-..)	Denso Monozone 2
 Ducato (250)	CLIMA	2.3 JTD (06-..)	Denso Monozone 2
 Ducato (250)	CLIMA	3.0 JTD (06-..)	Denso Monozone 2
 Ducato (250)	DASHBOARD	2.2 JTD (06-..)	Marelli Dashboard
 Ducato (250)	DASHBOARD	2.3 JTD (06-..)	Marelli Dashboard
 Ducato (250)	DASHBOARD	3.0 JTD (06-..)	Marelli Dashboard
 Ducato (250)	ENGINE MANAGEME	2.2 JTD (06-..)	VISTEON PUMA AUTODETECT
 Ducato (250)	ENGINE MANAGEME	2.3 JTD (06-..)	BOSCH EDC 16 Common Rail
 Ducato (250)	ENGINE MANAGEME	3.0 JTD (06-..)	BOSCH EDC 16 Common Rail
 Ducato (250)	MAINTENANCE	2.2 JTD (06-..)	Marelli Dashboard
 Ducato (250)	MAINTENANCE	2.2 JTD (06-..)	Marelli Dashboard
 Ducato (250)	MAINTENANCE	2.2 JTD (06-..)	Marelli Dashboard
 Ducato (250)	MAINTENANCE	2.2 JTD (06-..)	Marelli Dashboard
 Ducato (250)	MAINTENANCE	2.2 JTD (06-..)	VISTEON PUMA AUTODETECT
 Ducato (250)	MAINTENANCE	2.3 JTD (06-..)	BOSCH EDC 16 Common Rail
 Ducato (250)	MAINTENANCE	2.3 JTD (06-..)	Marelli Dashboard
 Ducato (250)	MAINTENANCE	2.3 JTD (06-..)	Marelli Dashboard
 Ducato (250)	MAINTENANCE	2.3 JTD (06-..)	Marelli Dashboard
 Ducato (250)	MAINTENANCE	2.3 JTD (06-..)	Marelli Dashboard
 Ducato (250)	MAINTENANCE	2.3 JTD (06-..)	Marelli Dashboard
 Ducato (250)	MAINTENANCE	3.0 JTD (06-..)	BOSCH EDC 16 Common Rail
 Ducato (250)	MAINTENANCE	3.0 JTD (06-..)	Marelli Dashboard
 Ducato (250)	MAINTENANCE	3.0 JTD (06-..)	Marelli Dashboard
 Ducato (250)	MAINTENANCE	3.0 JTD (06-..)	Marelli Dashboard
 Ducato (250)	MAINTENANCE	3.0 JTD (06-..)	Marelli Dashboard
 Ducato (250)	MAINTENANCE	3.0 JTD (06-..)	Marelli Dashboard
 Ducato (250)	PARKING HELP	2.2 JTD (06-..)	Bosch
 Ducato (250)	PARKING HELP	2.3 JTD (06-..)	Bosch

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Ducato (250)	PARKING HELP	3.0 JTD (06-..)	Bosch
 Ducato (250)	SERVICE LIGHT RES	2.2 JTD (06-..)	Marelli Dashboard
 Ducato (250)	SERVICE LIGHT RES	2.3 JTD (06-..)	Marelli Dashboard
 Ducato (250)	SERVICE LIGHT RES	3.0 JTD (06-..)	Marelli Dashboard
 Ducato (250)	VISUAL./TELEMATIC	2.2 JTD (06-..)	Marelli Connect 3
 Ducato (250)	VISUAL./TELEMATIC	2.2 JTD (06-..)	Marelli/Microsoft
 Ducato (250)	VISUAL./TELEMATIC	2.3 JTD (06-..)	Marelli Connect 3
 Ducato (250)	VISUAL./TELEMATIC	2.3 JTD (06-..)	Marelli/Microsoft
 Ducato (250)	VISUAL./TELEMATIC	3.0 JTD (06-..)	Marelli Connect 3
 Ducato (250)	VISUAL./TELEMATIC	3.0 JTD (06-..)	Marelli/Microsoft
 Fiorino (225)	ABS + TRACT. CONT	1.3 Multijet 16v 95cv (08-..)	ABS BOSCH 8.1 AUTODETECT
 Fiorino (225)	ABS + TRACT. CONT	1.3 Multijet 16v 95cv (08-..)	BOSCH ESP 8
 Fiorino (225)	ABS + TRACT. CONT	1.3 Multijet 75cv (08-..)	ABS BOSCH 8.1 AUTODETECT
 Fiorino (225)	ABS + TRACT. CONT	1.3 Multijet 75cv (08-..)	BOSCH ESP 8
 Fiorino (225)	ABS + TRACT. CONT	1.4 8v (08-..)	ABS BOSCH 8.1 AUTODETECT
 Fiorino (225)	ABS + TRACT. CONT	1.4 8v (08-..)	BOSCH ESP 8
 Fiorino (225)	ABS + TRACT. CONT	1.4 8v Natural Power (08-..)	ABS BOSCH 8.1 AUTODETECT
 Fiorino (225)	ABS + TRACT. CONT	1.4 8v Natural Power (08-..)	BOSCH ESP 8
 Fiorino (225)	AIRBAG	1.3 Multijet 16v 95cv (08-..)	AUTOLIV AirBag CENTRAL AUTODETECT
 Fiorino (225)	AIRBAG	1.3 Multijet 16v 95cv (08-..)	TRW SRS EP
 Fiorino (225)	AIRBAG	1.3 Multijet 75cv (08-..)	AUTOLIV AirBag CENTRAL AUTODETECT
 Fiorino (225)	AIRBAG	1.3 Multijet 75cv (08-..)	TRW SRS EP
 Fiorino (225)	AIRBAG	1.4 8v (08-..)	AUTOLIV AirBag CENTRAL AUTODETECT
 Fiorino (225)	AIRBAG	1.4 8v (08-..)	TRW SRS EP
 Fiorino (225)	AIRBAG	1.4 8v Natural Power (08-..)	AUTOLIV AirBag CENTRAL AUTODETECT
 Fiorino (225)	AIRBAG	1.4 8v Natural Power (08-..)	TRW SRS EP
 Fiorino (225)	AUTOM. TRANSMISSI	1.3 Multijet 16v 95cv (08-..)	Marelli Selespeed CFC300 (EP)
 Fiorino (225)	AUTOM. TRANSMISSI	1.3 Multijet 75cv (08-..)	Marelli Selespeed CFC300 (EP)
 Fiorino (225)	AUTOM. TRANSMISSI	1.4 8v (08-..)	Marelli Selespeed CFC300 (EP)
 Fiorino (225)	AUTOM. TRANSMISSI	1.4 8v Natural Power (08-..)	Marelli Selespeed CFC300 (EP)
 Fiorino (225)	CHASSIS NETWORK	1.3 Multijet 16v 95cv (08-..)	Body Computer BSI AUTODETECT
 Fiorino (225)	CHASSIS NETWORK	1.3 Multijet 16v 95cv (08-..)	DELPHI Body Computer
 Fiorino (225)	CHASSIS NETWORK	1.3 Multijet 16v 95cv (08-..)	DELPHI Body Computer CAN Info
 Fiorino (225)	CHASSIS NETWORK	1.3 Multijet 16v 95cv (08-..)	DELPHI Body Computer Proxi Alignement
 Fiorino (225)	CHASSIS NETWORK	1.3 Multijet 16v 95cv (08-..)	DELPHI EP
 Fiorino (225)	CHASSIS NETWORK	1.3 Multijet 75cv (08-..)	Body Computer BSI AUTODETECT
 Fiorino (225)	CHASSIS NETWORK	1.3 Multijet 75cv (08-..)	DELPHI Body Computer
 Fiorino (225)	CHASSIS NETWORK	1.3 Multijet 75cv (08-..)	DELPHI Body Computer CAN Info
 Fiorino (225)	CHASSIS NETWORK	1.3 Multijet 75cv (08-..)	DELPHI Body Computer Proxi Alignement
 Fiorino (225)	CHASSIS NETWORK	1.3 Multijet 75cv (08-..)	DELPHI EP
 Fiorino (225)	CHASSIS NETWORK	1.4 8v (08-..)	Body Computer BSI AUTODETECT
 Fiorino (225)	CHASSIS NETWORK	1.4 8v (08-..)	DELPHI Body Computer
 Fiorino (225)	CHASSIS NETWORK	1.4 8v (08-..)	DELPHI Body Computer CAN Info
 Fiorino (225)	CHASSIS NETWORK	1.4 8v (08-..)	DELPHI Body Computer Proxi Alignement
 Fiorino (225)	CHASSIS NETWORK	1.4 8v (08-..)	DELPHI EP
 Fiorino (225)	CHASSIS NETWORK	1.4 8v Natural Power (08-..)	Body Computer BSI AUTODETECT
 Fiorino (225)	CHASSIS NETWORK	1.4 8v Natural Power (08-..)	DELPHI Body Computer
 Fiorino (225)	CHASSIS NETWORK	1.4 8v Natural Power (08-..)	DELPHI Body Computer CAN Info
 Fiorino (225)	CHASSIS NETWORK	1.4 8v Natural Power (08-..)	DELPHI Body Computer Proxi Alignement
 Fiorino (225)	CHASSIS NETWORK	1.4 8v Natural Power (08-..)	DELPHI EP
 Fiorino (225)	DASHBOARD	1.3 Multijet 16v 95cv (08-..)	AUTODETECT
 Fiorino (225)	DASHBOARD	1.3 Multijet 16v 95cv (08-..)	Marelli Dashboard Comfort
 Fiorino (225)	DASHBOARD	1.3 Multijet 16v 95cv (08-..)	Marelli Dashboard Modale
 Fiorino (225)	DASHBOARD	1.3 Multijet 75cv (08-..)	AUTODETECT
 Fiorino (225)	DASHBOARD	1.3 Multijet 75cv (08-..)	Marelli Dashboard Comfort
 Fiorino (225)	DASHBOARD	1.3 Multijet 75cv (08-..)	Marelli Dashboard Modale
 Fiorino (225)	DASHBOARD	1.4 8v (08-..)	AUTODETECT
 Fiorino (225)	DASHBOARD	1.4 8v (08-..)	Marelli Dashboard Comfort

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Fiorino (225)	DASHBOARD	1.4 8v (08-..)	Marelli Dashboard Modale
 Fiorino (225)	DASHBOARD	1.4 8v Natural Power (08-..)	AUTODETECT
 Fiorino (225)	DASHBOARD	1.4 8v Natural Power (08-..)	Marelli Dashboard Comfort
 Fiorino (225)	DASHBOARD	1.4 8v Natural Power (08-..)	Marelli Dashboard Modale
 Fiorino (225)	ENGINE MANAGEME	1.3 Multijet 16v 95cv (09-..)	Marelli EDC 6F3 (D.P.F.)
 Fiorino (225)	ENGINE MANAGEME	1.3 Multijet 16v 95cv (09-..)	Marelli EDC 8F3 CF5
 Fiorino (225)	ENGINE MANAGEME	1.3 Multijet 75cv (08-..)	AUTODETECT
 Fiorino (225)	ENGINE MANAGEME	1.3 Multijet 75cv (08-..)	Marelli EDC 6F3
 Fiorino (225)	ENGINE MANAGEME	1.3 Multijet 75cv (08-..)	Marelli EDC 8F3 CF5
 Fiorino (225)	ENGINE MANAGEME	1.4 8v (08-..)	AUTODETECT
 Fiorino (225)	ENGINE MANAGEME	1.4 8v (08-..)	EOBD
 Fiorino (225)	ENGINE MANAGEME	1.4 8v Natural Power (08-..)	EOBD
 Fiorino (225)	FAP OIL PARAMETER	1.3 Multijet 75cv (08-..)	Marelli
 Fiorino (225)	MAINTENANCE	1.3 Multijet 16v 95cv (08-..)	BOSCH ESP 8
 Fiorino (225)	MAINTENANCE	1.3 Multijet 16v 95cv (08-..)	Marelli Dashboard
 Fiorino (225)	MAINTENANCE	1.3 Multijet 16v 95cv (08-..)	Marelli Dashboard Comfort
 Fiorino (225)	MAINTENANCE	1.3 Multijet 16v 95cv (08-..)	Marelli Dashboard Comfort
 Fiorino (225)	MAINTENANCE	1.3 Multijet 16v 95cv (08-..)	Marelli Dashboard Modale
 Fiorino (225)	MAINTENANCE	1.3 Multijet 16v 95cv (08-..)	Marelli Dashboard Modale
 Fiorino (225)	MAINTENANCE	1.3 Multijet 16v 95cv (09-..)	Marelli Dashboard
 Fiorino (225)	MAINTENANCE	1.3 Multijet 16v 95cv (09-..)	Marelli EDC 6F3 (D.P.F.)
 Fiorino (225)	MAINTENANCE	1.3 Multijet 16v 95cv (09-..)	Marelli EDC 6F3 (D.P.F.)
 Fiorino (225)	MAINTENANCE	1.3 Multijet 16v 95cv (09-..)	Marelli EDC 6F3 (D.P.F.)
 Fiorino (225)	MAINTENANCE	1.3 Multijet 16v 95cv (09-..)	Marelli EDC 6F3 (D.P.F.)
 Fiorino (225)	MAINTENANCE	1.3 Multijet 16v 95cv (09-..)	Marelli EDC 8F3 CF5
 Fiorino (225)	MAINTENANCE	1.3 Multijet 16v 95cv (09-..)	Marelli EDC 8F3 CF5
 Fiorino (225)	MAINTENANCE	1.3 Multijet 75cv (08-..)	BOSCH ESP 8
 Fiorino (225)	MAINTENANCE	1.3 Multijet 75cv (08-..)	Marelli
 Fiorino (225)	MAINTENANCE	1.3 Multijet 75cv (08-..)	Marelli Dashboard
 Fiorino (225)	MAINTENANCE	1.3 Multijet 75cv (08-..)	Marelli Dashboard Comfort
 Fiorino (225)	MAINTENANCE	1.3 Multijet 75cv (08-..)	Marelli Dashboard Comfort
 Fiorino (225)	MAINTENANCE	1.3 Multijet 75cv (08-..)	Marelli Dashboard Comfort
 Fiorino (225)	MAINTENANCE	1.3 Multijet 75cv (08-..)	Marelli Dashboard Modale
 Fiorino (225)	MAINTENANCE	1.3 Multijet 75cv (08-..)	Marelli Dashboard Modale
 Fiorino (225)	MAINTENANCE	1.3 Multijet 75cv (08-..)	Marelli EDC 6F3
 Fiorino (225)	MAINTENANCE	1.3 Multijet 75cv (08-..)	Marelli EDC 8F3 CF5
 Fiorino (225)	MAINTENANCE	1.3 Multijet 75cv (08-..)	Marelli EDC 8F3 CF5
 Fiorino (225)	MAINTENANCE	1.3 Multijet 75cv (09-..)	Marelli Dashboard
 Fiorino (225)	MAINTENANCE	1.4 8v (08-..)	BOSCH ESP 8
 Fiorino (225)	MAINTENANCE	1.4 8v (08-..)	Marelli Dashboard
 Fiorino (225)	MAINTENANCE	1.4 8v (08-..)	Marelli Dashboard Comfort
 Fiorino (225)	MAINTENANCE	1.4 8v (08-..)	Marelli Dashboard Comfort
 Fiorino (225)	MAINTENANCE	1.4 8v (08-..)	Marelli Dashboard Comfort
 Fiorino (225)	MAINTENANCE	1.4 8v (08-..)	Marelli Dashboard Modale
 Fiorino (225)	MAINTENANCE	1.4 8v (08-..)	Marelli Dashboard Modale
 Fiorino (225)	MAINTENANCE	1.4 8v (09-..)	Marelli Dashboard
 Fiorino (225)	MAINTENANCE	1.4 8v Natural Power (08-..)	BOSCH ESP 8
 Fiorino (225)	MAINTENANCE	1.4 8v Natural Power (08-..)	Marelli Dashboard
 Fiorino (225)	MAINTENANCE	1.4 8v Natural Power (08-..)	Marelli Dashboard Comfort
 Fiorino (225)	MAINTENANCE	1.4 8v Natural Power (08-..)	Marelli Dashboard Comfort
 Fiorino (225)	MAINTENANCE	1.4 8v Natural Power (08-..)	Marelli Dashboard Comfort
 Fiorino (225)	MAINTENANCE	1.4 8v Natural Power (08-..)	Marelli Dashboard Modale
 Fiorino (225)	MAINTENANCE	1.4 8v Natural Power (09-..)	Marelli Dashboard Modale
 Fiorino (225)	PARKING HELP	1.3 Multijet 16v 95cv (08-..)	AUTODETECT
 Fiorino (225)	PARKING HELP	1.3 Multijet 75cv (08-..)	AUTODETECT
 Fiorino (225)	PARKING HELP	1.4 8v (08-..)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Fiorino (225)	PARKING HELP	1.4 8v Natural Power (08-..)	AUTODETECT
 Fiorino (225)	SERVICE LIGHT RES	1.3 Multijet 16v 95cv (08-..)	Marelli Dashboard
 Fiorino (225)	SERVICE LIGHT RES	1.3 Multijet 16v 95cv (09-..)	Marelli Dashboard
 Fiorino (225)	SERVICE LIGHT RES	1.3 Multijet 75cv (08-..)	Marelli Dashboard
 Fiorino (225)	SERVICE LIGHT RES	1.3 Multijet 75cv (09-..)	Marelli Dashboard
 Fiorino (225)	SERVICE LIGHT RES	1.4 8v (08-..)	Marelli Dashboard
 Fiorino (225)	SERVICE LIGHT RES	1.4 8v (09-..)	Marelli Dashboard
 Fiorino (225)	SERVICE LIGHT RES	1.4 8v Natural Power (08-..)	Marelli Dashboard
 Fiorino (225)	SERVICE LIGHT RES	1.4 8v Natural Power (09-..)	Marelli Dashboard
 Fiorino (225)	VISUAL./TELEMATIC	1.3 Multijet 16v 95cv (08-..)	Marelli Convergence
 Fiorino (225)	VISUAL./TELEMATIC	1.3 Multijet 75cv (08-..)	Marelli Convergence
 Fiorino (225)	VISUAL./TELEMATIC	1.4 8v (08-..)	Marelli Convergence
 Fiorino (225)	VISUAL./TELEMATIC	1.4 8v Natural Power (08-..)	Marelli Convergence
 Fiorino (255)	ELECTRONIC INJECT	1.5 AT Kat	BOSCH MonoJetronic A2.2
 Fiorino (255)	ELECTRONIC INJECT	1.5 Kat	BOSCH MonoJetronic A2.2
 Fiorino (255)	ENGINE MANAGEME	1.6 Kat	BOSCH MonoMotronic MA1.7
 Idea	ABS	1.2 16v (.-03)	BOSCH ABS 8
 Idea	ABS	1.3 Multijet (.-03)	BOSCH ABS 8
 Idea	ABS	1.3 Multijet FAP (.-03)	BOSCH ABS 8
 Idea	ABS	1.4 16v (.-03)	BOSCH ABS 8
 Idea	ABS	1.4 8v (.-03)	BOSCH ABS 8
 Idea	ABS	1.6 MJET 16v (.-03)	BOSCH ABS 8
 Idea	ABS	1.9 JTD (.-03)	BOSCH ABS 8
 Idea	AIRBAG	1.2 16v	TRW AirBag MY 03 (2F-2P-2L-2T-I)
 Idea	AIRBAG	1.2 16v	TRW AirBag MY 03 (2F-2P-2T-I)
 Idea	AIRBAG	1.2 16v	TRW AirBag MY 03 (2F-2P-I)
 Idea	AIRBAG	1.3 Multijet	TRW AirBag MY 03 (2F-2P-2L-2T-I)
 Idea	AIRBAG	1.3 Multijet	TRW AirBag MY 03 (2F-2P-2T-I)
 Idea	AIRBAG	1.3 Multijet	TRW AirBag MY 03 (2F-2P-I)
 Idea	AIRBAG	1.3 Multijet FAP	TRW AirBag MY 03 (2F-2P-2L-2T-I)
 Idea	AIRBAG	1.3 Multijet FAP	TRW AirBag MY 03 (2F-2P-2T-I)
 Idea	AIRBAG	1.3 Multijet FAP	TRW AirBag MY 03 (2F-2P-I)
 Idea	AIRBAG	1.4 16v	TRW AirBag MY 03 (2F-2P-2L-2T-I)
 Idea	AIRBAG	1.4 16v	TRW AirBag MY 03 (2F-2P-2T-I)
 Idea	AIRBAG	1.4 16v	TRW AirBag MY 03 (2F-2P-I)
 Idea	AIRBAG	1.4 8v	TRW AirBag MY 03 (2F-2P-2L-2T-I)
 Idea	AIRBAG	1.4 8v	TRW AirBag MY 03 (2F-2P-2T-I)
 Idea	AIRBAG	1.4 8v	TRW AirBag MY 03 (2F-2P-I)
 Idea	AIRBAG	1.6 MJET 16v	TRW AirBag MY 03 (2F-2P-2L-2T-I)
 Idea	AIRBAG	1.6 MJET 16v	TRW AirBag MY 03 (2F-2P-2T-I)
 Idea	AIRBAG	1.6 MJET 16v	TRW AirBag MY 03 (2F-2P-I)
 Idea	AIRBAG	1.9 JTD	TRW AirBag MY 03 (2F-2P-2L-2T-I)
 Idea	AIRBAG	1.9 JTD	TRW AirBag MY 03 (2F-2P-2T-I)
 Idea	AIRBAG	1.9 JTD	TRW AirBag MY 03 (2F-2P-I)
 Idea	AUTOM. TRANSMISSI	1.2 16v	Marelli Selespeed CFC208F
 Idea	AUTOM. TRANSMISSI	1.2 16v	Marelli Selespeed CFC228F
 Idea	AUTOM. TRANSMISSI	1.3 Multijet	Marelli Selespeed CFC208F
 Idea	AUTOM. TRANSMISSI	1.3 Multijet	Marelli Selespeed CFC228F
 Idea	AUTOM. TRANSMISSI	1.3 Multijet FAP	Marelli Selespeed CFC208F
 Idea	AUTOM. TRANSMISSI	1.3 Multijet FAP	Marelli Selespeed CFC228F
 Idea	AUTOM. TRANSMISSI	1.4 16v	Marelli Selespeed CFC208F
 Idea	AUTOM. TRANSMISSI	1.4 16v	Marelli Selespeed CFC208F
 Idea	AUTOM. TRANSMISSI	1.4 16v	Marelli Selespeed CFC228F
 Idea	AUTOM. TRANSMISSI	1.4 8v	Marelli Selespeed CFC228F
 Idea	AUTOM. TRANSMISSI	1.6 MJET 16v	Marelli Selespeed CFC208F
 Idea	AUTOM. TRANSMISSI	1.6 MJET 16v	Marelli Selespeed CFC228F
 Idea	AUTOM. TRANSMISSI	1.6 MJET 16v (07-..)	Marelli Selespeed CFC208F
 Idea	AUTOM. TRANSMISSI	1.6 MJET 16v (07-..)	Marelli Selespeed CFC228F

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Idea	AUTOM. TRANSMISSI	1.9 JTD	Marelli Selespeed CFC208F
 Idea	AUTOM. TRANSMISSI	1.9 JTD	Marelli Selespeed CFC228F
 Idea	CLIMA	1.2 16v	DENSO CLIMA Bizone
 Idea	CLIMA	1.3 Multijet	DENSO CLIMA Bizone
 Idea	CLIMA	1.3 Multijet FAP	DENSO CLIMA Bizone
 Idea	CLIMA	1.4 16v	DENSO CLIMA Bizone
 Idea	CLIMA	1.4 8v	DENSO CLIMA Bizone
 Idea	CLIMA	1.6 MJET 16v	DENSO CLIMA Bizone
 Idea	CLIMA	1.6 MJET 16v (07-..)	DENSO CLIMA Bizone
 Idea	CLIMA	1.9 JTD	DENSO CLIMA Bizone
 Idea	DASHBOARD	1.2 16v	Marelli Dashboard Comfort
 Idea	DASHBOARD	1.2 16v	Marelli Dashboard Modale
 Idea	DASHBOARD	1.3 Multijet	Marelli Dashboard Comfort
 Idea	DASHBOARD	1.3 Multijet	Marelli Dashboard Modale
 Idea	DASHBOARD	1.3 Multijet FAP	Marelli Dashboard Comfort
 Idea	DASHBOARD	1.3 Multijet FAP	Marelli Dashboard Modale
 Idea	DASHBOARD	1.4 16v	Marelli Dashboard Comfort
 Idea	DASHBOARD	1.4 16v	Marelli Dashboard Modale
 Idea	DASHBOARD	1.4 8v	Marelli Dashboard Comfort
 Idea	DASHBOARD	1.4 8v	Marelli Dashboard Modale
 Idea	DASHBOARD	1.6 MJET 16v	Marelli Dashboard Comfort
 Idea	DASHBOARD	1.6 MJET 16v	Marelli Dashboard Modale
 Idea	DASHBOARD	1.9 JTD	Marelli Dashboard Comfort
 Idea	DASHBOARD	1.9 JTD	Marelli Dashboard Modale
 Idea	DRIVER SIDE DOOR	1.2 16v	BITRON DRIVER DOOR
 Idea	DRIVER SIDE DOOR	1.2 16v	G.E. PROCOND DRIVER DOOR
 Idea	DRIVER SIDE DOOR	1.2 16v (07-..)	G.E. PROCOND
 Idea	DRIVER SIDE DOOR	1.3 Multijet	BITRON DRIVER DOOR
 Idea	DRIVER SIDE DOOR	1.3 Multijet	G.E. PROCOND DRIVER DOOR
 Idea	DRIVER SIDE DOOR	1.3 Multijet (07-..)	G.E. PROCOND
 Idea	DRIVER SIDE DOOR	1.3 Multijet FAP	BITRON DRIVER DOOR
 Idea	DRIVER SIDE DOOR	1.3 Multijet FAP	G.E. PROCOND DRIVER DOOR
 Idea	DRIVER SIDE DOOR	1.3 Multijet FAP (07-..)	G.E. PROCOND
 Idea	DRIVER SIDE DOOR	1.4 16v	BITRON DRIVER DOOR
 Idea	DRIVER SIDE DOOR	1.4 16v	G.E. PROCOND DRIVER DOOR
 Idea	DRIVER SIDE DOOR	1.4 16v (07-..)	G.E. PROCOND
 Idea	DRIVER SIDE DOOR	1.4 8v	BITRON DRIVER DOOR
 Idea	DRIVER SIDE DOOR	1.4 8v	G.E. PROCOND DRIVER DOOR
 Idea	DRIVER SIDE DOOR	1.4 8v (07-..)	G.E. PROCOND
 Idea	DRIVER SIDE DOOR	1.6 MJET 16v	BITRON DRIVER DOOR
 Idea	DRIVER SIDE DOOR	1.6 MJET 16v	G.E. PROCOND DRIVER DOOR
 Idea	DRIVER SIDE DOOR	1.6 MJET 16v (07-..)	G.E. PROCOND
 Idea	DRIVER SIDE DOOR	1.9 JTD	BITRON DRIVER DOOR
 Idea	DRIVER SIDE DOOR	1.9 JTD	G.E. PROCOND DRIVER DOOR
 Idea	DRIVER SIDE DOOR	1.9 JTD (07-..)	G.E. PROCOND
 Idea	ELECTRIC STEERING	1.2 16v	TRW EPS
 Idea	ELECTRIC STEERING	1.3 Multijet	TRW EPS
 Idea	ELECTRIC STEERING	1.3 Multijet FAP	TRW EPS
 Idea	ELECTRIC STEERING	1.4 16v	TRW EPS
 Idea	ELECTRIC STEERING	1.4 8v	TRW EPS
 Idea	ELECTRIC STEERING	1.6 MJET 16v	TRW EPS
 Idea	ELECTRIC STEERING	1.9 JTD	TRW EPS
 Idea	ENGINE MANAGEME	1.2 16v	BOSCH Motronic ME7.3H4M EOBD
 Idea	ENGINE MANAGEME	1.3 Multijet	Marelli 6JF CF3 Common Rail
 Idea	ENGINE MANAGEME	1.3 Multijet	Marelli 8DF CF5
 Idea	ENGINE MANAGEME	1.3 Multijet FAP	Marelli 6F3 CF3 Common Rail
 Idea	ENGINE MANAGEME	1.4 16v	BOSCH Motronic ME7.3H4M EOBD
 Idea	ENGINE MANAGEME	1.4 8v	EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Idea	ENGINE MANAGEME	1.6 MJET 16v	Marelli 6JF CF3 Common Rail
 Idea	ENGINE MANAGEME	1.6 MJET 16v (07-..)	BOSCH EDC 16C39 CF5/EOBD
 Idea	ENGINE MANAGEME	1.9 JTD	BOSCH EDC 16 C9 Common Rail M-Jet
 Idea	HATCHBACK DOOR E	1.2 16v	G.E. PROCOND
 Idea	HATCHBACK DOOR E	1.3 Multijet	G.E. PROCOND
 Idea	HATCHBACK DOOR E	1.4 16v	G.E. PROCOND
 Idea	HATCHBACK DOOR E	1.4 8v	G.E. PROCOND
 Idea	HATCHBACK DOOR E	1.6 MJET 16v	G.E. PROCOND
 Idea	HATCHBACK DOOR E	1.9 JTD	G.E. PROCOND
 Idea	KEY ENCODE	1.2 16v	Marelli CODE Body Computer
 Idea	KEY ENCODE	1.3 Multijet	Marelli CODE Body Computer
 Idea	KEY ENCODE	1.4 16v	Marelli CODE Body Computer
 Idea	KEY ENCODE	1.4 8v	Marelli CODE Body Computer
 Idea	KEY ENCODE	1.6 MJET 16v	Marelli CODE Body Computer
 Idea	KEY ENCODE	1.9 JTD	Marelli CODE Body Computer
 Idea	MAINTENANCE	1.2 16v	Marelli
 Idea	MAINTENANCE	1.2 16v	Marelli Dashboard Comfort
 Idea	MAINTENANCE	1.2 16v	Marelli Dashboard Comfort
 Idea	MAINTENANCE	1.2 16v	Marelli Dashboard Modale
 Idea	MAINTENANCE	1.2 16v	Marelli Selespeed CFC208F
 Idea	MAINTENANCE	1.2 16v	Marelli Selespeed CFC208F
 Idea	MAINTENANCE	1.2 16v	Marelli Selespeed CFC228F
 Idea	MAINTENANCE	1.3 Multijet	Marelli
 Idea	MAINTENANCE	1.3 Multijet	Marelli Dashboard Comfort
 Idea	MAINTENANCE	1.3 Multijet	Marelli Dashboard Comfort
 Idea	MAINTENANCE	1.3 Multijet	Marelli Dashboard Modale
 Idea	MAINTENANCE	1.3 Multijet	Marelli Selespeed CFC208F
 Idea	MAINTENANCE	1.3 Multijet	Marelli Selespeed CFC208F
 Idea	MAINTENANCE	1.3 Multijet	Marelli Selespeed CFC228F
 Idea	MAINTENANCE	1.3 Multijet FAP	Marelli
 Idea	MAINTENANCE	1.3 Multijet FAP	Marelli 6F3 CF3 Common Rail
 Idea	MAINTENANCE	1.3 Multijet FAP	Marelli 6F3 CF3 Common Rail
 Idea	MAINTENANCE	1.3 Multijet FAP	Marelli 6F3 CF3 Common Rail
 Idea	MAINTENANCE	1.3 Multijet FAP	Marelli 6F3 CF3 Common Rail
 Idea	MAINTENANCE	1.3 Multijet FAP	Marelli Dashboard Comfort
 Idea	MAINTENANCE	1.3 Multijet FAP	Marelli Dashboard Comfort
 Idea	MAINTENANCE	1.3 Multijet FAP	Marelli Dashboard Modale
 Idea	MAINTENANCE	1.3 Multijet FAP	Marelli Selespeed CFC208F
 Idea	MAINTENANCE	1.3 Multijet FAP	Marelli Selespeed CFC208F
 Idea	MAINTENANCE	1.3 Multijet FAP	Marelli Selespeed CFC228F
 Idea	MAINTENANCE	1.4 16v	Marelli
 Idea	MAINTENANCE	1.4 16v	Marelli Dashboard Comfort
 Idea	MAINTENANCE	1.4 16v	Marelli Dashboard Comfort
 Idea	MAINTENANCE	1.4 16v	Marelli Dashboard Modale
 Idea	MAINTENANCE	1.4 16v	Marelli Selespeed CFC208F
 Idea	MAINTENANCE	1.4 16v	Marelli Selespeed CFC208F
 Idea	MAINTENANCE	1.4 16v	Marelli Selespeed CFC228F
 Idea	MAINTENANCE	1.4 8v	Marelli
 Idea	MAINTENANCE	1.4 8v	Marelli Dashboard Comfort
 Idea	MAINTENANCE	1.4 8v	Marelli Dashboard Comfort
 Idea	MAINTENANCE	1.4 8v	Marelli Dashboard Modale
 Idea	MAINTENANCE	1.4 8v	Marelli Selespeed CFC228F
 Idea	MAINTENANCE	1.6 MJET 16v	Marelli
 Idea	MAINTENANCE	1.6 MJET 16v	Marelli Dashboard Comfort
 Idea	MAINTENANCE	1.6 MJET 16v	Marelli Dashboard Comfort
 Idea	MAINTENANCE	1.6 MJET 16v	Marelli Dashboard Modale
 Idea	MAINTENANCE	1.6 MJET 16v	Marelli Selespeed CFC208F
 Idea	MAINTENANCE	1.6 MJET 16v	Marelli Selespeed CFC208F

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Idea	MAINTENANCE	1.6 MJET 16v	Marelli Selespeed CFC228F
 Idea	MAINTENANCE	1.6 MJET 16v (07-..)	BOSCH EDC 16C39 CF5/EOBD
 Idea	MAINTENANCE	1.6 MJET 16v (07-..)	BOSCH EDC 16C39 CF5/EOBD
 Idea	MAINTENANCE	1.6 MJET 16v (07-..)	Marelli Selespeed CFC208F
 Idea	MAINTENANCE	1.6 MJET 16v (07-..)	Marelli Selespeed CFC208F
 Idea	MAINTENANCE	1.6 MJET 16v (07-..)	Marelli Selespeed CFC228F
 Idea	MAINTENANCE	1.9 JTD	Marelli
 Idea	MAINTENANCE	1.9 JTD	Marelli Dashboard Comfort
 Idea	MAINTENANCE	1.9 JTD	Marelli Dashboard Comfort
 Idea	MAINTENANCE	1.9 JTD	Marelli Dashboard Modale
 Idea	MAINTENANCE	1.9 JTD	Marelli Selespeed CFC208F
 Idea	MAINTENANCE	1.9 JTD	Marelli Selespeed CFC208F
 Idea	MAINTENANCE	1.9 JTD	Marelli Selespeed CFC228F
 Idea	PARKING HELP	1.2 16v	Valeo
 Idea	PARKING HELP	1.3 Multijet	Valeo
 Idea	PARKING HELP	1.3 Multijet FAP	Valeo
 Idea	PARKING HELP	1.4 16v	Valeo
 Idea	PARKING HELP	1.4 8v	Valeo
 Idea	PARKING HELP	1.6 MJET 16v	Valeo
 Idea	PARKING HELP	1.9 JTD	Valeo
 Idea	PASS. SIDE DOOR	1.2 16v	G.E. PROCOND
 Idea	PASS. SIDE DOOR	1.3 Multijet	G.E. PROCOND
 Idea	PASS. SIDE DOOR	1.3 Multijet FAP	G.E. PROCOND
 Idea	PASS. SIDE DOOR	1.4 16v	G.E. PROCOND
 Idea	PASS. SIDE DOOR	1.4 8v	G.E. PROCOND
 Idea	PASS. SIDE DOOR	1.6 MJET 16v	G.E. PROCOND
 Idea	PASS. SIDE DOOR	1.9 JTD	G.E. PROCOND
 Idea	SERVICE LIGHT RES	1.2 16v	Marelli
 Idea	SERVICE LIGHT RES	1.3 Multijet	Marelli
 Idea	SERVICE LIGHT RES	1.3 Multijet FAP	Marelli
 Idea	SERVICE LIGHT RES	1.4 16v	Marelli
 Idea	SERVICE LIGHT RES	1.4 8v	Marelli
 Idea	SERVICE LIGHT RES	1.6 MJET 16v	Marelli
 Idea	SERVICE LIGHT RES	1.9 JTD	Marelli
 Idea	VISUAL./TELEMATIC	1.2 16v	Marelli Connect 3
 Idea	VISUAL./TELEMATIC	1.3 Multijet	Marelli Connect 3
 Idea	VISUAL./TELEMATIC	1.3 Multijet FAP	Marelli Connect 3
 Idea	VISUAL./TELEMATIC	1.4 16v	Marelli Connect 3
 Idea	VISUAL./TELEMATIC	1.4 8v	Marelli Connect 3
 Idea	VISUAL./TELEMATIC	1.6 MJET 16v	Marelli Connect 3
 Idea	VISUAL./TELEMATIC	1.9 JTD	Marelli Connect 3
 Marea	ABS	1.6 16v	LUCAS ABS EBC 430
 Marea	ABS	1.6 16v	LUCAS ABS FIII/IC
 Marea	ABS	1.8 16v	LUCAS ABS EBC 430
 Marea	ABS	1.8 16v	LUCAS ABS FIII/IC
 Marea	ABS	100 1.6 16v	LUCAS ABS EBC 430
 Marea	ABS	100 1.6 16v	LUCAS ABS FIII/IC
 Marea	ABS	100 1.6 16v CF3	LUCAS ABS EBC 430
 Marea	ABS	100 1.6 16v CF3	LUCAS ABS FIII/IC
 Marea	ABS	100 1.9 TD	LUCAS ABS EBC 430
 Marea	ABS	100 1.9 TD	LUCAS ABS FIII/IC
 Marea	ABS	105 1.9 JTD	LUCAS ABS EBC 430
 Marea	ABS	105 1.9 JTD	LUCAS ABS FIII/IC
 Marea	ABS	110 1.9 JTD	LUCAS ABS EBC 430
 Marea	ABS	110 1.9 JTD	LUCAS ABS FIII/IC
 Marea	ABS	115 1.8 16v	LUCAS ABS EBC 430
 Marea	ABS	115 1.8 16v	LUCAS ABS FIII/IC
 Marea	ABS	125 2.4 TD	LUCAS ABS EBC 430

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Marea	ABS	125 2.4 TD	LUCAS ABS FIII/IC
 Marea	ABS	130 2.4 JTD	LUCAS ABS EBC 430
 Marea	ABS	130 2.4 JTD	LUCAS ABS FIII/IC
 Marea	ABS	155 2.0 20v	LUCAS ABS EBC 430
 Marea	ABS	155 2.0 20v	LUCAS ABS FIII/IC
 Marea	ABS	2.0 20v	LUCAS ABS EBC 430
 Marea	ABS	2.0 20v	LUCAS ABS FIII/IC
 Marea	ABS	75 TD	LUCAS ABS EBC 430
 Marea	ABS	75 TD	LUCAS ABS FIII/IC
 Marea	ABS	80 1.2 16v	LUCAS ABS EBC 430
 Marea	ABS	80 1.2 16v	LUCAS ABS FIII/IC
 Marea	AIRBAG	1.6 16v	ALLIED AirBag MY 97 (2F-2P)
 Marea	AIRBAG	1.6 16v	ALLIED AirBag MY 97 (2F-2P-S)
 Marea	AIRBAG	1.6 16v	ALLIED AirBag Signal
 Marea	AIRBAG	1.6 16v	BREED AirBag MY 97 (2F-2P-2L)
 Marea	AIRBAG	1.6 16v	BREED AirBag MY 97 (2F-2P-2L-S)
 Marea	AIRBAG	1.6 16v (99-..)	ALLIED AirBag MY 97 (2F-2P)
 Marea	AIRBAG	1.6 16v (99-..)	ALLIED AirBag MY 97 (2F-2P-S)
 Marea	AIRBAG	1.6 16v (99-..)	ALLIED AirBag Signal
 Marea	AIRBAG	1.6 16v (99-..)	BREED AirBag MY 97 (2F-2P-2L)
 Marea	AIRBAG	1.6 16v (99-..)	BREED AirBag MY 97 (2F-2P-2L-S)
 Marea	AIRBAG	1.8 16v	ALLIED AirBag MY 97 (2F-2P)
 Marea	AIRBAG	1.8 16v	ALLIED AirBag MY 97 (2F-2P-S)
 Marea	AIRBAG	1.8 16v	ALLIED AirBag Signal
 Marea	AIRBAG	1.8 16v	BREED AirBag MY 97 (2F-2P-2L)
 Marea	AIRBAG	1.8 16v	BREED AirBag MY 97 (2F-2P-2L-S)
 Marea	AIRBAG	1.8 16v (99-..)	ALLIED AirBag MY 97 (2F-2P)
 Marea	AIRBAG	1.8 16v (99-..)	ALLIED AirBag MY 97 (2F-2P-S)
 Marea	AIRBAG	1.8 16v (99-..)	ALLIED AirBag Signal
 Marea	AIRBAG	1.8 16v (99-..)	BREED AirBag MY 97 (2F-2P-2L)
 Marea	AIRBAG	1.8 16v (99-..)	BREED AirBag MY 97 (2F-2P-2L-S)
 Marea	AIRBAG	100 1.6 16v	ALLIED AirBag MY 97 (2F-2P)
 Marea	AIRBAG	100 1.6 16v	ALLIED AirBag MY 97 (2F-2P-S)
 Marea	AIRBAG	100 1.6 16v	ALLIED AirBag Signal
 Marea	AIRBAG	100 1.6 16v	BREED AirBag MY 97 (2F-2P-2L)
 Marea	AIRBAG	100 1.6 16v	BREED AirBag MY 97 (2F-2P-2L-S)
 Marea	AIRBAG	100 1.6 16v (99-..)	ALLIED AirBag MY 97 (2F-2P)
 Marea	AIRBAG	100 1.6 16v (99-..)	ALLIED AirBag MY 97 (2F-2P-S)
 Marea	AIRBAG	100 1.6 16v (99-..)	ALLIED AirBag Signal
 Marea	AIRBAG	100 1.6 16v (99-..)	BREED AirBag MY 97 (2F-2P-2L)
 Marea	AIRBAG	100 1.6 16v (99-..)	BREED AirBag MY 97 (2F-2P-2L-S)
 Marea	AIRBAG	100 1.6 16v CF3	ALLIED AirBag MY 97 (2F-2P)
 Marea	AIRBAG	100 1.6 16v CF3	ALLIED AirBag MY 97 (2F-2P-S)
 Marea	AIRBAG	100 1.6 16v CF3	ALLIED AirBag Signal
 Marea	AIRBAG	100 1.6 16v CF3	BREED AirBag MY 97 (2F-2P-2L)
 Marea	AIRBAG	100 1.6 16v CF3	BREED AirBag MY 97 (2F-2P-2L-S)
 Marea	AIRBAG	100 1.6 16v CF3 (99-..)	ALLIED AirBag MY 97 (2F-2P)
 Marea	AIRBAG	100 1.6 16v CF3 (99-..)	ALLIED AirBag MY 97 (2F-2P-S)
 Marea	AIRBAG	100 1.6 16v CF3 (99-..)	ALLIED AirBag Signal
 Marea	AIRBAG	100 1.6 16v CF3 (99-..)	BREED AirBag MY 97 (2F-2P-2L)
 Marea	AIRBAG	100 1.6 16v CF3 (99-..)	BREED AirBag MY 97 (2F-2P-2L-S)
 Marea	AIRBAG	100 1.9 TD	ALLIED AirBag MY 97 (2F-2P)
 Marea	AIRBAG	100 1.9 TD	ALLIED AirBag MY 97 (2F-2P-S)
 Marea	AIRBAG	100 1.9 TD	ALLIED AirBag Signal
 Marea	AIRBAG	100 1.9 TD	BREED AirBag MY 97 (2F-2P-2L)
 Marea	AIRBAG	100 1.9 TD	BREED AirBag MY 97 (2F-2P-2L-S)
 Marea	AIRBAG	100 1.9 TD (99-..)	ALLIED AirBag MY 97 (2F-2P)
 Marea	AIRBAG	100 1.9 TD (99-..)	ALLIED AirBag MY 97 (2F-2P-S)

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Marea	AIRBAG	100 1.9 TD (99-..)	ALLIED AirBag Signal
 Marea	AIRBAG	100 1.9 TD (99-..)	BREED AirBag MY 97 (2F-2P-2L)
 Marea	AIRBAG	100 1.9 TD (99-..)	BREED AirBag MY 97 (2F-2P-2L-S)
 Marea	AIRBAG	105 1.9 JTD	ALLIED AirBag MY 97 (2F-2P)
 Marea	AIRBAG	105 1.9 JTD	ALLIED AirBag MY 97 (2F-2P-S)
 Marea	AIRBAG	105 1.9 JTD	ALLIED AirBag Signal
 Marea	AIRBAG	105 1.9 JTD	BREED AirBag MY 97 (2F-2P-2L)
 Marea	AIRBAG	105 1.9 JTD	BREED AirBag MY 97 (2F-2P-2L-S)
 Marea	AIRBAG	105 1.9 JTD (99-..)	ALLIED AirBag MY 97 (2F-2P)
 Marea	AIRBAG	105 1.9 JTD (99-..)	ALLIED AirBag MY 97 (2F-2P-S)
 Marea	AIRBAG	105 1.9 JTD (99-..)	ALLIED AirBag Signal
 Marea	AIRBAG	105 1.9 JTD (99-..)	BREED AirBag MY 97 (2F-2P-2L)
 Marea	AIRBAG	105 1.9 JTD (99-..)	BREED AirBag MY 97 (2F-2P-2L-S)
 Marea	AIRBAG	110 1.9 JTD	ALLIED AirBag MY 97 (2F-2P)
 Marea	AIRBAG	110 1.9 JTD	ALLIED AirBag MY 97 (2F-2P-S)
 Marea	AIRBAG	110 1.9 JTD	ALLIED AirBag Signal
 Marea	AIRBAG	110 1.9 JTD	BREED AirBag MY 97 (2F-2P-2L)
 Marea	AIRBAG	110 1.9 JTD	BREED AirBag MY 97 (2F-2P-2L-S)
 Marea	AIRBAG	110 1.9 JTD (99-..)	ALLIED AirBag MY 97 (2F-2P)
 Marea	AIRBAG	110 1.9 JTD (99-..)	ALLIED AirBag MY 97 (2F-2P-S)
 Marea	AIRBAG	110 1.9 JTD (99-..)	ALLIED AirBag Signal
 Marea	AIRBAG	110 1.9 JTD (99-..)	BREED AirBag MY 97 (2F-2P-2L)
 Marea	AIRBAG	110 1.9 JTD (99-..)	BREED AirBag MY 97 (2F-2P-2L-S)
 Marea	AIRBAG	115 1.8 16v	ALLIED AirBag MY 97 (2F-2P)
 Marea	AIRBAG	115 1.8 16v	ALLIED AirBag MY 97 (2F-2P-S)
 Marea	AIRBAG	115 1.8 16v	ALLIED AirBag Signal
 Marea	AIRBAG	115 1.8 16v	BREED AirBag MY 97 (2F-2P-2L)
 Marea	AIRBAG	115 1.8 16v	BREED AirBag MY 97 (2F-2P-2L-S)
 Marea	AIRBAG	115 1.8 16v (99-..)	ALLIED AirBag MY 97 (2F-2P)
 Marea	AIRBAG	115 1.8 16v (99-..)	ALLIED AirBag MY 97 (2F-2P-S)
 Marea	AIRBAG	115 1.8 16v (99-..)	ALLIED AirBag Signal
 Marea	AIRBAG	115 1.8 16v (99-..)	BREED AirBag MY 97 (2F-2P-2L)
 Marea	AIRBAG	115 1.8 16v (99-..)	BREED AirBag MY 97 (2F-2P-2L-S)
 Marea	AIRBAG	125 2.4 TD	ALLIED AirBag MY 97 (2F-2P)
 Marea	AIRBAG	125 2.4 TD	ALLIED AirBag MY 97 (2F-2P-S)
 Marea	AIRBAG	125 2.4 TD	ALLIED AirBag Signal
 Marea	AIRBAG	125 2.4 TD	BREED AirBag MY 97 (2F-2P-2L)
 Marea	AIRBAG	125 2.4 TD	BREED AirBag MY 97 (2F-2P-2L-S)
 Marea	AIRBAG	125 2.4 TD (99-..)	ALLIED AirBag MY 97 (2F-2P)
 Marea	AIRBAG	125 2.4 TD (99-..)	ALLIED AirBag MY 97 (2F-2P-S)
 Marea	AIRBAG	125 2.4 TD (99-..)	ALLIED AirBag Signal
 Marea	AIRBAG	125 2.4 TD (99-..)	BREED AirBag MY 97 (2F-2P-2L)
 Marea	AIRBAG	125 2.4 TD (99-..)	BREED AirBag MY 97 (2F-2P-2L-S)
 Marea	AIRBAG	130 2.4 JTD	ALLIED AirBag MY 97 (2F-2P)
 Marea	AIRBAG	130 2.4 JTD	ALLIED AirBag MY 97 (2F-2P-S)
 Marea	AIRBAG	130 2.4 JTD	ALLIED AirBag Signal
 Marea	AIRBAG	130 2.4 JTD	BREED AirBag MY 97 (2F-2P-2L)
 Marea	AIRBAG	130 2.4 JTD	BREED AirBag MY 97 (2F-2P-2L-S)
 Marea	AIRBAG	130 2.4 JTD (99-..)	ALLIED AirBag MY 97 (2F-2P)
 Marea	AIRBAG	130 2.4 JTD (99-..)	ALLIED AirBag MY 97 (2F-2P-S)
 Marea	AIRBAG	130 2.4 JTD (99-..)	ALLIED AirBag Signal
 Marea	AIRBAG	130 2.4 JTD (99-..)	BREED AirBag MY 97 (2F-2P-2L)
 Marea	AIRBAG	130 2.4 JTD (99-..)	BREED AirBag MY 97 (2F-2P-2L-S)
 Marea	AIRBAG	155 2.0 20v	ALLIED AirBag MY 97 (2F-2P)
 Marea	AIRBAG	155 2.0 20v	ALLIED AirBag MY 97 (2F-2P-S)
 Marea	AIRBAG	155 2.0 20v	ALLIED AirBag Signal
 Marea	AIRBAG	155 2.0 20v	BREED AirBag MY 97 (2F-2P-2L)
 Marea	AIRBAG	155 2.0 20v	BREED AirBag MY 97 (2F-2P-2L-S)

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Marea	AIRBAG	155 2.0 20v (99-..)	ALLIED AirBag MY 97 (2F-2P)
 Marea	AIRBAG	155 2.0 20v (99-..)	ALLIED AirBag MY 97 (2F-2P-S)
 Marea	AIRBAG	155 2.0 20v (99-..)	ALLIED AirBag Signal
 Marea	AIRBAG	155 2.0 20v (99-..)	BREED AirBag MY 97 (2F-2P-2L)
 Marea	AIRBAG	155 2.0 20v (99-..)	BREED AirBag MY 97 (2F-2P-2L-S)
 Marea	AIRBAG	2.0 20v	ALLIED AirBag MY 97 (2F-2P)
 Marea	AIRBAG	2.0 20v	ALLIED AirBag MY 97 (2F-2P-S)
 Marea	AIRBAG	2.0 20v	ALLIED AirBag Signal
 Marea	AIRBAG	2.0 20v	BREED AirBag MY 97 (2F-2P-2L)
 Marea	AIRBAG	2.0 20v	BREED AirBag MY 97 (2F-2P-2L-S)
 Marea	AIRBAG	2.0 20v (99-..)	ALLIED AirBag MY 97 (2F-2P)
 Marea	AIRBAG	2.0 20v (99-..)	ALLIED AirBag MY 97 (2F-2P-S)
 Marea	AIRBAG	2.0 20v (99-..)	ALLIED AirBag Signal
 Marea	AIRBAG	2.0 20v (99-..)	BREED AirBag MY 97 (2F-2P-2L)
 Marea	AIRBAG	2.0 20v (99-..)	BREED AirBag MY 97 (2F-2P-2L-S)
 Marea	AIRBAG	75 TD	ALLIED AirBag MY 97 (2F-2P)
 Marea	AIRBAG	75 TD	ALLIED AirBag MY 97 (2F-2P-S)
 Marea	AIRBAG	75 TD	ALLIED AirBag Signal
 Marea	AIRBAG	75 TD	BREED AirBag MY 97 (2F-2P-2L)
 Marea	AIRBAG	75 TD	BREED AirBag MY 97 (2F-2P-2L-S)
 Marea	AIRBAG	75 TD (99-..)	ALLIED AirBag MY 97 (2F-2P)
 Marea	AIRBAG	75 TD (99-..)	ALLIED AirBag MY 97 (2F-2P-S)
 Marea	AIRBAG	75 TD (99-..)	ALLIED AirBag Signal
 Marea	AIRBAG	75 TD (99-..)	BREED AirBag MY 97 (2F-2P-2L)
 Marea	AIRBAG	75 TD (99-..)	BREED AirBag MY 97 (2F-2P-2L-S)
 Marea	AIRBAG	80 1.2 16v	ALLIED AirBag MY 97 (2F-2P)
 Marea	AIRBAG	80 1.2 16v	ALLIED AirBag MY 97 (2F-2P-S)
 Marea	AIRBAG	80 1.2 16v	ALLIED AirBag Signal
 Marea	AIRBAG	80 1.2 16v	BREED AirBag MY 97 (2F-2P-2L)
 Marea	AIRBAG	80 1.2 16v	BREED AirBag MY 97 (2F-2P-2L-S)
 Marea	AIRBAG	80 1.2 16v (99-..)	ALLIED AirBag MY 97 (2F-2P)
 Marea	AIRBAG	80 1.2 16v (99-..)	ALLIED AirBag MY 97 (2F-2P-S)
 Marea	AIRBAG	80 1.2 16v (99-..)	ALLIED AirBag Signal
 Marea	AIRBAG	80 1.2 16v (99-..)	BREED AirBag MY 97 (2F-2P-2L)
 Marea	AIRBAG	80 1.2 16v (99-..)	BREED AirBag MY 97 (2F-2P-2L-S)
 Marea	CLIMA	75 TD	Borletti Klima MANUAL
 Marea	DIESEL MANAGEME	100 1.9 TD	LUCAS Diesel DCN
 Marea	DIESEL MANAGEME	100 1.9 TD	LUCAS Diesel DCN
 Marea	ENGINE MANAGEME	1.6 16v	Marelli IAW 1AF.16
 Marea	ENGINE MANAGEME	1.6 16v	Marelli IAW 1AF.16
 Marea	ENGINE MANAGEME	1.8 16v	HITACHI MPI MFI
 Marea	ENGINE MANAGEME	100 1.6 16v (99-..)	Marelli IAW 49F
 Marea	ENGINE MANAGEME	100 1.6 16v CF3 (01-..)	Marelli IAW 49F/59F EOBD
 Marea	ENGINE MANAGEME	105 1.9 JTD (...98)	BOSCH EDC 15 Common Rail
 Marea	ENGINE MANAGEME	110 1.9 JTD (99-..)	BOSCH EDC 15 Common Rail (JTD '99)
 Marea	ENGINE MANAGEME	115 1.8 16v (99-..)	HITACHI MPI MFI '98
 Marea	ENGINE MANAGEME	125 2.4 TD	BOSCH MSA 11
 Marea	ENGINE MANAGEME	130 2.4 JTD (99-..)	BOSCH EDC 15 Common Rail
 Marea	ENGINE MANAGEME	155 2.0 20v (99-..)	BOSCH Motronic ME3.1
 Marea	ENGINE MANAGEME	2.0 20v	BOSCH Motronic M2.10.4
 Marea	ENGINE MANAGEME	2.0 20v	BOSCH Motronic M2.10.4
 Marea	ENGINE MANAGEME	80 1.2 16v (99-..)	BOSCH Motronic M1.5.5
 Marea	KEY ENCODE	1.6 16v	BOSCH CODE MANUAL
 Marea	KEY ENCODE	1.8 16v	BOSCH CODE MANUAL
 Marea	KEY ENCODE	100 1.6 16v	BOSCH CODE MANUAL
 Marea	KEY ENCODE	100 1.6 16v CF3	BOSCH CODE MANUAL
 Marea	KEY ENCODE	100 1.9 TD	BOSCH CODE MANUAL
 Marea	KEY ENCODE	105 1.9 JTD	BOSCH CODE MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Marea	KEY ENCODE	110 1.9 JTD	BOSCH CODE MANUAL
 Marea	KEY ENCODE	115 1.8 16v	BOSCH CODE MANUAL
 Marea	KEY ENCODE	125 2.4 TD	BOSCH CODE MANUAL
 Marea	KEY ENCODE	130 2.4 JTD	BOSCH CODE MANUAL
 Marea	KEY ENCODE	155 2.0 20v	BOSCH CODE MANUAL
 Marea	KEY ENCODE	2.0 20v	BOSCH CODE MANUAL
 Marea	KEY ENCODE	75 TD	BOSCH CODE MANUAL
 Marea	KEY ENCODE	80 1.2 16v	BOSCH CODE MANUAL
 Marea	MAINTENANCE	1.6 16v	BOSCH CODE MANUAL
 Marea	MAINTENANCE	1.8 16v	BOSCH CODE MANUAL
 Marea	MAINTENANCE	100 1.6 16v	BOSCH CODE MANUAL
 Marea	MAINTENANCE	100 1.6 16v CF3	BOSCH CODE MANUAL
 Marea	MAINTENANCE	100 1.9 TD	BOSCH CODE MANUAL
 Marea	MAINTENANCE	105 1.9 JTD	BOSCH CODE MANUAL
 Marea	MAINTENANCE	110 1.9 JTD	BOSCH CODE MANUAL
 Marea	MAINTENANCE	115 1.8 16v	BOSCH CODE MANUAL
 Marea	MAINTENANCE	125 2.4 TD	BOSCH CODE MANUAL
 Marea	MAINTENANCE	130 2.4 JTD	BOSCH CODE MANUAL
 Marea	MAINTENANCE	155 2.0 20v	BOSCH CODE MANUAL
 Marea	MAINTENANCE	2.0 20v	BOSCH CODE MANUAL
 Marea	MAINTENANCE	75 TD	Borletti Klima MANUAL
 Marea	MAINTENANCE	75 TD	BOSCH CODE MANUAL
 Marea	MAINTENANCE	80 1.2 16v	BOSCH CODE MANUAL
 Multipla 02	ABS	1.6 16v	BOSCH ABS 5.3
 Multipla 02	ABS	1.6 16v Blupower	BOSCH ABS 5.3
 Multipla 02	ABS	1.6 16v Nat.power	BOSCH ABS 5.3
 Multipla 02	ABS	116 1.9 JTD	BOSCH ABS 5.3
 Multipla 02	ABS	120 1.9 JTD	BOSCH ABS 5.3
 Multipla 02	ABS + TRACT. CONT	1.6 16v	BOSCH ABS/VDC 5.7
 Multipla 02	ABS + TRACT. CONT	1.6 16v Blupower	BOSCH ABS/VDC 5.7
 Multipla 02	ABS + TRACT. CONT	1.6 16v Nat.power	BOSCH ABS/VDC 5.7
 Multipla 02	ABS + TRACT. CONT	116 1.9 JTD	BOSCH ABS/VDC 5.7
 Multipla 02	ABS + TRACT. CONT	120 1.9 JTD	BOSCH ABS/VDC 5.7
 Multipla 02	AIRBAG	1.6 16v	BREED AirBag MY 97 (3F-2L-I)
 Multipla 02	AIRBAG	1.6 16v	BREED AirBag MY 97 (3F-I)
 Multipla 02	AIRBAG	1.6 16v	SIEMENS AirBag MY 99 (1F)
 Multipla 02	AIRBAG	1.6 16v	SIEMENS AirBag MY 99 (2F-2L-2T-I)
 Multipla 02	AIRBAG	1.6 16v	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Multipla 02	AIRBAG	1.6 16v	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Multipla 02	AIRBAG	1.6 16v	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Multipla 02	AIRBAG	1.6 16v	SIEMENS AirBag MY 99 (2F-I)
 Multipla 02	AIRBAG	1.6 16v Blupower	BREED AirBag MY 97 (3F-2L-I)
 Multipla 02	AIRBAG	1.6 16v Blupower	BREED AirBag MY 97 (3F-I)
 Multipla 02	AIRBAG	1.6 16v Blupower	SIEMENS AirBag MY 99 (1F)
 Multipla 02	AIRBAG	1.6 16v Blupower	SIEMENS AirBag MY 99 (2F-2L-2T-I)
 Multipla 02	AIRBAG	1.6 16v Blupower	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Multipla 02	AIRBAG	1.6 16v Blupower	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Multipla 02	AIRBAG	1.6 16v Blupower	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Multipla 02	AIRBAG	1.6 16v Blupower	SIEMENS AirBag MY 99 (2F-I)
 Multipla 02	AIRBAG	1.6 16v Nat.power	BREED AirBag MY 97 (3F-2L-I)
 Multipla 02	AIRBAG	1.6 16v Nat.power	BREED AirBag MY 97 (3F-I)
 Multipla 02	AIRBAG	1.6 16v Nat.power	SIEMENS AirBag MY 99 (1F)
 Multipla 02	AIRBAG	1.6 16v Nat.power	SIEMENS AirBag MY 99 (2F-2L-2T-I)
 Multipla 02	AIRBAG	1.6 16v Nat.power	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Multipla 02	AIRBAG	1.6 16v Nat.power	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Multipla 02	AIRBAG	1.6 16v Nat.power	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Multipla 02	AIRBAG	1.6 16v Nat.power	SIEMENS AirBag MY 99 (2F-I)
 Multipla 02	AIRBAG	116 1.9 JTD	BREED AirBag MY 97 (3F-2L-I)

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Multipla 02	AIRBAG	116 1.9 JTD	BREED AirBag MY 97 (3F-I)
 Multipla 02	AIRBAG	116 1.9 JTD	SIEMENS AirBag MY 99 (1F)
 Multipla 02	AIRBAG	116 1.9 JTD	SIEMENS AirBag MY 99 (2F-2L-2T-I)
 Multipla 02	AIRBAG	116 1.9 JTD	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Multipla 02	AIRBAG	116 1.9 JTD	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Multipla 02	AIRBAG	116 1.9 JTD	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Multipla 02	AIRBAG	116 1.9 JTD	SIEMENS AirBag MY 99 (2F-I)
 Multipla 02	AIRBAG	120 1.9 JTD	BREED AirBag MY 97 (3F-2L-I)
 Multipla 02	AIRBAG	120 1.9 JTD	BREED AirBag MY 97 (3F-I)
 Multipla 02	AIRBAG	120 1.9 JTD	SIEMENS AirBag MY 99 (1F)
 Multipla 02	AIRBAG	120 1.9 JTD	SIEMENS AirBag MY 99 (2F-2L-2T-I)
 Multipla 02	AIRBAG	120 1.9 JTD	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Multipla 02	AIRBAG	120 1.9 JTD	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Multipla 02	AIRBAG	120 1.9 JTD	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Multipla 02	AIRBAG	120 1.9 JTD	SIEMENS AirBag MY 99 (2F-I)
 Multipla 02	CENTRAL LOCKING	1.6 16v	RF Bloccaporte/ricevitore VAS 97/3-4
 Multipla 02	CENTRAL LOCKING	1.6 16v Blupower	RF Bloccaporte/ricevitore VAS 97/3-4
 Multipla 02	CENTRAL LOCKING	1.6 16v Nat.power	RF Bloccaporte/ricevitore VAS 97/3-4
 Multipla 02	CENTRAL LOCKING	116 1.9 JTD	RF Bloccaporte/ricevitore VAS 97/3-4
 Multipla 02	CENTRAL LOCKING	120 1.9 JTD	RF Bloccaporte/ricevitore VAS 97/3-4
 Multipla 02	ENGINE MANAGEME	1.6 16v	Marelli IAW 49F/59F EOBD
 Multipla 02	ENGINE MANAGEME	1.6 16v Nat.power	Marelli IAW 49F/59F EOBD
 Multipla 02	ENGINE MANAGEME	116 1.9 JTD	BOSCH EDC 15 Common Rail (JTD '99)
 Multipla 02	ENGINE MANAGEME	120 1.9 JTD	BOSCH EDC 16 Common Rail
 Multipla 02	ENGINE MANAGEME	1.6 16v Nat.power	Metatron 5D0 EOBD
 Multipla 02	IMMOBILIZER	1.6 16v	Marelli CODE 2
 Multipla 02	IMMOBILIZER	1.6 16v Blupower	Marelli CODE 2
 Multipla 02	IMMOBILIZER	1.6 16v Nat.power	Marelli CODE 2
 Multipla 02	IMMOBILIZER	116 1.9 JTD	Marelli CODE 2
 Multipla 02	IMMOBILIZER	120 1.9 JTD	Marelli CODE 2
 Multipla 02	MAINTENANCE	1.6 16v (02-..)	MANUAL
 Multipla 02	MAINTENANCE	1.6 16v Blupower (02-..)	MANUAL
 Multipla 02	MAINTENANCE	1.6 16v Nat.power (02-..)	MANUAL
 Multipla 02	MAINTENANCE	116 1.9 JTD (02-..)	MANUAL
 Multipla 02	MAINTENANCE	120 1.9 JTD	BOSCH EDC 16 Common Rail
 Multipla 02	MAINTENANCE	120 1.9 JTD	BOSCH EDC 16 Common Rail
 Multipla 02	MAINTENANCE	120 1.9 JTD (02-..)	MANUAL
 Multipla 02	SERVICE LIGHT RES	1.6 16v (02-..)	MANUAL
 Multipla 02	SERVICE LIGHT RES	1.6 16v Blupower (02-..)	MANUAL
 Multipla 02	SERVICE LIGHT RES	1.6 16v Nat.power (02-..)	MANUAL
 Multipla 02	SERVICE LIGHT RES	116 1.9 JTD (02-..)	MANUAL
 Multipla 02	SERVICE LIGHT RES	120 1.9 JTD (02-..)	MANUAL
 Multipla	ABS	1.6 16v	BOSCH ABS 5.3
 Multipla	ABS	1.6 16v Bipower	BOSCH ABS 5.3
 Multipla	ABS	1.6 16v Blupower	BOSCH ABS 5.3
 Multipla	ABS	105 1.9 JTD	BOSCH ABS 5.3
 Multipla	ABS	110 1.9 JTD	BOSCH ABS 5.3
 Multipla	ABS	116 1.9 JTD	BOSCH ABS 5.3
 Multipla	ABS	120 1.9 JTD	BOSCH ABS 5.3
 Multipla	ABS + TRACT. CONT	1.6 16v (02-..)	BOSCH ABS/VDC 5.7
 Multipla	ABS + TRACT. CONT	1.6 16v Bipower (02-..)	BOSCH ABS/VDC 5.7
 Multipla	ABS + TRACT. CONT	1.6 16v Blupower (02-..)	BOSCH ABS/VDC 5.7
 Multipla	ABS + TRACT. CONT	105 1.9 JTD (02-..)	BOSCH ABS/VDC 5.7
 Multipla	ABS + TRACT. CONT	110 1.9 JTD (02-..)	BOSCH ABS/VDC 5.7
 Multipla	ABS + TRACT. CONT	116 1.9 JTD (02-..)	BOSCH ABS/VDC 5.7
 Multipla	ABS + TRACT. CONT	120 1.9 JTD (02-..)	BOSCH ABS/VDC 5.7
 Multipla	AIRBAG	1.6 16v	BREED AirBag MY 97 (3F-2L-I)
 Multipla	AIRBAG	1.6 16v	BREED AirBag MY 97 (3F-I)

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Multipla	AIRBAG	1.6 16v	SIEMENS AirBag MY 99 (1F)
 Multipla	AIRBAG	1.6 16v	SIEMENS AirBag MY 99 (2F-2L-2T-I)
 Multipla	AIRBAG	1.6 16v	SIEMENS AirBag MY 99 (2F-I)
 Multipla	AIRBAG	1.6 16v Bipower	BREED AirBag MY 97 (3F-2L-I)
 Multipla	AIRBAG	1.6 16v Bipower	BREED AirBag MY 97 (3F-I)
 Multipla	AIRBAG	1.6 16v Bipower	SIEMENS AirBag MY 99 (1F)
 Multipla	AIRBAG	1.6 16v Bipower	SIEMENS AirBag MY 99 (2F-2L-2T-I)
 Multipla	AIRBAG	1.6 16v Bipower	SIEMENS AirBag MY 99 (2F-I)
 Multipla	AIRBAG	1.6 16v Blupower	BREED AirBag MY 97 (3F-2L-I)
 Multipla	AIRBAG	1.6 16v Blupower	BREED AirBag MY 97 (3F-I)
 Multipla	AIRBAG	1.6 16v Blupower	SIEMENS AirBag MY 99 (1F)
 Multipla	AIRBAG	1.6 16v Blupower	SIEMENS AirBag MY 99 (2F-2L-2T-I)
 Multipla	AIRBAG	1.6 16v Blupower	SIEMENS AirBag MY 99 (2F-I)
 Multipla	AIRBAG	105 1.9 JTD	BREED AirBag MY 97 (3F-2L-I)
 Multipla	AIRBAG	105 1.9 JTD	BREED AirBag MY 97 (3F-I)
 Multipla	AIRBAG	105 1.9 JTD	SIEMENS AirBag MY 99 (1F)
 Multipla	AIRBAG	105 1.9 JTD	SIEMENS AirBag MY 99 (2F-2L-2T-I)
 Multipla	AIRBAG	105 1.9 JTD	SIEMENS AirBag MY 99 (2F-I)
 Multipla	AIRBAG	110 1.9 JTD	BREED AirBag MY 97 (3F-2L-I)
 Multipla	AIRBAG	110 1.9 JTD	BREED AirBag MY 97 (3F-I)
 Multipla	AIRBAG	110 1.9 JTD	SIEMENS AirBag MY 99 (1F)
 Multipla	AIRBAG	110 1.9 JTD	SIEMENS AirBag MY 99 (2F-2L-2T-I)
 Multipla	AIRBAG	110 1.9 JTD	SIEMENS AirBag MY 99 (2F-I)
 Multipla	AIRBAG	116 1.9 JTD	BREED AirBag MY 97 (3F-2L-I)
 Multipla	AIRBAG	116 1.9 JTD	BREED AirBag MY 97 (3F-I)
 Multipla	AIRBAG	116 1.9 JTD	SIEMENS AirBag MY 99 (1F)
 Multipla	AIRBAG	116 1.9 JTD	SIEMENS AirBag MY 99 (2F-2L-2T-I)
 Multipla	AIRBAG	116 1.9 JTD	SIEMENS AirBag MY 99 (2F-I)
 Multipla	AIRBAG	120 1.9 JTD	BREED AirBag MY 97 (3F-2L-I)
 Multipla	AIRBAG	120 1.9 JTD	BREED AirBag MY 97 (3F-I)
 Multipla	AIRBAG	120 1.9 JTD	SIEMENS AirBag MY 99 (1F)
 Multipla	AIRBAG	120 1.9 JTD	SIEMENS AirBag MY 99 (2F-2L-2T-I)
 Multipla	AIRBAG	120 1.9 JTD	SIEMENS AirBag MY 99 (2F-I)
 Multipla	ENGINE MANAGEME	1.6 16v	Marelli IAW 49F
 Multipla	ENGINE MANAGEME	1.6 16v	Marelli IAW 49F/59F EOBD
 Multipla	ENGINE MANAGEME	1.6 16v Bipower (01-..)	Marelli IAW 49F/59F EOBD
 Multipla	ENGINE MANAGEME	1.6 16v Bipower (99-00)	Marelli IAW 4GF
 Multipla	ENGINE MANAGEME	105 1.9 JTD (..-98)	BOSCH EDC 15 Common Rail
 Multipla	ENGINE MANAGEME	110 1.9 JTD (..-00)	BOSCH EDC 15 Common Rail (JTD '99)
 Multipla	ENGINE MANAGEME	116 1.9 JTD (01-..)	BOSCH EDC 15 Common Rail (JTD '99)
 Multipla	ENGINE MANAGEME	120 1.9 JTD (02-..)	BOSCH EDC 16C39 CF4/EOBD Common
 Multipla	ENGINE MANAGEME	1.6 16v Bipower (..-02)	Metatron Gas OMT 5D0
 Multipla	IMMOBILIZER	1.6 16v	Marelli CODE 2
 Multipla	IMMOBILIZER	1.6 16v (02-..)	Marelli CODE 2
 Multipla	IMMOBILIZER	1.6 16v Bipower	Marelli CODE 2
 Multipla	IMMOBILIZER	1.6 16v Blupower	Marelli CODE 2
 Multipla	IMMOBILIZER	105 1.9 JTD	Marelli CODE 2
 Multipla	IMMOBILIZER	110 1.9 JTD (99-..)	Marelli CODE 2
 Multipla	IMMOBILIZER	116 1.9 JTD (02-..)	Marelli CODE 2
 Multipla	IMMOBILIZER	120 1.9 JTD (02-..)	Marelli CODE 2
 Multipla	MAINTENANCE	1.6 16v (02-..)	MANUAL
 Multipla	MAINTENANCE	1.6 16v Bipower (02-..)	MANUAL
 Multipla	MAINTENANCE	1.6 16v Blupower (02-..)	MANUAL
 Multipla	MAINTENANCE	105 1.9 JTD (02-..)	MANUAL
 Multipla	MAINTENANCE	110 1.9 JTD (02-..)	MANUAL
 Multipla	MAINTENANCE	116 1.9 JTD (02-..)	MANUAL
 Multipla	MAINTENANCE	120 1.9 JTD (02-..)	BOSCH EDC 16C39 CF4/EOBD Common
 Multipla	MAINTENANCE	120 1.9 JTD (02-..)	BOSCH EDC 16C39 CF4/EOBD Common

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Multipla	MAINTENANCE	120 1.9 JTD (02-..)	MANUAL
 Multipla	SERVICE LIGHT RES	1.6 16v (02-..)	MANUAL
 Multipla	SERVICE LIGHT RES	1.6 16v Bipower (02-..)	MANUAL
 Multipla	SERVICE LIGHT RES	1.6 16v Blupower (02-..)	MANUAL
 Multipla	SERVICE LIGHT RES	105 1.9 JTD (02-..)	MANUAL
 Multipla	SERVICE LIGHT RES	110 1.9 JTD (02-..)	MANUAL
 Multipla	SERVICE LIGHT RES	116 1.9 JTD (02-..)	MANUAL
 Multipla	SERVICE LIGHT RES	120 1.9 JTD (02-..)	MANUAL
 Palio RST	ABS	1.0 16v	BOSCH ABS 5.3
 Palio RST	ABS	1.0 8v	BOSCH ABS 5.3
 Palio RST	ABS	1.2 16v	BOSCH ABS 5.3
 Palio RST	ABS	1.2 8v	BOSCH ABS 5.3
 Palio RST	ABS	1.3 Multijet	BOSCH ABS 5.3
 Palio RST	ABS	1.3 Multijet FAP	BOSCH ABS 5.3
 Palio RST	ABS	1.5 8v	BOSCH ABS 5.3
 Palio RST	ABS	1.6 16v	BOSCH ABS 5.3
 Palio RST	ABS	1.6 8v	BOSCH ABS 5.3
 Palio RST	ABS	1.7 TD	BOSCH ABS 5.3
 Palio RST	ABS	1.8	BOSCH ABS 5.3
 Palio RST	ABS	1.9 D	BOSCH ABS 5.3
 Palio RST	ABS	1.9 JTD	BOSCH ABS 5.3
 Palio RST	ABS	80 1.9 JTD	BOSCH ABS 5.3
 Palio RST	ABS	994	BOSCH ABS 5.3
 Palio RST	ABS	999 8v	BOSCH ABS 5.3
 Palio RST	AIRBAG	1.0 16v	TRW AirBag MY 97 (2F)
 Palio RST	AIRBAG	1.0 8v	TRW AirBag MY 97 (2F)
 Palio RST	AIRBAG	1.2 16v	TRW AirBag MY 97 (2F)
 Palio RST	AIRBAG	1.2 8v	TRW AirBag MY 97 (2F)
 Palio RST	AIRBAG	1.3 Multijet	TRW AirBag MY 97 (2F)
 Palio RST	AIRBAG	1.3 Multijet FAP	TRW AirBag MY 97 (2F)
 Palio RST	AIRBAG	1.5 8v	TRW AirBag MY 97 (2F)
 Palio RST	AIRBAG	1.6 16v	TRW AirBag MY 97 (2F)
 Palio RST	AIRBAG	1.6 8v	TRW AirBag MY 97 (2F)
 Palio RST	AIRBAG	1.7 TD	TRW AirBag MY 97 (2F)
 Palio RST	AIRBAG	1.8	TRW AirBag MY 97 (2F)
 Palio RST	AIRBAG	1.9 D	TRW AirBag MY 97 (2F)
 Palio RST	AIRBAG	1.9 JTD	TRW AirBag MY 97 (2F)
 Palio RST	AIRBAG	80 1.9 JTD	TRW AirBag MY 97 (2F)
 Palio RST	AIRBAG	994	TRW AirBag MY 97 (2F)
 Palio RST	AIRBAG	999 8v	TRW AirBag MY 97 (2F)
 Palio RST	CHASSIS NETWORK	1.0 16v	DELPHI/Marelli Body Computer
 Palio RST	CHASSIS NETWORK	1.0 16v	Fiat CAN Info
 Palio RST	CHASSIS NETWORK	1.0 16v	Fiat Proxi Alignement
 Palio RST	CHASSIS NETWORK	1.0 16v (03-..)	DELPHI/Marelli Body Computer
 Palio RST	CHASSIS NETWORK	1.0 16v (03-..)	Fiat Proxi Alignement
 Palio RST	CHASSIS NETWORK	1.0 8v	DELPHI/Marelli Body Computer
 Palio RST	CHASSIS NETWORK	1.0 8v	Fiat CAN Info
 Palio RST	CHASSIS NETWORK	1.0 8v	Fiat Proxi Alignement
 Palio RST	CHASSIS NETWORK	1.0 8v (03-..)	DELPHI/Marelli Body Computer
 Palio RST	CHASSIS NETWORK	1.0 8v (03-..)	Fiat Proxi Alignement
 Palio RST	CHASSIS NETWORK	1.2 16v	DELPHI/Marelli Body Computer
 Palio RST	CHASSIS NETWORK	1.2 16v	Fiat CAN Info
 Palio RST	CHASSIS NETWORK	1.2 16v	Fiat Proxi Alignement
 Palio RST	CHASSIS NETWORK	1.2 16v (03-..)	DELPHI/Marelli Body Computer
 Palio RST	CHASSIS NETWORK	1.2 16v (03-..)	Fiat Proxi Alignement
 Palio RST	CHASSIS NETWORK	1.2 8v	DELPHI/Marelli Body Computer
 Palio RST	CHASSIS NETWORK	1.2 8v	Fiat CAN Info
 Palio RST	CHASSIS NETWORK	1.2 8v	Fiat Proxi Alignement

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Palio RST	CHASSIS NETWORK	1.2 8v (03-..)	DELPHI/Marelli Body Computer
 Palio RST	CHASSIS NETWORK	1.2 8v (03-..)	Fiat Proxi Alignement
 Palio RST	CHASSIS NETWORK	1.3 Multijet	DELPHI/Marelli Body Computer
 Palio RST	CHASSIS NETWORK	1.3 Multijet	Fiat CAN Info
 Palio RST	CHASSIS NETWORK	1.3 Multijet	Fiat Proxi Alignement
 Palio RST	CHASSIS NETWORK	1.3 Multijet (03-..)	DELPHI/Marelli Body Computer
 Palio RST	CHASSIS NETWORK	1.3 Multijet (03-..)	Fiat Proxi Alignement
 Palio RST	CHASSIS NETWORK	1.3 Multijet FAP	DELPHI/Marelli Body Computer
 Palio RST	CHASSIS NETWORK	1.3 Multijet FAP	Fiat CAN Info
 Palio RST	CHASSIS NETWORK	1.3 Multijet FAP	Fiat Proxi Alignement
 Palio RST	CHASSIS NETWORK	1.3 Multijet FAP (03-..)	DELPHI/Marelli Body Computer
 Palio RST	CHASSIS NETWORK	1.3 Multijet FAP (03-..)	Fiat Proxi Alignement
 Palio RST	CHASSIS NETWORK	1.5 8v	DELPHI/Marelli Body Computer
 Palio RST	CHASSIS NETWORK	1.5 8v	Fiat CAN Info
 Palio RST	CHASSIS NETWORK	1.5 8v	Fiat Proxi Alignement
 Palio RST	CHASSIS NETWORK	1.5 8v (03-..)	DELPHI/Marelli Body Computer
 Palio RST	CHASSIS NETWORK	1.5 8v (03-..)	Fiat Proxi Alignement
 Palio RST	CHASSIS NETWORK	1.6 16v	DELPHI/Marelli Body Computer
 Palio RST	CHASSIS NETWORK	1.6 16v	Fiat CAN Info
 Palio RST	CHASSIS NETWORK	1.6 16v	Fiat Proxi Alignement
 Palio RST	CHASSIS NETWORK	1.6 16v (03-..)	DELPHI/Marelli Body Computer
 Palio RST	CHASSIS NETWORK	1.6 16v (03-..)	Fiat Proxi Alignement
 Palio RST	CHASSIS NETWORK	1.6 8v	DELPHI/Marelli Body Computer
 Palio RST	CHASSIS NETWORK	1.6 8v	Fiat CAN Info
 Palio RST	CHASSIS NETWORK	1.6 8v	Fiat Proxi Alignement
 Palio RST	CHASSIS NETWORK	1.6 8v (03-..)	DELPHI/Marelli Body Computer
 Palio RST	CHASSIS NETWORK	1.6 8v (03-..)	Fiat Proxi Alignement
 Palio RST	CHASSIS NETWORK	1.7 TD	DELPHI/Marelli Body Computer
 Palio RST	CHASSIS NETWORK	1.7 TD	Fiat CAN Info
 Palio RST	CHASSIS NETWORK	1.7 TD	Fiat Proxi Alignement
 Palio RST	CHASSIS NETWORK	1.7 TD (03-..)	DELPHI/Marelli Body Computer
 Palio RST	CHASSIS NETWORK	1.7 TD (03-..)	Fiat Proxi Alignement
 Palio RST	CHASSIS NETWORK	1.8	DELPHI/Marelli Body Computer
 Palio RST	CHASSIS NETWORK	1.8	Fiat CAN Info
 Palio RST	CHASSIS NETWORK	1.8	Fiat Proxi Alignement
 Palio RST	CHASSIS NETWORK	1.8 (03-..)	DELPHI/Marelli Body Computer
 Palio RST	CHASSIS NETWORK	1.8 (03-..)	Fiat Proxi Alignement
 Palio RST	CHASSIS NETWORK	1.9 D	DELPHI/Marelli Body Computer
 Palio RST	CHASSIS NETWORK	1.9 D	Fiat CAN Info
 Palio RST	CHASSIS NETWORK	1.9 D	Fiat Proxi Alignement
 Palio RST	CHASSIS NETWORK	1.9 D (03-..)	DELPHI/Marelli Body Computer
 Palio RST	CHASSIS NETWORK	1.9 D (03-..)	Fiat Proxi Alignement
 Palio RST	CHASSIS NETWORK	1.9 JTD	DELPHI/Marelli Body Computer
 Palio RST	CHASSIS NETWORK	1.9 JTD	Fiat CAN Info
 Palio RST	CHASSIS NETWORK	1.9 JTD	Fiat Proxi Alignement
 Palio RST	CHASSIS NETWORK	1.9 JTD (03-..)	DELPHI/Marelli Body Computer
 Palio RST	CHASSIS NETWORK	1.9 JTD (03-..)	Fiat Proxi Alignement
 Palio RST	CHASSIS NETWORK	80 1.9 JTD	DELPHI/Marelli Body Computer
 Palio RST	CHASSIS NETWORK	80 1.9 JTD	Fiat CAN Info
 Palio RST	CHASSIS NETWORK	80 1.9 JTD	Fiat Proxi Alignement
 Palio RST	CHASSIS NETWORK	80 1.9 JTD (03-..)	DELPHI/Marelli Body Computer
 Palio RST	CHASSIS NETWORK	80 1.9 JTD (03-..)	Fiat Proxi Alignement
 Palio RST	CHASSIS NETWORK	994	DELPHI/Marelli Body Computer
 Palio RST	CHASSIS NETWORK	994	Fiat CAN Info
 Palio RST	CHASSIS NETWORK	994	Fiat Proxi Alignement
 Palio RST	CHASSIS NETWORK	994 (03-..)	DELPHI/Marelli Body Computer
 Palio RST	CHASSIS NETWORK	994 (03-..)	Fiat Proxi Alignement
 Palio RST	CHASSIS NETWORK	999 8v	DELPHI/Marelli Body Computer

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Palio RST	CHASSIS NETWORK	999 8v	Fiat CAN Info
 Palio RST	CHASSIS NETWORK	999 8v	Fiat Proxi Alignement
 Palio RST	CHASSIS NETWORK	999 8v (03-..)	DELPHI/Marelli Body Computer
 Palio RST	CHASSIS NETWORK	999 8v (03-..)	Fiat Proxi Alignement
 Palio RST	DASHBOARD	1.0 16v	VEGLIA/Marelli Dashboard
 Palio RST	DASHBOARD	1.0 8v	VEGLIA/Marelli Dashboard
 Palio RST	DASHBOARD	1.2 16v	VEGLIA/Marelli Dashboard
 Palio RST	DASHBOARD	1.2 8v	VEGLIA/Marelli Dashboard
 Palio RST	DASHBOARD	1.3 Multijet	VEGLIA/Marelli Dashboard
 Palio RST	DASHBOARD	1.3 Multijet FAP	VEGLIA/Marelli Dashboard
 Palio RST	DASHBOARD	1.5 8v	VEGLIA/Marelli Dashboard
 Palio RST	DASHBOARD	1.6 16v	VEGLIA/Marelli Dashboard
 Palio RST	DASHBOARD	1.6 8v	VEGLIA/Marelli Dashboard
 Palio RST	DASHBOARD	1.7 TD	VEGLIA/Marelli Dashboard
 Palio RST	DASHBOARD	1.8	VEGLIA/Marelli Dashboard
 Palio RST	DASHBOARD	1.9 D	VEGLIA/Marelli Dashboard
 Palio RST	DASHBOARD	1.9 JTD	VEGLIA/Marelli Dashboard
 Palio RST	DASHBOARD	80 1.9 JTD	VEGLIA/Marelli Dashboard
 Palio RST	DASHBOARD	994	VEGLIA/Marelli Dashboard
 Palio RST	DASHBOARD	999 8v	VEGLIA/Marelli Dashboard
 Palio RST	DIESEL MANAGEMEN	1.9 D	LUCAS EPIC DCU3F
 Palio RST	ENGINE MANAGEME	1.2 16v	BOSCH Motronic ME7.3H4M EOBD
 Palio RST	ENGINE MANAGEME	1.2 8v	Marelli IAW 49F/59F EOBD
 Palio RST	ENGINE MANAGEME	1.2 8v	Marelli IAW 59F
 Palio RST	ENGINE MANAGEME	1.2 8v	Marelli IAW 5AF
 Palio RST	ENGINE MANAGEME	1.3 Multijet	Marelli EDC 6F3
 Palio RST	ENGINE MANAGEME	1.3 Multijet FAP	Marelli 6F3 CF3 Common Rail
 Palio RST	ENGINE MANAGEME	1.5 8v (01-..)	EOBD
 Palio RST	ENGINE MANAGEME	1.6 16v	Marelli IAW 49F
 Palio RST	ENGINE MANAGEME	1.6 16v	Marelli IAW 49F/59F EOBD
 Palio RST	ENGINE MANAGEME	1.8 (01-..)	EOBD
 Palio RST	ENGINE MANAGEME	1.9 JTD	BOSCH EDC 15 Common Rail (JTD '99)
 Palio RST	ENGINE MANAGEME	80 1.9 JTD	BOSCH EDC 15 Common Rail (JTD '99)
 Palio RST	ENGINE MANAGEME	999 8v	Marelli IAW 59F
 Palio RST	KEY ENCODE	1.0 16v	DELPHI/Marelli CODE Body Computer
 Palio RST	KEY ENCODE	1.0 8v	DELPHI/Marelli CODE Body Computer
 Palio RST	KEY ENCODE	1.2 16v	DELPHI/Marelli CODE Body Computer
 Palio RST	KEY ENCODE	1.2 8v	DELPHI/Marelli CODE Body Computer
 Palio RST	KEY ENCODE	1.3 Multijet FAP	DELPHI/Marelli CODE Body Computer
 Palio RST	KEY ENCODE	1.5 8v	DELPHI/Marelli CODE Body Computer
 Palio RST	KEY ENCODE	1.6 16v	DELPHI/Marelli CODE Body Computer
 Palio RST	KEY ENCODE	1.8	DELPHI/Marelli CODE Body Computer
 Palio RST	KEY ENCODE	1.9 D	DELPHI/Marelli CODE Body Computer
 Palio RST	KEY ENCODE	1.9 JTD	DELPHI/Marelli CODE Body Computer
 Palio RST	KEY ENCODE	80 1.9 JTD	DELPHI/Marelli CODE Body Computer
 Palio RST	KEY ENCODE	994	DELPHI/Marelli CODE Body Computer
 Palio RST	KEY ENCODE	999 8v	DELPHI/Marelli CODE Body Computer
 Palio RST	MAINTENANCE	1.2 8v	Marelli IAW 5AF
 Palio RST	MAINTENANCE	1.3 Multijet	Marelli EDC 6F3
 Palio RST	MAINTENANCE	1.3 Multijet FAP	Marelli 6F3 CF3 Common Rail
 Palio RST	MAINTENANCE	1.3 Multijet FAP	Marelli 6F3 CF3 Common Rail
 Palio RST	MAINTENANCE	1.3 Multijet FAP	Marelli 6F3 CF3 Common Rail
 Palio RST	MAINTENANCE	1.3 Multijet FAP	Marelli 6F3 CF3 Common Rail
 Palio	AIRBAG	1.2 16v	TRW AirBag MY 97 (2F)
 Palio	AIRBAG	1.2 16v	TRW AirBag TRW2
 Palio	AIRBAG	1.2 16v	TRW-Becker AirBag no Pret.
 Palio	AIRBAG	1.2 8v	TRW AirBag MY 97 (2F)
 Palio	AIRBAG	1.2 8v	TRW AirBag TRW2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Palio	AIRBAG	1.2 8v	TRW-Becker AirBag no Pret.
 Palio	AIRBAG	1.6 16v	TRW AirBag MY 97 (2F)
 Palio	AIRBAG	1.6 16v	TRW AirBag TRW2
 Palio	AIRBAG	1.6 16v	TRW-Becker AirBag no Pret.
 Palio	AIRBAG	1.9 D	TRW AirBag MY 97 (2F)
 Palio	AIRBAG	1.9 D	TRW AirBag TRW2
 Palio	AIRBAG	1.9 D	TRW-Becker AirBag no Pret.
 Palio	AIRBAG	999 8v	TRW AirBag MY 97 (2F)
 Palio	AIRBAG	999 8v	TRW AirBag TRW2
 Palio	AIRBAG	999 8v	TRW-Becker AirBag no Pret.
 Palio	DIESEL MANAGEMEN	1.9 D	LUCAS EPIC DCU3F
 Palio	ENGINE MANAGEME	1.2 16v	BOSCH Motronic ME7.3H4 EOBD
 Palio	ENGINE MANAGEME	1.2 8v	Marelli IAW 18F
 Palio	ENGINE MANAGEME	1.2 8v CF3	Marelli IAW 49F/59F EOBD
 Palio	ENGINE MANAGEME	1.6 16v	Marelli IAW 1AF.13
 Palio	ENGINE MANAGEME	1.6 16v	Marelli IAW 49F
 Palio	ENGINE MANAGEME	1.6 16v CF3	Marelli IAW 49F/59F EOBD
 Palio	ENGINE MANAGEME	999 8v	Marelli IAW 59F
 Panda (139)	ABS + TRACT. CONT	0.9 TwinAir Turbo 85cv (12-..)	BOSCH ABS 8 ESP
 Panda (139)	ABS + TRACT. CONT	1.2 (12-..)	BOSCH ABS 8 ESP
 Panda (139)	ABS + TRACT. CONT	1.3 Multijet 16v 75cv (12-..)	BOSCH ABS 8 ESP
 Panda (139)	DASHBOARD	0.9 TwinAir Turbo 85cv (12-..)	Marelli
 Panda (139)	DASHBOARD	1.2 (12-..)	Marelli
 Panda (139)	DASHBOARD	1.3 Multijet 16v 75cv (12-..)	Marelli
 Panda (139)	ELECTRIC STEERING	0.9 TwinAir Turbo 85cv (12-..)	
 Panda (139)	ELECTRIC STEERING	1.2 (12-..)	
 Panda (139)	ELECTRIC STEERING	1.3 Multijet 16v 75cv (12-..)	
 Panda (139)	ENGINE MANAGEME	1.3 Multijet 16v 75cv (12-..)	Marelli EDC 8F3 CF5
 Panda (139)	MAINTENANCE	0.9 TwinAir Turbo 85cv (12-..)	
 Panda (139)	MAINTENANCE	0.9 TwinAir Turbo 85cv (12-..)	Marelli
 Panda (139)	MAINTENANCE	0.9 TwinAir Turbo 85cv (12-..)	Marelli
 Panda (139)	MAINTENANCE	1.2 (12-..)	
 Panda (139)	MAINTENANCE	1.2 (12-..)	Marelli
 Panda (139)	MAINTENANCE	1.2 (12-..)	Marelli
 Panda (139)	MAINTENANCE	1.3 Multijet 16v 75cv (12-..)	
 Panda (139)	MAINTENANCE	1.3 Multijet 16v 75cv (12-..)	Marelli
 Panda (139)	MAINTENANCE	1.3 Multijet 16v 75cv (12-..)	Marelli
 Panda (139)	MAINTENANCE	1.3 Multijet 16v 75cv (12-..)	Marelli EDC 8F3 CF5
 Panda (139)	MAINTENANCE	1.3 Multijet 16v 75cv (12-..)	Marelli EDC 8F3 CF5
 Panda (141)	ELECTRONIC INJECT	1.0 Fire 4x4 Kat	BOSCH MonoJetronic A2.2
 Panda (141)	ELECTRONIC INJECT	1.0 Fire 4x4 Kat	BOSCH MonoJetronic A2.2
 Panda (141)	ELECTRONIC INJECT	1.0 Fire 4x4 Kat	BOSCH MonoJetronic A2.2
 Panda (141)	ELECTRONIC INJECT	1.0 Kat	BOSCH MonoJetronic A2.2
 Panda (141)	ELECTRONIC INJECT	1.0 Kat	BOSCH MonoJetronic A2.2
 Panda (141)	ELECTRONIC INJECT	1.0 Kat	BOSCH MonoJetronic A2.2
 Panda (141)	ELECTRONIC INJECT	1.1 4x4	BOSCH MonoJetronic A2.2
 Panda (141)	ELECTRONIC INJECT	1.1 AT Kat	BOSCH MonoJetronic A2.2
 Panda (141)	ELECTRONIC INJECT	1.1 Kat	BOSCH MonoJetronic A2.2
 Panda (141)	ELECTRONIC INJECT	1.1 Kat	BOSCH MonoJetronic A2.2
 Panda (141)	ELECTRONIC INJECT	1.1 Kat	BOSCH MonoJetronic A2.2
 Panda (141)	ENGINE MANAGEME	1.0 (01-..)	Marelli IAW 59F
 Panda (141)	ENGINE MANAGEME	1.0 Kat	Marelli IAW 6F.SH
 Panda (141)	ENGINE MANAGEME	1.0 Kat	Marelli IAW 6F.SH
 Panda (141)	ENGINE MANAGEME	1.1 4x4 ECO	Marelli IAW 49F/59F EOBD
 Panda (141)	ENGINE MANAGEME	1.1 4x4 Kat	Marelli IAW 16F.EB
 Panda (141)	ENGINE MANAGEME	1.1 4x4 Kat	Marelli IAW 16F.EH
 Panda (141)	ENGINE MANAGEME	1.1 4x4 Kat	Marelli IAW 16F.EJ
 Panda (141)	ENGINE MANAGEME	1.1 4x4 Kat	Marelli IAW 16F.EJ

Systems supported by ECUREADER / ECUDECODER (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Panda (141)	ENGINE MANAGEME	1.1 4x4 Kat	Marelli IAW 4EF
 Panda (141)	ENGINE MANAGEME	1.1 4x4 Kat	Marelli IAW 6F.SM
 Panda (141)	ENGINE MANAGEME	1.1 AT Kat	Marelli IAW 6F.SK
 Panda (141)	ENGINE MANAGEME	1.1 ECO	Marelli IAW 49F/59F EOBD
 Panda (141)	ENGINE MANAGEME	1.1 ECO	Marelli IAW 4EF
 Panda (141)	ENGINE MANAGEME	1.1 ECO (...03)	Marelli IAW 4AF/PP
 Panda (141)	ENGINE MANAGEME	1.1 Kat	Marelli IAW 6F.SJ
 Panda (141)	ENGINE MANAGEME	900 Kat	Marelli IAW 16F.EL
 Panda (141)	ENGINE MANAGEME	900 Kat	Marelli IAW 16F.EL
 Panda (141)	ENGINE MANAGEME	900 Kat	Marelli IAW 6F.SL
 Panda (141)	ENGINE MANAGEME	900 Kat	Marelli IAW 6F.SL
 Panda (141)	ENGINE MANAGEME	900 Kat	Marelli IAW 6F.SL
 Panda (141)	ENGINE MANAGEME	900 Kat	Marelli IAW 6F.SL
 Panda (141)	MAINTENANCE	1.1 ECO (...03)	Marelli IAW 4AF/PP
 Panda (169)	ABS	1.1 8v (03-..)	BOSCH ABS 8
 Panda (169)	ABS	1.1 8v (03-..)	BOSCH ABS/VDC 8
 Panda (169)	ABS	1.2 8v (03-..)	BOSCH ABS 8
 Panda (169)	ABS	1.2 8v (03-..)	BOSCH ABS/VDC 8
 Panda (169)	ABS	1.2 8v 4x4 (04-..)	BOSCH ABS 8
 Panda (169)	ABS	1.2 8v 4x4 (04-..)	BOSCH ABS/VDC 8
 Panda (169)	ABS	1.2 8v Natural Power (07-..)	BOSCH ABS 8
 Panda (169)	ABS	1.2 8v Natural Power (07-..)	BOSCH ABS/VDC 8
 Panda (169)	ABS	1.3 Multijet (04-..)	BOSCH ABS 8
 Panda (169)	ABS	1.3 Multijet (04-..)	BOSCH ABS/VDC 8
 Panda (169)	ABS	1.3 Multijet 4x4 (05-..)	BOSCH ABS 8
 Panda (169)	ABS	1.3 Multijet 4x4 (05-..)	BOSCH ABS/VDC 8
 Panda (169)	ABS	1.3 Multijet FAP (07-..)	BOSCH ABS 8
 Panda (169)	ABS	1.3 Multijet FAP (07-..)	BOSCH ABS/VDC 8
 Panda (169)	ABS	1.4 16v (06-..)	BOSCH ABS 8
 Panda (169)	ABS	1.4 16v (06-..)	BOSCH ABS/VDC 8
 Panda (169)	ABS	1.4 8v Natural Power (10-..)	BOSCH ABS 8
 Panda (169)	ABS	1.4 8v Natural Power (10-..)	BOSCH ABS/VDC 8
 Panda (169)	AIRBAG	1.1 8v (03-..)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Panda (169)	AIRBAG	1.1 8v (03-..)	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Panda (169)	AIRBAG	1.1 8v (03-..)	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Panda (169)	AIRBAG	1.2 8v (03-..)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Panda (169)	AIRBAG	1.2 8v (03-..)	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Panda (169)	AIRBAG	1.2 8v (03-..)	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Panda (169)	AIRBAG	1.2 8v 4x4 (04-..)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Panda (169)	AIRBAG	1.2 8v 4x4 (04-..)	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Panda (169)	AIRBAG	1.2 8v 4x4 (04-..)	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Panda (169)	AIRBAG	1.2 8v Natural Power (07-..)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Panda (169)	AIRBAG	1.2 8v Natural Power (07-..)	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Panda (169)	AIRBAG	1.2 8v Natural Power (07-..)	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Panda (169)	AIRBAG	1.3 Multijet (04-..)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Panda (169)	AIRBAG	1.3 Multijet (04-..)	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Panda (169)	AIRBAG	1.3 Multijet (04-..)	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Panda (169)	AIRBAG	1.3 Multijet 4x4 (05-..)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Panda (169)	AIRBAG	1.3 Multijet 4x4 (05-..)	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Panda (169)	AIRBAG	1.3 Multijet 4x4 (05-..)	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Panda (169)	AIRBAG	1.3 Multijet FAP (07-..)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Panda (169)	AIRBAG	1.3 Multijet FAP (07-..)	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Panda (169)	AIRBAG	1.3 Multijet FAP (07-..)	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Panda (169)	AIRBAG	1.4 16v (06-..)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Panda (169)	AIRBAG	1.4 16v (06-..)	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Panda (169)	AIRBAG	1.4 16v (06-..)	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Panda (169)	AIRBAG	1.4 8v Natural Power (10-..)	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Panda (169)	AIRBAG	1.4 8v Natural Power (10-..)	SIEMENS AirBag MY 99 (2F-2P-I-S)

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Panda (169)	AIRBAG	1.4 8v Natural Power (10-..)	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Panda (169)	AUTOM. TRANSMISSI	1.1 8v (03-..)	Marelli Selespeed CFC228F
 Panda (169)	AUTOM. TRANSMISSI	1.2 8v (03-..)	Marelli Selespeed CFC228F
 Panda (169)	AUTOM. TRANSMISSI	1.2 8v 4x4 (04-..)	Marelli Selespeed CFC228F
 Panda (169)	AUTOM. TRANSMISSI	1.2 8v Natural Power (07-..)	Marelli Selespeed CFC228F
 Panda (169)	AUTOM. TRANSMISSI	1.3 Multijet (04-..)	Marelli Selespeed CFC228F
 Panda (169)	AUTOM. TRANSMISSI	1.3 Multijet 4x4 (05-..)	Marelli Selespeed CFC228F
 Panda (169)	AUTOM. TRANSMISSI	1.3 Multijet FAP (07-..)	Marelli Selespeed CFC228F
 Panda (169)	AUTOM. TRANSMISSI	1.4 16v (06-..)	Marelli Selespeed CFC228F
 Panda (169)	AUTOM. TRANSMISSI	1.4 8v Natural Power (10-..)	Marelli Selespeed CFC228F
 Panda (169)	CHASSIS NETWORK	1.1 8v (03-..)	Body Computer
 Panda (169)	CHASSIS NETWORK	1.1 8v (03-..)	Fiat Proxi Alignement
 Panda (169)	CHASSIS NETWORK	1.2 8v (03-..)	Body Computer
 Panda (169)	CHASSIS NETWORK	1.2 8v (03-..)	Fiat Proxi Alignement
 Panda (169)	CHASSIS NETWORK	1.2 8v 4x4 (04-..)	Body Computer
 Panda (169)	CHASSIS NETWORK	1.2 8v 4x4 (04-..)	Fiat Proxi Alignement
 Panda (169)	CHASSIS NETWORK	1.2 8v Natural Power (07-..)	Body Computer
 Panda (169)	CHASSIS NETWORK	1.2 8v Natural Power (07-..)	Fiat Proxi Alignement
 Panda (169)	CHASSIS NETWORK	1.3 Multijet (04-..)	Body Computer
 Panda (169)	CHASSIS NETWORK	1.3 Multijet (04-..)	Fiat Proxi Alignement
 Panda (169)	CHASSIS NETWORK	1.3 Multijet 4x4 (05-..)	Body Computer
 Panda (169)	CHASSIS NETWORK	1.3 Multijet 4x4 (05-..)	Fiat Proxi Alignement
 Panda (169)	CHASSIS NETWORK	1.3 Multijet FAP (07-..)	Body Computer
 Panda (169)	CHASSIS NETWORK	1.3 Multijet FAP (07-..)	Fiat Proxi Alignement
 Panda (169)	CHASSIS NETWORK	1.4 16v (06-..)	Body Computer
 Panda (169)	CHASSIS NETWORK	1.4 16v (06-..)	Fiat Proxi Alignement
 Panda (169)	CHASSIS NETWORK	1.4 8v Natural Power (10-..)	Body Computer
 Panda (169)	CHASSIS NETWORK	1.4 8v Natural Power (10-..)	Fiat Proxi Alignement
 Panda (169)	CLIMA	1.1 8v (03-..)	Clima
 Panda (169)	CLIMA	1.2 8v (03-..)	Clima
 Panda (169)	CLIMA	1.2 8v 4x4 (04-..)	Clima
 Panda (169)	CLIMA	1.2 8v Natural Power (07-..)	Clima
 Panda (169)	CLIMA	1.3 Multijet (04-..)	Clima
 Panda (169)	CLIMA	1.3 Multijet 4x4 (05-..)	Clima
 Panda (169)	CLIMA	1.3 Multijet FAP (07-..)	Clima
 Panda (169)	CLIMA	1.4 16v (06-..)	Clima
 Panda (169)	CLIMA	1.4 8v Natural Power (10-..)	Clima
 Panda (169)	DASHBOARD	1.1 8v (03-..)	Marelli Dashboard Comfort
 Panda (169)	DASHBOARD	1.1 8v (03-..)	Marelli Dashboard Strip/Modale
 Panda (169)	DASHBOARD	1.2 8v (03-..)	Marelli Dashboard Comfort
 Panda (169)	DASHBOARD	1.2 8v (03-..)	Marelli Dashboard Strip/Modale
 Panda (169)	DASHBOARD	1.2 8v 4x4 (04-..)	Marelli Dashboard Comfort
 Panda (169)	DASHBOARD	1.2 8v 4x4 (04-..)	Marelli Dashboard Strip/Modale
 Panda (169)	DASHBOARD	1.2 8v Natural Power (07-..)	Marelli Dashboard Comfort
 Panda (169)	DASHBOARD	1.2 8v Natural Power (07-..)	Marelli Dashboard Strip/Modale
 Panda (169)	DASHBOARD	1.3 Multijet (04-..)	Marelli Dashboard Comfort
 Panda (169)	DASHBOARD	1.3 Multijet (04-..)	Marelli Dashboard Strip/Modale
 Panda (169)	DASHBOARD	1.3 Multijet 4x4 (05-..)	Marelli Dashboard Comfort
 Panda (169)	DASHBOARD	1.3 Multijet 4x4 (05-..)	Marelli Dashboard Strip/Modale
 Panda (169)	DASHBOARD	1.3 Multijet FAP (07-..)	Marelli Dashboard Comfort
 Panda (169)	DASHBOARD	1.3 Multijet FAP (07-..)	Marelli Dashboard Strip/Modale
 Panda (169)	DASHBOARD	1.4 16v (06-..)	Marelli Dashboard Comfort
 Panda (169)	DASHBOARD	1.4 16v (06-..)	Marelli Dashboard Strip/Modale
 Panda (169)	DASHBOARD	1.4 8v Natural Power (10-..)	Marelli Dashboard Comfort
 Panda (169)	DASHBOARD	1.4 8v Natural Power (10-..)	Marelli Dashboard Strip/Modale
 Panda (169)	ELECTRIC STEERING	1.1 8v (03-..)	DELPHI EPS
 Panda (169)	ELECTRIC STEERING	1.2 8v (03-..)	DELPHI EPS
 Panda (169)	ELECTRIC STEERING	1.2 8v 4x4 (04-..)	DELPHI EPS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Panda (169)	ELECTRIC STEERING	1.2 8v Natural Power (07-..)	DELPHI EPS
 Panda (169)	ELECTRIC STEERING	1.3 Multijet (04-..)	DELPHI EPS
 Panda (169)	ELECTRIC STEERING	1.3 Multijet 4x4 (05-..)	DELPHI EPS
 Panda (169)	ELECTRIC STEERING	1.3 Multijet FAP (07-..)	DELPHI EPS
 Panda (169)	ELECTRIC STEERING	1.4 16v (06-..)	DELPHI EPS
 Panda (169)	ELECTRIC STEERING	1.4 8v Natural Power (10-..)	DELPHI EPS
 Panda (169)	ENGINE MANAGEME	1.1 8v (03-..)	Marelli IAW 5AF SM
 Panda (169)	ENGINE MANAGEME	1.2 8v (03-..)	Marelli IAW 4EF/4AF/5AF/59F
 Panda (169)	ENGINE MANAGEME	1.2 8v 4x4 (04-..)	Marelli IAW 4EF/4AF/5AF/59F
 Panda (169)	ENGINE MANAGEME	1.2 8v Natural Power (03-..)	Marelli IAW 4EF/4AF/5AF/59F
 Panda (169)	ENGINE MANAGEME	1.3 Multijet (04-..)	Marelli 6JF CF3 Common Rail
 Panda (169)	ENGINE MANAGEME	1.3 Multijet (09-..)	Marelli 8DF CF5
 Panda (169)	ENGINE MANAGEME	1.3 Multijet 4x4 (05-..)	Marelli 6F3 (D.P.F.) CF3 Common Rail
 Panda (169)	ENGINE MANAGEME	1.3 Multijet 4x4 (05-..)	Marelli 6JF CF3 Common Rail
 Panda (169)	ENGINE MANAGEME	1.3 Multijet FAP (04-..)	Marelli 6F3 (D.P.F.) CF3 Common Rail
 Panda (169)	ENGINE MANAGEME	1.4 16v (04-..)	EOBD
 Panda (169)	ENGINE MANAGEME	1.4 8v Natural Power (10-..)	Marelli IAW 5SF8 Natural Power
 Panda (169)	ENGINE MANAGEME	1.2 8v Natural Power (07-..)	METATRON 6A0 EOBD
 Panda (169)	FAP OIL PARAMETER	1.3 Multijet (04-..)	Marelli
 Panda (169)	FAP OIL PARAMETER	1.3 Multijet 4x4 (05-..)	Marelli
 Panda (169)	FAP OIL PARAMETER	1.3 Multijet FAP (07-..)	Marelli
 Panda (169)	KEY ENCODE	1.1 8v (03-..)	Marelli CODE Body Computer
 Panda (169)	KEY ENCODE	1.2 8v (03-..)	Marelli CODE Body Computer
 Panda (169)	KEY ENCODE	1.2 8v 4x4 (04-..)	Marelli CODE Body Computer
 Panda (169)	KEY ENCODE	1.2 8v Natural Power (07-..)	Marelli CODE Body Computer
 Panda (169)	KEY ENCODE	1.3 Multijet (04-..)	Marelli CODE Body Computer
 Panda (169)	KEY ENCODE	1.3 Multijet 4x4 (05-..)	Marelli CODE Body Computer
 Panda (169)	KEY ENCODE	1.3 Multijet FAP (07-..)	Marelli CODE Body Computer
 Panda (169)	KEY ENCODE	1.4 16v (06-..)	Marelli CODE Body Computer
 Panda (169)	KEY ENCODE	1.4 8v Natural Power (10-..)	Marelli CODE Body Computer
 Panda (169)	MAINTENANCE	1.1 8v (03-..)	BOSCH ABS/VDC 8
 Panda (169)	MAINTENANCE	1.1 8v (03-..)	DELPHI EPS
 Panda (169)	MAINTENANCE	1.1 8v (03-..)	DELPHI EPS
 Panda (169)	MAINTENANCE	1.1 8v (03-..)	Marelli
 Panda (169)	MAINTENANCE	1.1 8v (03-..)	Marelli Dashboard Comfort
 Panda (169)	MAINTENANCE	1.1 8v (03-..)	Marelli Dashboard Comfort
 Panda (169)	MAINTENANCE	1.1 8v (03-..)	Marelli Dashboard Strip/Modale
 Panda (169)	MAINTENANCE	1.1 8v (03-..)	Marelli IAW 5AF SM
 Panda (169)	MAINTENANCE	1.1 8v (03-..)	Marelli Selespeed CFC228F
 Panda (169)	MAINTENANCE	1.2 8v (03-..)	BOSCH ABS/VDC 8
 Panda (169)	MAINTENANCE	1.2 8v (03-..)	DELPHI EPS
 Panda (169)	MAINTENANCE	1.2 8v (03-..)	DELPHI EPS
 Panda (169)	MAINTENANCE	1.2 8v (03-..)	Marelli
 Panda (169)	MAINTENANCE	1.2 8v (03-..)	Marelli Dashboard Comfort
 Panda (169)	MAINTENANCE	1.2 8v (03-..)	Marelli Dashboard Comfort
 Panda (169)	MAINTENANCE	1.2 8v (03-..)	Marelli Dashboard Strip/Modale
 Panda (169)	MAINTENANCE	1.2 8v (03-..)	Marelli IAW 4EF/4AF/5AF/59F
 Panda (169)	MAINTENANCE	1.2 8v (03-..)	Marelli Selespeed CFC228F
 Panda (169)	MAINTENANCE	1.2 8v 4x4 (04-..)	BOSCH ABS/VDC 8
 Panda (169)	MAINTENANCE	1.2 8v 4x4 (04-..)	DELPHI EPS
 Panda (169)	MAINTENANCE	1.2 8v 4x4 (04-..)	DELPHI EPS
 Panda (169)	MAINTENANCE	1.2 8v 4x4 (04-..)	Marelli
 Panda (169)	MAINTENANCE	1.2 8v 4x4 (04-..)	Marelli Dashboard Comfort
 Panda (169)	MAINTENANCE	1.2 8v 4x4 (04-..)	Marelli Dashboard Comfort
 Panda (169)	MAINTENANCE	1.2 8v 4x4 (04-..)	Marelli Dashboard Strip/Modale
 Panda (169)	MAINTENANCE	1.2 8v 4x4 (04-..)	Marelli IAW 4EF/4AF/5AF/59F
 Panda (169)	MAINTENANCE	1.2 8v 4x4 (04-..)	Marelli Selespeed CFC228F
 Panda (169)	MAINTENANCE	1.2 8v Natural Power (03-..)	Marelli IAW 4EF/4AF/5AF/59F

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Panda (169)	MAINTENANCE	1.2 8v Natural Power (07-..)	BOSCH ABS/VDC 8
 Panda (169)	MAINTENANCE	1.2 8v Natural Power (07-..)	DELPHI EPS
 Panda (169)	MAINTENANCE	1.2 8v Natural Power (07-..)	DELPHI EPS
 Panda (169)	MAINTENANCE	1.2 8v Natural Power (07-..)	Marelli
 Panda (169)	MAINTENANCE	1.2 8v Natural Power (07-..)	Marelli Dashboard Comfort
 Panda (169)	MAINTENANCE	1.2 8v Natural Power (07-..)	Marelli Dashboard Comfort
 Panda (169)	MAINTENANCE	1.2 8v Natural Power (07-..)	Marelli Dashboard Strip/Modale
 Panda (169)	MAINTENANCE	1.2 8v Natural Power (07-..)	Marelli Selespeed CFC228F
 Panda (169)	MAINTENANCE	1.3 Multijet (04-..)	BOSCH ABS/VDC 8
 Panda (169)	MAINTENANCE	1.3 Multijet (04-..)	DELPHI EPS
 Panda (169)	MAINTENANCE	1.3 Multijet (04-..)	DELPHI EPS
 Panda (169)	MAINTENANCE	1.3 Multijet (04-..)	Marelli
 Panda (169)	MAINTENANCE	1.3 Multijet (04-..)	Marelli
 Panda (169)	MAINTENANCE	1.3 Multijet (04-..)	Marelli Dashboard Comfort
 Panda (169)	MAINTENANCE	1.3 Multijet (04-..)	Marelli Dashboard Comfort
 Panda (169)	MAINTENANCE	1.3 Multijet (04-..)	Marelli Dashboard Strip/Modale
 Panda (169)	MAINTENANCE	1.3 Multijet (04-..)	Marelli Selespeed CFC228F
 Panda (169)	MAINTENANCE	1.3 Multijet 4x4 (05-..)	BOSCH ABS/VDC 8
 Panda (169)	MAINTENANCE	1.3 Multijet 4x4 (05-..)	DELPHI EPS
 Panda (169)	MAINTENANCE	1.3 Multijet 4x4 (05-..)	DELPHI EPS
 Panda (169)	MAINTENANCE	1.3 Multijet 4x4 (05-..)	Marelli
 Panda (169)	MAINTENANCE	1.3 Multijet 4x4 (05-..)	Marelli
 Panda (169)	MAINTENANCE	1.3 Multijet 4x4 (05-..)	Marelli 6F3 (D.P.F.) CF3 Common Rail
 Panda (169)	MAINTENANCE	1.3 Multijet 4x4 (05-..)	Marelli 6F3 (D.P.F.) CF3 Common Rail
 Panda (169)	MAINTENANCE	1.3 Multijet 4x4 (05-..)	Marelli 6F3 (D.P.F.) CF3 Common Rail
 Panda (169)	MAINTENANCE	1.3 Multijet 4x4 (05-..)	Marelli 6F3 (D.P.F.) CF3 Common Rail
 Panda (169)	MAINTENANCE	1.3 Multijet 4x4 (05-..)	Marelli Dashboard Comfort
 Panda (169)	MAINTENANCE	1.3 Multijet 4x4 (05-..)	Marelli Dashboard Comfort
 Panda (169)	MAINTENANCE	1.3 Multijet 4x4 (05-..)	Marelli Dashboard Strip/Modale
 Panda (169)	MAINTENANCE	1.3 Multijet 4x4 (05-..)	Marelli Selespeed CFC228F
 Panda (169)	MAINTENANCE	1.3 Multijet FAP (04-..)	Marelli 6F3 (D.P.F.) CF3 Common Rail
 Panda (169)	MAINTENANCE	1.3 Multijet FAP (04-..)	Marelli 6F3 (D.P.F.) CF3 Common Rail
 Panda (169)	MAINTENANCE	1.3 Multijet FAP (04-..)	Marelli 6F3 (D.P.F.) CF3 Common Rail
 Panda (169)	MAINTENANCE	1.3 Multijet FAP (04-..)	Marelli 6F3 (D.P.F.) CF3 Common Rail
 Panda (169)	MAINTENANCE	1.3 Multijet FAP (07-..)	BOSCH ABS/VDC 8
 Panda (169)	MAINTENANCE	1.3 Multijet FAP (07-..)	DELPHI EPS
 Panda (169)	MAINTENANCE	1.3 Multijet FAP (07-..)	DELPHI EPS
 Panda (169)	MAINTENANCE	1.3 Multijet FAP (07-..)	Marelli
 Panda (169)	MAINTENANCE	1.3 Multijet FAP (07-..)	Marelli
 Panda (169)	MAINTENANCE	1.3 Multijet FAP (07-..)	Marelli Dashboard Comfort
 Panda (169)	MAINTENANCE	1.3 Multijet FAP (07-..)	Marelli Dashboard Comfort
 Panda (169)	MAINTENANCE	1.3 Multijet FAP (07-..)	Marelli Dashboard Strip/Modale
 Panda (169)	MAINTENANCE	1.3 Multijet FAP (07-..)	Marelli Selespeed CFC228F
 Panda (169)	MAINTENANCE	1.4 16v (06-..)	BOSCH ABS/VDC 8
 Panda (169)	MAINTENANCE	1.4 16v (06-..)	DELPHI EPS
 Panda (169)	MAINTENANCE	1.4 16v (06-..)	DELPHI EPS
 Panda (169)	MAINTENANCE	1.4 16v (06-..)	Marelli
 Panda (169)	MAINTENANCE	1.4 16v (06-..)	Marelli Dashboard Comfort
 Panda (169)	MAINTENANCE	1.4 16v (06-..)	Marelli Dashboard Comfort
 Panda (169)	MAINTENANCE	1.4 16v (06-..)	Marelli Dashboard Strip/Modale
 Panda (169)	MAINTENANCE	1.4 16v (06-..)	Marelli Selespeed CFC228F
 Panda (169)	MAINTENANCE	1.4 8v Natural Power (10-..)	BOSCH ABS/VDC 8
 Panda (169)	MAINTENANCE	1.4 8v Natural Power (10-..)	DELPHI EPS
 Panda (169)	MAINTENANCE	1.4 8v Natural Power (10-..)	DELPHI EPS
 Panda (169)	MAINTENANCE	1.4 8v Natural Power (10-..)	Marelli
 Panda (169)	MAINTENANCE	1.4 8v Natural Power (10-..)	Marelli Dashboard Comfort
 Panda (169)	MAINTENANCE	1.4 8v Natural Power (10-..)	Marelli Dashboard Comfort
 Panda (169)	MAINTENANCE	1.4 8v Natural Power (10-..)	Marelli Dashboard Strip/Modale

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Panda (169)	MAINTENANCE	1.4 8v Natural Power (10-..)	Marelli IAW 5SF8 Natural Power
 Panda (169)	MAINTENANCE	1.4 8v Natural Power (10-..)	Marelli IAW 5SF8 Natural Power
 Panda (169)	MAINTENANCE	1.4 8v Natural Power (10-..)	Marelli IAW 5SF8 Natural Power
 Panda (169)	MAINTENANCE	1.4 8v Natural Power (10-..)	Marelli IAW 5SF8 Natural Power
 Panda (169)	MAINTENANCE	1.4 8v Natural Power (10-..)	Marelli IAW 5SF8 Natural Power
 Panda (169)	MAINTENANCE	1.4 8v Natural Power (10-..)	Marelli IAW 5SF8 Natural Power
 Panda (169)	MAINTENANCE	1.4 8v Natural Power (10-..)	Marelli IAW 5SF8 Natural Power
 Panda (169)	MAINTENANCE	1.4 8v Natural Power (10-..)	Marelli IAW 5SF8 Natural Power
 Panda (169)	MAINTENANCE	1.4 8v Natural Power (10-..)	Marelli IAW 5SF8 Natural Power
 Panda (169)	MAINTENANCE	1.4 8v Natural Power (10-..)	Marelli IAW 5SF8 Natural Power
 Panda (169)	MAINTENANCE	1.4 8v Natural Power (10-..)	Marelli IAW 5SF8 Natural Power
 Panda (169)	MAINTENANCE	1.4 8v Natural Power (10-..)	Marelli IAW 5SF8 Natural Power
 Panda (169)	MAINTENANCE	1.4 8v Natural Power (10-..)	Marelli IAW 5SF8 Natural Power
 Panda (169)	MAINTENANCE	1.4 8v Natural Power (10-..)	Marelli IAW 5SF8 Natural Power
 Panda (169)	MAINTENANCE	1.4 8v Natural Power (10-..)	Marelli IAW 5SF8 Natural Power
 Panda (169)	MAINTENANCE	1.4 8v Natural Power (10-..)	Marelli IAW 5SF8 Natural Power
 Panda (169)	MAINTENANCE	1.4 8v Natural Power (10-..)	Marelli IAW 5SF8 Natural Power
 Panda (169)	MAINTENANCE	1.4 8v Natural Power (10-..)	Marelli IAW 5SF8 Natural Power
 Panda (169)	MAINTENANCE	1.4 8v Natural Power (10-..)	Marelli IAW 5SF8 Natural Power
 Panda (169)	MAINTENANCE	1.4 8v Natural Power (10-..)	Marelli IAW 5SF8 Natural Power
 Panda (169)	MAINTENANCE	1.4 8v Natural Power (10-..)	Marelli Selespeed CFC228F
 Panda (169)	SERVICE LIGHT RES	1.1 8v (03-..)	Marelli
 Panda (169)	SERVICE LIGHT RES	1.2 8v (03-..)	Marelli
 Panda (169)	SERVICE LIGHT RES	1.2 8v 4x4 (04-..)	Marelli
 Panda (169)	SERVICE LIGHT RES	1.2 8v Natural Power (07-..)	Marelli
 Panda (169)	SERVICE LIGHT RES	1.3 Multijet (04-..)	Marelli
 Panda (169)	SERVICE LIGHT RES	1.3 Multijet 4x4 (05-..)	Marelli
 Panda (169)	SERVICE LIGHT RES	1.3 Multijet FAP (07-..)	Marelli
 Panda (169)	SERVICE LIGHT RES	1.4 16v (06-..)	Marelli
 Panda (169)	SERVICE LIGHT RES	1.4 8v Natural Power (10-..)	Marelli
 Panda (169)	VISUAL./TELEMATIC	1.1 8v (03-..)	Marelli Connect 3
 Panda (169)	VISUAL./TELEMATIC	1.2 8v (03-..)	Marelli Connect 3
 Panda (169)	VISUAL./TELEMATIC	1.2 8v 4x4 (04-..)	Marelli Connect 3
 Panda (169)	VISUAL./TELEMATIC	1.2 8v Natural Power (07-..)	Marelli Connect 3
 Panda (169)	VISUAL./TELEMATIC	1.3 Multijet (04-..)	Marelli Connect 3
 Panda (169)	VISUAL./TELEMATIC	1.3 Multijet 4x4 (05-..)	Marelli Connect 3
 Panda (169)	VISUAL./TELEMATIC	1.3 Multijet FAP (07-..)	Marelli Connect 3
 Panda (169)	VISUAL./TELEMATIC	1.4 16v (06-..)	Marelli Connect 3
 Panda (169)	VISUAL./TELEMATIC	1.4 8v Natural Power (10-..)	Marelli Connect 3
 Punto (176)	ABS	1.2 16v (97)	BOSCH ABS 2Si
 Punto (176)	ABS	1.2 16v (98-99)	BOSCH ABS 5.3
 Punto (176)	ABS	1.7 D (...99)	BOSCH ABS 2Si
 Punto (176)	ABS	1.7 D (98-99)	BOSCH ABS 5.3
 Punto (176)	ABS	1.7 TD (...99)	BOSCH ABS 2Si
 Punto (176)	ABS	1.7 TD (98-99)	BOSCH ABS 5.3
 Punto (176)	ABS	55 - 60 1.1 (...99)	BOSCH ABS 2Si
 Punto (176)	ABS	55 - 60 1.1 (98-99)	BOSCH ABS 5.3
 Punto (176)	ABS	55 - 60 1.2 (...99)	BOSCH ABS 2Si
 Punto (176)	ABS	55 - 60 1.2 (98-99)	BOSCH ABS 5.3
 Punto (176)	ABS	75 1.2 (...99)	BOSCH ABS 2Si
 Punto (176)	ABS	75 1.2 (98-99)	BOSCH ABS 5.3
 Punto (176)	ABS	85 1.4 (...99)	BOSCH ABS 2Si
 Punto (176)	ABS	85 1.4 (98-99)	BOSCH ABS 5.3
 Punto (176)	ABS	90 1.6 (...99)	BOSCH ABS 2Si
 Punto (176)	ABS	90 1.6 (98-99)	BOSCH ABS 5.3
 Punto (176)	ABS	GT 1.4 T (...99)	BOSCH ABS 2Si
 Punto (176)	ABS	GT 1.4 T (98-99)	BOSCH ABS 5.3
 Punto (176)	ABS	GT 1.4 T + Immob. (...99)	BOSCH ABS 2Si

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Punto (176)	ABS	GT 1.4 T + Immob. (98-99)	BOSCH ABS 5.3
 Punto (176)	AIRBAG	1.2 16v (...99)	TRW AirBag TRW2
 Punto (176)	AIRBAG	1.2 16v (...99)	TRW-Becker AirBag no Pret.
 Punto (176)	AIRBAG	1.2 16v (98-99)	TRW AirBag MY 97 (2F)
 Punto (176)	AIRBAG	1.7 D (...99)	TRW AirBag MY 97 (2F)
 Punto (176)	AIRBAG	1.7 D (...99)	TRW AirBag TRW2
 Punto (176)	AIRBAG	1.7 D (...99)	TRW-Becker AirBag no Pret.
 Punto (176)	AIRBAG	1.7 D (98-99)	TRW AirBag MY 97 (2F)
 Punto (176)	AIRBAG	1.7 TD (...99)	TRW AirBag MY 97 (2F)
 Punto (176)	AIRBAG	1.7 TD (...99)	TRW AirBag TRW2
 Punto (176)	AIRBAG	1.7 TD (...99)	TRW-Becker AirBag no Pret.
 Punto (176)	AIRBAG	1.7 TD (98-99)	TRW AirBag MY 97 (2F)
 Punto (176)	AIRBAG	55 - 60 1.1 (...99)	TRW AirBag MY 97 (2F)
 Punto (176)	AIRBAG	55 - 60 1.1 (...99)	TRW AirBag TRW2
 Punto (176)	AIRBAG	55 - 60 1.1 (...99)	TRW-Becker AirBag no Pret.
 Punto (176)	AIRBAG	55 - 60 1.1 (98-99)	TRW AirBag MY 97 (2F)
 Punto (176)	AIRBAG	55 - 60 1.2 (...99)	TRW AirBag TRW2
 Punto (176)	AIRBAG	55 - 60 1.2 (...99)	TRW-Becker AirBag no Pret.
 Punto (176)	AIRBAG	55 - 60 1.2 (98-99)	TRW AirBag MY 97 (2F)
 Punto (176)	AIRBAG	75 1.2 (...99)	TRW AirBag MY 97 (2F)
 Punto (176)	AIRBAG	75 1.2 (...99)	TRW AirBag TRW2
 Punto (176)	AIRBAG	75 1.2 (...99)	TRW-Becker AirBag no Pret.
 Punto (176)	AIRBAG	75 1.2 (98-99)	TRW AirBag MY 97 (2F)
 Punto (176)	AIRBAG	85 1.4 (...99)	TRW AirBag TRW2
 Punto (176)	AIRBAG	85 1.4 (...99)	TRW-Becker AirBag no Pret.
 Punto (176)	AIRBAG	85 1.4 (98-99)	TRW AirBag MY 97 (2F)
 Punto (176)	AIRBAG	90 1.6 (...99)	TRW AirBag MY 97 (2F)
 Punto (176)	AIRBAG	90 1.6 (...99)	TRW AirBag TRW2
 Punto (176)	AIRBAG	90 1.6 (...99)	TRW-Becker AirBag no Pret.
 Punto (176)	AIRBAG	90 1.6 (98-99)	TRW AirBag MY 97 (2F)
 Punto (176)	AIRBAG	GT 1.4 T (...99)	TRW AirBag MY 97 (2F)
 Punto (176)	AIRBAG	GT 1.4 T (...99)	TRW AirBag TRW2
 Punto (176)	AIRBAG	GT 1.4 T (...99)	TRW-Becker AirBag no Pret.
 Punto (176)	AIRBAG	GT 1.4 T (98-99)	TRW AirBag MY 97 (2F)
 Punto (176)	AIRBAG	GT 1.4 T + Immob. (...99)	TRW AirBag MY 97 (2F)
 Punto (176)	AIRBAG	GT 1.4 T + Immob. (...99)	TRW AirBag TRW2
 Punto (176)	AIRBAG	GT 1.4 T + Immob. (...99)	TRW-Becker AirBag no Pret.
 Punto (176)	AIRBAG	GT 1.4 T + Immob. (98-..)	TRW AirBag MY 97 (2F)
 Punto (176)	ENGINE MANAGEME	1.2 16v (...99)	Marelli IAW 18FD
 Punto (176)	ENGINE MANAGEME	55 - 60 1.1 (...99)	Marelli IAW 16F.EB
 Punto (176)	ENGINE MANAGEME	55 - 60 1.1 (...99)	Marelli IAW 16F.EB
 Punto (176)	ENGINE MANAGEME	55 - 60 1.1 (...99)	Marelli IAW 6F.SB
 Punto (176)	ENGINE MANAGEME	55 - 60 1.1 (...99)	Marelli IAW 6F.SB
 Punto (176)	ENGINE MANAGEME	55 - 60 1.2 (...99)	Marelli IAW 16F.E3
 Punto (176)	ENGINE MANAGEME	55 - 60 1.2 (...99)	Marelli IAW 16F.E3
 Punto (176)	ENGINE MANAGEME	55 - 60 1.2 (...99)	Marelli IAW 16F.EB
 Punto (176)	ENGINE MANAGEME	55 - 60 1.2 (...99)	Marelli IAW 6F.S3
 Punto (176)	ENGINE MANAGEME	55 - 60 1.2 (...99)	Marelli IAW 6F.S3
 Punto (176)	ENGINE MANAGEME	55 - 60 1.2 (...99)	Marelli IAW 6F.S3
 Punto (176)	ENGINE MANAGEME	75 1.2 (...99)	Marelli IAW 8F.52
 Punto (176)	ENGINE MANAGEME	75 1.2 (...99)	Marelli IAW 8F.5T
 Punto (176)	ENGINE MANAGEME	75 1.2 (...99)	Marelli IAW 8F.5T
 Punto (176)	ENGINE MANAGEME	75 1.2 (...99)	Marelli IAW 8F.5T
 Punto (176)	ENGINE MANAGEME	75 1.2 (...99)	Marelli IAW 8F.5T
 Punto (176)	ENGINE MANAGEME	75 1.2 (...99)	Marelli IAW 8F.5T
 Punto (176)	ENGINE MANAGEME	75 1.2 (...99)	Marelli IAW 8F.5T

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Punto (176)	ENGINE MANAGEME	75 1.2 (...99)	Marelli IAW 8F.5T
 Punto (176)	ENGINE MANAGEME	75 1.2 (...99)	Marelli IAW 8F.5T
 Punto (176)	ENGINE MANAGEME	75 1.2 (...99)	Marelli IAW 8F.5T
 Punto (176)	ENGINE MANAGEME	75 1.2 (...99)	Marelli IAW 8F.5T
 Punto (176)	ENGINE MANAGEME	75 1.2 (98-99)	Marelli IAW 49F
 Punto (176)	ENGINE MANAGEME	85 1.4 (...99)	BOSCH MonoMotronic MA1.7
 Punto (176)	ENGINE MANAGEME	90 1.6 (...99)	BOSCH MonoMotronic MA1.7
 Punto (176)	ENGINE MANAGEME	90 1.6 (...99)	GM MPI Rochester
 Punto (176)	ENGINE MANAGEME	90 1.6 (...99)	GM MPI Rochester
 Punto (176)	ENGINE MANAGEME	90 1.6 (...99)	GM MPI Rochester
 Punto (176)	ENGINE MANAGEME	90 1.6 (...99)	GM MPI Rochester
 Punto (176)	ENGINE MANAGEME	GT 1.4 T (...99)	BOSCH Motronic M2.7
 Punto (176)	ENGINE MANAGEME	GT 1.4 T + Immob. (...99)	BOSCH Motronic M2.7
 Punto (176)	ENGINE MANAGEME	GT 1.4 T + Immob. (...99)	BOSCH Motronic M2.7
 Punto (176)	KEY ENCODE	1.2 16v (...99)	BOSCH CODE MANUAL
 Punto (176)	KEY ENCODE	1.7 D (...99)	BOSCH CODE MANUAL
 Punto (176)	KEY ENCODE	1.7 TD (...99)	BOSCH CODE MANUAL
 Punto (176)	KEY ENCODE	55 - 60 1.1 (...99)	BOSCH CODE MANUAL
 Punto (176)	KEY ENCODE	55 - 60 1.2 (...99)	BOSCH CODE MANUAL
 Punto (176)	KEY ENCODE	75 1.2 (...99)	BOSCH CODE MANUAL
 Punto (176)	KEY ENCODE	85 1.4 (...99)	BOSCH CODE MANUAL
 Punto (176)	KEY ENCODE	90 1.6 (...99)	BOSCH CODE MANUAL
 Punto (176)	KEY ENCODE	GT 1.4 T (...99)	BOSCH CODE MANUAL
 Punto (176)	KEY ENCODE	GT 1.4 T + Immob. (...99)	BOSCH CODE MANUAL
 Punto (176)	MAINTENANCE	1.2 16v (...99)	BOSCH CODE MANUAL
 Punto (176)	MAINTENANCE	1.7 D (...99)	BOSCH CODE MANUAL
 Punto (176)	MAINTENANCE	1.7 TD (...99)	BOSCH CODE MANUAL
 Punto (176)	MAINTENANCE	55 - 60 1.1 (...99)	BOSCH CODE MANUAL
 Punto (176)	MAINTENANCE	55 - 60 1.2 (...99)	BOSCH CODE MANUAL
 Punto (176)	MAINTENANCE	75 1.2 (...99)	BOSCH CODE MANUAL
 Punto (176)	MAINTENANCE	85 1.4 (...99)	BOSCH CODE MANUAL
 Punto (176)	MAINTENANCE	90 1.6 (...99)	BOSCH CODE MANUAL
 Punto (176)	MAINTENANCE	GT 1.4 T (...99)	BOSCH CODE MANUAL
 Punto (176)	MAINTENANCE	GT 1.4 T + Immob. (...99)	BOSCH CODE MANUAL
 Punto (188)	ABS	1.2 16v (03-05)	BOSCH ABS 8
 Punto (188)	ABS	1.2 16v (99-03)	BOSCH ABS 5.3
 Punto (188)	ABS	1.2 8v (03-05)	BOSCH ABS 8
 Punto (188)	ABS	1.2 8v (99-03)	BOSCH ABS 5.3
 Punto (188)	ABS	1.2 8v Natural Power (03-05)	BOSCH ABS 8
 Punto (188)	ABS	1.2 8v Natural Power (99-03)	BOSCH ABS 5.3
 Punto (188)	ABS	1.3 Multijet (03-05)	BOSCH ABS 8
 Punto (188)	ABS	1.3 Multijet (99-03)	BOSCH ABS 5.3
 Punto (188)	ABS	1.4 16v (03-05)	BOSCH ABS 8
 Punto (188)	ABS	1.4 16v (99-03)	BOSCH ABS 5.3
 Punto (188)	ABS	1.8 16v (03-05)	BOSCH ABS 8
 Punto (188)	ABS	1.8 16v (99-03)	BOSCH ABS 5.3
 Punto (188)	ABS	1.8 16v (Abarth) (03-05)	BOSCH ABS 8
 Punto (188)	ABS	1.8 16v (Abarth) (99-03)	BOSCH ABS 5.3
 Punto (188)	ABS	1.9 D (03-05)	BOSCH ABS 8
 Punto (188)	ABS	1.9 D (99-03)	BOSCH ABS 5.3
 Punto (188)	ABS	1.9 JTD (03-05)	BOSCH ABS 8
 Punto (188)	ABS	1.9 JTD (99-03)	BOSCH ABS 5.3
 Punto (188)	ABS	1.9 Multijet (03-05)	BOSCH ABS 8
 Punto (188)	ABS	1.9 Multijet (99-03)	BOSCH ABS 5.3
 Punto (188)	AIRBAG	1.2 16v (03-05)	TRW AirBag MY 97 (2F-I)
 Punto (188)	AIRBAG	1.2 16v (03-05)	TRW AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Punto (188)	AIRBAG	1.2 16v (03-05)	TRW AirBag MY 99 (2F-2P-I-S)
 Punto (188)	AIRBAG	1.2 16v (03-05)	TRW AirBag MY 99 (2F-4P-4L-2T-2I-S)

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Punto (188)	AIRBAG	1.2 16v (99-03)	TRW AirBag MY 97 (2F-2L-I)
 Punto (188)	AIRBAG	1.2 16v (99-03)	TRW AirBag MY 97 (2F-I)
 Punto (188)	AIRBAG	1.2 16v (99-03)	TRW AirBag MY 99 (2F-2L-2T-I)
 Punto (188)	AIRBAG	1.2 8v (03-05)	TRW AirBag MY 97 (2F-I)
 Punto (188)	AIRBAG	1.2 8v (03-05)	TRW AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Punto (188)	AIRBAG	1.2 8v (03-05)	TRW AirBag MY 99 (2F-2P-I-S)
 Punto (188)	AIRBAG	1.2 8v (03-05)	TRW AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Punto (188)	AIRBAG	1.2 8v (99-03)	TRW AirBag MY 97 (2F-2L-I)
 Punto (188)	AIRBAG	1.2 8v (99-03)	TRW AirBag MY 97 (2F-I)
 Punto (188)	AIRBAG	1.2 8v (99-03)	TRW AirBag MY 99 (2F-2L-2T-I)
 Punto (188)	AIRBAG	1.2 8v Natural Power (03-05)	TRW AirBag MY 97 (2F-I)
 Punto (188)	AIRBAG	1.2 8v Natural Power (03-05)	TRW AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Punto (188)	AIRBAG	1.2 8v Natural Power (03-05)	TRW AirBag MY 99 (2F-2P-I-S)
 Punto (188)	AIRBAG	1.2 8v Natural Power (03-05)	TRW AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Punto (188)	AIRBAG	1.2 8v Natural Power (99-03)	TRW AirBag MY 97 (2F-I)
 Punto (188)	AIRBAG	1.2 8v Natural Power (99-03)	TRW AirBag MY 99 (2F-2L-2T-I)
 Punto (188)	AIRBAG	1.3 Multijet (03-05)	TRW AirBag MY 97 (2F-I)
 Punto (188)	AIRBAG	1.3 Multijet (03-05)	TRW AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Punto (188)	AIRBAG	1.3 Multijet (03-05)	TRW AirBag MY 99 (2F-2P-I-S)
 Punto (188)	AIRBAG	1.3 Multijet (03-05)	TRW AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Punto (188)	AIRBAG	1.3 Multijet (99-03)	TRW AirBag MY 97 (2F-I)
 Punto (188)	AIRBAG	1.3 Multijet (99-03)	TRW AirBag MY 99 (2F-2L-2T-I)
 Punto (188)	AIRBAG	1.4 16v (03-05)	TRW AirBag MY 97 (2F-I)
 Punto (188)	AIRBAG	1.4 16v (03-05)	TRW AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Punto (188)	AIRBAG	1.4 16v (03-05)	TRW AirBag MY 99 (2F-2P-I-S)
 Punto (188)	AIRBAG	1.4 16v (03-05)	TRW AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Punto (188)	AIRBAG	1.4 16v (99-03)	TRW AirBag MY 97 (2F-I)
 Punto (188)	AIRBAG	1.4 16v (99-03)	TRW AirBag MY 99 (2F-2L-2T-I)
 Punto (188)	AIRBAG	1.8 16v (03-05)	TRW AirBag MY 97 (2F-I)
 Punto (188)	AIRBAG	1.8 16v (03-05)	TRW AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Punto (188)	AIRBAG	1.8 16v (03-05)	TRW AirBag MY 99 (2F-2P-I-S)
 Punto (188)	AIRBAG	1.8 16v (03-05)	TRW AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Punto (188)	AIRBAG	1.8 16v (99-03)	TRW AirBag MY 97 (2F-I)
 Punto (188)	AIRBAG	1.8 16v (99-03)	TRW AirBag MY 99 (2F-2L-2T-I)
 Punto (188)	AIRBAG	1.8 16v (Abarth) (03-05)	TRW AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Punto (188)	AIRBAG	1.8 16v (Abarth) (03-05)	TRW AirBag MY 99 (2F-2P-I-S)
 Punto (188)	AIRBAG	1.8 16v (Abarth) (03-05)	TRW AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Punto (188)	AIRBAG	1.8 16v (Abarth) (99-03)	TRW AirBag MY 97 (2F-2L-I)
 Punto (188)	AIRBAG	1.8 16v (Abarth) (99-03)	TRW AirBag MY 97 (2F-I)
 Punto (188)	AIRBAG	1.8 16v (Abarth) (99-03)	TRW AirBag MY 99 (2F-2L-2T-I)
 Punto (188)	AIRBAG	1.9 D (03-05)	TRW AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Punto (188)	AIRBAG	1.9 D (03-05)	TRW AirBag MY 99 (2F-2P-I-S)
 Punto (188)	AIRBAG	1.9 D (03-05)	TRW AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Punto (188)	AIRBAG	1.9 D (99-03)	TRW AirBag MY 97 (2F-2L-I)
 Punto (188)	AIRBAG	1.9 D (99-03)	TRW AirBag MY 97 (2F-I)
 Punto (188)	AIRBAG	1.9 D (99-03)	TRW AirBag MY 99 (2F-2L-2T-I)
 Punto (188)	AIRBAG	1.9 JTD (03-05)	TRW AirBag MY 97 (2F-I)
 Punto (188)	AIRBAG	1.9 JTD (03-05)	TRW AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Punto (188)	AIRBAG	1.9 JTD (03-05)	TRW AirBag MY 99 (2F-2P-I-S)
 Punto (188)	AIRBAG	1.9 JTD (03-05)	TRW AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Punto (188)	AIRBAG	1.9 JTD (99-03)	TRW AirBag MY 97 (2F-2L-I)
 Punto (188)	AIRBAG	1.9 JTD (99-03)	TRW AirBag MY 97 (2F-I)
 Punto (188)	AIRBAG	1.9 JTD (99-03)	TRW AirBag MY 99 (2F-2L-2T-I)
 Punto (188)	AIRBAG	1.9 Multijet (03-05)	TRW AirBag MY 97 (2F-I)
 Punto (188)	AIRBAG	1.9 Multijet (03-05)	TRW AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Punto (188)	AIRBAG	1.9 Multijet (03-05)	TRW AirBag MY 99 (2F-2P-I-S)
 Punto (188)	AIRBAG	1.9 Multijet (03-05)	TRW AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Punto (188)	AIRBAG	1.9 Multijet (99-03)	TRW AirBag MY 97 (2F-I)

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Puncto (188)	AIRBAG	1.9 Multijet (99-03)	TRW AirBag MY 99 (2F-2L-2T-I)
 Puncto (188)	AUTOM. TRANSMISSI	1.2 16v (01-03)	Marelli Selespeed CFC208F
 Puncto (188)	AUTOM. TRANSMISSI	1.2 16v (01-03)	Marelli Selespeed CFC228F
 Puncto (188)	AUTOM. TRANSMISSI	1.2 16v (03-05)	Marelli Selespeed CFC208F
 Puncto (188)	AUTOM. TRANSMISSI	1.2 16v (03-05)	Marelli Selespeed CFC228F
 Puncto (188)	AUTOM. TRANSMISSI	1.2 16v (99-01)	Marelli Selespeed CFC208F
 Puncto (188)	AUTOM. TRANSMISSI	1.2 16v (99-01)	Marelli Selespeed CFC228F
 Puncto (188)	AUTOM. TRANSMISSI	1.2 16v (99-03)	Marelli Selespeed CFC208F
 Puncto (188)	AUTOM. TRANSMISSI	1.2 16v (99-03)	Marelli Selespeed CFC228F
 Puncto (188)	AUTOM. TRANSMISSI	1.2 8v (01-03)	Marelli Selespeed CFC208F
 Puncto (188)	AUTOM. TRANSMISSI	1.2 8v (01-03)	Marelli Selespeed CFC228F
 Puncto (188)	AUTOM. TRANSMISSI	1.2 8v (03-05)	Marelli Selespeed CFC208F
 Puncto (188)	AUTOM. TRANSMISSI	1.2 8v (03-05)	Marelli Selespeed CFC228F
 Puncto (188)	AUTOM. TRANSMISSI	1.2 8v (99-03)	Marelli Selespeed CFC208F
 Puncto (188)	AUTOM. TRANSMISSI	1.2 8v (99-03)	Marelli Selespeed CFC228F
 Puncto (188)	AUTOM. TRANSMISSI	1.2 8v Natural Power (03-05)	Marelli Selespeed CFC208F
 Puncto (188)	AUTOM. TRANSMISSI	1.2 8v Natural Power (03-05)	Marelli Selespeed CFC228F
 Puncto (188)	AUTOM. TRANSMISSI	1.3 Multijet (03-05)	Marelli Selespeed CFC208F
 Puncto (188)	AUTOM. TRANSMISSI	1.3 Multijet (03-05)	Marelli Selespeed CFC228F
 Puncto (188)	AUTOM. TRANSMISSI	1.4 16v (03-05)	Marelli Selespeed CFC208F
 Puncto (188)	AUTOM. TRANSMISSI	1.4 16v (03-05)	Marelli Selespeed CFC228F
 Puncto (188)	AUTOM. TRANSMISSI	1.8 16v (01-..)	Marelli Selespeed CFC208F
 Puncto (188)	AUTOM. TRANSMISSI	1.8 16v (01-..)	Marelli Selespeed CFC228F
 Puncto (188)	AUTOM. TRANSMISSI	1.8 16v (Abarth) (99-03)	Marelli Selespeed CFC208F
 Puncto (188)	AUTOM. TRANSMISSI	1.8 16v (Abarth) (99-03)	Marelli Selespeed CFC228F
 Puncto (188)	AUTOM. TRANSMISSI	1.9 JTD (03-05)	Marelli Selespeed CFC208F
 Puncto (188)	AUTOM. TRANSMISSI	1.9 JTD (03-05)	Marelli Selespeed CFC228F
 Puncto (188)	AUTOM. TRANSMISSI	1.9 JTD (99-03)	Marelli Selespeed CFC208F
 Puncto (188)	AUTOM. TRANSMISSI	1.9 JTD (99-03)	Marelli Selespeed CFC228F
 Puncto (188)	AUTOM. TRANSMISSI	1.9 Multijet (03-05)	Marelli Selespeed CFC208F
 Puncto (188)	AUTOM. TRANSMISSI	1.9 Multijet (03-05)	Marelli Selespeed CFC228F
 Puncto (188)	CHASSIS NETWORK	1.2 16v (03-05)	DELPHI/Marelli Body Computer
 Puncto (188)	CHASSIS NETWORK	1.2 16v (03-05)	Fiat CAN Info
 Puncto (188)	CHASSIS NETWORK	1.2 16v (03-05)	Fiat Proxi Alignement
 Puncto (188)	CHASSIS NETWORK	1.2 16v (99-03)	DELPHI/Marelli Body Computer
 Puncto (188)	CHASSIS NETWORK	1.2 16v (99-03)	Fiat CAN Info
 Puncto (188)	CHASSIS NETWORK	1.2 16v (99-03)	Fiat Proxi Alignement
 Puncto (188)	CHASSIS NETWORK	1.2 8v (03-05)	DELPHI/Marelli Body Computer
 Puncto (188)	CHASSIS NETWORK	1.2 8v (03-05)	Fiat CAN Info
 Puncto (188)	CHASSIS NETWORK	1.2 8v (03-05)	Fiat Proxi Alignement
 Puncto (188)	CHASSIS NETWORK	1.2 8v (99-03)	DELPHI/Marelli Body Computer
 Puncto (188)	CHASSIS NETWORK	1.2 8v (99-03)	Fiat Proxi Alignement
 Puncto (188)	CHASSIS NETWORK	1.2 8v Natural Power (03-05)	DELPHI/Marelli Body Computer
 Puncto (188)	CHASSIS NETWORK	1.2 8v Natural Power (03-05)	Fiat CAN Info
 Puncto (188)	CHASSIS NETWORK	1.2 8v Natural Power (03-05)	Fiat Proxi Alignement
 Puncto (188)	CHASSIS NETWORK	1.2 8v Natural Power (99-03)	DELPHI/Marelli Body Computer
 Puncto (188)	CHASSIS NETWORK	1.2 8v Natural Power (99-03)	Fiat Proxi Alignement
 Puncto (188)	CHASSIS NETWORK	1.3 Multijet (03-05)	DELPHI/Marelli Body Computer
 Puncto (188)	CHASSIS NETWORK	1.3 Multijet (03-05)	Fiat CAN Info
 Puncto (188)	CHASSIS NETWORK	1.3 Multijet (03-05)	Fiat Proxi Alignement
 Puncto (188)	CHASSIS NETWORK	1.3 Multijet (99-03)	DELPHI/Marelli Body Computer
 Puncto (188)	CHASSIS NETWORK	1.3 Multijet (99-03)	Fiat Proxi Alignement
 Puncto (188)	CHASSIS NETWORK	1.4 16v (03-05)	DELPHI/Marelli Body Computer
 Puncto (188)	CHASSIS NETWORK	1.4 16v (03-05)	Fiat CAN Info
 Puncto (188)	CHASSIS NETWORK	1.4 16v (03-05)	Fiat Proxi Alignement
 Puncto (188)	CHASSIS NETWORK	1.4 16v (99-03)	DELPHI/Marelli Body Computer
 Puncto (188)	CHASSIS NETWORK	1.4 16v (99-03)	Fiat Proxi Alignement
 Puncto (188)	CHASSIS NETWORK	1.8 16v (03-05)	DELPHI/Marelli Body Computer

Systems supported by ECUREADER / ECUDECODER (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 PUNTO (188)	CHASSIS NETWORK	1.8 16v (03-05)	Fiat CAN Info
 PUNTO (188)	CHASSIS NETWORK	1.8 16v (03-05)	Fiat Proxi Alignement
 PUNTO (188)	CHASSIS NETWORK	1.8 16v (99-03)	DELPHI/Marelli Body Computer
 PUNTO (188)	CHASSIS NETWORK	1.8 16v (99-03)	Fiat Proxi Alignement
 PUNTO (188)	CHASSIS NETWORK	1.8 16v (Abarth) (03-05)	DELPHI/Marelli Body Computer
 PUNTO (188)	CHASSIS NETWORK	1.8 16v (Abarth) (03-05)	Fiat Proxi Alignement
 PUNTO (188)	CHASSIS NETWORK	1.8 16v (Abarth) (99-03)	DELPHI/Marelli Body Computer
 PUNTO (188)	CHASSIS NETWORK	1.8 16v (Abarth) (99-03)	Fiat CAN Info
 PUNTO (188)	CHASSIS NETWORK	1.8 16v (Abarth) (99-03)	Fiat Proxi Alignement
 PUNTO (188)	CHASSIS NETWORK	1.9 D (03-05)	DELPHI/Marelli Body Computer
 PUNTO (188)	CHASSIS NETWORK	1.9 D (03-05)	Fiat Proxi Alignement
 PUNTO (188)	CHASSIS NETWORK	1.9 D (99-03)	DELPHI/Marelli Body Computer
 PUNTO (188)	CHASSIS NETWORK	1.9 D (99-03)	Fiat CAN Info
 PUNTO (188)	CHASSIS NETWORK	1.9 D (99-03)	Fiat Proxi Alignement
 PUNTO (188)	CHASSIS NETWORK	1.9 JTD (03-05)	DELPHI/Marelli Body Computer
 PUNTO (188)	CHASSIS NETWORK	1.9 JTD (03-05)	Fiat CAN Info
 PUNTO (188)	CHASSIS NETWORK	1.9 JTD (03-05)	Fiat Proxi Alignement
 PUNTO (188)	CHASSIS NETWORK	1.9 JTD (99-03)	DELPHI/Marelli Body Computer
 PUNTO (188)	CHASSIS NETWORK	1.9 JTD (99-03)	Fiat CAN Info
 PUNTO (188)	CHASSIS NETWORK	1.9 JTD (99-03)	Fiat Proxi Alignement
 PUNTO (188)	CHASSIS NETWORK	1.9 Multijet (03-05)	DELPHI/Marelli Body Computer
 PUNTO (188)	CHASSIS NETWORK	1.9 Multijet (03-05)	Fiat CAN Info
 PUNTO (188)	CHASSIS NETWORK	1.9 Multijet (03-05)	Fiat Proxi Alignement
 PUNTO (188)	CHASSIS NETWORK	1.9 Multijet (99-03)	DELPHI/Marelli Body Computer
 PUNTO (188)	CHASSIS NETWORK	1.9 Multijet (99-03)	Fiat Proxi Alignement
 PUNTO (188)	CLIMA	1.2 16v (03-05)	DENSO 2
 PUNTO (188)	CLIMA	1.2 8v (03-05)	DENSO 2
 PUNTO (188)	CLIMA	1.2 8v Natural Power (03-05)	DENSO 2
 PUNTO (188)	CLIMA	1.3 Multijet (03-05)	DENSO 2
 PUNTO (188)	CLIMA	1.4 16v (03-05)	DENSO 2
 PUNTO (188)	CLIMA	1.8 16v (03-05)	DENSO 2
 PUNTO (188)	CLIMA	1.9 JTD (03-05)	DENSO 2
 PUNTO (188)	CLIMA	1.9 Multijet (03-05)	DENSO 2
 PUNTO (188)	DASHBOARD	1.2 16v (03-05)	Marelli Dashboard Comfort
 PUNTO (188)	DASHBOARD	1.2 16v (03-05)	Marelli Dashboard Strip/Modale
 PUNTO (188)	DASHBOARD	1.2 16v (99-03)	VEGLIA/Marelli Dashboard
 PUNTO (188)	DASHBOARD	1.2 8v (03-05)	Marelli Dashboard Comfort
 PUNTO (188)	DASHBOARD	1.2 8v (03-05)	Marelli Dashboard Strip/Modale
 PUNTO (188)	DASHBOARD	1.2 8v (99-03)	VEGLIA/Marelli Dashboard
 PUNTO (188)	DASHBOARD	1.2 8v Natural Power (03-05)	Marelli Dashboard Comfort
 PUNTO (188)	DASHBOARD	1.2 8v Natural Power (03-05)	Marelli Dashboard Strip/Modale
 PUNTO (188)	DASHBOARD	1.2 8v Natural Power (99-03)	VEGLIA/Marelli Dashboard
 PUNTO (188)	DASHBOARD	1.3 Multijet (03-05)	Marelli Dashboard Comfort
 PUNTO (188)	DASHBOARD	1.3 Multijet (03-05)	Marelli Dashboard Strip/Modale
 PUNTO (188)	DASHBOARD	1.3 Multijet (99-03)	VEGLIA/Marelli Dashboard
 PUNTO (188)	DASHBOARD	1.4 16v (03-05)	Marelli Dashboard Comfort
 PUNTO (188)	DASHBOARD	1.4 16v (03-05)	Marelli Dashboard Strip/Modale
 PUNTO (188)	DASHBOARD	1.4 16v (99-03)	VEGLIA/Marelli Dashboard
 PUNTO (188)	DASHBOARD	1.8 16v (03-05)	Marelli Dashboard Comfort
 PUNTO (188)	DASHBOARD	1.8 16v (03-05)	Marelli Dashboard Strip/Modale
 PUNTO (188)	DASHBOARD	1.8 16v (99-03)	VEGLIA/Marelli Dashboard
 PUNTO (188)	DASHBOARD	1.8 16v (Abarth) (03-05)	Marelli Dashboard Strip/Modale
 PUNTO (188)	DASHBOARD	1.8 16v (Abarth) (99-03)	VEGLIA/Marelli Dashboard
 PUNTO (188)	DASHBOARD	1.8 16v (Abarth) (99-03)	VEGLIA/Marelli Dashboard
 PUNTO (188)	DASHBOARD	1.9 D (03-05)	Marelli Dashboard Comfort
 PUNTO (188)	DASHBOARD	1.9 D (03-05)	Marelli Dashboard Strip/Modale
 PUNTO (188)	DASHBOARD	1.9 D (99-03)	VEGLIA/Marelli Dashboard
 PUNTO (188)	DASHBOARD	1.9 JTD (03-05)	Marelli Dashboard Comfort

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Punto (188)	DASHBOARD	1.9 JTD (03-05)	Marelli Dashboard Strip/Modale
 Punto (188)	DASHBOARD	1.9 JTD (99-03)	VEGLIA/Marelli Dashboard
 Punto (188)	DASHBOARD	1.9 Multijet (03-05)	Marelli Dashboard Comfort
 Punto (188)	DASHBOARD	1.9 Multijet (03-05)	Marelli Dashboard Strip/Modale
 Punto (188)	DASHBOARD	1.9 Multijet (99-03)	VEGLIA/Marelli Dashboard
 Punto (188)	DIESEL MANAGEME	1.9 D (99-03)	LUCAS EPIC DCU3F
 Punto (188)	ELECTRIC STEERING	1.2 16v (03-05)	DELPHI EPS
 Punto (188)	ELECTRIC STEERING	1.2 16v (99-03)	DELPHI EPS
 Punto (188)	ELECTRIC STEERING	1.2 8v (03-05)	DELPHI EPS
 Punto (188)	ELECTRIC STEERING	1.2 8v (99-03)	DELPHI EPS
 Punto (188)	ELECTRIC STEERING	1.2 8v Natural Power (03-05)	DELPHI EPS
 Punto (188)	ELECTRIC STEERING	1.2 8v Natural Power (99-03)	DELPHI EPS
 Punto (188)	ELECTRIC STEERING	1.3 Multijet (03-05)	DELPHI EPS
 Punto (188)	ELECTRIC STEERING	1.3 Multijet (99-03)	DELPHI EPS
 Punto (188)	ELECTRIC STEERING	1.4 16v (03-05)	DELPHI EPS
 Punto (188)	ELECTRIC STEERING	1.4 16v (99-03)	DELPHI EPS
 Punto (188)	ELECTRIC STEERING	1.8 16v (03-05)	DELPHI EPS
 Punto (188)	ELECTRIC STEERING	1.8 16v (99-03)	DELPHI EPS
 Punto (188)	ELECTRIC STEERING	1.8 16v (Abarth) (03-05)	DELPHI EPS
 Punto (188)	ELECTRIC STEERING	1.8 16v (Abarth) (99-03)	DELPHI EPS
 Punto (188)	ELECTRIC STEERING	1.9 D (03-05)	DELPHI EPS
 Punto (188)	ELECTRIC STEERING	1.9 D (99-03)	DELPHI EPS
 Punto (188)	ELECTRIC STEERING	1.9 JTD (03-05)	DELPHI EPS
 Punto (188)	ELECTRIC STEERING	1.9 JTD (99-03)	DELPHI EPS
 Punto (188)	ELECTRIC STEERING	1.9 Multijet (03-05)	DELPHI EPS
 Punto (188)	ELECTRIC STEERING	1.9 Multijet (99-03)	DELPHI EPS
 Punto (188)	ENGINE MANAGEME	1.2 16v (01-03)	BOSCH Motronic ME7.3H4 EOBD
 Punto (188)	ENGINE MANAGEME	1.2 16v (03-05)	BOSCH Motronic ME7.3H4 EOBD
 Punto (188)	ENGINE MANAGEME	1.2 16v (99-01)	BOSCH Motronic ME7.3 H4
 Punto (188)	ENGINE MANAGEME	1.2 16v (99-03)	BOSCH Motronic Throttle Pos. Learning MA
 Punto (188)	ENGINE MANAGEME	1.2 8v (01-03)	Marelli IAW 49F/59F EOBD
 Punto (188)	ENGINE MANAGEME	1.2 8v (03-05)	Marelli IAW 5AF
 Punto (188)	ENGINE MANAGEME	1.2 8v (03-05)	Marelli IAW 5AF NY
 Punto (188)	ENGINE MANAGEME	1.2 8v (99-03)	Marelli IAW 59F
 Punto (188)	ENGINE MANAGEME	1.2 8v Natural Power (03-05)	Marelli IAW 5AF
 Punto (188)	ENGINE MANAGEME	1.3 Multijet (03-05)	Marelli 6JF CF3 Common Rail
 Punto (188)	ENGINE MANAGEME	1.4 16v (03-05)	BOSCH Motronic ME7.3H4M EOBD
 Punto (188)	ENGINE MANAGEME	1.8 16v (01-..)	EOBD
 Punto (188)	ENGINE MANAGEME	1.8 16v (Abarth) (99-03)	HITACHI MPI MFI '98
 Punto (188)	ENGINE MANAGEME	1.9 JTD (03-05)	BOSCH EDC 15 Common Rail (JTD '99)
 Punto (188)	ENGINE MANAGEME	1.9 JTD (99-03)	BOSCH EDC 15 Common Rail (JTD '99)
 Punto (188)	ENGINE MANAGEME	1.9 JTD (99-03)	BOSCH EDC 15 Common Rail (JTD '99)
 Punto (188)	ENGINE MANAGEME	1.9 Multijet (03-05)	BOSCH EDC 16 Common Rail
 Punto (188)	ENGINE MANAGEME	1.2 8v Natural Power (03-05)	METATRON 6A0 EOBD
 Punto (188)	KEY ENCODE	1.2 16v (99-03)	DELPHI/Marelli CODE Body Computer
 Punto (188)	KEY ENCODE	1.2 8v (03-05)	DELPHI/Marelli CODE Body Computer
 Punto (188)	KEY ENCODE	1.2 8v Natural Power (03-05)	DELPHI/Marelli CODE Body Computer
 Punto (188)	KEY ENCODE	1.3 Multijet (03-05)	DELPHI/Marelli CODE Body Computer
 Punto (188)	KEY ENCODE	1.4 16v (03-05)	DELPHI/Marelli CODE Body Computer
 Punto (188)	KEY ENCODE	1.8 16v (03-05)	DELPHI/Marelli CODE Body Computer
 Punto (188)	KEY ENCODE	1.8 16v (Abarth) (99-03)	DELPHI/Marelli CODE Body Computer
 Punto (188)	KEY ENCODE	1.9 D (99-03)	DELPHI/Marelli CODE Body Computer
 Punto (188)	KEY ENCODE	1.9 JTD (03-05)	DELPHI/Marelli CODE Body Computer
 Punto (188)	KEY ENCODE	1.9 Multijet (03-05)	DELPHI/Marelli CODE Body Computer
 Punto (188)	MAINTENANCE	1.2 16v (01-03)	Marelli Selespeed CFC208F
 Punto (188)	MAINTENANCE	1.2 16v (01-03)	Marelli Selespeed CFC208F
 Punto (188)	MAINTENANCE	1.2 16v (01-03)	Marelli Selespeed CFC228F
 Punto (188)	MAINTENANCE	1.2 16v (03-05)	DELPHI EPS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Punto (188)	MAINTENANCE	1.2 16v (03-05)	Marelli Dashboard
 Punto (188)	MAINTENANCE	1.2 16v (03-05)	Marelli Dashboard Comfort
 Punto (188)	MAINTENANCE	1.2 16v (03-05)	Marelli Dashboard Comfort
 Punto (188)	MAINTENANCE	1.2 16v (03-05)	Marelli Dashboard Strip/Modale
 Punto (188)	MAINTENANCE	1.2 16v (03-05)	Marelli Selespeed CFC208F
 Punto (188)	MAINTENANCE	1.2 16v (03-05)	Marelli Selespeed CFC208F
 Punto (188)	MAINTENANCE	1.2 16v (03-05)	Marelli Selespeed CFC228F
 Punto (188)	MAINTENANCE	1.2 16v (99-01)	Marelli Selespeed CFC208F
 Punto (188)	MAINTENANCE	1.2 16v (99-01)	Marelli Selespeed CFC208F
 Punto (188)	MAINTENANCE	1.2 16v (99-01)	Marelli Selespeed CFC228F
 Punto (188)	MAINTENANCE	1.2 16v (99-03)	BOSCH Motronic Throttle Pos. Learning MA
 Punto (188)	MAINTENANCE	1.2 16v (99-03)	DELPHI EPS
 Punto (188)	MAINTENANCE	1.2 16v (99-03)	Marelli Selespeed CFC208F
 Punto (188)	MAINTENANCE	1.2 16v (99-03)	Marelli Selespeed CFC208F
 Punto (188)	MAINTENANCE	1.2 16v (99-03)	Marelli Selespeed CFC228F
 Punto (188)	MAINTENANCE	1.2 8v (01-03)	Marelli Selespeed CFC208F
 Punto (188)	MAINTENANCE	1.2 8v (01-03)	Marelli Selespeed CFC208F
 Punto (188)	MAINTENANCE	1.2 8v (01-03)	Marelli Selespeed CFC228F
 Punto (188)	MAINTENANCE	1.2 8v (03-05)	DELPHI EPS
 Punto (188)	MAINTENANCE	1.2 8v (03-05)	Marelli Dashboard
 Punto (188)	MAINTENANCE	1.2 8v (03-05)	Marelli Dashboard Comfort
 Punto (188)	MAINTENANCE	1.2 8v (03-05)	Marelli Dashboard Comfort
 Punto (188)	MAINTENANCE	1.2 8v (03-05)	Marelli Dashboard Strip/Modale
 Punto (188)	MAINTENANCE	1.2 8v (03-05)	Marelli IAW 5AF
 Punto (188)	MAINTENANCE	1.2 8v (03-05)	Marelli IAW 5AF NY
 Punto (188)	MAINTENANCE	1.2 8v (03-05)	Marelli Selespeed CFC208F
 Punto (188)	MAINTENANCE	1.2 8v (03-05)	Marelli Selespeed CFC208F
 Punto (188)	MAINTENANCE	1.2 8v (03-05)	Marelli Selespeed CFC208F
 Punto (188)	MAINTENANCE	1.2 8v (03-05)	Marelli Selespeed CFC228F
 Punto (188)	MAINTENANCE	1.2 8v (03-05)	DELPHI EPS
 Punto (188)	MAINTENANCE	1.2 8v (99-03)	Marelli Selespeed CFC208F
 Punto (188)	MAINTENANCE	1.2 8v (99-03)	Marelli Selespeed CFC208F
 Punto (188)	MAINTENANCE	1.2 8v (99-03)	Marelli Selespeed CFC228F
 Punto (188)	MAINTENANCE	1.2 8v Natural Power (03-05)	DELPHI EPS
 Punto (188)	MAINTENANCE	1.2 8v Natural Power (03-05)	Marelli Dashboard
 Punto (188)	MAINTENANCE	1.2 8v Natural Power (03-05)	Marelli Dashboard Comfort
 Punto (188)	MAINTENANCE	1.2 8v Natural Power (03-05)	Marelli Dashboard Comfort
 Punto (188)	MAINTENANCE	1.2 8v Natural Power (03-05)	Marelli Dashboard Strip/Modale
 Punto (188)	MAINTENANCE	1.2 8v Natural Power (03-05)	Marelli IAW 5AF
 Punto (188)	MAINTENANCE	1.2 8v Natural Power (03-05)	Marelli Selespeed CFC208F
 Punto (188)	MAINTENANCE	1.2 8v Natural Power (03-05)	Marelli Selespeed CFC208F
 Punto (188)	MAINTENANCE	1.2 8v Natural Power (03-05)	Marelli Selespeed CFC228F
 Punto (188)	MAINTENANCE	1.2 8v Natural Power (99-03)	DELPHI EPS
 Punto (188)	MAINTENANCE	1.3 Multijet (03-05)	DELPHI EPS
 Punto (188)	MAINTENANCE	1.3 Multijet (03-05)	Marelli Dashboard
 Punto (188)	MAINTENANCE	1.3 Multijet (03-05)	Marelli Dashboard Comfort
 Punto (188)	MAINTENANCE	1.3 Multijet (03-05)	Marelli Dashboard Comfort
 Punto (188)	MAINTENANCE	1.3 Multijet (03-05)	Marelli Dashboard Strip/Modale
 Punto (188)	MAINTENANCE	1.3 Multijet (03-05)	Marelli Selespeed CFC208F
 Punto (188)	MAINTENANCE	1.3 Multijet (03-05)	Marelli Selespeed CFC208F
 Punto (188)	MAINTENANCE	1.3 Multijet (03-05)	Marelli Selespeed CFC228F
 Punto (188)	MAINTENANCE	1.3 Multijet (99-03)	DELPHI EPS
 Punto (188)	MAINTENANCE	1.4 16v (03-05)	DELPHI EPS
 Punto (188)	MAINTENANCE	1.4 16v (03-05)	Marelli Dashboard
 Punto (188)	MAINTENANCE	1.4 16v (03-05)	Marelli Dashboard Comfort
 Punto (188)	MAINTENANCE	1.4 16v (03-05)	Marelli Dashboard Comfort
 Punto (188)	MAINTENANCE	1.4 16v (03-05)	Marelli Dashboard Strip/Modale
 Punto (188)	MAINTENANCE	1.4 16v (03-05)	Marelli Selespeed CFC208F

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Punto (188)	MAINTENANCE	1.4 16v (03-05)	Marelli Selespeed CFC208F
 Punto (188)	MAINTENANCE	1.4 16v (03-05)	Marelli Selespeed CFC228F
 Punto (188)	MAINTENANCE	1.4 16v (99-03)	DELPHI EPS
 Punto (188)	MAINTENANCE	1.8 16v (01-..)	Marelli Selespeed CFC208F
 Punto (188)	MAINTENANCE	1.8 16v (01-..)	Marelli Selespeed CFC208F
 Punto (188)	MAINTENANCE	1.8 16v (01-..)	Marelli Selespeed CFC228F
 Punto (188)	MAINTENANCE	1.8 16v (03-05)	DELPHI EPS
 Punto (188)	MAINTENANCE	1.8 16v (03-05)	Marelli Dashboard
 Punto (188)	MAINTENANCE	1.8 16v (03-05)	Marelli Dashboard Comfort
 Punto (188)	MAINTENANCE	1.8 16v (03-05)	Marelli Dashboard Comfort
 Punto (188)	MAINTENANCE	1.8 16v (03-05)	Marelli Dashboard Strip/Modale
 Punto (188)	MAINTENANCE	1.8 16v (99-03)	DELPHI EPS
 Punto (188)	MAINTENANCE	1.8 16v (Abarth) (03-05)	DELPHI EPS
 Punto (188)	MAINTENANCE	1.8 16v (Abarth) (03-05)	Marelli Dashboard Strip/Modale
 Punto (188)	MAINTENANCE	1.8 16v (Abarth) (99-03)	DELPHI EPS
 Punto (188)	MAINTENANCE	1.8 16v (Abarth) (99-03)	Marelli Selespeed CFC208F
 Punto (188)	MAINTENANCE	1.8 16v (Abarth) (99-03)	Marelli Selespeed CFC208F
 Punto (188)	MAINTENANCE	1.8 16v (Abarth) (99-03)	Marelli Selespeed CFC228F
 Punto (188)	MAINTENANCE	1.9 D (03-05)	DELPHI EPS
 Punto (188)	MAINTENANCE	1.9 D (03-05)	Marelli Dashboard Comfort
 Punto (188)	MAINTENANCE	1.9 D (03-05)	Marelli Dashboard Comfort
 Punto (188)	MAINTENANCE	1.9 D (03-05)	Marelli Dashboard Strip/Modale
 Punto (188)	MAINTENANCE	1.9 D (99-03)	DELPHI EPS
 Punto (188)	MAINTENANCE	1.9 JTD (03-05)	DELPHI EPS
 Punto (188)	MAINTENANCE	1.9 JTD (03-05)	Marelli Dashboard
 Punto (188)	MAINTENANCE	1.9 JTD (03-05)	Marelli Dashboard Comfort
 Punto (188)	MAINTENANCE	1.9 JTD (03-05)	Marelli Dashboard Comfort
 Punto (188)	MAINTENANCE	1.9 JTD (03-05)	Marelli Dashboard Strip/Modale
 Punto (188)	MAINTENANCE	1.9 JTD (03-05)	Marelli Selespeed CFC208F
 Punto (188)	MAINTENANCE	1.9 JTD (03-05)	Marelli Selespeed CFC208F
 Punto (188)	MAINTENANCE	1.9 JTD (03-05)	Marelli Selespeed CFC228F
 Punto (188)	MAINTENANCE	1.9 JTD (99-03)	DELPHI EPS
 Punto (188)	MAINTENANCE	1.9 JTD (99-03)	Marelli Selespeed CFC208F
 Punto (188)	MAINTENANCE	1.9 JTD (99-03)	Marelli Selespeed CFC208F
 Punto (188)	MAINTENANCE	1.9 JTD (99-03)	Marelli Selespeed CFC228F
 Punto (188)	MAINTENANCE	1.9 Multijet (03-05)	BOSCH EDC 16 Common Rail
 Punto (188)	MAINTENANCE	1.9 Multijet (03-05)	BOSCH EDC 16 Common Rail
 Punto (188)	MAINTENANCE	1.9 Multijet (03-05)	DELPHI EPS
 Punto (188)	MAINTENANCE	1.9 Multijet (03-05)	Marelli Dashboard
 Punto (188)	MAINTENANCE	1.9 Multijet (03-05)	Marelli Dashboard Comfort
 Punto (188)	MAINTENANCE	1.9 Multijet (03-05)	Marelli Dashboard Comfort
 Punto (188)	MAINTENANCE	1.9 Multijet (03-05)	Marelli Dashboard Strip/Modale
 Punto (188)	MAINTENANCE	1.9 Multijet (03-05)	Marelli Selespeed CFC208F
 Punto (188)	MAINTENANCE	1.9 Multijet (03-05)	Marelli Selespeed CFC208F
 Punto (188)	MAINTENANCE	1.9 Multijet (03-05)	Marelli Selespeed CFC228F
 Punto (188)	MAINTENANCE	1.9 Multijet (99-03)	DELPHI EPS
 Punto (188)	SERVICE LIGHT RES	1.2 16v (03-05)	Marelli Dashboard
 Punto (188)	SERVICE LIGHT RES	1.2 8v (03-05)	Marelli Dashboard
 Punto (188)	SERVICE LIGHT RES	1.2 8v Natural Power (03-05)	Marelli Dashboard
 Punto (188)	SERVICE LIGHT RES	1.3 Multijet (03-05)	Marelli Dashboard
 Punto (188)	SERVICE LIGHT RES	1.4 16v (03-05)	Marelli Dashboard
 Punto (188)	SERVICE LIGHT RES	1.8 16v (03-05)	Marelli Dashboard
 Punto (188)	SERVICE LIGHT RES	1.9 JTD (03-05)	Marelli Dashboard
 Punto (188)	SERVICE LIGHT RES	1.9 Multijet (03-05)	Marelli Dashboard
 Punto (199)-Grande Punto	ABS + TRACT. CONT	1.2 8v (05-09)	Bosch ESP 8
 Punto (199)-Grande Punto	ABS + TRACT. CONT	1.3 Multijet 75cv (05-09)	Bosch ESP 8
 Punto (199)-Grande Punto	ABS + TRACT. CONT	1.3 Multijet 90cv (05-09)	Bosch ESP 8
 Punto (199)-Grande Punto	ABS + TRACT. CONT	1.4 16v (05-09)	Bosch ESP 8

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Punto (199)-Grande Punto	ABS + TRACT. CONT	1.4 8v (05-09)	Bosch ESP 8
 Punto (199)-Grande Punto	ABS + TRACT. CONT	1.4 8v Natural Power (05-09)	Bosch ESP 8
 Punto (199)-Grande Punto	ABS + TRACT. CONT	1.4 T-JET 16v (05-09)	Bosch ESP 8
 Punto (199)-Grande Punto	ABS + TRACT. CONT	1.6 MJET 16v (05-09)	Bosch ESP 8
 Punto (199)-Grande Punto	ABS + TRACT. CONT	1.9 Multijet 120cv (05-09)	Bosch ESP 8
 Punto (199)-Grande Punto	ABS + TRACT. CONT	1.9 Multijet 130cv (05-09)	Bosch ESP 8
 Punto (199)-Grande Punto	AIRBAG	1.2 8v (05-09)	TRW SRS EP
 Punto (199)-Grande Punto	AIRBAG	1.3 Multijet 75cv (05-09)	TRW SRS EP
 Punto (199)-Grande Punto	AIRBAG	1.3 Multijet 90cv (05-09)	TRW SRS EP
 Punto (199)-Grande Punto	AIRBAG	1.4 16v (05-09)	TRW SRS EP
 Punto (199)-Grande Punto	AIRBAG	1.4 8v (05-09)	TRW SRS EP
 Punto (199)-Grande Punto	AIRBAG	1.4 8v Natural Power (05-09)	TRW SRS EP
 Punto (199)-Grande Punto	AIRBAG	1.4 T-JET 16v (05-09)	TRW SRS EP
 Punto (199)-Grande Punto	AIRBAG	1.6 MJET 16v (05-09)	TRW SRS EP
 Punto (199)-Grande Punto	AIRBAG	1.9 Multijet 120cv (05-09)	TRW SRS EP
 Punto (199)-Grande Punto	AIRBAG	1.9 Multijet 130cv (05-09)	TRW SRS EP
 Punto (199)-Grande Punto	AUTOM. TRANSMISSI	1.2 8v (05-09)	Marelli Selespeed CFC328 - 2
 Punto (199)-Grande Punto	AUTOM. TRANSMISSI	1.3 Multijet 75cv (05-09)	Marelli Selespeed CFC328 - 2
 Punto (199)-Grande Punto	AUTOM. TRANSMISSI	1.3 Multijet 90cv (05-09)	Marelli Selespeed CFC328 - 2
 Punto (199)-Grande Punto	AUTOM. TRANSMISSI	1.4 16v (05-09)	Marelli Selespeed CFC328 - 2
 Punto (199)-Grande Punto	AUTOM. TRANSMISSI	1.4 8v (05-09)	Marelli Selespeed CFC328 - 2
 Punto (199)-Grande Punto	AUTOM. TRANSMISSI	1.4 8v Natural Power (05-09)	Marelli Selespeed CFC328 - 2
 Punto (199)-Grande Punto	AUTOM. TRANSMISSI	1.4 T-JET 16v (05-09)	Marelli Selespeed CFC328 - 2
 Punto (199)-Grande Punto	AUTOM. TRANSMISSI	1.6 MJET 16v (05-09)	Marelli Selespeed CFC328 - 2
 Punto (199)-Grande Punto	AUTOM. TRANSMISSI	1.9 Multijet 120cv (05-09)	Marelli Selespeed CFC328 - 2
 Punto (199)-Grande Punto	AUTOM. TRANSMISSI	1.9 Multijet 130cv (05-09)	Marelli Selespeed CFC328 - 2
 Punto (199)-Grande Punto	AUX. HEATING	1.2 8v (05-09)	DENSO EP
 Punto (199)-Grande Punto	AUX. HEATING	1.3 Multijet 75cv (05-09)	DENSO EP
 Punto (199)-Grande Punto	AUX. HEATING	1.3 Multijet 90cv (05-09)	DENSO EP
 Punto (199)-Grande Punto	AUX. HEATING	1.4 16v (05-09)	DENSO EP
 Punto (199)-Grande Punto	AUX. HEATING	1.4 8v (05-09)	DENSO EP
 Punto (199)-Grande Punto	AUX. HEATING	1.4 8v Natural Power (05-09)	DENSO EP
 Punto (199)-Grande Punto	AUX. HEATING	1.4 T-JET 16v (05-09)	DENSO EP
 Punto (199)-Grande Punto	AUX. HEATING	1.6 MJET 16v (05-09)	DENSO EP
 Punto (199)-Grande Punto	AUX. HEATING	1.9 Multijet 120cv (05-09)	DENSO EP
 Punto (199)-Grande Punto	AUX. HEATING	1.9 Multijet 130cv (05-09)	DENSO EP
 Punto (199)-Grande Punto	CHASSIS NETWORK	1.2 8v (05-09)	DELPHI Body Computer
 Punto (199)-Grande Punto	CHASSIS NETWORK	1.2 8v (05-09)	DELPHI Body Computer CAN Info
 Punto (199)-Grande Punto	CHASSIS NETWORK	1.2 8v (05-09)	DELPHI Body Computer Proxi Alignement
 Punto (199)-Grande Punto	CHASSIS NETWORK	1.3 Multijet 75cv (05-09)	DELPHI Body Computer
 Punto (199)-Grande Punto	CHASSIS NETWORK	1.3 Multijet 75cv (05-09)	DELPHI Body Computer CAN Info
 Punto (199)-Grande Punto	CHASSIS NETWORK	1.3 Multijet 75cv (05-09)	DELPHI Body Computer Proxi Alignement
 Punto (199)-Grande Punto	CHASSIS NETWORK	1.3 Multijet 90cv (05-09)	DELPHI Body Computer
 Punto (199)-Grande Punto	CHASSIS NETWORK	1.3 Multijet 90cv (05-09)	DELPHI Body Computer CAN Info
 Punto (199)-Grande Punto	CHASSIS NETWORK	1.3 Multijet 90cv (05-09)	DELPHI Body Computer Proxi Alignement
 Punto (199)-Grande Punto	CHASSIS NETWORK	1.4 16v (05-09)	DELPHI Body Computer
 Punto (199)-Grande Punto	CHASSIS NETWORK	1.4 16v (05-09)	DELPHI Body Computer CAN Info
 Punto (199)-Grande Punto	CHASSIS NETWORK	1.4 16v (05-09)	DELPHI Body Computer Proxi Alignement
 Punto (199)-Grande Punto	CHASSIS NETWORK	1.4 8v (05-09)	DELPHI Body Computer
 Punto (199)-Grande Punto	CHASSIS NETWORK	1.4 8v (05-09)	DELPHI Body Computer CAN Info
 Punto (199)-Grande Punto	CHASSIS NETWORK	1.4 8v (05-09)	DELPHI Body Computer Proxi Alignement
 Punto (199)-Grande Punto	CHASSIS NETWORK	1.4 8v Natural Power (05-09)	DELPHI Body Computer
 Punto (199)-Grande Punto	CHASSIS NETWORK	1.4 8v Natural Power (05-09)	DELPHI Body Computer CAN Info
 Punto (199)-Grande Punto	CHASSIS NETWORK	1.4 8v Natural Power (05-09)	DELPHI Body Computer Proxi Alignement
 Punto (199)-Grande Punto	CHASSIS NETWORK	1.4 T-JET 16v (05-09)	DELPHI Body Computer
 Punto (199)-Grande Punto	CHASSIS NETWORK	1.4 T-JET 16v (05-09)	DELPHI Body Computer CAN Info
 Punto (199)-Grande Punto	CHASSIS NETWORK	1.4 T-JET 16v (05-09)	DELPHI Body Computer Proxi Alignement
 Punto (199)-Grande Punto	CHASSIS NETWORK	1.6 MJET 16v (05-09)	DELPHI Body Computer

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Puncto (199)-Grande Puncto	CHASSIS NETWORK	1.6 MJET 16v (05-09)	DELPHI Body Computer CAN Info
 Puncto (199)-Grande Puncto	CHASSIS NETWORK	1.6 MJET 16v (05-09)	DELPHI Body Computer Proxi Alignement
 Puncto (199)-Grande Puncto	CHASSIS NETWORK	1.9 Multijet 120cv (05-09)	DELPHI Body Computer
 Puncto (199)-Grande Puncto	CHASSIS NETWORK	1.9 Multijet 120cv (05-09)	DELPHI Body Computer CAN Info
 Puncto (199)-Grande Puncto	CHASSIS NETWORK	1.9 Multijet 120cv (05-09)	DELPHI Body Computer Proxi Alignement
 Puncto (199)-Grande Puncto	CHASSIS NETWORK	1.9 Multijet 130cv (05-09)	DELPHI Body Computer
 Puncto (199)-Grande Puncto	CHASSIS NETWORK	1.9 Multijet 130cv (05-09)	DELPHI Body Computer CAN Info
 Puncto (199)-Grande Puncto	CHASSIS NETWORK	1.9 Multijet 130cv (05-09)	DELPHI Body Computer Proxi Alignement
 Puncto (199)-Grande Puncto	CLIMA	1.2 8v (05-09)	DENSO
 Puncto (199)-Grande Puncto	CLIMA	1.3 Multijet 75cv (05-09)	DENSO
 Puncto (199)-Grande Puncto	CLIMA	1.3 Multijet 90cv (05-09)	DENSO
 Puncto (199)-Grande Puncto	CLIMA	1.4 16v (05-09)	DENSO
 Puncto (199)-Grande Puncto	CLIMA	1.4 8v (05-09)	DENSO
 Puncto (199)-Grande Puncto	CLIMA	1.4 8v Natural Power (05-09)	DENSO
 Puncto (199)-Grande Puncto	CLIMA	1.4 T-JET 16v (05-09)	DENSO
 Puncto (199)-Grande Puncto	CLIMA	1.6 MJET 16v (05-09)	DENSO
 Puncto (199)-Grande Puncto	CLIMA	1.9 Multijet 120cv (05-09)	DENSO
 Puncto (199)-Grande Puncto	CLIMA	1.9 Multijet 130cv (05-09)	DENSO
 Puncto (199)-Grande Puncto	DASHBOARD	1.2 8v (05-09)	Marelli Dashboard Comfort
 Puncto (199)-Grande Puncto	DASHBOARD	1.2 8v (05-09)	Marelli Dashboard Modale
 Puncto (199)-Grande Puncto	DASHBOARD	1.2 8v (08-09)	Marelli Dashboard 3
 Puncto (199)-Grande Puncto	DASHBOARD	1.3 Multijet 75cv (05-09)	Marelli Dashboard Comfort
 Puncto (199)-Grande Puncto	DASHBOARD	1.3 Multijet 75cv (05-09)	Marelli Dashboard Modale
 Puncto (199)-Grande Puncto	DASHBOARD	1.3 Multijet 75cv (08-09)	Marelli Dashboard 3
 Puncto (199)-Grande Puncto	DASHBOARD	1.3 Multijet 90cv (05-09)	Marelli Dashboard Comfort
 Puncto (199)-Grande Puncto	DASHBOARD	1.3 Multijet 90cv (05-09)	Marelli Dashboard Modale
 Puncto (199)-Grande Puncto	DASHBOARD	1.3 Multijet 90cv (08-09)	Marelli Dashboard 3
 Puncto (199)-Grande Puncto	DASHBOARD	1.4 16v (05-09)	Marelli Dashboard Comfort
 Puncto (199)-Grande Puncto	DASHBOARD	1.4 16v (05-09)	Marelli Dashboard Modale
 Puncto (199)-Grande Puncto	DASHBOARD	1.4 16v (08-09)	Marelli Dashboard 3
 Puncto (199)-Grande Puncto	DASHBOARD	1.4 8v (05-09)	Marelli Dashboard Comfort
 Puncto (199)-Grande Puncto	DASHBOARD	1.4 8v (05-09)	Marelli Dashboard Modale
 Puncto (199)-Grande Puncto	DASHBOARD	1.4 8v (08-09)	Marelli Dashboard 3
 Puncto (199)-Grande Puncto	DASHBOARD	1.4 8v Natural Power (05-09)	Marelli Dashboard 3
 Puncto (199)-Grande Puncto	DASHBOARD	1.4 T-JET 16v (05-09)	Marelli Dashboard Comfort
 Puncto (199)-Grande Puncto	DASHBOARD	1.4 T-JET 16v (05-09)	Marelli Dashboard Modale
 Puncto (199)-Grande Puncto	DASHBOARD	1.4 T-JET 16v (08-09)	Marelli Dashboard 3
 Puncto (199)-Grande Puncto	DASHBOARD	1.6 MJET 16v (05-09)	Marelli Dashboard Comfort
 Puncto (199)-Grande Puncto	DASHBOARD	1.6 MJET 16v (05-09)	Marelli Dashboard Modale
 Puncto (199)-Grande Puncto	DASHBOARD	1.6 MJET 16v (08-09)	Marelli Dashboard 3
 Puncto (199)-Grande Puncto	DASHBOARD	1.9 Multijet 120cv (05-09)	Marelli Dashboard Comfort
 Puncto (199)-Grande Puncto	DASHBOARD	1.9 Multijet 120cv (05-09)	Marelli Dashboard Modale
 Puncto (199)-Grande Puncto	DASHBOARD	1.9 Multijet 120cv (08-09)	Marelli Dashboard 3
 Puncto (199)-Grande Puncto	DASHBOARD	1.9 Multijet 130cv (05-09)	Marelli Dashboard Comfort
 Puncto (199)-Grande Puncto	DASHBOARD	1.9 Multijet 130cv (05-09)	Marelli Dashboard Modale
 Puncto (199)-Grande Puncto	DASHBOARD	1.9 Multijet 130cv (08-09)	Marelli Dashboard 3
 Puncto (199)-Grande Puncto	ELECTRIC STEERING	1.2 8v (05-09)	DELPHI EPS
 Puncto (199)-Grande Puncto	ELECTRIC STEERING	1.2 8v (05-09)	DELPHI EPS EP 3
 Puncto (199)-Grande Puncto	ELECTRIC STEERING	1.3 Multijet 75cv (05-09)	DELPHI EPS
 Puncto (199)-Grande Puncto	ELECTRIC STEERING	1.3 Multijet 75cv (05-09)	DELPHI EPS EP 3
 Puncto (199)-Grande Puncto	ELECTRIC STEERING	1.3 Multijet 90cv (05-09)	DELPHI EPS
 Puncto (199)-Grande Puncto	ELECTRIC STEERING	1.3 Multijet 90cv (05-09)	DELPHI EPS EP 3
 Puncto (199)-Grande Puncto	ELECTRIC STEERING	1.4 16v (05-09)	DELPHI EPS
 Puncto (199)-Grande Puncto	ELECTRIC STEERING	1.4 16v (05-09)	DELPHI EPS EP 3
 Puncto (199)-Grande Puncto	ELECTRIC STEERING	1.4 8v (05-09)	DELPHI EPS
 Puncto (199)-Grande Puncto	ELECTRIC STEERING	1.4 8v (05-09)	DELPHI EPS EP 3
 Puncto (199)-Grande Puncto	ELECTRIC STEERING	1.4 8v Natural Power (05-09)	DELPHI EPS
 Puncto (199)-Grande Puncto	ELECTRIC STEERING	1.4 8v Natural Power (05-09)	DELPHI EPS EP 3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Punto (199)-Grande Punto	ELECTRIC STEERING	1.4 T-JET 16v (05-09)	DELPHI EPS
 Punto (199)-Grande Punto	ELECTRIC STEERING	1.4 T-JET 16v (05-09)	DELPHI EPS EP 3
 Punto (199)-Grande Punto	ELECTRIC STEERING	1.6 MJET 16v (05-09)	DELPHI EPS
 Punto (199)-Grande Punto	ELECTRIC STEERING	1.6 MJET 16v (05-09)	DELPHI EPS EP 3
 Punto (199)-Grande Punto	ELECTRIC STEERING	1.9 Multijet 120cv (05-09)	DELPHI EPS
 Punto (199)-Grande Punto	ELECTRIC STEERING	1.9 Multijet 120cv (05-09)	DELPHI EPS EP 3
 Punto (199)-Grande Punto	ELECTRIC STEERING	1.9 Multijet 130cv (05-09)	DELPHI EPS
 Punto (199)-Grande Punto	ELECTRIC STEERING	1.9 Multijet 130cv (05-09)	DELPHI EPS EP 3
 Punto (199)-Grande Punto	ENGINE MANAGEME	1.2 8v (05-09)	Marelli IAW 5SF3
 Punto (199)-Grande Punto	ENGINE MANAGEME	1.3 Multijet 75cv (05-09)	Marelli EDC 6F3
 Punto (199)-Grande Punto	ENGINE MANAGEME	1.3 Multijet 90cv (05-09)	Marelli EDC 6F3
 Punto (199)-Grande Punto	ENGINE MANAGEME	1.3 Multijet 90cv (05-09)	Marelli EDC 6F3 (D.P.F.)
 Punto (199)-Grande Punto	ENGINE MANAGEME	1.4 16v (05-09)	BOSCH Motronic ME7.9.10 CF4-EOBD
 Punto (199)-Grande Punto	ENGINE MANAGEME	1.4 8v (05-09)	EOBD
 Punto (199)-Grande Punto	ENGINE MANAGEME	1.4 8v Natural Power (08-09)	Marelli IAW 5FF8 E4
 Punto (199)-Grande Punto	ENGINE MANAGEME	1.4 T-JET 16v (05-09)	BOSCH Motronic ME7.9.10 CF4-EOBD
 Punto (199)-Grande Punto	ENGINE MANAGEME	1.6 MJET 16v (08-09)	BOSCH EDC16C39 CF5/EOBD
 Punto (199)-Grande Punto	ENGINE MANAGEME	1.9 MJET 8v (08-09)	BOSCH EDC16C39 CF4/EOBD CAN
 Punto (199)-Grande Punto	ENGINE MANAGEME	1.9 Multijet 120cv (05-09)	BOSCH EDC 16 Common Rail
 Punto (199)-Grande Punto	ENGINE MANAGEME	1.9 Multijet 130cv (05-09)	EOBD
 Punto (199)-Grande Punto	FAP OIL PARAMETER	1.3 Multijet 75cv (05-09)	Marelli
 Punto (199)-Grande Punto	FAP OIL PARAMETER	1.3 Multijet 90cv (05-09)	Marelli
 Punto (199)-Grande Punto	FAP OIL PARAMETER	1.9 Multijet 120cv (05-09)	Marelli
 Punto (199)-Grande Punto	FAP OIL PARAMETER	1.9 Multijet 130cv (05-09)	Marelli
 Punto (199)-Grande Punto	KEY ENCODE	1.2 8v (05-09)	DELPHI Body Computer
 Punto (199)-Grande Punto	KEY ENCODE	1.3 Multijet 75cv (05-09)	DELPHI Body Computer
 Punto (199)-Grande Punto	KEY ENCODE	1.3 Multijet 90cv (05-09)	DELPHI Body Computer
 Punto (199)-Grande Punto	KEY ENCODE	1.4 16v (05-09)	DELPHI Body Computer
 Punto (199)-Grande Punto	KEY ENCODE	1.4 8v (05-09)	DELPHI Body Computer
 Punto (199)-Grande Punto	KEY ENCODE	1.4 8v Natural Power (05-09)	DELPHI Body Computer
 Punto (199)-Grande Punto	KEY ENCODE	1.4 T-JET 16v (05-09)	DELPHI Body Computer
 Punto (199)-Grande Punto	KEY ENCODE	1.6 MJET 16v (05-09)	DELPHI Body Computer
 Punto (199)-Grande Punto	KEY ENCODE	1.9 Multijet 120cv (05-09)	DELPHI Body Computer
 Punto (199)-Grande Punto	KEY ENCODE	1.9 Multijet 130cv (05-09)	DELPHI Body Computer
 Punto (199)-Grande Punto	MAINTENANCE	1.2 8v (05-09)	Bosch ESP 8
 Punto (199)-Grande Punto	MAINTENANCE	1.2 8v (05-09)	DELPHI EPS
 Punto (199)-Grande Punto	MAINTENANCE	1.2 8v (05-09)	DELPHI EPS EP 3
 Punto (199)-Grande Punto	MAINTENANCE	1.2 8v (05-09)	Marelli Dashboard
 Punto (199)-Grande Punto	MAINTENANCE	1.2 8v (05-09)	Marelli Dashboard Comfort
 Punto (199)-Grande Punto	MAINTENANCE	1.2 8v (05-09)	Marelli Dashboard Comfort
 Punto (199)-Grande Punto	MAINTENANCE	1.2 8v (05-09)	Marelli Dashboard Comfort
 Punto (199)-Grande Punto	MAINTENANCE	1.2 8v (05-09)	Marelli Dashboard Modale
 Punto (199)-Grande Punto	MAINTENANCE	1.2 8v (05-09)	Marelli Dashboard Modale
 Punto (199)-Grande Punto	MAINTENANCE	1.2 8v (05-09)	Marelli IAW 5SF3
 Punto (199)-Grande Punto	MAINTENANCE	1.2 8v (08-09)	Marelli Dashboard 3
 Punto (199)-Grande Punto	MAINTENANCE	1.2 8v (08-09)	Marelli Dashboard 3
 Punto (199)-Grande Punto	MAINTENANCE	1.2 8v (08-09)	Marelli Dashboard 3
 Punto (199)-Grande Punto	MAINTENANCE	1.3 Multijet 75cv (05-09)	Bosch ESP 8
 Punto (199)-Grande Punto	MAINTENANCE	1.3 Multijet 75cv (05-09)	DELPHI EPS
 Punto (199)-Grande Punto	MAINTENANCE	1.3 Multijet 75cv (05-09)	DELPHI EPS EP 3
 Punto (199)-Grande Punto	MAINTENANCE	1.3 Multijet 75cv (05-09)	Marelli
 Punto (199)-Grande Punto	MAINTENANCE	1.3 Multijet 75cv (05-09)	Marelli Dashboard
 Punto (199)-Grande Punto	MAINTENANCE	1.3 Multijet 75cv (05-09)	Marelli Dashboard Comfort
 Punto (199)-Grande Punto	MAINTENANCE	1.3 Multijet 75cv (05-09)	Marelli Dashboard Comfort
 Punto (199)-Grande Punto	MAINTENANCE	1.3 Multijet 75cv (05-09)	Marelli Dashboard Modale
 Punto (199)-Grande Punto	MAINTENANCE	1.3 Multijet 75cv (05-09)	Marelli Dashboard Modale
 Punto (199)-Grande Punto	MAINTENANCE	1.3 Multijet 75cv (05-09)	Marelli EDC 6F3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Punto (199)-Grande Punto	MAINTENANCE	1.3 Multijet 75cv (08-09)	Marelli Dashboard 3
 Punto (199)-Grande Punto	MAINTENANCE	1.3 Multijet 75cv (08-09)	Marelli Dashboard 3
 Punto (199)-Grande Punto	MAINTENANCE	1.3 Multijet 75cv (08-09)	Marelli Dashboard 3
 Punto (199)-Grande Punto	MAINTENANCE	1.3 Multijet 90cv (05-09)	Bosch ESP 8
 Punto (199)-Grande Punto	MAINTENANCE	1.3 Multijet 90cv (05-09)	DELPHI EPS
 Punto (199)-Grande Punto	MAINTENANCE	1.3 Multijet 90cv (05-09)	DELPHI EPS EP 3
 Punto (199)-Grande Punto	MAINTENANCE	1.3 Multijet 90cv (05-09)	Marelli
 Punto (199)-Grande Punto	MAINTENANCE	1.3 Multijet 90cv (05-09)	Marelli Dashboard
 Punto (199)-Grande Punto	MAINTENANCE	1.3 Multijet 90cv (05-09)	Marelli Dashboard Comfort
 Punto (199)-Grande Punto	MAINTENANCE	1.3 Multijet 90cv (05-09)	Marelli Dashboard Comfort
 Punto (199)-Grande Punto	MAINTENANCE	1.3 Multijet 90cv (05-09)	Marelli Dashboard Comfort
 Punto (199)-Grande Punto	MAINTENANCE	1.3 Multijet 90cv (05-09)	Marelli Dashboard Modale
 Punto (199)-Grande Punto	MAINTENANCE	1.3 Multijet 90cv (05-09)	Marelli Dashboard Modale
 Punto (199)-Grande Punto	MAINTENANCE	1.3 Multijet 90cv (05-09)	Marelli EDC 6F3
 Punto (199)-Grande Punto	MAINTENANCE	1.3 Multijet 90cv (05-09)	Marelli EDC 6F3 (D.P.F.)
 Punto (199)-Grande Punto	MAINTENANCE	1.3 Multijet 90cv (05-09)	Marelli EDC 6F3 (D.P.F.)
 Punto (199)-Grande Punto	MAINTENANCE	1.3 Multijet 90cv (05-09)	Marelli EDC 6F3 (D.P.F.)
 Punto (199)-Grande Punto	MAINTENANCE	1.3 Multijet 90cv (08-09)	Marelli Dashboard 3
 Punto (199)-Grande Punto	MAINTENANCE	1.3 Multijet 90cv (08-09)	Marelli Dashboard 3
 Punto (199)-Grande Punto	MAINTENANCE	1.3 Multijet 90cv (08-09)	Marelli Dashboard 3
 Punto (199)-Grande Punto	MAINTENANCE	1.4 16v (05-09)	Bosch ESP 8
 Punto (199)-Grande Punto	MAINTENANCE	1.4 16v (05-09)	DELPHI EPS
 Punto (199)-Grande Punto	MAINTENANCE	1.4 16v (05-09)	DELPHI EPS EP 3
 Punto (199)-Grande Punto	MAINTENANCE	1.4 16v (05-09)	Marelli Dashboard
 Punto (199)-Grande Punto	MAINTENANCE	1.4 16v (05-09)	Marelli Dashboard Comfort
 Punto (199)-Grande Punto	MAINTENANCE	1.4 16v (05-09)	Marelli Dashboard Comfort
 Punto (199)-Grande Punto	MAINTENANCE	1.4 16v (05-09)	Marelli Dashboard Comfort
 Punto (199)-Grande Punto	MAINTENANCE	1.4 16v (05-09)	Marelli Dashboard Modale
 Punto (199)-Grande Punto	MAINTENANCE	1.4 16v (05-09)	Marelli Dashboard Modale
 Punto (199)-Grande Punto	MAINTENANCE	1.4 16v (08-09)	Marelli Dashboard 3
 Punto (199)-Grande Punto	MAINTENANCE	1.4 16v (08-09)	Marelli Dashboard 3
 Punto (199)-Grande Punto	MAINTENANCE	1.4 16v (08-09)	Marelli Dashboard 3
 Punto (199)-Grande Punto	MAINTENANCE	1.4 8v (05-09)	Bosch ESP 8
 Punto (199)-Grande Punto	MAINTENANCE	1.4 8v (05-09)	DELPHI EPS
 Punto (199)-Grande Punto	MAINTENANCE	1.4 8v (05-09)	DELPHI EPS EP 3
 Punto (199)-Grande Punto	MAINTENANCE	1.4 8v (05-09)	Marelli Dashboard
 Punto (199)-Grande Punto	MAINTENANCE	1.4 8v (05-09)	Marelli Dashboard Comfort
 Punto (199)-Grande Punto	MAINTENANCE	1.4 8v (05-09)	Marelli Dashboard Comfort
 Punto (199)-Grande Punto	MAINTENANCE	1.4 8v (05-09)	Marelli Dashboard Comfort
 Punto (199)-Grande Punto	MAINTENANCE	1.4 8v (05-09)	Marelli Dashboard Modale
 Punto (199)-Grande Punto	MAINTENANCE	1.4 8v (05-09)	Marelli Dashboard Modale
 Punto (199)-Grande Punto	MAINTENANCE	1.4 8v (08-09)	Marelli Dashboard 3
 Punto (199)-Grande Punto	MAINTENANCE	1.4 8v (08-09)	Marelli Dashboard 3
 Punto (199)-Grande Punto	MAINTENANCE	1.4 8v (08-09)	Marelli Dashboard 3
 Punto (199)-Grande Punto	MAINTENANCE	1.4 8v Natural Power (05-09)	Bosch ESP 8
 Punto (199)-Grande Punto	MAINTENANCE	1.4 8v Natural Power (05-09)	DELPHI EPS
 Punto (199)-Grande Punto	MAINTENANCE	1.4 8v Natural Power (05-09)	DELPHI EPS EP 3
 Punto (199)-Grande Punto	MAINTENANCE	1.4 8v Natural Power (05-09)	Marelli Dashboard 3
 Punto (199)-Grande Punto	MAINTENANCE	1.4 8v Natural Power (05-09)	Marelli Dashboard 3
 Punto (199)-Grande Punto	MAINTENANCE	1.4 8v Natural Power (05-09)	Marelli Dashboard 3
 Punto (199)-Grande Punto	MAINTENANCE	1.4 8v Natural Power (08-09)	Marelli IAW 5FF8 E4
 Punto (199)-Grande Punto	MAINTENANCE	1.4 T-JET 16v (05-09)	Bosch ESP 8
 Punto (199)-Grande Punto	MAINTENANCE	1.4 T-JET 16v (05-09)	DELPHI EPS
 Punto (199)-Grande Punto	MAINTENANCE	1.4 T-JET 16v (05-09)	DELPHI EPS EP 3
 Punto (199)-Grande Punto	MAINTENANCE	1.4 T-JET 16v (05-09)	Marelli Dashboard
 Punto (199)-Grande Punto	MAINTENANCE	1.4 T-JET 16v (05-09)	Marelli Dashboard Comfort
 Punto (199)-Grande Punto	MAINTENANCE	1.4 T-JET 16v (05-09)	Marelli Dashboard Comfort

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Punto (199)-Grande Punto	MAINTENANCE	1.4 T-JET 16v (05-09)	Marelli Dashboard Comfort
 Punto (199)-Grande Punto	MAINTENANCE	1.4 T-JET 16v (05-09)	Marelli Dashboard Modale
 Punto (199)-Grande Punto	MAINTENANCE	1.4 T-JET 16v (05-09)	Marelli Dashboard Modale
 Punto (199)-Grande Punto	MAINTENANCE	1.4 T-JET 16v (08-09)	Marelli Dashboard 3
 Punto (199)-Grande Punto	MAINTENANCE	1.4 T-JET 16v (08-09)	Marelli Dashboard 3
 Punto (199)-Grande Punto	MAINTENANCE	1.4 T-JET 16v (08-09)	Marelli Dashboard 3
 Punto (199)-Grande Punto	MAINTENANCE	1.6 MJET 16v (05-09)	Bosch ESP 8
 Punto (199)-Grande Punto	MAINTENANCE	1.6 MJET 16v (05-09)	DELPHI EPS
 Punto (199)-Grande Punto	MAINTENANCE	1.6 MJET 16v (05-09)	DELPHI EPS EP 3
 Punto (199)-Grande Punto	MAINTENANCE	1.6 MJET 16v (05-09)	Marelli Dashboard
 Punto (199)-Grande Punto	MAINTENANCE	1.6 MJET 16v (05-09)	Marelli Dashboard Comfort
 Punto (199)-Grande Punto	MAINTENANCE	1.6 MJET 16v (05-09)	Marelli Dashboard Comfort
 Punto (199)-Grande Punto	MAINTENANCE	1.6 MJET 16v (05-09)	Marelli Dashboard Comfort
 Punto (199)-Grande Punto	MAINTENANCE	1.6 MJET 16v (05-09)	Marelli Dashboard Modale
 Punto (199)-Grande Punto	MAINTENANCE	1.6 MJET 16v (05-09)	Marelli Dashboard Modale
 Punto (199)-Grande Punto	MAINTENANCE	1.6 MJET 16v (08-09)	BOSCH EDC16C39 CF5/EOBD
 Punto (199)-Grande Punto	MAINTENANCE	1.6 MJET 16v (08-09)	Marelli Dashboard 3
 Punto (199)-Grande Punto	MAINTENANCE	1.6 MJET 16v (08-09)	Marelli Dashboard 3
 Punto (199)-Grande Punto	MAINTENANCE	1.6 MJET 16v (08-09)	Marelli Dashboard 3
 Punto (199)-Grande Punto	MAINTENANCE	1.9 Multijet 120cv (05-09)	BOSCH EDC 16 Common Rail
 Punto (199)-Grande Punto	MAINTENANCE	1.9 Multijet 120cv (05-09)	Bosch ESP 8
 Punto (199)-Grande Punto	MAINTENANCE	1.9 Multijet 120cv (05-09)	DELPHI EPS
 Punto (199)-Grande Punto	MAINTENANCE	1.9 Multijet 120cv (05-09)	DELPHI EPS EP 3
 Punto (199)-Grande Punto	MAINTENANCE	1.9 Multijet 120cv (05-09)	Marelli
 Punto (199)-Grande Punto	MAINTENANCE	1.9 Multijet 120cv (05-09)	Marelli Dashboard
 Punto (199)-Grande Punto	MAINTENANCE	1.9 Multijet 120cv (05-09)	Marelli Dashboard Comfort
 Punto (199)-Grande Punto	MAINTENANCE	1.9 Multijet 120cv (05-09)	Marelli Dashboard Comfort
 Punto (199)-Grande Punto	MAINTENANCE	1.9 Multijet 120cv (05-09)	Marelli Dashboard Comfort
 Punto (199)-Grande Punto	MAINTENANCE	1.9 Multijet 120cv (05-09)	Marelli Dashboard Modale
 Punto (199)-Grande Punto	MAINTENANCE	1.9 Multijet 120cv (05-09)	Marelli Dashboard Modale
 Punto (199)-Grande Punto	MAINTENANCE	1.9 Multijet 120cv (08-09)	Marelli Dashboard 3
 Punto (199)-Grande Punto	MAINTENANCE	1.9 Multijet 120cv (08-09)	Marelli Dashboard 3
 Punto (199)-Grande Punto	MAINTENANCE	1.9 Multijet 120cv (08-09)	Marelli Dashboard 3
 Punto (199)-Grande Punto	MAINTENANCE	1.9 Multijet 130cv (05-09)	Bosch ESP 8
 Punto (199)-Grande Punto	MAINTENANCE	1.9 Multijet 130cv (05-09)	DELPHI EPS
 Punto (199)-Grande Punto	MAINTENANCE	1.9 Multijet 130cv (05-09)	DELPHI EPS EP 3
 Punto (199)-Grande Punto	MAINTENANCE	1.9 Multijet 130cv (05-09)	Marelli
 Punto (199)-Grande Punto	MAINTENANCE	1.9 Multijet 130cv (05-09)	Marelli Dashboard
 Punto (199)-Grande Punto	MAINTENANCE	1.9 Multijet 130cv (05-09)	Marelli Dashboard Comfort
 Punto (199)-Grande Punto	MAINTENANCE	1.9 Multijet 130cv (05-09)	Marelli Dashboard Comfort
 Punto (199)-Grande Punto	MAINTENANCE	1.9 Multijet 130cv (05-09)	Marelli Dashboard Comfort
 Punto (199)-Grande Punto	MAINTENANCE	1.9 Multijet 130cv (05-09)	Marelli Dashboard Modale
 Punto (199)-Grande Punto	MAINTENANCE	1.9 Multijet 130cv (05-09)	Marelli Dashboard Modale
 Punto (199)-Grande Punto	MAINTENANCE	1.9 Multijet 130cv (08-09)	Marelli Dashboard 3
 Punto (199)-Grande Punto	MAINTENANCE	1.9 Multijet 130cv (08-09)	Marelli Dashboard 3
 Punto (199)-Grande Punto	MAINTENANCE	1.9 Multijet 130cv (08-09)	Marelli Dashboard 3
 Punto (199)-Grande Punto	PARKING HELP	1.2 8v (05-09)	Valeo 2
 Punto (199)-Grande Punto	PARKING HELP	1.3 Multijet 75cv (05-09)	Valeo 2
 Punto (199)-Grande Punto	PARKING HELP	1.3 Multijet 90cv (05-09)	Valeo 2
 Punto (199)-Grande Punto	PARKING HELP	1.4 16v (05-09)	Valeo 2
 Punto (199)-Grande Punto	PARKING HELP	1.4 8v (05-09)	Valeo 2
 Punto (199)-Grande Punto	PARKING HELP	1.4 8v Natural Power (05-09)	Valeo 2
 Punto (199)-Grande Punto	PARKING HELP	1.4 T-JET 16v (05-09)	Valeo 2
 Punto (199)-Grande Punto	PARKING HELP	1.6 MJET 16v (05-09)	Valeo 2
 Punto (199)-Grande Punto	PARKING HELP	1.9 Multijet 120cv (05-09)	Valeo 2
 Punto (199)-Grande Punto	PARKING HELP	1.9 Multijet 130cv (05-09)	Valeo 2
 Punto (199)-Grande Punto	SERVICE LIGHT RES	1.2 8v (05-09)	Marelli Dashboard
 Punto (199)-Grande Punto	SERVICE LIGHT RES	1.2 8v (08-09)	Marelli Dashboard 3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Puncto (199)-Grande Puncto	SERVICE LIGHT RES	1.3 Multijet 75cv (05-09)	Marelli Dashboard
 Puncto (199)-Grande Puncto	SERVICE LIGHT RES	1.3 Multijet 75cv (08-09)	Marelli Dashboard 3
 Puncto (199)-Grande Puncto	SERVICE LIGHT RES	1.3 Multijet 90cv (05-09)	Marelli Dashboard
 Puncto (199)-Grande Puncto	SERVICE LIGHT RES	1.3 Multijet 90cv (08-09)	Marelli Dashboard 3
 Puncto (199)-Grande Puncto	SERVICE LIGHT RES	1.4 16v (05-09)	Marelli Dashboard
 Puncto (199)-Grande Puncto	SERVICE LIGHT RES	1.4 16v (08-09)	Marelli Dashboard 3
 Puncto (199)-Grande Puncto	SERVICE LIGHT RES	1.4 8v (05-09)	Marelli Dashboard
 Puncto (199)-Grande Puncto	SERVICE LIGHT RES	1.4 8v (08-09)	Marelli Dashboard 3
 Puncto (199)-Grande Puncto	SERVICE LIGHT RES	1.4 8v Natural Power (05-09)	Marelli Dashboard 3
 Puncto (199)-Grande Puncto	SERVICE LIGHT RES	1.4 T-JET 16v (05-09)	Marelli Dashboard
 Puncto (199)-Grande Puncto	SERVICE LIGHT RES	1.4 T-JET 16v (08-09)	Marelli Dashboard 3
 Puncto (199)-Grande Puncto	SERVICE LIGHT RES	1.6 MJET 16v (05-09)	Marelli Dashboard
 Puncto (199)-Grande Puncto	SERVICE LIGHT RES	1.6 MJET 16v (08-09)	Marelli Dashboard 3
 Puncto (199)-Grande Puncto	SERVICE LIGHT RES	1.9 Multijet 120cv (05-09)	Marelli Dashboard
 Puncto (199)-Grande Puncto	SERVICE LIGHT RES	1.9 Multijet 120cv (08-09)	Marelli Dashboard 3
 Puncto (199)-Grande Puncto	SERVICE LIGHT RES	1.9 Multijet 130cv (05-09)	Marelli Dashboard
 Puncto (199)-Grande Puncto	SERVICE LIGHT RES	1.9 Multijet 130cv (08-09)	Marelli Dashboard 3
 Puncto (199)-Grande Puncto	VISUAL./TELEMATIC	1.2 8v (05-09)	Marelli Convergence
 Puncto (199)-Grande Puncto	VISUAL./TELEMATIC	1.3 Multijet 75cv (05-09)	Marelli Convergence
 Puncto (199)-Grande Puncto	VISUAL./TELEMATIC	1.3 Multijet 90cv (05-09)	Marelli Convergence
 Puncto (199)-Grande Puncto	VISUAL./TELEMATIC	1.4 16v (05-09)	Marelli Convergence
 Puncto (199)-Grande Puncto	VISUAL./TELEMATIC	1.4 8v (05-09)	Marelli Convergence
 Puncto (199)-Grande Puncto	VISUAL./TELEMATIC	1.4 T-JET 16v (05-09)	Marelli Convergence
 Puncto (199)-Grande Puncto	VISUAL./TELEMATIC	1.6 MJET 16v (05-09)	Marelli Convergence
 Puncto (199)-Grande Puncto	VISUAL./TELEMATIC	1.9 Multijet 120cv (05-09)	Marelli Convergence
 Puncto (199)-Grande Puncto	VISUAL./TELEMATIC	1.9 Multijet 130cv (05-09)	Marelli Convergence
 Puncto 12 (199)	ABS + TRACT. CONT	0.9 TwinAir Turbo 105cv (09-..)	Bosch ESP 8
 Puncto 12 (199)	ABS + TRACT. CONT	1.2 8v (09-..)	Bosch ESP 8
 Puncto 12 (199)	ABS + TRACT. CONT	1.3 Multijet 16v 75cv (09-..)	Bosch ESP 8
 Puncto 12 (199)	ABS + TRACT. CONT	1.3 Multijet 16v 85cv (09-..)	Bosch ESP 8
 Puncto 12 (199)	ABS + TRACT. CONT	1.4 8v (09-..)	Bosch ESP 8
 Puncto 12 (199)	ABS + TRACT. CONT	1.4 8v Natural Power (09-..)	Bosch ESP 8
 Puncto 12 (199)	AIRBAG	0.9 TwinAir Turbo 105cv (09-..)	CONTINENTAL SRS EP
 Puncto 12 (199)	AIRBAG	1.2 8v (09-..)	CONTINENTAL SRS EP
 Puncto 12 (199)	AIRBAG	1.3 Multijet 16v 75cv (09-..)	CONTINENTAL SRS EP
 Puncto 12 (199)	AIRBAG	1.3 Multijet 16v 85cv (09-..)	CONTINENTAL SRS EP
 Puncto 12 (199)	AIRBAG	1.4 8v (09-..)	CONTINENTAL SRS EP
 Puncto 12 (199)	AIRBAG	1.4 8v Natural Power (09-..)	CONTINENTAL SRS EP
 Puncto 12 (199)	AUTOM. TRANSMISSI	0.9 TwinAir Turbo 105cv (09-..)	Marelli Selespeed CFC328 - 2
 Puncto 12 (199)	AUTOM. TRANSMISSI	1.2 8v (09-..)	Marelli Selespeed CFC328 - 2
 Puncto 12 (199)	AUTOM. TRANSMISSI	1.3 Multijet 16v 75cv (09-..)	Marelli Selespeed CFC328 - 2
 Puncto 12 (199)	AUTOM. TRANSMISSI	1.3 Multijet 16v 85cv (09-..)	Marelli Selespeed CFC328 - 2
 Puncto 12 (199)	AUTOM. TRANSMISSI	1.4 8v (09-..)	Marelli Selespeed CFC328 - 2
 Puncto 12 (199)	AUTOM. TRANSMISSI	1.4 8v Natural Power (09-..)	Marelli Selespeed CFC328 - 2
 Puncto 12 (199)	CHASSIS NETWORK	0.9 TwinAir Turbo 105cv (09-..)	DELPHI Body Computer
 Puncto 12 (199)	CHASSIS NETWORK	0.9 TwinAir Turbo 105cv (09-..)	DELPHI Body Computer CAN Info
 Puncto 12 (199)	CHASSIS NETWORK	0.9 TwinAir Turbo 105cv (09-..)	DELPHI Body Computer Proxi Alignement
 Puncto 12 (199)	CHASSIS NETWORK	1.2 8v (09-..)	DELPHI Body Computer
 Puncto 12 (199)	CHASSIS NETWORK	1.2 8v (09-..)	DELPHI Body Computer CAN Info
 Puncto 12 (199)	CHASSIS NETWORK	1.2 8v (09-..)	DELPHI Body Computer Proxi Alignement
 Puncto 12 (199)	CHASSIS NETWORK	1.3 Multijet 16v 75cv (09-..)	DELPHI Body Computer
 Puncto 12 (199)	CHASSIS NETWORK	1.3 Multijet 16v 75cv (09-..)	DELPHI Body Computer CAN Info
 Puncto 12 (199)	CHASSIS NETWORK	1.3 Multijet 16v 75cv (09-..)	DELPHI Body Computer Proxi Alignement
 Puncto 12 (199)	CHASSIS NETWORK	1.3 Multijet 16v 85cv (09-..)	DELPHI Body Computer
 Puncto 12 (199)	CHASSIS NETWORK	1.3 Multijet 16v 85cv (09-..)	DELPHI Body Computer CAN Info
 Puncto 12 (199)	CHASSIS NETWORK	1.3 Multijet 16v 85cv (09-..)	DELPHI Body Computer Proxi Alignement
 Puncto 12 (199)	CHASSIS NETWORK	1.4 8v (09-..)	DELPHI Body Computer
 Puncto 12 (199)	CHASSIS NETWORK	1.4 8v (09-..)	DELPHI Body Computer CAN Info

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Punto 12 (199)	CHASSIS NETWORK	1.4 8v (09-..)	DELPHI Body Computer Proxi Alignement
 Punto 12 (199)	CHASSIS NETWORK	1.4 8v Natural Power (09-..)	DELPHI Body Computer
 Punto 12 (199)	CHASSIS NETWORK	1.4 8v Natural Power (09-..)	DELPHI Body Computer CAN Info
 Punto 12 (199)	CHASSIS NETWORK	1.4 8v Natural Power (09-..)	DELPHI Body Computer Proxi Alignement
 Punto 12 (199)	CLIMA	0.9 TwinAir Turbo 105cv (09-..)	DENSO Clima
 Punto 12 (199)	CLIMA	1.2 8v (09-..)	DENSO Clima
 Punto 12 (199)	CLIMA	1.3 Multijet 16v 75cv (09-..)	DENSO Clima
 Punto 12 (199)	CLIMA	1.3 Multijet 16v 85cv (09-..)	DENSO Clima
 Punto 12 (199)	CLIMA	1.4 8v (09-..)	DENSO Clima
 Punto 12 (199)	CLIMA	1.4 8v Natural Power (09-..)	DENSO Clima
 Punto 12 (199)	DASHBOARD	0.9 TwinAir Turbo 105cv (09-..)	Marelli Dashboard 3
 Punto 12 (199)	DASHBOARD	1.2 8v (09-..)	Marelli Dashboard 3
 Punto 12 (199)	DASHBOARD	1.3 Multijet 16v 75cv (09-..)	Marelli Dashboard 3
 Punto 12 (199)	DASHBOARD	1.3 Multijet 16v 85cv (09-..)	Marelli Dashboard 3
 Punto 12 (199)	DASHBOARD	1.4 8v (09-..)	Marelli Dashboard 3
 Punto 12 (199)	DASHBOARD	1.4 8v Natural Power (09-..)	Marelli Dashboard 3
 Punto 12 (199)	ELECTRIC STEERING	0.9 TwinAir Turbo 105cv (09-..)	DELPHI EPS EP 3
 Punto 12 (199)	ELECTRIC STEERING	1.2 8v (09-..)	DELPHI EPS EP 3
 Punto 12 (199)	ELECTRIC STEERING	1.3 Multijet 16v 75cv (09-..)	DELPHI EPS
 Punto 12 (199)	ELECTRIC STEERING	1.3 Multijet 16v 75cv (09-..)	DELPHI EPS EP 3
 Punto 12 (199)	ELECTRIC STEERING	1.3 Multijet 16v 85cv (09-..)	DELPHI EPS EP 3
 Punto 12 (199)	ELECTRIC STEERING	1.4 8v (09-..)	DELPHI EPS EP 3
 Punto 12 (199)	ELECTRIC STEERING	1.4 8v Natural Power (09-..)	DELPHI EPS EP 3
 Punto 12 (199)	ENGINE MANAGEME	1.2 8v (09-..)	Marelli IAW 5SF8 CF5/EOBD
 Punto 12 (199)	ENGINE MANAGEME	1.3 Multijet 16v 85cv (09-..)	Marelli IAW 5SF8 CF5/EOBD
 Punto 12 (199)	ENGINE MANAGEME	1.4 8v (09-..)	Marelli IAW 5SF8 CF5/EOBD
 Punto 12 (199)	ENGINE MANAGEME	1.4 8v Natural Power (09-..)	Marelli IAW 5SF8 CF5/EOBD
 Punto 12 (199)	KEY ENCODE	0.9 TwinAir Turbo 105cv (09-..)	DELPHI Body Computer
 Punto 12 (199)	KEY ENCODE	1.2 8v (09-..)	DELPHI Body Computer
 Punto 12 (199)	KEY ENCODE	1.3 Multijet 16v 75cv (09-..)	DELPHI Body Computer
 Punto 12 (199)	KEY ENCODE	1.3 Multijet 16v 85cv (09-..)	DELPHI Body Computer
 Punto 12 (199)	KEY ENCODE	1.4 8v (09-..)	DELPHI Body Computer
 Punto 12 (199)	KEY ENCODE	1.4 8v Natural Power (09-..)	DELPHI Body Computer
 Punto 12 (199)	MAINTENANCE	0.9 TwinAir Turbo 105cv (09-..)	Bosch ESP 8
 Punto 12 (199)	MAINTENANCE	0.9 TwinAir Turbo 105cv (09-..)	DELPHI EPS EP 3
 Punto 12 (199)	MAINTENANCE	0.9 TwinAir Turbo 105cv (09-..)	Marelli Dashboard 3
 Punto 12 (199)	MAINTENANCE	0.9 TwinAir Turbo 105cv (09-..)	Marelli Dashboard 3
 Punto 12 (199)	MAINTENANCE	0.9 TwinAir Turbo 105cv (09-..)	Marelli Dashboard 3
 Punto 12 (199)	MAINTENANCE	1.2 8v (09-..)	Bosch ESP 8
 Punto 12 (199)	MAINTENANCE	1.2 8v (09-..)	DELPHI EPS EP 3
 Punto 12 (199)	MAINTENANCE	1.2 8v (09-..)	Marelli Dashboard 3
 Punto 12 (199)	MAINTENANCE	1.2 8v (09-..)	Marelli Dashboard 3
 Punto 12 (199)	MAINTENANCE	1.2 8v (09-..)	Marelli Dashboard 3
 Punto 12 (199)	MAINTENANCE	1.3 Multijet 16v 75cv (09-..)	Bosch ESP 8
 Punto 12 (199)	MAINTENANCE	1.3 Multijet 16v 75cv (09-..)	DELPHI EPS
 Punto 12 (199)	MAINTENANCE	1.3 Multijet 16v 75cv (09-..)	DELPHI EPS EP 3
 Punto 12 (199)	MAINTENANCE	1.3 Multijet 16v 75cv (09-..)	Marelli Dashboard 3
 Punto 12 (199)	MAINTENANCE	1.3 Multijet 16v 75cv (09-..)	Marelli Dashboard 3
 Punto 12 (199)	MAINTENANCE	1.3 Multijet 16v 75cv (09-..)	Marelli Dashboard 3
 Punto 12 (199)	MAINTENANCE	1.3 Multijet 16v 85cv (09-..)	Bosch ESP 8
 Punto 12 (199)	MAINTENANCE	1.3 Multijet 16v 85cv (09-..)	DELPHI EPS EP 3
 Punto 12 (199)	MAINTENANCE	1.3 Multijet 16v 85cv (09-..)	Marelli Dashboard 3
 Punto 12 (199)	MAINTENANCE	1.3 Multijet 16v 85cv (09-..)	Marelli Dashboard 3
 Punto 12 (199)	MAINTENANCE	1.4 8v (09-..)	Bosch ESP 8
 Punto 12 (199)	MAINTENANCE	1.4 8v (09-..)	DELPHI EPS EP 3
 Punto 12 (199)	MAINTENANCE	1.4 8v (09-..)	Marelli Dashboard 3
 Punto 12 (199)	MAINTENANCE	1.4 8v (09-..)	Marelli Dashboard 3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Punto 12 (199)	MAINTENANCE	1.4 8v (09-..)	Marelli Dashboard 3
 Punto 12 (199)	MAINTENANCE	1.4 8v Natural Power (09-..)	Bosch ESP 8
 Punto 12 (199)	MAINTENANCE	1.4 8v Natural Power (09-..)	DELPHI EPS EP 3
 Punto 12 (199)	MAINTENANCE	1.4 8v Natural Power (09-..)	Marelli Dashboard 3
 Punto 12 (199)	MAINTENANCE	1.4 8v Natural Power (09-..)	Marelli Dashboard 3
 Punto 12 (199)	MAINTENANCE	1.4 8v Natural Power (09-..)	Marelli Dashboard 3
 Punto 12 (199)	PARKING HELP	0.9 TwinAir Turbo 105cv (09-..)	Valeo 2
 Punto 12 (199)	PARKING HELP	1.2 8v (09-..)	Valeo 2
 Punto 12 (199)	PARKING HELP	1.3 Multijet 16v 75cv (09-..)	Valeo 2
 Punto 12 (199)	PARKING HELP	1.3 Multijet 16v 85cv (09-..)	Valeo 2
 Punto 12 (199)	PARKING HELP	1.4 8v (09-..)	Valeo 2
 Punto 12 (199)	PARKING HELP	1.4 8v Natural Power (09-..)	Valeo 2
 Punto 12 (199)	SERVICE LIGHT RES	0.9 TwinAir Turbo 105cv (09-..)	Marelli Dashboard 3
 Punto 12 (199)	SERVICE LIGHT RES	1.2 8v (09-..)	Marelli Dashboard 3
 Punto 12 (199)	SERVICE LIGHT RES	1.3 Multijet 16v 75cv (09-..)	Marelli Dashboard 3
 Punto 12 (199)	SERVICE LIGHT RES	1.3 Multijet 16v 85cv (09-..)	Marelli Dashboard 3
 Punto 12 (199)	SERVICE LIGHT RES	1.4 8v (09-..)	Marelli Dashboard 3
 Punto 12 (199)	SERVICE LIGHT RES	1.4 8v Natural Power (09-..)	Marelli Dashboard 3
 Punto 12 (199)	TIRE PRESSURE	0.9 TwinAir Turbo 105cv (09-..)	TRW
 Punto 12 (199)	TIRE PRESSURE	1.2 8v (09-..)	TRW
 Punto 12 (199)	TIRE PRESSURE	1.3 Multijet 16v 75cv (09-..)	TRW
 Punto 12 (199)	TIRE PRESSURE	1.3 Multijet 16v 85cv (09-..)	TRW
 Punto 12 (199)	TIRE PRESSURE	1.4 8v (09-..)	TRW
 Punto 12 (199)	TIRE PRESSURE	1.4 8v Natural Power (09-..)	TRW
 Punto 12 (199)	VISUAL./TELEMATIC	0.9 TwinAir Turbo 105cv (09-..)	Marelli Convergence
 Punto 12 (199)	VISUAL./TELEMATIC	1.2 8v (09-..)	Marelli Convergence
 Punto 12 (199)	VISUAL./TELEMATIC	1.3 Multijet 16v 75cv (09-..)	Marelli Convergence
 Punto 12 (199)	VISUAL./TELEMATIC	1.3 Multijet 16v 85cv (09-..)	Marelli Convergence
 Punto 12 (199)	VISUAL./TELEMATIC	1.4 8v (09-..)	Marelli Convergence
 Punto 12 (199)	VISUAL./TELEMATIC	1.4 8v Natural Power (09-..)	Marelli Convergence
 Punto Classic (188)	ABS	1.2 8v (.-10)	BOSCH ABS 8
 Punto Classic (188)	ABS	1.2 8v Active LPG (.-10)	BOSCH ABS 8
 Punto Classic (188)	ABS	1.2 8v Natural Power (.-10)	BOSCH ABS 8
 Punto Classic (188)	ABS	1.3 Multijet (.-10)	BOSCH ABS 8
 Punto Classic (188)	AIRBAG	1.2 8v (.-10)	TRW AirBag MY 97 (2F-I)
 Punto Classic (188)	AIRBAG	1.2 8v (.-10)	TRW AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Punto Classic (188)	AIRBAG	1.2 8v (.-10)	TRW AirBag MY 99 (2F-2P-I-S)
 Punto Classic (188)	AIRBAG	1.2 8v (.-10)	TRW AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Punto Classic (188)	AIRBAG	1.2 8v Active LPG (.-10)	TRW AirBag MY 97 (2F-I)
 Punto Classic (188)	AIRBAG	1.2 8v Active LPG (.-10)	TRW AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Punto Classic (188)	AIRBAG	1.2 8v Active LPG (.-10)	TRW AirBag MY 99 (2F-2P-I-S)
 Punto Classic (188)	AIRBAG	1.2 8v Active LPG (.-10)	TRW AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Punto Classic (188)	AIRBAG	1.2 8v Natural Power (.-10)	TRW AirBag MY 97 (2F-I)
 Punto Classic (188)	AIRBAG	1.2 8v Natural Power (.-10)	TRW AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Punto Classic (188)	AIRBAG	1.2 8v Natural Power (.-10)	TRW AirBag MY 99 (2F-2P-I-S)
 Punto Classic (188)	AIRBAG	1.2 8v Natural Power (.-10)	TRW AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Punto Classic (188)	AIRBAG	1.3 Multijet (.-10)	TRW AirBag MY 97 (2F-I)
 Punto Classic (188)	AIRBAG	1.3 Multijet (.-10)	TRW AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Punto Classic (188)	AIRBAG	1.3 Multijet (.-10)	TRW AirBag MY 99 (2F-2P-I-S)
 Punto Classic (188)	AIRBAG	1.3 Multijet (.-10)	TRW AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Punto Classic (188)	AUTOM. TRANSMISSI	1.2 8v (.-10)	FUJI SG-CVT CFC228F
 Punto Classic (188)	AUTOM. TRANSMISSI	1.2 8v Active LPG (.-10)	FUJI SG-CVT CFC228F
 Punto Classic (188)	AUTOM. TRANSMISSI	1.2 8v Natural Power (.-10)	FUJI SG-CVT CFC228F
 Punto Classic (188)	AUTOM. TRANSMISSI	1.3 Multijet (.-10)	FUJI SG-CVT CFC228F
 Punto Classic (188)	CHASSIS NETWORK	1.2 8v (.-10)	DELPHI/Marelli Body Computer
 Punto Classic (188)	CHASSIS NETWORK	1.2 8v (.-10)	Fiat CAN Info
 Punto Classic (188)	CHASSIS NETWORK	1.2 8v (.-10)	Fiat Proxi Alignement
 Punto Classic (188)	CHASSIS NETWORK	1.2 8v Active LPG (.-10)	DELPHI/Marelli Body Computer

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Puncto Classic (188)	CHASSIS NETWORK	1.2 8v Active LPG (...-10)	Fiat CAN Info
 Puncto Classic (188)	CHASSIS NETWORK	1.2 8v Active LPG (...-10)	Fiat Proxi Alignement
 Puncto Classic (188)	CHASSIS NETWORK	1.2 8v Natural Power (...-10)	DELPHI/Marelli Body Computer
 Puncto Classic (188)	CHASSIS NETWORK	1.2 8v Natural Power (...-10)	Fiat CAN Info
 Puncto Classic (188)	CHASSIS NETWORK	1.2 8v Natural Power (...-10)	Fiat Proxi Alignement
 Puncto Classic (188)	CHASSIS NETWORK	1.3 Multijet (...-10)	DELPHI/Marelli Body Computer
 Puncto Classic (188)	CHASSIS NETWORK	1.3 Multijet (...-10)	Fiat CAN Info
 Puncto Classic (188)	CHASSIS NETWORK	1.3 Multijet (...-10)	Fiat Proxi Alignement
 Puncto Classic (188)	DASHBOARD	1.2 8v (...-10)	Marelli Dashboard Comfort
 Puncto Classic (188)	DASHBOARD	1.2 8v (...-10)	Marelli Dashboard Strip/Modale
 Puncto Classic (188)	DASHBOARD	1.2 8v Active LPG (...-10)	Marelli Dashboard Comfort
 Puncto Classic (188)	DASHBOARD	1.2 8v Active LPG (...-10)	Marelli Dashboard Strip/Modale
 Puncto Classic (188)	DASHBOARD	1.2 8v Natural Power (...-10)	Marelli Dashboard Comfort
 Puncto Classic (188)	DASHBOARD	1.2 8v Natural Power (...-10)	Marelli Dashboard Strip/Modale
 Puncto Classic (188)	DASHBOARD	1.3 Multijet (...-10)	Marelli Dashboard Comfort
 Puncto Classic (188)	DASHBOARD	1.3 Multijet (...-10)	Marelli Dashboard Strip/Modale
 Puncto Classic (188)	ELECTRIC STEERING	1.2 8v (...-10)	DELPHI EPS
 Puncto Classic (188)	ELECTRIC STEERING	1.2 8v Active LPG (...-10)	DELPHI EPS
 Puncto Classic (188)	ELECTRIC STEERING	1.2 8v Natural Power (...-10)	DELPHI EPS
 Puncto Classic (188)	ELECTRIC STEERING	1.3 Multijet (...-10)	DELPHI EPS
 Puncto Classic (188)	ENGINE MANAGEME	1.2 8v (...-10)	Marelli IAW 5AF
 Puncto Classic (188)	ENGINE MANAGEME	1.2 8v (...-10)	Marelli IAW 5AF NY
 Puncto Classic (188)	ENGINE MANAGEME	1.2 8v Active LPG (...-10)	EOBD
 Puncto Classic (188)	ENGINE MANAGEME	1.2 8v Natural Power (...-10)	Marelli IAW 5AF
 Puncto Classic (188)	ENGINE MANAGEME	1.3 Multijet (...-10)	Marelli 6JF CF3 Common Rail
 Puncto Classic (188)	ENGINE MANAGEME	1.2 8v Natural Power (...-10)	METATRON 6A0 EOBD
 Puncto Classic (188)	KEY ENCODE	1.2 8v (...-10)	DELPHI/Marelli CODE Body Computer
 Puncto Classic (188)	KEY ENCODE	1.2 8v Active LPG (...-10)	DELPHI/Marelli CODE Body Computer
 Puncto Classic (188)	KEY ENCODE	1.2 8v Natural Power (...-10)	DELPHI/Marelli CODE Body Computer
 Puncto Classic (188)	KEY ENCODE	1.3 Multijet (...-10)	DELPHI/Marelli CODE Body Computer
 Puncto Classic (188)	MAINTENANCE	1.2 8v (...-10)	DELPHI EPS
 Puncto Classic (188)	MAINTENANCE	1.2 8v (...-10)	Marelli Dashboard
 Puncto Classic (188)	MAINTENANCE	1.2 8v (...-10)	Marelli Dashboard Comfort
 Puncto Classic (188)	MAINTENANCE	1.2 8v (...-10)	Marelli Dashboard Comfort
 Puncto Classic (188)	MAINTENANCE	1.2 8v (...-10)	Marelli Dashboard Strip/Modale
 Puncto Classic (188)	MAINTENANCE	1.2 8v (...-10)	Marelli IAW 5AF
 Puncto Classic (188)	MAINTENANCE	1.2 8v (...-10)	Marelli IAW 5AF NY
 Puncto Classic (188)	MAINTENANCE	1.2 8v Active LPG (...-10)	DELPHI EPS
 Puncto Classic (188)	MAINTENANCE	1.2 8v Active LPG (...-10)	Marelli Dashboard
 Puncto Classic (188)	MAINTENANCE	1.2 8v Active LPG (...-10)	Marelli Dashboard Comfort
 Puncto Classic (188)	MAINTENANCE	1.2 8v Active LPG (...-10)	Marelli Dashboard Comfort
 Puncto Classic (188)	MAINTENANCE	1.2 8v Active LPG (...-10)	Marelli Dashboard Strip/Modale
 Puncto Classic (188)	MAINTENANCE	1.2 8v Natural Power (...-10)	DELPHI EPS
 Puncto Classic (188)	MAINTENANCE	1.2 8v Natural Power (...-10)	Marelli Dashboard
 Puncto Classic (188)	MAINTENANCE	1.2 8v Natural Power (...-10)	Marelli Dashboard Comfort
 Puncto Classic (188)	MAINTENANCE	1.2 8v Natural Power (...-10)	Marelli Dashboard Comfort
 Puncto Classic (188)	MAINTENANCE	1.2 8v Natural Power (...-10)	Marelli Dashboard Strip/Modale
 Puncto Classic (188)	MAINTENANCE	1.2 8v Natural Power (...-10)	Marelli IAW 5AF
 Puncto Classic (188)	MAINTENANCE	1.3 Multijet (...-10)	DELPHI EPS
 Puncto Classic (188)	MAINTENANCE	1.3 Multijet (...-10)	Marelli Dashboard
 Puncto Classic (188)	MAINTENANCE	1.3 Multijet (...-10)	Marelli Dashboard Comfort
 Puncto Classic (188)	MAINTENANCE	1.3 Multijet (...-10)	Marelli Dashboard Comfort
 Puncto Classic (188)	MAINTENANCE	1.3 Multijet (...-10)	Marelli Dashboard Strip/Modale
 Puncto Classic (188)	SERVICE LIGHT RES	1.2 8v (...-10)	Marelli Dashboard
 Puncto Classic (188)	SERVICE LIGHT RES	1.2 8v Active LPG (...-10)	Marelli Dashboard
 Puncto Classic (188)	SERVICE LIGHT RES	1.2 8v Natural Power (...-10)	Marelli Dashboard
 Puncto Classic (188)	SERVICE LIGHT RES	1.3 Multijet (...-10)	Marelli Dashboard
 Puncto Evo (199)	ABS + TRACT. CONT	1.2 8v (09-..)	Bosch ESP 8

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Puncto Evo (199)	ABS + TRACT. CONT	1.3 Multijet 16v 75cv (09-..)	Bosch ESP 8
 Puncto Evo (199)	ABS + TRACT. CONT	1.3 Multijet 16v 90cv (09-..)	Bosch ESP 8
 Puncto Evo (199)	ABS + TRACT. CONT	1.3 Multijet 16v 95cv (09-..)	Bosch ESP 8
 Puncto Evo (199)	ABS + TRACT. CONT	1.4 8v (09-..)	Bosch ESP 8
 Puncto Evo (199)	ABS + TRACT. CONT	1.4 8v GPL (09-..)	Bosch ESP 8
 Puncto Evo (199)	ABS + TRACT. CONT	1.4 8v Natural Power (09-..)	Bosch ESP 8
 Puncto Evo (199)	ABS + TRACT. CONT	1.4 Multiair 16v 105cv (09-..)	Bosch ESP 8
 Puncto Evo (199)	ABS + TRACT. CONT	1.4 MultiAir Turbo 16v 135cv (09-..)	Bosch ESP 8
 Puncto Evo (199)	ABS + TRACT. CONT	1.6 MJET 16v (09-..)	Bosch ESP 8
 Puncto Evo (199)	AIRBAG	1.2 8v (09-..)	CONTINENTAL SRS EP
 Puncto Evo (199)	AIRBAG	1.3 Multijet 16v 75cv (09-..)	CONTINENTAL SRS EP
 Puncto Evo (199)	AIRBAG	1.3 Multijet 16v 90cv (09-..)	CONTINENTAL SRS EP
 Puncto Evo (199)	AIRBAG	1.3 Multijet 16v 95cv (09-..)	CONTINENTAL SRS EP
 Puncto Evo (199)	AIRBAG	1.4 8v (09-..)	CONTINENTAL SRS EP
 Puncto Evo (199)	AIRBAG	1.4 8v GPL (09-..)	CONTINENTAL SRS EP
 Puncto Evo (199)	AIRBAG	1.4 8v Natural Power (09-..)	CONTINENTAL SRS EP
 Puncto Evo (199)	AIRBAG	1.4 Multiair 16v 105cv (09-..)	CONTINENTAL SRS EP
 Puncto Evo (199)	AIRBAG	1.4 MultiAir Turbo 16v 135cv (09-..)	CONTINENTAL SRS EP
 Puncto Evo (199)	AIRBAG	1.6 MJET 16v (09-..)	CONTINENTAL SRS EP
 Puncto Evo (199)	AUTOM. TRANSMISSI	1.2 8v (09-..)	Marelli Selespeed CFC328 - 2
 Puncto Evo (199)	AUTOM. TRANSMISSI	1.3 Multijet 16v 75cv (09-..)	Marelli Selespeed CFC328 - 2
 Puncto Evo (199)	AUTOM. TRANSMISSI	1.3 Multijet 16v 90cv (09-..)	Marelli Selespeed CFC328 - 2
 Puncto Evo (199)	AUTOM. TRANSMISSI	1.3 Multijet 16v 95cv (09-..)	Marelli Selespeed CFC328 - 2
 Puncto Evo (199)	AUTOM. TRANSMISSI	1.4 8v (09-..)	Marelli Selespeed CFC328 - 2
 Puncto Evo (199)	AUTOM. TRANSMISSI	1.4 8v GPL (09-..)	Marelli Selespeed CFC328 - 2
 Puncto Evo (199)	AUTOM. TRANSMISSI	1.4 8v Natural Power (09-..)	Marelli Selespeed CFC328 - 2
 Puncto Evo (199)	AUTOM. TRANSMISSI	1.4 Multiair 16v 105cv (09-..)	Marelli Selespeed CFC328 - 2
 Puncto Evo (199)	AUTOM. TRANSMISSI	1.4 MultiAir Turbo 16v 135cv (09-..)	Marelli Selespeed CFC328 - 2
 Puncto Evo (199)	AUTOM. TRANSMISSI	1.6 MJET 16v (09-..)	Marelli Selespeed CFC328 - 2
 Puncto Evo (199)	CHASSIS NETWORK	1.2 8v (09-..)	DELPHI Body Computer
 Puncto Evo (199)	CHASSIS NETWORK	1.2 8v (09-..)	DELPHI Body Computer CAN Info
 Puncto Evo (199)	CHASSIS NETWORK	1.2 8v (09-..)	DELPHI Body Computer Proxi Alignement
 Puncto Evo (199)	CHASSIS NETWORK	1.3 Multijet 16v 75cv (09-..)	DELPHI Body Computer
 Puncto Evo (199)	CHASSIS NETWORK	1.3 Multijet 16v 75cv (09-..)	DELPHI Body Computer CAN Info
 Puncto Evo (199)	CHASSIS NETWORK	1.3 Multijet 16v 75cv (09-..)	DELPHI Body Computer Proxi Alignement
 Puncto Evo (199)	CHASSIS NETWORK	1.3 Multijet 16v 90cv (09-..)	DELPHI Body Computer
 Puncto Evo (199)	CHASSIS NETWORK	1.3 Multijet 16v 90cv (09-..)	DELPHI Body Computer CAN Info
 Puncto Evo (199)	CHASSIS NETWORK	1.3 Multijet 16v 90cv (09-..)	DELPHI Body Computer Proxi Alignement
 Puncto Evo (199)	CHASSIS NETWORK	1.3 Multijet 16v 95cv (09-..)	DELPHI Body Computer
 Puncto Evo (199)	CHASSIS NETWORK	1.3 Multijet 16v 95cv (09-..)	DELPHI Body Computer CAN Info
 Puncto Evo (199)	CHASSIS NETWORK	1.3 Multijet 16v 95cv (09-..)	DELPHI Body Computer Proxi Alignement
 Puncto Evo (199)	CHASSIS NETWORK	1.4 8v (09-..)	DELPHI Body Computer
 Puncto Evo (199)	CHASSIS NETWORK	1.4 8v (09-..)	DELPHI Body Computer CAN Info
 Puncto Evo (199)	CHASSIS NETWORK	1.4 8v (09-..)	DELPHI Body Computer Proxi Alignement
 Puncto Evo (199)	CHASSIS NETWORK	1.4 8v GPL (09-..)	DELPHI Body Computer
 Puncto Evo (199)	CHASSIS NETWORK	1.4 8v GPL (09-..)	DELPHI Body Computer CAN Info
 Puncto Evo (199)	CHASSIS NETWORK	1.4 8v GPL (09-..)	DELPHI Body Computer Proxi Alignement
 Puncto Evo (199)	CHASSIS NETWORK	1.4 8v Natural Power (09-..)	DELPHI Body Computer
 Puncto Evo (199)	CHASSIS NETWORK	1.4 8v Natural Power (09-..)	DELPHI Body Computer CAN Info
 Puncto Evo (199)	CHASSIS NETWORK	1.4 8v Natural Power (09-..)	DELPHI Body Computer Proxi Alignement
 Puncto Evo (199)	CHASSIS NETWORK	1.4 Multiair 16v 105cv (09-..)	DELPHI Body Computer
 Puncto Evo (199)	CHASSIS NETWORK	1.4 Multiair 16v 105cv (09-..)	DELPHI Body Computer CAN Info
 Puncto Evo (199)	CHASSIS NETWORK	1.4 Multiair 16v 105cv (09-..)	DELPHI Body Computer Proxi Alignement
 Puncto Evo (199)	CHASSIS NETWORK	1.4 MultiAir Turbo 16v 135cv (09-..)	DELPHI Body Computer
 Puncto Evo (199)	CHASSIS NETWORK	1.4 MultiAir Turbo 16v 135cv (09-..)	DELPHI Body Computer CAN Info
 Puncto Evo (199)	CHASSIS NETWORK	1.4 MultiAir Turbo 16v 135cv (09-..)	DELPHI Body Computer Proxi Alignement
 Puncto Evo (199)	CHASSIS NETWORK	1.6 MJET 16v (09-..)	DELPHI Body Computer
 Puncto Evo (199)	CHASSIS NETWORK	1.6 MJET 16v (09-..)	DELPHI Body Computer CAN Info

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Puncto Evo (199)	CHASSIS NETWORK	1.6 MJET 16v (09-..)	DELPHI Body Computer Proxi Alignement
 Puncto Evo (199)	CLIMA	1.2 8v (09-..)	DENSO Clima
 Puncto Evo (199)	CLIMA	1.3 Multijet 16v 75cv (09-..)	DENSO Clima
 Puncto Evo (199)	CLIMA	1.3 Multijet 16v 90cv (09-..)	DENSO Clima
 Puncto Evo (199)	CLIMA	1.3 Multijet 16v 95cv (09-..)	DENSO Clima
 Puncto Evo (199)	CLIMA	1.4 8v (09-..)	DENSO Clima
 Puncto Evo (199)	CLIMA	1.4 8v GPL (09-..)	DENSO Clima
 Puncto Evo (199)	CLIMA	1.4 8v Natural Power (09-..)	DENSO Clima
 Puncto Evo (199)	CLIMA	1.4 Multiair 16v 105cv (09-..)	DENSO Clima
 Puncto Evo (199)	CLIMA	1.4 MultiAir Turbo 16v 135cv (09-..)	DENSO Clima
 Puncto Evo (199)	CLIMA	1.6 MJET 16v (09-..)	DENSO Clima
 Puncto Evo (199)	DASHBOARD	1.2 8v (09-..)	Marelli Dashboard 3
 Puncto Evo (199)	DASHBOARD	1.3 Multijet 16v 75cv (09-..)	Marelli Dashboard 3
 Puncto Evo (199)	DASHBOARD	1.3 Multijet 16v 90cv (09-..)	Marelli Dashboard 3
 Puncto Evo (199)	DASHBOARD	1.3 Multijet 16v 95cv (09-..)	Marelli Dashboard 3
 Puncto Evo (199)	DASHBOARD	1.4 8v (09-..)	Marelli Dashboard 3
 Puncto Evo (199)	DASHBOARD	1.4 8v GPL (09-..)	Marelli Dashboard 3
 Puncto Evo (199)	DASHBOARD	1.4 8v Natural Power (09-..)	Marelli Dashboard 3
 Puncto Evo (199)	DASHBOARD	1.4 Multiair 16v 105cv (09-..)	Marelli Dashboard 3
 Puncto Evo (199)	DASHBOARD	1.4 MultiAir Turbo 16v 135cv (09-..)	Marelli Dashboard 3
 Puncto Evo (199)	DASHBOARD	1.6 MJET 16v (09-..)	Marelli Dashboard 3
 Puncto Evo (199)	ELECTRIC STEERING	1.2 8v (09-..)	DELPHI EPS
 Puncto Evo (199)	ELECTRIC STEERING	1.2 8v (09-..)	DELPHI EPS EP 3
 Puncto Evo (199)	ELECTRIC STEERING	1.3 Multijet 16v 75cv (09-..)	DELPHI EPS
 Puncto Evo (199)	ELECTRIC STEERING	1.3 Multijet 16v 75cv (09-..)	DELPHI EPS EP 3
 Puncto Evo (199)	ELECTRIC STEERING	1.3 Multijet 16v 90cv (09-..)	DELPHI EPS
 Puncto Evo (199)	ELECTRIC STEERING	1.3 Multijet 16v 90cv (09-..)	DELPHI EPS EP 3
 Puncto Evo (199)	ELECTRIC STEERING	1.3 Multijet 16v 95cv (09-..)	DELPHI EPS
 Puncto Evo (199)	ELECTRIC STEERING	1.3 Multijet 16v 95cv (09-..)	DELPHI EPS EP 3
 Puncto Evo (199)	ELECTRIC STEERING	1.4 8v (09-..)	DELPHI EPS
 Puncto Evo (199)	ELECTRIC STEERING	1.4 8v (09-..)	DELPHI EPS EP 3
 Puncto Evo (199)	ELECTRIC STEERING	1.4 8v GPL (09-..)	DELPHI EPS
 Puncto Evo (199)	ELECTRIC STEERING	1.4 8v GPL (09-..)	DELPHI EPS EP 3
 Puncto Evo (199)	ELECTRIC STEERING	1.4 8v Natural Power (09-..)	DELPHI EPS
 Puncto Evo (199)	ELECTRIC STEERING	1.4 8v Natural Power (09-..)	DELPHI EPS EP 3
 Puncto Evo (199)	ELECTRIC STEERING	1.4 Multiair 16v 105cv (09-..)	DELPHI EPS
 Puncto Evo (199)	ELECTRIC STEERING	1.4 Multiair 16v 105cv (09-..)	DELPHI EPS EP 3
 Puncto Evo (199)	ELECTRIC STEERING	1.4 MultiAir Turbo 16v 135cv (09-..)	DELPHI EPS
 Puncto Evo (199)	ELECTRIC STEERING	1.4 MultiAir Turbo 16v 135cv (09-..)	DELPHI EPS EP 3
 Puncto Evo (199)	ELECTRIC STEERING	1.6 MJET 16v (09-..)	DELPHI EPS
 Puncto Evo (199)	ELECTRIC STEERING	1.6 MJET 16v (09-..)	DELPHI EPS EP 3
 Puncto Evo (199)	ENGINE MANAGEME	1.2 8v (09-..)	Marelli IAW 5SF3
 Puncto Evo (199)	ENGINE MANAGEME	1.2 8v (09-..)	Marelli IAW 5SF8 CF5/EOBD
 Puncto Evo (199)	ENGINE MANAGEME	1.3 Multijet 16v 75cv (09-..)	Marelli EDC 6F3
 Puncto Evo (199)	ENGINE MANAGEME	1.3 Multijet 16v 75cv (09-..)	Marelli EDC 8DF CF5
 Puncto Evo (199)	ENGINE MANAGEME	1.3 Multijet 16v 75cv (09-..)	Marelli EDC 8F3 CF5
 Puncto Evo (199)	ENGINE MANAGEME	1.3 Multijet 16v 90cv (09-..)	Marelli EDC 6F3
 Puncto Evo (199)	ENGINE MANAGEME	1.3 Multijet 16v 90cv (09-..)	Marelli EDC 6F3 (D.P.F.)
 Puncto Evo (199)	ENGINE MANAGEME	1.3 Multijet 16v 95cv (09-..)	EOBD
 Puncto Evo (199)	ENGINE MANAGEME	1.3 Multijet 16v 95cv (09-..)	Marelli EDC 8DF CF5
 Puncto Evo (199)	ENGINE MANAGEME	1.3 Multijet 16v 95cv (09-..)	Marelli EDC 8F3 CF5
 Puncto Evo (199)	ENGINE MANAGEME	1.4 8v (09-..)	EOBD
 Puncto Evo (199)	ENGINE MANAGEME	1.4 8v GPL (09-..)	EOBD
 Puncto Evo (199)	ENGINE MANAGEME	1.4 8v Natural Power (09-..)	Marelli IAW 5FF8 E4
 Puncto Evo (199)	ENGINE MANAGEME	1.4 Multiair 16v 105cv (09-..)	EOBD
 Puncto Evo (199)	ENGINE MANAGEME	1.4 Multiair 16v 105cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Puncto Evo (199)	ENGINE MANAGEME	1.4 MultiAir Turbo 16v 135cv (09-..)	EOBD
 Puncto Evo (199)	ENGINE MANAGEME	1.4 MultiAir Turbo 16v 135cv (09-..)	Marelli IAW 8GMF CF5/EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Puncto Evo (199)	ENGINE MANAGEME	1.6 MJET 16v (09-..)	BOSCH EDC16C39 CF5/EOBD
 Puncto Evo (199)	FAP OIL PARAMETER	1.3 Multijet 16v 75cv (09-..)	Marelli
 Puncto Evo (199)	FAP OIL PARAMETER	1.3 Multijet 16v 90cv (09-..)	Marelli
 Puncto Evo (199)	FAP OIL PARAMETER	1.3 Multijet 16v 95cv (09-..)	Marelli
 Puncto Evo (199)	KEY ENCODE	1.2 8v (09-..)	DELPHI Body Computer
 Puncto Evo (199)	KEY ENCODE	1.3 Multijet 16v 75cv (09-..)	DELPHI Body Computer
 Puncto Evo (199)	KEY ENCODE	1.3 Multijet 16v 90cv (09-..)	DELPHI Body Computer
 Puncto Evo (199)	KEY ENCODE	1.3 Multijet 16v 95cv (09-..)	DELPHI Body Computer
 Puncto Evo (199)	KEY ENCODE	1.4 8v (09-..)	DELPHI Body Computer
 Puncto Evo (199)	KEY ENCODE	1.4 8v GPL (09-..)	DELPHI Body Computer
 Puncto Evo (199)	KEY ENCODE	1.4 8v Natural Power (09-..)	DELPHI Body Computer
 Puncto Evo (199)	KEY ENCODE	1.4 MultiAir 16v 105cv (09-..)	DELPHI Body Computer
 Puncto Evo (199)	KEY ENCODE	1.4 MultiAir Turbo 16v 135cv (09-..)	DELPHI Body Computer
 Puncto Evo (199)	KEY ENCODE	1.6 MJET 16v (09-..)	DELPHI Body Computer
 Puncto Evo (199)	MAINTENANCE	1.2 8v (09-..)	Bosch ESP 8
 Puncto Evo (199)	MAINTENANCE	1.2 8v (09-..)	DELPHI EPS
 Puncto Evo (199)	MAINTENANCE	1.2 8v (09-..)	DELPHI EPS EP 3
 Puncto Evo (199)	MAINTENANCE	1.2 8v (09-..)	Marelli Dashboard 3
 Puncto Evo (199)	MAINTENANCE	1.2 8v (09-..)	Marelli Dashboard 3
 Puncto Evo (199)	MAINTENANCE	1.2 8v (09-..)	Marelli Dashboard 3
 Puncto Evo (199)	MAINTENANCE	1.2 8v (09-..)	Marelli IAW 5SF3
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 75cv (09-..)	Bosch ESP 8
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 75cv (09-..)	DELPHI EPS
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 75cv (09-..)	DELPHI EPS EP 3
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 75cv (09-..)	Marelli
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 75cv (09-..)	Marelli Dashboard 3
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 75cv (09-..)	Marelli Dashboard 3
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 75cv (09-..)	Marelli Dashboard 3
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 75cv (09-..)	Marelli EDC 6F3
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 75cv (09-..)	Marelli EDC 8DF CF5
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 75cv (09-..)	Marelli EDC 8DF CF5
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 75cv (09-..)	Marelli EDC 8F3 CF5
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 75cv (09-..)	Marelli EDC 8F3 CF5
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 90cv (09-..)	Bosch ESP 8
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 90cv (09-..)	DELPHI EPS
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 90cv (09-..)	DELPHI EPS EP 3
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 90cv (09-..)	Marelli
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 90cv (09-..)	Marelli Dashboard 3
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 90cv (09-..)	Marelli Dashboard 3
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 90cv (09-..)	Marelli Dashboard 3
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 90cv (09-..)	Marelli EDC 6F3
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 90cv (09-..)	Marelli EDC 6F3 (D.P.F.)
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 90cv (09-..)	Marelli EDC 6F3 (D.P.F.)
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 90cv (09-..)	Marelli EDC 6F3 (D.P.F.)
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 90cv (09-..)	Marelli EDC 6F3 (D.P.F.)
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 95cv (09-..)	Bosch ESP 8
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 95cv (09-..)	DELPHI EPS
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 95cv (09-..)	DELPHI EPS EP 3
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 95cv (09-..)	Marelli
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 95cv (09-..)	Marelli Dashboard 3
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 95cv (09-..)	Marelli Dashboard 3
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 95cv (09-..)	Marelli Dashboard 3
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 95cv (09-..)	Marelli EDC 8DF CF5
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 95cv (09-..)	Marelli EDC 8DF CF5
 Puncto Evo (199)	MAINTENANCE	1.3 Multijet 16v 95cv (09-..)	Marelli EDC 8F3 CF5
 Puncto Evo (199)	MAINTENANCE	1.4 8v (09-..)	Bosch ESP 8
 Puncto Evo (199)	MAINTENANCE	1.4 8v (09-..)	DELPHI EPS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Punto Evo (199)	MAINTENANCE	1.4 8v (09-...)	DELPHI EPS EP 3
 Punto Evo (199)	MAINTENANCE	1.4 8v (09-...)	Marelli Dashboard 3
 Punto Evo (199)	MAINTENANCE	1.4 8v (09-...)	Marelli Dashboard 3
 Punto Evo (199)	MAINTENANCE	1.4 8v (09-...)	Marelli Dashboard 3
 Punto Evo (199)	MAINTENANCE	1.4 8v GPL (09-..)	Bosch ESP 8
 Punto Evo (199)	MAINTENANCE	1.4 8v GPL (09-..)	DELPHI EPS
 Punto Evo (199)	MAINTENANCE	1.4 8v GPL (09-..)	DELPHI EPS EP 3
 Punto Evo (199)	MAINTENANCE	1.4 8v GPL (09-..)	Marelli Dashboard 3
 Punto Evo (199)	MAINTENANCE	1.4 8v GPL (09-..)	Marelli Dashboard 3
 Punto Evo (199)	MAINTENANCE	1.4 8v GPL (09-..)	Marelli Dashboard 3
 Punto Evo (199)	MAINTENANCE	1.4 8v Natural Power (09-..)	Bosch ESP 8
 Punto Evo (199)	MAINTENANCE	1.4 8v Natural Power (09-..)	DELPHI EPS
 Punto Evo (199)	MAINTENANCE	1.4 8v Natural Power (09-..)	DELPHI EPS EP 3
 Punto Evo (199)	MAINTENANCE	1.4 8v Natural Power (09-..)	Marelli Dashboard 3
 Punto Evo (199)	MAINTENANCE	1.4 8v Natural Power (09-..)	Marelli Dashboard 3
 Punto Evo (199)	MAINTENANCE	1.4 8v Natural Power (09-..)	Marelli Dashboard 3
 Punto Evo (199)	MAINTENANCE	1.4 8v Natural Power (09-..)	Marelli IAW 5FF8 E4
 Punto Evo (199)	MAINTENANCE	1.4 Multiair 16v 105cv (09-..)	Bosch ESP 8
 Punto Evo (199)	MAINTENANCE	1.4 Multiair 16v 105cv (09-..)	DELPHI EPS
 Punto Evo (199)	MAINTENANCE	1.4 Multiair 16v 105cv (09-..)	DELPHI EPS EP 3
 Punto Evo (199)	MAINTENANCE	1.4 Multiair 16v 105cv (09-..)	Marelli Dashboard 3
 Punto Evo (199)	MAINTENANCE	1.4 Multiair 16v 105cv (09-..)	Marelli Dashboard 3
 Punto Evo (199)	MAINTENANCE	1.4 Multiair 16v 105cv (09-..)	Marelli Dashboard 3
 Punto Evo (199)	MAINTENANCE	1.4 Multiair 16v 105cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Punto Evo (199)	MAINTENANCE	1.4 Multiair 16v 105cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Punto Evo (199)	MAINTENANCE	1.4 Multiair 16v 105cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Punto Evo (199)	MAINTENANCE	1.4 Multiair 16v 105cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Punto Evo (199)	MAINTENANCE	1.4 Multiair 16v 105cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Punto Evo (199)	MAINTENANCE	1.4 Multiair 16v 105cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Punto Evo (199)	MAINTENANCE	1.4 Multiair 16v 105cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Punto Evo (199)	MAINTENANCE	1.4 Multiair 16v 105cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Punto Evo (199)	MAINTENANCE	1.4 Multiair 16v 105cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Punto Evo (199)	MAINTENANCE	1.4 Multiair 16v 105cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Punto Evo (199)	MAINTENANCE	1.4 Multiair 16v 105cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Punto Evo (199)	MAINTENANCE	1.4 MultiAir Turbo 16v 135cv (09-..)	Bosch ESP 8
 Punto Evo (199)	MAINTENANCE	1.4 MultiAir Turbo 16v 135cv (09-..)	DELPHI EPS
 Punto Evo (199)	MAINTENANCE	1.4 MultiAir Turbo 16v 135cv (09-..)	DELPHI EPS EP 3
 Punto Evo (199)	MAINTENANCE	1.4 MultiAir Turbo 16v 135cv (09-..)	Marelli Dashboard 3
 Punto Evo (199)	MAINTENANCE	1.4 MultiAir Turbo 16v 135cv (09-..)	Marelli Dashboard 3
 Punto Evo (199)	MAINTENANCE	1.4 MultiAir Turbo 16v 135cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Punto Evo (199)	MAINTENANCE	1.4 MultiAir Turbo 16v 135cv (09-..)	Marelli IAW 8GMF CF5/EOBD
 Punto Evo (199)	MAINTENANCE	1.4 MultiAir Turbo 16v 135cv (09-..)	Marelli IAW 8GMF CF5/EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

[illegible]

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Punto Evo (199)	TIRE PRESSURE	1.6 MJET 16v (09-..)	TRW
 Punto Evo (199)	VISUAL./TELEMATIC	1.2 8v (09-..)	Marelli Convergence
 Punto Evo (199)	VISUAL./TELEMATIC	1.3 Multijet 16v 75cv (08-..)	Marelli Convergence
 Punto Evo (199)	VISUAL./TELEMATIC	1.3 Multijet 16v 90cv (08-..)	Marelli Convergence
 Punto Evo (199)	VISUAL./TELEMATIC	1.3 Multijet 16v 95cv (08-..)	Marelli Convergence
 Punto Evo (199)	VISUAL./TELEMATIC	1.4 8v (08-..)	Marelli Convergence
 Punto Evo (199)	VISUAL./TELEMATIC	1.4 8v GPL (08-..)	Marelli Convergence
 Punto Evo (199)	VISUAL./TELEMATIC	1.4 8v Natural Power (08-..)	Marelli Convergence
 Punto Evo (199)	VISUAL./TELEMATIC	1.4 Multiair 16v 105cv (08-..)	Marelli Convergence
 Punto Evo (199)	VISUAL./TELEMATIC	1.4 MultiAir Turbo 16v 135cv (08-..)	Marelli Convergence
 Punto Evo (199)	VISUAL./TELEMATIC	1.6 MJET 16v (08-..)	Marelli Convergence
 Punto Van	ABS	1.2 8v (03-05)	BOSCH ABS 8
 Punto Van	ABS	1.2 8v Bipower (03-05)	BOSCH ABS 8
 Punto Van	ABS	1.3 Multijet (03-05)	BOSCH ABS 8
 Punto Van	AIRBAG	1.2 8v (03-05)	TRW AirBag MY 97 (2F-I)
 Punto Van	AIRBAG	1.2 8v (03-05)	TRW AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Punto Van	AIRBAG	1.2 8v (03-05)	TRW AirBag MY 99 (2F-2P-I-S)
 Punto Van	AIRBAG	1.2 8v (03-05)	TRW AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Punto Van	AIRBAG	1.2 8v Bipower (03-05)	TRW AirBag MY 97 (2F-I)
 Punto Van	AIRBAG	1.2 8v Bipower (03-05)	TRW AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Punto Van	AIRBAG	1.2 8v Bipower (03-05)	TRW AirBag MY 99 (2F-2P-I-S)
 Punto Van	AIRBAG	1.2 8v Bipower (03-05)	TRW AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Punto Van	AIRBAG	1.3 Multijet (03-05)	TRW AirBag MY 97 (2F-I)
 Punto Van	AIRBAG	1.3 Multijet (03-05)	TRW AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Punto Van	AIRBAG	1.3 Multijet (03-05)	TRW AirBag MY 99 (2F-2P-I-S)
 Punto Van	AIRBAG	1.3 Multijet (03-05)	TRW AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Punto Van	CHASSIS NETWORK	1.2 8v (03-05)	DELPHI/Marelli Body Computer
 Punto Van	CHASSIS NETWORK	1.2 8v (03-05)	Fiat CAN Info
 Punto Van	CHASSIS NETWORK	1.2 8v (03-05)	Fiat Proxi Alignement
 Punto Van	CHASSIS NETWORK	1.2 8v Bipower (03-05)	DELPHI/Marelli Body Computer
 Punto Van	CHASSIS NETWORK	1.2 8v Bipower (03-05)	Fiat CAN Info
 Punto Van	CHASSIS NETWORK	1.2 8v Bipower (03-05)	Fiat Proxi Alignement
 Punto Van	CHASSIS NETWORK	1.3 Multijet (03-05)	DELPHI/Marelli Body Computer
 Punto Van	CHASSIS NETWORK	1.3 Multijet (03-05)	Fiat CAN Info
 Punto Van	CHASSIS NETWORK	1.3 Multijet (03-05)	Fiat Proxi Alignement
 Punto Van	CLIMA	1.2 8v (03-05)	DENSO 2
 Punto Van	CLIMA	1.2 8v Bipower (03-05)	DENSO 2
 Punto Van	CLIMA	1.3 Multijet (03-05)	DENSO 2
 Punto Van	DASHBOARD	1.2 8v (03-05)	Marelli Dashboard Comfort
 Punto Van	DASHBOARD	1.2 8v (03-05)	Marelli Dashboard Strip/Modale
 Punto Van	DASHBOARD	1.2 8v Bipower (03-05)	Marelli Dashboard Comfort
 Punto Van	DASHBOARD	1.2 8v Bipower (03-05)	Marelli Dashboard Strip/Modale
 Punto Van	DASHBOARD	1.3 Multijet (03-05)	Marelli Dashboard Comfort
 Punto Van	DASHBOARD	1.3 Multijet (03-05)	Marelli Dashboard Strip/Modale
 Punto Van	ELECTRIC STEERING	1.2 8v (03-05)	DELPHI EPS
 Punto Van	ELECTRIC STEERING	1.2 8v Bipower (03-05)	DELPHI EPS
 Punto Van	ELECTRIC STEERING	1.3 Multijet (03-05)	DELPHI EPS
 Punto Van	ENGINE MANAGEME	1.2 8v (03-05)	BOSCH Motronic ME7.3H4 EOBD
 Punto Van	ENGINE MANAGEME	1.2 8v Bipower (03-05)	BOSCH Motronic ME7.3H4 EOBD
 Punto Van	ENGINE MANAGEME	1.3 Multijet (03-05)	BOSCH Motronic ME7.3H4 EOBD
 Punto Van	MAINTENANCE	1.2 8v (03-05)	DELPHI EPS
 Punto Van	MAINTENANCE	1.2 8v (03-05)	Marelli Dashboard
 Punto Van	MAINTENANCE	1.2 8v (03-05)	Marelli Dashboard Comfort
 Punto Van	MAINTENANCE	1.2 8v (03-05)	Marelli Dashboard Comfort
 Punto Van	MAINTENANCE	1.2 8v (03-05)	Marelli Dashboard Strip/Modale
 Punto Van	MAINTENANCE	1.2 8v Bipower (03-05)	DELPHI EPS
 Punto Van	MAINTENANCE	1.2 8v Bipower (03-05)	Marelli Dashboard
 Punto Van	MAINTENANCE	1.2 8v Bipower (03-05)	Marelli Dashboard Comfort

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Punto Van	MAINTENANCE	1.2 8v Bipower (03-05)	Marelli Dashboard Comfort
 Punto Van	MAINTENANCE	1.2 8v Bipower (03-05)	Marelli Dashboard Strip/Modale
 Punto Van	MAINTENANCE	1.3 Multijet (03-05)	DELPHI EPS
 Punto Van	MAINTENANCE	1.3 Multijet (03-05)	Marelli Dashboard
 Punto Van	MAINTENANCE	1.3 Multijet (03-05)	Marelli Dashboard Comfort
 Punto Van	MAINTENANCE	1.3 Multijet (03-05)	Marelli Dashboard Comfort
 Punto Van	MAINTENANCE	1.3 Multijet (03-05)	Marelli Dashboard Strip/Modale
 Punto Van	SERVICE LIGHT RES	1.2 8v (03-05)	Marelli Dashboard
 Punto Van	SERVICE LIGHT RES	1.2 8v Bipower (03-05)	Marelli Dashboard
 Punto Van	SERVICE LIGHT RES	1.3 Multijet (03-05)	Marelli Dashboard
 Qubo	ABS + TRACT. CONT	1.3 Multijet 16v 95cv (08-..)	ABS BOSCH 8.1 AUTODETECT
 Qubo	ABS + TRACT. CONT	1.3 Multijet 16v 95cv (08-..)	BOSCH ESP 8
 Qubo	ABS + TRACT. CONT	1.3 Multijet 75cv (08-..)	ABS BOSCH 8.1 AUTODETECT
 Qubo	ABS + TRACT. CONT	1.3 Multijet 75cv (08-..)	BOSCH ESP 8
 Qubo	ABS + TRACT. CONT	1.4 8v (08-..)	ABS BOSCH 8.1 AUTODETECT
 Qubo	ABS + TRACT. CONT	1.4 8v (08-..)	BOSCH ESP 8
 Qubo	ABS + TRACT. CONT	1.4 8v Natural Power (08-..)	ABS BOSCH 8.1 AUTODETECT
 Qubo	ABS + TRACT. CONT	1.4 8v Natural Power (08-..)	BOSCH ESP 8
 Qubo	AIRBAG	1.3 Multijet 16v 95cv (08-..)	AUTOLIV AirBag CENTRAL AUTODETECT
 Qubo	AIRBAG	1.3 Multijet 16v 95cv (08-..)	TRW SRS EP
 Qubo	AIRBAG	1.3 Multijet 75cv (08-..)	AUTOLIV AirBag CENTRAL AUTODETECT
 Qubo	AIRBAG	1.3 Multijet 75cv (08-..)	TRW SRS EP
 Qubo	AIRBAG	1.4 8v (08-..)	AUTOLIV AirBag CENTRAL AUTODETECT
 Qubo	AIRBAG	1.4 8v (08-..)	TRW SRS EP
 Qubo	AIRBAG	1.4 8v Natural Power (08-..)	AUTOLIV AirBag CENTRAL AUTODETECT
 Qubo	AIRBAG	1.4 8v Natural Power (08-..)	TRW SRS EP
 Qubo	AUTOM. TRANSMISSI	1.3 Multijet 16v 95cv (08-..)	Marelli Selespeed CFC300 (EP)
 Qubo	AUTOM. TRANSMISSI	1.3 Multijet 16v 95cv (08-..)	Marelli Selespeed CFC328 - 2
 Qubo	AUTOM. TRANSMISSI	1.3 Multijet 75cv (08-..)	Marelli Selespeed CFC300 (EP)
 Qubo	AUTOM. TRANSMISSI	1.3 Multijet 75cv (08-..)	Marelli Selespeed CFC328 - 2
 Qubo	AUTOM. TRANSMISSI	1.4 8v (08-..)	Marelli Selespeed CFC300 (EP)
 Qubo	AUTOM. TRANSMISSI	1.4 8v (08-..)	Marelli Selespeed CFC328 - 2
 Qubo	AUTOM. TRANSMISSI	1.4 8v Natural Power (08-..)	Marelli Selespeed CFC300 (EP)
 Qubo	AUTOM. TRANSMISSI	1.4 8v Natural Power (08-..)	Marelli Selespeed CFC328 - 2
 Qubo	CHASSIS NETWORK	1.3 Multijet 16v 95cv (08-..)	Body Computer BSI AUTODETECT
 Qubo	CHASSIS NETWORK	1.3 Multijet 16v 95cv (08-..)	DELPHI Body Computer
 Qubo	CHASSIS NETWORK	1.3 Multijet 16v 95cv (08-..)	DELPHI Body Computer CAN Info
 Qubo	CHASSIS NETWORK	1.3 Multijet 16v 95cv (08-..)	DELPHI Body Computer Proxi Alignement
 Qubo	CHASSIS NETWORK	1.3 Multijet 16v 95cv (08-..)	DELPHI EP
 Qubo	CHASSIS NETWORK	1.3 Multijet 75cv (08-..)	Body Computer BSI AUTODETECT
 Qubo	CHASSIS NETWORK	1.3 Multijet 75cv (08-..)	DELPHI Body Computer
 Qubo	CHASSIS NETWORK	1.3 Multijet 75cv (08-..)	DELPHI Body Computer CAN Info
 Qubo	CHASSIS NETWORK	1.3 Multijet 75cv (08-..)	DELPHI Body Computer Proxi Alignement
 Qubo	CHASSIS NETWORK	1.3 Multijet 75cv (08-..)	DELPHI EP
 Qubo	CHASSIS NETWORK	1.4 8v (08-..)	Body Computer BSI AUTODETECT
 Qubo	CHASSIS NETWORK	1.4 8v (08-..)	DELPHI Body Computer
 Qubo	CHASSIS NETWORK	1.4 8v (08-..)	DELPHI Body Computer CAN Info
 Qubo	CHASSIS NETWORK	1.4 8v (08-..)	DELPHI Body Computer Proxi Alignement
 Qubo	CHASSIS NETWORK	1.4 8v (08-..)	DELPHI EP
 Qubo	CHASSIS NETWORK	1.4 8v Natural Power (08-..)	Body Computer BSI AUTODETECT
 Qubo	CHASSIS NETWORK	1.4 8v Natural Power (08-..)	DELPHI Body Computer
 Qubo	CHASSIS NETWORK	1.4 8v Natural Power (08-..)	DELPHI Body Computer CAN Info
 Qubo	CHASSIS NETWORK	1.4 8v Natural Power (08-..)	DELPHI Body Computer Proxi Alignement
 Qubo	CHASSIS NETWORK	1.4 8v Natural Power (08-..)	DELPHI EP
 Qubo	DASHBOARD	1.3 Multijet 16v 95cv (08-..)	AUTODETECT
 Qubo	DASHBOARD	1.3 Multijet 16v 95cv (08-..)	Marelli Dashboard Comfort
 Qubo	DASHBOARD	1.3 Multijet 16v 95cv (08-..)	Marelli Dashboard Modale
 Qubo	DASHBOARD	1.3 Multijet 75cv (08-..)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Qubo	DASHBOARD	1.3 Multijet 75cv (08-..)	Marelli Dashboard Comfort
 Qubo	DASHBOARD	1.3 Multijet 75cv (08-..)	Marelli Dashboard Modale
 Qubo	DASHBOARD	1.4 8v (08-..)	AUTODETECT
 Qubo	DASHBOARD	1.4 8v (08-..)	Marelli Dashboard Comfort
 Qubo	DASHBOARD	1.4 8v (08-..)	Marelli Dashboard Modale
 Qubo	DASHBOARD	1.4 8v Natural Power (08-..)	AUTODETECT
 Qubo	DASHBOARD	1.4 8v Natural Power (08-..)	Marelli Dashboard Comfort
 Qubo	DASHBOARD	1.4 8v Natural Power (08-..)	Marelli Dashboard Modale
 Qubo	ENGINE MANAGEME	1.3 Multijet 16v 95cv (08-..)	Marelli EDC 8F3 CF5
 Qubo	ENGINE MANAGEME	1.3 Multijet 16v 95cv (09-..)	Marelli EDC 6F3 (D.P.F.)
 Qubo	ENGINE MANAGEME	1.3 Multijet 75cv (08-..)	AUTODETECT
 Qubo	ENGINE MANAGEME	1.3 Multijet 75cv (08-..)	Marelli EDC 8F3 CF5
 Qubo	ENGINE MANAGEME	1.4 8v (08-..)	EOBD
 Qubo	ENGINE MANAGEME	1.4 8v Natural Power (08-..)	EOBD
 Qubo	FAP OIL PARAMETER	1.3 Multijet 75cv (08-..)	Marelli
 Qubo	MAINTENANCE	1.3 Multijet 16v 95cv (08-..)	BOSCH ESP 8
 Qubo	MAINTENANCE	1.3 Multijet 16v 95cv (08-..)	Marelli Dashboard
 Qubo	MAINTENANCE	1.3 Multijet 16v 95cv (08-..)	Marelli Dashboard Comfort
 Qubo	MAINTENANCE	1.3 Multijet 16v 95cv (08-..)	Marelli Dashboard Comfort
 Qubo	MAINTENANCE	1.3 Multijet 16v 95cv (08-..)	Marelli Dashboard Modale
 Qubo	MAINTENANCE	1.3 Multijet 16v 95cv (08-..)	Marelli Dashboard Modale
 Qubo	MAINTENANCE	1.3 Multijet 16v 95cv (08-..)	Marelli EDC 8F3 CF5
 Qubo	MAINTENANCE	1.3 Multijet 16v 95cv (08-..)	Marelli EDC 8F3 CF5
 Qubo	MAINTENANCE	1.3 Multijet 16v 95cv (09-..)	Marelli Dashboard
 Qubo	MAINTENANCE	1.3 Multijet 16v 95cv (09-..)	Marelli EDC 6F3 (D.P.F.)
 Qubo	MAINTENANCE	1.3 Multijet 16v 95cv (09-..)	Marelli EDC 6F3 (D.P.F.)
 Qubo	MAINTENANCE	1.3 Multijet 16v 95cv (09-..)	Marelli EDC 6F3 (D.P.F.)
 Qubo	MAINTENANCE	1.3 Multijet 16v 95cv (09-..)	Marelli EDC 6F3 (D.P.F.)
 Qubo	MAINTENANCE	1.3 Multijet 75cv (08-..)	BOSCH ESP 8
 Qubo	MAINTENANCE	1.3 Multijet 75cv (08-..)	Marelli
 Qubo	MAINTENANCE	1.3 Multijet 75cv (08-..)	Marelli Dashboard
 Qubo	MAINTENANCE	1.3 Multijet 75cv (08-..)	Marelli Dashboard Comfort
 Qubo	MAINTENANCE	1.3 Multijet 75cv (08-..)	Marelli Dashboard Comfort
 Qubo	MAINTENANCE	1.3 Multijet 75cv (08-..)	Marelli Dashboard Modale
 Qubo	MAINTENANCE	1.3 Multijet 75cv (08-..)	Marelli Dashboard Modale
 Qubo	MAINTENANCE	1.3 Multijet 75cv (08-..)	Marelli EDC 8F3 CF5
 Qubo	MAINTENANCE	1.3 Multijet 75cv (08-..)	Marelli EDC 8F3 CF5
 Qubo	MAINTENANCE	1.3 Multijet 75cv (09-..)	Marelli Dashboard
 Qubo	MAINTENANCE	1.4 8v (08-..)	BOSCH ESP 8
 Qubo	MAINTENANCE	1.4 8v (08-..)	Marelli Dashboard
 Qubo	MAINTENANCE	1.4 8v (08-..)	Marelli Dashboard Comfort
 Qubo	MAINTENANCE	1.4 8v (08-..)	Marelli Dashboard Comfort
 Qubo	MAINTENANCE	1.4 8v (08-..)	Marelli Dashboard Comfort
 Qubo	MAINTENANCE	1.4 8v (08-..)	Marelli Dashboard Modale
 Qubo	MAINTENANCE	1.4 8v (08-..)	Marelli Dashboard Modale
 Qubo	MAINTENANCE	1.4 8v (09-..)	Marelli Dashboard
 Qubo	MAINTENANCE	1.4 8v Natural Power (08-..)	BOSCH ESP 8
 Qubo	MAINTENANCE	1.4 8v Natural Power (08-..)	Marelli Dashboard
 Qubo	MAINTENANCE	1.4 8v Natural Power (08-..)	Marelli Dashboard Comfort
 Qubo	MAINTENANCE	1.4 8v Natural Power (08-..)	Marelli Dashboard Comfort
 Qubo	MAINTENANCE	1.4 8v Natural Power (08-..)	Marelli Dashboard Modale
 Qubo	MAINTENANCE	1.4 8v Natural Power (08-..)	Marelli Dashboard Modale
 Qubo	MAINTENANCE	1.4 8v Natural Power (09-..)	Marelli Dashboard
 Qubo	PARKING HELP	1.3 Multijet 16v 95cv (08-..)	AUTODETECT
 Qubo	PARKING HELP	1.3 Multijet 75cv (08-..)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Qubo	PARKING HELP	1.4 8v (08-..)	AUTODETECT
 Qubo	PARKING HELP	1.4 8v Natural Power (08-..)	AUTODETECT
 Qubo	SERVICE LIGHT RES	1.3 Multijet 16v 95cv (08-..)	Marelli Dashboard
 Qubo	SERVICE LIGHT RES	1.3 Multijet 16v 95cv (09-..)	Marelli Dashboard
 Qubo	SERVICE LIGHT RES	1.3 Multijet 75cv (08-..)	Marelli Dashboard
 Qubo	SERVICE LIGHT RES	1.3 Multijet 75cv (09-..)	Marelli Dashboard
 Qubo	SERVICE LIGHT RES	1.4 8v (08-..)	Marelli Dashboard
 Qubo	SERVICE LIGHT RES	1.4 8v (09-..)	Marelli Dashboard
 Qubo	SERVICE LIGHT RES	1.4 8v Natural Power (08-..)	Marelli Dashboard
 Qubo	SERVICE LIGHT RES	1.4 8v Natural Power (09-..)	Marelli Dashboard
 Qubo	VISUAL./TELEMATIC	1.3 Multijet 16v 95cv (08-..)	Marelli Convergence
 Qubo	VISUAL./TELEMATIC	1.3 Multijet 75cv (08-..)	Marelli Convergence
 Qubo	VISUAL./TELEMATIC	1.4 8v (08-..)	Marelli Convergence
 Qubo	VISUAL./TELEMATIC	1.4 8v Natural Power (08-..)	Marelli Convergence
 Regata Restyling	ELECTRONIC INJECT	1.6 Kat	BOSCH MonoJetronic A2.2
 Regata	ELECTRONIC INJECT	1.5 AT Kat	BOSCH MonoJetronic A2.2
 Regata	ELECTRONIC INJECT	1.5 Kat	BOSCH MonoJetronic A2.2
 Ritmo 07	ABS + TRACT. CONT	1.4 16v	BOSCH ABS/VDC 8
 Ritmo 07	ABS + TRACT. CONT	1.9 Multijet 16v	BOSCH ABS/VDC 8
 Ritmo 07	ABS + TRACT. CONT	1.9 Multijet 8v	BOSCH ABS/VDC 8
 Ritmo 07	AIRBAG	1.4 16v	SIEMENS AirBag 1
 Ritmo 07	AIRBAG	1.9 Multijet 16v	SIEMENS AirBag 1
 Ritmo 07	AIRBAG	1.9 Multijet 8v	SIEMENS AirBag 1
 Ritmo 07	CHASSIS NETWORK	1.4 16v	Marelli Body Comp.+Key Encoding 8
 Ritmo 07	CHASSIS NETWORK	1.4 16v	Marelli CAN info
 Ritmo 07	CHASSIS NETWORK	1.9 Multijet 16v	Marelli Body Comp.+Key Encoding 8
 Ritmo 07	CHASSIS NETWORK	1.9 Multijet 16v	Marelli CAN info
 Ritmo 07	CHASSIS NETWORK	1.9 Multijet 8v	Marelli Body Comp.+Key Encoding 8
 Ritmo 07	CHASSIS NETWORK	1.9 Multijet 8v	Marelli CAN info
 Ritmo 07	DASHBOARD	1.4 16v	Marelli
 Ritmo 07	DASHBOARD	1.9 Multijet 16v	Marelli
 Ritmo 07	DASHBOARD	1.9 Multijet 8v	Marelli
 Ritmo 07	ELECTRIC STEERING	1.4 16v	TRW EPS 3
 Ritmo 07	ELECTRIC STEERING	1.9 Multijet 16v	TRW EPS 3
 Ritmo 07	ELECTRIC STEERING	1.9 Multijet 8v	TRW EPS 3
 Ritmo 07	ENGINE MANAGEME	1.4 16v	BOSCH Motronic ME7.3H4M EOBD
 Ritmo 07	ENGINE MANAGEME	1.9 Multijet 16v	BOSCH EDC 16 Common Rail
 Ritmo 07	ENGINE MANAGEME	1.9 Multijet 8v	BOSCH EDC 16 Common Rail
 Ritmo 07	MAINTENANCE	1.4 16v	Marelli
 Ritmo 07	MAINTENANCE	1.9 Multijet 16v	BOSCH EDC 16 Common Rail
 Ritmo 07	MAINTENANCE	1.9 Multijet 16v	BOSCH EDC 16 Common Rail
 Ritmo 07	MAINTENANCE	1.9 Multijet 16v	Marelli
 Ritmo 07	MAINTENANCE	1.9 Multijet 8v	BOSCH EDC 16 Common Rail
 Ritmo 07	MAINTENANCE	1.9 Multijet 8v	BOSCH EDC 16 Common Rail
 Ritmo 07	MAINTENANCE	1.9 Multijet 8v	Marelli
 Ritmo 07	PARKING HELP	1.4 16v	Valeo PDC
 Ritmo 07	PARKING HELP	1.9 Multijet 16v	Valeo PDC
 Ritmo 07	PARKING HELP	1.9 Multijet 8v	Valeo PDC
 Ritmo 07	VISUAL./TELEMATIC	1.4 16v	Marelli Connect 3
 Ritmo 07	VISUAL./TELEMATIC	1.9 Multijet 16v	Marelli Connect 3
 Ritmo 07	VISUAL./TELEMATIC	1.9 Multijet 8v	Marelli Connect 3
 Ritmo	ELECTRONIC INJECT	1.5 AT Kat	BOSCH MonoJetronic A2.2
 Ritmo	ELECTRONIC INJECT	1.5 Kat	BOSCH MonoJetronic A2.2
 Scudo (222)	ABS	1.6 Kat	BOSCH ABS ABR 5.3
 Scudo (222)	ABS	1.9 D (00-..)	BOSCH ABS ABR 5.3
 Scudo (222)	ABS	1.9 TD (97-..)	BOSCH ABS ABR 5.3
 Scudo (222)	ABS	2.0 16v (97-..)	BOSCH ABS ABR 5.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Scudo (222)	ABS	2.0 JTD	BOSCH ABS ABR 5.3
 Scudo (222)	ABS	2.0 JTD 16v (97-..)	BOSCH ABS ABR 5.3
 Scudo (222)	AIRBAG	1.6 Kat (00-..)	AUTOLIV AirBag CENTRAL ACU AUTODE
 Scudo (222)	AIRBAG	1.9 D (00-..)	AUTOLIV AirBag CENTRAL ACU AUTODE
 Scudo (222)	AIRBAG	1.9 TD (00-..)	AUTOLIV AirBag CENTRAL ACU AUTODE
 Scudo (222)	AIRBAG	2.0 16v (00-..)	AUTOLIV AirBag CENTRAL ACU AUTODE
 Scudo (222)	AIRBAG	2.0 JTD (00-..)	AUTOLIV AirBag CENTRAL ACU AUTODE
 Scudo (222)	AIRBAG	2.0 JTD 16v (00-..)	AUTOLIV AirBag CENTRAL ACU AUTODE
 Scudo (222)	AUTOM. TRANSMISSI	1.9 TD DHX (97-..)	A/T AL4 AUTODETECT
 Scudo (222)	DIESEL ADDITION	2.0 JTD FAP	MARVAL
 Scudo (222)	DIESEL MANAGEMEN	1.9 D WJY (00-..)	LUCAS DCN2 AUTODETECT
 Scudo (222)	DIESEL MANAGEMEN	1.9 D WJY (00-..)	LUCAS Diesel DCN2
 Scudo (222)	DIESEL MANAGEMEN	1.9 TD (97-..)	BOSCH AS3 VP20
 Scudo (222)	ENGINE MANAGEME	1.6 Kat	BOSCH MonoMotronic MA1.7
 Scudo (222)	ENGINE MANAGEME	2.0 16v (01-..)	EOBD
 Scudo (222)	ENGINE MANAGEME	2.0 JTD (.-99)	BOSCH EDC 15 C2 Common Rail
 Scudo (222)	ENGINE MANAGEME	2.0 JTD 16v RHW (.-99)	BOSCH EDC15 C2 Common Rail AUTODE
 Scudo (222)	ENGINE MANAGEME	2.0 JTD RHT (.-99)	BOSCH EDC 15 C2 Common Rail
 Scudo (222)	ENGINE MANAGEME	2.0 JTD RHW (.-99)	BOSCH EDC15 C2 Common Rail AUTODE
 Scudo (222)	MAINTENANCE	1.6 Kat	BOSCH ABS ABR 5.3
 Scudo (222)	MAINTENANCE	1.6 Kat	BOSCH ABS ABR 5.3
 Scudo (222)	MAINTENANCE	1.6 Kat	BOSCH ABS ABR 5.3
 Scudo (222)	MAINTENANCE	1.6 Kat	BOSCH ABS ABR 5.3
 Scudo (222)	MAINTENANCE	1.9 D (00-..)	BOSCH ABS ABR 5.3
 Scudo (222)	MAINTENANCE	1.9 D (00-..)	BOSCH ABS ABR 5.3
 Scudo (222)	MAINTENANCE	1.9 D (00-..)	BOSCH ABS ABR 5.3
 Scudo (222)	MAINTENANCE	1.9 D (00-..)	BOSCH ABS ABR 5.3
 Scudo (222)	MAINTENANCE	1.9 D (00-..)	BOSCH ABS ABR 5.3
 Scudo (222)	MAINTENANCE	1.9 TD (97-..)	BOSCH ABS ABR 5.3
 Scudo (222)	MAINTENANCE	1.9 TD (97-..)	BOSCH ABS ABR 5.3
 Scudo (222)	MAINTENANCE	1.9 TD (97-..)	BOSCH ABS ABR 5.3
 Scudo (222)	MAINTENANCE	1.9 TD (97-..)	BOSCH ABS ABR 5.3
 Scudo (222)	MAINTENANCE	1.9 TD DHX (97-..)	A/T AL4 AUTODETECT
 Scudo (222)	MAINTENANCE	2.0 16v (97-..)	BOSCH ABS ABR 5.3
 Scudo (222)	MAINTENANCE	2.0 16v (97-..)	BOSCH ABS ABR 5.3
 Scudo (222)	MAINTENANCE	2.0 16v (97-..)	BOSCH ABS ABR 5.3
 Scudo (222)	MAINTENANCE	2.0 16v (97-..)	BOSCH ABS ABR 5.3
 Scudo (222)	MAINTENANCE	2.0 JTD	BOSCH ABS ABR 5.3
 Scudo (222)	MAINTENANCE	2.0 JTD	BOSCH ABS ABR 5.3
 Scudo (222)	MAINTENANCE	2.0 JTD	BOSCH ABS ABR 5.3
 Scudo (222)	MAINTENANCE	2.0 JTD 16v (97-..)	BOSCH ABS ABR 5.3
 Scudo (222)	MAINTENANCE	2.0 JTD 16v (97-..)	BOSCH ABS ABR 5.3
 Scudo (222)	MAINTENANCE	2.0 JTD 16v (97-..)	BOSCH ABS ABR 5.3
 Scudo (222)	MAINTENANCE	2.0 JTD 16v (97-..)	BOSCH ABS ABR 5.3
 Scudo (222)	MAINTENANCE	2.0 JTD 16v RHW (.-99)	BOSCH EDC15 C2 Common Rail AUTODE
 Scudo (222)	MAINTENANCE	2.0 JTD FAP	MARVAL
 Scudo (222)	MAINTENANCE	2.0 JTD FAP	MARVAL
 Scudo (222)	MAINTENANCE	2.0 JTD RHT (.-99)	BOSCH EDC 15 C2 Common Rail
 Scudo (222)	MAINTENANCE	2.0 JTD RHW (.-99)	BOSCH EDC15 C2 Common Rail AUTODE
 Scudo (272)	ABS	1.6 JTD (07-..)	BOSCH ABS 8
 Scudo (272)	ABS	2.0 16v (07-..)	BOSCH ABS 8
 Scudo (272)	ABS	2.0 JTD (07-..)	BOSCH ABS 8
 Scudo (272)	ABS + TRACT. CONT	1.6 JTD (07-..)	BOSCH ABS 8.0 AUTODETECT
 Scudo (272)	ABS + TRACT. CONT	1.6 JTD (07-..)	BOSCH ABS 8.1 AUTODETECT
 Scudo (272)	ABS + TRACT. CONT	1.6 JTD (07-..)	BOSCH ESP 8.0 AUTODETECT
 Scudo (272)	ABS + TRACT. CONT	1.6 JTD (07-..)	BOSCH ESP 8.1 AUTODETECT
 Scudo (272)	ABS + TRACT. CONT	2.0 16v (07-..)	BOSCH ABS 8.0 AUTODETECT
 Scudo (272)	ABS + TRACT. CONT	2.0 16v (07-..)	BOSCH ABS 8.1 AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Scudo (272)	ABS + TRACT. CONT	2.0 16v (07-..)	BOSCH ESP 8.0 AUTODETECT
 Scudo (272)	ABS + TRACT. CONT	2.0 16v (07-..)	BOSCH ESP 8.1 AUTODETECT
 Scudo (272)	ABS + TRACT. CONT	2.0 JTD (07-..)	BOSCH ABS 8.0 AUTODETECT
 Scudo (272)	ABS + TRACT. CONT	2.0 JTD (07-..)	BOSCH ABS 8.1 AUTODETECT
 Scudo (272)	ABS + TRACT. CONT	2.0 JTD (07-..)	BOSCH ESP 8.0 AUTODETECT
 Scudo (272)	ABS + TRACT. CONT	2.0 JTD (07-..)	BOSCH ESP 8.1 AUTODETECT
 Scudo (272)	ABS + TRACT. CONT	2.0 JTD 16v (07-..)	BOSCH ABS 8.0 AUTODETECT
 Scudo (272)	ABS + TRACT. CONT	2.0 JTD 16v (07-..)	BOSCH ABS 8.1 AUTODETECT
 Scudo (272)	ABS + TRACT. CONT	2.0 JTD 16v (07-..)	BOSCH ESP 8.0 AUTODETECT
 Scudo (272)	ABS + TRACT. CONT	2.0 JTD 16v (07-..)	BOSCH ESP 8.1 AUTODETECT
 Scudo (272)	AIRBAG	1.6 JTD (07-..)	AirBag CENTRAL AUTODETECT
 Scudo (272)	AIRBAG	1.6 JTD (07-..)	Temic SRS
 Scudo (272)	AIRBAG	2.0 16v (07-..)	AirBag CENTRAL AUTODETECT
 Scudo (272)	AIRBAG	2.0 JTD (07-..)	AirBag CENTRAL AUTODETECT
 Scudo (272)	AIRBAG	2.0 JTD (07-..)	Temic SRS
 Scudo (272)	AIRBAG	2.0 JTD 16v (07-..)	AirBag CENTRAL AUTODETECT
 Scudo (272)	ANTITHEFT	1.6 JTD (07-..)	Alarm PSA2 AUTODETECT
 Scudo (272)	ANTITHEFT	2.0 16v (07-..)	Alarm PSA2 AUTODETECT
 Scudo (272)	ANTITHEFT	2.0 JTD (07-..)	Alarm PSA2 AUTODETECT
 Scudo (272)	ANTITHEFT	2.0 JTD 16v (07-..)	Alarm PSA2 AUTODETECT
 Scudo (272)	AUX. HEATING	1.6 JTD (07-..)	AUTODETECT
 Scudo (272)	AUX. HEATING	2.0 16v (07-..)	AUTODETECT
 Scudo (272)	AUX. HEATING	2.0 JTD (07-..)	AUTODETECT
 Scudo (272)	AUX. HEATING	2.0 JTD 16v (07-..)	AUTODETECT
 Scudo (272)	CHASSIS NETWORK	1.6 JTD (07-..)	Body Computer BSI AUTODETECT
 Scudo (272)	CHASSIS NETWORK	1.6 JTD (07-..)	Body Computer BSM AUTODETECT
 Scudo (272)	CHASSIS NETWORK	1.6 JTD (07-..)	Body Computer BSR AUTODETECT
 Scudo (272)	CHASSIS NETWORK	1.6 JTD (07-..)	Body Computer Chassis AUTODETECT
 Scudo (272)	CHASSIS NETWORK	1.6 JTD (07-..)	Valeo 2 1/2
 Scudo (272)	CHASSIS NETWORK	1.6 JTD (07-..)	Valeo 2 2/2
 Scudo (272)	CHASSIS NETWORK	2.0 16v (07-..)	Body Computer BSI AUTODETECT
 Scudo (272)	CHASSIS NETWORK	2.0 16v (07-..)	Body Computer BSM AUTODETECT
 Scudo (272)	CHASSIS NETWORK	2.0 16v (07-..)	Body Computer BSR AUTODETECT
 Scudo (272)	CHASSIS NETWORK	2.0 16v (07-..)	Body Computer Chassis AUTODETECT
 Scudo (272)	CHASSIS NETWORK	2.0 JTD (07-..)	Body Computer BSI AUTODETECT
 Scudo (272)	CHASSIS NETWORK	2.0 JTD (07-..)	Body Computer BSM AUTODETECT
 Scudo (272)	CHASSIS NETWORK	2.0 JTD (07-..)	Body Computer BSR AUTODETECT
 Scudo (272)	CHASSIS NETWORK	2.0 JTD (07-..)	Body Computer Chassis AUTODETECT
 Scudo (272)	CHASSIS NETWORK	2.0 JTD (07-..)	Valeo 2 1/2
 Scudo (272)	CHASSIS NETWORK	2.0 JTD (07-..)	Valeo 2 2/2
 Scudo (272)	CHASSIS NETWORK	2.0 JTD 16v (07-..)	Body Computer BSI AUTODETECT
 Scudo (272)	CHASSIS NETWORK	2.0 JTD 16v (07-..)	Body Computer BSM AUTODETECT
 Scudo (272)	CHASSIS NETWORK	2.0 JTD 16v (07-..)	Body Computer BSR AUTODETECT
 Scudo (272)	CHASSIS NETWORK	2.0 JTD 16v (07-..)	Body Computer Chassis AUTODETECT
 Scudo (272)	CLIMA	1.6 JTD (07-..)	CLIMA AUTODETECT
 Scudo (272)	CLIMA	2.0 16v (07-..)	CLIMA AUTODETECT
 Scudo (272)	CLIMA	2.0 JTD (07-..)	CLIMA AUTODETECT
 Scudo (272)	CLIMA	2.0 JTD 16v (07-..)	CLIMA AUTODETECT
 Scudo (272)	DASHBOARD	1.6 JTD (07-..)	AUTODETECT
 Scudo (272)	DASHBOARD	1.6 JTD (07-..)	Marelli Dashboard PSA
 Scudo (272)	DASHBOARD	2.0 16v (07-..)	AUTODETECT
 Scudo (272)	DASHBOARD	2.0 JTD (07-..)	AUTODETECT
 Scudo (272)	DASHBOARD	2.0 JTD (07-..)	Marelli Dashboard PSA
 Scudo (272)	DASHBOARD	2.0 JTD 16v (07-..)	AUTODETECT
 Scudo (272)	ELECTRIC STEERING	1.6 JTD (07-..)	AUTODETECT
 Scudo (272)	ELECTRIC STEERING	2.0 16v (07-..)	AUTODETECT
 Scudo (272)	ELECTRIC STEERING	2.0 JTD (07-..)	AUTODETECT
 Scudo (272)	ELECTRIC STEERING	2.0 JTD 16v (07-..)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Scudo (272)	ENGINE MANAGEME	1.6 JTD (07-..)	BOSCH EDC16 C34 Common Rail AUTOD
 Scudo (272)	ENGINE MANAGEME	1.6 JTD 9HU (07-..)	BOSCH EDC 16 34 Common Rail
 Scudo (272)	ENGINE MANAGEME	2.0 16v (07-..)	Marelli MM6KP AUTODETECT
 Scudo (272)	ENGINE MANAGEME	2.0 JTD (07-..)	EOBD
 Scudo (272)	ENGINE MANAGEME	2.0 JTD 16v (07-..)	SIEMENS SID 803A Common Rail AUTOD
 Scudo (272)	MAINTENANCE	1.6 JTD (07-..)	AirBag CENTRAL AUTODETECT
 Scudo (272)	MAINTENANCE	1.6 JTD (07-..)	AirBag CENTRAL AUTODETECT
 Scudo (272)	MAINTENANCE	1.6 JTD (07-..)	BOSCH ABS 8.0 AUTODETECT
 Scudo (272)	MAINTENANCE	1.6 JTD (07-..)	BOSCH ABS 8.0 AUTODETECT
 Scudo (272)	MAINTENANCE	1.6 JTD (07-..)	BOSCH EDC16 C34 Common Rail AUTOD
 Scudo (272)	MAINTENANCE	1.6 JTD (07-..)	BOSCH EDC16 C34 Common Rail AUTOD
 Scudo (272)	MAINTENANCE	1.6 JTD (07-..)	BOSCH EDC16 C34 Common Rail AUTOD
 Scudo (272)	MAINTENANCE	1.6 JTD (07-..)	BOSCH EDC16 C34 Common Rail AUTOD
 Scudo (272)	MAINTENANCE	1.6 JTD (07-..)	BOSCH EDC16 C34 Common Rail AUTOD
 Scudo (272)	MAINTENANCE	1.6 JTD (07-..)	BOSCH ESP 8.0 AUTODETECT
 Scudo (272)	MAINTENANCE	1.6 JTD (07-..)	BOSCH ESP 8.0 AUTODETECT
 Scudo (272)	MAINTENANCE	1.6 JTD (07-..)	BOSCH ESP 8.1 AUTODETECT
 Scudo (272)	MAINTENANCE	1.6 JTD (07-..)	BOSCH ESP 8.1 AUTODETECT
 Scudo (272)	MAINTENANCE	1.6 JTD (07-..)	MANUAL
 Scudo (272)	MAINTENANCE	1.6 JTD (07-..)	Marelli Dashboard PSA
 Scudo (272)	MAINTENANCE	1.6 JTD (07-..)	Valeo 2 1/2
 Scudo (272)	MAINTENANCE	1.6 JTD (07-..)	Valeo 2 1/2
 Scudo (272)	MAINTENANCE	2.0 16v (07-..)	AirBag CENTRAL AUTODETECT
 Scudo (272)	MAINTENANCE	2.0 16v (07-..)	AirBag CENTRAL AUTODETECT
 Scudo (272)	MAINTENANCE	2.0 16v (07-..)	BOSCH ABS 8.0 AUTODETECT
 Scudo (272)	MAINTENANCE	2.0 16v (07-..)	BOSCH ABS 8.0 AUTODETECT
 Scudo (272)	MAINTENANCE	2.0 16v (07-..)	BOSCH ESP 8.0 AUTODETECT
 Scudo (272)	MAINTENANCE	2.0 16v (07-..)	BOSCH ESP 8.0 AUTODETECT
 Scudo (272)	MAINTENANCE	2.0 16v (07-..)	BOSCH ESP 8.1 AUTODETECT
 Scudo (272)	MAINTENANCE	2.0 16v (07-..)	BOSCH ESP 8.1 AUTODETECT
 Scudo (272)	MAINTENANCE	2.0 16v (07-..)	BOSCH ESP 8.1 AUTODETECT
 Scudo (272)	MAINTENANCE	2.0 JTD (07-..)	AirBag CENTRAL AUTODETECT
 Scudo (272)	MAINTENANCE	2.0 JTD (07-..)	AirBag CENTRAL AUTODETECT
 Scudo (272)	MAINTENANCE	2.0 JTD (07-..)	BOSCH ABS 8.0 AUTODETECT
 Scudo (272)	MAINTENANCE	2.0 JTD (07-..)	BOSCH ABS 8.0 AUTODETECT
 Scudo (272)	MAINTENANCE	2.0 JTD (07-..)	BOSCH ESP 8.0 AUTODETECT
 Scudo (272)	MAINTENANCE	2.0 JTD (07-..)	BOSCH ESP 8.0 AUTODETECT
 Scudo (272)	MAINTENANCE	2.0 JTD (07-..)	BOSCH ESP 8.1 AUTODETECT
 Scudo (272)	MAINTENANCE	2.0 JTD (07-..)	BOSCH ESP 8.1 AUTODETECT
 Scudo (272)	MAINTENANCE	2.0 JTD (07-..)	MANUAL
 Scudo (272)	MAINTENANCE	2.0 JTD (07-..)	Marelli Dashboard PSA
 Scudo (272)	MAINTENANCE	2.0 JTD (07-..)	Valeo 2 1/2
 Scudo (272)	MAINTENANCE	2.0 JTD (07-..)	Valeo 2 1/2
 Scudo (272)	MAINTENANCE	2.0 JTD 16v (07-..)	AirBag CENTRAL AUTODETECT
 Scudo (272)	MAINTENANCE	2.0 JTD 16v (07-..)	AirBag CENTRAL AUTODETECT
 Scudo (272)	MAINTENANCE	2.0 JTD 16v (07-..)	BOSCH ABS 8.0 AUTODETECT
 Scudo (272)	MAINTENANCE	2.0 JTD 16v (07-..)	BOSCH ABS 8.0 AUTODETECT
 Scudo (272)	MAINTENANCE	2.0 JTD 16v (07-..)	BOSCH ESP 8.0 AUTODETECT
 Scudo (272)	MAINTENANCE	2.0 JTD 16v (07-..)	BOSCH ESP 8.0 AUTODETECT
 Scudo (272)	MAINTENANCE	2.0 JTD 16v (07-..)	BOSCH ESP 8.1 AUTODETECT
 Scudo (272)	MAINTENANCE	2.0 JTD 16v (07-..)	BOSCH ESP 8.1 AUTODETECT
 Scudo (272)	MAINTENANCE	2.0 JTD 16v (07-..)	SIEMENS SID 803A Common Rail AUTOD
 Scudo (272)	MAINTENANCE	2.0 JTD 16v (07-..)	SIEMENS SID 803A Common Rail AUTOD
 Scudo (272)	MAINTENANCE	2.0 JTD 16v (07-..)	SIEMENS SID 803A Common Rail AUTOD
 Scudo (272)	NAVIGATION	1.6 JTD (07-..)	AUTODETECT
 Scudo (272)	NAVIGATION	1.6 JTD (07-..)	AUTODETECT
 Scudo (272)	NAVIGATION	2.0 16v (07-..)	AUTODETECT
 Scudo (272)	NAVIGATION	2.0 16v (07-..)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Scudo (272)	NAVIGATION	2.0 JTD (07-..)	AUTODETECT
 Scudo (272)	NAVIGATION	2.0 JTD (07-..)	AUTODETECT
 Scudo (272)	NAVIGATION	2.0 JTD 16v (07-..)	AUTODETECT
 Scudo (272)	NAVIGATION	2.0 JTD 16v (07-..)	AUTODETECT
 Scudo (272)	PARKING HELP	1.6 JTD (07-..)	AUTODETECT
 Scudo (272)	PARKING HELP	2.0 16v (07-..)	AUTODETECT
 Scudo (272)	PARKING HELP	2.0 JTD (07-..)	AUTODETECT
 Scudo (272)	PARKING HELP	2.0 JTD 16v (07-..)	AUTODETECT
 Scudo (272)	PHONE	1.6 JTD (07-..)	AUTODETECT
 Scudo (272)	PHONE	2.0 16v (07-..)	AUTODETECT
 Scudo (272)	PHONE	2.0 JTD (07-..)	AUTODETECT
 Scudo (272)	PHONE	2.0 JTD 16v (07-..)	AUTODETECT
 Scudo (272)	RADIO / CD	1.6 JTD (07-..)	AudioSystem AUTODETECT
 Scudo (272)	RADIO / CD	1.6 JTD (07-..)	Blaupunkt AudioSystem
 Scudo (272)	RADIO / CD	1.6 JTD (07-..)	CD Changer AUTODETECT
 Scudo (272)	RADIO / CD	2.0 16v (07-..)	AudioSystem AUTODETECT
 Scudo (272)	RADIO / CD	2.0 16v (07-..)	CD Changer AUTODETECT
 Scudo (272)	RADIO / CD	2.0 JTD (07-..)	AudioSystem AUTODETECT
 Scudo (272)	RADIO / CD	2.0 JTD (07-..)	Blaupunkt AudioSystem
 Scudo (272)	RADIO / CD	2.0 JTD (07-..)	CD Changer AUTODETECT
 Scudo (272)	RADIO / CD	2.0 JTD 16v (07-..)	AudioSystem AUTODETECT
 Scudo (272)	RADIO / CD	2.0 JTD 16v (07-..)	CD Changer AUTODETECT
 Scudo (272)	RAIN-LUMINOSITY S	1.6 JTD (07-..)	AUTODETECT
 Scudo (272)	RAIN-LUMINOSITY S	2.0 16v (07-..)	AUTODETECT
 Scudo (272)	RAIN-LUMINOSITY S	2.0 JTD (07-..)	AUTODETECT
 Scudo (272)	RAIN-LUMINOSITY S	2.0 JTD 16v (07-..)	AUTODETECT
 Scudo (272)	REAR CLIMA	1.6 JTD (07-..)	AUTODETECT
 Scudo (272)	REAR CLIMA	2.0 16v (07-..)	AUTODETECT
 Scudo (272)	REAR CLIMA	2.0 JTD (07-..)	AUTODETECT
 Scudo (272)	REAR CLIMA	2.0 JTD 16v (07-..)	AUTODETECT
 Scudo (272)	SERVICE LIGHT RES	1.6 JTD (07-..)	MANUAL
 Scudo (272)	SERVICE LIGHT RES	2.0 JTD (07-..)	MANUAL
 Scudo (272)	STEERING COLUMN	1.6 JTD (07-..)	AUTODETECT
 Scudo (272)	STEERING COLUMN	2.0 16v (07-..)	AUTODETECT
 Scudo (272)	STEERING COLUMN	2.0 JTD (07-..)	AUTODETECT
 Scudo (272)	STEERING COLUMN	2.0 JTD 16v (07-..)	AUTODETECT
 Scudo (272)	SUSPENSION CONTR	1.6 JTD (07-..)	AUTODETECT
 Scudo (272)	SUSPENSION CONTR	2.0 16v (07-..)	AUTODETECT
 Scudo (272)	SUSPENSION CONTR	2.0 JTD (07-..)	AUTODETECT
 Scudo (272)	SUSPENSION CONTR	2.0 JTD 16v (07-..)	AUTODETECT
 Scudo (272)	SWITCHLIGHT MODU	1.6 JTD (07-..)	DELPHI
 Scudo (272)	SWITCHLIGHT MODU	2.0 JTD (07-..)	DELPHI
 Scudo (272)	VISUAL./TELEMATIC	1.6 JTD (07-..)	Display A+ AUTODETECT
 Scudo (272)	VISUAL./TELEMATIC	1.6 JTD (07-..)	Display C- AUTODETECT
 Scudo (272)	VISUAL./TELEMATIC	2.0 16v (07-..)	Display A+ AUTODETECT
 Scudo (272)	VISUAL./TELEMATIC	2.0 16v (07-..)	Display C- AUTODETECT
 Scudo (272)	VISUAL./TELEMATIC	2.0 JTD (07-..)	Display A+ AUTODETECT
 Scudo (272)	VISUAL./TELEMATIC	2.0 JTD (07-..)	Display C- AUTODETECT
 Scudo (272)	VISUAL./TELEMATIC	2.0 JTD 16v (07-..)	Display A+ AUTODETECT
 Scudo (272)	VISUAL./TELEMATIC	2.0 JTD 16v (07-..)	Display C- AUTODETECT
 Sedici	4WD ELECTRONICS	1.6 16v (06-..)	TC
 Sedici	4WD ELECTRONICS	1.9 JTD Multijet 8v (06-..)	TC
 Sedici	ABS	1.6 16v (06-..)	ABS
 Sedici	ABS	1.9 JTD Multijet 8v (06-..)	ABS
 Sedici	AIRBAG	1.6 16v (06-..)	SRS No Side AirBag
 Sedici	AIRBAG	1.6 16v (06-..)	SRS Side AirBag
 Sedici	AIRBAG	1.6 16v (06-..)	SRS Side AirBag-Side curtain AirBag
 Sedici	AIRBAG	1.9 JTD Multijet 8v (06-..)	SRS No Side AirBag

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sedici	AIRBAG	1.9 JTD Multijet 8v (06-..)	SRS Side AirBag
 Sedici	AIRBAG	1.9 JTD Multijet 8v (06-..)	SRS Side AirBag-Side curtain AirBag
 Sedici	CHASSIS NETWORK	1.6 16v (06-..)	Body Computer BCM
 Sedici	CHASSIS NETWORK	1.9 JTD Multijet 8v (06-..)	Body Computer BCM
 Sedici	ELECTRIC STEERING	1.6 16v (06-..)	EPS TSM
 Sedici	ELECTRIC STEERING	1.9 JTD Multijet 8v (06-..)	EPS TSM
 Sedici	ENGINE MANAGEME	1.6 16v (06-..)	DENSO MPI SZK
 Sedici	ENGINE MANAGEME	1.9 JTD Multijet 8v (06-..)	BOSCH EDC 16 Common Rail M-Jet
 Sedici	IMMOBILIZER	1.6 16v (06-..)	CODE
 Sedici	IMMOBILIZER	1.9 JTD Multijet 8v (06-..)	CODE
 Sedici	MAINTENANCE	1.6 16v (06-..)	NKS Remote MANUAL
 Sedici	MAINTENANCE	1.9 JTD Multijet 8v (06-..)	BOSCH EDC 16 Common Rail M-Jet
 Sedici	MAINTENANCE	1.9 JTD Multijet 8v (06-..)	BOSCH EDC 16 Common Rail M-Jet
 Sedici	MAINTENANCE	1.9 JTD Multijet 8v (06-..)	NKS Remote MANUAL
 Sedici	REMOTE CONTROL E	1.6 16v (06-..)	NKS Remote MANUAL
 Sedici	REMOTE CONTROL E	1.9 JTD Multijet 8v (06-..)	NKS Remote MANUAL
 Sedici	VISUAL./TELEMATIC	1.6 16v (06-..)	Marelli Connect 3
 Sedici	VISUAL./TELEMATIC	1.9 JTD Multijet 8v (06-..)	Marelli Connect 3
 Seicento	ABS	1.1	BOSCH ABS 5.3
 Seicento	ABS	1.1 CF3	BOSCH ABS 5.3
 Seicento	ABS	900	BOSCH ABS 5.3
 Seicento	ABS	Citymatic	BOSCH ABS 5.3
 Seicento	ABS	Elettra	BOSCH ABS 5.3
 Seicento	AIRBAG	1.1	TRW AirBag MY 97 (2F-I)
 Seicento	AIRBAG	1.1 CF3	TRW AirBag MY 97 (2F-I)
 Seicento	AIRBAG	900	TRW AirBag MY 97 (2F-I)
 Seicento	AIRBAG	Citymatic	TRW AirBag MY 97 (2F-I)
 Seicento	AIRBAG	Elettra	TRW AirBag MY 97 (2F-I)
 Seicento	ELECTRIC STEERING	1.1	NSK EPS
 Seicento	ELECTRIC STEERING	1.1 CF3	NSK EPS
 Seicento	ELECTRIC STEERING	900	NSK EPS
 Seicento	ELECTRIC STEERING	Citymatic	NSK EPS
 Seicento	ELECTRIC STEERING	Elettra	NSK EPS
 Seicento	ENGINE MANAGEME	1.1	Marelli IAW 4EF
 Seicento	ENGINE MANAGEME	1.1	Marelli IAW 59F
 Seicento	ENGINE MANAGEME	1.1 CF3	Marelli IAW 49F/59F EOBD
 Seicento	ENGINE MANAGEME	1.1 CF3	Marelli IAW 5AF
 Seicento	ENGINE MANAGEME	900	Marelli IAW 16FM.EC
 Seicento	ENGINE MANAGEME	900	Marelli IAW 16FM.EC
 Seicento	IMMOBILIZER	1.1	DELPHI CODE 2
 Seicento	IMMOBILIZER	1.1 CF3	DELPHI CODE 2
 Seicento	IMMOBILIZER	900	DELPHI CODE 2
 Seicento	IMMOBILIZER	Citymatic	DELPHI CODE 2
 Seicento	IMMOBILIZER	Elettra	DELPHI CODE 2
 Seicento	MAINTENANCE	1.1 CF3	Marelli IAW 5AF
 Siena	ENGINE MANAGEME	1.6 16v	Marelli IAW 1AF.13
 Stilo	ABS	1.2 16v (.-03)	BOSCH ABS 8
 Stilo	ABS	1.4 16v (.-03)	BOSCH ABS 8
 Stilo	ABS	1.6 16v (.-03)	BOSCH ABS 8
 Stilo	ABS	1.8 16v (.-03)	BOSCH ABS 8
 Stilo	ABS	1.9 JTD 16v (.-03)	BOSCH ABS 8
 Stilo	ABS	1.9 JTD 8v (.-03)	BOSCH ABS 8
 Stilo	ABS	1.9 JTD Multijet 16v (.-03)	BOSCH ABS 8
 Stilo	ABS	1.9 JTD Multijet 8v (.-03)	BOSCH ABS 8
 Stilo	ABS	2.4 20v (.-03)	BOSCH ABS 8
 Stilo	ABS	2.4 20v Selespeed (.-03)	BOSCH ABS 8
 Stilo	ABS	80 1.9 JTD (.-03)	BOSCH ABS 8
 Stilo	ABS + TRACT. CONT	1.2 16v	BOSCH ABS/VDC 5.7

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Stilo	ABS + TRACT. CONT	1.4 16v	BOSCH ABS/VDC 5.7
 Stilo	ABS + TRACT. CONT	1.6 16v	BOSCH ABS/VDC 5.7
 Stilo	ABS + TRACT. CONT	1.8 16v	BOSCH ABS/VDC 5.7
 Stilo	ABS + TRACT. CONT	1.9 JTD 16v	BOSCH ABS/VDC 5.7
 Stilo	ABS + TRACT. CONT	1.9 JTD 8v	BOSCH ABS/VDC 5.7
 Stilo	ABS + TRACT. CONT	1.9 JTD Multijet 16v	BOSCH ABS/VDC 5.7
 Stilo	ABS + TRACT. CONT	1.9 JTD Multijet 8v	BOSCH ABS/VDC 5.7
 Stilo	ABS + TRACT. CONT	2.4 20v	BOSCH ABS/VDC 5.7
 Stilo	ABS + TRACT. CONT	2.4 20v Selespeed	BOSCH ABS/VDC 5.7
 Stilo	ABS + TRACT. CONT	80 1.9 JTD	BOSCH ABS/VDC 5.7
 Stilo	AIRBAG	1.2 16v	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Stilo	AIRBAG	1.2 16v	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Stilo	AIRBAG	1.2 16v	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Stilo	AIRBAG	1.4 16v	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Stilo	AIRBAG	1.4 16v	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Stilo	AIRBAG	1.4 16v	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Stilo	AIRBAG	1.6 16v	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Stilo	AIRBAG	1.6 16v	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Stilo	AIRBAG	1.6 16v	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Stilo	AIRBAG	1.8 16v	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Stilo	AIRBAG	1.8 16v	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Stilo	AIRBAG	1.8 16v	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Stilo	AIRBAG	1.9 JTD 16v	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Stilo	AIRBAG	1.9 JTD 16v	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Stilo	AIRBAG	1.9 JTD 16v	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Stilo	AIRBAG	1.9 JTD 8v	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Stilo	AIRBAG	1.9 JTD 8v	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Stilo	AIRBAG	1.9 JTD 8v	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Stilo	AIRBAG	1.9 JTD Multijet 16v	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Stilo	AIRBAG	1.9 JTD Multijet 16v	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Stilo	AIRBAG	1.9 JTD Multijet 16v	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Stilo	AIRBAG	1.9 JTD Multijet 8v	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Stilo	AIRBAG	1.9 JTD Multijet 8v	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Stilo	AIRBAG	1.9 JTD Multijet 8v	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Stilo	AIRBAG	2.4 20v	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Stilo	AIRBAG	2.4 20v	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Stilo	AIRBAG	2.4 20v Selespeed	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Stilo	AIRBAG	2.4 20v Selespeed	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Stilo	AIRBAG	2.4 20v Selespeed	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Stilo	AIRBAG	80 1.9 JTD	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Stilo	AIRBAG	80 1.9 JTD	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Stilo	AIRBAG	80 1.9 JTD	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Stilo	CENTRAL ELECTRIC	1.2 16v	BITRON TRUNK
 Stilo	CENTRAL ELECTRIC	1.4 16v	BITRON TRUNK
 Stilo	CENTRAL ELECTRIC	1.6 16v	BITRON TRUNK
 Stilo	CENTRAL ELECTRIC	1.8 16v	BITRON TRUNK
 Stilo	CENTRAL ELECTRIC	1.9 JTD 16v	BITRON TRUNK
 Stilo	CENTRAL ELECTRIC	1.9 JTD 8v	BITRON TRUNK
 Stilo	CENTRAL ELECTRIC	1.9 JTD Multijet 16v	BITRON TRUNK
 Stilo	CENTRAL ELECTRIC	1.9 JTD Multijet 8v	BITRON TRUNK
 Stilo	CENTRAL ELECTRIC	2.4 20v	BITRON TRUNK
 Stilo	CENTRAL ELECTRIC	2.4 20v Selespeed	BITRON TRUNK
 Stilo	CENTRAL ELECTRIC	80 1.9 JTD	BITRON TRUNK
 Stilo	CHASSIS NETWORK	1.2 16v	DELPHI/Marelli Body Computer
 Stilo	CHASSIS NETWORK	1.2 16v	Fiat CAN Info
 Stilo	CHASSIS NETWORK	1.2 16v	Fiat Proxi Alignment
 Stilo	CHASSIS NETWORK	1.2 16v	FIAT TRUNK COMPARTMENT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Stilo	CHASSIS NETWORK	1.4 16v	DELPHI/Marelli Body Computer
 Stilo	CHASSIS NETWORK	1.4 16v	Fiat CAN Info
 Stilo	CHASSIS NETWORK	1.4 16v	Fiat Proxi Alignement
 Stilo	CHASSIS NETWORK	1.4 16v	FIAT TRUNK COMPARTMENT
 Stilo	CHASSIS NETWORK	1.6 16v	DELPHI/Marelli Body Computer
 Stilo	CHASSIS NETWORK	1.6 16v	Fiat CAN Info
 Stilo	CHASSIS NETWORK	1.6 16v	Fiat Proxi Alignement
 Stilo	CHASSIS NETWORK	1.6 16v	FIAT TRUNK COMPARTMENT
 Stilo	CHASSIS NETWORK	1.8 16v	DELPHI/Marelli Body Computer
 Stilo	CHASSIS NETWORK	1.8 16v	Fiat CAN Info
 Stilo	CHASSIS NETWORK	1.8 16v	Fiat Proxi Alignement
 Stilo	CHASSIS NETWORK	1.8 16v	FIAT TRUNK COMPARTMENT
 Stilo	CHASSIS NETWORK	1.9 JTD 16v	DELPHI/Marelli Body Computer
 Stilo	CHASSIS NETWORK	1.9 JTD 16v	Fiat CAN Info
 Stilo	CHASSIS NETWORK	1.9 JTD 16v	Fiat Proxi Alignement
 Stilo	CHASSIS NETWORK	1.9 JTD 16v	FIAT TRUNK COMPARTMENT
 Stilo	CHASSIS NETWORK	1.9 JTD 8v	DELPHI/Marelli Body Computer
 Stilo	CHASSIS NETWORK	1.9 JTD 8v	Fiat CAN Info
 Stilo	CHASSIS NETWORK	1.9 JTD 8v	Fiat Proxi Alignement
 Stilo	CHASSIS NETWORK	1.9 JTD 8v	FIAT TRUNK COMPARTMENT
 Stilo	CHASSIS NETWORK	1.9 JTD Multijet 16v	DELPHI/Marelli Body Computer
 Stilo	CHASSIS NETWORK	1.9 JTD Multijet 16v	Fiat CAN Info
 Stilo	CHASSIS NETWORK	1.9 JTD Multijet 16v	Fiat Proxi Alignement
 Stilo	CHASSIS NETWORK	1.9 JTD Multijet 16v	FIAT TRUNK COMPARTMENT
 Stilo	CHASSIS NETWORK	1.9 JTD Multijet 8v	DELPHI/Marelli Body Computer
 Stilo	CHASSIS NETWORK	1.9 JTD Multijet 8v	Fiat CAN Info
 Stilo	CHASSIS NETWORK	1.9 JTD Multijet 8v	Fiat Proxi Alignement
 Stilo	CHASSIS NETWORK	1.9 JTD Multijet 8v	FIAT TRUNK COMPARTMENT
 Stilo	CHASSIS NETWORK	2.4 20v	DELPHI/Marelli Body Computer
 Stilo	CHASSIS NETWORK	2.4 20v	Fiat CAN Info
 Stilo	CHASSIS NETWORK	2.4 20v	Fiat Proxi Alignement
 Stilo	CHASSIS NETWORK	2.4 20v	FIAT TRUNK COMPARTMENT
 Stilo	CHASSIS NETWORK	2.4 20v Selespeed	DELPHI/Marelli Body Computer
 Stilo	CHASSIS NETWORK	2.4 20v Selespeed	Fiat CAN Info
 Stilo	CHASSIS NETWORK	2.4 20v Selespeed	Fiat Proxi Alignement
 Stilo	CHASSIS NETWORK	2.4 20v Selespeed	FIAT TRUNK COMPARTMENT
 Stilo	CHASSIS NETWORK	80 1.9 JTD	DELPHI/Marelli Body Computer
 Stilo	CHASSIS NETWORK	80 1.9 JTD	Fiat CAN Info
 Stilo	CHASSIS NETWORK	80 1.9 JTD	Fiat Proxi Alignement
 Stilo	CHASSIS NETWORK	80 1.9 JTD	FIAT TRUNK COMPARTMENT
 Stilo	CLIMA	1.2 16v	Marelli Klima
 Stilo	CLIMA	1.4 16v	Marelli Klima
 Stilo	CLIMA	1.6 16v	Marelli Klima
 Stilo	CLIMA	1.8 16v	Marelli Klima
 Stilo	CLIMA	1.9 JTD 16v	Marelli Klima
 Stilo	CLIMA	1.9 JTD 8v	Marelli Klima
 Stilo	CLIMA	1.9 JTD Multijet 16v	Marelli Klima
 Stilo	CLIMA	2.4 20v	Marelli Klima
 Stilo	CLIMA	80 1.9 JTD	Marelli Klima
 Stilo	DASHBOARD	1.2 16v	VISTEON Dashboard
 Stilo	DASHBOARD	1.4 16v	VISTEON Dashboard
 Stilo	DASHBOARD	1.6 16v	VISTEON Dashboard
 Stilo	DASHBOARD	1.8 16v	VISTEON Dashboard
 Stilo	DASHBOARD	1.9 JTD 16v	VISTEON Dashboard
 Stilo	DASHBOARD	1.9 JTD 8v	VISTEON Dashboard
 Stilo	DASHBOARD	1.9 JTD Multijet 16v	VISTEON Dashboard
 Stilo	DASHBOARD	2.4 20v	VISTEON Dashboard
 Stilo	DASHBOARD	2.4 20v Selespeed	VISTEON Dashboard

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Stilo	DASHBOARD	80 1.9 JTD	VISTEON Dashboard
 Stilo	DRIVER SIDE DOOR	1.2 16v	BITRON DRIVER DOOR
 Stilo	DRIVER SIDE DOOR	1.2 16v	PROCOND DRIVER DOOR
 Stilo	DRIVER SIDE DOOR	1.4 16v	BITRON DRIVER DOOR
 Stilo	DRIVER SIDE DOOR	1.4 16v	PROCOND DRIVER DOOR
 Stilo	DRIVER SIDE DOOR	1.6 16v	BITRON DRIVER DOOR
 Stilo	DRIVER SIDE DOOR	1.6 16v	PROCOND DRIVER DOOR
 Stilo	DRIVER SIDE DOOR	1.8 16v	BITRON DRIVER DOOR
 Stilo	DRIVER SIDE DOOR	1.8 16v	PROCOND DRIVER DOOR
 Stilo	DRIVER SIDE DOOR	1.9 JTD 16v	BITRON DRIVER DOOR
 Stilo	DRIVER SIDE DOOR	1.9 JTD 16v	PROCOND DRIVER DOOR
 Stilo	DRIVER SIDE DOOR	1.9 JTD 8v	BITRON DRIVER DOOR
 Stilo	DRIVER SIDE DOOR	1.9 JTD 8v	PROCOND DRIVER DOOR
 Stilo	DRIVER SIDE DOOR	1.9 JTD Multijet 16v	BITRON DRIVER DOOR
 Stilo	DRIVER SIDE DOOR	1.9 JTD Multijet 16v	PROCOND DRIVER DOOR
 Stilo	DRIVER SIDE DOOR	1.9 JTD Multijet 8v	BITRON DRIVER DOOR
 Stilo	DRIVER SIDE DOOR	1.9 JTD Multijet 8v	PROCOND DRIVER DOOR
 Stilo	DRIVER SIDE DOOR	2.4 20v	BITRON DRIVER DOOR
 Stilo	DRIVER SIDE DOOR	2.4 20v	PROCOND DRIVER DOOR
 Stilo	DRIVER SIDE DOOR	2.4 20v Selespeed	BITRON DRIVER DOOR
 Stilo	DRIVER SIDE DOOR	2.4 20v Selespeed	PROCOND DRIVER DOOR
 Stilo	DRIVER SIDE DOOR	80 1.9 JTD	BITRON DRIVER DOOR
 Stilo	DRIVER SIDE DOOR	80 1.9 JTD	PROCOND DRIVER DOOR
 Stilo	ELECTRIC STEERING	1.2 16v	TRW EPS
 Stilo	ELECTRIC STEERING	1.4 16v	TRW EPS
 Stilo	ELECTRIC STEERING	1.6 16v	TRW EPS
 Stilo	ELECTRIC STEERING	1.8 16v	TRW EPS
 Stilo	ELECTRIC STEERING	1.9 JTD 16v	TRW EPS
 Stilo	ELECTRIC STEERING	1.9 JTD 8v	TRW EPS
 Stilo	ELECTRIC STEERING	1.9 JTD Multijet 16v	TRW EPS
 Stilo	ELECTRIC STEERING	1.9 JTD Multijet 8v	TRW EPS
 Stilo	ELECTRIC STEERING	2.4 20v	TRW EPS
 Stilo	ELECTRIC STEERING	2.4 20v Selespeed	TRW EPS
 Stilo	ELECTRIC STEERING	80 1.9 JTD	TRW EPS
 Stilo	ENGINE MANAGEME	1.2 16v	BOSCH Motronic ME7.3H4M EOBD
 Stilo	ENGINE MANAGEME	1.2 16v (01-..)	EOBD
 Stilo	ENGINE MANAGEME	1.4 16v	BOSCH Motronic ME7.3H4M EOBD
 Stilo	ENGINE MANAGEME	1.6 16v	Marelli IAW 5NF EOBD
 Stilo	ENGINE MANAGEME	1.6 16v (01-..)	EOBD
 Stilo	ENGINE MANAGEME	1.8 16v (01-..)	EOBD
 Stilo	ENGINE MANAGEME	1.9 JTD 16v	BOSCH EDC 15 Common Rail (JTD '99)
 Stilo	ENGINE MANAGEME	1.9 JTD 8v	BOSCH EDC 15 Common Rail (JTD '99)
 Stilo	ENGINE MANAGEME	1.9 JTD Multijet 16v (03-..)	BOSCH EDC 16 CF3 Common Rail M-Jet
 Stilo	ENGINE MANAGEME	1.9 JTD Multijet 16v (06-..)	BOSCH EDC 16 C39 CF4/EOBD Common
 Stilo	ENGINE MANAGEME	1.9 JTD Multijet 8v (06-..)	BOSCH EDC 16C39 CF4/EOBD Common
 Stilo	ENGINE MANAGEME	2.4 20v (01-..)	EOBD
 Stilo	ENGINE MANAGEME	2.4 20v Selespeed	EOBD
 Stilo	ENGINE MANAGEME	80 1.9 JTD	BOSCH EDC 15 Common Rail (JTD '99)
 Stilo	FRONT DOORS	1.2 16v	BITRON FRONT DOORS
 Stilo	FRONT DOORS	1.4 16v	BITRON FRONT DOORS
 Stilo	FRONT DOORS	1.6 16v	BITRON FRONT DOORS
 Stilo	FRONT DOORS	1.8 16v	BITRON FRONT DOORS
 Stilo	FRONT DOORS	1.9 JTD 16v	BITRON FRONT DOORS
 Stilo	FRONT DOORS	1.9 JTD 8v	BITRON FRONT DOORS
 Stilo	FRONT DOORS	1.9 JTD Multijet 16v	BITRON FRONT DOORS
 Stilo	FRONT DOORS	1.9 JTD Multijet 8v	BITRON FRONT DOORS
 Stilo	FRONT DOORS	2.4 20v	BITRON FRONT DOORS
 Stilo	FRONT DOORS	2.4 20v Selespeed	BITRON FRONT DOORS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Stilo	FRONT DOORS	80 1.9 JTD	BITRON FRONT DOORS
 Stilo	KEY ENCODE	1.2 16v	Marelli CODE Body Computer
 Stilo	KEY ENCODE	1.4 16v	Marelli CODE Body Computer
 Stilo	KEY ENCODE	1.6 16v	Marelli CODE Body Computer
 Stilo	KEY ENCODE	1.8 16v	Marelli CODE Body Computer
 Stilo	KEY ENCODE	1.9 JTD 16v	Marelli CODE Body Computer
 Stilo	KEY ENCODE	1.9 JTD 8v	Marelli CODE Body Computer
 Stilo	KEY ENCODE	1.9 JTD Multijet 16v	Marelli CODE Body Computer
 Stilo	KEY ENCODE	1.9 JTD Multijet 8v	Marelli CODE Body Computer
 Stilo	KEY ENCODE	2.4 20v	Marelli CODE Body Computer
 Stilo	KEY ENCODE	2.4 20v Selespeed	Marelli CODE Body Computer
 Stilo	KEY ENCODE	80 1.9 JTD	Marelli CODE Body Computer
 Stilo	MAINTENANCE	1.2 16v	VISTEON Dashboard
 Stilo	MAINTENANCE	1.2 16v (01-..)	VISTEON Dashboard
 Stilo	MAINTENANCE	1.4 16v	
 Stilo	MAINTENANCE	1.4 16v (01-..)	VISTEON Dashboard
 Stilo	MAINTENANCE	1.6 16v	
 Stilo	MAINTENANCE	1.6 16v (01-..)	VISTEON Dashboard
 Stilo	MAINTENANCE	1.8 16v	
 Stilo	MAINTENANCE	1.8 16v (01-..)	VISTEON Dashboard
 Stilo	MAINTENANCE	1.9 JTD 16v	
 Stilo	MAINTENANCE	1.9 JTD 16v (01-..)	VISTEON Dashboard
 Stilo	MAINTENANCE	1.9 JTD 8v	
 Stilo	MAINTENANCE	1.9 JTD 8v (01-..)	VISTEON Dashboard
 Stilo	MAINTENANCE	1.9 JTD Multijet 16v	
 Stilo	MAINTENANCE	1.9 JTD Multijet 16v (01-..)	BOSCH EDC 16 C39 CF4/EOBD Common
 Stilo	MAINTENANCE	1.9 JTD Multijet 16v (06-..)	
 Stilo	MAINTENANCE	1.9 JTD Multijet 16v (06-..)	BOSCH EDC 16C39 CF4/EOBD Common
 Stilo	MAINTENANCE	1.9 JTD Multijet 8v (01-..)	
 Stilo	MAINTENANCE	1.9 JTD Multijet 8v (06-..)	BOSCH EDC 16C39 CF4/EOBD Common
 Stilo	MAINTENANCE	1.9 JTD Multijet 8v (06-..)	
 Stilo	MAINTENANCE	2.4 20v	VISTEON Dashboard
 Stilo	MAINTENANCE	2.4 20v (01-..)	
 Stilo	MAINTENANCE	2.4 20v Selespeed	VISTEON Dashboard
 Stilo	MAINTENANCE	2.4 20v Selespeed (01-..)	
 Stilo	MAINTENANCE	80 1.9 JTD	VISTEON Dashboard
 Stilo	MAINTENANCE	80 1.9 JTD (01-..)	
 Stilo	PARKING HELP	1.2 16v	Valeo
 Stilo	PARKING HELP	1.6 16v	Valeo
 Stilo	PARKING HELP	1.8 16v	Valeo
 Stilo	PARKING HELP	1.9 JTD 16v	Valeo
 Stilo	PARKING HELP	1.9 JTD 8v	Valeo
 Stilo	PARKING HELP	1.9 JTD Multijet 16v	Valeo
 Stilo	PARKING HELP	1.9 JTD Multijet 8v	Valeo
 Stilo	PARKING HELP	2.4 20v	Valeo
 Stilo	PARKING HELP	2.4 20v Selespeed	Valeo
 Stilo	PARKING HELP	80 1.9 JTD	Valeo
 Stilo	PASS SEAT CONTRO	1.2 16v	LEAR PASSENGER SEAT
 Stilo	PASS SEAT CONTRO	1.4 16v	LEAR PASSENGER SEAT
 Stilo	PASS SEAT CONTRO	1.6 16v	LEAR PASSENGER SEAT
 Stilo	PASS SEAT CONTRO	1.8 16v	LEAR PASSENGER SEAT
 Stilo	PASS SEAT CONTRO	1.9 JTD 16v	LEAR PASSENGER SEAT
 Stilo	PASS SEAT CONTRO	1.9 JTD 8v	LEAR PASSENGER SEAT
 Stilo	PASS SEAT CONTRO	1.9 JTD Multijet 16v	LEAR PASSENGER SEAT
 Stilo	PASS SEAT CONTRO	1.9 JTD Multijet 8v	LEAR PASSENGER SEAT
 Stilo	PASS SEAT CONTRO	2.4 20v	LEAR PASSENGER SEAT
 Stilo	PASS SEAT CONTRO	2.4 20v Selespeed	LEAR PASSENGER SEAT
 Stilo	PASS SEAT CONTRO	80 1.9 JTD	LEAR PASSENGER SEAT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Stilo	PASS. SIDE DOOR	1.2 16v	BITRON PASSENGER DOOR
 Stilo	PASS. SIDE DOOR	1.2 16v	PROCOND PASSENGER DOOR
 Stilo	PASS. SIDE DOOR	1.4 16v	BITRON PASSENGER DOOR
 Stilo	PASS. SIDE DOOR	1.4 16v	PROCOND PASSENGER DOOR
 Stilo	PASS. SIDE DOOR	1.6 16v	BITRON PASSENGER DOOR
 Stilo	PASS. SIDE DOOR	1.6 16v	PROCOND PASSENGER DOOR
 Stilo	PASS. SIDE DOOR	1.8 16v	BITRON PASSENGER DOOR
 Stilo	PASS. SIDE DOOR	1.8 16v	PROCOND PASSENGER DOOR
 Stilo	PASS. SIDE DOOR	1.9 JTD 16v	BITRON PASSENGER DOOR
 Stilo	PASS. SIDE DOOR	1.9 JTD 16v	PROCOND PASSENGER DOOR
 Stilo	PASS. SIDE DOOR	1.9 JTD 8v	BITRON PASSENGER DOOR
 Stilo	PASS. SIDE DOOR	1.9 JTD 8v	PROCOND PASSENGER DOOR
 Stilo	PASS. SIDE DOOR	1.9 JTD Multijet 16v	BITRON PASSENGER DOOR
 Stilo	PASS. SIDE DOOR	1.9 JTD Multijet 16v	PROCOND PASSENGER DOOR
 Stilo	PASS. SIDE DOOR	1.9 JTD Multijet 8v	BITRON PASSENGER DOOR
 Stilo	PASS. SIDE DOOR	1.9 JTD Multijet 8v	PROCOND PASSENGER DOOR
 Stilo	PASS. SIDE DOOR	2.4 20v	BITRON PASSENGER DOOR
 Stilo	PASS. SIDE DOOR	2.4 20v	PROCOND PASSENGER DOOR
 Stilo	PASS. SIDE DOOR	2.4 20v Selespeed	BITRON PASSENGER DOOR
 Stilo	PASS. SIDE DOOR	2.4 20v Selespeed	PROCOND PASSENGER DOOR
 Stilo	PASS. SIDE DOOR	80 1.9 JTD	BITRON PASSENGER DOOR
 Stilo	PASS. SIDE DOOR	80 1.9 JTD	PROCOND PASSENGER DOOR
 Stilo	SERVICE LIGHT RES	1.2 16v (01-..)	
 Stilo	SERVICE LIGHT RES	1.4 16v (01-..)	
 Stilo	SERVICE LIGHT RES	1.6 16v (01-..)	
 Stilo	SERVICE LIGHT RES	1.8 16v (01-..)	
 Stilo	SERVICE LIGHT RES	1.9 JTD 16v (01-..)	
 Stilo	SERVICE LIGHT RES	1.9 JTD 8v (01-..)	
 Stilo	SERVICE LIGHT RES	1.9 JTD Multijet 16v (01-..)	
 Stilo	SERVICE LIGHT RES	1.9 JTD Multijet 8v (01-..)	
 Stilo	SERVICE LIGHT RES	2.4 20v (01-..)	
 Stilo	SERVICE LIGHT RES	2.4 20v Selespeed (01-..)	
 Stilo	SERVICE LIGHT RES	80 1.9 JTD (01-..)	
 Stilo	VISUAL./TELEMATIC	1.2 16v	Marelli Connect 3
 Stilo	VISUAL./TELEMATIC	1.4 16v	Marelli Connect 3
 Stilo	VISUAL./TELEMATIC	1.6 16v	Marelli Connect 3
 Stilo	VISUAL./TELEMATIC	1.8 16v	Marelli Connect 3
 Stilo	VISUAL./TELEMATIC	1.9 JTD 16v	Marelli Connect 3
 Stilo	VISUAL./TELEMATIC	1.9 JTD 8v	Marelli Connect 3
 Stilo	VISUAL./TELEMATIC	1.9 JTD Multijet 16v	Marelli Connect 3
 Stilo	VISUAL./TELEMATIC	1.9 JTD Multijet 8v	Marelli Connect 3
 Stilo	VISUAL./TELEMATIC	2.4 20v	Marelli Connect 3
 Stilo	VISUAL./TELEMATIC	2.4 20v Selespeed	Marelli Connect 3
 Stilo	VISUAL./TELEMATIC	80 1.9 JTD	Marelli Connect 3
 Strada	ABS	1.3 Multijet	BOSCH ABS 5.3
 Strada	DIESEL MANAGEMEN	1.9 D (99-..)	LUCAS EPIC DCU3F
 Strada	ENGINE MANAGEME	1.3 Multijet (04-..)	Marelli 6F3 (D.P.F.) CF3 Common Rail
 Strada	MAINTENANCE	1.3 Multijet (04-..)	Marelli 6F3 (D.P.F.) CF3 Common Rail
 Strada	MAINTENANCE	1.3 Multijet (04-..)	Marelli 6F3 (D.P.F.) CF3 Common Rail
 Strada	MAINTENANCE	1.3 Multijet (04-..)	Marelli 6F3 (D.P.F.) CF3 Common Rail
 Strada	MAINTENANCE	1.3 Multijet (04-..)	Marelli 6F3 (D.P.F.) CF3 Common Rail
 Tempra	ABS	1.4 Kat	BOSCH ABS 2Si
 Tempra	ABS	1.6 Kat	BOSCH ABS 2Si
 Tempra	ABS	1.8	BOSCH ABS 2Si
 Tempra	ABS	1.8 Kat	BOSCH ABS 2Si
 Tempra	ABS	2.0 16v Kat	BOSCH ABS 2Si
 Tempra	ABS	2.0 4X4 Kat	BOSCH ABS 2Si
 Tempra	ABS	2.0 AT Kat	BOSCH ABS 2Si

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Tempra	ABS	2.0 Kat	BOSCH ABS 2Si
 Tempra	ELECTRONIC INJECT	1.4 Kat	BOSCH MonoJetronic A2.2
 Tempra	ELECTRONIC INJECT	1.4 Kat	BOSCH MonoJetronic A2.2
 Tempra	ELECTRONIC INJECT	1.6 Kat	BOSCH MonoJetronic A2.2
 Tempra	ELECTRONIC INJECT	1.6 Kat	BOSCH MonoJetronic A2.2
 Tempra	ENGINE MANAGEME	1.4 Kat	BOSCH MonoMotronic MA1.7
 Tempra	ENGINE MANAGEME	1.4 Kat	BOSCH MonoMotronic MA1.7
 Tempra	ENGINE MANAGEME	1.6 Kat	BOSCH MonoMotronic MA1.7
 Tempra	ENGINE MANAGEME	1.6 Kat	BOSCH MonoMotronic MA1.7
 Tempra	ENGINE MANAGEME	1.6 Kat	GM MPI Rochester
 Tempra	ENGINE MANAGEME	1.6 Kat	GM MPI Rochester
 Tempra	ENGINE MANAGEME	1.6 Kat	GM MPI Rochester
 Tempra	ENGINE MANAGEME	1.8	Marelli IAW 04S
 Tempra	ENGINE MANAGEME	1.8	Marelli IAW 4T1
 Tempra	ENGINE MANAGEME	1.8	Marelli IAW 4T1
 Tempra	ENGINE MANAGEME	1.8	Marelli IAW 4T1
 Tempra	ENGINE MANAGEME	1.8 Kat	Marelli IAW 4U6
 Tempra	ENGINE MANAGEME	1.8 Kat	Marelli IAW 4U6
 Tempra	ENGINE MANAGEME	1.8 Kat	Marelli IAW 4U6
 Tempra	ENGINE MANAGEME	1.8 Kat	Marelli IAW 8F.52
 Tempra	ENGINE MANAGEME	1.8 Kat	Marelli IAW 8F.5M
 Tempra	ENGINE MANAGEME	1.8 Kat	Marelli IAW 8F.5M(1)
 Tempra	ENGINE MANAGEME	1.8 Kat	Marelli IAW 8F.5M(2)
 Tempra	ENGINE MANAGEME	2.0 16v Kat	Marelli IAW 4Q2
 Tempra	ENGINE MANAGEME	2.0 16v Kat	Marelli IAW 4Q2.P8
 Tempra	ENGINE MANAGEME	2.0 16v Kat	Marelli IAW 4Q2.P8
 Tempra	ENGINE MANAGEME	2.0 4X4 Kat	Marelli IAW 4S1
 Tempra	ENGINE MANAGEME	2.0 AT Kat	Marelli IAW 4S1
 Tempra	ENGINE MANAGEME	2.0 AT Kat	Marelli IAW 4U2.P8
 Tempra	ENGINE MANAGEME	2.0 Kat	Marelli IAW 4S1
 Tempra	ENGINE MANAGEME	2.0 Kat	Marelli IAW 4S1
 Tempra	ENGINE MANAGEME	2.0 Kat	Marelli IAW 4S1
 Tipo	ELECTRONIC INJECT	1.4	BOSCH MonoJetronic A2.2
 Tipo	ELECTRONIC INJECT	1.4 AT	BOSCH MonoJetronic
 Tipo	ELECTRONIC INJECT	1.4 AT	BOSCH MonoJetronic A2.2
 Tipo	ELECTRONIC INJECT	1.4 AT Kat	BOSCH MonoJetronic
 Tipo	ELECTRONIC INJECT	1.4 AT Kat	BOSCH MonoJetronic A2.2
 Tipo	ELECTRONIC INJECT	1.4 Kat	BOSCH MonoJetronic A2.2
 Tipo	ELECTRONIC INJECT	1.4 Kat	BOSCH MonoJetronic A2.2
 Tipo	ELECTRONIC INJECT	1.4 Kat	BOSCH MonoJetronic A2.2
 Tipo	ELECTRONIC INJECT	1.6 Kat	BOSCH MonoJetronic A2.2
 Tipo	ELECTRONIC INJECT	1.6 Kat	BOSCH MonoJetronic A2.2
 Tipo	ELECTRONIC INJECT	1.6 Kat	BOSCH MonoJetronic A2.2
 Tipo	ELECTRONIC INJECT	1.6 Kat	BOSCH MonoJetronic A2.2
 Tipo	ENGINE MANAGEME	1.1 Kat	BOSCH MonoMotronic MA1.7
 Tipo	ENGINE MANAGEME	1.1 Kat	BOSCH MonoMotronic MA1.7
 Tipo	ENGINE MANAGEME	1.4 Kat	BOSCH MonoMotronic MA1.7
 Tipo	ENGINE MANAGEME	1.4 Kat	BOSCH MonoMotronic MA1.7
 Tipo	ENGINE MANAGEME	1.6 Kat	BOSCH MonoMotronic MA1.7
 Tipo	ENGINE MANAGEME	1.6 Kat	BOSCH MonoMotronic MA1.7
 Tipo	ENGINE MANAGEME	1.6 Kat	BOSCH MonoMotronic MA1.7
 Tipo	ENGINE MANAGEME	1.6 Kat	BOSCH MonoMotronic MA1.7
 Tipo	ENGINE MANAGEME	1.8	Marelli IAW 4T3
 Tipo	ENGINE MANAGEME	1.8	Marelli IAW 4T3
 Tipo	ENGINE MANAGEME	1.8 16v	Marelli IAW 04N
 Tipo	ENGINE MANAGEME	1.8 16v	Marelli IAW 04N
 Tipo	ENGINE MANAGEME	1.8 16v	Marelli IAW 04N

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Tipo	ENGINE MANAGEME	1.8 16v	Marelli IAW 04N
 Tipo	ENGINE MANAGEME	1.8 Kat	Marelli IAW 4U7
 Tipo	ENGINE MANAGEME	1.8 Kat	Marelli IAW 8F.52
 Tipo	ENGINE MANAGEME	1.8 Kat	Marelli IAW 8F.5M
 Tipo	ENGINE MANAGEME	1.8 Kat	Marelli IAW 8F.5M
 Tipo	ENGINE MANAGEME	1.8 Kat	Marelli IAW 8F.5W
 Tipo	ENGINE MANAGEME	1.8 Kat	Marelli IAW 8F.5W
 Tipo	ENGINE MANAGEME	2.0 16v Kat	Marelli IAW 4Q1
 Tipo	ENGINE MANAGEME	2.0 16v Kat	Marelli IAW 4Q1
 Tipo	ENGINE MANAGEME	2.0 16v Kat	Marelli IAW 4Q1
 Tipo	ENGINE MANAGEME	2.0 16v Kat	Marelli IAW 4Q5.P8
 Tipo	ENGINE MANAGEME	2.0 16v Kat	Marelli IAW 4Q5.P8
 Tipo	ENGINE MANAGEME	2.0 16v Kat	Marelli IAW 4Q5.P8
 Tipo	ENGINE MANAGEME	2.0 16v Kat	Marelli IAW 4Q5.P8
 Tipo	ENGINE MANAGEME	2.0 AT Kat	Marelli IAW 4U3
 Tipo	ENGINE MANAGEME	2.0 AT Kat	Marelli IAW 4U3
 Tipo	ENGINE MANAGEME	2.0 Kat	Marelli IAW 4U3
 Tipo	ENGINE MANAGEME	2.0 Kat	Marelli IAW 4U3
 Tipo	ENGINE MANAGEME	2.0 Kat	Marelli IAW 4U3
 Tipo	ENGINE MANAGEME	2.0 Kat	Marelli IAW 4U3
 Tipo	ENGINE MANAGEME	2.0 Kat	Marelli IAW 4U3
 Ulysse (179)	ABS + TRACT. CONT	2.0 JTD 16v 120cv (07-..)	BOSCH ESP 8.1
 Ulysse (179)	ABS + TRACT. CONT	2.0 JTD FAP 16v 136cv (07-..)	BOSCH ESP 8.1
 Ulysse (179)	ABS + TRACT. CONT	2.2 JTD FAP 16v 170cv (07-..)	BOSCH ESP 8.1
 Ulysse (179)	AIRBAG	2.0 JTD 16v 120cv (05-..)	TEMIC AirBag
 Ulysse (179)	AIRBAG	2.0 JTD 16v 120cv (07-..)	Temic SRS
 Ulysse (179)	AIRBAG	2.0 JTD FAP 16v 136cv (05-..)	TEMIC AirBag
 Ulysse (179)	AIRBAG	2.0 JTD FAP 16v 136cv (07-..)	Temic SRS
 Ulysse (179)	AIRBAG	2.2 JTD FAP 16v 170cv (05-..)	TEMIC AirBag
 Ulysse (179)	AIRBAG	2.2 JTD FAP 16v 170cv (07-..)	Temic SRS
 Ulysse (179)	ANTITHEFT	2.0 JTD 16v 120cv (07-..)	Alarm PSA2
 Ulysse (179)	ANTITHEFT	2.2 JTD FAP 16v 170cv (07-..)	Alarm PSA2
 Ulysse (179)	DASH LAMPS	2.0 JTD 16v 120cv (05-..)	Marelli
 Ulysse (179)	DASH LAMPS	2.0 JTD FAP 16v 136cv (05-..)	Marelli
 Ulysse (179)	DASH LAMPS	2.2 JTD FAP 16v 170cv (05-..)	Marelli
 Ulysse (179)	DASHBOARD	2.0 JTD 16v 120cv (05-..)	Marelli Dashboard
 Ulysse (179)	DASHBOARD	2.0 JTD FAP 16v 136cv (05-..)	Marelli Dashboard
 Ulysse (179)	DASHBOARD	2.2 JTD FAP 16v 170cv (05-..)	Marelli Dashboard
 Ulysse (179)	ENGINE MANAGEME	2.0 JTD 16v 120cv (05-..)	EOBD
 Ulysse (179)	ENGINE MANAGEME	2.0 JTD FAP 16v 136cv (05-..)	EOBD
 Ulysse (179)	ENGINE MANAGEME	2.2 JTD FAP 16v 170cv (05-..)	EOBD
 Ulysse (179)	MAINTENANCE	2.0 JTD 16v 120cv (05-..)	EOBD
 Ulysse (179)	MAINTENANCE	2.0 JTD 16v 120cv (05-..)	EOBD
 Ulysse (179)	MAINTENANCE	2.0 JTD 16v 120cv (05-..)	EOBD
 Ulysse (179)	MAINTENANCE	2.0 JTD 16v 120cv (05-..)	Marelli
 Ulysse (179)	MAINTENANCE	2.0 JTD 16v 120cv (07-..)	BOSCH ESP 8.1
 Ulysse (179)	MAINTENANCE	2.0 JTD 16v 120cv (07-..)	BOSCH ESP 8.1
 Ulysse (179)	MAINTENANCE	2.0 JTD FAP 16v 136cv (05-..)	Marelli
 Ulysse (179)	MAINTENANCE	2.0 JTD FAP 16v 136cv (07-..)	BOSCH ESP 8.1
 Ulysse (179)	MAINTENANCE	2.0 JTD FAP 16v 136cv (07-..)	BOSCH ESP 8.1
 Ulysse (179)	MAINTENANCE	2.2 JTD FAP 16v 170cv (05-..)	Marelli
 Ulysse (179)	MAINTENANCE	2.2 JTD FAP 16v 170cv (07-..)	BOSCH ESP 8.1
 Ulysse (179)	MAINTENANCE	2.2 JTD FAP 16v 170cv (07-..)	BOSCH ESP 8.1
 Ulysse (179)	RADIO / CD	2.0 JTD 16v 120cv (07-..)	Blaupunkt AudioSystem
 Ulysse (179)	RADIO / CD	2.0 JTD 16v 120cv (07-..)	CD Changer AUTODETECT
 Ulysse (179)	RADIO / CD	2.0 JTD FAP 16v 136cv (07-..)	Blaupunkt AudioSystem
 Ulysse (179)	RADIO / CD	2.0 JTD FAP 16v 136cv (07-..)	CD Changer AUTODETECT
 Ulysse (179)	RADIO / CD	2.2 JTD FAP 16v 170cv (07-..)	Blaupunkt AudioSystem

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Ulysse (179)	RADIO / CD	2.2 JTD FAP 16v 170cv (07-..)	CD Changer AUTODETECT
 Ulysse 02	ABS	2.0 16v	BOSCH ABS ABR 5.7
 Ulysse 02	ABS	2.0 JTD	BOSCH ABS ABR 5.7
 Ulysse 02	ABS	2.2 JTD	BOSCH ABS ABR 5.7
 Ulysse 02	ABS + TRACT. CONT	2.0 16v	BOSCH ABS/ESP 5.7
 Ulysse 02	ABS + TRACT. CONT	2.0 JTD	BOSCH ABS/ESP 5.7
 Ulysse 02	ABS + TRACT. CONT	2.2 JTD	BOSCH ABS/ESP 5.7
 Ulysse 02	AIRBAG	2.0 16v	TEMIC AirBag
 Ulysse 02	AIRBAG	2.0 JTD	TEMIC AirBag
 Ulysse 02	AIRBAG	2.2 JTD	TEMIC AirBag
 Ulysse 02	CHASSIS NETWORK	2.0 16v	SAGEM Body Computer
 Ulysse 02	CHASSIS NETWORK	2.0 JTD	SAGEM Body Computer
 Ulysse 02	CHASSIS NETWORK	2.2 JTD	SAGEM Body Computer
 Ulysse 02	CLIMA	2.0 16v	Marelli klima
 Ulysse 02	CLIMA	2.0 JTD	Marelli klima
 Ulysse 02	CLIMA	2.2 JTD	Marelli klima
 Ulysse 02	DASH LAMPS	2.0 16v	BTO_MM
 Ulysse 02	DASH LAMPS	2.0 JTD	BTO_MM
 Ulysse 02	DASH LAMPS	2.2 JTD	BTO_MM
 Ulysse 02	DASHBOARD	2.0 16v	Marelli Dashboard
 Ulysse 02	DASHBOARD	2.0 JTD	Marelli Dashboard
 Ulysse 02	DASHBOARD	2.2 JTD	Marelli Dashboard
 Ulysse 02	DIESEL ADDITION	2.2 JTD FAP	Marelli
 Ulysse 02	DRIVER SIDE DOOR	2.0 16v	Marelli MTP CONDUCT
 Ulysse 02	DRIVER SIDE DOOR	2.0 JTD	Marelli MTP CONDUCT
 Ulysse 02	DRIVER SIDE DOOR	2.2 JTD	Marelli MTP CONDUCT
 Ulysse 02	ENGINE MANAGEME	2.0 16v	EOBD
 Ulysse 02	ENGINE MANAGEME	2.0 JTD RHT	BOSCH EDC 15 C2 Common Rail
 Ulysse 02	ENGINE MANAGEME	2.2 JTD	EOBD
 Ulysse 02	ENGINE MANAGEME	2.2 JTD 4HW-FAP	BOSCH EDC 15 C2 Common Rail
 Ulysse 02	MAINTENANCE	2.0 16v	BOSCH ABS/ESP 5.7
 Ulysse 02	MAINTENANCE	2.0 16v	BOSCH ABS/ESP 5.7
 Ulysse 02	MAINTENANCE	2.0 16v	BOSCH ABS/ESP 5.7
 Ulysse 02	MAINTENANCE	2.0 16v	BOSCH ABS/ESP 5.7
 Ulysse 02	MAINTENANCE	2.0 16v	BOSCH ABS/ESP 5.7
 Ulysse 02	MAINTENANCE	2.0 16v	BTO_MM
 Ulysse 02	MAINTENANCE	2.0 JTD	BOSCH ABS/ESP 5.7
 Ulysse 02	MAINTENANCE	2.0 JTD	BOSCH ABS/ESP 5.7
 Ulysse 02	MAINTENANCE	2.0 JTD	BOSCH ABS/ESP 5.7
 Ulysse 02	MAINTENANCE	2.0 JTD	BOSCH ABS/ESP 5.7
 Ulysse 02	MAINTENANCE	2.0 JTD	BOSCH ABS/ESP 5.7
 Ulysse 02	MAINTENANCE	2.0 JTD	BTO_MM
 Ulysse 02	MAINTENANCE	2.0 JTD RHT	BOSCH EDC 15 C2 Common Rail
 Ulysse 02	MAINTENANCE	2.2 JTD	BOSCH ABS/ESP 5.7
 Ulysse 02	MAINTENANCE	2.2 JTD	BOSCH ABS/ESP 5.7
 Ulysse 02	MAINTENANCE	2.2 JTD	BOSCH ABS/ESP 5.7
 Ulysse 02	MAINTENANCE	2.2 JTD	BOSCH ABS/ESP 5.7
 Ulysse 02	MAINTENANCE	2.2 JTD	BOSCH ABS/ESP 5.7
 Ulysse 02	MAINTENANCE	2.2 JTD	BTO_MM
 Ulysse 02	MAINTENANCE	2.2 JTD 4HW-FAP	BOSCH EDC 15 C2 Common Rail
 Ulysse 02	MAINTENANCE	2.2 JTD FAP	Marelli
 Ulysse 02	MAINTENANCE	2.2 JTD FAP	Marelli
 Ulysse 02	MAINTENANCE	2.2 JTD FAP	Marelli
 Ulysse 02	MAINTENANCE	2.2 JTD FAP	Marelli
 Ulysse 02	PARKING HELP	2.0 16v	VALEO
 Ulysse 02	PARKING HELP	2.0 JTD	VALEO
 Ulysse 02	PARKING HELP	2.2 JTD	VALEO
 Ulysse 02	PASS. SIDE DOOR	2.0 16v	Marelli MTP PASS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Ulysse 02	PASS. SIDE DOOR	2.0 JTD	Marelli MTP PASS
 Ulysse 02	PASS. SIDE DOOR	2.2 JTD	Marelli MTP PASS
 Ulysse 02	RADIO / CD	2.0 16v	CLARION
 Ulysse 02	RADIO / CD	2.0 16v	PHILIPS AudioSystem
 Ulysse 02	RADIO / CD	2.0 16v	VDO AudioSystem
 Ulysse 02	RADIO / CD	2.0 JTD	CLARION
 Ulysse 02	RADIO / CD	2.0 JTD	PHILIPS AudioSystem
 Ulysse 02	RADIO / CD	2.0 JTD	VDO AudioSystem
 Ulysse 02	RADIO / CD	2.2 JTD	CLARION
 Ulysse 02	RADIO / CD	2.2 JTD	PHILIPS AudioSystem
 Ulysse 02	RADIO / CD	2.2 JTD	VDO AudioSystem
 Ulysse 02	SWITCHLIGHT MODU	2.0 16v	EATON COM 2000
 Ulysse 02	SWITCHLIGHT MODU	2.0 JTD	EATON COM 2000
 Ulysse 02	SWITCHLIGHT MODU	2.2 JTD	EATON COM 2000
 Ulysse 02	VISUAL./TELEMATIC	2.0 16v (02-02)	SAGEM
 Ulysse 02	VISUAL./TELEMATIC	2.0 JTD (02-02)	SAGEM
 Ulysse 02	VISUAL./TELEMATIC	2.2 JTD (02-02)	SAGEM
 Ulysse	ABS	1.8	BENDIX ABS
 Ulysse	ABS	1.8	BOSCH ABS ABR 5.3
 Ulysse	ABS	1.9 TD	BENDIX ABS
 Ulysse	ABS	1.9 TD	BOSCH ABS ABR 5.3
 Ulysse	ABS	2.0	BENDIX ABS
 Ulysse	ABS	2.0	BOSCH ABS ABR 5.3
 Ulysse	ABS	2.0 JTD	BENDIX ABS
 Ulysse	ABS	2.0 JTD	BOSCH ABS ABR 5.3
 Ulysse	ABS	2.0 T	BENDIX ABS
 Ulysse	ABS	2.0 T	BOSCH ABS ABR 5.3
 Ulysse	ABS	2.1 TD	BENDIX ABS
 Ulysse	ABS	2.1 TD	BOSCH ABS ABR 5.3
 Ulysse	DIESEL MANAGEMEN	1.9 TD DHX	BOSCH AS3 VP20
 Ulysse	ENGINE MANAGEME	1.8	BOSCH MonoMotronic MA1.7
 Ulysse	ENGINE MANAGEME	2.0 JTD RHZ (...00)	BOSCH EDC 15 C2 Common Rail
 Ulysse	ENGINE MANAGEME	2.0 RFU	Marelli IAW 08P.22
 Ulysse	ENGINE MANAGEME	2.0 T RGX	BOSCH Motronic MP3.2
 Ulysse	ENGINE MANAGEME	2.1 TD P8C	LUCAS Diesel EPIC
 Ulysse	MAINTENANCE	1.8	BOSCH ABS ABR 5.3
 Ulysse	MAINTENANCE	1.8	BOSCH ABS ABR 5.3
 Ulysse	MAINTENANCE	1.8	BOSCH ABS ABR 5.3
 Ulysse	MAINTENANCE	1.8	BOSCH ABS ABR 5.3
 Ulysse	MAINTENANCE	1.8 (98-..)	MANUAL
 Ulysse	MAINTENANCE	1.9 TD	BOSCH ABS ABR 5.3
 Ulysse	MAINTENANCE	1.9 TD	BOSCH ABS ABR 5.3
 Ulysse	MAINTENANCE	1.9 TD	BOSCH ABS ABR 5.3
 Ulysse	MAINTENANCE	1.9 TD	BOSCH ABS ABR 5.3
 Ulysse	MAINTENANCE	1.9 TD (98-..)	MANUAL
 Ulysse	MAINTENANCE	2.0	BOSCH ABS ABR 5.3
 Ulysse	MAINTENANCE	2.0	BOSCH ABS ABR 5.3
 Ulysse	MAINTENANCE	2.0	BOSCH ABS ABR 5.3
 Ulysse	MAINTENANCE	2.0	BOSCH ABS ABR 5.3
 Ulysse	MAINTENANCE	2.0 (98-..)	MANUAL
 Ulysse	MAINTENANCE	2.0 JTD	BOSCH ABS ABR 5.3
 Ulysse	MAINTENANCE	2.0 JTD	BOSCH ABS ABR 5.3
 Ulysse	MAINTENANCE	2.0 JTD	BOSCH ABS ABR 5.3
 Ulysse	MAINTENANCE	2.0 JTD	BOSCH ABS ABR 5.3
 Ulysse	MAINTENANCE	2.0 JTD (98-..)	MANUAL
 Ulysse	MAINTENANCE	2.0 T	BOSCH ABS ABR 5.3
 Ulysse	MAINTENANCE	2.0 T	BOSCH ABS ABR 5.3
 Ulysse	MAINTENANCE	2.0 T	BOSCH ABS ABR 5.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Ulysse	MAINTENANCE	2.0 T	BOSCH ABS ABR 5.3
 Ulysse	MAINTENANCE	2.0 T (98-..)	MANUAL
 Ulysse	MAINTENANCE	2.1 TD	BOSCH ABS ABR 5.3
 Ulysse	MAINTENANCE	2.1 TD	BOSCH ABS ABR 5.3
 Ulysse	MAINTENANCE	2.1 TD	BOSCH ABS ABR 5.3
 Ulysse	MAINTENANCE	2.1 TD	BOSCH ABS ABR 5.3
 Ulysse	MAINTENANCE	2.1 TD (98-..)	MANUAL
 Ulysse	SERVICE LIGHT RES	1.8 (98-..)	MANUAL
 Ulysse	SERVICE LIGHT RES	1.9 TD (98-..)	MANUAL
 Ulysse	SERVICE LIGHT RES	2.0 (98-..)	MANUAL
 Ulysse	SERVICE LIGHT RES	2.0 JTD (98-..)	MANUAL
 Ulysse	SERVICE LIGHT RES	2.0 T (98-..)	MANUAL
 Ulysse	SERVICE LIGHT RES	2.1 TD (98-..)	MANUAL
 Uno	ABS	1.4 T	BOSCH ABS 2S
 Uno	ELECTRONIC INJECT	1.0 Fire Kat	BOSCH MonoJetronic A2.2
 Uno	ELECTRONIC INJECT	1.0 Fire Kat	BOSCH MonoJetronic A2.2
 Uno	ELECTRONIC INJECT	1.0 Fire Kat	BOSCH MonoJetronic A2.2
 Uno	ELECTRONIC INJECT	1.0 Fire Kat	BOSCH MonoJetronic A2.2
 Uno	ELECTRONIC INJECT	1.0 Fire Kat	BOSCH MonoJetronic A2.2
 Uno	ELECTRONIC INJECT	1.0 Fire Kat	BOSCH MonoJetronic A2.2
 Uno	ELECTRONIC INJECT	1.1 Fire Kat	BOSCH MonoJetronic A2.2
 Uno	ELECTRONIC INJECT	1.1 Fire Kat	BOSCH MonoJetronic A2.2
 Uno	ELECTRONIC INJECT	1.1 Fire Kat	BOSCH MonoJetronic A2.2
 Uno	ELECTRONIC INJECT	1.4	BOSCH MonoJetronic A2.2
 Uno	ELECTRONIC INJECT	1.4 AT	BOSCH MonoJetronic A2.2
 Uno	ELECTRONIC INJECT	1.4 AT	BOSCH MonoJetronic A2.2
 Uno	ELECTRONIC INJECT	1.4 AT Kat	BOSCH MonoJetronic A2.2
 Uno	ELECTRONIC INJECT	1.4 AT Kat	BOSCH MonoJetronic A2.2
 Uno	ELECTRONIC INJECT	1.4 Kat	BOSCH MonoJetronic A2.2
 Uno	ELECTRONIC INJECT	1.4 Kat	BOSCH MonoJetronic A2.2
 Uno	ELECTRONIC INJECT	1.4 Kat	BOSCH MonoJetronic A2.2
 Uno	ELECTRONIC INJECT	1.5 AT Kat	BOSCH MonoJetronic A2.2
 Uno	ELECTRONIC INJECT	1.5 Kat	BOSCH MonoJetronic A2.2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Bantam	ENGINE MANAGEME	1.3 (03-05)	ROCAM S.A.
 C-MAX 04	ABS + TRACT. CONT	1.6 TDCi 110cv	ATE ABS/ESP Mkxx
 C-MAX 04	ABS + TRACT. CONT	1.6 TDCi 90cv	ATE ABS/ESP Mkxx
 C-MAX 04	ABS + TRACT. CONT	1.6 Ti-VCT 115cv	ATE ABS/ESP Mkxx
 C-MAX 04	ABS + TRACT. CONT	1.8	ATE ABS/ESP Mkxx
 C-MAX 04	ABS + TRACT. CONT	1.8 TDCi 115cv	ATE ABS/ESP Mkxx
 C-MAX 04	ABS + TRACT. CONT	2.0 TDCi 136cv	ATE ABS/ESP Mkxx
 C-MAX 04	ABS + TRACT. CONT	2.0 Ti-VCT 145cv	ATE ABS/ESP Mkxx
 C-MAX 04	AIRBAG	1.6 TDCi 110cv	BOSCH RCM
 C-MAX 04	AIRBAG	1.6 TDCi 90cv	BOSCH RCM
 C-MAX 04	AIRBAG	1.6 Ti-VCT 115cv	BOSCH RCM
 C-MAX 04	AIRBAG	1.8	BOSCH RCM
 C-MAX 04	AIRBAG	1.8 TDCi 115cv	BOSCH RCM
 C-MAX 04	AIRBAG	2.0 TDCi 136cv	BOSCH RCM
 C-MAX 04	AIRBAG	2.0 Ti-VCT 145cv	BOSCH RCM
 C-MAX 04	CHASSIS NETWORK	1.6 TDCi 110cv	GEM
 C-MAX 04	CHASSIS NETWORK	1.6 TDCi 90cv	GEM
 C-MAX 04	CHASSIS NETWORK	1.6 Ti-VCT 115cv	GEM
 C-MAX 04	CHASSIS NETWORK	1.8	GEM
 C-MAX 04	CHASSIS NETWORK	1.8 TDCi 115cv	GEM
 C-MAX 04	CHASSIS NETWORK	2.0 TDCi 136cv	GEM
 C-MAX 04	CHASSIS NETWORK	2.0 TDCi 136cv	GEM FAP
 C-MAX 04	CHASSIS NETWORK	2.0 Ti-VCT 145cv	GEM
 C-MAX 04	CLIMA	1.6 TDCi 110cv	EATC
 C-MAX 04	CLIMA	1.6 TDCi 90cv	EATC
 C-MAX 04	CLIMA	1.6 Ti-VCT 115cv	EATC
 C-MAX 04	CLIMA	1.8	EATC
 C-MAX 04	CLIMA	1.8 TDCi 115cv	EATC
 C-MAX 04	CLIMA	2.0 TDCi 136cv	EATC
 C-MAX 04	CLIMA	2.0 TDCi 136cv	EATC FAP
 C-MAX 04	CLIMA	2.0 Ti-VCT 145cv	EATC
 C-MAX 04	DASHBOARD	1.6 TDCi 110cv	IC
 C-MAX 04	DASHBOARD	1.6 TDCi 90cv	IC
 C-MAX 04	DASHBOARD	1.6 Ti-VCT 115cv	IC
 C-MAX 04	DASHBOARD	1.8	IC
 C-MAX 04	DASHBOARD	1.8 TDCi 115cv	IC
 C-MAX 04	DASHBOARD	2.0 TDCi 136cv	IC
 C-MAX 04	DASHBOARD	2.0 TDCi 136cv	IC FAP
 C-MAX 04	DASHBOARD	2.0 Ti-VCT 145cv	IC
 C-MAX 04	ELECTRIC STEERING	1.6 TDCi 110cv	EPS
 C-MAX 04	ELECTRIC STEERING	1.6 TDCi 90cv	EPS
 C-MAX 04	ELECTRIC STEERING	1.6 Ti-VCT 115cv	EPS
 C-MAX 04	ELECTRIC STEERING	1.8	EPS
 C-MAX 04	ELECTRIC STEERING	1.8 TDCi 115cv	EPS
 C-MAX 04	ELECTRIC STEERING	2.0 TDCi 136cv	EPS
 C-MAX 04	ELECTRIC STEERING	2.0 TDCi 136cv	EPS FAP
 C-MAX 04	ELECTRIC STEERING	2.0 Ti-VCT 145cv	EPS
 C-MAX 04	ENGINE MANAGEME	1.6 TDCi 110cv	EOBD
 C-MAX 04	ENGINE MANAGEME	1.6 TDCi 90cv HHDA	PCM Duratorq
 C-MAX 04	ENGINE MANAGEME	1.6 Ti-VCT 115cv	EOBD
 C-MAX 04	ENGINE MANAGEME	1.8	EOBD
 C-MAX 04	ENGINE MANAGEME	1.8 TDCi 115cv	EOBD
 C-MAX 04	ENGINE MANAGEME	2.0 TDCi 136cv	PCM Duratorq + DPF
 C-MAX 04	ENGINE MANAGEME	2.0 TDCi 136cv DA3	PCM Duratorq
 C-MAX 04	ENGINE MANAGEME	2.0 TDCi 136cv FAP (04-..)	EOBD
 C-MAX 04	ENGINE MANAGEME	2.0 Ti-VCT 145cv	PCM Duratec
 C-MAX 04	MAINTENANCE	1.6 TDCi 110cv	ATE ABS/ESP Mkxx
 C-MAX 04	MAINTENANCE	1.6 TDCi 110cv	ATE ABS/ESP Mkxx

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C-MAX 04	MAINTENANCE	1.6 TDCi 90cv	ATE ABS/ESP Mkxx
 C-MAX 04	MAINTENANCE	1.6 TDCi 90cv	ATE ABS/ESP Mkxx
 C-MAX 04	MAINTENANCE	1.6 TDCi 90cv HHDA	PCM Duratorq
 C-MAX 04	MAINTENANCE	1.6 Ti-VCT 115cv	ATE ABS/ESP Mkxx
 C-MAX 04	MAINTENANCE	1.6 Ti-VCT 115cv	ATE ABS/ESP Mkxx
 C-MAX 04	MAINTENANCE	1.8	ATE ABS/ESP Mkxx
 C-MAX 04	MAINTENANCE	1.8	ATE ABS/ESP Mkxx
 C-MAX 04	MAINTENANCE	1.8 TDCi 115cv	ATE ABS/ESP Mkxx
 C-MAX 04	MAINTENANCE	1.8 TDCi 115cv	ATE ABS/ESP Mkxx
 C-MAX 04	MAINTENANCE	2.0 TDCi 136cv	ATE ABS/ESP Mkxx
 C-MAX 04	MAINTENANCE	2.0 TDCi 136cv	ATE ABS/ESP Mkxx
 C-MAX 04	MAINTENANCE	2.0 Ti-VCT 145cv	ATE ABS/ESP Mkxx
 C-MAX 04	MAINTENANCE	2.0 Ti-VCT 145cv	ATE ABS/ESP Mkxx
 Continental	ENGINE MANAGEME	4.6 (97-00)	FORD SEFI EEC-V
 Contour	ENGINE MANAGEME	2.0 (.-00)	FORD SEFI EEC-V
 Contour	ENGINE MANAGEME	2.5 (.-00)	FORD SEFI EEC-V
 Cougar	ENGINE MANAGEME	2.0 16v (99-..)	FORD SEFI EEC-V
 Cougar	ENGINE MANAGEME	2.5 (99-..)	FORD SEFI EEC-V
 Cougar	ENGINE MANAGEME	2.5 V6 24v (99-..)	FORD SEFI EEC-V
 Cougar	KEY ENCODE	2.0 16v (97-..)	FORD PATS MANUAL
 Cougar	KEY ENCODE	2.5 (97-..)	FORD PATS MANUAL
 Cougar	KEY ENCODE	2.5 V6 24v (97-..)	FORD PATS MANUAL
 Cougar	MAINTENANCE	2.0 16v (06-..)	MANUAL
 Cougar	MAINTENANCE	2.0 16v (97-..)	FORD PATS MANUAL
 Cougar	MAINTENANCE	2.5 (06-..)	MANUAL
 Cougar	MAINTENANCE	2.5 (97-..)	FORD PATS MANUAL
 Cougar	MAINTENANCE	2.5 V6 24v (06-..)	MANUAL
 Cougar	MAINTENANCE	2.5 V6 24v (97-..)	FORD PATS MANUAL
 Cougar	SERVICE LIGHT RES	2.0 16v (06-..)	MANUAL
 Cougar	SERVICE LIGHT RES	2.5 (06-..)	MANUAL
 Cougar	SERVICE LIGHT RES	2.5 V6 24v (06-..)	MANUAL
 Courier	ENGINE MANAGEME	1.3 J4C (95-..)	FORD SEFI EEC-V
 Courier	ENGINE MANAGEME	1.3 J6B (.-96)	FORD EFI EEC-IV
 Courier	ENGINE MANAGEME	1.4 FHA (95-..)	FORD SEFI EEC-V
 Crown Victoria	ENGINE MANAGEME	4.6 (96-00)	FORD SEFI EEC-V
 Econoline E150	ENGINE MANAGEME	4.6 (99-99)	FORD SEFI EEC-V
 Econoline E250	ENGINE MANAGEME	4.2 (99-99)	FORD SEFI EEC-V
 Econoline	ENGINE MANAGEME	4.2 (97-99)	FORD SEFI EEC-V
 Econoline	ENGINE MANAGEME	4.6 (97-99)	FORD SEFI EEC-V
 Econoline	ENGINE MANAGEME	5.4 (97-99)	FORD SEFI EEC-V
 Econoline	ENGINE MANAGEME	6.8 (97-99)	FORD SEFI EEC-V
 Econoline	ENGINE MANAGEME	7.3 (97-99)	FORD SEFI EEC-V
 Escort 86	AIRBAG	1.1 (.-99)	FORD AirBag MANUAL
 Escort 86	AIRBAG	1.3 (.-99)	FORD AirBag MANUAL
 Escort 86	AIRBAG	1.4 Kat (.-99)	FORD AirBag MANUAL
 Escort 86	AIRBAG	1.6 (.-99)	FORD AirBag MANUAL
 Escort 86	AIRBAG	1.6 D (.-99)	FORD AirBag MANUAL
 Escort 86	AIRBAG	1.6 Kat (.-99)	FORD AirBag MANUAL
 Escort 86	AIRBAG	1.8 Diesel (.-99)	FORD AirBag MANUAL
 Escort 86	ELECTRONIC IGNITI	1.6 L4B (.-94)	FORD ESC-II KE-Jetr.
 Escort 86	ENGINE MANAGEME	1.4 Kat F6B (.-94)	FORD CFI EEC-IV
 Escort 86	ENGINE MANAGEME	1.4 Kat F6D (.-94)	FORD CFI EEC-IV
 Escort 86	ENGINE MANAGEME	1.6 Kat LJB (.-94)	FORD EFI EEC-IV
 Escort 86	ENGINE MANAGEME	1.6 LJA (.-94)	FORD EFI EEC-IV
 Escort 86	MAINTENANCE	1.1 (.-99)	FORD AirBag MANUAL
 Escort 86	MAINTENANCE	1.3 (.-99)	FORD AirBag MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Escort 86	MAINTENANCE	1.4 Kat (...99)	FORD AirBag MANUAL
 Escort 86	MAINTENANCE	1.6 (...99)	FORD AirBag MANUAL
 Escort 86	MAINTENANCE	1.6 D (...99)	FORD AirBag MANUAL
 Escort 86	MAINTENANCE	1.6 Kat (...99)	FORD AirBag MANUAL
 Escort 86	MAINTENANCE	1.8 Diesel (...99)	FORD AirBag MANUAL
 Escort 91	AIRBAG	1.3 (...99)	FORD AirBag MANUAL-KAT
 Escort 91	AIRBAG	1.4 (...99)	FORD AirBag MANUAL
 Escort 91	AIRBAG	1.4 (...99)	FORD AirBag MANUAL-KAT
 Escort 91	AIRBAG	1.6 (...99)	FORD AirBag MANUAL
 Escort 91	AIRBAG	1.6 16v (...99)	FORD AirBag MANUAL
 Escort 91	AIRBAG	1.6 LJF-Kat (...99)	FORD AirBag MANUAL
 Escort 91	AIRBAG	1.8 16v (...99)	FORD AirBag MANUAL
 Escort 91	AIRBAG	1.8 Diesel (...99)	FORD AirBag MANUAL
 Escort 91	AIRBAG	1.8 TD (...99)	FORD AirBag MANUAL
 Escort 91	AIRBAG	2.0 16v (...99)	FORD AirBag MANUAL
 Escort 91	AIRBAG	RS Cosworth Kat (...99)	FORD AirBag MANUAL
 Escort 91	ENGINE MANAGEME	1.3 J6A (...94)	FORD CFI EEC-IV-KAT
 Escort 91	ENGINE MANAGEME	1.4 F4B (...94)	FORD SEFI EEC-IV (Fast)
 Escort 91	ENGINE MANAGEME	1.4 F4B (...94)	FORD SEFI EEC-IV-KAT
 Escort 91	ENGINE MANAGEME	1.4 F6F (...96)	FORD CFI EEC-IV-KAT
 Escort 91	ENGINE MANAGEME	1.4 F6F (94-..)	FORD SEFI EEC-V-KAT
 Escort 91	ENGINE MANAGEME	1.4 F6G (...96)	FORD CFI EEC-IV-KAT
 Escort 91	ENGINE MANAGEME	1.6 16v L1E (...94)	FORD SEFI EEC-IV
 Escort 91	ENGINE MANAGEME	1.6 16v L1E (...94)	FORD SEFI EEC-IV (Fast)
 Escort 91	ENGINE MANAGEME	1.6 16v L1H (...94)	FORD SEFI EEC-IV
 Escort 91	ENGINE MANAGEME	1.6 16v L1H (...95)	FORD SEFI EEC-IV (Fast)
 Escort 91	ENGINE MANAGEME	1.6 16v L1K (...94)	FORD SEFI EEC-IV (Fast)
 Escort 91	ENGINE MANAGEME	1.6 LJE (...94)	FORD EFI EEC-IV
 Escort 91	ENGINE MANAGEME	1.6 LJF-Kat (...94)	FORD EFI EEC-IV
 Escort 91	ENGINE MANAGEME	1.8 16v RDA (...94)	FORD SEFI EEC-IV
 Escort 91	ENGINE MANAGEME	1.8 16v RDA (...96)	FORD SEFI EEC-IV (Fast)
 Escort 91	ENGINE MANAGEME	1.8 16v RQB (...94)	FORD SEFI EEC-IV
 Escort 91	ENGINE MANAGEME	1.8 16v RQB (...96)	FORD SEFI EEC-IV (Fast)
 Escort 91	ENGINE MANAGEME	2.0 16v N5E (...96)	FORD SEFI EEC-IV (Fast)
 Escort 91	ENGINE MANAGEME	RS Cosworth Kat N5E (...94)	FORD EFI EEC-IV
 Escort 91	KEY ENCODE	1.3 (...94)	FORD PATS MANUAL-KAT
 Escort 91	KEY ENCODE	1.4 (...94)	FORD PATS MANUAL
 Escort 91	KEY ENCODE	1.4 (...94)	FORD PATS MANUAL-KAT
 Escort 91	KEY ENCODE	1.6 (...94)	FORD PATS MANUAL
 Escort 91	KEY ENCODE	1.6 16v (...94)	FORD PATS MANUAL
 Escort 91	KEY ENCODE	1.6 LJF-Kat (...94)	FORD PATS MANUAL
 Escort 91	KEY ENCODE	1.8 16v (...94)	FORD PATS MANUAL
 Escort 91	KEY ENCODE	1.8 Diesel (...94)	FORD PATS MANUAL
 Escort 91	KEY ENCODE	1.8 TD (...94)	FORD PATS MANUAL
 Escort 91	KEY ENCODE	2.0 16v (...94)	FORD PATS MANUAL
 Escort 91	KEY ENCODE	RS Cosworth Kat (...94)	FORD PATS MANUAL
 Escort 91	MAINTENANCE	1.3 (...94)	FORD PATS MANUAL-KAT
 Escort 91	MAINTENANCE	1.3 (...99)	FORD AirBag MANUAL-KAT
 Escort 91	MAINTENANCE	1.4 (...94)	FORD PATS MANUAL
 Escort 91	MAINTENANCE	1.4 (...94)	FORD PATS MANUAL-KAT
 Escort 91	MAINTENANCE	1.4 (...99)	FORD AirBag MANUAL
 Escort 91	MAINTENANCE	1.4 (...99)	FORD AirBag MANUAL-KAT
 Escort 91	MAINTENANCE	1.6 (...94)	FORD PATS MANUAL
 Escort 91	MAINTENANCE	1.6 (...99)	FORD AirBag MANUAL
 Escort 91	MAINTENANCE	1.6 16v (...94)	FORD PATS MANUAL
 Escort 91	MAINTENANCE	1.6 16v (...99)	FORD AirBag MANUAL
 Escort 91	MAINTENANCE	1.6 LJF-Kat (...94)	FORD PATS MANUAL
 Escort 91	MAINTENANCE	1.6 LJF-Kat (...99)	FORD AirBag MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Escort 91	MAINTENANCE	1.8 16v (...94)	FORD PATS MANUAL
 Escort 91	MAINTENANCE	1.8 16v (...99)	FORD AirBag MANUAL
 Escort 91	MAINTENANCE	1.8 Diesel (...94)	FORD PATS MANUAL
 Escort 91	MAINTENANCE	1.8 Diesel (...99)	FORD AirBag MANUAL
 Escort 91	MAINTENANCE	1.8 TD (...94)	FORD PATS MANUAL
 Escort 91	MAINTENANCE	1.8 TD (...99)	FORD AirBag MANUAL
 Escort 91	MAINTENANCE	2.0 16v (...94)	FORD PATS MANUAL
 Escort 91	MAINTENANCE	2.0 16v (...99)	FORD AirBag MANUAL
 Escort 91	MAINTENANCE	RS Cosworth Kat (...94)	FORD PATS MANUAL
 Escort 91	MAINTENANCE	RS Cosworth Kat (...99)	FORD AirBag MANUAL
 Escort 95	ABS + TRACT. CONT	1.3 (95-..)	ATE Teves Mk20-I
 Escort 95	ABS + TRACT. CONT	1.4 (95-..)	ATE Teves Mk20-I
 Escort 95	ABS + TRACT. CONT	1.6 16v (95-..)	ATE Teves Mk20-I
 Escort 95	ABS + TRACT. CONT	1.8 16v (95-..)	ATE Teves Mk20-I
 Escort 95	ABS + TRACT. CONT	1.8 Diesel (95-..)	ATE Teves Mk20-I
 Escort 95	ABS + TRACT. CONT	1.8 TD (95-..)	ATE Teves Mk20-I
 Escort 95	ABS + TRACT. CONT	2.0 16v (95-..)	ATE Teves Mk20-I
 Escort 95	ABS + TRACT. CONT	RS Cosworth (95-..)	ATE Teves Mk20-I
 Escort 95	AIRBAG	1.3 (...99)	FORD AirBag MANUAL
 Escort 95	AIRBAG	1.4 (...99)	FORD AirBag MANUAL
 Escort 95	AIRBAG	1.6 16v (...99)	FORD AirBag MANUAL
 Escort 95	AIRBAG	1.8 16v (...99)	FORD AirBag MANUAL
 Escort 95	AIRBAG	1.8 Diesel (...99)	FORD AirBag MANUAL
 Escort 95	AIRBAG	1.8 TD (...99)	FORD AirBag MANUAL
 Escort 95	AIRBAG	2.0 16v (...99)	FORD AirBag MANUAL
 Escort 95	AIRBAG	RS Cosworth (...99)	FORD AirBag MANUAL
 Escort 95	ENGINE MANAGEME	1.3 J4B (94-..)	FORD SEFI EEC-V
 Escort 95	ENGINE MANAGEME	1.4 F4B (...95)	FORD SEFI EEC-IV (Fast)
 Escort 95	ENGINE MANAGEME	1.4 F4B (...97)	FORD SEFI EEC-IV (Fast)
 Escort 95	ENGINE MANAGEME	1.6 16v L1E (94-..)	FORD SEFI EEC-V
 Escort 95	ENGINE MANAGEME	1.6 16v L1H (...97)	FORD SEFI EEC-IV (Fast)
 Escort 95	ENGINE MANAGEME	1.6 16v L1H (94-..)	FORD SEFI EEC-V
 Escort 95	ENGINE MANAGEME	1.6 16v L1K (94-..)	FORD SEFI EEC-V
 Escort 95	ENGINE MANAGEME	1.8 16v RDA (94-..)	FORD SEFI EEC-V
 Escort 95	ENGINE MANAGEME	1.8 16v RKC (...97)	FORD SEFI EEC-IV (Fast)
 Escort 95	ENGINE MANAGEME	1.8 16v RKC (97-..)	FORD SEFI EEC-V
 Escort 95	ENGINE MANAGEME	1.8 16v RQB (94-..)	FORD SEFI EEC-V
 Escort 95	ENGINE MANAGEME	1.8 TD (97-..)	FORD Diesel EEC-V
 Escort 95	ENGINE MANAGEME	2.0 16v (97-..)	FORD SEFI EEC-V
 Escort 95	ENGINE MANAGEME	RS Cosworth N5E (94-..)	FORD SEFI EEC-V
 Escort 95	KEY ENCODE	1.3 (95-96)	FORD PATS MANUAL
 Escort 95	KEY ENCODE	1.4 (95-96)	FORD PATS MANUAL
 Escort 95	KEY ENCODE	1.6 16v (95-96)	FORD PATS MANUAL
 Escort 95	KEY ENCODE	1.8 16v (95-96)	FORD PATS MANUAL
 Escort 95	KEY ENCODE	1.8 Diesel (95-96)	FORD PATS MANUAL
 Escort 95	KEY ENCODE	1.8 TD (95-96)	FORD PATS MANUAL
 Escort 95	KEY ENCODE	2.0 16v (95-96)	FORD PATS MANUAL
 Escort 95	KEY ENCODE	RS Cosworth (95-96)	FORD PATS MANUAL
 Escort 95	MAINTENANCE	1.3 (...99)	FORD AirBag MANUAL
 Escort 95	MAINTENANCE	1.3 (95-96)	FORD PATS MANUAL
 Escort 95	MAINTENANCE	1.4 (...99)	FORD AirBag MANUAL
 Escort 95	MAINTENANCE	1.4 (95-96)	FORD PATS MANUAL
 Escort 95	MAINTENANCE	1.6 16v (...99)	FORD AirBag MANUAL
 Escort 95	MAINTENANCE	1.6 16v (95-96)	FORD PATS MANUAL
 Escort 95	MAINTENANCE	1.8 16v (...99)	FORD AirBag MANUAL
 Escort 95	MAINTENANCE	1.8 16v (95-96)	FORD PATS MANUAL
 Escort 95	MAINTENANCE	1.8 Diesel (...99)	FORD AirBag MANUAL
 Escort 95	MAINTENANCE	1.8 Diesel (95-96)	FORD PATS MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Escort 95	MAINTENANCE	1.8 TD (...99)	FORD AirBag MANUAL
 Escort 95	MAINTENANCE	1.8 TD (95-96)	FORD PATS MANUAL
 Escort 95	MAINTENANCE	2.0 16v (...99)	FORD AirBag MANUAL
 Escort 95	MAINTENANCE	2.0 16v (95-96)	FORD PATS MANUAL
 Escort 95	MAINTENANCE	RS Cosworth (...99)	FORD AirBag MANUAL
 Escort 95	MAINTENANCE	RS Cosworth (95-96)	FORD PATS MANUAL
 Escort 98	ABS + TRACT. CONT	(98-..)	ATE Teves Mk20-I
 Escort 98	KEY ENCODE	(97-..)	FORD PATS MANUAL
 Escort 98	MAINTENANCE	(97-..)	FORD PATS MANUAL
 Excursion	ENGINE MANAGEME	5.4 (00-00)	FORD SEFI EEC-V
 Excursion	ENGINE MANAGEME	6.8 (00-00)	FORD SEFI EEC-V
 Excursion	ENGINE MANAGEME	7.3 (00-00)	FORD SEFI EEC-V
 Expedition	ENGINE MANAGEME	4.6 (98-00)	FORD SEFI EEC-V
 Expedition	ENGINE MANAGEME	5.4 (98-00)	FORD SEFI EEC-V
 Explorer 93	ENGINE MANAGEME	4.0 V6 (94-..)	FORD EFI EEC-V
 Explorer 93	ENGINE MANAGEME	4.0 V6 (94-..)	FORD SEFI EEC-V
 Explorer	ENGINE MANAGEME	4.0 ATX (97-00)	FORD SEFI EEC-V
 Explorer	ENGINE MANAGEME	4.0 MTX (97-00)	FORD SEFI EEC-V
 Explorer	ENGINE MANAGEME	5.0 (97-00)	FORD SEFI EEC-V
 F Ser-s DUTY	ENGINE MANAGEME	4.2 (99-00)	FORD SEFI EEC-V
 F Ser-s DUTY	ENGINE MANAGEME	5.4 (00-00)	FORD SEFI EEC-V
 F Ser-s DUTY	ENGINE MANAGEME	6.8 (99-00)	FORD SEFI EEC-V
 F Ser-s DUTY	ENGINE MANAGEME	7.3 (99-99)	FORD SEFI EEC-V
 F Ser-s DUTY	ENGINE MANAGEME	7.3 Diesel (00-00)	FORD SEFI EEC-V
 F-150	ENGINE MANAGEME	4.2 ATX (97-00)	FORD SEFI EEC-V
 F-150	ENGINE MANAGEME	4.2 MTX (97-00)	FORD SEFI EEC-V
 F-150	ENGINE MANAGEME	4.6 ATX (97-00)	FORD SEFI EEC-V
 F-150	ENGINE MANAGEME	4.6 MTX (97-00)	FORD SEFI EEC-V
 F-150	ENGINE MANAGEME	5.4 ATX (97-00)	FORD SEFI EEC-V
 F-150	ENGINE MANAGEME	5.4 MTX (97-00)	FORD SEFI EEC-V
 F-250	ENGINE MANAGEME	4.6 ATX (97-00)	FORD SEFI EEC-V
 F-250	ENGINE MANAGEME	4.6 MTX (97-00)	FORD SEFI EEC-V
 F-250	ENGINE MANAGEME	5.4 NGV (97-00)	FORD SEFI EEC-V
 F-250	ENGINE MANAGEME	7.3 (97-97)	FORD SEFI EEC-V
 F-350	ENGINE MANAGEME	4.6 ATX (97-97)	FORD SEFI EEC-V
 F-350	ENGINE MANAGEME	4.6 MTX (97-97)	FORD SEFI EEC-V
 F-350	ENGINE MANAGEME	5.4 NGV (97-97)	FORD SEFI EEC-V
 F-350	ENGINE MANAGEME	7.3 (97-97)	FORD SEFI EEC-V
 Fairlane/LTD	ENGINE MANAGEME	4.0 (99-00)	FORD SEFI EEC-V
 Fairlane/LTD	ENGINE MANAGEME	5.0 (99-00)	FORD SEFI EEC-V
 Fairmont/Ghia	ENGINE MANAGEME	4.0 (99-00)	FORD SEFI EEC-V
 Fairmont/Ghia	ENGINE MANAGEME	5.0 (99-00)	FORD SEFI EEC-V
 Falcon AU	ENGINE MANAGEME	4.0 (99-00)	FORD SEFI EEC-V
 Falcon AU	ENGINE MANAGEME	5.0 (99-00)	FORD SEFI EEC-V
 Falcon BA	ENGINE MANAGEME	4.0 (02-..)	FORD SEFI EEC-V
 Falcon BA	ENGINE MANAGEME	5.4 (02-..)	FORD SEFI EEC-V
 Falcon BF	ENGINE MANAGEME	4.0 (05-..)	FORD SEFI EEC-V
 Falcon BF	ENGINE MANAGEME	5.4 (05-..)	FORD SEFI EEC-V
 Falcon Forte	ENGINE MANAGEME	4.0 (99-00)	FORD SEFI EEC-V
 Falcon Forte	ENGINE MANAGEME	5.0 (99-00)	FORD SEFI EEC-V
 Falcon Futura	ENGINE MANAGEME	4.0 (99-00)	FORD SEFI EEC-V
 Falcon Futura	ENGINE MANAGEME	5.0 (99-00)	FORD SEFI EEC-V
 Fiesta 02	ABS	1.2 Duratec 16v (02-06)	ATE-TEVES ABS
 Fiesta 02	ABS	1.2 Duratec 16v (06-08)	ATE-TEVES ABS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Fiesta 02	ABS	1.3 (02-06)	ATE-TEVES ABS
 Fiesta 02	ABS	1.3 (06-08)	ATE-TEVES ABS
 Fiesta 02	ABS	1.4 Duratec 16v (02-06)	ATE-TEVES ABS
 Fiesta 02	ABS	1.4 Duratec 16v (06-08)	ATE-TEVES ABS
 Fiesta 02	ABS	1.4 TDCi (02-06)	ATE-TEVES ABS
 Fiesta 02	ABS	1.4 TDCi (06-08)	ATE-TEVES ABS
 Fiesta 02	ABS	1.6 Duratec 16v (02-06)	ATE-TEVES ABS
 Fiesta 02	ABS	1.6 Duratec 16v (06-08)	ATE-TEVES ABS
 Fiesta 02	ABS	1.6 TDCi (02-06)	ATE-TEVES ABS
 Fiesta 02	ABS	1.6 TDCi (06-08)	ATE-TEVES ABS
 Fiesta 02	ABS	2.0 16v (02-06)	ATE-TEVES ABS
 Fiesta 02	ABS	2.0 16v (06-08)	ATE-TEVES ABS
 Fiesta 02	ABS	ST 150 (02-06)	ATE-TEVES ABS
 Fiesta 02	ABS	ST 150 (06-08)	ATE-TEVES ABS
 Fiesta 02	ABS + TRACT. CONT	1.2 Duratec 16v (02-06)	ATE ABS Mk60
 Fiesta 02	ABS + TRACT. CONT	1.2 Duratec 16v (06-08)	ATE ABS Mk60
 Fiesta 02	ABS + TRACT. CONT	1.3 (02-06)	ATE ABS Mk60
 Fiesta 02	ABS + TRACT. CONT	1.3 (06-08)	ATE ABS Mk60
 Fiesta 02	ABS + TRACT. CONT	1.4 Duratec 16v (02-06)	ATE ABS Mk60
 Fiesta 02	ABS + TRACT. CONT	1.4 Duratec 16v (06-08)	ATE ABS Mk60
 Fiesta 02	ABS + TRACT. CONT	1.4 TDCi (02-06)	ATE ABS Mk60
 Fiesta 02	ABS + TRACT. CONT	1.4 TDCi (06-08)	ATE ABS Mk60
 Fiesta 02	ABS + TRACT. CONT	1.6 Duratec 16v (02-06)	ATE ABS Mk60
 Fiesta 02	ABS + TRACT. CONT	1.6 Duratec 16v (06-08)	ATE ABS Mk60
 Fiesta 02	ABS + TRACT. CONT	1.6 TDCi (02-06)	ATE ABS Mk60
 Fiesta 02	ABS + TRACT. CONT	1.6 TDCi (06-08)	ATE ABS Mk60
 Fiesta 02	ABS + TRACT. CONT	2.0 16v (02-06)	ATE ABS Mk60
 Fiesta 02	ABS + TRACT. CONT	2.0 16v (06-08)	ATE ABS Mk60
 Fiesta 02	ABS + TRACT. CONT	ST 150 (02-06)	ATE ABS Mk60
 Fiesta 02	ABS + TRACT. CONT	ST 150 (06-08)	ATE ABS Mk60
 Fiesta 02	AIRBAG	1.2 Duratec 16v (02-06)	SIEMENS-VDO SRS
 Fiesta 02	AIRBAG	1.2 Duratec 16v (06-08)	SIEMENS-VDO SRS
 Fiesta 02	AIRBAG	1.3 (02-06)	SIEMENS-VDO SRS
 Fiesta 02	AIRBAG	1.3 (06-08)	SIEMENS-VDO SRS
 Fiesta 02	AIRBAG	1.4 Duratec 16v (02-06)	SIEMENS-VDO SRS
 Fiesta 02	AIRBAG	1.4 Duratec 16v (06-08)	SIEMENS-VDO SRS
 Fiesta 02	AIRBAG	1.4 TDCi (02-06)	SIEMENS-VDO SRS
 Fiesta 02	AIRBAG	1.4 TDCi (06-08)	SIEMENS-VDO SRS
 Fiesta 02	AIRBAG	1.6 Duratec 16v (02-06)	SIEMENS-VDO SRS
 Fiesta 02	AIRBAG	1.6 Duratec 16v (06-08)	SIEMENS-VDO SRS
 Fiesta 02	AIRBAG	1.6 TDCi (02-06)	SIEMENS-VDO SRS
 Fiesta 02	AIRBAG	1.6 TDCi (06-08)	SIEMENS-VDO SRS
 Fiesta 02	AIRBAG	2.0 16v (02-06)	SIEMENS-VDO SRS
 Fiesta 02	AIRBAG	2.0 16v (06-08)	SIEMENS-VDO SRS
 Fiesta 02	AIRBAG	ST 150 (02-06)	SIEMENS-VDO SRS
 Fiesta 02	AIRBAG	ST 150 (06-08)	SIEMENS-VDO SRS
 Fiesta 02	CHASSIS NETWORK	1.2 Duratec 16v (02-06)	SIEMENS GEM Body Computer
 Fiesta 02	CHASSIS NETWORK	1.2 Duratec 16v (06-08)	SIEMENS GEM Body Computer
 Fiesta 02	CHASSIS NETWORK	1.3 (02-06)	SIEMENS GEM Body Computer
 Fiesta 02	CHASSIS NETWORK	1.3 (06-08)	SIEMENS GEM Body Computer
 Fiesta 02	CHASSIS NETWORK	1.4 Duratec 16v (02-06)	SIEMENS GEM Body Computer
 Fiesta 02	CHASSIS NETWORK	1.4 Duratec 16v (06-08)	SIEMENS GEM Body Computer
 Fiesta 02	CHASSIS NETWORK	1.4 TDCi (02-06)	SIEMENS GEM Body Computer
 Fiesta 02	CHASSIS NETWORK	1.4 TDCi (06-08)	SIEMENS GEM Body Computer
 Fiesta 02	CHASSIS NETWORK	1.6 Duratec 16v (02-06)	SIEMENS GEM Body Computer
 Fiesta 02	CHASSIS NETWORK	1.6 Duratec 16v (06-08)	SIEMENS GEM Body Computer
 Fiesta 02	CHASSIS NETWORK	1.6 TDCi (02-06)	SIEMENS GEM Body Computer
 Fiesta 02	CHASSIS NETWORK	1.6 TDCi (06-08)	SIEMENS GEM Body Computer

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Fiesta 02	CHASSIS NETWORK	2.0 16v (02-06)	SIEMENS GEM Body Computer
 Fiesta 02	CHASSIS NETWORK	2.0 16v (06-08)	SIEMENS GEM Body Computer
 Fiesta 02	CHASSIS NETWORK	ST 150 (02-06)	SIEMENS GEM Body Computer
 Fiesta 02	CHASSIS NETWORK	ST 150 (06-08)	SIEMENS GEM Body Computer
 Fiesta 02	DASHBOARD	1.2 Duratec 16v (02-06)	Instrument Cluster
 Fiesta 02	DASHBOARD	1.2 Duratec 16v (06-08)	Instrument Cluster
 Fiesta 02	DASHBOARD	1.3 (02-06)	Instrument Cluster
 Fiesta 02	DASHBOARD	1.3 (06-08)	Instrument Cluster
 Fiesta 02	DASHBOARD	1.4 Duratec 16v (02-06)	Instrument Cluster
 Fiesta 02	DASHBOARD	1.4 Duratec 16v (06-08)	Instrument Cluster
 Fiesta 02	DASHBOARD	1.4 TDCi (02-06)	Instrument Cluster
 Fiesta 02	DASHBOARD	1.4 TDCi (06-08)	Instrument Cluster
 Fiesta 02	DASHBOARD	1.6 Duratec 16v (02-06)	Instrument Cluster
 Fiesta 02	DASHBOARD	1.6 Duratec 16v (06-08)	Instrument Cluster
 Fiesta 02	DASHBOARD	1.6 TDCi (02-06)	Instrument Cluster
 Fiesta 02	DASHBOARD	1.6 TDCi (06-08)	Instrument Cluster
 Fiesta 02	DASHBOARD	2.0 16v (02-06)	Instrument Cluster
 Fiesta 02	DASHBOARD	2.0 16v (06-08)	Instrument Cluster
 Fiesta 02	DASHBOARD	ST 150 (02-06)	Instrument Cluster
 Fiesta 02	DASHBOARD	ST 150 (06-08)	Instrument Cluster
 Fiesta 02	ELECTRIC STEERING	1.2 Duratec 16v (06-08)	EPS
 Fiesta 02	ELECTRIC STEERING	1.3 (06-08)	EPS
 Fiesta 02	ELECTRIC STEERING	1.4 Duratec 16v (06-08)	EPS
 Fiesta 02	ELECTRIC STEERING	1.4 TDCi (06-08)	EPS
 Fiesta 02	ELECTRIC STEERING	1.6 Duratec 16v (06-08)	EPS
 Fiesta 02	ELECTRIC STEERING	1.6 TDCi (06-08)	EPS
 Fiesta 02	ELECTRIC STEERING	2.0 16v (06-08)	EPS
 Fiesta 02	ELECTRIC STEERING	ST 150 (06-08)	EPS
 Fiesta 02	ENGINE MANAGEME	1.2 Duratec 16v (02-06)	SIEMENS 3BMA
 Fiesta 02	ENGINE MANAGEME	1.2 Duratec 16v (06-08)	SIEMENS 3BMA
 Fiesta 02	ENGINE MANAGEME	1.3 (02-06)	EOBD
 Fiesta 02	ENGINE MANAGEME	1.3 (06-08)	EOBD
 Fiesta 02	ENGINE MANAGEME	1.4 Duratec 16v (02-06)	SIEMENS 3BMA
 Fiesta 02	ENGINE MANAGEME	1.4 Duratec 16v (06-08)	SIEMENS 3BMA
 Fiesta 02	ENGINE MANAGEME	1.4 Duratec 16v FXJA (02-06)	EOBD
 Fiesta 02	ENGINE MANAGEME	1.4 TDCi (02-06)	DELPHI
 Fiesta 02	ENGINE MANAGEME	1.4 TDCi (06-08)	DELPHI
 Fiesta 02	ENGINE MANAGEME	1.6 Duratec 16v (06-08)	EOBD
 Fiesta 02	ENGINE MANAGEME	1.6 Duratec 16v FYJA (02-06)	EOBD
 Fiesta 02	ENGINE MANAGEME	1.6 TDCi (02-06)	PCM Duratorque
 Fiesta 02	ENGINE MANAGEME	1.6 TDCi (06-08)	PCM Duratorque
 Fiesta 02	ENGINE MANAGEME	2.0 16v (02-06)	EOBD
 Fiesta 02	ENGINE MANAGEME	2.0 16v (06-08)	EOBD
 Fiesta 02	ENGINE MANAGEME	ST 150 (02-06)	EOBD
 Fiesta 02	ENGINE MANAGEME	ST 150 (06-08)	EOBD
 Fiesta 02	MAINTENANCE	1.6 TDCi (02-06)	PCM Duratorque
 Fiesta 02	MAINTENANCE	1.6 TDCi (06-08)	PCM Duratorque
 Fiesta 08	ABS	1.2 Duratec 16v (08-..)	ABS
 Fiesta 08	ABS	1.4 Duratec 16v (08-..)	ABS
 Fiesta 08	ABS	1.4 TDCi (08-..)	ABS
 Fiesta 08	ABS	1.6 Duratec 16v (08-..)	ABS
 Fiesta 08	ABS	1.6 TDCi (08-..)	ABS
 Fiesta 08	AIRBAG	1.2 Duratec 16v (08-..)	SRS
 Fiesta 08	AIRBAG	1.4 Duratec 16v (08-..)	SRS
 Fiesta 08	AIRBAG	1.4 TDCi (08-..)	SRS
 Fiesta 08	AIRBAG	1.6 Duratec 16v (08-..)	SRS
 Fiesta 08	AIRBAG	1.6 TDCi (08-..)	SRS
 Fiesta 08	AUTOM. TRANSMISSI	1.2 Duratec 16v (08-..)	TCM

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Fiesta 08	AUTOM. TRANSMISSI	1.4 Duratec 16v (08-..)	TCM
 Fiesta 08	AUTOM. TRANSMISSI	1.4 TDCi (08-..)	TCM
 Fiesta 08	AUTOM. TRANSMISSI	1.6 Duratec 16v (08-..)	TCM
 Fiesta 08	AUTOM. TRANSMISSI	1.6 TDCi (08-..)	TCM
 Fiesta 08	CHASSIS NETWORK	1.2 Duratec 16v (08-..)	BCM
 Fiesta 08	CHASSIS NETWORK	1.2 Duratec 16v (08-..)	SRM Speech Recognition Module
 Fiesta 08	CHASSIS NETWORK	1.4 Duratec 16v (08-..)	BCM
 Fiesta 08	CHASSIS NETWORK	1.4 Duratec 16v (08-..)	SRM Speech Recognition Module
 Fiesta 08	CHASSIS NETWORK	1.4 TDCi (08-..)	BCM
 Fiesta 08	CHASSIS NETWORK	1.4 TDCi (08-..)	SRM Speech Recognition Module
 Fiesta 08	CHASSIS NETWORK	1.6 Duratec 16v (08-..)	BCM
 Fiesta 08	CHASSIS NETWORK	1.6 Duratec 16v (08-..)	SRM Speech Recognition Module
 Fiesta 08	CHASSIS NETWORK	1.6 TDCi (08-..)	BCM
 Fiesta 08	CHASSIS NETWORK	1.6 TDCi (08-..)	SRM Speech Recognition Module
 Fiesta 08	CLIMA	1.2 Duratec 16v (08-..)	Clima
 Fiesta 08	CLIMA	1.4 Duratec 16v (08-..)	Clima
 Fiesta 08	CLIMA	1.4 TDCi (08-..)	Clima
 Fiesta 08	CLIMA	1.6 Duratec 16v (08-..)	Clima
 Fiesta 08	CLIMA	1.6 TDCi (08-..)	Clima
 Fiesta 08	DASHBOARD	1.2 Duratec 16v (08-..)	IPC
 Fiesta 08	DASHBOARD	1.4 Duratec 16v (08-..)	IPC
 Fiesta 08	DASHBOARD	1.4 TDCi (08-..)	IPC
 Fiesta 08	DASHBOARD	1.6 Duratec 16v (08-..)	IPC
 Fiesta 08	DASHBOARD	1.6 TDCi (08-..)	IPC
 Fiesta 08	ELECTRIC STEERING	1.2 Duratec 16v (08-..)	EPS
 Fiesta 08	ELECTRIC STEERING	1.4 Duratec 16v (08-..)	EPS
 Fiesta 08	ELECTRIC STEERING	1.4 TDCi (08-..)	EPS
 Fiesta 08	ELECTRIC STEERING	1.6 Duratec 16v (08-..)	EPS
 Fiesta 08	ELECTRIC STEERING	1.6 TDCi (08-..)	EPS
 Fiesta 08	ENGINE MANAGEME	1.2 Duratec 16v (08-..)	PCM
 Fiesta 08	ENGINE MANAGEME	1.4 Duratec 16v (08-..)	PCM
 Fiesta 08	ENGINE MANAGEME	1.4 TDCi F6JD (08-..)	PCM
 Fiesta 08	ENGINE MANAGEME	1.6 Duratec 16v (08-..)	EOBD
 Fiesta 08	ENGINE MANAGEME	1.6 TDCi (08-..)	EOBD
 Fiesta 08	MAINTENANCE	1.2 Duratec 16v (08-..)	MANUAL
 Fiesta 08	MAINTENANCE	1.4 Duratec 16v (08-..)	MANUAL
 Fiesta 08	MAINTENANCE	1.4 TDCi (08-..)	MANUAL
 Fiesta 08	MAINTENANCE	1.6 Duratec 16v (08-..)	MANUAL
 Fiesta 08	MAINTENANCE	1.6 TDCi (08-..)	MANUAL
 Fiesta 08	RADIO / CD	1.2 Duratec 16v (08-..)	ACM
 Fiesta 08	RADIO / CD	1.4 Duratec 16v (08-..)	ACM
 Fiesta 08	RADIO / CD	1.4 TDCi (08-..)	ACM
 Fiesta 08	RADIO / CD	1.6 Duratec 16v (08-..)	ACM
 Fiesta 08	RADIO / CD	1.6 TDCi (08-..)	ACM
 Fiesta 08	SERVICE LIGHT RES	1.2 Duratec 16v (08-..)	MANUAL
 Fiesta 08	SERVICE LIGHT RES	1.4 Duratec 16v (08-..)	MANUAL
 Fiesta 08	SERVICE LIGHT RES	1.4 TDCi (08-..)	MANUAL
 Fiesta 08	SERVICE LIGHT RES	1.6 Duratec 16v (08-..)	MANUAL
 Fiesta 08	SERVICE LIGHT RES	1.6 TDCi (08-..)	MANUAL
 Fiesta 08	VISUAL./TELEMATIC	1.2 Duratec 16v (08-..)	FCDIM Display Module
 Fiesta 08	VISUAL./TELEMATIC	1.4 Duratec 16v (08-..)	FCDIM Display Module
 Fiesta 08	VISUAL./TELEMATIC	1.4 TDCi (08-..)	FCDIM Display Module
 Fiesta 08	VISUAL./TELEMATIC	1.6 Duratec 16v (08-..)	FCDIM Display Module
 Fiesta 08	VISUAL./TELEMATIC	1.6 TDCi (08-..)	FCDIM Display Module
 Fiesta 13	ABS	1.0 (12-..)	ABS
 Fiesta 13	ABS	1.0 Ecoboost (12-..)	ABS
 Fiesta 13	ABS	1.2 8v (12-..)	ABS
 Fiesta 13	ABS	1.4 GPL (12-..)	ABS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Fiesta 13	ABS	1.5 TDCi (12-..)	ABS
 Fiesta 13	ABS	1.6 TDCi (12-..)	ABS
 Fiesta 13	CLIMA	1.0 (12-..)	Clima
 Fiesta 13	CLIMA	1.0 Ecoboost (12-..)	Clima
 Fiesta 13	CLIMA	1.2 8v (12-..)	Clima
 Fiesta 13	CLIMA	1.4 GPL (12-..)	Clima
 Fiesta 13	CLIMA	1.5 TDCi (12-..)	Clima
 Fiesta 13	CLIMA	1.6 TDCi (08-..)	Clima
 Fiesta 13	DASHBOARD	1.0 (12-..)	IPC
 Fiesta 13	DASHBOARD	1.0 Ecoboost (12-..)	IPC
 Fiesta 13	DASHBOARD	1.2 8v (12-..)	IPC
 Fiesta 13	DASHBOARD	1.4 GPL (12-..)	IPC
 Fiesta 13	DASHBOARD	1.5 TDCi (12-..)	IPC
 Fiesta 13	DASHBOARD	1.6 TDCi (08-..)	IPC
 Fiesta 13	ELECTRIC STEERING	1.0 (08-..)	EPS
 Fiesta 13	ELECTRIC STEERING	1.0 Ecoboost (08-..)	EPS
 Fiesta 13	ELECTRIC STEERING	1.2 8v (08-..)	EPS
 Fiesta 13	ELECTRIC STEERING	1.4 GPL (08-..)	EPS
 Fiesta 13	ELECTRIC STEERING	1.5 TDCi (08-..)	EPS
 Fiesta 13	ELECTRIC STEERING	1.6 TDCi (08-..)	EPS
 Fiesta 87	AIRBAG	1.0 (.-89)	FORD AirBag MANUAL
 Fiesta 87	AIRBAG	1.1 (.-89)	FORD AirBag MANUAL
 Fiesta 87	AIRBAG	1.3 (.-89)	FORD AirBag MANUAL
 Fiesta 87	AIRBAG	1.4 Kat (.-89)	FORD AirBag MANUAL
 Fiesta 87	AIRBAG	1.6 (.-89)	FORD AirBag MANUAL
 Fiesta 87	AIRBAG	1.6 D (.-89)	FORD AirBag MANUAL
 Fiesta 87	ENGINE MANAGEME	1.4 Kat F6A (.-89)	FORD CFI EEC-IV
 Fiesta 87	ENGINE MANAGEME	1.4 Kat F6C (.-89)	FORD CFI EEC-IV
 Fiesta 87	MAINTENANCE	1.0 (.-89)	FORD AirBag MANUAL
 Fiesta 87	MAINTENANCE	1.1 (.-89)	FORD AirBag MANUAL
 Fiesta 87	MAINTENANCE	1.3 (.-89)	FORD AirBag MANUAL
 Fiesta 87	MAINTENANCE	1.4 Kat (.-89)	FORD AirBag MANUAL
 Fiesta 87	MAINTENANCE	1.6 (.-89)	FORD AirBag MANUAL
 Fiesta 87	MAINTENANCE	1.6 D (.-89)	FORD AirBag MANUAL
 Fiesta 89	AIRBAG	1.0 (.-96)	FORD AirBag MANUAL
 Fiesta 89	AIRBAG	1.1 Kat (.-99)	FORD AirBag MANUAL
 Fiesta 89	AIRBAG	1.3 Kat (.-99)	FORD AirBag MANUAL
 Fiesta 89	AIRBAG	1.4 Kat (.-99)	FORD AirBag MANUAL
 Fiesta 89	AIRBAG	1.6 (.-99)	FORD AirBag MANUAL
 Fiesta 89	AIRBAG	1.6 16v (.-99)	FORD AirBag MANUAL
 Fiesta 89	AIRBAG	1.6 D (.-96)	FORD AirBag MANUAL
 Fiesta 89	AIRBAG	1.6 L1G-Kat (.-99)	FORD AirBag MANUAL
 Fiesta 89	AIRBAG	1.6 T (.-99)	FORD AirBag MANUAL
 Fiesta 89	AIRBAG	1.8 16v (.-99)	FORD AirBag MANUAL
 Fiesta 89	AIRBAG	1.8 Diesel (.-96)	FORD AirBag MANUAL
 Fiesta 89	AIRBAG	1.8 Kat (.-99)	FORD AirBag MANUAL
 Fiesta 89	AIRBAG	1.8 TD (.-96)	FORD AirBag MANUAL
 Fiesta 89	ENGINE MANAGEME	1.1 Kat G6A (.-96)	FORD CFI EEC-IV
 Fiesta 89	ENGINE MANAGEME	1.3 Kat J6B (.-96)	FORD CFI EEC-IV
 Fiesta 89	ENGINE MANAGEME	1.4 Kat F4A (94-96)	FORD CFI EEC-IV (Fast)
 Fiesta 89	ENGINE MANAGEME	1.4 Kat F6E (.-96)	FORD CFI EEC-IV
 Fiesta 89	ENGINE MANAGEME	1.6 16v L1G (.-96)	FORD SEFI EEC-IV
 Fiesta 89	ENGINE MANAGEME	1.6 L1G-Kat (.-96)	FORD EFI EEC-IV
 Fiesta 89	ENGINE MANAGEME	1.6 L1G-Kat (94-96)	FORD CFI EEC-IV (Fast)
 Fiesta 89	ENGINE MANAGEME	1.6 LJC (.-96)	FORD EFI EEC-IV
 Fiesta 89	ENGINE MANAGEME	1.6 T LHA (.-96)	FORD EFI EEC-IV
 Fiesta 89	ENGINE MANAGEME	1.8 16v RDB (.-96)	FORD SEFI EEC-IV
 Fiesta 89	ENGINE MANAGEME	1.8 16v RQC (.-96)	FORD SEFI EEC-IV

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Fiesta 89	ENGINE MANAGEME	1.8 Kat RDB (91-96)	FORD CFI EEC-IV (Fast)
 Fiesta 89	ENGINE MANAGEME	1.8 Kat RQC (91-96)	FORD CFI EEC-IV (Fast)
 Fiesta 89	KEY ENCODE	1.0 (94-96)	FORD PATS MANUAL
 Fiesta 89	KEY ENCODE	1.1 Kat (94-96)	FORD PATS MANUAL
 Fiesta 89	KEY ENCODE	1.3 Kat (94-96)	FORD PATS MANUAL
 Fiesta 89	KEY ENCODE	1.4 Kat (94-96)	FORD PATS MANUAL
 Fiesta 89	KEY ENCODE	1.6 (94-96)	FORD PATS MANUAL
 Fiesta 89	KEY ENCODE	1.6 16v (94-96)	FORD PATS MANUAL
 Fiesta 89	KEY ENCODE	1.6 L1G-Kat (94-96)	FORD PATS MANUAL
 Fiesta 89	KEY ENCODE	1.6 T (94-96)	FORD PATS MANUAL
 Fiesta 89	KEY ENCODE	1.8 16v (94-96)	FORD PATS MANUAL
 Fiesta 89	KEY ENCODE	1.8 Diesel (94-96)	FORD PATS MANUAL
 Fiesta 89	KEY ENCODE	1.8 Kat (94-96)	FORD PATS MANUAL
 Fiesta 89	KEY ENCODE	1.8 TD (94-96)	FORD PATS MANUAL
 Fiesta 89	MAINTENANCE	1.0 (...96)	FORD AirBag MANUAL
 Fiesta 89	MAINTENANCE	1.0 (94-96)	FORD PATS MANUAL
 Fiesta 89	MAINTENANCE	1.1 Kat (...99)	FORD AirBag MANUAL
 Fiesta 89	MAINTENANCE	1.1 Kat (94-96)	FORD PATS MANUAL
 Fiesta 89	MAINTENANCE	1.3 Kat (...99)	FORD AirBag MANUAL
 Fiesta 89	MAINTENANCE	1.3 Kat (94-96)	FORD PATS MANUAL
 Fiesta 89	MAINTENANCE	1.4 Kat (...99)	FORD AirBag MANUAL
 Fiesta 89	MAINTENANCE	1.4 Kat (94-96)	FORD PATS MANUAL
 Fiesta 89	MAINTENANCE	1.6 (...99)	FORD AirBag MANUAL
 Fiesta 89	MAINTENANCE	1.6 (94-96)	FORD PATS MANUAL
 Fiesta 89	MAINTENANCE	1.6 16v (...99)	FORD AirBag MANUAL
 Fiesta 89	MAINTENANCE	1.6 16v (94-96)	FORD PATS MANUAL
 Fiesta 89	MAINTENANCE	1.6 D (...96)	FORD AirBag MANUAL
 Fiesta 89	MAINTENANCE	1.6 L1G-Kat (...99)	FORD AirBag MANUAL
 Fiesta 89	MAINTENANCE	1.6 L1G-Kat (94-96)	FORD PATS MANUAL
 Fiesta 89	MAINTENANCE	1.6 T (...99)	FORD AirBag MANUAL
 Fiesta 89	MAINTENANCE	1.6 T (94-96)	FORD PATS MANUAL
 Fiesta 89	MAINTENANCE	1.8 16v (...99)	FORD AirBag MANUAL
 Fiesta 89	MAINTENANCE	1.8 16v (94-96)	FORD PATS MANUAL
 Fiesta 89	MAINTENANCE	1.8 Diesel (...96)	FORD AirBag MANUAL
 Fiesta 89	MAINTENANCE	1.8 Diesel (94-96)	FORD PATS MANUAL
 Fiesta 89	MAINTENANCE	1.8 Kat (...99)	FORD AirBag MANUAL
 Fiesta 89	MAINTENANCE	1.8 Kat (94-96)	FORD PATS MANUAL
 Fiesta 89	MAINTENANCE	1.8 TD (...96)	FORD AirBag MANUAL
 Fiesta 89	MAINTENANCE	1.8 TD (94-96)	FORD PATS MANUAL
 Fiesta 96	ABS + TRACT. CONT	1.0	ATE Teves Mk20-I
 Fiesta 96	ABS + TRACT. CONT	1.1	ATE Teves Mk20-I
 Fiesta 96	ABS + TRACT. CONT	1.2	ATE Teves Mk20-I
 Fiesta 96	ABS + TRACT. CONT	1.3	ATE Teves Mk20-I
 Fiesta 96	ABS + TRACT. CONT	1.4	ATE Teves Mk20-I
 Fiesta 96	ABS + TRACT. CONT	1.6	ATE Teves Mk20-I
 Fiesta 96	ABS + TRACT. CONT	1.8 Diesel	ATE Teves Mk20-I
 Fiesta 96	ABS + TRACT. CONT	1.8 TDDi	ATE Teves Mk20-I
 Fiesta 96	AIRBAG	1.0 (...99)	FORD AirBag MANUAL
 Fiesta 96	AIRBAG	1.0 (00-..)	BOSCH AirBag SRS
 Fiesta 96	AIRBAG	1.1 (...99)	FORD AirBag MANUAL
 Fiesta 96	AIRBAG	1.1 (00-..)	BOSCH AirBag SRS
 Fiesta 96	AIRBAG	1.2 (...99)	FORD AirBag MANUAL
 Fiesta 96	AIRBAG	1.2 (00-..)	BOSCH AirBag SRS
 Fiesta 96	AIRBAG	1.3 (...99)	FORD AirBag MANUAL
 Fiesta 96	AIRBAG	1.3 (00-..)	BOSCH AirBag SRS
 Fiesta 96	AIRBAG	1.4 (...99)	FORD AirBag MANUAL
 Fiesta 96	AIRBAG	1.4 (00-..)	BOSCH AirBag SRS
 Fiesta 96	AIRBAG	1.6 (...99)	FORD AirBag MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Fiesta 96	AIRBAG	1.6 (00-..)	BOSCH AirBag SRS
 Fiesta 96	AIRBAG	1.8 Diesel (...99)	FORD AirBag MANUAL
 Fiesta 96	AIRBAG	1.8 Diesel (00-..)	BOSCH AirBag SRS
 Fiesta 96	AIRBAG	1.8 TDDi (...99)	FORD AirBag MANUAL
 Fiesta 96	AIRBAG	1.8 TDDi (00-..)	BOSCH AirBag SRS
 Fiesta 96	ENGINE MANAGEME	1.0 (96-..)	FORD SEFI EEC-V
 Fiesta 96	ENGINE MANAGEME	1.2 DHA (95-..)	FORD SEFI EEC-V
 Fiesta 96	ENGINE MANAGEME	1.2 DHB (95-..)	FORD SEFI EEC-V
 Fiesta 96	ENGINE MANAGEME	1.2 DHC (99-..)	FORD SEFI EEC-V
 Fiesta 96	ENGINE MANAGEME	1.3 J4C (95-..)	FORD SEFI EEC-V
 Fiesta 96	ENGINE MANAGEME	1.3 JJA (95-..)	FORD SEFI EEC-V
 Fiesta 96	ENGINE MANAGEME	1.4 FHA (95-..)	FORD SEFI EEC-V
 Fiesta 96	ENGINE MANAGEME	1.6 (97-..)	FORD SEFI EEC-V
 Fiesta 96	ENGINE MANAGEME	1.8 TDDi RTN	FORD Diesel - Endura-Di EEC-V
 Fiesta 96	ENGINE MANAGEME	1.8 TDDi RTP	FORD Diesel - Endura-Di EEC-V
 Fiesta 96	ENGINE MANAGEME	1.8 TDDi RTQ	FORD Diesel - Endura-Di EEC-V
 Fiesta 96	KEY ENCODE	1.0 (97-..)	FORD PATS MANUAL
 Fiesta 96	KEY ENCODE	1.1 (97-..)	FORD PATS MANUAL
 Fiesta 96	KEY ENCODE	1.2 (97-..)	FORD PATS MANUAL
 Fiesta 96	KEY ENCODE	1.3 (97-..)	FORD PATS MANUAL
 Fiesta 96	KEY ENCODE	1.4 (97-..)	FORD PATS MANUAL
 Fiesta 96	KEY ENCODE	1.6 (97-..)	FORD PATS MANUAL
 Fiesta 96	KEY ENCODE	1.8 Diesel (97-..)	FORD PATS MANUAL
 Fiesta 96	KEY ENCODE	1.8 TDDi (97-..)	FORD PATS MANUAL
 Fiesta 96	MAINTENANCE	1.0 (...99)	FORD AirBag MANUAL
 Fiesta 96	MAINTENANCE	1.0 (97-..)	FORD PATS MANUAL
 Fiesta 96	MAINTENANCE	1.1 (...99)	FORD AirBag MANUAL
 Fiesta 96	MAINTENANCE	1.1 (97-..)	FORD PATS MANUAL
 Fiesta 96	MAINTENANCE	1.2 (...99)	FORD AirBag MANUAL
 Fiesta 96	MAINTENANCE	1.2 (97-..)	FORD PATS MANUAL
 Fiesta 96	MAINTENANCE	1.3 (...99)	FORD AirBag MANUAL
 Fiesta 96	MAINTENANCE	1.3 (97-..)	FORD PATS MANUAL
 Fiesta 96	MAINTENANCE	1.4 (...99)	FORD AirBag MANUAL
 Fiesta 96	MAINTENANCE	1.4 (97-..)	FORD PATS MANUAL
 Fiesta 96	MAINTENANCE	1.6 (...99)	FORD AirBag MANUAL
 Fiesta 96	MAINTENANCE	1.6 (97-..)	FORD PATS MANUAL
 Fiesta 96	MAINTENANCE	1.8 Diesel (...99)	FORD AirBag MANUAL
 Fiesta 96	MAINTENANCE	1.8 Diesel (97-..)	FORD PATS MANUAL
 Fiesta 96	MAINTENANCE	1.8 TDDi (...99)	FORD AirBag MANUAL
 Fiesta 96	MAINTENANCE	1.8 TDDi (97-..)	FORD PATS MANUAL
 Focus 04	ABS + TRACT. CONT	1.4	ATE ABS/ESP Mkxx
 Focus 04	ABS + TRACT. CONT	1.6 TDCi 110cv	ATE ABS/ESP Mkxx
 Focus 04	ABS + TRACT. CONT	1.6 TDCi 90cv	ATE ABS/ESP Mkxx
 Focus 04	ABS + TRACT. CONT	1.6 Ti-VCT 115cv	ATE ABS/ESP Mkxx
 Focus 04	ABS + TRACT. CONT	1.8	ATE ABS/ESP Mkxx
 Focus 04	ABS + TRACT. CONT	1.8 TDCi 115cv	ATE ABS/ESP Mkxx
 Focus 04	ABS + TRACT. CONT	2.0 TDCi 136cv	ATE ABS/ESP Mkxx
 Focus 04	ABS + TRACT. CONT	2.0 TDCi 136cv	ATE-FAP ABS/ESP Mkxx
 Focus 04	ABS + TRACT. CONT	2.0 Ti-VCT 145cv	ATE ABS/ESP Mkxx
 Focus 04	ABS + TRACT. CONT	2.5 VCT Turbo	ATE ABS/ESP Mkxx
 Focus 04	AIRBAG	1.4	BOSCH RCM
 Focus 04	AIRBAG	1.6 TDCi 110cv	BOSCH RCM
 Focus 04	AIRBAG	1.6 TDCi 90cv	BOSCH RCM
 Focus 04	AIRBAG	1.6 Ti-VCT 115cv	BOSCH RCM
 Focus 04	AIRBAG	1.8 TDCi 115cv	BOSCH RCM
Focus 04	AIRBAG	2.0 TDCi 136cv	BOSCH RCM
Focus 04	AIRBAG	2.0 TDCi 136cv	BOSCH-FAP RCM
Focus 04	AIRBAG	2.0 Ti-VCT 145cv	BOSCH RCM

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Focus 04	AIRBAG	2.5 VCT Turbo	BOSCH RCM
 Focus 04	CHASSIS NETWORK	1.4	GEM
 Focus 04	CHASSIS NETWORK	1.6 TDCi 110cv	GEM
 Focus 04	CHASSIS NETWORK	1.6 TDCi 90cv	GEM
 Focus 04	CHASSIS NETWORK	1.6 Ti-VCT 115cv	GEM
 Focus 04	CHASSIS NETWORK	1.8	GEM
 Focus 04	CHASSIS NETWORK	1.8 TDCi 115cv	GEM
 Focus 04	CHASSIS NETWORK	2.0 TDCi 136cv	FAP GEM
 Focus 04	CHASSIS NETWORK	2.0 TDCi 136cv	GEM
 Focus 04	CHASSIS NETWORK	2.0 Ti-VCT 145cv	GEM
 Focus 04	CHASSIS NETWORK	2.5 VCT Turbo	GEM
 Focus 04	CLIMA	1.4	EATC
 Focus 04	CLIMA	1.6 TDCi 110cv	EATC
 Focus 04	CLIMA	1.6 TDCi 90cv	EATC
 Focus 04	CLIMA	1.6 Ti-VCT 115cv	EATC
 Focus 04	CLIMA	1.8	EATC
 Focus 04	CLIMA	1.8 TDCi 115cv	EATC
 Focus 04	CLIMA	2.0 TDCi 136cv	EATC
 Focus 04	CLIMA	2.0 TDCi 136cv	FAP EATC
 Focus 04	CLIMA	2.0 Ti-VCT 145cv	EATC
 Focus 04	CLIMA	2.5 VCT Turbo	EATC
 Focus 04	DASHBOARD	1.4	IC
 Focus 04	DASHBOARD	1.6 TDCi 110cv	IC
 Focus 04	DASHBOARD	1.6 TDCi 90cv	IC
 Focus 04	DASHBOARD	1.6 Ti-VCT 115cv	IC
 Focus 04	DASHBOARD	1.8	IC
 Focus 04	DASHBOARD	1.8 TDCi 115cv	IC
 Focus 04	DASHBOARD	2.0 TDCi 136cv	FAP IC
 Focus 04	DASHBOARD	2.0 TDCi 136cv	IC
 Focus 04	DASHBOARD	2.0 Ti-VCT 145cv	IC
 Focus 04	DASHBOARD	2.5 VCT Turbo	IC
 Focus 04	ELECTRIC STEERING	1.4	EPS
 Focus 04	ELECTRIC STEERING	1.6 TDCi 110cv	EPS
 Focus 04	ELECTRIC STEERING	1.6 TDCi 90cv	EPS
 Focus 04	ELECTRIC STEERING	1.6 Ti-VCT 115cv	EPS
 Focus 04	ELECTRIC STEERING	1.8	EPS
 Focus 04	ELECTRIC STEERING	1.8 TDCi 115cv	EPS
 Focus 04	ELECTRIC STEERING	2.0 TDCi 136cv	EPS
 Focus 04	ELECTRIC STEERING	2.0 TDCi 136cv	FAP EPS
 Focus 04	ELECTRIC STEERING	2.0 Ti-VCT 145cv	EPS
 Focus 04	ELECTRIC STEERING	2.5 VCT Turbo	EPS
 Focus 04	ENGINE MANAGEME	1.4	EOBD
 Focus 04	ENGINE MANAGEME	1.4 (04-..)	PCM
 Focus 04	ENGINE MANAGEME	1.6 TDCi 110cv	EOBD
 Focus 04	ENGINE MANAGEME	1.6 TDCi 90cv HHDA	PCM Duratorq
 Focus 04	ENGINE MANAGEME	1.8	EOBD
 Focus 04	ENGINE MANAGEME	1.8 TDCi 115cv	PCM Duratorq
 Focus 04	ENGINE MANAGEME	2.0 TDCi 136cv	PCM Duratorq + DPF
 Focus 04	ENGINE MANAGEME	2.0 TDCi 136cv DA3	PCM Duratorq
 Focus 04	ENGINE MANAGEME	2.0 TDCi 136cv FAP	EOBD
 Focus 04	ENGINE MANAGEME	2.0 Ti-VCT 145cv	PCM Duratec
 Focus 04	ENGINE MANAGEME	2.5 VCT Turbo	EOBD
 Focus 04	MAINTENANCE	1.4	ATE ABS/ESP Mkxx
 Focus 04	MAINTENANCE	1.4	ATE ABS/ESP Mkxx
 Focus 04	MAINTENANCE	1.6 TDCi 110cv	ATE ABS/ESP Mkxx
 Focus 04	MAINTENANCE	1.6 TDCi 110cv	ATE ABS/ESP Mkxx
 Focus 04	MAINTENANCE	1.6 TDCi 90cv	ATE ABS/ESP Mkxx
 Focus 04	MAINTENANCE	1.6 TDCi 90cv	ATE ABS/ESP Mkxx

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Focus 04	MAINTENANCE	1.6 TDCi 90cv HHDA	PCM Duratorq
 Focus 04	MAINTENANCE	1.6 Ti-VCT 115cv	ATE ABS/ESP Mkxx
 Focus 04	MAINTENANCE	1.6 Ti-VCT 115cv	ATE ABS/ESP Mkxx
 Focus 04	MAINTENANCE	1.8	ATE ABS/ESP Mkxx
 Focus 04	MAINTENANCE	1.8	ATE ABS/ESP Mkxx
 Focus 04	MAINTENANCE	1.8 TDCi 115cv	ATE ABS/ESP Mkxx
 Focus 04	MAINTENANCE	1.8 TDCi 115cv	ATE ABS/ESP Mkxx
 Focus 04	MAINTENANCE	2.0 TDCi 136cv	ATE ABS/ESP Mkxx
 Focus 04	MAINTENANCE	2.0 TDCi 136cv	ATE ABS/ESP Mkxx
 Focus 04	MAINTENANCE	2.0 TDCi 136cv	ATE-FAP ABS/ESP Mkxx
 Focus 04	MAINTENANCE	2.0 TDCi 136cv	ATE-FAP ABS/ESP Mkxx
 Focus 04	MAINTENANCE	2.0 Ti-VCT 145cv	ATE ABS/ESP Mkxx
 Focus 04	MAINTENANCE	2.0 Ti-VCT 145cv	ATE ABS/ESP Mkxx
 Focus 04	MAINTENANCE	2.5 VCT Turbo	ATE ABS/ESP Mkxx
 Focus 04	MAINTENANCE	2.5 VCT Turbo	ATE ABS/ESP Mkxx
 Focus 07	ABS + TRACT. CONT	1.6 i 16v	ATE ABS/ESP Mkxx
 Focus 07	ABS + TRACT. CONT	1.6 TDCi 110cv	ATE ABS/ESP Mkxx
 Focus 07	ABS + TRACT. CONT	1.6 TDCi 90cv	ATE ABS/ESP Mkxx
 Focus 07	ABS + TRACT. CONT	1.6 Ti-VCT 115cv	ATE ABS/ESP Mkxx
 Focus 07	ABS + TRACT. CONT	1.8 Flexyfuel 125cv	ATE ABS/ESP Mkxx
 Focus 07	ABS + TRACT. CONT	1.8 TDCi 115cv	ATE ABS/ESP Mkxx
 Focus 07	ABS + TRACT. CONT	2.0 TDCi 136cv	ATE ABS/ESP Mkxx
 Focus 07	ABS + TRACT. CONT	2.0 Ti-VCT 145cv	ATE ABS/ESP Mkxx
 Focus 07	ABS + TRACT. CONT	2.5 VCT Turbo	ATE ABS/ESP Mkxx
 Focus 07	AIRBAG	1.6 i 16v	RCM
 Focus 07	AIRBAG	1.6 TDCi 110cv	RCM
 Focus 07	AIRBAG	1.6 TDCi 90cv	RCM
 Focus 07	AIRBAG	1.6 Ti-VCT 115cv	RCM
 Focus 07	AIRBAG	1.8 Flexyfuel 125cv	RCM
 Focus 07	AIRBAG	1.8 TDCi 115cv	RCM
 Focus 07	AIRBAG	2.0 TDCi 136cv	RCM
 Focus 07	AIRBAG	2.0 Ti-VCT 145cv	RCM
 Focus 07	AIRBAG	2.5 VCT Turbo	RCM
 Focus 07	CHASSIS NETWORK	1.6 i 16v	GEM
 Focus 07	CHASSIS NETWORK	1.6 TDCi 110cv	GEM
 Focus 07	CHASSIS NETWORK	1.6 TDCi 90cv	GEM
 Focus 07	CHASSIS NETWORK	1.6 Ti-VCT 115cv	GEM
 Focus 07	CHASSIS NETWORK	1.8 Flexyfuel 125cv	GEM
 Focus 07	CHASSIS NETWORK	1.8 TDCi 115cv	GEM
 Focus 07	CHASSIS NETWORK	2.0 TDCi 136cv	GEM
 Focus 07	CHASSIS NETWORK	2.0 Ti-VCT 145cv	GEM
 Focus 07	CHASSIS NETWORK	2.5 VCT Turbo	GEM
 Focus 07	CLIMA	1.6 i 16v	EATC
 Focus 07	CLIMA	1.6 TDCi 110cv	EATC
 Focus 07	CLIMA	1.6 TDCi 90cv	EATC
 Focus 07	CLIMA	1.6 Ti-VCT 115cv	EATC
 Focus 07	CLIMA	1.8 Flexyfuel 125cv	EATC
 Focus 07	CLIMA	1.8 TDCi 115cv	EATC
 Focus 07	CLIMA	2.0 TDCi 136cv	EATC
 Focus 07	CLIMA	2.0 Ti-VCT 145cv	EATC
 Focus 07	CLIMA	2.5 VCT Turbo	EATC
 Focus 07	DASHBOARD	1.6 i 16v	IC
 Focus 07	DASHBOARD	1.6 TDCi 110cv	IC
 Focus 07	DASHBOARD	1.6 TDCi 90cv	IC
 Focus 07	DASHBOARD	1.6 Ti-VCT 115cv	IC
 Focus 07	DASHBOARD	1.8 Flexyfuel 125cv	IC
 Focus 07	DASHBOARD	1.8 TDCi 115cv	IC
 Focus 07	DASHBOARD	2.0 TDCi 136cv	IC

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Focus 07	DASHBOARD	2.0 Ti-VCT 145cv	IC
 Focus 07	DASHBOARD	2.5 VCT Turbo	IC
 Focus 07	ELECTRIC STEERING	1.6 i 16v	EPS
 Focus 07	ELECTRIC STEERING	1.6 TDCi 110cv	EPS
 Focus 07	ELECTRIC STEERING	1.6 TDCi 90cv	EPS
 Focus 07	ELECTRIC STEERING	1.6 Ti-VCT 115cv	EPS
 Focus 07	ELECTRIC STEERING	1.8 Flexyfuel 125cv	EPS
 Focus 07	ELECTRIC STEERING	1.8 TDCi 115cv	EPS
 Focus 07	ELECTRIC STEERING	2.0 TDCi 136cv	EPS
 Focus 07	ELECTRIC STEERING	2.0 Ti-VCT 145cv	EPS
 Focus 07	ELECTRIC STEERING	2.5 VCT Turbo	EPS
 Focus 07	ENGINE MANAGEME	1.6 TDCi 110cv G8DB	PCM Duratorq (D.P.F.)
 Focus 07	ENGINE MANAGEME	1.6 TDCi 90cv HHDA	PCM Duratorq
 Focus 07	ENGINE MANAGEME	1.6 Ti-VCT 115cv	EOBD
 Focus 07	ENGINE MANAGEME	1.8 Flexyfuel 125cv	EOBD
 Focus 07	ENGINE MANAGEME	1.8 TDCi 115cv	EOBD
 Focus 07	ENGINE MANAGEME	2.0 TDCi 136cv (07-..)	Common Rail PCM
 Focus 07	ENGINE MANAGEME	2.0 TDCi 136cv (08-..)	Common Rail PCM
 Focus 07	ENGINE MANAGEME	2.0 Ti-VCT 145cv	EOBD
 Focus 07	ENGINE MANAGEME	2.5 VCT Turbo	EOBD
 Focus 07	MAINTENANCE	1.6 i 16v	ATE ABS/ESP Mkxx
 Focus 07	MAINTENANCE	1.6 i 16v	ATE ABS/ESP Mkxx
 Focus 07	MAINTENANCE	1.6 i 16v	MANUAL
 Focus 07	MAINTENANCE	1.6 TDCi 110cv	ATE ABS/ESP Mkxx
 Focus 07	MAINTENANCE	1.6 TDCi 110cv	ATE ABS/ESP Mkxx
 Focus 07	MAINTENANCE	1.6 TDCi 110cv	MANUAL
 Focus 07	MAINTENANCE	1.6 TDCi 90cv	ATE ABS/ESP Mkxx
 Focus 07	MAINTENANCE	1.6 TDCi 90cv	ATE ABS/ESP Mkxx
 Focus 07	MAINTENANCE	1.6 TDCi 90cv	MANUAL
 Focus 07	MAINTENANCE	1.6 TDCi 90cv HHDA	PCM Duratorq
 Focus 07	MAINTENANCE	1.6 Ti-VCT 115cv	ATE ABS/ESP Mkxx
 Focus 07	MAINTENANCE	1.6 Ti-VCT 115cv	ATE ABS/ESP Mkxx
 Focus 07	MAINTENANCE	1.6 Ti-VCT 115cv	MANUAL
 Focus 07	MAINTENANCE	1.8 Flexyfuel 125cv	ATE ABS/ESP Mkxx
 Focus 07	MAINTENANCE	1.8 Flexyfuel 125cv	ATE ABS/ESP Mkxx
 Focus 07	MAINTENANCE	1.8 Flexyfuel 125cv	MANUAL
 Focus 07	MAINTENANCE	1.8 TDCi 115cv	ATE ABS/ESP Mkxx
 Focus 07	MAINTENANCE	1.8 TDCi 115cv	ATE ABS/ESP Mkxx
 Focus 07	MAINTENANCE	1.8 TDCi 115cv	MANUAL
 Focus 07	MAINTENANCE	2.0 TDCi 136cv	ATE ABS/ESP Mkxx
 Focus 07	MAINTENANCE	2.0 TDCi 136cv	ATE ABS/ESP Mkxx
 Focus 07	MAINTENANCE	2.0 TDCi 136cv	MANUAL
 Focus 07	MAINTENANCE	2.0 Ti-VCT 145cv	ATE ABS/ESP Mkxx
 Focus 07	MAINTENANCE	2.0 Ti-VCT 145cv	ATE ABS/ESP Mkxx
 Focus 07	MAINTENANCE	2.0 Ti-VCT 145cv	MANUAL
 Focus 07	MAINTENANCE	2.5 VCT Turbo	ATE ABS/ESP Mkxx
 Focus 07	MAINTENANCE	2.5 VCT Turbo	ATE ABS/ESP Mkxx
 Focus 07	MAINTENANCE	2.5 VCT Turbo	MANUAL
 Focus 07	REAR CAM	1.6 i 16v	CMR
 Focus 07	REAR CAM	1.6 TDCi 110cv	CMR
 Focus 07	REAR CAM	1.6 TDCi 90cv	CMR
 Focus 07	REAR CAM	1.6 Ti-VCT 115cv	CMR
 Focus 07	REAR CAM	1.8 Flexyfuel 125cv	CMR
 Focus 07	REAR CAM	1.8 TDCi 115cv	CMR
 Focus 07	REAR CAM	2.0 TDCi 136cv	CMR
 Focus 07	REAR CAM	2.0 Ti-VCT 145cv	CMR
 Focus 07	REAR CAM	2.5 VCT Turbo	CMR
 Focus 07	SERVICE LIGHT RES	1.6 i 16v	MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Focus 07	SERVICE LIGHT RES	1.6 TDCi 110cv	MANUAL
 Focus 07	SERVICE LIGHT RES	1.6 TDCi 90cv	MANUAL
 Focus 07	SERVICE LIGHT RES	1.6 Ti-VCT 115cv	MANUAL
 Focus 07	SERVICE LIGHT RES	1.8 Flexyfuel 125cv	MANUAL
 Focus 07	SERVICE LIGHT RES	1.8 TDCi 115cv	MANUAL
 Focus 07	SERVICE LIGHT RES	2.0 TDCi 136cv	MANUAL
 Focus 07	SERVICE LIGHT RES	2.0 Ti-VCT 145cv	MANUAL
 Focus 07	SERVICE LIGHT RES	2.5 VCT Turbo	MANUAL
 Focus	ABS + TRACT. CONT	1.4 16v (99-..)	BOSCH ABS/TCS+EBD 5
 Focus	ABS + TRACT. CONT	1.6 16v (99-..)	BOSCH ABS/TCS+EBD 5
 Focus	ABS + TRACT. CONT	1.8 16v (99-..)	BOSCH ABS/TCS+EBD 5
 Focus	ABS + TRACT. CONT	1.8 TDCi (99-..)	BOSCH ABS/TCS+EBD 5
 Focus	ABS + TRACT. CONT	1.8 TDDi (99-..)	BOSCH ABS/TCS+EBD 5
 Focus	ABS + TRACT. CONT	2.0 16v (99-..)	BOSCH ABS/TCS+EBD 5
 Focus	ABS + TRACT. CONT	RS (99-..)	BOSCH ABS/TCS+EBD 5
 Focus	ABS + TRACT. CONT	ST 170 (99-..)	BOSCH ABS/TCS+EBD 5
 Focus	AIRBAG	1.4 16v (..-98)	FORD AirBag MANUAL
 Focus	AIRBAG	1.4 16v (01-04)	BOSCH AirBag SRS
 Focus	AIRBAG	1.4 16v (99-01)	BOSCH AirBag SRS
 Focus	AIRBAG	1.6 16v (..-98)	FORD AirBag MANUAL
 Focus	AIRBAG	1.6 16v (01-04)	BOSCH AirBag SRS
 Focus	AIRBAG	1.6 16v (99-01)	BOSCH AirBag SRS
 Focus	AIRBAG	1.8 16v (..-98)	FORD AirBag MANUAL
 Focus	AIRBAG	1.8 16v (01-04)	BOSCH AirBag SRS
 Focus	AIRBAG	1.8 16v (99-01)	BOSCH AirBag SRS
 Focus	AIRBAG	1.8 TDCi (..-98)	FORD AirBag MANUAL
 Focus	AIRBAG	1.8 TDCi (01-04)	BOSCH AirBag SRS
 Focus	AIRBAG	1.8 TDCi (99-01)	BOSCH AirBag SRS
 Focus	AIRBAG	1.8 TDDi (..-98)	FORD AirBag MANUAL
 Focus	AIRBAG	1.8 TDDi (01-04)	BOSCH AirBag SRS
 Focus	AIRBAG	1.8 TDDi (99-01)	BOSCH AirBag SRS
 Focus	AIRBAG	2.0 16v (..-98)	FORD AirBag MANUAL
 Focus	AIRBAG	2.0 16v (01-04)	BOSCH AirBag SRS
 Focus	AIRBAG	2.0 16v (99-01)	BOSCH AirBag SRS
 Focus	AIRBAG	RS (..-98)	FORD AirBag MANUAL
 Focus	AIRBAG	RS (01-04)	BOSCH AirBag SRS
 Focus	AIRBAG	RS (99-01)	BOSCH AirBag SRS
 Focus	AIRBAG	ST 170 (..-98)	FORD AirBag MANUAL
 Focus	AIRBAG	ST 170 (01-04)	BOSCH AirBag SRS
 Focus	AIRBAG	ST 170 (99-01)	BOSCH AirBag SRS
 Focus	CRUISE CONTROL	2.0 16v	FORD IC
 Focus	CRUISE CONTROL	RS	FORD IC
 Focus	CRUISE CONTROL	ST 170	FORD IC
 Focus	DASHBOARD	1.6 16v FYDD	FORD IC
 Focus	DASHBOARD	1.8 16v	FORD IC
 Focus	DASHBOARD	1.8 TDCi F9DA	FORD IC
 Focus	DASHBOARD	1.8 TDDi BHDB	FORD IC
 Focus	DASHBOARD	1.8 TDDi C9DA	FORD IC
 Focus	DASHBOARD	1.8 TDDi C9DB	FORD IC
 Focus	DASHBOARD	1.8 TDDi C9DC	FORD IC
 Focus	ELECTRONIC INJECT	1.6 16v FYDA	FORD SEFI EEC-V
 Focus	ENGINE MANAGEME	1.4 16v (01-..)	FORD SEFI EEC-V
 Focus	ENGINE MANAGEME	1.6 16v FYDD (01-..)	EOBD
 Focus	ENGINE MANAGEME	1.6 16v FYDD (01-..)	FORD SEFI EEC-V
 Focus	ENGINE MANAGEME	1.8 16v FYDD (01-..)	EOBD
 Focus	ENGINE MANAGEME	1.8 16v FYDD (01-..)	FORD SEFI EEC-V
 Focus	ENGINE MANAGEME	1.8 TDCi F9DA	FORD DELPHI Common Rail-Endura-Ci
 Focus	ENGINE MANAGEME	1.8 TDDi BHDB	FORD Diesel - Endura-Di EEC-V

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Focus	ENGINE MANAGEME	1.8 TDDi C9DA	FORD Diesel - Endura-Di EEC-V
 Focus	ENGINE MANAGEME	1.8 TDDi C9DB	FORD Diesel - Endura-Di EEC-V
 Focus	ENGINE MANAGEME	1.8 TDDi C9DC	FORD Diesel - Endura-Di EEC-V
 Focus	ENGINE MANAGEME	2.0 16v (01-..)	EOBD
 Focus	ENGINE MANAGEME	2.0 16v (01-..)	FORD SEFI EEC-V
 Focus	ENGINE MANAGEME	RS (01-..)	EOBD
 Focus	ENGINE MANAGEME	ST 170 (01-..)	EOBD
 Focus	KEY ENCODE	1.4 16v	FORD PATS MANUAL
 Focus	KEY ENCODE	1.6 16v	FORD PATS MANUAL
 Focus	KEY ENCODE	1.8 16v	FORD PATS MANUAL
 Focus	KEY ENCODE	1.8 TDCi	FORD PATS MANUAL
 Focus	KEY ENCODE	1.8 TDDi	FORD PATS MANUAL
 Focus	KEY ENCODE	2.0 16v	FORD PATS MANUAL
 Focus	KEY ENCODE	RS	FORD PATS MANUAL
 Focus	KEY ENCODE	ST 170	FORD PATS MANUAL
 Focus	MAINTENANCE	1.4 16v	FORD PATS MANUAL
 Focus	MAINTENANCE	1.4 16v (...98)	FORD AirBag MANUAL
 Focus	MAINTENANCE	1.6 16v	FORD PATS MANUAL
 Focus	MAINTENANCE	1.6 16v (...98)	FORD AirBag MANUAL
 Focus	MAINTENANCE	1.8 16v	FORD PATS MANUAL
 Focus	MAINTENANCE	1.8 16v (...98)	FORD AirBag MANUAL
 Focus	MAINTENANCE	1.8 TDCi	FORD PATS MANUAL
 Focus	MAINTENANCE	1.8 TDCi (...98)	FORD AirBag MANUAL
 Focus	MAINTENANCE	1.8 TDDi	FORD PATS MANUAL
 Focus	MAINTENANCE	1.8 TDDi (...98)	FORD AirBag MANUAL
 Focus	MAINTENANCE	2.0 16v	FORD PATS MANUAL
 Focus	MAINTENANCE	2.0 16v (...98)	FORD AirBag MANUAL
 Focus	MAINTENANCE	RS	FORD PATS MANUAL
 Focus	MAINTENANCE	RS (...98)	FORD AirBag MANUAL
 Focus	MAINTENANCE	ST 170	FORD PATS MANUAL
 Focus	MAINTENANCE	ST 170 (...98)	FORD AirBag MANUAL
 Fusion	ABS	1.2 Duratec 16v (02-04)	ATE-TEVES ABS
 Fusion	ABS	1.2 Duratec 16v (06-..)	ATE-TEVES ABS
 Fusion	ABS	1.4 Duratec 16v (02-04)	ATE-TEVES ABS
 Fusion	ABS	1.4 Duratec 16v (06-..)	ATE-TEVES ABS
 Fusion	ABS	1.4 TDCi (02-04)	ATE-TEVES ABS
 Fusion	ABS	1.4 TDCi (06-..)	ATE-TEVES ABS
 Fusion	ABS	1.6 Duratec 16v (02-04)	ATE-TEVES ABS
 Fusion	ABS	1.6 Duratec 16v (06-..)	ATE-TEVES ABS
 Fusion	ABS	1.6 TDCi (06-..)	ATE-TEVES ABS
 Fusion	ABS	1.6 TDCi 90cv (02-04)	ATE-TEVES ABS
 Fusion	ABS + TRACT. CONT	1.2 Duratec 16v (02-04)	ATE ABS Mk60
 Fusion	ABS + TRACT. CONT	1.2 Duratec 16v (06-..)	ATE ABS Mk60
 Fusion	ABS + TRACT. CONT	1.4 Duratec 16v (02-04)	ATE ABS Mk60
 Fusion	ABS + TRACT. CONT	1.4 Duratec 16v (06-..)	ATE ABS Mk60
 Fusion	ABS + TRACT. CONT	1.4 TDCi (02-04)	ATE ABS Mk60
 Fusion	ABS + TRACT. CONT	1.4 TDCi (06-..)	ATE ABS Mk60
 Fusion	ABS + TRACT. CONT	1.6 Duratec 16v (02-04)	ATE ABS Mk60
 Fusion	ABS + TRACT. CONT	1.6 Duratec 16v (06-..)	ATE ABS Mk60
 Fusion	ABS + TRACT. CONT	1.6 TDCi (06-..)	ATE ABS Mk60
 Fusion	ABS + TRACT. CONT	1.6 TDCi 90cv (02-04)	ATE ABS Mk60
 Fusion	AIRBAG	1.2 Duratec 16v (02-04)	SIEMENS-VDO SRS
 Fusion	AIRBAG	1.2 Duratec 16v (06-..)	SIEMENS-VDO SRS
 Fusion	AIRBAG	1.4 Duratec 16v (02-04)	SIEMENS-VDO SRS
Fusion	AIRBAG	1.4 Duratec 16v (06-..)	SIEMENS-VDO SRS
Fusion	AIRBAG	1.4 TDCi (02-04)	SIEMENS-VDO SRS
Fusion	AIRBAG	1.4 TDCi (06-..)	SIEMENS-VDO SRS
Fusion	AIRBAG	1.6 Duratec 16v (02-04)	SIEMENS-VDO SRS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Fusion	AIRBAG	1.6 Duratec 16v (06-..)	SIEMENS-VDO SRS
 Fusion	AIRBAG	1.6 TDCi (06-..)	SIEMENS-VDO SRS
 Fusion	AIRBAG	1.6 TDCi 90cv (02-04)	SIEMENS-VDO SRS
 Fusion	CHASSIS NETWORK	1.2 Duratec 16v (02-04)	SIEMENS GEM Body Computer
 Fusion	CHASSIS NETWORK	1.2 Duratec 16v (05-06)	GEM
 Fusion	CHASSIS NETWORK	1.2 Duratec 16v (06-..)	SIEMENS GEM Body Computer
 Fusion	CHASSIS NETWORK	1.4 Duratec 16v (02-04)	SIEMENS GEM Body Computer
 Fusion	CHASSIS NETWORK	1.4 Duratec 16v (05-06)	GEM
 Fusion	CHASSIS NETWORK	1.4 Duratec 16v (06-..)	SIEMENS GEM Body Computer
 Fusion	CHASSIS NETWORK	1.4 TDCi (02-04)	SIEMENS GEM Body Computer
 Fusion	CHASSIS NETWORK	1.4 TDCi (05-06)	GEM
 Fusion	CHASSIS NETWORK	1.4 TDCi (06-..)	SIEMENS GEM Body Computer
 Fusion	CHASSIS NETWORK	1.6 Duratec 16v (02-04)	SIEMENS GEM Body Computer
 Fusion	CHASSIS NETWORK	1.6 Duratec 16v (05-06)	GEM
 Fusion	CHASSIS NETWORK	1.6 Duratec 16v (06-..)	SIEMENS GEM Body Computer
 Fusion	CHASSIS NETWORK	1.6 TDCi (06-..)	SIEMENS GEM Body Computer
 Fusion	CHASSIS NETWORK	1.6 TDCi 90cv (02-04)	SIEMENS GEM Body Computer
 Fusion	CHASSIS NETWORK	1.6 TDCi 90cv (05-06)	GEM
 Fusion	ENGINE MANAGEME	1.2 Duratec 16v (02-04)	SIEMENS 3BMA
 Fusion	ENGINE MANAGEME	1.2 Duratec 16v (06-..)	SIEMENS 3BMA
 Fusion	ENGINE MANAGEME	1.4 Duratec 16v (06-..)	EOBD
 Fusion	ENGINE MANAGEME	1.4 Duratec 16v (06-09)	SIEMENS 3BMA
 Fusion	ENGINE MANAGEME	1.4 Duratec 16v FXJA (02-04)	EOBD
 Fusion	ENGINE MANAGEME	1.4 TDCi (02-04)	DELPHI
 Fusion	ENGINE MANAGEME	1.4 TDCi (06-..)	DELPHI
 Fusion	ENGINE MANAGEME	1.6 Duratec 16v (06-..)	EOBD
 Fusion	ENGINE MANAGEME	1.6 Duratec 16v FYJA (02-04)	EOBD
 Fusion	ENGINE MANAGEME	1.6 TDCi (06-..)	EOBD
 Fusion	ENGINE MANAGEME	1.6 TDCi (06-..)	PCM Duratorq
 Fusion	ENGINE MANAGEME	1.6 TDCi 90cv HHDA (06-..)	PCM Duratorq
 Fusion	MAINTENANCE	1.6 TDCi (06-..)	PCM Duratorq
 Fusion	MAINTENANCE	1.6 TDCi 90cv HHDA (06-..)	PCM Duratorq
 Galaxy	ABS	1.9 TDI (..-01)	
 Galaxy	ABS	2.0 (..-01)	
 Galaxy	ABS	2.3 16v (..-01)	
 Galaxy	ABS	2.8 V6 (..-01)	
 Galaxy	AIRBAG	1.9 TDI (..-01)	
 Galaxy	AIRBAG	2.0 (..-01)	
 Galaxy	AIRBAG	2.3 16v (..-01)	
 Galaxy	AIRBAG	2.8 V6 (..-01)	
 Galaxy	AUTOM. TRANSMISSI	1.9 TDI (..-01)	
 Galaxy	AUTOM. TRANSMISSI	2.0 (..-01)	
 Galaxy	AUTOM. TRANSMISSI	2.3 16v (..-01)	
 Galaxy	AUTOM. TRANSMISSI	2.8 V6 (..-01)	
 Galaxy	CENTRAL LOCKING	1.9 TDI (..-01)	
 Galaxy	CENTRAL LOCKING	2.0 (..-01)	
 Galaxy	CENTRAL LOCKING	2.3 16v (..-01)	
 Galaxy	CENTRAL LOCKING	2.8 V6 (..-01)	
 Galaxy	CLIMA	1.9 TDI (..-01)	
 Galaxy	CLIMA	2.0 (..-01)	
 Galaxy	CLIMA	2.3 16v (..-01)	
 Galaxy	CLIMA	2.8 V6 (..-01)	
 Galaxy	CONV. TOP/SUNROO	1.9 TDI (..-01)	
 Galaxy	CONV. TOP/SUNROO	2.3 16v (..-01)	
 Galaxy	CONV. TOP/SUNROO	2.8 V6 (..-01)	
 Galaxy	DASHBOARD	1.9 TDI (..-01)	
 Galaxy	DASHBOARD	2.3 16v (..-01)	
 Galaxy	DASHBOARD	2.8 V6 (..-01)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Galaxy	ENGINE MANAGEME	1.9 TDI (.-01)	BOSCH EDC
 Galaxy	ENGINE MANAGEME	1.9 TDI (.-01)	
 Galaxy	ENGINE MANAGEME	1.9 TDI (.-01)	
 Galaxy	ENGINE MANAGEME	1.9 TDI 1Z (.-01)	
 Galaxy	ENGINE MANAGEME	2.3 16v (.-01)	FORD SEFI EEC-V
 Galaxy	ENGINE MANAGEME	2.3 16v (.-01)	
 Galaxy	ENGINE MANAGEME	2.3 16v (.-01)	
 Galaxy	ENGINE MANAGEME	2.3 16v Y5B (.-01)	
 Galaxy	ENGINE MANAGEME	2.8 V6 (.-01)	BOSCH Motronic
 Galaxy	ENGINE MANAGEME	2.8 V6 (.-01)	
 Galaxy	ENGINE MANAGEME	2.8 V6 (.-01)	
 Galaxy	ENGINE MANAGEME	2.8 V6 AAA (.-01)	
 Galaxy	IMMOBILIZER	1.9 TDI (.-01)	
 Galaxy	IMMOBILIZER	2.3 16v (.-01)	
 Galaxy	IMMOBILIZER	2.8 V6 (.-01)	
 Galaxy	MAINTENANCE	1.9 TDI (.-01)	
 Galaxy	MAINTENANCE	1.9 TDI (.-01)	
 Galaxy	MAINTENANCE	1.9 TDI (.-01)	
 Galaxy	MAINTENANCE	1.9 TDI (.-01)	
 Galaxy	MAINTENANCE	1.9 TDI (99-01)	
 Galaxy	MAINTENANCE	2.0 (.-01)	
 Galaxy	MAINTENANCE	2.0 (.-01)	
 Galaxy	MAINTENANCE	2.0 (.-01)	
 Galaxy	MAINTENANCE	2.0 (.-01)	
 Galaxy	MAINTENANCE	2.0 (.-01)	
 Galaxy	MAINTENANCE	2.0 (99-01)	
 Galaxy	MAINTENANCE	2.3 16v (.-01)	
 Galaxy	MAINTENANCE	2.3 16v (.-01)	
 Galaxy	MAINTENANCE	2.3 16v (.-01)	
 Galaxy	MAINTENANCE	2.3 16v (.-01)	
 Galaxy	MAINTENANCE	2.3 16v (99-01)	
 Galaxy	MAINTENANCE	2.8 V6 (.-01)	
 Galaxy	MAINTENANCE	2.8 V6 (.-01)	
 Galaxy	MAINTENANCE	2.8 V6 (.-01)	
 Galaxy	MAINTENANCE	2.8 V6 (.-01)	
 Galaxy	MAINTENANCE	2.8 V6 (.-01)	
 Galaxy	SERVICE LIGHT RES	1.9 TDI (.-01)	
 Galaxy	SERVICE LIGHT RES	1.9 TDI (99-01)	
 Galaxy	SERVICE LIGHT RES	2.0 (.-01)	
 Galaxy	SERVICE LIGHT RES	2.0 (99-01)	
 Galaxy	SERVICE LIGHT RES	2.3 16v (.-01)	
 Galaxy	SERVICE LIGHT RES	2.3 16v (99-01)	
 Galaxy	SERVICE LIGHT RES	2.8 V6 (.-01)	
 Galaxy	SERVICE LIGHT RES	2.8 V6 (.-01)	
 Granada 85	ENGINE MANAGEME	2.0 N9B (.-94)	FORD EFI EEC-IV
 Granada 85	ENGINE MANAGEME	2.0 N9D KAT (.-94)	FORD EFI EEC-IV
 Granada 85	ENGINE MANAGEME	2.0 N9F KAT (.-94)	FORD EFI EEC-IV
 Granada 85	ENGINE MANAGEME	2.0 NRA (.-94)	FORD EFI EEC-IV
 Granada 85	ENGINE MANAGEME	2.0 NRA KAT (.-94)	FORD EFI EEC-IV
 Granada 85	ENGINE MANAGEME	2.0 NRC KAT (.-94)	FORD EFI EEC-IV
 Granada 85	ENGINE MANAGEME	2.0 NRI (.-94)	FORD EFI EEC-IV
 Granada 85	ENGINE MANAGEME	2.4 V6 ARC (.-94)	FORD EFI EEC-IV
 Granada 85	ENGINE MANAGEME	2.4 V6 ARD KAT (.-94)	FORD EFI EEC-IV
 Granada 85	ENGINE MANAGEME	2.8 V6 PR3 (.-94)	FORD EFI EEC-IV
 Granada 85	ENGINE MANAGEME	2.8 V6 PR3 (S-CH) (.-94)	FORD EFI EEC-IV

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Granada 85	ENGINE MANAGEME	2.8 V6 PR4 (...94)	FORD EFI EEC-IV
 Granada 85	ENGINE MANAGEME	2.8 V6 PR4 (S-CH) (...94)	FORD EFI EEC-IV
 Granada 85	ENGINE MANAGEME	2.8 V6 PRE (...94)	FORD EFI EEC-IV
 Granada 85	ENGINE MANAGEME	2.8 V6 PRE (S-CH) (...94)	FORD EFI EEC-IV
 Granada 85	ENGINE MANAGEME	2.9 V6 24v BOA (...94)	FORD EFI EEC-IV
 Granada 85	ENGINE MANAGEME	2.9 V6 BRC (...94)	FORD EFI EEC-IV
 Granada 85	ENGINE MANAGEME	2.9 V6 BRD (...94)	FORD EFI EEC-IV
 Granada 85	ENGINE MANAGEME	2.9 V6 BRE KAT (...94)	FORD EFI EEC-IV
 Granada 85	ENGINE MANAGEME	2.9 V6 BRF KAT (...94)	FORD EFI EEC-IV
 Grand Marquis	ENGINE MANAGEME	4.6 (96-00)	FORD SEFI EEC-V
 Ikon	ENGINE MANAGEME	1.3 (00-00)	FORD SEFI EEC-V
 Ikon	ENGINE MANAGEME	1.3 (03-05)	ROCAM S.A.
 Ikon	ENGINE MANAGEME	1.6 (00-00)	FORD SEFI EEC-V
 Ikon	ENGINE MANAGEME	1.6 (03-05)	ROCAM S.A.
 Ikon	ENGINE MANAGEME	1.8 Diesel (00-00)	FORD SEFI EEC-V
 Ka (08-..)	ABS + TRACT. CONT	1.2 8v 69cv (08-..)	BOSCH ABS 8 ESP
 Ka (08-..)	ABS + TRACT. CONT	1.3 Multijet 16v 75cv (08-..)	BOSCH ABS 8 ESP
 Ka (08-..)	AIRBAG	1.2 8v 69cv (08-..)	SIEMENS AirBag
 Ka (08-..)	AIRBAG	1.2 8v 69cv (09-..)	Continental AirBag
 Ka (08-..)	AIRBAG	1.3 Multijet 16v 75cv (08-..)	Continental AirBag
 Ka (08-..)	AIRBAG	1.3 Multijet 16v 75cv (08-..)	SIEMENS AirBag
 Ka (08-..)	CHASSIS NETWORK	1.2 8v 69cv (08-..)	DELPHI Body Computer 2
 Ka (08-..)	CHASSIS NETWORK	1.3 Multijet 16v 75cv (08-..)	DELPHI Body Computer 2
 Ka (08-..)	DASHBOARD	1.2 8v 69cv (08-..)	Marelli IC 2
 Ka (08-..)	DASHBOARD	1.3 Multijet 16v 75cv (08-..)	Marelli IC 2
 Ka (08-..)	ELECTRIC STEERING	1.2 8v 69cv (08-..)	DELPHI 2
 Ka (08-..)	ELECTRIC STEERING	1.3 Multijet 16v 75cv (08-..)	DELPHI 2
 Ka (08-..)	ENGINE MANAGEME	1.2 8v 69cv (08-..)	Marelli IAW 5SF8 CF5/EOBD
 Ka (08-..)	ENGINE MANAGEME	1.2 8v 69cv (08-..)	Marelli IAW 5SF9
 Ka (08-..)	ENGINE MANAGEME	1.3 Multijet 16v 75cv (08-..)	Marelli 6F3 EOBD CAN 2
 Ka (08-..)	ENGINE MANAGEME	1.3 Multijet 16v 75cv FAP (08-..)	Marelli 6F3 EOBD CAN 2
 Ka (08-..)	KEY ENCODE	1.2 8v 69cv (08-..)	DELPHI Body Computer
 Ka (08-..)	KEY ENCODE	1.3 Multijet 16v 75cv (08-..)	DELPHI Body Computer
 Ka (08-..)	MAINTENANCE	1.2 8v 69cv (08-..)	DELPHI 2
 Ka (08-..)	MAINTENANCE	1.2 8v 69cv (08-..)	Marelli IAW 5SF9
 Ka (08-..)	MAINTENANCE	1.3 Multijet 16v 75cv (08-..)	DELPHI 2
 Ka (08-..)	MAINTENANCE	1.3 Multijet 16v 75cv (08-..)	Marelli 6F3 EOBD CAN 2
 Ka (08-..)	MAINTENANCE	1.3 Multijet 16v 75cv (08-..)	Marelli 6F3 EOBD CAN 2
 Ka (08-..)	MAINTENANCE	1.3 Multijet 16v 75cv (08-..)	Marelli 6F3 EOBD CAN 2
 Ka (08-..)	MAINTENANCE	1.3 Multijet 16v 75cv (08-..)	Marelli 6F3 EOBD CAN 2
 Ka (08-..)	MAINTENANCE	1.3 Multijet 16v 75cv FAP (08-..)	Marelli 6F3 EOBD CAN 2
 Ka (08-..)	MAINTENANCE	1.3 Multijet 16v 75cv FAP (08-..)	Marelli 6F3 EOBD CAN 2
 Ka (08-..)	MAINTENANCE	1.3 Multijet 16v 75cv FAP (08-..)	Marelli 6F3 EOBD CAN 2
 Ka (96-08)	ABS	1.0	ATE Teves ABS Mk20-I
 Ka (96-08)	ABS	1.3	ATE Teves ABS Mk20-I
 Ka (96-08)	ABS	1.6	ATE Teves ABS Mk20-I
 Ka (96-08)	ENGINE MANAGEME	1.0 (01-..)	EOBD
 Ka (96-08)	ENGINE MANAGEME	1.3 J4C (96-..)	FORD SEFI EEC-V
 Ka (96-08)	ENGINE MANAGEME	1.3 J4D (96-..)	FORD SEFI EEC-V
 Ka (96-08)	ENGINE MANAGEME	1.3 J4K (98-00)	FORD SEFI EEC-V
 Ka (96-08)	ENGINE MANAGEME	1.3 J4M (98-00)	FORD SEFI EEC-V
 Ka (96-08)	ENGINE MANAGEME	1.3 J4P (98-00)	FORD SEFI EEC-V
 Ka (96-08)	ENGINE MANAGEME	1.3 JJA (96-..)	FORD SEFI EEC-V
 Ka (96-08)	ENGINE MANAGEME	1.3 JJB (96-..)	FORD SEFI EEC-V
 Ka (96-08)	ENGINE MANAGEME	1.3 JJD (98-00)	FORD SEFI EEC-V
 Ka (96-08)	ENGINE MANAGEME	1.3 JJF (98-00)	FORD SEFI EEC-V
 Ka (96-08)	ENGINE MANAGEME	1.6 (01-..)	EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Ka (96-08)	KEY ENCODE	1.0 (96)	FORD PATS MANUAL
 Ka (96-08)	KEY ENCODE	1.0 (97-..)	FORD PATS MANUAL
 Ka (96-08)	KEY ENCODE	1.3 (96)	FORD PATS MANUAL
 Ka (96-08)	KEY ENCODE	1.3 (97-..)	FORD PATS MANUAL
 Ka (96-08)	KEY ENCODE	1.6 (96)	FORD PATS MANUAL
 Ka (96-08)	KEY ENCODE	1.6 (97-..)	FORD PATS MANUAL
 Ka (96-08)	MAINTENANCE	1.0 (96)	FORD PATS MANUAL
 Ka (96-08)	MAINTENANCE	1.0 (97-..)	FORD PATS MANUAL
 Ka (96-08)	MAINTENANCE	1.3 (96)	FORD PATS MANUAL
 Ka (96-08)	MAINTENANCE	1.3 (97-..)	FORD PATS MANUAL
 Ka (96-08)	MAINTENANCE	1.6 (96)	FORD PATS MANUAL
 Ka (96-08)	MAINTENANCE	1.6 (97-..)	FORD PATS MANUAL
 Kuga	4WD ELECTRONICS	2.0 TDCi (08-..)	AWD
 Kuga	ABS + TRACT. CONT	2.0 TDCi (08-..)	ABS
 Kuga	AIRBAG	2.0 TDCi (08-..)	RCM
 Kuga	CHASSIS NETWORK	2.0 TDCi (08-..)	GEM
 Kuga	CLIMA	2.0 TDCi (08-..)	EATC
 Kuga	DASHBOARD	2.0 TDCi (08-..)	IC
 Kuga	DRIVER SIDE DOOR	2.0 TDCi (08-..)	D-DCU
 Kuga	ELECTRIC STEERING	2.0 TDCi (08-..)	EPS
 Kuga	ENGINE MANAGEME	2.0 TDCi (08-..)	PCM Common Rail
 Kuga	MAINTENANCE	2.0 TDCi (08-..)	
 Kuga	MAINTENANCE	2.0 TDCi (08-..)	ABS
 Kuga	PARKING HELP	2.0 TDCi (08-..)	PAM
 Kuga	PASS. SIDE DOOR	2.0 TDCi (08-..)	PDM
 Kuga	SERVICE LIGHT RES	2.0 TDCi (08-..)	
 LS (Lincoln)	ENGINE MANAGEME	3.0 (00-00)	FORD SEFI EEC-V
 LS (Lincoln)	ENGINE MANAGEME	3.9 (00-00)	FORD SEFI EEC-V
 Mondeo 07	ABS + TRACT. CONT	1.6	ABS/ESP
 Mondeo 07	ABS + TRACT. CONT	1.8 TDCi	ABS/ESP
 Mondeo 07	ABS + TRACT. CONT	2.0	ABS/ESP
 Mondeo 07	ABS + TRACT. CONT	2.0 TDCi 130cv	ABS/ESP
 Mondeo 07	ABS + TRACT. CONT	2.0 TDCi 140cv	ABS/ESP
 Mondeo 07	ABS + TRACT. CONT	2.2 TDCi	ABS/ESP
 Mondeo 07	ABS + TRACT. CONT	2.3	ABS/ESP
 Mondeo 07	ABS + TRACT. CONT	2.3	ABS/ESP
 Mondeo 07	ABS + TRACT. CONT	2.5	ABS/ESP
 Mondeo 07	ABS + TRACT. CONT	2.5	ABS/ESP
 Mondeo 07	AIRBAG	1.6	SRS RCM
 Mondeo 07	AIRBAG	1.8 TDCi	SRS RCM
 Mondeo 07	AIRBAG	2.0	SRS RCM
 Mondeo 07	AIRBAG	2.0 TDCi 130cv	SRS RCM
 Mondeo 07	AIRBAG	2.0 TDCi 140cv	SRS RCM
 Mondeo 07	AIRBAG	2.2 TDCi	SRS RCM
 Mondeo 07	AIRBAG	2.3	SRS RCM
 Mondeo 07	AIRBAG	2.3	SRS RCM
 Mondeo 07	AIRBAG	2.5	SRS RCM
 Mondeo 07	AIRBAG	2.5	SRS RCM
 Mondeo 07	CHASSIS NETWORK	1.6	BCMii
 Mondeo 07	CHASSIS NETWORK	1.8 TDCi	BCMii
 Mondeo 07	CHASSIS NETWORK	2.0	BCMii
 Mondeo 07	CHASSIS NETWORK	2.0 TDCi 130cv	BCMii
 Mondeo 07	CHASSIS NETWORK	2.0 TDCi 140cv	BCMii
 Mondeo 07	CHASSIS NETWORK	2.2 TDCi	BCMii
 Mondeo 07	CHASSIS NETWORK	2.3	BCMii
 Mondeo 07	CHASSIS NETWORK	2.3	BCMii
 Mondeo 07	CHASSIS NETWORK	2.5	BCMii
 Mondeo 07	CHASSIS NETWORK	2.5	BCMii

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Mondeo 07	CLIMA	1.6	HVAC
 Mondeo 07	CLIMA	1.8 TDCi	HVAC
 Mondeo 07	CLIMA	2.0	HVAC
 Mondeo 07	CLIMA	2.0 TDCi 130cv	HVAC
 Mondeo 07	CLIMA	2.0 TDCi 140cv	HVAC
 Mondeo 07	CLIMA	2.2 TDCi	HVAC
 Mondeo 07	CLIMA	2.3	HVAC
 Mondeo 07	CLIMA	2.3	HVAC
 Mondeo 07	CLIMA	2.5	HVAC
 Mondeo 07	CLIMA	2.5	HVAC
 Mondeo 07	DASHBOARD	1.6	IC
 Mondeo 07	DASHBOARD	1.8 TDCi	IC
 Mondeo 07	DASHBOARD	2.0	IC
 Mondeo 07	DASHBOARD	2.0 TDCi 130cv	IC
 Mondeo 07	DASHBOARD	2.0 TDCi 140cv	IC
 Mondeo 07	DASHBOARD	2.2 TDCi	IC
 Mondeo 07	DASHBOARD	2.3	IC
 Mondeo 07	DASHBOARD	2.3	IC
 Mondeo 07	DASHBOARD	2.5	IC
 Mondeo 07	DASHBOARD	2.5	IC
 Mondeo 07	ENGINE MANAGEME	1.6	PCM Duratec
 Mondeo 07	ENGINE MANAGEME	1.8 TDCi	PCM Duratorq
 Mondeo 07	ENGINE MANAGEME	2.0	PCM Duratec
 Mondeo 07	ENGINE MANAGEME	2.0 TDCi 130cv	Common Rail
 Mondeo 07	ENGINE MANAGEME	2.0 TDCi 130cv	PCM Duratorq + DPF
 Mondeo 07	ENGINE MANAGEME	2.0 TDCi 140cv	Common Rail
 Mondeo 07	ENGINE MANAGEME	2.0 TDCi 140cv	EOBD
 Mondeo 07	ENGINE MANAGEME	2.0 TDCi 140cv	PCM Duratorq + DPF
 Mondeo 07	ENGINE MANAGEME	2.2 TDCi	Common Rail
 Mondeo 07	ENGINE MANAGEME	2.3	EOBD
 Mondeo 07	ENGINE MANAGEME	2.5	EOBD
 Mondeo 07	MAINTENANCE	1.6	ABS/ESP
 Mondeo 07	MAINTENANCE	1.6	MANUAL
 Mondeo 07	MAINTENANCE	1.8 TDCi	ABS/ESP
 Mondeo 07	MAINTENANCE	1.8 TDCi	MANUAL
 Mondeo 07	MAINTENANCE	2.0	ABS/ESP
 Mondeo 07	MAINTENANCE	2.0	MANUAL
 Mondeo 07	MAINTENANCE	2.0 TDCi 130cv	ABS/ESP
 Mondeo 07	MAINTENANCE	2.0 TDCi 130cv	MANUAL
 Mondeo 07	MAINTENANCE	2.0 TDCi 140cv	ABS/ESP
 Mondeo 07	MAINTENANCE	2.0 TDCi 140cv	MANUAL
 Mondeo 07	MAINTENANCE	2.2 TDCi	ABS/ESP
 Mondeo 07	MAINTENANCE	2.2 TDCi	Common Rail
 Mondeo 07	MAINTENANCE	2.2 TDCi	MANUAL
 Mondeo 07	MAINTENANCE	2.3	ABS/ESP
 Mondeo 07	MAINTENANCE	2.3	MANUAL
 Mondeo 07	MAINTENANCE	2.5	ABS/ESP
 Mondeo 07	MAINTENANCE	2.5	MANUAL
 Mondeo 07	PARKING HELP	1.6	
 Mondeo 07	PARKING HELP	1.8 TDCi	
 Mondeo 07	PARKING HELP	2.0	
 Mondeo 07	PARKING HELP	2.0 TDCi 130cv	
 Mondeo 07	PARKING HELP	2.0 TDCi 140cv	
 Mondeo 07	PARKING HELP	2.2 TDCi	
 Mondeo 07	SERVICE LIGHT RES	1.6	MANUAL
 Mondeo 07	SERVICE LIGHT RES	1.8 TDCi	MANUAL
 Mondeo 07	SERVICE LIGHT RES	2.0	MANUAL
 Mondeo 07	SERVICE LIGHT RES	2.0 TDCi 130cv	MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Mondeo 07	SERVICE LIGHT RES	2.0 TDCi 140cv	MANUAL
 Mondeo 07	SERVICE LIGHT RES	2.2 TDCi	MANUAL
 Mondeo 07	SERVICE LIGHT RES	2.3	MANUAL
 Mondeo 07	SERVICE LIGHT RES	2.3	MANUAL
 Mondeo 07	SERVICE LIGHT RES	2.5	MANUAL
 Mondeo 07	SERVICE LIGHT RES	2.5	MANUAL
 Mondeo	ABS	1.8 16v (03-..)	BOSCH ABS
 Mondeo	ABS	1.8 16v (04-..)	ABS
 Mondeo	ABS	2.0 16v (03-..)	BOSCH ABS
 Mondeo	ABS	2.0 16v (04-..)	ABS
 Mondeo	ABS	2.0 TDCi (03-..)	BOSCH ABS
 Mondeo	ABS	2.0 TDCi (04-..)	ABS
 Mondeo	ABS	2.2 TDCi (03-..)	BOSCH ABS
 Mondeo	ABS	2.2 TDCi (04-..)	ABS
 Mondeo	ABS	2.5 V6 (03-..)	BOSCH ABS
 Mondeo	ABS	2.5 V6 (04-..)	ABS
 Mondeo	ABS	3.0 V6 (03-..)	BOSCH ABS
 Mondeo	ABS	3.0 V6 (04-..)	ABS
 Mondeo	AIRBAG	1.6 16v (...99)	FORD AirBag MANUAL
 Mondeo	AIRBAG	1.8 16v (...99)	FORD AirBag MANUAL
 Mondeo	AIRBAG	1.8 16v (03-03)	Autoliv SRS ARM
 Mondeo	AIRBAG	1.8 16v (04-..)	Autoliv SRS
 Mondeo	AIRBAG	1.8 TD (...99)	FORD AirBag MANUAL
 Mondeo	AIRBAG	2.0 16v (...99)	FORD AirBag MANUAL
 Mondeo	AIRBAG	2.0 16v (03-03)	Autoliv SRS ARM
 Mondeo	AIRBAG	2.0 16v (04-..)	Autoliv SRS
 Mondeo	AIRBAG	2.0 TDCi (...99)	FORD AirBag MANUAL
 Mondeo	AIRBAG	2.0 TDCi (03-03)	Autoliv SRS ARM
 Mondeo	AIRBAG	2.0 TDCi (04-..)	Autoliv SRS
 Mondeo	AIRBAG	2.0 TDDi (...99)	FORD AirBag MANUAL
 Mondeo	AIRBAG	2.2 TDCi (...99)	FORD AirBag MANUAL
 Mondeo	AIRBAG	2.2 TDCi (03-03)	Autoliv SRS ARM
 Mondeo	AIRBAG	2.2 TDCi (04-..)	Autoliv SRS
 Mondeo	AIRBAG	2.5 V6 (...99)	FORD AirBag MANUAL
 Mondeo	AIRBAG	2.5 V6 (03-03)	Autoliv SRS ARM
 Mondeo	AIRBAG	2.5 V6 (04-..)	Autoliv SRS
 Mondeo	AIRBAG	3.0 V6 (...99)	FORD AirBag MANUAL
 Mondeo	AIRBAG	3.0 V6 (03-03)	Autoliv SRS ARM
 Mondeo	AIRBAG	3.0 V6 (04-..)	Autoliv SRS
 Mondeo	CHASSIS NETWORK	1.8 16v (03-..)	SIEMENS GEM Body Computer
 Mondeo	CHASSIS NETWORK	2.0 16v (03-..)	SIEMENS GEM Body Computer
 Mondeo	CHASSIS NETWORK	2.0 TDCi (03-..)	SIEMENS GEM Body Computer
 Mondeo	CHASSIS NETWORK	2.2 TDCi (03-..)	SIEMENS GEM Body Computer
 Mondeo	CHASSIS NETWORK	2.5 V6 (03-..)	SIEMENS GEM Body Computer
 Mondeo	CHASSIS NETWORK	3.0 V6 (03-..)	SIEMENS GEM Body Computer
 Mondeo	CLIMA	1.8 16v (04-..)	CLIMA
 Mondeo	CLIMA	2.0 16v (04-..)	CLIMA
 Mondeo	CLIMA	2.0 TDCi (04-..)	CLIMA
 Mondeo	CLIMA	2.2 TDCi (04-..)	CLIMA
 Mondeo	CLIMA	2.5 V6 (04-..)	CLIMA
 Mondeo	CLIMA	3.0 V6 (04-..)	CLIMA
 Mondeo	DASHBOARD	1.8 16v (03-..)	VISTEON Kombinstrum.
 Mondeo	DASHBOARD	2.0 16v (03-..)	VISTEON Kombinstrum.
 Mondeo	DASHBOARD	2.0 TDCi (03-..)	VISTEON Kombinstrum.
 Mondeo	DASHBOARD	2.2 TDCi (03-..)	VISTEON Kombinstrum.
 Mondeo	DASHBOARD	2.5 V6 (03-..)	VISTEON Kombinstrum.
 Mondeo	DASHBOARD	3.0 V6 (03-..)	VISTEON Kombinstrum.
 Mondeo	ENGINE MANAGEME	1.6 16v L1F (93-95)	FORD SEFI EEC-IV

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Mondeo	ENGINE MANAGEME	1.6 16v L1F (93-95)	FORD SEFI EEC-IV (Fast)
 Mondeo	ENGINE MANAGEME	1.6 16v L1F (95-96)	FORD SEFI EEC-IV (Fast)
 Mondeo	ENGINE MANAGEME	1.6 16v L1F (96-..)	FORD SEFI EEC-V
 Mondeo	ENGINE MANAGEME	1.6 16v L1J (93-95)	FORD SEFI EEC-IV (Fast)
 Mondeo	ENGINE MANAGEME	1.6 16v L1J (95-96)	FORD SEFI EEC-IV (Fast)
 Mondeo	ENGINE MANAGEME	1.6 16v L1J (96-..)	FORD SEFI EEC-V
 Mondeo	ENGINE MANAGEME	1.8 16v CGBB (01-..)	EOBD
 Mondeo	ENGINE MANAGEME	1.8 16v CHBB (01-..)	EOBD
 Mondeo	ENGINE MANAGEME	1.8 16v RKA (..-95)	FORD SEFI EEC-IV (Fast)
 Mondeo	ENGINE MANAGEME	1.8 16v RKA (93-95)	FORD SEFI EEC-IV
 Mondeo	ENGINE MANAGEME	1.8 16v RKA (93-95)	FORD SEFI EEC-IV (Fast)
 Mondeo	ENGINE MANAGEME	1.8 16v RKA (95-96)	FORD SEFI EEC-IV (Fast)
 Mondeo	ENGINE MANAGEME	1.8 16v RKA (96-..)	FORD SEFI EEC-V
 Mondeo	ENGINE MANAGEME	1.8 16v RKB (..-95)	FORD SEFI EEC-IV (Fast)
 Mondeo	ENGINE MANAGEME	1.8 16v RKB (93-95)	FORD SEFI EEC-IV (Fast)
 Mondeo	ENGINE MANAGEME	1.8 16v RKB (95-96)	FORD SEFI EEC-IV (Fast)
 Mondeo	ENGINE MANAGEME	1.8 16v RKB (96-..)	FORD SEFI EEC-V
 Mondeo	ENGINE MANAGEME	1.8 TD (97-..)	FORD Diesel EEC-V
 Mondeo	ENGINE MANAGEME	2.0 16v NGA (..-95)	FORD SEFI EEC-IV (Fast)
 Mondeo	ENGINE MANAGEME	2.0 16v NGA (93-95)	FORD SEFI EEC-IV
 Mondeo	ENGINE MANAGEME	2.0 16v NGA (93-95)	FORD SEFI EEC-IV (Fast)
 Mondeo	ENGINE MANAGEME	2.0 16v NGA (95-96)	FORD SEFI EEC-IV (Fast)
 Mondeo	ENGINE MANAGEME	2.0 TDCi FMBA (01-..)	FORD DELPHI Duratorq-Ci
 Mondeo	ENGINE MANAGEME	2.0 TDCi FMBB (01-..)	FORD DELPHI Duratorq-Ci
 Mondeo	ENGINE MANAGEME	2.0 TDDi D5BA (01-..)	FORD Diesel - Duratorq-Di EEC-V
 Mondeo	ENGINE MANAGEME	2.0 TDDi D6BA (01-..)	FORD Diesel - Duratorq-Di EEC-V
 Mondeo	ENGINE MANAGEME	2.5 V6 SEA (..-95)	FORD SEFI EEC-IV (Fast)
 Mondeo	ENGINE MANAGEME	2.5 V6 SEA (93-95)	FORD SEFI EEC-IV (Fast)
 Mondeo	ENGINE MANAGEME	2.5 V6 SEA (95-96)	FORD SEFI EEC-IV (Fast)
 Mondeo	ENGINE MANAGEME	2.5 V6 SEA (96-..)	FORD SEFI EEC-V
 Mondeo	KEY ENCODE	1.6 16v (95-96)	FORD PATS MANUAL
 Mondeo	KEY ENCODE	1.6 16v (97-..)	FORD PATS MANUAL
 Mondeo	KEY ENCODE	1.8 16v (95-96)	FORD PATS MANUAL
 Mondeo	KEY ENCODE	1.8 16v (97-..)	FORD PATS MANUAL
 Mondeo	KEY ENCODE	1.8 TD (95-96)	FORD PATS MANUAL
 Mondeo	KEY ENCODE	1.8 TD (97-..)	FORD PATS MANUAL
 Mondeo	KEY ENCODE	2.0 16v (95-96)	FORD PATS MANUAL
 Mondeo	KEY ENCODE	2.0 16v (97-..)	FORD PATS MANUAL
 Mondeo	KEY ENCODE	2.0 TDCi (95-96)	FORD PATS MANUAL
 Mondeo	KEY ENCODE	2.0 TDCi (97-..)	FORD PATS MANUAL
 Mondeo	KEY ENCODE	2.0 TDDi (95-96)	FORD PATS MANUAL
 Mondeo	KEY ENCODE	2.0 TDDi (97-..)	FORD PATS MANUAL
 Mondeo	KEY ENCODE	2.2 TDCi (95-96)	FORD PATS MANUAL
 Mondeo	KEY ENCODE	2.2 TDCi (97-..)	FORD PATS MANUAL
 Mondeo	KEY ENCODE	2.5 V6 (95-96)	FORD PATS MANUAL
 Mondeo	KEY ENCODE	2.5 V6 (97-..)	FORD PATS MANUAL
 Mondeo	KEY ENCODE	3.0 V6 (95-96)	FORD PATS MANUAL
 Mondeo	KEY ENCODE	3.0 V6 (97-..)	FORD PATS MANUAL
 Mondeo	MAINTENANCE	1.6 16v	FORD MANUAL
 Mondeo	MAINTENANCE	1.6 16v (..-99)	FORD AirBag MANUAL
 Mondeo	MAINTENANCE	1.6 16v (95-96)	FORD PATS MANUAL
 Mondeo	MAINTENANCE	1.6 16v (97-..)	FORD PATS MANUAL
 Mondeo	MAINTENANCE	1.8 16v	FORD MANUAL
 Mondeo	MAINTENANCE	1.8 16v (..-99)	FORD AirBag MANUAL
 Mondeo	MAINTENANCE	1.8 16v (03-..)	BOSCH ABS
 Mondeo	MAINTENANCE	1.8 16v (03-..)	BOSCH ABS
 Mondeo	MAINTENANCE	1.8 16v (03-..)	BOSCH ABS
 Mondeo	MAINTENANCE	1.8 16v (03-..)	BOSCH ABS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Mondeo	MAINTENANCE	1.8 16v (04-..)	ABS
 Mondeo	MAINTENANCE	1.8 16v (04-..)	ABS
 Mondeo	MAINTENANCE	1.8 16v (04-..)	ABS
 Mondeo	MAINTENANCE	1.8 16v (04-..)	ABS
 Mondeo	MAINTENANCE	1.8 16v (95-96)	FORD PATS MANUAL
 Mondeo	MAINTENANCE	1.8 16v (97-..)	FORD PATS MANUAL
 Mondeo	MAINTENANCE	1.8 TD	FORD MANUAL
 Mondeo	MAINTENANCE	1.8 TD (...99)	FORD AirBag MANUAL
 Mondeo	MAINTENANCE	1.8 TD (95-96)	FORD PATS MANUAL
 Mondeo	MAINTENANCE	1.8 TD (97-..)	FORD PATS MANUAL
 Mondeo	MAINTENANCE	2.0 16v	FORD MANUAL
 Mondeo	MAINTENANCE	2.0 16v (...99)	FORD AirBag MANUAL
 Mondeo	MAINTENANCE	2.0 16v (03-..)	BOSCH ABS
 Mondeo	MAINTENANCE	2.0 16v (03-..)	BOSCH ABS
 Mondeo	MAINTENANCE	2.0 16v (03-..)	BOSCH ABS
 Mondeo	MAINTENANCE	2.0 16v (03-..)	BOSCH ABS
 Mondeo	MAINTENANCE	2.0 16v (04-..)	ABS
 Mondeo	MAINTENANCE	2.0 16v (04-..)	ABS
 Mondeo	MAINTENANCE	2.0 16v (04-..)	ABS
 Mondeo	MAINTENANCE	2.0 16v (04-..)	ABS
 Mondeo	MAINTENANCE	2.0 16v (95-96)	FORD PATS MANUAL
 Mondeo	MAINTENANCE	2.0 16v (97-..)	FORD PATS MANUAL
 Mondeo	MAINTENANCE	2.0 TDCi	FORD MANUAL
 Mondeo	MAINTENANCE	2.0 TDCi (...99)	FORD AirBag MANUAL
 Mondeo	MAINTENANCE	2.0 TDCi (03-..)	BOSCH ABS
 Mondeo	MAINTENANCE	2.0 TDCi (03-..)	BOSCH ABS
 Mondeo	MAINTENANCE	2.0 TDCi (03-..)	BOSCH ABS
 Mondeo	MAINTENANCE	2.0 TDCi (03-..)	BOSCH ABS
 Mondeo	MAINTENANCE	2.0 TDCi (04-..)	ABS
 Mondeo	MAINTENANCE	2.0 TDCi (04-..)	ABS
 Mondeo	MAINTENANCE	2.0 TDCi (04-..)	ABS
 Mondeo	MAINTENANCE	2.0 TDCi (04-..)	ABS
 Mondeo	MAINTENANCE	2.0 TDCi (95-96)	FORD PATS MANUAL
 Mondeo	MAINTENANCE	2.0 TDCi (97-..)	FORD PATS MANUAL
 Mondeo	MAINTENANCE	2.0 TDDi	FORD MANUAL
 Mondeo	MAINTENANCE	2.0 TDDi (...99)	FORD AirBag MANUAL
 Mondeo	MAINTENANCE	2.0 TDDi (95-96)	FORD PATS MANUAL
 Mondeo	MAINTENANCE	2.0 TDDi (97-..)	FORD PATS MANUAL
 Mondeo	MAINTENANCE	2.2 TDCi	FORD MANUAL
 Mondeo	MAINTENANCE	2.2 TDCi (...99)	FORD AirBag MANUAL
 Mondeo	MAINTENANCE	2.2 TDCi (03-..)	BOSCH ABS
 Mondeo	MAINTENANCE	2.2 TDCi (03-..)	BOSCH ABS
 Mondeo	MAINTENANCE	2.2 TDCi (03-..)	BOSCH ABS
 Mondeo	MAINTENANCE	2.2 TDCi (03-..)	BOSCH ABS
 Mondeo	MAINTENANCE	2.2 TDCi (04-..)	ABS
 Mondeo	MAINTENANCE	2.2 TDCi (04-..)	ABS
 Mondeo	MAINTENANCE	2.2 TDCi (04-..)	ABS
 Mondeo	MAINTENANCE	2.2 TDCi (04-..)	ABS
 Mondeo	MAINTENANCE	2.2 TDCi (95-96)	FORD PATS MANUAL
 Mondeo	MAINTENANCE	2.2 TDCi (97-..)	FORD PATS MANUAL
 Mondeo	MAINTENANCE	2.5 V6	FORD MANUAL
 Mondeo	MAINTENANCE	2.5 V6 (...99)	FORD AirBag MANUAL
 Mondeo	MAINTENANCE	2.5 V6 (03-..)	BOSCH ABS
 Mondeo	MAINTENANCE	2.5 V6 (03-..)	BOSCH ABS
 Mondeo	MAINTENANCE	2.5 V6 (03-..)	BOSCH ABS
 Mondeo	MAINTENANCE	2.5 V6 (03-..)	BOSCH ABS
 Mondeo	MAINTENANCE	2.5 V6 (04-..)	ABS
 Mondeo	MAINTENANCE	2.5 V6 (04-..)	ABS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Mondeo	MAINTENANCE	2.5 V6 (04-..)	ABS
 Mondeo	MAINTENANCE	2.5 V6 (04-..)	ABS
 Mondeo	MAINTENANCE	2.5 V6 (95-96)	FORD PATS MANUAL
 Mondeo	MAINTENANCE	2.5 V6 (97-..)	FORD PATS MANUAL
 Mondeo	MAINTENANCE	3.0 V6	FORD MANUAL
 Mondeo	MAINTENANCE	3.0 V6 (.-99)	FORD AirBag MANUAL
 Mondeo	MAINTENANCE	3.0 V6 (03-..)	BOSCH ABS
 Mondeo	MAINTENANCE	3.0 V6 (03-..)	BOSCH ABS
 Mondeo	MAINTENANCE	3.0 V6 (03-..)	BOSCH ABS
 Mondeo	MAINTENANCE	3.0 V6 (03-..)	BOSCH ABS
 Mondeo	MAINTENANCE	3.0 V6 (04-..)	ABS
 Mondeo	MAINTENANCE	3.0 V6 (04-..)	ABS
 Mondeo	MAINTENANCE	3.0 V6 (04-..)	ABS
 Mondeo	MAINTENANCE	3.0 V6 (04-..)	ABS
 Mondeo	MAINTENANCE	3.0 V6 (95-96)	FORD PATS MANUAL
 Mondeo	MAINTENANCE	3.0 V6 (97-..)	FORD PATS MANUAL
 Mondeo	SERVICE LIGHT RES	1.6 16v	FORD MANUAL
 Mondeo	SERVICE LIGHT RES	1.8 16v	FORD MANUAL
 Mondeo	SERVICE LIGHT RES	1.8 TD	FORD MANUAL
 Mondeo	SERVICE LIGHT RES	2.0 16v	FORD MANUAL
 Mondeo	SERVICE LIGHT RES	2.0 TDCi	FORD MANUAL
 Mondeo	SERVICE LIGHT RES	2.0 TDDi	FORD MANUAL
 Mondeo	SERVICE LIGHT RES	2.2 TDCi	FORD MANUAL
 Mondeo	SERVICE LIGHT RES	2.5 V6	FORD MANUAL
 Mondeo	SERVICE LIGHT RES	3.0 V6	FORD MANUAL
 Mountaineer	ENGINE MANAGEME	4.0 (98-00)	FORD SEFI EEC-V
 Mountaineer	ENGINE MANAGEME	5.0 (97-00)	FORD SEFI EEC-V
 Mustang	ENGINE MANAGEME	3.8 (96-00)	FORD SEFI EEC-V
 Mustang	ENGINE MANAGEME	4.6 (96-00)	FORD SEFI EEC-V
 Mystique	ENGINE MANAGEME	2.0 (00-00)	FORD SEFI EEC-V
 Mystique	ENGINE MANAGEME	2.5 (00-00)	FORD SEFI EEC-V
 Navigator	ENGINE MANAGEME	5.4 (98-00)	FORD SEFI EEC-V
 New Galaxy	ABS + TRACT. CONT	1.8 TDCi 100cv (07-..)	ABS/ESP
 New Galaxy	ABS + TRACT. CONT	1.8 TDCi 125cv (07-..)	ABS/ESP
 New Galaxy	ABS + TRACT. CONT	2.0 145cv (07-..)	ABS/ESP
 New Galaxy	ABS + TRACT. CONT	2.0 TDCi 130cv (07-..)	ABS/ESP
 New Galaxy	ABS + TRACT. CONT	2.0 TDCi 140cv (07-..)	ABS/ESP
 New Galaxy	ABS + TRACT. CONT	2.0 TDCi 140cv DPF (07-..)	ABS/ESP
 New Galaxy	ABS + TRACT. CONT	2.3 161cv (07-..)	ABS/ESP
 New Galaxy	AIRBAG	1.8 TDCi 100cv (06-..)	RCM
 New Galaxy	AIRBAG	1.8 TDCi 100cv (10-..)	RCM
 New Galaxy	AIRBAG	1.8 TDCi 125cv (06-..)	RCM
 New Galaxy	AIRBAG	1.8 TDCi 125cv (10-..)	RCM
 New Galaxy	AIRBAG	2.0 145cv (06-..)	RCM
 New Galaxy	AIRBAG	2.0 145cv (10-..)	RCM
 New Galaxy	AIRBAG	2.0 TDCi 130cv (06-..)	RCM
 New Galaxy	AIRBAG	2.0 TDCi 130cv (10-..)	RCM
 New Galaxy	AIRBAG	2.0 TDCi 140cv (06-..)	RCM
 New Galaxy	AIRBAG	2.0 TDCi 140cv (10-..)	RCM
 New Galaxy	AIRBAG	2.0 TDCi 140cv DPF (06-..)	RCM
 New Galaxy	AIRBAG	2.0 TDCi 140cv DPF (10-..)	RCM
 New Galaxy	AIRBAG	2.3 161cv (06-..)	RCM
 New Galaxy	AIRBAG	2.3 161cv (10-..)	RCM
 New Galaxy	ANTITHEFT	1.8 TDCi 100cv (07-..)	
 New Galaxy	ANTITHEFT	1.8 TDCi 125cv (07-..)	
 New Galaxy	ANTITHEFT	2.0 145cv (07-..)	
 New Galaxy	ANTITHEFT	2.0 TDCi 130cv (07-..)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 New Galaxy	ANTITHEFT	2.0 TDCi 140cv (07-..)	
 New Galaxy	ANTITHEFT	2.0 TDCi 140cv DPF (07-..)	
 New Galaxy	ANTITHEFT	2.3 161cv (07-..)	
 New Galaxy	CHASSIS NETWORK	1.8 TDCi 100cv (07-..)	GEM
 New Galaxy	CHASSIS NETWORK	1.8 TDCi 125cv (07-..)	GEM
 New Galaxy	CHASSIS NETWORK	2.0 145cv (07-..)	GEM
 New Galaxy	CHASSIS NETWORK	2.0 TDCi 130cv (07-..)	GEM
 New Galaxy	CHASSIS NETWORK	2.0 TDCi 140cv (07-..)	GEM
 New Galaxy	CHASSIS NETWORK	2.0 TDCi 140cv DPF (07-..)	GEM
 New Galaxy	CHASSIS NETWORK	2.3 161cv (07-..)	GEM
 New Galaxy	CLIMA	1.8 TDCi 100cv (07-..)	EATC
 New Galaxy	CLIMA	1.8 TDCi 125cv (07-..)	EATC
 New Galaxy	CLIMA	2.0 145cv (07-..)	EATC
 New Galaxy	CLIMA	2.0 TDCi 130cv (07-..)	EATC
 New Galaxy	CLIMA	2.0 TDCi 140cv (07-..)	EATC
 New Galaxy	CLIMA	2.0 TDCi 140cv DPF (07-..)	EATC
 New Galaxy	CLIMA	2.3 161cv (07-..)	EATC
 New Galaxy	DASHBOARD	1.8 TDCi 100cv (07-..)	IC
 New Galaxy	DASHBOARD	1.8 TDCi 125cv (07-..)	IC
 New Galaxy	DASHBOARD	2.0 145cv (07-..)	IC
 New Galaxy	DASHBOARD	2.0 TDCi 130cv (07-..)	IC
 New Galaxy	DASHBOARD	2.0 TDCi 140cv (07-..)	IC
 New Galaxy	DASHBOARD	2.0 TDCi 140cv DPF (07-..)	IC
 New Galaxy	DASHBOARD	2.3 161cv (07-..)	IC
 New Galaxy	ELECTRIC STEERING	1.8 TDCi 100cv (07-..)	TSCM
 New Galaxy	ELECTRIC STEERING	1.8 TDCi 125cv (07-..)	TSCM
 New Galaxy	ELECTRIC STEERING	2.0 145cv (07-..)	TSCM
 New Galaxy	ELECTRIC STEERING	2.0 TDCi 130cv (07-..)	TSCM
 New Galaxy	ELECTRIC STEERING	2.0 TDCi 140cv (07-..)	TSCM
 New Galaxy	ELECTRIC STEERING	2.0 TDCi 140cv DPF (07-..)	TSCM
 New Galaxy	ELECTRIC STEERING	2.3 161cv (07-..)	TSCM
 New Galaxy	ENGINE MANAGEME	1.8 TDCi 100cv (07-..)	EOBD
 New Galaxy	ENGINE MANAGEME	1.8 TDCi 125cv (06-..)	EOBD
 New Galaxy	ENGINE MANAGEME	2.0 145cv (07-..)	PCM Duratec
 New Galaxy	ENGINE MANAGEME	2.0 TDCi 130cv (07-..)	EOBD
 New Galaxy	ENGINE MANAGEME	2.0 TDCi 140cv (07-..)	PCM
 New Galaxy	ENGINE MANAGEME	2.0 TDCi 140cv DPF (07-..)	EOBD
 New Galaxy	ENGINE MANAGEME	2.0 TDCi 140cv DPF (07-..)	PCM Duratorq
 New Galaxy	ENGINE MANAGEME	2.3 161cv (06-..)	EOBD
 New Galaxy	MAINTENANCE	1.8 TDCi 100cv	MANUAL
 New Galaxy	MAINTENANCE	1.8 TDCi 125cv	MANUAL
 New Galaxy	MAINTENANCE	2.0 145cv	MANUAL
 New Galaxy	MAINTENANCE	2.0 TDCi 130cv	MANUAL
 New Galaxy	MAINTENANCE	2.0 TDCi 140cv	MANUAL
 New Galaxy	MAINTENANCE	2.0 TDCi 140cv (07-..)	PCM
 New Galaxy	MAINTENANCE	2.0 TDCi 140cv DPF	MANUAL
 New Galaxy	MAINTENANCE	2.3 161cv	MANUAL
 New Galaxy	PARKING HELP	1.8 TDCi 100cv (07-..)	PAM
 New Galaxy	PARKING HELP	1.8 TDCi 125cv (07-..)	PAM
 New Galaxy	PARKING HELP	2.0 145cv (07-..)	PAM
 New Galaxy	PARKING HELP	2.0 TDCi 130cv (07-..)	PAM
 New Galaxy	PARKING HELP	2.0 TDCi 140cv (07-..)	PAM
 New Galaxy	PARKING HELP	2.0 TDCi 140cv DPF (07-..)	PAM
 New Galaxy	PARKING HELP	2.3 161cv (07-..)	PAM
 New Galaxy	RADIO / CD	1.8 TDCi 100cv (07-..)	ACM
 New Galaxy	RADIO / CD	1.8 TDCi 125cv (07-..)	ACM
 New Galaxy	RADIO / CD	2.0 145cv (07-..)	ACM
 New Galaxy	RADIO / CD	2.0 TDCi 130cv (07-..)	ACM

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 New Galaxy	RADIO / CD	2.0 TDCi 140cv (07-..)	ACM
 New Galaxy	RADIO / CD	2.0 TDCi 140cv DPF (07-..)	ACM
 New Galaxy	RADIO / CD	2.3 161cv (07-..)	ACM
 New Galaxy	SERVICE LIGHT RES	1.8 TDCi 100cv	MANUAL
 New Galaxy	SERVICE LIGHT RES	1.8 TDCi 125cv	MANUAL
 New Galaxy	SERVICE LIGHT RES	2.0 145cv	MANUAL
 New Galaxy	SERVICE LIGHT RES	2.0 TDCi 130cv	MANUAL
 New Galaxy	SERVICE LIGHT RES	2.0 TDCi 140cv	MANUAL
 New Galaxy	SERVICE LIGHT RES	2.0 TDCi 140cv DPF	MANUAL
 New Galaxy	SERVICE LIGHT RES	2.3 161cv	MANUAL
 Orion 86	ELECTRONIC IGNITI	1.6 Kat L4B (...-94)	FORD ESC-II KE-Jetr.
 Orion 86	ENGINE MANAGEME	1.4 Kat F6B (...-94)	FORD CFI EEC-IV
 Orion 86	ENGINE MANAGEME	1.4 Kat F6D (...-94)	FORD CFI EEC-IV
 Orion 86	ENGINE MANAGEME	1.6 Kat LJB (...-94)	FORD EFI EEC-IV
 Orion 86	ENGINE MANAGEME	1.6 LJA (...-94)	FORD EFI EEC-IV
 Orion 91	ENGINE MANAGEME	1.3 Kat J6A (...-94)	FORD CFI EEC-IV
 Orion 91	ENGINE MANAGEME	1.4 Kat F6F (...-94)	FORD CFI EEC-IV
 Orion 91	ENGINE MANAGEME	1.4 Kat F6G (...-94)	FORD CFI EEC-IV
 Orion 91	ENGINE MANAGEME	1.6 16v L1E (...-94)	FORD SEFI EEC-IV
 Orion 91	ENGINE MANAGEME	1.6 16v L1E (92-93)	FORD SEFI EEC-IV (Fast)
 Orion 91	ENGINE MANAGEME	1.6 Kat LJF (...-94)	FORD EFI EEC-IV
 Orion 91	ENGINE MANAGEME	1.6 LJE (...-94)	FORD EFI EEC-IV
 Orion 91	ENGINE MANAGEME	1.8 16v RDA (...-94)	FORD SEFI EEC-IV
 Orion 91	ENGINE MANAGEME	1.8 16v RDA (91-93)	FORD SEFI EEC-IV (Fast)
 Orion 91	ENGINE MANAGEME	1.8 16v RQB (...-94)	FORD SEFI EEC-IV
 Orion 91	ENGINE MANAGEME	1.8 16v RQB (92-93)	FORD SEFI EEC-IV (Fast)
 Orion 91	KEY ENCODE	1.3 Kat (...-94)	FORD PATS MANUAL
 Orion 91	KEY ENCODE	1.4 Kat (...-94)	FORD PATS MANUAL
 Orion 91	KEY ENCODE	1.6 (...-94)	FORD PATS MANUAL
 Orion 91	KEY ENCODE	1.6 16v (...-94)	FORD PATS MANUAL
 Orion 91	KEY ENCODE	1.6 Kat (...-94)	FORD PATS MANUAL
 Orion 91	KEY ENCODE	1.8 16v (...-94)	FORD PATS MANUAL
 Orion 91	MAINTENANCE	1.3 Kat (...-94)	FORD PATS MANUAL
 Orion 91	MAINTENANCE	1.4 Kat (...-94)	FORD PATS MANUAL
 Orion 91	MAINTENANCE	1.6 (...-94)	FORD PATS MANUAL
 Orion 91	MAINTENANCE	1.6 16v (...-94)	FORD PATS MANUAL
 Orion 91	MAINTENANCE	1.6 Kat (...-94)	FORD PATS MANUAL
 Orion 91	MAINTENANCE	1.8 16v (...-94)	FORD PATS MANUAL
 Probe	ENGINE MANAGEME	2.0 (96-97)	FORD SEFI EEC-V
 Puma	ABS + TRACT. CONT	1.4 16v	ATE Teves Mk20-I
 Puma	ABS + TRACT. CONT	1.6 16v	ATE Teves Mk20-I
 Puma	ABS + TRACT. CONT	1.7 16v	ATE Teves Mk20-I
 Puma	ABS + TRACT. CONT	ST 160	ATE Teves Mk20-I
 Puma	AIRBAG	1.4 16v (...-99)	FORD AirBag MANUAL
 Puma	AIRBAG	1.6 16v (...-99)	FORD AirBag MANUAL
 Puma	AIRBAG	1.7 16v (...-99)	FORD AirBag MANUAL
 Puma	AIRBAG	Racing (...-99)	FORD AirBag MANUAL
 Puma	AIRBAG	ST 160 (...-99)	FORD AirBag MANUAL
 Puma	ENGINE MANAGEME	1.4 16v FHD (98-..)	FORD SEFI EEC-V
 Puma	ENGINE MANAGEME	1.4 16v FHF (98-..)	FORD SEFI EEC-V
 Puma	ENGINE MANAGEME	1.6 16v (01-..)	EOBD
 Puma	ENGINE MANAGEME	1.7 16v MHA (97-..)	FORD SEFI EEC-V
 Puma	ENGINE MANAGEME	ST 160 (01-..)	EOBD
 Puma	KEY ENCODE	1.4 16v (97-..)	FORD PATS MANUAL
 Puma	KEY ENCODE	1.6 16v (97-..)	FORD PATS MANUAL
 Puma	KEY ENCODE	1.7 16v (97-..)	FORD PATS MANUAL
 Puma	KEY ENCODE	Racing (97-..)	FORD PATS MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Puma	KEY ENCODE	ST 160 (97-..)	FORD PATS MANUAL
 Puma	MAINTENANCE	1.4 16v (..99)	FORD AirBag MANUAL
 Puma	MAINTENANCE	1.4 16v (97-..)	FORD PATS MANUAL
 Puma	MAINTENANCE	1.6 16v (..99)	FORD AirBag MANUAL
 Puma	MAINTENANCE	1.6 16v (97-..)	FORD PATS MANUAL
 Puma	MAINTENANCE	1.7 16v (..99)	FORD AirBag MANUAL
 Puma	MAINTENANCE	1.7 16v (97-..)	FORD PATS MANUAL
 Puma	MAINTENANCE	Racing (..99)	FORD AirBag MANUAL
 Puma	MAINTENANCE	Racing (97-..)	FORD PATS MANUAL
 Puma	MAINTENANCE	ST 160 (..99)	FORD AirBag MANUAL
 Puma	MAINTENANCE	ST 160 (97-..)	FORD PATS MANUAL
 Ranger	ENGINE MANAGEME	2.3 (96-97)	FORD SEFI EEC-V
 Ranger	ENGINE MANAGEME	2.6 (98-00)	FORD SEFI EEC-V
 Ranger	ENGINE MANAGEME	3.0 (96-00)	FORD SEFI EEC-V
 Ranger	ENGINE MANAGEME	4.0 (96-00)	FORD SEFI EEC-V
 Sapphire	ENGINE MANAGEME	1.6 Kat L6B (..-94)	FORD CFI EEC-IV
 Sapphire	ENGINE MANAGEME	1.8 Kat R6A (..-94)	FORD CFI EEC-IV
 Sapphire	ENGINE MANAGEME	2.0 (S-CH) N4A (..-94)	FORD EFI EEC-IV
 Sapphire	ENGINE MANAGEME	2.0 (S-CH) NRB (..-94)	FORD EFI EEC-IV
 Sapphire	ENGINE MANAGEME	2.0 Kat N4B (..-94)	FORD EFI EEC-IV
 Sapphire	ENGINE MANAGEME	2.0 Kat N9C (..-94)	FORD EFI EEC-IV
 Sapphire	ENGINE MANAGEME	2.0 Kat NRD (..-94)	FORD EFI EEC-IV
 Sapphire	ENGINE MANAGEME	2.0 N4A (..-94)	FORD EFI EEC-IV
 Sapphire	ENGINE MANAGEME	2.0 N4I (..-94)	FORD EFI EEC-IV
 Sapphire	ENGINE MANAGEME	2.0 N9A (..-94)	FORD EFI EEC-IV
 Sapphire	ENGINE MANAGEME	2.0 N9E (..-94)	FORD EFI EEC-IV
 Sapphire	ENGINE MANAGEME	2.0 NRB (..-94)	FORD EFI EEC-IV
 Sapphire	ENGINE MANAGEME	2.8 V6 Kat PR5 (..-94)	FORD EFI EEC-IV
 Sapphire	ENGINE MANAGEME	2.8 V6 Kat PR6 (..-94)	FORD EFI EEC-IV
 Sapphire	ENGINE MANAGEME	2.8 V6 Kat PR7 (..-94)	FORD EFI EEC-IV
 Sapphire	ENGINE MANAGEME	2.8 V6 Kat PR8 (..-94)	FORD EFI EEC-IV
 Sapphire	ENGINE MANAGEME	2.8 V6 Kat PRI (..-94)	FORD EFI EEC-IV
 Sapphire	ENGINE MANAGEME	2.8 V6 PR (..-94)	FORD EFI EEC-IV
 Sapphire	ENGINE MANAGEME	2.8 V6 PR5 (..-94)	FORD EFI EEC-IV
 Sapphire	ENGINE MANAGEME	2.8 V6 PR6 (..-94)	FORD EFI EEC-IV
 Sapphire	ENGINE MANAGEME	2.8 V6 PRI (..-94)	FORD EFI EEC-IV
 Sapphire	ENGINE MANAGEME	2.9 V6 B4A (..-94)	FORD EFI EEC-IV
 Sapphire	ENGINE MANAGEME	2.9 V6 Kat B4B (..-94)	FORD EFI EEC-IV
 Sapphire	ENGINE MANAGEME	2.9 V6 Kat B4C (..-94)	FORD EFI EEC-IV
 Scorpio 85	ENGINE MANAGEME	2.0 N9B (..-94)	FORD EFI EEC-IV
 Scorpio 85	ENGINE MANAGEME	2.0 N9D (..-94)	FORD EFI EEC-IV
 Scorpio 85	ENGINE MANAGEME	2.0 N9F (..-94)	FORD EFI EEC-IV
 Scorpio 85	ENGINE MANAGEME	2.0 NRA (..-94)	FORD EFI EEC-IV
 Scorpio 85	ENGINE MANAGEME	2.0 NRC (..-94)	FORD EFI EEC-IV
 Scorpio 85	ENGINE MANAGEME	2.0 NRI (..-94)	FORD EFI EEC-IV
 Scorpio 85	ENGINE MANAGEME	2.4 V6 ARC (..-94)	FORD EFI EEC-IV
 Scorpio 85	ENGINE MANAGEME	2.4 V6 ARD (..-94)	FORD EFI EEC-IV
 Scorpio 85	ENGINE MANAGEME	2.8 V6 (S-CH) PR3 (..-94)	FORD EFI EEC-IV
 Scorpio 85	ENGINE MANAGEME	2.8 V6 (S-CH) PR4 (..-94)	FORD EFI EEC-IV
 Scorpio 85	ENGINE MANAGEME	2.8 V6 (S-CH) PRE (..-94)	FORD EFI EEC-IV
 Scorpio 85	ENGINE MANAGEME	2.9 V6 24v BOA (..-94)	FORD EFI EEC-IV
 Scorpio 85	ENGINE MANAGEME	2.9 V6 24v BOA (93-94)	FORD EFI EEC-IV (Fast)
 Scorpio 85	ENGINE MANAGEME	2.9 V6 BRC (..-94)	FORD EFI EEC-IV
 Scorpio 85	ENGINE MANAGEME	2.9 V6 BRD (..-94)	FORD EFI EEC-IV
 Scorpio 85	ENGINE MANAGEME	2.9 V6 BRE KAT (..-94)	FORD EFI EEC-IV
 Scorpio 85	ENGINE MANAGEME	2.9 V6 BRF KAT (..-94)	FORD EFI EEC-IV
 Scorpio 95	ABS + TRACT. CONT	2.3 16v (97-..)	ATE Teves Mk20-I

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Scorpio 95	ENGINE MANAGEME	2.3 16v Y5A (94-..)	FORD SEFI EEC-V
 Scorpio 95	KEY ENCODE	2.3 16v (95-96)	FORD PATS MANUAL
 Scorpio 95	MAINTENANCE	2.3 16v (95-96)	FORD PATS MANUAL
 Sierra 83	ENGINE MANAGEME	2.0 N4A (S-CH) (...94)	FORD EFI EEC-IV
 Sierra 83	ENGINE MANAGEME	2.0 NR2 (...94)	FORD EFI EEC-IV
 Sierra 83	ENGINE MANAGEME	2.0 NRB (...94)	FORD EFI EEC-IV
 Sierra 83	ENGINE MANAGEME	2.0 NRB (S-CH) (...94)	FORD EFI EEC-IV
 Sierra 83	ENGINE MANAGEME	2.0 NRD KAT (...94)	FORD EFI EEC-IV
 Sierra 83	ENGINE MANAGEME	2.8 V6 PR (...94)	FORD EFI EEC-IV
 Sierra 83	ENGINE MANAGEME	2.8 V6 PR5 (...94)	FORD EFI EEC-IV
 Sierra 83	ENGINE MANAGEME	2.8 V6 PR5 KAT (...94)	FORD EFI EEC-IV
 Sierra 83	ENGINE MANAGEME	2.8 V6 PR6 (...94)	FORD EFI EEC-IV
 Sierra 83	ENGINE MANAGEME	2.8 V6 PR6 KAT (...94)	FORD EFI EEC-IV
 Sierra 83	ENGINE MANAGEME	2.8 V6 PRI (...94)	FORD EFI EEC-IV
 Sierra 83	ENGINE MANAGEME	2.8 V6 PRI KAT (...94)	FORD EFI EEC-IV
 Sierra 87	ENGINE MANAGEME	1.6 Kat L6B (...94)	FORD CFI EEC-IV
 Sierra 87	ENGINE MANAGEME	1.8 Kat R6A (...94)	FORD CFI EEC-IV
 Sierra 87	ENGINE MANAGEME	2.0 Kat N4B (...94)	FORD EFI EEC-IV
 Sierra 87	ENGINE MANAGEME	2.0 Kat N9C (...94)	FORD EFI EEC-IV
 Sierra 87	ENGINE MANAGEME	2.0 N4A (...94)	FORD EFI EEC-IV
 Sierra 87	ENGINE MANAGEME	2.0 N4I (...94)	FORD EFI EEC-IV
 Sierra 87	ENGINE MANAGEME	2.0 N9A (...94)	FORD EFI EEC-IV
 Sierra 87	ENGINE MANAGEME	2.0 N9E (...94)	FORD EFI EEC-IV
 Sierra 87	ENGINE MANAGEME	2.8 V6 Kat PR7 (...94)	FORD EFI EEC-IV
 Sierra 87	ENGINE MANAGEME	2.8 V6 Kat PR8 (...94)	FORD EFI EEC-IV
 Sierra 87	ENGINE MANAGEME	2.9 V6 B4A (...94)	FORD EFI EEC-IV
 Sierra 87	ENGINE MANAGEME	2.9 V6 B4B KAT (...94)	FORD EFI EEC-IV
 Sierra 87	ENGINE MANAGEME	2.9 V6 B4C KAT (...94)	FORD EFI EEC-IV
 S-MAX	ABS + TRACT. CONT	1.8 TDCi 125cv (06-..)	ABS/ESP
 S-MAX	ABS + TRACT. CONT	2.0 145cv (06-..)	ABS/ESP
 S-MAX	ABS + TRACT. CONT	2.0 TDCi 115cv (06-..)	ABS/ESP
 S-MAX	ABS + TRACT. CONT	2.0 TDCi 130cv DPF (06-..)	ABS/ESP
 S-MAX	ABS + TRACT. CONT	2.0 TDCi 140cv (06-..)	ABS/ESP
 S-MAX	ABS + TRACT. CONT	2.0 TDCi 140cv DPF (06-..)	ABS/ESP
 S-MAX	ABS + TRACT. CONT	2.0 TDCi 163cv (06-..)	ABS/ESP
 S-MAX	ABS + TRACT. CONT	2.2 TDCi (06-..)	ABS/ESP
 S-MAX	ABS + TRACT. CONT	2.3 161cv (06-..)	ABS/ESP
 S-MAX	ABS + TRACT. CONT	2.5 220cv (06-..)	ABS/ESP
 S-MAX	AIRBAG	1.8 TDCi 125cv (06-..)	RCM
 S-MAX	AIRBAG	2.0 145cv (06-..)	RCM
 S-MAX	AIRBAG	2.0 TDCi 115cv (06-..)	RCM
 S-MAX	AIRBAG	2.0 TDCi 130cv DPF (06-..)	RCM
 S-MAX	AIRBAG	2.0 TDCi 140cv (06-..)	RCM
 S-MAX	AIRBAG	2.0 TDCi 140cv DPF (06-..)	RCM
 S-MAX	AIRBAG	2.0 TDCi 163cv (06-..)	RCM
 S-MAX	AIRBAG	2.2 TDCi (06-..)	RCM
 S-MAX	AIRBAG	2.3 161cv (06-..)	RCM
 S-MAX	AIRBAG	2.5 220cv (06-..)	RCM
 S-MAX	CHASSIS NETWORK	1.8 TDCi 125cv (06-..)	GEM
 S-MAX	CHASSIS NETWORK	2.0 145cv (06-..)	GEM
 S-MAX	CHASSIS NETWORK	2.0 TDCi 115cv (06-..)	GEM
 S-MAX	CHASSIS NETWORK	2.0 TDCi 130cv DPF (06-..)	GEM
 S-MAX	CHASSIS NETWORK	2.0 TDCi 140cv (06-..)	GEM
 S-MAX	CHASSIS NETWORK	2.0 TDCi 140cv DPF (06-..)	GEM
 S-MAX	CHASSIS NETWORK	2.0 TDCi 163cv (06-..)	GEM
 S-MAX	CHASSIS NETWORK	2.2 TDCi (06-..)	GEM
 S-MAX	CHASSIS NETWORK	2.3 161cv (06-..)	GEM
 S-MAX	CHASSIS NETWORK	2.5 220cv (06-..)	GEM

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 S-MAX	DASHBOARD	1.8 TDCi 125cv (06-..)	IC
 S-MAX	DASHBOARD	2.0 145cv (06-..)	IC
 S-MAX	DASHBOARD	2.0 TDCi 115cv (06-..)	IC
 S-MAX	DASHBOARD	2.0 TDCi 130cv DPF (06-..)	IC
 S-MAX	DASHBOARD	2.0 TDCi 140cv (06-..)	IC
 S-MAX	DASHBOARD	2.0 TDCi 140cv DPF (06-..)	IC
 S-MAX	DASHBOARD	2.0 TDCi 163cv (06-..)	IC
 S-MAX	DASHBOARD	2.2 TDCi (06-..)	IC
 S-MAX	DASHBOARD	2.3 161cv (06-..)	IC
 S-MAX	DASHBOARD	2.5 220cv (06-..)	IC
 S-MAX	ENGINE MANAGEME	1.8 TDCi 125cv (06-..)	PCM Duratorq
 S-MAX	ENGINE MANAGEME	2.0 145cv (06-..)	EOBD
 S-MAX	ENGINE MANAGEME	2.0 TDCi 115cv (06-..)	EOBD
 S-MAX	ENGINE MANAGEME	2.0 TDCi 130cv DPF (06-..)	PCM Duratorq + DPF
 S-MAX	ENGINE MANAGEME	2.0 TDCi 140cv (06-..)	PCM Duratorq
 S-MAX	ENGINE MANAGEME	2.0 TDCi 140cv DPF (06-..)	PCM Duratorq + DPF
 S-MAX	ENGINE MANAGEME	2.0 TDCi 163cv (06-..)	EOBD
 S-MAX	ENGINE MANAGEME	2.2 TDCi (06-..)	EOBD
 S-MAX	ENGINE MANAGEME	2.3 161cv (06-..)	EOBD
 S-MAX	ENGINE MANAGEME	2.5 220cv (06-..)	EOBD
 S-MAX	MAINTENANCE	1.8 TDCi 125cv (06-..)	ABS/ESP
 S-MAX	MAINTENANCE	1.8 TDCi 125cv (06-..)	MANUAL
 S-MAX	MAINTENANCE	2.0 145cv (06-..)	ABS/ESP
 S-MAX	MAINTENANCE	2.0 145cv (06-..)	MANUAL
 S-MAX	MAINTENANCE	2.0 TDCi 115cv (06-..)	ABS/ESP
 S-MAX	MAINTENANCE	2.0 TDCi 115cv (06-..)	MANUAL
 S-MAX	MAINTENANCE	2.0 TDCi 130cv DPF (06-..)	ABS/ESP
 S-MAX	MAINTENANCE	2.0 TDCi 130cv DPF (06-..)	MANUAL
 S-MAX	MAINTENANCE	2.0 TDCi 140cv (06-..)	ABS/ESP
 S-MAX	MAINTENANCE	2.0 TDCi 140cv (06-..)	MANUAL
 S-MAX	MAINTENANCE	2.0 TDCi 140cv (06-..)	PCM Duratorq
 S-MAX	MAINTENANCE	2.0 TDCi 140cv DPF (06-..)	ABS/ESP
 S-MAX	MAINTENANCE	2.0 TDCi 140cv DPF (06-..)	MANUAL
 S-MAX	MAINTENANCE	2.0 TDCi 163cv (06-..)	ABS/ESP
 S-MAX	MAINTENANCE	2.0 TDCi 163cv (06-..)	MANUAL
 S-MAX	MAINTENANCE	2.2 TDCi (06-..)	ABS/ESP
 S-MAX	MAINTENANCE	2.2 TDCi (06-..)	MANUAL
 S-MAX	MAINTENANCE	2.3 161cv (06-..)	ABS/ESP
 S-MAX	MAINTENANCE	2.3 161cv (06-..)	MANUAL
 S-MAX	MAINTENANCE	2.5 220cv (06-..)	ABS/ESP
 S-MAX	MAINTENANCE	2.5 220cv (06-..)	MANUAL
 S-MAX	SERVICE LIGHT RES	1.8 TDCi 125cv (06-..)	MANUAL
 S-MAX	SERVICE LIGHT RES	2.0 145cv (06-..)	MANUAL
 S-MAX	SERVICE LIGHT RES	2.0 TDCi 115cv (06-..)	MANUAL
 S-MAX	SERVICE LIGHT RES	2.0 TDCi 130cv DPF (06-..)	MANUAL
 S-MAX	SERVICE LIGHT RES	2.0 TDCi 140cv (06-..)	MANUAL
 S-MAX	SERVICE LIGHT RES	2.0 TDCi 140cv DPF (06-..)	MANUAL
 S-MAX	SERVICE LIGHT RES	2.0 TDCi 163cv (06-..)	MANUAL
 S-MAX	SERVICE LIGHT RES	2.2 TDCi (06-..)	MANUAL
 S-MAX	SERVICE LIGHT RES	2.3 161cv (06-..)	MANUAL
 S-MAX	SERVICE LIGHT RES	2.5 220cv (06-..)	MANUAL
 Taurus	ENGINE MANAGEME	3.0 (96-00)	FORD SEFI EEC-V
 Taurus	ENGINE MANAGEME	3.0 4v (96-98)	FORD SEFI EEC-V
 Thunderbird	ENGINE MANAGEME	3.8 (96-97)	FORD SEFI EEC-V
 Thunderbird	ENGINE MANAGEME	4.6 (96-97)	FORD SEFI EEC-V
 Tourneo Connect	ABS + TRACT. CONT	1.8 TDCi Duratorq (07-..)	ABS
 Tourneo Connect	ENGINE MANAGEME	1.8 TDCi Duratorq (07-..)	PCM Common Rail
 Tourneo Connect	RADIO / CD	1.8 TDCi Duratorq (07-..)	Audio Module

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Tourneo	ENGINE MANAGEME	2.0 NGS (94-..)	FORD SEFI EEC-V
 Tourneo	ENGINE MANAGEME	2.0 NSF (94-..)	FORD SEFI EEC-V
 Town Car	ENGINE MANAGEME	4.6 (96-00)	FORD SEFI EEC-V
 Tracer	ENGINE MANAGEME	2.0 (97-99)	FORD SEFI EEC-V
 Transit Connect	ABS	1.8 Duratec (07-..)	ABS
 Transit Connect	ABS	1.8 TDCi Duratorq (07-..)	ABS
 Transit Connect	ABS	1.8 TDDi Duratorq (07-..)	ABS
 Transit Connect	AIRBAG	1.8 Duratec (07-..)	RCM
 Transit Connect	AIRBAG	1.8 TDCi Duratorq (07-..)	RCM
 Transit Connect	AIRBAG	1.8 TDDi Duratorq (07-..)	RCM
 Transit Connect	ENGINE MANAGEME	1.8 TDCi Duratorq (07-..)	PCM Common Rail
 Transit Connect	RADIO / CD	1.8 Duratec (07-..)	Audio Module
 Transit Connect	RADIO / CD	1.8 TDCi Duratorq (07-..)	Audio Module
 Transit Connect	RADIO / CD	1.8 TDDi Duratorq (07-..)	Audio Module
 Transit	ABS	2.0	BOSCH ABS 5
 Transit	ABS	2.0 DI	BOSCH ABS 5
 Transit	ABS	2.0 TDCi (00-06)	BOSCH ABS 5
 Transit	ABS	2.2 TDCi 110cv	BOSCH ABS 5
 Transit	ABS	2.2 TDCi 110cv (07-..)	ABS Var.1
 Transit	ABS	2.2 TDCi 110cv (07-..)	ABS Var.2
 Transit	ABS	2.2 TDCi 130cv (07-..)	ABS Var.1
 Transit	ABS	2.2 TDCi 130cv (07-..)	ABS Var.2
 Transit	ABS	2.2 TDCi 140cv	BOSCH ABS 5
 Transit	ABS	2.2 TDCi 140cv (07-..)	ABS Var.1
 Transit	ABS	2.2 TDCi 140cv (07-..)	ABS Var.2
 Transit	ABS	2.2 TDCi 85cv (07-..)	ABS Var.1
 Transit	ABS	2.2 TDCi 85cv (07-..)	ABS Var.2
 Transit	ABS	2.3	BOSCH ABS 5
 Transit	ABS	2.3 (07-..)	ABS Var.1
 Transit	ABS	2.3 (07-..)	ABS Var.2
 Transit	ABS	2.4 D (...00)	BOSCH ABS 5
 Transit	ABS	2.4 DI	BOSCH ABS 5
 Transit	ABS	2.4 TD	BOSCH ABS 5
 Transit	ABS	2.4 TDCi 100cv	BOSCH ABS 5
 Transit	ABS	2.4 TDCi 100cv (07-..)	ABS Var.1
 Transit	ABS	2.4 TDCi 100cv (07-..)	ABS Var.2
 Transit	ABS	2.4 TDCi 115cv	BOSCH ABS 5
 Transit	ABS	2.4 TDCi 115cv (07-..)	ABS Var.1
 Transit	ABS	2.4 TDCi 115cv (07-..)	ABS Var.2
 Transit	ABS	2.4 TDCi 140cv	BOSCH ABS 5
 Transit	ABS	2.4 TDCi 140cv (07-..)	ABS Var.1
 Transit	ABS	2.4 TDCi 140cv (07-..)	ABS Var.2
 Transit	ABS	2.4 TDDi	BOSCH ABS 5
 Transit	ABS	2.4 TDE (00-06)	BOSCH ABS 5
 Transit	ABS	2.5 DI	BOSCH ABS 5
 Transit	ABS	2.5 TD	BOSCH ABS 5
 Transit	ABS	2.5 TDI (...00)	BOSCH ABS 5
 Transit	ABS	3.2 TDCi 200cv	BOSCH ABS 5
 Transit	ABS	3.2 TDCi 200cv (07-..)	ABS Var.1
 Transit	ABS	3.2 TDCi 200cv (07-..)	ABS Var.2
 Transit	AIRBAG	2.0 (...00)	FORD AirBag MANUAL
 Transit	AIRBAG	2.0 (...01)	FORD AirBag SRS
 Transit	AIRBAG	2.0 DI (...00)	FORD AirBag MANUAL
 Transit	AIRBAG	2.0 DI (...01)	FORD AirBag SRS
 Transit	AIRBAG	2.0 TDCi (...00)	FORD AirBag MANUAL
 Transit	AIRBAG	2.0 TDCi (...01)	FORD AirBag SRS
 Transit	AIRBAG	2.2 TDCi 110cv (...00)	FORD AirBag MANUAL

Systems supported by ECUREADER / ECUDECODER (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Transit	AIRBAG	2.2 TDCi 110cv (...01)	FORD AirBag SRS
 Transit	AIRBAG	2.2 TDCi 110cv (07-..)	RCM
 Transit	AIRBAG	2.2 TDCi 130cv (07-..)	RCM
 Transit	AIRBAG	2.2 TDCi 140cv (...00)	FORD AirBag MANUAL
 Transit	AIRBAG	2.2 TDCi 140cv (...01)	FORD AirBag SRS
 Transit	AIRBAG	2.2 TDCi 140cv (07-..)	RCM
 Transit	AIRBAG	2.2 TDCi 85cv (07-..)	RCM
 Transit	AIRBAG	2.3 (...00)	FORD AirBag MANUAL
 Transit	AIRBAG	2.3 (...01)	FORD AirBag SRS
 Transit	AIRBAG	2.3 (07-..)	RCM
 Transit	AIRBAG	2.4 D (...00)	FORD AirBag MANUAL
 Transit	AIRBAG	2.4 D (...00)	FORD AirBag SRS
 Transit	AIRBAG	2.4 DI (...00)	FORD AirBag MANUAL
 Transit	AIRBAG	2.4 DI (...01)	FORD AirBag SRS
 Transit	AIRBAG	2.4 TD (...00)	FORD AirBag MANUAL
 Transit	AIRBAG	2.4 TD (...01)	FORD AirBag SRS
 Transit	AIRBAG	2.4 TDCi 100cv (...00)	FORD AirBag MANUAL
 Transit	AIRBAG	2.4 TDCi 100cv (...01)	FORD AirBag SRS
 Transit	AIRBAG	2.4 TDCi 100cv (07-..)	RCM
 Transit	AIRBAG	2.4 TDCi 115cv (...00)	FORD AirBag MANUAL
 Transit	AIRBAG	2.4 TDCi 115cv (...01)	FORD AirBag SRS
 Transit	AIRBAG	2.4 TDCi 115cv (07-..)	RCM
 Transit	AIRBAG	2.4 TDCi 140cv (...00)	FORD AirBag MANUAL
 Transit	AIRBAG	2.4 TDCi 140cv (...01)	FORD AirBag SRS
 Transit	AIRBAG	2.4 TDCi 140cv (07-..)	RCM
 Transit	AIRBAG	2.4 TDDi (...00)	FORD AirBag MANUAL
 Transit	AIRBAG	2.4 TDDi (...01)	FORD AirBag SRS
 Transit	AIRBAG	2.4 TDE (...00)	FORD AirBag MANUAL
 Transit	AIRBAG	2.4 TDE (...01)	FORD AirBag SRS
 Transit	AIRBAG	2.5 DI (...00)	FORD AirBag MANUAL
 Transit	AIRBAG	2.5 DI (...01)	FORD AirBag SRS
 Transit	AIRBAG	2.5 TD (...00)	FORD AirBag MANUAL
 Transit	AIRBAG	2.5 TD (...01)	FORD AirBag SRS
 Transit	AIRBAG	2.5 TDI (...00)	FORD AirBag MANUAL
 Transit	AIRBAG	2.5 TDI (...00)	FORD AirBag SRS
 Transit	AIRBAG	3.2 TDCi 200cv (...00)	FORD AirBag MANUAL
 Transit	AIRBAG	3.2 TDCi 200cv (...01)	FORD AirBag SRS
 Transit	AIRBAG	3.2 TDCi 200cv (07-..)	RCM
 Transit	CHASSIS NETWORK	2.2 TDCi 110cv (07-..)	Body Computer
 Transit	CHASSIS NETWORK	2.2 TDCi 110cv (07-..)	
 Transit	CHASSIS NETWORK	2.2 TDCi 130cv (07-..)	Body Computer
 Transit	CHASSIS NETWORK	2.2 TDCi 130cv (07-..)	
 Transit	CHASSIS NETWORK	2.2 TDCi 140cv (07-..)	Body Computer
 Transit	CHASSIS NETWORK	2.2 TDCi 140cv (07-..)	
 Transit	CHASSIS NETWORK	2.2 TDCi 85cv (07-..)	Body Computer
 Transit	CHASSIS NETWORK	2.2 TDCi 85cv (07-..)	
 Transit	CHASSIS NETWORK	2.3 (07-..)	Body Computer
 Transit	CHASSIS NETWORK	2.3 (07-..)	
 Transit	CHASSIS NETWORK	2.4 TDCi 100cv (07-..)	Body Computer
 Transit	CHASSIS NETWORK	2.4 TDCi 100cv (07-..)	
 Transit	CHASSIS NETWORK	2.4 TDCi 115cv (07-..)	Body Computer
 Transit	CHASSIS NETWORK	2.4 TDCi 115cv (07-..)	
 Transit	CHASSIS NETWORK	2.4 TDCi 140cv (07-..)	Body Computer
 Transit	CHASSIS NETWORK	2.4 TDCi 140cv (07-..)	
 Transit	CHASSIS NETWORK	3.2 TDCi 200cv (07-..)	Body Computer
 Transit	CHASSIS NETWORK	3.2 TDCi 200cv (07-..)	
 Transit	DASHBOARD	2.2 TDCi 110cv (07-..)	IPC Var.2
 Transit	DASHBOARD	2.2 TDCi 110cv (07-..)	Var.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Transit	DASHBOARD	2.2 TDCi 130cv (07-..)	IPC Var.2
 Transit	DASHBOARD	2.2 TDCi 130cv (07-..)	Var.1
 Transit	DASHBOARD	2.2 TDCi 140cv (07-..)	IPC Var.2
 Transit	DASHBOARD	2.2 TDCi 140cv (07-..)	Var.1
 Transit	DASHBOARD	2.2 TDCi 85cv (07-..)	IPC Var.2
 Transit	DASHBOARD	2.2 TDCi 85cv (07-..)	Var.1
 Transit	DASHBOARD	2.3 (07-..)	IPC Var.2
 Transit	DASHBOARD	2.3 (07-..)	Var.1
 Transit	DASHBOARD	2.4 TDCi 100cv (07-..)	IPC Var.2
 Transit	DASHBOARD	2.4 TDCi 100cv (07-..)	Var.1
 Transit	DASHBOARD	2.4 TDCi 115cv (07-..)	IPC Var.2
 Transit	DASHBOARD	2.4 TDCi 115cv (07-..)	Var.1
 Transit	DASHBOARD	2.4 TDCi 140cv (07-..)	IPC Var.2
 Transit	DASHBOARD	2.4 TDCi 140cv (07-..)	Var.1
 Transit	DASHBOARD	3.2 TDCi 200cv (07-..)	IPC Var.2
 Transit	DASHBOARD	3.2 TDCi 200cv (07-..)	Var.1
 Transit	ENGINE MANAGEME	2.0 (97-..)	FORD SEFI EEC-V
 Transit	ENGINE MANAGEME	2.0 DI (04-06)	EOBD
 Transit	ENGINE MANAGEME	2.0 TDCi (04-06)	EOBD
 Transit	ENGINE MANAGEME	2.2 TDCi 110cv (04-06)	PCM
 Transit	ENGINE MANAGEME	2.2 TDCi 140cv (04-06)	PCM
 Transit	ENGINE MANAGEME	2.4 DI (04-06)	EOBD
 Transit	ENGINE MANAGEME	2.4 TDCi 100cv (07-..)	
 Transit	ENGINE MANAGEME	2.4 TDCi 100cv (07-..)	PCM
 Transit	ENGINE MANAGEME	2.4 TDCi 115cv (07-..)	PCM
 Transit	ENGINE MANAGEME	2.4 TDCi 140cv (07-..)	PCM
 Transit	ENGINE MANAGEME	2.4 TDDi DOFA (..-01)	FORD Diesel - Duratorq-Di EEC-V
 Transit	ENGINE MANAGEME	2.4 TDE (04-06)	EOBD
 Transit	ENGINE MANAGEME	2.5 TD (97-..)	FORD Diesel EEC-V
 Transit	KEY ENCODE	2.0 (..-00)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.0 (95-99)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.0 DI (..-00)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.0 TDCi (..-00)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.2 TDCi 110cv (..-00)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.2 TDCi 110cv (95-99)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.2 TDCi 140cv (..-00)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.2 TDCi 140cv (95-99)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.3 (..-00)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.3 (95-99)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.4 D (..-00)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.4 DI (..-00)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.4 TD (..-00)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.4 TD (95-99)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.4 TDCi 100cv (..-00)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.4 TDCi 100cv (95-99)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.4 TDCi 115cv (..-00)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.4 TDCi 115cv (95-99)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.4 TDCi 140cv (..-00)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.4 TDCi 140cv (95-99)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.4 TDDi (..-00)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.4 TDDi (95-99)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.4 TDE (..-00)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.5 DI (..-00)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.5 TD (..-00)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.5 TD (95-99)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.5 TDI (..-00)	FORD PATS MANUAL
 Transit	KEY ENCODE	3.2 TDCi 200cv (..-00)	FORD PATS MANUAL
 Transit	KEY ENCODE	3.2 TDCi 200cv (95-99)	FORD PATS MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Transit	MAINTENANCE	2.0 (...00)	FORD AirBag MANUAL
 Transit	MAINTENANCE	2.0 (...00)	FORD PATS MANUAL
 Transit	MAINTENANCE	2.0 (00-..)	MANUAL
 Transit	MAINTENANCE	2.0 (95-99)	FORD PATS MANUAL
 Transit	MAINTENANCE	2.0 DI (...00)	FORD AirBag MANUAL
 Transit	MAINTENANCE	2.0 DI (...00)	FORD PATS MANUAL
 Transit	MAINTENANCE	2.0 DI (00-..)	MANUAL
 Transit	MAINTENANCE	2.0 TDCi (...00)	FORD AirBag MANUAL
 Transit	MAINTENANCE	2.0 TDCi (...00)	FORD PATS MANUAL
 Transit	MAINTENANCE	2.0 TDCi (00-..)	MANUAL
 Transit	MAINTENANCE	2.2 TDCi 110cv (...00)	FORD AirBag MANUAL
 Transit	MAINTENANCE	2.2 TDCi 110cv (...00)	FORD PATS MANUAL
 Transit	MAINTENANCE	2.2 TDCi 110cv (00-..)	MANUAL
 Transit	MAINTENANCE	2.2 TDCi 110cv (07-..)	ABS Var.2
 Transit	MAINTENANCE	2.2 TDCi 110cv (95-99)	FORD PATS MANUAL
 Transit	MAINTENANCE	2.2 TDCi 130cv (07-..)	ABS Var.2
 Transit	MAINTENANCE	2.2 TDCi 140cv (...00)	FORD AirBag MANUAL
 Transit	MAINTENANCE	2.2 TDCi 140cv (...00)	FORD PATS MANUAL
 Transit	MAINTENANCE	2.2 TDCi 140cv (00-..)	MANUAL
 Transit	MAINTENANCE	2.2 TDCi 140cv (07-..)	ABS Var.2
 Transit	MAINTENANCE	2.2 TDCi 140cv (95-99)	FORD PATS MANUAL
 Transit	MAINTENANCE	2.2 TDCi 85cv (07-..)	ABS Var.2
 Transit	MAINTENANCE	2.3 (...00)	FORD AirBag MANUAL
 Transit	MAINTENANCE	2.3 (...00)	FORD PATS MANUAL
 Transit	MAINTENANCE	2.3 (00-..)	MANUAL
 Transit	MAINTENANCE	2.3 (07-..)	ABS Var.2
 Transit	MAINTENANCE	2.3 (95-99)	FORD PATS MANUAL
 Transit	MAINTENANCE	2.4 D (...00)	FORD AirBag MANUAL
 Transit	MAINTENANCE	2.4 D (...00)	FORD PATS MANUAL
 Transit	MAINTENANCE	2.4 DI (...00)	FORD AirBag MANUAL
 Transit	MAINTENANCE	2.4 DI (...00)	FORD PATS MANUAL
 Transit	MAINTENANCE	2.4 DI (00-..)	MANUAL
 Transit	MAINTENANCE	2.4 TD (...00)	FORD AirBag MANUAL
 Transit	MAINTENANCE	2.4 TD (...00)	FORD PATS MANUAL
 Transit	MAINTENANCE	2.4 TD (00-..)	MANUAL
 Transit	MAINTENANCE	2.4 TD (95-99)	FORD PATS MANUAL
 Transit	MAINTENANCE	2.4 TDCi 100cv (...00)	FORD AirBag MANUAL
 Transit	MAINTENANCE	2.4 TDCi 100cv (...00)	FORD PATS MANUAL
 Transit	MAINTENANCE	2.4 TDCi 100cv (00-..)	MANUAL
 Transit	MAINTENANCE	2.4 TDCi 100cv (07-..)	ABS Var.2
 Transit	MAINTENANCE	2.4 TDCi 100cv (95-99)	FORD PATS MANUAL
 Transit	MAINTENANCE	2.4 TDCi 115cv (...00)	FORD AirBag MANUAL
 Transit	MAINTENANCE	2.4 TDCi 115cv (...00)	FORD PATS MANUAL
 Transit	MAINTENANCE	2.4 TDCi 115cv (00-..)	MANUAL
 Transit	MAINTENANCE	2.4 TDCi 115cv (07-..)	ABS Var.2
 Transit	MAINTENANCE	2.4 TDCi 115cv (95-99)	FORD PATS MANUAL
 Transit	MAINTENANCE	2.4 TDCi 140cv (...00)	FORD AirBag MANUAL
 Transit	MAINTENANCE	2.4 TDCi 140cv (...00)	FORD PATS MANUAL
 Transit	MAINTENANCE	2.4 TDCi 140cv (00-..)	MANUAL
 Transit	MAINTENANCE	2.4 TDCi 140cv (07-..)	ABS Var.2
 Transit	MAINTENANCE	2.4 TDCi 140cv (95-99)	FORD PATS MANUAL
 Transit	MAINTENANCE	2.4 TDDi (...00)	FORD AirBag MANUAL
 Transit	MAINTENANCE	2.4 TDDi (...00)	FORD PATS MANUAL
 Transit	MAINTENANCE	2.4 TDDi (00-..)	MANUAL
 Transit	MAINTENANCE	2.4 TDDi (95-99)	FORD PATS MANUAL
 Transit	MAINTENANCE	2.4 TDE (...00)	FORD AirBag MANUAL
 Transit	MAINTENANCE	2.4 TDE (...00)	FORD PATS MANUAL
 Transit	MAINTENANCE	2.4 TDE (00-..)	MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Transit	MAINTENANCE	2.5 DI (.-00)	FORD AirBag MANUAL
 Transit	MAINTENANCE	2.5 DI (.-00)	FORD PATS MANUAL
 Transit	MAINTENANCE	2.5 DI (00-..)	MANUAL
 Transit	MAINTENANCE	2.5 TD (.-00)	FORD AirBag MANUAL
 Transit	MAINTENANCE	2.5 TD (.-00)	FORD PATS MANUAL
 Transit	MAINTENANCE	2.5 TD (00-..)	MANUAL
 Transit	MAINTENANCE	2.5 TD (95-99)	FORD PATS MANUAL
 Transit	MAINTENANCE	2.5 TDI (.-00)	FORD AirBag MANUAL
 Transit	MAINTENANCE	2.5 TDI (.-00)	FORD PATS MANUAL
 Transit	MAINTENANCE	3.2 TDCi 200cv (.-00)	FORD AirBag MANUAL
 Transit	MAINTENANCE	3.2 TDCi 200cv (.-00)	FORD PATS MANUAL
 Transit	MAINTENANCE	3.2 TDCi 200cv (00-..)	MANUAL
 Transit	MAINTENANCE	3.2 TDCi 200cv (07-..)	ABS Var.2
 Transit	MAINTENANCE	3.2 TDCi 200cv (95-99)	FORD PATS MANUAL
 Transit	SERVICE LIGHT RES	2.0 (00-..)	MANUAL
 Transit	SERVICE LIGHT RES	2.0 DI (00-..)	MANUAL
 Transit	SERVICE LIGHT RES	2.0 TDCi (00-..)	MANUAL
 Transit	SERVICE LIGHT RES	2.2 TDCi 110cv (00-..)	MANUAL
 Transit	SERVICE LIGHT RES	2.2 TDCi 140cv (00-..)	MANUAL
 Transit	SERVICE LIGHT RES	2.3 (00-..)	MANUAL
 Transit	SERVICE LIGHT RES	2.4 DI (00-..)	MANUAL
 Transit	SERVICE LIGHT RES	2.4 TD (00-..)	MANUAL
 Transit	SERVICE LIGHT RES	2.4 TDCi 100cv (00-..)	MANUAL
 Transit	SERVICE LIGHT RES	2.4 TDCi 115cv (00-..)	MANUAL
 Transit	SERVICE LIGHT RES	2.4 TDCi 140cv (00-..)	MANUAL
 Transit	SERVICE LIGHT RES	2.4 TDDi (00-..)	MANUAL
 Transit	SERVICE LIGHT RES	2.4 TDE (00-..)	MANUAL
 Transit	SERVICE LIGHT RES	2.5 DI (00-..)	MANUAL
 Transit	SERVICE LIGHT RES	2.5 TD (00-..)	MANUAL
 Transit	SERVICE LIGHT RES	3.2 TDCi 200cv (00-..)	MANUAL
 Windstar	ENGINE MANAGEME	3.0 (94-..)	FORD SEFI EEC-V
 Windstar	ENGINE MANAGEME	3.0 (97-00)	FORD SEFI EEC-V
 Windstar	ENGINE MANAGEME	3.8 (97-00)	FORD SEFI EEC-V

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Holden

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Astra AH	ABS	1.3 16v CDTI (04-..)	TEVES ABS Mk70
 Astra AH	ABS	1.4 16v (04-..)	TEVES ABS Mk70
 Astra AH	ABS	1.6 16v (04-..)	TEVES ABS Mk70
 Astra AH	ABS	1.7 16v CDTI (04-..)	TEVES ABS Mk70
 Astra AH	ABS	1.8 16v (04-..)	TEVES ABS Mk70
 Astra AH	ABS	1.9 16v CDTI (04-..)	TEVES ABS Mk70
 Astra AH	ABS	1.9 CDTI (04-..)	TEVES ABS Mk70
 Astra AH	ABS	2.0 T 16v (04-..)	TEVES ABS Mk70
 Astra AH	AIRBAG	1.3 16v CDTI (04-..)	TEMIC AirBag MRSZ
 Astra AH	AIRBAG	1.4 16v (04-..)	TEMIC AirBag MRSZ
 Astra AH	AIRBAG	1.6 16v (04-..)	TEMIC AirBag MRSZ
 Astra AH	AIRBAG	1.7 16v CDTI (04-..)	TEMIC AirBag MRSZ
 Astra AH	AIRBAG	1.8 16v (04-..)	TEMIC AirBag MRSZ
 Astra AH	AIRBAG	1.9 16v CDTI (04-..)	TEMIC AirBag MRSZ
 Astra AH	AIRBAG	1.9 CDTI (04-..)	TEMIC AirBag MRSZ
 Astra AH	AIRBAG	2.0 T 16v (04-..)	TEMIC AirBag MRSZ
 Astra AH	AIRBAG CODING	1.3 16v CDTI (04-..)	Temic SRS
 Astra AH	AIRBAG CODING	1.4 16v (04-..)	Temic SRS
 Astra AH	AIRBAG CODING	1.6 16v (04-..)	Temic SRS
 Astra AH	AIRBAG CODING	1.7 16v CDTI (04-..)	Temic SRS
 Astra AH	AIRBAG CODING	1.8 16v (04-..)	Temic SRS
 Astra AH	AIRBAG CODING	1.9 16v CDTI (04-..)	Temic SRS
 Astra AH	AIRBAG CODING	1.9 CDTI (04-..)	Temic SRS
 Astra AH	AIRBAG CODING	2.0 T 16v (04-..)	Temic SRS
 Astra AH	CHASSIS NETWORK	1.3 16v CDTI (04-..)	EUC Front Module
 Astra AH	CHASSIS NETWORK	1.3 16v CDTI (04-..)	REC Rear Module
 Astra AH	CHASSIS NETWORK	1.4 16v (04-..)	EUC Front Module
 Astra AH	CHASSIS NETWORK	1.4 16v (04-..)	REC Rear Module
 Astra AH	CHASSIS NETWORK	1.6 16v (04-..)	EUC Front Module
 Astra AH	CHASSIS NETWORK	1.6 16v (04-..)	REC Rear Module
 Astra AH	CHASSIS NETWORK	1.7 16v CDTI (04-..)	EUC Front Module
 Astra AH	CHASSIS NETWORK	1.7 16v CDTI (04-..)	REC Rear Module
 Astra AH	CHASSIS NETWORK	1.8 16v (04-..)	EUC Front Module
 Astra AH	CHASSIS NETWORK	1.8 16v (04-..)	REC Rear Module
 Astra AH	CHASSIS NETWORK	1.9 16v CDTI (04-..)	REC Rear Module
 Astra AH	CHASSIS NETWORK	1.9 CDTI (04-..)	EUC Front Module
 Astra AH	CHASSIS NETWORK	1.9 CDTI (04-..)	REC Rear Module
 Astra AH	CHASSIS NETWORK	2.0 T 16v (04-..)	EUC Front Module
 Astra AH	CHASSIS NETWORK	2.0 T 16v (04-..)	REC Rear Module
 Astra AH	DASHBOARD	1.3 16v CDTI (04-..)	Dashboard
 Astra AH	DASHBOARD	1.4 16v (04-..)	Dashboard
 Astra AH	DASHBOARD	1.6 16v (04-..)	Dashboard
 Astra AH	DASHBOARD	1.7 16v CDTI (04-..)	Dashboard
 Astra AH	DASHBOARD	1.8 16v (04-..)	Dashboard
 Astra AH	DASHBOARD	1.9 16v CDTI (04-..)	Dashboard
 Astra AH	DASHBOARD	1.9 CDTI (04-..)	Dashboard
 Astra AH	DASHBOARD	2.0 T 16v (04-..)	Dashboard
 Astra AH	ELECTRIC STEERING	1.3 16v CDTI (04-..)	EHPS
 Astra AH	ELECTRIC STEERING	1.3 16v CDTI (06-..)	EHPS No CAN
 Astra AH	ELECTRIC STEERING	1.4 16v (04-..)	EHPS
 Astra AH	ELECTRIC STEERING	1.4 16v (06-..)	EHPS No CAN
 Astra AH	ELECTRIC STEERING	1.6 16v (04-..)	EHPS
 Astra AH	ELECTRIC STEERING	1.6 16v (06-..)	EHPS No CAN
 Astra AH	ELECTRIC STEERING	1.7 16v CDTI (04-..)	EHPS
 Astra AH	ELECTRIC STEERING	1.7 16v CDTI (06-..)	EHPS No CAN
 Astra AH	ELECTRIC STEERING	1.8 16v (04-..)	EHPS
 Astra AH	ELECTRIC STEERING	1.8 16v (06-..)	EHPS No CAN
 Astra AH	ELECTRIC STEERING	1.9 16v CDTI (04-..)	EHPS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Holden

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Astra AH	ELECTRIC STEERING	1.9 16v CDTI (06-..)	EHPS No CAN
 Astra AH	ELECTRIC STEERING	1.9 CDTI (04-..)	EHPS
 Astra AH	ELECTRIC STEERING	2.0 T 16v (04-..)	EHPS
 Astra AH	ELECTRIC STEERING	2.0 T 16v (06-..)	EHPS No CAN
 Astra AH	ENGINE MANAGEME	1.3 16v CDTI Z13DTH	Marelli Multijet 602 Common Rail
 Astra AH	ENGINE MANAGEME	1.4 16v Z14XEP	SIEMENS MPI MS75
 Astra AH	ENGINE MANAGEME	1.6 16v Z16XER	SIEMENS MPI MS75
 Astra AH	ENGINE MANAGEME	1.7 16v CDTI Z17DTH (04-..)	BOSCH EDC 16 Common Rail
 Astra AH	ENGINE MANAGEME	1.8 16v Z18XER	SIEMENS MPI MS75
 Astra AH	ENGINE MANAGEME	1.9 16v CDTI Z19DT (04-..)	BOSCH EDC 16 Common Rail
 Astra AH	ENGINE MANAGEME	1.9 CDTI Z19DTH (04-..)	BOSCH EDC 16 Common Rail
 Astra AH	KEY ENCODE	1.3 16v CDTI (04-..)	Valeo CIM
 Astra AH	KEY ENCODE	1.4 16v (04-..)	Valeo CIM
 Astra AH	KEY ENCODE	1.6 16v (04-..)	Valeo CIM
 Astra AH	KEY ENCODE	1.7 16v CDTI (04-..)	Valeo CIM
 Astra AH	KEY ENCODE	1.8 16v (04-..)	Valeo CIM
 Astra AH	KEY ENCODE	1.9 16v CDTI (04-..)	Valeo CIM
 Astra AH	KEY ENCODE	1.9 CDTI (04-..)	Valeo CIM
 Astra AH	KEY ENCODE	2.0 T 16v (04-..)	Valeo CIM
 Astra AH	MAINTENANCE	1.3 16v CDTI (04-..)	Dashboard
 Astra AH	MAINTENANCE	1.3 16v CDTI (04-..)	Dashboard
 Astra AH	MAINTENANCE	1.3 16v CDTI (04-..)	Dashboard
 Astra AH	MAINTENANCE	1.3 16v CDTI (04-..)	IPC
 Astra AH	MAINTENANCE	1.3 16v CDTI (04-..)	MANUAL
 Astra AH	MAINTENANCE	1.4 16v (04-..)	Dashboard
 Astra AH	MAINTENANCE	1.4 16v (04-..)	Dashboard
 Astra AH	MAINTENANCE	1.4 16v (04-..)	Dashboard
 Astra AH	MAINTENANCE	1.4 16v (04-..)	IPC
 Astra AH	MAINTENANCE	1.4 16v (04-..)	MANUAL
 Astra AH	MAINTENANCE	1.4 16v Z14XEP	SIEMENS MPI MS75
 Astra AH	MAINTENANCE	1.6 16v (04-..)	Dashboard
 Astra AH	MAINTENANCE	1.6 16v (04-..)	Dashboard
 Astra AH	MAINTENANCE	1.6 16v (04-..)	Dashboard
 Astra AH	MAINTENANCE	1.6 16v (04-..)	IPC
 Astra AH	MAINTENANCE	1.6 16v (04-..)	MANUAL
 Astra AH	MAINTENANCE	1.6 16v Z16XER	SIEMENS MPI MS75
 Astra AH	MAINTENANCE	1.7 16v CDTI (04-..)	Dashboard
 Astra AH	MAINTENANCE	1.7 16v CDTI (04-..)	Dashboard
 Astra AH	MAINTENANCE	1.7 16v CDTI (04-..)	Dashboard
 Astra AH	MAINTENANCE	1.7 16v CDTI (04-..)	IPC
 Astra AH	MAINTENANCE	1.7 16v CDTI (04-..)	MANUAL
 Astra AH	MAINTENANCE	1.8 16v (04-..)	Dashboard
 Astra AH	MAINTENANCE	1.8 16v (04-..)	Dashboard
 Astra AH	MAINTENANCE	1.8 16v (04-..)	Dashboard
 Astra AH	MAINTENANCE	1.8 16v (04-..)	IPC
 Astra AH	MAINTENANCE	1.8 16v (04-..)	MANUAL
 Astra AH	MAINTENANCE	1.8 16v Z18XER	SIEMENS MPI MS75
 Astra AH	MAINTENANCE	1.9 16v CDTI (04-..)	Dashboard
 Astra AH	MAINTENANCE	1.9 16v CDTI (04-..)	Dashboard
 Astra AH	MAINTENANCE	1.9 16v CDTI (04-..)	Dashboard
 Astra AH	MAINTENANCE	1.9 16v CDTI (04-..)	IPC
 Astra AH	MAINTENANCE	1.9 16v CDTI (04-..)	MANUAL
 Astra AH	MAINTENANCE	1.9 CDTI (04-..)	Dashboard
 Astra AH	MAINTENANCE	1.9 CDTI (04-..)	Dashboard
 Astra AH	MAINTENANCE	1.9 CDTI (04-..)	Dashboard
 Astra AH	MAINTENANCE	1.9 CDTI (04-..)	IPC
 Astra AH	MAINTENANCE	1.9 CDTI (04-..)	MANUAL
 Astra AH	MAINTENANCE	2.0 T 16v (04-..)	Dashboard

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Holden

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Astra AH	MAINTENANCE	2.0 T 16v (04-..)	Dashboard
 Astra AH	MAINTENANCE	2.0 T 16v (04-..)	Dashboard
 Astra AH	MAINTENANCE	2.0 T 16v (04-..)	IPC
 Astra AH	MAINTENANCE	2.0 T 16v (04-..)	MANUAL
 Astra AH	SERVICE LIGHT RES	1.3 16v CDTI (04-..)	IPC
 Astra AH	SERVICE LIGHT RES	1.3 16v CDTI (04-..)	MANUAL
 Astra AH	SERVICE LIGHT RES	1.4 16v (04-..)	IPC
 Astra AH	SERVICE LIGHT RES	1.4 16v (04-..)	MANUAL
 Astra AH	SERVICE LIGHT RES	1.6 16v (04-..)	IPC
 Astra AH	SERVICE LIGHT RES	1.6 16v (04-..)	MANUAL
 Astra AH	SERVICE LIGHT RES	1.7 16v CDTI (04-..)	IPC
 Astra AH	SERVICE LIGHT RES	1.7 16v CDTI (04-..)	MANUAL
 Astra AH	SERVICE LIGHT RES	1.8 16v (04-..)	IPC
 Astra AH	SERVICE LIGHT RES	1.8 16v (04-..)	MANUAL
 Astra AH	SERVICE LIGHT RES	1.9 16v CDTI (04-..)	IPC
 Astra AH	SERVICE LIGHT RES	1.9 16v CDTI (04-..)	MANUAL
 Astra AH	SERVICE LIGHT RES	1.9 CDTI (04-..)	IPC
 Astra AH	SERVICE LIGHT RES	1.9 CDTI (04-..)	MANUAL
 Astra AH	SERVICE LIGHT RES	2.0 T 16v (04-..)	IPC
 Astra AH	SERVICE LIGHT RES	2.0 T 16v (04-..)	MANUAL
 Astra AH	STEERING WHEEL E	1.3 16v CDTI (04-..)	Valeo CIM
 Astra AH	STEERING WHEEL E	1.4 16v (04-..)	Valeo CIM
 Astra AH	STEERING WHEEL E	1.6 16v (04-..)	Valeo CIM
 Astra AH	STEERING WHEEL E	1.7 16v CDTI (04-..)	Valeo CIM
 Astra AH	STEERING WHEEL E	1.8 16v (04-..)	Valeo CIM
 Astra AH	STEERING WHEEL E	1.9 16v CDTI (04-..)	Valeo CIM
 Astra AH	STEERING WHEEL E	1.9 CDTI (04-..)	Valeo CIM
 Astra AH	STEERING WHEEL E	2.0 T 16v (04-..)	Valeo CIM
 Astra TR	ENGINE MANAGEME	1.4 14SE (93-94)	GM Multec M
 Astra TR	ENGINE MANAGEME	1.4 14SE (95-98)	GM Multec M + Immob.
 Astra TR	ENGINE MANAGEME	1.4 16v X14XE (96-98)	GM Multec (F)
 Astra TR	ENGINE MANAGEME	1.4 C14NZ (92-94)	GM Multec TBI
 Astra TR	ENGINE MANAGEME	1.4 C14SE (92-94)	GM Multec M
 Astra TR	ENGINE MANAGEME	1.4 C14SE (95-98)	GM Multec M + Immob.
 Astra TR	ENGINE MANAGEME	1.4 X14NZ (01-..)	EOBD
 Astra TR	ENGINE MANAGEME	1.6 16LZ2 (95-96)	GM Multec TBI
 Astra TR	ENGINE MANAGEME	1.6 16LZ2 (95-96)	GM Multec TBI + Immob.
 Astra TR	ENGINE MANAGEME	1.6 16SZR (96-98)	GM Multec F
 Astra TR	ENGINE MANAGEME	1.6 16v X16XEL (..-95)	GM Multec S
 Astra TR	ENGINE MANAGEME	1.6 16v X16XEL (96-98)	GM Multec S
 Astra TR	ENGINE MANAGEME	1.6 16v X16XEL (96-98)	GM Multec S (F)
 Astra TR	ENGINE MANAGEME	1.6 C16SE (92-94)	GM Multec M
 Astra TR	ENGINE MANAGEME	1.6 Kat C16NZ (92-..)	GM Multec TBI MANUAL
 Astra TR	ENGINE MANAGEME	1.6 X16NE (01-..)	EOBD
 Astra TR	ENGINE MANAGEME	1.6 X16SZ (93-94)	GM Multec SZ
 Astra TR	ENGINE MANAGEME	1.6 X16SZ (95-96)	GM Multec SZ
 Astra TR	ENGINE MANAGEME	1.6 X16SZR (96-98)	GM Multec S (F)
 Astra TR	ENGINE MANAGEME	1.8 16v C18XE (..-95)	SIEMENS Simtec 56.0
 Astra TR	ENGINE MANAGEME	1.8 16v X18XE (96-98)	SIEMENS Simtec 56.5
 Astra TR	ENGINE MANAGEME	1.8 C18NZ (..-94)	GM Multec TBI
 Astra TR	ENGINE MANAGEME	2.0 16v C20XE (..-92)	BOSCH Motronic M2.5
 Astra TR	ENGINE MANAGEME	2.0 16v C20XE (93-98)	BOSCH Motronic M2.8
 Astra TR	ENGINE MANAGEME	2.0 16v X20XEV (..-95)	SIEMENS Simtec 56.0 - 56.1
 Astra TR	ENGINE MANAGEME	2.0 16v X20XEV (96-98)	SIEMENS Simtec 56.5
 Astra TR	ENGINE MANAGEME	2.0 C20NE (92-98)	BOSCH Motronic M1.5.2
 Astra TR	IMMOBILIZER	1.4 (96-97)	GM Immobilizer
 Astra TR	IMMOBILIZER	1.4 16v (96-97)	GM Immobilizer
 Astra TR	IMMOBILIZER	1.6 (96-97)	GM Immobilizer

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Holden

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Astra TR	IMMOBILIZER	1.6 16v (96-97)	GM Immobilizer
 Astra TR	IMMOBILIZER	1.6 Kat (96-97)	GM Immobilizer
 Astra TR	IMMOBILIZER	1.8 (96-97)	GM Immobilizer
 Astra TR	IMMOBILIZER	1.8 16v (96-97)	GM Immobilizer
 Astra TR	IMMOBILIZER	2.0 (96-97)	GM Immobilizer
 Astra TR	IMMOBILIZER	2.0 16v (96-97)	GM Immobilizer
 Astra TR	MAINTENANCE	1.6 Kat C16NZ (92-..)	GM Multec TBI MANUAL
 Astra TS	AIRBAG	1.2 (...00)	SIEMENS AirBag SAB6
 Astra TS	AIRBAG	1.2 (00-..)	SIEMENS AirBag SAB6m
 Astra TS	AIRBAG	1.2 (01-..)	SIEMENS AirBag SAB8x
 Astra TS	AIRBAG	1.2 16v (...00)	SIEMENS AirBag SAB6
 Astra TS	AIRBAG	1.2 16v (00-..)	SIEMENS AirBag SAB6m
 Astra TS	AIRBAG	1.2 16v (01-..)	SIEMENS AirBag SAB8x
 Astra TS	AIRBAG	1.4 (...00)	SIEMENS AirBag SAB6
 Astra TS	AIRBAG	1.4 (00-..)	SIEMENS AirBag SAB6m
 Astra TS	AIRBAG	1.4 (01-..)	SIEMENS AirBag SAB8x
 Astra TS	AIRBAG	1.4 16v (...00)	SIEMENS AirBag SAB6
 Astra TS	AIRBAG	1.4 16v (00-..)	SIEMENS AirBag SAB6m
 Astra TS	AIRBAG	1.4 16v (01-..)	SIEMENS AirBag SAB8x
 Astra TS	AIRBAG	1.6 (...00)	SIEMENS AirBag SAB6
 Astra TS	AIRBAG	1.6 (00-..)	SIEMENS AirBag SAB6m
 Astra TS	AIRBAG	1.6 (01-..)	SIEMENS AirBag SAB8x
 Astra TS	AIRBAG	1.6 16v (...00)	SIEMENS AirBag SAB6
 Astra TS	AIRBAG	1.6 16v (00-..)	SIEMENS AirBag SAB6m
 Astra TS	AIRBAG	1.6 16v (01-..)	SIEMENS AirBag SAB8x
 Astra TS	AIRBAG	1.7 DTL (...00)	SIEMENS AirBag SAB6
 Astra TS	AIRBAG	1.7 DTL (00-..)	SIEMENS AirBag SAB6m
 Astra TS	AIRBAG	1.7 DTL (01-..)	SIEMENS AirBag SAB8x
 Astra TS	AIRBAG	1.7 TD (...00)	SIEMENS AirBag SAB6
 Astra TS	AIRBAG	1.7 TD (00-..)	SIEMENS AirBag SAB6m
 Astra TS	AIRBAG	1.7 TD (01-..)	SIEMENS AirBag SAB8x
 Astra TS	AIRBAG	1.8 (...00)	SIEMENS AirBag SAB6
 Astra TS	AIRBAG	1.8 (00-..)	SIEMENS AirBag SAB6m
 Astra TS	AIRBAG	1.8 (01-..)	SIEMENS AirBag SAB8x
 Astra TS	AIRBAG	1.8 16v (...00)	SIEMENS AirBag SAB6
 Astra TS	AIRBAG	1.8 16v (00-..)	SIEMENS AirBag SAB6m
 Astra TS	AIRBAG	1.8 16v (01-..)	SIEMENS AirBag SAB8x
 Astra TS	AIRBAG	2.0 (...00)	SIEMENS AirBag SAB6
 Astra TS	AIRBAG	2.0 (00-..)	SIEMENS AirBag SAB6m
 Astra TS	AIRBAG	2.0 (01-..)	SIEMENS AirBag SAB8x
 Astra TS	AIRBAG	2.0 16v (...00)	SIEMENS AirBag SAB6
 Astra TS	AIRBAG	2.0 16v (00-..)	SIEMENS AirBag SAB6m
 Astra TS	AIRBAG	2.0 16v (01-..)	SIEMENS AirBag SAB8x
 Astra TS	AIRBAG	2.0 TD 16v (...00)	SIEMENS AirBag SAB6
 Astra TS	AIRBAG	2.0 TD 16v (00-..)	SIEMENS AirBag SAB6m
 Astra TS	AIRBAG	2.0 TD 16v (01-..)	SIEMENS AirBag SAB8x
 Astra TS	AIRBAG	2.2 (...00)	SIEMENS AirBag SAB6
 Astra TS	AIRBAG	2.2 (00-..)	SIEMENS AirBag SAB6m
 Astra TS	AIRBAG	2.2 (01-..)	SIEMENS AirBag SAB8x
 Astra TS	ENGINE COOLING	1.2 16v X12XE (98-..)	BOSCH xx
 Astra TS	ENGINE COOLING	1.4 16v X14XE (98-..)	BOSCH xx
 Astra TS	ENGINE COOLING	1.6 1.6SZR (98-..)	BOSCH xx
 Astra TS	ENGINE COOLING	1.6 16v X16XEL (98-..)	BOSCH xx
 Astra TS	ENGINE COOLING	1.7 TD X17DTL (98-..)	BOSCH xx
 Astra TS	ENGINE COOLING	1.8 16v X18XE1 (98-..)	BOSCH xx
 Astra TS	ENGINE COOLING	2.0 TD 16v X20DTL (98-..)	BOSCH xx
 Astra TS	ENGINE MANAGEME	1.2 16v X12XE (98-00)	BOSCH Motronic M1.5.5
 Astra TS	ENGINE MANAGEME	1.2 16v Z12XE (01-..)	BOSCH Motronic M1.5.5

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Holden

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Astra TS	ENGINE MANAGEME	1.2 Z12SE (01-..)	EOBD
 Astra TS	ENGINE MANAGEME	1.4 16v X14XE (98-00)	GM Multec H
 Astra TS	ENGINE MANAGEME	1.4 16v Z14XE (...01)	GM Multec
 Astra TS	ENGINE MANAGEME	1.4 Z14SE (01-..)	EOBD
 Astra TS	ENGINE MANAGEME	1.6 16SZR (98-00)	GM Multec F
 Astra TS	ENGINE MANAGEME	1.6 16v X16XEL (98-00)	GM Multec H
 Astra TS	ENGINE MANAGEME	1.6 16v Z16SE (01-..)	EOBD
 Astra TS	ENGINE MANAGEME	1.6 16v Z16XE (...04)	GM Multec H
 Astra TS	ENGINE MANAGEME	1.6 Z16SE (01-..)	EOBD
 Astra TS	ENGINE MANAGEME	1.6 Z16SZR (01-..)	EOBD
 Astra TS	ENGINE MANAGEME	1.6 Z16XE (01-..)	EOBD
 Astra TS	ENGINE MANAGEME	1.7 DTL Y17DT (01-..)	DELPHI EDC HDRC
 Astra TS	ENGINE MANAGEME	1.7 DTL Y17DT (99-01)	DELPHI EDC HDRC
 Astra TS	ENGINE MANAGEME	1.7 TD X17DTL (98-00)	BOSCH EDC MSA 15 M
 Astra TS	ENGINE MANAGEME	1.8 16v X18XE1 (98-00)	SIEMENS Simtec 70
 Astra TS	ENGINE MANAGEME	1.8 Z18XE (01-..)	EOBD
 Astra TS	ENGINE MANAGEME	1.8 Z18XEL (01-..)	EOBD
 Astra TS	ENGINE MANAGEME	2.0 16v X20XEV (98-00)	SIEMENS Simtec 70
 Astra TS	ENGINE MANAGEME	2.0 TD 16v X20DTL (98-00)	BOSCH EDC MSA 15 M
 Astra TS	ENGINE MANAGEME	2.0 TD 16v Y20DTH (01-..)	BOSCH EDC MSA 15 M
 Astra TS	ENGINE MANAGEME	2.0 Z20LET (01-..)	EOBD
 Astra TS	ENGINE MANAGEME	2.2 Z22SE (01-..)	EOBD
 Astra TS	IMMOBILIZER	1.2 (99-..)	SIEMENS
 Astra TS	IMMOBILIZER	1.2 16v (99-..)	SIEMENS
 Astra TS	IMMOBILIZER	1.4 (99-..)	SIEMENS
 Astra TS	IMMOBILIZER	1.4 16v (99-..)	SIEMENS
 Astra TS	IMMOBILIZER	1.6 (99-..)	SIEMENS
 Astra TS	IMMOBILIZER	1.6 16v (99-..)	SIEMENS
 Astra TS	IMMOBILIZER	1.7 DTL (99-..)	SIEMENS
 Astra TS	IMMOBILIZER	1.7 TD (99-..)	SIEMENS
 Astra TS	IMMOBILIZER	1.8 (99-..)	SIEMENS
 Astra TS	IMMOBILIZER	1.8 16v (99-..)	SIEMENS
 Astra TS	IMMOBILIZER	2.0 (99-..)	SIEMENS
 Astra TS	IMMOBILIZER	2.0 16v (99-..)	SIEMENS
 Astra TS	IMMOBILIZER	2.0 TD 16v (99-..)	SIEMENS
 Astra TS	IMMOBILIZER	2.2 (99-..)	SIEMENS
 Astra TS	MAINTENANCE	1.2 (98-00)	GM MANUAL
 Astra TS	MAINTENANCE	1.2 16v (98-00)	GM MANUAL
 Astra TS	MAINTENANCE	1.4 (98-00)	GM MANUAL
 Astra TS	MAINTENANCE	1.4 16v (98-00)	GM MANUAL
 Astra TS	MAINTENANCE	1.6 (98-00)	GM MANUAL
 Astra TS	MAINTENANCE	1.6 16v (98-00)	GM MANUAL
 Astra TS	MAINTENANCE	1.7 DTL (98-00)	GM MANUAL
 Astra TS	MAINTENANCE	1.7 TD (98-00)	GM MANUAL
 Astra TS	MAINTENANCE	1.8 (98-00)	GM MANUAL
 Astra TS	MAINTENANCE	1.8 16v (98-00)	GM MANUAL
 Astra TS	MAINTENANCE	2.0 (98-00)	GM MANUAL
 Astra TS	MAINTENANCE	2.0 16v (98-00)	GM MANUAL
 Astra TS	MAINTENANCE	2.0 TD 16v (98-00)	GM MANUAL
 Astra TS	MAINTENANCE	2.2 (98-00)	GM MANUAL
 Astra TS	SERVICE LIGHT RES	1.2 (98-00)	GM MANUAL
 Astra TS	SERVICE LIGHT RES	1.2 16v (98-00)	GM MANUAL
 Astra TS	SERVICE LIGHT RES	1.4 (98-00)	GM MANUAL
 Astra TS	SERVICE LIGHT RES	1.4 16v (98-00)	GM MANUAL
 Astra TS	SERVICE LIGHT RES	1.6 (98-00)	GM MANUAL
 Astra TS	SERVICE LIGHT RES	1.6 16v (98-00)	GM MANUAL
 Astra TS	SERVICE LIGHT RES	1.7 DTL (98-00)	GM MANUAL
 Astra TS	SERVICE LIGHT RES	1.7 TD (98-00)	GM MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Holden

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Astra TS	SERVICE LIGHT RES	1.8 (98-00)	GM MANUAL
 Astra TS	SERVICE LIGHT RES	1.8 16v (98-00)	GM MANUAL
 Astra TS	SERVICE LIGHT RES	2.0 (98-00)	GM MANUAL
 Astra TS	SERVICE LIGHT RES	2.0 16v (98-00)	GM MANUAL
 Astra TS	SERVICE LIGHT RES	2.0 TD 16v (98-00)	GM MANUAL
 Astra TS	SERVICE LIGHT RES	2.2 (98-00)	GM MANUAL
 Barina & Combo SB	AIRBAG	1.2 (87-93)	GM AirBag S
 Barina & Combo SB	AIRBAG	1.4 (87-93)	GM AirBag S
 Barina & Combo SB	AIRBAG	1.6 (87-93)	GM AirBag S
 Barina & Combo SB	AIRBAG	1.6 Kat (87-93)	GM AirBag S
 Barina & Combo SB	ENGINE MANAGEME	1.2 12NZ (...94)	GM Multec TBI
 Barina & Combo SB	ENGINE MANAGEME	1.2 C12NZ (...94)	GM Multec TBI
 Barina & Combo SB	ENGINE MANAGEME	1.4 C14NZ (...94)	GM Multec TBI
 Barina & Combo SB	ENGINE MANAGEME	1.4 C14SE (...94)	GM Multec M
 Barina & Combo SB	ENGINE MANAGEME	1.6 C16SE (...93)	GM Multec M
 Barina & Combo SB	ENGINE MANAGEME	1.6 E16NZ (83-93)	GM Multec TBI MANUAL
 Barina & Combo SB	ENGINE MANAGEME	1.6 Kat C16NZ (83-93)	GM Multec TBI MANUAL
 Barina & Combo SB	MAINTENANCE	1.6 E16NZ (83-93)	GM Multec TBI MANUAL
 Barina & Combo SB	MAINTENANCE	1.6 Kat C16NZ (83-93)	GM Multec TBI MANUAL
 Barina & Combo XC	ABS	1.0 12v	GM ABS 415
 Barina & Combo XC	ABS	1.2	GM ABS 415
 Barina & Combo XC	ABS	1.2 16v	GM ABS 415
 Barina & Combo XC	ABS	1.4	GM ABS 415
 Barina & Combo XC	ABS	1.4 16v	GM ABS 415
 Barina & Combo XC	ABS	1.6 16v	GM ABS 415
 Barina & Combo XC	AIRBAG	1.0 12v (...00)	SIEMENS AirBag SAB6
 Barina & Combo XC	AIRBAG	1.0 12v (93-00)	GM AirBag S
 Barina & Combo XC	AIRBAG	1.2 (...00)	SIEMENS AirBag SAB6
 Barina & Combo XC	AIRBAG	1.2 (93-00)	GM AirBag S
 Barina & Combo XC	AIRBAG	1.2 16v (...00)	SIEMENS AirBag SAB6
 Barina & Combo XC	AIRBAG	1.2 16v (93-00)	GM AirBag S
 Barina & Combo XC	AIRBAG	1.4 (...00)	SIEMENS AirBag SAB6
 Barina & Combo XC	AIRBAG	1.4 (93-00)	GM AirBag S
 Barina & Combo XC	AIRBAG	1.4 16v (...00)	SIEMENS AirBag SAB6
 Barina & Combo XC	AIRBAG	1.4 16v (93-00)	GM AirBag S
 Barina & Combo XC	AIRBAG	1.6 16v (...00)	SIEMENS AirBag SAB6
 Barina & Combo XC	AIRBAG	1.6 16v (93-00)	GM AirBag S
 Barina & Combo XC	ENGINE MANAGEME	1.0 12v X10XE (96-00)	BOSCH Motronic M1.5.5
 Barina & Combo XC	ENGINE MANAGEME	1.2 12NZ (95-00)	GM Multec TBI
 Barina & Combo XC	ENGINE MANAGEME	1.2 16v X12XE (98-00)	BOSCH Motronic M1.5.5
 Barina & Combo XC	ENGINE MANAGEME	1.2 C12NZ (95-00)	GM Multec TBI
 Barina & Combo XC	ENGINE MANAGEME	1.2 X12SZ (...94)	GM Multec SZ
 Barina & Combo XC	ENGINE MANAGEME	1.2 X12SZ (95-00)	GM Multec SZ
 Barina & Combo XC	ENGINE MANAGEME	1.4 16v X14XE (...95)	GM Multec S
 Barina & Combo XC	ENGINE MANAGEME	1.4 16v X14XE (96-00)	GM Multec S (F)
 Barina & Combo XC	ENGINE MANAGEME	1.4 C14NZ (95-00)	GM Multec TBI
 Barina & Combo XC	ENGINE MANAGEME	1.4 C14SE (95-00)	GM Multec M + Immob.
 Barina & Combo XC	ENGINE MANAGEME	1.4 X14SZ (96-00)	GM Multec S (F)
 Barina & Combo XC	ENGINE MANAGEME	1.6 16v C16XE (93-94)	GM Multec S
 Barina & Combo XC	ENGINE MANAGEME	1.6 16v X16XE (...95)	GM Multec S
 Barina & Combo XC	ENGINE MANAGEME	1.6 16v X16XE (96-00)	GM Multec S (F)
 Barina & Combo XC	IMMOBILIZER	1.0 12v (96-00)	GM Immobilizer
 Barina & Combo XC	IMMOBILIZER	1.2 (96-00)	GM Immobilizer
 Barina & Combo XC	IMMOBILIZER	1.2 16v (96-00)	GM Immobilizer
 Barina & Combo XC	IMMOBILIZER	1.4 (96-00)	GM Immobilizer
 Barina & Combo XC	IMMOBILIZER	1.4 16v (96-00)	GM Immobilizer
 Barina & Combo XC	IMMOBILIZER	1.6 16v (96-00)	GM Immobilizer
 Barina TK	ENGINE MANAGEME	1.2 (05-..)	EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Holden

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Barina TK	ENGINE MANAGEME	1.4 16v (05-..)	EOBD
 Calibra YE	AIRBAG	2.0 (93-97)	GM AirBag S
 Calibra YE	AIRBAG	2.0 16v (93-97)	GM AirBag S
 Calibra YE	AIRBAG	2.0 T (93-97)	GM AirBag S
 Calibra YE	AIRBAG	2.5 24v (93-97)	GM AirBag S
 Calibra YE	ENGINE MANAGEME	2.0 16v C20XE (...92)	BOSCH Motronic M2.5
 Calibra YE	ENGINE MANAGEME	2.0 16v C20XE (...96)	BOSCH Motronic M2.8
 Calibra YE	ENGINE MANAGEME	2.0 16v X20XEV (94-95)	SIEMENS Simtec 56.0 - 56.1
 Calibra YE	ENGINE MANAGEME	2.0 16v X20XEV (95-96)	SIEMENS Simtec 56.1
 Calibra YE	ENGINE MANAGEME	2.0 16v X20XEV (96-00)	SIEMENS Simtec 56.5
 Calibra YE	ENGINE MANAGEME	2.0 C20NE (...96)	BOSCH Motronic M1.5
 Calibra YE	ENGINE MANAGEME	2.0 T C20LET (...96)	BOSCH Motronic M2.7
 Calibra YE	ENGINE MANAGEME	2.5 24v C25XE (...96)	BOSCH Motronic M2.8
 Captiva	ABS + TRACT. CONT	2.0 CDTI	TEVES ESC 0300
 Captiva	ABS + TRACT. CONT	2.4 16v	TEVES ESC 0300
 Captiva	ABS + TRACT. CONT	3.2 V6	TEVES ESC 0300
 Captiva	CHASSIS NETWORK	2.0 CDTI	BCM Front
 Captiva	CHASSIS NETWORK	2.0 CDTI	XBCM Rear
 Captiva	CHASSIS NETWORK	2.4 16v	BCM Front
 Captiva	CHASSIS NETWORK	2.4 16v	XBCM Rear
 Captiva	CHASSIS NETWORK	3.2 V6	BCM Front
 Captiva	CHASSIS NETWORK	3.2 V6	XBCM Rear
 Captiva	CLIMA	2.0 CDTI	ECC
 Captiva	CLIMA	2.4 16v	ECC
 Captiva	CLIMA	3.2 V6	ECC
 Captiva	DASHBOARD	2.0 CDTI	IPC
 Captiva	DASHBOARD	2.4 16v	IPC
 Captiva	DASHBOARD	3.2 V6	IPC
 Captiva	ENGINE MANAGEME	2.0 CDTI 2.0L	BOSCH EDC 16 39 Common Rail
 Captiva	PARKING HELP	2.0 CDTI	PAS
 Captiva	PARKING HELP	2.4 16v	PAS
 Captiva	PARKING HELP	3.2 V6	PAS
 Commodore VE	ENGINE MANAGEME	3.6 (06-..)	EOBD
 Commodore VE	ENGINE MANAGEME	6.0 (06-..)	EOBD
 Epica	ENGINE MANAGEME	2.0 (05-..)	EOBD
 Epica	ENGINE MANAGEME	2.5 (05-..)	EOBD
 Frontera	ABS	2.0	GM ABS 415
 Frontera	ABS	2.2 16v	GM ABS 415
 Frontera	ABS	2.4	GM ABS 415
 Frontera	ABS	2.5 TD	GM ABS 415
 Frontera	ENGINE MANAGEME	2.0 C20NE (...95)	BOSCH Motronic M1.5
 Frontera	ENGINE MANAGEME	2.0 X20SE (95-00)	BOSCH Motronic M1.5.4
 Frontera	ENGINE MANAGEME	2.2 16v X22XE (95-00)	BOSCH Motronic M1.5.4
 Frontera	ENGINE MANAGEME	2.4 C24NE (...95)	BOSCH Motronic M1.5
 Frontera	ENGINE MANAGEME	2.5 TD 25TDS (97-00)	BOSCH EDC MSA 15.5
 Frontera-B	ENGINE MANAGEME	2.2 TD 16v X22DTH (99-00)	BOSCH EDC MSA 15 M
 Frontera-B	ENGINE MANAGEME	2.2 Y22SE (01-..)	EOBD
 Frontera-B	ENGINE MANAGEME	3.2 6VD1 (01-..)	EOBD
 Jackaroo	ENGINE MANAGEME	4ZE1	Isuzu MFI-i I-TEC MANUAL
 Jackaroo	MAINTENANCE	4ZE1	Isuzu MFI-i I-TEC MANUAL
 Vectra JR	AIRBAG	1.6 (93-95)	GM AirBag S
Vectra JR	AIRBAG	1.6 Kat (93-95)	GM AirBag S
Vectra JR	AIRBAG	1.8 (93-95)	GM AirBag S
Vectra JR	AIRBAG	2.0 (93-95)	GM AirBag S
Vectra JR	AIRBAG	2.0 16v (93-95)	GM AirBag S
Vectra JR	AIRBAG	2.0 T (93-95)	GM AirBag S

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Holden

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Vectra JR	AIRBAG	2.5 24v (93-95)	GM AirBag S
 Vectra JR	ENGINE MANAGEME	1.6 16LZ2 (...-95)	GM Multec TBI
 Vectra JR	ENGINE MANAGEME	1.6 16LZ2 (...-95)	GM Multec TBI + Immob.
 Vectra JR	ENGINE MANAGEME	1.6 C16NZ2 (...-94)	GM Multec TBI
 Vectra JR	ENGINE MANAGEME	1.6 C16NZ2 (94-..)	GM Multec TBI + Immob.
 Vectra JR	ENGINE MANAGEME	1.6 E16NZ (89-95)	GM Multec TBI MANUAL
 Vectra JR	ENGINE MANAGEME	1.6 Kat C16NZ (89-95)	GM Multec TBI MANUAL
 Vectra JR	ENGINE MANAGEME	1.6 X16SZ (...-94)	GM Multec SZ
 Vectra JR	ENGINE MANAGEME	1.6 X16SZ (94-00)	GM Multec SZ
 Vectra JR	ENGINE MANAGEME	1.8 C18NZ (...-95)	GM Multec TBI + Immob.
 Vectra JR	ENGINE MANAGEME	1.8 C18NZ (91-94)	GM Multec TBI
 Vectra JR	ENGINE MANAGEME	2.0 16v 20XEJ (89-..)	BOSCH Motronic M2.5
 Vectra JR	ENGINE MANAGEME	2.0 16v C20XE (...-92)	BOSCH Motronic M2.5
 Vectra JR	ENGINE MANAGEME	2.0 16v C20XE (92-..)	BOSCH Motronic M2.8
 Vectra JR	ENGINE MANAGEME	2.0 16v X20XEV (...-95)	SIEMENS Simtec 56.0 - 56.1
 Vectra JR	ENGINE MANAGEME	2.0 20NE (...-89)	BOSCH Motronic ML4.1
 Vectra JR	ENGINE MANAGEME	2.0 20NE (89-..)	BOSCH Motronic M1.5
 Vectra JR	ENGINE MANAGEME	2.0 20SEH (...-89)	BOSCH Motronic ML4.1
 Vectra JR	ENGINE MANAGEME	2.0 20SEH (89-..)	BOSCH Motronic M1.5
 Vectra JR	ENGINE MANAGEME	2.0 C20NE (...-89)	BOSCH Motronic ML4.1
 Vectra JR	ENGINE MANAGEME	2.0 C20NE (89-..)	BOSCH Motronic M1.5
 Vectra JR	ENGINE MANAGEME	2.0 T C20LET (...-95)	BOSCH Motronic M2.7
 Vectra JR	ENGINE MANAGEME	2.5 24v C25XE (93-95)	BOSCH Motronic M2.8
 Vectra JR	MAINTENANCE	1.6 E16NZ (89-95)	GM Multec TBI MANUAL
 Vectra JR	MAINTENANCE	1.6 Kat C16NZ (89-95)	GM Multec TBI MANUAL
 Vectra JS	ABS	1.6	GM ABS 415
 Vectra JS	ABS	1.6 16v	GM ABS 415
 Vectra JS	ABS	1.8	GM ABS 415
 Vectra JS	ABS	1.8 16v	GM ABS 415
 Vectra JS	ABS	2.0	GM ABS 415
 Vectra JS	ABS	2.0 16v	GM ABS 415
 Vectra JS	ABS	2.0 TD 16v	GM ABS 415
 Vectra JS	ABS	2.2	GM ABS 415
 Vectra JS	ABS	2.5 24v	GM ABS 415
 Vectra JS	ABS	2.6	GM ABS 415
 Vectra JS	AIRBAG	1.6 (...-01)	SIEMENS AirBag SAB6
 Vectra JS	AIRBAG	1.6 (96-97)	SIEMENS AirBag SAE4 (a)
 Vectra JS	AIRBAG	1.6 (96-97)	SIEMENS AirBag SAE4 (b)
 Vectra JS	AIRBAG	1.6 16v (...-01)	SIEMENS AirBag SAB6
 Vectra JS	AIRBAG	1.6 16v (96-97)	SIEMENS AirBag SAE4 (a)
 Vectra JS	AIRBAG	1.6 16v (96-97)	SIEMENS AirBag SAE4 (b)
 Vectra JS	AIRBAG	1.8 (...-01)	SIEMENS AirBag SAB6
 Vectra JS	AIRBAG	1.8 (96-97)	SIEMENS AirBag SAE4 (a)
 Vectra JS	AIRBAG	1.8 (96-97)	SIEMENS AirBag SAE4 (b)
 Vectra JS	AIRBAG	1.8 16v (...-01)	SIEMENS AirBag SAB6
 Vectra JS	AIRBAG	1.8 16v (96-97)	SIEMENS AirBag SAE4 (a)
 Vectra JS	AIRBAG	1.8 16v (96-97)	SIEMENS AirBag SAE4 (b)
 Vectra JS	AIRBAG	2.0 (...-01)	SIEMENS AirBag SAB6
 Vectra JS	AIRBAG	2.0 (96-97)	SIEMENS AirBag SAE4 (a)
 Vectra JS	AIRBAG	2.0 (96-97)	SIEMENS AirBag SAE4 (b)
 Vectra JS	AIRBAG	2.0 16v (...-01)	SIEMENS AirBag SAB6
 Vectra JS	AIRBAG	2.0 16v (96-97)	SIEMENS AirBag SAE4 (a)
 Vectra JS	AIRBAG	2.0 16v (96-97)	SIEMENS AirBag SAE4 (b)
 Vectra JS	AIRBAG	2.0 TD 16v (...-01)	SIEMENS AirBag SAB6
 Vectra JS	AIRBAG	2.0 TD 16v (96-97)	SIEMENS AirBag SAE4 (a)
 Vectra JS	AIRBAG	2.0 TD 16v (96-97)	SIEMENS AirBag SAE4 (b)
 Vectra JS	AIRBAG	2.2 (...-01)	SIEMENS AirBag SAB6
 Vectra JS	AIRBAG	2.2 (96-97)	SIEMENS AirBag SAE4 (a)

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Holden

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Vectra JS	AIRBAG	2.2 (96-97)	SIEMENS AirBag SAE4 (b)
 Vectra JS	AIRBAG	2.5 24v (...01)	SIEMENS AirBag SAB6
 Vectra JS	AIRBAG	2.5 24v (96-97)	SIEMENS AirBag SAE4 (a)
 Vectra JS	AIRBAG	2.5 24v (96-97)	SIEMENS AirBag SAE4 (b)
 Vectra JS	AIRBAG	2.6 (...01)	SIEMENS AirBag SAB6
 Vectra JS	AIRBAG	2.6 (96-97)	SIEMENS AirBag SAE4 (a)
 Vectra JS	AIRBAG	2.6 (96-97)	SIEMENS AirBag SAE4 (b)
 Vectra JS	CLIMA	1.6 16v X20DTH (97-01)	GM Clima ECC
 Vectra JS	CLIMA	1.6 X20DTH (97-01)	GM Clima ECC
 Vectra JS	CLIMA	1.8 16v X20DTH (97-01)	GM Clima ECC
 Vectra JS	CLIMA	1.8 X20DTH (97-01)	GM Clima ECC
 Vectra JS	CLIMA	2.0 16v X20DTH (97-01)	GM Clima ECC
 Vectra JS	CLIMA	2.0 TD 16v X20DTH (97-01)	GM Clima ECC
 Vectra JS	CLIMA	2.0 X20DTH (97-01)	GM Clima ECC
 Vectra JS	CLIMA	2.2 X20DTH (97-01)	GM Clima ECC
 Vectra JS	CLIMA	2.5 24v X20DTH (97-01)	GM Clima ECC
 Vectra JS	CLIMA	2.6 X20DTH (97-01)	GM Clima ECC
 Vectra JS	ENGINE MANAGEME	1.6 16LZ2 (...96)	GM Multec TBI
 Vectra JS	ENGINE MANAGEME	1.6 16LZ2 (96-00)	GM Multec TBI + Immob.
 Vectra JS	ENGINE MANAGEME	1.6 16v X16XEL (96-00)	GM Multec (F)
 Vectra JS	ENGINE MANAGEME	1.6 X16SZR (96-00)	GM Multec (F)
 Vectra JS	ENGINE MANAGEME	1.6 Y16XE (00/01-..)	EOBD
 Vectra JS	ENGINE MANAGEME	1.6 Y16XEL (00/01-..)	EOBD
 Vectra JS	ENGINE MANAGEME	1.6 Z16XE (00/01-..)	EOBD
 Vectra JS	ENGINE MANAGEME	1.8 16v X18XE (96-00)	SIEMENS Simtec 56.5
 Vectra JS	ENGINE MANAGEME	1.8 16v X18XE1 (98-00)	SIEMENS Simtec 70
 Vectra JS	ENGINE MANAGEME	1.8 Z18XE (00/01-..)	EOBD
 Vectra JS	ENGINE MANAGEME	1.8 Z18XEL (00/01-..)	EOBD
 Vectra JS	ENGINE MANAGEME	2.0 16v X20XEV (96-00)	SIEMENS Simtec 56.5
 Vectra JS	ENGINE MANAGEME	2.0 20NEJ (96-00)	BOSCH Motronic M1.5.4
 Vectra JS	ENGINE MANAGEME	2.0 TD 16v X20DTH (98-00)	BOSCH EDC MSA 15 M
 Vectra JS	ENGINE MANAGEME	2.0 TD 16v X20DTL (98-00)	BOSCH EDC MSA 15 M
 Vectra JS	ENGINE MANAGEME	2.0 TD 16v Y20DTH (01-..)	BOSCH EDC MSA 15 M
 Vectra JS	ENGINE MANAGEME	2.2 Z22SE (00/01-..)	EOBD
 Vectra JS	ENGINE MANAGEME	2.5 24v X25XE (96-00)	BOSCH Motronic M2.8.3
 Vectra JS	ENGINE MANAGEME	2.5 24v X25XE1 (98-00)	BOSCH Motronic M2.8.3
 Vectra JS	ENGINE MANAGEME	2.6 Z26SE (00/01-..)	EOBD
 Vectra JS	IMMOBILIZER	1.6 (96-97)	GM Immobilizer
 Vectra JS	IMMOBILIZER	1.6 (98-..)	SIEMENS
 Vectra JS	IMMOBILIZER	1.6 16v (96-97)	GM Immobilizer
 Vectra JS	IMMOBILIZER	1.6 16v (98-..)	SIEMENS
 Vectra JS	IMMOBILIZER	1.8 (96-97)	GM Immobilizer
 Vectra JS	IMMOBILIZER	1.8 (98-..)	SIEMENS
 Vectra JS	IMMOBILIZER	1.8 16v (96-97)	GM Immobilizer
 Vectra JS	IMMOBILIZER	1.8 16v (98-..)	SIEMENS
 Vectra JS	IMMOBILIZER	2.0 (96-97)	GM Immobilizer
 Vectra JS	IMMOBILIZER	2.0 (98-..)	SIEMENS
 Vectra JS	IMMOBILIZER	2.0 16v (96-97)	GM Immobilizer
 Vectra JS	IMMOBILIZER	2.0 16v (98-..)	SIEMENS
 Vectra JS	IMMOBILIZER	2.0 TD 16v (96-97)	GM Immobilizer
 Vectra JS	IMMOBILIZER	2.0 TD 16v (98-..)	SIEMENS
 Vectra JS	IMMOBILIZER	2.2 (96-97)	GM Immobilizer
 Vectra JS	IMMOBILIZER	2.2 (98-..)	SIEMENS
 Vectra JS	IMMOBILIZER	2.5 24v (96-97)	GM Immobilizer
 Vectra JS	IMMOBILIZER	2.5 24v (98-..)	SIEMENS
 Vectra JS	IMMOBILIZER	2.6 (96-97)	GM Immobilizer
 Vectra JS	IMMOBILIZER	2.6 (98-..)	SIEMENS
 Vectra JS	MAINTENANCE	1.6 (98-00)	GM MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Holden

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Vectra JS	MAINTENANCE	1.6 16v (98-00)	GM MANUAL
 Vectra JS	MAINTENANCE	1.8 (98-00)	GM MANUAL
 Vectra JS	MAINTENANCE	1.8 16v (98-00)	GM MANUAL
 Vectra JS	MAINTENANCE	2.0 (98-00)	GM MANUAL
 Vectra JS	MAINTENANCE	2.0 16v (98-00)	GM MANUAL
 Vectra JS	MAINTENANCE	2.0 TD 16v (98-00)	GM MANUAL
 Vectra JS	MAINTENANCE	2.2 (98-00)	GM MANUAL
 Vectra JS	MAINTENANCE	2.5 24v (98-00)	GM MANUAL
 Vectra JS	MAINTENANCE	2.6 (98-00)	GM MANUAL
 Vectra JS	SERVICE LIGHT RES	1.6 (98-00)	GM MANUAL
 Vectra JS	SERVICE LIGHT RES	1.6 16v (98-00)	GM MANUAL
 Vectra JS	SERVICE LIGHT RES	1.8 (98-00)	GM MANUAL
 Vectra JS	SERVICE LIGHT RES	1.8 16v (98-00)	GM MANUAL
 Vectra JS	SERVICE LIGHT RES	2.0 (98-00)	GM MANUAL
 Vectra JS	SERVICE LIGHT RES	2.0 16v (98-00)	GM MANUAL
 Vectra JS	SERVICE LIGHT RES	2.0 TD 16v (98-00)	GM MANUAL
 Vectra JS	SERVICE LIGHT RES	2.2 (98-00)	GM MANUAL
 Vectra JS	SERVICE LIGHT RES	2.5 24v (98-00)	GM MANUAL
 Vectra JS	SERVICE LIGHT RES	2.6 (98-00)	GM MANUAL
 Vectra ZC	ABS + TRACT. CONT	1.8 16v (02-..)	ABS/TC/ESP
 Vectra ZC	ABS + TRACT. CONT	1.9 16v CDTI (02-..)	ABS/TC/ESP
 Vectra ZC	ABS + TRACT. CONT	1.9 CDTI (02-..)	ABS/TC/ESP
 Vectra ZC	ABS + TRACT. CONT	2.0 16v DTI (02-..)	ABS/TC/ESP
 Vectra ZC	ABS + TRACT. CONT	2.2 16v DTI (02-..)	ABS/TC/ESP
 Vectra ZC	ABS + TRACT. CONT	2.2 CDTI (02-..)	ABS/TC/ESP
 Vectra ZC	AIRBAG	1.8 16v (02-..)	AirBag SDM
 Vectra ZC	AIRBAG	1.9 16v CDTI (02-..)	AirBag SDM
 Vectra ZC	AIRBAG	1.9 CDTI (02-..)	AirBag SDM
 Vectra ZC	AIRBAG	2.0 16v DTI (02-..)	AirBag SDM
 Vectra ZC	AIRBAG	2.2 16v DTI (02-..)	AirBag SDM
 Vectra ZC	AIRBAG	2.2 CDTI (02-..)	AirBag SDM
 Vectra ZC	AUTOM. TRANSMISSI	1.8 16v (02-..)	A/T AF-23-5/33-5
 Vectra ZC	AUTOM. TRANSMISSI	1.9 16v CDTI (02-..)	A/T AF-23-5/33-5
 Vectra ZC	AUTOM. TRANSMISSI	1.9 CDTI (02-..)	A/T AF-23-5/33-5
 Vectra ZC	AUTOM. TRANSMISSI	2.0 16v DTI (02-..)	A/T AF-23-5/33-5
 Vectra ZC	AUTOM. TRANSMISSI	2.2 16v DTI (02-..)	A/T AF-23-5/33-5
 Vectra ZC	AUTOM. TRANSMISSI	2.2 CDTI (02-..)	A/T AF-23-5/33-5
 Vectra ZC	CHASSIS NETWORK	1.8 16v (02-..)	BCM External lightning
 Vectra ZC	CHASSIS NETWORK	1.9 16v CDTI (02-..)	BCM External lightning
 Vectra ZC	CHASSIS NETWORK	1.9 CDTI (02-..)	BCM External lightning
 Vectra ZC	CHASSIS NETWORK	2.0 16v DTI (02-..)	BCM External lightning
 Vectra ZC	CHASSIS NETWORK	2.2 16v DTI (02-..)	BCM External lightning
 Vectra ZC	CHASSIS NETWORK	2.2 CDTI (02-..)	BCM External lightning
 Vectra ZC	CLIMA	1.8 16v (02-..)	Clima
 Vectra ZC	CLIMA	1.9 16v CDTI (02-..)	Clima
 Vectra ZC	CLIMA	1.9 CDTI (02-..)	Clima
 Vectra ZC	CLIMA	2.0 16v DTI (02-..)	Clima
 Vectra ZC	CLIMA	2.2 16v DTI (02-..)	Clima
 Vectra ZC	CLIMA	2.2 CDTI (02-..)	Clima
 Vectra ZC	DASHBOARD	1.8 16v (02-..)	VDO IPC 0400
 Vectra ZC	DASHBOARD	1.9 16v CDTI (02-..)	VDO IPC 0400
 Vectra ZC	DASHBOARD	1.9 CDTI (02-..)	VDO IPC 0400
 Vectra ZC	DASHBOARD	2.0 16v DTI (02-..)	VDO IPC 0400
 Vectra ZC	DASHBOARD	2.2 16v DTI (02-..)	VDO IPC 0400
 Vectra ZC	DASHBOARD	2.2 CDTI (02-..)	VDO IPC 0400
 Vectra ZC	ELECTRIC STEERING	1.8 16v (02-..)	TRW Automotive EHPS 0300
 Vectra ZC	ELECTRIC STEERING	1.9 16v CDTI (02-..)	TRW Automotive EHPS 0300
 Vectra ZC	ELECTRIC STEERING	1.9 CDTI (02-..)	TRW Automotive EHPS 0300

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Holden

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Vectra ZC	ELECTRIC STEERING	2.0 16v DTI (02-..)	TRW Automotive EHPS 0300
 Vectra ZC	ELECTRIC STEERING	2.2 16v DTI (02-..)	TRW Automotive EHPS 0300
 Vectra ZC	ELECTRIC STEERING	2.2 CDTI (02-..)	TRW Automotive EHPS 0300
 Vectra ZC	ENGINE MANAGEME	1.8 16v Z18XE (02-..)	EOBD
 Vectra ZC	ENGINE MANAGEME	1.8 16v Z18XER	SIEMENS MPI MS75
 Vectra ZC	ENGINE MANAGEME	1.9 16v CDTI Z19DT	BOSCH EDC 16 Common Rail
 Vectra ZC	ENGINE MANAGEME	1.9 CDTI Z19DTH	BOSCH EDC 16 Common Rail
 Vectra ZC	ENGINE MANAGEME	2.2 CDTI Y22DTR	BOSCH EDC Common Rail
 Vectra ZC	MAINTENANCE	1.8 16v	MANUAL
 Vectra ZC	MAINTENANCE	1.8 16v Z18XER	SIEMENS MPI MS75
 Vectra ZC	MAINTENANCE	1.9 16v CDTI	MANUAL
 Vectra ZC	MAINTENANCE	1.9 CDTI	MANUAL
 Vectra ZC	MAINTENANCE	2.0 16v DTI	MANUAL
 Vectra ZC	MAINTENANCE	2.2 16v DTI	MANUAL
 Vectra ZC	MAINTENANCE	2.2 CDTI	MANUAL
 Vectra ZC	MAINTENANCE	2.2 CDTI Y22DTR	BOSCH EDC Common Rail
 Vectra ZC	SERVICE LIGHT RES	1.8 16v	MANUAL
 Vectra ZC	SERVICE LIGHT RES	1.9 16v CDTI	MANUAL
 Vectra ZC	SERVICE LIGHT RES	1.9 CDTI	MANUAL
 Vectra ZC	SERVICE LIGHT RES	2.0 16v DTI	MANUAL
 Vectra ZC	SERVICE LIGHT RES	2.2 16v DTI	MANUAL
 Vectra ZC	SERVICE LIGHT RES	2.2 CDTI	MANUAL
 Vectra ZC	VISUAL./TELEMATIC	1.8 16v (02-..)	Color Info Display
 Vectra ZC	VISUAL./TELEMATIC	1.9 16v CDTI (02-..)	Color Info Display
 Vectra ZC	VISUAL./TELEMATIC	1.9 CDTI (02-..)	Color Info Display
 Vectra ZC	VISUAL./TELEMATIC	2.0 16v DTI (02-..)	Color Info Display
 Vectra ZC	VISUAL./TELEMATIC	2.2 16v DTI (02-..)	Color Info Display
 Vectra ZC	VISUAL./TELEMATIC	2.2 CDTI (02-..)	Color Info Display
 Viva	ENGINE MANAGEME	1.4 16v (05-..)	EOBD
 Zafira TT	ABS	1.6	BOSCH ABS 5.3/5.4(+TC)
 Zafira TT	ABS	1.6 16v	BOSCH ABS 5.3/5.4(+TC)
 Zafira TT	ABS	1.7 16v CDTI	BOSCH ABS 5.3/5.4(+TC)
 Zafira TT	ABS	1.8	BOSCH ABS 5.3/5.4(+TC)
 Zafira TT	ABS	1.8 16v	BOSCH ABS 5.3/5.4(+TC)
 Zafira TT	ABS	2.0	BOSCH ABS 5.3/5.4(+TC)
 Zafira TT	ABS	2.0 TD 16v	BOSCH ABS 5.3/5.4(+TC)
 Zafira TT	ABS	2.2	BOSCH ABS 5.3/5.4(+TC)
 Zafira TT	AIRBAG	1.6 (...00)	SIEMENS AirBag SAB6
 Zafira TT	AIRBAG	1.6 (01-..)	SIEMENS AirBag SAB8x
 Zafira TT	AIRBAG	1.6 16v (...00)	SIEMENS AirBag SAB6
 Zafira TT	AIRBAG	1.6 16v (01-..)	SIEMENS AirBag SAB8x
 Zafira TT	AIRBAG	1.7 16v CDTI (...00)	SIEMENS AirBag SAB6
 Zafira TT	AIRBAG	1.7 16v CDTI (01-..)	SIEMENS AirBag SAB8x
 Zafira TT	AIRBAG	1.8 (...00)	SIEMENS AirBag SAB6
 Zafira TT	AIRBAG	1.8 (01-..)	SIEMENS AirBag SAB8x
 Zafira TT	AIRBAG	1.8 16v (...00)	SIEMENS AirBag SAB6
 Zafira TT	AIRBAG	1.8 16v (01-..)	SIEMENS AirBag SAB8x
 Zafira TT	AIRBAG	2.0 (...00)	SIEMENS AirBag SAB6
 Zafira TT	AIRBAG	2.0 (01-..)	SIEMENS AirBag SAB8x
 Zafira TT	AIRBAG	2.0 TD 16v (...00)	SIEMENS AirBag SAB6
 Zafira TT	AIRBAG	2.0 TD 16v (01-..)	SIEMENS AirBag SAB8x
 Zafira TT	AIRBAG	2.2 (...00)	SIEMENS AirBag SAB6
 Zafira TT	AIRBAG	2.2 (01-..)	SIEMENS AirBag SAB8x
 Zafira TT	ENGINE COOLING	1.6 16v X16XEL (98-..)	BOSCH xx
 Zafira TT	ENGINE COOLING	1.6 Z16XE (98-..)	BOSCH xx
 Zafira TT	ENGINE COOLING	1.8 16v X18XE1 (98-..)	BOSCH xx
 Zafira TT	ENGINE COOLING	2.0 TD 16v X20DTH (98-..)	BOSCH xx
 Zafira TT	ENGINE COOLING	2.0 TD 16v X20DTL (98-..)	BOSCH xx

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Holden

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Zafira TT	ENGINE MANAGEME	1.6 16v X16XEL (98-00)	GM Multec H
 Zafira TT	ENGINE MANAGEME	1.6 16v Z16XER	SIEMENS MPI MS75
 Zafira TT	ENGINE MANAGEME	1.6 Z16XE (01-..)	EOBD
 Zafira TT	ENGINE MANAGEME	1.7 16v CDTI Z17DTH (04-..)	BOSCH EDC 16 Common Rail
 Zafira TT	ENGINE MANAGEME	1.8 16v X18XE1 (98-00)	SIEMENS Simtec 70
 Zafira TT	ENGINE MANAGEME	1.8 16v Z18XER	SIEMENS MPI MS75
 Zafira TT	ENGINE MANAGEME	1.8 Z18XE (01-..)	EOBD
 Zafira TT	ENGINE MANAGEME	2.0 TD 16v X20DTL (99-00)	BOSCH EDC MSA 15 M
 Zafira TT	ENGINE MANAGEME	2.0 TD 16v Y20DTH (00-01)	BOSCH EDC MSA 15 M
 Zafira TT	ENGINE MANAGEME	2.0 Z20LET (01-..)	EOBD
 Zafira TT	ENGINE MANAGEME	2.2 Z22SE (01-..)	EOBD
 Zafira TT	IMMOBILIZER	1.6 (99-..)	SIEMENS
 Zafira TT	IMMOBILIZER	1.6 16v (99-..)	SIEMENS
 Zafira TT	IMMOBILIZER	1.7 16v CDTI (99-..)	SIEMENS
 Zafira TT	IMMOBILIZER	1.8 (99-..)	SIEMENS
 Zafira TT	IMMOBILIZER	1.8 16v (99-..)	SIEMENS
 Zafira TT	IMMOBILIZER	2.0 (99-..)	SIEMENS
 Zafira TT	IMMOBILIZER	2.0 TD 16v (99-..)	SIEMENS
 Zafira TT	IMMOBILIZER	2.2 (99-..)	SIEMENS
 Zafira TT	MAINTENANCE	1.6 (98-00)	GM MANUAL
 Zafira TT	MAINTENANCE	1.6 16v (98-00)	GM MANUAL
 Zafira TT	MAINTENANCE	1.6 16v Z16XER	SIEMENS MPI MS75
 Zafira TT	MAINTENANCE	1.7 16v CDTI (98-00)	GM MANUAL
 Zafira TT	MAINTENANCE	1.8 (98-00)	GM MANUAL
 Zafira TT	MAINTENANCE	1.8 16v (98-00)	GM MANUAL
 Zafira TT	MAINTENANCE	1.8 16v Z18XER	SIEMENS MPI MS75
 Zafira TT	MAINTENANCE	2.0 (98-00)	GM MANUAL
 Zafira TT	MAINTENANCE	2.0 TD 16v (98-00)	GM MANUAL
 Zafira TT	MAINTENANCE	2.2 (98-00)	GM MANUAL
 Zafira TT	SERVICE LIGHT RES	1.6 (98-00)	GM MANUAL
 Zafira TT	SERVICE LIGHT RES	1.6 16v (98-00)	GM MANUAL
 Zafira TT	SERVICE LIGHT RES	1.7 16v CDTI (98-00)	GM MANUAL
 Zafira TT	SERVICE LIGHT RES	1.8 (98-00)	GM MANUAL
 Zafira TT	SERVICE LIGHT RES	1.8 16v (98-00)	GM MANUAL
 Zafira TT	SERVICE LIGHT RES	2.0 (98-00)	GM MANUAL
 Zafira TT	SERVICE LIGHT RES	2.0 TD 16v (98-00)	GM MANUAL
 Zafira TT	SERVICE LIGHT RES	2.2 (98-00)	GM MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Honda

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Accord IV	AIRBAG	1.8 (89-93)	Honda AirBag-SRS Type II MANUAL
 Accord IV	AIRBAG	2.0 (89-93)	Honda AirBag-SRS Type II MANUAL
 Accord IV	AIRBAG	2.2 (89-93)	Honda AirBag-SRS Type II MANUAL
 Accord IV	ENGINE MANAGEME	1.8 F18A2 (89-93)	Honda EFI MANUAL PGM-CARB
 Accord IV	ENGINE MANAGEME	2.0 F20A2 (89-93)	Honda EFI MANUAL PGM-CARB
 Accord IV	ENGINE MANAGEME	2.0 F20A3 (89-93)	Honda EFI MANUAL PGM-CARB
 Accord IV	ENGINE MANAGEME	2.0 F20A4 (89-93)	Honda EFI MANUAL PGM-FI
 Accord IV	ENGINE MANAGEME	2.0 F20A5 (89-93)	Honda EFI MANUAL PGM-FI
 Accord IV	ENGINE MANAGEME	2.0 F20A6 (89-93)	Honda EFI MANUAL PGM-CARB
 Accord IV	MAINTENANCE	1.8 (89-93)	Honda AirBag-SRS Type II MANUAL
 Accord IV	MAINTENANCE	1.8 F18A2 (89-93)	Honda EFI MANUAL PGM-CARB
 Accord IV	MAINTENANCE	2.0 (89-93)	Honda AirBag-SRS Type II MANUAL
 Accord IV	MAINTENANCE	2.0 F20A2 (89-93)	Honda EFI MANUAL PGM-CARB
 Accord IV	MAINTENANCE	2.0 F20A3 (89-93)	Honda EFI MANUAL PGM-CARB
 Accord IV	MAINTENANCE	2.0 F20A4 (89-93)	Honda EFI MANUAL PGM-FI
 Accord IV	MAINTENANCE	2.0 F20A5 (89-93)	Honda EFI MANUAL PGM-FI
 Accord IV	MAINTENANCE	2.0 F20A6 (89-93)	Honda EFI MANUAL PGM-CARB
 Accord IV	MAINTENANCE	2.2 (89-93)	Honda AirBag-SRS Type II MANUAL
 Accord VII	ENGINE MANAGEME	1.6 (01-02)	EOBD
 Accord VII	ENGINE MANAGEME	1.8 (01-02)	EOBD
 Accord VII	ENGINE MANAGEME	2.0 (01-02)	EOBD
 Accord VII	ENGINE MANAGEME	2.2 (01-02)	EOBD
 Accord VII	ENGINE MANAGEME	2.3 (01-02)	EOBD
 Accord VII	ENGINE MANAGEME	3.0 (01-02)	EOBD
 Accord VIII	ABS	2.0 i-VTEC 16v (02-08)	ABS/TCS
 Accord VIII	ABS	2.2 i-CTDi (02-08)	ABS/TCS
 Accord VIII	ABS	2.4 i-VTEC 16v (02-08)	ABS/TCS
 Accord VIII	ABS	3.0 V6 (02-08)	ABS/TCS
 Accord VIII	AIRBAG	2.0 i-VTEC 16v (02-08)	SRS
 Accord VIII	AIRBAG	2.2 i-CTDi (02-08)	SRS
 Accord VIII	AIRBAG	2.4 i-VTEC 16v (02-08)	SRS
 Accord VIII	AIRBAG	3.0 V6 (02-08)	SRS
 Accord VIII	CHASSIS NETWORK	2.0 i-VTEC 16v (02-08)	Body Computer MICU
 Accord VIII	CHASSIS NETWORK	2.0 i-VTEC 16v (02-08)	Power Windows
 Accord VIII	CHASSIS NETWORK	2.0 i-VTEC 16v (02-08)	Relay Module
 Accord VIII	CHASSIS NETWORK	2.2 i-CTDi (02-08)	Body Computer MICU
 Accord VIII	CHASSIS NETWORK	2.2 i-CTDi (02-08)	Power Windows
 Accord VIII	CHASSIS NETWORK	2.2 i-CTDi (02-08)	Relay Module
 Accord VIII	CHASSIS NETWORK	2.4 i-VTEC 16v (02-08)	Body Computer MICU
 Accord VIII	CHASSIS NETWORK	2.4 i-VTEC 16v (02-08)	Power Windows
 Accord VIII	CHASSIS NETWORK	2.4 i-VTEC 16v (02-08)	Relay Module
 Accord VIII	CHASSIS NETWORK	3.0 V6 (02-08)	Body Computer MICU
 Accord VIII	CHASSIS NETWORK	3.0 V6 (02-08)	Power Windows
 Accord VIII	CHASSIS NETWORK	3.0 V6 (02-08)	Relay Module
 Accord VIII	CLIMA	2.0 i-VTEC 16v (03-05)	Aircond Module
 Accord VIII	CLIMA	2.2 i-CTDi (03-05)	Aircond Module
 Accord VIII	CLIMA	2.4 i-VTEC 16v (03-05)	Aircond Module
 Accord VIII	CLIMA	3.0 V6 (03-05)	Aircond Module
 Accord VIII	ENGINE MANAGEME	2.0 i-VTEC 16v (02-08)	EOBD
 Accord VIII	ENGINE MANAGEME	2.2 i-CTDi (02-08)	EDC Common Rail
 Accord VIII	ENGINE MANAGEME	2.4 i-VTEC 16v (03-05)	EOBD
 Accord VIII	HEADLIGHT LEVEL	2.0 i-VTEC 16v (02-08)	Auto Light
 Accord VIII	HEADLIGHT LEVEL	2.2 i-CTDi (02-08)	Auto Light
 Accord VIII	HEADLIGHT LEVEL	2.4 i-VTEC 16v (02-08)	Auto Light
 Accord VIII	HEADLIGHT LEVEL	3.0 V6 (02-08)	Auto Light
 Accord VIII	SWITCHLIGHT MODU	2.0 i-VTEC 16v (02-08)	Combi
 Accord VIII	SWITCHLIGHT MODU	2.2 i-CTDi (02-08)	Combi
 Accord VIII	SWITCHLIGHT MODU	2.4 i-VTEC 16v (02-08)	Combi

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Honda

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Accord VIII	SWITCHLIGHT MODU	3.0 V6 (02-08)	Combi
 Accord V-VI	ABS	1.8 (93-97)	Honda ABS MANUAL ALB
 Accord V-VI	ABS	2.0 (93-97)	Honda ABS MANUAL ALB
 Accord V-VI	ABS	2.0 TD (93-97)	Honda ABS MANUAL ALB
 Accord V-VI	ABS	2.2 (93-97)	Honda ABS MANUAL ALB
 Accord V-VI	ABS	2.3 (93-97)	Honda ABS MANUAL ALB
 Accord V-VI	ENGINE MANAGEME	1.8 (93-97)	Honda EFI MANUAL PGM-FI
 Accord V-VI	ENGINE MANAGEME	2.0 (93-97)	Honda EFI MANUAL PGM-FI
 Accord V-VI	ENGINE MANAGEME	2.0 TD (93-97)	Honda EFI MANUAL PGM-FI
 Accord V-VI	ENGINE MANAGEME	2.0 TD 20T2N (93-97)	BOSCH MSA11 MANUAL
 Accord V-VI	ENGINE MANAGEME	2.2 (93-97)	Honda EFI MANUAL PGM-FI
 Accord V-VI	ENGINE MANAGEME	2.3 (93-97)	Honda EFI MANUAL PGM-FI
 Accord V-VI	MAINTENANCE	1.8 (93-97)	Honda ABS MANUAL ALB
 Accord V-VI	MAINTENANCE	1.8 (93-97)	Honda EFI MANUAL PGM-FI
 Accord V-VI	MAINTENANCE	2.0 (93-97)	Honda ABS MANUAL ALB
 Accord V-VI	MAINTENANCE	2.0 (93-97)	Honda EFI MANUAL PGM-FI
 Accord V-VI	MAINTENANCE	2.0 TD (93-97)	Honda ABS MANUAL ALB
 Accord V-VI	MAINTENANCE	2.0 TD (93-97)	Honda EFI MANUAL PGM-FI
 Accord V-VI	MAINTENANCE	2.0 TD 20T2N (93-97)	BOSCH MSA11 MANUAL
 Accord V-VI	MAINTENANCE	2.2 (93-97)	Honda ABS MANUAL ALB
 Accord V-VI	MAINTENANCE	2.2 (93-97)	Honda EFI MANUAL PGM-FI
 Accord V-VI	MAINTENANCE	2.3 (93-97)	Honda ABS MANUAL ALB
 Accord V-VI	MAINTENANCE	2.3 (93-97)	Honda EFI MANUAL PGM-FI
 Civic 2p	ENGINE MANAGEME	1.3 16v D13B2 (92-96)	Honda EFI MANUAL PGM-CARB
 Civic 2p	MAINTENANCE	1.3 16v D13B2 (92-96)	Honda EFI MANUAL PGM-CARB
 Civic 2p-4p	AIRBAG	(92-96)	Honda AirBag-SRS MANUAL
 Civic 2p-4p	MAINTENANCE	(92-96)	Honda AirBag-SRS MANUAL
 Civic Coupe'	ENGINE MANAGEME	1.7 88kw (01-..)	EOBD
 Civic Coupe'	ENGINE MANAGEME	1.7 92kw (01-..)	EOBD
 Civic	ENGINE MANAGEME	1.4 55kw (91-00)	Honda EFI MANUAL PGM-FI
 Civic	ENGINE MANAGEME	1.4 61kw (06-..)	EOBD
 Civic	ENGINE MANAGEME	1.6 81kw (01-..)	EOBD
 Civic	ENGINE MANAGEME	1.6 81kw (91-00)	Honda EFI MANUAL PGM-FI
 Civic	ENGINE MANAGEME	2.0 147kw (01-..)	EOBD
 Civic	ENGINE MANAGEME	2.0 147kw (91-00)	Honda EFI MANUAL PGM-FI
 Civic	ENGINE MANAGEME	2.2 i-CTDi	EDC Common Rail
 Civic	MAINTENANCE	1.4 55kw (91-00)	Honda EFI MANUAL PGM-FI
 Civic	MAINTENANCE	1.6 81kw (91-00)	Honda EFI MANUAL PGM-FI
 Civic	MAINTENANCE	2.0 147kw (91-00)	Honda EFI MANUAL PGM-FI
 CR-V	ABS	2.0 i-VTEC (07-..)	ABS
 CR-V	ABS	2.2 i-CTDi (07-..)	ABS
 CR-V	ENGINE MANAGEME	2.0 i-VTEC (01-02)	EOBD
 CR-V	ENGINE MANAGEME	2.0 i-VTEC (07-..)	EOBD
 CR-V	ENGINE MANAGEME	2.2 i-CTDi (07-..)	EDC Common Rail
 CRX	ENGINE MANAGEME	1.6 16v i-VTEC B16A2 (92-94)	Honda EFI MANUAL PGM-FI
 CRX	ENGINE MANAGEME	1.6 16v i-VTEC D16Z6 (92-94)	Honda EFI MANUAL PGM-FI
 CRX	ENGINE MANAGEME	1.6 16v i-VTEC D16Z7 (92-94)	Honda EFI MANUAL PGM-FI
 CRX	MAINTENANCE	1.6 16v i-VTEC B16A2 (92-94)	Honda EFI MANUAL PGM-FI
 CRX	MAINTENANCE	1.6 16v i-VTEC D16Z6 (92-94)	Honda EFI MANUAL PGM-FI
 CRX	MAINTENANCE	1.6 16v i-VTEC D16Z7 (92-94)	Honda EFI MANUAL PGM-FI
 FR-V	ENGINE MANAGEME	2.2 i-CTDi	EDC Common Rail
 HR-V	ENGINE MANAGEME	1.6 D16W1 (01-..)	Honda EFI PGM-FI
 HR-V	ENGINE MANAGEME	1.6 i-VTEC 91kw (01-..)	EOBD
 Jazz	ENGINE MANAGEME	1.4 61kw (01-..)	EOBD
 Legend	ABS	3.5 V6 (.-96)	Honda ABS MANUAL ALB
 Legend	ENGINE MANAGEME	3.5 V6 (91-..)	Honda EFI MANUAL PGM-FI

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Honda

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Legend	ENGINE MANAGEME	3.5 V6 C35A2 (01-..)	Honda EFI PGM-FI
 Legend	MAINTENANCE	3.5 V6 (..-96)	Honda ABS MANUAL ALB
 Legend	MAINTENANCE	3.5 V6 (91-..)	Honda EFI MANUAL PGM-FI
 Logo	ENGINE MANAGEME	1.3 D13B7 (01-..)	Honda EFI PGM-FI
 NSX	ENGINE MANAGEME	188kw F-Matic (01-..)	EOBD
 NSX	ENGINE MANAGEME	3.2 C32B2 (01-..)	Honda EFI PGM-FI
 Prelude	ABS	2.0 (..-96)	Honda ABS MANUAL ALB
 Prelude	ABS	2.2 (..-96)	Honda ABS MANUAL ALB
 Prelude	ABS	2.2 i-VTEC (..-96)	Honda ABS MANUAL ALB
 Prelude	ABS	2.3 (..-96)	Honda ABS MANUAL ALB
 Prelude	ENGINE MANAGEME	2.0 B20A7 (88-94)	Honda EFI MANUAL PGM-FI
 Prelude	ENGINE MANAGEME	2.2 F22A1 (88-94)	Honda EFI MANUAL PGM-FI
 Prelude	ENGINE MANAGEME	2.2 F22A2 (88-94)	Honda EFI MANUAL PGM-FI
 Prelude	ENGINE MANAGEME	2.2 H22A2 (88-94)	Honda EFI MANUAL PGM-FI
 Prelude	ENGINE MANAGEME	2.2 i-VTEC H22A1 (88-94)	Honda EFI MANUAL PGM-FI
 Prelude	ENGINE MANAGEME	2.3 F23A1 (88-94)	Honda EFI MANUAL PGM-FI
 Prelude	MAINTENANCE	2.0 (..-96)	Honda ABS MANUAL ALB
 Prelude	MAINTENANCE	2.0 B20A7 (88-94)	Honda EFI MANUAL PGM-FI
 Prelude	MAINTENANCE	2.2 (..-96)	Honda ABS MANUAL ALB
 Prelude	MAINTENANCE	2.2 F22A1 (88-94)	Honda EFI MANUAL PGM-FI
 Prelude	MAINTENANCE	2.2 F22A2 (88-94)	Honda EFI MANUAL PGM-FI
 Prelude	MAINTENANCE	2.2 H22A2 (88-94)	Honda EFI MANUAL PGM-FI
 Prelude	MAINTENANCE	2.2 i-VTEC (..-96)	Honda ABS MANUAL ALB
 Prelude	MAINTENANCE	2.2 i-VTEC H22A1 (88-94)	Honda EFI MANUAL PGM-FI
 Prelude	MAINTENANCE	2.3 (..-96)	Honda ABS MANUAL ALB
 Prelude	MAINTENANCE	2.3 F23A1 (88-94)	Honda EFI MANUAL PGM-FI
 S2000	ENGINE MANAGEME	2.0 DOHC i-VTEC F20C (01-..)	Honda EFI PGM-FI
 Stream	ENGINE MANAGEME	1.7 92kw (01-..)	EOBD
 Stream	ENGINE MANAGEME	2.0 115kw (01-..)	EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Hyundai

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Accent	ABS	1.4 16v (06-..)	MANDO ABS
 Accent	ABS	1.5 CRDi (06-..)	MANDO ABS
 Accent	AIRBAG	1.3 (01-..)	SRS
 Accent	AIRBAG	1.5 (01-..)	SRS
 Accent	AIRBAG	1.5 CRDi (01-..)	SRS
 Accent	CLIMA	1.4 16v (06-..)	AutoClima
 Accent	CLIMA	1.5 CRDi (06-..)	AutoClima
 Accent	ENGINE MANAGEME	1.3 (01-..)	EOBD
 Accent	ENGINE MANAGEME	1.3 (01-..)	KEFICO MPI
 Accent	ENGINE MANAGEME	1.5 (01-..)	EOBD
 Accent	ENGINE MANAGEME	1.5 CRDi (01-..)	BOSCH EDC
 Accent	ENGINE MANAGEME	1.5 CRDi (06-..)	BOSCH EDC Common Rail
 Atos Prime GLS	ENGINE MANAGEME	1.0 (01-..)	EOBD
 Atos	ABS	1.1 12v (06-..)	ABS
 Atos	AIRBAG	1.1 12v (06-..)	AirBag
 Atos	ENGINE MANAGEME	1.0 (99-00)	
 Atos	ENGINE MANAGEME	1.1 12v (06-..)	MPI
 Atos	IMMOBILIZER	1.1 12v (06-..)	
 Coupe	ABS	1.6 i 16v (00-..)	MANDO ABS 4/4 HMC
 Coupe	ABS	2.0 i 16v (00-..)	MANDO ABS 4/4 HMC
 Coupe	ABS	2.7 i V6 24v (00-..)	MANDO ABS 4/4 HMC
 Coupe	ENGINE MANAGEME	2.0 i 16v (01-..)	EOBD
 Elantra	ENGINE MANAGEME	2.0 CRDi (01-..)	BOSCH EDC
 Getz	ABS	1.1 12v (06-..)	MANDO ABS
 Getz	ABS	1.3 12v (06-..)	MANDO ABS
 Getz	ABS	1.4 16v (06-..)	MANDO ABS
 Getz	ABS	1.5 16v CRDi (06-..)	MANDO ABS
 Getz	ABS	1.5 CRDi (06-..)	MANDO ABS
 Getz	AIRBAG	1.1 12v (06-..)	SRS
 Getz	AIRBAG	1.3 12v (06-..)	SRS
 Getz	AIRBAG	1.4 16v (06-..)	SRS
 Getz	AIRBAG	1.5 16v CRDi (06-..)	SRS
 Getz	AIRBAG	1.5 CRDi (06-..)	SRS
 Getz	CLIMA	1.1 12v (06-..)	AutoClima
 Getz	CLIMA	1.3 12v (06-..)	AutoClima
 Getz	CLIMA	1.4 16v (06-..)	AutoClima
 Getz	CLIMA	1.5 16v CRDi (06-..)	AutoClima
 Getz	CLIMA	1.5 CRDi (06-..)	AutoClima
 Getz	ELECTRIC STEERING	1.1 12v (06-..)	
 Getz	ELECTRIC STEERING	1.3 12v (06-..)	
 Getz	ELECTRIC STEERING	1.4 16v (06-..)	
 Getz	ELECTRIC STEERING	1.5 16v CRDi (06-..)	
 Getz	ELECTRIC STEERING	1.5 CRDi (06-..)	
 Getz	ENGINE MANAGEME	1.1 12v (06-..)	EOBD
 Getz	ENGINE MANAGEME	1.3 12v (06-..)	MPI
 Getz	ENGINE MANAGEME	1.4 16v (06-..)	EOBD
 Getz	ENGINE MANAGEME	1.5 16v CRDi (06-..)	BOSCH EDC Common Rail
 Getz	ENGINE MANAGEME	1.5 CRDi (01-..)	BOSCH EDC
 H-1 Starex	ENGINE MANAGEME	2.4 (01-..)	EOBD
 I 30	ELECTRIC STEERING	1.4 16v (07-..)	EPS
 I 30	ELECTRIC STEERING	1.6 16v (07-..)	EPS
 I 30	ELECTRIC STEERING	1.6 16v CRDi VGT 116cv DPF (07-..)	EPS
 I 30	ELECTRIC STEERING	1.6 16v CRDi VGT 90cv (07-..)	EPS
 I 30	ELECTRIC STEERING	1.6 16v CRDi VGT 90cv DPF (07-..)	EPS
 I 30	ENGINE MANAGEME	1.4 16v (07-..)	EOBD
 I 30	ENGINE MANAGEME	1.6 16v (07-..)	EOBD
 I 30	ENGINE MANAGEME	1.6 16v CRDi VGT 116cv DPF (07-..)	EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Hyundai

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 I 30	ENGINE MANAGEME	1.6 16v CRDi VGT 90cv (07-..)	BOSCH EDC Common Rail
 I 30	ENGINE MANAGEME	1.6 16v CRDi VGT 90cv DPF (07-..)	EOBD
 I 30	IMMOBILIZER	1.4 16v (07-..)	
 I 30	IMMOBILIZER	1.6 16v (07-..)	
 I 30	IMMOBILIZER	1.6 16v CRDi VGT 116cv DPF (07-..)	
 I 30	IMMOBILIZER	1.6 16v CRDi VGT 90cv (07-..)	
 I 30	IMMOBILIZER	1.6 16v CRDi VGT 90cv DPF (07-..)	
 I 30	TIRE PRESSURE	1.4 16v (07-..)	
 I 30	TIRE PRESSURE	1.6 16v (07-..)	
 I 30	TIRE PRESSURE	1.6 16v CRDi VGT 116cv DPF (07-..)	
 I 30	TIRE PRESSURE	1.6 16v CRDi VGT 90cv (07-..)	
 I 30	TIRE PRESSURE	1.6 16v CRDi VGT 90cv DPF (07-..)	
 Lantra	ENGINE MANAGEME	1.5 G4-J (91-95)	Mitsubishi MFI-s MANUAL ECI-Multi
 Lantra	ENGINE MANAGEME	1.6 (01-..)	EOBD
 Lantra	ENGINE MANAGEME	1.6 G4-R (91-95)	Mitsubishi MFI-s MANUAL ECI-Multi
 Lantra	ENGINE MANAGEME	2.0 (01-..)	EOBD
 Lantra	MAINTENANCE	1.5 G4-J (91-95)	Mitsubishi MFI-s MANUAL ECI-Multi
 Lantra	MAINTENANCE	1.6 G4-R (91-95)	Mitsubishi MFI-s MANUAL ECI-Multi
 Matrix	ABS	1.5 CRDi (01-..)	MANDO ABS 4/4 HMC
 Matrix	ABS	1.6 i 16v (01-..)	MANDO ABS 4/4 HMC
 Matrix	ABS	1.8 i 16v (01-..)	MANDO ABS 4/4 HMC
 Matrix	AIRBAG	1.5 CRDi (01-..)	SRS AirBag
 Matrix	AIRBAG	1.6 i 16v (01-..)	SRS AirBag
 Matrix	AIRBAG	1.8 i 16v (01-..)	SRS AirBag
 Matrix	ENGINE MANAGEME	1.5 CRDi (01-..)	BOSCH EDC
 Matrix	ENGINE MANAGEME	1.6 i 16v (01-..)	EOBD
 Matrix	ENGINE MANAGEME	1.8 i 16v (01-..)	EOBD
 Santa Fe	4WD ELECTRONICS	2.0 16v (06-..)	4WD
 Santa Fe	4WD ELECTRONICS	2.0 16v CRDi (06-..)	4WD
 Santa Fe	4WD ELECTRONICS	2.7 V6 (06-..)	4WD
 Santa Fe	ABS	2.0 CRDi (01-..)	MANDO ABS 4/4 HMC
 Santa Fe	ABS	2.4 i (01-..)	MANDO ABS 4/4 HMC
 Santa Fe	ABS	2.7 i V6 24v (01-..)	MANDO ABS 4/4 HMC
 Santa Fe	ABS + TRACT. CONT	2.0 16v (06-..)	MANDO ABS
 Santa Fe	ABS + TRACT. CONT	2.0 16v CRDi (06-..)	MANDO ABS
 Santa Fe	ABS + TRACT. CONT	2.7 V6 (06-..)	MANDO ABS
 Santa Fe	AIRBAG	2.0 16v (06-..)	AirBag
 Santa Fe	AIRBAG	2.0 16v CRDi (06-..)	AirBag
 Santa Fe	AIRBAG	2.0 CRDi (01-..)	SRS
 Santa Fe	AIRBAG	2.4 i (01-..)	SRS
 Santa Fe	AIRBAG	2.7 i V6 24v (01-..)	SRS
 Santa Fe	AIRBAG	2.7 V6 (06-..)	AirBag
 Santa Fe	AUTOM. TRANSMISSI	2.0 CRDi (01-..)	A/T
 Santa Fe	AUTOM. TRANSMISSI	2.4 i (01-..)	A/T
 Santa Fe	AUTOM. TRANSMISSI	2.7 i V6 24v (01-..)	A/T
 Santa Fe	CHASSIS NETWORK	2.0 16v (06-..)	Body Computer ETACS
 Santa Fe	CHASSIS NETWORK	2.0 16v CRDi (06-..)	Body Computer ETACS
 Santa Fe	CHASSIS NETWORK	2.7 V6 (06-..)	Body Computer ETACS
 Santa Fe	CLIMA	2.0 16v (06-..)	Klimautomatik
 Santa Fe	CLIMA	2.0 16v CRDi (06-..)	Klimautomatik
 Santa Fe	CLIMA	2.7 V6 (06-..)	Klimautomatik
 Santa Fe	ENGINE MANAGEME	2.0 16v (06-..)	EOBD
 Santa Fe	ENGINE MANAGEME	2.0 16v CRDi (06-..)	BOSCH EDC Common Rail
 Santa Fe	ENGINE MANAGEME	2.0 16v CRDi (06-..)	EOBD
 Santa Fe	ENGINE MANAGEME	2.0 CRDi (01-..)	BOSCH EDC
 Santa Fe	ENGINE MANAGEME	2.4 i G4JS (01-..)	EOBD
 Santa Fe	ENGINE MANAGEME	2.7 i V6 24v (01-..)	EOBD
 Santa Fe	ENGINE MANAGEME	2.7 V6 (06-..)	EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Hyundai

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Scoupe	ENGINE MANAGEME	1.5 G4-E (92-95)	Bosch Motronic MANUAL
 Scoupe	ENGINE MANAGEME	1.5 T G4-E (92-95)	Chang Won Carb-2v MANUAL 30-32
 Scoupe	MAINTENANCE	1.5 G4-E (92-95)	Bosch Motronic MANUAL
 Scoupe	MAINTENANCE	1.5 T G4-E (92-95)	Chang Won Carb-2v MANUAL 30-32
 Sonata/Sonica	ENGINE MANAGEME	2.0 (01-..)	EOBD
 Sonata/Sonica	ENGINE MANAGEME	2.7 (01-..)	EOBD
 Trajet	ENGINE MANAGEME	2.0 (00-..)	EOBD
 Trajet	ENGINE MANAGEME	2.0 CRDi (01-..)	BOSCH EDC
 Trajet	ENGINE MANAGEME	2.7 (01-..)	EOBD
 Tucson	4WD ELECTRONICS	2.0 16v (05-..)	4WD
 Tucson	4WD ELECTRONICS	2.0 16v CRDi (05-..)	4WD
 Tucson	4WD ELECTRONICS	2.7 V6 (05-..)	4WD
 Tucson	ABS + TRACT. CONT	2.0 16v (05-..)	MANDO ABS
 Tucson	ABS + TRACT. CONT	2.0 16v CRDi (05-..)	MANDO ABS
 Tucson	ABS + TRACT. CONT	2.7 V6 (05-..)	MANDO ABS
 Tucson	AIRBAG	2.0 16v (05-..)	AirBag
 Tucson	AIRBAG	2.0 16v CRDi (05-..)	AirBag
 Tucson	AIRBAG	2.7 V6 (05-..)	AirBag
 Tucson	CHASSIS NETWORK	2.0 16v (05-..)	Body Computer ETACS
 Tucson	CHASSIS NETWORK	2.0 16v CRDi (05-..)	Body Computer ETACS
 Tucson	CHASSIS NETWORK	2.7 V6 (05-..)	Body Computer ETACS
 Tucson	CLIMA	2.0 16v (05-05)	Klimautomatik
 Tucson	CLIMA	2.0 16v CRDi (05-05)	Klimautomatik
 Tucson	CLIMA	2.7 V6 (05-05)	Klimautomatik
 Tucson	ENGINE MANAGEME	2.0 16v (05-..)	EOBD
 Tucson	ENGINE MANAGEME	2.0 16v CRDi (05-..)	BOSCH EDC
 Tucson	ENGINE MANAGEME	2.0 16v CRDi (05-..)	EOBD
 Tucson	ENGINE MANAGEME	2.7 V6 (05-..)	EOBD
 XG	ENGINE MANAGEME	3.0 (01-..)	EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Innocenti

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Elba	ELECTRONIC INJECT	1.5 Kat	BOSCH MonoJetronic A2.4

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Isuzu

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Piazza	ENGINE MANAGEME	2.0 T 4ZC1-T	Isuzu MFI-i MANUAL I-TEC
 Piazza	MAINTENANCE	2.0 T 4ZC1-T	Isuzu MFI-i MANUAL I-TEC
 Trooper	ENGINE MANAGEME	4ZE1	Isuzu MFI-i MANUAL I-TEC
 Trooper	MAINTENANCE	4ZE1	Isuzu MFI-i MANUAL I-TEC

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Daily & TurboDaily	ABS + TRACT. CONT	29 L 10 FIAE0481A	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	29 L 11 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	29 L 12 FIAE0481B	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	29 L 9 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	35 C 10 FIAE0481A	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	35 C 11 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	35 C 12 FIAE0481B	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	35 C 13 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	35 C 9 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	35 L 9 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	35 S 11 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	35 S 12 FIAE0481B	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	35 S 13 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	40 C 10 FIAE0481A	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	40 C 11 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	40 C 12 FIAE0481B	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	40 C 13 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	40 C 9 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	65 C 15 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	AIRBAG	2.3 HPI 16v	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	2.3 Unijet	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	2.8 Unijet	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	29 L 10	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	29 L 11	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	29 L 12	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	29 L 9	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	35 C 10	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	35 C 11	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	35 C 12	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	35 C 13	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	35 C 9	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	35 L 9	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	35 S 11	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	35 S 12	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	35 S 13	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	40 C 10	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	40 C 11	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	40 C 12	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	40 C 13	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	40 C 9	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	65 C 15	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	CLIMA	2.3 HPI 16v (...-02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	2.3 Unijet (...-02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	2.3 Unijet (02-05)	Marelli
 Daily & TurboDaily	CLIMA	2.8 Unijet (...-02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	2.8 Unijet (02-05)	Marelli
 Daily & TurboDaily	CLIMA	29 L 10 (...-02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	29 L 11 (...-02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	29 L 12 (...-02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	29 L 9 (...-02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	35 C 10 (...-02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	35 C 11 (...-02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	35 C 12 (...-02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	35 C 13 (...-02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	35 C 9 (...-02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	35 L 9 (...-02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	35 S 11 (...-02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	35 S 12 (...-02)	Marelli A/C Clima

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Daily & TurboDaily	CLIMA	35 S 13 (.-02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	40 C 10 (.-02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	40 C 11 (.-02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	40 C 12 (.-02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	40 C 13 (.-02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	40 C 9 (.-02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	65 C 15 (.-02)	Marelli A/C Clima
 Daily & TurboDaily	ENGINE MANAGEME	2.3 HPI 16v F1AE0481A	BOSCH EDC 16 Common Rail
 Daily & TurboDaily	ENGINE MANAGEME	2.3 HPI 16v F1AE0481B	BOSCH EDC 16 Common Rail
 Daily & TurboDaily	ENGINE MANAGEME	2.3 Unijet (02-06)	BOSCH EDC MS6.3
 Daily & TurboDaily	ENGINE MANAGEME	2.8 Unijet 8140 (00-04)	BOSCH EDC MS6.3
 Daily & TurboDaily	IMMOBILIZER	2.3 HPI 16v	BOSCH
 Daily & TurboDaily	IMMOBILIZER	2.3 Unijet	
 Daily & TurboDaily	IMMOBILIZER	2.3 Unijet	BOSCH
 Daily & TurboDaily	IMMOBILIZER	2.8 Unijet	BOSCH
 Daily & TurboDaily	IMMOBILIZER	29 L 10	BOSCH
 Daily & TurboDaily	IMMOBILIZER	29 L 11	BOSCH
 Daily & TurboDaily	IMMOBILIZER	29 L 12	BOSCH
 Daily & TurboDaily	IMMOBILIZER	29 L 9	BOSCH
 Daily & TurboDaily	IMMOBILIZER	35 C 10	BOSCH
 Daily & TurboDaily	IMMOBILIZER	35 C 11	BOSCH
 Daily & TurboDaily	IMMOBILIZER	35 C 12	BOSCH
 Daily & TurboDaily	IMMOBILIZER	35 C 13	BOSCH
 Daily & TurboDaily	IMMOBILIZER	35 C 9	BOSCH
 Daily & TurboDaily	IMMOBILIZER	35 L 9	BOSCH
 Daily & TurboDaily	IMMOBILIZER	35 S 11	BOSCH
 Daily & TurboDaily	IMMOBILIZER	35 S 12	BOSCH
 Daily & TurboDaily	IMMOBILIZER	35 S 13	BOSCH
 Daily & TurboDaily	IMMOBILIZER	40 C 10	BOSCH
 Daily & TurboDaily	IMMOBILIZER	40 C 11	BOSCH
 Daily & TurboDaily	IMMOBILIZER	40 C 12	BOSCH
 Daily & TurboDaily	IMMOBILIZER	40 C 13	BOSCH
 Daily & TurboDaily	IMMOBILIZER	40 C 9	BOSCH
 Daily & TurboDaily	IMMOBILIZER	65 C 15	BOSCH
 Daily & TurboDaily	KEY ENCODE	2.3 HPI 16v	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	2.3 Unijet	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	2.8 Unijet	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	29 L 10	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	29 L 11	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	29 L 12	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	29 L 9	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	35 C 10	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	35 C 11	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	35 C 12	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	35 C 13	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	35 C 9	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	35 L 9	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	35 S 11	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	35 S 12	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	35 S 13	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	40 C 10	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	40 C 11	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	40 C 12	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	40 C 13	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	40 C 9	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	65 C 15	BOSCH CODE
 New Daily	ABS + TRACT. CONT	2.3 HPI 116cv	BOSCH ABS 8
 New Daily	ABS + TRACT. CONT	2.3 HPI 96cv	BOSCH ABS 8

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 New Daily	ABS + TRACT. CONT	2.3 HPT 136cv	BOSCH ABS 8
 New Daily	ABS + TRACT. CONT	3.0 CNG	BOSCH ABS 8
 New Daily	ABS + TRACT. CONT	3.0 HPI	BOSCH ABS 8
 New Daily	ABS + TRACT. CONT	3.0 HPT	BOSCH ABS 8
 New Daily	AIRBAG	2.3 HPI 116cv (07-..)	AB/SRS
 New Daily	AIRBAG	2.3 HPI 96cv (07-..)	AB/SRS
 New Daily	AIRBAG	2.3 HPT 136cv (07-..)	AB/SRS
 New Daily	AIRBAG	3.0 CNG (07-..)	AB/SRS
 New Daily	AIRBAG	3.0 HPI (07-..)	AB/SRS
 New Daily	AIRBAG	3.0 HPT (07-..)	AB/SRS
 New Daily	CHASSIS NETWORK	2.3 HPI 116cv	
 New Daily	CHASSIS NETWORK	2.3 HPI 96cv	
 New Daily	CHASSIS NETWORK	2.3 HPT 136cv	
 New Daily	CHASSIS NETWORK	3.0 CNG	
 New Daily	CHASSIS NETWORK	3.0 HPI	
 New Daily	CHASSIS NETWORK	3.0 HPT	
 New Daily	DASHBOARD	2.3 HPI 116cv	Marelli
 New Daily	DASHBOARD	2.3 HPI 96cv	Marelli
 New Daily	DASHBOARD	2.3 HPT 136cv	Marelli
 New Daily	DASHBOARD	3.0 CNG	Marelli
 New Daily	DASHBOARD	3.0 HPI	Marelli
 New Daily	DASHBOARD	3.0 HPT	Marelli
 New Daily	DPF REGENERATION	2.3 HPI 116cv	BOSCH EDC Common Rail 16 C 39 DPF
 New Daily	DPF REGENERATION	2.3 HPI 96cv	BOSCH EDC Common Rail 16 C 39 DPF
 New Daily	DPF REGENERATION	2.3 HPT 136cv	BOSCH EDC Common Rail 16 C 39 DPF
 New Daily	DPF REGENERATION	3.0 HPI F1CE0481H	BOSCH EDC Common Rail 16 C 39 DPF
 New Daily	DPF REGENERATION	3.0 HPT	BOSCH EDC Common Rail 16 C 39 DPF
 New Daily	ENGINE MANAGEME	2.3 HPI 116cv	BOSCH EDC 16 Common Rail
 New Daily	ENGINE MANAGEME	2.3 HPI 96cv	BOSCH EDC 16 Common Rail
 New Daily	ENGINE MANAGEME	2.3 HPT 136cv	BOSCH EDC 16 Common Rail
 New Daily	ENGINE MANAGEME	3.0 HPI	BOSCH EDC 16 Common Rail
 New Daily	ENGINE MANAGEME	3.0 HPI F1CE0481H	BOSCH EDC Common Rail 16 C 39 DPF
 New Daily	ENGINE MANAGEME	3.0 HPT	BOSCH EDC 16 Common Rail
 New Daily	MAINTENANCE	2.3 HPI 116cv	BOSCH EDC Common Rail 16 C 39 DPF
 New Daily	MAINTENANCE	2.3 HPI 116cv	BOSCH EDC Common Rail 16 C 39 DPF
 New Daily	MAINTENANCE	2.3 HPI 96cv	BOSCH EDC Common Rail 16 C 39 DPF
 New Daily	MAINTENANCE	2.3 HPI 96cv	BOSCH EDC Common Rail 16 C 39 DPF
 New Daily	MAINTENANCE	2.3 HPT 136cv	BOSCH EDC Common Rail 16 C 39 DPF
 New Daily	MAINTENANCE	2.3 HPT 136cv	BOSCH EDC Common Rail 16 C 39 DPF
 New Daily	MAINTENANCE	3.0 HPI F1CE0481H	BOSCH EDC Common Rail 16 C 39 DPF
 New Daily	MAINTENANCE	3.0 HPI F1CE0481H	BOSCH EDC Common Rail 16 C 39 DPF
 New Daily	MAINTENANCE	3.0 HPT	BOSCH EDC Common Rail 16 C 39 DPF
 New Daily	MAINTENANCE	3.0 HPT	BOSCH EDC Common Rail 16 C 39 DPF

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Jaguar

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 S-Type	ENGINE MANAGEME	2.5 V6 147kw (01-..)	EOBD
 S-Type	ENGINE MANAGEME	3.0 V6 FC (01-..)	EOBD
 S-Type	ENGINE MANAGEME	4.2 V8 219kw (01-..)	EOBD
 S-Type	ENGINE MANAGEME	4.2 V8 291kw (01-..)	EOBD
 XJ	ENGINE MANAGEME	3.2 V8 179kw (01-..)	EOBD
 XJ	MAINTENANCE	2.7 TD V6 (03-07)	
 XJ	MAINTENANCE	3.0 V6 (03-07)	
 XJ	MAINTENANCE	3.5 V8 (03-07)	
 XJ	MAINTENANCE	4.2 V8 (03-07)	
 XJ	SERVICE LIGHT RES	2.7 TD V6 (03-07)	
 XJ	SERVICE LIGHT RES	3.0 V6 (03-07)	
 XJ	SERVICE LIGHT RES	3.5 V8 (03-07)	
 XJ	SERVICE LIGHT RES	4.2 V8 (03-07)	
 XJ8 Sovereign	ENGINE MANAGEME	4.0 V8 216kw (01-..)	EOBD
 XJR Supercharged	ENGINE MANAGEME	4.0 V8 276 kw (01-..)	EOBD
 XK8	ENGINE MANAGEME	4.0 V8 216kw (01-..)	EOBD
 XKR	ENGINE MANAGEME	4.2 V8 291kw (01-..)	EOBD
 X-Type	AIRBAG	2.0 TD (03-..)	Autoliv SRS ARM
 X-Type	AIRBAG	2.1 V6 115kw (03-..)	Autoliv SRS ARM
 X-Type	AIRBAG	2.5 V6 144kw (03-..)	Autoliv SRS ARM
 X-Type	AIRBAG	3.0 V6 169 kw (03-..)	Autoliv SRS ARM
 X-Type	ENGINE MANAGEME	2.0 TD 6B (03-..)	DELPHI EDC Common Rail
 X-Type	ENGINE MANAGEME	2.1 V6 115kw (01-..)	EOBD
 X-Type	ENGINE MANAGEME	2.5 V6 144kw (01-..)	EOBD
 X-Type	ENGINE MANAGEME	3.0 V6 169 kw (01-..)	EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Jeep

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Cherokee	ABS + TRACT. CONT	2.8 CRD (08-..)	TEVES ABS
 Cherokee	ABS + TRACT. CONT	3.7 V6 (08-..)	TEVES ABS
 Cherokee	ENGINE MANAGEME	2.4 110kw (01-..)	EOBD
 Cherokee	ENGINE MANAGEME	2.5 CRD Common rail 105kw (04-..)	EOBD
 Cherokee	ENGINE MANAGEME	3.7 155kw (01-..)	EOBD
 Cherokee	MAINTENANCE	2.8 CRD (08-..)	TEVES ABS
 Cherokee	MAINTENANCE	3.7 V6 (08-..)	TEVES ABS
 Commander	MAINTENANCE	3.0 V6 CRD (06-..)	MANUAL
 Commander	MAINTENANCE	4.7 V8 (06-..)	MANUAL
 Commander	MAINTENANCE	5.7 V8 HEMI (06-..)	MANUAL
 Commander	SERVICE LIGHT RES	3.0 V6 CRD (06-..)	MANUAL
 Commander	SERVICE LIGHT RES	4.7 V8 (06-..)	MANUAL
 Commander	SERVICE LIGHT RES	5.7 V8 HEMI (06-..)	MANUAL
 Compass	4WD ELECTRONICS	2.0 Turbodiesel (07-..)	AWD
 Compass	4WD ELECTRONICS	2.4 L (07-..)	AWD
 Compass	AIRBAG	2.0 Turbodiesel (07-..)	TRW ORC
 Compass	AIRBAG	2.4 L (07-..)	TRW ORC
 Compass	CHASSIS NETWORK	2.0 Turbodiesel (07-..)	Central Gateway
 Compass	CHASSIS NETWORK	2.4 L (07-..)	Central Gateway
 Compass	DASHBOARD	2.0 Turbodiesel (07-..)	CCN
 Compass	DASHBOARD	2.4 L (07-..)	CCN
 Compass	ELECTRIC STEERING	2.0 Turbodiesel (07-..)	EPS
 Compass	ELECTRIC STEERING	2.4 L (07-..)	EPS
 Compass	ENGINE MANAGEME	2.0 Turbodiesel (07-..)	BOSCH EDC Common Rail
 Compass	ENGINE MANAGEME	2.4 L (07-..)	EOBD
 Compass	RADIO / CD	2.0 Turbodiesel (07-..)	
 Compass	RADIO / CD	2.4 L (07-..)	
 Grand Cherokee MY 05	MAINTENANCE	3.0 V6 CRD (05-..)	MANUAL
 Grand Cherokee MY 05	MAINTENANCE	3.7 V6 (05-..)	MANUAL
 Grand Cherokee MY 05	MAINTENANCE	4.7 V8 (05-..)	MANUAL
 Grand Cherokee MY 05	MAINTENANCE	5.7 V8 (05-..)	MANUAL
 Grand Cherokee MY 05	MAINTENANCE	6.1 V8 (05-..)	MANUAL
 Grand Cherokee MY 05	SERVICE LIGHT RES	3.0 V6 CRD (05-..)	MANUAL
 Grand Cherokee MY 05	SERVICE LIGHT RES	3.7 V6 (05-..)	MANUAL
 Grand Cherokee MY 05	SERVICE LIGHT RES	4.7 V8 (05-..)	MANUAL
 Grand Cherokee MY 05	SERVICE LIGHT RES	5.7 V8 (05-..)	MANUAL
 Grand Cherokee MY 05	SERVICE LIGHT RES	6.1 V8 (05-..)	MANUAL
 Grand Cherokee	AUTOM. TRANSMISSI	2.7 CRD Common Rail 120kw (99-04	BOSCH EGS
 Grand Cherokee	AUTOM. TRANSMISSI	4.0 (99-04)	BOSCH EGS
 Grand Cherokee	AUTOM. TRANSMISSI	4.7 V8 (99-04)	BOSCH EGS
 Grand Cherokee	ENGINE MANAGEME	2.7 CRD Common Rail 120kw (04-..)	EOBD
 Grand Cherokee	ENGINE MANAGEME	2.7 CRD Common Rail 120kw (99-04	BOSCH
 Grand Cherokee	ENGINE MANAGEME	4.0 (01-..)	EOBD
 Grand Cherokee	ENGINE MANAGEME	4.7 V8 164kw (01-..)	EOBD
 Grand Cherokee	ENGINE MANAGEME	4.7 V8 190kw (01-..)	EOBD
 Grand Cherokee	MAINTENANCE	2.7 CRD Common Rail 120kw (93-98	MANUAL
 Grand Cherokee	MAINTENANCE	2.7 CRD Common Rail 120kw (99-04	BOSCH
 Grand Cherokee	MAINTENANCE	2.7 CRD Common Rail 120kw (99-04	BOSCH
 Grand Cherokee	MAINTENANCE	2.7 CRD Common Rail 120kw (99-04	BOSCH
 Grand Cherokee	MAINTENANCE	2.7 CRD Common Rail 120kw (99-04	BOSCH
 Grand Cherokee	MAINTENANCE	2.7 CRD Common Rail 120kw (99-04	MANUAL
 Grand Cherokee	MAINTENANCE	4.0 (93-98)	MANUAL
 Grand Cherokee	MAINTENANCE	4.0 (99-04)	MANUAL
 Grand Cherokee	MAINTENANCE	4.7 V8 (99-04)	MANUAL
 Grand Cherokee	MAINTENANCE	4.7 V8 164kw (93-98)	MANUAL
 Grand Cherokee	MAINTENANCE	4.7 V8 190kw (93-98)	MANUAL
 Grand Cherokee	SERVICE LIGHT RES	2.7 CRD Common Rail 120kw (93-98	MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Jeep

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Grand Cherokee	SERVICE LIGHT RES	2.7 CRD Common Rail 120kw (99-04	MANUAL
 Grand Cherokee	SERVICE LIGHT RES	4.0 (93-98)	MANUAL
 Grand Cherokee	SERVICE LIGHT RES	4.0 (99-04)	MANUAL
 Grand Cherokee	SERVICE LIGHT RES	4.7 V8 (99-04)	MANUAL
 Grand Cherokee	SERVICE LIGHT RES	4.7 V8 164kw (93-98)	MANUAL
 Grand Cherokee	SERVICE LIGHT RES	4.7 V8 190kw (93-98)	MANUAL
 Wrangler	ENGINE MANAGEME	2.5 87kw (01-..)	EOBD
 Wrangler	ENGINE MANAGEME	4.0 130kw (01-..)	EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

KIA

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Carenis	ENGINE MANAGEME	1.8 81kw (01-..)	EOBD
 Carnival II	ENGINE MANAGEME	2.5 V6 110kw (01-..)	EOBD
 Carnival	ENGINE MANAGEME	2.9 TD (04-..)	EOBD
 Cee'd	AIRBAG	1.4 CVVT 16v	SRS
 Cee'd	AIRBAG	1.6 16v CRDi VGT 116cv	SRS
 Cee'd	AIRBAG	1.6 16v CRDi VGT 90cv	SRS
 Cee'd	AIRBAG	1.6 CVVT 16v	SRS
 Cee'd	AIRBAG	2.0 16v CRDi	SRS
 Cee'd	CLIMA	1.4 CVVT 16v	AutoClima
 Cee'd	CLIMA	1.6 16v CRDi VGT 116cv	AutoClima
 Cee'd	CLIMA	1.6 16v CRDi VGT 90cv	AutoClima
 Cee'd	CLIMA	1.6 CVVT 16v	AutoClima
 Cee'd	CLIMA	2.0 16v CRDi	AutoClima
 Cee'd	ENGINE MANAGEME	1.4 CVVT 16v	EOBD
 Cee'd	ENGINE MANAGEME	1.6 16v CRDi VGT 116cv	EOBD
 Cee'd	ENGINE MANAGEME	1.6 16v CRDi VGT 90cv	EOBD
 Cee'd	ENGINE MANAGEME	1.6 CVVT 16v	EOBD
 Cee'd	ENGINE MANAGEME	2.0 16v CRDi	EOBD
 Clarus	ENGINE MANAGEME	1.8 85kw (01-..)	EOBD
 Clarus	ENGINE MANAGEME	2.0 98kw (01-..)	EOBD
 Joice	ENGINE MANAGEME	2.0 88kw (01-..)	EOBD
 Magentis	ENGINE MANAGEME	2.0 100kw (01-..)	EOBD
 Magentis	ENGINE MANAGEME	2.5 V6 124kw (01-..)	EOBD
 Picanto	ABS	1.0 12v (05-..)	ABS/EBD
 Picanto	ABS	1.1 12v (05-..)	ABS/EBD
 Picanto	ABS	1.1 CRDi (05-..)	ABS/EBD
 Picanto	AIRBAG	1.0 12v (05-..)	SRS
 Picanto	AIRBAG	1.1 12v (05-..)	SRS
 Picanto	AIRBAG	1.1 CRDi (05-..)	SRS
 Picanto	ENGINE MANAGEME	1.0 12v (05-..)	EFI
 Picanto	ENGINE MANAGEME	1.1 12v (05-..)	EFI
 Picanto	ENGINE MANAGEME	1.1 CRDi (05-..)	EOBD
 Picanto	IMMOBILIZER	1.0 12v (05-..)	Immobilizer
 Picanto	IMMOBILIZER	1.1 12v (05-..)	Immobilizer
 Picanto	IMMOBILIZER	1.1 CRDi (05-..)	Immobilizer
 Retona	ENGINE MANAGEME	2.0 TD (04-..)	EOBD
 Rio	ABS	1.4 16v (06-..)	MANDO ABS
 Rio	ABS	1.5 16v CRDi (06-..)	MANDO ABS
 Rio	ABS	1.6 16v (06-..)	MANDO ABS
 Rio	AIRBAG	1.4 16v (06-..)	SRS
 Rio	AIRBAG	1.5 16v CRDi (06-..)	SRS
 Rio	AIRBAG	1.6 16v (06-..)	SRS
 Rio	ENGINE MANAGEME	1.3 55kw (01-..)	EOBD
 Rio	ENGINE MANAGEME	1.4 16v (06-..)	EOBD
 Rio	ENGINE MANAGEME	1.5 16v CRDi (06-..)	BOSCH EDC Common Rail
 Rio	ENGINE MANAGEME	1.6 16v (06-..)	EOBD
 Shuma II	ENGINE MANAGEME	1.6 75kw (01-..)	EOBD
 Shuma	ENGINE MANAGEME	1.5 65kw (01-..)	EOBD
 Shuma	ENGINE MANAGEME	1.8 81kw (01-..)	EOBD
 Sorento	4WD ELECTRONICS	2.4 16v (05-..)	4WD
 Sorento	4WD ELECTRONICS	2.5 16v CRDi (05-..)	4WD
 Sorento	4WD ELECTRONICS	3.3 24v V6 (05-..)	4WD
Sorento	4WD ELECTRONICS	3.5 24v V6 (05-..)	4WD
Sorento	ABS	2.5 16v CRDi (02-04)	BOSCH ABS 5.3
Sorento	ABS	3.5 24v V6 (02-04)	BOSCH ABS 5.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

KIA

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sorento	ABS + TRACT. CONT	2.4 16v (05-..)	MANDO ABS
 Sorento	ABS + TRACT. CONT	2.5 16v CRDi (05-..)	MANDO ABS
 Sorento	ABS + TRACT. CONT	3.3 24v V6 (05-..)	MANDO ABS
 Sorento	AIRBAG	2.4 16v (05-..)	AirBag
 Sorento	AIRBAG	2.5 16v CRDi (02-04)	AirBag
 Sorento	AIRBAG	2.5 16v CRDi (05-..)	AirBag
 Sorento	AIRBAG	3.3 24v V6 (05-..)	AirBag
 Sorento	AIRBAG	3.5 24v V6 (02-04)	AirBag
 Sorento	AUTOM. TRANSMISSI	2.5 16v CRDi (05-..)	A/T
 Sorento	AUTOM. TRANSMISSI	3.5 24v V6 (05-..)	A/T
 Sorento	CHASSIS NETWORK	2.4 16v (05-..)	Body Computer ETACS
 Sorento	CHASSIS NETWORK	2.5 16v CRDi (05-..)	Body Computer ETACS
 Sorento	CHASSIS NETWORK	3.3 24v V6 (05-..)	Body Computer ETACS
 Sorento	CHASSIS NETWORK	3.5 24v V6 (05-..)	Body Computer ETACS
 Sorento	CLIMA	2.4 16v (05-..)	Klimautomatik
 Sorento	CLIMA	2.5 16v CRDi (05-..)	Klimautomatik
 Sorento	CLIMA	3.3 24v V6 (05-..)	Klimautomatik
 Sorento	ENGINE MANAGEME	2.4 16v (05-..)	EOBD
 Sorento	ENGINE MANAGEME	2.5 16v CRDi (02-..)	EDC Common Rail
 Sorento	ENGINE MANAGEME	2.5 16v CRDi (05-..)	EOBD
 Sorento	ENGINE MANAGEME	3.3 24v V6 (05-..)	EOBD
 Sorento	IMMOBILIZER	2.4 16v (05-..)	Immobilizer 1x
 Sorento	IMMOBILIZER	2.4 16v (05-..)	Immobilizer 2x
 Sorento	IMMOBILIZER	2.5 16v CRDi (05-..)	Immobilizer 1x
 Sorento	IMMOBILIZER	2.5 16v CRDi (05-..)	Immobilizer 2x
 Sorento	IMMOBILIZER	3.3 24v V6 (05-..)	Immobilizer 1x
 Sorento	IMMOBILIZER	3.3 24v V6 (05-..)	Immobilizer 2x
 Sorento	IMMOBILIZER	3.5 24v V6 (05-..)	Immobilizer 1x
 Sorento	IMMOBILIZER	3.5 24v V6 (05-..)	Immobilizer 2x
 Sorento	MAINTENANCE	2.5 16v CRDi (02-04)	BOSCH ABS 5.3
 Sorento	MAINTENANCE	2.5 16v CRDi (02-04)	BOSCH ABS 5.3
 Sorento	MAINTENANCE	2.5 16v CRDi (02-04)	BOSCH ABS 5.3
 Sorento	MAINTENANCE	2.5 16v CRDi (02-04)	BOSCH ABS 5.3
 Sorento	MAINTENANCE	3.5 24v V6 (02-04)	BOSCH ABS 5.3
 Sorento	MAINTENANCE	3.5 24v V6 (02-04)	BOSCH ABS 5.3
 Sorento	MAINTENANCE	3.5 24v V6 (02-04)	BOSCH ABS 5.3
 Sorento	MAINTENANCE	3.5 24v V6 (02-04)	BOSCH ABS 5.3
 Sportage	4WD ELECTRONICS	2.0 16v (05-..)	4WD
 Sportage	4WD ELECTRONICS	2.0 16v CRDi (05-..)	4WD
 Sportage	4WD ELECTRONICS	2.7 V6 (05-..)	4WD
 Sportage	ABS + TRACT. CONT	2.0 16v (05-..)	MANDO ABS
 Sportage	ABS + TRACT. CONT	2.0 16v CRDi (05-..)	MANDO ABS
 Sportage	ABS + TRACT. CONT	2.7 V6 (05-..)	MANDO ABS
 Sportage	AIRBAG	2.0 16v (05-..)	AirBag
 Sportage	AIRBAG	2.0 16v CRDi (05-..)	AirBag
 Sportage	AIRBAG	2.7 V6 (05-..)	AirBag
 Sportage	CHASSIS NETWORK	2.0 16v (05-..)	Body Computer ETACS
 Sportage	CHASSIS NETWORK	2.0 16v CRDi (05-..)	Body Computer ETACS
 Sportage	CHASSIS NETWORK	2.7 V6 (05-..)	Body Computer ETACS
 Sportage	CLIMA	2.0 16v (05-05)	Klimautomatik
 Sportage	CLIMA	2.0 16v CRDi (05-05)	Klimautomatik
 Sportage	CLIMA	2.7 V6 (05-05)	Klimautomatik
 Sportage	ENGINE MANAGEME	2.0 16v (05-..)	EOBD
 Sportage	ENGINE MANAGEME	2.0 16v CRDi (05-..)	EOBD
 Sportage	ENGINE MANAGEME	2.7 V6 (05-..)	EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Lancia

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Dedra	ABS	1.6	BOSCH ABS 2E
 Dedra	ABS	1.6 16v	BOSCH ABS 2E
 Dedra	ABS	1.6 Kat	BOSCH ABS 2E
 Dedra	ABS	1.8	BOSCH ABS 2E
 Dedra	ABS	1.8 16v	BOSCH ABS 2E
 Dedra	ABS	1.8 Kat	BOSCH ABS 2E
 Dedra	ABS	2.0	BOSCH ABS 2E
 Dedra	ABS	2.0 16v Kat	BOSCH ABS 2E
 Dedra	ABS	2.0 AT	BOSCH ABS 2E
 Dedra	ABS	2.0 Integrale	BOSCH ABS 2E
 Dedra	ABS	2.0 Kat	BOSCH ABS 2E
 Dedra	ABS	2.0 T	BOSCH ABS 2E
 Dedra	ABS	2.0 T 16v Kat	BOSCH ABS 2E
 Dedra	ABS	2.0 T Integrale	BOSCH ABS 2E
 Dedra	ABS	2.0 T Integrale 16v	BOSCH ABS 2E
 Dedra	ABS	2.0 T Integrale Kat	BOSCH ABS 2E
 Dedra	ABS	2.0 T Kat	BOSCH ABS 2E
 Dedra	ELECTRONIC INJECT	1.6 Kat	BOSCH MonoJetronic A2.2
 Dedra	ELECTRONIC INJECT	1.6 Kat	BOSCH MonoJetronic A2.2
 Dedra	ENGINE MANAGEME	1.6	Marelli MIW 0L2.12C
 Dedra	ENGINE MANAGEME	1.6	Marelli MIW 0L2.12D
 Dedra	ENGINE MANAGEME	1.6	Marelli MIW 0L2.12J
 Dedra	ENGINE MANAGEME	1.6	Marelli MIW 0L2.12O
 Dedra	ENGINE MANAGEME	1.6	Marelli MIW LD2
 Dedra	ENGINE MANAGEME	1.6	Marelli MIW LD2
 Dedra	ENGINE MANAGEME	1.6 16v (...96)	Marelli IAW 49F
 Dedra	ENGINE MANAGEME	1.6 Kat	BOSCH MonoMotronic MA1.7
 Dedra	ENGINE MANAGEME	1.6 Kat	GM MPI Rochester
 Dedra	ENGINE MANAGEME	1.6 Kat	GM MPI Rochester
 Dedra	ENGINE MANAGEME	1.8	Marelli IAW 04T
 Dedra	ENGINE MANAGEME	1.8	Marelli IAW 04T
 Dedra	ENGINE MANAGEME	1.8	Marelli IAW 04Tgv
 Dedra	ENGINE MANAGEME	1.8	Marelli IAW 04U
 Dedra	ENGINE MANAGEME	1.8 16v	HITACHI MPI MFI
 Dedra	ENGINE MANAGEME	1.8 16v	HITACHI MPI MFI
 Dedra	ENGINE MANAGEME	1.8 Kat	Marelli IAW 04U
 Dedra	ENGINE MANAGEME	1.8 Kat	Marelli IAW 04U
 Dedra	ENGINE MANAGEME	1.8 Kat	Marelli IAW 04U
 Dedra	ENGINE MANAGEME	1.8 Kat	Marelli IAW 8F.52
 Dedra	ENGINE MANAGEME	1.8 Kat	Marelli IAW 8F.5K
 Dedra	ENGINE MANAGEME	1.8 Kat	Marelli IAW 8F.5K
 Dedra	ENGINE MANAGEME	2.0	Marelli IAW 04K
 Dedra	ENGINE MANAGEME	2.0	Marelli IAW 04K
 Dedra	ENGINE MANAGEME	2.0	Marelli IAW 04K
 Dedra	ENGINE MANAGEME	2.0	Marelli IAW 04K
 Dedra	ENGINE MANAGEME	2.0 16v Kat	Marelli IAW 4Q6
 Dedra	ENGINE MANAGEME	2.0 16v Kat	Marelli IAW 4Q6.P8
 Dedra	ENGINE MANAGEME	2.0 16v Kat	Marelli IAW 4Q6.P8
 Dedra	ENGINE MANAGEME	2.0 16v Kat	Marelli IAW 4Q6.P8
 Dedra	ENGINE MANAGEME	2.0 AT	Marelli IAW 04J
 Dedra	ENGINE MANAGEME	2.0 Integrale	Marelli IAW 473
 Dedra	ENGINE MANAGEME	2.0 Kat	Marelli IAW 04J
 Dedra	ENGINE MANAGEME	2.0 Kat	Marelli IAW 04J
 Dedra	ENGINE MANAGEME	2.0 Kat	Marelli IAW 04J
 Dedra	ENGINE MANAGEME	2.0 T	Marelli IAW 471
 Dedra	ENGINE MANAGEME	2.0 T	Marelli IAW 471
 Dedra	ENGINE MANAGEME	2.0 T 16v Kat	Marelli IAW 4WD
 Dedra	ENGINE MANAGEME	2.0 T 16v Kat	Marelli IAW 4WD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Lancia

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Dedra	ENGINE MANAGEME	2.0 T Integrale	Marelli IAW 471.08
 Dedra	ENGINE MANAGEME	2.0 T Integrale	Marelli IAW 473
 Dedra	ENGINE MANAGEME	2.0 T Integrale	Marelli IAW 473
 Dedra	ENGINE MANAGEME	2.0 T Integrale 16v	Marelli IAW 4WC
 Dedra	ENGINE MANAGEME	2.0 T Integrale 16v	Marelli IAW 4WC
 Dedra	ENGINE MANAGEME	2.0 T Integrale Kat	Marelli IAW 472
 Dedra	ENGINE MANAGEME	2.0 T Integrale Kat	Marelli IAW 474
 Dedra	ENGINE MANAGEME	2.0 T Integrale Kat	Marelli IAW 474
 Dedra	ENGINE MANAGEME	2.0 T Kat	Marelli IAW 472
 Dedra	ENGINE MANAGEME	2.0 T Kat	Marelli IAW 472
 Delta (111)	ABS	1.6 16v	BOSCH ABS 2E
 Delta (111)	ABS	1.6 16v (96-98)	BOSCH ABS 5.3
 Delta (111)	ABS	1.6 16v Kat	BOSCH ABS 2E
 Delta (111)	ABS	1.6 16v Kat (96-98)	BOSCH ABS 5.3
 Delta (111)	ABS	1.6 T	BOSCH ABS 2E
 Delta (111)	ABS	1.6 T (96-98)	BOSCH ABS 5.3
 Delta (111)	ABS	1.6 T Kat	BOSCH ABS 2E
 Delta (111)	ABS	1.6 T Kat (96-98)	BOSCH ABS 5.3
 Delta (111)	ABS	1.8 16v	BOSCH ABS 2E
 Delta (111)	ABS	1.8 16v (96-98)	BOSCH ABS 5.3
 Delta (111)	ABS	1.8 16v Kat	BOSCH ABS 2E
 Delta (111)	ABS	1.8 16v Kat (96-98)	BOSCH ABS 5.3
 Delta (111)	ABS	2.0 16v Kat	BOSCH ABS 2E
 Delta (111)	ABS	2.0 16v Kat (96-98)	BOSCH ABS 5.3
 Delta (111)	ABS	2.0 Integrale	BOSCH ABS 2E
 Delta (111)	ABS	2.0 Integrale (96-98)	BOSCH ABS 5.3
 Delta (111)	ABS	2.0 Integrale 16v	BOSCH ABS 2E
 Delta (111)	ABS	2.0 Integrale 16v (96-98)	BOSCH ABS 5.3
 Delta (111)	ABS	2.0 Integrale 16v EVOL	BOSCH ABS 2E
 Delta (111)	ABS	2.0 Integrale 16v EVOL (96-98)	BOSCH ABS 5.3
 Delta (111)	ABS	2.0 Integrale Kat	BOSCH ABS 2E
 Delta (111)	ABS	2.0 Integrale Kat (96-98)	BOSCH ABS 5.3
 Delta (111)	ABS	2.0 T 16v Kat	BOSCH ABS 2E
 Delta (111)	ABS	2.0 T 16v Kat (96-98)	BOSCH ABS 5.3
 Delta (111)	ABS	2.0 T Integrale	BOSCH ABS 2E
 Delta (111)	ABS	2.0 T Integrale (96-98)	BOSCH ABS 5.3
 Delta (111)	ENGINE MANAGEME	1.6 16v	Marelli IAW 02P.03
 Delta (111)	ENGINE MANAGEME	1.6 16v	Marelli IAW 02P.03
 Delta (111)	ENGINE MANAGEME	1.6 16v	Marelli IAW 02P.03
 Delta (111)	ENGINE MANAGEME	1.6 16v	Marelli IAW 02P.04
 Delta (111)	ENGINE MANAGEME	1.6 16v	Marelli IAW 02P.04
 Delta (111)	ENGINE MANAGEME	1.6 16v	Marelli IAW 04P.07
 Delta (111)	ENGINE MANAGEME	1.6 16v	Marelli IAW 1AF.16
 Delta (111)	ENGINE MANAGEME	1.6 16v	Marelli IAW 1AF.16
 Delta (111)	ENGINE MANAGEME	1.6 16v	Marelli IAW 1AF.16
 Delta (111)	ENGINE MANAGEME	1.6 16v (98-..)	Marelli IAW 49F
 Delta (111)	ENGINE MANAGEME	1.6 16v Kat	BOSCH MonoMotronic MA1.7
 Delta (111)	ENGINE MANAGEME	1.6 16v Kat	BOSCH MonoMotronic MA1.7
 Delta (111)	ENGINE MANAGEME	1.6 16v Kat	GM MPI Rochester
 Delta (111)	ENGINE MANAGEME	1.6 T	Marelli IAW 049.01
 Delta (111)	ENGINE MANAGEME	1.6 T	Marelli IAW 049.03
 Delta (111)	ENGINE MANAGEME	1.6 T	Marelli IAW 049.03
 Delta (111)	ENGINE MANAGEME	1.6 T	Marelli IAW 049.07
 Delta (111)	ENGINE MANAGEME	1.6 T Kat	Marelli IAW 04D.06
 Delta (111)	ENGINE MANAGEME	1.6 T Kat	Marelli IAW 04D.06
 Delta (111)	ENGINE MANAGEME	1.6 T Kat	Marelli IAW 04D.06
 Delta (111)	ENGINE MANAGEME	1.8 16v	HITACHI MPI MFI
 Delta (111)	ENGINE MANAGEME	1.8 16v	HITACHI MPI MFI

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Lancia

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Delta (111)	ENGINE MANAGEME	1.8 16v Kat	Marelli IAW 8F.52
 Delta (111)	ENGINE MANAGEME	1.8 16v Kat	Marelli IAW 8F.52
 Delta (111)	ENGINE MANAGEME	1.8 16v Kat	Marelli IAW 8F.52
 Delta (111)	ENGINE MANAGEME	1.8 16v Kat	Marelli IAW 8F.52
 Delta (111)	ENGINE MANAGEME	1.8 16v Kat	Marelli IAW 8F.5K
 Delta (111)	ENGINE MANAGEME	1.8 16v Kat	Marelli IAW 8F.5K
 Delta (111)	ENGINE MANAGEME	2.0 16v Kat	Marelli IAW 4Q3
 Delta (111)	ENGINE MANAGEME	2.0 16v Kat	Marelli IAW 4Q3.P8
 Delta (111)	ENGINE MANAGEME	2.0 16v Kat	Marelli IAW 4Q3.P8
 Delta (111)	ENGINE MANAGEME	2.0 16v Kat	Marelli IAW 4Q3.P8
 Delta (111)	ENGINE MANAGEME	2.0 16v Kat	Marelli IAW 4Q5
 Delta (111)	ENGINE MANAGEME	2.0 16v Kat	Marelli IAW 4Q5
 Delta (111)	ENGINE MANAGEME	2.0 16v Kat	Marelli IAW 4Q5
 Delta (111)	ENGINE MANAGEME	2.0 Integrale	Marelli IAW 04E.03
 Delta (111)	ENGINE MANAGEME	2.0 Integrale 16v	Marelli IAW 04W
 Delta (111)	ENGINE MANAGEME	2.0 Integrale 16v	Marelli IAW 04W
 Delta (111)	ENGINE MANAGEME	2.0 Integrale 16v	Marelli IAW 4WA
 Delta (111)	ENGINE MANAGEME	2.0 Integrale 16v	Marelli IAW 4WA
 Delta (111)	ENGINE MANAGEME	2.0 Integrale 16v EVOL	Marelli IAW 4WG
 Delta (111)	ENGINE MANAGEME	2.0 Integrale 16v EVOL	Marelli IAW 4WG
 Delta (111)	ENGINE MANAGEME	2.0 Integrale Kat	Marelli IAW 047
 Delta (111)	ENGINE MANAGEME	2.0 T 16v Kat	Marelli IAW 4WB
 Delta (111)	ENGINE MANAGEME	2.0 T 16v Kat	Marelli IAW 4WB
 Delta (111)	ENGINE MANAGEME	2.0 T 16v Kat	Marelli IAW 4WB
 Delta (111)	ENGINE MANAGEME	2.0 T Integrale	Marelli IAW 04E.03
 Delta (181)	ABS + TRACT. CONT	1.4 T-JET 16v (08-..)	TRW ESP
 Delta (181)	ABS + TRACT. CONT	1.4 Turbo Multiair 16v (08-..)	TRW ESP
 Delta (181)	ABS + TRACT. CONT	1.6 MJET 16v (08-..)	TRW ESP
 Delta (181)	ABS + TRACT. CONT	1.8 T-JET 16v (08-..)	TRW ESP
 Delta (181)	ABS + TRACT. CONT	1.9 MJET 16v twintb (08-..)	TRW ESP
 Delta (181)	ABS + TRACT. CONT	2.0 MJET 16v (08-..)	TRW ESP
 Delta (181)	AIRBAG	1.4 T-JET 16v (08-..)	SIEMENS AirBag 1
 Delta (181)	AIRBAG	1.4 Turbo Multiair 16v (08-..)	SIEMENS AirBag 1
 Delta (181)	AIRBAG	1.6 MJET 16v (08-..)	SIEMENS AirBag 1
 Delta (181)	AIRBAG	1.8 T-JET 16v (08-..)	SIEMENS AirBag 1
 Delta (181)	AIRBAG	1.9 MJET 16v twintb (08-..)	SIEMENS AirBag 1
 Delta (181)	AIRBAG	2.0 MJET 16v (08-..)	SIEMENS AirBag 1
 Delta (181)	AUTOM. TRANSMISSI	1.4 T-JET 16v (08-..)	Marelli Selespeed CFC300
 Delta (181)	AUTOM. TRANSMISSI	1.4 Turbo Multiair 16v (08-..)	Marelli Selespeed CFC300
 Delta (181)	AUTOM. TRANSMISSI	1.6 MJET 16v (08-..)	Marelli Selespeed CFC300
 Delta (181)	AUTOM. TRANSMISSI	1.8 T-JET 16v (08-..)	Marelli Selespeed CFC300
 Delta (181)	AUTOM. TRANSMISSI	1.9 MJET 16v twintb (08-..)	Marelli Selespeed CFC300
 Delta (181)	AUTOM. TRANSMISSI	2.0 MJET 16v (08-..)	Marelli Selespeed CFC300
 Delta (181)	CHASSIS NETWORK	1.4 T-JET 16v (08-..)	Marelli Body Comp.+Key Encoding 8
 Delta (181)	CHASSIS NETWORK	1.4 T-JET 16v (08-..)	Marelli CAN info
 Delta (181)	CHASSIS NETWORK	1.4 Turbo Multiair 16v (08-..)	Marelli Body Comp.+Key Encoding 8
 Delta (181)	CHASSIS NETWORK	1.4 Turbo Multiair 16v (08-..)	Marelli CAN info
 Delta (181)	CHASSIS NETWORK	1.6 MJET 16v (08-..)	Marelli Body Comp.+Key Encoding 8
 Delta (181)	CHASSIS NETWORK	1.6 MJET 16v (08-..)	Marelli CAN info
 Delta (181)	CHASSIS NETWORK	1.8 T-JET 16v (08-..)	Marelli Body Comp.+Key Encoding 8
 Delta (181)	CHASSIS NETWORK	1.8 T-JET 16v (08-..)	Marelli CAN info
 Delta (181)	CHASSIS NETWORK	1.9 MJET 16v twintb (08-..)	Marelli Body Comp.+Key Encoding 8
 Delta (181)	CHASSIS NETWORK	1.9 MJET 16v twintb (08-..)	Marelli CAN info
 Delta (181)	CHASSIS NETWORK	2.0 MJET 16v (08-..)	Marelli Body Comp.+Key Encoding 8
 Delta (181)	CHASSIS NETWORK	2.0 MJET 16v (08-..)	Marelli CAN info
 Delta (181)	DASHBOARD	1.4 T-JET 16v (08-..)	Marelli Dashboard
 Delta (181)	DASHBOARD	1.4 Turbo Multiair 16v (08-..)	Marelli Dashboard
 Delta (181)	DASHBOARD	1.6 MJET 16v (08-..)	Marelli Dashboard

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Lancia

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Delta (181)	DASHBOARD	1.8 T-JET 16v (08-..)	Marelli Dashboard
 Delta (181)	DASHBOARD	1.9 MJET 16v twintb (08-..)	Marelli Dashboard
 Delta (181)	DASHBOARD	2.0 MJET 16v (08-..)	Marelli Dashboard
 Delta (181)	ELECTRIC STEERING	1.4 T-JET 16v (08-..)	TRW EPS 3
 Delta (181)	ELECTRIC STEERING	1.4 Turbo Multiair 16v (08-..)	TRW EPS 3
 Delta (181)	ELECTRIC STEERING	1.6 MJET 16v (08-..)	TRW EPS 3
 Delta (181)	ELECTRIC STEERING	1.8 T-JET 16v (08-..)	TRW EPS 3
 Delta (181)	ELECTRIC STEERING	1.9 MJET 16v twintb (08-..)	TRW EPS 3
 Delta (181)	ELECTRIC STEERING	2.0 MJET 16v (08-..)	TRW EPS 3
 Delta (181)	ENGINE MANAGEME	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
 Delta (181)	ENGINE MANAGEME	1.6 MJET 16v (08-..)	BOSCH EDC 16C39 CF5/EOBD
 Delta (181)	ENGINE MANAGEME	1.8 T-JET 16v (08-..)	BOSCH MeD17.3.1 CF5/EOBD
 Delta (181)	ENGINE MANAGEME	1.9 MJET 16v twintb (08-..)	Bosch EDC 16C39 CF5/EOBD
 Delta (181)	ENGINE MANAGEME	2.0 MJET 16v (08-..)	Bosch EDC 16C39 CF5/EOBD
 Delta (181)	HEADLIGHT LEVEL	1.4 T-JET 16v (08-..)	
 Delta (181)	HEADLIGHT LEVEL	1.4 Turbo Multiair 16v (08-..)	
 Delta (181)	HEADLIGHT LEVEL	1.6 MJET 16v (08-..)	
 Delta (181)	HEADLIGHT LEVEL	1.9 MJET 16v twintb (08-..)	
 Delta (181)	HEADLIGHT LEVEL	2.0 MJET 16v (08-..)	
 Delta (181)	MAINTENANCE	1.4 T-JET 16v (08-..)	Marelli Dashboard
 Delta (181)	MAINTENANCE	1.4 T-JET 16v (08-..)	Marelli Selespeed CFC300
 Delta (181)	MAINTENANCE	1.4 T-JET 16v (08-..)	Marelli Selespeed CFC300
 Delta (181)	MAINTENANCE	1.4 T-JET 16v (08-..)	TRW EPS 3
 Delta (181)	MAINTENANCE	1.4 Turbo Multiair 16v (08-..)	Marelli Dashboard
 Delta (181)	MAINTENANCE	1.4 Turbo Multiair 16v (08-..)	Marelli Selespeed CFC300
 Delta (181)	MAINTENANCE	1.4 Turbo Multiair 16v (08-..)	Marelli Selespeed CFC300
 Delta (181)	MAINTENANCE	1.4 Turbo Multiair 16v (08-..)	TRW EPS 3
 Delta (181)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
 Delta (181)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
 Delta (181)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
 Delta (181)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
 Delta (181)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
 Delta (181)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
 Delta (181)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
 Delta (181)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
 Delta (181)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
 Delta (181)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
 Delta (181)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
 Delta (181)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
 Delta (181)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
 Delta (181)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
 Delta (181)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
 Delta (181)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
 Delta (181)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
 Delta (181)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
 Delta (181)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
 Delta (181)	MAINTENANCE	1.4 Turbo Multiair 16v (09-..)	Marelli IAW 8GMF CF5/EOBD
 Delta (181)	MAINTENANCE	1.6 MJET 16v (08-..)	BOSCH EDC 16C39 CF5/EOBD
 Delta (181)	MAINTENANCE	1.6 MJET 16v (08-..)	BOSCH EDC 16C39 CF5/EOBD
 Delta (181)	MAINTENANCE	1.6 MJET 16v (08-..)	Marelli Dashboard
 Delta (181)	MAINTENANCE	1.6 MJET 16v (08-..)	Marelli Selespeed CFC300
 Delta (181)	MAINTENANCE	1.6 MJET 16v (08-..)	Marelli Selespeed CFC300

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Lancia

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Delta (181)	MAINTENANCE	1.6 MJET 16v (08-..)	TRW EPS 3
 Delta (181)	MAINTENANCE	1.8 T-JET 16v (08-..)	BOSCH MeD17.3.1 CF5/EOBD
 Delta (181)	MAINTENANCE	1.8 T-JET 16v (08-..)	BOSCH MeD17.3.1 CF5/EOBD
 Delta (181)	MAINTENANCE	1.8 T-JET 16v (08-..)	BOSCH MeD17.3.1 CF5/EOBD
 Delta (181)	MAINTENANCE	1.8 T-JET 16v (08-..)	BOSCH MeD17.3.1 CF5/EOBD
 Delta (181)	MAINTENANCE	1.8 T-JET 16v (08-..)	BOSCH MeD17.3.1 CF5/EOBD
 Delta (181)	MAINTENANCE	1.8 T-JET 16v (08-..)	BOSCH MeD17.3.1 CF5/EOBD
 Delta (181)	MAINTENANCE	1.8 T-JET 16v (08-..)	BOSCH MeD17.3.1 CF5/EOBD
 Delta (181)	MAINTENANCE	1.8 T-JET 16v (08-..)	BOSCH MeD17.3.1 CF5/EOBD
 Delta (181)	MAINTENANCE	1.8 T-JET 16v (08-..)	BOSCH MeD17.3.1 CF5/EOBD
 Delta (181)	MAINTENANCE	1.8 T-JET 16v (08-..)	BOSCH MeD17.3.1 CF5/EOBD
 Delta (181)	MAINTENANCE	1.8 T-JET 16v (08-..)	BOSCH MeD17.3.1 CF5/EOBD
 Delta (181)	MAINTENANCE	1.8 T-JET 16v (08-..)	BOSCH MeD17.3.1 CF5/EOBD
 Delta (181)	MAINTENANCE	1.8 T-JET 16v (08-..)	BOSCH MeD17.3.1 CF5/EOBD
 Delta (181)	MAINTENANCE	1.8 T-JET 16v (08-..)	BOSCH MeD17.3.1 CF5/EOBD
 Delta (181)	MAINTENANCE	1.8 T-JET 16v (08-..)	BOSCH MeD17.3.1 CF5/EOBD
 Delta (181)	MAINTENANCE	1.8 T-JET 16v (08-..)	BOSCH MeD17.3.1 CF5/EOBD
 Delta (181)	MAINTENANCE	1.8 T-JET 16v (08-..)	BOSCH MeD17.3.1 CF5/EOBD
 Delta (181)	MAINTENANCE	1.8 T-JET 16v (08-..)	Marelli Dashboard
 Delta (181)	MAINTENANCE	1.8 T-JET 16v (08-..)	Marelli Selespeed CFC300
 Delta (181)	MAINTENANCE	1.8 T-JET 16v (08-..)	Marelli Selespeed CFC300
 Delta (181)	MAINTENANCE	1.8 T-JET 16v (08-..)	TRW EPS 3
 Delta (181)	MAINTENANCE	1.9 MJET 16v twintb (08-..)	Bosch EDC 16C39 CF5/EOBD
 Delta (181)	MAINTENANCE	1.9 MJET 16v twintb (08-..)	Bosch EDC 16C39 CF5/EOBD
 Delta (181)	MAINTENANCE	1.9 MJET 16v twintb (08-..)	Marelli Dashboard
 Delta (181)	MAINTENANCE	1.9 MJET 16v twintb (08-..)	Marelli Selespeed CFC300
 Delta (181)	MAINTENANCE	1.9 MJET 16v twintb (08-..)	Marelli Selespeed CFC300
 Delta (181)	MAINTENANCE	1.9 MJET 16v twintb (08-..)	TRW EPS 3
 Delta (181)	MAINTENANCE	2.0 MJET 16v (08-..)	Bosch EDC 16C39 CF5/EOBD
 Delta (181)	MAINTENANCE	2.0 MJET 16v (08-..)	Bosch EDC 16C39 CF5/EOBD
 Delta (181)	MAINTENANCE	2.0 MJET 16v (08-..)	Marelli Dashboard
 Delta (181)	MAINTENANCE	2.0 MJET 16v (08-..)	Marelli Selespeed CFC300
 Delta (181)	MAINTENANCE	2.0 MJET 16v (08-..)	Marelli Selespeed CFC300
 Delta (181)	MAINTENANCE	2.0 MJET 16v (08-..)	TRW EPS 3
 Delta (181)	PARKING HELP	1.4 T-JET 16v (08-..)	Valeo 2
 Delta (181)	PARKING HELP	1.4 Turbo Multiair 16v (08-..)	Valeo 2
 Delta (181)	PARKING HELP	1.6 MJET 16v (08-..)	Valeo 2
 Delta (181)	PARKING HELP	1.8 T-JET 16v (08-..)	Valeo 2
 Delta (181)	PARKING HELP	1.9 MJET 16v twintb (08-..)	Valeo 2
 Delta (181)	PARKING HELP	2.0 MJET 16v (08-..)	Valeo 2
 K	ABS	2.0 (...99)	BOSCH ABS 5.3
 K	ABS	2.0 T (...99)	BOSCH ABS 5.3
 K	ABS	2.0 V.I.S. (...99)	BOSCH ABS 5.3
 K	ABS	2.4 (...99)	BOSCH ABS 5.3
 K	ABS	2.4 JTD (...99)	BOSCH ABS 5.3
 K	ABS	2.4 TD (...99)	BOSCH ABS 5.3
 K	ABS	3.0 (...99)	BOSCH ABS 5.3
 K	AIRBAG	2.0	TRW AirBag MY 97 (2F-2P)
 K	AIRBAG	2.0	TRW AirBag MY 97 (2F-2P-2L)
 K	AIRBAG	2.0	TRW AirBag MY 97 (2F-2P-2L-S)
 K	AIRBAG	2.0	TRW AirBag MY 97 (2F-2P-S)
 K	AIRBAG	2.0	TRW AirBag TRW2
 K	AIRBAG	2.0	TRW-Becker AirBag no Pret.
 K	AIRBAG	2.0 (99-..)	TRW AirBag MY 97 (2F-2P)
 K	AIRBAG	2.0 (99-..)	TRW AirBag MY 97 (2F-2P-2L)
 K	AIRBAG	2.0 (99-..)	TRW AirBag MY 97 (2F-2P-2L-S)
 K	AIRBAG	2.0 (99-..)	TRW AirBag MY 97 (2F-2P-S)

Systems supported by ECUREADER / ECUdecoder (up to V6.90)

CARS

Lancia

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 K	AIRBAG	2.0 T	TRW AirBag MY 97 (2F-2P)
 K	AIRBAG	2.0 T	TRW AirBag MY 97 (2F-2P-2L)
 K	AIRBAG	2.0 T	TRW AirBag MY 97 (2F-2P-2L-S)
 K	AIRBAG	2.0 T	TRW AirBag MY 97 (2F-2P-S)
 K	AIRBAG	2.0 T	TRW AirBag TRW2
 K	AIRBAG	2.0 T	TRW-Becker AirBag no Pret.
 K	AIRBAG	2.0 T (99-..)	TRW AirBag MY 97 (2F-2P)
 K	AIRBAG	2.0 T (99-..)	TRW AirBag MY 97 (2F-2P-2L)
 K	AIRBAG	2.0 T (99-..)	TRW AirBag MY 97 (2F-2P-2L-S)
 K	AIRBAG	2.0 T (99-..)	TRW AirBag MY 97 (2F-2P-S)
 K	AIRBAG	2.0 V.I.S.	TRW AirBag MY 97 (2F-2P)
 K	AIRBAG	2.0 V.I.S.	TRW AirBag MY 97 (2F-2P-2L)
 K	AIRBAG	2.0 V.I.S.	TRW AirBag MY 97 (2F-2P-2L-S)
 K	AIRBAG	2.0 V.I.S.	TRW AirBag MY 97 (2F-2P-S)
 K	AIRBAG	2.0 V.I.S.	TRW AirBag TRW2
 K	AIRBAG	2.0 V.I.S.	TRW-Becker AirBag no Pret.
 K	AIRBAG	2.0 V.I.S. (99-..)	TRW AirBag MY 97 (2F-2P)
 K	AIRBAG	2.0 V.I.S. (99-..)	TRW AirBag MY 97 (2F-2P-2L)
 K	AIRBAG	2.0 V.I.S. (99-..)	TRW AirBag MY 97 (2F-2P-2L-S)
 K	AIRBAG	2.0 V.I.S. (99-..)	TRW AirBag MY 97 (2F-2P-S)
 K	AIRBAG	2.4	TRW AirBag MY 97 (2F-2P)
 K	AIRBAG	2.4	TRW AirBag MY 97 (2F-2P-2L)
 K	AIRBAG	2.4	TRW AirBag MY 97 (2F-2P-2L-S)
 K	AIRBAG	2.4	TRW AirBag MY 97 (2F-2P-S)
 K	AIRBAG	2.4	TRW AirBag TRW2
 K	AIRBAG	2.4	TRW-Becker AirBag no Pret.
 K	AIRBAG	2.4 (99-..)	TRW AirBag MY 97 (2F-2P)
 K	AIRBAG	2.4 (99-..)	TRW AirBag MY 97 (2F-2P-2L)
 K	AIRBAG	2.4 (99-..)	TRW AirBag MY 97 (2F-2P-2L-S)
 K	AIRBAG	2.4 (99-..)	TRW AirBag MY 97 (2F-2P-S)
 K	AIRBAG	2.4 JTD	TRW AirBag MY 97 (2F-2P)
 K	AIRBAG	2.4 JTD	TRW AirBag MY 97 (2F-2P-2L)
 K	AIRBAG	2.4 JTD	TRW AirBag MY 97 (2F-2P-2L-S)
 K	AIRBAG	2.4 JTD	TRW AirBag MY 97 (2F-2P-S)
 K	AIRBAG	2.4 JTD	TRW AirBag TRW2
 K	AIRBAG	2.4 JTD	TRW-Becker AirBag no Pret.
 K	AIRBAG	2.4 JTD (99-..)	TRW AirBag MY 97 (2F-2P)
 K	AIRBAG	2.4 JTD (99-..)	TRW AirBag MY 97 (2F-2P-2L)
 K	AIRBAG	2.4 JTD (99-..)	TRW AirBag MY 97 (2F-2P-2L-S)
 K	AIRBAG	2.4 JTD (99-..)	TRW AirBag MY 97 (2F-2P-S)
 K	AIRBAG	2.4 TD	TRW AirBag MY 97 (2F-2P)
 K	AIRBAG	2.4 TD	TRW AirBag MY 97 (2F-2P-2L)
 K	AIRBAG	2.4 TD	TRW AirBag MY 97 (2F-2P-2L-S)
 K	AIRBAG	2.4 TD	TRW AirBag MY 97 (2F-2P-S)
 K	AIRBAG	2.4 TD	TRW AirBag TRW2
 K	AIRBAG	2.4 TD	TRW-Becker AirBag no Pret.
 K	AIRBAG	2.4 TD (99-..)	TRW AirBag MY 97 (2F-2P)
 K	AIRBAG	2.4 TD (99-..)	TRW AirBag MY 97 (2F-2P-2L)
 K	AIRBAG	2.4 TD (99-..)	TRW AirBag MY 97 (2F-2P-2L-S)
 K	AIRBAG	2.4 TD (99-..)	TRW AirBag MY 97 (2F-2P-S)
 K	AIRBAG	3.0	TRW AirBag MY 97 (2F-2P)
 K	AIRBAG	3.0	TRW AirBag MY 97 (2F-2P-2L)
 K	AIRBAG	3.0	TRW AirBag MY 97 (2F-2P-2L-S)
 K	AIRBAG	3.0	TRW AirBag MY 97 (2F-2P-S)
 K	AIRBAG	3.0	TRW AirBag TRW2
 K	AIRBAG	3.0	TRW-Becker AirBag no Pret.
 K	AIRBAG	3.0 (99-..)	TRW AirBag MY 97 (2F-2P)
 K	AIRBAG	3.0 (99-..)	TRW AirBag MY 97 (2F-2P-2L)

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Lancia

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 K	AIRBAG	3.0 (99-..)	TRW AirBag MY 97 (2F-2P-2L-S)
 K	AIRBAG	3.0 (99-..)	TRW AirBag MY 97 (2F-2P-S)
 K	CLIMA	2.0	Clima MANUAL
 K	CLIMA	2.0 T	Clima MANUAL
 K	CLIMA	2.0 V.I.S.	Clima MANUAL
 K	CLIMA	2.4	Clima MANUAL
 K	CLIMA	2.4 JTD	Clima MANUAL
 K	CLIMA	2.4 TD	Clima MANUAL
 K	CLIMA	3.0	Clima MANUAL
 K	ENGINE MANAGEME	2.0	BOSCH Motronic M2.10.3
 K	ENGINE MANAGEME	2.0 (99-..)	BOSCH Motronic ME3.1
 K	ENGINE MANAGEME	2.0 (99-..)	BOSCH Motronic ME3.1 EOBD
 K	ENGINE MANAGEME	2.0 T	BOSCH Motronic M2.7
 K	ENGINE MANAGEME	2.0 T	BOSCH Motronic M2.7
 K	ENGINE MANAGEME	2.0 T	BOSCH Motronic M2.7
 K	ENGINE MANAGEME	2.0 V.I.S.	BOSCH Motronic M2.10.3
 K	ENGINE MANAGEME	2.4	BOSCH Motronic M2.10.3
 K	ENGINE MANAGEME	2.4 (99-..)	BOSCH Motronic ME3.1
 K	ENGINE MANAGEME	2.4 (99-..)	BOSCH Motronic ME3.1 EOBD
 K	ENGINE MANAGEME	2.4 JTD (..-98)	BOSCH EDC 15 Common Rail
 K	ENGINE MANAGEME	2.4 JTD (99-..)	BOSCH EDC 15 Common Rail (JTD '99)
 K	ENGINE MANAGEME	2.4 TD	BOSCH MSA 11
 K	ENGINE MANAGEME	3.0	BOSCH Motronic M3.7
 K	ENGINE MANAGEME	3.0 (99-..)	BOSCH Motronic ME2.1
 K	KEY ENCODE	2.0	BOSCH CODE MANUAL
 K	KEY ENCODE	2.0 T	BOSCH CODE MANUAL
 K	KEY ENCODE	2.0 V.I.S.	BOSCH CODE MANUAL
 K	KEY ENCODE	2.4	BOSCH CODE MANUAL
 K	KEY ENCODE	2.4 JTD	BOSCH CODE MANUAL
 K	KEY ENCODE	2.4 TD	BOSCH CODE MANUAL
 K	KEY ENCODE	3.0	BOSCH CODE MANUAL
 K	MAINTENANCE	2.0	BOSCH CODE MANUAL
 K	MAINTENANCE	2.0	Clima MANUAL
 K	MAINTENANCE	2.0 T	BOSCH CODE MANUAL
 K	MAINTENANCE	2.0 T	Clima MANUAL
 K	MAINTENANCE	2.0 V.I.S.	BOSCH CODE MANUAL
 K	MAINTENANCE	2.0 V.I.S.	Clima MANUAL
 K	MAINTENANCE	2.4	BOSCH CODE MANUAL
 K	MAINTENANCE	2.4	Clima MANUAL
 K	MAINTENANCE	2.4 JTD	BOSCH CODE MANUAL
 K	MAINTENANCE	2.4 JTD	Clima MANUAL
 K	MAINTENANCE	2.4 TD	BOSCH CODE MANUAL
 K	MAINTENANCE	2.4 TD	Clima MANUAL
 K	MAINTENANCE	3.0	BOSCH CODE MANUAL
 K	MAINTENANCE	3.0	Clima MANUAL
 Lybra	ABS	1.6	BOSCH ABS 5.3
 Lybra	ABS	1.6	Lucas TRW ABS
 Lybra	ABS	1.8	BOSCH ABS 5.3
 Lybra	ABS	1.8	Lucas TRW ABS
 Lybra	ABS	1.9 JTD	BOSCH ABS 5.3
 Lybra	ABS	1.9 JTD	Lucas TRW ABS
 Lybra	ABS	2.0	BOSCH ABS 5.3
 Lybra	ABS	2.0	Lucas TRW ABS
 Lybra	ABS	2.4 JTD	BOSCH ABS 5.3
 Lybra	ABS	2.4 JTD	Lucas TRW ABS
 Lybra	AIRBAG	1.6	ALLIED AB MY 97 (2F-2P-2L-2T-I)
Lybra	AIRBAG	1.6	ALLIED AB MY 97 (2F-2P-2L-I)
Lybra	AIRBAG	1.6	ALLIED AB MY 97 (2F-2P-2L-I-S)

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Lancia

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Lybra	AIRBAG	1.6	ALLIED AB MY 97 (2F-2P-I)
 Lybra	AIRBAG	1.6	ALLIED AB MY 97 (2F-2P-I-S)
 Lybra	AIRBAG	1.6 (01-..)	SIEMENS AB MY 99 (2F-2P-2L-2T-2I-S)
 Lybra	AIRBAG	1.6 (01-..)	SIEMENS AB MY 99 (2F-2P-I-S)
 Lybra	AIRBAG	1.6 (01-..)	SIEMENS AB MY 99 (2F-4P-4L-2T-2I-S)
 Lybra	AIRBAG	1.8	ALLIED AB MY 97 (2F-2P-2L-2T-I)
 Lybra	AIRBAG	1.8	ALLIED AB MY 97 (2F-2P-2L-I)
 Lybra	AIRBAG	1.8	ALLIED AB MY 97 (2F-2P-2L-I-S)
 Lybra	AIRBAG	1.8	ALLIED AB MY 97 (2F-2P-I)
 Lybra	AIRBAG	1.8	ALLIED AB MY 97 (2F-2P-I-S)
 Lybra	AIRBAG	1.8 (01-..)	SIEMENS AB MY 99 (2F-2P-2L-2T-2I-S)
 Lybra	AIRBAG	1.8 (01-..)	SIEMENS AB MY 99 (2F-2P-I-S)
 Lybra	AIRBAG	1.8 (01-..)	SIEMENS AB MY 99 (2F-4P-4L-2T-2I-S)
 Lybra	AIRBAG	1.9 JTD	ALLIED AB MY 97 (2F-2P-2L-2T-I)
 Lybra	AIRBAG	1.9 JTD	ALLIED AB MY 97 (2F-2P-2L-I)
 Lybra	AIRBAG	1.9 JTD	ALLIED AB MY 97 (2F-2P-2L-I-S)
 Lybra	AIRBAG	1.9 JTD	ALLIED AB MY 97 (2F-2P-I)
 Lybra	AIRBAG	1.9 JTD	ALLIED AB MY 97 (2F-2P-I-S)
 Lybra	AIRBAG	1.9 JTD (01-..)	SIEMENS AB MY 99 (2F-2P-2L-2T-2I-S)
 Lybra	AIRBAG	1.9 JTD (01-..)	SIEMENS AB MY 99 (2F-2P-I-S)
 Lybra	AIRBAG	1.9 JTD (01-..)	SIEMENS AB MY 99 (2F-4P-4L-2T-2I-S)
 Lybra	AIRBAG	2.0	ALLIED AB MY 97 (2F-2P-2L-2T-I)
 Lybra	AIRBAG	2.0	ALLIED AB MY 97 (2F-2P-2L-I)
 Lybra	AIRBAG	2.0	ALLIED AB MY 97 (2F-2P-2L-I-S)
 Lybra	AIRBAG	2.0	ALLIED AB MY 97 (2F-2P-I)
 Lybra	AIRBAG	2.0	ALLIED AB MY 97 (2F-2P-I-S)
 Lybra	AIRBAG	2.0 (01-..)	SIEMENS AB MY 99 (2F-2P-2L-2T-2I-S)
 Lybra	AIRBAG	2.0 (01-..)	SIEMENS AB MY 99 (2F-2P-I-S)
 Lybra	AIRBAG	2.0 (01-..)	SIEMENS AB MY 99 (2F-4P-4L-2T-2I-S)
 Lybra	AIRBAG	2.4 JTD	ALLIED AB MY 97 (2F-2P-2L-2T-I)
 Lybra	AIRBAG	2.4 JTD	ALLIED AB MY 97 (2F-2P-2L-I)
 Lybra	AIRBAG	2.4 JTD	ALLIED AB MY 97 (2F-2P-2L-I-S)
 Lybra	AIRBAG	2.4 JTD	ALLIED AB MY 97 (2F-2P-I)
 Lybra	AIRBAG	2.4 JTD	ALLIED AB MY 97 (2F-2P-I-S)
 Lybra	AIRBAG	2.4 JTD (01-..)	SIEMENS AB MY 99 (2F-2P-2L-2T-2I-S)
 Lybra	AIRBAG	2.4 JTD (01-..)	SIEMENS AB MY 99 (2F-2P-I-S)
 Lybra	AIRBAG	2.4 JTD (01-..)	SIEMENS AB MY 99 (2F-4P-4L-2T-2I-S)
 Lybra	CENTRAL LOCKING	1.6	RF Bloccaporte/ricevitore VAS 97/3
 Lybra	CENTRAL LOCKING	1.8	RF Bloccaporte/ricevitore VAS 97/3
 Lybra	CENTRAL LOCKING	1.9 JTD	RF Bloccaporte/ricevitore VAS 97/3
 Lybra	CENTRAL LOCKING	2.0	RF Bloccaporte/ricevitore VAS 97/3
 Lybra	CENTRAL LOCKING	2.4 JTD	RF Bloccaporte/ricevitore VAS 97/3
 Lybra	ENGINE MANAGEME	1.6	Marelli IAW 49F
 Lybra	ENGINE MANAGEME	1.6	Marelli IAW 49F/59F EOBD
 Lybra	ENGINE MANAGEME	1.8	HITACHI MPI MFI '98
 Lybra	ENGINE MANAGEME	1.9 JTD (..-98)	BOSCH EDC 15 Common Rail
 Lybra	ENGINE MANAGEME	1.9 JTD (01-..)	BOSCH EDC 15 Common Rail (JTD '99)
 Lybra	ENGINE MANAGEME	1.9 JTD (99-..)	BOSCH EDC 15 Common Rail (JTD '99)
 Lybra	ENGINE MANAGEME	2.0	BOSCH Motronic ME3.1
 Lybra	ENGINE MANAGEME	2.0	BOSCH Motronic ME3.1 EOBD
 Lybra	ENGINE MANAGEME	2.4 JTD (..-98)	BOSCH EDC 15 Common Rail
 Lybra	ENGINE MANAGEME	2.4 JTD (01-..)	BOSCH EDC 15 Common Rail (JTD '99)
 Lybra	IMMOBILIZER	1.6	Marelli CODE 2
 Lybra	IMMOBILIZER	1.8	Marelli CODE 2
 Lybra	IMMOBILIZER	1.9 JTD	Marelli CODE 2
 Lybra	IMMOBILIZER	2.0	Marelli CODE 2
 Lybra	IMMOBILIZER	2.4 JTD	Marelli CODE 2
 Musa	ABS	1.3 Multijet	BOSCH ABS 8

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Lancia

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Musa	ABS	1.3 Multijet FAP	BOSCH ABS 8
 Musa	ABS	1.4 16v	BOSCH ABS 8
 Musa	ABS	1.4 8v	BOSCH ABS 8
 Musa	ABS	1.6 MJET 16v	BOSCH ABS 8
 Musa	ABS	1.9 JTD	BOSCH ABS 8
 Musa	AIRBAG	1.3 Multijet	TRW AirBag MY 03 (2F-2P-2L-2T-I)
 Musa	AIRBAG	1.3 Multijet	TRW AirBag MY 03 (2F-2P-2T-I)
 Musa	AIRBAG	1.3 Multijet	TRW AirBag MY 03 (2F-2P-I)
 Musa	AIRBAG	1.3 Multijet FAP	TRW AirBag MY 03 (2F-2P-2L-2T-I)
 Musa	AIRBAG	1.3 Multijet FAP	TRW AirBag MY 03 (2F-2P-2T-I)
 Musa	AIRBAG	1.3 Multijet FAP	TRW AirBag MY 03 (2F-2P-I)
 Musa	AIRBAG	1.4 16v	TRW AirBag MY 03 (2F-2P-2L-2T-I)
 Musa	AIRBAG	1.4 16v	TRW AirBag MY 03 (2F-2P-2T-I)
 Musa	AIRBAG	1.4 16v	TRW AirBag MY 03 (2F-2P-I)
 Musa	AIRBAG	1.4 8v	TRW AirBag MY 03 (2F-2P-2L-2T-I)
 Musa	AIRBAG	1.4 8v	TRW AirBag MY 03 (2F-2P-2T-I)
 Musa	AIRBAG	1.4 8v	TRW AirBag MY 03 (2F-2P-I)
 Musa	AIRBAG	1.6 MJET 16v	TRW AirBag MY 03 (2F-2P-2L-2T-I)
 Musa	AIRBAG	1.6 MJET 16v	TRW AirBag MY 03 (2F-2P-2T-I)
 Musa	AIRBAG	1.6 MJET 16v	TRW AirBag MY 03 (2F-2P-I)
 Musa	AIRBAG	1.9 JTD	TRW AirBag MY 03 (2F-2P-2L-2T-I)
 Musa	AIRBAG	1.9 JTD	TRW AirBag MY 03 (2F-2P-2T-I)
 Musa	AIRBAG	1.9 JTD	TRW AirBag MY 03 (2F-2P-I)
 Musa	AUTOM. TRANSMISSI	1.3 Multijet FAP	Marelli Selespeed CFC208F
 Musa	AUTOM. TRANSMISSI	1.3 Multijet FAP	Marelli Selespeed CFC228F
 Musa	AUTOM. TRANSMISSI	1.4 16v	Marelli Selespeed CFC208F
 Musa	AUTOM. TRANSMISSI	1.4 16v	Marelli Selespeed CFC228F
 Musa	AUTOM. TRANSMISSI	1.4 8v	Marelli Selespeed CFC208F
 Musa	AUTOM. TRANSMISSI	1.4 8v	Marelli Selespeed CFC228F
 Musa	AUTOM. TRANSMISSI	1.6 MJET 16v	Marelli Selespeed CFC208F
 Musa	AUTOM. TRANSMISSI	1.6 MJET 16v	Marelli Selespeed CFC228F
 Musa	AUTOM. TRANSMISSI	1.9 JTD	Marelli Selespeed CFC208F
 Musa	AUTOM. TRANSMISSI	1.9 JTD	Marelli Selespeed CFC228F
 Musa	DASHBOARD	1.3 Multijet	Marelli Dashboard Comfort
 Musa	DASHBOARD	1.3 Multijet	Marelli Dashboard Modale
 Musa	DASHBOARD	1.3 Multijet FAP	Marelli Dashboard Comfort
 Musa	DASHBOARD	1.3 Multijet FAP	Marelli Dashboard Modale
 Musa	DASHBOARD	1.4 16v	Marelli Dashboard Comfort
 Musa	DASHBOARD	1.4 16v	Marelli Dashboard Modale
 Musa	DASHBOARD	1.4 8v	Marelli Dashboard Comfort
 Musa	DASHBOARD	1.4 8v	Marelli Dashboard Modale
 Musa	DASHBOARD	1.6 MJET 16v	Marelli Dashboard Comfort
 Musa	DASHBOARD	1.6 MJET 16v	Marelli Dashboard Modale
 Musa	DASHBOARD	1.9 JTD	Marelli Dashboard Comfort
 Musa	DASHBOARD	1.9 JTD	Marelli Dashboard Modale
 Musa	DRIVER SIDE DOOR	1.3 Multijet	G.E.PROCOND DRIVER DOOR
 Musa	DRIVER SIDE DOOR	1.3 Multijet FAP	G.E.PROCOND DRIVER DOOR
 Musa	DRIVER SIDE DOOR	1.3 Multijet FAP	UNICO/BITRON DRIVER DOOR
 Musa	DRIVER SIDE DOOR	1.4 16v	G.E.PROCOND DRIVER DOOR
 Musa	DRIVER SIDE DOOR	1.4 16v	UNICO/BITRON DRIVER DOOR
 Musa	DRIVER SIDE DOOR	1.4 8v	G.E.PROCOND DRIVER DOOR
 Musa	DRIVER SIDE DOOR	1.4 8v	UNICO/BITRON DRIVER DOOR
 Musa	DRIVER SIDE DOOR	1.6 MJET 16v	G.E.PROCOND DRIVER DOOR
 Musa	DRIVER SIDE DOOR	1.6 MJET 16v	UNICO/BITRON DRIVER DOOR
 Musa	DRIVER SIDE DOOR	1.9 JTD	G.E.PROCOND DRIVER DOOR
 Musa	DRIVER SIDE DOOR	1.9 JTD	UNICO/BITRON DRIVER DOOR
 Musa	ELECTRIC STEERING	1.3 Multijet	TRW EPS
 Musa	ELECTRIC STEERING	1.3 Multijet FAP	TRW EPS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Lancia

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Musa	ELECTRIC STEERING	1.4 16v	TRW EPS
 Musa	ELECTRIC STEERING	1.4 8v	TRW EPS
 Musa	ELECTRIC STEERING	1.6 MJET 16v	TRW EPS
 Musa	ELECTRIC STEERING	1.9 JTD	TRW EPS
 Musa	ENGINE MANAGEME	1.3 Multijet	Marelli 6JF CF3 Common Rail
 Musa	ENGINE MANAGEME	1.3 Multijet	Marelli 8DF CF5
 Musa	ENGINE MANAGEME	1.3 Multijet FAP	Marelli 6F3 CF3 Common Rail
 Musa	ENGINE MANAGEME	1.4 16v	BOSCH Motronic ME7.3H4M EOBD
 Musa	ENGINE MANAGEME	1.4 8v	EOBD
 Musa	ENGINE MANAGEME	1.6 MJET 16v (08-..)	BOSCH EDC 16C39 CF5/EOBD
 Musa	ENGINE MANAGEME	1.9 JTD	BOSCH EDC 16 C9 Common Rail M-Jet
 Musa	HATCHBACK DOOR E	1.3 Multijet	G.E.PROCOND TRUNK COMPARTMENT
 Musa	HATCHBACK DOOR E	1.3 Multijet FAP	G.E.PROCOND TRUNK COMPARTMENT
 Musa	HATCHBACK DOOR E	1.4 16v	G.E.PROCOND TRUNK COMPARTMENT
 Musa	HATCHBACK DOOR E	1.4 8v	G.E.PROCOND TRUNK COMPARTMENT
 Musa	HATCHBACK DOOR E	1.6 MJET 16v	G.E.PROCOND TRUNK COMPARTMENT
 Musa	HATCHBACK DOOR E	1.9 JTD	G.E.PROCOND TRUNK COMPARTMENT
 Musa	KEY ENCODE	1.3 Multijet	Marelli CODE Body Computer
 Musa	KEY ENCODE	1.3 Multijet FAP	Marelli CODE Body Computer
 Musa	KEY ENCODE	1.4 16v	Marelli CODE Body Computer
 Musa	KEY ENCODE	1.4 8v	Marelli CODE Body Computer
 Musa	KEY ENCODE	1.6 MJET 16v	Marelli CODE Body Computer
 Musa	KEY ENCODE	1.9 JTD	Marelli CODE Body Computer
 Musa	MAINTENANCE	1.3 Multijet	Marelli
 Musa	MAINTENANCE	1.3 Multijet	Marelli Dashboard Comfort
 Musa	MAINTENANCE	1.3 Multijet	Marelli Dashboard Comfort
 Musa	MAINTENANCE	1.3 Multijet	Marelli Dashboard Modale
 Musa	MAINTENANCE	1.3 Multijet FAP	Marelli
 Musa	MAINTENANCE	1.3 Multijet FAP	Marelli 6F3 CF3 Common Rail
 Musa	MAINTENANCE	1.3 Multijet FAP	Marelli 6F3 CF3 Common Rail
 Musa	MAINTENANCE	1.3 Multijet FAP	Marelli 6F3 CF3 Common Rail
 Musa	MAINTENANCE	1.3 Multijet FAP	Marelli 6F3 CF3 Common Rail
 Musa	MAINTENANCE	1.3 Multijet FAP	Marelli Dashboard Comfort
 Musa	MAINTENANCE	1.3 Multijet FAP	Marelli Dashboard Comfort
 Musa	MAINTENANCE	1.3 Multijet FAP	Marelli Dashboard Modale
 Musa	MAINTENANCE	1.3 Multijet FAP	Marelli Selespeed CFC208F
 Musa	MAINTENANCE	1.3 Multijet FAP	Marelli Selespeed CFC208F
 Musa	MAINTENANCE	1.3 Multijet FAP	Marelli Selespeed CFC228F
 Musa	MAINTENANCE	1.4 16v	Marelli
 Musa	MAINTENANCE	1.4 16v	Marelli Dashboard Comfort
 Musa	MAINTENANCE	1.4 16v	Marelli Dashboard Comfort
 Musa	MAINTENANCE	1.4 16v	Marelli Dashboard Modale
 Musa	MAINTENANCE	1.4 16v	Marelli Selespeed CFC208F
 Musa	MAINTENANCE	1.4 16v	Marelli Selespeed CFC208F
 Musa	MAINTENANCE	1.4 16v	Marelli Selespeed CFC228F
 Musa	MAINTENANCE	1.4 8v	Marelli
 Musa	MAINTENANCE	1.4 8v	Marelli Dashboard Comfort
 Musa	MAINTENANCE	1.4 8v	Marelli Dashboard Comfort
 Musa	MAINTENANCE	1.4 8v	Marelli Dashboard Modale
 Musa	MAINTENANCE	1.4 8v	Marelli Selespeed CFC208F
 Musa	MAINTENANCE	1.4 8v	Marelli Selespeed CFC208F
 Musa	MAINTENANCE	1.4 8v	Marelli Selespeed CFC228F
 Musa	MAINTENANCE	1.6 MJET 16v	Marelli
 Musa	MAINTENANCE	1.6 MJET 16v	Marelli Dashboard Comfort
 Musa	MAINTENANCE	1.6 MJET 16v	Marelli Dashboard Comfort
 Musa	MAINTENANCE	1.6 MJET 16v	Marelli Dashboard Modale
 Musa	MAINTENANCE	1.6 MJET 16v	Marelli Selespeed CFC208F
 Musa	MAINTENANCE	1.6 MJET 16v	Marelli Selespeed CFC208F

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Lancia

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Musa	MAINTENANCE	1.6 MJET 16v	Marelli Selespeed CFC228F
 Musa	MAINTENANCE	1.6 MJET 16v (08-..)	BOSCH EDC 16C39 CF5/EOBD
 Musa	MAINTENANCE	1.6 MJET 16v (08-..)	BOSCH EDC 16C39 CF5/EOBD
 Musa	MAINTENANCE	1.9 JTD	Marelli
 Musa	MAINTENANCE	1.9 JTD	Marelli Dashboard Comfort
 Musa	MAINTENANCE	1.9 JTD	Marelli Dashboard Comfort
 Musa	MAINTENANCE	1.9 JTD	Marelli Dashboard Modale
 Musa	MAINTENANCE	1.9 JTD	Marelli Selespeed CFC208F
 Musa	MAINTENANCE	1.9 JTD	Marelli Selespeed CFC208F
 Musa	MAINTENANCE	1.9 JTD	Marelli Selespeed CFC228F
 Musa	PARKING HELP	1.3 Multijet	Valeo
 Musa	PARKING HELP	1.3 Multijet FAP	Valeo
 Musa	PARKING HELP	1.4 16v	Valeo
 Musa	PARKING HELP	1.4 8v	Valeo
 Musa	PARKING HELP	1.6 MJET 16v	Valeo
 Musa	PARKING HELP	1.9 JTD	Valeo
 Musa	PASS. SIDE DOOR	1.3 Multijet	G.E.PROCOND PASSENGER DOOR
 Musa	PASS. SIDE DOOR	1.3 Multijet FAP	G.E.PROCOND PASSENGER DOOR
 Musa	PASS. SIDE DOOR	1.4 16v	G.E.PROCOND PASSENGER DOOR
 Musa	PASS. SIDE DOOR	1.4 8v	G.E.PROCOND PASSENGER DOOR
 Musa	PASS. SIDE DOOR	1.6 MJET 16v	G.E.PROCOND PASSENGER DOOR
 Musa	PASS. SIDE DOOR	1.9 JTD	G.E.PROCOND PASSENGER DOOR
 Musa	SERVICE LIGHT RES	1.3 Multijet	Marelli
 Musa	SERVICE LIGHT RES	1.3 Multijet FAP	Marelli
 Musa	SERVICE LIGHT RES	1.4 16v	Marelli
 Musa	SERVICE LIGHT RES	1.4 8v	Marelli
 Musa	SERVICE LIGHT RES	1.6 MJET 16v	Marelli
 Musa	SERVICE LIGHT RES	1.9 JTD	Marelli
 Musa	VISUAL./TELEMATIC	1.3 Multijet	Marelli Connect 3
 Musa	VISUAL./TELEMATIC	1.3 Multijet FAP	Marelli Connect 3
 Musa	VISUAL./TELEMATIC	1.4 16v	Marelli Connect 3
 Musa	VISUAL./TELEMATIC	1.4 8v	Marelli Connect 3
 Musa	VISUAL./TELEMATIC	1.6 MJET 16v	Marelli Connect 3
 Musa	VISUAL./TELEMATIC	1.9 JTD	Marelli Connect 3
 Phedra (180)	ABS + TRACT. CONT	2.0 JTD 16v 120cv (07-..)	BOSCH ESP 8.1
 Phedra (180)	ABS + TRACT. CONT	2.0 JTD FAP 16v 136cv (07-..)	BOSCH ESP 8.1
 Phedra (180)	ABS + TRACT. CONT	2.2 JTD FAP 16v 170cv (07-..)	BOSCH ESP 8.1
 Phedra (180)	AIRBAG	2.0 JTD 16v 120cv (05-..)	TEMIC AirBag
 Phedra (180)	AIRBAG	2.0 JTD FAP 16v 136cv (05-..)	TEMIC AirBag
 Phedra (180)	AIRBAG	2.2 JTD FAP 16v 170cv (05-..)	TEMIC AirBag
 Phedra (180)	ANTITHEFT	2.0 JTD 16v 120cv (07-..)	Alarm PSA2 AUTODETECT
 Phedra (180)	ANTITHEFT	2.2 JTD FAP 16v 170cv (07-..)	Alarm PSA2 AUTODETECT
 Phedra (180)	DASH LAMPS	2.0 JTD 16v 120cv (05-..)	Marelli
 Phedra (180)	DASH LAMPS	2.0 JTD FAP 16v 136cv (05-..)	Marelli
 Phedra (180)	DASH LAMPS	2.2 JTD FAP 16v 170cv (05-..)	Marelli
 Phedra (180)	DASHBOARD	2.0 JTD 16v 120cv (05-..)	Marelli Dashboard
 Phedra (180)	DASHBOARD	2.0 JTD FAP 16v 136cv (05-..)	Marelli Dashboard
 Phedra (180)	DASHBOARD	2.2 JTD FAP 16v 170cv (05-..)	Marelli Dashboard
 Phedra (180)	ENGINE MANAGEME	2.0 JTD 16v 120cv (05-..)	EOBD
 Phedra (180)	ENGINE MANAGEME	2.0 JTD FAP 16v 136cv (05-..)	EOBD
 Phedra (180)	ENGINE MANAGEME	2.2 JTD FAP 16v 170cv (05-..)	EOBD
 Phedra (180)	MAINTENANCE	2.0 JTD 16v 120cv (05-..)	EOBD
 Phedra (180)	MAINTENANCE	2.0 JTD 16v 120cv (05-..)	EOBD
 Phedra (180)	MAINTENANCE	2.0 JTD 16v 120cv (05-..)	EOBD
 Phedra (180)	MAINTENANCE	2.0 JTD 16v 120cv (07-..)	Marelli
 Phedra (180)	MAINTENANCE	2.0 JTD 16v 120cv (07-..)	BOSCH ESP 8.1
 Phedra (180)	MAINTENANCE	2.0 JTD FAP 16v 136cv (05-..)	Marelli

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Lancia

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Phedra (180)	MAINTENANCE	2.0 JTD FAP 16v 136cv (07-..)	BOSCH ESP 8.1
 Phedra (180)	MAINTENANCE	2.0 JTD FAP 16v 136cv (07-..)	BOSCH ESP 8.1
 Phedra (180)	MAINTENANCE	2.2 JTD FAP 16v 170cv (05-..)	Marelli
 Phedra (180)	MAINTENANCE	2.2 JTD FAP 16v 170cv (07-..)	BOSCH ESP 8.1
 Phedra (180)	MAINTENANCE	2.2 JTD FAP 16v 170cv (07-..)	BOSCH ESP 8.1
 Phedra (180)	RADIO / CD	2.0 JTD 16v 120cv (07-..)	Blaupunkt AudioSystem
 Phedra (180)	RADIO / CD	2.0 JTD 16v 120cv (07-..)	CD Changer AUTODETECT
 Phedra (180)	RADIO / CD	2.0 JTD FAP 16v 136cv (07-..)	Blaupunkt AudioSystem
 Phedra (180)	RADIO / CD	2.0 JTD FAP 16v 136cv (07-..)	CD Changer AUTODETECT
 Phedra (180)	RADIO / CD	2.2 JTD FAP 16v 170cv (07-..)	Blaupunkt AudioSystem
 Phedra (180)	RADIO / CD	2.2 JTD FAP 16v 170cv (07-..)	CD Changer AUTODETECT
 Phedra	ABS	2.0 16v (.-05)	BOSCH ABS ABR 5.7
 Phedra	ABS	2.2 JTD (.-05)	BOSCH ABS ABR 5.7
 Phedra	ABS	2.2 JTD FAP (.-05)	BOSCH ABS ABR 5.7
 Phedra	ABS	3.0 V6 24v (.-05)	BOSCH ABS ABR 5.7
 Phedra	ABS + TRACT. CONT	2.0 16v (.-05)	BOSCH ABS/ESP 5.7
 Phedra	ABS + TRACT. CONT	2.2 JTD (.-05)	BOSCH ABS/ESP 5.7
 Phedra	ABS + TRACT. CONT	2.2 JTD FAP (.-05)	BOSCH ABS/ESP 5.7
 Phedra	ABS + TRACT. CONT	3.0 V6 24v (.-05)	BOSCH ABS/ESP 5.7
 Phedra	AIRBAG	2.0 16v (.-05)	TEMIC AirBag
 Phedra	AIRBAG	2.2 JTD (.-05)	TEMIC AirBag
 Phedra	AIRBAG	2.2 JTD FAP (.-05)	TEMIC AirBag
 Phedra	AIRBAG	3.0 V6 24v (.-05)	TEMIC AirBag
 Phedra	CHASSIS NETWORK	2.0 16v (.-05)	SAGEM Body Computer
 Phedra	CHASSIS NETWORK	2.2 JTD (.-05)	SAGEM Body Computer
 Phedra	CHASSIS NETWORK	2.2 JTD FAP (.-05)	SAGEM Body Computer
 Phedra	CHASSIS NETWORK	3.0 V6 24v (.-05)	SAGEM Body Computer
 Phedra	CLIMA	2.0 16v (.-05)	Marelli Klima
 Phedra	CLIMA	2.2 JTD (.-05)	Marelli Klima
 Phedra	CLIMA	2.2 JTD FAP (.-05)	Marelli Klima
 Phedra	CLIMA	3.0 V6 24v (.-05)	Marelli Klima
 Phedra	DASH LAMPS	2.0 16v (.-05)	BTO_MM
 Phedra	DASH LAMPS	2.2 JTD (.-05)	BTO_MM
 Phedra	DASH LAMPS	2.2 JTD FAP (.-05)	BTO_MM
 Phedra	DASH LAMPS	3.0 V6 24v (.-05)	BTO_MM
 Phedra	DASHBOARD	2.0 16v (.-05)	Marelli Dashboard
 Phedra	DASHBOARD	2.2 JTD (.-05)	Marelli Dashboard
 Phedra	DASHBOARD	2.2 JTD FAP (.-05)	Marelli Dashboard
 Phedra	DASHBOARD	3.0 V6 24v (.-05)	Marelli Dashboard
 Phedra	DIESEL ADDITION	2.2 JTD FAP (.-05)	Marelli
 Phedra	DRIVER SIDE DOOR	2.0 16v (.-05)	Marelli MTP CONDUCT
 Phedra	DRIVER SIDE DOOR	2.2 JTD (.-05)	Marelli MTP CONDUCT
 Phedra	DRIVER SIDE DOOR	2.2 JTD FAP (.-05)	Marelli MTP CONDUCT
 Phedra	DRIVER SIDE DOOR	3.0 V6 24v (.-05)	Marelli MTP CONDUCT
 Phedra	ENGINE MANAGEME	2.0 16v (.-05)	EOBD
 Phedra	ENGINE MANAGEME	2.2 JTD 4HW- FAP (.-05)	BOSCH EDC 15 C2 Common Rail
 Phedra	ENGINE MANAGEME	2.2 JTD 4HX (.-05)	BOSCH EDC 15 C2 Common Rail
 Phedra	ENGINE MANAGEME	3.0 V6 24v (.-05)	EOBD
 Phedra	MAINTENANCE	2.0 16v (.-05)	BOSCH ABS/ESP 5.7
 Phedra	MAINTENANCE	2.0 16v (.-05)	BOSCH ABS/ESP 5.7
 Phedra	MAINTENANCE	2.0 16v (.-05)	BOSCH ABS/ESP 5.7
 Phedra	MAINTENANCE	2.0 16v (.-05)	BOSCH ABS/ESP 5.7
 Phedra	MAINTENANCE	2.0 16v (.-05)	BOSCH ABS/ESP 5.7
 Phedra	MAINTENANCE	2.0 16v (.-05)	BTO_MM
 Phedra	MAINTENANCE	2.2 JTD (.-05)	BOSCH ABS/ESP 5.7
 Phedra	MAINTENANCE	2.2 JTD (.-05)	BOSCH ABS/ESP 5.7
 Phedra	MAINTENANCE	2.2 JTD (.-05)	BOSCH ABS/ESP 5.7
 Phedra	MAINTENANCE	2.2 JTD (.-05)	BOSCH ABS/ESP 5.7

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Lancia

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Phedra	MAINTENANCE	2.2 JTD (.-05)	BOSCH ABS/ESP 5.7
 Phedra	MAINTENANCE	2.2 JTD (.-05)	BTO_MM
 Phedra	MAINTENANCE	2.2 JTD 4HW- FAP (.-05)	BOSCH EDC 15 C2 Common Rail
 Phedra	MAINTENANCE	2.2 JTD 4HX (.-05)	BOSCH EDC 15 C2 Common Rail
 Phedra	MAINTENANCE	2.2 JTD FAP (.-05)	BOSCH ABS/ESP 5.7
 Phedra	MAINTENANCE	2.2 JTD FAP (.-05)	BOSCH ABS/ESP 5.7
 Phedra	MAINTENANCE	2.2 JTD FAP (.-05)	BOSCH ABS/ESP 5.7
 Phedra	MAINTENANCE	2.2 JTD FAP (.-05)	BOSCH ABS/ESP 5.7
 Phedra	MAINTENANCE	2.2 JTD FAP (.-05)	BOSCH ABS/ESP 5.7
 Phedra	MAINTENANCE	2.2 JTD FAP (.-05)	BTO_MM
 Phedra	MAINTENANCE	2.2 JTD FAP (.-05)	Marelli
 Phedra	MAINTENANCE	2.2 JTD FAP (.-05)	Marelli
 Phedra	MAINTENANCE	2.2 JTD FAP (.-05)	Marelli
 Phedra	MAINTENANCE	2.2 JTD FAP (.-05)	Marelli
 Phedra	MAINTENANCE	3.0 V6 24v (.-05)	BOSCH ABS/ESP 5.7
 Phedra	MAINTENANCE	3.0 V6 24v (.-05)	BOSCH ABS/ESP 5.7
 Phedra	MAINTENANCE	3.0 V6 24v (.-05)	BOSCH ABS/ESP 5.7
 Phedra	MAINTENANCE	3.0 V6 24v (.-05)	BOSCH ABS/ESP 5.7
 Phedra	MAINTENANCE	3.0 V6 24v (.-05)	BOSCH ABS/ESP 5.7
 Phedra	MAINTENANCE	3.0 V6 24v (.-05)	BTO_MM
 Phedra	PARKING HELP	2.0 16v (.-05)	VALEO
 Phedra	PARKING HELP	2.2 JTD (.-05)	VALEO
 Phedra	PARKING HELP	2.2 JTD FAP (.-05)	VALEO
 Phedra	PARKING HELP	3.0 V6 24v (.-05)	VALEO
 Phedra	PASS. SIDE DOOR	2.0 16v (.-05)	Marelli MTP PASS
 Phedra	PASS. SIDE DOOR	2.2 JTD (.-05)	Marelli MTP PASS
 Phedra	PASS. SIDE DOOR	2.2 JTD FAP (.-05)	Marelli MTP PASS
 Phedra	PASS. SIDE DOOR	3.0 V6 24v (.-05)	Marelli MTP PASS
 Phedra	RADIO / CD	2.0 16v (.-05)	CLARION
 Phedra	RADIO / CD	2.0 16v (.-05)	PHILIPS AudioSystem
 Phedra	RADIO / CD	2.0 16v (.-05)	VDO AudioSystem
 Phedra	RADIO / CD	2.2 JTD (.-05)	CLARION
 Phedra	RADIO / CD	2.2 JTD (.-05)	PHILIPS AudioSystem
 Phedra	RADIO / CD	2.2 JTD (.-05)	VDO AudioSystem
 Phedra	RADIO / CD	2.2 JTD FAP (.-05)	CLARION
 Phedra	RADIO / CD	2.2 JTD FAP (.-05)	PHILIPS AudioSystem
 Phedra	RADIO / CD	2.2 JTD FAP (.-05)	VDO AudioSystem
 Phedra	RADIO / CD	3.0 V6 24v (.-05)	CLARION
 Phedra	RADIO / CD	3.0 V6 24v (.-05)	PHILIPS AudioSystem
 Phedra	RADIO / CD	3.0 V6 24v (.-05)	VDO AudioSystem
 Phedra	SWITCHLIGHT MODU	2.0 16v (.-05)	EATON COM 2000
 Phedra	SWITCHLIGHT MODU	2.2 JTD (.-05)	EATON COM 2000
 Phedra	SWITCHLIGHT MODU	2.2 JTD FAP (.-05)	EATON COM 2000
 Phedra	SWITCHLIGHT MODU	3.0 V6 24v (.-05)	EATON COM 2000
 Prisma	ENGINE MANAGEME	1.6	Marelli IAW 02P.03
 Prisma	ENGINE MANAGEME	1.6	Marelli IAW 02P.03
 Prisma	ENGINE MANAGEME	1.6	Marelli IAW 02P.03
 Prisma	ENGINE MANAGEME	1.6	Marelli IAW 02P.04
 Prisma	ENGINE MANAGEME	1.6	Marelli IAW 02P.04
 Prisma	ENGINE MANAGEME	1.6	Marelli IAW 04P.07
 Prisma	ENGINE MANAGEME	2.0 4WD	Marelli IAW 02G.03
 Prisma	ENGINE MANAGEME	2.0 4WD	Marelli IAW 02G.04
 Prisma	ENGINE MANAGEME	2.0 4WD	Marelli IAW 04G.07
 Prisma	ENGINE MANAGEME	2.0 4WD Kat	Marelli IAW 04H.06
 Thema	ABS	2.0 16v Kat	BOSCH ABS 2Si
 Thema	ABS	2.0 T 16v Kat	BOSCH ABS 2Si
 Thema	ABS	3.0 V6 Kat	BOSCH ABS 2Si
 Thema	ENGINE MANAGEME	2.0 16v Kat	BOSCH Motronic M1.7

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Lancia

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Thema	ENGINE MANAGEME	2.0 16v Kat	BOSCH Motronic M1.7
 Thema	ENGINE MANAGEME	2.0 T 16v Kat	BOSCH Motronic M2.7
 Thema	ENGINE MANAGEME	3.0 V6 Kat	BOSCH Motronic M1.7
 Thema	ENGINE MANAGEME	3.0 V6 Kat	BOSCH Motronic M1.7
 Thema	ENGINE MANAGEME	3.0 V6 Kat	BOSCH Motronic M1.7
 Thesis	AIRBAG	2.0 T	TRW AirBag MY 99 (2F-4P-4L-2T-I-S)
 Thesis	AIRBAG	2.4 20v	TRW AirBag MY 99 (2F-4P-4L-2T-I-S)
 Thesis	AIRBAG	2.4 JTD 10v	TRW AirBag MY 99 (2F-4P-4L-2T-I-S)
 Thesis	AIRBAG	2.4 JTD 20v	TRW AirBag MY 99 (2F-4P-4L-2T-I-S)
 Thesis	AIRBAG	3.0 V6 24v	TRW AirBag MY 99 (2F-4P-4L-2T-I-S)
 Thesis	AIRBAG	3.2 V6	TRW AirBag MY 99 (2F-4P-4L-2T-I-S)
 Thesis	CHANGE BRAKE PAD	2.0 T	MANUAL
 Thesis	CHANGE BRAKE PAD	2.4 20v	MANUAL
 Thesis	CHANGE BRAKE PAD	2.4 JTD 10v	MANUAL
 Thesis	CHANGE BRAKE PAD	2.4 JTD 20v	MANUAL
 Thesis	CHANGE BRAKE PAD	3.0 V6 24v	MANUAL
 Thesis	CHANGE BRAKE PAD	3.2 V6	MANUAL
 Thesis	CHASSIS NETWORK	2.0 T	Marelli Easy go Body Computer
 Thesis	CHASSIS NETWORK	2.0 T	Marelli Full Body Computer
 Thesis	CHASSIS NETWORK	2.4 20v	Marelli Easy go Body Computer
 Thesis	CHASSIS NETWORK	2.4 20v	Marelli Full Body Computer
 Thesis	CHASSIS NETWORK	2.4 JTD 10v	Marelli Easy go Body Computer
 Thesis	CHASSIS NETWORK	2.4 JTD 10v	Marelli Full Body Computer
 Thesis	CHASSIS NETWORK	2.4 JTD 20v	Marelli Easy go Body Computer
 Thesis	CHASSIS NETWORK	2.4 JTD 20v	Marelli Full Body Computer
 Thesis	CHASSIS NETWORK	3.0 V6 24v	Marelli Easy go Body Computer
 Thesis	CHASSIS NETWORK	3.0 V6 24v	Marelli Full Body Computer
 Thesis	CHASSIS NETWORK	3.2 V6	Marelli Easy go Body Computer
 Thesis	CHASSIS NETWORK	3.2 V6	Marelli Full Body Computer
 Thesis	ENGINE MANAGEME	2.0 T	EOBD
 Thesis	ENGINE MANAGEME	2.4 20v	EOBD
 Thesis	ENGINE MANAGEME	2.4 JTD 10v	BOSCH EDC 15 Common Rail (JTD '99)
 Thesis	ENGINE MANAGEME	2.4 JTD 20v	BOSCH EDC 15 Common Rail (JTD '99)
 Thesis	ENGINE MANAGEME	2.4 JTD 20v (...03)	BOSCH EDC 16 CF3 Common Rail M-Jet
 Thesis	ENGINE MANAGEME	2.4 JTD 20v (...03)	BOSCH EDC 16C39 CF4/EOBD Common
 Thesis	ENGINE MANAGEME	3.0 V6 24v	EOBD
 Thesis	ENGINE MANAGEME	3.2 V6 (01-..)	BOSCH Motronic ME7.3.1 EOBD
 Thesis	MAINTENANCE	2.0 T	MANUAL
 Thesis	MAINTENANCE	2.4 20v	MANUAL
 Thesis	MAINTENANCE	2.4 JTD 10v	MANUAL
 Thesis	MAINTENANCE	2.4 JTD 20v	MANUAL
 Thesis	MAINTENANCE	2.4 JTD 20v (...03)	BOSCH EDC 16C39 CF4/EOBD Common
 Thesis	MAINTENANCE	2.4 JTD 20v (...03)	BOSCH EDC 16C39 CF4/EOBD Common
 Thesis	MAINTENANCE	3.0 V6 24v	MANUAL
 Thesis	MAINTENANCE	3.2 V6	MANUAL
 Thesis	PARKING HELP	2.0 T	Valeo
 Thesis	PARKING HELP	2.4 20v	Valeo
 Thesis	PARKING HELP	2.4 JTD 10v	Valeo
 Thesis	PARKING HELP	2.4 JTD 20v	Valeo
 Thesis	PARKING HELP	3.0 V6 24v	Valeo
 Thesis	PARKING HELP	3.2 V6	Valeo
 Y	ABS	1.1	BOSCH ABS 5.3
 Y	ABS	1.2	BOSCH ABS 5.3
 Y	ABS	1.2 16v	BOSCH ABS 5.3
 Y	ABS	1.2 8v CF3	BOSCH ABS 5.3
 Y	ABS	1.4	BOSCH ABS 5.3
 Y	AIRBAG	1.1	ALLIED AirBag MY 97 (2F-2P)
 Y	AIRBAG	1.1	ALLIED AirBag MY 97 (2F-2P-2L-I)

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Lancia

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Y	AIRBAG	1.1	ALLIED AirBag MY 97 (2F-2P-2L-S)
 Y	AIRBAG	1.1	ALLIED AirBag MY 97 (2F-2P-I)
 Y	AIRBAG	1.1	ALLIED AirBag MY 97 (2F-2P-S)
 Y	AIRBAG	1.1	ALLIED AirBag Signal
 Y	AIRBAG	1.2	ALLIED AirBag MY 97 (2F-2P)
 Y	AIRBAG	1.2	ALLIED AirBag MY 97 (2F-2P-2L-I)
 Y	AIRBAG	1.2	ALLIED AirBag MY 97 (2F-2P-2L-S)
 Y	AIRBAG	1.2	ALLIED AirBag MY 97 (2F-2P-I)
 Y	AIRBAG	1.2	ALLIED AirBag MY 97 (2F-2P-S)
 Y	AIRBAG	1.2	ALLIED AirBag Signal
 Y	AIRBAG	1.2 16v	ALLIED AirBag MY 97 (2F-2P)
 Y	AIRBAG	1.2 16v	ALLIED AirBag MY 97 (2F-2P-2L-I)
 Y	AIRBAG	1.2 16v	ALLIED AirBag MY 97 (2F-2P-2L-S)
 Y	AIRBAG	1.2 16v	ALLIED AirBag MY 97 (2F-2P-I)
 Y	AIRBAG	1.2 16v	ALLIED AirBag MY 97 (2F-2P-S)
 Y	AIRBAG	1.2 16v	ALLIED AirBag Signal
 Y	AIRBAG	1.2 8v CF3	ALLIED AirBag MY 97 (2F-2P)
 Y	AIRBAG	1.2 8v CF3	ALLIED AirBag MY 97 (2F-2P-2L-I)
 Y	AIRBAG	1.2 8v CF3	ALLIED AirBag MY 97 (2F-2P-2L-S)
 Y	AIRBAG	1.2 8v CF3	ALLIED AirBag MY 97 (2F-2P-I)
 Y	AIRBAG	1.2 8v CF3	ALLIED AirBag MY 97 (2F-2P-S)
 Y	AIRBAG	1.2 8v CF3	ALLIED AirBag Signal
 Y	AIRBAG	1.4	ALLIED AirBag MY 97 (2F-2P)
 Y	AIRBAG	1.4	ALLIED AirBag MY 97 (2F-2P-2L-I)
 Y	AIRBAG	1.4	ALLIED AirBag MY 97 (2F-2P-2L-S)
 Y	AIRBAG	1.4	ALLIED AirBag MY 97 (2F-2P-I)
 Y	AIRBAG	1.4	ALLIED AirBag MY 97 (2F-2P-S)
 Y	AIRBAG	1.4	ALLIED AirBag Signal
 Y	ENGINE MANAGEME	1.1	Marelli IAW 16F.EB
 Y	ENGINE MANAGEME	1.1	Marelli IAW 16F.EB
 Y	ENGINE MANAGEME	1.2	Marelli IAW 16F.ET
 Y	ENGINE MANAGEME	1.2	Marelli IAW 16F.ET
 Y	ENGINE MANAGEME	1.2	Marelli IAW 16F.ET
 Y	ENGINE MANAGEME	1.2	Marelli IAW 16F.EU
 Y	ENGINE MANAGEME	1.2	Marelli IAW 4EF
 Y	ENGINE MANAGEME	1.2	Marelli IAW 59F
 Y	ENGINE MANAGEME	1.2 16v	BOSCH Motronic ME7.3 H4
 Y	ENGINE MANAGEME	1.2 16v	BOSCH Motronic Throttle Pos. Learning MA
 Y	ENGINE MANAGEME	1.2 16v	Marelli IAW 18FD
 Y	ENGINE MANAGEME	1.2 8v CF3	Marelli IAW 49F/59F EOBD
 Y	ENGINE MANAGEME	1.4	BOSCH MonoMotronic MA1.7.3
 Y	ENGINE MANAGEME	1.4	BOSCH MonoMotronic MA1.7.3
 Y	KEY ENCODE	1.1	BOSCH CODE MANUAL
 Y	KEY ENCODE	1.2	BOSCH CODE MANUAL
 Y	KEY ENCODE	1.2 16v	BOSCH CODE MANUAL
 Y	KEY ENCODE	1.2 8v CF3	BOSCH CODE MANUAL
 Y	KEY ENCODE	1.4	BOSCH CODE MANUAL
 Y	MAINTENANCE	1.1	BOSCH CODE MANUAL
 Y	MAINTENANCE	1.2	BOSCH CODE MANUAL
 Y	MAINTENANCE	1.2 16v	BOSCH CODE MANUAL
 Y	MAINTENANCE	1.2 16v	BOSCH Motronic Throttle Pos. Learning MA
 Y	MAINTENANCE	1.2 8v CF3	BOSCH CODE MANUAL
 Y	MAINTENANCE	1.4	BOSCH CODE MANUAL
 Ypsilon (402)	ABS + TRACT. CONT	0.9 8V TwinAir Metano (11-..)	BOSCH ESP 8
 Ypsilon (402)	ABS + TRACT. CONT	0.9 TwinAir Turbo 85cv (11-..)	BOSCH ESP 8
 Ypsilon (402)	ABS + TRACT. CONT	1.2 8v (11-..)	BOSCH ESP 8
 Ypsilon (402)	ABS + TRACT. CONT	1.2 8v GPL (11-..)	BOSCH ESP 8
 Ypsilon (402)	ABS + TRACT. CONT	1.3 Multijet 16v 95cv (11-..)	BOSCH ESP 8

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Lancia

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Ypsilon (402)	AIRBAG	0.9 8V TwinAir Metano (11-..)	Continental AirBag
 Ypsilon (402)	AIRBAG	0.9 TwinAir Turbo 85cv (11-..)	Continental AirBag
 Ypsilon (402)	AIRBAG	1.2 8v (11-..)	Continental AirBag
 Ypsilon (402)	AIRBAG	1.2 8v GPL (11-..)	Continental AirBag
 Ypsilon (402)	AIRBAG	1.3 Multijet 16v 95cv (11-..)	Continental AirBag
 Ypsilon (402)	CHASSIS NETWORK	0.9 8V TwinAir Metano (11-..)	DELPHI Body Computer 2
 Ypsilon (402)	CHASSIS NETWORK	0.9 TwinAir Turbo 85cv (11-..)	DELPHI Body Computer 2
 Ypsilon (402)	CHASSIS NETWORK	1.2 8v (11-..)	DELPHI Body Computer 2
 Ypsilon (402)	CHASSIS NETWORK	1.2 8v GPL (11-..)	DELPHI Body Computer 2
 Ypsilon (402)	CHASSIS NETWORK	1.3 Multijet 16v 95cv (11-..)	DELPHI Body Computer 2
 Ypsilon (402)	ENGINE MANAGEME	1.3 Multijet 16v 95cv (11-..)	Common Rail
 Ypsilon (402)	ENGINE MANAGEME	1.3 Multijet 16v 95cv (11-..)	Marelli EDC 8F3 CF5
 Ypsilon (402)	MAINTENANCE	1.3 Multijet 16v 95cv (11-..)	Marelli EDC 8F3 CF5
 Ypsilon (402)	MAINTENANCE	1.3 Multijet 16v 95cv (11-..)	Marelli EDC 8F3 CF5
 Ypsilon (402)	PARKING HELP	0.9 8V TwinAir Metano (05-09)	Valeo 2
 Ypsilon (402)	PARKING HELP	0.9 TwinAir Turbo 85cv (05-09)	Valeo 2
 Ypsilon (402)	PARKING HELP	1.2 8v (11-..)	Valeo 2
 Ypsilon (402)	PARKING HELP	1.2 8v GPL (11-..)	Valeo 2
 Ypsilon (402)	PARKING HELP	1.3 Multijet 16v 95cv (11-..)	Valeo 2
 Ypsilon	ABS	1.2 16v	Lucas TRW ABS
 Ypsilon	ABS	1.2 8v	Lucas TRW ABS
 Ypsilon	ABS	1.3 Multijet	Lucas TRW ABS
 Ypsilon	ABS	1.4 16v	Lucas TRW ABS
 Ypsilon	ABS	1.4 8v	Lucas TRW ABS
 Ypsilon	AIRBAG	1.2 16v	Autoliv AirBag 1
 Ypsilon	AIRBAG	1.2 16v	Autoliv AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Ypsilon	AIRBAG	1.2 16v	Autoliv AirBag MY 99 (2F-2P-I-S)
 Ypsilon	AIRBAG	1.2 16v	Autoliv AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Ypsilon	AIRBAG	1.2 8v	Autoliv AirBag 1
 Ypsilon	AIRBAG	1.2 8v	Autoliv AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Ypsilon	AIRBAG	1.2 8v	Autoliv AirBag MY 99 (2F-2P-I-S)
 Ypsilon	AIRBAG	1.2 8v	Autoliv AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Ypsilon	AIRBAG	1.3 Multijet	Autoliv AirBag 1
 Ypsilon	AIRBAG	1.3 Multijet	Autoliv AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Ypsilon	AIRBAG	1.3 Multijet	Autoliv AirBag MY 99 (2F-2P-I-S)
 Ypsilon	AIRBAG	1.3 Multijet	Autoliv AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Ypsilon	AIRBAG	1.3 Multijet FAP	Autoliv AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Ypsilon	AIRBAG	1.3 Multijet FAP	Autoliv AirBag MY 99 (2F-2P-I-S)
 Ypsilon	AIRBAG	1.3 Multijet FAP	Autoliv AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Ypsilon	AIRBAG	1.4 16v	Autoliv AirBag 1
 Ypsilon	AIRBAG	1.4 16v	Autoliv AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Ypsilon	AIRBAG	1.4 16v	Autoliv AirBag MY 99 (2F-2P-I-S)
 Ypsilon	AIRBAG	1.4 16v	Autoliv AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Ypsilon	AIRBAG	1.4 8v	Autoliv AirBag 1
 Ypsilon	AIRBAG	1.4 8v	Autoliv AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Ypsilon	AIRBAG	1.4 8v	Autoliv AirBag MY 99 (2F-2P-I-S)
 Ypsilon	AIRBAG	1.4 8v	Autoliv AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Ypsilon	AUTOM. TRANSMISSI	1.2 16v	Marelli Selespeed CFC208F
 Ypsilon	AUTOM. TRANSMISSI	1.2 16v	Marelli Selespeed CFC228F
 Ypsilon	AUTOM. TRANSMISSI	1.2 8v	Marelli Selespeed CFC208F
 Ypsilon	AUTOM. TRANSMISSI	1.2 8v	Marelli Selespeed CFC228F
 Ypsilon	AUTOM. TRANSMISSI	1.3 Multijet	Marelli Selespeed CFC208F
 Ypsilon	AUTOM. TRANSMISSI	1.3 Multijet	Marelli Selespeed CFC228F
 Ypsilon	AUTOM. TRANSMISSI	1.3 Multijet FAP	Marelli Selespeed CFC208F
 Ypsilon	AUTOM. TRANSMISSI	1.3 Multijet FAP	Marelli Selespeed CFC228F
 Ypsilon	AUTOM. TRANSMISSI	1.4 16v	Marelli Selespeed CFC208F
 Ypsilon	AUTOM. TRANSMISSI	1.4 16v	Marelli Selespeed CFC228F
 Ypsilon	AUTOM. TRANSMISSI	1.4 8v	Marelli Selespeed CFC208F

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Lancia

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Ypsilon	AUTOM. TRANSMISSI	1.4 8v	Marelli Selespeed CFC228F
 Ypsilon	CHASSIS NETWORK	1.2 16v	DELPHI/Marelli Body Computer
 Ypsilon	CHASSIS NETWORK	1.2 16v	Fiat CAN Info
 Ypsilon	CHASSIS NETWORK	1.2 16v	Fiat Proxi Alignement
 Ypsilon	CHASSIS NETWORK	1.2 16v	Marelli Body Computer
 Ypsilon	CHASSIS NETWORK	1.2 16v (06-..)	Marelli Body Computer 7
 Ypsilon	CHASSIS NETWORK	1.2 8v	DELPHI/Marelli Body Computer
 Ypsilon	CHASSIS NETWORK	1.2 8v	Fiat CAN Info
 Ypsilon	CHASSIS NETWORK	1.2 8v	Fiat Proxi Alignement
 Ypsilon	CHASSIS NETWORK	1.2 8v	Marelli Body Computer
 Ypsilon	CHASSIS NETWORK	1.2 8v (06-..)	Marelli Body Computer 7
 Ypsilon	CHASSIS NETWORK	1.3 Multijet	DELPHI/Marelli Body Computer
 Ypsilon	CHASSIS NETWORK	1.3 Multijet	Fiat CAN Info
 Ypsilon	CHASSIS NETWORK	1.3 Multijet	Fiat Proxi Alignement
 Ypsilon	CHASSIS NETWORK	1.3 Multijet	Marelli Body Computer
 Ypsilon	CHASSIS NETWORK	1.3 Multijet (06-..)	Marelli Body Computer 7
 Ypsilon	CHASSIS NETWORK	1.3 Multijet FAP	DELPHI/Marelli Body Computer
 Ypsilon	CHASSIS NETWORK	1.3 Multijet FAP	Fiat CAN Info
 Ypsilon	CHASSIS NETWORK	1.3 Multijet FAP	Fiat Proxi Alignement
 Ypsilon	CHASSIS NETWORK	1.3 Multijet FAP	Marelli Body Computer
 Ypsilon	CHASSIS NETWORK	1.3 Multijet FAP (06-..)	Marelli Body Computer 7
 Ypsilon	CHASSIS NETWORK	1.4 16v	Fiat CAN Info
 Ypsilon	CHASSIS NETWORK	1.4 16v	Fiat Proxi Alignement
 Ypsilon	CHASSIS NETWORK	1.4 16v	Marelli Body Computer
 Ypsilon	CHASSIS NETWORK	1.4 16v (06-..)	Marelli Body Computer 7
 Ypsilon	CHASSIS NETWORK	1.4 8v	Fiat CAN Info
 Ypsilon	CHASSIS NETWORK	1.4 8v	Fiat Proxi Alignement
 Ypsilon	CHASSIS NETWORK	1.4 8v	Marelli Body Computer
 Ypsilon	CHASSIS NETWORK	1.4 8v (06-..)	Marelli Body Computer 7
 Ypsilon	CLIMA	1.2 16v (06-..)	Denso CLIMATE BIZON
 Ypsilon	CLIMA	1.2 16v (06-..)	
 Ypsilon	CLIMA	1.2 8v (06-..)	
 Ypsilon	CLIMA	1.2 8v (06-..)	Denso CLIMATE BIZON
 Ypsilon	CLIMA	1.3 Multijet (06-..)	
 Ypsilon	CLIMA	1.3 Multijet (06-..)	
 Ypsilon	CLIMA	1.3 Multijet FAP (06-..)	Denso CLIMATE BIZON
 Ypsilon	CLIMA	1.3 Multijet FAP (06-..)	
 Ypsilon	CLIMA	1.4 16v (06-..)	
 Ypsilon	CLIMA	1.4 16v (06-..)	Denso CLIMATE BIZON
 Ypsilon	CLIMA	1.4 8v (06-..)	
 Ypsilon	CLIMA	1.4 8v (06-..)	
 Ypsilon	DASHBOARD	1.2 16v	SIEMENS Dashboard
 Ypsilon	DASHBOARD	1.2 8v	SIEMENS Dashboard
 Ypsilon	DASHBOARD	1.3 Multijet	SIEMENS Dashboard
 Ypsilon	DASHBOARD	1.4 16v	SIEMENS Dashboard
 Ypsilon	DASHBOARD	1.4 8v	SIEMENS Dashboard
 Ypsilon	DRIVER SIDE DOOR	1.2 16v (06-..)	BITRON DRIVER DOOR
 Ypsilon	DRIVER SIDE DOOR	1.2 16v (06-..)	PROCOND DRIVER DOOR
 Ypsilon	DRIVER SIDE DOOR	1.2 16v (06-..)	UNICO/PROCOND DRIVER DOOR
 Ypsilon	DRIVER SIDE DOOR	1.2 8v (06-..)	BITRON DRIVER DOOR
 Ypsilon	DRIVER SIDE DOOR	1.2 8v (06-..)	PROCOND DRIVER DOOR
 Ypsilon	DRIVER SIDE DOOR	1.2 8v (06-..)	UNICO/PROCOND DRIVER DOOR
 Ypsilon	DRIVER SIDE DOOR	1.3 Multijet (06-..)	BITRON DRIVER DOOR
 Ypsilon	DRIVER SIDE DOOR	1.3 Multijet (06-..)	PROCOND DRIVER DOOR
 Ypsilon	DRIVER SIDE DOOR	1.3 Multijet (06-..)	UNICO/PROCOND DRIVER DOOR
 Ypsilon	DRIVER SIDE DOOR	1.3 Multijet FAP (06-..)	BITRON DRIVER DOOR
 Ypsilon	DRIVER SIDE DOOR	1.3 Multijet FAP (06-..)	PROCOND DRIVER DOOR
 Ypsilon	DRIVER SIDE DOOR	1.3 Multijet FAP (06-..)	UNICO/PROCOND DRIVER DOOR

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Lancia

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Ypsilon	DRIVER SIDE DOOR	1.4 16v (06-..)	BITRON DRIVER DOOR
 Ypsilon	DRIVER SIDE DOOR	1.4 16v (06-..)	PROCOND DRIVER DOOR
 Ypsilon	DRIVER SIDE DOOR	1.4 16v (06-..)	UNICO/PROCOND DRIVER DOOR
 Ypsilon	DRIVER SIDE DOOR	1.4 8v (06-..)	BITRON DRIVER DOOR
 Ypsilon	DRIVER SIDE DOOR	1.4 8v (06-..)	PROCOND DRIVER DOOR
 Ypsilon	DRIVER SIDE DOOR	1.4 8v (06-..)	UNICO/PROCOND DRIVER DOOR
 Ypsilon	ELECTRIC STEERING	1.2 16v	DELPHI EPS
 Ypsilon	ELECTRIC STEERING	1.2 16v	DELPHI EPS x.x
 Ypsilon	ELECTRIC STEERING	1.2 8v	DELPHI EPS
 Ypsilon	ELECTRIC STEERING	1.2 8v	DELPHI EPS x.x
 Ypsilon	ELECTRIC STEERING	1.3 Multijet	DELPHI EPS
 Ypsilon	ELECTRIC STEERING	1.3 Multijet	DELPHI EPS x.x
 Ypsilon	ELECTRIC STEERING	1.3 Multijet FAP	DELPHI EPS
 Ypsilon	ELECTRIC STEERING	1.3 Multijet FAP	DELPHI EPS x.x
 Ypsilon	ELECTRIC STEERING	1.4 16v	DELPHI EPS
 Ypsilon	ELECTRIC STEERING	1.4 16v	DELPHI EPS x.x
 Ypsilon	ELECTRIC STEERING	1.4 8v	DELPHI EPS
 Ypsilon	ELECTRIC STEERING	1.4 8v	DELPHI EPS x.x
 Ypsilon	ENGINE MANAGEME	1.2 16v	BOSCH Motronic ME7.3H4M EOBD
 Ypsilon	ENGINE MANAGEME	1.2 8v	Marelli IAW 5AF
 Ypsilon	ENGINE MANAGEME	1.2 8v	Marelli IAW 5AF NY
 Ypsilon	ENGINE MANAGEME	1.3 Multijet	Marelli 6JF CF3 Common Rail
 Ypsilon	ENGINE MANAGEME	1.3 Multijet	Marelli 8DF CF5
 Ypsilon	ENGINE MANAGEME	1.3 Multijet FAP	Marelli 6F3 CF3 Common Rail
 Ypsilon	ENGINE MANAGEME	1.4 16v	BOSCH Motronic ME7.3H4M EOBD
 Ypsilon	ENGINE MANAGEME	1.4 8v	EOBD
 Ypsilon	ENGINE MANAGEME	1.4 8v (06-..)	Marelli IAW 5SF8 CF5/EOBD
 Ypsilon	KEY ENCODE	1.2 16v	Marelli CODE Body Computer
 Ypsilon	KEY ENCODE	1.2 8v	Marelli CODE Body Computer
 Ypsilon	KEY ENCODE	1.3 Multijet	Marelli CODE Body Computer
 Ypsilon	KEY ENCODE	1.3 Multijet FAP	Marelli CODE Body Computer
 Ypsilon	KEY ENCODE	1.4 16v	Marelli CODE Body Computer
 Ypsilon	KEY ENCODE	1.4 8v	Marelli CODE Body Computer
 Ypsilon	MAINTENANCE	1.2 16v	DELPHI EPS
 Ypsilon	MAINTENANCE	1.2 16v	DELPHI EPS x.x
 Ypsilon	MAINTENANCE	1.2 16v	DELPHI EPS x.x
 Ypsilon	MAINTENANCE	1.2 16v	Marelli Selespeed CFC208F
 Ypsilon	MAINTENANCE	1.2 16v	Marelli Selespeed CFC208F
 Ypsilon	MAINTENANCE	1.2 16v	Marelli Selespeed CFC228F
 Ypsilon	MAINTENANCE	1.2 16v	SIEMENS
 Ypsilon	MAINTENANCE	1.2 16v	SIEMENS Dashboard
 Ypsilon	MAINTENANCE	1.2 16v	SIEMENS Dashboard
 Ypsilon	MAINTENANCE	1.2 16v (06-..)	
 Ypsilon	MAINTENANCE	1.2 8v	DELPHI EPS
 Ypsilon	MAINTENANCE	1.2 8v	DELPHI EPS x.x
 Ypsilon	MAINTENANCE	1.2 8v	DELPHI EPS x.x
 Ypsilon	MAINTENANCE	1.2 8v	Marelli IAW 5AF
 Ypsilon	MAINTENANCE	1.2 8v	Marelli IAW 5AF NY
 Ypsilon	MAINTENANCE	1.2 8v	Marelli Selespeed CFC208F
 Ypsilon	MAINTENANCE	1.2 8v	Marelli Selespeed CFC208F
 Ypsilon	MAINTENANCE	1.2 8v	Marelli Selespeed CFC228F
 Ypsilon	MAINTENANCE	1.2 8v	SIEMENS
 Ypsilon	MAINTENANCE	1.2 8v	SIEMENS Dashboard
 Ypsilon	MAINTENANCE	1.2 8v	SIEMENS Dashboard
 Ypsilon	MAINTENANCE	1.2 8v (06-..)	
 Ypsilon	MAINTENANCE	1.3 Multijet	DELPHI EPS
 Ypsilon	MAINTENANCE	1.3 Multijet	DELPHI EPS x.x
 Ypsilon	MAINTENANCE	1.3 Multijet	DELPHI EPS x.x

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Lancia

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Ypsilon	MAINTENANCE	1.3 Multijet	Marelli Selespeed CFC208F
 Ypsilon	MAINTENANCE	1.3 Multijet	Marelli Selespeed CFC208F
 Ypsilon	MAINTENANCE	1.3 Multijet	Marelli Selespeed CFC228F
 Ypsilon	MAINTENANCE	1.3 Multijet	SIEMENS
 Ypsilon	MAINTENANCE	1.3 Multijet	SIEMENS Dashboard
 Ypsilon	MAINTENANCE	1.3 Multijet	SIEMENS Dashboard
 Ypsilon	MAINTENANCE	1.3 Multijet (06-..)	
 Ypsilon	MAINTENANCE	1.3 Multijet FAP	DELPHI EPS
 Ypsilon	MAINTENANCE	1.3 Multijet FAP	DELPHI EPS x.x
 Ypsilon	MAINTENANCE	1.3 Multijet FAP	DELPHI EPS x.x
 Ypsilon	MAINTENANCE	1.3 Multijet FAP	Marelli 6F3 CF3 Common Rail
 Ypsilon	MAINTENANCE	1.3 Multijet FAP	Marelli 6F3 CF3 Common Rail
 Ypsilon	MAINTENANCE	1.3 Multijet FAP	Marelli 6F3 CF3 Common Rail
 Ypsilon	MAINTENANCE	1.3 Multijet FAP	Marelli 6F3 CF3 Common Rail
 Ypsilon	MAINTENANCE	1.3 Multijet FAP	Marelli Selespeed CFC208F
 Ypsilon	MAINTENANCE	1.3 Multijet FAP	Marelli Selespeed CFC208F
 Ypsilon	MAINTENANCE	1.3 Multijet FAP	Marelli Selespeed CFC228F
 Ypsilon	MAINTENANCE	1.3 Multijet FAP	SIEMENS
 Ypsilon	MAINTENANCE	1.3 Multijet FAP (06-..)	
 Ypsilon	MAINTENANCE	1.4 16v	DELPHI EPS
 Ypsilon	MAINTENANCE	1.4 16v	DELPHI EPS x.x
 Ypsilon	MAINTENANCE	1.4 16v	DELPHI EPS x.x
 Ypsilon	MAINTENANCE	1.4 16v	Marelli Selespeed CFC208F
 Ypsilon	MAINTENANCE	1.4 16v	Marelli Selespeed CFC208F
 Ypsilon	MAINTENANCE	1.4 16v	Marelli Selespeed CFC228F
 Ypsilon	MAINTENANCE	1.4 16v	SIEMENS
 Ypsilon	MAINTENANCE	1.4 16v	SIEMENS Dashboard
 Ypsilon	MAINTENANCE	1.4 16v	SIEMENS Dashboard
 Ypsilon	MAINTENANCE	1.4 16v (06-..)	
 Ypsilon	MAINTENANCE	1.4 8v	DELPHI EPS
 Ypsilon	MAINTENANCE	1.4 8v	DELPHI EPS x.x
 Ypsilon	MAINTENANCE	1.4 8v	DELPHI EPS x.x
 Ypsilon	MAINTENANCE	1.4 8v	Marelli Selespeed CFC208F
 Ypsilon	MAINTENANCE	1.4 8v	Marelli Selespeed CFC208F
 Ypsilon	MAINTENANCE	1.4 8v	Marelli Selespeed CFC228F
 Ypsilon	MAINTENANCE	1.4 8v	SIEMENS
 Ypsilon	MAINTENANCE	1.4 8v	SIEMENS Dashboard
 Ypsilon	MAINTENANCE	1.4 8v	SIEMENS Dashboard
 Ypsilon	MAINTENANCE	1.4 8v (06-..)	
 Ypsilon	MAINTENANCE	1.4 8v (06-..)	Marelli IAW 5SF8 CF5/EOBD
 Ypsilon	MAINTENANCE	1.4 8v (06-..)	Marelli IAW 5SF8 CF5/EOBD
 Ypsilon	MAINTENANCE	1.4 8v (06-..)	Marelli IAW 5SF8 CF5/EOBD
 Ypsilon	MAINTENANCE	1.4 8v (06-..)	Marelli IAW 5SF8 CF5/EOBD
 Ypsilon	MAINTENANCE	1.4 8v (06-..)	Marelli IAW 5SF8 CF5/EOBD
 Ypsilon	MAINTENANCE	1.4 8v (06-..)	Marelli IAW 5SF8 CF5/EOBD
 Ypsilon	MAINTENANCE	1.4 8v (06-..)	Marelli IAW 5SF8 CF5/EOBD
 Ypsilon	MAINTENANCE	1.4 8v (06-..)	Marelli IAW 5SF8 CF5/EOBD
 Ypsilon	MAINTENANCE	1.4 8v (06-..)	Marelli IAW 5SF8 CF5/EOBD
 Ypsilon	MAINTENANCE	1.4 8v (06-..)	Marelli IAW 5SF8 CF5/EOBD
 Ypsilon	MAINTENANCE	1.4 8v (06-..)	Marelli IAW 5SF8 CF5/EOBD
 Ypsilon	MAINTENANCE	1.4 8v (06-..)	Marelli IAW 5SF8 CF5/EOBD
 Ypsilon	MAINTENANCE	1.4 8v (06-..)	Marelli IAW 5SF8 CF5/EOBD
 Ypsilon	MAINTENANCE	1.4 8v (06-..)	Marelli IAW 5SF8 CF5/EOBD
 Ypsilon	MAINTENANCE	1.4 8v (06-..)	Marelli IAW 5SF8 CF5/EOBD
 Ypsilon	MAINTENANCE	1.4 8v (06-..)	Marelli IAW 5SF8 CF5/EOBD
 Ypsilon	MAINTENANCE	1.4 8v (06-..)	Marelli IAW 5SF8 CF5/EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Lancia

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Ypsilon	MAINTENANCE	1.4 8v (06-..)	Marelli IAW 5SF8 CF5/EOBD
 Ypsilon	PARKING HELP	1.2 16v (06-..)	
 Ypsilon	PARKING HELP	1.2 8v (06-..)	
 Ypsilon	PARKING HELP	1.3 Multijet (06-..)	
 Ypsilon	PARKING HELP	1.3 Multijet FAP (06-..)	
 Ypsilon	PARKING HELP	1.4 16v (06-..)	
 Ypsilon	PARKING HELP	1.4 8v (06-..)	
 Ypsilon	PASS. SIDE DOOR	1.2 16v (06-..)	BITRON PASSENGER DOOR
 Ypsilon	PASS. SIDE DOOR	1.2 16v (06-..)	PROCOND PASSENGER DOOR
 Ypsilon	PASS. SIDE DOOR	1.2 8v (06-..)	BITRON PASSENGER DOOR
 Ypsilon	PASS. SIDE DOOR	1.2 8v (06-..)	PROCOND PASSENGER DOOR
 Ypsilon	PASS. SIDE DOOR	1.3 Multijet (06-..)	BITRON PASSENGER DOOR
 Ypsilon	PASS. SIDE DOOR	1.3 Multijet (06-..)	PROCOND PASSENGER DOOR
 Ypsilon	PASS. SIDE DOOR	1.3 Multijet FAP (06-..)	BITRON PASSENGER DOOR
 Ypsilon	PASS. SIDE DOOR	1.3 Multijet FAP (06-..)	PROCOND PASSENGER DOOR
 Ypsilon	PASS. SIDE DOOR	1.4 16v (06-..)	BITRON PASSENGER DOOR
 Ypsilon	PASS. SIDE DOOR	1.4 16v (06-..)	PROCOND PASSENGER DOOR
 Ypsilon	PASS. SIDE DOOR	1.4 8v (06-..)	BITRON PASSENGER DOOR
 Ypsilon	PASS. SIDE DOOR	1.4 8v (06-..)	PROCOND PASSENGER DOOR
 Ypsilon	SERVICE LIGHT RES	1.2 16v	SIEMENS
 Ypsilon	SERVICE LIGHT RES	1.2 8v	SIEMENS
 Ypsilon	SERVICE LIGHT RES	1.3 Multijet	SIEMENS
 Ypsilon	SERVICE LIGHT RES	1.3 Multijet FAP	SIEMENS
 Ypsilon	SERVICE LIGHT RES	1.4 16v	SIEMENS
 Ypsilon	SERVICE LIGHT RES	1.4 8v	SIEMENS
 Ypsilon	VISUAL./TELEMATIC	1.2 16v	Marelli Connect 3
 Ypsilon	VISUAL./TELEMATIC	1.2 8v	Marelli Connect 3
 Ypsilon	VISUAL./TELEMATIC	1.3 Multijet	Marelli Connect 3
 Ypsilon	VISUAL./TELEMATIC	1.3 Multijet FAP	Marelli Connect 3
 Ypsilon	VISUAL./TELEMATIC	1.4 16v	Marelli Connect 3
 Ypsilon	VISUAL./TELEMATIC	1.4 8v	Marelli Connect 3
 Z	ABS	2.0 16v	BENDIX ABS
 Z	ABS	2.0 JTD	BENDIX ABS
 Z	ABS	2.0 T	BENDIX ABS
 Z	ABS	2.1 TD	BENDIX ABS
 Z	ENGINE MANAGEME	2.0 16v (01-..)	EOBD
 Z	ENGINE MANAGEME	2.0 JTD RHZ (.-00)	BOSCH EDC 15 C2 Common Rail
 Z	ENGINE MANAGEME	2.0 T RGX	BOSCH Motronic MP3.2
 Z	ENGINE MANAGEME	2.1 TD P8C	LUCAS Diesel EPIC
 Z	MAINTENANCE	2.0 JTD (98-..)	MANUAL
 Z	MAINTENANCE	2.0 T (98-..)	MANUAL
 Z	MAINTENANCE	2.1 TD (98-..)	MANUAL
 Z	SERVICE LIGHT RES	2.0 JTD (98-..)	MANUAL
 Z	SERVICE LIGHT RES	2.0 T (98-..)	MANUAL
 Z	SERVICE LIGHT RES	2.0 T (98-..)	MANUAL
 Z	SERVICE LIGHT RES	2.1 TD (98-..)	MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Land Rover

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Defender 110	ENGINE MANAGEME	2.5 TD TD5 (04-..)	EOBD
 Defender 90	DASHBOARD	2.4 TD (04-..)	
 Defender 90	ENGINE MANAGEME	2.4 TD TD4 (04-..)	Common Rail
 Defender 90	ENGINE MANAGEME	2.5 TD TD5 (04-..)	EOBD
 Discovery 3	ABS + TRACT. CONT	2.7 TD V6 (04-..)	
 Discovery 3	ABS + TRACT. CONT	4.4 V8 (04-..)	
 Discovery 3	AIRBAG	2.7 TD V6 (04-..)	
 Discovery 3	AIRBAG	4.4 V8 (04-..)	
 Discovery 3	AUTOM. TRANSMISSI	2.7 TD V6 (04-..)	A/T
 Discovery 3	AUTOM. TRANSMISSI	4.4 V8 (04-..)	A/T
 Discovery 3	CHASSIS NETWORK	2.7 TD V6 (04-..)	
 Discovery 3	CHASSIS NETWORK	4.4 V8 (04-..)	
 Discovery 3	CLIMA	2.7 TD V6 (04-..)	Clima 1
 Discovery 3	CLIMA	2.7 TD V6 (04-..)	Clima 2
 Discovery 3	CLIMA	4.4 V8 (04-..)	Clima 1
 Discovery 3	CLIMA	4.4 V8 (04-..)	Clima 2
 Discovery 3	DASHBOARD	2.7 TD V6 (04-..)	
 Discovery 3	DASHBOARD	4.4 V8 (04-..)	
 Discovery 3	ELECTRIC STEERING	2.7 TD V6 (04-..)	
 Discovery 3	ELECTRIC STEERING	4.4 V8 (04-..)	
 Discovery 3	ENGINE MANAGEME	2.7 TD V6 (04-..)	
 Discovery 3	ENGINE MANAGEME	4.4 V8 (04-..)	EOBD
 Discovery 3	MAINTENANCE	2.7 TD V6 (04-..)	
 Discovery 3	MAINTENANCE	4.4 V8 (04-..)	
 Discovery 3	SERVICE LIGHT RES	2.7 TD V6 (04-..)	
 Discovery 3	SERVICE LIGHT RES	4.4 V8 (04-..)	
 Discovery	ABS	2.5 TD (99-..)	Wabco ABS
 Discovery	ABS	V8 i (99-..)	Wabco ABS
 Discovery	ENGINE MANAGEME	2.5 TD TD5 (04-..)	EOBD
 Discovery	ENGINE MANAGEME	V8 i (01-..)	EOBD
 Freelander 2	ABS	2.2 S4 TD4 (06-..)	
 Freelander 2	ABS	3.2 V6 (06-..)	
 Freelander 2	AIRBAG	2.2 S4 TD4 (06-..)	
 Freelander 2	AIRBAG	3.2 V6 (06-..)	
 Freelander 2	AUTOM. TRANSMISSI	2.2 S4 TD4 (06-..)	
 Freelander 2	AUTOM. TRANSMISSI	3.2 V6 (06-..)	
 Freelander 2	CHASSIS NETWORK	2.2 S4 TD4 (06-..)	
 Freelander 2	CHASSIS NETWORK	3.2 V6 (06-..)	
 Freelander 2	CLIMA	2.2 S4 TD4 (06-..)	
 Freelander 2	CLIMA	3.2 V6 (06-..)	
 Freelander 2	DASHBOARD	2.2 S4 TD4 (06-..)	IC
 Freelander 2	DASHBOARD	3.2 V6 (06-..)	IC
 Freelander 2	DRIVER SIDE DOOR	2.2 S4 TD4 (06-..)	DRIVER DOOR
 Freelander 2	DRIVER SIDE DOOR	3.2 V6 (06-..)	DRIVER DOOR
 Freelander 2	ELECTRIC STEERING	2.2 S4 TD4 (06-..)	
 Freelander 2	ELECTRIC STEERING	3.2 V6 (06-..)	
 Freelander 2	ENGINE MANAGEME	2.2 S4 TD4 (06-..)	
 Freelander 2	GEARBOX MANAGEM	2.2 S4 TD4 (06-..)	
 Freelander 2	GEARBOX MANAGEM	3.2 V6 (06-..)	
 Freelander 2	HEADLIGHT LEVEL	2.2 S4 TD4 (06-..)	
 Freelander 2	HEADLIGHT LEVEL	3.2 V6 (06-..)	
Freelander 2	MAINTENANCE	2.2 S4 TD4 (06-..)	
Freelander 2	MAINTENANCE	2.2 S4 TD4 (06-..)	
Freelander 2	MAINTENANCE	2.2 S4 TD4 (06-..)	
Freelander 2	MAINTENANCE	2.2 S4 TD4 (06-..)	
Freelander 2	MAINTENANCE	2.2 S4 TD4 (06-..)	
Freelander 2	MAINTENANCE	2.2 S4 TD4 (06-..)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Land Rover

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Freelander 2	MAINTENANCE	3.2 V6 (06-..)	
 Freelander 2	MAINTENANCE	3.2 V6 (06-..)	
 Freelander 2	PASS. SIDE DOOR	2.2 S4 TD4 (06-..)	PASSENGER DOOR
 Freelander 2	PASS. SIDE DOOR	3.2 V6 (06-..)	PASSENGER DOOR
 Freelander 2	STEERING COLUMN	2.2 S4 TD4 (06-..)	
 Freelander 2	STEERING COLUMN	3.2 V6 (06-..)	
 Freelander 2	SUSPENSION CONTR	2.2 S4 TD4 (06-..)	
 Freelander 2	SUSPENSION CONTR	3.2 V6 (06-..)	
 Freelander	ABS	1.8 i (01-..)	ATE ABS
 Freelander	ABS	1.8 i (98-00)	Wabco ABS
 Freelander	ABS	2.0 TD (98-00)	Wabco ABS
 Freelander	ABS	2.0 TD4 (01-..)	ATE ABS
 Freelander	AIRBAG	1.8 i (98-00)	SRS
 Freelander	AIRBAG	2.0 TD (98-00)	SRS
 Freelander	ENGINE MANAGEME	1.8 i (01-..)	EOBD
 Freelander	ENGINE MANAGEME	1.8 i K series (...99)	ROVER MEMS mpi
 Freelander	ENGINE MANAGEME	2.0 TD (...00)	BOSCH EDC MSA
 Freelander	ENGINE MANAGEME	2.0 TD TD4 (04-..)	EOBD
 Freelander	ENGINE MANAGEME	2.0 TD4 M47 (01-..)	BOSCH EDC 15 C4 Common Rail DDE4.0
 Range Rover Sport	ABS + TRACT. CONT	2.7 TD V6 (05-..)	DIAG 1
 Range Rover Sport	ABS + TRACT. CONT	2.7 TD V6 (05-..)	DIAG 2
 Range Rover Sport	ABS + TRACT. CONT	3.6 TD V8 (05-..)	DIAG 1
 Range Rover Sport	ABS + TRACT. CONT	3.6 TD V8 (05-..)	DIAG 2
 Range Rover Sport	ABS + TRACT. CONT	4.2 V8 (05-..)	DIAG 1
 Range Rover Sport	ABS + TRACT. CONT	4.2 V8 (05-..)	DIAG 2
 Range Rover Sport	ABS + TRACT. CONT	4.4 V8 (05-..)	DIAG 1
 Range Rover Sport	ABS + TRACT. CONT	4.4 V8 (05-..)	DIAG 2
 Range Rover Sport	AIRBAG	2.7 TD V6 (05-..)	AirBag
 Range Rover Sport	AIRBAG	3.6 TD V8 (05-..)	AirBag
 Range Rover Sport	AIRBAG	4.2 V8 (05-..)	AirBag
 Range Rover Sport	AIRBAG	4.4 V8 (05-..)	AirBag
 Range Rover Sport	AUTOM. TRANSMISSI	2.7 TD V6 (05-..)	A/T
 Range Rover Sport	AUTOM. TRANSMISSI	3.6 TD V8 (05-..)	A/T
 Range Rover Sport	AUTOM. TRANSMISSI	4.2 V8 (05-..)	A/T
 Range Rover Sport	AUTOM. TRANSMISSI	4.4 V8 (05-..)	A/T
 Range Rover Sport	ENGINE MANAGEME	2.7 TD V6 (05-..)	BOSCH EDC Common Rail
 Range Rover Sport	ENGINE MANAGEME	3.6 TD V8 (05-..)	EOBD
 Range Rover Sport	ENGINE MANAGEME	4.2 V8 (05-..)	EOBD
 Range Rover Sport	ENGINE MANAGEME	4.4 V8 (05-..)	EOBD
 Range Rover Sport	MAINTENANCE	2.7 TD V6 (05-..)	
 Range Rover Sport	MAINTENANCE	3.6 TD V8 (05-..)	
 Range Rover Sport	MAINTENANCE	4.2 V8 (05-..)	
 Range Rover Sport	MAINTENANCE	4.4 V8 (05-..)	
 Range Rover Sport	SERVICE LIGHT RES	2.7 TD V6 (05-..)	
 Range Rover Sport	SERVICE LIGHT RES	3.6 TD V8 (05-..)	
 Range Rover Sport	SERVICE LIGHT RES	4.2 V8 (05-..)	
 Range Rover Sport	SERVICE LIGHT RES	4.4 V8 (05-..)	
 Range Rover	ABS + TRACT. CONT	3.6 TD V8 (02-09)	
 Range Rover	ABS + TRACT. CONT	3.6 TD V8 (10-..)	
 Range Rover	ABS + TRACT. CONT	4.4 Td V8 (02-09)	
 Range Rover	ABS + TRACT. CONT	4.4 Td V8 (10-..)	
 Range Rover	ABS + TRACT. CONT	5.0 V8 (02-09)	
 Range Rover	ABS + TRACT. CONT	5.0 V8 (10-..)	
 Range Rover	AIRBAG	3.6 TD V8 (02-09)	
 Range Rover	AIRBAG	3.6 TD V8 (10-..)	
 Range Rover	AIRBAG	4.4 Td V8 (02-09)	
 Range Rover	AIRBAG	4.4 Td V8 (10-..)	
 Range Rover	AIRBAG	5.0 V8 (02-09)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Land Rover

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Range Rover	AIRBAG	5.0 V8 (10-..)	
 Range Rover	AUTOM. TRANSMISSI	3.6 TD V8 (02-09)	
 Range Rover	AUTOM. TRANSMISSI	3.6 TD V8 (10-..)	
 Range Rover	AUTOM. TRANSMISSI	4.4 Td V8 (02-09)	
 Range Rover	AUTOM. TRANSMISSI	4.4 Td V8 (10-..)	
 Range Rover	AUTOM. TRANSMISSI	5.0 V8 (02-09)	
 Range Rover	AUTOM. TRANSMISSI	5.0 V8 (10-..)	
 Range Rover	CENTRAL LOCKING	3.6 TD V8 (10-..)	
 Range Rover	CENTRAL LOCKING	4.4 Td V8 (10-..)	
 Range Rover	CENTRAL LOCKING	5.0 V8 (10-..)	
 Range Rover	CHASSIS MANAGEM	3.6 TD V8 (10-..)	Pneumatic control / sunroof
 Range Rover	CHASSIS MANAGEM	4.4 Td V8 (10-..)	Pneumatic control / sunroof
 Range Rover	CHASSIS MANAGEM	5.0 V8 (10-..)	Pneumatic control / sunroof
 Range Rover	CHASSIS NETWORK	3.6 TD V8 (10-..)	Locks/mirrors
 Range Rover	CHASSIS NETWORK	4.4 Td V8 (10-..)	Locks/mirrors
 Range Rover	CHASSIS NETWORK	5.0 V8 (10-..)	Locks/mirrors
 Range Rover	CLIMA	3.6 TD V8 (10-..)	
 Range Rover	CLIMA	4.4 Td V8 (10-..)	
 Range Rover	CLIMA	5.0 V8 (10-..)	
 Range Rover	DASHBOARD	3.6 TD V8 (02-09)	
 Range Rover	DASHBOARD	3.6 TD V8 (10-..)	
 Range Rover	DASHBOARD	4.4 Td V8 (02-09)	
 Range Rover	DASHBOARD	4.4 Td V8 (10-..)	
 Range Rover	DASHBOARD	5.0 V8 (02-09)	
 Range Rover	DASHBOARD	5.0 V8 (10-..)	
 Range Rover	DRIVER SEAT CONT	3.6 TD V8 (10-..)	
 Range Rover	DRIVER SEAT CONT	4.4 Td V8 (10-..)	
 Range Rover	DRIVER SEAT CONT	5.0 V8 (10-..)	
 Range Rover	ELECTRIC STEERING	3.6 TD V8 (02-09)	
 Range Rover	ELECTRIC STEERING	3.6 TD V8 (10-..)	
 Range Rover	ELECTRIC STEERING	4.4 Td V8 (02-09)	
 Range Rover	ELECTRIC STEERING	4.4 Td V8 (10-..)	
 Range Rover	ELECTRIC STEERING	5.0 V8 (02-09)	
 Range Rover	ELECTRIC STEERING	5.0 V8 (10-..)	
 Range Rover	ELECTRONIC TRIM	3.6 TD V8 (10-..)	
 Range Rover	ELECTRONIC TRIM	4.4 Td V8 (10-..)	
 Range Rover	ELECTRONIC TRIM	5.0 V8 (10-..)	
 Range Rover	ENGINE MANAGEME	3.6 TD V8 (10-..)	
 Range Rover	ENGINE MANAGEME	3.6 TD V8 HSE (02-09)	
 Range Rover	GEARBOX MANAGEM	3.6 TD V8 (10-..)	
 Range Rover	GEARBOX MANAGEM	4.4 Td V8 (10-..)	
 Range Rover	GEARBOX MANAGEM	5.0 V8 (10-..)	
 Range Rover	HEADLIGHT LEVEL	3.6 TD V8 (10-..)	
 Range Rover	HEADLIGHT LEVEL	4.4 Td V8 (10-..)	
 Range Rover	HEADLIGHT LEVEL	5.0 V8 (10-..)	
 Range Rover	MAINTENANCE	3.6 TD V8 (03-..)	
 Range Rover	MAINTENANCE	3.6 TD V8 (10-..)	
 Range Rover	MAINTENANCE	3.6 TD V8 (10-..)	
 Range Rover	MAINTENANCE	3.6 TD V8 (10-..)	
 Range Rover	MAINTENANCE	3.6 TD V8 HSE (02-09)	
 Range Rover	MAINTENANCE	4.4 Td V8 (03-..)	
 Range Rover	MAINTENANCE	4.4 Td V8 (10-..)	
 Range Rover	MAINTENANCE	4.4 Td V8 (10-..)	
 Range Rover	MAINTENANCE	4.4 Td V8 (10-..)	
 Range Rover	MAINTENANCE	5.0 V8 (10-..)	
 Range Rover	MAINTENANCE	5.0 V8 (10-..)	
 Range Rover	MAINTENANCE	5.0 V8 (10-..)	
 Range Rover	MAINTENANCE	5.0 V8 (10-..)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Land Rover

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Range Rover	PARK.BRAKE	3.6 TD V8 (10-..)	
 Range Rover	PARK.BRAKE	3.6 TD V8 (10-..)	
 Range Rover	PARK.BRAKE	4.4 Td V8 (10-..)	
 Range Rover	PARK.BRAKE	4.4 Td V8 (10-..)	
 Range Rover	PARK.BRAKE	5.0 V8 (10-..)	
 Range Rover	PARK.BRAKE	5.0 V8 (10-..)	
 Range Rover	PARKING HELP	3.6 TD V8 (10-..)	
 Range Rover	PARKING HELP	4.4 Td V8 (10-..)	
 Range Rover	PARKING HELP	5.0 V8 (10-..)	
 Range Rover	SERVICE LIGHT RES	3.6 TD V8 (03-..)	
 Range Rover	SERVICE LIGHT RES	4.4 Td V8 (03-..)	
 Range Rover	SERVICE LIGHT RES	5.0 V8 (10-..)	
 Range Rover	STEERING COLUMN	3.6 TD V8 (10-..)	
 Range Rover	STEERING COLUMN	4.4 Td V8 (10-..)	
 Range Rover	STEERING COLUMN	5.0 V8 (10-..)	
 Range Rover	SUSPENSION CONTR	3.6 TD V8 (10-..)	
 Range Rover	SUSPENSION CONTR	4.4 Td V8 (10-..)	
 Range Rover	SUSPENSION CONTR	5.0 V8 (10-..)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

LDV

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Bodybuild SVO	ENGINE MANAGEME	2.4 Duratorq	DELPHI EPIC DI
 Convoy Van	ENGINE MANAGEME	2.4 Duratorq	DELPHI EPIC DI
 Minibus	ENGINE MANAGEME	2.4 Duratorq	DELPHI EPIC DI
 Pilot	ENGINE MANAGEME	2.4 Duratorq	DELPHI EPIC DI
 School Bus	ENGINE MANAGEME	2.4 Duratorq	DELPHI EPIC DI

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Lexus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 GS 300	ENGINE MANAGEME	3.0 6Cyl 157kw (01-..)	EOBD
 GS 430	ENGINE MANAGEME	4.3 V8 208kw (01-..)	EOBD
 IS 200	ENGINE MANAGEME	2.0 6Cyl 114kw (01-..)	EOBD
 IS	MAINTENANCE	220D	
 IS	SERVICE LIGHT RES	220D	
 LS 430	ENGINE MANAGEME	4.3 V8 201kw (01-..)	EOBD
 RX 300	ABS	3.0 150kw (04-..)	ABS
 RX 300	AIRBAG	3.0 150kw (04-..)	AirBag
 RX 300	CENTRAL LOCKING	3.0 150kw (04-..)	Master Switch
 RX 300	CHASSIS NETWORK	3.0 150kw (04-..)	Body Computer
 RX 300	CLIMA	3.0 150kw (04-..)	Clima
 RX 300	CONV. TOP/SUNROO	3.0 150kw (04-..)	Roof
 RX 300	CRUISE CONTROL	3.0 150kw (04-..)	Cruise Control
 RX 300	DASHBOARD	3.0 150kw (04-..)	Combinator Meter
 RX 300	ENGINE MANAGEME	3.0 150kw (04-..)	MPI
 RX 300	HATCHBACK DOOR E	3.0 150kw (04-..)	Back door
 RX 300	IMMOBILIZER	3.0 150kw (04-..)	Immobilizer
 RX 300	LEFT MIRROR	3.0 150kw (04-..)	Mirror SX
 RX 300	MAINTENANCE	3.0 150kw (04-..)	Combinator Meter
 RX 300	MAINTENANCE	3.0 150kw (04-..)	MPI
 RX 300	RIGHT MIRROR	3.0 150kw (04-..)	Mirror DX
 RX 300	SUSPENSION CONTR	3.0 150kw (04-..)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Lotus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Elan	ENGINE MANAGEME	1.6 AXE1MT (..-91)	ISUZU-GM Multec MPI MANUAL
 Elan	MAINTENANCE	1.6 AXE1MT (..-91)	ISUZU-GM Multec MPI MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mazda

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 121	ENGINE MANAGEME	1.3 (01-..)	EOBD
 121	ENGINE MANAGEME	1.3 16v (01-..)	EOBD
 2 MY 06	ABS	1.3 16v (06-..)	
 2 MY 06	ABS	1.4 CD 16v (06-..)	
 2 MY 06	ABS	1.5 16v (06-..)	
 2 MY 06	ABS	1.6 CD 16v (06-..)	
 2 MY 06	AIRBAG	1.3 16v (06-..)	
 2 MY 06	AIRBAG	1.4 CD 16v (06-..)	
 2 MY 06	AIRBAG	1.5 16v (06-..)	
 2 MY 06	AIRBAG	1.6 CD 16v (06-..)	
 2 MY 06	ELECTRIC STEERING	1.3 16v (06-..)	
 2 MY 06	ELECTRIC STEERING	1.4 CD 16v (06-..)	
 2 MY 06	ELECTRIC STEERING	1.5 16v (06-..)	
 2 MY 06	ELECTRIC STEERING	1.6 CD 16v (06-..)	
 2 MY 06	ENGINE MANAGEME	1.3 16v (06-..)	EOBD
 2 MY 06	ENGINE MANAGEME	1.4 CD 16v (06-..)	EOBD
 2 MY 06	ENGINE MANAGEME	1.5 16v (06-..)	EOBD
 2 MY 06	ENGINE MANAGEME	1.6 CD 16v (06-..)	EOBD
 2	ENGINE MANAGEME	1.2 16v 1.25 MZI (...02)	EOBD
 2	ENGINE MANAGEME	1.4 16v 1.4 MZI (...02)	EOBD
 2	ENGINE MANAGEME	1.6 16v 1.6 MZI (...02)	EOBD
 3 MY 09	ABS + TRACT. CONT	1.6	ABS
 3 MY 09	ABS + TRACT. CONT	1.6 16v Bifuel	ABS
 3 MY 09	ABS + TRACT. CONT	1.6 CD 16v	ABS
 3 MY 09	ABS + TRACT. CONT	2.0	ABS
 3 MY 09	ABS + TRACT. CONT	2.2 CD 16v 150cv	ABS
 3 MY 09	ABS + TRACT. CONT	2.2 CD 16v 185cv	ABS
 3 MY 09	ABS + TRACT. CONT	2.3 MPS	ABS
 3 MY 09	ABS + TRACT. CONT	2.5	ABS
 3 MY 09	AIRBAG	1.6	RCM
 3 MY 09	AIRBAG	1.6 16v Bifuel	RCM
 3 MY 09	AIRBAG	1.6 CD 16v	RCM
 3 MY 09	AIRBAG	2.0	RCM
 3 MY 09	AIRBAG	2.2 CD 16v 150cv	RCM
 3 MY 09	AIRBAG	2.2 CD 16v 185cv	RCM
 3 MY 09	AIRBAG	2.3 MPS	RCM
 3 MY 09	AIRBAG	2.5	RCM
 3 MY 09	CHASSIS NETWORK	1.6	GEM
 3 MY 09	CHASSIS NETWORK	1.6 16v Bifuel	GEM
 3 MY 09	CHASSIS NETWORK	1.6 CD 16v	GEM
 3 MY 09	CHASSIS NETWORK	2.0	GEM
 3 MY 09	CHASSIS NETWORK	2.2 CD 16v 150cv	GEM
 3 MY 09	CHASSIS NETWORK	2.2 CD 16v 185cv	GEM
 3 MY 09	CHASSIS NETWORK	2.3 MPS	GEM
 3 MY 09	CHASSIS NETWORK	2.5	GEM
 3 MY 09	CLIMA	1.6	EATC
 3 MY 09	CLIMA	1.6 16v Bifuel	EATC
 3 MY 09	CLIMA	1.6 CD 16v	EATC
 3 MY 09	CLIMA	2.0	EATC
 3 MY 09	CLIMA	2.2 CD 16v 150cv	EATC
 3 MY 09	CLIMA	2.2 CD 16v 185cv	EATC
 3 MY 09	CLIMA	2.3 MPS	EATC
 3 MY 09	CLIMA	2.5	EATC
 3 MY 09	DASHBOARD	1.6	IC
 3 MY 09	DASHBOARD	1.6 16v Bifuel	IC
 3 MY 09	DASHBOARD	1.6 CD 16v	IC
 3 MY 09	DASHBOARD	2.0	IC
 3 MY 09	DASHBOARD	2.2 CD 16v 150cv	IC

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mazda

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 3 MY 09	DASHBOARD	2.2 CD 16v 185cv	IC
 3 MY 09	DASHBOARD	2.3 MPS	IC
 3 MY 09	DASHBOARD	2.5	IC
 3 MY 09	DIESEL ADDITION	1.6 CD 16v	FACM
 3 MY 09	ENGINE MANAGEME	1.6	EOBD
 3 MY 09	ENGINE MANAGEME	1.6 16v Bifuel	EOBD
 3 MY 09	ENGINE MANAGEME	1.6 CD 16v	PCM
 3 MY 09	ENGINE MANAGEME	2.0	EOBD
 3 MY 09	ENGINE MANAGEME	2.2 16v D	DENSO EDC Common Rail
 3 MY 09	ENGINE MANAGEME	2.2 CD 16v 150cv	EOBD
 3 MY 09	ENGINE MANAGEME	2.2 CD 16v 185cv	EOBD
 3 MY 09	ENGINE MANAGEME	2.3 MPS	EOBD
 3 MY 09	ENGINE MANAGEME	2.5	EOBD
 3 MY 09	MAINTENANCE	2.2 16v D	DENSO EDC Common Rail
 3 MY 09	MAINTENANCE	2.2 16v D	DENSO EDC Common Rail
 3 MY 09	MAINTENANCE	2.2 16v D	DENSO EDC Common Rail
 3 MY 09	MAINTENANCE	2.2 16v D	DENSO EDC Common Rail
 3 MY 09	MAINTENANCE	2.2 16v D	DENSO EDC Common Rail
 3	ABS + TRACT. CONT	1.4	ABS
 3	ABS + TRACT. CONT	1.6	ABS
 3	ABS + TRACT. CONT	1.6 D	ABS
 3	ABS + TRACT. CONT	2.0	ABS
 3	ABS + TRACT. CONT	2.0 D	ABS
 3	ABS + TRACT. CONT	2.3	ABS
 3	AIRBAG	1.4	RCM
 3	AIRBAG	1.6	RCM
 3	AIRBAG	1.6 D	RCM
 3	AIRBAG	2.0	RCM
 3	AIRBAG	2.0 D	RCM
 3	AIRBAG	2.3	RCM
 3	CHASSIS NETWORK	1.4	GEM
 3	CHASSIS NETWORK	1.6	GEM
 3	CHASSIS NETWORK	1.6 D	GEM
 3	CHASSIS NETWORK	2.0	GEM
 3	CHASSIS NETWORK	2.0 D	GEM
 3	CHASSIS NETWORK	2.3	GEM
 3	CLIMA	1.4	EATC
 3	CLIMA	1.6	EATC
 3	CLIMA	1.6 D	EATC
 3	CLIMA	2.0	EATC
 3	CLIMA	2.0 D	EATC
 3	CLIMA	2.3	EATC
 3	DASHBOARD	1.4	IC
 3	DASHBOARD	1.6	IC
 3	DASHBOARD	1.6 D	IC
 3	DASHBOARD	2.0	IC
 3	DASHBOARD	2.0 D	IC
 3	DASHBOARD	2.3	IC
 3	DIESEL ADDITION	1.6 D	FACM
 3	ELECTRIC STEERING	1.4	EPS
 3	ELECTRIC STEERING	1.6	EPS
 3	ELECTRIC STEERING	1.6 D	EPS
 3	ELECTRIC STEERING	2.0	EPS
 3	ELECTRIC STEERING	2.0 D	EPS
 3	ELECTRIC STEERING	2.3	EPS
 3	ENGINE MANAGEME	1.4	EOBD
 3	ENGINE MANAGEME	1.6	EOBD
 3	ENGINE MANAGEME	1.6 D	PCM

Systems supported by ECUREADER / ECUdecoder (up to V6.90)

CARS

Mazda

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 3	ENGINE MANAGEME	2.0	EOBD
 3	ENGINE MANAGEME	2.0 MZR CD 120cv	DENSO EDC RF5P Common Rail
 3	ENGINE MANAGEME	2.0 MZR CD 136cv	EOBD
 3	ENGINE MANAGEME	2.0 MZR CD 143cv	DENSO EDC Common Rail
 3	ENGINE MANAGEME	2.0 MZR CD 143cv FAP	DENSO EDC Common Rail
 3	ENGINE MANAGEME	2.3	EOBD
 3	MAINTENANCE	2.0 MZR CD 143cv FAP	DENSO EDC Common Rail
 3	MAINTENANCE	2.0 MZR CD 143cv FAP	DENSO EDC Common Rail
 3	MAINTENANCE	2.0 MZR CD 143cv FAP	DENSO EDC Common Rail
 3	MAINTENANCE	2.0 MZR CD 143cv FAP	DENSO EDC Common Rail
 3	MAINTENANCE	2.0 MZR CD 143cv FAP	DENSO EDC Common Rail
 323	ENGINE MANAGEME	1.3 16v B3 (89-94)	Mazda EGI MANUAL
 323	ENGINE MANAGEME	1.3 B3 (89-94)	Mazda EGI MANUAL
 323	ENGINE MANAGEME	1.4 (01-..)	EOBD
 323	ENGINE MANAGEME	1.6 (01-..)	EOBD
 323	ENGINE MANAGEME	1.6 i B6 (89-94)	Mazda EGI MANUAL
 323	ENGINE MANAGEME	1.8 16v BP (..-94)	Mazda EGI MANUAL
 323	ENGINE MANAGEME	2.0 (01-..)	EOBD
 323	ENGINE MANAGEME	2.0 TD (04-..)	EOBD
 323	MAINTENANCE	1.3 16v B3 (89-94)	Mazda EGI MANUAL
 323	MAINTENANCE	1.3 16v B3 (89-94)	Mazda EGI MANUAL
 323	MAINTENANCE	1.3 B3 (89-94)	Mazda EGI MANUAL
 323	MAINTENANCE	1.3 B3 (89-94)	Mazda EGI MANUAL
 323	MAINTENANCE	1.6 i B6 (89-94)	Mazda EGI MANUAL
 323	MAINTENANCE	1.6 i B6 (89-94)	Mazda EGI MANUAL
 323	MAINTENANCE	1.8 16v BP (..-94)	Mazda EGI MANUAL
 323	MAINTENANCE	1.8 16v BP (..-94)	Mazda EGI MANUAL
 5	ABS + TRACT. CONT	1.8	ABS
 5	ABS + TRACT. CONT	2.0	ABS
 5	ABS + TRACT. CONT	2.0 D CRD	ABS
 5	AIRBAG	1.8	SRS
 5	AIRBAG	2.0	SRS
 5	AIRBAG	2.0 D CRD	SRS
 5	CHASSIS NETWORK	1.8	GEM
 5	CHASSIS NETWORK	2.0	GEM
 5	CHASSIS NETWORK	2.0 D CRD	GEM
 5	CLIMA	1.8	EATC
 5	CLIMA	2.0	EATC
 5	CLIMA	2.0 D CRD	EATC
 5	DASHBOARD	1.8	IC
 5	DASHBOARD	2.0	IC
 5	DASHBOARD	2.0 D CRD	IC
 5	ENGINE COOLING	2.0 D CRD	FFH
 5	ENGINE MANAGEME	1.8	EOBD
 5	ENGINE MANAGEME	2.0	EOBD
 5	ENGINE MANAGEME	2.0 D CRD	PCM
 6 MY 08	ABS + TRACT. CONT	1.8 (08-..)	ABS
 6 MY 08	ABS + TRACT. CONT	2.0 (08-..)	ABS
 6 MY 08	ABS + TRACT. CONT	2.0 MZR CD 140cv FAP (08-..)	ABS
 6 MY 08	ABS + TRACT. CONT	2.2 MZR CD 163cv FAP (08-..)	ABS
 6 MY 08	ABS + TRACT. CONT	2.2 MZR CD 185cv FAP (08-..)	ABS
 6 MY 08	ABS + TRACT. CONT	2.5 (08-..)	ABS
 6 MY 08	AIRBAG	1.8 (08-..)	RCM
 6 MY 08	AIRBAG	2.0 (08-..)	RCM
 6 MY 08	AIRBAG	2.0 MZR CD 140cv FAP (08-..)	RCM
 6 MY 08	AIRBAG	2.2 MZR CD 163cv FAP (08-..)	RCM
 6 MY 08	AIRBAG	2.2 MZR CD 185cv FAP (08-..)	RCM
 6 MY 08	AIRBAG	2.5 (08-..)	RCM

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mazda

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 6 MY 08	AUX. HEATING	1.8 (08-..)	FFH
 6 MY 08	AUX. HEATING	2.0 (08-..)	FFH
 6 MY 08	AUX. HEATING	2.0 MZR CD 140cv FAP (08-..)	FFH
 6 MY 08	AUX. HEATING	2.2 MZR CD 163cv FAP (08-..)	FFH
 6 MY 08	AUX. HEATING	2.2 MZR CD 185cv FAP (08-..)	FFH
 6 MY 08	AUX. HEATING	2.5 (08-..)	FFH
 6 MY 08	CHASSIS NETWORK	1.8 (08-..)	BCM
 6 MY 08	CHASSIS NETWORK	2.0 (08-..)	BCM
 6 MY 08	CHASSIS NETWORK	2.0 MZR CD 140cv FAP (08-..)	BCM
 6 MY 08	CHASSIS NETWORK	2.2 MZR CD 163cv FAP (08-..)	BCM
 6 MY 08	CHASSIS NETWORK	2.2 MZR CD 185cv FAP (08-..)	BCM
 6 MY 08	CHASSIS NETWORK	2.5 (08-..)	BCM
 6 MY 08	CLIMA	1.8 (08-..)	EATC
 6 MY 08	CLIMA	2.0 (08-..)	EATC
 6 MY 08	CLIMA	2.0 MZR CD 140cv FAP (08-..)	EATC
 6 MY 08	CLIMA	2.2 MZR CD 163cv FAP (08-..)	EATC
 6 MY 08	CLIMA	2.2 MZR CD 185cv FAP (08-..)	EATC
 6 MY 08	CLIMA	2.5 (08-..)	EATC
 6 MY 08	DASHBOARD	1.8 (08-..)	IC
 6 MY 08	DASHBOARD	2.0 (08-..)	IC
 6 MY 08	DASHBOARD	2.0 MZR CD 140cv FAP (08-..)	IC
 6 MY 08	DASHBOARD	2.2 MZR CD 163cv FAP (08-..)	IC
 6 MY 08	DASHBOARD	2.2 MZR CD 185cv FAP (08-..)	IC
 6 MY 08	DASHBOARD	2.5 (08-..)	IC
 6 MY 08	ELECTRIC STEERING	1.8 (08-..)	EPS
 6 MY 08	ELECTRIC STEERING	2.0 (08-..)	EPS
 6 MY 08	ELECTRIC STEERING	2.0 MZR CD 140cv FAP (08-..)	EPS
 6 MY 08	ELECTRIC STEERING	2.2 MZR CD 163cv FAP (08-..)	EPS
 6 MY 08	ELECTRIC STEERING	2.2 MZR CD 185cv FAP (08-..)	EPS
 6 MY 08	ELECTRIC STEERING	2.5 (08-..)	EPS
 6 MY 08	ENGINE MANAGEME	1.8 (08-..)	EOBD
 6 MY 08	ENGINE MANAGEME	2.0 (08-..)	EOBD
 6 MY 08	ENGINE MANAGEME	2.0 MZR CD 140cv FAP (08-..)	Common Rail
 6 MY 08	ENGINE MANAGEME	2.2 16v D (08-..)	DENSO EDC Common Rail
 6 MY 08	ENGINE MANAGEME	2.2 MZR CD 163cv FAP (08-..)	EOBD
 6 MY 08	ENGINE MANAGEME	2.2 MZR CD 185cv FAP (08-..)	EOBD
 6 MY 08	ENGINE MANAGEME	2.5 (08-..)	EOBD
 6 MY 08	MAINTENANCE	1.8 (08-..)	EPS
 6 MY 08	MAINTENANCE	2.0 (08-..)	EPS
 6 MY 08	MAINTENANCE	2.0 MZR CD 140cv FAP (08-..)	Common Rail
 6 MY 08	MAINTENANCE	2.0 MZR CD 140cv FAP (08-..)	Common Rail
 6 MY 08	MAINTENANCE	2.0 MZR CD 140cv FAP (08-..)	Common Rail
 6 MY 08	MAINTENANCE	2.0 MZR CD 140cv FAP (08-..)	Common Rail
 6 MY 08	MAINTENANCE	2.0 MZR CD 140cv FAP (08-..)	Common Rail
 6 MY 08	MAINTENANCE	2.0 MZR CD 140cv FAP (08-..)	EPS
 6 MY 08	MAINTENANCE	2.2 16v D (08-..)	DENSO EDC Common Rail
 6 MY 08	MAINTENANCE	2.2 16v D (08-..)	DENSO EDC Common Rail
 6 MY 08	MAINTENANCE	2.2 16v D (08-..)	DENSO EDC Common Rail
 6 MY 08	MAINTENANCE	2.2 16v D (08-..)	DENSO EDC Common Rail
 6 MY 08	MAINTENANCE	2.2 16v D (08-..)	DENSO EDC Common Rail
 6 MY 08	MAINTENANCE	2.2 MZR CD 163cv FAP (08-..)	EPS
 6 MY 08	MAINTENANCE	2.2 MZR CD 185cv FAP (08-..)	EPS
 6 MY 08	MAINTENANCE	2.5 (08-..)	EPS
 6	ABS + TRACT. CONT	1.8 MZR	ABS+DSC
 6	ABS + TRACT. CONT	2.0 MZR	ABS+DSC
 6	ABS + TRACT. CONT	2.0 MZR CD 120cv	ABS+DSC
 6	ABS + TRACT. CONT	2.0 MZR CD 136cv	ABS+DSC
 6	ABS + TRACT. CONT	2.0 MZR CD 143cv	ABS+DSC

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mazda

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 6	ABS + TRACT. CONT	2.0 MZR CD 143cv FAP	ABS+DSC
 6	ABS + TRACT. CONT	2.3 MZR	ABS+DSC
 6	AIRBAG	1.8 MZR	TAKATA SRS
 6	AIRBAG	2.0 MZR	TAKATA SRS
 6	AIRBAG	2.0 MZR CD 120cv	TAKATA SRS
 6	AIRBAG	2.0 MZR CD 136cv	TAKATA SRS
 6	AIRBAG	2.0 MZR CD 143cv	TAKATA SRS
 6	AIRBAG	2.0 MZR CD 143cv FAP	TAKATA SRS
 6	AIRBAG	2.3 MZR	TAKATA SRS
 6	DASHBOARD	1.8 MZR	Kombi
 6	DASHBOARD	2.0 MZR	Kombi
 6	DASHBOARD	2.0 MZR CD 120cv	Kombi
 6	DASHBOARD	2.0 MZR CD 136cv	Kombi
 6	DASHBOARD	2.0 MZR CD 143cv	Kombi
 6	DASHBOARD	2.0 MZR CD 143cv FAP	Kombi
 6	DASHBOARD	2.3 MZR	Kombi
 6	ENGINE MANAGEME	1.8 MZR	EOBD
 6	ENGINE MANAGEME	2.0 MZR	EOBD
 6	ENGINE MANAGEME	2.0 MZR CD 120cv	DENSO EDC RF5P Common Rail
 6	ENGINE MANAGEME	2.0 MZR CD 136cv (04-..)	EOBD
 6	ENGINE MANAGEME	2.0 MZR CD 143cv	DENSO EDC Common Rail
 6	ENGINE MANAGEME	2.0 MZR CD 143cv FAP	DENSO EDC Common Rail
 6	MAINTENANCE	2.0 MZR CD 143cv FAP	DENSO EDC Common Rail
 6	MAINTENANCE	2.0 MZR CD 143cv FAP	DENSO EDC Common Rail
 6	MAINTENANCE	2.0 MZR CD 143cv FAP	DENSO EDC Common Rail
 6	MAINTENANCE	2.0 MZR CD 143cv FAP	DENSO EDC Common Rail
 6	MAINTENANCE	2.0 MZR CD 143cv FAP	DENSO EDC Common Rail
 626	ENGINE MANAGEME	1.8 16v BP (92-97)	Mazda EGI MANUAL
 626	ENGINE MANAGEME	1.9 (01-..)	EOBD
 626	ENGINE MANAGEME	2.0 100kw (01-..)	EOBD
 626	ENGINE MANAGEME	2.0 16v FS (92-97)	Mazda EGI MANUAL
 626	ENGINE MANAGEME	2.0 85kw (01-..)	EOBD
 626	ENGINE MANAGEME	2.0 Compex D RF-CX (92-97)	Mazda EDC MANUAL
 626	ENGINE MANAGEME	2.5 V6 24v Xerxes KL (92-97)	Mazda EGI MANUAL
 626	MAINTENANCE	1.8 16v BP (92-97)	Mazda EGI MANUAL
 626	MAINTENANCE	1.8 16v BP (92-97)	Mazda EGI MANUAL
 626	MAINTENANCE	2.0 16v FS (92-97)	Mazda EGI MANUAL
 626	MAINTENANCE	2.0 16v FS (92-97)	Mazda EGI MANUAL
 626	MAINTENANCE	2.0 Compex D RF-CX (92-97)	Mazda EDC MANUAL
 626	MAINTENANCE	2.0 Compex D RF-CX (92-97)	Mazda EDC MANUAL
 626	MAINTENANCE	2.5 V6 24v Xerxes KL (92-97)	Mazda EGI MANUAL
 626	MAINTENANCE	2.5 V6 24v Xerxes KL (92-97)	Mazda EGI MANUAL
 B- Series	ENGINE MANAGEME	2.5 TD 61 kw (04-..)	EOBD
 B- Series	ENGINE MANAGEME	2.5 TD 80 kw (04-..)	EOBD
 CX-7	ABS	2.2 16v D	ABS
 CX-7	AIRBAG	2.2 16v D	RCM
 CX-7	CHASSIS NETWORK	2.2 16v D	GEM
 CX-7	CLIMA	2.2 16v D	EATC
 CX-7	DASHBOARD	2.2 16v D	IC RCM
 CX-7	DIESEL ADDITION	2.2 16v D	SCR
 CX-7	ELECTRIC STEERING	2.2 16v D	EPS
 CX-7	ENGINE MANAGEME	2.2 16v D	DENSO EDC Common Rail
 CX-7	MAINTENANCE	2.2 16v D	DENSO EDC Common Rail
 CX-7	MAINTENANCE	2.2 16v D	DENSO EDC Common Rail
 CX-7	MAINTENANCE	2.2 16v D	DENSO EDC Common Rail
 CX-7	MAINTENANCE	2.2 16v D	DENSO EDC Common Rail
 CX-7	MAINTENANCE	2.2 16v D	DENSO EDC Common Rail

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mazda

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Demio	ENGINE MANAGEME	1.4 (01-..)	EOBD
 Demio	ENGINE MANAGEME	1.5 BF SOCH (00-01)	EOBD
 MPV	ENGINE MANAGEME	2.0 (01-..)	EOBD
 MX3	ENGINE MANAGEME	1.6 16v B6 (91-94)	Mazda EGI MANUAL
 MX3	ENGINE MANAGEME	1.8 16v K8 (91-00)	Mazda EGI MANUAL
 MX3	MAINTENANCE	1.6 16v B6 (91-94)	Mazda EGI MANUAL
 MX3	MAINTENANCE	1.6 16v B6 (91-94)	Mazda EGI MANUAL
 MX3	MAINTENANCE	1.8 16v K8 (91-00)	Mazda EGI MANUAL
 MX3	MAINTENANCE	1.8 16v K8 (91-00)	Mazda EGI MANUAL
 MX5	ENGINE MANAGEME	1.6 (01-..)	EOBD
 MX5	ENGINE MANAGEME	1.6 B6 DOHC (00-01)	EOBD
 MX5	ENGINE MANAGEME	1.9 (01-..)	EOBD
 MX6	ENGINE MANAGEME	2.0 16v FS (91-94)	Mazda EGI MANUAL
 MX6	ENGINE MANAGEME	2.5 V6 24v KL (91-97)	Mazda EGI MANUAL
 MX6	MAINTENANCE	2.0 16v FS (91-94)	Mazda EGI MANUAL
 MX6	MAINTENANCE	2.0 16v FS (91-94)	Mazda EGI MANUAL
 MX6	MAINTENANCE	2.5 V6 24v KL (91-97)	Mazda EGI MANUAL
 MX6	MAINTENANCE	2.5 V6 24v KL (91-97)	Mazda EGI MANUAL
 Premacy	ENGINE MANAGEME	1.9 (01-..)	EOBD
 Premacy	ENGINE MANAGEME	2.0 (01-..)	EOBD
 Premacy	ENGINE MANAGEME	2.0 TDI (01-..)	EOBD
 Tribute	ENGINE MANAGEME	2.0 (01-..)	EOBD
 Tribute	ENGINE MANAGEME	3.0 (01-..)	EOBD
 Xedos 6	ENGINE MANAGEME	1.6 16v B6 (92-00)	Mazda EGI MANUAL
 Xedos 6	ENGINE MANAGEME	2.0 V6 24v KF (92-00)	Mazda EGI MANUAL
 Xedos 6	MAINTENANCE	1.6 16v B6 (92-00)	Mazda EGI MANUAL
 Xedos 6	MAINTENANCE	1.6 16v B6 (92-00)	Mazda EGI MANUAL
 Xedos 6	MAINTENANCE	2.0 V6 24v KF (92-00)	Mazda EGI MANUAL
 Xedos 6	MAINTENANCE	2.0 V6 24v KF (92-00)	Mazda EGI MANUAL
 Xedos 9	ENGINE MANAGEME	2.0 V6 24v KF (..-94)	Mazda EGI MANUAL
 Xedos 9	ENGINE MANAGEME	2.5 (00-01)	EOBD
 Xedos 9	ENGINE MANAGEME	2.5 (01-..)	EOBD
 Xedos 9	ENGINE MANAGEME	2.5 V6 24v KL (94-..)	Mazda EGI MANUAL
 Xedos 9	MAINTENANCE	2.0 V6 24v KF (..-94)	Mazda EGI MANUAL
 Xedos 9	MAINTENANCE	2.0 V6 24v KF (..-94)	Mazda EGI MANUAL
 Xedos 9	MAINTENANCE	2.5 V6 24v KL (94-..)	Mazda EGI MANUAL
 Xedos 9	MAINTENANCE	2.5 V6 24v KL (94-..)	Mazda EGI MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 129 SL-Class	ABS + TRACT. CONT	300 SL (89-95)	BOSCH ETS 5
 129 SL-Class	ABS + TRACT. CONT	300 SL 2.8 (89-95)	BOSCH ETS 5
 129 SL-Class	ABS + TRACT. CONT	300 SL 3.2 (89-95)	BOSCH ETS 5
 129 SL-Class	ABS + TRACT. CONT	300 SL-24 (89-95)	BOSCH ETS 5
 129 SL-Class	ABS + TRACT. CONT	500 SL (89-95)	BOSCH ETS 5
 129 SL-Class	ABS + TRACT. CONT	600 SL (89-95)	BOSCH ETS 5
 129 SL-Class	ABS + TRACT. CONT	SL 280 (89-95)	BOSCH ETS 5
 129 SL-Class	ABS + TRACT. CONT	SL 320 (89-95)	BOSCH ETS 5
 129 SL-Class	ABS + TRACT. CONT	SL 500 (89-95)	BOSCH ETS 5
 129 SL-Class	ABS + TRACT. CONT	SL 55 AMG (89-95)	BOSCH ETS 5
 129 SL-Class	ABS + TRACT. CONT	SL 60 AMG (89-95)	BOSCH ETS 5
 129 SL-Class	ABS + TRACT. CONT	SL 600 (89-95)	BOSCH ETS 5
 129 SL-Class	AIRBAG	300 SL (...99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 129 SL-Class	AIRBAG	300 SL 2.8 (...99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 129 SL-Class	AIRBAG	300 SL 3.2 (...99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 129 SL-Class	AIRBAG	300 SL-24 (...99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 129 SL-Class	AIRBAG	500 SL (...99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 129 SL-Class	AIRBAG	600 SL (...99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 129 SL-Class	AIRBAG	SL 280 (...99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 129 SL-Class	AIRBAG	SL 320 (...99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 129 SL-Class	AIRBAG	SL 500 (...99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 129 SL-Class	AIRBAG	SL 55 AMG (...99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 129 SL-Class	AIRBAG	SL 60 AMG (...99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 129 SL-Class	AIRBAG	SL 600 (...99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 129 SL-Class	CHASSIS NETWORK	300 SL (89-95)	Base Module
 129 SL-Class	CHASSIS NETWORK	300 SL 2.8 (89-95)	Base Module
 129 SL-Class	CHASSIS NETWORK	300 SL 3.2 (89-95)	Base Module
 129 SL-Class	CHASSIS NETWORK	300 SL-24 (89-95)	Base Module
 129 SL-Class	CHASSIS NETWORK	500 SL (89-95)	Base Module
 129 SL-Class	CHASSIS NETWORK	600 SL (89-95)	Base Module
 129 SL-Class	CHASSIS NETWORK	SL 280 (89-95)	Base Module
 129 SL-Class	CHASSIS NETWORK	SL 320 (89-95)	Base Module
 129 SL-Class	CHASSIS NETWORK	SL 500 (89-95)	Base Module
 129 SL-Class	CHASSIS NETWORK	SL 55 AMG (89-95)	Base Module
 129 SL-Class	CHASSIS NETWORK	SL 60 AMG (89-95)	Base Module
 129 SL-Class	CHASSIS NETWORK	SL 600 (89-95)	Base Module
 129 SL-Class	CRUISE CONTROL	300 SL (89-95)	BOSCH/VDO EA/CC/ISC
 129 SL-Class	CRUISE CONTROL	300 SL 2.8 (89-95)	BOSCH/VDO EA/CC/ISC
 129 SL-Class	CRUISE CONTROL	300 SL 3.2 (89-95)	BOSCH/VDO EA/CC/ISC
 129 SL-Class	CRUISE CONTROL	300 SL-24 (89-95)	BOSCH/VDO EA/CC/ISC
 129 SL-Class	CRUISE CONTROL	500 SL (89-95)	BOSCH/VDO EA/CC/ISC
 129 SL-Class	CRUISE CONTROL	600 SL (89-95)	BOSCH/VDO EA/CC/ISC
 129 SL-Class	CRUISE CONTROL	SL 280 (89-95)	BOSCH/VDO EA/CC/ISC
 129 SL-Class	CRUISE CONTROL	SL 320 (89-95)	BOSCH/VDO EA/CC/ISC
 129 SL-Class	CRUISE CONTROL	SL 500 (89-95)	BOSCH/VDO EA/CC/ISC
 129 SL-Class	CRUISE CONTROL	SL 55 AMG (89-95)	BOSCH/VDO EA/CC/ISC
 129 SL-Class	CRUISE CONTROL	SL 60 AMG (89-95)	BOSCH/VDO EA/CC/ISC
 129 SL-Class	CRUISE CONTROL	SL 600 (89-95)	BOSCH/VDO EA/CC/ISC
 129 SL-Class	ENGINE MANAGEME	300 SL 103 (89-95)	BOSCH LH-Jetronic 4.1
 129 SL-Class	ENGINE MANAGEME	300 SL 2.8 104 (89-95)	BOSCH LH-Jetronic 4.1
 129 SL-Class	ENGINE MANAGEME	300 SL 2.8 104 (89-95)	SIEMENS-VDO HFM SFI
 129 SL-Class	ENGINE MANAGEME	300 SL 3.2 104 (89-95)	BOSCH LH-Jetronic 4.1
 129 SL-Class	ENGINE MANAGEME	300 SL-24 104 (89-95)	BOSCH LH-Jetronic 4.1
 129 SL-Class	ENGINE MANAGEME	500 SL 119 (89-95)	BOSCH LH-Jetronic 4.1
 129 SL-Class	ENGINE MANAGEME	600 SL 120 (89-95)	BOSCH LH-Jetronic 4.1
 129 SL-Class	ENGINE MANAGEME	SL 280 104 (...99)	BOSCH Motronic ME 1.0
 129 SL-Class	ENGINE MANAGEME	SL 280 104 (...99)	BOSCH Motronic ME 2.0
 129 SL-Class	ENGINE MANAGEME	SL 280 104 (...99)	BOSCH Motronic ME 2.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 129 SL-Class	ENGINE MANAGEME	SL 280 104 (89-95)	BOSCH LH-Jetronic 4.1
 129 SL-Class	ENGINE MANAGEME	SL 280 104 (89-95)	SIEMENS-VDO HFM SFI
 129 SL-Class	ENGINE MANAGEME	SL 280 112 (89-95)	BOSCH LH-Jetronic 4.1
 129 SL-Class	ENGINE MANAGEME	SL 320 104 (...99)	BOSCH Motronic ME 2.1
 129 SL-Class	ENGINE MANAGEME	SL 320 104 (89-95)	SIEMENS-VDO HFM SFI
 129 SL-Class	ENGINE MANAGEME	SL 320 112 (89-95)	BOSCH LH-Jetronic 4.1
 129 SL-Class	ENGINE MANAGEME	SL 500 113 (89-95)	BOSCH LH-Jetronic 4.1
 129 SL-Class	ENGINE MANAGEME	SL 500 119 (...99)	BOSCH Motronic ME 1.0
 129 SL-Class	ENGINE MANAGEME	SL 600 120 (...99)	BOSCH Motronic ME 1.0
 129 SL-Class	MAINTENANCE	300 SL (99-03)	VDO/Marelli MANUAL
 129 SL-Class	MAINTENANCE	300 SL 2.8 (99-03)	VDO/Marelli MANUAL
 129 SL-Class	MAINTENANCE	300 SL 3.2 (99-03)	VDO/Marelli MANUAL
 129 SL-Class	MAINTENANCE	300 SL-24 (99-03)	VDO/Marelli MANUAL
 129 SL-Class	MAINTENANCE	500 SL (99-03)	VDO/Marelli MANUAL
 129 SL-Class	MAINTENANCE	600 SL (99-03)	VDO/Marelli MANUAL
 129 SL-Class	MAINTENANCE	SL 320 (99-03)	VDO/Marelli MANUAL
 129 SL-Class	MAINTENANCE	SL 280 (99-03)	VDO/Marelli MANUAL
 129 SL-Class	MAINTENANCE	SL 500 (99-03)	VDO/Marelli MANUAL
 129 SL-Class	MAINTENANCE	SL 55 AMG (99-03)	VDO/Marelli MANUAL
 129 SL-Class	MAINTENANCE	SL 60 AMG (99-03)	VDO/Marelli MANUAL
 129 SL-Class	MAINTENANCE	SL 600 (99-03)	VDO/Marelli MANUAL
 129 SL-Class	SERVICE LIGHT RES	300 SL (99-03)	VDO/Marelli MANUAL
 129 SL-Class	SERVICE LIGHT RES	300 SL 2.8 (99-03)	VDO/Marelli MANUAL
 129 SL-Class	SERVICE LIGHT RES	300 SL 3.2 (99-03)	VDO/Marelli MANUAL
 129 SL-Class	SERVICE LIGHT RES	300 SL-24 (99-03)	VDO/Marelli MANUAL
 129 SL-Class	SERVICE LIGHT RES	500 SL (99-03)	VDO/Marelli MANUAL
 129 SL-Class	SERVICE LIGHT RES	600 SL (99-03)	VDO/Marelli MANUAL
 129 SL-Class	SERVICE LIGHT RES	SL 280 (99-03)	VDO/Marelli MANUAL
 129 SL-Class	SERVICE LIGHT RES	SL 320 (99-03)	VDO/Marelli MANUAL
 129 SL-Class	SERVICE LIGHT RES	SL 500 (99-03)	VDO/Marelli MANUAL
 129 SL-Class	SERVICE LIGHT RES	SL 55 AMG (99-03)	VDO/Marelli MANUAL
 129 SL-Class	SERVICE LIGHT RES	SL 60 AMG (99-03)	VDO/Marelli MANUAL
 129 SL-Class	SERVICE LIGHT RES	SL 600 (99-03)	VDO/Marelli MANUAL
 140 CL-Class	ABS + TRACT. CONT	CL 420 Coupe' (...99)	BOSCH ASR/ABD BAS/ETS
 140 CL-Class	ABS + TRACT. CONT	CL 500 Coupe' (...99)	BOSCH ASR/ABD BAS/ETS
 140 CL-Class	ABS + TRACT. CONT	CL 600 Coupe' (...99)	BOSCH ASR/ABD BAS/ETS
 140 CL-Class	AIRBAG	CL 420 Coupe' (...99)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 140 CL-Class	AIRBAG	CL 500 Coupe' (...99)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 140 CL-Class	AIRBAG	CL 600 Coupe' (...99)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 140 CL-Class	AUTOM. TRANSMISSI	CL 420 Coupe' (...99)	BOSCH ETC 6
 140 CL-Class	AUTOM. TRANSMISSI	CL 500 Coupe' (...99)	BOSCH ETC 6
 140 CL-Class	AUTOM. TRANSMISSI	CL 600 Coupe' (...99)	BOSCH ETC 6
 140 CL-Class	ENGINE MANAGEME	CL 420 Coupe' 119 (...99)	BOSCH Motronic ME 1.0
 140 CL-Class	ENGINE MANAGEME	CL 420 Coupe' 119 (...99)	BOSCH Motronic ME 2.0
 140 CL-Class	ENGINE MANAGEME	CL 500 Coupe' 119 (...99)	BOSCH Motronic ME 1.0
 140 CL-Class	ENGINE MANAGEME	CL 500 Coupe' 119 (...99)	BOSCH Motronic ME 2.0
 140 CL-Class	ENGINE MANAGEME	CL 600 Coupe' 120 (...99)	BOSCH Motronic ME 1 (ecu 1)
 140 CL-Class	ENGINE MANAGEME	CL 600 Coupe' 120 (...99)	BOSCH Motronic ME 2.0
 140 CL-Class	ENGINE MANAGEME	CL 600 Coupe' 120 (...99)	BOSCH Motronic ME 1 (ecu 2)
 140 S-Class	ABS + TRACT. CONT	300 D Turbo (...99)	BOSCH ASR/ABD BAS/ETS
 140 S-Class	ABS + TRACT. CONT	300 D Turbo (89-95)	BOSCH ETS 5
 140 S-Class	ABS + TRACT. CONT	300 SE 2.8 (...99)	BOSCH ASR/ABD BAS/ETS
 140 S-Class	ABS + TRACT. CONT	300 SE 2.8 (89-95)	BOSCH ETS 5
 140 S-Class	ABS + TRACT. CONT	300 SE/SEL 3.2 (...99)	BOSCH ASR/ABD BAS/ETS
 140 S-Class	ABS + TRACT. CONT	300 SE/SEL 3.2 (89-95)	BOSCH ETS 5
 140 S-Class	ABS + TRACT. CONT	400 SE/SEL (...99)	BOSCH ASR/ABD BAS/ETS
 140 S-Class	ABS + TRACT. CONT	400 SE/SEL (89-95)	BOSCH ETS 5
 140 S-Class	ABS + TRACT. CONT	500 SE/SEC (...99)	BOSCH ASR/ABD BAS/ETS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 140 S-Class	ABS + TRACT. CONT	500 SE/SEC (89-95)	BOSCH ETS 5
 140 S-Class	ABS + TRACT. CONT	500 SEC (...99)	BOSCH ASR/ABD BAS/ETS
 140 S-Class	ABS + TRACT. CONT	500 SEC (89-95)	BOSCH ETS 5
 140 S-Class	ABS + TRACT. CONT	600 SE/SEL V12 (...99)	BOSCH ASR/ABD BAS/ETS
 140 S-Class	ABS + TRACT. CONT	600 SE/SEL V12 (89-95)	BOSCH ETS 5
 140 S-Class	ABS + TRACT. CONT	600 SEC V12 (...99)	BOSCH ASR/ABD BAS/ETS
 140 S-Class	ABS + TRACT. CONT	600 SEC V12 (89-95)	BOSCH ETS 5
 140 S-Class	ABS + TRACT. CONT	CL 420 (...99)	BOSCH ASR/ABD BAS/ETS
 140 S-Class	ABS + TRACT. CONT	CL 420 (89-95)	BOSCH ETS 5
 140 S-Class	ABS + TRACT. CONT	CL 500 (...99)	BOSCH ASR/ABD BAS/ETS
 140 S-Class	ABS + TRACT. CONT	CL 500 (89-95)	BOSCH ETS 5
 140 S-Class	ABS + TRACT. CONT	CL 600 (...99)	BOSCH ASR/ABD BAS/ETS
 140 S-Class	ABS + TRACT. CONT	CL 600 (89-95)	BOSCH ETS 5
 140 S-Class	ABS + TRACT. CONT	S 280 (...99)	BOSCH ASR/ABD BAS/ETS
 140 S-Class	ABS + TRACT. CONT	S 280 (89-95)	BOSCH ETS 5
 140 S-Class	ABS + TRACT. CONT	S 300 D Turbo (...99)	BOSCH ASR/ABD BAS/ETS
 140 S-Class	ABS + TRACT. CONT	S 300 D Turbo (89-95)	BOSCH ETS 5
 140 S-Class	ABS + TRACT. CONT	S 320 (...99)	BOSCH ASR/ABD BAS/ETS
 140 S-Class	ABS + TRACT. CONT	S 320 (89-95)	BOSCH ETS 5
 140 S-Class	ABS + TRACT. CONT	S 350 D Turbo (...99)	BOSCH ASR/ABD BAS/ETS
 140 S-Class	ABS + TRACT. CONT	S 350 D Turbo (89-95)	BOSCH ETS 5
 140 S-Class	ABS + TRACT. CONT	S 420 (...99)	BOSCH ASR/ABD BAS/ETS
 140 S-Class	ABS + TRACT. CONT	S 420 (89-95)	BOSCH ETS 5
 140 S-Class	ABS + TRACT. CONT	S 500 (...99)	BOSCH ASR/ABD BAS/ETS
 140 S-Class	ABS + TRACT. CONT	S 500 (89-95)	BOSCH ETS 5
 140 S-Class	ABS + TRACT. CONT	S 600 (...99)	BOSCH ASR/ABD BAS/ETS
 140 S-Class	ABS + TRACT. CONT	S 600 (89-95)	BOSCH ETS 5
 140 S-Class	AUTOM. TRANSMISSI	300 D Turbo (...99)	BOSCH ETC 6
 140 S-Class	AUTOM. TRANSMISSI	300 SE 2.8 (...99)	BOSCH ETC 6
 140 S-Class	AUTOM. TRANSMISSI	300 SE/SEL 3.2 (...99)	BOSCH ETC 6
 140 S-Class	AUTOM. TRANSMISSI	400 SE/SEL (...99)	BOSCH ETC 6
 140 S-Class	AUTOM. TRANSMISSI	500 SE/SEC (...99)	BOSCH ETC 6
 140 S-Class	AUTOM. TRANSMISSI	500 SEC (...99)	BOSCH ETC 6
 140 S-Class	AUTOM. TRANSMISSI	600 SE/SEL V12 (...99)	BOSCH ETC 6
 140 S-Class	AUTOM. TRANSMISSI	600 SEC V12 (...99)	BOSCH ETC 6
 140 S-Class	AUTOM. TRANSMISSI	CL 420 (...99)	BOSCH ETC 6
 140 S-Class	AUTOM. TRANSMISSI	CL 500 (...99)	BOSCH ETC 6
 140 S-Class	AUTOM. TRANSMISSI	CL 600 (...99)	BOSCH ETC 6
 140 S-Class	AUTOM. TRANSMISSI	S 280 (...99)	BOSCH ETC 6
 140 S-Class	AUTOM. TRANSMISSI	S 300 D Turbo (...99)	BOSCH ETC 6
 140 S-Class	AUTOM. TRANSMISSI	S 320 (...99)	BOSCH ETC 6
 140 S-Class	AUTOM. TRANSMISSI	S 350 D Turbo (...99)	BOSCH ETC 6
 140 S-Class	AUTOM. TRANSMISSI	S 420 (...99)	BOSCH ETC 6
 140 S-Class	AUTOM. TRANSMISSI	S 500 (...99)	BOSCH ETC 6
 140 S-Class	AUTOM. TRANSMISSI	S 600 (...99)	BOSCH ETC 6
 140 S-Class	CHASSIS NETWORK	300 D Turbo	Base Module
 140 S-Class	CHASSIS NETWORK	300 SE 2.8	Base Module
 140 S-Class	CHASSIS NETWORK	300 SE/SEL 3.2	Base Module
 140 S-Class	CHASSIS NETWORK	400 SE/SEL	Base Module
 140 S-Class	CHASSIS NETWORK	500 SE/SEC	Base Module
 140 S-Class	CHASSIS NETWORK	500 SEC	Base Module
 140 S-Class	CHASSIS NETWORK	600 SE/SEL V12	Base Module
 140 S-Class	CHASSIS NETWORK	600 SEC V12	Base Module
 140 S-Class	CHASSIS NETWORK	CL 420	Base Module
 140 S-Class	CHASSIS NETWORK	CL 500	Base Module
 140 S-Class	CHASSIS NETWORK	CL 600	Base Module
 140 S-Class	CHASSIS NETWORK	S 280	Base Module
 140 S-Class	CHASSIS NETWORK	S 300 D Turbo	Base Module

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 140 S-Class	CHASSIS NETWORK	S 320	Base Module
 140 S-Class	CHASSIS NETWORK	S 350 D Turbo	Base Module
 140 S-Class	CHASSIS NETWORK	S 420	Base Module
 140 S-Class	CHASSIS NETWORK	S 500	Base Module
 140 S-Class	CHASSIS NETWORK	S 600	Base Module
 140 S-Class	CRUISE CONTROL	300 D Turbo (89-95)	BOSCH/VDO EA/CC/ISC
 140 S-Class	CRUISE CONTROL	300 SE 2.8 (89-95)	BOSCH/VDO EA/CC/ISC
 140 S-Class	CRUISE CONTROL	300 SE/SEL 3.2 (89-95)	BOSCH/VDO EA/CC/ISC
 140 S-Class	CRUISE CONTROL	400 SE/SEL (89-95)	BOSCH/VDO EA/CC/ISC
 140 S-Class	CRUISE CONTROL	500 SE/SEC (89-95)	BOSCH/VDO EA/CC/ISC
 140 S-Class	CRUISE CONTROL	500 SEC (89-95)	BOSCH/VDO EA/CC/ISC
 140 S-Class	CRUISE CONTROL	600 SE/SEL V12 (89-95)	BOSCH/VDO EA/CC/ISC
 140 S-Class	CRUISE CONTROL	600 SEC V12 (89-95)	BOSCH/VDO EA/CC/ISC
 140 S-Class	CRUISE CONTROL	CL 420 (89-95)	BOSCH/VDO EA/CC/ISC
 140 S-Class	CRUISE CONTROL	CL 500 (89-95)	BOSCH/VDO EA/CC/ISC
 140 S-Class	CRUISE CONTROL	CL 600 (89-95)	BOSCH/VDO EA/CC/ISC
 140 S-Class	CRUISE CONTROL	S 280 (89-95)	BOSCH/VDO EA/CC/ISC
 140 S-Class	CRUISE CONTROL	S 300 D Turbo (89-95)	BOSCH/VDO EA/CC/ISC
 140 S-Class	CRUISE CONTROL	S 320 (89-95)	BOSCH/VDO EA/CC/ISC
 140 S-Class	CRUISE CONTROL	S 350 D Turbo (89-95)	BOSCH/VDO EA/CC/ISC
 140 S-Class	CRUISE CONTROL	S 420 (89-95)	BOSCH/VDO EA/CC/ISC
 140 S-Class	CRUISE CONTROL	S 500 (89-95)	BOSCH/VDO EA/CC/ISC
 140 S-Class	CRUISE CONTROL	S 600 (89-95)	BOSCH/VDO EA/CC/ISC
 140 S-Class	DIESEL MANAGEMEN	300 D Turbo 606 (...99)	BOSCH IFI (ERE) (EPC)
 140 S-Class	DIESEL MANAGEMEN	S 300 D Turbo 606 (...99)	BOSCH IFI (ERE) (EPC)
 140 S-Class	ENGINE MANAGEME	300 SE 2.8 104 (89-95)	BOSCH LH-Jetronic 4.1
 140 S-Class	ENGINE MANAGEME	300 SE 2.8 104 (89-95)	SIEMENS/VDO HFM SFI
 140 S-Class	ENGINE MANAGEME	300 SE/SEL 3.2 104 (89-95)	BOSCH LH-Jetronic 4.1
 140 S-Class	ENGINE MANAGEME	300 SE/SEL 3.2 104 (89-95)	SIEMENS/VDO HFM SFI
 140 S-Class	ENGINE MANAGEME	400 SE/SEL 119 (89-95)	BOSCH LH-Jetronic 4.1
 140 S-Class	ENGINE MANAGEME	400 SE/SEL 119 (89-95)	SIEMENS/VDO HFM SFI
 140 S-Class	ENGINE MANAGEME	500 SE/SEC 119 (89-95)	BOSCH LH-Jetronic 4.1
 140 S-Class	ENGINE MANAGEME	500 SE/SEC 119 (89-95)	SIEMENS/VDO HFM SFI
 140 S-Class	ENGINE MANAGEME	500 SEC 119 (89-95)	BOSCH LH-Jetronic 4.1
 140 S-Class	ENGINE MANAGEME	500 SEC 119 (89-95)	SIEMENS/VDO HFM SFI
 140 S-Class	ENGINE MANAGEME	600 SE/SEL V12 120 (89-95)	BOSCH LH-Jetronic 4.1
 140 S-Class	ENGINE MANAGEME	600 SE/SEL V12 120 (89-95)	SIEMENS/VDO HFM SFI
 140 S-Class	ENGINE MANAGEME	600 SEC V12 120 (89-95)	BOSCH LH-Jetronic 4.1
 140 S-Class	ENGINE MANAGEME	CL 420 119 (89-95)	BOSCH LH-Jetronic 4.1
 140 S-Class	ENGINE MANAGEME	CL 420 119 (89-95)	SIEMENS/VDO HFM SFI
 140 S-Class	ENGINE MANAGEME	CL 500 119 (89-95)	BOSCH LH-Jetronic 4.1
 140 S-Class	ENGINE MANAGEME	CL 500 119 (89-95)	SIEMENS/VDO HFM SFI
 140 S-Class	ENGINE MANAGEME	CL 600 120 (89-95)	BOSCH LH-Jetronic 4.1
 140 S-Class	ENGINE MANAGEME	CL 600 120 (89-95)	SIEMENS/VDO HFM SFI
 140 S-Class	ENGINE MANAGEME	S 280 104 (...99)	BOSCH Motronic ME 2.1
 140 S-Class	ENGINE MANAGEME	S 280 104 (89-95)	BOSCH LH-Jetronic 4.1
 140 S-Class	ENGINE MANAGEME	S 280 104 (89-95)	SIEMENS/VDO HFM SFI
 140 S-Class	ENGINE MANAGEME	S 320 104 (...99)	BOSCH Motronic ME 2.1
 140 S-Class	ENGINE MANAGEME	S 320 104 (89-95)	BOSCH LH-Jetronic 4.1
 140 S-Class	ENGINE MANAGEME	S 320 104 (89-95)	SIEMENS/VDO HFM SFI
 140 S-Class	ENGINE MANAGEME	S 420 119 (...99)	BOSCH Motronic ME 1.0
 140 S-Class	ENGINE MANAGEME	S 420 119 (89-95)	BOSCH LH-Jetronic 4.1
 140 S-Class	ENGINE MANAGEME	S 420 119 (89-95)	SIEMENS/VDO HFM SFI
 140 S-Class	ENGINE MANAGEME	S 500 119 (...99)	BOSCH Motronic ME 1.0
 140 S-Class	ENGINE MANAGEME	S 500 119 (89-95)	BOSCH LH-Jetronic 4.1
 140 S-Class	ENGINE MANAGEME	S 500 119 (89-95)	SIEMENS/VDO HFM SFI
 140 S-Class	ENGINE MANAGEME	S 600 120 (...99)	BOSCH Motronic ME 1 (ecu 1)
 140 S-Class	ENGINE MANAGEME	S 600 120 (89-95)	BOSCH LH-Jetronic 4.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 140 S-Class	ENGINE MANAGEME	S 600 120 (89-95)	SIEMENS/VDO HFM SFI
 140 S-Class	ENGINE MANAGEME	S 600 120 (...99)	BOSCH Motronic ME 1 (ecu 2)
 140 S-Class	MAINTENANCE	300 D Turbo (99-03)	VDO/Marelli MANUAL
 140 S-Class	MAINTENANCE	300 SE 2.8 (99-03)	VDO/Marelli MANUAL
 140 S-Class	MAINTENANCE	300 SE/SEL 3.2 (99-03)	VDO/Marelli MANUAL
 140 S-Class	MAINTENANCE	400 SE/SEL (99-03)	VDO/Marelli MANUAL
 140 S-Class	MAINTENANCE	500 SE/SEC (99-03)	VDO/Marelli MANUAL
 140 S-Class	MAINTENANCE	500 SEC (99-03)	VDO/Marelli MANUAL
 140 S-Class	MAINTENANCE	600 SE/SEL V12 (99-03)	VDO/Marelli MANUAL
 140 S-Class	MAINTENANCE	600 SEC V12 (99-03)	VDO/Marelli MANUAL
 140 S-Class	MAINTENANCE	CL 420 (99-03)	VDO/Marelli MANUAL
 140 S-Class	MAINTENANCE	CL 500 (99-03)	VDO/Marelli MANUAL
 140 S-Class	MAINTENANCE	CL 600 (99-03)	VDO/Marelli MANUAL
 140 S-Class	MAINTENANCE	S 280 (99-03)	VDO/Marelli MANUAL
 140 S-Class	MAINTENANCE	S 300 D Turbo (99-03)	VDO/Marelli MANUAL
 140 S-Class	MAINTENANCE	S 320 (99-03)	VDO/Marelli MANUAL
 140 S-Class	MAINTENANCE	S 350 D Turbo (99-03)	VDO/Marelli MANUAL
 140 S-Class	MAINTENANCE	S 420 (99-03)	VDO/Marelli MANUAL
 140 S-Class	MAINTENANCE	S 500 (99-03)	VDO/Marelli MANUAL
 140 S-Class	MAINTENANCE	S 600 (99-03)	VDO/Marelli MANUAL
 140 S-Class	SERVICE LIGHT RES	300 D Turbo (99-03)	VDO/Marelli MANUAL
 140 S-Class	SERVICE LIGHT RES	300 SE 2.8 (99-03)	VDO/Marelli MANUAL
 140 S-Class	SERVICE LIGHT RES	300 SE/SEL 3.2 (99-03)	VDO/Marelli MANUAL
 140 S-Class	SERVICE LIGHT RES	400 SE/SEL (99-03)	VDO/Marelli MANUAL
 140 S-Class	SERVICE LIGHT RES	500 SE/SEC (99-03)	VDO/Marelli MANUAL
 140 S-Class	SERVICE LIGHT RES	500 SEC (99-03)	VDO/Marelli MANUAL
 140 S-Class	SERVICE LIGHT RES	600 SE/SEL V12 (99-03)	VDO/Marelli MANUAL
 140 S-Class	SERVICE LIGHT RES	600 SEC V12 (99-03)	VDO/Marelli MANUAL
 140 S-Class	SERVICE LIGHT RES	CL 420 (99-03)	VDO/Marelli MANUAL
 140 S-Class	SERVICE LIGHT RES	CL 500 (99-03)	VDO/Marelli MANUAL
 140 S-Class	SERVICE LIGHT RES	CL 600 (99-03)	VDO/Marelli MANUAL
 140 S-Class	SERVICE LIGHT RES	S 280 (99-03)	VDO/Marelli MANUAL
 140 S-Class	SERVICE LIGHT RES	S 300 D Turbo (99-03)	VDO/Marelli MANUAL
 140 S-Class	SERVICE LIGHT RES	S 320 (99-03)	VDO/Marelli MANUAL
 140 S-Class	SERVICE LIGHT RES	S 350 D Turbo (99-03)	VDO/Marelli MANUAL
 140 S-Class	SERVICE LIGHT RES	S 420 (99-03)	VDO/Marelli MANUAL
 140 S-Class	SERVICE LIGHT RES	S 500 (99-03)	VDO/Marelli MANUAL
 140 S-Class	SERVICE LIGHT RES	S 600 (99-03)	VDO/Marelli MANUAL
 163 ML-Class	ABS + TRACT. CONT	ML 230 (00-05)	TEVES ESP 1
 163 ML-Class	ABS + TRACT. CONT	ML 230 (00-05)	TEVES ESP 2
 163 ML-Class	ABS + TRACT. CONT	ML 270 CDI (00-05)	TEVES ESP 1
 163 ML-Class	ABS + TRACT. CONT	ML 270 CDI (00-05)	TEVES ESP 2
 163 ML-Class	ABS + TRACT. CONT	ML 320 (00-05)	TEVES ESP 1
 163 ML-Class	ABS + TRACT. CONT	ML 320 (00-05)	TEVES ESP 2
 163 ML-Class	ABS + TRACT. CONT	ML 350 (00-05)	TEVES ESP 1
 163 ML-Class	ABS + TRACT. CONT	ML 350 (00-05)	TEVES ESP 2
 163 ML-Class	ABS + TRACT. CONT	ML 400 CDI (00-05)	TEVES ESP 1
 163 ML-Class	ABS + TRACT. CONT	ML 400 CDI (00-05)	TEVES ESP 2
 163 ML-Class	ABS + TRACT. CONT	ML 430 (00-05)	TEVES ESP 1
 163 ML-Class	ABS + TRACT. CONT	ML 430 (00-05)	TEVES ESP 2
 163 ML-Class	ABS + TRACT. CONT	ML 500 (00-05)	TEVES ESP 1
 163 ML-Class	ABS + TRACT. CONT	ML 500 (00-05)	TEVES ESP 2
 163 ML-Class	ABS + TRACT. CONT	ML 55 AMG (00-05)	TEVES ESP 1
 163 ML-Class	ABS + TRACT. CONT	ML 55 AMG (00-05)	TEVES ESP 2
 163 ML-Class	AIRBAG	ML 230 (00-05)	TEMIC SRS
 163 ML-Class	AIRBAG	ML 270 CDI (00-05)	TEMIC SRS
 163 ML-Class	AIRBAG	ML 320 (00-05)	TEMIC SRS
 163 ML-Class	AIRBAG	ML 350 (00-05)	TEMIC SRS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 163 ML-Class	AIRBAG	ML 400 CDI (00-05)	TEMIC SRS
 163 ML-Class	AIRBAG	ML 430 (00-05)	TEMIC SRS
 163 ML-Class	AIRBAG	ML 500 (00-05)	TEMIC SRS
 163 ML-Class	AIRBAG	ML 55 AMG (00-05)	TEMIC SRS
 163 ML-Class	AUTOM. TRANSMISSI	ML 230 (.-05)	DELPHI EWM Selector Lever
 163 ML-Class	AUTOM. TRANSMISSI	ML 230 (.-05)	SIEMENS EGS 52
 163 ML-Class	AUTOM. TRANSMISSI	ML 270 CDI (.-05)	DELPHI EWM Selector Lever
 163 ML-Class	AUTOM. TRANSMISSI	ML 270 CDI (.-05)	SIEMENS EGS 52
 163 ML-Class	AUTOM. TRANSMISSI	ML 320 (.-05)	DELPHI EWM Selector Lever
 163 ML-Class	AUTOM. TRANSMISSI	ML 320 (.-05)	SIEMENS EGS 52
 163 ML-Class	AUTOM. TRANSMISSI	ML 350 (.-05)	DELPHI EWM Selector Lever
 163 ML-Class	AUTOM. TRANSMISSI	ML 350 (.-05)	SIEMENS EGS 52
 163 ML-Class	AUTOM. TRANSMISSI	ML 400 CDI (.-05)	DELPHI EWM Selector Lever
 163 ML-Class	AUTOM. TRANSMISSI	ML 400 CDI (.-05)	SIEMENS EGS 52
 163 ML-Class	AUTOM. TRANSMISSI	ML 430 (.-05)	DELPHI EWM Selector Lever
 163 ML-Class	AUTOM. TRANSMISSI	ML 430 (.-05)	SIEMENS EGS 52
 163 ML-Class	AUTOM. TRANSMISSI	ML 500 (.-05)	DELPHI EWM Selector Lever
 163 ML-Class	AUTOM. TRANSMISSI	ML 500 (.-05)	SIEMENS EGS 52
 163 ML-Class	AUTOM. TRANSMISSI	ML 55 AMG (.-05)	DELPHI EWM Selector Lever
 163 ML-Class	AUTOM. TRANSMISSI	ML 55 AMG (.-05)	SIEMENS EGS 52
 163 ML-Class	BRAKE POWER SUP	ML 230 (00-05)	TEVES BAS
 163 ML-Class	BRAKE POWER SUP	ML 270 CDI (00-05)	TEVES BAS
 163 ML-Class	BRAKE POWER SUP	ML 320 (00-05)	TEVES BAS
 163 ML-Class	BRAKE POWER SUP	ML 350 (00-05)	TEVES BAS
 163 ML-Class	BRAKE POWER SUP	ML 400 CDI (00-05)	TEVES BAS
 163 ML-Class	BRAKE POWER SUP	ML 430 (00-05)	TEVES BAS
 163 ML-Class	BRAKE POWER SUP	ML 500 (00-05)	TEVES BAS
 163 ML-Class	BRAKE POWER SUP	ML 55 AMG (00-05)	TEVES BAS
 163 ML-Class	CHASSIS NETWORK	ML 230 (00-05)	Kostal AAM
 163 ML-Class	CHASSIS NETWORK	ML 230 (00-05)	Kostal EAM
 163 ML-Class	CHASSIS NETWORK	ML 230 (02-05)	Kostal UBF
 163 ML-Class	CHASSIS NETWORK	ML 270 CDI (00-05)	Kostal AAM
 163 ML-Class	CHASSIS NETWORK	ML 270 CDI (00-05)	Kostal EAM
 163 ML-Class	CHASSIS NETWORK	ML 270 CDI (02-05)	Kostal UBF
 163 ML-Class	CHASSIS NETWORK	ML 320 (00-05)	Kostal AAM
 163 ML-Class	CHASSIS NETWORK	ML 320 (00-05)	Kostal EAM
 163 ML-Class	CHASSIS NETWORK	ML 320 (02-05)	Kostal UBF
 163 ML-Class	CHASSIS NETWORK	ML 350 (00-05)	Kostal AAM
 163 ML-Class	CHASSIS NETWORK	ML 350 (00-05)	Kostal EAM
 163 ML-Class	CHASSIS NETWORK	ML 350 (02-05)	Kostal UBF
 163 ML-Class	CHASSIS NETWORK	ML 400 CDI (00-05)	Kostal AAM
 163 ML-Class	CHASSIS NETWORK	ML 400 CDI (00-05)	Kostal EAM
 163 ML-Class	CHASSIS NETWORK	ML 400 CDI (02-05)	Kostal UBF
 163 ML-Class	CHASSIS NETWORK	ML 430 (00-05)	Kostal AAM
 163 ML-Class	CHASSIS NETWORK	ML 430 (00-05)	Kostal EAM
 163 ML-Class	CHASSIS NETWORK	ML 430 (02-05)	Kostal UBF
 163 ML-Class	CHASSIS NETWORK	ML 500 (00-05)	Kostal AAM
 163 ML-Class	CHASSIS NETWORK	ML 500 (00-05)	Kostal EAM
 163 ML-Class	CHASSIS NETWORK	ML 500 (02-05)	Kostal UBF
 163 ML-Class	CHASSIS NETWORK	ML 55 AMG (00-05)	Kostal AAM
 163 ML-Class	CHASSIS NETWORK	ML 55 AMG (00-05)	Kostal EAM
 163 ML-Class	CHASSIS NETWORK	ML 55 AMG (02-05)	Kostal UBF
 163 ML-Class	CLIMA	ML 230 (00-05)	HELLA KLA
 163 ML-Class	CLIMA	ML 270 CDI (00-05)	HELLA KLA
 163 ML-Class	CLIMA	ML 320 (00-05)	HELLA KLA
 163 ML-Class	CLIMA	ML 350 (00-05)	HELLA KLA
 163 ML-Class	CLIMA	ML 400 CDI (00-05)	HELLA KLA
 163 ML-Class	CLIMA	ML 430 (00-05)	HELLA KLA

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 163 ML-Class	CLIMA	ML 500 (00-05)	HELLA KLA
 163 ML-Class	CLIMA	ML 55 AMG (00-05)	HELLA KLA
 163 ML-Class	DASHBOARD	ML 230 (00-05)	VDO KIW
 163 ML-Class	DASHBOARD	ML 270 CDI (00-05)	VDO KIW
 163 ML-Class	DASHBOARD	ML 320 (00-05)	VDO KIW
 163 ML-Class	DASHBOARD	ML 350 (00-05)	VDO KIW
 163 ML-Class	DASHBOARD	ML 400 CDI (00-05)	VDO KIW
 163 ML-Class	DASHBOARD	ML 430 (00-05)	VDO KIW
 163 ML-Class	DASHBOARD	ML 500 (00-05)	VDO KIW
 163 ML-Class	DASHBOARD	ML 55 AMG (00-05)	VDO KIW
 163 ML-Class	ENGINE MANAGEME	ML 230 (01-05)	EOBD
 163 ML-Class	ENGINE MANAGEME	ML 270 CDI (01-05)	BOSCH EDC 15 C6 Common Rail CDI 2
 163 ML-Class	ENGINE MANAGEME	ML 270 CDI (05-..)	BOSCH EDC 15 Common Rail CDI 3
 163 ML-Class	ENGINE MANAGEME	ML 270 CDI 612 (98-00)	BOSCH EDC 15 C4 Common Rail
 163 ML-Class	ENGINE MANAGEME	ML 320 (..-99)	SIEMENS-VDO HFM SFI1
 163 ML-Class	ENGINE MANAGEME	ML 320 112 (..-99)	BOSCH Motronic ME 2.0
 163 ML-Class	ENGINE MANAGEME	ML 350 (01-05)	EOBD
 163 ML-Class	ENGINE MANAGEME	ML 400 CDI (04-05)	EOBD
 163 ML-Class	ENGINE MANAGEME	ML 430 113 (..-99)	SIEMENS-VDO HFM SFI1
 163 ML-Class	ENGINE MANAGEME	ML 500 (01-05)	EOBD
 163 ML-Class	ENGINE MANAGEME	ML 55 AMG (01-05)	EOBD
 163 ML-Class	IMMOBILIZER	ML 230 (00-05)	Kostal FBS
 163 ML-Class	IMMOBILIZER	ML 270 CDI (00-05)	Kostal FBS
 163 ML-Class	IMMOBILIZER	ML 320 (00-05)	Kostal FBS
 163 ML-Class	IMMOBILIZER	ML 350 (00-05)	Kostal FBS
 163 ML-Class	IMMOBILIZER	ML 400 CDI (00-05)	Kostal FBS
 163 ML-Class	IMMOBILIZER	ML 430 (00-05)	Kostal FBS
 163 ML-Class	IMMOBILIZER	ML 500 (00-05)	Kostal FBS
 163 ML-Class	IMMOBILIZER	ML 55 AMG (00-05)	Kostal FBS
 163 ML-Class	MAINTENANCE	ML 230 (00-05)	TEVES ESP 1
 163 ML-Class	MAINTENANCE	ML 230 (00-05)	TEVES ESP 2
 163 ML-Class	MAINTENANCE	ML 230 (00-05)	VDO KIW
 163 ML-Class	MAINTENANCE	ML 230 (00-05)	VDO KIW
 163 ML-Class	MAINTENANCE	ML 230 (99-03)	VDO/Marelli MANUAL
 163 ML-Class	MAINTENANCE	ML 270 CDI (00-05)	TEVES ESP 1
 163 ML-Class	MAINTENANCE	ML 270 CDI (00-05)	TEVES ESP 2
 163 ML-Class	MAINTENANCE	ML 270 CDI (00-05)	VDO KIW
 163 ML-Class	MAINTENANCE	ML 270 CDI (00-05)	VDO KIW
 163 ML-Class	MAINTENANCE	ML 270 CDI (99-03)	VDO/Marelli MANUAL
 163 ML-Class	MAINTENANCE	ML 320 (00-05)	TEVES ESP 1
 163 ML-Class	MAINTENANCE	ML 320 (00-05)	TEVES ESP 2
 163 ML-Class	MAINTENANCE	ML 320 (00-05)	VDO KIW
 163 ML-Class	MAINTENANCE	ML 320 (00-05)	VDO KIW
 163 ML-Class	MAINTENANCE	ML 320 (99-03)	VDO/Marelli MANUAL
 163 ML-Class	MAINTENANCE	ML 350 (00-05)	TEVES ESP 1
 163 ML-Class	MAINTENANCE	ML 350 (00-05)	TEVES ESP 2
 163 ML-Class	MAINTENANCE	ML 350 (00-05)	VDO KIW
 163 ML-Class	MAINTENANCE	ML 350 (00-05)	VDO KIW
 163 ML-Class	MAINTENANCE	ML 350 (99-03)	VDO/Marelli MANUAL
 163 ML-Class	MAINTENANCE	ML 400 CDI (00-05)	TEVES ESP 1
 163 ML-Class	MAINTENANCE	ML 400 CDI (00-05)	TEVES ESP 2
 163 ML-Class	MAINTENANCE	ML 400 CDI (00-05)	VDO KIW
 163 ML-Class	MAINTENANCE	ML 400 CDI (00-05)	VDO KIW
 163 ML-Class	MAINTENANCE	ML 400 CDI (99-03)	VDO/Marelli MANUAL
 163 ML-Class	MAINTENANCE	ML 430 (00-05)	TEVES ESP 1
 163 ML-Class	MAINTENANCE	ML 430 (00-05)	TEVES ESP 2
 163 ML-Class	MAINTENANCE	ML 430 (00-05)	VDO KIW
 163 ML-Class	MAINTENANCE	ML 430 (00-05)	VDO KIW

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 163 ML-Class	MAINTENANCE	ML 430 (99-03)	VDO/Marelli MANUAL
 163 ML-Class	MAINTENANCE	ML 500 (00-05)	TEVES ESP 1
 163 ML-Class	MAINTENANCE	ML 500 (00-05)	TEVES ESP 2
 163 ML-Class	MAINTENANCE	ML 500 (00-05)	VDO KIW
 163 ML-Class	MAINTENANCE	ML 500 (00-05)	VDO KIW
 163 ML-Class	MAINTENANCE	ML 500 (99-03)	VDO/Marelli MANUAL
 163 ML-Class	MAINTENANCE	ML 55 AMG (00-05)	TEVES ESP 1
 163 ML-Class	MAINTENANCE	ML 55 AMG (00-05)	TEVES ESP 2
 163 ML-Class	MAINTENANCE	ML 55 AMG (00-05)	VDO KIW
 163 ML-Class	MAINTENANCE	ML 55 AMG (00-05)	VDO KIW
 163 ML-Class	MAINTENANCE	ML 55 AMG (99-03)	VDO/Marelli MANUAL
 163 ML-Class	POWER BRAKE	ML 230 (00-05)	HELLA UP
 163 ML-Class	POWER BRAKE	ML 270 CDI (00-05)	HELLA UP
 163 ML-Class	POWER BRAKE	ML 320 (00-05)	HELLA UP
 163 ML-Class	POWER BRAKE	ML 350 (00-05)	HELLA UP
 163 ML-Class	POWER BRAKE	ML 400 CDI (00-05)	HELLA UP
 163 ML-Class	POWER BRAKE	ML 430 (00-05)	HELLA UP
 163 ML-Class	POWER BRAKE	ML 500 (00-05)	HELLA UP
 163 ML-Class	POWER BRAKE	ML 55 AMG (00-05)	HELLA UP
 163 ML-Class	SERVICE LIGHT RES	ML 230 (99-03)	VDO/Marelli MANUAL
 163 ML-Class	SERVICE LIGHT RES	ML 270 CDI (99-03)	VDO/Marelli MANUAL
 163 ML-Class	SERVICE LIGHT RES	ML 320 (99-03)	VDO/Marelli MANUAL
 163 ML-Class	SERVICE LIGHT RES	ML 350 (99-03)	VDO/Marelli MANUAL
 163 ML-Class	SERVICE LIGHT RES	ML 400 CDI (99-03)	VDO/Marelli MANUAL
 163 ML-Class	SERVICE LIGHT RES	ML 430 (99-03)	VDO/Marelli MANUAL
 163 ML-Class	SERVICE LIGHT RES	ML 500 (99-03)	VDO/Marelli MANUAL
 163 ML-Class	SERVICE LIGHT RES	ML 55 AMG (99-03)	VDO/Marelli MANUAL
 163 ML-Class	TRACTION CONTROL	ML 230 (.-05)	BorgWarner VG
 163 ML-Class	TRACTION CONTROL	ML 270 CDI (.-05)	BorgWarner VG
 163 ML-Class	TRACTION CONTROL	ML 320 (.-05)	BorgWarner VG
 163 ML-Class	TRACTION CONTROL	ML 350 (.-05)	BorgWarner VG
 163 ML-Class	TRACTION CONTROL	ML 400 CDI (.-05)	BorgWarner VG
 163 ML-Class	TRACTION CONTROL	ML 430 (.-05)	BorgWarner VG
 163 ML-Class	TRACTION CONTROL	ML 500 (.-05)	BorgWarner VG
 163 ML-Class	TRACTION CONTROL	ML 55 AMG (.-05)	BorgWarner VG
 164 ML-Class	ABS + TRACT. CONT	ML 280 CDI	TEVES ESP
 164 ML-Class	ABS + TRACT. CONT	ML 300 CDI	TEVES ESP
 164 ML-Class	ABS + TRACT. CONT	ML 320 CDI	TEVES ESP
 164 ML-Class	ABS + TRACT. CONT	ML 350	TEVES ESP
 164 ML-Class	ABS + TRACT. CONT	ML 350 CDI	TEVES ESP
 164 ML-Class	ABS + TRACT. CONT	ML 420 CDI	TEVES ESP
 164 ML-Class	ABS + TRACT. CONT	ML 450 CDI	TEVES ESP
 164 ML-Class	ABS + TRACT. CONT	ML 500	TEVES ESP
 164 ML-Class	ABS + TRACT. CONT	ML 63 AMG	TEVES ESP
 164 ML-Class	AIRBAG	ML 280 CDI	BOSCH SRS
 164 ML-Class	AIRBAG	ML 300 CDI	BOSCH SRS
 164 ML-Class	AIRBAG	ML 320 CDI	BOSCH SRS
 164 ML-Class	AIRBAG	ML 350	BOSCH SRS
 164 ML-Class	AIRBAG	ML 350 CDI	BOSCH SRS
 164 ML-Class	AIRBAG	ML 420 CDI	BOSCH SRS
 164 ML-Class	AIRBAG	ML 450 CDI	BOSCH SRS
 164 ML-Class	AIRBAG	ML 500	BOSCH SRS
 164 ML-Class	AIRBAG	ML 63 AMG	BOSCH SRS
 164 ML-Class	AUTOM. TRANSMISSI	ML 280 CDI	Siemens EGS 7 Gtronic 722.9
 164 ML-Class	AUTOM. TRANSMISSI	ML 300 CDI	Siemens EGS 7 Gtronic 722.9
 164 ML-Class	AUTOM. TRANSMISSI	ML 320 CDI	Siemens EGS 7 Gtronic 722.9
 164 ML-Class	AUTOM. TRANSMISSI	ML 350	Siemens EGS 7 Gtronic 722.9
 164 ML-Class	AUTOM. TRANSMISSI	ML 350 CDI	Siemens EGS 7 Gtronic 722.9

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 164 ML-Class	AUTOM. TRANSMISSI	ML 420 CDI	Siemens EGS 7 Gtronic 722.9
 164 ML-Class	AUTOM. TRANSMISSI	ML 450 CDI	Siemens EGS 7 Gtronic 722.9
 164 ML-Class	AUTOM. TRANSMISSI	ML 500	Siemens EGS 7 Gtronic 722.9
 164 ML-Class	AUTOM. TRANSMISSI	ML 63 AMG	Siemens EGS 7 Gtronic 722.9
 164 ML-Class	CLIMA	ML 280 CDI	Hella KLA Klimautomatik
 164 ML-Class	CLIMA	ML 300 CDI	Hella KLA Klimautomatik
 164 ML-Class	CLIMA	ML 320 CDI	Hella KLA Klimautomatik
 164 ML-Class	CLIMA	ML 350	Hella KLA Klimautomatik
 164 ML-Class	CLIMA	ML 350 CDI	Hella KLA Klimautomatik
 164 ML-Class	CLIMA	ML 420 CDI	Hella KLA Klimautomatik
 164 ML-Class	CLIMA	ML 450 CDI	Hella KLA Klimautomatik
 164 ML-Class	CLIMA	ML 500	Hella KLA Klimautomatik
 164 ML-Class	CLIMA	ML 63 AMG	Hella KLA Klimautomatik
 164 ML-Class	DASHBOARD	ML 280 CDI	VDO KI
 164 ML-Class	DASHBOARD	ML 300 CDI	VDO KI
 164 ML-Class	DASHBOARD	ML 320 CDI	VDO KI
 164 ML-Class	DASHBOARD	ML 350	VDO KI
 164 ML-Class	DASHBOARD	ML 350 CDI	VDO KI
 164 ML-Class	DASHBOARD	ML 420 CDI	VDO KI
 164 ML-Class	DASHBOARD	ML 450 CDI	VDO KI
 164 ML-Class	DASHBOARD	ML 500	VDO KI
 164 ML-Class	DASHBOARD	ML 63 AMG	VDO KI
 164 ML-Class	ENGINE MANAGEME	ML 280 CDI	EOBD
 164 ML-Class	ENGINE MANAGEME	ML 300 CDI	EOBD
 164 ML-Class	ENGINE MANAGEME	ML 320 CDI (07-..)	BOSCH EDC Common Rail CDI 4
 164 ML-Class	ENGINE MANAGEME	ML 350	EOBD
 164 ML-Class	ENGINE MANAGEME	ML 350 CDI	EOBD
 164 ML-Class	ENGINE MANAGEME	ML 420 CDI	EOBD
 164 ML-Class	ENGINE MANAGEME	ML 450 CDI	EOBD
 164 ML-Class	ENGINE MANAGEME	ML 500	EOBD
 164 ML-Class	ENGINE MANAGEME	ML 63 AMG	EOBD
 164 ML-Class	GEARBOX MANAGEM	ML 280 CDI	Siemens ISM
 164 ML-Class	GEARBOX MANAGEM	ML 300 CDI	Siemens ISM
 164 ML-Class	GEARBOX MANAGEM	ML 320 CDI	Siemens ISM
 164 ML-Class	GEARBOX MANAGEM	ML 350	Siemens ISM
 164 ML-Class	GEARBOX MANAGEM	ML 350 CDI	Siemens ISM
 164 ML-Class	GEARBOX MANAGEM	ML 420 CDI	Siemens ISM
 164 ML-Class	GEARBOX MANAGEM	ML 450 CDI	Siemens ISM
 164 ML-Class	GEARBOX MANAGEM	ML 500	Siemens ISM
 164 ML-Class	GEARBOX MANAGEM	ML 63 AMG	Siemens ISM
 164 ML-Class	MAINTENANCE	ML 280 CDI	TEVES ESP
 164 ML-Class	MAINTENANCE	ML 280 CDI	VDO Assyst Plus
 164 ML-Class	MAINTENANCE	ML 280 CDI	VDO Assyst Plus
 164 ML-Class	MAINTENANCE	ML 280 CDI	VDO/Marelli/xx MANUAL
 164 ML-Class	MAINTENANCE	ML 300 CDI	TEVES ESP
 164 ML-Class	MAINTENANCE	ML 300 CDI	VDO Assyst Plus
 164 ML-Class	MAINTENANCE	ML 300 CDI	VDO Assyst Plus
 164 ML-Class	MAINTENANCE	ML 300 CDI	VDO/Marelli/xx MANUAL
 164 ML-Class	MAINTENANCE	ML 320 CDI	TEVES ESP
 164 ML-Class	MAINTENANCE	ML 320 CDI	VDO Assyst Plus
 164 ML-Class	MAINTENANCE	ML 320 CDI	VDO Assyst Plus
 164 ML-Class	MAINTENANCE	ML 320 CDI	VDO/Marelli/xx MANUAL
 164 ML-Class	MAINTENANCE	ML 320 CDI (07-..)	BOSCH EDC Common Rail CDI 4
 164 ML-Class	MAINTENANCE	ML 320 CDI (07-..)	BOSCH EDC Common Rail CDI 4
 164 ML-Class	MAINTENANCE	ML 350	TEVES ESP
 164 ML-Class	MAINTENANCE	ML 350	VDO Assyst Plus
 164 ML-Class	MAINTENANCE	ML 350	VDO Assyst Plus
 164 ML-Class	MAINTENANCE	ML 350	VDO/Marelli/xx MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 164 ML-Class	MAINTENANCE	ML 350 CDI	TEVES ESP
 164 ML-Class	MAINTENANCE	ML 350 CDI	VDO Assyst Plus
 164 ML-Class	MAINTENANCE	ML 350 CDI	VDO Assyst Plus
 164 ML-Class	MAINTENANCE	ML 350 CDI	VDO/Marelli/xx MANUAL
 164 ML-Class	MAINTENANCE	ML 420 CDI	TEVES ESP
 164 ML-Class	MAINTENANCE	ML 420 CDI	VDO Assyst Plus
 164 ML-Class	MAINTENANCE	ML 420 CDI	VDO Assyst Plus
 164 ML-Class	MAINTENANCE	ML 420 CDI	VDO/Marelli/xx MANUAL
 164 ML-Class	MAINTENANCE	ML 450 CDI	TEVES ESP
 164 ML-Class	MAINTENANCE	ML 450 CDI	VDO Assyst Plus
 164 ML-Class	MAINTENANCE	ML 450 CDI	VDO Assyst Plus
 164 ML-Class	MAINTENANCE	ML 450 CDI	VDO/Marelli/xx MANUAL
 164 ML-Class	MAINTENANCE	ML 500	TEVES ESP
 164 ML-Class	MAINTENANCE	ML 500	VDO Assyst Plus
 164 ML-Class	MAINTENANCE	ML 500	VDO Assyst Plus
 164 ML-Class	MAINTENANCE	ML 500	VDO/Marelli/xx MANUAL
 164 ML-Class	MAINTENANCE	ML 63 AMG	TEVES ESP
 164 ML-Class	MAINTENANCE	ML 63 AMG	VDO Assyst Plus
 164 ML-Class	MAINTENANCE	ML 63 AMG	VDO Assyst Plus
 164 ML-Class	MAINTENANCE	ML 63 AMG	VDO/Marelli/xx MANUAL
 164 ML-Class	SERVICE LIGHT RES	ML 280 CDI	VDO Assyst Plus
 164 ML-Class	SERVICE LIGHT RES	ML 280 CDI	VDO/Marelli/xx MANUAL
 164 ML-Class	SERVICE LIGHT RES	ML 300 CDI	VDO Assyst Plus
 164 ML-Class	SERVICE LIGHT RES	ML 300 CDI	VDO/Marelli/xx MANUAL
 164 ML-Class	SERVICE LIGHT RES	ML 320 CDI	VDO Assyst Plus
 164 ML-Class	SERVICE LIGHT RES	ML 320 CDI	VDO/Marelli/xx MANUAL
 164 ML-Class	SERVICE LIGHT RES	ML 350	VDO Assyst Plus
 164 ML-Class	SERVICE LIGHT RES	ML 350	VDO/Marelli/xx MANUAL
 164 ML-Class	SERVICE LIGHT RES	ML 350 CDI	VDO Assyst Plus
 164 ML-Class	SERVICE LIGHT RES	ML 350 CDI	VDO/Marelli/xx MANUAL
 164 ML-Class	SERVICE LIGHT RES	ML 420 CDI	VDO Assyst Plus
 164 ML-Class	SERVICE LIGHT RES	ML 420 CDI	VDO/Marelli/xx MANUAL
 164 ML-Class	SERVICE LIGHT RES	ML 450 CDI	VDO Assyst Plus
 164 ML-Class	SERVICE LIGHT RES	ML 450 CDI	VDO/Marelli/xx MANUAL
 164 ML-Class	SERVICE LIGHT RES	ML 500	VDO Assyst Plus
 164 ML-Class	SERVICE LIGHT RES	ML 500	VDO/Marelli/xx MANUAL
 164 ML-Class	SERVICE LIGHT RES	ML 63 AMG	VDO Assyst Plus
 164 ML-Class	SERVICE LIGHT RES	ML 63 AMG	VDO/Marelli/xx MANUAL
 164 ML-Class	STEERING COLUMN	ML 280 CDI	KOSTAL MRM 7
 164 ML-Class	STEERING COLUMN	ML 300 CDI	KOSTAL MRM 7
 164 ML-Class	STEERING COLUMN	ML 320 CDI	KOSTAL MRM 7
 164 ML-Class	STEERING COLUMN	ML 350	KOSTAL MRM 7
 164 ML-Class	STEERING COLUMN	ML 350 CDI	KOSTAL MRM 7
 164 ML-Class	STEERING COLUMN	ML 420 CDI	KOSTAL MRM 7
 164 ML-Class	STEERING COLUMN	ML 450 CDI	KOSTAL MRM 7
 164 ML-Class	STEERING COLUMN	ML 500	KOSTAL MRM 7
 164 ML-Class	STEERING COLUMN	ML 63 AMG	KOSTAL MRM 7
 164 ML-Class	SUSPENSION CONTR	ML 280 CDI	Temic AIRmatic
 164 ML-Class	SUSPENSION CONTR	ML 300 CDI	Temic AIRmatic
 164 ML-Class	SUSPENSION CONTR	ML 320 CDI	Temic AIRmatic
 164 ML-Class	SUSPENSION CONTR	ML 350	Temic AIRmatic
 164 ML-Class	SUSPENSION CONTR	ML 350 CDI	Temic AIRmatic
 164 ML-Class	SUSPENSION CONTR	ML 420 CDI	Temic AIRmatic
 164 ML-Class	SUSPENSION CONTR	ML 450 CDI	Temic AIRmatic
 164 ML-Class	SUSPENSION CONTR	ML 500	Temic AIRmatic
 164 ML-Class	SUSPENSION CONTR	ML 63 AMG	Temic AIRmatic
 168 A-Class	ABS + TRACT. CONT	A 140	BOSCH ESP
 168 A-Class	ABS + TRACT. CONT	A 160	BOSCH ESP

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 168 A-Class	ABS + TRACT. CONT	A 160 CDI	BOSCH ESP
 168 A-Class	ABS + TRACT. CONT	A 170 CDI	BOSCH ESP
 168 A-Class	ABS + TRACT. CONT	A 190	BOSCH ESP
 168 A-Class	ABS + TRACT. CONT	A 210	BOSCH ESP
 168 A-Class	AIRBAG	A 140 (.-01)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 168 A-Class	AIRBAG	A 140 (.-01)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 168 A-Class	AIRBAG	A 160 (.-01)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 168 A-Class	AIRBAG	A 160 (.-01)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 168 A-Class	AIRBAG	A 160 CDI (.-01)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 168 A-Class	AIRBAG	A 160 CDI (.-01)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 168 A-Class	AIRBAG	A 170 CDI (.-01)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 168 A-Class	AIRBAG	A 170 CDI (.-01)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 168 A-Class	AIRBAG	A 190 (.-01)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 168 A-Class	AIRBAG	A 190 (.-01)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 168 A-Class	AIRBAG	A 210 (.-01)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 168 A-Class	AIRBAG	A 210 (.-01)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 168 A-Class	CENTRAL LOCKING	A 140 (.-00)	Siemens FFZ
 168 A-Class	CENTRAL LOCKING	A 160 (.-00)	Siemens FFZ
 168 A-Class	CENTRAL LOCKING	A 160 CDI (.-00)	Siemens FFZ
 168 A-Class	CENTRAL LOCKING	A 170 CDI (.-00)	Siemens FFZ
 168 A-Class	CENTRAL LOCKING	A 190 (.-00)	Siemens FFZ
 168 A-Class	CENTRAL LOCKING	A 210 (.-00)	Siemens FFZ
 168 A-Class	CHASSIS NETWORK	A 140 (.-01)	Kostal UBF
 168 A-Class	CHASSIS NETWORK	A 160 (.-01)	Kostal UBF
 168 A-Class	CHASSIS NETWORK	A 160 CDI (.-01)	Kostal UBF
 168 A-Class	CHASSIS NETWORK	A 170 CDI (.-01)	Kostal UBF
 168 A-Class	CHASSIS NETWORK	A 190 (.-01)	Kostal UBF
 168 A-Class	CHASSIS NETWORK	A 210 (.-01)	Kostal UBF
 168 A-Class	CLIMA	A 140 (00-05)	Kammerer TAU
 168 A-Class	CLIMA	A 160 (00-05)	Kammerer TAU
 168 A-Class	CLIMA	A 160 CDI (00-05)	Kammerer TAU
 168 A-Class	CLIMA	A 170 CDI (00-05)	Kammerer TAU
 168 A-Class	CLIMA	A 190 (00-05)	Kammerer TAU
 168 A-Class	CLIMA	A 210 (00-05)	Kammerer TAU
 168 A-Class	DASHBOARD	A 140 (00-05)	Marelli KI
 168 A-Class	DASHBOARD	A 160 (00-05)	Marelli KI
 168 A-Class	DASHBOARD	A 160 CDI (00-05)	Marelli KI
 168 A-Class	DASHBOARD	A 170 CDI (00-05)	Marelli KI
 168 A-Class	DASHBOARD	A 190 (00-05)	Marelli KI
 168 A-Class	DASHBOARD	A 210 (00-05)	Marelli KI
 168 A-Class	ENGINE MANAGEME	A 140 116 (.-99)	SIEMENS-VDO HFM SFI
 168 A-Class	ENGINE MANAGEME	A 140 166 (.-99)	BOSCH Motronic ME 2.0
 168 A-Class	ENGINE MANAGEME	A 140 166 (00-01)	EOBD
 168 A-Class	ENGINE MANAGEME	A 140 166 (98-..)	EOBD
 168 A-Class	ENGINE MANAGEME	A 160 116 (.-99)	SIEMENS-VDO HFM SFI1
 168 A-Class	ENGINE MANAGEME	A 160 166 (.-99)	BOSCH Motronic ME 2.0
 168 A-Class	ENGINE MANAGEME	A 160 CDI 668 (.-99)	BOSCH EDC 15 C4 Common Rail
 168 A-Class	ENGINE MANAGEME	A 170 CDI 668 (.-99)	BOSCH EDC 15 C4 Common Rail
 168 A-Class	ENGINE MANAGEME	A 190 (01-..)	EOBD
 168 A-Class	ENGINE MANAGEME	A 210 (01-..)	EOBD
 168 A-Class	GEARBOX MANAGEM	A 140 (.-01)	Siemens FGS
 168 A-Class	GEARBOX MANAGEM	A 160 (.-01)	Siemens FGS
 168 A-Class	GEARBOX MANAGEM	A 160 CDI (.-01)	Siemens FGS
 168 A-Class	GEARBOX MANAGEM	A 170 CDI (.-01)	Siemens FGS
 168 A-Class	GEARBOX MANAGEM	A 190 (.-01)	Siemens FGS
 168 A-Class	GEARBOX MANAGEM	A 210 (.-01)	Siemens FGS
 168 A-Class	LEFT FRONT DOOR	A 140 (.-00)	Kostal TGS VL
 168 A-Class	LEFT FRONT DOOR	A 160 (.-00)	Kostal TGS VL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 168 A-Class	LEFT FRONT DOOR	A 160 CDI (.-00)	Kostal TGS VL
 168 A-Class	LEFT FRONT DOOR	A 170 CDI (.-00)	Kostal TGS VL
 168 A-Class	LEFT FRONT DOOR	A 190 (.-00)	Kostal TGS VL
 168 A-Class	LEFT FRONT DOOR	A 210 (.-00)	Kostal TGS VL
 168 A-Class	LEFT REAR DOOR	A 140 (.-00)	Kostal TGS PS
 168 A-Class	LEFT REAR DOOR	A 160 (.-00)	Kostal TGS PS
 168 A-Class	LEFT REAR DOOR	A 160 CDI (.-00)	Kostal TGS PS
 168 A-Class	LEFT REAR DOOR	A 170 CDI (.-00)	Kostal TGS PS
 168 A-Class	LEFT REAR DOOR	A 190 (.-00)	Kostal TGS PS
 168 A-Class	LEFT REAR DOOR	A 210 (.-00)	Kostal TGS PS
 168 A-Class	MAINTENANCE	A 140 (99-03)	VDO/Marelli MANUAL
 168 A-Class	MAINTENANCE	A 160 (99-03)	VDO/Marelli MANUAL
 168 A-Class	MAINTENANCE	A 160 CDI (99-03)	VDO/Marelli MANUAL
 168 A-Class	MAINTENANCE	A 170 CDI (99-03)	VDO/Marelli MANUAL
 168 A-Class	MAINTENANCE	A 190 (99-03)	VDO/Marelli MANUAL
 168 A-Class	MAINTENANCE	A 210 (99-03)	VDO/Marelli MANUAL
 168 A-Class	RATIO SEL. MANAGE	A 140 (.-01)	Kostal GEM
 168 A-Class	RATIO SEL. MANAGE	A 160 (.-01)	Kostal GEM
 168 A-Class	RATIO SEL. MANAGE	A 160 CDI (.-01)	Kostal GEM
 168 A-Class	RATIO SEL. MANAGE	A 170 CDI (.-01)	Kostal GEM
 168 A-Class	RATIO SEL. MANAGE	A 190 (.-01)	Kostal GEM
 168 A-Class	RATIO SEL. MANAGE	A 210 (.-01)	Kostal GEM
 168 A-Class	RIGHT FRONT DOOR	A 140 (.-00)	Kostal TGS VR
 168 A-Class	RIGHT FRONT DOOR	A 160 (.-00)	Kostal TGS VR
 168 A-Class	RIGHT FRONT DOOR	A 160 CDI (.-00)	Kostal TGS VR
 168 A-Class	RIGHT FRONT DOOR	A 170 CDI (.-00)	Kostal TGS VR
 168 A-Class	RIGHT FRONT DOOR	A 190 (.-00)	Kostal TGS VR
 168 A-Class	RIGHT FRONT DOOR	A 210 (.-00)	Kostal TGS VR
 168 A-Class	RIGHT REAR DOOR	A 140 (.-00)	Kostal TGS PD
 168 A-Class	RIGHT REAR DOOR	A 160 (.-00)	Kostal TGS PD
 168 A-Class	RIGHT REAR DOOR	A 160 CDI (.-00)	Kostal TGS PD
 168 A-Class	RIGHT REAR DOOR	A 170 CDI (.-00)	Kostal TGS PD
 168 A-Class	RIGHT REAR DOOR	A 190 (.-00)	Kostal TGS PD
 168 A-Class	RIGHT REAR DOOR	A 210 (.-00)	Kostal TGS PD
 168 A-Class	SERVICE LIGHT RES	A 140 (99-03)	VDO/Marelli MANUAL
 168 A-Class	SERVICE LIGHT RES	A 160 (99-03)	VDO/Marelli MANUAL
 168 A-Class	SERVICE LIGHT RES	A 160 CDI (99-03)	VDO/Marelli MANUAL
 168 A-Class	SERVICE LIGHT RES	A 170 CDI (99-03)	VDO/Marelli MANUAL
 168 A-Class	SERVICE LIGHT RES	A 190 (99-03)	VDO/Marelli MANUAL
 168 A-Class	SERVICE LIGHT RES	A 210 (99-03)	VDO/Marelli MANUAL
 169 A-Class	ABS + TRACT. CONT	A 150 (04-..)	BOSCH ABS/ESP
 169 A-Class	ABS + TRACT. CONT	A 160 (04-..)	BOSCH ABS/ESP
 169 A-Class	ABS + TRACT. CONT	A 160 CDI (04-..)	BOSCH ABS/ESP
 169 A-Class	ABS + TRACT. CONT	A 170 (04-..)	BOSCH ABS/ESP
 169 A-Class	ABS + TRACT. CONT	A 180 (04-..)	BOSCH ABS/ESP
 169 A-Class	ABS + TRACT. CONT	A 180 CDI (04-..)	BOSCH ABS/ESP
 169 A-Class	ABS + TRACT. CONT	A 200 (04-..)	BOSCH ABS/ESP
 169 A-Class	ABS + TRACT. CONT	A 200 CDI (04-..)	BOSCH ABS/ESP
 169 A-Class	ABS + TRACT. CONT	A 200 Turbo (04-..)	BOSCH ABS/ESP
 169 A-Class	AIRBAG	A 150 (04-..)	TRW AirBag
 169 A-Class	AIRBAG	A 160 (04-..)	TRW AirBag
 169 A-Class	AIRBAG	A 160 CDI (04-..)	TRW AirBag
 169 A-Class	AIRBAG	A 170 (04-..)	TRW AirBag
 169 A-Class	AIRBAG	A 180 (04-..)	TRW AirBag
 169 A-Class	AIRBAG	A 180 CDI (04-..)	TRW AirBag
 169 A-Class	AIRBAG	A 200 (04-..)	TRW AirBag
 169 A-Class	AIRBAG	A 200 CDI (04-..)	TRW AirBag
 169 A-Class	AIRBAG	A 200 Turbo (04-..)	TRW AirBag

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 169 A-Class	AUTOM. TRANSMISSI	A 150	DELPHI EWM Selector Lever
 169 A-Class	AUTOM. TRANSMISSI	A 150 (04-..)	TEMIC FCVT
 169 A-Class	AUTOM. TRANSMISSI	A 160	DELPHI EWM Selector Lever
 169 A-Class	AUTOM. TRANSMISSI	A 160 (04-..)	TEMIC FCVT
 169 A-Class	AUTOM. TRANSMISSI	A 160 CDI	DELPHI EWM Selector Lever
 169 A-Class	AUTOM. TRANSMISSI	A 160 CDI (04-..)	TEMIC FCVT
 169 A-Class	AUTOM. TRANSMISSI	A 170	DELPHI EWM Selector Lever
 169 A-Class	AUTOM. TRANSMISSI	A 170 (04-..)	TEMIC FCVT
 169 A-Class	AUTOM. TRANSMISSI	A 180	DELPHI EWM Selector Lever
 169 A-Class	AUTOM. TRANSMISSI	A 180 (04-..)	TEMIC FCVT
 169 A-Class	AUTOM. TRANSMISSI	A 180 CDI	DELPHI EWM Selector Lever
 169 A-Class	AUTOM. TRANSMISSI	A 180 CDI (04-..)	TEMIC FCVT
 169 A-Class	AUTOM. TRANSMISSI	A 200	DELPHI EWM Selector Lever
 169 A-Class	AUTOM. TRANSMISSI	A 200 (04-..)	TEMIC FCVT
 169 A-Class	AUTOM. TRANSMISSI	A 200 CDI	DELPHI EWM Selector Lever
 169 A-Class	AUTOM. TRANSMISSI	A 200 CDI (04-..)	TEMIC FCVT
 169 A-Class	AUTOM. TRANSMISSI	A 200 Turbo	DELPHI EWM Selector Lever
 169 A-Class	AUTOM. TRANSMISSI	A 200 Turbo (04-..)	TEMIC FCVT
 169 A-Class	CHASSIS NETWORK	A 150 (04-..)	SAM-V
 169 A-Class	CHASSIS NETWORK	A 160 (04-..)	SAM-V
 169 A-Class	CHASSIS NETWORK	A 160 CDI (04-..)	SAM-V
 169 A-Class	CHASSIS NETWORK	A 170 (04-..)	SAM-V
 169 A-Class	CHASSIS NETWORK	A 180 (04-..)	SAM-V
 169 A-Class	CHASSIS NETWORK	A 180 CDI (04-..)	SAM-V
 169 A-Class	CHASSIS NETWORK	A 200 (04-..)	SAM-V
 169 A-Class	CHASSIS NETWORK	A 200 CDI (04-..)	SAM-V
 169 A-Class	CHASSIS NETWORK	A 200 Turbo (04-..)	SAM-V
 169 A-Class	CLIMA	A 150 (04-..)	VALEO Klimautomatik
 169 A-Class	CLIMA	A 150 (06-..)	VALEO KLA
 169 A-Class	CLIMA	A 160 (04-..)	VALEO Klimautomatik
 169 A-Class	CLIMA	A 160 (06-..)	VALEO KLA
 169 A-Class	CLIMA	A 160 CDI (04-..)	VALEO Klimautomatik
 169 A-Class	CLIMA	A 160 CDI (06-..)	VALEO KLA
 169 A-Class	CLIMA	A 170 (04-..)	VALEO Klimautomatik
 169 A-Class	CLIMA	A 170 (06-..)	VALEO KLA
 169 A-Class	CLIMA	A 180 (04-..)	VALEO Klimautomatik
 169 A-Class	CLIMA	A 180 (06-..)	VALEO KLA
 169 A-Class	CLIMA	A 180 CDI (04-..)	VALEO Klimautomatik
 169 A-Class	CLIMA	A 180 CDI (06-..)	VALEO KLA
 169 A-Class	CLIMA	A 200 (04-..)	VALEO Klimautomatik
 169 A-Class	CLIMA	A 200 (06-..)	VALEO KLA
 169 A-Class	CLIMA	A 200 CDI (04-..)	VALEO Klimautomatik
 169 A-Class	CLIMA	A 200 CDI (06-..)	VALEO KLA
 169 A-Class	CLIMA	A 200 Turbo (04-..)	VALEO Klimautomatik
 169 A-Class	CLIMA	A 200 Turbo (06-..)	VALEO KLA
 169 A-Class	DASHBOARD	A 150 (04-05)	BOSCH Kombi KI
 169 A-Class	DASHBOARD	A 150 (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	DASHBOARD	A 160 (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	DASHBOARD	A 160 CDI (04-05)	BOSCH Kombi KI
 169 A-Class	DASHBOARD	A 160 CDI (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	DASHBOARD	A 170 (04-05)	BOSCH Kombi KI
 169 A-Class	DASHBOARD	A 170 (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	DASHBOARD	A 180 (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	DASHBOARD	A 180 CDI (04-05)	BOSCH Kombi KI
 169 A-Class	DASHBOARD	A 180 CDI (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	DASHBOARD	A 200 (04-05)	BOSCH Kombi KI
 169 A-Class	DASHBOARD	A 200 (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	DASHBOARD	A 200 CDI (04-05)	BOSCH Kombi KI

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 169 A-Class	DASHBOARD	A 200 CDI (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	DASHBOARD	A 200 Turbo (04-05)	BOSCH Kombi KI
 169 A-Class	DASHBOARD	A 200 Turbo (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	ELECTRIC STEERING	A 150 (04-..)	KOYO EPS
 169 A-Class	ELECTRIC STEERING	A 160 (04-..)	KOYO EPS
 169 A-Class	ELECTRIC STEERING	A 160 CDI (04-..)	KOYO EPS
 169 A-Class	ELECTRIC STEERING	A 170 (04-..)	KOYO EPS
 169 A-Class	ELECTRIC STEERING	A 180 (04-..)	KOYO EPS
 169 A-Class	ELECTRIC STEERING	A 180 CDI (04-..)	KOYO EPS
 169 A-Class	ELECTRIC STEERING	A 200 (04-..)	KOYO EPS
 169 A-Class	ELECTRIC STEERING	A 200 CDI (04-..)	KOYO EPS
 169 A-Class	ELECTRIC STEERING	A 200 Turbo (04-..)	KOYO EPS
 169 A-Class	ENGINE MANAGEME	A 150 (04-..)	SIEMENS SIM 266
 169 A-Class	ENGINE MANAGEME	A 160 (09-..)	EOBD
 169 A-Class	ENGINE MANAGEME	A 160 CDI (04-..)	BOSCH EDC Common Rail
 169 A-Class	ENGINE MANAGEME	A 170 (04-..)	SIEMENS MPI M60G70
 169 A-Class	ENGINE MANAGEME	A 180 (09-..)	EOBD
 169 A-Class	ENGINE MANAGEME	A 180 CDI (04-..)	BOSCH EDC Common Rail
 169 A-Class	ENGINE MANAGEME	A 200 (04-..)	EOBD
 169 A-Class	ENGINE MANAGEME	A 200 CDI (04-..)	BOSCH EDC Common Rail
 169 A-Class	ENGINE MANAGEME	A 200 Turbo (04-..)	EOBD
 169 A-Class	IGNITION SWITCH	A 150 (04-..)	Kostal EZS
 169 A-Class	IGNITION SWITCH	A 160 (04-..)	Kostal EZS
 169 A-Class	IGNITION SWITCH	A 160 CDI (04-..)	Kostal EZS
 169 A-Class	IGNITION SWITCH	A 170 (04-..)	Kostal EZS
 169 A-Class	IGNITION SWITCH	A 180 (04-..)	Kostal EZS
 169 A-Class	IGNITION SWITCH	A 180 CDI (04-..)	Kostal EZS
 169 A-Class	IGNITION SWITCH	A 200 (04-..)	Kostal EZS
 169 A-Class	IGNITION SWITCH	A 200 CDI (04-..)	Kostal EZS
 169 A-Class	IGNITION SWITCH	A 200 Turbo (04-..)	Kostal EZS
 169 A-Class	LEFT FRONT DOOR	A 150 (06-..)	KOSTAL TSG-VL
 169 A-Class	LEFT FRONT DOOR	A 160 (06-..)	KOSTAL TSG-VL
 169 A-Class	LEFT FRONT DOOR	A 160 CDI (06-..)	KOSTAL TSG-VL
 169 A-Class	LEFT FRONT DOOR	A 170 (06-..)	KOSTAL TSG-VL
 169 A-Class	LEFT FRONT DOOR	A 180 (06-..)	KOSTAL TSG-VL
 169 A-Class	LEFT FRONT DOOR	A 180 CDI (06-..)	KOSTAL TSG-VL
 169 A-Class	LEFT FRONT DOOR	A 200 (06-..)	KOSTAL TSG-VL
 169 A-Class	LEFT FRONT DOOR	A 200 CDI (06-..)	KOSTAL TSG-VL
 169 A-Class	LEFT FRONT DOOR	A 200 Turbo (06-..)	KOSTAL TSG-VL
 169 A-Class	MAINTENANCE	A 150 (..-05)	VDO Assyst
 169 A-Class	MAINTENANCE	A 150 (..-05)	VDO Assyst
 169 A-Class	MAINTENANCE	A 150 (..-05)	VDO Assyst
 169 A-Class	MAINTENANCE	A 150 (..-05)	VDO Assyst Plus
 169 A-Class	MAINTENANCE	A 150 (..-05)	VDO Assyst Plus
 169 A-Class	MAINTENANCE	A 150 (..-05)	VDO Assyst Plus
 169 A-Class	MAINTENANCE	A 150 (04-..)	KOYO EPS
 169 A-Class	MAINTENANCE	A 150 (04-05)	MANUAL
 169 A-Class	MAINTENANCE	A 150 (06-..)	BOSCH Assyst/Assyst Plus
 169 A-Class	MAINTENANCE	A 150 (06-..)	BOSCH Assyst/Assyst Plus
 169 A-Class	MAINTENANCE	A 150 (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	MAINTENANCE	A 150 (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	MAINTENANCE	A 150 (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	MAINTENANCE	A 150 (06-..)	MANUAL
 169 A-Class	MAINTENANCE	A 160 (04-..)	KOYO EPS
 169 A-Class	MAINTENANCE	A 160 (06-..)	BOSCH Assyst/Assyst Plus
 169 A-Class	MAINTENANCE	A 160 (06-..)	BOSCH Assyst/Assyst Plus
 169 A-Class	MAINTENANCE	A 160 (06-..)	BOSCH Kombi KIW + Service

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 169 A-Class	MAINTENANCE	A 160 (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	MAINTENANCE	A 160 (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	MAINTENANCE	A 160 (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	MAINTENANCE	A 160 (06-..)	MANUAL
 169 A-Class	MAINTENANCE	A 160 CDI (..-05)	VDO Assyst
 169 A-Class	MAINTENANCE	A 160 CDI (..-05)	VDO Assyst
 169 A-Class	MAINTENANCE	A 160 CDI (..-05)	VDO Assyst
 169 A-Class	MAINTENANCE	A 160 CDI (..-05)	VDO Assyst Plus
 169 A-Class	MAINTENANCE	A 160 CDI (..-05)	VDO Assyst Plus
 169 A-Class	MAINTENANCE	A 160 CDI (..-05)	VDO Assyst Plus
 169 A-Class	MAINTENANCE	A 160 CDI (04-..)	KOYO EPS
 169 A-Class	MAINTENANCE	A 160 CDI (04-05)	MANUAL
 169 A-Class	MAINTENANCE	A 160 CDI (06-..)	BOSCH Assyst/Assyst Plus
 169 A-Class	MAINTENANCE	A 160 CDI (06-..)	BOSCH Assyst/Assyst Plus
 169 A-Class	MAINTENANCE	A 160 CDI (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	MAINTENANCE	A 160 CDI (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	MAINTENANCE	A 160 CDI (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	MAINTENANCE	A 160 CDI (06-..)	MANUAL
 169 A-Class	MAINTENANCE	A 170 (..-05)	VDO Assyst
 169 A-Class	MAINTENANCE	A 170 (..-05)	VDO Assyst
 169 A-Class	MAINTENANCE	A 170 (..-05)	VDO Assyst
 169 A-Class	MAINTENANCE	A 170 (..-05)	VDO Assyst Plus
 169 A-Class	MAINTENANCE	A 170 (..-05)	VDO Assyst Plus
 169 A-Class	MAINTENANCE	A 170 (..-05)	VDO Assyst Plus
 169 A-Class	MAINTENANCE	A 170 (04-..)	KOYO EPS
 169 A-Class	MAINTENANCE	A 170 (04-05)	MANUAL
 169 A-Class	MAINTENANCE	A 170 (06-..)	BOSCH Assyst/Assyst Plus
 169 A-Class	MAINTENANCE	A 170 (06-..)	BOSCH Assyst/Assyst Plus
 169 A-Class	MAINTENANCE	A 170 (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	MAINTENANCE	A 170 (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	MAINTENANCE	A 170 (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	MAINTENANCE	A 170 (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	MAINTENANCE	A 170 (06-..)	MANUAL
 169 A-Class	MAINTENANCE	A 180 (04-..)	KOYO EPS
 169 A-Class	MAINTENANCE	A 180 (06-..)	BOSCH Assyst/Assyst Plus
 169 A-Class	MAINTENANCE	A 180 (06-..)	BOSCH Assyst/Assyst Plus
 169 A-Class	MAINTENANCE	A 180 (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	MAINTENANCE	A 180 (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	MAINTENANCE	A 180 (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	MAINTENANCE	A 180 (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	MAINTENANCE	A 180 (06-..)	MANUAL
 169 A-Class	MAINTENANCE	A 180 CDI (..-05)	VDO Assyst
 169 A-Class	MAINTENANCE	A 180 CDI (..-05)	VDO Assyst
 169 A-Class	MAINTENANCE	A 180 CDI (..-05)	VDO Assyst
 169 A-Class	MAINTENANCE	A 180 CDI (..-05)	VDO Assyst Plus
 169 A-Class	MAINTENANCE	A 180 CDI (..-05)	VDO Assyst Plus
 169 A-Class	MAINTENANCE	A 180 CDI (..-05)	VDO Assyst Plus
 169 A-Class	MAINTENANCE	A 180 CDI (04-..)	KOYO EPS
 169 A-Class	MAINTENANCE	A 180 CDI (04-05)	MANUAL
 169 A-Class	MAINTENANCE	A 180 CDI (06-..)	BOSCH Assyst/Assyst Plus
 169 A-Class	MAINTENANCE	A 180 CDI (06-..)	BOSCH Assyst/Assyst Plus
 169 A-Class	MAINTENANCE	A 180 CDI (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	MAINTENANCE	A 180 CDI (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	MAINTENANCE	A 180 CDI (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	MAINTENANCE	A 180 CDI (06-..)	MANUAL
 169 A-Class	MAINTENANCE	A 200 (..-05)	VDO Assyst

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 169 A-Class	MAINTENANCE	A 200 (.-05)	VDO Assyst
 169 A-Class	MAINTENANCE	A 200 (.-05)	VDO Assyst
 169 A-Class	MAINTENANCE	A 200 (.-05)	VDO Assyst Plus
 169 A-Class	MAINTENANCE	A 200 (.-05)	VDO Assyst Plus
 169 A-Class	MAINTENANCE	A 200 (.-05)	VDO Assyst Plus
 169 A-Class	MAINTENANCE	A 200 (04-..)	KOYO EPS
 169 A-Class	MAINTENANCE	A 200 (04-05)	MANUAL
 169 A-Class	MAINTENANCE	A 200 (06-..)	BOSCH Assyst/Assyst Plus
 169 A-Class	MAINTENANCE	A 200 (06-..)	BOSCH Assyst/Assyst Plus
 169 A-Class	MAINTENANCE	A 200 (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	MAINTENANCE	A 200 (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	MAINTENANCE	A 200 (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	MAINTENANCE	A 200 (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	MAINTENANCE	A 200 (06-..)	MANUAL
 169 A-Class	MAINTENANCE	A 200 CDI (.-05)	VDO Assyst
 169 A-Class	MAINTENANCE	A 200 CDI (.-05)	VDO Assyst
 169 A-Class	MAINTENANCE	A 200 CDI (.-05)	VDO Assyst
 169 A-Class	MAINTENANCE	A 200 CDI (.-05)	VDO Assyst Plus
 169 A-Class	MAINTENANCE	A 200 CDI (.-05)	VDO Assyst Plus
 169 A-Class	MAINTENANCE	A 200 CDI (.-05)	VDO Assyst Plus
 169 A-Class	MAINTENANCE	A 200 CDI (04-..)	KOYO EPS
 169 A-Class	MAINTENANCE	A 200 CDI (04-05)	MANUAL
 169 A-Class	MAINTENANCE	A 200 CDI (06-..)	BOSCH Assyst/Assyst Plus
 169 A-Class	MAINTENANCE	A 200 CDI (06-..)	BOSCH Assyst/Assyst Plus
 169 A-Class	MAINTENANCE	A 200 CDI (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	MAINTENANCE	A 200 CDI (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	MAINTENANCE	A 200 CDI (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	MAINTENANCE	A 200 CDI (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	MAINTENANCE	A 200 CDI (06-..)	MANUAL
 169 A-Class	MAINTENANCE	A 200 Turbo (.-05)	VDO Assyst
 169 A-Class	MAINTENANCE	A 200 Turbo (.-05)	VDO Assyst
 169 A-Class	MAINTENANCE	A 200 Turbo (.-05)	VDO Assyst
 169 A-Class	MAINTENANCE	A 200 Turbo (.-05)	VDO Assyst Plus
 169 A-Class	MAINTENANCE	A 200 Turbo (.-05)	VDO Assyst Plus
 169 A-Class	MAINTENANCE	A 200 Turbo (.-05)	VDO Assyst Plus
 169 A-Class	MAINTENANCE	A 200 Turbo (04-..)	KOYO EPS
 169 A-Class	MAINTENANCE	A 200 Turbo (04-05)	MANUAL
 169 A-Class	MAINTENANCE	A 200 Turbo (06-..)	BOSCH Assyst/Assyst Plus
 169 A-Class	MAINTENANCE	A 200 Turbo (06-..)	BOSCH Assyst/Assyst Plus
 169 A-Class	MAINTENANCE	A 200 Turbo (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	MAINTENANCE	A 200 Turbo (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	MAINTENANCE	A 200 Turbo (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	MAINTENANCE	A 200 Turbo (06-..)	BOSCH Kombi KIW + Service
 169 A-Class	MAINTENANCE	A 200 Turbo (06-..)	MANUAL
 169 A-Class	MAINTENANCE SYST	A 150 (.-05)	VDO Assyst
 169 A-Class	MAINTENANCE SYST	A 150 (.-05)	VDO Assyst Plus
 169 A-Class	MAINTENANCE SYST	A 150 (06-..)	BOSCH Assyst/Assyst Plus
 169 A-Class	MAINTENANCE SYST	A 160 (06-..)	BOSCH Assyst/Assyst Plus
 169 A-Class	MAINTENANCE SYST	A 160 CDI (.-05)	VDO Assyst
 169 A-Class	MAINTENANCE SYST	A 160 CDI (.-05)	VDO Assyst Plus
 169 A-Class	MAINTENANCE SYST	A 160 CDI (06-..)	BOSCH Assyst/Assyst Plus
 169 A-Class	MAINTENANCE SYST	A 170 (.-05)	VDO Assyst
 169 A-Class	MAINTENANCE SYST	A 170 (.-05)	VDO Assyst Plus
 169 A-Class	MAINTENANCE SYST	A 170 (06-..)	BOSCH Assyst/Assyst Plus
 169 A-Class	MAINTENANCE SYST	A 180 (06-..)	BOSCH Assyst/Assyst Plus
 169 A-Class	MAINTENANCE SYST	A 180 CDI (.-05)	VDO Assyst
 169 A-Class	MAINTENANCE SYST	A 180 CDI (.-05)	VDO Assyst Plus
 169 A-Class	MAINTENANCE SYST	A 180 CDI (06-..)	BOSCH Assyst/Assyst Plus

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 169 A-Class	MAINTENANCE SYST	A 200 (.-05)	VDO Assyst
 169 A-Class	MAINTENANCE SYST	A 200 (.-05)	VDO Assyst Plus
 169 A-Class	MAINTENANCE SYST	A 200 (06-..)	BOSCH Assyst/Assyst Plus
 169 A-Class	MAINTENANCE SYST	A 200 CDI (.-05)	VDO Assyst
 169 A-Class	MAINTENANCE SYST	A 200 CDI (.-05)	VDO Assyst Plus
 169 A-Class	MAINTENANCE SYST	A 200 CDI (06-..)	BOSCH Assyst/Assyst Plus
 169 A-Class	MAINTENANCE SYST	A 200 Turbo (.-05)	VDO Assyst
 169 A-Class	MAINTENANCE SYST	A 200 Turbo (.-05)	VDO Assyst Plus
 169 A-Class	MAINTENANCE SYST	A 200 Turbo (06-..)	BOSCH Assyst/Assyst Plus
 169 A-Class	PARKING HELP	A 150 (04-08)	VALEO PTS5
 169 A-Class	PARKING HELP	A 150 (09-..)	BOSCH PTS11
 169 A-Class	PARKING HELP	A 160 (09-..)	BOSCH PTS11
 169 A-Class	PARKING HELP	A 160 CDI (04-08)	VALEO PTS5
 169 A-Class	PARKING HELP	A 160 CDI (09-..)	BOSCH PTS11
 169 A-Class	PARKING HELP	A 170 (04-08)	VALEO PTS5
 169 A-Class	PARKING HELP	A 170 (09-..)	BOSCH PTS11
 169 A-Class	PARKING HELP	A 180 (09-..)	BOSCH PTS11
 169 A-Class	PARKING HELP	A 180 CDI (04-08)	VALEO PTS5
 169 A-Class	PARKING HELP	A 180 CDI (09-..)	BOSCH PTS11
 169 A-Class	PARKING HELP	A 200 (04-08)	VALEO PTS5
 169 A-Class	PARKING HELP	A 200 (09-..)	BOSCH PTS11
 169 A-Class	PARKING HELP	A 200 CDI (04-08)	VALEO PTS5
 169 A-Class	PARKING HELP	A 200 CDI (09-..)	BOSCH PTS11
 169 A-Class	PARKING HELP	A 200 Turbo (04-08)	VALEO PTS5
 169 A-Class	PARKING HELP	A 200 Turbo (09-..)	BOSCH PTS11
 169 A-Class	RIGHT FRONT DOOR	A 150 (06-..)	KOSTAL TSG-VR
 169 A-Class	RIGHT FRONT DOOR	A 160 (06-..)	KOSTAL TSG-VR
 169 A-Class	RIGHT FRONT DOOR	A 160 CDI (06-..)	KOSTAL TSG-VR
 169 A-Class	RIGHT FRONT DOOR	A 170 (06-..)	KOSTAL TSG-VR
 169 A-Class	RIGHT FRONT DOOR	A 180 (06-..)	KOSTAL TSG-VR
 169 A-Class	RIGHT FRONT DOOR	A 180 CDI (06-..)	KOSTAL TSG-VR
 169 A-Class	RIGHT FRONT DOOR	A 200 (06-..)	KOSTAL TSG-VR
 169 A-Class	RIGHT FRONT DOOR	A 200 CDI (06-..)	KOSTAL TSG-VR
 169 A-Class	RIGHT FRONT DOOR	A 200 Turbo (06-..)	KOSTAL TSG-VR
 169 A-Class	SERVICE LIGHT RES	A 150 (04-05)	MANUAL
 169 A-Class	SERVICE LIGHT RES	A 150 (06-..)	MANUAL
 169 A-Class	SERVICE LIGHT RES	A 160 (06-..)	MANUAL
 169 A-Class	SERVICE LIGHT RES	A 160 CDI (04-05)	MANUAL
 169 A-Class	SERVICE LIGHT RES	A 160 CDI (06-..)	MANUAL
 169 A-Class	SERVICE LIGHT RES	A 170 (04-05)	MANUAL
 169 A-Class	SERVICE LIGHT RES	A 170 (06-..)	MANUAL
 169 A-Class	SERVICE LIGHT RES	A 180 (06-..)	MANUAL
 169 A-Class	SERVICE LIGHT RES	A 180 CDI (04-05)	MANUAL
 169 A-Class	SERVICE LIGHT RES	A 180 CDI (06-..)	MANUAL
 169 A-Class	SERVICE LIGHT RES	A 200 (04-05)	MANUAL
 169 A-Class	SERVICE LIGHT RES	A 200 (06-..)	MANUAL
 169 A-Class	SERVICE LIGHT RES	A 200 CDI (04-05)	MANUAL
 169 A-Class	SERVICE LIGHT RES	A 200 CDI (06-..)	MANUAL
 169 A-Class	SERVICE LIGHT RES	A 200 Turbo (04-05)	MANUAL
 169 A-Class	SERVICE LIGHT RES	A 200 Turbo (06-..)	MANUAL
 169 A-Class	SWITCHLIGHT MODU	A 150 (04-..)	VALEO
 169 A-Class	SWITCHLIGHT MODU	A 160 (04-..)	VALEO
 169 A-Class	SWITCHLIGHT MODU	A 160 CDI (04-..)	VALEO
 169 A-Class	SWITCHLIGHT MODU	A 170 (04-..)	VALEO
 169 A-Class	SWITCHLIGHT MODU	A 180 (04-..)	VALEO
 169 A-Class	SWITCHLIGHT MODU	A 180 CDI (04-..)	VALEO
 169 A-Class	SWITCHLIGHT MODU	A 200 (04-..)	VALEO
 169 A-Class	SWITCHLIGHT MODU	A 200 CDI (04-..)	VALEO

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 169 A-Class	SWITCHLIGHT MODU	A 200 Turbo (04-..)	VALEO
 170 SLK-Class	ABS + TRACT. CONT	SLK 200 (...00)	BOSCH ETS 5
 170 SLK-Class	ABS + TRACT. CONT	SLK 200 (...99)	BOSCH ASR/ABD BAS/ETS
 170 SLK-Class	ABS + TRACT. CONT	SLK 200 (01-03)	TEVES ESP 2
 170 SLK-Class	ABS + TRACT. CONT	SLK 200 Kompr. (...00)	BOSCH ETS 5
 170 SLK-Class	ABS + TRACT. CONT	SLK 200 Kompr. (...99)	BOSCH ASR/ABD BAS/ETS
 170 SLK-Class	ABS + TRACT. CONT	SLK 200 Kompr. (01-03)	TEVES ESP 2
 170 SLK-Class	ABS + TRACT. CONT	SLK 230 Kompr. (...00)	BOSCH ETS 5
 170 SLK-Class	ABS + TRACT. CONT	SLK 230 Kompr. (...99)	BOSCH ASR/ABD BAS/ETS
 170 SLK-Class	ABS + TRACT. CONT	SLK 230 Kompr. (01-03)	TEVES ESP 2
 170 SLK-Class	ABS + TRACT. CONT	SLK 32 AMG Kompr. (...00)	BOSCH ETS 5
 170 SLK-Class	ABS + TRACT. CONT	SLK 32 AMG Kompr. (...99)	BOSCH ASR/ABD BAS/ETS
 170 SLK-Class	ABS + TRACT. CONT	SLK 32 AMG Kompr. (01-03)	TEVES ESP 2
 170 SLK-Class	ABS + TRACT. CONT	SLK 320 (...00)	BOSCH ETS 5
 170 SLK-Class	ABS + TRACT. CONT	SLK 320 (...99)	BOSCH ASR/ABD BAS/ETS
 170 SLK-Class	ABS + TRACT. CONT	SLK 320 (01-03)	TEVES ESP 2
 170 SLK-Class	AIRBAG	SLK 200 (99-..)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 170 SLK-Class	AIRBAG	SLK 200 Kompr. (99-..)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 170 SLK-Class	AIRBAG	SLK 230 Kompr. (99-..)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 170 SLK-Class	AIRBAG	SLK 32 AMG Kompr. (99-..)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 170 SLK-Class	AIRBAG	SLK 320 (99-..)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 170 SLK-Class	AUTOM. TRANSMISSI	SLK 200 (...99)	BOSCH ETC 6
 170 SLK-Class	AUTOM. TRANSMISSI	SLK 200 Kompr. (...99)	BOSCH ETC 6
 170 SLK-Class	AUTOM. TRANSMISSI	SLK 230 Kompr. (...99)	BOSCH ETC 6
 170 SLK-Class	AUTOM. TRANSMISSI	SLK 32 AMG Kompr. (...99)	BOSCH ETC 6
 170 SLK-Class	AUTOM. TRANSMISSI	SLK 320 (...99)	BOSCH ETC 6
 170 SLK-Class	CENTRAL LOCKING	SLK 200 (01-..)	HELLA PSE
 170 SLK-Class	CENTRAL LOCKING	SLK 200 (01-..)	Siemens FFZ
 170 SLK-Class	CENTRAL LOCKING	SLK 200 Kompr. (01-..)	HELLA PSE
 170 SLK-Class	CENTRAL LOCKING	SLK 200 Kompr. (01-..)	Siemens FFZ
 170 SLK-Class	CENTRAL LOCKING	SLK 230 Kompr. (01-..)	HELLA PSE
 170 SLK-Class	CENTRAL LOCKING	SLK 230 Kompr. (01-..)	Siemens FFZ
 170 SLK-Class	CENTRAL LOCKING	SLK 32 AMG Kompr. (01-..)	HELLA PSE
 170 SLK-Class	CENTRAL LOCKING	SLK 32 AMG Kompr. (01-..)	Siemens FFZ
 170 SLK-Class	CENTRAL LOCKING	SLK 320 (01-..)	HELLA PSE
 170 SLK-Class	CENTRAL LOCKING	SLK 320 (01-..)	Siemens FFZ
 170 SLK-Class	CHASSIS NETWORK	SLK 200 (01-..)	TEMIC SKF
 170 SLK-Class	CHASSIS NETWORK	SLK 200 Kompr. (01-..)	TEMIC SKF
 170 SLK-Class	CHASSIS NETWORK	SLK 230 Kompr. (01-..)	TEMIC SKF
 170 SLK-Class	CHASSIS NETWORK	SLK 32 AMG Kompr. (01-..)	TEMIC SKF
 170 SLK-Class	CHASSIS NETWORK	SLK 320 (01-..)	TEMIC SKF
 170 SLK-Class	CONV. TOP/SUNROO	SLK 200 (01-..)	TEMIC VD
 170 SLK-Class	CONV. TOP/SUNROO	SLK 200 Kompr. (01-..)	TEMIC VD
 170 SLK-Class	CONV. TOP/SUNROO	SLK 230 Kompr. (01-..)	TEMIC VD
 170 SLK-Class	CONV. TOP/SUNROO	SLK 32 AMG Kompr. (01-..)	TEMIC VD
 170 SLK-Class	CONV. TOP/SUNROO	SLK 320 (01-..)	TEMIC VD
 170 SLK-Class	DASHBOARD	SLK 200 (01-..)	VDO KIW
 170 SLK-Class	DASHBOARD	SLK 200 Kompr. (01-..)	VDO KIW
 170 SLK-Class	DASHBOARD	SLK 230 Kompr. (01-..)	VDO KIW
 170 SLK-Class	DASHBOARD	SLK 32 AMG Kompr. (01-..)	VDO KIW
 170 SLK-Class	DASHBOARD	SLK 320 (01-..)	VDO KIW
 170 SLK-Class	ENGINE MANAGEME	SLK 200 (01-03)	EOBD
 170 SLK-Class	ENGINE MANAGEME	SLK 200 Kompr. 111 (...99)	BOSCH Motronic ME 1.0
 170 SLK-Class	ENGINE MANAGEME	SLK 200 Kompr. 111 (...99)	BOSCH Motronic ME 2.0
 170 SLK-Class	ENGINE MANAGEME	SLK 200 Kompr. 111 (...99)	BOSCH Motronic ME 2.1
 170 SLK-Class	ENGINE MANAGEME	SLK 200 Kompr. 111 (...99)	SIEMENS-VDO HFM SFI
 170 SLK-Class	ENGINE MANAGEME	SLK 200 Kompr. 111 (00-03)	BOSCH BOSCH-SIEMENS ME-SIM4 EVO
 170 SLK-Class	ENGINE MANAGEME	SLK 230 Kompr. 111 (00-03)	BOSCH BOSCH-SIEMENS ME-SIM4 EVO

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 170 SLK-Class	ENGINE MANAGEME	SLK 32 AMG Kompr. (01-03)	EOBD
 170 SLK-Class	ENGINE MANAGEME	SLK 320 (01-03)	EOBD
 170 SLK-Class	MAINTENANCE	SLK 200 (01-..)	VDO KIW
 170 SLK-Class	MAINTENANCE	SLK 200 (99-03)	VDO/Marelli MANUAL
 170 SLK-Class	MAINTENANCE	SLK 200 Kompr. (01-..)	VDO KIW
 170 SLK-Class	MAINTENANCE	SLK 200 Kompr. (99-03)	VDO/Marelli MANUAL
 170 SLK-Class	MAINTENANCE	SLK 200 Kompr. 111 (00-03)	BOSCH BOSCH-SIEMENS ME-SIM4 EVO
 170 SLK-Class	MAINTENANCE	SLK 230 Kompr. (01-..)	VDO KIW
 170 SLK-Class	MAINTENANCE	SLK 230 Kompr. (99-03)	VDO/Marelli MANUAL
 170 SLK-Class	MAINTENANCE	SLK 230 Kompr. 111 (00-03)	BOSCH BOSCH-SIEMENS ME-SIM4 EVO
 170 SLK-Class	MAINTENANCE	SLK 32 AMG Kompr. (01-..)	VDO KIW
 170 SLK-Class	MAINTENANCE	SLK 32 AMG Kompr. (99-03)	VDO/Marelli MANUAL
 170 SLK-Class	MAINTENANCE	SLK 320 (01-..)	VDO KIW
 170 SLK-Class	MAINTENANCE	SLK 320 (99-03)	VDO/Marelli MANUAL
 170 SLK-Class	POWER BRAKE	SLK 200 (01-..)	TEVES BAS
 170 SLK-Class	POWER BRAKE	SLK 200 Kompr. (01-..)	TEVES BAS
 170 SLK-Class	POWER BRAKE	SLK 230 Kompr. (01-..)	TEVES BAS
 170 SLK-Class	POWER BRAKE	SLK 32 AMG Kompr. (01-..)	TEVES BAS
 170 SLK-Class	POWER BRAKE	SLK 320 (01-..)	TEVES BAS
 170 SLK-Class	RADIO / CD	SLK 200 (01-..)	Becker D2B
 170 SLK-Class	RADIO / CD	SLK 200 Kompr. (01-..)	Becker D2B
 170 SLK-Class	RADIO / CD	SLK 230 Kompr. (01-..)	Becker D2B
 170 SLK-Class	RADIO / CD	SLK 32 AMG Kompr. (01-..)	Becker D2B
 170 SLK-Class	RADIO / CD	SLK 320 (01-..)	Becker D2B
 170 SLK-Class	SERVICE LIGHT RES	SLK 200 (99-03)	VDO/Marelli MANUAL
 170 SLK-Class	SERVICE LIGHT RES	SLK 200 Kompr. (99-03)	VDO/Marelli MANUAL
 170 SLK-Class	SERVICE LIGHT RES	SLK 230 Kompr. (99-03)	VDO/Marelli MANUAL
 170 SLK-Class	SERVICE LIGHT RES	SLK 32 AMG Kompr. (99-03)	VDO/Marelli MANUAL
 170 SLK-Class	SERVICE LIGHT RES	SLK 320 (99-03)	VDO/Marelli MANUAL
 171 SLK-Class	ABS + TRACT. CONT	SLK 200 Kompr.	TEVES ABS+ESP
 171 SLK-Class	ABS + TRACT. CONT	SLK 280	TEVES ABS+ESP
 171 SLK-Class	ABS + TRACT. CONT	SLK 300	TEVES ABS+ESP
 171 SLK-Class	ABS + TRACT. CONT	SLK 350	TEVES ABS+ESP
 171 SLK-Class	ABS + TRACT. CONT	SLK 55 AMG	TEVES ABS+ESP
 171 SLK-Class	AIRBAG	SLK 200 Kompr.	TEMIC AirBag SRS
 171 SLK-Class	AIRBAG	SLK 280	TEMIC AirBag SRS
 171 SLK-Class	AIRBAG	SLK 300	TEMIC AirBag SRS
 171 SLK-Class	AIRBAG	SLK 350	TEMIC AirBag SRS
 171 SLK-Class	AIRBAG	SLK 55 AMG	TEMIC AirBag SRS
 171 SLK-Class	AUTOM. TRANSMISSI	SLK 200 Kompr.	SIEMENS EGS 722.6 EGS52
 171 SLK-Class	AUTOM. TRANSMISSI	SLK 280	SIEMENS EGS 722.6 EGS52
 171 SLK-Class	AUTOM. TRANSMISSI	SLK 300	SIEMENS EGS 722.6 EGS52
 171 SLK-Class	AUTOM. TRANSMISSI	SLK 350	SIEMENS EGS 722.6 EGS52
 171 SLK-Class	AUTOM. TRANSMISSI	SLK 55 AMG	SIEMENS EGS 722.6 EGS52
 171 SLK-Class	ENGINE MANAGEME	SLK 200 Kompr.	EOBD
 171 SLK-Class	ENGINE MANAGEME	SLK 280	EOBD
 171 SLK-Class	ENGINE MANAGEME	SLK 300	EOBD
 171 SLK-Class	ENGINE MANAGEME	SLK 350	EOBD
 171 SLK-Class	ENGINE MANAGEME	SLK 55 AMG	EOBD
 172 SLK-Class	ABS + TRACT. CONT	200 CGI BlueEfficiency (11-..)	Teves ESP
 172 SLK-Class	ABS + TRACT. CONT	250 CDI BlueEfficiency (11-..)	Teves ESP
 172 SLK-Class	ABS + TRACT. CONT	250 CGI BlueEfficiency (11-..)	Teves ESP
 172 SLK-Class	ABS + TRACT. CONT	350 V6 (11-..)	Teves ESP
 172 SLK-Class	ABS + TRACT. CONT	SLK 55 AMG (11-..)	Teves ESP
 172 SLK-Class	AUTOM. TRANSMISSI	200 CGI BlueEfficiency (11-..)	Siemens EGS 53
 172 SLK-Class	AUTOM. TRANSMISSI	250 CDI BlueEfficiency (11-..)	Siemens EGS 53
 172 SLK-Class	AUTOM. TRANSMISSI	250 CGI BlueEfficiency (11-..)	Siemens EGS 53
 172 SLK-Class	AUTOM. TRANSMISSI	350 V6 (11-..)	Siemens EGS 53

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 172 SLK-Class	AUTOM. TRANSMISSI	SLK 55 AMG (11-..)	Siemens EGS 53
 172 SLK-Class	MAINTENANCE	200 CGI BlueEfficiency (11-..)	Teves ESP
 172 SLK-Class	MAINTENANCE	250 CDI BlueEfficiency (11-..)	Teves ESP
 172 SLK-Class	MAINTENANCE	250 CGI BlueEfficiency (11-..)	Teves ESP
 172 SLK-Class	MAINTENANCE	350 V6 (11-..)	Teves ESP
 172 SLK-Class	MAINTENANCE	SLK 55 AMG (11-..)	Teves ESP
 202 C-Class	ABS + TRACT. CONT	C 180 (..-00)	BOSCH ETS 5
 202 C-Class	ABS + TRACT. CONT	C 180 (..-99)	ATE ABS
 202 C-Class	ABS + TRACT. CONT	C 180 (..-99)	BOSCH ASR/ABD BAS/ETS
 202 C-Class	ABS + TRACT. CONT	C 200 (..-00)	BOSCH ETS 5
 202 C-Class	ABS + TRACT. CONT	C 200 (..-99)	ATE ABS
 202 C-Class	ABS + TRACT. CONT	C 200 (..-99)	BOSCH ASR/ABD BAS/ETS
 202 C-Class	ABS + TRACT. CONT	C 200 CDI (..-00)	BOSCH ETS 5
 202 C-Class	ABS + TRACT. CONT	C 200 CDI (..-99)	ATE ABS
 202 C-Class	ABS + TRACT. CONT	C 200 CDI (..-99)	BOSCH ASR/ABD BAS/ETS
 202 C-Class	ABS + TRACT. CONT	C 200 D (..-00)	BOSCH ETS 5
 202 C-Class	ABS + TRACT. CONT	C 200 D (..-99)	ATE ABS
 202 C-Class	ABS + TRACT. CONT	C 200 D (..-99)	BOSCH ASR/ABD BAS/ETS
 202 C-Class	ABS + TRACT. CONT	C 200 Kompr. (..-00)	BOSCH ETS 5
 202 C-Class	ABS + TRACT. CONT	C 200 Kompr. (..-99)	ATE ABS
 202 C-Class	ABS + TRACT. CONT	C 200 Kompr. (..-99)	BOSCH ASR/ABD BAS/ETS
 202 C-Class	ABS + TRACT. CONT	C 220 (..-00)	BOSCH ETS 5
 202 C-Class	ABS + TRACT. CONT	C 220 (..-99)	ATE ABS
 202 C-Class	ABS + TRACT. CONT	C 220 (..-99)	BOSCH ASR/ABD BAS/ETS
 202 C-Class	ABS + TRACT. CONT	C 220 CDI (..-00)	BOSCH ETS 5
 202 C-Class	ABS + TRACT. CONT	C 220 CDI (..-99)	ATE ABS
 202 C-Class	ABS + TRACT. CONT	C 220 CDI (..-99)	BOSCH ASR/ABD BAS/ETS
 202 C-Class	ABS + TRACT. CONT	C 220 D (..-00)	BOSCH ETS 5
 202 C-Class	ABS + TRACT. CONT	C 220 D (..-99)	ATE ABS
 202 C-Class	ABS + TRACT. CONT	C 220 D (..-99)	BOSCH ASR/ABD BAS/ETS
 202 C-Class	ABS + TRACT. CONT	C 230 (..-00)	BOSCH ETS 5
 202 C-Class	ABS + TRACT. CONT	C 230 (..-99)	ATE ABS
 202 C-Class	ABS + TRACT. CONT	C 230 (..-99)	BOSCH ASR/ABD BAS/ETS
 202 C-Class	ABS + TRACT. CONT	C 230 Kompr. (..-00)	BOSCH ETS 5
 202 C-Class	ABS + TRACT. CONT	C 230 Kompr. (..-99)	ATE ABS
 202 C-Class	ABS + TRACT. CONT	C 230 Kompr. (..-99)	BOSCH ASR/ABD BAS/ETS
 202 C-Class	ABS + TRACT. CONT	C 240 (..-00)	BOSCH ETS 5
 202 C-Class	ABS + TRACT. CONT	C 240 (..-99)	ATE ABS
 202 C-Class	ABS + TRACT. CONT	C 240 (..-99)	BOSCH ASR/ABD BAS/ETS
 202 C-Class	ABS + TRACT. CONT	C 250 D (..-00)	BOSCH ETS 5
 202 C-Class	ABS + TRACT. CONT	C 250 D (..-99)	ATE ABS
 202 C-Class	ABS + TRACT. CONT	C 250 D (..-99)	BOSCH ASR/ABD BAS/ETS
 202 C-Class	ABS + TRACT. CONT	C 250 TD (..-00)	BOSCH ETS 5
 202 C-Class	ABS + TRACT. CONT	C 250 TD (..-99)	ATE ABS
 202 C-Class	ABS + TRACT. CONT	C 250 TD (..-99)	BOSCH ASR/ABD BAS/ETS
 202 C-Class	ABS + TRACT. CONT	C 280 (..-00)	BOSCH ETS 5
 202 C-Class	ABS + TRACT. CONT	C 280 (..-99)	ATE ABS
 202 C-Class	ABS + TRACT. CONT	C 280 (..-99)	BOSCH ASR/ABD BAS/ETS
 202 C-Class	ABS + TRACT. CONT	C 36 AMG (..-00)	BOSCH ETS 5
 202 C-Class	ABS + TRACT. CONT	C 36 AMG (..-99)	ATE ABS
 202 C-Class	ABS + TRACT. CONT	C 36 AMG (..-99)	BOSCH ASR/ABD BAS/ETS
 202 C-Class	ABS + TRACT. CONT	C 43 AMG (..-00)	BOSCH ETS 5
 202 C-Class	ABS + TRACT. CONT	C 43 AMG (..-99)	ATE ABS
 202 C-Class	ABS + TRACT. CONT	C 43 AMG (..-99)	BOSCH ASR/ABD BAS/ETS
 202 C-Class	AIRBAG	C 180 (..-99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 202 C-Class	AIRBAG	C 180 (..-99)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 202 C-Class	AIRBAG	C 200 (..-99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 202 C-Class	AIRBAG	C 200 (..-99)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 202 C-Class	AIRBAG	C 200 CDI (...99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 202 C-Class	AIRBAG	C 200 CDI (...99)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 202 C-Class	AIRBAG	C 200 D (...99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 202 C-Class	AIRBAG	C 200 D (...99)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 202 C-Class	AIRBAG	C 200 Kompr. (...99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 202 C-Class	AIRBAG	C 200 Kompr. (...99)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 202 C-Class	AIRBAG	C 220 (...99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 202 C-Class	AIRBAG	C 220 (...99)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 202 C-Class	AIRBAG	C 220 CDI (...99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 202 C-Class	AIRBAG	C 220 CDI (...99)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 202 C-Class	AIRBAG	C 220 D (...99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 202 C-Class	AIRBAG	C 220 D (...99)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 202 C-Class	AIRBAG	C 230 (...99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 202 C-Class	AIRBAG	C 230 (...99)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 202 C-Class	AIRBAG	C 230 Kompr. (...99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 202 C-Class	AIRBAG	C 230 Kompr. (...99)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 202 C-Class	AIRBAG	C 240 (...99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 202 C-Class	AIRBAG	C 240 (...99)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 202 C-Class	AIRBAG	C 250 D (...99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 202 C-Class	AIRBAG	C 250 D (...99)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 202 C-Class	AIRBAG	C 250 TD (...99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 202 C-Class	AIRBAG	C 250 TD (...99)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 202 C-Class	AIRBAG	C 280 (...99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 202 C-Class	AIRBAG	C 280 (...99)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 202 C-Class	AIRBAG	C 36 AMG (...99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 202 C-Class	AIRBAG	C 36 AMG (...99)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 202 C-Class	AIRBAG	C 43 AMG (...99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 202 C-Class	AIRBAG	C 43 AMG (...99)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 202 C-Class	AUTOM. TRANSMISSI	C 180 (...99)	BOSCH ETC 6
 202 C-Class	AUTOM. TRANSMISSI	C 200 (...99)	BOSCH ETC 6
 202 C-Class	AUTOM. TRANSMISSI	C 200 CDI (...99)	BOSCH ETC 6
 202 C-Class	AUTOM. TRANSMISSI	C 200 D (...99)	BOSCH ETC 6
 202 C-Class	AUTOM. TRANSMISSI	C 200 Kompr. (...99)	BOSCH ETC 6
 202 C-Class	AUTOM. TRANSMISSI	C 220 (...99)	BOSCH ETC 6
 202 C-Class	AUTOM. TRANSMISSI	C 220 CDI (...99)	BOSCH ETC 6
 202 C-Class	AUTOM. TRANSMISSI	C 220 D (...99)	BOSCH ETC 6
 202 C-Class	AUTOM. TRANSMISSI	C 230 (...99)	BOSCH ETC 6
 202 C-Class	AUTOM. TRANSMISSI	C 230 Kompr. (...99)	BOSCH ETC 6
 202 C-Class	AUTOM. TRANSMISSI	C 240 (...99)	BOSCH ETC 6
 202 C-Class	AUTOM. TRANSMISSI	C 250 D (...99)	BOSCH ETC 6
 202 C-Class	AUTOM. TRANSMISSI	C 250 TD (...99)	BOSCH ETC 6
 202 C-Class	AUTOM. TRANSMISSI	C 280 (...99)	BOSCH ETC 6
 202 C-Class	AUTOM. TRANSMISSI	C 36 AMG (...99)	BOSCH ETC 6
 202 C-Class	AUTOM. TRANSMISSI	C 43 AMG (...99)	BOSCH ETC 6
 202 C-Class	CHASSIS NETWORK	C 180 (...99)	SAM
 202 C-Class	CHASSIS NETWORK	C 200 (...99)	SAM
 202 C-Class	CHASSIS NETWORK	C 200 CDI (...99)	SAM
 202 C-Class	CHASSIS NETWORK	C 200 D (...99)	SAM
 202 C-Class	CHASSIS NETWORK	C 200 Kompr. (...99)	SAM
 202 C-Class	CHASSIS NETWORK	C 220 (...99)	SAM
 202 C-Class	CHASSIS NETWORK	C 220 CDI (...99)	SAM
 202 C-Class	CHASSIS NETWORK	C 220 D (...99)	SAM
 202 C-Class	CHASSIS NETWORK	C 230 (...99)	SAM
 202 C-Class	CHASSIS NETWORK	C 230 Kompr. (...99)	SAM
 202 C-Class	CHASSIS NETWORK	C 240 (...99)	SAM
 202 C-Class	CHASSIS NETWORK	C 250 D (...99)	SAM
 202 C-Class	CHASSIS NETWORK	C 250 TD (...99)	SAM
 202 C-Class	CHASSIS NETWORK	C 280 (...99)	SAM

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 202 C-Class	CHASSIS NETWORK	C 36 AMG (...99)	SAM
 202 C-Class	CHASSIS NETWORK	C 43 AMG (...99)	SAM
 202 C-Class	CRUISE CONTROL	C 180 (...00)	BOSCH/VDO EA/CC/ISC
 202 C-Class	CRUISE CONTROL	C 200 (...00)	BOSCH/VDO EA/CC/ISC
 202 C-Class	CRUISE CONTROL	C 200 CDI (...00)	BOSCH/VDO EA/CC/ISC
 202 C-Class	CRUISE CONTROL	C 200 D (...00)	BOSCH/VDO EA/CC/ISC
 202 C-Class	CRUISE CONTROL	C 200 Kompr. (...00)	BOSCH/VDO EA/CC/ISC
 202 C-Class	CRUISE CONTROL	C 220 (...00)	BOSCH/VDO EA/CC/ISC
 202 C-Class	CRUISE CONTROL	C 220 CDI (...00)	BOSCH/VDO EA/CC/ISC
 202 C-Class	CRUISE CONTROL	C 220 D (...00)	BOSCH/VDO EA/CC/ISC
 202 C-Class	CRUISE CONTROL	C 230 (...00)	BOSCH/VDO EA/CC/ISC
 202 C-Class	CRUISE CONTROL	C 230 Kompr. (...00)	BOSCH/VDO EA/CC/ISC
 202 C-Class	CRUISE CONTROL	C 240 (...00)	BOSCH/VDO EA/CC/ISC
 202 C-Class	CRUISE CONTROL	C 250 D (...00)	BOSCH/VDO EA/CC/ISC
 202 C-Class	CRUISE CONTROL	C 250 TD (...00)	BOSCH/VDO EA/CC/ISC
 202 C-Class	CRUISE CONTROL	C 280 (...00)	BOSCH/VDO EA/CC/ISC
 202 C-Class	CRUISE CONTROL	C 36 AMG (...00)	BOSCH/VDO EA/CC/ISC
 202 C-Class	CRUISE CONTROL	C 43 AMG (...00)	BOSCH/VDO EA/CC/ISC
 202 C-Class	DASHBOARD	C 180 (...99)	VDO KIW
 202 C-Class	DASHBOARD	C 200 (...99)	VDO KIW
 202 C-Class	DASHBOARD	C 200 CDI (...99)	VDO KIW
 202 C-Class	DASHBOARD	C 200 D (...99)	VDO KIW
 202 C-Class	DASHBOARD	C 200 Kompr. (...99)	VDO KIW
 202 C-Class	DASHBOARD	C 220 (...99)	VDO KIW
 202 C-Class	DASHBOARD	C 220 CDI (...99)	VDO KIW
 202 C-Class	DASHBOARD	C 220 D (...99)	VDO KIW
 202 C-Class	DASHBOARD	C 230 (...99)	VDO KIW
 202 C-Class	DASHBOARD	C 230 Kompr. (...99)	VDO KIW
 202 C-Class	DASHBOARD	C 240 (...99)	VDO KIW
 202 C-Class	DASHBOARD	C 250 D (...99)	VDO KIW
 202 C-Class	DASHBOARD	C 250 TD (...99)	VDO KIW
 202 C-Class	DASHBOARD	C 280 (...99)	VDO KIW
 202 C-Class	DASHBOARD	C 36 AMG (...99)	VDO KIW
 202 C-Class	DASHBOARD	C 43 AMG (...99)	VDO KIW
 202 C-Class	DIESEL MANAGEMEN	C 200 CDI 606 (...99)	BOSCH IFI (ERE) (EPC)
 202 C-Class	DIESEL MANAGEMEN	C 200 D 606 (...99)	BOSCH IFI (ERE) (EPC)
 202 C-Class	DIESEL MANAGEMEN	C 250 D 605 (...99)	BOSCH IFI (ERE) (EPC)
 202 C-Class	DIESEL MANAGEMEN	C 250 D 606 (...99)	BOSCH IFI (ERE) (EPC)
 202 C-Class	DIESEL MANAGEMEN	C 250 TD 606 (...99)	BOSCH IFI (ERE) (EPC)
 202 C-Class	ENGINE MANAGEME	C 180 111 (...99)	BOSCH Motronic ME 1.0
 202 C-Class	ENGINE MANAGEME	C 180 111 (...99)	BOSCH Motronic ME 2.0
 202 C-Class	ENGINE MANAGEME	C 180 111 (...99)	SIEMENS-VDO HFM SFI
 202 C-Class	ENGINE MANAGEME	C 200 111 (...99)	BOSCH Motronic ME 1.0
 202 C-Class	ENGINE MANAGEME	C 200 111 (...99)	BOSCH Motronic ME 2.0
 202 C-Class	ENGINE MANAGEME	C 200 111 (...99)	SIEMENS-VDO HFM SFI
 202 C-Class	ENGINE MANAGEME	C 200 D (...99)	LUCAS BOSCH IFI (EVE)
 202 C-Class	ENGINE MANAGEME	C 200 Kompr. 111 (...99)	BOSCH Motronic ME 1.0
 202 C-Class	ENGINE MANAGEME	C 200 Kompr. 111 (...99)	BOSCH Motronic ME 2.0
 202 C-Class	ENGINE MANAGEME	C 200 Kompr. 111 (...99)	SIEMENS-VDO HFM SFI
 202 C-Class	ENGINE MANAGEME	C 220 CDI 611 (98-00)	BOSCH EDC 15 C4 Common Rail
 202 C-Class	ENGINE MANAGEME	C 220 CDI 611 (98-00)	BOSCH EDC 15 C6 Common Rail
 202 C-Class	ENGINE MANAGEME	C 220 D (...99)	LUCAS BOSCH IFI (EVE)
 202 C-Class	ENGINE MANAGEME	C 230 111 (...99)	BOSCH Motronic ME 1.0
 202 C-Class	ENGINE MANAGEME	C 230 111 (...99)	BOSCH Motronic ME 2.0
 202 C-Class	ENGINE MANAGEME	C 230 111 (...99)	SIEMENS-VDO HFM SFI
 202 C-Class	ENGINE MANAGEME	C 230 Kompr. 111 (...99)	BOSCH Motronic ME 1.0
 202 C-Class	ENGINE MANAGEME	C 230 Kompr. 111 (...99)	BOSCH Motronic ME 2.0
 202 C-Class	ENGINE MANAGEME	C 230 Kompr. 111 (...99)	SIEMENS-VDO HFM SFI

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 202 C-Class	ENGINE MANAGEME	C 240 111 (...99)	BOSCH Motronic ME 1.0
 202 C-Class	ENGINE MANAGEME	C 240 111 (...99)	BOSCH Motronic ME 2.0
 202 C-Class	ENGINE MANAGEME	C 240 111 (...99)	SIEMENS-VDO HFM SFI
 202 C-Class	ENGINE MANAGEME	C 250 D (...99)	LUCAS BOSCH IFI (EVE)
 202 C-Class	ENGINE MANAGEME	C 280 112 (...99)	BOSCH Motronic ME 1.0
 202 C-Class	ENGINE MANAGEME	C 280 112 (...99)	BOSCH Motronic ME 2.0
 202 C-Class	ENGINE MANAGEME	C 280 112 (...99)	SIEMENS-VDO HFM SFI
 202 C-Class	ENGINE MANAGEME	C 43 AMG 113 (...99)	BOSCH Motronic ME 1.0
 202 C-Class	ENGINE MANAGEME	C 43 AMG 113 (...99)	BOSCH Motronic ME 2.0
 202 C-Class	ENGINE MANAGEME	C 43 AMG 113 (...99)	SIEMENS-VDO HFM SFI
 202 C-Class	MAINTENANCE	C 180 (...00)	VDO/Marelli MANUAL
 202 C-Class	MAINTENANCE	C 200 (...00)	VDO/Marelli MANUAL
 202 C-Class	MAINTENANCE	C 200 CDI (...00)	VDO/Marelli MANUAL
 202 C-Class	MAINTENANCE	C 200 D (...00)	VDO/Marelli MANUAL
 202 C-Class	MAINTENANCE	C 200 Kompr. (...00)	VDO/Marelli MANUAL
 202 C-Class	MAINTENANCE	C 220 (...00)	VDO/Marelli MANUAL
 202 C-Class	MAINTENANCE	C 220 CDI (...00)	VDO/Marelli MANUAL
 202 C-Class	MAINTENANCE	C 220 D (...00)	VDO/Marelli MANUAL
 202 C-Class	MAINTENANCE	C 230 (...00)	VDO/Marelli MANUAL
 202 C-Class	MAINTENANCE	C 230 Kompr. (...00)	VDO/Marelli MANUAL
 202 C-Class	MAINTENANCE	C 240 (...00)	VDO/Marelli MANUAL
 202 C-Class	MAINTENANCE	C 250 D (...00)	VDO/Marelli MANUAL
 202 C-Class	MAINTENANCE	C 250 TD (...00)	VDO/Marelli MANUAL
 202 C-Class	MAINTENANCE	C 280 (...00)	VDO/Marelli MANUAL
 202 C-Class	MAINTENANCE	C 36 AMG (...00)	VDO/Marelli MANUAL
 202 C-Class	MAINTENANCE	C 43 AMG (...00)	VDO/Marelli MANUAL
 202 C-Class	SERVICE LIGHT RES	C 180 (...00)	VDO/Marelli MANUAL
 202 C-Class	SERVICE LIGHT RES	C 200 (...00)	VDO/Marelli MANUAL
 202 C-Class	SERVICE LIGHT RES	C 200 CDI (...00)	VDO/Marelli MANUAL
 202 C-Class	SERVICE LIGHT RES	C 200 D (...00)	VDO/Marelli MANUAL
 202 C-Class	SERVICE LIGHT RES	C 200 Kompr. (...00)	VDO/Marelli MANUAL
 202 C-Class	SERVICE LIGHT RES	C 220 (...00)	VDO/Marelli MANUAL
 202 C-Class	SERVICE LIGHT RES	C 220 CDI (...00)	VDO/Marelli MANUAL
 202 C-Class	SERVICE LIGHT RES	C 220 D (...00)	VDO/Marelli MANUAL
 202 C-Class	SERVICE LIGHT RES	C 230 (...00)	VDO/Marelli MANUAL
 202 C-Class	SERVICE LIGHT RES	C 230 Kompr. (...00)	VDO/Marelli MANUAL
 202 C-Class	SERVICE LIGHT RES	C 240 (...00)	VDO/Marelli MANUAL
 202 C-Class	SERVICE LIGHT RES	C 250 D (...00)	VDO/Marelli MANUAL
 202 C-Class	SERVICE LIGHT RES	C 250 TD (...00)	VDO/Marelli MANUAL
 202 C-Class	SERVICE LIGHT RES	C 280 (...00)	VDO/Marelli MANUAL
 202 C-Class	SERVICE LIGHT RES	C 36 AMG (...00)	VDO/Marelli MANUAL
 202 C-Class	SERVICE LIGHT RES	C 43 AMG (...00)	VDO/Marelli MANUAL
 203 C-Class	ABS	C 180 (00-03)	TEVES ABS/ABR
 203 C-Class	ABS	C 180 Kompr. (02-03)	TEVES ABS/ABR
 203 C-Class	ABS	C 200 CDI (00-03)	TEVES ABS/ABR
 203 C-Class	ABS	C 200 Kompr. (02-03)	TEVES ABS/ABR
 203 C-Class	ABS	C 220 CDI (00-03)	TEVES ABS/ABR
 203 C-Class	ABS	C 240 (00-03)	TEVES ABS/ABR
 203 C-Class	ABS	C 270 CDI (00-03)	TEVES ABS/ABR
 203 C-Class	ABS	C 30 CDI AMG (02-03)	TEVES ABS/ABR
 203 C-Class	ABS	C 32 Kompr. AMG (02-03)	TEVES ABS/ABR
 203 C-Class	ABS	C 320 (00-03)	TEVES ABS/ABR
 203 C-Class	ABS + TRACT. CONT	C 180 (00-02)	BOSCH ASR/ABD BAS/ETS
 203 C-Class	ABS + TRACT. CONT	C 180 (00-03)	BOSCH ESP
 203 C-Class	ABS + TRACT. CONT	C 180 Kompr. (02-03)	BOSCH ESP
 203 C-Class	ABS + TRACT. CONT	C 180 Kompr. (03-07)	ATE ESP
 203 C-Class	ABS + TRACT. CONT	C 200 CDI (00-02)	BOSCH ASR/ABD BAS/ETS
 203 C-Class	ABS + TRACT. CONT	C 200 CDI (00-03)	BOSCH ESP

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 203 C-Class	ABS + TRACT. CONT	C 200 CDI (03-07)	ATE ESP
 203 C-Class	ABS + TRACT. CONT	C 200 CGI Kompr. (02-03)	BOSCH ESP
 203 C-Class	ABS + TRACT. CONT	C 200 CGI Kompr. (03-07)	ATE ESP
 203 C-Class	ABS + TRACT. CONT	C 200 Kompr. (02-03)	BOSCH ESP
 203 C-Class	ABS + TRACT. CONT	C 200 Kompr. (03-07)	ATE ESP
 203 C-Class	ABS + TRACT. CONT	C 220 CDI (00-02)	BOSCH ASR/ABD BAS/ETS
 203 C-Class	ABS + TRACT. CONT	C 220 CDI (00-03)	BOSCH ESP
 203 C-Class	ABS + TRACT. CONT	C 220 CDI (03-07)	ATE ESP
 203 C-Class	ABS + TRACT. CONT	C 230 (04-07)	ATE ESP
 203 C-Class	ABS + TRACT. CONT	C 230 Kompr. (04-05)	ATE ESP
 203 C-Class	ABS + TRACT. CONT	C 240 (00-02)	BOSCH ASR/ABD BAS/ETS
 203 C-Class	ABS + TRACT. CONT	C 240 (00-03)	BOSCH ESP
 203 C-Class	ABS + TRACT. CONT	C 240 (03-05)	ATE ESP
 203 C-Class	ABS + TRACT. CONT	C 270 CDI (00-02)	BOSCH ASR/ABD BAS/ETS
 203 C-Class	ABS + TRACT. CONT	C 270 CDI (00-03)	BOSCH ESP
 203 C-Class	ABS + TRACT. CONT	C 270 CDI (03-07)	ATE ESP
 203 C-Class	ABS + TRACT. CONT	C 280 (05-07)	ATE ESP
 203 C-Class	ABS + TRACT. CONT	C 30 CDI AMG (02-03)	BOSCH ESP
 203 C-Class	ABS + TRACT. CONT	C 30 CDI AMG (03-05)	ATE ESP
 203 C-Class	ABS + TRACT. CONT	C 32 Kompr. AMG (00-02)	BOSCH ASR/ABD BAS/ETS
 203 C-Class	ABS + TRACT. CONT	C 32 Kompr. AMG (00-03)	BOSCH ESP
 203 C-Class	ABS + TRACT. CONT	C 32 Kompr. AMG (03-04)	ATE ESP
 203 C-Class	ABS + TRACT. CONT	C 320 (00-02)	BOSCH ASR/ABD BAS/ETS
 203 C-Class	ABS + TRACT. CONT	C 320 (00-03)	BOSCH ESP
 203 C-Class	ABS + TRACT. CONT	C 320 (03-05)	ATE ESP
 203 C-Class	ABS + TRACT. CONT	C 320 CDI (05-07)	ATE ESP
 203 C-Class	ABS + TRACT. CONT	C 350 (05-07)	ATE ESP
 203 C-Class	ABS + TRACT. CONT	C 55 AMG (04-07)	ATE ESP
 203 C-Class	AIRBAG	C 180 (00-03)	BOSCH AirBag SRS 7.8.1
 203 C-Class	AIRBAG	C 180 Kompr. (03-07)	BOSCH SRS AirBag
 203 C-Class	AIRBAG	C 180 Kompr. (03-07)	TRW SRS
 203 C-Class	AIRBAG	C 200 CDI (00-03)	BOSCH AirBag SRS 7.8.1
 203 C-Class	AIRBAG	C 200 CDI (03-07)	BOSCH SRS AirBag
 203 C-Class	AIRBAG	C 200 CDI (03-07)	TRW SRS
 203 C-Class	AIRBAG	C 200 CGI Kompr. (02-03)	BOSCH AirBag SRS 7.8.1
 203 C-Class	AIRBAG	C 200 CGI Kompr. (03-07)	BOSCH SRS AirBag
 203 C-Class	AIRBAG	C 200 CGI Kompr. (03-07)	TRW SRS
 203 C-Class	AIRBAG	C 200 Kompr. (02-03)	BOSCH AirBag SRS 7.8.1
 203 C-Class	AIRBAG	C 200 Kompr. (03-07)	BOSCH SRS AirBag
 203 C-Class	AIRBAG	C 200 Kompr. (03-07)	TRW SRS
 203 C-Class	AIRBAG	C 220 CDI (00-03)	BOSCH AirBag SRS 7.8.1
 203 C-Class	AIRBAG	C 220 CDI (03-07)	BOSCH SRS AirBag
 203 C-Class	AIRBAG	C 220 CDI (03-07)	TRW SRS
 203 C-Class	AIRBAG	C 230 (04-07)	BOSCH SRS AirBag
 203 C-Class	AIRBAG	C 230 (04-07)	TRW SRS
 203 C-Class	AIRBAG	C 230 Kompr. (04-05)	BOSCH SRS AirBag
 203 C-Class	AIRBAG	C 230 Kompr. (04-05)	TRW SRS
 203 C-Class	AIRBAG	C 240 (00-03)	BOSCH AirBag SRS 7.8.1
 203 C-Class	AIRBAG	C 240 (03-05)	BOSCH SRS AirBag
 203 C-Class	AIRBAG	C 240 (03-05)	TRW SRS
 203 C-Class	AIRBAG	C 270 CDI (00-03)	BOSCH AirBag SRS 7.8.1
 203 C-Class	AIRBAG	C 270 CDI (03-07)	BOSCH SRS AirBag
 203 C-Class	AIRBAG	C 270 CDI (03-07)	TRW SRS
 203 C-Class	AIRBAG	C 280 (05-07)	BOSCH SRS AirBag
 203 C-Class	AIRBAG	C 280 (05-07)	TRW SRS
 203 C-Class	AIRBAG	C 30 CDI AMG (03-05)	BOSCH SRS AirBag
 203 C-Class	AIRBAG	C 30 CDI AMG (03-05)	TRW SRS
 203 C-Class	AIRBAG	C 32 Kompr. AMG (00-03)	BOSCH AirBag SRS 7.8.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 203 C-Class	AIRBAG	C 32 Kompr. AMG (03-04)	BOSCH SRS AirBag
 203 C-Class	AIRBAG	C 32 Kompr. AMG (03-04)	TRW SRS
 203 C-Class	AIRBAG	C 320 (00-03)	BOSCH AirBag SRS 7.8.1
 203 C-Class	AIRBAG	C 320 (03-05)	BOSCH SRS AirBag
 203 C-Class	AIRBAG	C 320 (03-05)	TRW SRS
 203 C-Class	AIRBAG	C 320 CDI (05-07)	BOSCH SRS AirBag
 203 C-Class	AIRBAG	C 320 CDI (05-07)	TRW SRS
 203 C-Class	AIRBAG	C 350 (05-07)	BOSCH SRS AirBag
 203 C-Class	AIRBAG	C 350 (05-07)	TRW SRS
 203 C-Class	AIRBAG	C 55 AMG (04-07)	BOSCH SRS AirBag
 203 C-Class	AIRBAG	C 55 AMG (04-07)	TRW SRS
 203 C-Class	AUTOM. TRANSMISSI	C 180 Kompr. (03-07)	SIEMENS EGS 7G-Tronic
 203 C-Class	AUTOM. TRANSMISSI	C 200 CDI (03-07)	SIEMENS EGS 7G-Tronic
 203 C-Class	AUTOM. TRANSMISSI	C 200 CGI Kompr. (03-07)	SIEMENS EGS 7G-Tronic
 203 C-Class	AUTOM. TRANSMISSI	C 200 Kompr. (03-07)	SIEMENS EGS 7G-Tronic
 203 C-Class	AUTOM. TRANSMISSI	C 220 CDI (03-07)	SIEMENS EGS 7G-Tronic
 203 C-Class	AUTOM. TRANSMISSI	C 230 (04-07)	SIEMENS EGS 7G-Tronic
 203 C-Class	AUTOM. TRANSMISSI	C 230 Kompr. (04-05)	SIEMENS EGS 7G-Tronic
 203 C-Class	AUTOM. TRANSMISSI	C 240 (03-05)	SIEMENS EGS 7G-Tronic
 203 C-Class	AUTOM. TRANSMISSI	C 270 CDI (03-07)	SIEMENS EGS 7G-Tronic
 203 C-Class	AUTOM. TRANSMISSI	C 280 (05-07)	SIEMENS EGS 7G-Tronic
 203 C-Class	AUTOM. TRANSMISSI	C 30 CDI AMG (03-05)	SIEMENS EGS 7G-Tronic
 203 C-Class	AUTOM. TRANSMISSI	C 32 Kompr. AMG (03-04)	SIEMENS EGS 7G-Tronic
 203 C-Class	AUTOM. TRANSMISSI	C 320 (03-05)	SIEMENS EGS 7G-Tronic
 203 C-Class	AUTOM. TRANSMISSI	C 320 CDI (05-07)	SIEMENS EGS 7G-Tronic
 203 C-Class	AUTOM. TRANSMISSI	C 350 (05-07)	SIEMENS EGS 7G-Tronic
 203 C-Class	AUTOM. TRANSMISSI	C 55 AMG (04-07)	SIEMENS EGS 7G-Tronic
 203 C-Class	CHASSIS NETWORK	C 180 (00-03)	Marquardt OBF
 203 C-Class	CHASSIS NETWORK	C 180 (00-03)	SAM rear
 203 C-Class	CHASSIS NETWORK	C 180 Kompr. (00-03)	Marquardt OBF
 203 C-Class	CHASSIS NETWORK	C 180 Kompr. (02-03)	SAM rear
 203 C-Class	CHASSIS NETWORK	C 180 Kompr. (03-07)	SAM-V
 203 C-Class	CHASSIS NETWORK	C 200 CDI (00-03)	Marquardt OBF
 203 C-Class	CHASSIS NETWORK	C 200 CDI (00-03)	SAM rear
 203 C-Class	CHASSIS NETWORK	C 200 CDI (03-07)	SAM-V
 203 C-Class	CHASSIS NETWORK	C 200 CGI Kompr. (00-03)	Marquardt OBF
 203 C-Class	CHASSIS NETWORK	C 200 CGI Kompr. (02-03)	SAM rear
 203 C-Class	CHASSIS NETWORK	C 200 CGI Kompr. (03-07)	SAM-V
 203 C-Class	CHASSIS NETWORK	C 200 Kompr. (00-03)	Marquardt OBF
 203 C-Class	CHASSIS NETWORK	C 200 Kompr. (02-03)	SAM rear
 203 C-Class	CHASSIS NETWORK	C 200 Kompr. (03-07)	SAM-V
 203 C-Class	CHASSIS NETWORK	C 220 CDI (00-03)	Marquardt OBF
 203 C-Class	CHASSIS NETWORK	C 220 CDI (00-03)	SAM rear
 203 C-Class	CHASSIS NETWORK	C 220 CDI (03-07)	SAM-V
 203 C-Class	CHASSIS NETWORK	C 230 (00-03)	Marquardt OBF
 203 C-Class	CHASSIS NETWORK	C 230 (04-07)	SAM-V
 203 C-Class	CHASSIS NETWORK	C 230 Kompr. (00-03)	Marquardt OBF
 203 C-Class	CHASSIS NETWORK	C 230 Kompr. (04-05)	SAM-V
 203 C-Class	CHASSIS NETWORK	C 240 (00-03)	Marquardt OBF
 203 C-Class	CHASSIS NETWORK	C 240 (00-03)	SAM rear
 203 C-Class	CHASSIS NETWORK	C 240 (03-05)	SAM-V
 203 C-Class	CHASSIS NETWORK	C 270 CDI (00-03)	Marquardt OBF
 203 C-Class	CHASSIS NETWORK	C 270 CDI (00-03)	SAM rear
 203 C-Class	CHASSIS NETWORK	C 270 CDI (03-07)	SAM-V
 203 C-Class	CHASSIS NETWORK	C 280 (00-03)	Marquardt OBF
 203 C-Class	CHASSIS NETWORK	C 280 (05-07)	SAM-V
 203 C-Class	CHASSIS NETWORK	C 30 CDI AMG (00-03)	Marquardt OBF
 203 C-Class	CHASSIS NETWORK	C 30 CDI AMG (02-03)	SAM rear

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 203 C-Class	CHASSIS NETWORK	C 30 CDI AMG (03-05)	SAM-V
 203 C-Class	CHASSIS NETWORK	C 32 Kompr. AMG (00-03)	Marquardt OBF
 203 C-Class	CHASSIS NETWORK	C 32 Kompr. AMG (02-03)	SAM rear
 203 C-Class	CHASSIS NETWORK	C 32 Kompr. AMG (03-04)	SAM-V
 203 C-Class	CHASSIS NETWORK	C 320 (00-03)	Marquardt OBF
 203 C-Class	CHASSIS NETWORK	C 320 (00-03)	SAM rear
 203 C-Class	CHASSIS NETWORK	C 320 (03-05)	SAM-V
 203 C-Class	CHASSIS NETWORK	C 320 CDI (05-07)	SAM-V
 203 C-Class	CHASSIS NETWORK	C 350 (05-07)	SAM-V
 203 C-Class	CHASSIS NETWORK	C 55 AMG (04-07)	SAM-V
 203 C-Class	CLIMA	C 180 (00-03)	Klima Klimautomatik x.x.
 203 C-Class	CLIMA	C 180 Kompr. (02-03)	Klima Klimautomatik x.x.
 203 C-Class	CLIMA	C 180 Kompr. (03-07)	Klimautomatik
 203 C-Class	CLIMA	C 200 CDI (00-03)	Klima Klimautomatik x.x.
 203 C-Class	CLIMA	C 200 CDI (03-07)	Klimautomatik
 203 C-Class	CLIMA	C 200 CGI Kompr. (00-03)	Klima Klimautomatik x.x.
 203 C-Class	CLIMA	C 200 CGI Kompr. (03-07)	Klimautomatik
 203 C-Class	CLIMA	C 200 Kompr. (00-03)	Klima Klimautomatik x.x.
 203 C-Class	CLIMA	C 200 Kompr. (03-07)	Klimautomatik
 203 C-Class	CLIMA	C 220 CDI (00-03)	Klima Klimautomatik x.x.
 203 C-Class	CLIMA	C 220 CDI (03-07)	Klimautomatik
 203 C-Class	CLIMA	C 230 (04-07)	Klimautomatik
 203 C-Class	CLIMA	C 230 Kompr. (04-05)	Klimautomatik
 203 C-Class	CLIMA	C 240 (00-03)	Klima Klimautomatik x.x.
 203 C-Class	CLIMA	C 240 (03-05)	Klimautomatik
 203 C-Class	CLIMA	C 270 CDI (00-03)	Klima Klimautomatik x.x.
 203 C-Class	CLIMA	C 270 CDI (03-07)	Klimautomatik
 203 C-Class	CLIMA	C 280 (05-07)	Klimautomatik
 203 C-Class	CLIMA	C 30 CDI AMG (02-03)	Klima Klimautomatik x.x.
 203 C-Class	CLIMA	C 30 CDI AMG (03-05)	Klimautomatik
 203 C-Class	CLIMA	C 32 Kompr. AMG (00-03)	Klima Klimautomatik x.x.
 203 C-Class	CLIMA	C 32 Kompr. AMG (03-04)	Klimautomatik
 203 C-Class	CLIMA	C 320 (00-03)	Klima Klimautomatik x.x.
 203 C-Class	CLIMA	C 320 (03-05)	Klimautomatik
 203 C-Class	CLIMA	C 320 CDI (05-07)	Klimautomatik
 203 C-Class	CLIMA	C 350 (05-07)	Klimautomatik
 203 C-Class	CLIMA	C 55 AMG (04-07)	Klimautomatik
 203 C-Class	CONV. TOP/SUNROO	C 180 (00-03)	HELLA DBE
 203 C-Class	CONV. TOP/SUNROO	C 180 (00-03)	TEMIC VD
 203 C-Class	CONV. TOP/SUNROO	C 180 Kompr. (00-03)	HELLA DBE
 203 C-Class	CONV. TOP/SUNROO	C 180 Kompr. (00-03)	TEMIC VD
 203 C-Class	CONV. TOP/SUNROO	C 200 CDI (00-03)	HELLA DBE
 203 C-Class	CONV. TOP/SUNROO	C 200 CDI (00-03)	TEMIC VD
 203 C-Class	CONV. TOP/SUNROO	C 200 CGI Kompr. (00-03)	HELLA DBE
 203 C-Class	CONV. TOP/SUNROO	C 200 CGI Kompr. (00-03)	TEMIC VD
 203 C-Class	CONV. TOP/SUNROO	C 200 Kompr. (00-03)	HELLA DBE
 203 C-Class	CONV. TOP/SUNROO	C 200 Kompr. (00-03)	TEMIC VD
 203 C-Class	CONV. TOP/SUNROO	C 220 CDI (00-03)	HELLA DBE
 203 C-Class	CONV. TOP/SUNROO	C 220 CDI (00-03)	TEMIC VD
 203 C-Class	CONV. TOP/SUNROO	C 230 (00-03)	HELLA DBE
 203 C-Class	CONV. TOP/SUNROO	C 230 (00-03)	TEMIC VD
 203 C-Class	CONV. TOP/SUNROO	C 230 Kompr. (00-03)	HELLA DBE
 203 C-Class	CONV. TOP/SUNROO	C 230 Kompr. (00-03)	TEMIC VD
 203 C-Class	CONV. TOP/SUNROO	C 240 (00-03)	HELLA DBE
 203 C-Class	CONV. TOP/SUNROO	C 240 (00-03)	TEMIC VD
 203 C-Class	CONV. TOP/SUNROO	C 270 CDI (00-03)	HELLA DBE
 203 C-Class	CONV. TOP/SUNROO	C 270 CDI (00-03)	TEMIC VD
 203 C-Class	CONV. TOP/SUNROO	C 280 (00-03)	HELLA DBE

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 203 C-Class	CONV. TOP/SUNROO	C 280 (00-03)	TEMIC VD
 203 C-Class	CONV. TOP/SUNROO	C 30 CDI AMG (00-03)	HELLA DBE
 203 C-Class	CONV. TOP/SUNROO	C 30 CDI AMG (00-03)	TEMIC VD
 203 C-Class	CONV. TOP/SUNROO	C 32 Kompr. AMG (00-03)	HELLA DBE
 203 C-Class	CONV. TOP/SUNROO	C 32 Kompr. AMG (00-03)	TEMIC VD
 203 C-Class	CONV. TOP/SUNROO	C 320 (00-03)	HELLA DBE
 203 C-Class	CONV. TOP/SUNROO	C 320 (00-03)	TEMIC VD
 203 C-Class	DASHBOARD	C 180 (00-03)	VDO Kombinstrum. 1.0
 203 C-Class	DASHBOARD	C 180 (03-07)	
 203 C-Class	DASHBOARD	C 180 Kompr. (02-03)	VDO Kombinstrum. 1.0
 203 C-Class	DASHBOARD	C 180 Kompr. (03-07)	
 203 C-Class	DASHBOARD	C 200 CDI (00-03)	VDO Kombinstrum. 1.0
 203 C-Class	DASHBOARD	C 200 CDI (03-07)	
 203 C-Class	DASHBOARD	C 200 CGI Kompr. (02-03)	VDO Kombinstrum. 1.0
 203 C-Class	DASHBOARD	C 200 CGI Kompr. (03-07)	
 203 C-Class	DASHBOARD	C 200 Kompr. (02-03)	VDO Kombinstrum. 1.0
 203 C-Class	DASHBOARD	C 200 Kompr. (03-07)	
 203 C-Class	DASHBOARD	C 220 CDI (00-03)	VDO Kombinstrum. 1.0
 203 C-Class	DASHBOARD	C 220 CDI (03-07)	
 203 C-Class	DASHBOARD	C 240 (00-03)	VDO Kombinstrum. 1.0
 203 C-Class	DASHBOARD	C 270 CDI (00-03)	VDO Kombinstrum. 1.0
 203 C-Class	DASHBOARD	C 270 CDI (03-07)	
 203 C-Class	DASHBOARD	C 30 CDI AMG (02-03)	VDO Kombinstrum. 1.0
 203 C-Class	DASHBOARD	C 32 Kompr. AMG (00-03)	VDO Kombinstrum. 1.0
 203 C-Class	DASHBOARD	C 320 (00-03)	VDO Kombinstrum. 1.0
 203 C-Class	ELECTRIC STEERING	C 180 Kompr. (03-07)	MRM
 203 C-Class	ELECTRIC STEERING	C 200 CDI (03-07)	MRM
 203 C-Class	ELECTRIC STEERING	C 200 CGI Kompr. (03-07)	MRM
 203 C-Class	ELECTRIC STEERING	C 200 Kompr. (03-07)	MRM
 203 C-Class	ELECTRIC STEERING	C 220 CDI (03-07)	MRM
 203 C-Class	ELECTRIC STEERING	C 230 (04-07)	MRM
 203 C-Class	ELECTRIC STEERING	C 230 Kompr. (04-05)	MRM
 203 C-Class	ELECTRIC STEERING	C 240 (03-05)	MRM
 203 C-Class	ELECTRIC STEERING	C 270 CDI (03-07)	MRM
 203 C-Class	ELECTRIC STEERING	C 280 (05-07)	MRM
 203 C-Class	ELECTRIC STEERING	C 30 CDI AMG (03-05)	MRM
 203 C-Class	ELECTRIC STEERING	C 32 Kompr. AMG (03-04)	MRM
 203 C-Class	ELECTRIC STEERING	C 320 (03-05)	MRM
 203 C-Class	ELECTRIC STEERING	C 320 CDI (05-07)	MRM
 203 C-Class	ELECTRIC STEERING	C 350 (05-07)	MRM
 203 C-Class	ELECTRIC STEERING	C 55 AMG (04-07)	MRM
 203 C-Class	ENGINE MANAGEME	C 180 111 (00-03)	BOSCH BOSCH-SIEMENS ME-SIM4 EVO
 203 C-Class	ENGINE MANAGEME	C 180 Kompr. (02-07)	SIEMENS MPI
 203 C-Class	ENGINE MANAGEME	C 200 CDI (03-07)	BOSCH EDC Common Rail CDI 3
 203 C-Class	ENGINE MANAGEME	C 200 CDI 611 (00-03)	BOSCH EDC 15 C4 Common Rail
 203 C-Class	ENGINE MANAGEME	C 200 CDI 611 (00-03)	BOSCH EDC 15 C6 Common Rail
 203 C-Class	ENGINE MANAGEME	C 200 CGI Kompr. (03-07)	EOBD
 203 C-Class	ENGINE MANAGEME	C 200 Kompr. 111 (02-03)	BOSCH BOSCH-SIEMENS ME-SIM4 EVO
 203 C-Class	ENGINE MANAGEME	C 220 CDI (00-03)	BOSCH EDC 15 Common Rail CDI 2
 203 C-Class	ENGINE MANAGEME	C 220 CDI (03-07)	BOSCH EDC 15 Common Rail CDI 3
 203 C-Class	ENGINE MANAGEME	C 220 CDI 611 (00-03)	BOSCH EDC 15 C4 Common Rail
 203 C-Class	ENGINE MANAGEME	C 220 CDI 611 (00-03)	BOSCH EDC 15 C6 Common Rail
 203 C-Class	ENGINE MANAGEME	C 230 (01-..)	EOBD
 203 C-Class	ENGINE MANAGEME	C 230 Kompr. (01-..)	EOBD
 203 C-Class	ENGINE MANAGEME	C 240 112 (00-05)	SIEMENS MPI ME SE
 203 C-Class	ENGINE MANAGEME	C 240 112 (01-05)	EOBD
 203 C-Class	ENGINE MANAGEME	C 270 CDI 612 (00-00)	BOSCH EDC 15 C4 Common Rail
 203 C-Class	ENGINE MANAGEME	C 270 CDI 612 (00-03)	BOSCH EDC 15 C6 Common Rail

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 203 C-Class	ENGINE MANAGEME	C 280 (05-07)	EOBD
 203 C-Class	ENGINE MANAGEME	C 30 CDI AMG (04-05)	EOBD
 203 C-Class	ENGINE MANAGEME	C 32 Kompr. AMG 112 - 260kW (01-	EOBD
 203 C-Class	ENGINE MANAGEME	C 320 112 - 160kW (01-05)	EOBD
 203 C-Class	ENGINE MANAGEME	C 320 CDI (05-07)	EOBD
 203 C-Class	ENGINE MANAGEME	C 350 (05-07)	EOBD
 203 C-Class	ENGINE MANAGEME	C 55 AMG (04-07)	EOBD
 203 C-Class	IGNITION SWITCH	C 180 (00-03)	EZS
 203 C-Class	IGNITION SWITCH	C 180 Kompr. (02-03)	EZS
 203 C-Class	IGNITION SWITCH	C 180 Kompr. (03-07)	EZS
 203 C-Class	IGNITION SWITCH	C 200 CDI (00-03)	EZS
 203 C-Class	IGNITION SWITCH	C 200 CDI (03-07)	EZS
 203 C-Class	IGNITION SWITCH	C 200 CGI Kompr. (02-03)	EZS
 203 C-Class	IGNITION SWITCH	C 200 CGI Kompr. (03-07)	EZS
 203 C-Class	IGNITION SWITCH	C 200 Kompr. (02-03)	EZS
 203 C-Class	IGNITION SWITCH	C 200 Kompr. (03-07)	EZS
 203 C-Class	IGNITION SWITCH	C 220 CDI (00-03)	EZS
 203 C-Class	IGNITION SWITCH	C 220 CDI (03-07)	EZS
 203 C-Class	IGNITION SWITCH	C 230 (04-07)	EZS
 203 C-Class	IGNITION SWITCH	C 230 Kompr. (04-05)	EZS
 203 C-Class	IGNITION SWITCH	C 240 (00-03)	EZS
 203 C-Class	IGNITION SWITCH	C 240 (03-05)	EZS
 203 C-Class	IGNITION SWITCH	C 270 CDI (00-03)	EZS
 203 C-Class	IGNITION SWITCH	C 270 CDI (03-07)	EZS
 203 C-Class	IGNITION SWITCH	C 280 (05-07)	EZS
 203 C-Class	IGNITION SWITCH	C 30 CDI AMG (02-03)	EZS
 203 C-Class	IGNITION SWITCH	C 30 CDI AMG (03-05)	EZS
 203 C-Class	IGNITION SWITCH	C 32 Kompr. AMG (00-03)	EZS
 203 C-Class	IGNITION SWITCH	C 32 Kompr. AMG (03-04)	EZS
 203 C-Class	IGNITION SWITCH	C 320 (00-03)	EZS
 203 C-Class	IGNITION SWITCH	C 320 (03-05)	EZS
 203 C-Class	IGNITION SWITCH	C 320 CDI (05-07)	EZS
 203 C-Class	IGNITION SWITCH	C 350 (05-07)	EZS
 203 C-Class	IGNITION SWITCH	C 55 AMG (04-07)	EZS
 203 C-Class	LEFT FRONT DOOR	C 180 (00-03)	Temic TSG-VL
 203 C-Class	LEFT FRONT DOOR	C 180 Kompr. (02-03)	Temic TSG-VL
 203 C-Class	LEFT FRONT DOOR	C 200 CDI (00-03)	Temic TSG-VL
 203 C-Class	LEFT FRONT DOOR	C 220 CDI (00-03)	Temic TSG-VL
 203 C-Class	LEFT FRONT DOOR	C 240 (00-03)	Temic TSG-VL
 203 C-Class	LEFT FRONT DOOR	C 270 CDI (00-03)	Temic TSG-VL
 203 C-Class	LEFT FRONT DOOR	C 30 CDI AMG (02-03)	Temic TSG-VL
 203 C-Class	LEFT FRONT DOOR	C 32 Kompr. AMG (00-03)	Temic TSG-VL
 203 C-Class	LEFT FRONT DOOR	C 320 (00-03)	Temic TSG-VL
 203 C-Class	LEFT REAR DOOR	C 180 (00-03)	Temic TSG-PS
 203 C-Class	LEFT REAR DOOR	C 180 Kompr. (02-03)	Temic TSG-PS
 203 C-Class	LEFT REAR DOOR	C 200 CDI (00-03)	Temic TSG-PS
 203 C-Class	LEFT REAR DOOR	C 200 CGI Kompr. (02-03)	Temic TSG-PS
 203 C-Class	LEFT REAR DOOR	C 200 Kompr. (02-03)	Temic TSG-PS
 203 C-Class	LEFT REAR DOOR	C 220 CDI (00-03)	Temic TSG-PS
 203 C-Class	LEFT REAR DOOR	C 240 (00-03)	Temic TSG-PS
 203 C-Class	LEFT REAR DOOR	C 270 CDI (00-03)	Temic TSG-PS
 203 C-Class	LEFT REAR DOOR	C 30 CDI AMG (02-03)	Temic TSG-PS
 203 C-Class	LEFT REAR DOOR	C 32 Kompr. AMG (00-03)	Temic TSG-PS
 203 C-Class	LEFT REAR DOOR	C 320 (00-03)	Temic TSG-PS
 203 C-Class	MAINTENANCE	C 180 (00-03)	BOSCH ESP
 203 C-Class	MAINTENANCE	C 180 (00-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 180 (00-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 180 (00-03)	VDO Kombinstrum. 1.0

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 203 C-Class	MAINTENANCE	C 180 (00-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 180 (00-03)	VDO/Marelli MANUAL
 203 C-Class	MAINTENANCE	C 180 (03-07)	
 203 C-Class	MAINTENANCE	C 180 (03-07)	
 203 C-Class	MAINTENANCE	C 180 111 (00-03)	BOSCH BOSCH-SIEMENS ME-SIM4 EVO
 203 C-Class	MAINTENANCE	C 180 Kompr. (02-03)	BOSCH ESP
 203 C-Class	MAINTENANCE	C 180 Kompr. (02-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 180 Kompr. (02-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 180 Kompr. (02-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 180 Kompr. (02-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 180 Kompr. (02-03)	VDO/Marelli MANUAL
 203 C-Class	MAINTENANCE	C 180 Kompr. (03-07)	
 203 C-Class	MAINTENANCE	C 180 Kompr. (03-07)	
 203 C-Class	MAINTENANCE	C 180 Kompr. (03-07)	MANUAL
 203 C-Class	MAINTENANCE	C 200 CDI (00-03)	BOSCH ESP
 203 C-Class	MAINTENANCE	C 200 CDI (00-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 200 CDI (00-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 200 CDI (00-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 200 CDI (00-03)	VDO/Marelli MANUAL
 203 C-Class	MAINTENANCE	C 200 CDI (03-07)	
 203 C-Class	MAINTENANCE	C 200 CDI (03-07)	
 203 C-Class	MAINTENANCE	C 200 CDI (03-07)	MANUAL
 203 C-Class	MAINTENANCE	C 200 CGI Kompr. (00-03)	VDO/Marelli MANUAL
 203 C-Class	MAINTENANCE	C 200 CGI Kompr. (02-03)	BOSCH ESP
 203 C-Class	MAINTENANCE	C 200 CGI Kompr. (02-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 200 CGI Kompr. (02-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 200 CGI Kompr. (02-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 200 CGI Kompr. (02-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 200 CGI Kompr. (03-07)	
 203 C-Class	MAINTENANCE	C 200 CGI Kompr. (03-07)	
 203 C-Class	MAINTENANCE	C 200 CGI Kompr. (03-07)	MANUAL
 203 C-Class	MAINTENANCE	C 200 Kompr. (00-03)	VDO/Marelli MANUAL
 203 C-Class	MAINTENANCE	C 200 Kompr. (02-03)	BOSCH ESP
 203 C-Class	MAINTENANCE	C 200 Kompr. (02-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 200 Kompr. (02-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 200 Kompr. (02-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 200 Kompr. (03-07)	
 203 C-Class	MAINTENANCE	C 200 Kompr. (03-07)	
 203 C-Class	MAINTENANCE	C 200 Kompr. (03-07)	MANUAL
 203 C-Class	MAINTENANCE	C 200 Kompr. 111 (02-03)	BOSCH BOSCH-SIEMENS ME-SIM4 EVO
 203 C-Class	MAINTENANCE	C 220 CDI (00-03)	BOSCH ESP
 203 C-Class	MAINTENANCE	C 220 CDI (00-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 220 CDI (00-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 220 CDI (00-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 220 CDI (00-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 220 CDI (00-03)	VDO/Marelli MANUAL
 203 C-Class	MAINTENANCE	C 220 CDI (03-07)	
 203 C-Class	MAINTENANCE	C 220 CDI (03-07)	
 203 C-Class	MAINTENANCE	C 220 CDI (03-07)	MANUAL
 203 C-Class	MAINTENANCE	C 230 (04-07)	MANUAL
 203 C-Class	MAINTENANCE	C 230 Kompr. (04-05)	MANUAL
 203 C-Class	MAINTENANCE	C 240 (00-03)	BOSCH ESP
 203 C-Class	MAINTENANCE	C 240 (00-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 240 (00-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 240 (00-03)	VDO Kombinstrum. 1.0

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 203 C-Class	MAINTENANCE	C 240 (00-03)	VDO/Marelli MANUAL
 203 C-Class	MAINTENANCE	C 240 (03-05)	MANUAL
 203 C-Class	MAINTENANCE	C 270 CDI (00-03)	BOSCH ESP
 203 C-Class	MAINTENANCE	C 270 CDI (00-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 270 CDI (00-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 270 CDI (00-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 270 CDI (00-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 270 CDI (00-03)	VDO/Marelli MANUAL
 203 C-Class	MAINTENANCE	C 270 CDI (03-07)	
 203 C-Class	MAINTENANCE	C 270 CDI (03-07)	
 203 C-Class	MAINTENANCE	C 270 CDI (03-07)	MANUAL
 203 C-Class	MAINTENANCE	C 280 (05-07)	MANUAL
 203 C-Class	MAINTENANCE	C 30 CDI AMG (02-03)	BOSCH ESP
 203 C-Class	MAINTENANCE	C 30 CDI AMG (02-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 30 CDI AMG (02-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 30 CDI AMG (02-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 30 CDI AMG (02-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 30 CDI AMG (02-03)	VDO/Marelli MANUAL
 203 C-Class	MAINTENANCE	C 30 CDI AMG (03-05)	MANUAL
 203 C-Class	MAINTENANCE	C 32 Kompr. AMG (00-03)	BOSCH ESP
 203 C-Class	MAINTENANCE	C 32 Kompr. AMG (00-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 32 Kompr. AMG (00-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 32 Kompr. AMG (00-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 32 Kompr. AMG (00-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 32 Kompr. AMG (00-03)	VDO/Marelli MANUAL
 203 C-Class	MAINTENANCE	C 32 Kompr. AMG (03-04)	MANUAL
 203 C-Class	MAINTENANCE	C 320 (00-03)	BOSCH ESP
 203 C-Class	MAINTENANCE	C 320 (00-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 320 (00-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 320 (00-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 320 (00-03)	VDO Kombinstrum. 1.0
 203 C-Class	MAINTENANCE	C 320 (00-03)	VDO/Marelli MANUAL
 203 C-Class	MAINTENANCE	C 320 (03-05)	MANUAL
 203 C-Class	MAINTENANCE	C 320 CDI (05-07)	MANUAL
 203 C-Class	MAINTENANCE	C 350 (05-07)	MANUAL
 203 C-Class	MAINTENANCE	C 55 AMG (04-07)	MANUAL
 203 C-Class	PARKING HELP	C 180 Kompr. (03-07)	PDC
 203 C-Class	PARKING HELP	C 200 CDI (03-07)	PDC
 203 C-Class	PARKING HELP	C 200 CGI Kompr. (03-07)	PDC
 203 C-Class	PARKING HELP	C 200 Kompr. (03-07)	PDC
 203 C-Class	PARKING HELP	C 220 CDI (03-07)	PDC
 203 C-Class	PARKING HELP	C 230 (04-07)	PDC
 203 C-Class	PARKING HELP	C 230 Kompr. (04-05)	PDC
 203 C-Class	PARKING HELP	C 240 (03-05)	PDC
 203 C-Class	PARKING HELP	C 270 CDI (03-07)	PDC
 203 C-Class	PARKING HELP	C 280 (05-07)	PDC
 203 C-Class	PARKING HELP	C 30 CDI AMG (03-05)	PDC
 203 C-Class	PARKING HELP	C 32 Kompr. AMG (03-04)	PDC
 203 C-Class	PARKING HELP	C 320 (03-05)	PDC
 203 C-Class	PARKING HELP	C 320 CDI (05-07)	PDC
 203 C-Class	PARKING HELP	C 350 (05-07)	PDC
 203 C-Class	PARKING HELP	C 55 AMG (04-07)	PDC
 203 C-Class	RADIO / CD	C 180 (03-07)	Becker D2B
 203 C-Class	RADIO / CD	C 180 Kompr. (03-07)	Becker D2B
 203 C-Class	RADIO / CD	C 200 CDI (03-07)	Becker D2B
 203 C-Class	RADIO / CD	C 200 CGI Kompr. (03-07)	Becker D2B
 203 C-Class	RADIO / CD	C 200 Kompr. (03-07)	Becker D2B
 203 C-Class	RADIO / CD	C 220 CDI (03-07)	Becker D2B

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 203 C-Class	RADIO / CD	C 230 (04-07)	Becker D2B
 203 C-Class	RADIO / CD	C 230 Kompr. (04-05)	Becker D2B
 203 C-Class	RADIO / CD	C 240 (03-05)	Becker D2B
 203 C-Class	RADIO / CD	C 270 CDI (03-07)	Becker D2B
 203 C-Class	RADIO / CD	C 280 (05-07)	Becker D2B
 203 C-Class	RADIO / CD	C 30 CDI AMG (03-05)	Becker D2B
 203 C-Class	RADIO / CD	C 32 Kompr. AMG (03-04)	Becker D2B
 203 C-Class	RADIO / CD	C 320 (03-05)	Becker D2B
 203 C-Class	RADIO / CD	C 320 CDI (05-07)	Becker D2B
 203 C-Class	RADIO / CD	C 350 (05-07)	Becker D2B
 203 C-Class	RADIO / CD	C 55 AMG (04-07)	Becker D2B
 203 C-Class	RIGHT FRONT DOOR	C 180 (00-03)	Temic TSG-VR
 203 C-Class	RIGHT FRONT DOOR	C 180 Kompr. (02-03)	Temic TSG-VR
 203 C-Class	RIGHT FRONT DOOR	C 200 CDI (00-03)	Temic TSG-VR
 203 C-Class	RIGHT FRONT DOOR	C 200 CGI Kompr. (02-03)	Temic TSG-VR
 203 C-Class	RIGHT FRONT DOOR	C 200 CGI Kompr. (02-03)	Temic TSG-VR
 203 C-Class	RIGHT FRONT DOOR	C 200 Kompr. (02-03)	Temic TSG-VR
 203 C-Class	RIGHT FRONT DOOR	C 200 Kompr. (02-03)	Temic TSG-VR
 203 C-Class	RIGHT FRONT DOOR	C 220 CDI (00-03)	Temic TSG-VR
 203 C-Class	RIGHT FRONT DOOR	C 240 (00-03)	Temic TSG-VR
 203 C-Class	RIGHT FRONT DOOR	C 270 CDI (00-03)	Temic TSG-VR
 203 C-Class	RIGHT FRONT DOOR	C 30 CDI AMG (02-03)	Temic TSG-VR
 203 C-Class	RIGHT FRONT DOOR	C 32 Kompr. AMG (00-03)	Temic TSG-VR
 203 C-Class	RIGHT FRONT DOOR	C 320 (00-03)	Temic TSG-VR
 203 C-Class	RIGHT REAR DOOR	C 180 (00-03)	Temic TSG-PD
 203 C-Class	RIGHT REAR DOOR	C 180 Kompr. (02-03)	Temic TSG-PD
 203 C-Class	RIGHT REAR DOOR	C 200 CDI (00-03)	Temic TSG-PD
 203 C-Class	RIGHT REAR DOOR	C 200 CGI Kompr. (02-03)	Temic TSG-PD
 203 C-Class	RIGHT REAR DOOR	C 200 Kompr. (02-03)	Temic TSG-PD
 203 C-Class	RIGHT REAR DOOR	C 220 CDI (00-03)	Temic TSG-PD
 203 C-Class	RIGHT REAR DOOR	C 240 (00-03)	Temic TSG-PD
 203 C-Class	RIGHT REAR DOOR	C 270 CDI (00-03)	Temic TSG-PD
 203 C-Class	RIGHT REAR DOOR	C 30 CDI AMG (02-03)	Temic TSG-PD
 203 C-Class	RIGHT REAR DOOR	C 32 Kompr. AMG (00-03)	Temic TSG-PD
 203 C-Class	RIGHT REAR DOOR	C 320 (00-03)	Temic TSG-PD
 203 C-Class	SERVICE LIGHT RES	C 180 (00-03)	VDO/Marelli MANUAL
 203 C-Class	SERVICE LIGHT RES	C 180 Kompr. (02-03)	VDO/Marelli MANUAL
 203 C-Class	SERVICE LIGHT RES	C 180 Kompr. (03-07)	MANUAL
 203 C-Class	SERVICE LIGHT RES	C 200 CDI (00-03)	VDO/Marelli MANUAL
 203 C-Class	SERVICE LIGHT RES	C 200 CDI (03-07)	MANUAL
 203 C-Class	SERVICE LIGHT RES	C 200 CGI Kompr. (00-03)	VDO/Marelli MANUAL
 203 C-Class	SERVICE LIGHT RES	C 200 CGI Kompr. (03-07)	MANUAL
 203 C-Class	SERVICE LIGHT RES	C 200 Kompr. (00-03)	VDO/Marelli MANUAL
 203 C-Class	SERVICE LIGHT RES	C 200 Kompr. (03-07)	MANUAL
 203 C-Class	SERVICE LIGHT RES	C 220 CDI (00-03)	VDO/Marelli MANUAL
 203 C-Class	SERVICE LIGHT RES	C 220 CDI (03-07)	MANUAL
 203 C-Class	SERVICE LIGHT RES	C 230 (04-07)	MANUAL
 203 C-Class	SERVICE LIGHT RES	C 230 Kompr. (04-05)	MANUAL
 203 C-Class	SERVICE LIGHT RES	C 240 (00-03)	VDO/Marelli MANUAL
 203 C-Class	SERVICE LIGHT RES	C 240 (03-05)	MANUAL
 203 C-Class	SERVICE LIGHT RES	C 270 CDI (00-03)	VDO/Marelli MANUAL
 203 C-Class	SERVICE LIGHT RES	C 270 CDI (03-07)	MANUAL
 203 C-Class	SERVICE LIGHT RES	C 280 (05-07)	MANUAL
 203 C-Class	SERVICE LIGHT RES	C 30 CDI AMG (02-03)	VDO/Marelli MANUAL
 203 C-Class	SERVICE LIGHT RES	C 30 CDI AMG (03-05)	MANUAL
 203 C-Class	SERVICE LIGHT RES	C 32 Kompr. AMG (00-03)	VDO/Marelli MANUAL
 203 C-Class	SERVICE LIGHT RES	C 32 Kompr. AMG (03-04)	MANUAL
 203 C-Class	SERVICE LIGHT RES	C 320 (00-03)	VDO/Marelli MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 203 C-Class	SERVICE LIGHT RES	C 320 (03-05)	MANUAL
 203 C-Class	SERVICE LIGHT RES	C 320 CDI (05-07)	MANUAL
 203 C-Class	SERVICE LIGHT RES	C 350 (05-07)	MANUAL
 203 C-Class	SERVICE LIGHT RES	C 55 AMG (04-07)	MANUAL
 203 C-Class	TOW FUNCTION	C 180 (00-03)	Hella AHE
 203 C-Class	TOW FUNCTION	C 180 Kompr. (02-03)	Hella AHE
 203 C-Class	TOW FUNCTION	C 200 CDI (00-03)	Hella AHE
 203 C-Class	TOW FUNCTION	C 200 CGI Kompr. (02-03)	Hella AHE
 203 C-Class	TOW FUNCTION	C 200 Kompr. (02-03)	Hella AHE
 203 C-Class	TOW FUNCTION	C 220 CDI (00-03)	Hella AHE
 203 C-Class	TOW FUNCTION	C 240 (00-03)	Hella AHE
 203 C-Class	TOW FUNCTION	C 270 CDI (00-03)	Hella AHE
 203 C-Class	TOW FUNCTION	C 30 CDI AMG (02-03)	Hella AHE
 203 C-Class	TOW FUNCTION	C 32 Kompr. AMG (00-03)	Hella AHE
 203 C-Class	TOW FUNCTION	C 320 (00-03)	Hella AHE
 204 C-Class	ABS + TRACT. CONT	C 180 CGI (07-..)	Teves ESP
 204 C-Class	ABS + TRACT. CONT	C 180 Kompr. (07-..)	Teves ESP
 204 C-Class	ABS + TRACT. CONT	C 200 CDI (07-..)	Teves ESP
 204 C-Class	ABS + TRACT. CONT	C 200 CGI (07-..)	Teves ESP
 204 C-Class	ABS + TRACT. CONT	C 200 Kompr. (07-..)	Teves ESP
 204 C-Class	ABS + TRACT. CONT	C 220 CDI (07-..)	Teves ESP
 204 C-Class	ABS + TRACT. CONT	C 230 (07-..)	Teves ESP
 204 C-Class	ABS + TRACT. CONT	C 250 CDI (07-..)	Teves ESP
 204 C-Class	ABS + TRACT. CONT	C 250 CGI (07-..)	Teves ESP
 204 C-Class	ABS + TRACT. CONT	C 280 (07-..)	Teves ESP
 204 C-Class	ABS + TRACT. CONT	C 300 (07-..)	Teves ESP
 204 C-Class	ABS + TRACT. CONT	C 320 CDI (07-..)	Teves ESP
 204 C-Class	ABS + TRACT. CONT	C 350 (07-..)	Teves ESP
 204 C-Class	ABS + TRACT. CONT	C 350 CDI (07-..)	Teves ESP
 204 C-Class	ABS + TRACT. CONT	C 350 CGI (07-..)	Teves ESP
 204 C-Class	ABS + TRACT. CONT	C 63 AMG (07-..)	Teves ESP
 204 C-Class	AIRBAG	C 180 CGI (07-..)	Siemens VDO
 204 C-Class	AIRBAG	C 180 Kompr. (07-..)	Siemens VDO
 204 C-Class	AIRBAG	C 200 CDI (07-..)	Siemens VDO
 204 C-Class	AIRBAG	C 200 CGI (07-..)	Siemens VDO
 204 C-Class	AIRBAG	C 200 Kompr. (07-..)	Siemens VDO
 204 C-Class	AIRBAG	C 220 CDI (07-..)	Siemens VDO
 204 C-Class	AIRBAG	C 230 (07-..)	Siemens VDO
 204 C-Class	AIRBAG	C 250 CDI (07-..)	Siemens VDO
 204 C-Class	AIRBAG	C 250 CGI (07-..)	Siemens VDO
 204 C-Class	AIRBAG	C 280 (07-..)	Siemens VDO
 204 C-Class	AIRBAG	C 300 (07-..)	Siemens VDO
 204 C-Class	AIRBAG	C 320 CDI (07-..)	Siemens VDO
 204 C-Class	AIRBAG	C 350 (07-..)	Siemens VDO
 204 C-Class	AIRBAG	C 350 CGI (07-..)	Siemens VDO
 204 C-Class	AIRBAG	C 63 AMG (07-..)	Siemens VDO
 204 C-Class	AUTOM. TRANSMISSI	C 180 CGI (07-..)	Siemens EGS 53
 204 C-Class	AUTOM. TRANSMISSI	C 180 Kompr. (07-..)	Siemens EGS 53
 204 C-Class	AUTOM. TRANSMISSI	C 200 CDI (07-..)	Siemens EGS 53
 204 C-Class	AUTOM. TRANSMISSI	C 200 CGI (07-..)	Siemens EGS 53
 204 C-Class	AUTOM. TRANSMISSI	C 200 Kompr. (07-..)	Siemens EGS 53
 204 C-Class	AUTOM. TRANSMISSI	C 220 CDI (07-..)	Siemens EGS 53
 204 C-Class	AUTOM. TRANSMISSI	C 230 (07-..)	Siemens EGS 53
 204 C-Class	AUTOM. TRANSMISSI	C 250 CDI (07-..)	Siemens EGS 53
 204 C-Class	AUTOM. TRANSMISSI	C 250 CGI (07-..)	Siemens EGS 53
 204 C-Class	AUTOM. TRANSMISSI	C 280 (07-..)	Siemens EGS 53
 204 C-Class	AUTOM. TRANSMISSI	C 300 (07-..)	Siemens EGS 53
 204 C-Class	AUTOM. TRANSMISSI	C 320 CDI (07-..)	Siemens EGS 53

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 204 C-Class	AUTOM. TRANSMISSI	C 350 (07-..)	Siemens EGS 53
 204 C-Class	AUTOM. TRANSMISSI	C 350 CDI (07-..)	Siemens EGS 53
 204 C-Class	AUTOM. TRANSMISSI	C 350 CGI (07-..)	Siemens EGS 53
 204 C-Class	AUTOM. TRANSMISSI	C 63 AMG (07-..)	Siemens EGS 53
 204 C-Class	CHASSIS NETWORK	C 180 CGI (07-..)	Bosch ZGW
 204 C-Class	CHASSIS NETWORK	C 180 Kompr. (07-..)	Bosch ZGW
 204 C-Class	CHASSIS NETWORK	C 200 CDI (07-..)	Bosch ZGW
 204 C-Class	CHASSIS NETWORK	C 200 CGI (07-..)	Bosch ZGW
 204 C-Class	CHASSIS NETWORK	C 200 Kompr. (07-..)	Bosch ZGW
 204 C-Class	CHASSIS NETWORK	C 220 CDI (07-..)	Bosch ZGW
 204 C-Class	CHASSIS NETWORK	C 230 (07-..)	Bosch ZGW
 204 C-Class	CHASSIS NETWORK	C 250 CDI (07-..)	Bosch ZGW
 204 C-Class	CHASSIS NETWORK	C 280 (07-..)	Bosch ZGW
 204 C-Class	CHASSIS NETWORK	C 300 (07-..)	Bosch ZGW
 204 C-Class	CHASSIS NETWORK	C 320 CDI (07-..)	Bosch ZGW
 204 C-Class	CHASSIS NETWORK	C 350 (07-..)	Bosch ZGW
 204 C-Class	CHASSIS NETWORK	C 350 CGI (07-..)	Bosch ZGW
 204 C-Class	CHASSIS NETWORK	C 63 AMG (07-..)	Bosch ZGW
 204 C-Class	CLIMA	C 180 CGI (07-..)	VDO KLA
 204 C-Class	CLIMA	C 180 Kompr. (07-..)	VDO KLA
 204 C-Class	CLIMA	C 200 CDI (07-..)	VDO KLA
 204 C-Class	CLIMA	C 200 CGI (07-..)	VDO KLA
 204 C-Class	CLIMA	C 200 Kompr. (07-..)	VDO KLA
 204 C-Class	CLIMA	C 220 CDI (07-..)	VDO KLA
 204 C-Class	CLIMA	C 230 (07-..)	VDO KLA
 204 C-Class	CLIMA	C 250 CDI (07-..)	VDO KLA
 204 C-Class	CLIMA	C 250 CGI (07-..)	VDO KLA
 204 C-Class	CLIMA	C 280 (07-..)	VDO KLA
 204 C-Class	CLIMA	C 300 (07-..)	VDO KLA
 204 C-Class	CLIMA	C 320 CDI (07-..)	VDO KLA
 204 C-Class	CLIMA	C 350 (07-..)	VDO KLA
 204 C-Class	CLIMA	C 350 CDI (07-..)	VDO KLA
 204 C-Class	CLIMA	C 350 CGI (07-..)	VDO KLA
 204 C-Class	CLIMA	C 63 AMG (07-..)	VDO KLA
 204 C-Class	DASHBOARD	C 180 CGI (07-..)	Siemens VDO
 204 C-Class	DASHBOARD	C 180 Kompr. (07-..)	Siemens VDO
 204 C-Class	DASHBOARD	C 200 CDI (07-..)	Siemens VDO
 204 C-Class	DASHBOARD	C 200 CGI (07-..)	Siemens VDO
 204 C-Class	DASHBOARD	C 200 Kompr. (07-..)	Siemens VDO
 204 C-Class	DASHBOARD	C 220 CDI (07-..)	Siemens VDO
 204 C-Class	DASHBOARD	C 230 (07-..)	Siemens VDO
 204 C-Class	DASHBOARD	C 250 CDI (07-..)	Siemens VDO
 204 C-Class	DASHBOARD	C 250 CGI (07-..)	Siemens VDO
 204 C-Class	DASHBOARD	C 280 (07-..)	Siemens VDO
 204 C-Class	DASHBOARD	C 300 (07-..)	Siemens VDO
 204 C-Class	DASHBOARD	C 320 CDI (07-..)	Siemens VDO
 204 C-Class	DASHBOARD	C 350 (07-..)	Siemens VDO
 204 C-Class	DASHBOARD	C 350 CDI (07-..)	Siemens VDO
 204 C-Class	DASHBOARD	C 350 CGI (07-..)	Siemens VDO
 204 C-Class	DASHBOARD	C 63 AMG (07-..)	Siemens VDO
 204 C-Class	ENGINE MANAGEME	C 180 CGI (07-..)	EOBD
 204 C-Class	ENGINE MANAGEME	C 180 Kompr. (07-..)	Siemens
 204 C-Class	ENGINE MANAGEME	C 200 CDI (07-..)	EOBD
 204 C-Class	ENGINE MANAGEME	C 200 CGI (07-..)	EOBD
 204 C-Class	ENGINE MANAGEME	C 200 Kompr. (07-..)	Siemens
 204 C-Class	ENGINE MANAGEME	C 220 CDI (07-..)	DELPHI EDC
 204 C-Class	ENGINE MANAGEME	C 220 CDI (07-..)	EOBD
 204 C-Class	ENGINE MANAGEME	C 230 (07-..)	EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 204 C-Class	ENGINE MANAGEME	C 250 CDI (07-..)	DELPHI EDC
 204 C-Class	ENGINE MANAGEME	C 250 CGI (07-..)	EOBD
 204 C-Class	ENGINE MANAGEME	C 280 (07-..)	EOBD
 204 C-Class	ENGINE MANAGEME	C 300 (07-..)	EOBD
 204 C-Class	ENGINE MANAGEME	C 320 CDI (07-..)	EOBD
 204 C-Class	ENGINE MANAGEME	C 350 (07-..)	EOBD
 204 C-Class	ENGINE MANAGEME	C 350 CDI (07-..)	EOBD
 204 C-Class	ENGINE MANAGEME	C 350 CGI (07-..)	EOBD
 204 C-Class	ENGINE MANAGEME	C 63 AMG (07-..)	EOBD
 204 C-Class	MAINTENANCE	C 180 CGI (07-..)	
 204 C-Class	MAINTENANCE	C 180 CGI (07-..)	
 204 C-Class	MAINTENANCE	C 180 CGI (07-..)	Siemens VDO
 204 C-Class	MAINTENANCE	C 180 CGI (07-..)	Teves ESP
 204 C-Class	MAINTENANCE	C 180 CGI (07-..)	VDO KLA
 204 C-Class	MAINTENANCE	C 180 CGI (07-..)	VDO MANUAL
 204 C-Class	MAINTENANCE	C 180 Kompr. (07-..)	
 204 C-Class	MAINTENANCE	C 180 Kompr. (07-..)	
 204 C-Class	MAINTENANCE	C 180 Kompr. (07-..)	Siemens VDO
 204 C-Class	MAINTENANCE	C 180 Kompr. (07-..)	Teves ESP
 204 C-Class	MAINTENANCE	C 180 Kompr. (07-..)	VDO KLA
 204 C-Class	MAINTENANCE	C 180 Kompr. (07-..)	VDO MANUAL
 204 C-Class	MAINTENANCE	C 200 CDI (07-..)	
 204 C-Class	MAINTENANCE	C 200 CDI (07-..)	
 204 C-Class	MAINTENANCE	C 200 CDI (07-..)	Siemens VDO
 204 C-Class	MAINTENANCE	C 200 CDI (07-..)	Teves ESP
 204 C-Class	MAINTENANCE	C 200 CDI (07-..)	VDO KLA
 204 C-Class	MAINTENANCE	C 200 CDI (07-..)	VDO MANUAL
 204 C-Class	MAINTENANCE	C 200 CGI (07-..)	
 204 C-Class	MAINTENANCE	C 200 CGI (07-..)	
 204 C-Class	MAINTENANCE	C 200 CGI (07-..)	Siemens VDO
 204 C-Class	MAINTENANCE	C 200 CGI (07-..)	Teves ESP
 204 C-Class	MAINTENANCE	C 200 CGI (07-..)	VDO KLA
 204 C-Class	MAINTENANCE	C 200 CGI (07-..)	VDO MANUAL
 204 C-Class	MAINTENANCE	C 200 Kompr. (07-..)	
 204 C-Class	MAINTENANCE	C 200 Kompr. (07-..)	
 204 C-Class	MAINTENANCE	C 200 Kompr. (07-..)	Siemens VDO
 204 C-Class	MAINTENANCE	C 200 Kompr. (07-..)	Teves ESP
 204 C-Class	MAINTENANCE	C 200 Kompr. (07-..)	VDO KLA
 204 C-Class	MAINTENANCE	C 200 Kompr. (07-..)	VDO MANUAL
 204 C-Class	MAINTENANCE	C 220 CDI (07-..)	
 204 C-Class	MAINTENANCE	C 220 CDI (07-..)	
 204 C-Class	MAINTENANCE	C 220 CDI (07-..)	Siemens VDO
 204 C-Class	MAINTENANCE	C 220 CDI (07-..)	Teves ESP
 204 C-Class	MAINTENANCE	C 220 CDI (07-..)	VDO KLA
 204 C-Class	MAINTENANCE	C 220 CDI (07-..)	VDO MANUAL
 204 C-Class	MAINTENANCE	C 230 (07-..)	
 204 C-Class	MAINTENANCE	C 230 (07-..)	
 204 C-Class	MAINTENANCE	C 230 (07-..)	Siemens VDO
 204 C-Class	MAINTENANCE	C 230 (07-..)	Teves ESP
 204 C-Class	MAINTENANCE	C 230 (07-..)	VDO KLA
 204 C-Class	MAINTENANCE	C 230 (07-..)	VDO MANUAL
 204 C-Class	MAINTENANCE	C 250 CDI (07-..)	
 204 C-Class	MAINTENANCE	C 250 CDI (07-..)	
 204 C-Class	MAINTENANCE	C 250 CDI (07-..)	Siemens VDO
 204 C-Class	MAINTENANCE	C 250 CDI (07-..)	Teves ESP
 204 C-Class	MAINTENANCE	C 250 CDI (07-..)	VDO KLA
 204 C-Class	MAINTENANCE	C 250 CDI (07-..)	VDO MANUAL
 204 C-Class	MAINTENANCE	C 250 CGI (07-..)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 204 C-Class	MAINTENANCE	C 250 CGI (07-..)	
 204 C-Class	MAINTENANCE	C 250 CGI (07-..)	Siemens VDO
 204 C-Class	MAINTENANCE	C 250 CGI (07-..)	Teves ESP
 204 C-Class	MAINTENANCE	C 250 CGI (07-..)	VDO KLA
 204 C-Class	MAINTENANCE	C 250 CGI (07-..)	VDO MANUAL
 204 C-Class	MAINTENANCE	C 280 (07-..)	
 204 C-Class	MAINTENANCE	C 280 (07-..)	
 204 C-Class	MAINTENANCE	C 280 (07-..)	Siemens VDO
 204 C-Class	MAINTENANCE	C 280 (07-..)	Teves ESP
 204 C-Class	MAINTENANCE	C 280 (07-..)	VDO KLA
 204 C-Class	MAINTENANCE	C 280 (07-..)	VDO MANUAL
 204 C-Class	MAINTENANCE	C 300 (07-..)	
 204 C-Class	MAINTENANCE	C 300 (07-..)	
 204 C-Class	MAINTENANCE	C 300 (07-..)	Siemens VDO
 204 C-Class	MAINTENANCE	C 300 (07-..)	Teves ESP
 204 C-Class	MAINTENANCE	C 300 (07-..)	VDO KLA
 204 C-Class	MAINTENANCE	C 300 (07-..)	VDO MANUAL
 204 C-Class	MAINTENANCE	C 320 CDI (07-..)	
 204 C-Class	MAINTENANCE	C 320 CDI (07-..)	
 204 C-Class	MAINTENANCE	C 320 CDI (07-..)	Siemens VDO
 204 C-Class	MAINTENANCE	C 320 CDI (07-..)	Teves ESP
 204 C-Class	MAINTENANCE	C 320 CDI (07-..)	VDO KLA
 204 C-Class	MAINTENANCE	C 320 CDI (07-..)	VDO MANUAL
 204 C-Class	MAINTENANCE	C 350 (07-..)	
 204 C-Class	MAINTENANCE	C 350 (07-..)	
 204 C-Class	MAINTENANCE	C 350 (07-..)	Siemens VDO
 204 C-Class	MAINTENANCE	C 350 (07-..)	Teves ESP
 204 C-Class	MAINTENANCE	C 350 (07-..)	VDO KLA
 204 C-Class	MAINTENANCE	C 350 (07-..)	VDO MANUAL
 204 C-Class	MAINTENANCE	C 350 CDI (07-..)	
 204 C-Class	MAINTENANCE	C 350 CDI (07-..)	
 204 C-Class	MAINTENANCE	C 350 CDI (07-..)	Siemens VDO
 204 C-Class	MAINTENANCE	C 350 CDI (07-..)	Teves ESP
 204 C-Class	MAINTENANCE	C 350 CDI (07-..)	VDO KLA
 204 C-Class	MAINTENANCE	C 350 CDI (07-..)	VDO MANUAL
 204 C-Class	MAINTENANCE	C 350 CGI (07-..)	
 204 C-Class	MAINTENANCE	C 350 CGI (07-..)	
 204 C-Class	MAINTENANCE	C 350 CGI (07-..)	Siemens VDO
 204 C-Class	MAINTENANCE	C 350 CGI (07-..)	Teves ESP
 204 C-Class	MAINTENANCE	C 350 CGI (07-..)	VDO KLA
 204 C-Class	MAINTENANCE	C 350 CGI (07-..)	VDO MANUAL
 204 C-Class	MAINTENANCE	C 63 AMG (07-..)	
 204 C-Class	MAINTENANCE	C 63 AMG (07-..)	
 204 C-Class	MAINTENANCE	C 63 AMG (07-..)	Siemens VDO
 204 C-Class	MAINTENANCE	C 63 AMG (07-..)	Teves ESP
 204 C-Class	MAINTENANCE	C 63 AMG (07-..)	VDO KLA
 204 C-Class	MAINTENANCE	C 63 AMG (07-..)	VDO MANUAL
 204 C-Class	PARKING HELP	C 180 CGI (07-..)	
 204 C-Class	PARKING HELP	C 180 Kompr. (07-..)	
 204 C-Class	PARKING HELP	C 200 CDI (07-..)	
 204 C-Class	PARKING HELP	C 200 CGI (07-..)	
 204 C-Class	PARKING HELP	C 200 Kompr. (07-..)	
 204 C-Class	PARKING HELP	C 220 CDI (07-..)	
 204 C-Class	PARKING HELP	C 230 (07-..)	
 204 C-Class	PARKING HELP	C 250 CDI (07-..)	
 204 C-Class	PARKING HELP	C 250 CGI (07-..)	
 204 C-Class	PARKING HELP	C 280 (07-..)	
 204 C-Class	PARKING HELP	C 300 (07-..)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 204 C-Class	PARKING HELP	C 320 CDI (07-..)	
 204 C-Class	PARKING HELP	C 350 (07-..)	
 204 C-Class	PARKING HELP	C 350 CDI (07-..)	
 204 C-Class	PARKING HELP	C 350 CGI (07-..)	
 204 C-Class	PARKING HELP	C 63 AMG (07-..)	
 204 C-Class	SERVICE LIGHT RES	C 180 CGI (07-..)	
 204 C-Class	SERVICE LIGHT RES	C 180 CGI (07-..)	VDO MANUAL
 204 C-Class	SERVICE LIGHT RES	C 180 Kompr. (07-..)	
 204 C-Class	SERVICE LIGHT RES	C 180 Kompr. (07-..)	VDO MANUAL
 204 C-Class	SERVICE LIGHT RES	C 200 CDI (07-..)	
 204 C-Class	SERVICE LIGHT RES	C 200 CDI (07-..)	VDO MANUAL
 204 C-Class	SERVICE LIGHT RES	C 200 CGI (07-..)	
 204 C-Class	SERVICE LIGHT RES	C 200 CGI (07-..)	VDO MANUAL
 204 C-Class	SERVICE LIGHT RES	C 200 Kompr. (07-..)	
 204 C-Class	SERVICE LIGHT RES	C 200 Kompr. (07-..)	VDO MANUAL
 204 C-Class	SERVICE LIGHT RES	C 220 CDI (07-..)	
 204 C-Class	SERVICE LIGHT RES	C 220 CDI (07-..)	VDO MANUAL
 204 C-Class	SERVICE LIGHT RES	C 230 (07-..)	
 204 C-Class	SERVICE LIGHT RES	C 230 (07-..)	VDO MANUAL
 204 C-Class	SERVICE LIGHT RES	C 250 CDI (07-..)	
 204 C-Class	SERVICE LIGHT RES	C 250 CDI (07-..)	VDO MANUAL
 204 C-Class	SERVICE LIGHT RES	C 250 CGI (07-..)	
 204 C-Class	SERVICE LIGHT RES	C 250 CGI (07-..)	VDO MANUAL
 204 C-Class	SERVICE LIGHT RES	C 280 (07-..)	
 204 C-Class	SERVICE LIGHT RES	C 280 (07-..)	VDO MANUAL
 204 C-Class	SERVICE LIGHT RES	C 300 (07-..)	
 204 C-Class	SERVICE LIGHT RES	C 300 (07-..)	VDO MANUAL
 204 C-Class	SERVICE LIGHT RES	C 320 CDI (07-..)	
 204 C-Class	SERVICE LIGHT RES	C 320 CDI (07-..)	VDO MANUAL
 204 C-Class	SERVICE LIGHT RES	C 350 (07-..)	
 204 C-Class	SERVICE LIGHT RES	C 350 (07-..)	VDO MANUAL
 204 C-Class	SERVICE LIGHT RES	C 350 CDI (07-..)	
 204 C-Class	SERVICE LIGHT RES	C 350 CDI (07-..)	VDO MANUAL
 204 C-Class	SERVICE LIGHT RES	C 350 CGI (07-..)	
 204 C-Class	SERVICE LIGHT RES	C 350 CGI (07-..)	VDO MANUAL
 204 C-Class	SERVICE LIGHT RES	C 63 AMG (07-..)	
 204 C-Class	SERVICE LIGHT RES	C 63 AMG (07-..)	VDO MANUAL
 207 E Coupe'-Class	ABS + TRACT. CONT	200 CDI BlueEfficiency (09-..)	BOSCH ESP
 207 E Coupe'-Class	ABS + TRACT. CONT	200 CGI (09-..)	BOSCH ESP
 207 E Coupe'-Class	ABS + TRACT. CONT	250 CGI (09-..)	BOSCH ESP
 207 E Coupe'-Class	ABS + TRACT. CONT	300 BlueEfficiency (09-..)	BOSCH ESP
 207 E Coupe'-Class	ABS + TRACT. CONT	350 BlueEfficiency (09-..)	BOSCH ESP
 207 E Coupe'-Class	ABS + TRACT. CONT	350 CDI (09-..)	BOSCH ESP
 207 E Coupe'-Class	ABS + TRACT. CONT	350 CDI BlueEfficiency (09-..)	BOSCH ESP
 207 E Coupe'-Class	ABS + TRACT. CONT	500 BlueEfficiency (09-..)	BOSCH ESP
 207 E Coupe'-Class	ABS + TRACT. CONT	500 V8 (09-..)	BOSCH ESP
 207 E Coupe'-Class	ABS + TRACT. CONT	E 220 CDI (09-..)	BOSCH ESP
 207 E Coupe'-Class	ABS + TRACT. CONT	E 250 CDI (09-..)	BOSCH ESP
 207 E Coupe'-Class	AUTOM. TRANSMISSI	200 CDI BlueEfficiency (09-..)	Siemens EGS 53
 207 E Coupe'-Class	AUTOM. TRANSMISSI	200 CGI (09-..)	Siemens EGS 53
 207 E Coupe'-Class	AUTOM. TRANSMISSI	250 CGI (09-..)	Siemens EGS 53
 207 E Coupe'-Class	AUTOM. TRANSMISSI	300 BlueEfficiency (09-..)	Siemens EGS 53
 207 E Coupe'-Class	AUTOM. TRANSMISSI	350 BlueEfficiency (09-..)	Siemens EGS 53
 207 E Coupe'-Class	AUTOM. TRANSMISSI	350 CDI (09-..)	Siemens EGS 53
 207 E Coupe'-Class	AUTOM. TRANSMISSI	350 CDI BlueEfficiency (09-..)	Siemens EGS 53
 207 E Coupe'-Class	AUTOM. TRANSMISSI	500 BlueEfficiency (09-..)	Siemens EGS 53
 207 E Coupe'-Class	AUTOM. TRANSMISSI	500 V8 (09-..)	Siemens EGS 53
 207 E Coupe'-Class	AUTOM. TRANSMISSI	E 220 CDI (09-..)	Siemens EGS 53

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 207 E Coupe'-Class	AUTOM. TRANSMISSI	E 250 CDI (09-..)	Siemens EGS 53
 207 E Coupe'-Class	CLIMA	200 CDI BlueEfficiency (09-..)	VDO KLA Klimautomatik
 207 E Coupe'-Class	CLIMA	200 CGI (09-..)	VDO KLA Klimautomatik
 207 E Coupe'-Class	CLIMA	250 CGI (09-..)	VDO KLA Klimautomatik
 207 E Coupe'-Class	CLIMA	300 BlueEfficiency (09-..)	VDO KLA Klimautomatik
 207 E Coupe'-Class	CLIMA	350 BlueEfficiency (09-..)	VDO KLA Klimautomatik
 207 E Coupe'-Class	CLIMA	350 CDI (09-..)	VDO KLA Klimautomatik
 207 E Coupe'-Class	CLIMA	350 CDI BlueEfficiency (09-..)	VDO KLA Klimautomatik
 207 E Coupe'-Class	CLIMA	500 BlueEfficiency (09-..)	VDO KLA Klimautomatik
 207 E Coupe'-Class	CLIMA	500 V8 (09-..)	VDO KLA Klimautomatik
 207 E Coupe'-Class	CLIMA	E 220 CDI (09-..)	VDO KLA Klimautomatik
 207 E Coupe'-Class	CLIMA	E 250 CDI (09-..)	VDO KLA Klimautomatik
 207 E Coupe'-Class	PARKING HELP	200 CDI BlueEfficiency (09-..)	
 207 E Coupe'-Class	PARKING HELP	200 CGI (09-..)	
 207 E Coupe'-Class	PARKING HELP	300 BlueEfficiency (09-..)	
 207 E Coupe'-Class	PARKING HELP	350 BlueEfficiency (09-..)	
 207 E Coupe'-Class	PARKING HELP	350 CDI (09-..)	
 207 E Coupe'-Class	PARKING HELP	350 CDI BlueEfficiency (09-..)	
 207 E Coupe'-Class	PARKING HELP	500 BlueEfficiency (09-..)	
 207 E Coupe'-Class	PARKING HELP	500 V8 (09-..)	
 207 E Coupe'-Class	PARKING HELP	E 220 CDI (09-..)	
 207 E Coupe'-Class	PARKING HELP	E 250 CDI (09-..)	
 208 CLK-Class	ABS + TRACT. CONT	CLK 200 (...99)	BOSCH ASR/ABD BAS/ETS
 208 CLK-Class	ABS + TRACT. CONT	CLK 200 (97-..)	BOSCH ETS 5
 208 CLK-Class	ABS + TRACT. CONT	CLK 200 Kompr. (...99)	BOSCH ASR/ABD BAS/ETS
 208 CLK-Class	ABS + TRACT. CONT	CLK 200 Kompr. (97-..)	BOSCH ETS 5
 208 CLK-Class	ABS + TRACT. CONT	CLK 230 Kompr. (...99)	BOSCH ASR/ABD BAS/ETS
 208 CLK-Class	ABS + TRACT. CONT	CLK 230 Kompr. (97-..)	BOSCH ETS 5
 208 CLK-Class	ABS + TRACT. CONT	CLK 320 (...99)	BOSCH ASR/ABD BAS/ETS
 208 CLK-Class	ABS + TRACT. CONT	CLK 320 (97-..)	BOSCH ETS 5
 208 CLK-Class	ABS + TRACT. CONT	CLK 430 (...99)	BOSCH ASR/ABD BAS/ETS
 208 CLK-Class	ABS + TRACT. CONT	CLK 430 (97-..)	BOSCH ETS 5
 208 CLK-Class	AIRBAG	CLK 200 (...99)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 208 CLK-Class	AIRBAG	CLK 200 Kompr. (...99)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 208 CLK-Class	AIRBAG	CLK 230 Kompr. (...99)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 208 CLK-Class	AIRBAG	CLK 320 (...99)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 208 CLK-Class	AIRBAG	CLK 430 (...99)	BOSCH AirBag SRS 7.1/7.2 SIDE AB+ETR
 208 CLK-Class	AUTOM. TRANSMISSI	CLK 200 (...99)	BOSCH ETC 6
 208 CLK-Class	AUTOM. TRANSMISSI	CLK 200 Kompr. (...99)	BOSCH ETC 6
 208 CLK-Class	AUTOM. TRANSMISSI	CLK 230 Kompr. (...99)	BOSCH ETC 6
 208 CLK-Class	AUTOM. TRANSMISSI	CLK 320 (...99)	BOSCH ETC 6
 208 CLK-Class	AUTOM. TRANSMISSI	CLK 430 (...99)	BOSCH ETC 6
 208 CLK-Class	ENGINE MANAGEME	CLK 200 111 (...99)	BOSCH Motronic ME 1.0
 208 CLK-Class	ENGINE MANAGEME	CLK 200 111 (...99)	BOSCH Motronic ME 2.0
 208 CLK-Class	ENGINE MANAGEME	CLK 200 111 (...99)	SIEMENS-VDO HFM SFI
 208 CLK-Class	ENGINE MANAGEME	CLK 200 Kompr. 111 - 120kW (01-..)	EOBD
 208 CLK-Class	ENGINE MANAGEME	CLK 200 Kompr. 111 (...03)	BOSCH BOSCH-SIEMENS ME-SIM4 EVO
 208 CLK-Class	ENGINE MANAGEME	CLK 200 Kompr. 111 (...99)	BOSCH Motronic ME 1.0
 208 CLK-Class	ENGINE MANAGEME	CLK 200 Kompr. 111 (...99)	BOSCH Motronic ME 2.1
 208 CLK-Class	ENGINE MANAGEME	CLK 230 Kompr. 111 - 145kW (01-..)	EOBD
 208 CLK-Class	ENGINE MANAGEME	CLK 230 Kompr. 111 (...03)	BOSCH BOSCH-SIEMENS ME-SIM4 EVO
 208 CLK-Class	ENGINE MANAGEME	CLK 230 Kompr. 111 (...99)	BOSCH Motronic ME 1.0
 208 CLK-Class	ENGINE MANAGEME	CLK 230 Kompr. 111 (...99)	BOSCH Motronic ME 2.0
 208 CLK-Class	ENGINE MANAGEME	CLK 230 Kompr. 111 (...99)	SIEMENS-VDO HFM SFI
 208 CLK-Class	ENGINE MANAGEME	CLK 320 111 (...99)	BOSCH Motronic ME 1.0
 208 CLK-Class	ENGINE MANAGEME	CLK 320 111 (...99)	BOSCH Motronic ME 2.0
 208 CLK-Class	ENGINE MANAGEME	CLK 320 111 (...99)	SIEMENS-VDO HFM SFI
 208 CLK-Class	ENGINE MANAGEME	CLK 320 112 - 160kW (01-..)	EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 208 CLK-Class	ENGINE MANAGEME	CLK 430 113 - 205kW (01-..)	EOBD
 208 CLK-Class	ENGINE MANAGEME	CLK 55 AMG 113 - 255kW (01-..)	EOBD
 208 CLK-Class	MAINTENANCE	CLK 200 (..-03)	VDO/Marelli MANUAL
 208 CLK-Class	MAINTENANCE	CLK 200 Kompr. (..-03)	VDO/Marelli MANUAL
 208 CLK-Class	MAINTENANCE	CLK 200 Kompr. 111 (..-03)	BOSCH BOSCH-SIEMENS ME-SIM4 EVO
 208 CLK-Class	MAINTENANCE	CLK 230 Kompr. (..-03)	VDO/Marelli MANUAL
 208 CLK-Class	MAINTENANCE	CLK 230 Kompr. 111 (..-03)	BOSCH BOSCH-SIEMENS ME-SIM4 EVO
 208 CLK-Class	MAINTENANCE	CLK 320 (..-03)	VDO/Marelli MANUAL
 208 CLK-Class	MAINTENANCE	CLK 430 (..-03)	VDO/Marelli MANUAL
 208 CLK-Class	MAINTENANCE	CLK 55 AMG (..-03)	VDO/Marelli MANUAL
 208 CLK-Class	SERVICE LIGHT RES	CLK 200 (..-03)	VDO/Marelli MANUAL
 208 CLK-Class	SERVICE LIGHT RES	CLK 200 Kompr. (..-03)	VDO/Marelli MANUAL
 208 CLK-Class	SERVICE LIGHT RES	CLK 230 Kompr. (..-03)	VDO/Marelli MANUAL
 208 CLK-Class	SERVICE LIGHT RES	CLK 320 (..-03)	VDO/Marelli MANUAL
 208 CLK-Class	SERVICE LIGHT RES	CLK 430 (..-03)	VDO/Marelli MANUAL
 208 CLK-Class	SERVICE LIGHT RES	CLK 55 AMG (..-03)	VDO/Marelli MANUAL
 209 CLK-Class	ABS + TRACT. CONT	CLK 200 CGI (..-99)	BOSCH ASR/ABD BAS/ETS
 209 CLK-Class	ABS + TRACT. CONT	CLK 200 CGI (06-..)	TEVES ESP
 209 CLK-Class	ABS + TRACT. CONT	CLK 200 Kompr. (..-99)	BOSCH ASR/ABD BAS/ETS
 209 CLK-Class	ABS + TRACT. CONT	CLK 200 Kompr. (06-..)	TEVES ESP
 209 CLK-Class	ABS + TRACT. CONT	CLK 220 CDI (..-99)	BOSCH ASR/ABD BAS/ETS
 209 CLK-Class	ABS + TRACT. CONT	CLK 220 CDI (06-..)	TEVES ESP
 209 CLK-Class	ABS + TRACT. CONT	CLK 240 (..-99)	BOSCH ASR/ABD BAS/ETS
 209 CLK-Class	ABS + TRACT. CONT	CLK 240 (06-..)	TEVES ESP
 209 CLK-Class	ABS + TRACT. CONT	CLK 270 CDI T (..-99)	BOSCH ASR/ABD BAS/ETS
 209 CLK-Class	ABS + TRACT. CONT	CLK 280 (..-99)	BOSCH ASR/ABD BAS/ETS
 209 CLK-Class	ABS + TRACT. CONT	CLK 280 (06-..)	TEVES ESP
 209 CLK-Class	ABS + TRACT. CONT	CLK 320 (..-99)	BOSCH ASR/ABD BAS/ETS
 209 CLK-Class	ABS + TRACT. CONT	CLK 320 (06-..)	TEVES ESP
 209 CLK-Class	ABS + TRACT. CONT	CLK 320 CDI (..-99)	BOSCH ASR/ABD BAS/ETS
 209 CLK-Class	ABS + TRACT. CONT	CLK 320 CDI (06-..)	TEVES ESP
 209 CLK-Class	ABS + TRACT. CONT	CLK 350 (..-99)	BOSCH ASR/ABD BAS/ETS
 209 CLK-Class	ABS + TRACT. CONT	CLK 350 (06-..)	TEVES ESP
 209 CLK-Class	ABS + TRACT. CONT	CLK 500 (..-99)	BOSCH ASR/ABD BAS/ETS
 209 CLK-Class	ABS + TRACT. CONT	CLK 500 (06-..)	TEVES ESP
 209 CLK-Class	ABS + TRACT. CONT	CLK 55 AMG (..-99)	BOSCH ASR/ABD BAS/ETS
 209 CLK-Class	ABS + TRACT. CONT	CLK 55 AMG (06-..)	TEVES ESP
 209 CLK-Class	ABS + TRACT. CONT	CLK 63 AMG (..-99)	BOSCH ASR/ABD BAS/ETS
 209 CLK-Class	ABS + TRACT. CONT	CLK 63 AMG (06-..)	TEVES ESP
 209 CLK-Class	AIRBAG	CLK 200 CGI (06-..)	BOSCH SRS AirBag
 209 CLK-Class	AIRBAG	CLK 200 Kompr. (06-..)	BOSCH SRS AirBag
 209 CLK-Class	AIRBAG	CLK 220 CDI (06-..)	BOSCH SRS AirBag
 209 CLK-Class	AIRBAG	CLK 240 (06-..)	BOSCH SRS AirBag
 209 CLK-Class	AIRBAG	CLK 280 (06-..)	BOSCH SRS AirBag
 209 CLK-Class	AIRBAG	CLK 320 (06-..)	BOSCH SRS AirBag
 209 CLK-Class	AIRBAG	CLK 320 CDI (06-..)	BOSCH SRS AirBag
 209 CLK-Class	AIRBAG	CLK 350 (06-..)	BOSCH SRS AirBag
 209 CLK-Class	AIRBAG	CLK 500 (06-..)	BOSCH SRS AirBag
 209 CLK-Class	AIRBAG	CLK 55 AMG (06-..)	BOSCH SRS AirBag
 209 CLK-Class	AIRBAG	CLK 63 AMG (06-..)	BOSCH SRS AirBag
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 200 CGI (..-99)	BOSCH ETC 6
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 200 CGI (04-..)	DELPHI EWM Selector Lever
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 200 CGI (06-..)	SIEMENS EGS 7G-Tronic
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 200 Kompr. (..-99)	BOSCH ETC 6
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 200 Kompr. (04-..)	DELPHI EWM Selector Lever
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 200 Kompr. (06-..)	SIEMENS EGS 7G-Tronic
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 220 CDI (..-99)	BOSCH ETC 6
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 220 CDI (04-..)	DELPHI EWM Selector Lever

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 220 CDI (06-..)	SIEMENS EGS 7G-Tronic
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 240 (...99)	BOSCH ETC 6
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 240 (04-..)	DELPHI EWM Selector Lever
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 240 (06-..)	SIEMENS EGS 7G-Tronic
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 270 CDI T (...99)	BOSCH ETC 6
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 280 (...99)	BOSCH ETC 6
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 280 (04-..)	DELPHI EWM Selector Lever
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 280 (06-..)	SIEMENS EGS 7G-Tronic
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 320 (...99)	BOSCH ETC 6
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 320 (04-..)	DELPHI EWM Selector Lever
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 320 (06-..)	SIEMENS EGS 7G-Tronic
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 320 CDI (...99)	BOSCH ETC 6
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 320 CDI (04-..)	DELPHI EWM Selector Lever
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 320 CDI (06-..)	SIEMENS EGS 7G-Tronic
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 350 (...99)	BOSCH ETC 6
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 350 (04-..)	DELPHI EWM Selector Lever
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 350 (06-..)	SIEMENS EGS 7G-Tronic
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 500 (...99)	BOSCH ETC 6
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 500 (04-..)	DELPHI EWM Selector Lever
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 500 (06-..)	SIEMENS EGS 7G-Tronic
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 55 AMG (...99)	BOSCH ETC 6
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 55 AMG (04-..)	DELPHI EWM Selector Lever
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 55 AMG (06-..)	SIEMENS EGS 7G-Tronic
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 63 AMG (...99)	BOSCH ETC 6
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 63 AMG (04-..)	DELPHI EWM Selector Lever
 209 CLK-Class	AUTOM. TRANSMISSI	CLK 63 AMG (06-..)	SIEMENS EGS 7G-Tronic
 209 CLK-Class	CLIMA	CLK 200 CGI (06-..)	GKR KLA
 209 CLK-Class	CLIMA	CLK 200 Kompr. (06-..)	GKR KLA
 209 CLK-Class	CLIMA	CLK 220 CDI (06-..)	GKR KLA
 209 CLK-Class	CLIMA	CLK 240 (06-..)	GKR KLA
 209 CLK-Class	CLIMA	CLK 280 (06-..)	GKR KLA
 209 CLK-Class	CLIMA	CLK 320 (06-..)	GKR KLA
 209 CLK-Class	CLIMA	CLK 320 CDI (06-..)	GKR KLA
 209 CLK-Class	CLIMA	CLK 350 (06-..)	GKR KLA
 209 CLK-Class	CLIMA	CLK 500 (06-..)	GKR KLA
 209 CLK-Class	CLIMA	CLK 55 AMG (06-..)	GKR KLA
 209 CLK-Class	CLIMA	CLK 63 AMG (06-..)	GKR KLA
 209 CLK-Class	CONV. TOP/SUNROO	CLK 200 CGI (06-..)	HELLA DBE
 209 CLK-Class	CONV. TOP/SUNROO	CLK 200 Kompr. (06-..)	HELLA DBE
 209 CLK-Class	CONV. TOP/SUNROO	CLK 220 CDI (06-..)	HELLA DBE
 209 CLK-Class	CONV. TOP/SUNROO	CLK 240 (06-..)	HELLA DBE
 209 CLK-Class	CONV. TOP/SUNROO	CLK 280 (06-..)	HELLA DBE
 209 CLK-Class	CONV. TOP/SUNROO	CLK 320 (06-..)	HELLA DBE
 209 CLK-Class	CONV. TOP/SUNROO	CLK 320 CDI (06-..)	HELLA DBE
 209 CLK-Class	CONV. TOP/SUNROO	CLK 350 (06-..)	HELLA DBE
 209 CLK-Class	CONV. TOP/SUNROO	CLK 500 (06-..)	HELLA DBE
 209 CLK-Class	CONV. TOP/SUNROO	CLK 55 AMG (06-..)	HELLA DBE
 209 CLK-Class	CONV. TOP/SUNROO	CLK 63 AMG (06-..)	HELLA DBE
 209 CLK-Class	DASHBOARD	CLK 200 CGI (08-..)	KIW Kombi Instrument
 209 CLK-Class	DASHBOARD	CLK 200 Kompr. (08-..)	KIW Kombi Instrument
 209 CLK-Class	DASHBOARD	CLK 220 CDI (08-..)	KIW Kombi Instrument
 209 CLK-Class	DASHBOARD	CLK 240 (08-..)	KIW Kombi Instrument
 209 CLK-Class	DASHBOARD	CLK 280 (08-..)	KIW Kombi Instrument
 209 CLK-Class	DASHBOARD	CLK 320 (08-..)	KIW Kombi Instrument
 209 CLK-Class	DASHBOARD	CLK 320 CDI (08-..)	KIW Kombi Instrument
 209 CLK-Class	DASHBOARD	CLK 350 (08-..)	KIW Kombi Instrument
 209 CLK-Class	DASHBOARD	CLK 500 (08-..)	KIW Kombi Instrument
 209 CLK-Class	DASHBOARD	CLK 55 AMG (08-..)	KIW Kombi Instrument

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 209 CLK-Class	DASHBOARD	CLK 63 AMG (08-..)	KIW Kombi Instrument
 209 CLK-Class	ENGINE MANAGEME	CLK 200 CGI (02-..)	
 209 CLK-Class	ENGINE MANAGEME	CLK 200 Kompr. (06-..)	SIEMENS MPI ME SE
 209 CLK-Class	ENGINE MANAGEME	CLK 220 CDI (06-..)	
 209 CLK-Class	ENGINE MANAGEME	CLK 240 112 (08-..)	BOSCH EDC 15 C4 Common Rail
 209 CLK-Class	ENGINE MANAGEME	CLK 270 CDI T (98-00)	
 209 CLK-Class	ENGINE MANAGEME	CLK 270 CDI T (98-00)	BOSCH EDC 15 C6 Common Rail
 209 CLK-Class	ENGINE MANAGEME	CLK 280 (06-..)	
 209 CLK-Class	ENGINE MANAGEME	CLK 320 (02-..)	
 209 CLK-Class	ENGINE MANAGEME	CLK 320 CDI (06-..)	
 209 CLK-Class	ENGINE MANAGEME	CLK 350 (06-..)	
 209 CLK-Class	ENGINE MANAGEME	CLK 500 (06-..)	
 209 CLK-Class	ENGINE MANAGEME	CLK 55 AMG (02-..)	
 209 CLK-Class	ENGINE MANAGEME	CLK 63 AMG (02-..)	
 209 CLK-Class	MAINTENANCE	CLK 200 CGI (..-03)	VDO/Marelli MANUAL
 209 CLK-Class	MAINTENANCE	CLK 200 CGI (06-..)	TEVES ESP
 209 CLK-Class	MAINTENANCE	CLK 200 Kompr. (..-03)	VDO/Marelli MANUAL
 209 CLK-Class	MAINTENANCE	CLK 200 Kompr. (06-..)	TEVES ESP
 209 CLK-Class	MAINTENANCE	CLK 220 CDI (06-..)	TEVES ESP
 209 CLK-Class	MAINTENANCE	CLK 220 CDI (99-03)	VDO/Marelli MANUAL
 209 CLK-Class	MAINTENANCE	CLK 240 (06-..)	TEVES ESP
 209 CLK-Class	MAINTENANCE	CLK 240 (99-03)	VDO/Marelli MANUAL
 209 CLK-Class	MAINTENANCE	CLK 270 CDI T (99-03)	VDO/Marelli MANUAL
 209 CLK-Class	MAINTENANCE	CLK 280 (06-..)	TEVES ESP
 209 CLK-Class	MAINTENANCE	CLK 280 (99-03)	VDO/Marelli MANUAL
 209 CLK-Class	MAINTENANCE	CLK 320 (..-03)	VDO/Marelli MANUAL
 209 CLK-Class	MAINTENANCE	CLK 320 (06-..)	TEVES ESP
 209 CLK-Class	MAINTENANCE	CLK 320 CDI (06-..)	TEVES ESP
 209 CLK-Class	MAINTENANCE	CLK 320 CDI (99-03)	VDO/Marelli MANUAL
 209 CLK-Class	MAINTENANCE	CLK 350 (06-..)	TEVES ESP
 209 CLK-Class	MAINTENANCE	CLK 350 (99-03)	VDO/Marelli MANUAL
 209 CLK-Class	MAINTENANCE	CLK 500 (06-..)	TEVES ESP
 209 CLK-Class	MAINTENANCE	CLK 500 (99-03)	VDO/Marelli MANUAL
 209 CLK-Class	MAINTENANCE	CLK 55 AMG (..-03)	VDO/Marelli MANUAL
 209 CLK-Class	MAINTENANCE	CLK 55 AMG (06-..)	TEVES ESP
 209 CLK-Class	MAINTENANCE	CLK 63 AMG (..-03)	VDO/Marelli MANUAL
 209 CLK-Class	MAINTENANCE	CLK 63 AMG (06-..)	TEVES ESP
 209 CLK-Class	SERVICE LIGHT RES	CLK 200 CGI (..-03)	VDO/Marelli MANUAL
 209 CLK-Class	SERVICE LIGHT RES	CLK 200 Kompr. (..-03)	VDO/Marelli MANUAL
 209 CLK-Class	SERVICE LIGHT RES	CLK 220 CDI (99-03)	VDO/Marelli MANUAL
 209 CLK-Class	SERVICE LIGHT RES	CLK 240 (99-03)	VDO/Marelli MANUAL
 209 CLK-Class	SERVICE LIGHT RES	CLK 270 CDI T (99-03)	VDO/Marelli MANUAL
 209 CLK-Class	SERVICE LIGHT RES	CLK 280 (99-03)	VDO/Marelli MANUAL
 209 CLK-Class	SERVICE LIGHT RES	CLK 320 (..-03)	VDO/Marelli MANUAL
 209 CLK-Class	SERVICE LIGHT RES	CLK 320 CDI (99-03)	VDO/Marelli MANUAL
 209 CLK-Class	SERVICE LIGHT RES	CLK 350 (99-03)	VDO/Marelli MANUAL
 209 CLK-Class	SERVICE LIGHT RES	CLK 500 (99-03)	VDO/Marelli MANUAL
 209 CLK-Class	SERVICE LIGHT RES	CLK 55 AMG (..-03)	VDO/Marelli MANUAL
 209 CLK-Class	SERVICE LIGHT RES	CLK 63 AMG (..-03)	VDO/Marelli MANUAL
 209 CLK-Class	SWITCHLIGHT MODU	CLK 200 CGI (06-..)	Valeo MRM
 209 CLK-Class	SWITCHLIGHT MODU	CLK 200 Kompr. (06-..)	Valeo MRM
 209 CLK-Class	SWITCHLIGHT MODU	CLK 220 CDI (06-..)	Valeo MRM
 209 CLK-Class	SWITCHLIGHT MODU	CLK 240 (06-..)	Valeo MRM
 209 CLK-Class	SWITCHLIGHT MODU	CLK 280 (06-..)	Valeo MRM
 209 CLK-Class	SWITCHLIGHT MODU	CLK 320 (06-..)	Valeo MRM
 209 CLK-Class	SWITCHLIGHT MODU	CLK 320 CDI (06-..)	Valeo MRM
 209 CLK-Class	SWITCHLIGHT MODU	CLK 350 (06-..)	Valeo MRM
 209 CLK-Class	SWITCHLIGHT MODU	CLK 500 (06-..)	Valeo MRM

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 209 CLK-Class	SWITCHLIGHT MODU	CLK 55 AMG (06-..)	Valeo MRM
 209 CLK-Class	SWITCHLIGHT MODU	CLK 63 AMG (06-..)	Valeo MRM
 210 E-Class	ABS + TRACT. CONT	E 200 (..-99)	BOSCH ASR/ABD BAS/ETS
 210 E-Class	ABS + TRACT. CONT	E 200 (95-..)	BOSCH ETS 5
 210 E-Class	ABS + TRACT. CONT	E 200 CDI (..-99)	BOSCH ASR/ABD BAS/ETS
 210 E-Class	ABS + TRACT. CONT	E 200 CDI (95-..)	BOSCH ETS 5
 210 E-Class	ABS + TRACT. CONT	E 200 D (..-99)	BOSCH ASR/ABD BAS/ETS
 210 E-Class	ABS + TRACT. CONT	E 200 D (95-..)	BOSCH ETS 5
 210 E-Class	ABS + TRACT. CONT	E 200 Kompr. (..-99)	BOSCH ASR/ABD BAS/ETS
 210 E-Class	ABS + TRACT. CONT	E 200 Kompr. (95-..)	BOSCH ETS 5
 210 E-Class	ABS + TRACT. CONT	E 220 CDI (..-99)	BOSCH ASR/ABD BAS/ETS
 210 E-Class	ABS + TRACT. CONT	E 220 CDI (95-..)	BOSCH ETS 5
 210 E-Class	ABS + TRACT. CONT	E 220 D (..-99)	BOSCH ASR/ABD BAS/ETS
 210 E-Class	ABS + TRACT. CONT	E 220 D (95-..)	BOSCH ETS 5
 210 E-Class	ABS + TRACT. CONT	E 230 (..-99)	BOSCH ASR/ABD BAS/ETS
 210 E-Class	ABS + TRACT. CONT	E 230 (95-..)	BOSCH ETS 5
 210 E-Class	ABS + TRACT. CONT	E 240 (..-99)	BOSCH ASR/ABD BAS/ETS
 210 E-Class	ABS + TRACT. CONT	E 240 (95-..)	BOSCH ETS 5
 210 E-Class	ABS + TRACT. CONT	E 250 D (..-99)	BOSCH ASR/ABD BAS/ETS
 210 E-Class	ABS + TRACT. CONT	E 250 D (95-..)	BOSCH ETS 5
 210 E-Class	ABS + TRACT. CONT	E 250 D Turbo (..-99)	BOSCH ASR/ABD BAS/ETS
 210 E-Class	ABS + TRACT. CONT	E 250 D Turbo (95-..)	BOSCH ETS 5
 210 E-Class	ABS + TRACT. CONT	E 270 CDI (..-99)	BOSCH ASR/ABD BAS/ETS
 210 E-Class	ABS + TRACT. CONT	E 270 CDI (95-..)	BOSCH ETS 5
 210 E-Class	ABS + TRACT. CONT	E 280 (..-99)	BOSCH ASR/ABD BAS/ETS
 210 E-Class	ABS + TRACT. CONT	E 280 (95-..)	BOSCH ETS 5
 210 E-Class	ABS + TRACT. CONT	E 290 TD (..-99)	BOSCH ASR/ABD BAS/ETS
 210 E-Class	ABS + TRACT. CONT	E 290 TD (95-..)	BOSCH ETS 5
 210 E-Class	ABS + TRACT. CONT	E 300 D (..-99)	BOSCH ASR/ABD BAS/ETS
 210 E-Class	ABS + TRACT. CONT	E 300 D (95-..)	BOSCH ETS 5
 210 E-Class	ABS + TRACT. CONT	E 300 TD (..-99)	BOSCH ASR/ABD BAS/ETS
 210 E-Class	ABS + TRACT. CONT	E 300 TD (95-..)	BOSCH ETS 5
 210 E-Class	ABS + TRACT. CONT	E 320 (..-99)	BOSCH ASR/ABD BAS/ETS
 210 E-Class	ABS + TRACT. CONT	E 320 (95-..)	BOSCH ETS 5
 210 E-Class	ABS + TRACT. CONT	E 320 CDI (..-99)	BOSCH ASR/ABD BAS/ETS
 210 E-Class	ABS + TRACT. CONT	E 320 CDI (95-..)	BOSCH ETS 5
 210 E-Class	ABS + TRACT. CONT	E 36 AMG (..-99)	BOSCH ASR/ABD BAS/ETS
 210 E-Class	ABS + TRACT. CONT	E 36 AMG (95-..)	BOSCH ETS 5
 210 E-Class	ABS + TRACT. CONT	E 420 (..-99)	BOSCH ASR/ABD BAS/ETS
 210 E-Class	ABS + TRACT. CONT	E 420 (95-..)	BOSCH ETS 5
 210 E-Class	ABS + TRACT. CONT	E 430 (..-99)	BOSCH ASR/ABD BAS/ETS
 210 E-Class	ABS + TRACT. CONT	E 430 (95-..)	BOSCH ETS 5
 210 E-Class	ABS + TRACT. CONT	E 50 AMG (..-99)	BOSCH ASR/ABD BAS/ETS
 210 E-Class	ABS + TRACT. CONT	E 50 AMG (95-..)	BOSCH ETS 5
 210 E-Class	ABS + TRACT. CONT	E 55 AMG (..-99)	BOSCH ASR/ABD BAS/ETS
 210 E-Class	ABS + TRACT. CONT	E 55 AMG (95-..)	BOSCH ETS 5
 210 E-Class	AIRBAG	E 200 (..-00)	TEMIC SRS
 210 E-Class	AIRBAG	E 200 (..-99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 210 E-Class	AIRBAG	E 200 CDI (..-00)	TEMIC SRS
 210 E-Class	AIRBAG	E 200 CDI (..-99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 210 E-Class	AIRBAG	E 200 D (..-00)	TEMIC SRS
 210 E-Class	AIRBAG	E 200 D (..-99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 210 E-Class	AIRBAG	E 200 Kompr. (..-00)	TEMIC SRS
 210 E-Class	AIRBAG	E 200 Kompr. (..-99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 210 E-Class	AIRBAG	E 220 CDI (..-00)	TEMIC SRS
 210 E-Class	AIRBAG	E 220 CDI (..-99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 210 E-Class	AIRBAG	E 220 D (..-00)	TEMIC SRS
 210 E-Class	AIRBAG	E 220 D (..-99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 210 E-Class	AIRBAG	E 230 (.-00)	TEMIC SRS
 210 E-Class	AIRBAG	E 230 (.-99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 210 E-Class	AIRBAG	E 240 (.-00)	TEMIC SRS
 210 E-Class	AIRBAG	E 240 (.-99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 210 E-Class	AIRBAG	E 250 D (.-00)	TEMIC SRS
 210 E-Class	AIRBAG	E 250 D (.-99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 210 E-Class	AIRBAG	E 250 D Turbo (.-00)	TEMIC SRS
 210 E-Class	AIRBAG	E 250 D Turbo (.-99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 210 E-Class	AIRBAG	E 270 CDI (.-00)	TEMIC SRS
 210 E-Class	AIRBAG	E 270 CDI (.-99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 210 E-Class	AIRBAG	E 280 (.-00)	TEMIC SRS
 210 E-Class	AIRBAG	E 280 (.-99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 210 E-Class	AIRBAG	E 290 TD (.-00)	TEMIC SRS
 210 E-Class	AIRBAG	E 290 TD (.-99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 210 E-Class	AIRBAG	E 300 D (.-00)	TEMIC SRS
 210 E-Class	AIRBAG	E 300 D (.-99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 210 E-Class	AIRBAG	E 300 TD (.-00)	TEMIC SRS
 210 E-Class	AIRBAG	E 300 TD (.-99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 210 E-Class	AIRBAG	E 320 (.-00)	TEMIC SRS
 210 E-Class	AIRBAG	E 320 (.-99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 210 E-Class	AIRBAG	E 320 CDI (.-00)	TEMIC SRS
 210 E-Class	AIRBAG	E 320 CDI (.-99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 210 E-Class	AIRBAG	E 36 AMG (.-00)	TEMIC SRS
 210 E-Class	AIRBAG	E 36 AMG (.-99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 210 E-Class	AIRBAG	E 420 (.-00)	TEMIC SRS
 210 E-Class	AIRBAG	E 420 (.-99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 210 E-Class	AIRBAG	E 430 (.-00)	TEMIC SRS
 210 E-Class	AIRBAG	E 430 (.-99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 210 E-Class	AIRBAG	E 50 AMG (.-00)	TEMIC SRS
 210 E-Class	AIRBAG	E 50 AMG (.-99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 210 E-Class	AIRBAG	E 55 AMG (.-00)	TEMIC SRS
 210 E-Class	AIRBAG	E 55 AMG (.-99)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 210 E-Class	AUTOM. TRANSMISSI	E 200 (.-00)	DELPHI EWM Selector Lever
 210 E-Class	AUTOM. TRANSMISSI	E 200 (.-99)	BOSCH ETC 6
 210 E-Class	AUTOM. TRANSMISSI	E 200 CDI (.-00)	DELPHI EWM Selector Lever
 210 E-Class	AUTOM. TRANSMISSI	E 200 CDI (.-99)	BOSCH ETC 6
 210 E-Class	AUTOM. TRANSMISSI	E 200 D (.-00)	DELPHI EWM Selector Lever
 210 E-Class	AUTOM. TRANSMISSI	E 200 D (.-99)	BOSCH ETC 6
 210 E-Class	AUTOM. TRANSMISSI	E 200 Kompr. (.-00)	DELPHI EWM Selector Lever
 210 E-Class	AUTOM. TRANSMISSI	E 200 Kompr. (.-99)	BOSCH ETC 6
 210 E-Class	AUTOM. TRANSMISSI	E 220 CDI (.-00)	DELPHI EWM Selector Lever
 210 E-Class	AUTOM. TRANSMISSI	E 220 CDI (.-99)	BOSCH ETC 6
 210 E-Class	AUTOM. TRANSMISSI	E 220 D (.-00)	DELPHI EWM Selector Lever
 210 E-Class	AUTOM. TRANSMISSI	E 220 D (.-99)	BOSCH ETC 6
 210 E-Class	AUTOM. TRANSMISSI	E 230 (.-00)	DELPHI EWM Selector Lever
 210 E-Class	AUTOM. TRANSMISSI	E 230 (.-99)	BOSCH ETC 6
 210 E-Class	AUTOM. TRANSMISSI	E 240 (.-00)	DELPHI EWM Selector Lever
 210 E-Class	AUTOM. TRANSMISSI	E 240 (.-99)	BOSCH ETC 6
 210 E-Class	AUTOM. TRANSMISSI	E 250 D (.-00)	DELPHI EWM Selector Lever
 210 E-Class	AUTOM. TRANSMISSI	E 250 D (.-99)	BOSCH ETC 6
 210 E-Class	AUTOM. TRANSMISSI	E 250 D Turbo (.-00)	DELPHI EWM Selector Lever
 210 E-Class	AUTOM. TRANSMISSI	E 250 D Turbo (.-99)	BOSCH ETC 6
 210 E-Class	AUTOM. TRANSMISSI	E 270 CDI (.-00)	DELPHI EWM Selector Lever
 210 E-Class	AUTOM. TRANSMISSI	E 270 CDI (.-99)	BOSCH ETC 6
 210 E-Class	AUTOM. TRANSMISSI	E 280 (.-00)	DELPHI EWM Selector Lever
 210 E-Class	AUTOM. TRANSMISSI	E 280 (.-99)	BOSCH ETC 6
 210 E-Class	AUTOM. TRANSMISSI	E 290 TD (.-00)	DELPHI EWM Selector Lever
 210 E-Class	AUTOM. TRANSMISSI	E 290 TD (.-99)	BOSCH ETC 6

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 210 E-Class	AUTOM. TRANSMISSI	E 300 D (...00)	DELPHI EWM Selector Lever
 210 E-Class	AUTOM. TRANSMISSI	E 300 D (...99)	BOSCH ETC 6
 210 E-Class	AUTOM. TRANSMISSI	E 300 TD (...00)	DELPHI EWM Selector Lever
 210 E-Class	AUTOM. TRANSMISSI	E 300 TD (...99)	BOSCH ETC 6
 210 E-Class	AUTOM. TRANSMISSI	E 320 (...00)	DELPHI EWM Selector Lever
 210 E-Class	AUTOM. TRANSMISSI	E 320 (...99)	BOSCH ETC 6
 210 E-Class	AUTOM. TRANSMISSI	E 320 CDI (...00)	DELPHI EWM Selector Lever
 210 E-Class	AUTOM. TRANSMISSI	E 320 CDI (...99)	BOSCH ETC 6
 210 E-Class	AUTOM. TRANSMISSI	E 36 AMG (...00)	DELPHI EWM Selector Lever
 210 E-Class	AUTOM. TRANSMISSI	E 36 AMG (...99)	BOSCH ETC 6
 210 E-Class	AUTOM. TRANSMISSI	E 420 (...99)	BOSCH ETC 6
 210 E-Class	AUTOM. TRANSMISSI	E 430 (...00)	DELPHI EWM Selector Lever
 210 E-Class	AUTOM. TRANSMISSI	E 430 (...99)	BOSCH ETC 6
 210 E-Class	AUTOM. TRANSMISSI	E 50 AMG (...00)	DELPHI EWM Selector Lever
 210 E-Class	AUTOM. TRANSMISSI	E 50 AMG (...99)	BOSCH ETC 6
 210 E-Class	AUTOM. TRANSMISSI	E 55 AMG (...00)	DELPHI EWM Selector Lever
 210 E-Class	AUTOM. TRANSMISSI	E 55 AMG (...99)	BOSCH ETC 6
 210 E-Class	CLIMA	E 200 (...99)	Klima
 210 E-Class	CLIMA	E 200 CDI (...99)	Klima
 210 E-Class	CLIMA	E 200 D (...99)	Klima
 210 E-Class	CLIMA	E 200 Kompr. (...99)	Klima
 210 E-Class	CLIMA	E 220 CDI (...99)	Klima
 210 E-Class	CLIMA	E 220 D (...99)	Klima
 210 E-Class	CLIMA	E 230 (...99)	Klima
 210 E-Class	CLIMA	E 240 (...99)	Klima
 210 E-Class	CLIMA	E 250 D (...99)	Klima
 210 E-Class	CLIMA	E 250 D Turbo (...99)	Klima
 210 E-Class	CLIMA	E 270 CDI (...99)	Klima
 210 E-Class	CLIMA	E 280 (...99)	Klima
 210 E-Class	CLIMA	E 290 TD (...99)	Klima
 210 E-Class	CLIMA	E 300 D (...99)	Klima
 210 E-Class	CLIMA	E 300 TD (...99)	Klima
 210 E-Class	CLIMA	E 320 (...99)	Klima
 210 E-Class	CLIMA	E 320 CDI (...99)	Klima
 210 E-Class	CLIMA	E 36 AMG (...99)	Klima
 210 E-Class	CLIMA	E 420 (...99)	Klima
 210 E-Class	CLIMA	E 430 (...99)	Klima
 210 E-Class	CLIMA	E 50 AMG (...99)	Klima
 210 E-Class	CLIMA	E 55 AMG (...99)	Klima
 210 E-Class	CRUISE CONTROL	E 200 (95-..)	BOSCH/VDO EA/CC/ISC
 210 E-Class	CRUISE CONTROL	E 200 CDI (95-..)	BOSCH/VDO EA/CC/ISC
 210 E-Class	CRUISE CONTROL	E 200 D (95-..)	BOSCH/VDO EA/CC/ISC
 210 E-Class	CRUISE CONTROL	E 200 Kompr. (95-..)	BOSCH/VDO EA/CC/ISC
 210 E-Class	CRUISE CONTROL	E 220 CDI (95-..)	BOSCH/VDO EA/CC/ISC
 210 E-Class	CRUISE CONTROL	E 220 D (95-..)	BOSCH/VDO EA/CC/ISC
 210 E-Class	CRUISE CONTROL	E 230 (95-..)	BOSCH/VDO EA/CC/ISC
 210 E-Class	CRUISE CONTROL	E 240 (95-..)	BOSCH/VDO EA/CC/ISC
 210 E-Class	CRUISE CONTROL	E 250 D (95-..)	BOSCH/VDO EA/CC/ISC
 210 E-Class	CRUISE CONTROL	E 250 D Turbo (95-..)	BOSCH/VDO EA/CC/ISC
 210 E-Class	CRUISE CONTROL	E 270 CDI (95-..)	BOSCH/VDO EA/CC/ISC
 210 E-Class	CRUISE CONTROL	E 280 (95-..)	BOSCH/VDO EA/CC/ISC
 210 E-Class	CRUISE CONTROL	E 290 TD (95-..)	BOSCH/VDO EA/CC/ISC
 210 E-Class	CRUISE CONTROL	E 300 D (95-..)	BOSCH/VDO EA/CC/ISC
 210 E-Class	CRUISE CONTROL	E 300 TD (95-..)	BOSCH/VDO EA/CC/ISC
 210 E-Class	CRUISE CONTROL	E 320 (95-..)	BOSCH/VDO EA/CC/ISC
 210 E-Class	CRUISE CONTROL	E 320 CDI (95-..)	BOSCH/VDO EA/CC/ISC
 210 E-Class	CRUISE CONTROL	E 36 AMG (95-..)	BOSCH/VDO EA/CC/ISC
 210 E-Class	CRUISE CONTROL	E 420 (95-..)	BOSCH/VDO EA/CC/ISC

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 210 E-Class	CRUISE CONTROL	E 430 (95-..)	BOSCH/VDO EA/CC/ISC
 210 E-Class	CRUISE CONTROL	E 50 AMG (95-..)	BOSCH/VDO EA/CC/ISC
 210 E-Class	CRUISE CONTROL	E 55 AMG (95-..)	BOSCH/VDO EA/CC/ISC
 210 E-Class	DASHBOARD	E 200 (00-01)	Siemens-VDO KIW
 210 E-Class	DASHBOARD	E 200 (97-99)	VDO KI
 210 E-Class	DASHBOARD	E 200 CDI (00-01)	Siemens-VDO KIW
 210 E-Class	DASHBOARD	E 200 CDI (97-99)	VDO KI
 210 E-Class	DASHBOARD	E 200 D (00-01)	Siemens-VDO KIW
 210 E-Class	DASHBOARD	E 200 D (97-99)	VDO KI
 210 E-Class	DASHBOARD	E 200 Kompr. (00-01)	Siemens-VDO KIW
 210 E-Class	DASHBOARD	E 200 Kompr. (97-99)	VDO KI
 210 E-Class	DASHBOARD	E 220 CDI (00-01)	Siemens-VDO KIW
 210 E-Class	DASHBOARD	E 220 CDI (97-99)	VDO KI
 210 E-Class	DASHBOARD	E 220 D (00-01)	Siemens-VDO KIW
 210 E-Class	DASHBOARD	E 220 D (97-99)	VDO KI
 210 E-Class	DASHBOARD	E 230 (00-01)	Siemens-VDO KIW
 210 E-Class	DASHBOARD	E 230 (97-99)	VDO KI
 210 E-Class	DASHBOARD	E 240 (00-01)	Siemens-VDO KIW
 210 E-Class	DASHBOARD	E 240 (97-99)	VDO KI
 210 E-Class	DASHBOARD	E 250 D (00-01)	Siemens-VDO KIW
 210 E-Class	DASHBOARD	E 250 D (97-99)	VDO KI
 210 E-Class	DASHBOARD	E 250 D Turbo (00-01)	Siemens-VDO KIW
 210 E-Class	DASHBOARD	E 250 D Turbo (97-99)	VDO KI
 210 E-Class	DASHBOARD	E 270 CDI (00-01)	Siemens-VDO KIW
 210 E-Class	DASHBOARD	E 270 CDI (97-99)	VDO KI
 210 E-Class	DASHBOARD	E 280 (00-01)	Siemens-VDO KIW
 210 E-Class	DASHBOARD	E 280 (97-99)	VDO KI
 210 E-Class	DASHBOARD	E 290 TD (00-01)	Siemens-VDO KIW
 210 E-Class	DASHBOARD	E 290 TD (97-99)	VDO KI
 210 E-Class	DASHBOARD	E 300 D (00-01)	Siemens-VDO KIW
 210 E-Class	DASHBOARD	E 300 D (97-99)	VDO KI
 210 E-Class	DASHBOARD	E 300 TD (00-01)	Siemens-VDO KIW
 210 E-Class	DASHBOARD	E 300 TD (97-99)	VDO KI
 210 E-Class	DASHBOARD	E 320 (00-01)	Siemens-VDO KIW
 210 E-Class	DASHBOARD	E 320 (97-99)	VDO KI
 210 E-Class	DASHBOARD	E 320 CDI (00-01)	Siemens-VDO KIW
 210 E-Class	DASHBOARD	E 320 CDI (97-99)	VDO KI
 210 E-Class	DASHBOARD	E 36 AMG (00-01)	Siemens-VDO KIW
 210 E-Class	DASHBOARD	E 36 AMG (97-99)	VDO KI
 210 E-Class	DASHBOARD	E 420 (00-01)	Siemens-VDO KIW
 210 E-Class	DASHBOARD	E 420 (97-99)	VDO KI
 210 E-Class	DASHBOARD	E 430 (00-01)	Siemens-VDO KIW
 210 E-Class	DASHBOARD	E 430 (97-99)	VDO KI
 210 E-Class	DASHBOARD	E 50 AMG (00-01)	Siemens-VDO KIW
 210 E-Class	DASHBOARD	E 50 AMG (97-99)	VDO KI
 210 E-Class	DASHBOARD	E 55 AMG (00-01)	Siemens-VDO KIW
 210 E-Class	DASHBOARD	E 55 AMG (97-99)	VDO KI
 210 E-Class	DIESEL MANAGEMEN	E 250 D 605 (..-99)	BOSCH IFI (ERE) (EPC)
 210 E-Class	DIESEL MANAGEMEN	E 250 D Turbo 605 (..-99)	BOSCH IFI (ERE) (EPC)
 210 E-Class	DIESEL MANAGEMEN	E 300 D 606 (..-99)	BOSCH IFI (ERE) (EPC)
 210 E-Class	DIESEL MANAGEMEN	E 300 TD 606 (..-99)	BOSCH IFI (ERE) (EPC)
 210 E-Class	ENGINE MANAGEME	E 200 111 (..-99)	BOSCH Motronic ME 1.0
 210 E-Class	ENGINE MANAGEME	E 200 111 (..-99)	BOSCH Motronic ME 2.0
 210 E-Class	ENGINE MANAGEME	E 200 111 (..-99)	SIEMENS-VDO HFM SFI
 210 E-Class	ENGINE MANAGEME	E 200 CDI 611 (98-00)	BOSCH EDC 15 C4 Common Rail
 210 E-Class	ENGINE MANAGEME	E 200 CDI 611 (98-00)	BOSCH EDC 15 C6 Common Rail
 210 E-Class	ENGINE MANAGEME	E 200 Kompr. 111 (..-99)	BOSCH Motronic ME 1.0
 210 E-Class	ENGINE MANAGEME	E 200 Kompr. 111 (..-99)	BOSCH Motronic ME 2.0

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 210 E-Class	ENGINE MANAGEME	E 200 Kompr. 111 (...99)	BOSCH Motronic ME 2.1
 210 E-Class	ENGINE MANAGEME	E 220 CDI	BOSCH EDC 15 C4 Common Rail
 210 E-Class	ENGINE MANAGEME	E 220 CDI	BOSCH EDC 15 C6 Common Rail
 210 E-Class	ENGINE MANAGEME	E 220 CDI 611 (98-00)	BOSCH EDC 15 C4 Common Rail
 210 E-Class	ENGINE MANAGEME	E 220 CDI 611 (98-00)	BOSCH EDC 15 C6 Common Rail
 210 E-Class	ENGINE MANAGEME	E 240 112 (...99)	BOSCH Motronic ME 1.0
 210 E-Class	ENGINE MANAGEME	E 240 112 (...99)	BOSCH Motronic ME 2.0
 210 E-Class	ENGINE MANAGEME	E 240 112 (...99)	SIEMENS-VDO HFM SFI
 210 E-Class	ENGINE MANAGEME	E 270 CDI 612 (98-00)	BOSCH EDC 15 C4 Common Rail
 210 E-Class	ENGINE MANAGEME	E 270 CDI 612 (98-00)	BOSCH EDC 15 C6 Common Rail
 210 E-Class	ENGINE MANAGEME	E 280 112 (...99)	BOSCH Motronic ME 1.0
 210 E-Class	ENGINE MANAGEME	E 280 112 (...99)	BOSCH Motronic ME 2.0
 210 E-Class	ENGINE MANAGEME	E 280 112 (...99)	SIEMENS-VDO HFM SFI
 210 E-Class	ENGINE MANAGEME	E 320 104 (...99)	SIEMENS-VDO HFM SFI
 210 E-Class	ENGINE MANAGEME	E 320 112 (...99)	BOSCH Motronic ME 1.0
 210 E-Class	ENGINE MANAGEME	E 320 112 (...99)	BOSCH Motronic ME 2.0
 210 E-Class	ENGINE MANAGEME	E 320 112 (...99)	SIEMENS-VDO HFM SFI
 210 E-Class	ENGINE MANAGEME	E 320 CDI (...00)	BOSCH EDC Common Rail CDI 2
 210 E-Class	ENGINE MANAGEME	E 320 CDI 613 (98-00)	BOSCH EDC 15 C4 Common Rail
 210 E-Class	ENGINE MANAGEME	E 320 CDI 613 (98-00)	BOSCH EDC 15 C6 Common Rail
 210 E-Class	ENGINE MANAGEME	E 420 119 (...99)	SIEMENS-VDO HFM SFI
 210 E-Class	ENGINE MANAGEME	E 430 113 (...99)	BOSCH Motronic ME 1.0
 210 E-Class	ENGINE MANAGEME	E 430 113 (...99)	BOSCH Motronic ME 2.0
 210 E-Class	ENGINE MANAGEME	E 430 113 (...99)	SIEMENS-VDO HFM SFI
 210 E-Class	ENGINE MANAGEME	E 55 AMG 113 (...99)	BOSCH Motronic ME 1.0
 210 E-Class	ENGINE MANAGEME	E 55 AMG 113 (...99)	BOSCH Motronic ME 2.0
 210 E-Class	ENGINE MANAGEME	E 55 AMG 113 (...99)	SIEMENS-VDO HFM SFI
 210 E-Class	MAINTENANCE	E 200 (99-03)	VDO/Marelli MANUAL
 210 E-Class	MAINTENANCE	E 200 CDI (99-03)	VDO/Marelli MANUAL
 210 E-Class	MAINTENANCE	E 200 D (99-03)	VDO/Marelli MANUAL
 210 E-Class	MAINTENANCE	E 200 Kompr. (99-03)	VDO/Marelli MANUAL
 210 E-Class	MAINTENANCE	E 220 CDI (99-03)	VDO/Marelli MANUAL
 210 E-Class	MAINTENANCE	E 220 D (99-03)	VDO/Marelli MANUAL
 210 E-Class	MAINTENANCE	E 230 (99-03)	VDO/Marelli MANUAL
 210 E-Class	MAINTENANCE	E 240 (99-03)	VDO/Marelli MANUAL
 210 E-Class	MAINTENANCE	E 250 D (99-03)	VDO/Marelli MANUAL
 210 E-Class	MAINTENANCE	E 250 D Turbo (99-03)	VDO/Marelli MANUAL
 210 E-Class	MAINTENANCE	E 270 CDI (99-03)	VDO/Marelli MANUAL
 210 E-Class	MAINTENANCE	E 280 (99-03)	VDO/Marelli MANUAL
 210 E-Class	MAINTENANCE	E 290 TD (99-03)	VDO/Marelli MANUAL
 210 E-Class	MAINTENANCE	E 300 D (99-03)	VDO/Marelli MANUAL
 210 E-Class	MAINTENANCE	E 300 TD (99-03)	VDO/Marelli MANUAL
 210 E-Class	MAINTENANCE	E 320 (99-03)	VDO/Marelli MANUAL
 210 E-Class	MAINTENANCE	E 320 CDI (99-03)	VDO/Marelli MANUAL
 210 E-Class	MAINTENANCE	E 36 AMG (99-03)	VDO/Marelli MANUAL
 210 E-Class	MAINTENANCE	E 420 (99-03)	VDO/Marelli MANUAL
 210 E-Class	MAINTENANCE	E 430 (99-03)	VDO/Marelli MANUAL
 210 E-Class	MAINTENANCE	E 50 AMG (99-03)	VDO/Marelli MANUAL
 210 E-Class	MAINTENANCE	E 55 AMG (99-03)	VDO/Marelli MANUAL
 210 E-Class	RADIO / CD	E 200 (...00)	Becker/X.x AudioSys
 210 E-Class	RADIO / CD	E 200 CDI (...00)	Becker/X.x AudioSys
 210 E-Class	RADIO / CD	E 200 D (...00)	Becker/X.x AudioSys
 210 E-Class	RADIO / CD	E 200 Kompr. (...00)	Becker/X.x AudioSys
 210 E-Class	RADIO / CD	E 220 CDI (...00)	Becker/X.x AudioSys
 210 E-Class	RADIO / CD	E 220 D (...00)	Becker/X.x AudioSys
 210 E-Class	RADIO / CD	E 230 (...00)	Becker/X.x AudioSys
 210 E-Class	RADIO / CD	E 240 (...00)	Becker/X.x AudioSys
 210 E-Class	RADIO / CD	E 250 D (...00)	Becker/X.x AudioSys

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 210 E-Class	RADIO / CD	E 250 D Turbo (...00)	Becker/X.x AudioSys
 210 E-Class	RADIO / CD	E 270 CDI (...00)	Becker/X.x AudioSys
 210 E-Class	RADIO / CD	E 280 (...00)	Becker/X.x AudioSys
 210 E-Class	RADIO / CD	E 290 TD (...00)	Becker/X.x AudioSys
 210 E-Class	RADIO / CD	E 300 D (...00)	Becker/X.x AudioSys
 210 E-Class	RADIO / CD	E 300 TD (...00)	Becker/X.x AudioSys
 210 E-Class	RADIO / CD	E 320 (...00)	Becker/X.x AudioSys
 210 E-Class	RADIO / CD	E 320 CDI (...00)	Becker/X.x AudioSys
 210 E-Class	RADIO / CD	E 36 AMG (...00)	Becker/X.x AudioSys
 210 E-Class	RADIO / CD	E 430 (...00)	Becker/X.x AudioSys
 210 E-Class	RADIO / CD	E 50 AMG (...00)	Becker/X.x AudioSys
 210 E-Class	RADIO / CD	E 55 AMG (...00)	Becker/X.x AudioSys
 210 E-Class	SERVICE LIGHT RES	E 200 (99-03)	VDO/Marelli MANUAL
 210 E-Class	SERVICE LIGHT RES	E 200 CDI (99-03)	VDO/Marelli MANUAL
 210 E-Class	SERVICE LIGHT RES	E 200 D (99-03)	VDO/Marelli MANUAL
 210 E-Class	SERVICE LIGHT RES	E 200 Kompr. (99-03)	VDO/Marelli MANUAL
 210 E-Class	SERVICE LIGHT RES	E 220 CDI (99-03)	VDO/Marelli MANUAL
 210 E-Class	SERVICE LIGHT RES	E 220 D (99-03)	VDO/Marelli MANUAL
 210 E-Class	SERVICE LIGHT RES	E 230 (99-03)	VDO/Marelli MANUAL
 210 E-Class	SERVICE LIGHT RES	E 240 (99-03)	VDO/Marelli MANUAL
 210 E-Class	SERVICE LIGHT RES	E 250 D (99-03)	VDO/Marelli MANUAL
 210 E-Class	SERVICE LIGHT RES	E 250 D Turbo (99-03)	VDO/Marelli MANUAL
 210 E-Class	SERVICE LIGHT RES	E 270 CDI (99-03)	VDO/Marelli MANUAL
 210 E-Class	SERVICE LIGHT RES	E 280 (99-03)	VDO/Marelli MANUAL
 210 E-Class	SERVICE LIGHT RES	E 290 TD (99-03)	VDO/Marelli MANUAL
 210 E-Class	SERVICE LIGHT RES	E 300 D (99-03)	VDO/Marelli MANUAL
 210 E-Class	SERVICE LIGHT RES	E 300 TD (99-03)	VDO/Marelli MANUAL
 210 E-Class	SERVICE LIGHT RES	E 320 (99-03)	VDO/Marelli MANUAL
 210 E-Class	SERVICE LIGHT RES	E 320 CDI (99-03)	VDO/Marelli MANUAL
 210 E-Class	SERVICE LIGHT RES	E 36 AMG (99-03)	VDO/Marelli MANUAL
 210 E-Class	SERVICE LIGHT RES	E 420 (99-03)	VDO/Marelli MANUAL
 210 E-Class	SERVICE LIGHT RES	E 430 (99-03)	VDO/Marelli MANUAL
 210 E-Class	SERVICE LIGHT RES	E 50 AMG (99-03)	VDO/Marelli MANUAL
 210 E-Class	SERVICE LIGHT RES	E 55 AMG (99-03)	VDO/Marelli MANUAL
 211 E-Class	ABS + TRACT. CONT	E 200 CDI (02-06)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 200 CDI (06-..)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 200 CGI (02-06)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 200 CGI (06-..)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 200 Kompr. (02-06)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 200 Kompr. (06-..)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 200 NGT (02-06)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 200 NGT (06-..)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 220 CDI (02-06)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 220 CDI (06-..)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 230 (02-06)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 230 (06-..)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 240 (02-06)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 240 (06-..)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 250 CDI (02-06)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 250 CDI (06-..)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 270 CDI (02-06)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 270 CDI (06-..)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 280 (02-06)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 280 (06-..)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 280 CDI (02-06)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 280 CDI (06-..)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 300 BlueTEC (02-06)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 300 BlueTEC (06-..)	BOSCH ESP

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 211 E-Class	ABS + TRACT. CONT	E 320 (02-06)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 320 (06-..)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 320 CDI (02-06)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 320 CDI (06-..)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 350 (02-06)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 350 (06-..)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 350 CGI (02-06)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 350 CGI (06-..)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 400 CDI (02-06)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 400 CDI (06-..)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 420 CDI (02-06)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 420 CDI (06-..)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 500 (02-06)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 500 (06-..)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 55 AMG (02-06)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 55 AMG (06-..)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 63 AMG (02-06)	BOSCH ESP
 211 E-Class	ABS + TRACT. CONT	E 63 AMG (06-..)	BOSCH ESP
 211 E-Class	AIRBAG	E 200 CDI (02-06)	TEMIC AirBag
 211 E-Class	AIRBAG	E 200 CDI (06-..)	BOSCH SRS AirBag
 211 E-Class	AIRBAG	E 200 CGI (02-06)	TEMIC AirBag
 211 E-Class	AIRBAG	E 200 CGI (06-..)	BOSCH SRS AirBag
 211 E-Class	AIRBAG	E 200 Kompr. (02-06)	TEMIC AirBag
 211 E-Class	AIRBAG	E 200 Kompr. (06-..)	BOSCH SRS AirBag
 211 E-Class	AIRBAG	E 200 NGT (02-06)	TEMIC AirBag
 211 E-Class	AIRBAG	E 200 NGT (06-..)	BOSCH SRS AirBag
 211 E-Class	AIRBAG	E 220 CDI (02-06)	TEMIC AirBag
 211 E-Class	AIRBAG	E 220 CDI (06-..)	BOSCH SRS AirBag
 211 E-Class	AIRBAG	E 230 (02-06)	TEMIC AirBag
 211 E-Class	AIRBAG	E 230 (06-..)	BOSCH SRS AirBag
 211 E-Class	AIRBAG	E 240 (02-06)	TEMIC AirBag
 211 E-Class	AIRBAG	E 240 (06-..)	BOSCH SRS AirBag
 211 E-Class	AIRBAG	E 250 CDI (02-06)	TEMIC AirBag
 211 E-Class	AIRBAG	E 250 CDI (06-..)	BOSCH SRS AirBag
 211 E-Class	AIRBAG	E 270 CDI (02-06)	TEMIC AirBag
 211 E-Class	AIRBAG	E 270 CDI (06-..)	BOSCH SRS AirBag
 211 E-Class	AIRBAG	E 280 (02-06)	TEMIC AirBag
 211 E-Class	AIRBAG	E 280 (06-..)	BOSCH SRS AirBag
 211 E-Class	AIRBAG	E 280 CDI (02-06)	TEMIC AirBag
 211 E-Class	AIRBAG	E 280 CDI (06-..)	BOSCH SRS AirBag
 211 E-Class	AIRBAG	E 300 BlueTEC (02-06)	TEMIC AirBag
 211 E-Class	AIRBAG	E 300 BlueTEC (06-..)	BOSCH SRS AirBag
 211 E-Class	AIRBAG	E 320 (02-06)	TEMIC AirBag
 211 E-Class	AIRBAG	E 320 (06-..)	BOSCH SRS AirBag
 211 E-Class	AIRBAG	E 320 CDI (02-06)	TEMIC AirBag
 211 E-Class	AIRBAG	E 320 CDI (06-..)	BOSCH SRS AirBag
 211 E-Class	AIRBAG	E 350 (02-06)	TEMIC AirBag
 211 E-Class	AIRBAG	E 350 (06-..)	BOSCH SRS AirBag
 211 E-Class	AIRBAG	E 350 CGI (02-06)	TEMIC AirBag
 211 E-Class	AIRBAG	E 350 CGI (06-..)	BOSCH SRS AirBag
 211 E-Class	AIRBAG	E 400 CDI (02-06)	TEMIC AirBag
 211 E-Class	AIRBAG	E 400 CDI (06-..)	BOSCH SRS AirBag
 211 E-Class	AIRBAG	E 420 CDI (02-06)	TEMIC AirBag
 211 E-Class	AIRBAG	E 420 CDI (06-..)	BOSCH SRS AirBag
 211 E-Class	AIRBAG	E 500 (02-06)	TEMIC AirBag
 211 E-Class	AIRBAG	E 500 (06-..)	BOSCH SRS AirBag
 211 E-Class	AIRBAG	E 55 AMG (02-06)	TEMIC AirBag
 211 E-Class	AIRBAG	E 55 AMG (06-..)	BOSCH SRS AirBag

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 211 E-Class	AIRBAG	E 63 AMG (02-06)	TEMIC AirBag
 211 E-Class	AIRBAG	E 63 AMG (06-..)	BOSCH SRS AirBag
 211 E-Class	AUTOM. TRANSMISSI	E 200 CDI (02-06)	SIEMENS EGS G-Tronic/4MATIC
 211 E-Class	AUTOM. TRANSMISSI	E 200 CDI (07-..)	DELPHI EWM Selector Lever
 211 E-Class	AUTOM. TRANSMISSI	E 200 CDI (07-..)	SIEMENS EGS 7G-Tronic
 211 E-Class	AUTOM. TRANSMISSI	E 200 CGI (..-06)	SIEMENS EGS G-Tronic/4MATIC
 211 E-Class	AUTOM. TRANSMISSI	E 200 CGI (07-..)	DELPHI EWM Selector Lever
 211 E-Class	AUTOM. TRANSMISSI	E 200 CGI (07-..)	SIEMENS EGS 7G-Tronic
 211 E-Class	AUTOM. TRANSMISSI	E 200 Kompr. (..-06)	SIEMENS EGS G-Tronic/4MATIC
 211 E-Class	AUTOM. TRANSMISSI	E 200 Kompr. (07-..)	DELPHI EWM Selector Lever
 211 E-Class	AUTOM. TRANSMISSI	E 200 Kompr. (07-..)	SIEMENS EGS 7G-Tronic
 211 E-Class	AUTOM. TRANSMISSI	E 200 NGT (..-06)	SIEMENS EGS G-Tronic/4MATIC
 211 E-Class	AUTOM. TRANSMISSI	E 200 NGT (07-..)	DELPHI EWM Selector Lever
 211 E-Class	AUTOM. TRANSMISSI	E 200 NGT (07-..)	SIEMENS EGS 7G-Tronic
 211 E-Class	AUTOM. TRANSMISSI	E 220 CDI (..-06)	SIEMENS EGS G-Tronic/4MATIC
 211 E-Class	AUTOM. TRANSMISSI	E 220 CDI (07-..)	DELPHI EWM Selector Lever
 211 E-Class	AUTOM. TRANSMISSI	E 220 CDI (07-..)	SIEMENS EGS 7G-Tronic
 211 E-Class	AUTOM. TRANSMISSI	E 230 (..-06)	SIEMENS EGS G-Tronic/4MATIC
 211 E-Class	AUTOM. TRANSMISSI	E 230 (07-..)	DELPHI EWM Selector Lever
 211 E-Class	AUTOM. TRANSMISSI	E 230 (07-..)	SIEMENS EGS 7G-Tronic
 211 E-Class	AUTOM. TRANSMISSI	E 240 (..-06)	SIEMENS EGS G-Tronic/4MATIC
 211 E-Class	AUTOM. TRANSMISSI	E 240 (07-..)	DELPHI EWM Selector Lever
 211 E-Class	AUTOM. TRANSMISSI	E 240 (07-..)	SIEMENS EGS 7G-Tronic
 211 E-Class	AUTOM. TRANSMISSI	E 250 CDI (..-06)	SIEMENS EGS G-Tronic/4MATIC
 211 E-Class	AUTOM. TRANSMISSI	E 250 CDI (07-..)	DELPHI EWM Selector Lever
 211 E-Class	AUTOM. TRANSMISSI	E 250 CDI (07-..)	SIEMENS EGS 7G-Tronic
 211 E-Class	AUTOM. TRANSMISSI	E 270 CDI (..-06)	SIEMENS EGS G-Tronic/4MATIC
 211 E-Class	AUTOM. TRANSMISSI	E 270 CDI (07-..)	DELPHI EWM Selector Lever
 211 E-Class	AUTOM. TRANSMISSI	E 270 CDI (07-..)	SIEMENS EGS 7G-Tronic
 211 E-Class	AUTOM. TRANSMISSI	E 280 (..-06)	SIEMENS EGS G-Tronic/4MATIC
 211 E-Class	AUTOM. TRANSMISSI	E 280 (07-..)	DELPHI EWM Selector Lever
 211 E-Class	AUTOM. TRANSMISSI	E 280 (07-..)	SIEMENS EGS 7G-Tronic
 211 E-Class	AUTOM. TRANSMISSI	E 280 CDI (..-06)	SIEMENS EGS G-Tronic/4MATIC
 211 E-Class	AUTOM. TRANSMISSI	E 280 CDI (07-..)	DELPHI EWM Selector Lever
 211 E-Class	AUTOM. TRANSMISSI	E 280 CDI (07-..)	SIEMENS EGS 7G-Tronic
 211 E-Class	AUTOM. TRANSMISSI	E 300 BlueTEC (..-06)	SIEMENS EGS G-Tronic/4MATIC
 211 E-Class	AUTOM. TRANSMISSI	E 300 BlueTEC (07-..)	DELPHI EWM Selector Lever
 211 E-Class	AUTOM. TRANSMISSI	E 300 BlueTEC (07-..)	SIEMENS EGS 7G-Tronic
 211 E-Class	AUTOM. TRANSMISSI	E 320 (..-06)	SIEMENS EGS G-Tronic/4MATIC
 211 E-Class	AUTOM. TRANSMISSI	E 320 (07-..)	DELPHI EWM Selector Lever
 211 E-Class	AUTOM. TRANSMISSI	E 320 (07-..)	SIEMENS EGS 7G-Tronic
 211 E-Class	AUTOM. TRANSMISSI	E 320 CDI (..-06)	SIEMENS EGS G-Tronic/4MATIC
 211 E-Class	AUTOM. TRANSMISSI	E 320 CDI (07-..)	DELPHI EWM Selector Lever
 211 E-Class	AUTOM. TRANSMISSI	E 320 CDI (07-..)	SIEMENS EGS 7G-Tronic
 211 E-Class	AUTOM. TRANSMISSI	E 350 (..-06)	SIEMENS EGS G-Tronic/4MATIC
 211 E-Class	AUTOM. TRANSMISSI	E 350 (07-..)	DELPHI EWM Selector Lever
 211 E-Class	AUTOM. TRANSMISSI	E 350 (07-..)	SIEMENS EGS 7G-Tronic
 211 E-Class	AUTOM. TRANSMISSI	E 350 CGI (..-06)	SIEMENS EGS G-Tronic/4MATIC
 211 E-Class	AUTOM. TRANSMISSI	E 350 CGI (07-..)	DELPHI EWM Selector Lever
 211 E-Class	AUTOM. TRANSMISSI	E 350 CGI (07-..)	SIEMENS EGS 7G-Tronic
 211 E-Class	AUTOM. TRANSMISSI	E 400 CDI (..-06)	SIEMENS EGS G-Tronic/4MATIC
 211 E-Class	AUTOM. TRANSMISSI	E 400 CDI (07-..)	DELPHI EWM Selector Lever
 211 E-Class	AUTOM. TRANSMISSI	E 400 CDI (07-..)	SIEMENS EGS 7G-Tronic
 211 E-Class	AUTOM. TRANSMISSI	E 420 CDI (..-06)	SIEMENS EGS G-Tronic/4MATIC
 211 E-Class	AUTOM. TRANSMISSI	E 420 CDI (07-..)	DELPHI EWM Selector Lever
 211 E-Class	AUTOM. TRANSMISSI	E 420 CDI (07-..)	SIEMENS EGS 7G-Tronic
 211 E-Class	AUTOM. TRANSMISSI	E 500 (..-06)	SIEMENS EGS G-Tronic/4MATIC
 211 E-Class	AUTOM. TRANSMISSI	E 500 (07-..)	DELPHI EWM Selector Lever

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 211 E-Class	AUTOM. TRANSMISSI	E 500 (07-..)	SIEMENS EGS 7G-Tronic
 211 E-Class	AUTOM. TRANSMISSI	E 55 AMG (...06)	SIEMENS EGS G-Tronic/4MATIC
 211 E-Class	AUTOM. TRANSMISSI	E 55 AMG (07-..)	DELPHI EWM Selector Lever
 211 E-Class	AUTOM. TRANSMISSI	E 55 AMG (07-..)	SIEMENS EGS 7G-Tronic
 211 E-Class	AUTOM. TRANSMISSI	E 63 AMG (...06)	SIEMENS EGS G-Tronic/4MATIC
 211 E-Class	AUTOM. TRANSMISSI	E 63 AMG (07-..)	DELPHI EWM Selector Lever
 211 E-Class	AUTOM. TRANSMISSI	E 63 AMG (07-..)	SIEMENS EGS 7G-Tronic
 211 E-Class	BRAKE POWER SUP	E 200 CDI (02-06)	BOSCH SBC
 211 E-Class	BRAKE POWER SUP	E 200 CDI (06-..)	BOSCH SBC Sensotronic Brake Control
 211 E-Class	BRAKE POWER SUP	E 200 CGI (02-06)	BOSCH SBC
 211 E-Class	BRAKE POWER SUP	E 200 CGI (06-..)	BOSCH SBC Sensotronic Brake Control
 211 E-Class	BRAKE POWER SUP	E 200 Kompr. (02-06)	BOSCH SBC
 211 E-Class	BRAKE POWER SUP	E 200 Kompr. (06-..)	BOSCH SBC Sensotronic Brake Control
 211 E-Class	BRAKE POWER SUP	E 200 NGT (02-06)	BOSCH SBC
 211 E-Class	BRAKE POWER SUP	E 200 NGT (06-..)	BOSCH SBC Sensotronic Brake Control
 211 E-Class	BRAKE POWER SUP	E 220 CDI (02-06)	BOSCH SBC
 211 E-Class	BRAKE POWER SUP	E 220 CDI (06-..)	BOSCH SBC Sensotronic Brake Control
 211 E-Class	BRAKE POWER SUP	E 230 (02-06)	BOSCH SBC
 211 E-Class	BRAKE POWER SUP	E 230 (06-..)	BOSCH SBC Sensotronic Brake Control
 211 E-Class	BRAKE POWER SUP	E 240 (02-06)	BOSCH SBC
 211 E-Class	BRAKE POWER SUP	E 240 (06-..)	BOSCH SBC Sensotronic Brake Control
 211 E-Class	BRAKE POWER SUP	E 250 CDI (02-06)	BOSCH SBC
 211 E-Class	BRAKE POWER SUP	E 250 CDI (06-..)	BOSCH SBC Sensotronic Brake Control
 211 E-Class	BRAKE POWER SUP	E 270 CDI (02-06)	BOSCH SBC
 211 E-Class	BRAKE POWER SUP	E 270 CDI (06-..)	BOSCH SBC Sensotronic Brake Control
 211 E-Class	BRAKE POWER SUP	E 280 (02-06)	BOSCH SBC
 211 E-Class	BRAKE POWER SUP	E 280 (06-..)	BOSCH SBC Sensotronic Brake Control
 211 E-Class	BRAKE POWER SUP	E 280 CDI (02-06)	BOSCH SBC
 211 E-Class	BRAKE POWER SUP	E 280 CDI (06-..)	BOSCH SBC Sensotronic Brake Control
 211 E-Class	BRAKE POWER SUP	E 300 BlueTEC (02-06)	BOSCH SBC
 211 E-Class	BRAKE POWER SUP	E 300 BlueTEC (06-..)	BOSCH SBC Sensotronic Brake Control
 211 E-Class	BRAKE POWER SUP	E 320 (02-06)	BOSCH SBC
 211 E-Class	BRAKE POWER SUP	E 320 (06-..)	BOSCH SBC Sensotronic Brake Control
 211 E-Class	BRAKE POWER SUP	E 320 CDI (02-06)	BOSCH SBC
 211 E-Class	BRAKE POWER SUP	E 320 CDI (06-..)	BOSCH SBC Sensotronic Brake Control
 211 E-Class	BRAKE POWER SUP	E 350 (02-06)	BOSCH SBC
 211 E-Class	BRAKE POWER SUP	E 350 (06-..)	BOSCH SBC Sensotronic Brake Control
 211 E-Class	BRAKE POWER SUP	E 350 CGI (02-06)	BOSCH SBC
 211 E-Class	BRAKE POWER SUP	E 350 CGI (06-..)	BOSCH SBC Sensotronic Brake Control
 211 E-Class	BRAKE POWER SUP	E 400 CDI (02-06)	BOSCH SBC
 211 E-Class	BRAKE POWER SUP	E 400 CDI (06-..)	BOSCH SBC Sensotronic Brake Control
 211 E-Class	BRAKE POWER SUP	E 420 CDI (02-06)	BOSCH SBC
 211 E-Class	BRAKE POWER SUP	E 420 CDI (06-..)	BOSCH SBC Sensotronic Brake Control
 211 E-Class	BRAKE POWER SUP	E 500 (02-06)	BOSCH SBC
 211 E-Class	BRAKE POWER SUP	E 500 (06-..)	BOSCH SBC Sensotronic Brake Control
 211 E-Class	BRAKE POWER SUP	E 55 AMG (02-06)	BOSCH SBC
 211 E-Class	BRAKE POWER SUP	E 55 AMG (06-..)	BOSCH SBC Sensotronic Brake Control
 211 E-Class	BRAKE POWER SUP	E 63 AMG (02-06)	BOSCH SBC
 211 E-Class	BRAKE POWER SUP	E 63 AMG (06-..)	BOSCH SBC Sensotronic Brake Control
 211 E-Class	CHANGE BRAKE PAD	E 200 CDI (02-06)	BOSCH SBC MANUAL
 211 E-Class	CHANGE BRAKE PAD	E 200 CGI (02-06)	BOSCH SBC MANUAL
 211 E-Class	CHANGE BRAKE PAD	E 200 Kompr. (02-06)	BOSCH SBC MANUAL
 211 E-Class	CHANGE BRAKE PAD	E 200 NGT (02-06)	BOSCH SBC MANUAL
 211 E-Class	CHANGE BRAKE PAD	E 220 CDI (02-06)	BOSCH SBC MANUAL
 211 E-Class	CHANGE BRAKE PAD	E 230 (02-06)	BOSCH SBC MANUAL
 211 E-Class	CHANGE BRAKE PAD	E 240 (02-06)	BOSCH SBC MANUAL
 211 E-Class	CHANGE BRAKE PAD	E 250 CDI (02-06)	BOSCH SBC MANUAL
 211 E-Class	CHANGE BRAKE PAD	E 270 CDI (02-06)	BOSCH SBC MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 211 E-Class	CHANGE BRAKE PAD	E 280 (02-06)	BOSCH SBC MANUAL
 211 E-Class	CHANGE BRAKE PAD	E 280 CDI (02-06)	BOSCH SBC MANUAL
 211 E-Class	CHANGE BRAKE PAD	E 300 BlueTEC (02-06)	BOSCH SBC MANUAL
 211 E-Class	CHANGE BRAKE PAD	E 320 (02-06)	BOSCH SBC MANUAL
 211 E-Class	CHANGE BRAKE PAD	E 320 CDI (02-06)	BOSCH SBC MANUAL
 211 E-Class	CHANGE BRAKE PAD	E 350 (02-06)	BOSCH SBC MANUAL
 211 E-Class	CHANGE BRAKE PAD	E 350 CGI (02-06)	BOSCH SBC MANUAL
 211 E-Class	CHANGE BRAKE PAD	E 400 CDI (02-06)	BOSCH SBC MANUAL
 211 E-Class	CHANGE BRAKE PAD	E 420 CDI (02-06)	BOSCH SBC MANUAL
 211 E-Class	CHANGE BRAKE PAD	E 500 (02-06)	BOSCH SBC MANUAL
 211 E-Class	CHANGE BRAKE PAD	E 55 AMG (02-06)	BOSCH SBC MANUAL
 211 E-Class	CHANGE BRAKE PAD	E 63 AMG (02-06)	BOSCH SBC MANUAL
 211 E-Class	CHASSIS NETWORK	E 200 CDI (06-08)	GATEWAY
 211 E-Class	CHASSIS NETWORK	E 200 CGI (06-..)	GATEWAY
 211 E-Class	CHASSIS NETWORK	E 200 Kompr. (06-..)	GATEWAY
 211 E-Class	CHASSIS NETWORK	E 200 NGT (06-..)	GATEWAY
 211 E-Class	CHASSIS NETWORK	E 220 CDI (06-..)	GATEWAY
 211 E-Class	CHASSIS NETWORK	E 230 (06-..)	GATEWAY
 211 E-Class	CHASSIS NETWORK	E 240 (06-..)	GATEWAY
 211 E-Class	CHASSIS NETWORK	E 250 CDI (06-..)	GATEWAY
 211 E-Class	CHASSIS NETWORK	E 270 CDI (06-..)	GATEWAY
 211 E-Class	CHASSIS NETWORK	E 280 (06-..)	GATEWAY
 211 E-Class	CHASSIS NETWORK	E 280 CDI (06-..)	GATEWAY
 211 E-Class	CHASSIS NETWORK	E 300 BlueTEC (06-..)	GATEWAY
 211 E-Class	CHASSIS NETWORK	E 320 CDI (06-..)	GATEWAY
 211 E-Class	CHASSIS NETWORK	E 350 (06-..)	GATEWAY
 211 E-Class	CHASSIS NETWORK	E 350 CGI (06-..)	GATEWAY
 211 E-Class	CHASSIS NETWORK	E 420 CDI (06-..)	GATEWAY
 211 E-Class	CHASSIS NETWORK	E 500 (06-..)	GATEWAY
 211 E-Class	CHASSIS NETWORK	E 55 AMG (06-..)	GATEWAY
 211 E-Class	CHASSIS NETWORK	E 63 AMG (06-..)	GATEWAY
 211 E-Class	CLIMA	E 200 CDI (02-06)	VDO Klima KLA
 211 E-Class	CLIMA	E 200 CGI (02-06)	VDO Klima KLA
 211 E-Class	CLIMA	E 200 Kompr. (02-06)	VDO Klima KLA
 211 E-Class	CLIMA	E 200 NGT (02-06)	VDO Klima KLA
 211 E-Class	CLIMA	E 220 CDI (02-06)	VDO Klima KLA
 211 E-Class	CLIMA	E 230 (02-06)	VDO Klima KLA
 211 E-Class	CLIMA	E 240 (02-06)	VDO Klima KLA
 211 E-Class	CLIMA	E 250 CDI (02-06)	VDO Klima KLA
 211 E-Class	CLIMA	E 270 CDI (02-06)	VDO Klima KLA
 211 E-Class	CLIMA	E 280 CDI (02-06)	VDO Klima KLA
 211 E-Class	CLIMA	E 300 BlueTEC (02-06)	VDO Klima KLA
 211 E-Class	CLIMA	E 320 (02-06)	VDO Klima KLA
 211 E-Class	CLIMA	E 320 CDI (02-06)	VDO Klima KLA
 211 E-Class	CLIMA	E 350 (02-06)	VDO Klima KLA
 211 E-Class	CLIMA	E 350 CGI (02-06)	VDO Klima KLA
 211 E-Class	CLIMA	E 400 CDI (02-06)	VDO Klima KLA
 211 E-Class	CLIMA	E 500 (02-06)	VDO Klima KLA
 211 E-Class	CLIMA	E 55 AMG (02-06)	VDO Klima KLA
 211 E-Class	CLIMA	E 63 AMG (02-06)	VDO Klima KLA
 211 E-Class	ENGINE MANAGEME	E 200 CDI (02-06)	BOSCH EDC 15 Common Rail CDI 3
 211 E-Class	ENGINE MANAGEME	E 200 CGI (02-..)	EOBD
 211 E-Class	ENGINE MANAGEME	E 200 Kompr. (02-..)	EOBD
 211 E-Class	ENGINE MANAGEME	E 200 NGT (02-..)	EOBD
 211 E-Class	ENGINE MANAGEME	E 220 CDI (02-06)	BOSCH EDC 15 Common Rail CDI 3
 211 E-Class	ENGINE MANAGEME	E 230 (02-..)	EOBD
 211 E-Class	ENGINE MANAGEME	E 240 (02-..)	EOBD
 211 E-Class	ENGINE MANAGEME	E 250 CDI (04-..)	EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 211 E-Class	ENGINE MANAGEME	E 270 CDI (02-06)	BOSCH EDC 15 Common Rail CDI 3
 211 E-Class	ENGINE MANAGEME	E 280 (02-..)	EOBD
 211 E-Class	ENGINE MANAGEME	E 280 CDI (06-..)	BOSCH EDC Common Rail CDI 4
 211 E-Class	ENGINE MANAGEME	E 300 BlueTEC (02-..)	EOBD
 211 E-Class	ENGINE MANAGEME	E 320 (02-10)	EOBD
 211 E-Class	ENGINE MANAGEME	E 320 CDI (02-06)	BOSCH EDC 15 Common Rail CDI 3
 211 E-Class	ENGINE MANAGEME	E 350 (02-..)	EOBD
 211 E-Class	ENGINE MANAGEME	E 350 CGI (02-..)	EOBD
 211 E-Class	ENGINE MANAGEME	E 400 CDI (02-..)	EOBD
 211 E-Class	ENGINE MANAGEME	E 420 CDI (03-..)	EOBD
 211 E-Class	ENGINE MANAGEME	E 500 (02-..)	EOBD
 211 E-Class	ENGINE MANAGEME	E 55 AMG (02-..)	EOBD
 211 E-Class	ENGINE MANAGEME	E 63 AMG (02-..)	EOBD
 211 E-Class	MAINTENANCE	E 200 CDI (02-06)	BOSCH SBC MANUAL
 211 E-Class	MAINTENANCE	E 200 CDI (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	MAINTENANCE	E 200 CGI (02-06)	BOSCH SBC MANUAL
 211 E-Class	MAINTENANCE	E 200 CGI (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	MAINTENANCE	E 200 Kompr. (02-06)	BOSCH SBC MANUAL
 211 E-Class	MAINTENANCE	E 200 Kompr. (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	MAINTENANCE	E 200 NGT (02-06)	BOSCH SBC MANUAL
 211 E-Class	MAINTENANCE	E 200 NGT (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	MAINTENANCE	E 220 CDI (02-06)	BOSCH SBC MANUAL
 211 E-Class	MAINTENANCE	E 220 CDI (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	MAINTENANCE	E 230 (02-06)	BOSCH SBC MANUAL
 211 E-Class	MAINTENANCE	E 230 (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	MAINTENANCE	E 240 (02-06)	BOSCH SBC MANUAL
 211 E-Class	MAINTENANCE	E 240 (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	MAINTENANCE	E 250 CDI (02-06)	BOSCH SBC MANUAL
 211 E-Class	MAINTENANCE	E 250 CDI (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	MAINTENANCE	E 270 CDI (02-06)	BOSCH SBC MANUAL
 211 E-Class	MAINTENANCE	E 270 CDI (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	MAINTENANCE	E 280 (02-06)	BOSCH SBC MANUAL
 211 E-Class	MAINTENANCE	E 280 (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	MAINTENANCE	E 280 CDI (02-06)	BOSCH SBC MANUAL
 211 E-Class	MAINTENANCE	E 280 CDI (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	MAINTENANCE	E 300 BlueTEC (02-06)	BOSCH SBC MANUAL
 211 E-Class	MAINTENANCE	E 300 BlueTEC (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	MAINTENANCE	E 320 (02-06)	BOSCH SBC MANUAL
 211 E-Class	MAINTENANCE	E 320 (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	MAINTENANCE	E 320 CDI (02-06)	BOSCH SBC MANUAL
 211 E-Class	MAINTENANCE	E 320 CDI (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	MAINTENANCE	E 350 (02-06)	BOSCH SBC MANUAL
 211 E-Class	MAINTENANCE	E 350 (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	MAINTENANCE	E 350 CGI (02-06)	BOSCH SBC MANUAL
 211 E-Class	MAINTENANCE	E 350 CGI (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	MAINTENANCE	E 400 CDI (02-06)	BOSCH SBC MANUAL
 211 E-Class	MAINTENANCE	E 400 CDI (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	MAINTENANCE	E 420 CDI (02-06)	BOSCH SBC MANUAL
 211 E-Class	MAINTENANCE	E 420 CDI (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	MAINTENANCE	E 500 (02-06)	BOSCH SBC MANUAL
 211 E-Class	MAINTENANCE	E 500 (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	MAINTENANCE	E 55 AMG (02-06)	BOSCH SBC MANUAL
 211 E-Class	MAINTENANCE	E 55 AMG (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	MAINTENANCE	E 63 AMG (02-06)	BOSCH SBC MANUAL
 211 E-Class	MAINTENANCE	E 63 AMG (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	PARKING HELP	E 200 CDI (06-08)	BOSCH Parktronic
 211 E-Class	PARKING HELP	E 200 CGI (06-..)	BOSCH Parktronic
 211 E-Class	PARKING HELP	E 200 Kompr. (06-..)	BOSCH Parktronic

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 211 E-Class	PARKING HELP	E 200 NGT (06-..)	BOSCH Parktronic
 211 E-Class	PARKING HELP	E 220 CDI (06-..)	BOSCH Parktronic
 211 E-Class	PARKING HELP	E 230 (06-..)	BOSCH Parktronic
 211 E-Class	PARKING HELP	E 240 (06-..)	BOSCH Parktronic
 211 E-Class	PARKING HELP	E 250 CDI (06-..)	BOSCH Parktronic
 211 E-Class	PARKING HELP	E 270 CDI (06-..)	BOSCH Parktronic
 211 E-Class	PARKING HELP	E 280 (06-..)	BOSCH Parktronic
 211 E-Class	PARKING HELP	E 280 CDI (06-..)	BOSCH Parktronic
 211 E-Class	PARKING HELP	E 300 BlueTEC (06-..)	BOSCH Parktronic
 211 E-Class	PARKING HELP	E 320 CDI (06-..)	BOSCH Parktronic
 211 E-Class	PARKING HELP	E 350 (06-..)	BOSCH Parktronic
 211 E-Class	PARKING HELP	E 350 CGI (06-..)	BOSCH Parktronic
 211 E-Class	PARKING HELP	E 400 CDI (06-..)	BOSCH Parktronic
 211 E-Class	PARKING HELP	E 420 CDI (06-..)	BOSCH Parktronic
 211 E-Class	PARKING HELP	E 500 (06-..)	BOSCH Parktronic
 211 E-Class	PARKING HELP	E 55 AMG (06-..)	BOSCH Parktronic
 211 E-Class	PARKING HELP	E 63 AMG (06-..)	BOSCH Parktronic
 211 E-Class	SERVICE LIGHT RES	E 200 CDI (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	SERVICE LIGHT RES	E 200 CGI (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	SERVICE LIGHT RES	E 200 Kompr. (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	SERVICE LIGHT RES	E 200 NGT (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	SERVICE LIGHT RES	E 220 CDI (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	SERVICE LIGHT RES	E 230 (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	SERVICE LIGHT RES	E 240 (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	SERVICE LIGHT RES	E 250 CDI (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	SERVICE LIGHT RES	E 270 CDI (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	SERVICE LIGHT RES	E 280 (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	SERVICE LIGHT RES	E 280 CDI (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	SERVICE LIGHT RES	E 300 BlueTEC (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	SERVICE LIGHT RES	E 320 (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	SERVICE LIGHT RES	E 320 CDI (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	SERVICE LIGHT RES	E 350 (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	SERVICE LIGHT RES	E 350 CGI (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	SERVICE LIGHT RES	E 400 CDI (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	SERVICE LIGHT RES	E 420 CDI (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	SERVICE LIGHT RES	E 500 (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	SERVICE LIGHT RES	E 55 AMG (02-06)	VDO/Marelli/xx MANUAL
 211 E-Class	SERVICE LIGHT RES	E 63 AMG (02-06)	VDO/Marelli/xx MANUAL
 212 E-Class	ABS + TRACT. CONT	E 200 CDI (09-..)	BOSCH ESP
 212 E-Class	ABS + TRACT. CONT	E 200 CGI (09-..)	BOSCH ESP
 212 E-Class	ABS + TRACT. CONT	E 220 CDI (09-..)	BOSCH ESP
 212 E-Class	ABS + TRACT. CONT	E 250 CDI (09-..)	BOSCH ESP
 212 E-Class	ABS + TRACT. CONT	E 250 CGI (09-..)	BOSCH ESP
 212 E-Class	ABS + TRACT. CONT	E 350 4MATIC (09-..)	BOSCH ESP
 212 E-Class	ABS + TRACT. CONT	E 350 BlueTEC (09-..)	BOSCH ESP
 212 E-Class	ABS + TRACT. CONT	E 350 CDI (09-..)	BOSCH ESP
 212 E-Class	ABS + TRACT. CONT	E 350 CDI 4MATIC (09-..)	BOSCH ESP
 212 E-Class	ABS + TRACT. CONT	E 350 CGI (09-..)	BOSCH ESP
 212 E-Class	ABS + TRACT. CONT	E 500 (09-..)	BOSCH ESP
 212 E-Class	ABS + TRACT. CONT	E 500 4MATIC (09-..)	BOSCH ESP
 212 E-Class	ABS + TRACT. CONT	E 63 AMG (09-..)	BOSCH ESP
 212 E-Class	AIRBAG	E 200 CDI (09-..)	Continental Airbag
 212 E-Class	AIRBAG	E 200 CGI (09-..)	Continental Airbag
 212 E-Class	AIRBAG	E 220 CDI (09-..)	Continental Airbag
 212 E-Class	AIRBAG	E 250 CDI (09-..)	Continental Airbag
 212 E-Class	AIRBAG	E 250 CGI (09-..)	Continental Airbag
 212 E-Class	AIRBAG	E 350 4MATIC (09-..)	Continental Airbag
 212 E-Class	AIRBAG	E 350 BlueTEC (09-..)	Continental Airbag

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 212 E-Class	AIRBAG	E 350 CDI (09-..)	Continental Airbag
 212 E-Class	AIRBAG	E 350 CDI 4MATIC (09-..)	Continental Airbag
 212 E-Class	AIRBAG	E 350 CGI (09-..)	Continental Airbag
 212 E-Class	AIRBAG	E 500 (09-..)	Continental Airbag
 212 E-Class	AIRBAG	E 500 4MATIC (09-..)	Continental Airbag
 212 E-Class	AIRBAG	E 63 AMG (09-..)	Continental Airbag
 212 E-Class	AUTOM. TRANSMISSI	E 200 CDI (09-..)	EWM Selector lever
 212 E-Class	AUTOM. TRANSMISSI	E 200 CDI (09-..)	Siemens EGS 53
 212 E-Class	AUTOM. TRANSMISSI	E 200 CGI (09-..)	EWM Selector lever
 212 E-Class	AUTOM. TRANSMISSI	E 200 CGI (09-..)	Siemens EGS 53
 212 E-Class	AUTOM. TRANSMISSI	E 220 CDI (09-..)	EWM Selector lever
 212 E-Class	AUTOM. TRANSMISSI	E 220 CDI (09-..)	Siemens EGS 53
 212 E-Class	AUTOM. TRANSMISSI	E 250 CDI (09-..)	EWM Selector lever
 212 E-Class	AUTOM. TRANSMISSI	E 250 CDI (09-..)	Siemens EGS 53
 212 E-Class	AUTOM. TRANSMISSI	E 250 CGI (09-..)	EWM Selector lever
 212 E-Class	AUTOM. TRANSMISSI	E 250 CGI (09-..)	Siemens EGS 53
 212 E-Class	AUTOM. TRANSMISSI	E 350 4MATIC (09-..)	EWM Selector lever
 212 E-Class	AUTOM. TRANSMISSI	E 350 4MATIC (09-..)	Siemens EGS 53
 212 E-Class	AUTOM. TRANSMISSI	E 350 BlueTEC (09-..)	EWM Selector lever
 212 E-Class	AUTOM. TRANSMISSI	E 350 BlueTEC (09-..)	Siemens EGS 53
 212 E-Class	AUTOM. TRANSMISSI	E 350 CDI (09-..)	EWM Selector lever
 212 E-Class	AUTOM. TRANSMISSI	E 350 CDI (09-..)	Siemens EGS 53
 212 E-Class	AUTOM. TRANSMISSI	E 350 CDI 4MATIC (09-..)	EWM Selector lever
 212 E-Class	AUTOM. TRANSMISSI	E 350 CDI 4MATIC (09-..)	Siemens EGS 53
 212 E-Class	AUTOM. TRANSMISSI	E 350 CGI (09-..)	EWM Selector lever
 212 E-Class	AUTOM. TRANSMISSI	E 350 CGI (09-..)	Siemens EGS 53
 212 E-Class	AUTOM. TRANSMISSI	E 500 (09-..)	EWM Selector lever
 212 E-Class	AUTOM. TRANSMISSI	E 500 (09-..)	Siemens EGS 53
 212 E-Class	AUTOM. TRANSMISSI	E 500 4MATIC (09-..)	EWM Selector lever
 212 E-Class	AUTOM. TRANSMISSI	E 500 4MATIC (09-..)	Siemens EGS 53
 212 E-Class	AUTOM. TRANSMISSI	E 63 AMG (09-..)	EWM Selector lever
 212 E-Class	AUTOM. TRANSMISSI	E 63 AMG (09-..)	Siemens EGS 53
 212 E-Class	CHASSIS NETWORK	E 200 CDI (09-..)	Gateway Centrale ZGW
 212 E-Class	CHASSIS NETWORK	E 200 CGI (09-..)	Gateway Centrale ZGW
 212 E-Class	CHASSIS NETWORK	E 220 CDI (09-..)	Gateway Centrale ZGW
 212 E-Class	CHASSIS NETWORK	E 250 CDI (09-..)	Gateway Centrale ZGW
 212 E-Class	CHASSIS NETWORK	E 250 CGI (09-..)	Gateway Centrale ZGW
 212 E-Class	CHASSIS NETWORK	E 350 4MATIC (09-..)	Gateway Centrale ZGW
 212 E-Class	CHASSIS NETWORK	E 350 BlueTEC (09-..)	Gateway Centrale ZGW
 212 E-Class	CHASSIS NETWORK	E 350 CDI (09-..)	Gateway Centrale ZGW
 212 E-Class	CHASSIS NETWORK	E 350 CDI 4MATIC (09-..)	Gateway Centrale ZGW
 212 E-Class	CHASSIS NETWORK	E 350 CGI (09-..)	Gateway Centrale ZGW
 212 E-Class	CHASSIS NETWORK	E 500 (09-..)	Gateway Centrale ZGW
 212 E-Class	CHASSIS NETWORK	E 500 4MATIC (09-..)	Gateway Centrale ZGW
 212 E-Class	CHASSIS NETWORK	E 63 AMG (09-..)	Gateway Centrale ZGW
 212 E-Class	CLIMA	E 200 CDI (09-..)	VDO KLA Klimautomatik
 212 E-Class	CLIMA	E 200 CGI (09-..)	VDO KLA Klimautomatik
 212 E-Class	CLIMA	E 220 CDI (09-..)	VDO KLA Klimautomatik
 212 E-Class	CLIMA	E 250 CDI (09-..)	VDO KLA Klimautomatik
 212 E-Class	CLIMA	E 250 CGI (09-..)	VDO KLA Klimautomatik
 212 E-Class	CLIMA	E 350 4MATIC (09-..)	VDO KLA Klimautomatik
 212 E-Class	CLIMA	E 350 BlueTEC (09-..)	VDO KLA Klimautomatik
 212 E-Class	CLIMA	E 350 CDI (09-..)	VDO KLA Klimautomatik
 212 E-Class	CLIMA	E 350 CDI 4MATIC (09-..)	VDO KLA Klimautomatik
 212 E-Class	CLIMA	E 350 CGI (09-..)	VDO KLA Klimautomatik
 212 E-Class	CLIMA	E 500 (09-..)	VDO KLA Klimautomatik
 212 E-Class	CLIMA	E 500 4MATIC (09-..)	VDO KLA Klimautomatik
 212 E-Class	CLIMA	E 63 AMG (09-..)	VDO KLA Klimautomatik

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 212 E-Class	DASHBOARD	E 200 CDI (09-..)	VDO Siemens KI 4.1
 212 E-Class	DASHBOARD	E 200 CGI (09-..)	VDO Siemens KI 4.1
 212 E-Class	DASHBOARD	E 220 CDI (09-..)	VDO Siemens KI 4.1
 212 E-Class	DASHBOARD	E 250 CDI (09-..)	VDO Siemens KI 4.1
 212 E-Class	DASHBOARD	E 250 CGI (09-..)	VDO Siemens KI 4.1
 212 E-Class	DASHBOARD	E 350 4MATIC (09-..)	VDO Siemens KI 4.1
 212 E-Class	DASHBOARD	E 350 BlueTEC (09-..)	VDO Siemens KI 4.1
 212 E-Class	DASHBOARD	E 350 CDI (09-..)	VDO Siemens KI 4.1
 212 E-Class	DASHBOARD	E 350 CDI 4MATIC (09-..)	VDO Siemens KI 4.1
 212 E-Class	DASHBOARD	E 350 CGI (09-..)	VDO Siemens KI 4.1
 212 E-Class	DASHBOARD	E 500 (09-..)	VDO Siemens KI 4.1
 212 E-Class	DASHBOARD	E 500 4MATIC (09-..)	VDO Siemens KI 4.1
 212 E-Class	DASHBOARD	E 63 AMG (09-..)	VDO Siemens KI 4.1
 212 E-Class	ENGINE MANAGEME	E 200 CDI (09-..)	EOBD
 212 E-Class	ENGINE MANAGEME	E 200 CGI (09-..)	EOBD
 212 E-Class	ENGINE MANAGEME	E 220 CDI (09-..)	EOBD
 212 E-Class	ENGINE MANAGEME	E 250 CDI (09-..)	EOBD
 212 E-Class	ENGINE MANAGEME	E 250 CGI (09-..)	EOBD
 212 E-Class	ENGINE MANAGEME	E 350 4MATIC (09-..)	EOBD
 212 E-Class	ENGINE MANAGEME	E 350 BlueTEC (09-..)	EOBD
 212 E-Class	ENGINE MANAGEME	E 350 CDI (09-..)	EOBD
 212 E-Class	ENGINE MANAGEME	E 350 CDI 4MATIC (09-..)	EOBD
 212 E-Class	ENGINE MANAGEME	E 350 CGI (09-..)	EOBD
 212 E-Class	ENGINE MANAGEME	E 500 (09-..)	EOBD
 212 E-Class	ENGINE MANAGEME	E 500 4MATIC (09-..)	EOBD
 212 E-Class	ENGINE MANAGEME	E 63 AMG (09-..)	EOBD
 212 E-Class	IGNITION SWITCH	E 200 CDI (09-..)	Kostal EZS
 212 E-Class	IGNITION SWITCH	E 200 CGI (09-..)	Kostal EZS
 212 E-Class	IGNITION SWITCH	E 220 CDI (09-..)	Kostal EZS
 212 E-Class	IGNITION SWITCH	E 250 CDI (09-..)	Kostal EZS
 212 E-Class	IGNITION SWITCH	E 250 CGI (09-..)	Kostal EZS
 212 E-Class	IGNITION SWITCH	E 350 4MATIC (09-..)	Kostal EZS
 212 E-Class	IGNITION SWITCH	E 350 BlueTEC (09-..)	Kostal EZS
 212 E-Class	IGNITION SWITCH	E 350 CDI (09-..)	Kostal EZS
 212 E-Class	IGNITION SWITCH	E 350 CDI 4MATIC (09-..)	Kostal EZS
 212 E-Class	IGNITION SWITCH	E 350 CGI (09-..)	Kostal EZS
 212 E-Class	IGNITION SWITCH	E 500 (09-..)	Kostal EZS
 212 E-Class	IGNITION SWITCH	E 500 4MATIC (09-..)	Kostal EZS
 212 E-Class	IGNITION SWITCH	E 63 AMG (09-..)	Kostal EZS
 212 E-Class	MAINTENANCE	E 200 CDI (09-..)	
 212 E-Class	MAINTENANCE	E 200 CDI (09-..)	VDO Siemens KI 4.1
 212 E-Class	MAINTENANCE	E 200 CGI (09-..)	
 212 E-Class	MAINTENANCE	E 200 CGI (09-..)	VDO Siemens KI 4.1
 212 E-Class	MAINTENANCE	E 220 CDI (09-..)	
 212 E-Class	MAINTENANCE	E 220 CDI (09-..)	VDO Siemens KI 4.1
 212 E-Class	MAINTENANCE	E 250 CDI (09-..)	
 212 E-Class	MAINTENANCE	E 250 CDI (09-..)	VDO Siemens KI 4.1
 212 E-Class	MAINTENANCE	E 250 CGI (09-..)	
 212 E-Class	MAINTENANCE	E 250 CGI (09-..)	VDO Siemens KI 4.1
 212 E-Class	MAINTENANCE	E 350 4MATIC (09-..)	
 212 E-Class	MAINTENANCE	E 350 4MATIC (09-..)	VDO Siemens KI 4.1
 212 E-Class	MAINTENANCE	E 350 BlueTEC (09-..)	
 212 E-Class	MAINTENANCE	E 350 BlueTEC (09-..)	VDO Siemens KI 4.1
 212 E-Class	MAINTENANCE	E 350 CDI (09-..)	
 212 E-Class	MAINTENANCE	E 350 CDI (09-..)	VDO Siemens KI 4.1
 212 E-Class	MAINTENANCE	E 350 CDI 4MATIC (09-..)	
 212 E-Class	MAINTENANCE	E 350 CDI 4MATIC (09-..)	VDO Siemens KI 4.1
 212 E-Class	MAINTENANCE	E 350 CGI (09-..)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 212 E-Class	MAINTENANCE	E 350 CGI (09-..)	VDO Siemens KI 4.1
 212 E-Class	MAINTENANCE	E 500 (09-..)	
 212 E-Class	MAINTENANCE	E 500 (09-..)	VDO Siemens KI 4.1
 212 E-Class	MAINTENANCE	E 500 4MATIC (09-..)	
 212 E-Class	MAINTENANCE	E 500 4MATIC (09-..)	VDO Siemens KI 4.1
 212 E-Class	MAINTENANCE	E 63 AMG (09-..)	
 212 E-Class	MAINTENANCE	E 63 AMG (09-..)	VDO Siemens KI 4.1
 212 E-Class	PARKING HELP	E 200 CDI (09-..)	
 212 E-Class	PARKING HELP	E 200 CGI (09-..)	
 212 E-Class	PARKING HELP	E 220 CDI (09-..)	
 212 E-Class	PARKING HELP	E 250 CDI (09-..)	
 212 E-Class	PARKING HELP	E 250 CGI (09-..)	
 212 E-Class	PARKING HELP	E 300 BlueTEC (09-..)	
 212 E-Class	PARKING HELP	E 350 4MATIC (09-..)	
 212 E-Class	PARKING HELP	E 350 CDI (09-..)	
 212 E-Class	PARKING HELP	E 350 CDI 4MATIC (09-..)	
 212 E-Class	PARKING HELP	E 350 CGI (09-..)	
 212 E-Class	PARKING HELP	E 500 (09-..)	
 212 E-Class	PARKING HELP	E 500 4MATIC (09-..)	
 212 E-Class	PARKING HELP	E 63 AMG (09-..)	
 212 E-Class	SERVICE LIGHT RES	E 200 CDI (09-..)	
 212 E-Class	SERVICE LIGHT RES	E 200 CGI (09-..)	
 212 E-Class	SERVICE LIGHT RES	E 220 CDI (09-..)	
 212 E-Class	SERVICE LIGHT RES	E 250 CDI (09-..)	
 212 E-Class	SERVICE LIGHT RES	E 250 CGI (09-..)	
 212 E-Class	SERVICE LIGHT RES	E 350 4MATIC (09-..)	
 212 E-Class	SERVICE LIGHT RES	E 350 BlueTEC (09-..)	
 212 E-Class	SERVICE LIGHT RES	E 350 CDI (09-..)	
 212 E-Class	SERVICE LIGHT RES	E 350 CDI 4MATIC (09-..)	
 212 E-Class	SERVICE LIGHT RES	E 350 CGI (09-..)	
 212 E-Class	SERVICE LIGHT RES	E 500 (09-..)	
 212 E-Class	SERVICE LIGHT RES	E 500 4MATIC (09-..)	
 212 E-Class	SERVICE LIGHT RES	E 63 AMG (09-..)	
 215 CL-Class	ENGINE MANAGEME	CL 500 (01-06)	EOBD
 215 CL-Class	ENGINE MANAGEME	CL 55 AMG (01-06)	EOBD
 215 CL-Class	ENGINE MANAGEME	CL 55 AMG Kompr. (01-06)	EOBD
 215 CL-Class	ENGINE MANAGEME	CL 600 (01-06)	EOBD
 215 CL-Class	ENGINE MANAGEME	CL 63 AMG (01-06)	EOBD
 215 CL-Class	ENGINE MANAGEME	CL 65 AMG (01-06)	EOBD
 215 CL-Class	MAINTENANCE	CL 500 (99-03)	VDO/Marelli/xx MANUAL
 215 CL-Class	MAINTENANCE	CL 55 AMG (99-03)	VDO/Marelli/xx MANUAL
 215 CL-Class	MAINTENANCE	CL 55 AMG Kompr. (99-03)	VDO/Marelli/xx MANUAL
 215 CL-Class	MAINTENANCE	CL 600 (99-03)	VDO/Marelli/xx MANUAL
 215 CL-Class	MAINTENANCE	CL 63 AMG (99-03)	VDO/Marelli/xx MANUAL
 215 CL-Class	MAINTENANCE	CL 65 AMG (99-03)	VDO/Marelli/xx MANUAL
 215 CL-Class	SERVICE LIGHT RES	CL 500 (99-03)	VDO/Marelli/xx MANUAL
 215 CL-Class	SERVICE LIGHT RES	CL 55 AMG (99-03)	VDO/Marelli/xx MANUAL
 215 CL-Class	SERVICE LIGHT RES	CL 55 AMG Kompr. (99-03)	VDO/Marelli/xx MANUAL
 215 CL-Class	SERVICE LIGHT RES	CL 600 (99-03)	VDO/Marelli/xx MANUAL
 215 CL-Class	SERVICE LIGHT RES	CL 63 AMG (99-03)	VDO/Marelli/xx MANUAL
 215 CL-Class	SERVICE LIGHT RES	CL 65 AMG (99-03)	VDO/Marelli/xx MANUAL
 216 CL-Class	AUTOM. TRANSMISSI	500 (06-..)	Siemens EGS 53
 216 CL-Class	AUTOM. TRANSMISSI	600 (06-..)	Siemens EGS 53
 216 CL-Class	AUTOM. TRANSMISSI	CL 63 AMG (06-..)	Siemens EGS 53
 216 CL-Class	AUTOM. TRANSMISSI	CL 63 AMG V-Max (06-..)	Siemens EGS 53
 216 CL-Class	AUTOM. TRANSMISSI	CL 65 AMG V-Max (06-..)	Siemens EGS 53
 216 CL-Class	ENGINE MANAGEME	CL 500 (06-..)	EOBD
 216 CL-Class	ENGINE MANAGEME	CL 600 (06-..)	EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 216 CL-Class	ENGINE MANAGEME	CL 63 AMG (06-..)	EOBD
 216 CL-Class	ENGINE MANAGEME	CL 65 AMG (06-..)	EOBD
 216 CL-Class	MAINTENANCE	CL 500 (06-..)	VDO MANUAL
 216 CL-Class	MAINTENANCE	CL 600 (06-..)	VDO MANUAL
 216 CL-Class	MAINTENANCE	CL 63 AMG (06-..)	VDO MANUAL
 216 CL-Class	MAINTENANCE	CL 65 AMG (06-..)	VDO MANUAL
 216 CL-Class	SERVICE LIGHT RES	CL 500 (06-..)	VDO MANUAL
 216 CL-Class	SERVICE LIGHT RES	CL 600 (06-..)	VDO MANUAL
 216 CL-Class	SERVICE LIGHT RES	CL 63 AMG (06-..)	VDO MANUAL
 216 CL-Class	SERVICE LIGHT RES	CL 65 AMG (06-..)	VDO MANUAL
 219 CLS-Class	ABS + TRACT. CONT	CLS 280	BOSCH ABR
 219 CLS-Class	ABS + TRACT. CONT	CLS 300	BOSCH ABR
 219 CLS-Class	ABS + TRACT. CONT	CLS 320 CDI	BOSCH ABR
 219 CLS-Class	ABS + TRACT. CONT	CLS 350	BOSCH ABR
 219 CLS-Class	ABS + TRACT. CONT	CLS 350 CDI	BOSCH ABR
 219 CLS-Class	ABS + TRACT. CONT	CLS 350 CGI	BOSCH ABR
 219 CLS-Class	ABS + TRACT. CONT	CLS 500	BOSCH ABR
 219 CLS-Class	ABS + TRACT. CONT	CLS 55 AMG	BOSCH ABR
 219 CLS-Class	ABS + TRACT. CONT	CLS 63 AMG	BOSCH ABR
 219 CLS-Class	AIRBAG	CLS 280	BOSCH SRS
 219 CLS-Class	AIRBAG	CLS 300	BOSCH SRS
 219 CLS-Class	AIRBAG	CLS 320 CDI	BOSCH SRS
 219 CLS-Class	AIRBAG	CLS 350	BOSCH SRS
 219 CLS-Class	AIRBAG	CLS 350 CDI	BOSCH SRS
 219 CLS-Class	AIRBAG	CLS 350 CGI	BOSCH SRS
 219 CLS-Class	AIRBAG	CLS 500	BOSCH SRS
 219 CLS-Class	AIRBAG	CLS 55 AMG	BOSCH SRS
 219 CLS-Class	AIRBAG	CLS 63 AMG	BOSCH SRS
 219 CLS-Class	AUTOM. TRANSMISSI	CLS 280	DELPHI EWM Selector Lever
 219 CLS-Class	AUTOM. TRANSMISSI	CLS 280	SIEMENS EGS 7G-Tronic
 219 CLS-Class	AUTOM. TRANSMISSI	CLS 300	DELPHI EWM Selector Lever
 219 CLS-Class	AUTOM. TRANSMISSI	CLS 300	SIEMENS EGS 7G-Tronic
 219 CLS-Class	AUTOM. TRANSMISSI	CLS 320 CDI	DELPHI EWM Selector Lever
 219 CLS-Class	AUTOM. TRANSMISSI	CLS 320 CDI	SIEMENS EGS 7G-Tronic
 219 CLS-Class	AUTOM. TRANSMISSI	CLS 350	DELPHI EWM Selector Lever
 219 CLS-Class	AUTOM. TRANSMISSI	CLS 350	SIEMENS EGS 7G-Tronic
 219 CLS-Class	AUTOM. TRANSMISSI	CLS 350 CDI	DELPHI EWM Selector Lever
 219 CLS-Class	AUTOM. TRANSMISSI	CLS 350 CDI	SIEMENS EGS 7G-Tronic
 219 CLS-Class	AUTOM. TRANSMISSI	CLS 350 CGI	DELPHI EWM Selector Lever
 219 CLS-Class	AUTOM. TRANSMISSI	CLS 350 CGI	SIEMENS EGS 7G-Tronic
 219 CLS-Class	AUTOM. TRANSMISSI	CLS 500	DELPHI EWM Selector Lever
 219 CLS-Class	AUTOM. TRANSMISSI	CLS 500	SIEMENS EGS 7G-Tronic
 219 CLS-Class	AUTOM. TRANSMISSI	CLS 55 AMG	DELPHI EWM Selector Lever
 219 CLS-Class	AUTOM. TRANSMISSI	CLS 55 AMG	SIEMENS EGS 7G-Tronic
 219 CLS-Class	AUTOM. TRANSMISSI	CLS 63 AMG	DELPHI EWM Selector Lever
 219 CLS-Class	AUTOM. TRANSMISSI	CLS 63 AMG	SIEMENS EGS 7G-Tronic
 219 CLS-Class	CLIMA	CLS 280	K-KLA
 219 CLS-Class	CLIMA	CLS 300	K-KLA
 219 CLS-Class	CLIMA	CLS 320 CDI	K-KLA
 219 CLS-Class	CLIMA	CLS 350	K-KLA
 219 CLS-Class	CLIMA	CLS 350 CDI	K-KLA
 219 CLS-Class	CLIMA	CLS 350 CGI	K-KLA
 219 CLS-Class	CLIMA	CLS 500	K-KLA
 219 CLS-Class	CLIMA	CLS 55 AMG	K-KLA
 219 CLS-Class	CLIMA	CLS 63 AMG	K-KLA
 219 CLS-Class	DASHBOARD	CLS 280	VDO KI Kombi Instrument
 219 CLS-Class	DASHBOARD	CLS 300	VDO KI Kombi Instrument
 219 CLS-Class	DASHBOARD	CLS 320 CDI	VDO KI Kombi Instrument

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 219 CLS-Class	DASHBOARD	CLS 350	VDO KI Kombi Instrument
 219 CLS-Class	DASHBOARD	CLS 350 CDI	VDO KI Kombi Instrument
 219 CLS-Class	DASHBOARD	CLS 350 CGI	VDO KI Kombi Instrument
 219 CLS-Class	DASHBOARD	CLS 500	VDO KI Kombi Instrument
 219 CLS-Class	DASHBOARD	CLS 55 AMG	VDO KI Kombi Instrument
 219 CLS-Class	DASHBOARD	CLS 63 AMG	VDO KI Kombi Instrument
 219 CLS-Class	ENGINE MANAGEME	CLS 280	EOBD
 219 CLS-Class	ENGINE MANAGEME	CLS 300	EOBD
 219 CLS-Class	ENGINE MANAGEME	CLS 320 CDI (06-..)	BOSCH EDC Common Rail CDI 4
 219 CLS-Class	ENGINE MANAGEME	CLS 350	EOBD
 219 CLS-Class	ENGINE MANAGEME	CLS 350 CDI	EOBD
 219 CLS-Class	ENGINE MANAGEME	CLS 350 CGI	EOBD
 219 CLS-Class	ENGINE MANAGEME	CLS 500	BOSCH Motronic ME9.7
 219 CLS-Class	ENGINE MANAGEME	CLS 55 AMG	EOBD
 219 CLS-Class	ENGINE MANAGEME	CLS 63 AMG	EOBD
 219 CLS-Class	HEADLIGHT LEVEL	CLS 280	HELLA LWR
 219 CLS-Class	HEADLIGHT LEVEL	CLS 300	HELLA LWR
 219 CLS-Class	HEADLIGHT LEVEL	CLS 320 CDI	HELLA LWR
 219 CLS-Class	HEADLIGHT LEVEL	CLS 350	HELLA LWR
 219 CLS-Class	HEADLIGHT LEVEL	CLS 350 CDI	HELLA LWR
 219 CLS-Class	HEADLIGHT LEVEL	CLS 350 CGI	HELLA LWR
 219 CLS-Class	HEADLIGHT LEVEL	CLS 500	HELLA LWR
 219 CLS-Class	HEADLIGHT LEVEL	CLS 55 AMG	HELLA LWR
 219 CLS-Class	HEADLIGHT LEVEL	CLS 63 AMG	HELLA LWR
 219 CLS-Class	MAINTENANCE	CLS 280	HELLA LWR
 219 CLS-Class	MAINTENANCE	CLS 280	HELLA LWR
 219 CLS-Class	MAINTENANCE	CLS 300	HELLA LWR
 219 CLS-Class	MAINTENANCE	CLS 300	HELLA LWR
 219 CLS-Class	MAINTENANCE	CLS 320 CDI	HELLA LWR
 219 CLS-Class	MAINTENANCE	CLS 320 CDI	HELLA LWR
 219 CLS-Class	MAINTENANCE	CLS 320 CDI (06-..)	BOSCH EDC Common Rail CDI 4
 219 CLS-Class	MAINTENANCE	CLS 350	HELLA LWR
 219 CLS-Class	MAINTENANCE	CLS 350	HELLA LWR
 219 CLS-Class	MAINTENANCE	CLS 350 CDI	HELLA LWR
 219 CLS-Class	MAINTENANCE	CLS 350 CDI	HELLA LWR
 219 CLS-Class	MAINTENANCE	CLS 350 CGI	HELLA LWR
 219 CLS-Class	MAINTENANCE	CLS 350 CGI	HELLA LWR
 219 CLS-Class	MAINTENANCE	CLS 500	HELLA LWR
 219 CLS-Class	MAINTENANCE	CLS 500	HELLA LWR
 219 CLS-Class	MAINTENANCE	CLS 55 AMG	HELLA LWR
 219 CLS-Class	MAINTENANCE	CLS 55 AMG	HELLA LWR
 219 CLS-Class	MAINTENANCE	CLS 63 AMG	HELLA LWR
 219 CLS-Class	MAINTENANCE	CLS 63 AMG	HELLA LWR
 219 CLS-Class	MAINTENANCE SYST	CLS 280	Assyst
 219 CLS-Class	MAINTENANCE SYST	CLS 300	Assyst
 219 CLS-Class	MAINTENANCE SYST	CLS 320 CDI	Assyst
 219 CLS-Class	MAINTENANCE SYST	CLS 350	Assyst
 219 CLS-Class	MAINTENANCE SYST	CLS 350 CDI	Assyst
 219 CLS-Class	MAINTENANCE SYST	CLS 350 CGI	Assyst
 219 CLS-Class	MAINTENANCE SYST	CLS 500	Assyst
 219 CLS-Class	MAINTENANCE SYST	CLS 55 AMG	Assyst
 219 CLS-Class	MAINTENANCE SYST	CLS 63 AMG	Assyst
 219 CLS-Class	PARKING HELP	CLS 280	BOSCH PTS Parktronic system
 219 CLS-Class	PARKING HELP	CLS 300	BOSCH PTS Parktronic system
 219 CLS-Class	PARKING HELP	CLS 320 CDI	BOSCH PTS Parktronic system
 219 CLS-Class	PARKING HELP	CLS 350	BOSCH PTS Parktronic system
 219 CLS-Class	PARKING HELP	CLS 350 CDI	BOSCH PTS Parktronic system
 219 CLS-Class	PARKING HELP	CLS 350 CGI	BOSCH PTS Parktronic system

Systems supported by ECUREADER / ECUDECODER (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 219 CLS-Class	PARKING HELP	CLS 500	BOSCH PTS Parktronic system
 219 CLS-Class	PARKING HELP	CLS 55 AMG	BOSCH PTS Parktronic system
 219 CLS-Class	PARKING HELP	CLS 63 AMG	BOSCH PTS Parktronic system
 219 CLS-Class	STEERING COLUMN	CLS 280	BOSCH MRM
 219 CLS-Class	STEERING COLUMN	CLS 300	BOSCH MRM
 219 CLS-Class	STEERING COLUMN	CLS 320 CDI	BOSCH MRM
 219 CLS-Class	STEERING COLUMN	CLS 350	BOSCH MRM
 219 CLS-Class	STEERING COLUMN	CLS 350 CDI	BOSCH MRM
 219 CLS-Class	STEERING COLUMN	CLS 350 CGI	BOSCH MRM
 219 CLS-Class	STEERING COLUMN	CLS 500	BOSCH MRM
 219 CLS-Class	STEERING COLUMN	CLS 55 AMG	BOSCH MRM
 219 CLS-Class	STEERING COLUMN	CLS 63 AMG	BOSCH MRM
 220 S-Class	ABS + TRACT. CONT	S 280 (.-99)	BOSCH ASR/ABD BAS/ETS
 220 S-Class	ABS + TRACT. CONT	S 320 (.-99)	BOSCH ASR/ABD BAS/ETS
 220 S-Class	ABS + TRACT. CONT	S 350 (.-99)	BOSCH ASR/ABD BAS/ETS
 220 S-Class	ABS + TRACT. CONT	S 400 CDI (.-99)	BOSCH ASR/ABD BAS/ETS
 220 S-Class	ABS + TRACT. CONT	S 430 (.-99)	BOSCH ASR/ABD BAS/ETS
 220 S-Class	ABS + TRACT. CONT	S 500 (.-99)	BOSCH ASR/ABD BAS/ETS
 220 S-Class	ABS + TRACT. CONT	S 55 AMG (.-99)	BOSCH ASR/ABD BAS/ETS
 220 S-Class	ABS + TRACT. CONT	S 55 AMG Kompr. (.-99)	BOSCH ASR/ABD BAS/ETS
 220 S-Class	ABS + TRACT. CONT	S 600 (.-99)	BOSCH ASR/ABD BAS/ETS
 220 S-Class	ABS + TRACT. CONT	S 63 AMG (.-99)	BOSCH ASR/ABD BAS/ETS
 220 S-Class	ABS + TRACT. CONT	S 65 AMG (.-99)	BOSCH ASR/ABD BAS/ETS
 220 S-Class	AUTOM. TRANSMISSI	S 280 (.-99)	BOSCH ETC 6
 220 S-Class	AUTOM. TRANSMISSI	S 320 (.-99)	BOSCH ETC 6
 220 S-Class	AUTOM. TRANSMISSI	S 350 (.-99)	BOSCH ETC 6
 220 S-Class	AUTOM. TRANSMISSI	S 400 CDI (.-99)	BOSCH ETC 6
 220 S-Class	AUTOM. TRANSMISSI	S 430 (.-99)	BOSCH ETC 6
 220 S-Class	AUTOM. TRANSMISSI	S 500 (.-99)	BOSCH ETC 6
 220 S-Class	AUTOM. TRANSMISSI	S 55 AMG (.-99)	BOSCH ETC 6
 220 S-Class	AUTOM. TRANSMISSI	S 55 AMG Kompr. (.-99)	BOSCH ETC 6
 220 S-Class	AUTOM. TRANSMISSI	S 600 (.-99)	BOSCH ETC 6
 220 S-Class	AUTOM. TRANSMISSI	S 63 AMG (.-99)	BOSCH ETC 6
 220 S-Class	AUTOM. TRANSMISSI	S 65 AMG (.-99)	BOSCH ETC 6
 220 S-Class	ENGINE MANAGEME	S 280 (01-05)	EOBD
 220 S-Class	ENGINE MANAGEME	S 320 CDI (02-..)	BOSCH EDC 15 Common Rail CDI 3
 220 S-Class	ENGINE MANAGEME	S 320 CDI 613 (00-01)	EOBD
 220 S-Class	ENGINE MANAGEME	S 320 CDI 613 (98-00)	BOSCH EDC 15 C4 Common Rail
 220 S-Class	ENGINE MANAGEME	S 320 CDI 613 (98-00)	BOSCH EDC 15 C6 Common Rail
 220 S-Class	ENGINE MANAGEME	S 350 (01-05)	EOBD
 220 S-Class	ENGINE MANAGEME	S 400 CDI 628 (98-00)	BOSCH EDC 15 C4 Common Rail
 220 S-Class	ENGINE MANAGEME	S 400 CDI 628 (98-00)	BOSCH EDC 15 C6 Common Rail
 220 S-Class	ENGINE MANAGEME	S 55 AMG (01-05)	EOBD
 220 S-Class	ENGINE MANAGEME	S 55 AMG Kompr. (01-05)	EOBD
 220 S-Class	ENGINE MANAGEME	S 600 (01-05)	EOBD
 220 S-Class	ENGINE MANAGEME	S 63 AMG (01-05)	EOBD
 220 S-Class	ENGINE MANAGEME	S 65 AMG (01-05)	EOBD
 220 S-Class	MAINTENANCE	S 280 (99-03)	VDO/Marelli MANUAL
 220 S-Class	MAINTENANCE	S 320 (99-03)	VDO/Marelli MANUAL
 220 S-Class	MAINTENANCE	S 320 CDI (99-03)	VDO/Marelli MANUAL
 220 S-Class	MAINTENANCE	S 350 (99-03)	VDO/Marelli MANUAL
 220 S-Class	MAINTENANCE	S 400 CDI (99-03)	VDO/Marelli MANUAL
 220 S-Class	MAINTENANCE	S 430 (99-03)	VDO/Marelli MANUAL
 220 S-Class	MAINTENANCE	S 500 (99-03)	VDO/Marelli MANUAL
 220 S-Class	MAINTENANCE	S 55 AMG (99-03)	VDO/Marelli MANUAL
 220 S-Class	MAINTENANCE	S 55 AMG Kompr. (99-03)	VDO/Marelli MANUAL
 220 S-Class	MAINTENANCE	S 600 (99-03)	VDO/Marelli MANUAL
 220 S-Class	MAINTENANCE	S 63 AMG (99-03)	VDO/Marelli MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 220 S-Class	MAINTENANCE	S 65 AMG (99-03)	VDO/Marelli MANUAL
 220 S-Class	SERVICE LIGHT RES	S 280 (99-03)	VDO/Marelli MANUAL
 220 S-Class	SERVICE LIGHT RES	S 320 (99-03)	VDO/Marelli MANUAL
 220 S-Class	SERVICE LIGHT RES	S 320 CDI (99-03)	VDO/Marelli MANUAL
 220 S-Class	SERVICE LIGHT RES	S 350 (99-03)	VDO/Marelli MANUAL
 220 S-Class	SERVICE LIGHT RES	S 400 CDI (99-03)	VDO/Marelli MANUAL
 220 S-Class	SERVICE LIGHT RES	S 430 (99-03)	VDO/Marelli MANUAL
 220 S-Class	SERVICE LIGHT RES	S 500 (99-03)	VDO/Marelli MANUAL
 220 S-Class	SERVICE LIGHT RES	S 55 AMG (99-03)	VDO/Marelli MANUAL
 220 S-Class	SERVICE LIGHT RES	S 55 AMG Kompr. (99-03)	VDO/Marelli MANUAL
 220 S-Class	SERVICE LIGHT RES	S 600 (99-03)	VDO/Marelli MANUAL
 220 S-Class	SERVICE LIGHT RES	S 63 AMG (99-03)	VDO/Marelli MANUAL
 220 S-Class	SERVICE LIGHT RES	S 65 AMG (99-03)	VDO/Marelli MANUAL
 221 S-Class	AUTOM. TRANSMISSI	250 CDI BlueEfficiency (06-..)	Siemens EGS 53
 221 S-Class	AUTOM. TRANSMISSI	350 BlueEfficiency (06-..)	Siemens EGS 53
 221 S-Class	AUTOM. TRANSMISSI	350 CDI BlueEfficiency (06-..)	Siemens EGS 53
 221 S-Class	AUTOM. TRANSMISSI	400 Hybrid (06-..)	Siemens EGS 53
 221 S-Class	AUTOM. TRANSMISSI	S 320 CDI (06-..)	Siemens EGS 53
 221 S-Class	AUTOM. TRANSMISSI	S 350 (06-..)	Siemens EGS 53
 221 S-Class	AUTOM. TRANSMISSI	S 420 CDI (06-..)	Siemens EGS 53
 221 S-Class	AUTOM. TRANSMISSI	S 450 (06-..)	Siemens EGS 53
 221 S-Class	AUTOM. TRANSMISSI	S 500 (06-..)	Siemens EGS 53
 221 S-Class	AUTOM. TRANSMISSI	S 600 (06-..)	Siemens EGS 53
 221 S-Class	AUTOM. TRANSMISSI	S 65 AMG (06-..)	Siemens EGS 53
 221 S-Class	ENGINE MANAGEME	250 CDI BlueEfficiency (05-..)	EOBD
 221 S-Class	ENGINE MANAGEME	350 BlueEfficiency (05-..)	EOBD
 221 S-Class	ENGINE MANAGEME	350 CDI BlueEfficiency (05-..)	EOBD
 221 S-Class	ENGINE MANAGEME	400 Hybrid (05-..)	EOBD
 221 S-Class	ENGINE MANAGEME	S 320 CDI (05-..)	EOBD
 221 S-Class	ENGINE MANAGEME	S 350 (05-..)	EOBD
 221 S-Class	ENGINE MANAGEME	S 420 CDI (05-..)	EOBD
 221 S-Class	ENGINE MANAGEME	S 450 (05-..)	EOBD
 221 S-Class	ENGINE MANAGEME	S 500 (05-..)	EOBD
 221 S-Class	ENGINE MANAGEME	S 600 (05-..)	EOBD
 221 S-Class	ENGINE MANAGEME	S 63 AMG (05-..)	EOBD
 221 S-Class	ENGINE MANAGEME	S 65 AMG (05-..)	EOBD
 221 S-Class	MAINTENANCE	250 CDI BlueEfficiency (05-..)	VDO MANUAL
 221 S-Class	MAINTENANCE	350 BlueEfficiency (05-..)	VDO MANUAL
 221 S-Class	MAINTENANCE	350 CDI BlueEfficiency (05-..)	VDO MANUAL
 221 S-Class	MAINTENANCE	400 Hybrid (05-..)	VDO MANUAL
 221 S-Class	MAINTENANCE	S 320 CDI (05-..)	VDO MANUAL
 221 S-Class	MAINTENANCE	S 350 (05-..)	VDO MANUAL
 221 S-Class	MAINTENANCE	S 420 CDI (05-..)	VDO MANUAL
 221 S-Class	MAINTENANCE	S 450 (05-..)	VDO MANUAL
 221 S-Class	MAINTENANCE	S 500 (05-..)	VDO MANUAL
 221 S-Class	MAINTENANCE	S 600 (05-..)	VDO MANUAL
 221 S-Class	MAINTENANCE	S 63 AMG (05-..)	VDO MANUAL
 221 S-Class	MAINTENANCE	S 65 AMG (05-..)	VDO MANUAL
 221 S-Class	SERVICE LIGHT RES	250 CDI BlueEfficiency (05-..)	VDO MANUAL
 221 S-Class	SERVICE LIGHT RES	350 BlueEfficiency (05-..)	VDO MANUAL
 221 S-Class	SERVICE LIGHT RES	350 CDI BlueEfficiency (05-..)	VDO MANUAL
 221 S-Class	SERVICE LIGHT RES	400 Hybrid (05-..)	VDO MANUAL
 221 S-Class	SERVICE LIGHT RES	S 320 CDI (05-..)	VDO MANUAL
 221 S-Class	SERVICE LIGHT RES	S 350 (05-..)	VDO MANUAL
 221 S-Class	SERVICE LIGHT RES	S 420 CDI (05-..)	VDO MANUAL
 221 S-Class	SERVICE LIGHT RES	S 450 (05-..)	VDO MANUAL
 221 S-Class	SERVICE LIGHT RES	S 500 (05-..)	VDO MANUAL
 221 S-Class	SERVICE LIGHT RES	S 600 (05-..)	VDO MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 221 S-Class	SERVICE LIGHT RES	S 63 AMG (05-..)	VDO MANUAL
 221 S-Class	SERVICE LIGHT RES	S 65 AMG (05-..)	VDO MANUAL
 245 B-Class	ABS + TRACT. CONT	B 150 (05-..)	BOSCH ABS/ESP
 245 B-Class	ABS + TRACT. CONT	B 160 (05-..)	BOSCH ABS/ESP
 245 B-Class	ABS + TRACT. CONT	B 170 (05-..)	BOSCH ABS/ESP
 245 B-Class	ABS + TRACT. CONT	B 180 (05-..)	BOSCH ABS/ESP
 245 B-Class	ABS + TRACT. CONT	B 180 CDI (05-..)	BOSCH ABS/ESP
 245 B-Class	ABS + TRACT. CONT	B 200 (05-..)	BOSCH ABS/ESP
 245 B-Class	ABS + TRACT. CONT	B 200 CDI (05-..)	BOSCH ABS/ESP
 245 B-Class	ABS + TRACT. CONT	B 200 T (05-..)	BOSCH ABS/ESP
 245 B-Class	AIRBAG	B 150 (05-..)	TRW AirBag
 245 B-Class	AIRBAG	B 160 (05-..)	TRW AirBag
 245 B-Class	AIRBAG	B 170 (05-..)	TRW AirBag
 245 B-Class	AIRBAG	B 180 (05-..)	TRW AirBag
 245 B-Class	AIRBAG	B 180 CDI (05-..)	TRW AirBag
 245 B-Class	AIRBAG	B 200 (05-..)	TRW AirBag
 245 B-Class	AIRBAG	B 200 CDI (05-..)	TRW AirBag
 245 B-Class	AIRBAG	B 200 T (05-..)	TRW AirBag
 245 B-Class	AUTOM. TRANSMISSI	B 150	DELPHI EWM Selector Lever
 245 B-Class	AUTOM. TRANSMISSI	B 160	DELPHI EWM Selector Lever
 245 B-Class	AUTOM. TRANSMISSI	B 170	DELPHI EWM Selector Lever
 245 B-Class	AUTOM. TRANSMISSI	B 180	DELPHI EWM Selector Lever
 245 B-Class	AUTOM. TRANSMISSI	B 180 CDI	DELPHI EWM Selector Lever
 245 B-Class	AUTOM. TRANSMISSI	B 200	DELPHI EWM Selector Lever
 245 B-Class	AUTOM. TRANSMISSI	B 200 CDI	DELPHI EWM Selector Lever
 245 B-Class	AUTOM. TRANSMISSI	B 200 T	DELPHI EWM Selector Lever
 245 B-Class	CHASSIS NETWORK	B 150 (05-..)	SAM-V
 245 B-Class	CHASSIS NETWORK	B 160 (05-..)	SAM-V
 245 B-Class	CHASSIS NETWORK	B 170 (05-..)	SAM-V
 245 B-Class	CHASSIS NETWORK	B 180 (05-..)	SAM-V
 245 B-Class	CHASSIS NETWORK	B 180 CDI (05-..)	SAM-V
 245 B-Class	CHASSIS NETWORK	B 200 (05-..)	SAM-V
 245 B-Class	CHASSIS NETWORK	B 200 CDI (05-..)	SAM-V
 245 B-Class	CHASSIS NETWORK	B 200 T (05-..)	SAM-V
 245 B-Class	CLIMA	B 150 (05-..)	VALEO Klimautom.
 245 B-Class	CLIMA	B 160 (05-..)	VALEO Klimautom.
 245 B-Class	CLIMA	B 170 (05-..)	VALEO Klimautom.
 245 B-Class	CLIMA	B 180 (05-..)	VALEO Klimautom.
 245 B-Class	CLIMA	B 180 CDI (05-..)	VALEO Klimautom.
 245 B-Class	CLIMA	B 200 (05-..)	VALEO Klimautom.
 245 B-Class	CLIMA	B 200 CDI (05-..)	VALEO Klimautom.
 245 B-Class	CLIMA	B 200 T (05-..)	VALEO Klimautom.
 245 B-Class	DASHBOARD	B 150 (..-05)	BOSCH KIW
 245 B-Class	DASHBOARD	B 150 (06-..)	BOSCH KIW + Service
 245 B-Class	DASHBOARD	B 160 (06-..)	BOSCH KIW + Service
 245 B-Class	DASHBOARD	B 170 (..-05)	BOSCH KIW
 245 B-Class	DASHBOARD	B 170 (06-..)	BOSCH KIW + Service
 245 B-Class	DASHBOARD	B 180 (06-..)	BOSCH KIW + Service
 245 B-Class	DASHBOARD	B 180 CDI (..-05)	BOSCH KIW
 245 B-Class	DASHBOARD	B 180 CDI (06-..)	BOSCH KIW + Service
 245 B-Class	DASHBOARD	B 200 (..-05)	BOSCH KIW
 245 B-Class	DASHBOARD	B 200 (06-..)	BOSCH KIW + Service
 245 B-Class	DASHBOARD	B 200 CDI (..-05)	BOSCH KIW
 245 B-Class	DASHBOARD	B 200 CDI (06-..)	BOSCH KIW + Service
 245 B-Class	DASHBOARD	B 200 T (..-05)	BOSCH KIW
 245 B-Class	DASHBOARD	B 200 T (06-..)	BOSCH KIW + Service
 245 B-Class	ELECTRIC STEERING	B 150 (05-..)	KOYO EPS
 245 B-Class	ELECTRIC STEERING	B 160 (05-..)	KOYO EPS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 245 B-Class	ELECTRIC STEERING	B 170 (05-..)	KOYO EPS
 245 B-Class	ELECTRIC STEERING	B 180 (05-..)	KOYO EPS
 245 B-Class	ELECTRIC STEERING	B 180 CDI (05-..)	KOYO EPS
 245 B-Class	ELECTRIC STEERING	B 200 (05-..)	KOYO EPS
 245 B-Class	ELECTRIC STEERING	B 200 CDI (05-..)	KOYO EPS
 245 B-Class	ELECTRIC STEERING	B 200 T (05-..)	KOYO EPS
 245 B-Class	ENGINE MANAGEME	B 150 (05-..)	SIEMENS SIM 266
 245 B-Class	ENGINE MANAGEME	B 160 (09-..)	EOBD
 245 B-Class	ENGINE MANAGEME	B 170 (05-..)	SIEMENS MPI M60G70
 245 B-Class	ENGINE MANAGEME	B 180 (09-..)	EOBD
 245 B-Class	ENGINE MANAGEME	B 180 CDI (05-..)	BOSCH EDC Common Rail
 245 B-Class	ENGINE MANAGEME	B 200 (05-..)	EOBD
 245 B-Class	ENGINE MANAGEME	B 200 CDI (05-..)	BOSCH EDC Common Rail
 245 B-Class	ENGINE MANAGEME	B 200 T (05-..)	EOBD
 245 B-Class	MAINTENANCE	B 150	MANUAL
 245 B-Class	MAINTENANCE	B 150 (05-..)	KOYO EPS
 245 B-Class	MAINTENANCE	B 150 (06-..)	BOSCH KIW + Service
 245 B-Class	MAINTENANCE	B 150 (06-..)	BOSCH KIW + Service
 245 B-Class	MAINTENANCE	B 150 (06-..)	BOSCH KIW + Service
 245 B-Class	MAINTENANCE	B 150 (06-..)	BOSCH KIW + Service
 245 B-Class	MAINTENANCE	B 160	MANUAL
 245 B-Class	MAINTENANCE	B 160 (05-..)	KOYO EPS
 245 B-Class	MAINTENANCE	B 160 (06-..)	BOSCH KIW + Service
 245 B-Class	MAINTENANCE	B 160 (06-..)	BOSCH KIW + Service
 245 B-Class	MAINTENANCE	B 160 (06-..)	BOSCH KIW + Service
 245 B-Class	MAINTENANCE	B 160 (06-..)	BOSCH KIW + Service
 245 B-Class	MAINTENANCE	B 170	MANUAL
 245 B-Class	MAINTENANCE	B 170 (05-..)	KOYO EPS
 245 B-Class	MAINTENANCE	B 170 (06-..)	BOSCH KIW + Service
 245 B-Class	MAINTENANCE	B 170 (06-..)	BOSCH KIW + Service
 245 B-Class	MAINTENANCE	B 170 (06-..)	BOSCH KIW + Service
 245 B-Class	MAINTENANCE	B 170 (06-..)	BOSCH KIW + Service
 245 B-Class	MAINTENANCE	B 180	MANUAL
 245 B-Class	MAINTENANCE	B 180 (05-..)	KOYO EPS
 245 B-Class	MAINTENANCE	B 180 (06-..)	BOSCH KIW + Service
 245 B-Class	MAINTENANCE	B 180 (06-..)	BOSCH KIW + Service
 245 B-Class	MAINTENANCE	B 180 (06-..)	BOSCH KIW + Service
 245 B-Class	MAINTENANCE	B 180 (06-..)	BOSCH KIW + Service
 245 B-Class	MAINTENANCE	B 180 CDI	MANUAL
 245 B-Class	MAINTENANCE	B 180 CDI (05-..)	KOYO EPS
 245 B-Class	MAINTENANCE	B 180 CDI (06-..)	BOSCH KIW + Service
 245 B-Class	MAINTENANCE	B 180 CDI (06-..)	BOSCH KIW + Service
 245 B-Class	MAINTENANCE	B 180 CDI (06-..)	BOSCH KIW + Service
 245 B-Class	MAINTENANCE	B 180 CDI (06-..)	BOSCH KIW + Service
 245 B-Class	MAINTENANCE	B 200	MANUAL
 245 B-Class	MAINTENANCE	B 200 (05-..)	KOYO EPS
 245 B-Class	MAINTENANCE	B 200 (06-..)	BOSCH KIW + Service
 245 B-Class	MAINTENANCE	B 200 (06-..)	BOSCH KIW + Service
 245 B-Class	MAINTENANCE	B 200 (06-..)	BOSCH KIW + Service
 245 B-Class	MAINTENANCE	B 200 (06-..)	BOSCH KIW + Service
 245 B-Class	MAINTENANCE	B 200 CDI	MANUAL
 245 B-Class	MAINTENANCE	B 200 CDI (05-..)	KOYO EPS
 245 B-Class	MAINTENANCE	B 200 CDI (06-..)	BOSCH KIW + Service
 245 B-Class	MAINTENANCE	B 200 CDI (06-..)	BOSCH KIW + Service
 245 B-Class	MAINTENANCE	B 200 CDI (06-..)	BOSCH KIW + Service
 245 B-Class	MAINTENANCE	B 200 CDI (06-..)	BOSCH KIW + Service
 245 B-Class	MAINTENANCE	B 200 T	MANUAL
 245 B-Class	MAINTENANCE	B 200 T (05-..)	KOYO EPS

Systems supported by ECUREADER / ECUDECODER (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 245 B-Class	MAINTENANCE	B 200 T (06-..)	BOSCH KIW + Service
 245 B-Class	MAINTENANCE	B 200 T (06-..)	BOSCH KIW + Service
 245 B-Class	MAINTENANCE	B 200 T (06-..)	BOSCH KIW + Service
 245 B-Class	MAINTENANCE	B 200 T (06-..)	BOSCH KIW + Service
 245 B-Class	SERVICE LIGHT RES	B 150	MANUAL
 245 B-Class	SERVICE LIGHT RES	B 160	MANUAL
 245 B-Class	SERVICE LIGHT RES	B 170	MANUAL
 245 B-Class	SERVICE LIGHT RES	B 180	MANUAL
 245 B-Class	SERVICE LIGHT RES	B 180 CDI	MANUAL
 245 B-Class	SERVICE LIGHT RES	B 200	MANUAL
 245 B-Class	SERVICE LIGHT RES	B 200 CDI	MANUAL
 245 B-Class	SERVICE LIGHT RES	B 200 T	MANUAL
 245 B-Class	SWITCHLIGHT MODU	B 150 (05-..)	VALEO
 245 B-Class	SWITCHLIGHT MODU	B 160 (05-..)	VALEO
 245 B-Class	SWITCHLIGHT MODU	B 170 (05-..)	VALEO
 245 B-Class	SWITCHLIGHT MODU	B 180 (05-..)	VALEO
 245 B-Class	SWITCHLIGHT MODU	B 180 CDI (05-..)	VALEO
 245 B-Class	SWITCHLIGHT MODU	B 200 (05-..)	VALEO
 245 B-Class	SWITCHLIGHT MODU	B 200 CDI (05-..)	VALEO
 245 B-Class	SWITCHLIGHT MODU	B 200 T (05-..)	VALEO
 251 R-Class	ABS + TRACT. CONT	R 280	TEVES ESP
 251 R-Class	ABS + TRACT. CONT	R 280 CDI	TEVES ESP
 251 R-Class	ABS + TRACT. CONT	R 320 CDI	TEVES ESP
 251 R-Class	ABS + TRACT. CONT	R 350	TEVES ESP
 251 R-Class	ABS + TRACT. CONT	R 500	TEVES ESP
 251 R-Class	ABS + TRACT. CONT	R 63 AMG	TEVES ESP
 251 R-Class	AIRBAG	R 280	BOSCH SRS
 251 R-Class	AIRBAG	R 280 CDI	BOSCH SRS
 251 R-Class	AIRBAG	R 320 CDI	BOSCH SRS
 251 R-Class	AIRBAG	R 350	BOSCH SRS
 251 R-Class	AIRBAG	R 500	BOSCH SRS
 251 R-Class	AIRBAG	R 63 AMG	BOSCH SRS
 251 R-Class	AUTOM. TRANSMISSI	R 280	Siemens EGS 7 Gtronic 722.9
 251 R-Class	AUTOM. TRANSMISSI	R 280 CDI	Siemens EGS 7 Gtronic 722.9
 251 R-Class	AUTOM. TRANSMISSI	R 320 CDI	Siemens EGS 7 Gtronic 722.9
 251 R-Class	AUTOM. TRANSMISSI	R 350	Siemens EGS 7 Gtronic 722.9
 251 R-Class	AUTOM. TRANSMISSI	R 500	Siemens EGS 7 Gtronic 722.9
 251 R-Class	AUTOM. TRANSMISSI	R 63 AMG	Siemens EGS 7 Gtronic 722.9
 251 R-Class	CLIMA	R 280	Hella KLA Klimautomatik
 251 R-Class	CLIMA	R 280 CDI	Hella KLA Klimautomatik
 251 R-Class	CLIMA	R 320 CDI	Hella KLA Klimautomatik
 251 R-Class	CLIMA	R 350	Hella KLA Klimautomatik
 251 R-Class	CLIMA	R 500	Hella KLA Klimautomatik
 251 R-Class	CLIMA	R 63 AMG	Hella KLA Klimautomatik
 251 R-Class	DASHBOARD	R 280	VDO KI
 251 R-Class	DASHBOARD	R 280 CDI	VDO KI
 251 R-Class	DASHBOARD	R 320 CDI	VDO KI
 251 R-Class	DASHBOARD	R 350	VDO KI
 251 R-Class	DASHBOARD	R 500	VDO KI
 251 R-Class	DASHBOARD	R 63 AMG	VDO KI
 251 R-Class	ENGINE MANAGEME	R 280	EOBD
 251 R-Class	ENGINE MANAGEME	R 280 CDI	EOBD
 251 R-Class	ENGINE MANAGEME	R 320 CDI (07-..)	BOSCH EDC Common Rail CDI 4
 251 R-Class	ENGINE MANAGEME	R 350	EOBD
 251 R-Class	ENGINE MANAGEME	R 500	EOBD
 251 R-Class	ENGINE MANAGEME	R 63 AMG	EOBD
 251 R-Class	GEARBOX MANAGEM	R 280	Siemens ISM
 251 R-Class	GEARBOX MANAGEM	R 280 CDI	Siemens ISM

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 251 R-Class	GEARBOX MANAGEM	R 320 CDI	Siemens ISM
 251 R-Class	GEARBOX MANAGEM	R 350	Siemens ISM
 251 R-Class	GEARBOX MANAGEM	R 500	Siemens ISM
 251 R-Class	GEARBOX MANAGEM	R 63 AMG	Siemens ISM
 251 R-Class	MAINTENANCE	R 280	TEVES ESP
 251 R-Class	MAINTENANCE	R 280	VDO Assyst Plus
 251 R-Class	MAINTENANCE	R 280	VDO Assyst Plus
 251 R-Class	MAINTENANCE	R 280 CDI	TEVES ESP
 251 R-Class	MAINTENANCE	R 280 CDI	VDO Assyst Plus
 251 R-Class	MAINTENANCE	R 280 CDI	VDO Assyst Plus
 251 R-Class	MAINTENANCE	R 320 CDI	TEVES ESP
 251 R-Class	MAINTENANCE	R 320 CDI	VDO Assyst Plus
 251 R-Class	MAINTENANCE	R 320 CDI	VDO Assyst Plus
 251 R-Class	MAINTENANCE	R 320 CDI (07-..)	BOSCH EDC Common Rail CDI 4
 251 R-Class	MAINTENANCE	R 320 CDI (07-..)	BOSCH EDC Common Rail CDI 4
 251 R-Class	MAINTENANCE	R 350	TEVES ESP
 251 R-Class	MAINTENANCE	R 350	VDO Assyst Plus
 251 R-Class	MAINTENANCE	R 350	VDO Assyst Plus
 251 R-Class	MAINTENANCE	R 500	TEVES ESP
 251 R-Class	MAINTENANCE	R 500	VDO Assyst Plus
 251 R-Class	MAINTENANCE	R 500	VDO Assyst Plus
 251 R-Class	MAINTENANCE	R 500	VDO Assyst Plus
 251 R-Class	MAINTENANCE	R 63 AMG	TEVES ESP
 251 R-Class	MAINTENANCE	R 63 AMG	VDO Assyst Plus
 251 R-Class	MAINTENANCE	R 63 AMG	VDO Assyst Plus
 251 R-Class	SERVICE LIGHT RES	R 280	VDO Assyst
 251 R-Class	SERVICE LIGHT RES	R 280	VDO Assyst Plus
 251 R-Class	SERVICE LIGHT RES	R 280 CDI	VDO Assyst
 251 R-Class	SERVICE LIGHT RES	R 280 CDI	VDO Assyst Plus
 251 R-Class	SERVICE LIGHT RES	R 320 CDI	VDO Assyst
 251 R-Class	SERVICE LIGHT RES	R 320 CDI	VDO Assyst Plus
 251 R-Class	SERVICE LIGHT RES	R 350	VDO Assyst
 251 R-Class	SERVICE LIGHT RES	R 350	VDO Assyst Plus
 251 R-Class	SERVICE LIGHT RES	R 500	VDO Assyst
 251 R-Class	SERVICE LIGHT RES	R 500	VDO Assyst Plus
 251 R-Class	SERVICE LIGHT RES	R 500	VDO Assyst Plus
 251 R-Class	SERVICE LIGHT RES	R 63 AMG	VDO Assyst
 251 R-Class	SERVICE LIGHT RES	R 63 AMG	VDO Assyst Plus
 251 R-Class	STEERING COLUMN	R 280	KOSTAL MRM 7
 251 R-Class	STEERING COLUMN	R 280 CDI	KOSTAL MRM 7
 251 R-Class	STEERING COLUMN	R 320 CDI	KOSTAL MRM 7
 251 R-Class	STEERING COLUMN	R 350	KOSTAL MRM 7
 251 R-Class	STEERING COLUMN	R 500	KOSTAL MRM 7
 251 R-Class	STEERING COLUMN	R 63 AMG	KOSTAL MRM 7
 251 R-Class	SUSPENSION CONTR	R 280	Temic AIRmatic
 251 R-Class	SUSPENSION CONTR	R 280 CDI	Temic AIRmatic
 251 R-Class	SUSPENSION CONTR	R 320 CDI	Temic AIRmatic
 251 R-Class	SUSPENSION CONTR	R 350	Temic AIRmatic
 251 R-Class	SUSPENSION CONTR	R 500	Temic AIRmatic
 251 R-Class	SUSPENSION CONTR	R 63 AMG	Temic AIRmatic
 463 G-Class	ABS + TRACT. CONT	230 GE	BOSCH ETS 5
 463 G-Class	ABS + TRACT. CONT	230 GE (.-99)	BOSCH ASR/ABD BAS/ETS
 463 G-Class	ABS + TRACT. CONT	250 GD	BOSCH ETS 5
 463 G-Class	ABS + TRACT. CONT	250 GD (.-99)	BOSCH ASR/ABD BAS/ETS
 463 G-Class	ABS + TRACT. CONT	300 GD	BOSCH ETS 5
 463 G-Class	ABS + TRACT. CONT	300 GD (.-99)	BOSCH ASR/ABD BAS/ETS
 463 G-Class	ABS + TRACT. CONT	300 GE	BOSCH ETS 5
 463 G-Class	ABS + TRACT. CONT	300 GE (.-99)	BOSCH ASR/ABD BAS/ETS
463 G-Class	ABS + TRACT. CONT	350 G TurboD	BOSCH ETS 5
463 G-Class	ABS + TRACT. CONT	350 G TurboD (.-99)	BOSCH ASR/ABD BAS/ETS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 463 G-Class	ABS + TRACT. CONT	G 270 CDI	BOSCH ETS 5
 463 G-Class	ABS + TRACT. CONT	G 270 CDI (...99)	BOSCH ASR/ABD BAS/ETS
 463 G-Class	ABS + TRACT. CONT	G 300 TD	BOSCH ETS 5
 463 G-Class	ABS + TRACT. CONT	G 300 TD (...99)	BOSCH ASR/ABD BAS/ETS
 463 G-Class	ABS + TRACT. CONT	G 320	BOSCH ETS 5
 463 G-Class	ABS + TRACT. CONT	G 320 (...99)	BOSCH ASR/ABD BAS/ETS
 463 G-Class	ABS + TRACT. CONT	G 320 CDI	BOSCH ETS 5
 463 G-Class	ABS + TRACT. CONT	G 320 CDI (...99)	BOSCH ASR/ABD BAS/ETS
 463 G-Class	ABS + TRACT. CONT	G 36 AMG	BOSCH ETS 5
 463 G-Class	ABS + TRACT. CONT	G 36 AMG (...99)	BOSCH ASR/ABD BAS/ETS
 463 G-Class	ABS + TRACT. CONT	G 400 CDI	BOSCH ETS 5
 463 G-Class	ABS + TRACT. CONT	G 400 CDI (...99)	BOSCH ASR/ABD BAS/ETS
 463 G-Class	ABS + TRACT. CONT	G 500	BOSCH ETS 5
 463 G-Class	ABS + TRACT. CONT	G 500 (...99)	BOSCH ASR/ABD BAS/ETS
 463 G-Class	ABS + TRACT. CONT	G 55 AMG	BOSCH ETS 5
 463 G-Class	ABS + TRACT. CONT	G 55 AMG (...99)	BOSCH ASR/ABD BAS/ETS
 463 G-Class	AUTOM. TRANSMISSI	230 GE (...99)	BOSCH ETC 6
 463 G-Class	AUTOM. TRANSMISSI	250 GD (...99)	BOSCH ETC 6
 463 G-Class	AUTOM. TRANSMISSI	300 GD (...99)	BOSCH ETC 6
 463 G-Class	AUTOM. TRANSMISSI	300 GE (...99)	BOSCH ETC 6
 463 G-Class	AUTOM. TRANSMISSI	350 Bluetech (06-..)	Siemens EGS 53
 463 G-Class	AUTOM. TRANSMISSI	350 CDI (06-..)	Siemens EGS 53
 463 G-Class	AUTOM. TRANSMISSI	350 G TurboD (...99)	BOSCH ETC 6
 463 G-Class	AUTOM. TRANSMISSI	500 (06-..)	Siemens EGS 53
 463 G-Class	AUTOM. TRANSMISSI	63 AMG (06-..)	Siemens EGS 53
 463 G-Class	AUTOM. TRANSMISSI	65 AMG (06-..)	Siemens EGS 53
 463 G-Class	AUTOM. TRANSMISSI	G 270 CDI (...99)	BOSCH ETC 6
 463 G-Class	AUTOM. TRANSMISSI	G 300 TD (...99)	BOSCH ETC 6
 463 G-Class	AUTOM. TRANSMISSI	G 320 (...99)	BOSCH ETC 6
 463 G-Class	AUTOM. TRANSMISSI	G 320 CDI (...99)	BOSCH ETC 6
 463 G-Class	AUTOM. TRANSMISSI	G 320 CDI (06-..)	Siemens EGS 53
 463 G-Class	AUTOM. TRANSMISSI	G 36 AMG (...99)	BOSCH ETC 6
 463 G-Class	AUTOM. TRANSMISSI	G 400 CDI (...99)	BOSCH ETC 6
 463 G-Class	AUTOM. TRANSMISSI	G 500 (...99)	BOSCH ETC 6
 463 G-Class	AUTOM. TRANSMISSI	G 55 AMG (...99)	BOSCH ETC 6
 463 G-Class	AUTOM. TRANSMISSI	G 55 AMG (06-..)	Siemens EGS 53
 463 G-Class	CRUISE CONTROL	230 GE	BOSCH/VDO EA/CC/ISC
 463 G-Class	CRUISE CONTROL	250 GD	BOSCH/VDO EA/CC/ISC
 463 G-Class	CRUISE CONTROL	300 GD	BOSCH/VDO EA/CC/ISC
 463 G-Class	CRUISE CONTROL	300 GE	BOSCH/VDO EA/CC/ISC
 463 G-Class	CRUISE CONTROL	350 G TurboD	BOSCH/VDO EA/CC/ISC
 463 G-Class	CRUISE CONTROL	G 270 CDI	BOSCH/VDO EA/CC/ISC
 463 G-Class	CRUISE CONTROL	G 300 TD	BOSCH/VDO EA/CC/ISC
 463 G-Class	CRUISE CONTROL	G 320	BOSCH/VDO EA/CC/ISC
 463 G-Class	CRUISE CONTROL	G 320 CDI	BOSCH/VDO EA/CC/ISC
 463 G-Class	CRUISE CONTROL	G 36 AMG	BOSCH/VDO EA/CC/ISC
 463 G-Class	CRUISE CONTROL	G 400 CDI	BOSCH/VDO EA/CC/ISC
 463 G-Class	CRUISE CONTROL	G 500	BOSCH/VDO EA/CC/ISC
 463 G-Class	CRUISE CONTROL	G 55 AMG	BOSCH/VDO EA/CC/ISC
 463 G-Class	DASHBOARD	230 GE (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	DASHBOARD	250 GD (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	DASHBOARD	300 GD (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	DASHBOARD	300 GE (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	DASHBOARD	G 270 CDI (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	DASHBOARD	G 320 (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	DASHBOARD	G 320 CDI (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	DASHBOARD	G 400 CDI (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	DASHBOARD	G 500 (00-03)	VDO Kombinstrum. 1.0

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 463 G-Class	DASHBOARD	G 55 AMG (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	ENGINE MANAGEME	G 320 CDI (02-..)	BOSCH EDC 15 Common Rail CDI 3
 463 G-Class	ENGINE MANAGEME	G 400 CDI 628 (98-00)	BOSCH EDC 15 C4 Common Rail
 463 G-Class	ENGINE MANAGEME	G 400 CDI 628 (98-00)	BOSCH EDC 15 C6 Common Rail
 463 G-Class	MAINTENANCE	230 GE (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	230 GE (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	230 GE (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	230 GE (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	230 GE (99-03)	VDO/Marelli MANUAL
 463 G-Class	MAINTENANCE	250 GD (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	250 GD (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	250 GD (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	250 GD (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	250 GD (99-03)	VDO/Marelli MANUAL
 463 G-Class	MAINTENANCE	300 GD (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	300 GD (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	300 GD (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	300 GD (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	300 GD (99-03)	VDO/Marelli MANUAL
 463 G-Class	MAINTENANCE	300 GE (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	300 GE (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	300 GE (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	300 GE (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	300 GE (99-03)	VDO/Marelli MANUAL
 463 G-Class	MAINTENANCE	350 G TurboD (99-03)	VDO/Marelli MANUAL
 463 G-Class	MAINTENANCE	G 270 CDI (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	G 270 CDI (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	G 270 CDI (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	G 270 CDI (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	G 270 CDI (99-03)	VDO/Marelli MANUAL
 463 G-Class	MAINTENANCE	G 300 TD (99-03)	VDO/Marelli MANUAL
 463 G-Class	MAINTENANCE	G 320 (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	G 320 (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	G 320 (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	G 320 (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	G 320 (99-03)	VDO/Marelli MANUAL
 463 G-Class	MAINTENANCE	G 320 CDI (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	G 320 CDI (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	G 320 CDI (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	G 320 CDI (99-03)	VDO/Marelli MANUAL
 463 G-Class	MAINTENANCE	G 36 AMG (99-03)	VDO/Marelli MANUAL
 463 G-Class	MAINTENANCE	G 400 CDI (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	G 400 CDI (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	G 400 CDI (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	G 400 CDI (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	G 400 CDI (99-03)	VDO/Marelli MANUAL
 463 G-Class	MAINTENANCE	G 500 (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	G 500 (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	G 500 (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	G 500 (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	G 500 (99-03)	VDO/Marelli MANUAL
 463 G-Class	MAINTENANCE	G 55 AMG (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	G 55 AMG (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	G 55 AMG (00-03)	VDO Kombinstrum. 1.0
 463 G-Class	MAINTENANCE	G 55 AMG (99-03)	VDO/Marelli MANUAL
 463 G-Class	SERVICE LIGHT RES	230 GE (99-03)	VDO/Marelli MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 463 G-Class	SERVICE LIGHT RES	250 GD (99-03)	VDO/Marelli MANUAL
 463 G-Class	SERVICE LIGHT RES	300 GD (99-03)	VDO/Marelli MANUAL
 463 G-Class	SERVICE LIGHT RES	300 GE (99-03)	VDO/Marelli MANUAL
 463 G-Class	SERVICE LIGHT RES	350 G TurboD (99-03)	VDO/Marelli MANUAL
 463 G-Class	SERVICE LIGHT RES	G 270 CDI (99-03)	VDO/Marelli MANUAL
 463 G-Class	SERVICE LIGHT RES	G 300 TD (99-03)	VDO/Marelli MANUAL
 463 G-Class	SERVICE LIGHT RES	G 320 (99-03)	VDO/Marelli MANUAL
 463 G-Class	SERVICE LIGHT RES	G 320 CDI (99-03)	VDO/Marelli MANUAL
 463 G-Class	SERVICE LIGHT RES	G 36 AMG (99-03)	VDO/Marelli MANUAL
 463 G-Class	SERVICE LIGHT RES	G 400 CDI (99-03)	VDO/Marelli MANUAL
 463 G-Class	SERVICE LIGHT RES	G 500 (99-03)	VDO/Marelli MANUAL
 463 G-Class	SERVICE LIGHT RES	G 55 AMG (99-03)	VDO/Marelli MANUAL
 Model 124	ABS + TRACT. CONT	200 CE (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	200 E (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	200 TE (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	220 CE (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	220 E (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	220 TE (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	230 CE (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	230 E (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	230 TE (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	260 TE (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	280 E (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	280 TE (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	300 CE-24 (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	300 E-24 (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	300 TE-24 (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	320 CE (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	320 E (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	320 TE (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	400 E (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	500 E (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	600 E (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	CE 3.4 AMG (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	E 200 (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	E 200 D (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	E 220 (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	E 250 D (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	E 250 TD (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	E 280 (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	E 3.4 AMG (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	E 300 (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	E 300 D (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	E 300 TD (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	E 320 (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	E 36 AMG (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	E 420 (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	E 500 (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	E 60 AMG (89-95)	BOSCH ETS 5
 Model 124	ABS + TRACT. CONT	TE 3.4 AMG (89-95)	BOSCH ETS 5
 Model 124	AIRBAG	200 CE (...-95)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 Model 124	AIRBAG	200 E (...-95)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 Model 124	AIRBAG	200 TE (...-95)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 Model 124	AIRBAG	220 CE (...-95)	BOSCH AirBag SRS 6.2 / 6.3
 Model 124	AIRBAG	220 E (...-95)	BOSCH AirBag SRS 6.2 / 6.3
 Model 124	AIRBAG	220 TE (...-95)	BOSCH AirBag SRS 6.2 / 6.3
 Model 124	AIRBAG	230 CE (...-95)	BOSCH AirBag SRS 6.2 / 6.3
 Model 124	AIRBAG	230 E (...-95)	BOSCH AirBag SRS 6.2 / 6.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Model 124	AIRBAG	230 TE (...-95)	BOSCH AirBag SRS 6.2 / 6.3
 Model 124	AIRBAG	260 TE (...-95)	BOSCH AirBag SRS 6.2 / 6.3
 Model 124	AIRBAG	280 E (...-95)	BOSCH AirBag SRS 6.2 / 6.3
 Model 124	AIRBAG	280 TE (...-95)	BOSCH AirBag SRS 6.2 / 6.3
 Model 124	AIRBAG	300 CE-24 (...-95)	BOSCH AirBag SRS 6.2 / 6.3
 Model 124	AIRBAG	300 E-24 (...-95)	BOSCH AirBag SRS 6.2 / 6.3
 Model 124	AIRBAG	300 TE-24 (...-95)	BOSCH AirBag SRS 6.2 / 6.3
 Model 124	AIRBAG	320 CE (...-95)	BOSCH AirBag SRS 6.2 / 6.3
 Model 124	AIRBAG	320 E (...-95)	BOSCH AirBag SRS 6.2 / 6.3
 Model 124	AIRBAG	320 TE (...-95)	BOSCH AirBag SRS 6.2 / 6.3
 Model 124	AIRBAG	400 E (...-95)	BOSCH AirBag SRS 6.2 / 6.3
 Model 124	AIRBAG	500 E (...-95)	BOSCH AirBag SRS 6.2 / 6.3
 Model 124	AIRBAG	600 E (...-95)	BOSCH AirBag SRS 6.2 / 6.3
 Model 124	AIRBAG	CE 3.4 AMG (...-95)	BOSCH AirBag SRS 6.2 / 6.3
 Model 124	AIRBAG	E 200 (...-95)	BOSCH AirBag SRS 6.2 / 6.3
 Model 124	AIRBAG	E 200 D (...-95)	BOSCH AirBag SRS 6.2 / 6.3
 Model 124	AIRBAG	E 220 (...-95)	BOSCH AirBag SRS 6.2 / 6.3
 Model 124	AIRBAG	E 250 D (...-95)	BOSCH AirBag SRS 6.2 / 6.3
 Model 124	AIRBAG	E 250 TD (...-95)	BOSCH AirBag SRS 6.2 / 6.3
 Model 124	AIRBAG	E 280 (...-95)	BOSCH AirBag SRS 6.2 / 6.3
 Model 124	AIRBAG	E 3.4 AMG (...-95)	BOSCH AirBag SRS 6.2 / 6.3
 Model 124	AIRBAG	E 300 (...-95)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 Model 124	AIRBAG	E 300 D (...-95)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 Model 124	AIRBAG	E 300 TD (...-95)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 Model 124	AIRBAG	E 320 (...-95)	BOSCH AirBag SRS 6.2 / 6.3
 Model 124	AIRBAG	E 36 AMG (...-95)	BOSCH AirBag SRS 6.2 / 6.3
 Model 124	AIRBAG	E 420 (...-95)	BOSCH AirBag SRS 6.2 / 6.3
 Model 124	AIRBAG	E 500 (...-95)	BOSCH AirBag SRS 6.2 / 6.3
 Model 124	AIRBAG	E 60 AMG (...-95)	BOSCH AirBag SRS 6.2 / 6.3 no SIDE AB
 Model 124	AIRBAG	TE 3.4 AMG (...-95)	BOSCH AirBag SRS 6.2 / 6.3
 Model 124	CRUISE CONTROL	200 CE (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	200 E (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	200 TE (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	220 CE (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	220 E (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	220 TE (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	230 CE (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	230 E (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	230 TE (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	260 TE (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	280 E (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	280 TE (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	300 CE-24 (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	300 E-24 (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	300 TE-24 (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	320 CE (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	320 E (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	320 TE (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	400 E (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	500 E (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	600 E (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	CE 3.4 AMG (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	E 200 (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	E 200 D (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	E 220 (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	E 250 D (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	E 250 TD (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	E 280 (89-95)	BOSCH/VDO EA/CC/ISC

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Model 124	CRUISE CONTROL	E 3.4 AMG (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	E 300 (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	E 300 D (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	E 300 TD (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	E 320 (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	E 36 AMG (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	E 420 (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	E 500 (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	E 60 AMG (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	CRUISE CONTROL	TE 3.4 AMG (89-95)	BOSCH/VDO EA/CC/ISC
 Model 124	DIESEL MANAGEMEN	E 300 D 606 (89-95)	BOSCH IFI (ERE) (EPC)
 Model 124	ENGINE MANAGEME	200 CE 111 (89-95)	SIEMENS/VDO HFM SFI
 Model 124	ENGINE MANAGEME	200 E 111 (89-95)	SIEMENS/VDO HFM SFI
 Model 124	ENGINE MANAGEME	200 TE 111 (89-95)	SIEMENS/VDO HFM SFI
 Model 124	ENGINE MANAGEME	220 CE 111 (89-95)	SIEMENS/VDO HFM SFI
 Model 124	ENGINE MANAGEME	220 E 111 (89-95)	SIEMENS/VDO HFM SFI
 Model 124	ENGINE MANAGEME	220 TE 111 (89-95)	SIEMENS/VDO HFM SFI
 Model 124	ENGINE MANAGEME	280 E 104 (89-95)	SIEMENS/VDO HFM SFI
 Model 124	ENGINE MANAGEME	280 TE 104 (89-95)	SIEMENS/VDO HFM SFI
 Model 124	ENGINE MANAGEME	300 CE-24 104 (89-95)	SIEMENS/VDO HFM SFI
 Model 124	ENGINE MANAGEME	300 E-24 104 (89-95)	SIEMENS/VDO HFM SFI
 Model 124	ENGINE MANAGEME	300 TE-24 104 (89-95)	SIEMENS/VDO HFM SFI
 Model 124	ENGINE MANAGEME	320 CE 104 (89-95)	SIEMENS/VDO HFM SFI
 Model 124	ENGINE MANAGEME	320 E 104 (89-95)	SIEMENS/VDO HFM SFI
 Model 124	ENGINE MANAGEME	320 TE 104 (89-95)	SIEMENS/VDO HFM SFI
 Model 124	ENGINE MANAGEME	400 E 119 (89-95)	BOSCH LH-Jetronic 4.1
 Model 124	ENGINE MANAGEME	500 E 119 (89-95)	BOSCH LH-Jetronic 4.1
 Model 124	ENGINE MANAGEME	600 E 119 (89-95)	BOSCH LH-Jetronic 4.1
 Model 124	ENGINE MANAGEME	CE 3.4 AMG 104 (89-95)	SIEMENS/VDO HFM SFI
 Model 124	ENGINE MANAGEME	E 200 111 (89-95)	SIEMENS/VDO HFM SFI
 Model 124	ENGINE MANAGEME	E 220 111 (89-95)	SIEMENS/VDO HFM SFI
 Model 124	ENGINE MANAGEME	E 280 104 (89-95)	SIEMENS/VDO HFM SFI
 Model 124	ENGINE MANAGEME	E 3.4 AMG 104 (89-95)	SIEMENS/VDO HFM SFI
 Model 124	ENGINE MANAGEME	E 320 104 (89-95)	SIEMENS/VDO HFM SFI
 Model 124	ENGINE MANAGEME	E 36 AMG 104 (89-95)	SIEMENS/VDO HFM SFI
 Model 124	ENGINE MANAGEME	E 420 119 (89-95)	BOSCH LH-Jetronic 4.1
 Model 124	ENGINE MANAGEME	E 500 119 (89-95)	BOSCH LH-Jetronic 4.1
 Model 124	ENGINE MANAGEME	TE 3.4 AMG 104 (89-95)	SIEMENS/VDO HFM SFI
 Model 124	MAINTENANCE	200 CE (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	200 E (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	200 TE (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	220 CE (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	220 E (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	220 TE (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	230 CE (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	230 E (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	230 TE (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	260 TE (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	280 E (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	280 TE (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	300 CE-24 (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	300 E-24 (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	300 TE-24 (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	320 CE (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	320 E (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	320 TE (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	400 E (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	500 E (99-03)	VDO/Marelli MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Model 124	MAINTENANCE	600 E (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	CE 3.4 AMG (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	E 200 (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	E 200 D (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	E 220 (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	E 250 D (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	E 250 TD (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	E 280 (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	E 3.4 AMG (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	E 300 (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	E 300 D (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	E 300 TD (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	E 320 (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	E 36 AMG (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	E 420 (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	E 500 (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	E 60 AMG (99-03)	VDO/Marelli MANUAL
 Model 124	MAINTENANCE	TE 3.4 AMG (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	200 CE (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	200 E (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	200 TE (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	220 CE (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	220 E (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	220 TE (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	230 CE (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	230 E (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	230 TE (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	260 TE (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	280 E (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	280 TE (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	300 CE-24 (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	300 E-24 (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	300 TE-24 (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	320 CE (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	320 E (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	320 TE (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	400 E (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	500 E (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	600 E (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	CE 3.4 AMG (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	E 200 (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	E 200 D (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	E 220 (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	E 250 D (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	E 250 TD (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	E 280 (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	E 3.4 AMG (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	E 300 (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	E 300 D (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	E 300 TD (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	E 320 (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	E 36 AMG (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	E 420 (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	E 500 (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	E 60 AMG (99-03)	VDO/Marelli MANUAL
 Model 124	SERVICE LIGHT RES	TE 3.4 AMG (99-03)	VDO/Marelli MANUAL
 Sprinter	ABS	208 CDI (...-06)	ABS
 Sprinter	ABS	208 D (...-06)	ABS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sprinter	ABS	210 D (.-06)	ABS
 Sprinter	ABS	211 CDI (.-06)	ABS
 Sprinter	ABS	212 D (.-06)	ABS
 Sprinter	ABS	213 CDI (.-06)	ABS
 Sprinter	ABS	214 (.-06)	ABS
 Sprinter	ABS	214 NGT (.-06)	ABS
 Sprinter	ABS	216 CDI (.-06)	ABS
 Sprinter	ABS	308 CDI (.-06)	ABS
 Sprinter	ABS	308 D (.-06)	ABS
 Sprinter	ABS	308 E (.-06)	ABS
 Sprinter	ABS	310 D (.-06)	ABS
 Sprinter	ABS	311 CDI (.-06)	ABS
 Sprinter	ABS	313 CDI (.-06)	ABS
 Sprinter	ABS	314 (.-06)	ABS
 Sprinter	ABS	314 NGT (.-06)	ABS
 Sprinter	ABS	316 CDI (.-06)	ABS
 Sprinter	ABS	408 CDI (.-06)	ABS
 Sprinter	ABS	408 D (.-06)	ABS
 Sprinter	ABS	410 D (.-06)	ABS
 Sprinter	ABS	411 CDI (.-06)	ABS
 Sprinter	ABS	412 D (.-06)	ABS
 Sprinter	ABS	413 CDI (.-06)	ABS
 Sprinter	ABS	414 (.-06)	ABS
 Sprinter	ABS	416 CDI (.-06)	ABS
 Sprinter	ABS	616 CDI (.-06)	ABS
 Sprinter	ABS + TRACT. CONT	208 CDI (.-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	208 D (.-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	209 CDI (07-..)	BOSCH ESP ABS ESP 906
 Sprinter	ABS + TRACT. CONT	210 CDI (07-..)	BOSCH ESP ABS ESP 906
 Sprinter	ABS + TRACT. CONT	210 D (.-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	211 CDI (.-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	211 CDI (07-..)	BOSCH ESP ABS ESP 906
 Sprinter	ABS + TRACT. CONT	212 D (.-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	213 CDI (.-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	214 (.-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	214 NGT (.-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	215 CDI (07-..)	BOSCH ESP ABS ESP 906
 Sprinter	ABS + TRACT. CONT	216 (07-..)	BOSCH ESP ABS ESP 906
 Sprinter	ABS + TRACT. CONT	216 CDI (.-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	218 CDI (07-..)	BOSCH ESP ABS ESP 906
 Sprinter	ABS + TRACT. CONT	219 CDI (07-..)	BOSCH ESP ABS ESP 906
 Sprinter	ABS + TRACT. CONT	224 (07-..)	BOSCH ESP ABS ESP 906
 Sprinter	ABS + TRACT. CONT	308 CDI (.-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	308 D (.-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	308 E (.-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	310 D (.-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	311 CDI (.-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	313 CDI (.-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	314 (.-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	314 NGT (.-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	315 CDI (07-..)	BOSCH ESP ABS ESP 906
 Sprinter	ABS + TRACT. CONT	316 CDI (.-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	318 CDI (07-..)	BOSCH ESP ABS ESP 906
 Sprinter	ABS + TRACT. CONT	408 CDI (.-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	408 D (.-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	410 D (.-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	411 CDI (.-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	412 D (.-06)	EBS KWP

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sprinter	ABS + TRACT. CONT	413 CDI (.-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	414 (.-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	415 CDI (07-..)	BOSCH ESP ABS ESP 906
 Sprinter	ABS + TRACT. CONT	416 CDI (.-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	418 CDI (07-..)	BOSCH ESP ABS ESP 906
 Sprinter	ABS + TRACT. CONT	518 CDI (07-..)	BOSCH ESP ABS ESP 906
 Sprinter	ABS + TRACT. CONT	616 CDI (.-06)	EBS KWP
 Sprinter	AIRBAG	209 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	210 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	211 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	215 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	216 (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	218 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	219 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	224 (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	309 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	310 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	311 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	313 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	315 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	316 (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	316 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	316 NGT (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	318 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	319 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	324 (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	415 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	418 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	419 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	424 (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	509 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	510 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	511 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	513 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	515 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	516 (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	516 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	516 NGT (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	518 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	519 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	524 (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AUTOM. TRANSMISSI	208 CDI (.-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	208 D (.-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	209 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	210 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	210 D (.-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	211 CDI (.-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	211 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	212 D (.-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	213 CDI (.-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	214 (.-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	214 NGT (.-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	215 CDI (.-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	215 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	216 (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	216 CDI (.-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	218 CDI (.-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	218 CDI (07-..)	SIEMENS EGS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sprinter	AUTOM. TRANSMISSI	219 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	224 (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	308 CDI (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	308 D (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	308 E (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	309 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	310 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	310 D (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	311 CDI (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	311 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	312 D (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	313 CDI (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	313 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	314 (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	314 NGT (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	315 CDI (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	315 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	316 (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	316 CDI (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	316 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	316 NGT (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	318 CDI (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	318 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	319 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	324 (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	408 CDI (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	408 D (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	410 D (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	411 CDI (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	412 D (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	413 CDI (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	414 (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	415 CDI (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	415 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	416 CDI (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	418 CDI (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	418 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	419 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	424 (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	509 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	510 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	511 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	513 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	515 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	516 (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	516 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	516 NGT (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	518 CDI (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	518 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	519 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	524 (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	616 CDI (...-06)	MB SSG Sprintshift
 Sprinter	CHASSIS NETWORK	209 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	209 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	210 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	210 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	211 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	211 CDI (07-..)	TEMIC SAM

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sprinter	CHASSIS NETWORK	215 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	215 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	216 (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	216 (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	218 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	218 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	219 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	219 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	224 (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	224 (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	309 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	309 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	310 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	310 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	311 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	311 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	313 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	313 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	315 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	315 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	316 (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	316 (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	316 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	316 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	316 NGT (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	316 NGT (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	318 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	318 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	319 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	319 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	324 (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	324 (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	415 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	415 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	418 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	418 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	419 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	419 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	424 (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	424 (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	509 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	509 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	510 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	510 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	511 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	511 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	513 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	513 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	515 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	515 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	516 (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	516 (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	516 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	516 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	516 NGT (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	516 NGT (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	518 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	518 CDI (07-..)	TEMIC SAM

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sprinter	CHASSIS NETWORK	519 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	519 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	524 (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	524 (07-..)	TEMIC SAM
 Sprinter	CLIMA	209 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	210 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	211 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	215 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	216 (07-..)	HELLA KLA
 Sprinter	CLIMA	218 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	219 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	224 (07-..)	HELLA KLA
 Sprinter	CLIMA	309 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	310 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	311 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	313 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	315 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	316 (07-..)	HELLA KLA
 Sprinter	CLIMA	316 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	316 NGT (07-..)	HELLA KLA
 Sprinter	CLIMA	318 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	319 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	324 (07-..)	HELLA KLA
 Sprinter	CLIMA	415 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	418 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	419 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	424 (07-..)	HELLA KLA
 Sprinter	CLIMA	509 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	510 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	511 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	513 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	515 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	516 (07-..)	HELLA KLA
 Sprinter	CLIMA	516 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	516 NGT (07-..)	HELLA KLA
 Sprinter	CLIMA	518 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	519 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	524 (07-..)	HELLA KLA
 Sprinter	DASHBOARD	208 CDI (...06)	VDO KOMBI
 Sprinter	DASHBOARD	208 D (...06)	VDO KOMBI
 Sprinter	DASHBOARD	209 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	210 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	210 D (...06)	VDO KOMBI
 Sprinter	DASHBOARD	211 CDI (...06)	VDO KOMBI
 Sprinter	DASHBOARD	211 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	212 D (...06)	VDO KOMBI
 Sprinter	DASHBOARD	213 CDI (...06)	VDO KOMBI
 Sprinter	DASHBOARD	214 (...06)	VDO KOMBI
 Sprinter	DASHBOARD	214 NGT (...06)	VDO KOMBI
 Sprinter	DASHBOARD	215 CDI (...06)	VDO KOMBI
 Sprinter	DASHBOARD	215 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	216 (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	216 CDI (...06)	VDO KOMBI
 Sprinter	DASHBOARD	218 CDI (...06)	VDO KOMBI
 Sprinter	DASHBOARD	218 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	219 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	224 (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	308 CDI (...06)	VDO KOMBI

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sprinter	DASHBOARD	308 D (...-06)	VDO KOMBI
 Sprinter	DASHBOARD	308 E (...-06)	VDO KOMBI
 Sprinter	DASHBOARD	309 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	310 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	310 D (...-06)	VDO KOMBI
 Sprinter	DASHBOARD	311 CDI (...-06)	VDO KOMBI
 Sprinter	DASHBOARD	311 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	313 CDI (...-06)	VDO KOMBI
 Sprinter	DASHBOARD	313 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	314 (...-06)	VDO KOMBI
 Sprinter	DASHBOARD	314 NGT (...-06)	VDO KOMBI
 Sprinter	DASHBOARD	315 CDI (...-06)	VDO KOMBI
 Sprinter	DASHBOARD	315 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	316 (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	316 CDI (...-06)	VDO KOMBI
 Sprinter	DASHBOARD	316 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	316 NGT (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	318 CDI (...-06)	VDO KOMBI
 Sprinter	DASHBOARD	318 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	319 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	324 (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	408 CDI (...-06)	VDO KOMBI
 Sprinter	DASHBOARD	408 D (...-06)	VDO KOMBI
 Sprinter	DASHBOARD	410 D (...-06)	VDO KOMBI
 Sprinter	DASHBOARD	411 CDI (...-06)	VDO KOMBI
 Sprinter	DASHBOARD	412 D (...-06)	VDO KOMBI
 Sprinter	DASHBOARD	413 CDI (...-06)	VDO KOMBI
 Sprinter	DASHBOARD	414 (...-06)	VDO KOMBI
 Sprinter	DASHBOARD	415 CDI (...-06)	VDO KOMBI
 Sprinter	DASHBOARD	415 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	416 CDI (...-06)	VDO KOMBI
 Sprinter	DASHBOARD	418 CDI (...-06)	VDO KOMBI
 Sprinter	DASHBOARD	418 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	419 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	424 (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	509 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	510 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	511 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	513 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	515 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	516 (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	516 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	516 NGT (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	518 CDI (...-06)	VDO KOMBI
 Sprinter	DASHBOARD	518 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	519 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	524 (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	616 CDI (...-06)	VDO KOMBI
 Sprinter	DIESEL MANAGEMEN	312 D 602980 (96-..)	BOSCH EVE
 Sprinter	DRIVER SIDE DOOR	209 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	210 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	211 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	215 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	216 (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	218 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	219 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	224 (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	309 CDI (07-..)	TEMIC TSG

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sprinter	DRIVER SIDE DOOR	310 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	311 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	313 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	315 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	316 (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	316 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	316 NGT (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	318 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	319 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	324 (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	415 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	418 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	419 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	424 (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	509 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	510 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	511 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	513 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	515 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	516 (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	516 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	516 NGT (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	518 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	519 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	524 (07-..)	TEMIC TSG
 Sprinter	ENGINE MANAGEME	208 CDI (.-06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	208 D (04-06)	EOBD
 Sprinter	ENGINE MANAGEME	209 CDI (07-..)	EOBD
 Sprinter	ENGINE MANAGEME	210 CDI (07-..)	EOBD
 Sprinter	ENGINE MANAGEME	210 D (04-06)	EOBD
 Sprinter	ENGINE MANAGEME	211 CDI (.-06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	211 CDI (07-..)	EOBD
 Sprinter	ENGINE MANAGEME	212 D (04-06)	EOBD
 Sprinter	ENGINE MANAGEME	213 CDI (.-06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	214 (01-06)	EOBD
 Sprinter	ENGINE MANAGEME	214 NGT (01-06)	EOBD
 Sprinter	ENGINE MANAGEME	215 CDI (07-..)	BOSCH EDC CDI 4 Common Rail
 Sprinter	ENGINE MANAGEME	216 (07-..)	EOBD
 Sprinter	ENGINE MANAGEME	216 CDI (.-06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	218 CDI (07-..)	BOSCH EDC CDI 4 Common Rail
 Sprinter	ENGINE MANAGEME	219 CDI (07-..)	EOBD
 Sprinter	ENGINE MANAGEME	224 (07-..)	EOBD
 Sprinter	ENGINE MANAGEME	308 CDI (.-06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	308 D (04-06)	EOBD
 Sprinter	ENGINE MANAGEME	308 E (01-06)	EOBD
 Sprinter	ENGINE MANAGEME	309 CDI (07-..)	EOBD
 Sprinter	ENGINE MANAGEME	310 CDI (07-..)	EOBD
 Sprinter	ENGINE MANAGEME	310 D (04-06)	EOBD
 Sprinter	ENGINE MANAGEME	311 CDI (.-06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	311 CDI (07-..)	EOBD
 Sprinter	ENGINE MANAGEME	313 CDI (.-06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	313 CDI (07-..)	EOBD
 Sprinter	ENGINE MANAGEME	314 (01-06)	EOBD
 Sprinter	ENGINE MANAGEME	314 NGT (01-06)	EOBD
 Sprinter	ENGINE MANAGEME	315 CDI (07-..)	BOSCH EDC CDI 4 Common Rail
 Sprinter	ENGINE MANAGEME	316 (07-..)	EOBD
 Sprinter	ENGINE MANAGEME	316 CDI (.-06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	316 CDI (07-..)	EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sprinter	ENGINE MANAGEME	316 NGT (07-..)	EOBD
 Sprinter	ENGINE MANAGEME	318 CDI (07-..)	BOSCH EDC CDI 4 Common Rail
 Sprinter	ENGINE MANAGEME	319 CDI (07-..)	EOBD
 Sprinter	ENGINE MANAGEME	324 (07-..)	EOBD
 Sprinter	ENGINE MANAGEME	408 CDI (..-06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	408 D (04-06)	EOBD
 Sprinter	ENGINE MANAGEME	410 D (04-06)	EOBD
 Sprinter	ENGINE MANAGEME	411 CDI (..-06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	412 D (04-06)	EOBD
 Sprinter	ENGINE MANAGEME	413 CDI (..-06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	414 (01-06)	EOBD
 Sprinter	ENGINE MANAGEME	415 CDI (07-..)	BOSCH EDC CDI 4 Common Rail
 Sprinter	ENGINE MANAGEME	416 CDI (..-06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	418 CDI (07-..)	BOSCH EDC CDI 4 Common Rail
 Sprinter	ENGINE MANAGEME	419 CDI (07-..)	EOBD
 Sprinter	ENGINE MANAGEME	424 (07-..)	EOBD
 Sprinter	ENGINE MANAGEME	509 CDI (07-..)	EOBD
 Sprinter	ENGINE MANAGEME	510 CDI (07-..)	EOBD
 Sprinter	ENGINE MANAGEME	511 CDI (07-..)	EOBD
 Sprinter	ENGINE MANAGEME	513 CDI (07-..)	EOBD
 Sprinter	ENGINE MANAGEME	515 CDI (07-..)	EOBD
 Sprinter	ENGINE MANAGEME	516 (07-..)	EOBD
 Sprinter	ENGINE MANAGEME	516 CDI (07-..)	EOBD
 Sprinter	ENGINE MANAGEME	516 NGT (07-..)	EOBD
 Sprinter	ENGINE MANAGEME	518 CDI (07-..)	BOSCH EDC CDI 4 Common Rail
 Sprinter	ENGINE MANAGEME	519 CDI (07-..)	EOBD
 Sprinter	ENGINE MANAGEME	524 (07-..)	EOBD
 Sprinter	ENGINE MANAGEME	616 CDI (..-06)	BOSCH EDC Common Rail
 Sprinter	IGNITION SWITCH	209 CDI (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	210 CDI (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	211 CDI (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	215 CDI (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	216 (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	218 CDI (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	219 CDI (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	224 (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	309 CDI (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	310 CDI (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	311 CDI (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	313 CDI (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	315 CDI (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	316 (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	316 CDI (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	316 NGT (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	318 CDI (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	319 CDI (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	324 (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	415 CDI (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	418 CDI (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	419 CDI (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	424 (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	509 CDI (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	510 CDI (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	511 CDI (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	513 CDI (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	515 CDI (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	516 (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	516 CDI (07-..)	MARQUARDT EZS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sprinter	IGNITION SWITCH	516 NGT (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	518 CDI (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	519 CDI (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	524 (07-..)	MARQUARDT EZS
 Sprinter	IMMOBILIZER	208 CDI (..-06)	
 Sprinter	IMMOBILIZER	208 D (..-06)	
 Sprinter	IMMOBILIZER	210 D (..-06)	
 Sprinter	IMMOBILIZER	211 CDI (..-06)	
 Sprinter	IMMOBILIZER	212 D (..-06)	
 Sprinter	IMMOBILIZER	213 CDI (..-06)	
 Sprinter	IMMOBILIZER	214 (..-06)	
 Sprinter	IMMOBILIZER	214 NGT (..-06)	
 Sprinter	IMMOBILIZER	215 CDI (..-06)	
 Sprinter	IMMOBILIZER	216 CDI (..-06)	
 Sprinter	IMMOBILIZER	218 CDI (..-06)	
 Sprinter	IMMOBILIZER	308 CDI (..-06)	
 Sprinter	IMMOBILIZER	308 D (..-06)	
 Sprinter	IMMOBILIZER	308 E (..-06)	
 Sprinter	IMMOBILIZER	310 D (..-06)	
 Sprinter	IMMOBILIZER	311 CDI (..-06)	
 Sprinter	IMMOBILIZER	313 CDI (..-06)	
 Sprinter	IMMOBILIZER	314 (..-06)	
 Sprinter	IMMOBILIZER	314 NGT (..-06)	
 Sprinter	IMMOBILIZER	315 CDI (..-06)	
 Sprinter	IMMOBILIZER	316 CDI (..-06)	
 Sprinter	IMMOBILIZER	318 CDI (..-06)	
 Sprinter	IMMOBILIZER	408 CDI (..-06)	
 Sprinter	IMMOBILIZER	408 D (..-06)	
 Sprinter	IMMOBILIZER	410 D (..-06)	
 Sprinter	IMMOBILIZER	411 CDI (..-06)	
 Sprinter	IMMOBILIZER	412 D (..-06)	
 Sprinter	IMMOBILIZER	413 CDI (..-06)	
 Sprinter	IMMOBILIZER	414 (..-06)	
 Sprinter	IMMOBILIZER	415 CDI (..-06)	
 Sprinter	IMMOBILIZER	416 CDI (..-06)	
 Sprinter	IMMOBILIZER	418 CDI (..-06)	
 Sprinter	IMMOBILIZER	518 CDI (..-06)	
 Sprinter	IMMOBILIZER	616 CDI (..-06)	
 Sprinter	MAINTENANCE	208 CDI (..-06)	EBS KWP
 Sprinter	MAINTENANCE	208 CDI (99-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	208 D (..-06)	EBS KWP
 Sprinter	MAINTENANCE	208 D (99-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	209 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	209 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	210 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	210 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	210 D (..-06)	EBS KWP
 Sprinter	MAINTENANCE	210 D (99-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	211 CDI (..-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	211 CDI (..-06)	EBS KWP
 Sprinter	MAINTENANCE	211 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	211 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	212 D (..-06)	EBS KWP
 Sprinter	MAINTENANCE	212 D (99-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	213 CDI (..-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	213 CDI (..-06)	EBS KWP
 Sprinter	MAINTENANCE	214 (..-06)	EBS KWP
 Sprinter	MAINTENANCE	214 (99-03)	VDO/Marelli MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sprinter	MAINTENANCE	214 NGT (.-06)	EBS KWP
 Sprinter	MAINTENANCE	214 NGT (99-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	215 CDI (.-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	215 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	215 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	216 (07-..)	MANUAL
 Sprinter	MAINTENANCE	216 (07-..)	MANUAL
 Sprinter	MAINTENANCE	216 CDI (.-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	216 CDI (.-06)	EBS KWP
 Sprinter	MAINTENANCE	218 CDI (.-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	218 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	218 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	219 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	219 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	224 (07-..)	MANUAL
 Sprinter	MAINTENANCE	224 (07-..)	MANUAL
 Sprinter	MAINTENANCE	308 CDI (.-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	308 CDI (.-06)	EBS KWP
 Sprinter	MAINTENANCE	308 D (.-06)	EBS KWP
 Sprinter	MAINTENANCE	308 D (99-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	308 E (.-06)	EBS KWP
 Sprinter	MAINTENANCE	308 E (99-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	309 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	309 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	310 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	310 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	310 D (.-06)	EBS KWP
 Sprinter	MAINTENANCE	310 D (99-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	311 CDI (.-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	311 CDI (.-06)	EBS KWP
 Sprinter	MAINTENANCE	311 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	311 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	312 D (.-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	313 CDI (.-06)	EBS KWP
 Sprinter	MAINTENANCE	313 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	313 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	313 CDI (99-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	314 (.-06)	EBS KWP
 Sprinter	MAINTENANCE	314 (99-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	314 NGT (.-06)	EBS KWP
 Sprinter	MAINTENANCE	314 NGT (99-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	315 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	315 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	315 CDI (99-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	316 (07-..)	MANUAL
 Sprinter	MAINTENANCE	316 (07-..)	MANUAL
 Sprinter	MAINTENANCE	316 CDI (.-06)	EBS KWP
 Sprinter	MAINTENANCE	316 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	316 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	316 CDI (99-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	316 NGT (07-..)	MANUAL
 Sprinter	MAINTENANCE	316 NGT (07-..)	MANUAL
 Sprinter	MAINTENANCE	318 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	318 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	318 CDI (99-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	319 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	319 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	324 (07-..)	MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sprinter	MAINTENANCE	324 (07-..)	MANUAL
 Sprinter	MAINTENANCE	408 CDI (...-06)	EBS KWP
 Sprinter	MAINTENANCE	408 CDI (99-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	408 D (...-06)	EBS KWP
 Sprinter	MAINTENANCE	408 D (99-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	410 D (...-06)	EBS KWP
 Sprinter	MAINTENANCE	410 D (99-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	411 CDI (...-06)	EBS KWP
 Sprinter	MAINTENANCE	411 CDI (99-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	412 D (...-06)	EBS KWP
 Sprinter	MAINTENANCE	412 D (99-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	413 CDI (...-06)	EBS KWP
 Sprinter	MAINTENANCE	413 CDI (99-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	414 (...-06)	EBS KWP
 Sprinter	MAINTENANCE	414 (99-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	415 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	415 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	415 CDI (99-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	416 CDI (...-06)	EBS KWP
 Sprinter	MAINTENANCE	416 CDI (99-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	418 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	418 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	418 CDI (99-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	419 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	419 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	424 (07-..)	MANUAL
 Sprinter	MAINTENANCE	424 (07-..)	MANUAL
 Sprinter	MAINTENANCE	509 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	509 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	510 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	510 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	511 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	511 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	513 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	513 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	515 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	515 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	516 (07-..)	MANUAL
 Sprinter	MAINTENANCE	516 (07-..)	MANUAL
 Sprinter	MAINTENANCE	516 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	516 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	516 NGT (07-..)	MANUAL
 Sprinter	MAINTENANCE	516 NGT (07-..)	MANUAL
 Sprinter	MAINTENANCE	518 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	518 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	518 CDI (99-03)	VDO/Marelli MANUAL
 Sprinter	MAINTENANCE	519 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	519 CDI (07-..)	MANUAL
 Sprinter	MAINTENANCE	524 (07-..)	MANUAL
 Sprinter	MAINTENANCE	524 (07-..)	MANUAL
 Sprinter	MAINTENANCE	616 CDI (...-06)	EBS KWP
 Sprinter	MAINTENANCE	616 CDI (99-03)	VDO/Marelli MANUAL
 Sprinter	RATIO SEL. MANAGE	209 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	210 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	211 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	215 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	216 (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	218 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sprinter	RATIO SEL. MANAGE	219 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	224 (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	309 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	310 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	311 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	313 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	315 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	316 (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	316 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	316 NGT (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	318 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	319 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	324 (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	415 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	418 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	419 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	424 (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	509 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	510 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	511 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	513 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	515 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	516 (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	516 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	516 NGT (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	518 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	519 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	524 (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	SERVICE LIGHT RES	208 CDI (99-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	208 D (99-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	209 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	209 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	210 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	210 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	210 D (99-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	211 CDI (.-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	211 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	211 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	212 D (99-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	213 CDI (.-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	214 (99-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	214 NGT (99-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	215 CDI (.-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	215 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	215 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	216 (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	216 (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	216 CDI (.-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	218 CDI (.-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	218 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	218 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	219 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	219 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	224 (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	224 (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	308 CDI (.-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	308 D (99-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	308 E (99-03)	VDO/Marelli MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sprinter	SERVICE LIGHT RES	309 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	309 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	310 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	310 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	310 D (99-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	311 CDI (.-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	311 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	311 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	312 D (.-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	313 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	313 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	313 CDI (99-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	314 (99-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	314 NGT (99-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	315 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	315 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	315 CDI (99-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	316 (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	316 (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	316 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	316 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	316 CDI (99-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	316 NGT (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	316 NGT (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	318 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	318 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	318 CDI (99-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	319 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	319 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	324 (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	324 (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	408 CDI (99-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	408 D (99-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	410 D (99-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	411 CDI (99-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	412 D (99-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	413 CDI (99-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	414 (99-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	415 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	415 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	415 CDI (99-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	416 CDI (99-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	418 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	418 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	418 CDI (99-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	419 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	419 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	424 (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	424 (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	509 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	509 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	510 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	510 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	511 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	511 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	513 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	513 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	515 CDI (07-..)	MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sprinter	SERVICE LIGHT RES	515 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	516 (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	516 (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	516 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	516 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	516 NGT (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	516 NGT (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	518 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	518 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	518 CDI (99-03)	VDO/Marelli MANUAL
 Sprinter	SERVICE LIGHT RES	519 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	519 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	524 (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	524 (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	616 CDI (99-03)	VDO/Marelli MANUAL
 Sprinter	SWITCHLIGHT MODU	209 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	210 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	211 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	215 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	216 (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	218 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	219 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	224 (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	309 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	310 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	311 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	313 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	315 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	316 (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	316 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	316 NGT (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	318 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	319 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	324 (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	415 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	418 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	419 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	424 (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	509 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	510 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	511 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	513 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	515 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	516 (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	516 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	516 NGT (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	518 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	519 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	524 (07-..)	VALEO MRM
 Vaneo	ABS + TRACT. CONT	1.4 (02-06)	BOSCH ESP
 Vaneo	ABS + TRACT. CONT	1.6 (02-06)	BOSCH ESP
 Vaneo	ABS + TRACT. CONT	1.7 CDI (02-06)	BOSCH ESP
 Vaneo	ABS + TRACT. CONT	1.9 (02-06)	BOSCH ESP
 Vaneo	AIRBAG	1.4 (02-06)	SRS
 Vaneo	AIRBAG	1.6 (02-06)	SRS
 Vaneo	AIRBAG	1.7 CDI (02-06)	SRS
 Vaneo	AIRBAG	1.9 (02-06)	SRS
 Vaneo	CENTRAL LOCKING	1.4 (02-06)	VDO ZV

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Vaneo	CENTRAL LOCKING	1.6 (02-06)	VDO ZV
 Vaneo	CENTRAL LOCKING	1.7 CDI (02-06)	VDO ZV
 Vaneo	CENTRAL LOCKING	1.9 (02-06)	VDO ZV
 Vaneo	CLIMA	1.4 (02-06)	Clima HAU/TAU
 Vaneo	CLIMA	1.6 (02-06)	Clima HAU/TAU
 Vaneo	CLIMA	1.7 CDI (02-06)	Clima HAU/TAU
 Vaneo	CLIMA	1.9 (02-06)	Clima HAU/TAU
 Vaneo	DASHBOARD	1.4 (02-06)	Magneti Marelli KI
 Vaneo	DASHBOARD	1.6 (02-06)	Magneti Marelli KI
 Vaneo	DASHBOARD	1.7 CDI (02-06)	Magneti Marelli KI
 Vaneo	DASHBOARD	1.9 (02-06)	Magneti Marelli KI
 Vaneo	ENGINE MANAGEME	1.7 CDI (02-06)	BOSCH CDI
 Vaneo	IMMOBILIZER	1.4 (02-06)	SIEMENS FBS
 Vaneo	IMMOBILIZER	1.6 (02-06)	SIEMENS FBS
 Vaneo	IMMOBILIZER	1.7 CDI (02-06)	SIEMENS FBS
 Vaneo	IMMOBILIZER	1.9 (02-06)	SIEMENS FBS
 Vaneo	MAINTENANCE	1.4 (02-06)	Magneti Marelli KI
 Vaneo	MAINTENANCE	1.4 (02-06)	MANUAL
 Vaneo	MAINTENANCE	1.6 (02-06)	Magneti Marelli KI
 Vaneo	MAINTENANCE	1.6 (02-06)	MANUAL
 Vaneo	MAINTENANCE	1.7 CDI (02-06)	Magneti Marelli KI
 Vaneo	MAINTENANCE	1.7 CDI (02-06)	MANUAL
 Vaneo	MAINTENANCE	1.9 (02-06)	Magneti Marelli KI
 Vaneo	MAINTENANCE	1.9 (02-06)	MANUAL
 Vaneo	SERVICE LIGHT RES	1.4 (02-06)	MANUAL
 Vaneo	SERVICE LIGHT RES	1.6 (02-06)	MANUAL
 Vaneo	SERVICE LIGHT RES	1.7 CDI (02-06)	MANUAL
 Vaneo	SERVICE LIGHT RES	1.9 (02-06)	MANUAL
 V-Class & VITO	ABS + TRACT. CONT	V 200	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	V 200 (.-99)	BOSCH ASR/ABD BAS/ETS
 V-Class & VITO	ABS + TRACT. CONT	V 200 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	V 200 CDI (.-99)	BOSCH ASR/ABD BAS/ETS
 V-Class & VITO	ABS + TRACT. CONT	V 220 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	V 220 CDI (.-99)	BOSCH ASR/ABD BAS/ETS
 V-Class & VITO	ABS + TRACT. CONT	V 230	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	V 230 (.-99)	BOSCH ASR/ABD BAS/ETS
 V-Class & VITO	ABS + TRACT. CONT	V 230 TD	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	V 230 TD (.-99)	BOSCH ASR/ABD BAS/ETS
 V-Class & VITO	ABS + TRACT. CONT	V 280	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	V 280 (.-99)	BOSCH ASR/ABD BAS/ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito 108 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito 108 CDI (.-99)	BOSCH ASR/ABD BAS/ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito 108 D	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito 108 D (.-99)	BOSCH ASR/ABD BAS/ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito 110 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito 110 CDI (.-99)	BOSCH ASR/ABD BAS/ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito 110 TD	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito 110 TD (.-99)	BOSCH ASR/ABD BAS/ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito 112 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito 112 CDI (.-99)	BOSCH ASR/ABD BAS/ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito 113	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito 113 (.-99)	BOSCH ASR/ABD BAS/ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito 114	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito 114 (.-99)	BOSCH ASR/ABD BAS/ETS
 V-Class & VITO	AUTOM. TRANSMISSI	V 200 (.-99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	V 200 CDI (.-99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	V 220 CDI (.-99)	BOSCH ETC 6
V-Class & VITO	AUTOM. TRANSMISSI	V 230 (.-99)	BOSCH ETC 6

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 V-Class & VITO	AUTOM. TRANSMISSI	V 230 TD (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	V 280 (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito 108 CDI (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito 108 D (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito 110 CDI (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito 110 TD (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito 112 CDI (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito 113 (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito 114 (...99)	BOSCH ETC 6
 V-Class & VITO	ENGINE MANAGEME	V 114 111 (...99)	BOSCH Motronic ME 2.0
 V-Class & VITO	ENGINE MANAGEME	V 200 (01-03)	EOBD
 V-Class & VITO	ENGINE MANAGEME	V 200 CDI 611 (98-00)	BOSCH EDC 15 C4 Common Rail
 V-Class & VITO	ENGINE MANAGEME	V 200 CDI 611 (98-00)	BOSCH EDC 15 C6 Common Rail
 V-Class & VITO	ENGINE MANAGEME	V 220 CDI 611 (98-00)	BOSCH EDC 15 C4 Common Rail
 V-Class & VITO	ENGINE MANAGEME	V 220 CDI 611 (98-00)	BOSCH EDC 15 C6 Common Rail
 V-Class & VITO	ENGINE MANAGEME	V 230 111 (...99)	BOSCH Motronic ME 2.0
 V-Class & VITO	ENGINE MANAGEME	Vito 108 CDI 611 (98-00)	BOSCH EDC 15 C4 Common Rail
 V-Class & VITO	ENGINE MANAGEME	Vito 108 CDI 611 (98-00)	BOSCH EDC 15 C6 Common Rail
 V-Class & VITO	MAINTENANCE	V 114 (99-03)	VDO/Marelli MANUAL
 V-Class & VITO	MAINTENANCE	V 200 (99-03)	VDO/Marelli MANUAL
 V-Class & VITO	MAINTENANCE	V 200 CDI (99-03)	VDO/Marelli MANUAL
 V-Class & VITO	MAINTENANCE	V 220 CDI (99-03)	VDO/Marelli MANUAL
 V-Class & VITO	MAINTENANCE	V 230 (99-03)	VDO/Marelli MANUAL
 V-Class & VITO	MAINTENANCE	V 230 TD (99-03)	VDO/Marelli MANUAL
 V-Class & VITO	MAINTENANCE	V 280 (99-03)	VDO/Marelli MANUAL
 V-Class & VITO	MAINTENANCE	Vito 108 CDI (99-03)	VDO/Marelli MANUAL
 V-Class & VITO	MAINTENANCE	Vito 108 D (99-03)	VDO/Marelli MANUAL
 V-Class & VITO	MAINTENANCE	Vito 110 CDI (99-03)	VDO/Marelli MANUAL
 V-Class & VITO	MAINTENANCE	Vito 110 TD (99-03)	VDO/Marelli MANUAL
 V-Class & VITO	MAINTENANCE	Vito 112 CDI (99-03)	VDO/Marelli MANUAL
 V-Class & VITO	MAINTENANCE	Vito 113 (99-03)	VDO/Marelli MANUAL
 V-Class & VITO	MAINTENANCE	Vito 114 (99-03)	VDO/Marelli MANUAL
 V-Class & VITO	SERVICE LIGHT RES	V 114 (99-03)	VDO/Marelli MANUAL
 V-Class & VITO	SERVICE LIGHT RES	V 200 (99-03)	VDO/Marelli MANUAL
 V-Class & VITO	SERVICE LIGHT RES	V 200 CDI (99-03)	VDO/Marelli MANUAL
 V-Class & VITO	SERVICE LIGHT RES	V 220 CDI (99-03)	VDO/Marelli MANUAL
 V-Class & VITO	SERVICE LIGHT RES	V 230 (99-03)	VDO/Marelli MANUAL
 V-Class & VITO	SERVICE LIGHT RES	V 230 TD (99-03)	VDO/Marelli MANUAL
 V-Class & VITO	SERVICE LIGHT RES	V 280 (99-03)	VDO/Marelli MANUAL
 V-Class & VITO	SERVICE LIGHT RES	Vito 108 CDI (99-03)	VDO/Marelli MANUAL
 V-Class & VITO	SERVICE LIGHT RES	Vito 108 D (99-03)	VDO/Marelli MANUAL
 V-Class & VITO	SERVICE LIGHT RES	Vito 110 CDI (99-03)	VDO/Marelli MANUAL
 V-Class & VITO	SERVICE LIGHT RES	Vito 110 TD (99-03)	VDO/Marelli MANUAL
 V-Class & VITO	SERVICE LIGHT RES	Vito 112 CDI (99-03)	VDO/Marelli MANUAL
 V-Class & VITO	SERVICE LIGHT RES	Vito 113 (99-03)	VDO/Marelli MANUAL
 V-Class & VITO	SERVICE LIGHT RES	Vito 114 (99-03)	VDO/Marelli MANUAL
 Vito	ABS + TRACT. CONT	109 CDI (07-..)	BOSCH ESP ABS
 Vito	ABS + TRACT. CONT	111 CDI (07-..)	BOSCH ESP ABS
 Vito	ABS + TRACT. CONT	111 CDI 4X4 (07-..)	BOSCH ESP ABS
 Vito	ABS + TRACT. CONT	115 CDI (07-..)	BOSCH ESP ABS
 Vito	ABS + TRACT. CONT	115 CDI 4X4 (07-..)	BOSCH ESP ABS
 Vito	ABS + TRACT. CONT	119 (07-..)	BOSCH ESP ABS
 Vito	ABS + TRACT. CONT	120 CDI (07-..)	BOSCH ESP ABS
 Vito	ABS + TRACT. CONT	122 (07-..)	BOSCH ESP ABS
 Vito	ABS + TRACT. CONT	123 (07-..)	BOSCH ESP ABS
 Vito	ABS + TRACT. CONT	126 (07-..)	BOSCH ESP ABS
 Vito	AIRBAG	109 CDI (07-..)	BOSCH SRS ARCADE 639
 Vito	AIRBAG	111 CDI (07-..)	BOSCH SRS ARCADE 639

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Vito	AIRBAG	111 CDI 4X4 (07-..)	BOSCH SRS ARCADE 639
 Vito	AIRBAG	115 CDI (07-..)	BOSCH SRS ARCADE 639
 Vito	AIRBAG	115 CDI 4X4 (07-..)	BOSCH SRS ARCADE 639
 Vito	AIRBAG	119 (07-..)	BOSCH SRS ARCADE 639
 Vito	AIRBAG	120 CDI (07-..)	BOSCH SRS ARCADE 639
 Vito	AIRBAG	122 (07-..)	BOSCH SRS ARCADE 639
 Vito	AIRBAG	123 (07-..)	BOSCH SRS ARCADE 639
 Vito	AIRBAG	126 (07-..)	BOSCH SRS ARCADE 639
 Vito	AUTOM. TRANSMISSI	109 CDI (07-..)	SIEMENS EGS
 Vito	AUTOM. TRANSMISSI	111 CDI (07-..)	SIEMENS EGS
 Vito	AUTOM. TRANSMISSI	111 CDI 4X4 (07-..)	SIEMENS EGS
 Vito	AUTOM. TRANSMISSI	115 CDI (07-..)	SIEMENS EGS
 Vito	AUTOM. TRANSMISSI	115 CDI 4X4 (07-..)	SIEMENS EGS
 Vito	AUTOM. TRANSMISSI	119 (07-..)	SIEMENS EGS
 Vito	AUTOM. TRANSMISSI	120 CDI (07-..)	SIEMENS EGS
 Vito	AUTOM. TRANSMISSI	122 (07-..)	SIEMENS EGS
 Vito	AUTOM. TRANSMISSI	123 (07-..)	SIEMENS EGS
 Vito	AUTOM. TRANSMISSI	126 (07-..)	SIEMENS EGS
 Vito	CHASSIS NETWORK	109 CDI (07-..)	Marquardt OBF Upper Switches Panel
 Vito	CHASSIS NETWORK	111 CDI (07-..)	Marquardt OBF Upper Switches Panel
 Vito	CHASSIS NETWORK	111 CDI 4X4 (07-..)	Marquardt OBF Upper Switches Panel
 Vito	CHASSIS NETWORK	115 CDI (07-..)	Marquardt OBF Upper Switches Panel
 Vito	CHASSIS NETWORK	115 CDI 4X4 (07-..)	Marquardt OBF Upper Switches Panel
 Vito	CHASSIS NETWORK	119 (07-..)	Marquardt OBF Upper Switches Panel
 Vito	CHASSIS NETWORK	120 CDI (07-..)	Marquardt OBF Upper Switches Panel
 Vito	CHASSIS NETWORK	122 (07-..)	Marquardt OBF Upper Switches Panel
 Vito	CHASSIS NETWORK	123 (07-..)	Marquardt OBF Upper Switches Panel
 Vito	CHASSIS NETWORK	126 (07-..)	Marquardt OBF Upper Switches Panel
 Vito	DASHBOARD	109 CDI (07-..)	BORG Kombi Instrument 639 M
 Vito	DASHBOARD	111 CDI (07-..)	BORG Kombi Instrument 639 M
 Vito	DASHBOARD	111 CDI 4X4 (07-..)	BORG Kombi Instrument 639 M
 Vito	DASHBOARD	115 CDI (07-..)	BORG Kombi Instrument 639 M
 Vito	DASHBOARD	115 CDI 4X4 (07-..)	BORG Kombi Instrument 639 M
 Vito	DASHBOARD	119 (07-..)	BORG Kombi Instrument 639 M
 Vito	DASHBOARD	120 CDI (07-..)	BORG Kombi Instrument 639 M
 Vito	DASHBOARD	122 (07-..)	BORG Kombi Instrument 639 M
 Vito	DASHBOARD	123 (07-..)	BORG Kombi Instrument 639 M
 Vito	DASHBOARD	126 (07-..)	BORG Kombi Instrument 639 M
 Vito	ENGINE MANAGEME	109 CDI (07-..)	EOBD
 Vito	ENGINE MANAGEME	111 CDI (07-..)	BOSCH EDC
 Vito	ENGINE MANAGEME	111 CDI 4X4 (07-..)	EOBD
 Vito	ENGINE MANAGEME	119 (07-..)	EOBD
 Vito	ENGINE MANAGEME	120 CDI (07-..)	EOBD
 Vito	ENGINE MANAGEME	122 (07-..)	EOBD
 Vito	ENGINE MANAGEME	123 (07-..)	EOBD
 Vito	ENGINE MANAGEME	126 (07-..)	EOBD
 Vito	IGNITION SWITCH	109 CDI (07-..)	EZS
 Vito	IGNITION SWITCH	111 CDI (07-..)	EZS
 Vito	IGNITION SWITCH	111 CDI 4X4 (07-..)	EZS
 Vito	IGNITION SWITCH	115 CDI (07-..)	EZS
 Vito	IGNITION SWITCH	115 CDI 4X4 (07-..)	EZS
 Vito	IGNITION SWITCH	119 (07-..)	EZS
 Vito	IGNITION SWITCH	120 CDI (07-..)	EZS
 Vito	IGNITION SWITCH	122 (07-..)	EZS
 Vito	IGNITION SWITCH	123 (07-..)	EZS
 Vito	IGNITION SWITCH	126 (07-..)	EZS
 Vito	LEFT FRONT DOOR	109 CDI (07-..)	TEMIC TSG-VL
 Vito	LEFT FRONT DOOR	111 CDI (07-..)	TEMIC TSG-VL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Vito	LEFT FRONT DOOR	111 CDI 4X4 (07-..)	TEMIC TSG-VL
 Vito	LEFT FRONT DOOR	115 CDI (07-..)	TEMIC TSG-VL
 Vito	LEFT FRONT DOOR	115 CDI 4X4 (07-..)	TEMIC TSG-VL
 Vito	LEFT FRONT DOOR	119 (07-..)	TEMIC TSG-VL
 Vito	LEFT FRONT DOOR	120 CDI (07-..)	TEMIC TSG-VL
 Vito	LEFT FRONT DOOR	122 (07-..)	TEMIC TSG-VL
 Vito	LEFT FRONT DOOR	123 (07-..)	TEMIC TSG-VL
 Vito	LEFT FRONT DOOR	126 (07-..)	TEMIC TSG-VL
 Vito	MAINTENANCE	109 CDI (03-07)	MANUAL
 Vito	MAINTENANCE	111 CDI (03-07)	MANUAL
 Vito	MAINTENANCE	111 CDI 4X4 (03-07)	MANUAL
 Vito	MAINTENANCE	115 CDI (03-07)	MANUAL
 Vito	MAINTENANCE	115 CDI 4X4 (03-07)	MANUAL
 Vito	MAINTENANCE	119 (03-07)	MANUAL
 Vito	MAINTENANCE	120 CDI (03-07)	MANUAL
 Vito	MAINTENANCE	122 (03-07)	MANUAL
 Vito	MAINTENANCE	123 (03-07)	MANUAL
 Vito	MAINTENANCE	126 (03-07)	MANUAL
 Vito	RATIO SEL. MANAGE	109 CDI (07-..)	EWM
 Vito	RATIO SEL. MANAGE	111 CDI (07-..)	EWM
 Vito	RATIO SEL. MANAGE	111 CDI 4X4 (07-..)	EWM
 Vito	RATIO SEL. MANAGE	115 CDI (07-..)	EWM
 Vito	RATIO SEL. MANAGE	115 CDI 4X4 (07-..)	EWM
 Vito	RATIO SEL. MANAGE	119 (07-..)	EWM
 Vito	RATIO SEL. MANAGE	120 CDI (07-..)	EWM
 Vito	RATIO SEL. MANAGE	122 (07-..)	EWM
 Vito	RATIO SEL. MANAGE	123 (07-..)	EWM
 Vito	RATIO SEL. MANAGE	126 (07-..)	EWM
 Vito	RIGHT FRONT DOOR	109 CDI (07-..)	TEMIC TSG-VR
 Vito	RIGHT FRONT DOOR	111 CDI (07-..)	TEMIC TSG-VR
 Vito	RIGHT FRONT DOOR	111 CDI 4X4 (07-..)	TEMIC TSG-VR
 Vito	RIGHT FRONT DOOR	115 CDI (07-..)	TEMIC TSG-VR
 Vito	RIGHT FRONT DOOR	115 CDI 4X4 (07-..)	TEMIC TSG-VR
 Vito	RIGHT FRONT DOOR	119 (07-..)	TEMIC TSG-VR
 Vito	RIGHT FRONT DOOR	120 CDI (07-..)	TEMIC TSG-VR
 Vito	RIGHT FRONT DOOR	122 (07-..)	TEMIC TSG-VR
 Vito	RIGHT FRONT DOOR	123 (07-..)	TEMIC TSG-VR
 Vito	RIGHT FRONT DOOR	126 (07-..)	TEMIC TSG-VR
 Vito	SERVICE LIGHT RES	109 CDI (03-07)	MANUAL
 Vito	SERVICE LIGHT RES	111 CDI (03-07)	MANUAL
 Vito	SERVICE LIGHT RES	111 CDI 4X4 (03-07)	MANUAL
 Vito	SERVICE LIGHT RES	115 CDI (03-07)	MANUAL
 Vito	SERVICE LIGHT RES	115 CDI 4X4 (03-07)	MANUAL
 Vito	SERVICE LIGHT RES	119 (03-07)	MANUAL
 Vito	SERVICE LIGHT RES	120 CDI (03-07)	MANUAL
 Vito	SERVICE LIGHT RES	122 (03-07)	MANUAL
 Vito	SERVICE LIGHT RES	123 (03-07)	MANUAL
 Vito	SERVICE LIGHT RES	126 (03-07)	MANUAL
 Vito	SUSPENSION CONTR	109 CDI (07-..)	WEHRLE ENR
 Vito	SUSPENSION CONTR	111 CDI (07-..)	WEHRLE ENR
 Vito	SUSPENSION CONTR	111 CDI 4X4 (07-..)	WEHRLE ENR
 Vito	SUSPENSION CONTR	115 CDI (07-..)	WEHRLE ENR
 Vito	SUSPENSION CONTR	115 CDI 4X4 (07-..)	WEHRLE ENR
 Vito	SUSPENSION CONTR	119 (07-..)	WEHRLE ENR
 Vito	SUSPENSION CONTR	120 CDI (07-..)	WEHRLE ENR
 Vito	SUSPENSION CONTR	122 (07-..)	WEHRLE ENR
 Vito	SUSPENSION CONTR	123 (07-..)	WEHRLE ENR
 Vito	SUSPENSION CONTR	126 (07-..)	WEHRLE ENR

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 X204 GLK-Class	ABS + TRACT. CONT	200 CDI BlueEfficiency (09-..)	Teves ESP
 X204 GLK-Class	ABS + TRACT. CONT	220 Bluetec (09-..)	Teves ESP
 X204 GLK-Class	ABS + TRACT. CONT	220 CDI BlueEfficiency (09-..)	Teves ESP
 X204 GLK-Class	ABS + TRACT. CONT	250 Bluetec (09-..)	Teves ESP
 X204 GLK-Class	ABS + TRACT. CONT	250 CDI BlueEfficiency (09-..)	Teves ESP
 X204 GLK-Class	ABS + TRACT. CONT	320 CDI (09-..)	Teves ESP
 X204 GLK-Class	ABS + TRACT. CONT	350 BlueEfficiency (09-..)	Teves ESP
 X204 GLK-Class	ABS + TRACT. CONT	350 CDI (09-..)	Teves ESP
 X204 GLK-Class	ABS + TRACT. CONT	350 CDI BlueEfficiency (09-..)	Teves ESP
 X204 GLK-Class	AUTOM. TRANSMISSI	220 Bluetec (09-..)	Siemens EGS 53
 X204 GLK-Class	AUTOM. TRANSMISSI	220 CDI BlueEfficiency (09-..)	Siemens EGS 53
 X204 GLK-Class	AUTOM. TRANSMISSI	250 Bluetec (09-..)	Siemens EGS 53
 X204 GLK-Class	AUTOM. TRANSMISSI	250 CDI BlueEfficiency (09-..)	Siemens EGS 53
 X204 GLK-Class	AUTOM. TRANSMISSI	320 CDI (09-..)	Siemens EGS 53
 X204 GLK-Class	AUTOM. TRANSMISSI	350 BlueEfficiency (09-..)	Siemens EGS 53
 X204 GLK-Class	AUTOM. TRANSMISSI	350 CDI (09-..)	Siemens EGS 53
 X204 GLK-Class	AUTOM. TRANSMISSI	350 CDI BlueEfficiency (09-..)	Siemens EGS 53
 X204 GLK-Class	CLIMA	200 CDI BlueEfficiency (09-..)	VDO KLA
 X204 GLK-Class	CLIMA	220 Bluetec (09-..)	VDO KLA
 X204 GLK-Class	CLIMA	220 CDI BlueEfficiency (09-..)	VDO KLA
 X204 GLK-Class	CLIMA	250 Bluetec (09-..)	VDO KLA
 X204 GLK-Class	CLIMA	250 CDI BlueEfficiency (09-..)	VDO KLA
 X204 GLK-Class	CLIMA	320 CDI (09-..)	VDO KLA
 X204 GLK-Class	CLIMA	350 BlueEfficiency (09-..)	VDO KLA
 X204 GLK-Class	CLIMA	350 CDI BlueEfficiency (09-..)	VDO KLA
 X204 GLK-Class	MAINTENANCE	200 CDI BlueEfficiency (09-..)	Teves ESP
 X204 GLK-Class	MAINTENANCE	200 CDI BlueEfficiency (09-..)	VDO KLA
 X204 GLK-Class	MAINTENANCE	220 Bluetec (09-..)	Teves ESP
 X204 GLK-Class	MAINTENANCE	220 Bluetec (09-..)	VDO KLA
 X204 GLK-Class	MAINTENANCE	220 CDI BlueEfficiency (09-..)	Teves ESP
 X204 GLK-Class	MAINTENANCE	220 CDI BlueEfficiency (09-..)	VDO KLA
 X204 GLK-Class	MAINTENANCE	250 Bluetec (09-..)	Teves ESP
 X204 GLK-Class	MAINTENANCE	250 Bluetec (09-..)	VDO KLA
 X204 GLK-Class	MAINTENANCE	250 CDI BlueEfficiency (09-..)	Teves ESP
 X204 GLK-Class	MAINTENANCE	250 CDI BlueEfficiency (09-..)	VDO KLA
 X204 GLK-Class	MAINTENANCE	320 CDI (09-..)	Teves ESP
 X204 GLK-Class	MAINTENANCE	320 CDI (09-..)	VDO KLA
 X204 GLK-Class	MAINTENANCE	350 BlueEfficiency (09-..)	Teves ESP
 X204 GLK-Class	MAINTENANCE	350 BlueEfficiency (09-..)	VDO KLA
 X204 GLK-Class	MAINTENANCE	350 CDI (09-..)	Teves ESP
 X204 GLK-Class	MAINTENANCE	350 CDI BlueEfficiency (09-..)	Teves ESP
 X204 GLK-Class	MAINTENANCE	350 CDI BlueEfficiency (09-..)	VDO KLA
 X204 GLK-Class	PARKING HELP	200 CDI BlueEfficiency (09-..)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

MG

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 ZT 160	AIRBAG	1.8	TEMIC AirBag
 ZT 190	AIRBAG	2.5 V6	TEMIC AirBag
 ZT 190	ENGINE MANAGEME	2.5 V6	EMS 2000
 ZT CDTi	AIRBAG	2.0 CDTI	TEMIC AirBag
 ZT CDTi	ENGINE MANAGEME	2.0 CDTI	BOSCH EDC 15 C4 Common Rail

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mini

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Mini Cooper (R50-R52-R53)	ABS + TRACT. CONT	1.6 16v 116cv (01-05)	TEVES ABS/ABR Mk60
 Mini Cooper (R50-R52-R53)	AIRBAG	1.6 16v 116cv (01-05)	TEMIC AirBag MRS4
 Mini Cooper (R50-R52-R53)	DASHBOARD	1.6 16v 116cv (01-05)	VDO Kombinstrum+Service KOM
 Mini Cooper (R50-R52-R53)	ELECTRIC STEERING	1.6 16v 116cv (01-05)	EHPS
 Mini Cooper (R50-R52-R53)	ENGINE MANAGEME	1.6 16v 116cv (01-05)	SIEMENS EMS 2000 DME
 Mini Cooper (R50-R52-R53)	IMMOBILIZER	1.6 16v 116cv (01-05)	Kostal Immobilizer EWSIII
 Mini Cooper (R50-R52-R53)	MAINTENANCE	1.6 16v 116cv (01-05)	MANUAL
 Mini Cooper (R50-R52-R53)	MAINTENANCE	1.6 16v 116cv (01-05)	SIEMENS EMS 2000 DME
 Mini Cooper (R50-R52-R53)	MAINTENANCE	1.6 16v 116cv (01-05)	VDO Kombinstrum+Service KOM
 Mini Cooper (R50-R52-R53)	MAINTENANCE	1.6 16v 116cv (01-05)	VDO Kombinstrum+Service KOM
 Mini Cooper (R50-R52-R53)	MAINTENANCE	1.6 16v 116cv (01-05)	VDO Kombinstrum+Service KOM
 Mini Cooper (R50-R52-R53)	RADIO / CD	1.6 16v 116cv (01-05)	RAD SoundSystem
 Mini Cooper (R50-R52-R53)	SERVICE LIGHT RES	1.6 16v 116cv (01-05)	MANUAL
 Mini Cooper (R55-R56-R57-	DASHBOARD	1.6 16v (09-..)	KOMB56
 Mini Cooper (R55-R56-R57-	IMMOBILIZER	1.6 16v (09-..)	CAS
 Mini Cooper (R55-R56-R57-	MAINTENANCE	1.6 16v (07-10)	
 Mini Cooper (R55-R56-R57-	MAINTENANCE	1.6 16v (07-10)	
 Mini Cooper (R55-R56-R57-	NAVIGATION	1.6 16v (09-..)	CICMR
 Mini Cooper (R55-R56-R57-	SERVICE LIGHT RES	1.6 16v (07-10)	
 Mini Cooper (R55-R56-R57-	SERVICE LIGHT RES	1.6 16v (07-10)	
 Mini Cooper (R55-R56-R57-	STEERING COLUMN	1.6 16v (09-..)	SZL56
 Mini Cooper (R55-R56-R57-	VISUAL./TELEMATIC	1.6 16v (09-..)	Info Display CID90
 Mini Cooper D (R55-R56-R	DASHBOARD	1.6 D (09-..)	KOMB56
 Mini Cooper D (R55-R56-R	DASHBOARD	2.0 D (09-..)	KOMB56
 Mini Cooper D (R55-R56-R	ENGINE MANAGEME	1.6 D (09-..)	DDE 7.01
 Mini Cooper D (R55-R56-R	ENGINE MANAGEME	2.0 D (09-..)	DDE 7.01
 Mini Cooper D (R55-R56-R	IMMOBILIZER	1.6 D (09-..)	CAS
 Mini Cooper D (R55-R56-R	IMMOBILIZER	2.0 D (09-..)	CAS
 Mini Cooper D (R55-R56-R	MAINTENANCE	1.6 D (07-10)	
 Mini Cooper D (R55-R56-R	MAINTENANCE	1.6 D (07-10)	
 Mini Cooper D (R55-R56-R	MAINTENANCE	2.0 D (07-10)	
 Mini Cooper D (R55-R56-R	MAINTENANCE	2.0 D (07-10)	
 Mini Cooper D (R55-R56-R	NAVIGATION	1.6 D (09-..)	CICMR
 Mini Cooper D (R55-R56-R	NAVIGATION	2.0 D (09-..)	CICMR
 Mini Cooper D (R55-R56-R	SERVICE LIGHT RES	1.6 D (07-10)	
 Mini Cooper D (R55-R56-R	SERVICE LIGHT RES	1.6 D (07-10)	
 Mini Cooper D (R55-R56-R	SERVICE LIGHT RES	2.0 D (07-10)	
 Mini Cooper D (R55-R56-R	SERVICE LIGHT RES	2.0 D (07-10)	
 Mini Cooper D (R55-R56-R	STEERING COLUMN	1.6 D (09-..)	SZL56
 Mini Cooper D (R55-R56-R	STEERING COLUMN	2.0 D (09-..)	SZL56
 Mini Cooper D (R55-R56-R	VISUAL./TELEMATIC	1.6 D (09-..)	Info Display CID90
 Mini Cooper D (R55-R56-R	VISUAL./TELEMATIC	2.0d (09-..)	Info Display CID90
 Mini Cooper S (R50-R52-R	ABS + TRACT. CONT	1.6 16v 163cv (02-06)	TEVES ABS/ABR Mk60
 Mini Cooper S (R50-R52-R	AIRBAG	1.6 16v 163cv (02-03)	TEMIC AirBag MRS4
 Mini Cooper S (R50-R52-R	DASHBOARD	1.6 16v 163cv (02-06)	VDO Kombinstrum+Service KOM
 Mini Cooper S (R50-R52-R	ELECTRIC STEERING	1.6 16v 163cv (01-06)	EHPS
 Mini Cooper S (R50-R52-R	ENGINE MANAGEME	1.6 16v 163cv (01-..)	EOBD
 Mini Cooper S (R50-R52-R	ENGINE MANAGEME	1.6 16v 163cv (02-06)	SIEMENS EMS 2000 DME
 Mini Cooper S (R50-R52-R	IMMOBILIZER	1.6 16v 163cv (02-03)	Kostal Immobilizer EWSIII
 Mini Cooper S (R50-R52-R	MAINTENANCE	1.6 16v 163cv (02-06)	MANUAL
 Mini Cooper S (R50-R52-R	MAINTENANCE	1.6 16v 163cv (02-06)	SIEMENS EMS 2000 DME
 Mini Cooper S (R50-R52-R	MAINTENANCE	1.6 16v 163cv (02-06)	VDO Kombinstrum+Service KOM
 Mini Cooper S (R50-R52-R	MAINTENANCE	1.6 16v 163cv (02-06)	VDO Kombinstrum+Service KOM
 Mini Cooper S (R50-R52-R	MAINTENANCE	1.6 16v 163cv (02-06)	VDO Kombinstrum+Service KOM
 Mini Cooper S (R50-R52-R	RADIO / CD	1.6 16v 163cv (02-06)	RAD SoundSystem
 Mini Cooper S (R50-R52-R	SERVICE LIGHT RES	1.6 16v 163cv (02-06)	MANUAL
 Mini Cooper S (R55-R56-R	DASHBOARD	1.6 16v (09-..)	KOMB56

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mini

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Mini Cooper S (R55-R56-R	IMMOBILIZER	1.6 16v (09-..)	CAS
 Mini Cooper S (R55-R56-R	MAINTENANCE	1.6 16v (07-10)	
 Mini Cooper S (R55-R56-R	MAINTENANCE	1.6 16v (07-10)	
 Mini Cooper S (R55-R56-R	NAVIGATION	1.6 16v (09-..)	CICMR
 Mini Cooper S (R55-R56-R	SERVICE LIGHT RES	1.6 16v (07-10)	
 Mini Cooper S (R55-R56-R	SERVICE LIGHT RES	1.6 16v (07-10)	
 Mini Cooper S (R55-R56-R	STEERING COLUMN	1.6 16v (09-..)	SZL56
 Mini Cooper S (R55-R56-R	VISUAL./TELEMATIC	1.6 16v (09-..)	Info Display CID90
 Mini Cooper SD (R55-R56-	DASHBOARD	2.0 D (09-..)	KOMB56
 Mini Cooper SD (R55-R56-	ENGINE MANAGEME	2.0 D (09-..)	DDE 7.01
 Mini Cooper SD (R55-R56-	IMMOBILIZER	2.0 D (09-..)	CAS
 Mini Cooper SD (R55-R56-	MAINTENANCE	2.0 D (07-10)	
 Mini Cooper SD (R55-R56-	MAINTENANCE	2.0 D (07-10)	
 Mini Cooper SD (R55-R56-	NAVIGATION	2.0 D (09-..)	CICMR
 Mini Cooper SD (R55-R56-	SERVICE LIGHT RES	2.0 D (07-10)	
 Mini Cooper SD (R55-R56-	SERVICE LIGHT RES	2.0 D (07-10)	
 Mini Cooper SD (R55-R56-	STEERING COLUMN	2.0 D (09-..)	SZL56
 Mini Cooper SD (R55-R56-	VISUAL./TELEMATIC	2.0 D (09-..)	Info Display CID90
 Mini JCW (R55-R56-R57-R	DASHBOARD	1.6 16v (09-..)	KOMB56
 Mini JCW (R55-R56-R57-R	IMMOBILIZER	1.6 16v (09-..)	CAS
 Mini JCW (R55-R56-R57-R	MAINTENANCE	1.6 16v (07-10)	
 Mini JCW (R55-R56-R57-R	MAINTENANCE	1.6 16v (07-10)	
 Mini JCW (R55-R56-R57-R	NAVIGATION	1.6 16v (09-..)	CICMR
 Mini JCW (R55-R56-R57-R	SERVICE LIGHT RES	1.6 16v (07-10)	
 Mini JCW (R55-R56-R57-R	SERVICE LIGHT RES	1.6 16v (07-10)	
 Mini JCW (R55-R56-R57-R	STEERING COLUMN	1.6 16v (09-..)	SZL56
 Mini JCW (R55-R56-R57-R	VISUAL./TELEMATIC	1.6 16v (09-..)	Info Display CID90
 Mini One (R50-R52-R53)	ABS + TRACT. CONT	1.6 16v 90cv (01-05)	TEVES ABS/ABR Mk60
 Mini One (R50-R52-R53)	AIRBAG	1.6 16v 90cv (01-05)	TEMIC AirBag MRS4
 Mini One (R50-R52-R53)	DASHBOARD	1.6 16v 90cv (01-05)	VDO Kombinstrum+Service KOM
 Mini One (R50-R52-R53)	ELECTRIC STEERING	1.6 16v 90cv (01-05)	EHPS
 Mini One (R50-R52-R53)	ENGINE MANAGEME	1.6 16v 90cv (01-..)	EOBD
 Mini One (R50-R52-R53)	ENGINE MANAGEME	1.6 16v 90cv (01-05)	SIEMENS EMS 2000 DME
 Mini One (R50-R52-R53)	IMMOBILIZER	1.6 16v 90cv (01-05)	Kostal Immobilizer EWSIII
 Mini One (R50-R52-R53)	MAINTENANCE	1.6 16v 90cv (01-05)	MANUAL
 Mini One (R50-R52-R53)	MAINTENANCE	1.6 16v 90cv (01-05)	SIEMENS EMS 2000 DME
 Mini One (R50-R52-R53)	MAINTENANCE	1.6 16v 90cv (01-05)	VDO Kombinstrum+Service KOM
 Mini One (R50-R52-R53)	MAINTENANCE	1.6 16v 90cv (01-05)	VDO Kombinstrum+Service KOM
 Mini One (R50-R52-R53)	MAINTENANCE	1.6 16v 90cv (01-05)	VDO Kombinstrum+Service KOM
 Mini One (R50-R52-R53)	RADIO / CD	1.6 16v 90cv (01-05)	RAD SoundSystem
 Mini One (R50-R52-R53)	SERVICE LIGHT RES	1.6 16v 90cv (01-05)	MANUAL
 Mini One (R55-R56-R57-R5	DASHBOARD	1.6 (09-..)	KOMB56
 Mini One (R55-R56-R57-R5	IMMOBILIZER	1.6 (09-..)	CAS
 Mini One (R55-R56-R57-R5	MAINTENANCE	1.6 (07-10)	
 Mini One (R55-R56-R57-R5	NAVIGATION	1.6 (09-..)	CICMR
 Mini One (R55-R56-R57-R5	SERVICE LIGHT RES	1.6 (07-10)	
 Mini One (R55-R56-R57-R5	STEERING COLUMN	1.6 (09-..)	SZL56
 Mini One (R55-R56-R57-R5	VISUAL./TELEMATIC	1.6 (09-..)	Info Display CID90
 Mini One D (R50-R52-R53)	ABS + TRACT. CONT	1.4 TDI (04-06)	TEVES ABS/ABR Mk60
 Mini One D (R50-R52-R53)	AIRBAG	1.4 TDI (04-06)	TEMIC AirBag MRS4
 Mini One D (R50-R52-R53)	DASHBOARD	1.4 TDI (04-06)	VDO Kombinstrum+Service KOM
 Mini One D (R50-R52-R53)	ELECTRIC STEERING	1.4 TDI (04-06)	EHPS
 Mini One D (R50-R52-R53)	ENGINE MANAGEME	1.4 TDI (04-06)	DDE
 Mini One D (R50-R52-R53)	IMMOBILIZER	1.4 TDI (04-06)	Kostal Immobilizer EWSIII
 Mini One D (R50-R52-R53)	MAINTENANCE	1.4 TDI (04-06)	MANUAL
 Mini One D (R50-R52-R53)	MAINTENANCE	1.4 TDI (04-06)	VDO Kombinstrum+Service KOM
 Mini One D (R50-R52-R53)	MAINTENANCE	1.4 TDI (04-06)	VDO Kombinstrum+Service KOM

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mini

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Mini One D (R50-R52-R53)	MAINTENANCE	1.4 TDI (04-06)	VDO Kombinstrum+Service KOM
 Mini One D (R50-R52-R53)	RADIO / CD	1.4 TDI (04-06)	RAD SoundSystem
 Mini One D (R50-R52-R53)	SERVICE LIGHT RES	1.4 TDI (04-06)	MANUAL
 Mini One D (R55-R56-R57-	DASHBOARD	1.6 D (09-..)	KOMB56
 Mini One D (R55-R56-R57-	ENGINE MANAGEME	1.6 D (09-..)	DDE 7.01
 Mini One D (R55-R56-R57-	IMMOBILIZER	1.6 D (09-..)	CAS
 Mini One D (R55-R56-R57-	MAINTENANCE	1.6 D (07-10)	
 Mini One D (R55-R56-R57-	MAINTENANCE	1.6 D (07-10)	
 Mini One D (R55-R56-R57-	NAVIGATION	1.6 D (09-..)	CICMR
 Mini One D (R55-R56-R57-	SERVICE LIGHT RES	1.6 D (07-10)	
 Mini One D (R55-R56-R57-	SERVICE LIGHT RES	1.6 D (07-10)	
 Mini One D (R55-R56-R57-	STEERING COLUMN	1.6 D (09-..)	SZL56
 Mini One D (R55-R56-R57-	VISUAL./TELEMATIC	1.6 D (09-..)	Info Display CID90

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Mitsubishi

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Avenger	AIRBAG	(01-..)	AirBag
 Carisma	ENGINE MANAGEME	1.6 (01-..)	EOBD
 Carisma	ENGINE MANAGEME	1.8 4G93 (01-..)	EOBD
 Carisma	ENGINE MANAGEME	1.9 DI-D (04-..)	EOBD
 Colt	ENGINE MANAGEME	1.3 4G13 (01-..)	EOBD
 Colt	ENGINE MANAGEME	1.6 (01-..)	EOBD
 Eclipse	AIRBAG	2.4 (01-..)	AirBag
 Eclipse	AIRBAG	3.8 (01-..)	AirBag
 Eclipse	ENGINE MANAGEME	1.8 i 4G37 (91-95)	Mitsubishi MFI-s MANUAL ECI-Multi
 Eclipse	MAINTENANCE	1.8 i 4G37 (91-95)	Mitsubishi MFI-s MANUAL ECI-Multi
 Galant	ENGINE MANAGEME	2.0 (01-..)	EOBD
 Galant	ENGINE MANAGEME	2.4 GDI 4G64 (01-..)	EOBD
 Galant	ENGINE MANAGEME	2.5 V6 (01-..)	EOBD
 L200	ABS + TRACT. CONT	2.5 DI-D (07-..)	ABS
 L200	AIRBAG	2.4 V6 (00-05)	TAKATA AirBag SRS
 L200	AIRBAG	2.5 DI-D (07-..)	SRS
 L200	AIRBAG	2.5 TDI (00-05)	TAKATA AirBag SRS
 L200	CENTRAL ELECTRIC	2.5 DI-D (07-..)	Power Window (LUN)
 L200	CHASSIS NETWORK	2.5 DI-D (07-..)	Body Computer ETACS
 L200	CLIMA	2.5 DI-D (07-..)	Climate Control
 L200	DRIVER SIDE DOOR	2.5 DI-D (07-..)	Power Window (G)
 L200	ENGINE MANAGEME	2.4 V6 (98-..)	EOBD
 L200	ENGINE MANAGEME	2.5 DI-D (07-..)	EDC
 L200	ENGINE MANAGEME	2.5 TDI (00-05)	Mitsubishi EDC
 L200	IMMOBILIZER	2.5 DI-D (07-..)	Immobilizer
 L200	LEFT REAR DOOR	2.5 DI-D (07-..)	Power Window (PSX)
 L200	MAINTENANCE	2.5 DI-D (07-..)	SAS Angle steering calibration
 L200	MAINTENANCE	2.5 DI-D (07-..)	SAS Angle steering calibration
 L200	PASS. SIDE DOOR	2.5 DI-D (07-..)	Power Window (P)
 L200	RIGHT REAR DOOR	2.5 DI-D (07-..)	Power Window (RDX)
 L200	STEERING COLUMN	2.5 DI-D (07-..)	SAS Angle steering calibration
 Lancer Evo	AIRBAG	2.0 16v (03-..)	AirBag SRS
 Lancer Wagon	AIRBAG	1.6 16v (04-..)	AirBag SRS
 Lancer Wagon	AIRBAG	2.0 16v (04-..)	AirBag SRS
 Lancer	AIRBAG	1.3 16v (01-03)	AirBag SRS
 Lancer	AIRBAG	1.3 16v (03-..)	AirBag SRS
 Lancer	AIRBAG	1.6 16v (01-03)	AirBag SRS
 Lancer	AIRBAG	1.6 16v (03-..)	AirBag SRS
 Lancer	AIRBAG	2.0 16v (01-03)	AirBag SRS
 Lancer	AIRBAG	2.0 16v (03-..)	AirBag SRS
 Lancer	ENGINE MANAGEME	1.5 12v 4G15 (91-95)	Mitsubishi MFI-s MANUAL ECI-Multi
 Lancer	MAINTENANCE	1.5 12v 4G15 (91-95)	Mitsubishi MFI-s MANUAL ECI-Multi
 Outlander	MAINTENANCE	2.2 DI-D 156cv	
 Outlander	MAINTENANCE	2.2 DI-D 177cv	
 Outlander	SERVICE LIGHT RES	2.2 DI-D 156cv	
 Outlander	SERVICE LIGHT RES	2.2 DI-D 177cv	
 Pajero Pinin	ENGINE MANAGEME	1.8 4G93 (02-..)	EOBD
 Pajero Sport	AIRBAG	2.5 TDI (00-06)	TAKATA SRS
 Pajero Sport	ENGINE MANAGEME	2.5 TDI (..-05)	Mitsubishi EDC
 Pajero Sport	ENGINE MANAGEME	2.5 TDI (00-06)	Mitsubishi EDC
 Pajero Sport	ENGINE MANAGEME	3.0 (01-..)	EOBD
 Pajero	ABS + TRACT. CONT	3.2 DI-D (05-..)	AINIS ABS
 Pajero	AIRBAG	2.5 TDI (00-05)	TAKATA SRS
 Pajero	AIRBAG	3.2 DI-D (00-05)	TAKATA SRS
 Pajero	ENGINE MANAGEME	2.5 TDI (00-06)	Mitsubishi EDC

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS			Mitsubishi
MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Pajero	ENGINE MANAGEME	3.2 DI-D (00-06)	Mitsubishi EDC Direct Injection
 Pajero	ENGINE MANAGEME	3.5 GDI (01-..)	EOBD
 Space Gear	ENGINE MANAGEME	2.0 4G63 (00-..)	EOBD
 Space Runner	ENGINE MANAGEME	2.0 (01-..)	EOBD
 Space Runner	ENGINE MANAGEME	2.4 GDI (01-..)	EOBD
 Space Star	ENGINE MANAGEME	1.3 16v (01-..)	EOBD
 Space Star	ENGINE MANAGEME	1.6 16v (01-..)	EOBD
 Space Star	ENGINE MANAGEME	1.8 GDI 4G93 (01-..)	EOBD
 Space Star	ENGINE MANAGEME	1.9 DI-D	BOSCH EDC 15 C3 Common Rail
 Space Star	ENGINE MANAGEME	1.9 DI-D (04-..)	EOBD
 Space Wagon	ENGINE MANAGEME	2.4 GDI 4G64 (02-..)	EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

MULTICAR

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 M26	ENGINE MANAGEME	8140	BOSCH EDC MS 6.3 CR
 M30	ENGINE MANAGEME	8140	BOSCH EDC MS 6.3 CR

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Nissan

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 100NX	ENGINE MANAGEME	1.6 GA16DE (91-..)	Nissan ECCS MANUAL
 100NX	ENGINE MANAGEME	2.0 SR20xx (91-..)	Nissan ECCS MANUAL
 100NX	MAINTENANCE	1.6 GA16DE (91-..)	Nissan ECCS MANUAL
 100NX	MAINTENANCE	2.0 SR20xx (91-..)	Nissan ECCS MANUAL
 Almera Tino	ENGINE MANAGEME	1.8 16v QG18DE (00-..)	Denso ECCS
 Almera Tino	ENGINE MANAGEME	2.0 100kw A/T (01-..)	EOBD
 Almera Tino	ENGINE MANAGEME	2.2 Diesel YD22 (04-..)	EOBD
 Almera	ENGINE MANAGEME	1.4 GA14DE (91-..)	Nissan ECCS MANUAL
 Almera	ENGINE MANAGEME	1.5 16v QG15DE (00-..)	Denso ECCS
 Almera	ENGINE MANAGEME	1.5 66kw (00/01-..)	EOBD
 Almera	ENGINE MANAGEME	1.5 dCi 65cv K9K (02-..)	DELPHI LUCAS LVCR Common Rail
 Almera	ENGINE MANAGEME	1.6 GA16DE (91-..)	Nissan ECCS MANUAL
 Almera	ENGINE MANAGEME	1.8 (00/01-..)	EOBD
 Almera	ENGINE MANAGEME	1.8 16v QG18DE (00-..)	Denso ECCS
 Almera	ENGINE MANAGEME	2.0 D CD20X (91-..)	BOSCH EDC MANUAL
 Almera	ENGINE MANAGEME	2.0 SR20xx (91-..)	Nissan ECCS MANUAL
 Almera	MAINTENANCE	1.4 GA14DE (91-..)	Nissan ECCS MANUAL
 Almera	MAINTENANCE	1.6 GA16DE (91-..)	Nissan ECCS MANUAL
 Almera	MAINTENANCE	2.0 D CD20X (91-..)	BOSCH EDC MANUAL
 Almera	MAINTENANCE	2.0 SR20xx (91-..)	Nissan ECCS MANUAL
 Atleon	ENGINE MANAGEME	3.0 TD	BOSCH EDC MSA 15
 Atleon	IMMOBILIZER	3.0 TD	NATS
 Cabstar	ENGINE MANAGEME	3.0 TD	BOSCH EDC MSA 15
 Cabstar	IMMOBILIZER	3.0 TD	NATS
 Interstar	ABS	1.9 dCi 60kw	TEVES ABS MK20T
 Interstar	ABS	1.9 dCi 60kw (01-..)	TEVES ABS Mk60
 Interstar	ABS	1.9 dTi 59kw	TEVES ABS MK20T
 Interstar	ABS	1.9 dTi 59kw (01-..)	TEVES ABS Mk60
 Interstar	ABS	2.1 D 60kw	TEVES ABS MK20T
 Interstar	ABS	2.1 D 60kw (01-..)	TEVES ABS Mk60
 Interstar	ABS	2.2 16v dCi 66kw	TEVES ABS MK20T
 Interstar	ABS	2.2 16v dCi 66kw (01-..)	TEVES ABS Mk60
 Interstar	ABS	2.2 67kw	TEVES ABS MK20T
 Interstar	ABS	2.2 67kw (01-..)	TEVES ABS Mk60
 Interstar	ABS	2.2 71kw	TEVES ABS MK20T
 Interstar	ABS	2.2 71kw (01-..)	TEVES ABS Mk60
 Interstar	ABS	2.5 D 59kw	TEVES ABS MK20T
 Interstar	ABS	2.5 D 59kw (01-..)	TEVES ABS Mk60
 Interstar	ABS	2.5 dCi 16v 107kw	TEVES ABS MK20T
 Interstar	ABS	2.5 dCi 16v 107kw (01-..)	TEVES ABS Mk60
 Interstar	ABS	2.5 dCi 74kw	TEVES ABS MK20T
 Interstar	ABS	2.5 dCi 74kw (01-..)	TEVES ABS Mk60
 Interstar	ABS	2.5 dCi 85kw	TEVES ABS MK20T
 Interstar	ABS	2.5 dCi 85kw (01-..)	TEVES ABS Mk60
 Interstar	ABS	2.5 dCi 88kw	TEVES ABS MK20T
 Interstar	ABS	2.5 dCi 88kw (01-..)	TEVES ABS Mk60
 Interstar	ABS	2.8 DTI 84kw	TEVES ABS MK20T
 Interstar	ABS	2.8 DTI 84kw (01-..)	TEVES ABS Mk60
 Interstar	ABS	2.8 DTI 85kw	TEVES ABS MK20T
 Interstar	ABS	2.8 DTI 85kw (01-..)	TEVES ABS Mk60
 Interstar	ABS	3.0 dCi 100Kw	TEVES ABS MK20T
 Interstar	ABS	3.0 dCi 100Kw (01-..)	TEVES ABS Mk60
 Interstar	AIRBAG	1.9 dCi 60kw	SAGEM - Autoliv AirBag ACU 3
 Interstar	AIRBAG	1.9 dCi 60kw	SIEMENS - Autoliv AirBag AC4
 Interstar	AIRBAG	1.9 dCi 60kw	SIEMENS - Autoliv AirBag EC5
 Interstar	AIRBAG	1.9 dTi 59kw	SAGEM - Autoliv AirBag ACU 3
 Interstar	AIRBAG	1.9 dTi 59kw	SIEMENS - Autoliv AirBag AC4

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Nissan

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Interstar	AIRBAG	1.9 dTi 59kw	SIEMENS - Autoliv AirBag EC5
 Interstar	AIRBAG	2.1 D 60kw	SAGEM - Autoliv AirBag ACU 3
 Interstar	AIRBAG	2.1 D 60kw	SIEMENS - Autoliv AirBag AC4
 Interstar	AIRBAG	2.1 D 60kw	SIEMENS - Autoliv AirBag EC5
 Interstar	AIRBAG	2.2 16v dCi 66kw	SAGEM - Autoliv AirBag ACU 3
 Interstar	AIRBAG	2.2 16v dCi 66kw	SIEMENS - Autoliv AirBag AC4
 Interstar	AIRBAG	2.2 16v dCi 66kw	SIEMENS - Autoliv AirBag EC5
 Interstar	AIRBAG	2.2 67kw	SAGEM - Autoliv AirBag ACU 3
 Interstar	AIRBAG	2.2 67kw	SIEMENS - Autoliv AirBag AC4
 Interstar	AIRBAG	2.2 67kw	SIEMENS - Autoliv AirBag EC5
 Interstar	AIRBAG	2.2 71kw	SAGEM - Autoliv AirBag ACU 3
 Interstar	AIRBAG	2.2 71kw	SIEMENS - Autoliv AirBag AC4
 Interstar	AIRBAG	2.2 71kw	SIEMENS - Autoliv AirBag EC5
 Interstar	AIRBAG	2.5 D 59kw	SAGEM - Autoliv AirBag ACU 3
 Interstar	AIRBAG	2.5 D 59kw	SIEMENS - Autoliv AirBag AC4
 Interstar	AIRBAG	2.5 D 59kw	SIEMENS - Autoliv AirBag EC5
 Interstar	AIRBAG	2.5 dCi 16v 107kw	SAGEM - Autoliv AirBag ACU 3
 Interstar	AIRBAG	2.5 dCi 16v 107kw	SIEMENS - Autoliv AirBag AC4
 Interstar	AIRBAG	2.5 dCi 16v 107kw	SIEMENS - Autoliv AirBag EC5
 Interstar	AIRBAG	2.5 dCi 74kw	SAGEM - Autoliv AirBag ACU 3
 Interstar	AIRBAG	2.5 dCi 74kw	SIEMENS - Autoliv AirBag AC4
 Interstar	AIRBAG	2.5 dCi 74kw	SIEMENS - Autoliv AirBag EC5
 Interstar	AIRBAG	2.5 dCi 85kw	SAGEM - Autoliv AirBag ACU 3
 Interstar	AIRBAG	2.5 dCi 85kw	SIEMENS - Autoliv AirBag AC4
 Interstar	AIRBAG	2.5 dCi 85kw	SIEMENS - Autoliv AirBag EC5
 Interstar	AIRBAG	2.5 dCi 88kw	SAGEM - Autoliv AirBag ACU 3
 Interstar	AIRBAG	2.5 dCi 88kw	SIEMENS - Autoliv AirBag AC4
 Interstar	AIRBAG	2.5 dCi 88kw	SIEMENS - Autoliv AirBag EC5
 Interstar	AIRBAG	2.8 DTi 84kw	SAGEM - Autoliv AirBag ACU 3
 Interstar	AIRBAG	2.8 DTi 84kw	SIEMENS - Autoliv AirBag AC4
 Interstar	AIRBAG	2.8 DTi 84kw	SIEMENS - Autoliv AirBag EC5
 Interstar	AIRBAG	2.8 DTi 85kw	SAGEM - Autoliv AirBag ACU 3
 Interstar	AIRBAG	2.8 DTi 85kw	SIEMENS - Autoliv AirBag AC4
 Interstar	AIRBAG	2.8 DTi 85kw	SIEMENS - Autoliv AirBag EC5
 Interstar	AIRBAG	3.0 dCi 100Kw	SAGEM - Autoliv AirBag ACU 3
 Interstar	AIRBAG	3.0 dCi 100Kw	SIEMENS - Autoliv AirBag AC4
 Interstar	AIRBAG	3.0 dCi 100Kw	SIEMENS - Autoliv AirBag EC5
 Interstar	AUTOM. TRANSMISSI	2.2 16v dCi 66kw	AUTODETECT
 Interstar	AUTOM. TRANSMISSI	2.5 dCi 16v 107kw	AUTODETECT
 Interstar	AUTOM. TRANSMISSI	2.5 dCi 88kw	AUTODETECT
 Interstar	AUTOM. TRANSMISSI	3.0 dCi 100Kw	AUTODETECT
 Interstar	ENGINE MANAGEME	2.2 16v dCi 66kw G9T-722 (01-..)	BOSCH EDC 15 C3 Common Rail
 Interstar	ENGINE MANAGEME	2.2 67kw J7T-782	SIEMENS MPI
 Interstar	ENGINE MANAGEME	2.2 71kw J7T-788	SIEMENS MPI
 Interstar	ENGINE MANAGEME	2.5 dCi 16v 107kw (04-..)	EOBD
 Interstar	ENGINE MANAGEME	2.5 dCi 88kw G9U-650 (01-..)	BOSCH EDC 15 C3 Common Rail
 Interstar	ENGINE MANAGEME	3.0 dCi 100Kw (04-..)	EOBD
 Interstar	IMMOBILIZER	1.9 dCi 60kw	SAGEM Immobilizer Key encoding
 Interstar	IMMOBILIZER	1.9 dTi 59kw	SAGEM Immobilizer Key encoding
 Interstar	IMMOBILIZER	2.1 D 60kw	SAGEM Immobilizer Key encoding
 Interstar	IMMOBILIZER	2.2 16v dCi 66kw	SAGEM Immobilizer Key encoding
 Interstar	IMMOBILIZER	2.2 67kw	SAGEM Immobilizer Key encoding
 Interstar	IMMOBILIZER	2.2 71kw	SAGEM Immobilizer Key encoding
 Interstar	IMMOBILIZER	2.5 D 59kw	SAGEM Immobilizer Key encoding
 Interstar	IMMOBILIZER	2.5 dCi 16v 107kw	SAGEM Immobilizer Key encoding
 Interstar	IMMOBILIZER	2.5 dCi 74kw	SAGEM Immobilizer Key encoding
 Interstar	IMMOBILIZER	2.5 dCi 88kw	SAGEM Immobilizer Key encoding
 Interstar	IMMOBILIZER	2.8 DTi 84kw	SAGEM Immobilizer Key encoding

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Nissan

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Interstar	IMMOBILIZER	2.8 DTi 85kw	SAGEM Immobilizer Key encoding
 Juke	ABS	1.5 dCi (10-..)	ABS
 Juke	ABS	1.6 (10-..)	ABS
 Juke	AIRBAG	1.5 dCi (10-..)	AirBag
 Juke	AIRBAG	1.6 (10-..)	AirBag
 Juke	ANTITHEFT	1.5 dCi (10-..)	Alarm
 Juke	ANTITHEFT	1.6 (10-..)	Alarm
 Juke	CENTRAL LOCKING	1.5 dCi (10-..)	Lock / unlock doors
 Juke	CENTRAL LOCKING	1.6 (10-..)	Lock / unlock doors
 Juke	CHASSIS NETWORK	1.5 dCi (10-..)	Battery buffer
 Juke	CHASSIS NETWORK	1.5 dCi (10-..)	Battery Saving
 Juke	CHASSIS NETWORK	1.5 dCi (10-..)	Blinker
 Juke	CHASSIS NETWORK	1.5 dCi (10-..)	Buzzer
 Juke	CHASSIS NETWORK	1.5 dCi (10-..)	ECU reset
 Juke	CHASSIS NETWORK	1.5 dCi (10-..)	Heated rear window
 Juke	CHASSIS NETWORK	1.5 dCi (10-..)	Intelligent Key
 Juke	CHASSIS NETWORK	1.5 dCi (10-..)	Interior lights
 Juke	CHASSIS NETWORK	1.5 dCi (10-..)	IPDME-R
 Juke	CHASSIS NETWORK	1.5 dCi (10-..)	Light control lever
 Juke	CHASSIS NETWORK	1.5 dCi (10-..)	Timer power
 Juke	CHASSIS NETWORK	1.5 dCi (10-..)	TRUNK
 Juke	CHASSIS NETWORK	1.5 dCi (10-..)	Wiper
 Juke	CHASSIS NETWORK	1.6 (10-..)	Battery buffer
 Juke	CHASSIS NETWORK	1.6 (10-..)	Battery Saving
 Juke	CHASSIS NETWORK	1.6 (10-..)	Blinker
 Juke	CHASSIS NETWORK	1.6 (10-..)	Buzzer
 Juke	CHASSIS NETWORK	1.6 (10-..)	ECU reset
 Juke	CHASSIS NETWORK	1.6 (10-..)	Heated rear window
 Juke	CHASSIS NETWORK	1.6 (10-..)	Intelligent Key
 Juke	CHASSIS NETWORK	1.6 (10-..)	Interior lights
 Juke	CHASSIS NETWORK	1.6 (10-..)	IPDME-R
 Juke	CHASSIS NETWORK	1.6 (10-..)	Light control lever
 Juke	CHASSIS NETWORK	1.6 (10-..)	Timer power
 Juke	CHASSIS NETWORK	1.6 (10-..)	TRUNK
 Juke	CHASSIS NETWORK	1.6 (10-..)	Wiper
 Juke	CLIMA	1.5 dCi (10-..)	CLIMA
 Juke	CLIMA	1.5 dCi (10-..)	Klima
 Juke	CLIMA	1.6 (10-..)	CLIMA
 Juke	CLIMA	1.6 (10-..)	Klima
 Juke	DASHBOARD	1.5 dCi (10-..)	IC
 Juke	DASHBOARD	1.6 (10-..)	IC
 Juke	ELECTRIC STEERING	1.5 dCi (10-..)	EPS
 Juke	ELECTRIC STEERING	1.6 (10-..)	EPS
 Juke	ENGINE MANAGEME	1.6 (10-..)	MPI
 Juke	HEADLIGHT LEVEL	1.5 dCi (10-..)	
 Juke	HEADLIGHT LEVEL	1.6 (10-..)	
 Juke	IMMOBILIZER	1.5 dCi (10-..)	IMMU
 Juke	IMMOBILIZER	1.6 (10-..)	IMMU
 Juke	MAINTENANCE	1.6 (10-..)	MANUAL
 Juke	SERVICE LIGHT RES	1.6 (10-..)	MANUAL
 Juke	VISUAL./TELEMATIC	1.5 dCi (10-..)	Info Display
 Juke	VISUAL./TELEMATIC	1.6 (10-..)	Info Display
 Maxima QX	ENGINE MANAGEME	2.0 103kw (01-..)	EOBD
 Maxima QX	ENGINE MANAGEME	3.0 147kw (01-..)	EOBD
 Micra K11	ABS	1.0 16v (.-96)	Nissan ABS MANUAL
 Micra K11	ABS	1.2 16v (.-96)	Nissan ABS MANUAL
 Micra K11	ABS	1.3 16v (.-96)	Nissan ABS MANUAL
 Micra K11	ABS	1.4 16v (.-96)	Nissan ABS MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Nissan

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Micra K11	ABS	1.5 D (...-96)	Nissan ABS MANUAL
 Micra K11	ENGINE MANAGEME	1.0 16v (95-02)	BOSCH-Nissan EFI JECS-Nissan
 Micra K11	ENGINE MANAGEME	1.0 16v CG10 (01-..)	EOBD
 Micra K11	ENGINE MANAGEME	1.0 16v CG10DE (95-02)	Denso ECCS
 Micra K11	ENGINE MANAGEME	1.0 16v CG10DE (95-02)	Nissan ECCS MANUAL
 Micra K11	ENGINE MANAGEME	1.0 16v CG10DE (95-02)	Nissan MPI
 Micra K11	ENGINE MANAGEME	1.3 16v (95-02)	BOSCH-Nissan EFI JECS-Nissan
 Micra K11	ENGINE MANAGEME	1.3 16v CG13DE (95-02)	Denso ECCS
 Micra K11	ENGINE MANAGEME	1.3 16v CG13DE (95-02)	Nissan ECCS MANUAL
 Micra K11	ENGINE MANAGEME	1.3 16v CGA3 (95-02)	Nissan MPI
 Micra K11	ENGINE MANAGEME	1.4 16v CCA3 (01-..)	EOBD
 Micra K11	MAINTENANCE	1.0 16v (...-96)	Nissan ABS MANUAL
 Micra K11	MAINTENANCE	1.0 16v CG10DE (95-02)	Nissan ECCS MANUAL
 Micra K11	MAINTENANCE	1.2 16v (...-96)	Nissan ABS MANUAL
 Micra K11	MAINTENANCE	1.3 16v (...-96)	Nissan ABS MANUAL
 Micra K11	MAINTENANCE	1.3 16v CG13DE (95-02)	Nissan ECCS MANUAL
 Micra K11	MAINTENANCE	1.4 16v (...-96)	Nissan ABS MANUAL
 Micra K11	MAINTENANCE	1.5 D (...-96)	Nissan ABS MANUAL
 Micra K12	ABS	1.0 16v (02-..)	BOSCH ABS 8
 Micra K12	ABS	1.2 16v (02-..)	BOSCH ABS 8
 Micra K12	ABS	1.4 16v (02-..)	BOSCH ABS 8
 Micra K12	ABS	1.5 dCi 65cv (02-..)	BOSCH ABS 8
 Micra K12	ABS	1.5 dCi 82cv (02-..)	BOSCH ABS 8
 Micra K12	ABS	1.6 16v (02-..)	BOSCH ABS 8
 Micra K12	AIRBAG	1.0 16v (02-..)	BOSCH TRW SRS
 Micra K12	AIRBAG	1.2 16v (02-..)	BOSCH TRW SRS
 Micra K12	AIRBAG	1.4 16v (02-..)	BOSCH TRW SRS
 Micra K12	AIRBAG	1.5 dCi 65cv (02-..)	BOSCH TRW SRS
 Micra K12	AIRBAG	1.5 dCi 82cv (02-..)	BOSCH TRW SRS
 Micra K12	AIRBAG	1.6 16v (02-..)	BOSCH TRW SRS
 Micra K12	CHASSIS NETWORK	1.0 16v (02-..)	Body Computer BCM-1
 Micra K12	CHASSIS NETWORK	1.0 16v (02-..)	Body Computer BCM-2
 Micra K12	CHASSIS NETWORK	1.0 16v (02-..)	Body Computer IPDM E/R
 Micra K12	CHASSIS NETWORK	1.2 16v (02-..)	Body Computer BCM-1
 Micra K12	CHASSIS NETWORK	1.2 16v (02-..)	Body Computer BCM-2
 Micra K12	CHASSIS NETWORK	1.2 16v (02-..)	Body Computer IPDM E/R
 Micra K12	CHASSIS NETWORK	1.4 16v (02-..)	Body Computer BCM-1
 Micra K12	CHASSIS NETWORK	1.4 16v (02-..)	Body Computer BCM-2
 Micra K12	CHASSIS NETWORK	1.4 16v (02-..)	Body Computer IPDM E/R
 Micra K12	CHASSIS NETWORK	1.5 dCi 65cv (02-..)	Body Computer BCM-1
 Micra K12	CHASSIS NETWORK	1.5 dCi 65cv (02-..)	Body Computer BCM-2
 Micra K12	CHASSIS NETWORK	1.5 dCi 65cv (02-..)	Body Computer IPDM E/R
 Micra K12	CHASSIS NETWORK	1.5 dCi 82cv (02-..)	Body Computer BCM-1
 Micra K12	CHASSIS NETWORK	1.5 dCi 82cv (02-..)	Body Computer BCM-2
 Micra K12	CHASSIS NETWORK	1.5 dCi 82cv (02-..)	Body Computer IPDM E/R
 Micra K12	CHASSIS NETWORK	1.6 16v (02-..)	Body Computer BCM-1
 Micra K12	CHASSIS NETWORK	1.6 16v (02-..)	Body Computer BCM-2
 Micra K12	CHASSIS NETWORK	1.6 16v (02-..)	Body Computer IPDM E/R
 Micra K12	ELECTRIC STEERING	1.0 16v (02-..)	EPS
 Micra K12	ELECTRIC STEERING	1.2 16v (02-..)	EPS
 Micra K12	ELECTRIC STEERING	1.4 16v (02-..)	EPS
 Micra K12	ELECTRIC STEERING	1.5 dCi 65cv (02-..)	EPS
 Micra K12	ELECTRIC STEERING	1.5 dCi 82cv (02-..)	EPS
 Micra K12	ELECTRIC STEERING	1.6 16v (02-..)	EPS
 Micra K12	ENGINE MANAGEME	1.2 16v CR12 (02-..)	HITACHI MEC 32
 Micra K12	ENGINE MANAGEME	1.4 16v (01-..)	EOBD
 Micra K12	ENGINE MANAGEME	1.5 dCi 65cv K12 K9K (02-..)	DELPHI/LUCAS LVCR Common Rail
 Micra K12	ENGINE MANAGEME	1.5 dCi 82cv (01-..)	EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Nissan

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Micra K12	IMMOBILIZER	1.0 16v (02-..)	I-KEY
 Micra K12	IMMOBILIZER	1.2 16v (02-..)	I-KEY
 Micra K12	IMMOBILIZER	1.4 16v (02-..)	I-KEY
 Micra K12	IMMOBILIZER	1.5 dCi 65cv (02-..)	Immobilizer
 Micra K12	IMMOBILIZER	1.5 dCi 82cv (02-..)	Immobilizer
 Micra K12	IMMOBILIZER	1.6 16v (02-..)	I-KEY
 Micra K12	MAINTENANCE	1.0 16v (02-..)	Body Computer BCM-2
 Micra K12	MAINTENANCE	1.0 16v (02-..)	Body Computer BCM-2
 Micra K12	MAINTENANCE	1.0 16v (02-..)	EPS
 Micra K12	MAINTENANCE	1.0 16v (02-..)	MANUAL
 Micra K12	MAINTENANCE	1.2 16v (02-..)	Body Computer BCM-2
 Micra K12	MAINTENANCE	1.2 16v (02-..)	Body Computer BCM-2
 Micra K12	MAINTENANCE	1.2 16v (02-..)	EPS
 Micra K12	MAINTENANCE	1.2 16v (02-..)	MANUAL
 Micra K12	MAINTENANCE	1.2 16v CR12 (02-..)	HITACHI MEC 32
 Micra K12	MAINTENANCE	1.4 16v (02-..)	Body Computer BCM-2
 Micra K12	MAINTENANCE	1.4 16v (02-..)	Body Computer BCM-2
 Micra K12	MAINTENANCE	1.4 16v (02-..)	EPS
 Micra K12	MAINTENANCE	1.4 16v (02-..)	MANUAL
 Micra K12	MAINTENANCE	1.5 dCi 65cv (02-..)	Body Computer BCM-2
 Micra K12	MAINTENANCE	1.5 dCi 65cv (02-..)	Body Computer BCM-2
 Micra K12	MAINTENANCE	1.5 dCi 65cv (02-..)	EPS
 Micra K12	MAINTENANCE	1.5 dCi 65cv (02-..)	MANUAL
 Micra K12	MAINTENANCE	1.5 dCi 82cv (02-..)	Body Computer BCM-2
 Micra K12	MAINTENANCE	1.5 dCi 82cv (02-..)	Body Computer BCM-2
 Micra K12	MAINTENANCE	1.5 dCi 82cv (02-..)	EPS
 Micra K12	MAINTENANCE	1.5 dCi 82cv (02-..)	MANUAL
 Micra K12	MAINTENANCE	1.6 16v (02-..)	Body Computer BCM-2
 Micra K12	MAINTENANCE	1.6 16v (02-..)	Body Computer BCM-2
 Micra K12	MAINTENANCE	1.6 16v (02-..)	EPS
 Micra K12	MAINTENANCE	1.6 16v (02-..)	MANUAL
 Micra K12	SERVICE LIGHT RES	1.0 16v (02-..)	MANUAL
 Micra K12	SERVICE LIGHT RES	1.2 16v (02-..)	MANUAL
 Micra K12	SERVICE LIGHT RES	1.4 16v (02-..)	MANUAL
 Micra K12	SERVICE LIGHT RES	1.5 dCi 65cv (02-..)	MANUAL
 Micra K12	SERVICE LIGHT RES	1.5 dCi 82cv (02-..)	MANUAL
 Micra K12	SERVICE LIGHT RES	1.6 16v (02-..)	MANUAL
 Micra K13	ABS	1.2 16v (10-..)	ABS
 Micra K13	ANTITHEFT	1.2 16v (10-..)	
 Micra K13	CHASSIS NETWORK	1.2 16v (10-..)	Battery Saver
 Micra K13	CHASSIS NETWORK	1.2 16v (10-..)	Buzzer
 Micra K13	CHASSIS NETWORK	1.2 16v (10-..)	Control lever 1
 Micra K13	CHASSIS NETWORK	1.2 16v (10-..)	Control lever 2
 Micra K13	CHASSIS NETWORK	1.2 16v (10-..)	Direction indicators
 Micra K13	CHASSIS NETWORK	1.2 16v (10-..)	DOOR LOCKING
 Micra K13	CHASSIS NETWORK	1.2 16v (10-..)	Heated Rear Window
 Micra K13	CHASSIS NETWORK	1.2 16v (10-..)	Interior light
 Micra K13	CHASSIS NETWORK	1.2 16v (10-..)	IPDM
 Micra K13	CHASSIS NETWORK	1.2 16v (10-..)	Memory Boot
 Micra K13	CHASSIS NETWORK	1.2 16v (10-..)	Remote control
 Micra K13	CHASSIS NETWORK	1.2 16v (10-..)	TRUNK
 Micra K13	CLIMA	1.2 16v (10-..)	
 Micra K13	DASHBOARD	1.2 16v (10-..)	Dashboard
 Micra K13	ELECTRIC STEERING	1.2 16v (10-..)	EPS
 Micra K13	ENGINE MANAGEME	1.2 16v (10-..)	ECM
 Micra K13	WIPERS	1.2 16v (10-..)	
 Navara	4WD ELECTRONICS	2.5 dCi (04-..)	4WD
 Navara	ABS + TRACT. CONT	2.5 dCi (04-..)	DENSO ABS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Nissan

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Navara	AIRBAG	2.5 dCi (04-..)	DENSO AirBag
 Navara	CHASSIS NETWORK	2.5 dCi (04-..)	BCM Alarm
 Navara	CHASSIS NETWORK	2.5 dCi (04-..)	BCM Battery Saving
 Navara	CHASSIS NETWORK	2.5 dCi (04-..)	BCM Blinker
 Navara	CHASSIS NETWORK	2.5 dCi (04-..)	BCM Buzzer
 Navara	CHASSIS NETWORK	2.5 dCi (04-..)	BCM Clima
 Navara	CHASSIS NETWORK	2.5 dCi (04-..)	BCM Dimmer Switch
 Navara	CHASSIS NETWORK	2.5 dCi (04-..)	BCM Door Locking
 Navara	CHASSIS NETWORK	2.5 dCi (04-..)	BCM Heated Rear Window
 Navara	CHASSIS NETWORK	2.5 dCi (04-..)	BCM Immobilizer
 Navara	CHASSIS NETWORK	2.5 dCi (04-..)	BCM Intelligent key
 Navara	CHASSIS NETWORK	2.5 dCi (04-..)	BCM Internal Light
 Navara	CHASSIS NETWORK	2.5 dCi (04-..)	BCM Light Module
 Navara	CHASSIS NETWORK	2.5 dCi (04-..)	BCM Memory Buffer
 Navara	CHASSIS NETWORK	2.5 dCi (04-..)	BCM Remote Control
 Navara	CHASSIS NETWORK	2.5 dCi (04-..)	BCM Windshield Wiper
 Navara	CHASSIS NETWORK	2.5 dCi (04-..)	Body Computer IPDME
 Navara	CLIMA	2.5 dCi (04-..)	Climate Control
 Navara	DASHBOARD	2.5 dCi (04-..)	IC
 Navara	DIFFERENTIAL LOCK	2.5 dCi (04-..)	DL
 Navara	ENGINE MANAGEME	2.4 88kw (01-..)	EOBD
 Navara	ENGINE MANAGEME	2.5 D (04-..)	EOBD
 Navara	ENGINE MANAGEME	2.5 dCi (04-..)	DENSO EDC
 Navara	ENGINE MANAGEME	2.5 TD (04-..)	EOBD
 Note	ABS	1.4 16v (06-..)	ABS
 Note	ABS	1.5 dCi 103cv DPF (06-..)	ABS
 Note	ABS	1.5 dCi 86cv (06-..)	ABS
 Note	ABS	1.6 16v (06-..)	ABS
 Note	AIRBAG	1.4 16v (06-..)	SRS
 Note	AIRBAG	1.5 dCi 103cv DPF (06-..)	SRS
 Note	AIRBAG	1.5 dCi 86cv (06-..)	SRS
 Note	AIRBAG	1.6 16v (06-..)	SRS
 Note	CHASSIS NETWORK	1.4 16v (06-..)	Body Computer BCM
 Note	CHASSIS NETWORK	1.4 16v (06-..)	Body Computer IPDM E/R
 Note	CHASSIS NETWORK	1.5 dCi 103cv DPF (06-..)	Body Computer BCM
 Note	CHASSIS NETWORK	1.5 dCi 103cv DPF (06-..)	Body Computer IPDM E/R
 Note	CHASSIS NETWORK	1.5 dCi 86cv (06-..)	Body Computer BCM
 Note	CHASSIS NETWORK	1.5 dCi 86cv (06-..)	Body Computer IPDM E/R
 Note	CHASSIS NETWORK	1.6 16v (06-..)	Body Computer BCM
 Note	CHASSIS NETWORK	1.6 16v (06-..)	Body Computer IPDM E/R
 Note	ELECTRIC STEERING	1.4 16v (06-..)	KOYO EPS
 Note	ELECTRIC STEERING	1.5 dCi 103cv DPF (06-..)	KOYO EPS
 Note	ELECTRIC STEERING	1.5 dCi 86cv (06-..)	KOYO EPS
 Note	ELECTRIC STEERING	1.6 16v (06-..)	KOYO EPS
 Note	ENGINE MANAGEME	1.4 16v (06-..)	EOBD
 Note	ENGINE MANAGEME	1.5 dCi 103cv DPF (06-..)	EOBD
 Note	ENGINE MANAGEME	1.5 dCi 86cv (06-..)	EOBD
 Note	ENGINE MANAGEME	1.6 16v (06-..)	Denso MPI
 Note	IMMOBILIZER	1.4 16v (06-..)	I-KEY
 Note	IMMOBILIZER	1.4 16v (06-..)	Immobilizer
 Note	IMMOBILIZER	1.5 dCi 103cv DPF (06-..)	I-KEY
 Note	IMMOBILIZER	1.5 dCi 103cv DPF (06-..)	Immobilizer
 Note	IMMOBILIZER	1.5 dCi 86cv (06-..)	I-KEY
 Note	IMMOBILIZER	1.5 dCi 86cv (06-..)	Immobilizer
 Note	IMMOBILIZER	1.6 16v (06-..)	I-KEY
 Note	IMMOBILIZER	1.6 16v (06-..)	Immobilizer
 Note	MAINTENANCE	1.4 16v (06-..)	
 Note	MAINTENANCE	1.5 dCi 103cv DPF (06-..)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Nissan

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Note	MAINTENANCE	1.5 dCi 86cv (06-..)	
 Note	MAINTENANCE	1.6 16v (06-..)	
 Note	MAINTENANCE	1.6 16v (06-..)	Denso MPI
 Note	PASSIVE ENTRY	1.4 16v (06-..)	I-KEY
 Note	PASSIVE ENTRY	1.5 dCi 103cv DPF (06-..)	I-KEY
 Note	PASSIVE ENTRY	1.5 dCi 86cv (06-..)	I-KEY
 Note	PASSIVE ENTRY	1.6 16v (06-..)	I-KEY
 Note	SERVICE LIGHT RES	1.4 16v (06-..)	
 Note	SERVICE LIGHT RES	1.5 dCi 103cv DPF (06-..)	
 Note	SERVICE LIGHT RES	1.5 dCi 86cv (06-..)	
 Note	SERVICE LIGHT RES	1.6 16v (06-..)	
 Pathfinder	ENGINE MANAGEME	3.5 162kw (04-..)	EOBD
 Patrol GR	ENGINE MANAGEME	3.0 Di (01-..)	EOBD
 Pick-Up	ENGINE MANAGEME	2.4 88kw (01-..)	EOBD
 Pick-Up	ENGINE MANAGEME	2.5 D (04-..)	EOBD
 Pick-Up	ENGINE MANAGEME	2.5 TD (04-..)	EOBD
 Primastar	AUTOM. TRANSMISSI	1.9 dCi 60kw (03-06)	AUTODETECT
 Primastar	AUTOM. TRANSMISSI	1.9 dCi 60kw (07-..)	AUTODETECT
 Primastar	AUTOM. TRANSMISSI	1.9 dCi 74kw (03-06)	AUTODETECT
 Primastar	AUTOM. TRANSMISSI	1.9 dCi 74kw (07-..)	AUTODETECT
 Primastar	AUTOM. TRANSMISSI	2.0 dCi 16v 66kw (03-06)	AUTODETECT
 Primastar	AUTOM. TRANSMISSI	2.0 dCi 16v 66kw (07-..)	AUTODETECT
 Primastar	AUTOM. TRANSMISSI	2.0 dCi 16v 84kw (03-06)	AUTODETECT
 Primastar	AUTOM. TRANSMISSI	2.0 dCi 16v 84kw (07-..)	AUTODETECT
 Primastar	AUTOM. TRANSMISSI	2.0i 16v 86kw (03-06)	AUTODETECT
 Primastar	AUTOM. TRANSMISSI	2.0i 16v 86kw (07-..)	AUTODETECT
 Primastar	AUTOM. TRANSMISSI	2.0i 16v 88kw (03-06)	AUTODETECT
 Primastar	AUTOM. TRANSMISSI	2.0i 16v 88kw (07-..)	AUTODETECT
 Primastar	AUTOM. TRANSMISSI	2.5 dCi 16v 107kw (03-06)	AUTODETECT
 Primastar	AUTOM. TRANSMISSI	2.5 dCi 16v 107kw (07-..)	AUTODETECT
 Primastar	AUTOM. TRANSMISSI	2.5 dCi 16v 84kw (03-06)	AUTODETECT
 Primastar	AUTOM. TRANSMISSI	2.5 dCi 16v 84kw (07-..)	AUTODETECT
 Primastar	AUTOM. TRANSMISSI	2.5 dCi 16v 99kw (03-06)	AUTODETECT
 Primastar	AUTOM. TRANSMISSI	2.5 dCi 16v 99kw (07-..)	AUTODETECT
 Primastar	CHASSIS NETWORK	1.9 dCi 60kw (03-06)	UCC AUTODETECT
 Primastar	CHASSIS NETWORK	1.9 dCi 60kw (07-..)	UCC AUTODETECT
 Primastar	CHASSIS NETWORK	1.9 dCi 74kw (03-06)	UCC AUTODETECT
 Primastar	CHASSIS NETWORK	1.9 dCi 74kw (07-..)	UCC AUTODETECT
 Primastar	CHASSIS NETWORK	2.0 dCi 16v 66kw (03-06)	UCC AUTODETECT
 Primastar	CHASSIS NETWORK	2.0 dCi 16v 66kw (07-..)	UCC AUTODETECT
 Primastar	CHASSIS NETWORK	2.0 dCi 16v 84kw (03-06)	UCC AUTODETECT
 Primastar	CHASSIS NETWORK	2.0 dCi 16v 84kw (07-..)	UCC AUTODETECT
 Primastar	CHASSIS NETWORK	2.0i 16v 86kw (03-06)	UCC AUTODETECT
 Primastar	CHASSIS NETWORK	2.0i 16v 86kw (07-..)	UCC AUTODETECT
 Primastar	CHASSIS NETWORK	2.0i 16v 88kw (03-06)	UCC AUTODETECT
 Primastar	CHASSIS NETWORK	2.0i 16v 88kw (07-..)	UCC AUTODETECT
 Primastar	CHASSIS NETWORK	2.5 dCi 16v 107kw (03-06)	UCC AUTODETECT
 Primastar	CHASSIS NETWORK	2.5 dCi 16v 107kw (07-..)	UCC AUTODETECT
 Primastar	CHASSIS NETWORK	2.5 dCi 16v 84kw (03-06)	UCC AUTODETECT
 Primastar	CHASSIS NETWORK	2.5 dCi 16v 84kw (07-..)	UCC AUTODETECT
 Primastar	CHASSIS NETWORK	2.5 dCi 16v 99kw (03-06)	UCC AUTODETECT
 Primastar	CHASSIS NETWORK	2.5 dCi 16v 99kw (07-..)	UCC AUTODETECT
 Primastar	ENGINE MANAGEME	1.9 dCi 60kw (03-06)	AUTODETECT
 Primastar	ENGINE MANAGEME	1.9 dCi 60kw (07-..)	AUTODETECT
 Primastar	ENGINE MANAGEME	1.9 dCi 74kw (03-06)	AUTODETECT
 Primastar	ENGINE MANAGEME	1.9 dCi 74kw (07-..)	AUTODETECT
 Primastar	ENGINE MANAGEME	1.9 dCi F9Q	BOSCH EDC 15 C3 Common Rail

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Nissan

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Primastar	ENGINE MANAGEME	2.0 dCi 16v 66kw (03-06)	AUTODETECT
 Primastar	ENGINE MANAGEME	2.0 dCi 16v 66kw (07-..)	AUTODETECT
 Primastar	ENGINE MANAGEME	2.0 dCi 16v 84kw (03-06)	AUTODETECT
 Primastar	ENGINE MANAGEME	2.0 dCi 16v 84kw (07-..)	AUTODETECT
 Primastar	ENGINE MANAGEME	2.0i 16v 86kw (03-06)	AUTODETECT
 Primastar	ENGINE MANAGEME	2.0i 16v 86kw (07-..)	AUTODETECT
 Primastar	ENGINE MANAGEME	2.0i 16v 88kw (03-06)	AUTODETECT
 Primastar	ENGINE MANAGEME	2.5 dCi 16v 107kw (03-06)	AUTODETECT
 Primastar	ENGINE MANAGEME	2.5 dCi 16v 107kw (07-..)	AUTODETECT
 Primastar	ENGINE MANAGEME	2.5 dCi 16v 84kw (03-06)	AUTODETECT
 Primastar	ENGINE MANAGEME	2.5 dCi 16v 84kw (07-..)	AUTODETECT
 Primastar	ENGINE MANAGEME	2.5 dCi 16v 99kw (03-06)	AUTODETECT
 Primastar	ENGINE MANAGEME	2.5 dCi 16v 99kw (07-..)	AUTODETECT
 Primastar	IMMOBILIZER	1.9 dCi 60kw (...02)	SAGEM Immobilizer Key encoding
 Primastar	IMMOBILIZER	1.9 dCi 74kw (...02)	SAGEM Immobilizer Key encoding
 Primastar	IMMOBILIZER	2.0 dCi 16v 66kw (...02)	SAGEM Immobilizer Key encoding
 Primastar	IMMOBILIZER	2.0 dCi 16v 84kw (...02)	SAGEM Immobilizer Key encoding
 Primastar	IMMOBILIZER	2.0i 16v 86kw (...02)	SAGEM Immobilizer Key encoding
 Primastar	IMMOBILIZER	2.0i 16v 88kw (...02)	SAGEM Immobilizer Key encoding
 Primastar	IMMOBILIZER	2.5 dCi 16v 107kw (...02)	SAGEM Immobilizer Key encoding
 Primastar	IMMOBILIZER	2.5 dCi 16v 84kw (...02)	SAGEM Immobilizer Key encoding
 Primastar	IMMOBILIZER	2.5 dCi 16v 99kw (...02)	SAGEM Immobilizer Key encoding
 Primastar	MAINTENANCE	1.9 dCi 60kw (...02)	MANUAL
 Primastar	MAINTENANCE	1.9 dCi 74kw (...02)	MANUAL
 Primastar	MAINTENANCE	2.0 dCi 16v 66kw (...02)	MANUAL
 Primastar	MAINTENANCE	2.0 dCi 16v 84kw (...02)	MANUAL
 Primastar	MAINTENANCE	2.0i 16v 86kw (...02)	MANUAL
 Primastar	MAINTENANCE	2.0i 16v 88kw (...02)	MANUAL
 Primastar	MAINTENANCE	2.5 dCi 16v 107kw (...02)	MANUAL
 Primastar	MAINTENANCE	2.5 dCi 16v 84kw (...02)	MANUAL
 Primastar	MAINTENANCE	2.5 dCi 16v 99kw (...02)	MANUAL
 Primastar	SERVICE LIGHT RES	1.9 dCi 60kw (...02)	MANUAL
 Primastar	SERVICE LIGHT RES	1.9 dCi 74kw (...02)	MANUAL
 Primastar	SERVICE LIGHT RES	2.0 dCi 16v 66kw (...02)	MANUAL
 Primastar	SERVICE LIGHT RES	2.0 dCi 16v 84kw (...02)	MANUAL
 Primastar	SERVICE LIGHT RES	2.0i 16v 86kw (...02)	MANUAL
 Primastar	SERVICE LIGHT RES	2.0i 16v 88kw (...02)	MANUAL
 Primastar	SERVICE LIGHT RES	2.5 dCi 16v 107kw (...02)	MANUAL
 Primastar	SERVICE LIGHT RES	2.5 dCi 16v 84kw (...02)	MANUAL
 Primastar	SERVICE LIGHT RES	2.5 dCi 16v 99kw (...02)	MANUAL
 Primera	ABS	1.9 dCi (03-..)	ABS
 Primera	ENGINE MANAGEME	1.6 GA16DE (91-..)	Nissan ECCS MANUAL
 Primera	ENGINE MANAGEME	1.8 16v QG18DE (00-..)	Denso ECCS
 Primera	ENGINE MANAGEME	1.8 84kw (01-..)	EOBD
 Primera	ENGINE MANAGEME	1.9 dCi F9Q (03-..)	BOSCH EDC 15 Common Rail
 Primera	ENGINE MANAGEME	2.0 103kw (01-..)	EOBD
 Primera	ENGINE MANAGEME	2.0 SR20xx (91-..)	Nissan ECCS MANUAL
 Primera	ENGINE MANAGEME	2.0 TD (01-..)	EOBD
 Primera	ENGINE MANAGEME	2.0 TD CD20x (91-..)	BOSCH EDC MANUAL
 Primera	MAINTENANCE	1.6 GA16DE (91-..)	Nissan ECCS MANUAL
 Primera	MAINTENANCE	2.0 SR20xx (91-..)	Nissan ECCS MANUAL
 Primera	MAINTENANCE	2.0 TD CD20x (91-..)	BOSCH EDC MANUAL
 Pulsar	ENGINE MANAGEME	1.4 GA14DE (91-..)	Nissan ECCS MANUAL
 Pulsar	ENGINE MANAGEME	1.5 16v QG15DE (00-..)	Denso ECCS
 Pulsar	ENGINE MANAGEME	1.5 66kw (00/01-..)	EOBD
 Pulsar	ENGINE MANAGEME	1.5 dCi 65cv K9K (02-..)	DELPHI LUCAS LVCR Common Rail
 Pulsar	ENGINE MANAGEME	1.6 GA16DE (91-..)	Nissan ECCS MANUAL
 Pulsar	ENGINE MANAGEME	1.8 (00/01-..)	EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Nissan

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Pulsar	ENGINE MANAGEME	1.8 16v QG18DE (00-..)	Denso ECCS
 Pulsar	ENGINE MANAGEME	2.0 D CD20X (91-..)	BOSCH EDC MANUAL
 Pulsar	ENGINE MANAGEME	2.0 SR20xx (91-..)	Nissan ECCS MANUAL
 Pulsar	MAINTENANCE	1.4 GA14DE (91-..)	Nissan ECCS MANUAL
 Pulsar	MAINTENANCE	1.6 GA16DE (91-..)	Nissan ECCS MANUAL
 Pulsar	MAINTENANCE	2.0 D CD20X (91-..)	BOSCH EDC MANUAL
 Pulsar	MAINTENANCE	2.0 SR20xx (91-..)	Nissan ECCS MANUAL
 Qashqai	ABS	1.5 dCi (07-..)	BOSCH ABS+TC
 Qashqai	ABS	1.6 16v (07-..)	BOSCH ABS+TC
 Qashqai	ABS	2.0 16v (07-..)	BOSCH ABS+TC
 Qashqai	ABS	2.0 dCi (07-..)	BOSCH ABS+TC
 Qashqai	AIRBAG	1.5 dCi (07-..)	AirBag SRS
 Qashqai	AIRBAG	1.6 16v (07-..)	AirBag SRS
 Qashqai	AIRBAG	2.0 16v (07-..)	AirBag SRS
 Qashqai	AIRBAG	2.0 dCi (07-..)	AirBag SRS
 Qashqai	ANTITHEFT	1.5 dCi (07-..)	Antitheft
 Qashqai	ANTITHEFT	1.6 16v (07-..)	Antitheft
 Qashqai	ANTITHEFT	2.0 16v (07-..)	Antitheft
 Qashqai	ANTITHEFT	2.0 dCi (07-..)	Antitheft
 Qashqai	AUTOM. TRANSMISSI	1.5 dCi (07-..)	TCM
 Qashqai	AUTOM. TRANSMISSI	1.6 16v (07-..)	TCM
 Qashqai	AUTOM. TRANSMISSI	2.0 16v (07-..)	TCM
 Qashqai	AUTOM. TRANSMISSI	2.0 dCi (07-..)	TCM
 Qashqai	CHASSIS NETWORK	1.5 dCi (07-..)	Battery Saving
 Qashqai	CHASSIS NETWORK	1.5 dCi (07-..)	Blinker
 Qashqai	CHASSIS NETWORK	1.5 dCi (07-..)	Buzzer
 Qashqai	CHASSIS NETWORK	1.5 dCi (07-..)	Door Locking
 Qashqai	CHASSIS NETWORK	1.5 dCi (07-..)	Hatch-Bach Door
 Qashqai	CHASSIS NETWORK	1.5 dCi (07-..)	Heated Rear Window
 Qashqai	CHASSIS NETWORK	1.5 dCi (07-..)	Internal Light
 Qashqai	CHASSIS NETWORK	1.5 dCi (07-..)	IPDM
 Qashqai	CHASSIS NETWORK	1.5 dCi (07-..)	Memory Buffer
 Qashqai	CHASSIS NETWORK	1.5 dCi (07-..)	PTC Heater
 Qashqai	CHASSIS NETWORK	1.5 dCi (07-..)	Remote Control
 Qashqai	CHASSIS NETWORK	1.5 dCi (07-..)	Windshield Wiper
 Qashqai	CHASSIS NETWORK	1.6 16v (07-..)	Battery Saving
 Qashqai	CHASSIS NETWORK	1.6 16v (07-..)	Blinker
 Qashqai	CHASSIS NETWORK	1.6 16v (07-..)	Buzzer
 Qashqai	CHASSIS NETWORK	1.6 16v (07-..)	Door Locking
 Qashqai	CHASSIS NETWORK	1.6 16v (07-..)	Hatch-Bach Door
 Qashqai	CHASSIS NETWORK	1.6 16v (07-..)	Heated Rear Window
 Qashqai	CHASSIS NETWORK	1.6 16v (07-..)	Internal Light
 Qashqai	CHASSIS NETWORK	1.6 16v (07-..)	IPDM
 Qashqai	CHASSIS NETWORK	1.6 16v (07-..)	Memory Buffer
 Qashqai	CHASSIS NETWORK	1.6 16v (07-..)	PTC Heater
 Qashqai	CHASSIS NETWORK	1.6 16v (07-..)	Remote Control
 Qashqai	CHASSIS NETWORK	1.6 16v (07-..)	Windshield Wiper
 Qashqai	CHASSIS NETWORK	2.0 16v (07-..)	Battery Saving
 Qashqai	CHASSIS NETWORK	2.0 16v (07-..)	Blinker
 Qashqai	CHASSIS NETWORK	2.0 16v (07-..)	Buzzer
 Qashqai	CHASSIS NETWORK	2.0 16v (07-..)	Door Locking
 Qashqai	CHASSIS NETWORK	2.0 16v (07-..)	Hatch-Bach Door
 Qashqai	CHASSIS NETWORK	2.0 16v (07-..)	Heated Rear Window
 Qashqai	CHASSIS NETWORK	2.0 16v (07-..)	Internal Light
 Qashqai	CHASSIS NETWORK	2.0 16v (07-..)	IPDM
 Qashqai	CHASSIS NETWORK	2.0 16v (07-..)	Memory Buffer
 Qashqai	CHASSIS NETWORK	2.0 16v (07-..)	PTC Heater
 Qashqai	CHASSIS NETWORK	2.0 16v (07-..)	Remote Control

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Nissan

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Qashqai	CHASSIS NETWORK	2.0 16v (07-..)	Windshield Wiper
 Qashqai	CHASSIS NETWORK	2.0 dCi (07-..)	Battery Saving
 Qashqai	CHASSIS NETWORK	2.0 dCi (07-..)	Blinker
 Qashqai	CHASSIS NETWORK	2.0 dCi (07-..)	Buzzer
 Qashqai	CHASSIS NETWORK	2.0 dCi (07-..)	Door Locking
 Qashqai	CHASSIS NETWORK	2.0 dCi (07-..)	Hatch-Bach Door
 Qashqai	CHASSIS NETWORK	2.0 dCi (07-..)	Heated Rear Window
 Qashqai	CHASSIS NETWORK	2.0 dCi (07-..)	Internal Light
 Qashqai	CHASSIS NETWORK	2.0 dCi (07-..)	IPDM
 Qashqai	CHASSIS NETWORK	2.0 dCi (07-..)	Memory Buffer
 Qashqai	CHASSIS NETWORK	2.0 dCi (07-..)	PTC Heater
 Qashqai	CHASSIS NETWORK	2.0 dCi (07-..)	Remote Control
 Qashqai	CHASSIS NETWORK	2.0 dCi (07-..)	Windshield Wiper
 Qashqai	CLIMA	1.5 dCi (07-..)	Clima
 Qashqai	CLIMA	1.6 16v (07-..)	Clima
 Qashqai	CLIMA	2.0 16v (07-..)	Clima
 Qashqai	CLIMA	2.0 dCi (07-..)	Clima
 Qashqai	DASHBOARD	1.5 dCi (07-..)	IC
 Qashqai	DASHBOARD	1.6 16v (07-..)	IC
 Qashqai	DASHBOARD	2.0 16v (07-..)	IC
 Qashqai	DASHBOARD	2.0 dCi (07-..)	IC
 Qashqai	ELECTRIC STEERING	1.5 dCi (07-..)	EPS
 Qashqai	ELECTRIC STEERING	1.6 16v (07-..)	EPS
 Qashqai	ELECTRIC STEERING	2.0 16v (07-..)	EPS
 Qashqai	ELECTRIC STEERING	2.0 dCi (07-..)	EPS
 Qashqai	ENGINE MANAGEME	1.5 dCi (07-..)	ECM
 Qashqai	ENGINE MANAGEME	1.6 16v (07-..)	EOBD
 Qashqai	ENGINE MANAGEME	2.0 16v (07-..)	EOBD
 Qashqai	ENGINE MANAGEME	2.0 dCi MR9 (07-..)	BOSCH EDC Common Rail 3Y
 Qashqai	IMMOBILIZER	1.5 dCi (07-..)	Immobilizer
 Qashqai	IMMOBILIZER	1.6 16v (07-..)	Immobilizer
 Qashqai	IMMOBILIZER	2.0 16v (07-..)	Immobilizer
 Qashqai	IMMOBILIZER	2.0 dCi (07-..)	Immobilizer
 Qashqai	MAINTENANCE	1.5 dCi (07-..)	Buzzer
 Qashqai	MAINTENANCE	1.5 dCi (07-..)	Buzzer
 Qashqai	MAINTENANCE	1.5 dCi (07-..)	MANUAL
 Qashqai	MAINTENANCE	1.6 16v (07-..)	Buzzer
 Qashqai	MAINTENANCE	1.6 16v (07-..)	Buzzer
 Qashqai	MAINTENANCE	1.6 16v (07-..)	MANUAL
 Qashqai	MAINTENANCE	2.0 16v (07-..)	Buzzer
 Qashqai	MAINTENANCE	2.0 16v (07-..)	Buzzer
 Qashqai	MAINTENANCE	2.0 16v (07-..)	MANUAL
 Qashqai	MAINTENANCE	2.0 dCi (07-..)	Buzzer
 Qashqai	MAINTENANCE	2.0 dCi (07-..)	Buzzer
 Qashqai	MAINTENANCE	2.0 dCi (07-..)	MANUAL
 Qashqai	MAINTENANCE	2.0 dCi MR9 (07-..)	BOSCH EDC Common Rail 3Y
 Qashqai	SERVICE LIGHT RES	1.5 dCi (07-..)	MANUAL
 Qashqai	SERVICE LIGHT RES	1.6 16v (07-..)	MANUAL
 Qashqai	SERVICE LIGHT RES	2.0 16v (07-..)	MANUAL
 Qashqai	SERVICE LIGHT RES	2.0 dCi (07-..)	MANUAL
 Qashqai	SWITCHLIGHT MODU	1.5 dCi (07-..)	Light Module
 Qashqai	SWITCHLIGHT MODU	1.6 16v (07-..)	Light Module
 Qashqai	SWITCHLIGHT MODU	2.0 16v (07-..)	Light Module
 Qashqai	SWITCHLIGHT MODU	2.0 dCi (07-..)	Light Module
 Serena	ABS	1.6 (...96)	Nissan ABS MANUAL
 Serena	ABS	2.0 (...96)	Nissan ABS MANUAL
 Serena	ABS	2.0 D (...96)	Nissan ABS MANUAL
 Serena	ABS	2.3 D (...96)	Nissan ABS MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Nissan

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Serena	ABS	2.4 (...96)	Nissan ABS MANUAL
 Serena	ENGINE MANAGEME	1.6 GA16DE (93-..)	Nissan ECCS MANUAL
 Serena	ENGINE MANAGEME	2.0 SR20xx (93-..)	Nissan ECCS MANUAL
 Serena	MAINTENANCE	1.6 (...96)	Nissan ABS MANUAL
 Serena	MAINTENANCE	1.6 GA16DE (93-..)	Nissan ECCS MANUAL
 Serena	MAINTENANCE	2.0 (...96)	Nissan ABS MANUAL
 Serena	MAINTENANCE	2.0 D (...96)	Nissan ABS MANUAL
 Serena	MAINTENANCE	2.0 SR20xx (93-..)	Nissan ECCS MANUAL
 Serena	MAINTENANCE	2.3 D (...96)	Nissan ABS MANUAL
 Serena	MAINTENANCE	2.4 (...96)	Nissan ABS MANUAL
 Sunny	ENGINE MANAGEME	1.4 GA14DE (91-..)	Nissan ECCS MANUAL
 Sunny	ENGINE MANAGEME	1.6 GA16DE (91-..)	Nissan ECCS MANUAL
 Sunny	ENGINE MANAGEME	2.0 SR20xx (91-..)	Nissan ECCS MANUAL
 Sunny	MAINTENANCE	1.4 GA14DE (91-..)	Nissan ECCS MANUAL
 Sunny	MAINTENANCE	1.6 GA16DE (91-..)	Nissan ECCS MANUAL
 Sunny	MAINTENANCE	2.0 SR20xx (91-..)	Nissan ECCS MANUAL
 Terrano II	ENGINE MANAGEME	2.4 KA24E (91-..)	Nissan ECCS MANUAL
 Terrano II	ENGINE MANAGEME	2.7 TD	BOSCH EDC MSA 15
 Terrano II	ENGINE MANAGEME	2.7 TD (04-..)	EOBD
 Terrano II	ENGINE MANAGEME	2.7 TD TD27Ti (96-..)	BOSCH EDC MANUAL
 Terrano II	ENGINE MANAGEME	3.0 TD	BOSCH EDC MSA 15
 Terrano II	IMMOBILIZER	2.7 TD	NATS
 Terrano II	IMMOBILIZER	3.0 TD	NATS
 Terrano II	MAINTENANCE	2.4 KA24E (91-..)	Nissan ECCS MANUAL
 Terrano II	MAINTENANCE	2.7 TD TD27Ti (96-..)	BOSCH EDC MANUAL
 X-Trail	4WD ELECTRONICS	2.0 16v (03-..)	4WD
 X-Trail	4WD ELECTRONICS	2.2 dCi (03-..)	4WD
 X-Trail	4WD ELECTRONICS	2.5 16v (03-..)	4WD
 X-Trail	ABS	2.0 16v (05-..)	ABS
 X-Trail	ABS	2.2 dCi (04-..)	ABS
 X-Trail	ABS	2.2 dCi (05-..)	ABS
 X-Trail	ABS	2.5 16v (05-..)	ABS
 X-Trail	AIRBAG	2.0 16v (03-..)	BOSCH TRW SRS
 X-Trail	AIRBAG	2.2 dCi	BOSCH TRW SRS
 X-Trail	AIRBAG	2.5 16v (03-..)	BOSCH TRW SRS
 X-Trail	ENGINE MANAGEME	2.0 16v (01-..)	EOBD
 X-Trail	ENGINE MANAGEME	2.2 dCi (03-..)	Nissan EDC Common Rail
 X-Trail	ENGINE MANAGEME	2.2 TD Di (01-..)	EOBD
 X-Trail	IMMOBILIZER	2.0 16v	NATS
 X-Trail	IMMOBILIZER	2.2 dCi	NATS
 X-Trail	IMMOBILIZER	2.5 16v	NATS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Agila	ABS	1.0 12v (03-..)	
 Agila	ABS	1.2 16v (03-..)	
 Agila	ABS	1.3 CDTi (03-..)	
 Agila	AIRBAG	1.0 12v (03-..)	
 Agila	AIRBAG	1.2 16v (03-..)	
 Agila	AIRBAG	1.3 CDTi (03-..)	
 Agila	DASHBOARD	1.0 12v (03-..)	
 Agila	DASHBOARD	1.2 16v (03-..)	
 Agila	DASHBOARD	1.3 CDTi (03-..)	
 Agila	ELECTRIC STEERING	1.0 12v (03-..)	
 Agila	ELECTRIC STEERING	1.2 16v (03-..)	
 Agila	ELECTRIC STEERING	1.3 CDTi (03-..)	
 Agila	ENGINE MANAGEME	1.0 12v Z10XE (00-..)	EOBD
 Agila	ENGINE MANAGEME	1.2 16v Z12XE (00-..)	BOSCH Motronic M1.5.5
 Agila	ENGINE MANAGEME	1.2 16v Z12XE (03-..)	
 Agila	ENGINE MANAGEME	1.3 CDTi Z13DT (03-..)	Marelli 6JF CF3 Common Rail
 Agila	IMMOBILIZER	1.0 12v (03-..)	
 Agila	IMMOBILIZER	1.2 16v (03-..)	
 Agila	IMMOBILIZER	1.3 CDTi (03-..)	
 Agila	MAINTENANCE	1.0 12v (03-..)	MANUAL
 Agila	MAINTENANCE	1.2 16v (03-..)	MANUAL
 Agila	MAINTENANCE	1.3 CDTi (03-..)	MANUAL
 Agila	SERVICE LIGHT RES	1.0 12v (03-..)	MANUAL
 Agila	SERVICE LIGHT RES	1.2 16v (03-..)	MANUAL
 Agila	SERVICE LIGHT RES	1.3 CDTi (03-..)	MANUAL
 Agila-B	ABS + TRACT. CONT	1.0 12v (08-..)	
 Agila-B	ABS + TRACT. CONT	1.2 16v (08-..)	
 Agila-B	ABS + TRACT. CONT	1.3 CDTi (08-..)	
 Agila-B	AIRBAG	1.0 12v (08-..)	
 Agila-B	AIRBAG	1.2 16v (08-..)	
 Agila-B	AIRBAG	1.3 CDTi (08-..)	
 Agila-B	CHASSIS NETWORK	1.0 12v (08-..)	
 Agila-B	CHASSIS NETWORK	1.2 16v (08-..)	
 Agila-B	CHASSIS NETWORK	1.3 CDTi (08-..)	
 Agila-B	ELECTRIC STEERING	1.0 12v (08-..)	EPS
 Agila-B	ELECTRIC STEERING	1.2 16v (08-..)	EPS
 Agila-B	ELECTRIC STEERING	1.3 CDTi (08-..)	EPS
 Agila-B	ENGINE MANAGEME	1.0 12v (08-..)	
 Agila-B	ENGINE MANAGEME	1.0 12v (08-..)	EOBD
 Agila-B	ENGINE MANAGEME	1.2 16v (08-..)	
 Agila-B	ENGINE MANAGEME	1.3 CDTi (08-..)	EOBD
 Agila-B	IMMOBILIZER	1.0 12v (08-..)	
 Agila-B	IMMOBILIZER	1.2 16v (08-..)	
 Agila-B	IMMOBILIZER	1.3 CDTi (08-..)	
 Agila-B	MAINTENANCE	1.0 12v (08-..)	
 Agila-B	MAINTENANCE	1.2 16v (08-..)	
 Agila-B	MAINTENANCE	1.3 CDTi (08-..)	
 Antara	ABS + TRACT. CONT	2.0 CDTi	TEVES ESC 0300
 Antara	ABS + TRACT. CONT	2.4 16v	TEVES ESC 0300
 Antara	ABS + TRACT. CONT	3.2 V6	TEVES ESC 0300
 Antara	AIRBAG	2.0 CDTi	SDM
 Antara	AIRBAG	2.4 16v	SDM
 Antara	AIRBAG	3.2 V6	SDM
 Antara	AUTOM. TRANSMISSI	2.0 CDTi	AISIN A/T
 Antara	AUTOM. TRANSMISSI	2.4 16v	AISIN A/T
 Antara	AUTOM. TRANSMISSI	3.2 V6	AISIN A/T
 Antara	CHASSIS NETWORK	2.0 CDTi	BCM Front
 Antara	CHASSIS NETWORK	2.0 CDTi	XBCM Rear

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Antara	CHASSIS NETWORK	2.4 16v	BCM Front
 Antara	CHASSIS NETWORK	2.4 16v	XBCM Rear
 Antara	CHASSIS NETWORK	3.2 V6	BCM Front
 Antara	CHASSIS NETWORK	3.2 V6	XBCM Rear
 Antara	CLIMA	2.0 CDTI	ECC
 Antara	CLIMA	2.4 16v	ECC
 Antara	CLIMA	3.2 V6	ECC
 Antara	DASHBOARD	2.0 CDTI	IPC
 Antara	DASHBOARD	2.4 16v	IPC
 Antara	DASHBOARD	3.2 V6	IPC
 Antara	ENGINE MANAGEME	2.0 CDTI 2.0L	BOSCH EDC 16 39 Common Rail
 Antara	ENGINE MANAGEME	2.4 16v	EOBD
 Antara	ENGINE MANAGEME	3.2 V6	EOBD
 Antara	IMMOBILIZER	2.0 CDTI	VTD
 Antara	IMMOBILIZER	2.4 16v	VTD
 Antara	IMMOBILIZER	3.2 V6	VTD
 Antara	MAINTENANCE	2.0 CDTI	OMRON TPMS 0400
 Antara	MAINTENANCE	2.4 16v	OMRON TPMS 0400
 Antara	MAINTENANCE	3.2 V6	OMRON TPMS 0400
 Antara	PARKING HELP	2.0 CDTI	PAS
 Antara	PARKING HELP	2.4 16v	PAS
 Antara	PARKING HELP	3.2 V6	PAS
 Antara	TIRE PRESSURE	2.0 CDTI	OMRON TPMS 0400
 Antara	TIRE PRESSURE	2.4 16v	OMRON TPMS 0400
 Antara	TIRE PRESSURE	3.2 V6	OMRON TPMS 0400
 Antara	TRACTION CONTROL	2.0 CDTI	TCCM
 Antara	TRACTION CONTROL	2.4 16v	TCCM
 Antara	TRACTION CONTROL	3.2 V6	TCCM
 Ascona/Cavalier	ENGINE MANAGEME	1.6 C16NZ (87-88)	GM Multec TBI MANUAL
 Ascona/Cavalier	ENGINE MANAGEME	1.6 E16NZ (87-88)	GM Multec TBI MANUAL
 Ascona/Cavalier	ENGINE MANAGEME	2.0 20NE (87-88)	BOSCH Motronic ML4.1
 Ascona/Cavalier	ENGINE MANAGEME	2.0 20SEH (87-88)	BOSCH Motronic ML4.1
 Ascona/Cavalier	ENGINE MANAGEME	2.0 C20NE (87-88)	BOSCH Motronic ML4.1
 Ascona/Cavalier	MAINTENANCE	1.6 C16NZ (87-88)	GM Multec TBI MANUAL
 Ascona/Cavalier	MAINTENANCE	1.6 E16NZ (87-88)	GM Multec TBI MANUAL
 Astra J	MAINTENANCE	1.3 CDTI	
 Astra J	MAINTENANCE	1.4 16v	
 Astra J	MAINTENANCE	1.4 Turbo 16v	
 Astra J	MAINTENANCE	1.6 16v	
 Astra J	MAINTENANCE	1.6 Turbo 16v	
 Astra J	MAINTENANCE	1.7 CDTI 110cv	
 Astra J	MAINTENANCE	1.7 CDTI 125cv	
 Astra J	MAINTENANCE	2.0 CDTI	
 Astra J	SERVICE LIGHT RES	1.3 CDTI	
 Astra J	SERVICE LIGHT RES	1.4 16v	
 Astra J	SERVICE LIGHT RES	1.4 Turbo 16v	
 Astra J	SERVICE LIGHT RES	1.6 16v	
 Astra J	SERVICE LIGHT RES	1.6 Turbo 16v	
 Astra J	SERVICE LIGHT RES	1.7 CDTI 110cv	
 Astra J	SERVICE LIGHT RES	1.7 CDTI 125cv	
 Astra J	SERVICE LIGHT RES	2.0 CDTI	
 Astra-F	AIRBAG	1.4 (93-97)	GM AirBag S
 Astra-F	AIRBAG	1.4 16v (93-97)	GM AirBag S
 Astra-F	AIRBAG	1.6 (93-97)	GM AirBag S
 Astra-F	AIRBAG	1.6 16v (93-97)	GM AirBag S
 Astra-F	AIRBAG	1.6 Kat (93-97)	GM AirBag S
 Astra-F	AIRBAG	1.7 D (93-97)	GM AirBag S
 Astra-F	AIRBAG	1.7 TD (93-97)	GM AirBag S

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Astra-F	AIRBAG	1.7 TDS (93-97)	GM AirBag S
 Astra-F	AIRBAG	1.8 (93-97)	GM AirBag S
 Astra-F	AIRBAG	1.8 16v (93-97)	GM AirBag S
 Astra-F	AIRBAG	2.0 (93-97)	GM AirBag S
 Astra-F	AIRBAG	2.0 16v (93-97)	GM AirBag S
 Astra-F	ENGINE MANAGEME	1.4 14SE (93-94)	GM Multec M
 Astra-F	ENGINE MANAGEME	1.4 14SE (95-98)	GM Multec M + Immob.
 Astra-F	ENGINE MANAGEME	1.4 16v X14XE (96-98)	GM Multec (F)
 Astra-F	ENGINE MANAGEME	1.4 C14NZ (92-94)	GM Multec TBI
 Astra-F	ENGINE MANAGEME	1.4 C14SE (92-94)	GM Multec M
 Astra-F	ENGINE MANAGEME	1.4 C14SE (95-98)	GM Multec M + Immob.
 Astra-F	ENGINE MANAGEME	1.4 X14NZ (01-..)	EOBD
 Astra-F	ENGINE MANAGEME	1.6 16LZ2 (95-96)	GM Multec TBI
 Astra-F	ENGINE MANAGEME	1.6 16LZ2 (95-96)	GM Multec TBI + Immob.
 Astra-F	ENGINE MANAGEME	1.6 16SZR (96-98)	GM Multec F
 Astra-F	ENGINE MANAGEME	1.6 16v X16XEL (..-95)	GM Multec S
 Astra-F	ENGINE MANAGEME	1.6 16v X16XEL (96-98)	GM Multec S
 Astra-F	ENGINE MANAGEME	1.6 16v X16XEL (96-98)	GM Multec S (F)
 Astra-F	ENGINE MANAGEME	1.6 C16NZ-Kat (92-..)	GM Multec TBI MANUAL
 Astra-F	ENGINE MANAGEME	1.6 C16SE (92-94)	GM Multec M
 Astra-F	ENGINE MANAGEME	1.6 X16NE (01-..)	EOBD
 Astra-F	ENGINE MANAGEME	1.6 X16SZ (93-94)	GM Multec SZ
 Astra-F	ENGINE MANAGEME	1.6 X16SZ (95-96)	GM Multec SZ
 Astra-F	ENGINE MANAGEME	1.6 X16SZR (96-98)	GM Multec S (F)
 Astra-F	ENGINE MANAGEME	1.8 16v C18XE (..-95)	SIEMENS Simtec 56.0
 Astra-F	ENGINE MANAGEME	1.8 16v X18XE (96-98)	SIEMENS Simtec 56.5
 Astra-F	ENGINE MANAGEME	1.8 C18NZ (..-94)	GM Multec TBI
 Astra-F	ENGINE MANAGEME	2.0 16v C20XE (..-92)	BOSCH Motronic M2.5
 Astra-F	ENGINE MANAGEME	2.0 16v C20XE (93-98)	BOSCH Motronic M2.8
 Astra-F	ENGINE MANAGEME	2.0 16v X20XEV (..-95)	SIEMENS Simtec 56.0 - 56.1
 Astra-F	ENGINE MANAGEME	2.0 16v X20XEV (96-98)	SIEMENS Simtec 56.5
 Astra-F	ENGINE MANAGEME	2.0 C20NE (92-98)	BOSCH Motronic M1.5.2
 Astra-F	IMMOBILIZER	1.4 (96-97)	GM Immobilizer
 Astra-F	IMMOBILIZER	1.4 16v (96-97)	GM Immobilizer
 Astra-F	IMMOBILIZER	1.6 (96-97)	GM Immobilizer
 Astra-F	IMMOBILIZER	1.6 16v (96-97)	GM Immobilizer
 Astra-F	IMMOBILIZER	1.6 Kat (96-97)	GM Immobilizer
 Astra-F	IMMOBILIZER	1.7 D (96-97)	GM Immobilizer
 Astra-F	IMMOBILIZER	1.7 TD (96-97)	GM Immobilizer
 Astra-F	IMMOBILIZER	1.7 TDS (96-97)	GM Immobilizer
 Astra-F	IMMOBILIZER	1.8 (96-97)	GM Immobilizer
 Astra-F	IMMOBILIZER	1.8 16v (96-97)	GM Immobilizer
 Astra-F	IMMOBILIZER	2.0 (96-97)	GM Immobilizer
 Astra-F	IMMOBILIZER	2.0 16v (96-97)	GM Immobilizer
 Astra-F	MAINTENANCE	1.6 C16NZ-Kat (92-..)	GM Multec TBI MANUAL
 Astra-G	ABS	1.2	BOSCH ABS 5.3/5.4(+TC)
 Astra-G	ABS	1.2 16v	BOSCH ABS 5.3/5.4(+TC)
 Astra-G	ABS	1.4	BOSCH ABS 5.3/5.4(+TC)
 Astra-G	ABS	1.4 16v	BOSCH ABS 5.3/5.4(+TC)
 Astra-G	ABS	1.6	BOSCH ABS 5.3/5.4(+TC)
 Astra-G	ABS	1.6 16v	BOSCH ABS 5.3/5.4(+TC)
 Astra-G	ABS	1.6 CNG	BOSCH ABS 5.3/5.4(+TC)
 Astra-G	ABS	1.7 16v CDTI	BOSCH ABS 5.3/5.4(+TC)
 Astra-G	ABS	1.7 DTI	BOSCH ABS 5.3/5.4(+TC)
 Astra-G	ABS	1.7 TD	BOSCH ABS 5.3/5.4(+TC)
 Astra-G	ABS	1.8	BOSCH ABS 5.3/5.4(+TC)
Astra-G	ABS	1.8 16v	BOSCH ABS 5.3/5.4(+TC)
Astra-G	ABS	2.0	BOSCH ABS 5.3/5.4(+TC)

Systems supported by ECUREADER / ECUDECODER (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Astra-G	ABS	2.0 16v	BOSCH ABS 5.3/5.4(+TC)
 Astra-G	ABS	2.0 DI	BOSCH ABS 5.3/5.4(+TC)
 Astra-G	ABS	2.0 DTI 16v	BOSCH ABS 5.3/5.4(+TC)
 Astra-G	ABS	2.0 T 16v	BOSCH ABS 5.3/5.4(+TC)
 Astra-G	ABS	2.2	BOSCH ABS 5.3/5.4(+TC)
 Astra-G	ABS	2.2 16v	BOSCH ABS 5.3/5.4(+TC)
 Astra-G	ABS	2.2 16v DTI	BOSCH ABS 5.3/5.4(+TC)
 Astra-G	AIRBAG	1.2 (...00)	SIEMENS AirBag SAB6
 Astra-G	AIRBAG	1.2 (00-..)	SIEMENS AirBag SAB6m
 Astra-G	AIRBAG	1.2 (01-..)	SIEMENS AirBag SAB8x
 Astra-G	AIRBAG	1.2 16v (...00)	SIEMENS AirBag SAB6
 Astra-G	AIRBAG	1.2 16v (00-..)	SIEMENS AirBag SAB6m
 Astra-G	AIRBAG	1.2 16v (01-..)	SIEMENS AirBag SAB8x
 Astra-G	AIRBAG	1.4 (...00)	SIEMENS AirBag SAB6
 Astra-G	AIRBAG	1.4 (00-..)	SIEMENS AirBag SAB6m
 Astra-G	AIRBAG	1.4 (01-..)	SIEMENS AirBag SAB8x
 Astra-G	AIRBAG	1.4 16v (...00)	SIEMENS AirBag SAB6
 Astra-G	AIRBAG	1.4 16v (00-..)	SIEMENS AirBag SAB6m
 Astra-G	AIRBAG	1.4 16v (01-..)	SIEMENS AirBag SAB8x
 Astra-G	AIRBAG	1.6 (...00)	SIEMENS AirBag SAB6
 Astra-G	AIRBAG	1.6 (00-..)	SIEMENS AirBag SAB6m
 Astra-G	AIRBAG	1.6 (01-..)	SIEMENS AirBag SAB8x
 Astra-G	AIRBAG	1.6 16v (...00)	SIEMENS AirBag SAB6
 Astra-G	AIRBAG	1.6 16v (00-..)	SIEMENS AirBag SAB6m
 Astra-G	AIRBAG	1.6 16v (01-..)	SIEMENS AirBag SAB8x
 Astra-G	AIRBAG	1.6 CNG (...00)	SIEMENS AirBag SAB6
 Astra-G	AIRBAG	1.6 CNG (00-..)	SIEMENS AirBag SAB6m
 Astra-G	AIRBAG	1.6 CNG (01-..)	SIEMENS AirBag SAB8x
 Astra-G	AIRBAG	1.7 16v CDTI (...00)	SIEMENS AirBag SAB6
 Astra-G	AIRBAG	1.7 16v CDTI (00-..)	SIEMENS AirBag SAB6m
 Astra-G	AIRBAG	1.7 16v CDTI (01-..)	SIEMENS AirBag SAB8x
 Astra-G	AIRBAG	1.7 DTI (...00)	SIEMENS AirBag SAB6
 Astra-G	AIRBAG	1.7 DTI (00-..)	SIEMENS AirBag SAB6m
 Astra-G	AIRBAG	1.7 DTI (01-..)	SIEMENS AirBag SAB8x
 Astra-G	AIRBAG	1.7 TD (...00)	SIEMENS AirBag SAB6
 Astra-G	AIRBAG	1.7 TD (00-..)	SIEMENS AirBag SAB6m
 Astra-G	AIRBAG	1.7 TD (01-..)	SIEMENS AirBag SAB8x
 Astra-G	AIRBAG	1.8 (...00)	SIEMENS AirBag SAB6
 Astra-G	AIRBAG	1.8 (00-..)	SIEMENS AirBag SAB6m
 Astra-G	AIRBAG	1.8 (01-..)	SIEMENS AirBag SAB8x
 Astra-G	AIRBAG	1.8 16v (...00)	SIEMENS AirBag SAB6
 Astra-G	AIRBAG	1.8 16v (00-..)	SIEMENS AirBag SAB6m
 Astra-G	AIRBAG	1.8 16v (01-..)	SIEMENS AirBag SAB8x
 Astra-G	AIRBAG	2.0 (...00)	SIEMENS AirBag SAB6
 Astra-G	AIRBAG	2.0 (00-..)	SIEMENS AirBag SAB6m
 Astra-G	AIRBAG	2.0 (01-..)	SIEMENS AirBag SAB8x
 Astra-G	AIRBAG	2.0 16v (...00)	SIEMENS AirBag SAB6
 Astra-G	AIRBAG	2.0 16v (00-..)	SIEMENS AirBag SAB6m
 Astra-G	AIRBAG	2.0 16v (01-..)	SIEMENS AirBag SAB8x
 Astra-G	AIRBAG	2.0 DI (...00)	SIEMENS AirBag SAB6
 Astra-G	AIRBAG	2.0 DI (00-..)	SIEMENS AirBag SAB6m
 Astra-G	AIRBAG	2.0 DI (01-..)	SIEMENS AirBag SAB8x
 Astra-G	AIRBAG	2.0 DTI 16v (...00)	SIEMENS AirBag SAB6
 Astra-G	AIRBAG	2.0 DTI 16v (00-..)	SIEMENS AirBag SAB6m
 Astra-G	AIRBAG	2.0 DTI 16v (01-..)	SIEMENS AirBag SAB8x
 Astra-G	AIRBAG	2.0 T 16v (...00)	SIEMENS AirBag SAB6
 Astra-G	AIRBAG	2.0 T 16v (00-..)	SIEMENS AirBag SAB6m
 Astra-G	AIRBAG	2.0 T 16v (01-..)	SIEMENS AirBag SAB8x

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Astra-G	AIRBAG	2.2 (...00)	SIEMENS AirBag SAB6
 Astra-G	AIRBAG	2.2 (00-..)	SIEMENS AirBag SAB6m
 Astra-G	AIRBAG	2.2 (01-..)	SIEMENS AirBag SAB8x
 Astra-G	AIRBAG	2.2 16v (...00)	SIEMENS AirBag SAB6
 Astra-G	AIRBAG	2.2 16v (00-..)	SIEMENS AirBag SAB6m
 Astra-G	AIRBAG	2.2 16v (01-..)	SIEMENS AirBag SAB8x
 Astra-G	AIRBAG	2.2 16v DTI (...00)	SIEMENS AirBag SAB6
 Astra-G	AIRBAG	2.2 16v DTI (00-..)	SIEMENS AirBag SAB6m
 Astra-G	AIRBAG	2.2 16v DTI (01-..)	SIEMENS AirBag SAB8x
 Astra-G	AUTOM. TRANSMISSI	1.2 16v	
 Astra-G	AUTOM. TRANSMISSI	1.4 16v	
 Astra-G	AUTOM. TRANSMISSI	1.6 16v	
 Astra-G	AUTOM. TRANSMISSI	1.6 CNG	
 Astra-G	AUTOM. TRANSMISSI	1.7 16v CDTI	
 Astra-G	AUTOM. TRANSMISSI	1.7 DTI	
 Astra-G	AUTOM. TRANSMISSI	1.7 TD	
 Astra-G	AUTOM. TRANSMISSI	1.8 16v	
 Astra-G	AUTOM. TRANSMISSI	2.0 16v	
 Astra-G	AUTOM. TRANSMISSI	2.0 DI	
 Astra-G	AUTOM. TRANSMISSI	2.0 DTI 16v	
 Astra-G	AUTOM. TRANSMISSI	2.0 T 16v	
 Astra-G	AUTOM. TRANSMISSI	2.2 16v	
 Astra-G	AUTOM. TRANSMISSI	2.2 16v DTI	
 Astra-G	CENTRAL LOCKING	1.2	Central Locking
 Astra-G	CENTRAL LOCKING	1.2 16v	Central Locking
 Astra-G	CENTRAL LOCKING	1.4	Central Locking
 Astra-G	CENTRAL LOCKING	1.4 16v	Central Locking
 Astra-G	CENTRAL LOCKING	1.6	Central Locking
 Astra-G	CENTRAL LOCKING	1.6 16v	Central Locking
 Astra-G	CENTRAL LOCKING	1.6 CNG	Central Locking
 Astra-G	CENTRAL LOCKING	1.7 16v CDTI	Central Locking
 Astra-G	CENTRAL LOCKING	1.7 DTI	Central Locking
 Astra-G	CENTRAL LOCKING	1.7 TD	Central Locking
 Astra-G	CENTRAL LOCKING	1.8	Central Locking
 Astra-G	CENTRAL LOCKING	1.8 16v	Central Locking
 Astra-G	CENTRAL LOCKING	2.0	Central Locking
 Astra-G	CENTRAL LOCKING	2.0 16v	Central Locking
 Astra-G	CENTRAL LOCKING	2.0 DI	Central Locking
 Astra-G	CENTRAL LOCKING	2.0 DTI 16v	Central Locking
 Astra-G	CENTRAL LOCKING	2.0 T 16v	Central Locking
 Astra-G	CENTRAL LOCKING	2.2	Central Locking
 Astra-G	CENTRAL LOCKING	2.2 16v	Central Locking
 Astra-G	CENTRAL LOCKING	2.2 16v DTI	Central Locking
 Astra-G	ENGINE COOLING	1.2 (98-..)	BOSCH xx
 Astra-G	ENGINE COOLING	1.2 16v (98-..)	BOSCH xx
 Astra-G	ENGINE COOLING	1.4 (98-..)	BOSCH xx
 Astra-G	ENGINE COOLING	1.4 16v (98-..)	BOSCH xx
 Astra-G	ENGINE COOLING	1.6 (98-..)	BOSCH xx
 Astra-G	ENGINE COOLING	1.6 16v (98-..)	BOSCH xx
 Astra-G	ENGINE COOLING	1.6 CNG (98-..)	BOSCH xx
 Astra-G	ENGINE COOLING	1.7 16v CDTI (98-..)	BOSCH xx
 Astra-G	ENGINE COOLING	1.7 DTI (98-..)	BOSCH xx
 Astra-G	ENGINE COOLING	1.7 TD (98-..)	BOSCH xx
 Astra-G	ENGINE COOLING	1.8 16v (98-..)	BOSCH xx
 Astra-G	ENGINE COOLING	2.0 (98-..)	BOSCH xx
 Astra-G	ENGINE COOLING	2.0 16v (98-..)	BOSCH xx
 Astra-G	ENGINE COOLING	2.0 DI (98-..)	BOSCH xx
 Astra-G	ENGINE COOLING	2.0 DTI 16v (98-..)	BOSCH xx

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Astra-G	ENGINE COOLING	2.0 T 16v (98-..)	BOSCH xx
 Astra-G	ENGINE COOLING	2.2 (98-..)	BOSCH xx
 Astra-G	ENGINE COOLING	2.2 16v (98-..)	BOSCH xx
 Astra-G	ENGINE COOLING	2.2 16v DTI (98-..)	BOSCH xx
 Astra-G	ENGINE MANAGEME	1.2 16v X12XE (98-00)	BOSCH Motronic M1.5.5
 Astra-G	ENGINE MANAGEME	1.2 16v Z12XE (01-..)	BOSCH Motronic M1.5.5
 Astra-G	ENGINE MANAGEME	1.2 Z12SE (01-..)	EOBD
 Astra-G	ENGINE MANAGEME	1.4 16v X14XE (98-00)	GM Multec H
 Astra-G	ENGINE MANAGEME	1.4 16v Z14XE (...04)	GM Multec H
 Astra-G	ENGINE MANAGEME	1.4 Z14SE (01-..)	EOBD
 Astra-G	ENGINE MANAGEME	1.6 16v X16SZR (98-00)	GM Multec F
 Astra-G	ENGINE MANAGEME	1.6 16v X16XEL (98-00)	GM Multec H
 Astra-G	ENGINE MANAGEME	1.6 16v Z16SE (01-..)	EOBD
 Astra-G	ENGINE MANAGEME	1.6 16v Z16XE (...04)	GM Multec H
 Astra-G	ENGINE MANAGEME	1.6 CNG (01-..)	EOBD
 Astra-G	ENGINE MANAGEME	1.6 X16SZR (98-00)	GM Multec F
 Astra-G	ENGINE MANAGEME	1.6 Z16SE (01-..)	EOBD
 Astra-G	ENGINE MANAGEME	1.6 Z16SZR (01-..)	EOBD
 Astra-G	ENGINE MANAGEME	1.6 Z16XE (01-..)	EOBD
 Astra-G	ENGINE MANAGEME	1.7 16v CDTI (04-..)	EOBD
 Astra-G	ENGINE MANAGEME	1.7 DTI Y17DT (01-..)	DELPHI EDC HDRC
 Astra-G	ENGINE MANAGEME	1.7 DTI Y17DT (99-01)	DELPHI EDC HDRC
 Astra-G	ENGINE MANAGEME	1.7 TD X17DTL (98-00)	BOSCH EDC MSA 15 M
 Astra-G	ENGINE MANAGEME	1.8 16v X18XE1 (98-00)	SIEMENS Simtec 70
 Astra-G	ENGINE MANAGEME	1.8 Z18XE (01-..)	EOBD
 Astra-G	ENGINE MANAGEME	1.8 Z18XEL (01-..)	EOBD
 Astra-G	ENGINE MANAGEME	2.0 16v X20XEV (98-00)	SIEMENS Simtec 70
 Astra-G	ENGINE MANAGEME	2.0 DI X20DTL (98-00)	BOSCH EDC MSA 15 M
 Astra-G	ENGINE MANAGEME	2.0 DI Y20DTH (01-..)	BOSCH EDC MSA 15 M
 Astra-G	ENGINE MANAGEME	2.0 DTI 16v (04-..)	EOBD
 Astra-G	ENGINE MANAGEME	2.0 T 16v (01-..)	EOBD
 Astra-G	ENGINE MANAGEME	2.0 Z20LET (01-..)	EOBD
 Astra-G	ENGINE MANAGEME	2.2 16v DTI (04-..)	EOBD
 Astra-G	ENGINE MANAGEME	2.2 16v Z22SE (01-..)	EOBD
 Astra-G	ENGINE MANAGEME	2.2 Z22SE (01-..)	EOBD
 Astra-G	IMMOBILIZER	1.2 (99-..)	SIEMENS
 Astra-G	IMMOBILIZER	1.2 16v (99-..)	SIEMENS
 Astra-G	IMMOBILIZER	1.4 (99-..)	SIEMENS
 Astra-G	IMMOBILIZER	1.4 16v (99-..)	SIEMENS
 Astra-G	IMMOBILIZER	1.6 (99-..)	SIEMENS
 Astra-G	IMMOBILIZER	1.6 16v (99-..)	SIEMENS
 Astra-G	IMMOBILIZER	1.6 CNG (99-..)	SIEMENS
 Astra-G	IMMOBILIZER	1.7 16v CDTI (99-..)	SIEMENS
 Astra-G	IMMOBILIZER	1.7 DTI (99-..)	SIEMENS
 Astra-G	IMMOBILIZER	1.7 TD (99-..)	SIEMENS
 Astra-G	IMMOBILIZER	1.8 (99-..)	SIEMENS
 Astra-G	IMMOBILIZER	1.8 16v (99-..)	SIEMENS
 Astra-G	IMMOBILIZER	2.0 (99-..)	SIEMENS
 Astra-G	IMMOBILIZER	2.0 16v (99-..)	SIEMENS
 Astra-G	IMMOBILIZER	2.0 DI (99-..)	SIEMENS
 Astra-G	IMMOBILIZER	2.0 DTI 16v (99-..)	SIEMENS
 Astra-G	IMMOBILIZER	2.0 T 16v (99-..)	SIEMENS
 Astra-G	IMMOBILIZER	2.2 (99-..)	SIEMENS
 Astra-G	IMMOBILIZER	2.2 16v (99-..)	SIEMENS
 Astra-G	IMMOBILIZER	2.2 16v DTI (99-..)	SIEMENS
 Astra-G	MAINTENANCE	1.2 (98-00)	GM MANUAL
 Astra-G	MAINTENANCE	1.2 16v (98-00)	GM MANUAL
 Astra-G	MAINTENANCE	1.4 (98-00)	GM MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Astra-G	MAINTENANCE	1.4 16v (98-00)	GM MANUAL
 Astra-G	MAINTENANCE	1.6 (98-00)	GM MANUAL
 Astra-G	MAINTENANCE	1.6 16v (98-00)	GM MANUAL
 Astra-G	MAINTENANCE	1.6 CNG (98-00)	GM MANUAL
 Astra-G	MAINTENANCE	1.7 16v CDTI (98-00)	GM MANUAL
 Astra-G	MAINTENANCE	1.7 DTI (98-00)	GM MANUAL
 Astra-G	MAINTENANCE	1.7 TD (98-00)	GM MANUAL
 Astra-G	MAINTENANCE	1.8 (98-00)	GM MANUAL
 Astra-G	MAINTENANCE	1.8 16v (98-00)	GM MANUAL
 Astra-G	MAINTENANCE	2.0 (98-00)	GM MANUAL
 Astra-G	MAINTENANCE	2.0 16v (98-00)	GM MANUAL
 Astra-G	MAINTENANCE	2.0 DI (98-00)	GM MANUAL
 Astra-G	MAINTENANCE	2.0 DTI 16v (98-00)	GM MANUAL
 Astra-G	MAINTENANCE	2.0 T 16v (98-00)	GM MANUAL
 Astra-G	MAINTENANCE	2.2 (98-00)	GM MANUAL
 Astra-G	MAINTENANCE	2.2 16v (98-00)	GM MANUAL
 Astra-G	MAINTENANCE	2.2 16v DTI (98-00)	GM MANUAL
 Astra-G	SERVICE LIGHT RES	1.2 (98-00)	GM MANUAL
 Astra-G	SERVICE LIGHT RES	1.2 16v (98-00)	GM MANUAL
 Astra-G	SERVICE LIGHT RES	1.4 (98-00)	GM MANUAL
 Astra-G	SERVICE LIGHT RES	1.4 16v (98-00)	GM MANUAL
 Astra-G	SERVICE LIGHT RES	1.6 (98-00)	GM MANUAL
 Astra-G	SERVICE LIGHT RES	1.6 16v (98-00)	GM MANUAL
 Astra-G	SERVICE LIGHT RES	1.6 CNG (98-00)	GM MANUAL
 Astra-G	SERVICE LIGHT RES	1.7 16v CDTI (98-00)	GM MANUAL
 Astra-G	SERVICE LIGHT RES	1.7 DTI (98-00)	GM MANUAL
 Astra-G	SERVICE LIGHT RES	1.7 TD (98-00)	GM MANUAL
 Astra-G	SERVICE LIGHT RES	1.8 (98-00)	GM MANUAL
 Astra-G	SERVICE LIGHT RES	1.8 16v (98-00)	GM MANUAL
 Astra-G	SERVICE LIGHT RES	2.0 (98-00)	GM MANUAL
 Astra-G	SERVICE LIGHT RES	2.0 16v (98-00)	GM MANUAL
 Astra-G	SERVICE LIGHT RES	2.0 DI (98-00)	GM MANUAL
 Astra-G	SERVICE LIGHT RES	2.0 DTI 16v (98-00)	GM MANUAL
 Astra-G	SERVICE LIGHT RES	2.0 T 16v (98-00)	GM MANUAL
 Astra-G	SERVICE LIGHT RES	2.2 (98-00)	GM MANUAL
 Astra-G	SERVICE LIGHT RES	2.2 16v (98-00)	GM MANUAL
 Astra-G	SERVICE LIGHT RES	2.2 16v DTI (98-00)	GM MANUAL
 Astra-H	ABS	1.3 16v CDTI (04-..)	TEVES ABS Mk70
 Astra-H	ABS	1.4 16v (04-..)	TEVES ABS Mk70
 Astra-H	ABS	1.6 16v (04-..)	TEVES ABS Mk70
 Astra-H	ABS	1.6 CNG (04-..)	TEVES ABS Mk70
 Astra-H	ABS	1.6 T (04-..)	TEVES ABS Mk70
 Astra-H	ABS	1.7 16v CDTI (04-..)	TEVES ABS Mk70
 Astra-H	ABS	1.8 16v (04-..)	TEVES ABS Mk70
 Astra-H	ABS	1.9 16v CDTI (04-..)	TEVES ABS Mk70
 Astra-H	ABS	1.9 8v CDTI (04-..)	TEVES ABS Mk70
 Astra-H	ABS	2.0 T 16v (04-..)	TEVES ABS Mk70
 Astra-H	AIRBAG	1.3 16v CDTI (04-..)	TEMIC AirBag MRSZ
 Astra-H	AIRBAG	1.4 16v (04-..)	TEMIC AirBag MRSZ
 Astra-H	AIRBAG	1.6 16v (04-..)	TEMIC AirBag MRSZ
 Astra-H	AIRBAG	1.6 CNG (04-..)	TEMIC AirBag MRSZ
 Astra-H	AIRBAG	1.6 T (04-..)	TEMIC AirBag MRSZ
 Astra-H	AIRBAG	1.7 16v CDTI (04-..)	TEMIC AirBag MRSZ
 Astra-H	AIRBAG	1.8 16v (04-..)	TEMIC AirBag MRSZ
 Astra-H	AIRBAG	1.9 16v CDTI (04-..)	TEMIC AirBag MRSZ
 Astra-H	AIRBAG	1.9 8v CDTI (04-..)	TEMIC AirBag MRSZ
 Astra-H	AIRBAG	2.0 T 16v (04-..)	TEMIC AirBag MRSZ
 Astra-H	AIRBAG CODING	1.3 16v CDTI (04-..)	Temic SRS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Astra-H	AIRBAG CODING	1.4 16v (04-..)	Temic SRS
 Astra-H	AIRBAG CODING	1.6 16v (04-..)	Temic SRS
 Astra-H	AIRBAG CODING	1.6 CNG (04-..)	Temic SRS
 Astra-H	AIRBAG CODING	1.6 T (04-..)	Temic SRS
 Astra-H	AIRBAG CODING	1.7 16v CDTI (04-..)	Temic SRS
 Astra-H	AIRBAG CODING	1.8 16v (04-..)	Temic SRS
 Astra-H	AIRBAG CODING	1.9 16v CDTI (04-..)	Temic SRS
 Astra-H	AIRBAG CODING	1.9 8v CDTI (04-..)	Temic SRS
 Astra-H	AIRBAG CODING	2.0 T 16v (04-..)	Temic SRS
 Astra-H	AUTOM. TRANSMISSI	1.3 16v CDTI (04-..)	A/T AF 40-6
 Astra-H	AUTOM. TRANSMISSI	1.3 16v CDTI (04-..)	MTA easytronic
 Astra-H	AUTOM. TRANSMISSI	1.4 16v (04-..)	A/T AF 40-6
 Astra-H	AUTOM. TRANSMISSI	1.4 16v (04-..)	MTA easytronic
 Astra-H	AUTOM. TRANSMISSI	1.6 16v (04-..)	A/T AF 40-6
 Astra-H	AUTOM. TRANSMISSI	1.6 16v (04-..)	MTA easytronic
 Astra-H	AUTOM. TRANSMISSI	1.6 CNG (04-..)	A/T AF 40-6
 Astra-H	AUTOM. TRANSMISSI	1.6 CNG (04-..)	MTA easytronic
 Astra-H	AUTOM. TRANSMISSI	1.6 T (04-..)	A/T AF 40-6
 Astra-H	AUTOM. TRANSMISSI	1.6 T (04-..)	MTA easytronic
 Astra-H	AUTOM. TRANSMISSI	1.7 16v CDTI (04-..)	A/T AF 40-6
 Astra-H	AUTOM. TRANSMISSI	1.7 16v CDTI (04-..)	MTA easytronic
 Astra-H	AUTOM. TRANSMISSI	1.8 16v (04-..)	A/T AF 40-6
 Astra-H	AUTOM. TRANSMISSI	1.8 16v (04-..)	MTA easytronic
 Astra-H	AUTOM. TRANSMISSI	1.9 16v CDTI (04-..)	A/T AF 40-6
 Astra-H	AUTOM. TRANSMISSI	1.9 16v CDTI (04-..)	MTA easytronic
 Astra-H	AUTOM. TRANSMISSI	1.9 8v CDTI (04-..)	A/T AF 40-6
 Astra-H	AUTOM. TRANSMISSI	1.9 8v CDTI (04-..)	MTA easytronic
 Astra-H	AUTOM. TRANSMISSI	2.0 T 16v (04-..)	A/T AF 40-6
 Astra-H	AUTOM. TRANSMISSI	2.0 T 16v (04-..)	MTA easytronic
 Astra-H	CHASSIS NETWORK	1.3 16v CDTI (04-..)	REC Rear Module
 Astra-H	CHASSIS NETWORK	1.3 16v CDTI (04-..)	UEC Front Module
 Astra-H	CHASSIS NETWORK	1.4 16v (04-..)	REC Rear Module
 Astra-H	CHASSIS NETWORK	1.4 16v (04-..)	UEC Front Module
 Astra-H	CHASSIS NETWORK	1.6 16v (04-..)	REC Rear Module
 Astra-H	CHASSIS NETWORK	1.6 16v (04-..)	UEC Front Module
 Astra-H	CHASSIS NETWORK	1.6 CNG (04-..)	REC Rear Module
 Astra-H	CHASSIS NETWORK	1.6 CNG (04-..)	UEC Front Module
 Astra-H	CHASSIS NETWORK	1.6 T (04-..)	REC Rear Module
 Astra-H	CHASSIS NETWORK	1.6 T (04-..)	UEC Front Module
 Astra-H	CHASSIS NETWORK	1.7 16v CDTI (04-..)	REC Rear Module
 Astra-H	CHASSIS NETWORK	1.7 16v CDTI (04-..)	UEC Front Module
 Astra-H	CHASSIS NETWORK	1.8 16v (04-..)	REC Rear Module
 Astra-H	CHASSIS NETWORK	1.8 16v (04-..)	UEC Front Module
 Astra-H	CHASSIS NETWORK	1.9 16v CDTI (04-..)	REC Rear Module
 Astra-H	CHASSIS NETWORK	1.9 16v CDTI (04-..)	UEC Front Module
 Astra-H	CHASSIS NETWORK	1.9 8v CDTI (04-..)	REC Rear Module
 Astra-H	CHASSIS NETWORK	1.9 8v CDTI (04-..)	UEC Front Module
 Astra-H	CHASSIS NETWORK	2.0 T 16v (04-..)	REC Rear Module
 Astra-H	CHASSIS NETWORK	2.0 T 16v (04-..)	UEC Front Module
 Astra-H	CLIMA	1.3 16v CDTI (04-..)	ECC
 Astra-H	CLIMA	1.3 16v CDTI (08-..)	ECC/SAC
 Astra-H	CLIMA	1.4 16v (04-..)	ECC
 Astra-H	CLIMA	1.4 16v (08-..)	ECC/SAC
 Astra-H	CLIMA	1.6 16v (04-..)	ECC
 Astra-H	CLIMA	1.6 16v (08-..)	ECC/SAC
 Astra-H	CLIMA	1.6 CNG (04-..)	ECC
 Astra-H	CLIMA	1.6 CNG (08-..)	ECC/SAC
 Astra-H	CLIMA	1.6 T (04-..)	ECC

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Astra-H	CLIMA	1.6 T (08-..)	ECC/SAC
 Astra-H	CLIMA	1.7 16v CDTI (04-..)	ECC
 Astra-H	CLIMA	1.7 16v CDTI (08-..)	ECC/SAC
 Astra-H	CLIMA	1.8 16v (04-..)	ECC
 Astra-H	CLIMA	1.8 16v (08-..)	ECC/SAC
 Astra-H	CLIMA	1.9 16v CDTI (04-..)	ECC
 Astra-H	CLIMA	1.9 16v CDTI (08-..)	ECC/SAC
 Astra-H	CLIMA	1.9 8v CDTI (04-..)	ECC
 Astra-H	CLIMA	1.9 8v CDTI (08-..)	ECC/SAC
 Astra-H	CLIMA	2.0 T 16v (04-..)	ECC
 Astra-H	CLIMA	2.0 T 16v (08-..)	ECC/SAC
 Astra-H	DASHBOARD	1.3 16v CDTI (04-..)	Dashboard
 Astra-H	DASHBOARD	1.4 16v (04-..)	Dashboard
 Astra-H	DASHBOARD	1.6 16v (04-..)	Dashboard
 Astra-H	DASHBOARD	1.6 CNG (04-..)	Dashboard
 Astra-H	DASHBOARD	1.6 T (04-..)	Dashboard
 Astra-H	DASHBOARD	1.7 16v CDTI (04-..)	Dashboard
 Astra-H	DASHBOARD	1.8 16v (04-..)	Dashboard
 Astra-H	DASHBOARD	1.9 16v CDTI (04-..)	Dashboard
 Astra-H	DASHBOARD	1.9 8v CDTI (04-..)	Dashboard
 Astra-H	DASHBOARD	2.0 T 16v (04-..)	Dashboard
 Astra-H	ELECTRIC STEERING	1.3 16v CDTI (04-..)	EHPS
 Astra-H	ELECTRIC STEERING	1.3 16v CDTI (06-..)	EHPS No CAN
 Astra-H	ELECTRIC STEERING	1.4 16v (04-..)	EHPS
 Astra-H	ELECTRIC STEERING	1.4 16v (06-..)	EHPS No CAN
 Astra-H	ELECTRIC STEERING	1.6 16v (04-..)	EHPS
 Astra-H	ELECTRIC STEERING	1.6 16v (06-..)	EHPS No CAN
 Astra-H	ELECTRIC STEERING	1.6 CNG (04-..)	EHPS
 Astra-H	ELECTRIC STEERING	1.6 CNG (06-..)	EHPS No CAN
 Astra-H	ELECTRIC STEERING	1.6 T (04-..)	EHPS
 Astra-H	ELECTRIC STEERING	1.6 T (06-..)	EHPS No CAN
 Astra-H	ELECTRIC STEERING	1.7 16v CDTI (04-..)	EHPS
 Astra-H	ELECTRIC STEERING	1.7 16v CDTI (06-..)	EHPS No CAN
 Astra-H	ELECTRIC STEERING	1.8 16v (04-..)	EHPS
 Astra-H	ELECTRIC STEERING	1.8 16v (06-..)	EHPS No CAN
 Astra-H	ELECTRIC STEERING	1.9 16v CDTI (04-..)	EHPS
 Astra-H	ELECTRIC STEERING	1.9 16v CDTI (06-..)	EHPS No CAN
 Astra-H	ELECTRIC STEERING	1.9 8v CDTI (04-..)	EHPS
 Astra-H	ELECTRIC STEERING	1.9 8v CDTI (06-..)	EHPS No CAN
 Astra-H	ELECTRIC STEERING	2.0 T 16v (04-..)	EHPS
 Astra-H	ELECTRIC STEERING	2.0 T 16v (06-..)	EHPS No CAN
 Astra-H	ENGINE MANAGEME	1.3 16v CDTI Z13DTH (04-..)	Marelli Multijet 603 Common Rail
 Astra-H	ENGINE MANAGEME	1.4 16v Z14XEP (04-..)	SIEMENS MPI MS75
 Astra-H	ENGINE MANAGEME	1.6 16v Z16XEP (04-..)	SIEMENS MPI MS75
 Astra-H	ENGINE MANAGEME	1.6 16v Z16XER (04-..)	SIEMENS MPI MS75
 Astra-H	ENGINE MANAGEME	1.6 CNG (04-..)	EOBD
 Astra-H	ENGINE MANAGEME	1.6 T (04-..)	EOBD
 Astra-H	ENGINE MANAGEME	1.7 16v CDTI Z17DTH (04-..)	BOSCH EDC 16 Common Rail
 Astra-H	ENGINE MANAGEME	1.7 16v CDTI Z17DTJ/DTR (07-..)	DENSO BCM Common Rail
 Astra-H	ENGINE MANAGEME	1.8 16v Z18XER (04-..)	SIEMENS MPI MS75
 Astra-H	ENGINE MANAGEME	1.9 16v CDTI Z19DTH (04-..)	BOSCH EDC 16 Common Rail
 Astra-H	ENGINE MANAGEME	1.9 16v CDTI Z19DTH (06-..)	BOSCH EDC 16 Common Rail FAP
 Astra-H	ENGINE MANAGEME	1.9 8v CDTI (04-..)	EOBD
 Astra-H	ENGINE MANAGEME	1.9 8v CDTI Z19DT (04-..)	BOSCH EDC 16 Common Rail
 Astra-H	ENGINE MANAGEME	1.9 8v CDTI Z19DT (06-..)	BOSCH EDC 16 Common Rail FAP
 Astra-H	ENGINE MANAGEME	2.0 T 16v (04-..)	EOBD
 Astra-H	KEY ENCODE	1.3 16v CDTI (04-..)	Valeo CIM
 Astra-H	KEY ENCODE	1.4 16v (04-..)	Valeo CIM

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Astra-H	KEY ENCODE	1.6 16v (04-..)	Valeo CIM
 Astra-H	KEY ENCODE	1.6 CNG (04-..)	Valeo CIM
 Astra-H	KEY ENCODE	1.6 T (04-..)	Valeo CIM
 Astra-H	KEY ENCODE	1.7 16v CDTI (04-..)	Valeo CIM
 Astra-H	KEY ENCODE	1.8 16v (04-..)	Valeo CIM
 Astra-H	KEY ENCODE	1.9 16v CDTI (04-..)	Valeo CIM
 Astra-H	KEY ENCODE	1.9 8v CDTI (04-..)	Valeo CIM
 Astra-H	KEY ENCODE	2.0 T 16v (04-..)	Valeo CIM
 Astra-H	MAINTENANCE	1.3 16v CDTI (04-..)	Dashboard
 Astra-H	MAINTENANCE	1.3 16v CDTI (04-..)	Dashboard
 Astra-H	MAINTENANCE	1.3 16v CDTI (04-..)	Dashboard
 Astra-H	MAINTENANCE	1.3 16v CDTI (04-..)	IPC
 Astra-H	MAINTENANCE	1.3 16v CDTI (04-..)	MANUAL
 Astra-H	MAINTENANCE	1.4 16v (04-..)	Dashboard
 Astra-H	MAINTENANCE	1.4 16v (04-..)	Dashboard
 Astra-H	MAINTENANCE	1.4 16v (04-..)	Dashboard
 Astra-H	MAINTENANCE	1.4 16v (04-..)	IPC
 Astra-H	MAINTENANCE	1.4 16v (04-..)	MANUAL
 Astra-H	MAINTENANCE	1.4 16v Z14XEP (04-..)	SIEMENS MPI MS75
 Astra-H	MAINTENANCE	1.6 16v (04-..)	Dashboard
 Astra-H	MAINTENANCE	1.6 16v (04-..)	Dashboard
 Astra-H	MAINTENANCE	1.6 16v (04-..)	Dashboard
 Astra-H	MAINTENANCE	1.6 16v (04-..)	IPC
 Astra-H	MAINTENANCE	1.6 16v (04-..)	MANUAL
 Astra-H	MAINTENANCE	1.6 16v Z16XEP (04-..)	SIEMENS MPI MS75
 Astra-H	MAINTENANCE	1.6 16v Z16XER (04-..)	SIEMENS MPI MS75
 Astra-H	MAINTENANCE	1.6 CNG (04-..)	Dashboard
 Astra-H	MAINTENANCE	1.6 CNG (04-..)	Dashboard
 Astra-H	MAINTENANCE	1.6 CNG (04-..)	Dashboard
 Astra-H	MAINTENANCE	1.6 CNG (04-..)	IPC
 Astra-H	MAINTENANCE	1.6 CNG (04-..)	MANUAL
 Astra-H	MAINTENANCE	1.6 T (04-..)	Dashboard
 Astra-H	MAINTENANCE	1.6 T (04-..)	Dashboard
 Astra-H	MAINTENANCE	1.6 T (04-..)	Dashboard
 Astra-H	MAINTENANCE	1.6 T (04-..)	IPC
 Astra-H	MAINTENANCE	1.6 T (04-..)	MANUAL
 Astra-H	MAINTENANCE	1.7 16v CDTI (04-..)	Dashboard
 Astra-H	MAINTENANCE	1.7 16v CDTI (04-..)	Dashboard
 Astra-H	MAINTENANCE	1.7 16v CDTI (04-..)	Dashboard
 Astra-H	MAINTENANCE	1.7 16v CDTI (04-..)	IPC
 Astra-H	MAINTENANCE	1.7 16v CDTI (04-..)	MANUAL
 Astra-H	MAINTENANCE	1.8 16v (04-..)	Dashboard
 Astra-H	MAINTENANCE	1.8 16v (04-..)	Dashboard
 Astra-H	MAINTENANCE	1.8 16v (04-..)	Dashboard
 Astra-H	MAINTENANCE	1.8 16v (04-..)	IPC
 Astra-H	MAINTENANCE	1.8 16v (04-..)	MANUAL
 Astra-H	MAINTENANCE	1.8 16v Z18XER (04-..)	SIEMENS MPI MS75
 Astra-H	MAINTENANCE	1.9 16v CDTI (04-..)	Dashboard
 Astra-H	MAINTENANCE	1.9 16v CDTI (04-..)	Dashboard
 Astra-H	MAINTENANCE	1.9 16v CDTI (04-..)	Dashboard
 Astra-H	MAINTENANCE	1.9 16v CDTI (04-..)	IPC
 Astra-H	MAINTENANCE	1.9 16v CDTI (04-..)	MANUAL
 Astra-H	MAINTENANCE	1.9 16v CDTI Z19DTH (06-..)	BOSCH EDC 16 Common Rail FAP
 Astra-H	MAINTENANCE	1.9 16v CDTI Z19DTH (06-..)	BOSCH EDC 16 Common Rail FAP
 Astra-H	MAINTENANCE	1.9 16v CDTI Z19DTH (06-..)	BOSCH EDC 16 Common Rail FAP
 Astra-H	MAINTENANCE	1.9 8v CDTI (04-..)	Dashboard
 Astra-H	MAINTENANCE	1.9 8v CDTI (04-..)	Dashboard
 Astra-H	MAINTENANCE	1.9 8v CDTI (04-..)	Dashboard

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Astra-H	MAINTENANCE	1.9 8v CDTI (04-..)	IPC
 Astra-H	MAINTENANCE	1.9 8v CDTI (04-..)	MANUAL
 Astra-H	MAINTENANCE	1.9 8v CDTI Z19DT (06-..)	BOSCH EDC 16 Common Rail FAP
 Astra-H	MAINTENANCE	1.9 8v CDTI Z19DT (06-..)	BOSCH EDC 16 Common Rail FAP
 Astra-H	MAINTENANCE	1.9 8v CDTI Z19DT (06-..)	BOSCH EDC 16 Common Rail FAP
 Astra-H	MAINTENANCE	2.0 T 16v (04-..)	Dashboard
 Astra-H	MAINTENANCE	2.0 T 16v (04-..)	Dashboard
 Astra-H	MAINTENANCE	2.0 T 16v (04-..)	Dashboard
 Astra-H	MAINTENANCE	2.0 T 16v (04-..)	IPC
 Astra-H	MAINTENANCE	2.0 T 16v (04-..)	MANUAL
 Astra-H	PARKING HELP	1.3 16v CDTI (04-..)	PAS
 Astra-H	PARKING HELP	1.4 16v (04-..)	PAS
 Astra-H	PARKING HELP	1.6 16v (04-..)	PAS
 Astra-H	PARKING HELP	1.6 CNG (04-..)	PAS
 Astra-H	PARKING HELP	1.6 T (04-..)	PAS
 Astra-H	PARKING HELP	1.7 16v CDTI (04-..)	PAS
 Astra-H	PARKING HELP	1.8 16v (04-..)	PAS
 Astra-H	PARKING HELP	1.9 16v CDTI (04-..)	PAS
 Astra-H	PARKING HELP	1.9 8v CDTI (04-..)	PAS
 Astra-H	PARKING HELP	2.0 T 16v (04-..)	PAS
 Astra-H	SERVICE LIGHT RES	1.3 16v CDTI (04-..)	IPC
 Astra-H	SERVICE LIGHT RES	1.3 16v CDTI (04-..)	MANUAL
 Astra-H	SERVICE LIGHT RES	1.4 16v (04-..)	IPC
 Astra-H	SERVICE LIGHT RES	1.4 16v (04-..)	MANUAL
 Astra-H	SERVICE LIGHT RES	1.6 16v (04-..)	IPC
 Astra-H	SERVICE LIGHT RES	1.6 16v (04-..)	MANUAL
 Astra-H	SERVICE LIGHT RES	1.6 CNG (04-..)	IPC
 Astra-H	SERVICE LIGHT RES	1.6 CNG (04-..)	MANUAL
 Astra-H	SERVICE LIGHT RES	1.6 T (04-..)	IPC
 Astra-H	SERVICE LIGHT RES	1.6 T (04-..)	MANUAL
 Astra-H	SERVICE LIGHT RES	1.7 16v CDTI (04-..)	IPC
 Astra-H	SERVICE LIGHT RES	1.7 16v CDTI (04-..)	MANUAL
 Astra-H	SERVICE LIGHT RES	1.8 16v (04-..)	IPC
 Astra-H	SERVICE LIGHT RES	1.8 16v (04-..)	MANUAL
 Astra-H	SERVICE LIGHT RES	1.9 16v CDTI (04-..)	IPC
 Astra-H	SERVICE LIGHT RES	1.9 16v CDTI (04-..)	MANUAL
 Astra-H	SERVICE LIGHT RES	1.9 8v CDTI (04-..)	IPC
 Astra-H	SERVICE LIGHT RES	1.9 8v CDTI (04-..)	MANUAL
 Astra-H	SERVICE LIGHT RES	2.0 T 16v (04-..)	IPC
 Astra-H	SERVICE LIGHT RES	2.0 T 16v (04-..)	MANUAL
 Astra-H	STEERING COLUMN	1.3 16v CDTI (04-..)	Valeo CIM
 Astra-H	STEERING COLUMN	1.4 16v (04-..)	Valeo CIM
 Astra-H	STEERING COLUMN	1.6 16v (04-..)	Valeo CIM
 Astra-H	STEERING COLUMN	1.6 CNG (04-..)	Valeo CIM
 Astra-H	STEERING COLUMN	1.6 T (04-..)	Valeo CIM
 Astra-H	STEERING COLUMN	1.7 16v CDTI (04-..)	Valeo CIM
 Astra-H	STEERING COLUMN	1.8 16v (04-..)	Valeo CIM
 Astra-H	STEERING COLUMN	1.9 16v CDTI (04-..)	Valeo CIM
 Astra-H	STEERING COLUMN	1.9 8v CDTI (04-..)	Valeo CIM
 Astra-H	STEERING COLUMN	2.0 T 16v (04-..)	Valeo CIM
 Calibra	AIRBAG	2.0 (93-97)	GM AirBag S
 Calibra	AIRBAG	2.0 16v (93-97)	GM AirBag S
 Calibra	AIRBAG	2.0 T (93-97)	GM AirBag S
 Calibra	AIRBAG	2.5 24v (93-97)	GM AirBag S
 Calibra	ENGINE MANAGEME	2.0 16v C20XE (...92)	BOSCH Motronic M2.5
 Calibra	ENGINE MANAGEME	2.0 16v C20XE (...96)	BOSCH Motronic M2.8
 Calibra	ENGINE MANAGEME	2.0 16v X20XEV (94-95)	SIEMENS Simtec 56.0 - 56.1
 Calibra	ENGINE MANAGEME	2.0 16v X20XEV (95-96)	SIEMENS Simtec 56.1

Systems supported by ECUREADER / ECUDECODER (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Calibra	ENGINE MANAGEME	2.0 16v X20XE (96-00)	SIEMENS Simtec 56.5
 Calibra	ENGINE MANAGEME	2.0 C20NE (...96)	BOSCH Motronic M1.5
 Calibra	ENGINE MANAGEME	2.0 T C20LET (...96)	BOSCH Motronic M2.7
 Calibra	ENGINE MANAGEME	2.5 24v C25XE (...96)	BOSCH Motronic M2.8
 Combo	ABS	1.3 CDTI (...03)	BOSCH ABS 5.3/5.4(+TC)
 Combo	ABS	1.3 CDTI (04-..)	BOSCH ABS 8
 Combo	ABS	1.4 (...03)	BOSCH ABS 5.3/5.4(+TC)
 Combo	ABS	1.4 (04-..)	BOSCH ABS 8
 Combo	ABS	1.6 (...03)	BOSCH ABS 5.3/5.4(+TC)
 Combo	ABS	1.6 (04-..)	BOSCH ABS 8
 Combo	ABS	1.6 16v (...03)	BOSCH ABS 5.3/5.4(+TC)
 Combo	ABS	1.6 16v (04-..)	BOSCH ABS 8
 Combo	ABS	1.6 CNG (...03)	BOSCH ABS 5.3/5.4(+TC)
 Combo	ABS	1.6 CNG (04-..)	BOSCH ABS 8
 Combo	ABS	1.7 16v CDTI (...03)	BOSCH ABS 5.3/5.4(+TC)
 Combo	ABS	1.7 16v CDTI (04-..)	BOSCH ABS 8
 Combo	ABS	1.7 DI (...03)	BOSCH ABS 5.3/5.4(+TC)
 Combo	ABS	1.7 DI (04-..)	BOSCH ABS 8
 Combo	ABS	1.7 DTI (...03)	BOSCH ABS 5.3/5.4(+TC)
 Combo	ABS	1.7 DTI (04-..)	BOSCH ABS 8
 Combo	AIRBAG	1.3 CDTI (04-..)	SIEMENS AirBag SAB8x
 Combo	AIRBAG	1.3 CDTI (04-..)	TEMIC AirBag 07
 Combo	AIRBAG	1.4	SIEMENS AirBag SAB8x
 Combo	AIRBAG	1.4 (01-..)	TEMIC AirBag 07
 Combo	AIRBAG	1.6	SIEMENS AirBag SAB8x
 Combo	AIRBAG	1.6 (01-..)	TEMIC AirBag 07
 Combo	AIRBAG	1.6 16v	SIEMENS AirBag SAB8x
 Combo	AIRBAG	1.6 16v (01-..)	TEMIC AirBag 07
 Combo	AIRBAG	1.6 CNG	SIEMENS AirBag SAB8x
 Combo	AIRBAG	1.6 CNG (01-..)	TEMIC AirBag 07
 Combo	AIRBAG	1.7 16v CDTI	SIEMENS AirBag SAB8x
 Combo	AIRBAG	1.7 16v CDTI (01-..)	TEMIC AirBag 07
 Combo	AIRBAG	1.7 DI	SIEMENS AirBag SAB8x
 Combo	AIRBAG	1.7 DI (01-..)	TEMIC AirBag 07
 Combo	AIRBAG	1.7 DTI	SIEMENS AirBag SAB8x
 Combo	AIRBAG	1.7 DTI (01-..)	TEMIC AirBag 07
 Combo	CHASSIS NETWORK	1.3 CDTI (04-..)	SIEMENS Body computer
 Combo	CHASSIS NETWORK	1.4	SIEMENS Body computer
 Combo	CHASSIS NETWORK	1.6	SIEMENS Body computer
 Combo	CHASSIS NETWORK	1.6 16v	SIEMENS Body computer
 Combo	CHASSIS NETWORK	1.6 CNG	SIEMENS Body computer
 Combo	CHASSIS NETWORK	1.7 16v CDTI	SIEMENS Body computer
 Combo	CHASSIS NETWORK	1.7 DI	SIEMENS Body computer
 Combo	CHASSIS NETWORK	1.7 DTI	SIEMENS Body computer
 Combo	DASHBOARD	1.3 CDTI (04-..)	SIEMENS Dashboard
 Combo	DASHBOARD	1.4 (02-..)	SIEMENS Dashboard
 Combo	DASHBOARD	1.6 (02-..)	SIEMENS Dashboard
 Combo	DASHBOARD	1.6 16v (02-..)	SIEMENS Dashboard
 Combo	DASHBOARD	1.6 CNG (02-..)	SIEMENS Dashboard
 Combo	DASHBOARD	1.7 16v CDTI (02-..)	SIEMENS Dashboard
 Combo	DASHBOARD	1.7 DI (02-..)	SIEMENS Dashboard
 Combo	DASHBOARD	1.7 DTI (02-..)	SIEMENS Dashboard
 Combo	ELECTRIC STEERING	1.3 CDTI (04-..)	EPS
 Combo	ELECTRIC STEERING	1.4	EPS
 Combo	ELECTRIC STEERING	1.6	EPS
 Combo	ELECTRIC STEERING	1.6 16v	EPS
 Combo	ELECTRIC STEERING	1.6 CNG	EPS
 Combo	ELECTRIC STEERING	1.7 16v CDTI	EPS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Combo	ELECTRIC STEERING	1.7 DI	EPS
 Combo	ELECTRIC STEERING	1.7 DTI	EPS
 Combo	ENGINE MANAGEME	1.3 CDTI Z13DT (04-..)	Marelli 6JF CF3 Common Rail
 Combo	ENGINE MANAGEME	1.4 X14SZ (97-00)	GM Multec S (F)
 Combo	ENGINE MANAGEME	1.6 (01-..)	EOBD
 Combo	ENGINE MANAGEME	1.6 16v (01-..)	EOBD
 Combo	ENGINE MANAGEME	1.6 CNG (01-..)	EOBD
 Combo	ENGINE MANAGEME	1.7 16v CDTI (04-..)	EOBD
 Combo	ENGINE MANAGEME	1.7 DI (04-..)	EOBD
 Combo	ENGINE MANAGEME	1.7 DTI Y17DT (01-05)	DELPHI EDC HDRC
 Combo	ENGINE MANAGEME	1.7 DTI Y17DTL (01-05)	DELPHI HDRC
 Combo	IMMOBILIZER	1.3 CDTI (04-..)	SIEMENS
 Combo	IMMOBILIZER	1.4	SIEMENS
 Combo	IMMOBILIZER	1.6	SIEMENS
 Combo	IMMOBILIZER	1.6 16v	SIEMENS
 Combo	IMMOBILIZER	1.6 CNG	SIEMENS
 Combo	IMMOBILIZER	1.7 16v CDTI	SIEMENS
 Combo	IMMOBILIZER	1.7 DI	SIEMENS
 Combo	IMMOBILIZER	1.7 DTI	SIEMENS
 Combo	MAINTENANCE	1.3 CDTI (04-..)	SIEMENS Dashboard
 Combo	MAINTENANCE	1.3 CDTI (04-..)	SIEMENS Dashboard
 Combo	MAINTENANCE	1.4 (02-..)	SIEMENS Dashboard
 Combo	MAINTENANCE	1.4 (02-..)	SIEMENS Dashboard
 Combo	MAINTENANCE	1.6 (02-..)	SIEMENS Dashboard
 Combo	MAINTENANCE	1.6 (02-..)	SIEMENS Dashboard
 Combo	MAINTENANCE	1.6 16v (02-..)	SIEMENS Dashboard
 Combo	MAINTENANCE	1.6 16v (02-..)	SIEMENS Dashboard
 Combo	MAINTENANCE	1.6 CNG (02-..)	SIEMENS Dashboard
 Combo	MAINTENANCE	1.6 CNG (02-..)	SIEMENS Dashboard
 Combo	MAINTENANCE	1.7 16v CDTI (02-..)	SIEMENS Dashboard
 Combo	MAINTENANCE	1.7 16v CDTI (02-..)	SIEMENS Dashboard
 Combo	MAINTENANCE	1.7 DI (02-..)	SIEMENS Dashboard
 Combo	MAINTENANCE	1.7 DI (02-..)	SIEMENS Dashboard
 Combo	MAINTENANCE	1.7 DTI (02-..)	SIEMENS Dashboard
 Combo	MAINTENANCE	1.7 DTI (02-..)	SIEMENS Dashboard
 Corsa-A	AIRBAG	1.0 (...93)	GM AirBag S
 Corsa-A	AIRBAG	1.2 (...93)	GM AirBag S
 Corsa-A	AIRBAG	1.3 (...93)	GM AirBag S
 Corsa-A	AIRBAG	1.4 (...93)	GM AirBag S
 Corsa-A	AIRBAG	1.5 D (...93)	GM AirBag S
 Corsa-A	AIRBAG	1.5 TD (...93)	GM AirBag S
 Corsa-A	AIRBAG	1.6 (...93)	GM AirBag S
 Corsa-A	AIRBAG	1.6 Kat (...93)	GM AirBag S
 Corsa-A	ENGINE MANAGEME	1.2 12NZ (...93)	GM Multec TBI
 Corsa-A	ENGINE MANAGEME	1.2 C12NZ (...93)	GM Multec TBI
 Corsa-A	ENGINE MANAGEME	1.4 C14NZ (...93)	GM Multec TBI
 Corsa-A	ENGINE MANAGEME	1.4 C14SE (...93)	GM Multec M
 Corsa-A	ENGINE MANAGEME	1.6 C16SE (...93)	GM Multec M
 Corsa-A	ENGINE MANAGEME	1.6 E16NZ (...93)	GM Multec TBI MANUAL
 Corsa-A	ENGINE MANAGEME	1.6 Kat C16NZ (...93)	GM Multec TBI MANUAL
 Corsa-A	MAINTENANCE	1.6 E16NZ (...93)	GM Multec TBI MANUAL
 Corsa-A	MAINTENANCE	1.6 Kat C16NZ (...93)	GM Multec TBI MANUAL
 Corsa-B	ABS	1.0 12v (...00)	GM ABS 415
 Corsa-B	ABS	1.2 16v (...00)	GM ABS 415
 Corsa-B	ABS	1.2 8v (...00)	GM ABS 415
 Corsa-B	ABS	1.4 (...00)	GM ABS 415
 Corsa-B	ABS	1.4 16v (...00)	GM ABS 415
 Corsa-B	ABS	1.5 D (...00)	GM ABS 415

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Corsa-B	ABS	1.5 TD (...00)	GM ABS 415
 Corsa-B	ABS	1.6 (...00)	GM ABS 415
 Corsa-B	ABS	1.6 16v (...00)	GM ABS 415
 Corsa-B	ABS	1.7 D (...00)	GM ABS 415
 Corsa-B	ABS	1.7 DTI (...00)	GM ABS 415
 Corsa-B	AIRBAG	1.0 12v (...00)	GM AirBag S
 Corsa-B	AIRBAG	1.0 12v (99-00)	SIEMENS AirBag SAB6
 Corsa-B	AIRBAG	1.2 16v (...00)	GM AirBag S
 Corsa-B	AIRBAG	1.2 16v (99-00)	SIEMENS AirBag SAB6
 Corsa-B	AIRBAG	1.2 8v (...00)	GM AirBag S
 Corsa-B	AIRBAG	1.2 8v (99-00)	SIEMENS AirBag SAB6
 Corsa-B	AIRBAG	1.4 (93-00)	GM AirBag S
 Corsa-B	AIRBAG	1.4 (99-00)	SIEMENS AirBag SAB6
 Corsa-B	AIRBAG	1.4 16v (93-00)	GM AirBag S
 Corsa-B	AIRBAG	1.4 16v (99-00)	SIEMENS AirBag SAB6
 Corsa-B	AIRBAG	1.5 D (93-00)	GM AirBag S
 Corsa-B	AIRBAG	1.5 D (99-00)	SIEMENS AirBag SAB6
 Corsa-B	AIRBAG	1.5 TD (93-00)	GM AirBag S
 Corsa-B	AIRBAG	1.5 TD (99-00)	SIEMENS AirBag SAB6
 Corsa-B	AIRBAG	1.6 (93-00)	GM AirBag S
 Corsa-B	AIRBAG	1.6 (99-00)	SIEMENS AirBag SAB6
 Corsa-B	AIRBAG	1.6 16v (93-00)	GM AirBag S
 Corsa-B	AIRBAG	1.6 16v (99-00)	SIEMENS AirBag SAB6
 Corsa-B	AIRBAG	1.7 D (93-00)	GM AirBag S
 Corsa-B	AIRBAG	1.7 D (99-00)	SIEMENS AirBag SAB6
 Corsa-B	AIRBAG	1.7 DTI (93-00)	GM AirBag S
 Corsa-B	AIRBAG	1.7 DTI (99-00)	SIEMENS AirBag SAB6
 Corsa-B	ENGINE MANAGEME	1.0 12v X10XE (...00)	BOSCH Motronic M1.5.5
 Corsa-B	ENGINE MANAGEME	1.2 16v X12XE (98-00)	BOSCH Motronic M1.5.5
 Corsa-B	ENGINE MANAGEME	1.2 8v 12NZ (95-00)	GM Multec TBI
 Corsa-B	ENGINE MANAGEME	1.2 8v C12NZ (95-00)	GM Multec TBI
 Corsa-B	ENGINE MANAGEME	1.2 8v X12SZ (...94)	GM Multec SZ
 Corsa-B	ENGINE MANAGEME	1.2 8v X12SZ (95-00)	GM Multec SZ
 Corsa-B	ENGINE MANAGEME	1.4 16v X14XE (...95)	GM Multec S
 Corsa-B	ENGINE MANAGEME	1.4 16v X14XE (96-00)	GM Multec S (F)
 Corsa-B	ENGINE MANAGEME	1.4 C14NZ (95-00)	GM Multec TBI
 Corsa-B	ENGINE MANAGEME	1.4 C14SE (95-00)	GM Multec M + Immob.
 Corsa-B	ENGINE MANAGEME	1.4 X14SZ (96-00)	GM Multec S (F)
 Corsa-B	ENGINE MANAGEME	1.6 16v C16XE (93-94)	GM Multec S
 Corsa-B	ENGINE MANAGEME	1.6 16v X16XE (...95)	GM Multec S
 Corsa-B	ENGINE MANAGEME	1.6 16v X16XE (96-00)	GM Multec S (F)
 Corsa-B	IMMOBILIZER	1.0 12v (...00)	GM Immobilizer
 Corsa-B	IMMOBILIZER	1.2 16v (96-00)	GM Immobilizer
 Corsa-B	IMMOBILIZER	1.2 8v (96-00)	GM Immobilizer
 Corsa-B	IMMOBILIZER	1.4 (96-00)	GM Immobilizer
 Corsa-B	IMMOBILIZER	1.4 16v (96-00)	GM Immobilizer
 Corsa-B	IMMOBILIZER	1.5 D (96-00)	GM Immobilizer
 Corsa-B	IMMOBILIZER	1.5 TD (96-00)	GM Immobilizer
 Corsa-B	IMMOBILIZER	1.6 (96-00)	GM Immobilizer
 Corsa-B	IMMOBILIZER	1.6 16v (96-00)	GM Immobilizer
 Corsa-B	IMMOBILIZER	1.7 D (96-00)	GM Immobilizer
 Corsa-B	IMMOBILIZER	1.7 DTI (96-00)	GM Immobilizer
 Corsa-C	ABS	1.0 12v (...03)	BOSCH ABS 5.3/5.4(+TC)
 Corsa-C	ABS	1.0 12v (04-..)	BOSCH ABS 8
 Corsa-C	ABS	1.2 16v (...03)	BOSCH ABS 5.3/5.4(+TC)
 Corsa-C	ABS	1.2 16v (04-..)	BOSCH ABS 8
 Corsa-C	ABS	1.3 CDTI (...03)	BOSCH ABS 5.3/5.4(+TC)
 Corsa-C	ABS	1.3 CDTI (04-..)	BOSCH ABS 8

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Corsa-C	ABS	1.4 16v (.-03)	BOSCH ABS 5.3/5.4(+TC)
 Corsa-C	ABS	1.4 16v (04-..)	BOSCH ABS 8
 Corsa-C	ABS	1.6 16v (.-03)	BOSCH ABS 5.3/5.4(+TC)
 Corsa-C	ABS	1.6 16v (04-..)	BOSCH ABS 8
 Corsa-C	ABS	1.7 CDTI (.-03)	BOSCH ABS 5.3/5.4(+TC)
 Corsa-C	ABS	1.7 CDTI (04-..)	BOSCH ABS 8
 Corsa-C	ABS	1.7 DI (.-03)	BOSCH ABS 5.3/5.4(+TC)
 Corsa-C	ABS	1.7 DI (04-..)	BOSCH ABS 8
 Corsa-C	ABS	1.7 DTI (.-03)	BOSCH ABS 5.3/5.4(+TC)
 Corsa-C	ABS	1.7 DTI (04-..)	BOSCH ABS 8
 Corsa-C	ABS	1.8 16v (.-03)	BOSCH ABS 5.3/5.4(+TC)
 Corsa-C	ABS	1.8 16v (04-..)	BOSCH ABS 8
 Corsa-C	AIRBAG	1.0 12v (.-01)	SIEMENS AirBag SAB8x
 Corsa-C	AIRBAG	1.0 12v (01-02)	TEMIC AirBag 07
 Corsa-C	AIRBAG	1.2 16v (.-01)	SIEMENS AirBag SAB8x
 Corsa-C	AIRBAG	1.2 16v (01-02)	TEMIC AirBag 07
 Corsa-C	AIRBAG	1.3 CDTI (04-..)	SIEMENS AirBag SAB8x
 Corsa-C	AIRBAG	1.3 CDTI (04-..)	TEMIC AirBag 07
 Corsa-C	AIRBAG	1.4 16v (00-..)	SIEMENS AirBag SAB8x
 Corsa-C	AIRBAG	1.4 16v (00-..)	TEMIC AirBag 07
 Corsa-C	AIRBAG	1.6 16v (00-..)	SIEMENS AirBag SAB8x
 Corsa-C	AIRBAG	1.6 16v (00-..)	TEMIC AirBag 07
 Corsa-C	AIRBAG	1.7 CDTI (.-01)	SIEMENS AirBag SAB8x
 Corsa-C	AIRBAG	1.7 DI (00-..)	SIEMENS AirBag SAB8x
 Corsa-C	AIRBAG	1.7 DI (00-..)	TEMIC AirBag 07
 Corsa-C	AIRBAG	1.7 DTI (00-..)	SIEMENS AirBag SAB8x
 Corsa-C	AIRBAG	1.7 DTI (00-..)	TEMIC AirBag 07
 Corsa-C	AIRBAG	1.8 16v (00-..)	SIEMENS AirBag SAB8x
 Corsa-C	AIRBAG	1.8 16v (00-..)	TEMIC AirBag 07
 Corsa-C	AUTOM. TRANSMISSI	1.0 12v (02-..)	Easytronic
 Corsa-C	AUTOM. TRANSMISSI	1.2 16v (02-..)	Easytronic
 Corsa-C	AUTOM. TRANSMISSI	1.3 CDTI (02-..)	Easytronic
 Corsa-C	AUTOM. TRANSMISSI	1.4 16v (02-..)	Easytronic
 Corsa-C	AUTOM. TRANSMISSI	1.6 16v (02-..)	Easytronic
 Corsa-C	AUTOM. TRANSMISSI	1.7 CDTI (02-..)	Easytronic
 Corsa-C	AUTOM. TRANSMISSI	1.7 DI (02-..)	Easytronic
 Corsa-C	AUTOM. TRANSMISSI	1.7 DTI (02-..)	Easytronic
 Corsa-C	AUTOM. TRANSMISSI	1.8 16v (02-..)	Easytronic
 Corsa-C	CHASSIS NETWORK	1.0 12v (01-..)	SIEMENS Body computer
 Corsa-C	CHASSIS NETWORK	1.2 16v (01-..)	SIEMENS Body computer
 Corsa-C	CHASSIS NETWORK	1.3 CDTI (04-..)	SIEMENS Body computer
 Corsa-C	CHASSIS NETWORK	1.4 16v (00-..)	SIEMENS Body computer
 Corsa-C	CHASSIS NETWORK	1.6 16v (00-..)	SIEMENS Body computer
 Corsa-C	CHASSIS NETWORK	1.7 CDTI (01-..)	SIEMENS Body computer
 Corsa-C	CHASSIS NETWORK	1.7 DI (01-..)	SIEMENS Body computer
 Corsa-C	CHASSIS NETWORK	1.7 DTI (01-..)	SIEMENS Body computer
 Corsa-C	CHASSIS NETWORK	1.8 16v (01-..)	SIEMENS Body computer
 Corsa-C	CLIMA	1.0 12v (02-..)	ECC
 Corsa-C	CLIMA	1.2 16v (02-..)	ECC
 Corsa-C	CLIMA	1.3 CDTI (02-..)	ECC
 Corsa-C	CLIMA	1.4 16v (02-..)	ECC
 Corsa-C	CLIMA	1.6 16v (02-..)	ECC
 Corsa-C	CLIMA	1.7 CDTI (02-..)	ECC
 Corsa-C	CLIMA	1.7 DI (02-..)	ECC
 Corsa-C	CLIMA	1.7 DTI (02-..)	ECC
 Corsa-C	CLIMA	1.8 16v (02-..)	ECC
 Corsa-C	DASHBOARD	1.0 12v (02-..)	SIEMENS Dashboard
 Corsa-C	DASHBOARD	1.2 16v (02-..)	SIEMENS Dashboard

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Corsa-C	DASHBOARD	1.3 CDTi (04-..)	SIEMENS Dashboard
 Corsa-C	DASHBOARD	1.4 16v (02-..)	SIEMENS Dashboard
 Corsa-C	DASHBOARD	1.6 16v (02-..)	SIEMENS Dashboard
 Corsa-C	DASHBOARD	1.7 CDTi (02-..)	SIEMENS Dashboard
 Corsa-C	DASHBOARD	1.7 DI (02-..)	SIEMENS Dashboard
 Corsa-C	DASHBOARD	1.7 DTi (02-..)	SIEMENS Dashboard
 Corsa-C	DASHBOARD	1.8 16v (02-..)	SIEMENS Dashboard
 Corsa-C	ELECTRIC STEERING	1.0 12v (01-..)	EPS
 Corsa-C	ELECTRIC STEERING	1.2 16v (01-..)	EPS
 Corsa-C	ELECTRIC STEERING	1.3 CDTi (04-..)	EPS
 Corsa-C	ELECTRIC STEERING	1.4 16v (00-..)	EPS
 Corsa-C	ELECTRIC STEERING	1.6 16v (00-..)	EPS
 Corsa-C	ELECTRIC STEERING	1.7 CDTi (01-..)	EPS
 Corsa-C	ELECTRIC STEERING	1.7 DI (01-..)	EPS
 Corsa-C	ELECTRIC STEERING	1.7 DTi (01-..)	EPS
 Corsa-C	ELECTRIC STEERING	1.8 16v (01-..)	EPS
 Corsa-C	ENGINE MANAGEME	1.0 12v Z10XE (01-05)	BOSCH Motronic ME1.5.5
 Corsa-C	ENGINE MANAGEME	1.0 12v Z10XE (01-05)	EOBD
 Corsa-C	ENGINE MANAGEME	1.2 16v Z12XE (01-05)	BOSCH Motronic M1.5.5
 Corsa-C	ENGINE MANAGEME	1.2 16v Z12XE (01-05)	EOBD
 Corsa-C	ENGINE MANAGEME	1.3 CDTi Z13DT (04-05)	Marelli 6JF CF3 Common Rail
 Corsa-C	ENGINE MANAGEME	1.4 16v Z14XE (01-05)	EOBD
 Corsa-C	ENGINE MANAGEME	1.6 16v Z16XE (01-05)	EOBD
 Corsa-C	ENGINE MANAGEME	1.7 CDTi Z17DTH (05-..)	EDC Common Rail
 Corsa-C	ENGINE MANAGEME	1.7 DI Y17DT (01-05)	DELPHI EDC HDRC
 Corsa-C	ENGINE MANAGEME	1.7 DTi Y17DTL (01-05)	DELPHI HDRC
 Corsa-C	ENGINE MANAGEME	1.8 16v Z18XE (01-..)	EOBD
 Corsa-C	IMMOBILIZER	1.0 12v (..01)	SIEMENS
 Corsa-C	IMMOBILIZER	1.2 16v (01-..)	SIEMENS
 Corsa-C	IMMOBILIZER	1.3 CDTi (04-..)	SIEMENS
 Corsa-C	IMMOBILIZER	1.4 16v (00-..)	SIEMENS
 Corsa-C	IMMOBILIZER	1.6 16v (00-..)	SIEMENS
 Corsa-C	IMMOBILIZER	1.7 CDTi (01-..)	SIEMENS
 Corsa-C	IMMOBILIZER	1.7 DI (01-..)	SIEMENS
 Corsa-C	IMMOBILIZER	1.7 DTi (00-..)	SIEMENS
 Corsa-C	IMMOBILIZER	1.8 16v (00-..)	SIEMENS
 Corsa-C	MAINTENANCE	1.0 12v (01-..)	SIEMENS
 Corsa-C	MAINTENANCE	1.0 12v (01-..)	SIEMENS
 Corsa-C	MAINTENANCE	1.0 12v (02-..)	SIEMENS Dashboard
 Corsa-C	MAINTENANCE	1.0 12v (02-..)	SIEMENS Dashboard
 Corsa-C	MAINTENANCE	1.2 16v (01-..)	SIEMENS
 Corsa-C	MAINTENANCE	1.2 16v (01-..)	SIEMENS
 Corsa-C	MAINTENANCE	1.2 16v (02-..)	SIEMENS Dashboard
 Corsa-C	MAINTENANCE	1.2 16v (02-..)	SIEMENS Dashboard
 Corsa-C	MAINTENANCE	1.3 CDTi (04-..)	SIEMENS
 Corsa-C	MAINTENANCE	1.3 CDTi (04-..)	SIEMENS
 Corsa-C	MAINTENANCE	1.3 CDTi (04-..)	SIEMENS Dashboard
 Corsa-C	MAINTENANCE	1.3 CDTi (04-..)	SIEMENS Dashboard
 Corsa-C	MAINTENANCE	1.4 16v (00-..)	SIEMENS
 Corsa-C	MAINTENANCE	1.4 16v (00-..)	SIEMENS
 Corsa-C	MAINTENANCE	1.4 16v (02-..)	SIEMENS Dashboard
 Corsa-C	MAINTENANCE	1.4 16v (02-..)	SIEMENS Dashboard
 Corsa-C	MAINTENANCE	1.6 16v (00-..)	SIEMENS
 Corsa-C	MAINTENANCE	1.6 16v (00-..)	SIEMENS
 Corsa-C	MAINTENANCE	1.6 16v (02-..)	SIEMENS Dashboard
 Corsa-C	MAINTENANCE	1.6 16v (02-..)	SIEMENS Dashboard
 Corsa-C	MAINTENANCE	1.7 CDTi (01-..)	SIEMENS
 Corsa-C	MAINTENANCE	1.7 CDTi (01-..)	SIEMENS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Corsa-C	MAINTENANCE	1.7 CDTi (02-..)	SIEMENS Dashboard
 Corsa-C	MAINTENANCE	1.7 CDTi (02-..)	SIEMENS Dashboard
 Corsa-C	MAINTENANCE	1.7 DI (01-..)	SIEMENS
 Corsa-C	MAINTENANCE	1.7 DI (01-..)	SIEMENS
 Corsa-C	MAINTENANCE	1.7 DI (02-..)	SIEMENS Dashboard
 Corsa-C	MAINTENANCE	1.7 DI (02-..)	SIEMENS Dashboard
 Corsa-C	MAINTENANCE	1.7 DTi (01-..)	SIEMENS
 Corsa-C	MAINTENANCE	1.7 DTi (01-..)	SIEMENS
 Corsa-C	MAINTENANCE	1.7 DTi (02-..)	SIEMENS Dashboard
 Corsa-C	MAINTENANCE	1.7 DTi (02-..)	SIEMENS Dashboard
 Corsa-C	MAINTENANCE	1.8 16v (01-..)	SIEMENS
 Corsa-C	MAINTENANCE	1.8 16v (01-..)	SIEMENS
 Corsa-C	MAINTENANCE	1.8 16v (02-..)	SIEMENS Dashboard
 Corsa-C	MAINTENANCE	1.8 16v (02-..)	SIEMENS Dashboard
 Corsa-C	SERVICE LIGHT RES	1.0 12v (01-..)	SIEMENS
 Corsa-C	SERVICE LIGHT RES	1.2 16v (01-..)	SIEMENS
 Corsa-C	SERVICE LIGHT RES	1.3 CDTi (04-..)	SIEMENS
 Corsa-C	SERVICE LIGHT RES	1.4 16v (00-..)	SIEMENS
 Corsa-C	SERVICE LIGHT RES	1.6 16v (00-..)	SIEMENS
 Corsa-C	SERVICE LIGHT RES	1.7 CDTi (01-..)	SIEMENS
 Corsa-C	SERVICE LIGHT RES	1.7 DI (01-..)	SIEMENS
 Corsa-C	SERVICE LIGHT RES	1.7 DTi (01-..)	SIEMENS
 Corsa-C	SERVICE LIGHT RES	1.8 16v (01-..)	SIEMENS
 Corsa-D	ABS + TRACT. CONT	1.0 12v	BOSCH ESP 8.1
 Corsa-D	ABS + TRACT. CONT	1.2 16v	BOSCH ESP 8.1
 Corsa-D	ABS + TRACT. CONT	1.3 CDTi 75cv	BOSCH ESP 8.1
 Corsa-D	ABS + TRACT. CONT	1.3 CDTi 90cv	BOSCH ESP 8.1
 Corsa-D	ABS + TRACT. CONT	1.4 16v	BOSCH ESP 8.1
 Corsa-D	ABS + TRACT. CONT	1.6 16v	BOSCH ESP 8.1
 Corsa-D	ABS + TRACT. CONT	1.7 CDTi	BOSCH ESP 8.1
 Corsa-D	AIRBAG	1.0 12v	TEMIC SRS MRSZ
 Corsa-D	AIRBAG	1.2 16v	TEMIC SRS MRSZ
 Corsa-D	AIRBAG	1.3 CDTi 75cv	TEMIC SRS MRSZ
 Corsa-D	AIRBAG	1.3 CDTi 90cv	TEMIC SRS MRSZ
 Corsa-D	AIRBAG	1.4 16v	TEMIC SRS MRSZ
 Corsa-D	AIRBAG	1.6 16v	TEMIC SRS MRSZ
 Corsa-D	AIRBAG	1.7 CDTi	TEMIC SRS MRSZ
 Corsa-D	CENTRAL LOCKING	1.0 12v	DELPHI BCM 0400
 Corsa-D	CENTRAL LOCKING	1.2 16v	DELPHI BCM 0400
 Corsa-D	CENTRAL LOCKING	1.3 CDTi 75cv	DELPHI BCM 0400
 Corsa-D	CENTRAL LOCKING	1.3 CDTi 90cv	DELPHI BCM 0400
 Corsa-D	CENTRAL LOCKING	1.4 16v	DELPHI BCM 0400
 Corsa-D	CENTRAL LOCKING	1.6 16v	DELPHI BCM 0400
 Corsa-D	CENTRAL LOCKING	1.7 CDTi	DELPHI BCM 0400
 Corsa-D	CHASSIS NETWORK	1.0 12v	DELPHI BCM 0400
 Corsa-D	CHASSIS NETWORK	1.0 12v	DELPHI Clima 0400
 Corsa-D	CHASSIS NETWORK	1.0 12v	DELPHI Ext. Light System 0400
 Corsa-D	CHASSIS NETWORK	1.0 12v	DELPHI Innner Light System 0400
 Corsa-D	CHASSIS NETWORK	1.0 12v	DELPHI Windshield Wipers 0400
 Corsa-D	CHASSIS NETWORK	1.2 16v	DELPHI BCM 0400
 Corsa-D	CHASSIS NETWORK	1.2 16v	DELPHI Clima 0400
 Corsa-D	CHASSIS NETWORK	1.2 16v	DELPHI Ext. Light System 0400
 Corsa-D	CHASSIS NETWORK	1.2 16v	DELPHI Innner Light System 0400
 Corsa-D	CHASSIS NETWORK	1.2 16v	DELPHI Windshield Wipers 0400
 Corsa-D	CHASSIS NETWORK	1.3 CDTi 75cv	DELPHI BCM 0400
 Corsa-D	CHASSIS NETWORK	1.3 CDTi 75cv	DELPHI Clima 0400
 Corsa-D	CHASSIS NETWORK	1.3 CDTi 75cv	DELPHI Ext. Light System 0400
 Corsa-D	CHASSIS NETWORK	1.3 CDTi 75cv	DELPHI Innner Light System 0400

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Corsa-D	CHASSIS NETWORK	1.3 CDTI 75cv	DELPHI Windshield Wipers 0400
 Corsa-D	CHASSIS NETWORK	1.3 CDTI 90cv	DELPHI BCM 0400
 Corsa-D	CHASSIS NETWORK	1.3 CDTI 90cv	DELPHI Clima 0400
 Corsa-D	CHASSIS NETWORK	1.3 CDTI 90cv	DELPHI Ext. Light System 0400
 Corsa-D	CHASSIS NETWORK	1.3 CDTI 90cv	DELPHI Innner Light System 0400
 Corsa-D	CHASSIS NETWORK	1.3 CDTI 90cv	DELPHI Windshield Wipers 0400
 Corsa-D	CHASSIS NETWORK	1.4 16v	DELPHI BCM 0400
 Corsa-D	CHASSIS NETWORK	1.4 16v	DELPHI Clima 0400
 Corsa-D	CHASSIS NETWORK	1.4 16v	DELPHI Ext. Light System 0400
 Corsa-D	CHASSIS NETWORK	1.4 16v	DELPHI Innner Light System 0400
 Corsa-D	CHASSIS NETWORK	1.4 16v	DELPHI Windshield Wipers 0400
 Corsa-D	CHASSIS NETWORK	1.6 16v	DELPHI BCM 0400
 Corsa-D	CHASSIS NETWORK	1.6 16v	DELPHI Clima 0400
 Corsa-D	CHASSIS NETWORK	1.6 16v	DELPHI Ext. Light System 0400
 Corsa-D	CHASSIS NETWORK	1.6 16v	DELPHI Innner Light System 0400
 Corsa-D	CHASSIS NETWORK	1.6 16v	DELPHI Windshield Wipers 0400
 Corsa-D	CHASSIS NETWORK	1.7 CDTI	DELPHI BCM 0400
 Corsa-D	CHASSIS NETWORK	1.7 CDTI	DELPHI Clima 0400
 Corsa-D	CHASSIS NETWORK	1.7 CDTI	DELPHI Ext. Light System 0400
 Corsa-D	CHASSIS NETWORK	1.7 CDTI	DELPHI Innner Light System 0400
 Corsa-D	CHASSIS NETWORK	1.7 CDTI	DELPHI Windshield Wipers 0400
 Corsa-D	CLIMA	1.0 12v	ECC
 Corsa-D	CLIMA	1.2 16v	ECC
 Corsa-D	CLIMA	1.3 CDTI 75cv	ECC
 Corsa-D	CLIMA	1.3 CDTI 90cv	ECC
 Corsa-D	CLIMA	1.4 16v	ECC
 Corsa-D	CLIMA	1.6 16v	ECC
 Corsa-D	CLIMA	1.7 CDTI	ECC
 Corsa-D	DASHBOARD	1.0 12v	IPC JCI04
 Corsa-D	DASHBOARD	1.2 16v	IPC JCI04
 Corsa-D	DASHBOARD	1.3 CDTI 75cv	IPC JCI04
 Corsa-D	DASHBOARD	1.3 CDTI 90cv	IPC JCI04
 Corsa-D	DASHBOARD	1.4 16v	IPC JCI04
 Corsa-D	DASHBOARD	1.6 16v	IPC JCI04
 Corsa-D	DASHBOARD	1.7 CDTI	IPC JCI04
 Corsa-D	ELECTRIC STEERING	1.0 12v	EPS 4400
 Corsa-D	ELECTRIC STEERING	1.2 16v	EPS 4400
 Corsa-D	ELECTRIC STEERING	1.3 CDTI 75cv	EPS 4400
 Corsa-D	ELECTRIC STEERING	1.3 CDTI 90cv	EPS 4400
 Corsa-D	ELECTRIC STEERING	1.4 16v	EPS 4400
 Corsa-D	ELECTRIC STEERING	1.6 16v	EPS 4400
 Corsa-D	ELECTRIC STEERING	1.7 CDTI	EPS 4400
 Corsa-D	ENGINE MANAGEME	1.0 12v Z10XEP	BOSCH Motronic ME 7.6.x
 Corsa-D	ENGINE MANAGEME	1.2 16v Z12XEP	BOSCH MPI ME 7.6.x
 Corsa-D	ENGINE MANAGEME	1.3 CDTI 75cv Z13DTJ	Marelli Multijet 603 Common Rail
 Corsa-D	ENGINE MANAGEME	1.3 CDTI 90cv	EOBD
 Corsa-D	ENGINE MANAGEME	1.3 CDTI 90cv Z13DTH	Marelli Multijet 603
 Corsa-D	ENGINE MANAGEME	1.4 16v Z14XEP	BOSCH Motronic ME 7.6.x
 Corsa-D	ENGINE MANAGEME	1.6 16v	EOBD
 Corsa-D	ENGINE MANAGEME	1.7 CDTI Z17DTR	DENSO BCM Common Rail
 Corsa-D	IMMOBILIZER	1.0 12v	DELPHI 0400
 Corsa-D	IMMOBILIZER	1.2 16v	DELPHI 0400
 Corsa-D	IMMOBILIZER	1.3 CDTI 75cv	DELPHI 0400
 Corsa-D	IMMOBILIZER	1.3 CDTI 90cv	DELPHI 0400
 Corsa-D	IMMOBILIZER	1.4 16v	DELPHI 0400
 Corsa-D	IMMOBILIZER	1.6 16v	DELPHI 0400
 Corsa-D	IMMOBILIZER	1.7 CDTI	DELPHI 0400
 Corsa-D	MAINTENANCE	1.0 12v	EPS 4400

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Corsa-D	MAINTENANCE	1.0 12v	IPC JCI04
 Corsa-D	MAINTENANCE	1.0 12v	Manual
 Corsa-D	MAINTENANCE	1.0 12v Z10XEP	BOSCH Motronic ME 7.6.x
 Corsa-D	MAINTENANCE	1.2 16v	EPS 4400
 Corsa-D	MAINTENANCE	1.2 16v	IPC JCI04
 Corsa-D	MAINTENANCE	1.2 16v	Manual
 Corsa-D	MAINTENANCE	1.3 CDTI 75cv	EPS 4400
 Corsa-D	MAINTENANCE	1.3 CDTI 75cv	IPC JCI04
 Corsa-D	MAINTENANCE	1.3 CDTI 75cv	Manual
 Corsa-D	MAINTENANCE	1.3 CDTI 90cv	EPS 4400
 Corsa-D	MAINTENANCE	1.3 CDTI 90cv	IPC JCI04
 Corsa-D	MAINTENANCE	1.3 CDTI 90cv	Manual
 Corsa-D	MAINTENANCE	1.3 CDTI 90cv Z13DTH	Marelli Multijet 603
 Corsa-D	MAINTENANCE	1.3 CDTI 90cv Z13DTH	Marelli Multijet 603
 Corsa-D	MAINTENANCE	1.4 16v	EPS 4400
 Corsa-D	MAINTENANCE	1.4 16v	IPC JCI04
 Corsa-D	MAINTENANCE	1.4 16v	Manual
 Corsa-D	MAINTENANCE	1.6 16v	EPS 4400
 Corsa-D	MAINTENANCE	1.6 16v	IPC JCI04
 Corsa-D	MAINTENANCE	1.6 16v	Manual
 Corsa-D	MAINTENANCE	1.7 CDTI	EPS 4400
 Corsa-D	MAINTENANCE	1.7 CDTI	IPC JCI04
 Corsa-D	MAINTENANCE	1.7 CDTI	Manual
 Corsa-D	PARKING HELP	1.0 12v	PAS
 Corsa-D	PARKING HELP	1.2 16v	PAS
 Corsa-D	PARKING HELP	1.3 CDTI 75cv	PAS
 Corsa-D	PARKING HELP	1.3 CDTI 90cv	PAS
 Corsa-D	PARKING HELP	1.4 16v	PAS
 Corsa-D	PARKING HELP	1.6 16v	PAS
 Corsa-D	PARKING HELP	1.7 CDTI	PAS
 Corsa-D	RADIO / CD	1.0 12v	EHU
 Corsa-D	RADIO / CD	1.2 16v	EHU
 Corsa-D	RADIO / CD	1.3 CDTI 75cv	EHU
 Corsa-D	RADIO / CD	1.3 CDTI 90cv	EHU
 Corsa-D	RADIO / CD	1.4 16v	EHU
 Corsa-D	RADIO / CD	1.6 16v	EHU
 Corsa-D	RADIO / CD	1.7 CDTI	EHU
 Corsa-D	SERVICE LIGHT RES	1.0 12v	Manual
 Corsa-D	SERVICE LIGHT RES	1.2 16v	Manual
 Corsa-D	SERVICE LIGHT RES	1.3 CDTI 75cv	Manual
 Corsa-D	SERVICE LIGHT RES	1.3 CDTI 90cv	Manual
 Corsa-D	SERVICE LIGHT RES	1.4 16v	Manual
 Corsa-D	SERVICE LIGHT RES	1.6 16v	Manual
 Corsa-D	SERVICE LIGHT RES	1.7 CDTI	Manual
 Corsa-D	VISUAL./TELEMATIC	1.0 12v	DIS 8.1
 Corsa-D	VISUAL./TELEMATIC	1.2 16v	DIS 8.1
 Corsa-D	VISUAL./TELEMATIC	1.3 CDTI 75cv	DIS 8.1
 Corsa-D	VISUAL./TELEMATIC	1.3 CDTI 90cv	DIS 8.1
 Corsa-D	VISUAL./TELEMATIC	1.4 16v	DIS 8.1
 Corsa-D	VISUAL./TELEMATIC	1.6 16v	DIS 8.1
 Corsa-D	VISUAL./TELEMATIC	1.7 CDTI	DIS 8.1
 Frontera	ABS	2.0	GM ABS 415
 Frontera	ABS	2.2 16v	GM ABS 415
 Frontera	ABS	2.3 TD	GM ABS 415
 Frontera	ABS	2.4	GM ABS 415
 Frontera	ABS	2.5 TD	GM ABS 415
 Frontera	ABS	2.8 TD	GM ABS 415
 Frontera	ENGINE MANAGEME	2.0 C20NE (.-95)	BOSCH Motronic M1.5

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Frontera	ENGINE MANAGEME	2.0 X20SE (95-00)	BOSCH Motronic M1.5.4
 Frontera	ENGINE MANAGEME	2.2 16v X22XE (95-00)	BOSCH Motronic M1.5.4
 Frontera	ENGINE MANAGEME	2.4 C24NE (..-95)	BOSCH Motronic M1.5
 Frontera	ENGINE MANAGEME	2.5 TD 25TDS (97-00)	BOSCH EDC MSA 15.5
 Frontera-B	ENGINE MANAGEME	2.2 TD 16v X22DTH (99-00)	BOSCH EDC MSA 15 M
 Frontera-B	ENGINE MANAGEME	2.2 Y22SE (01-..)	EOBD
 Frontera-B	ENGINE MANAGEME	3.2 6VD1 (01-..)	EOBD
 Insigna	ABS + TRACT. CONT	1.4 8v GPL	
 Insigna	ABS + TRACT. CONT	1.4 Turbo 16v	
 Insigna	ABS + TRACT. CONT	1.6 16v	
 Insigna	ABS + TRACT. CONT	1.6 Turbo 16v	
 Insigna	ABS + TRACT. CONT	1.8 16v	
 Insigna	ABS + TRACT. CONT	2.0 Biturbo CDTI	
 Insigna	ABS + TRACT. CONT	2.0 CDTI 110cv	
 Insigna	ABS + TRACT. CONT	2.0 CDTI 120cv	
 Insigna	ABS + TRACT. CONT	2.0 CDTI 130cv	
 Insigna	ABS + TRACT. CONT	2.0 CDTI 140cv	
 Insigna	ABS + TRACT. CONT	2.0 CDTI 160cv	
 Insigna	ABS + TRACT. CONT	2.0 Turbo 16v 220cv	
 Insigna	ABS + TRACT. CONT	2.0 Turbo 16v 250cv	
 Insigna	ABS + TRACT. CONT	2.8 V6	
 Insigna	ABS + TRACT. CONT	2.8 V6 Biturbo	
 Insigna	AIRBAG	1.4 8v GPL	
 Insigna	AIRBAG	1.4 Turbo 16v	
 Insigna	AIRBAG	1.6 16v	
 Insigna	AIRBAG	1.6 Turbo 16v	
 Insigna	AIRBAG	1.8 16v	
 Insigna	AIRBAG	2.0 Biturbo CDTI	
 Insigna	AIRBAG	2.0 CDTI 110cv	
 Insigna	AIRBAG	2.0 CDTI 120cv	
 Insigna	AIRBAG	2.0 CDTI 130cv	
 Insigna	AIRBAG	2.0 CDTI 140cv	
 Insigna	AIRBAG	2.0 CDTI 160cv	
 Insigna	AIRBAG	2.0 Turbo 16v 220cv	
 Insigna	AIRBAG	2.0 Turbo 16v 250cv	
 Insigna	AIRBAG	2.8 V6	
 Insigna	AIRBAG	2.8 V6 Biturbo	
 Insigna	CHASSIS NETWORK	1.4 8v GPL	CHASSIS 1
 Insigna	CHASSIS NETWORK	1.4 8v GPL	CHASSIS 2
 Insigna	CHASSIS NETWORK	1.4 Turbo 16v	CHASSIS 1
 Insigna	CHASSIS NETWORK	1.4 Turbo 16v	CHASSIS 2
 Insigna	CHASSIS NETWORK	1.6 16v	CHASSIS 1
 Insigna	CHASSIS NETWORK	1.6 16v	CHASSIS 2
 Insigna	CHASSIS NETWORK	1.6 Turbo 16v	CHASSIS 1
 Insigna	CHASSIS NETWORK	1.6 Turbo 16v	CHASSIS 2
 Insigna	CHASSIS NETWORK	1.8 16v	CHASSIS 1
 Insigna	CHASSIS NETWORK	1.8 16v	CHASSIS 2
 Insigna	CHASSIS NETWORK	2.0 Biturbo CDTI	CHASSIS 1
 Insigna	CHASSIS NETWORK	2.0 Biturbo CDTI	CHASSIS 2
 Insigna	CHASSIS NETWORK	2.0 CDTI 110cv	CHASSIS 1
 Insigna	CHASSIS NETWORK	2.0 CDTI 110cv	CHASSIS 2
 Insigna	CHASSIS NETWORK	2.0 CDTI 120cv	CHASSIS 1
 Insigna	CHASSIS NETWORK	2.0 CDTI 120cv	CHASSIS 2
 Insigna	CHASSIS NETWORK	2.0 CDTI 130cv	CHASSIS 1
 Insigna	CHASSIS NETWORK	2.0 CDTI 130cv	CHASSIS 2
 Insigna	CHASSIS NETWORK	2.0 CDTI 140cv	CHASSIS 1
 Insigna	CHASSIS NETWORK	2.0 CDTI 140cv	CHASSIS 2
 Insigna	CHASSIS NETWORK	2.0 CDTI 160cv	CHASSIS 1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Insignia	CHASSIS NETWORK	2.0 CDTI 160cv	CHASSIS 2
 Insignia	CHASSIS NETWORK	2.0 Turbo 16v 220cv	CHASSIS 1
 Insignia	CHASSIS NETWORK	2.0 Turbo 16v 220cv	CHASSIS 2
 Insignia	CHASSIS NETWORK	2.0 Turbo 16v 250cv	CHASSIS 1
 Insignia	CHASSIS NETWORK	2.0 Turbo 16v 250cv	CHASSIS 2
 Insignia	CHASSIS NETWORK	2.8 V6	CHASSIS 1
 Insignia	CHASSIS NETWORK	2.8 V6	CHASSIS 2
 Insignia	CHASSIS NETWORK	2.8 V6 Biturbo	CHASSIS 1
 Insignia	CHASSIS NETWORK	2.8 V6 Biturbo	CHASSIS 2
 Insignia	CLIMA	1.4 8v GPL	
 Insignia	CLIMA	1.4 Turbo 16v	
 Insignia	CLIMA	1.6 16v	
 Insignia	CLIMA	1.6 Turbo 16v	
 Insignia	CLIMA	1.8 16v	
 Insignia	CLIMA	2.0 Biturbo CDTI	
 Insignia	CLIMA	2.0 CDTI 110cv	
 Insignia	CLIMA	2.0 CDTI 120cv	
 Insignia	CLIMA	2.0 CDTI 130cv	
 Insignia	CLIMA	2.0 CDTI 140cv	
 Insignia	CLIMA	2.0 CDTI 160cv	
 Insignia	CLIMA	2.0 Turbo 16v 220cv	
 Insignia	CLIMA	2.0 Turbo 16v 250cv	
 Insignia	CLIMA	2.8 V6	
 Insignia	CLIMA	2.8 V6 Biturbo	
 Insignia	DASHBOARD	1.4 8v GPL	
 Insignia	DASHBOARD	1.4 Turbo 16v	
 Insignia	DASHBOARD	1.6 16v	
 Insignia	DASHBOARD	1.6 Turbo 16v	
 Insignia	DASHBOARD	1.8 16v	
 Insignia	DASHBOARD	2.0 Biturbo CDTI	
 Insignia	DASHBOARD	2.0 CDTI 110cv	
 Insignia	DASHBOARD	2.0 CDTI 120cv	
 Insignia	DASHBOARD	2.0 CDTI 130cv	
 Insignia	DASHBOARD	2.0 CDTI 140cv	
 Insignia	DASHBOARD	2.0 CDTI 160cv	
 Insignia	DASHBOARD	2.0 Turbo 16v 220cv	
 Insignia	DASHBOARD	2.0 Turbo 16v 250cv	
 Insignia	DASHBOARD	2.8 V6	
 Insignia	DASHBOARD	2.8 V6 Biturbo	
 Insignia	ENGINE MANAGEMEN	2.0 CDTI 160cv	
 Insignia	MAINTENANCE	1.4 8v GPL	
 Insignia	MAINTENANCE	1.4 8v GPL	
 Insignia	MAINTENANCE	1.4 8v GPL	CHASSIS 1
 Insignia	MAINTENANCE	1.4 8v GPL	CHASSIS 1
 Insignia	MAINTENANCE	1.4 8v GPL	CHASSIS 1
 Insignia	MAINTENANCE	1.4 8v GPL	CHASSIS 1
 Insignia	MAINTENANCE	1.4 8v GPL	CHASSIS 2
 Insignia	MAINTENANCE	1.4 8v GPL	CHASSIS 2
 Insignia	MAINTENANCE	1.4 8v GPL	CHASSIS 2
 Insignia	MAINTENANCE	1.4 8v GPL	CHASSIS 2
 Insignia	MAINTENANCE	1.4 8v GPL	CHASSIS 2
 Insignia	MAINTENANCE	1.4 8v GPL	CHASSIS 2
 Insignia	MAINTENANCE	1.4 Turbo 16v	
 Insignia	MAINTENANCE	1.4 Turbo 16v	
 Insignia	MAINTENANCE	1.4 Turbo 16v	CHASSIS 1
 Insignia	MAINTENANCE	1.4 Turbo 16v	CHASSIS 1
 Insignia	MAINTENANCE	1.4 Turbo 16v	CHASSIS 1
 Insignia	MAINTENANCE	1.4 Turbo 16v	CHASSIS 1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Insignia	MAINTENANCE	1.4 Turbo 16v	CHASSIS 2
 Insignia	MAINTENANCE	1.4 Turbo 16v	CHASSIS 2
 Insignia	MAINTENANCE	1.4 Turbo 16v	CHASSIS 2
 Insignia	MAINTENANCE	1.4 Turbo 16v	CHASSIS 2
 Insignia	MAINTENANCE	1.4 Turbo 16v	CHASSIS 2
 Insignia	MAINTENANCE	1.4 Turbo 16v	CHASSIS 2
 Insignia	MAINTENANCE	1.6 16v	
 Insignia	MAINTENANCE	1.6 16v	
 Insignia	MAINTENANCE	1.6 16v	
 Insignia	MAINTENANCE	1.6 16v	CHASSIS 1
 Insignia	MAINTENANCE	1.6 16v	CHASSIS 1
 Insignia	MAINTENANCE	1.6 16v	CHASSIS 1
 Insignia	MAINTENANCE	1.6 16v	CHASSIS 1
 Insignia	MAINTENANCE	1.6 16v	CHASSIS 2
 Insignia	MAINTENANCE	1.6 16v	CHASSIS 2
 Insignia	MAINTENANCE	1.6 16v	CHASSIS 2
 Insignia	MAINTENANCE	1.6 16v	CHASSIS 2
 Insignia	MAINTENANCE	1.6 16v	CHASSIS 2
 Insignia	MAINTENANCE	1.6 16v	CHASSIS 2
 Insignia	MAINTENANCE	1.6 Turbo 16v	
 Insignia	MAINTENANCE	1.6 Turbo 16v	
 Insignia	MAINTENANCE	1.6 Turbo 16v	
 Insignia	MAINTENANCE	1.6 Turbo 16v	CHASSIS 1
 Insignia	MAINTENANCE	1.6 Turbo 16v	CHASSIS 1
 Insignia	MAINTENANCE	1.6 Turbo 16v	CHASSIS 1
 Insignia	MAINTENANCE	1.6 Turbo 16v	CHASSIS 1
 Insignia	MAINTENANCE	1.6 Turbo 16v	CHASSIS 1
 Insignia	MAINTENANCE	1.6 Turbo 16v	CHASSIS 2
 Insignia	MAINTENANCE	1.6 Turbo 16v	CHASSIS 2
 Insignia	MAINTENANCE	1.6 Turbo 16v	CHASSIS 2
 Insignia	MAINTENANCE	1.6 Turbo 16v	CHASSIS 2
 Insignia	MAINTENANCE	1.6 Turbo 16v	CHASSIS 2
 Insignia	MAINTENANCE	1.6 Turbo 16v	CHASSIS 2
 Insignia	MAINTENANCE	1.8 16v	
 Insignia	MAINTENANCE	1.8 16v	
 Insignia	MAINTENANCE	1.8 16v	
 Insignia	MAINTENANCE	1.8 16v	CHASSIS 1
 Insignia	MAINTENANCE	1.8 16v	CHASSIS 1
 Insignia	MAINTENANCE	1.8 16v	CHASSIS 1
 Insignia	MAINTENANCE	1.8 16v	CHASSIS 1
 Insignia	MAINTENANCE	1.8 16v	CHASSIS 2
 Insignia	MAINTENANCE	1.8 16v	CHASSIS 2
 Insignia	MAINTENANCE	1.8 16v	CHASSIS 2
 Insignia	MAINTENANCE	1.8 16v	CHASSIS 2
 Insignia	MAINTENANCE	1.8 16v	CHASSIS 2
 Insignia	MAINTENANCE	1.8 16v	CHASSIS 2
 Insignia	MAINTENANCE	2.0 Biturbo CDTI	
 Insignia	MAINTENANCE	2.0 Biturbo CDTI	
 Insignia	MAINTENANCE	2.0 Biturbo CDTI	
 Insignia	MAINTENANCE	2.0 Biturbo CDTI	CHASSIS 1
 Insignia	MAINTENANCE	2.0 Biturbo CDTI	CHASSIS 1
 Insignia	MAINTENANCE	2.0 Biturbo CDTI	CHASSIS 1
 Insignia	MAINTENANCE	2.0 Biturbo CDTI	CHASSIS 1
 Insignia	MAINTENANCE	2.0 Biturbo CDTI	CHASSIS 2
 Insignia	MAINTENANCE	2.0 Biturbo CDTI	CHASSIS 2
 Insignia	MAINTENANCE	2.0 Biturbo CDTI	CHASSIS 2
 Insignia	MAINTENANCE	2.0 Biturbo CDTI	CHASSIS 2
 Insignia	MAINTENANCE	2.0 Biturbo CDTI	CHASSIS 2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Insignia	MAINTENANCE	2.0 CDTI 110cv	
 Insignia	MAINTENANCE	2.0 CDTI 110cv	
 Insignia	MAINTENANCE	2.0 CDTI 110cv	
 Insignia	MAINTENANCE	2.0 CDTI 110cv	CHASSIS 1
 Insignia	MAINTENANCE	2.0 CDTI 110cv	CHASSIS 1
 Insignia	MAINTENANCE	2.0 CDTI 110cv	CHASSIS 1
 Insignia	MAINTENANCE	2.0 CDTI 110cv	CHASSIS 1
 Insignia	MAINTENANCE	2.0 CDTI 110cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 CDTI 110cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 CDTI 110cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 CDTI 110cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 CDTI 110cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 CDTI 120cv	
 Insignia	MAINTENANCE	2.0 CDTI 120cv	
 Insignia	MAINTENANCE	2.0 CDTI 120cv	CHASSIS 1
 Insignia	MAINTENANCE	2.0 CDTI 120cv	CHASSIS 1
 Insignia	MAINTENANCE	2.0 CDTI 120cv	CHASSIS 1
 Insignia	MAINTENANCE	2.0 CDTI 120cv	CHASSIS 1
 Insignia	MAINTENANCE	2.0 CDTI 120cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 CDTI 120cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 CDTI 120cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 CDTI 120cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 CDTI 120cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 CDTI 120cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 CDTI 130cv	
 Insignia	MAINTENANCE	2.0 CDTI 130cv	
 Insignia	MAINTENANCE	2.0 CDTI 130cv	
 Insignia	MAINTENANCE	2.0 CDTI 130cv	CHASSIS 1
 Insignia	MAINTENANCE	2.0 CDTI 130cv	CHASSIS 1
 Insignia	MAINTENANCE	2.0 CDTI 130cv	CHASSIS 1
 Insignia	MAINTENANCE	2.0 CDTI 130cv	CHASSIS 1
 Insignia	MAINTENANCE	2.0 CDTI 130cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 CDTI 130cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 CDTI 130cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 CDTI 130cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 CDTI 130cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 CDTI 130cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 CDTI 140cv	
 Insignia	MAINTENANCE	2.0 CDTI 140cv	
 Insignia	MAINTENANCE	2.0 CDTI 140cv	CHASSIS 1
 Insignia	MAINTENANCE	2.0 CDTI 140cv	CHASSIS 1
 Insignia	MAINTENANCE	2.0 CDTI 140cv	CHASSIS 1
 Insignia	MAINTENANCE	2.0 CDTI 140cv	CHASSIS 1
 Insignia	MAINTENANCE	2.0 CDTI 140cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 CDTI 140cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 CDTI 140cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 CDTI 140cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 CDTI 140cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 CDTI 160cv	
 Insignia	MAINTENANCE	2.0 CDTI 160cv	
 Insignia	MAINTENANCE	2.0 CDTI 160cv	CHASSIS 1
 Insignia	MAINTENANCE	2.0 CDTI 160cv	CHASSIS 1
 Insignia	MAINTENANCE	2.0 CDTI 160cv	CHASSIS 1
 Insignia	MAINTENANCE	2.0 CDTI 160cv	CHASSIS 1
 Insignia	MAINTENANCE	2.0 CDTI 160cv	CHASSIS 2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Insignia	MAINTENANCE	2.0 CDTI 160cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 CDTI 160cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 CDTI 160cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 CDTI 160cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 CDTI 160cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 turbo 16v	
 Insignia	MAINTENANCE	2.0 Turbo 16v 220cv	
 Insignia	MAINTENANCE	2.0 Turbo 16v 220cv	
 Insignia	MAINTENANCE	2.0 Turbo 16v 220cv	CHASSIS 1
 Insignia	MAINTENANCE	2.0 Turbo 16v 220cv	CHASSIS 1
 Insignia	MAINTENANCE	2.0 Turbo 16v 220cv	CHASSIS 1
 Insignia	MAINTENANCE	2.0 Turbo 16v 220cv	CHASSIS 1
 Insignia	MAINTENANCE	2.0 Turbo 16v 220cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 Turbo 16v 220cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 Turbo 16v 220cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 Turbo 16v 220cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 Turbo 16v 220cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 Turbo 16v 250cv	
 Insignia	MAINTENANCE	2.0 Turbo 16v 250cv	
 Insignia	MAINTENANCE	2.0 Turbo 16v 250cv	CHASSIS 1
 Insignia	MAINTENANCE	2.0 Turbo 16v 250cv	CHASSIS 1
 Insignia	MAINTENANCE	2.0 Turbo 16v 250cv	CHASSIS 1
 Insignia	MAINTENANCE	2.0 Turbo 16v 250cv	CHASSIS 1
 Insignia	MAINTENANCE	2.0 Turbo 16v 250cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 Turbo 16v 250cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 Turbo 16v 250cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 Turbo 16v 250cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 Turbo 16v 250cv	CHASSIS 2
 Insignia	MAINTENANCE	2.0 Turbo 16v 250cv	CHASSIS 2
 Insignia	MAINTENANCE	2.8 Turbo	
 Insignia	MAINTENANCE	2.8 V6	
 Insignia	MAINTENANCE	2.8 V6	
 Insignia	MAINTENANCE	2.8 V6	CHASSIS 1
 Insignia	MAINTENANCE	2.8 V6	CHASSIS 1
 Insignia	MAINTENANCE	2.8 V6	CHASSIS 1
 Insignia	MAINTENANCE	2.8 V6	CHASSIS 1
 Insignia	MAINTENANCE	2.8 V6	CHASSIS 2
 Insignia	MAINTENANCE	2.8 V6	CHASSIS 2
 Insignia	MAINTENANCE	2.8 V6	CHASSIS 2
 Insignia	MAINTENANCE	2.8 V6	CHASSIS 2
 Insignia	MAINTENANCE	2.8 V6	CHASSIS 2
 Insignia	MAINTENANCE	2.8 V6	CHASSIS 2
 Insignia	MAINTENANCE	2.8 V6 Biturbo	
 Insignia	MAINTENANCE	2.8 V6 Biturbo	
 Insignia	MAINTENANCE	2.8 V6 Biturbo	CHASSIS 1
 Insignia	MAINTENANCE	2.8 V6 Biturbo	CHASSIS 1
 Insignia	MAINTENANCE	2.8 V6 Biturbo	CHASSIS 1
 Insignia	MAINTENANCE	2.8 V6 Biturbo	CHASSIS 1
 Insignia	MAINTENANCE	2.8 V6 Biturbo	CHASSIS 2
 Insignia	MAINTENANCE	2.8 V6 Biturbo	CHASSIS 2
 Insignia	MAINTENANCE	2.8 V6 Biturbo	CHASSIS 2
 Insignia	MAINTENANCE	2.8 V6 Biturbo	CHASSIS 2
 Insignia	MAINTENANCE	2.8 V6 Biturbo	CHASSIS 2
 Insignia	MAINTENANCE	2.8 V6 Biturbo	CHASSIS 2
 Insignia	PARK.BRAKE	1.4 8v GPL	
 Insignia	PARK.BRAKE	1.4 Turbo 16v	
 Insignia	PARK.BRAKE	1.6 16v	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Insignia	PARK.BRAKE	1.6 Turbo 16v	
 Insignia	PARK.BRAKE	1.8 16v	
 Insignia	PARK.BRAKE	2.0 Biturbo CDTI	
 Insignia	PARK.BRAKE	2.0 CDTI 110cv	
 Insignia	PARK.BRAKE	2.0 CDTI 120cv	
 Insignia	PARK.BRAKE	2.0 CDTI 130cv	
 Insignia	PARK.BRAKE	2.0 CDTI 140cv	
 Insignia	PARK.BRAKE	2.0 CDTI 160cv	
 Insignia	PARK.BRAKE	2.0 Turbo 16v 220cv	
 Insignia	PARK.BRAKE	2.0 Turbo 16v 250cv	
 Insignia	PARK.BRAKE	2.8 V6	
 Insignia	PARK.BRAKE	2.8 V6 Biturbo	
 Insignia	PARKING HELP	1.4 8v GPL	
 Insignia	PARKING HELP	1.4 Turbo 16v	
 Insignia	PARKING HELP	1.6 16v	
 Insignia	PARKING HELP	1.6 Turbo 16v	
 Insignia	PARKING HELP	1.8 16v	
 Insignia	PARKING HELP	2.0 Biturbo CDTI	
 Insignia	PARKING HELP	2.0 CDTI 110cv	
 Insignia	PARKING HELP	2.0 CDTI 120cv	
 Insignia	PARKING HELP	2.0 CDTI 130cv	
 Insignia	PARKING HELP	2.0 CDTI 140cv	
 Insignia	PARKING HELP	2.0 CDTI 160cv	
 Insignia	PARKING HELP	2.0 Turbo 16v 220cv	
 Insignia	PARKING HELP	2.0 Turbo 16v 250cv	
 Insignia	PARKING HELP	2.8 V6	
 Insignia	PARKING HELP	2.8 V6 Biturbo	
 Insignia	SERVICE LIGHT RES	1.6 16v	
 Insignia	SERVICE LIGHT RES	1.6 Turbo 16v	
 Insignia	SERVICE LIGHT RES	1.8 16v	
 Insignia	SERVICE LIGHT RES	2.0 Biturbo CDTI	
 Insignia	SERVICE LIGHT RES	2.0 CDTI 110cv	
 Insignia	SERVICE LIGHT RES	2.0 CDTI 130cv	
 Insignia	SERVICE LIGHT RES	2.0 CDTI 160cv	
 Insignia	SERVICE LIGHT RES	2.0 turbo 16v	
 Insignia	SERVICE LIGHT RES	2.8 Turbo	
 Insignia	STEERING COLUMN	1.4 8v GPL	
 Insignia	STEERING COLUMN	1.4 Turbo 16v	
 Insignia	STEERING COLUMN	1.6 16v	
 Insignia	STEERING COLUMN	1.6 Turbo 16v	
 Insignia	STEERING COLUMN	1.8 16v	
 Insignia	STEERING COLUMN	2.0 Biturbo CDTI	
 Insignia	STEERING COLUMN	2.0 CDTI 110cv	
 Insignia	STEERING COLUMN	2.0 CDTI 120cv	
 Insignia	STEERING COLUMN	2.0 CDTI 130cv	
 Insignia	STEERING COLUMN	2.0 CDTI 140cv	
 Insignia	STEERING COLUMN	2.0 CDTI 160cv	
 Insignia	STEERING COLUMN	2.0 Turbo 16v 220cv	
 Insignia	STEERING COLUMN	2.0 Turbo 16v 250cv	
 Insignia	STEERING COLUMN	2.8 V6	
 Insignia	STEERING COLUMN	2.8 V6 Biturbo	
 Kadett-E	ENGINE MANAGEME	1.4 C14NZ (..-91)	GM Multec TBI
 Kadett-E	ENGINE MANAGEME	1.6 C16NZ (85-..)	GM Multec TBI MANUAL
 Kadett-E	ENGINE MANAGEME	1.6 C16NZ (88-91)	GM Multec TBI MANUAL
 Kadett-E	ENGINE MANAGEME	1.6 E16NZ (88-91)	GM Multec TBI MANUAL
 Kadett-E	ENGINE MANAGEME	1.6 Kat C16NZ (85-..)	GM Multec TBI MANUAL
 Kadett-E	ENGINE MANAGEME	1.8 C18NZ (..-91)	GM Multec TBI
 Kadett-E	ENGINE MANAGEME	2.0 16v 20XE (..-89)	BOSCH Motronic M2.5

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kadett-E	ENGINE MANAGEME	2.0 16v 20XEJ (90-..)	BOSCH Motronic M2.5
 Kadett-E	ENGINE MANAGEME	2.0 16v C20XE (88-..)	BOSCH Motronic M2.5
 Kadett-E	ENGINE MANAGEME	2.0 20NE (..-89)	BOSCH Motronic ML4.1
 Kadett-E	ENGINE MANAGEME	2.0 20NE (90-..)	BOSCH Motronic M1.5
 Kadett-E	ENGINE MANAGEME	2.0 20SEH (..-89)	BOSCH Motronic ML4.1
 Kadett-E	ENGINE MANAGEME	2.0 20SEH (90-..)	BOSCH Motronic M1.5
 Kadett-E	ENGINE MANAGEME	2.0 20SER (..-89)	BOSCH Motronic ML4.1
 Kadett-E	ENGINE MANAGEME	2.0 20SER (90-..)	BOSCH Motronic M1.5
 Kadett-E	ENGINE MANAGEME	2.0 C20NE (..-89)	BOSCH Motronic ML4.1
 Kadett-E	ENGINE MANAGEME	2.0 C20NE (90-..)	BOSCH Motronic M1.5
 Kadett-E	MAINTENANCE	1.6 C16NZ (85-..)	GM Multec TBI MANUAL
 Kadett-E	MAINTENANCE	1.6 C16NZ (88-91)	GM Multec TBI MANUAL
 Kadett-E	MAINTENANCE	1.6 E16NZ (88-91)	GM Multec TBI MANUAL
 Kadett-E	MAINTENANCE	1.6 Kat C16NZ (85-..)	GM Multec TBI MANUAL
 Meriva B	ABS + TRACT. CONT	1.3 CDTI 75cv (11-..)	
 Meriva B	ABS + TRACT. CONT	1.3 CDTI 95cv (11-..)	
 Meriva B	ABS + TRACT. CONT	1.4 16v 100cv (11-..)	
 Meriva B	ABS + TRACT. CONT	1.4 16v Turbo 120 cv (11-..)	
 Meriva B	ABS + TRACT. CONT	1.4 16v Turbo 120 cv GPL-tech (11-..)	
 Meriva B	ABS + TRACT. CONT	1.7 CDTI 110cv (11-..)	
 Meriva B	ABS + TRACT. CONT	1.7 CDTI 130cv (11-..)	
 Meriva B	AUTOM. TRANSMISSI	1.3 CDTI 75cv (11-..)	
 Meriva B	AUTOM. TRANSMISSI	1.3 CDTI 95cv (11-..)	
 Meriva B	AUTOM. TRANSMISSI	1.4 16v 100cv (11-..)	
 Meriva B	AUTOM. TRANSMISSI	1.4 16v Turbo 120 cv (11-..)	
 Meriva B	AUTOM. TRANSMISSI	1.4 16v Turbo 120 cv GPL-tech (11-..)	
 Meriva B	AUTOM. TRANSMISSI	1.7 CDTI 110cv (11-..)	
 Meriva B	AUTOM. TRANSMISSI	1.7 CDTI 130cv (11-..)	
 Meriva B	CHASSIS NETWORK	1.3 CDTI 75cv (11-..)	
 Meriva B	CHASSIS NETWORK	1.3 CDTI 95cv (11-..)	
 Meriva B	CHASSIS NETWORK	1.4 16v 100cv (11-..)	
 Meriva B	CHASSIS NETWORK	1.4 16v Turbo 120 cv (11-..)	
 Meriva B	CHASSIS NETWORK	1.4 16v Turbo 120 cv GPL-tech (11-..)	
 Meriva B	CHASSIS NETWORK	1.7 CDTI 110cv (11-..)	
 Meriva B	CHASSIS NETWORK	1.7 CDTI 130cv (11-..)	
 Meriva B	ELECTRIC STEERING	1.3 CDTI 75cv (11-..)	
 Meriva B	ELECTRIC STEERING	1.3 CDTI 95cv (11-..)	
 Meriva B	ELECTRIC STEERING	1.4 16v 100cv (11-..)	
 Meriva B	ELECTRIC STEERING	1.4 16v Turbo 120 cv (11-..)	
 Meriva B	ELECTRIC STEERING	1.4 16v Turbo 120 cv GPL-tech (11-..)	
 Meriva B	ELECTRIC STEERING	1.7 CDTI 110cv (11-..)	
 Meriva B	ELECTRIC STEERING	1.7 CDTI 130cv (11-..)	
 Meriva B	ENGINE MANAGEME	1.3 CDTI 95cv A13DT (11-..)	
 Meriva B	ENGINE MANAGEME	1.7 CDTI 110cv A17DT (DECE2C) (	
 Meriva B	PARK.BRAKE	1.3 CDTI 75cv (11-..)	
 Meriva B	PARK.BRAKE	1.3 CDTI 95cv (11-..)	
 Meriva B	PARK.BRAKE	1.4 16v 100cv (11-..)	
 Meriva B	PARK.BRAKE	1.4 16v Turbo 120 cv (11-..)	
 Meriva B	PARK.BRAKE	1.4 16v Turbo 120 cv GPL-tech (11-..)	
 Meriva B	PARK.BRAKE	1.7 CDTI 110cv (11-..)	
 Meriva B	PARK.BRAKE	1.7 CDTI 130cv (11-..)	
 Meriva B	STEERING COLUMN	1.3 CDTI 75cv (11-..)	
 Meriva B	STEERING COLUMN	1.3 CDTI 95cv (11-..)	
 Meriva B	STEERING COLUMN	1.4 16v 100cv (11-..)	
 Meriva B	STEERING COLUMN	1.4 16v Turbo 120 cv (11-..)	
 Meriva B	STEERING COLUMN	1.4 16v Turbo 120 cv GPL-tech (11-..)	
 Meriva B	STEERING COLUMN	1.7 CDTI 110cv (11-..)	
 Meriva B	STEERING COLUMN	1.7 CDTI 130cv (11-..)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Meriva	ABS	1.3 CDTI (...04)	BOSCH ABS 5.3/5.4(+TC)
 Meriva	ABS	1.3 CDTI FAP (...04)	BOSCH ABS 5.3/5.4(+TC)
 Meriva	ABS	1.4 16v (...04)	BOSCH ABS 5.3/5.4(+TC)
 Meriva	ABS	1.6 16v (...04)	BOSCH ABS 5.3/5.4(+TC)
 Meriva	ABS	1.6 8v (...04)	BOSCH ABS 5.3/5.4(+TC)
 Meriva	ABS	1.6 T (...04)	BOSCH ABS 5.3/5.4(+TC)
 Meriva	ABS	1.7 CDTI (...04)	BOSCH ABS 5.3/5.4(+TC)
 Meriva	ABS	1.7 DTI (...04)	BOSCH ABS 5.3/5.4(+TC)
 Meriva	ABS	1.8 16v (...04)	BOSCH ABS 5.3/5.4(+TC)
 Meriva	AIRBAG	1.3 CDTI (05-..)	TEMIC AirBag 07
 Meriva	AIRBAG	1.3 CDTI FAP (05-..)	TEMIC AirBag 07
 Meriva	AIRBAG	1.4 16v (03-..)	TEMIC AirBag 07
 Meriva	AIRBAG	1.6 16v (03-..)	TEMIC AirBag 07
 Meriva	AIRBAG	1.6 8v (03-..)	TEMIC AirBag 07
 Meriva	AIRBAG	1.6 T (03-..)	TEMIC AirBag 07
 Meriva	AIRBAG	1.7 CDTI (03-..)	TEMIC AirBag 07
 Meriva	AIRBAG	1.7 DTI (03-..)	TEMIC AirBag 07
 Meriva	AIRBAG	1.8 16v (03-..)	TEMIC AirBag 07
 Meriva	CHASSIS NETWORK	1.3 CDTI (03-..)	SIEMENS Body computer
 Meriva	CHASSIS NETWORK	1.3 CDTI FAP (03-..)	SIEMENS Body computer
 Meriva	CHASSIS NETWORK	1.4 16v (03-..)	SIEMENS Body computer
 Meriva	CHASSIS NETWORK	1.6 16v (03-..)	SIEMENS Body computer
 Meriva	CHASSIS NETWORK	1.6 8v (03-..)	SIEMENS Body computer
 Meriva	CHASSIS NETWORK	1.6 T (03-..)	SIEMENS Body computer
 Meriva	CHASSIS NETWORK	1.7 CDTI (03-..)	SIEMENS Body computer
 Meriva	CHASSIS NETWORK	1.7 DTI (03-..)	SIEMENS Body computer
 Meriva	CHASSIS NETWORK	1.8 16v (03-..)	SIEMENS Body computer
 Meriva	DASHBOARD	1.3 CDTI (03-..)	SIEMENS Dashboard
 Meriva	DASHBOARD	1.3 CDTI FAP (03-..)	SIEMENS Dashboard
 Meriva	DASHBOARD	1.4 16v (03-..)	SIEMENS Dashboard
 Meriva	DASHBOARD	1.6 16v (03-..)	SIEMENS Dashboard
 Meriva	DASHBOARD	1.6 8v (03-..)	SIEMENS Dashboard
 Meriva	DASHBOARD	1.6 T (03-..)	SIEMENS Dashboard
 Meriva	DASHBOARD	1.7 CDTI (03-..)	SIEMENS Dashboard
 Meriva	DASHBOARD	1.7 DTI (03-..)	SIEMENS Dashboard
 Meriva	DASHBOARD	1.8 16v (03-..)	SIEMENS Dashboard
 Meriva	ELECTRIC STEERING	1.3 CDTI (...04)	EPS
 Meriva	ELECTRIC STEERING	1.3 CDTI FAP (...04)	EPS
 Meriva	ELECTRIC STEERING	1.4 16v (...04)	EPS
 Meriva	ELECTRIC STEERING	1.6 16v (...04)	EPS
 Meriva	ELECTRIC STEERING	1.6 8v (...04)	EPS
 Meriva	ELECTRIC STEERING	1.6 T (...04)	EPS
 Meriva	ELECTRIC STEERING	1.7 CDTI (...04)	EPS
 Meriva	ELECTRIC STEERING	1.7 DTI (...04)	EPS
 Meriva	ELECTRIC STEERING	1.8 16v (...04)	EPS
 Meriva	ENGINE MANAGEME	1.3 CDTI Z13DT (03-..)	Marelli 6JF CF3 Common Rail
 Meriva	ENGINE MANAGEME	1.3 CDTI Z13DTJ-FAP (06-..)	Marelli 6JF CF3 Common Rail
 Meriva	ENGINE MANAGEME	1.4 16v Z14XE (...04)	GM Multec H
 Meriva	ENGINE MANAGEME	1.4 16v Z14XEP (05-..)	BOSCH Motronic ME 7.6.x
 Meriva	ENGINE MANAGEME	1.6 16v Z16XE (...04)	GM Multec H
 Meriva	ENGINE MANAGEME	1.6 16v Z16XEP (05-..)	BOSCH Motronic ME 7.6.x
 Meriva	ENGINE MANAGEME	1.6 8v (03-..)	EOBD
 Meriva	ENGINE MANAGEME	1.6 T (03-..)	EOBD
 Meriva	ENGINE MANAGEME	1.7 CDTI Z17DTH (05-..)	EDC Common Rail
 Meriva	ENGINE MANAGEME	1.7 CDTI Z17DTR (FAP) (07-..)	EDC Common Rail
 Meriva	ENGINE MANAGEME	1.7 DTI Y17DT (04-..)	DELPHI HDRC
 Meriva	ENGINE MANAGEME	1.8 16v	EOBD
 Meriva	IMMOBILIZER	1.3 CDTI (03-..)	SIEMENS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Meriva	IMMOBILIZER	1.3 CDTI FAP (03-..)	SIEMENS
 Meriva	IMMOBILIZER	1.4 16v (03-..)	SIEMENS
 Meriva	IMMOBILIZER	1.6 16v (03-..)	SIEMENS
 Meriva	IMMOBILIZER	1.6 8v (03-..)	SIEMENS
 Meriva	IMMOBILIZER	1.6 T (03-..)	SIEMENS
 Meriva	IMMOBILIZER	1.7 CDTI (03-..)	SIEMENS
 Meriva	IMMOBILIZER	1.7 DTI (03-..)	SIEMENS
 Meriva	IMMOBILIZER	1.8 16v (03-..)	SIEMENS
 Meriva	MAINTENANCE	1.3 CDTI (03-..)	Manuale
 Meriva	MAINTENANCE	1.3 CDTI (03-..)	SIEMENS Dashboard
 Meriva	MAINTENANCE	1.3 CDTI (03-..)	SIEMENS Dashboard
 Meriva	MAINTENANCE	1.3 CDTI FAP (03-..)	Manuale
 Meriva	MAINTENANCE	1.3 CDTI FAP (03-..)	SIEMENS Dashboard
 Meriva	MAINTENANCE	1.3 CDTI FAP (03-..)	SIEMENS Dashboard
 Meriva	MAINTENANCE	1.3 CDTI Z13DTJ-FAP (06-..)	Marelli 6JF CF3 Common Rail
 Meriva	MAINTENANCE	1.3 CDTI Z13DTJ-FAP (06-..)	Marelli 6JF CF3 Common Rail
 Meriva	MAINTENANCE	1.4 16v (03-..)	Manuale
 Meriva	MAINTENANCE	1.4 16v (03-..)	SIEMENS Dashboard
 Meriva	MAINTENANCE	1.4 16v (03-..)	SIEMENS Dashboard
 Meriva	MAINTENANCE	1.6 16v (03-..)	Manuale
 Meriva	MAINTENANCE	1.6 16v (03-..)	SIEMENS Dashboard
 Meriva	MAINTENANCE	1.6 16v (03-..)	SIEMENS Dashboard
 Meriva	MAINTENANCE	1.6 8v (03-..)	Manuale
 Meriva	MAINTENANCE	1.6 8v (03-..)	SIEMENS Dashboard
 Meriva	MAINTENANCE	1.6 8v (03-..)	SIEMENS Dashboard
 Meriva	MAINTENANCE	1.6 T (03-..)	Manuale
 Meriva	MAINTENANCE	1.6 T (03-..)	SIEMENS Dashboard
 Meriva	MAINTENANCE	1.6 T (03-..)	SIEMENS Dashboard
 Meriva	MAINTENANCE	1.7 CDTI (03-..)	Manuale
 Meriva	MAINTENANCE	1.7 CDTI (03-..)	SIEMENS Dashboard
 Meriva	MAINTENANCE	1.7 CDTI (03-..)	SIEMENS Dashboard
 Meriva	MAINTENANCE	1.7 DTI (03-..)	Manuale
 Meriva	MAINTENANCE	1.7 DTI (03-..)	SIEMENS Dashboard
 Meriva	MAINTENANCE	1.7 DTI (03-..)	SIEMENS Dashboard
 Meriva	MAINTENANCE	1.8 16v (03-..)	Manuale
 Meriva	MAINTENANCE	1.8 16v (03-..)	SIEMENS Dashboard
 Meriva	MAINTENANCE	1.8 16v (03-..)	SIEMENS Dashboard
 Meriva	SERVICE LIGHT RES	1.3 CDTI (03-..)	Manuale
 Meriva	SERVICE LIGHT RES	1.3 CDTI FAP (03-..)	Manuale
 Meriva	SERVICE LIGHT RES	1.4 16v (03-..)	Manuale
 Meriva	SERVICE LIGHT RES	1.6 16v (03-..)	Manuale
 Meriva	SERVICE LIGHT RES	1.6 8v (03-..)	Manuale
 Meriva	SERVICE LIGHT RES	1.6 T (03-..)	Manuale
 Meriva	SERVICE LIGHT RES	1.7 CDTI (03-..)	Manuale
 Meriva	SERVICE LIGHT RES	1.7 DTI (03-..)	Manuale
 Meriva	SERVICE LIGHT RES	1.8 16v (03-..)	Manuale
 Movano	AUTOM. TRANSMISSI	2.5 CDTI 100 (04-09)	AUTODETECT
 Movano	AUTOM. TRANSMISSI	2.5 CDTI 120 (04-09)	AUTODETECT
 Movano	AUTOM. TRANSMISSI	2.5 CDTI 150 FAP (04-09)	AUTODETECT
 Movano	CHASSIS NETWORK	2.2 16v dCi 66kw (10-..)	UCC AUTODETECT
 Movano	CHASSIS NETWORK	2.3 CDTI 125cv (10-..)	UCC AUTODETECT
 Movano	CHASSIS NETWORK	2.3 CDTI 150cv (10-..)	UCC AUTODETECT
 Movano	CHASSIS NETWORK	2.5 CDTI 100 (04-09)	UCC AUTODETECT
 Movano	CHASSIS NETWORK	2.5 CDTI 100 (04-09)	UCC AUTODETECT
 Movano	CHASSIS NETWORK	2.5 CDTI 120 (04-09)	UCC AUTODETECT
 Movano	CHASSIS NETWORK	2.5 CDTI 120 (04-09)	UCC AUTODETECT
 Movano	CHASSIS NETWORK	2.5 CDTI 150 FAP (04-09)	UCC AUTODETECT
 Movano	CHASSIS NETWORK	2.5 CDTI 150 FAP (04-09)	UCC AUTODETECT

Systems supported by ECReader / ECDecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Movano	ENGINE MANAGEME	2.5 CDTI 100 (04-09)	AUTODETECT
 Movano	ENGINE MANAGEME	2.5 CDTI 120 (04-09)	AUTODETECT
 Movano	ENGINE MANAGEME	2.5 CDTI 150 FAP (04-09)	AUTODETECT
 Movano	MAINTENANCE	2.5 CDTI 100 (04-09)	MANUAL
 Movano	MAINTENANCE	2.5 CDTI 120 (04-09)	MANUAL
 Movano	MAINTENANCE	2.5 CDTI 150 FAP (04-09)	MANUAL
 Movano	PARKING HELP	2.2 16v dCi 66kw (10-..)	AUTODETECT
 Movano	PARKING HELP	2.3 CDTI 125cv (10-..)	AUTODETECT
 Movano	PARKING HELP	2.3 CDTI 150cv (10-..)	AUTODETECT
 Movano	RADIO / CD	2.2 16v dCi 66kw (10-..)	AUTODETECT
 Movano	RADIO / CD	2.3 CDTI 125cv (10-..)	AUTODETECT
 Movano	RADIO / CD	2.3 CDTI 150cv (10-..)	AUTODETECT
 Movano	SERVICE LIGHT RES	2.5 CDTI 100 (04-09)	MANUAL
 Movano	SERVICE LIGHT RES	2.5 CDTI 120 (04-09)	MANUAL
 Movano	SERVICE LIGHT RES	2.5 CDTI 150 FAP (04-09)	MANUAL
 Movano	STEERING WHEEL E	2.2 16v dCi 66kw (10-..)	AUTODETECT
 Movano	STEERING WHEEL E	2.3 CDTI 125cv (10-..)	AUTODETECT
 Movano	STEERING WHEEL E	2.3 CDTI 150cv (10-..)	AUTODETECT
 Movano	VISUAL./TELEMATIC	2.2 16v dCi 66kw (10-..)	USB AUTODETECT
 Movano	VISUAL./TELEMATIC	2.3 CDTI 125cv (10-..)	USB AUTODETECT
 Movano	VISUAL./TELEMATIC	2.3 CDTI 150cv (10-..)	USB AUTODETECT
 Omega	ENGINE MANAGEME	2.0 20SE (.-89)	BOSCH Motronic ML4.1
 Omega	ENGINE MANAGEME	2.0 20SE (89-..)	BOSCH Motronic M1.5
 Omega	ENGINE MANAGEME	2.0 C20NE (.-89)	BOSCH Motronic ML4.1
 Omega	ENGINE MANAGEME	2.0 C20NE (89-..)	BOSCH Motronic M1.5
 Omega	ENGINE MANAGEME	2.0 C20NEJ (89-..)	BOSCH Motronic M1.5
 Omega	ENGINE MANAGEME	2.4 C24NE (89-..)	BOSCH Motronic M1.5
 Omega	ENGINE MANAGEME	2.6 C26NE (91-..)	BOSCH Motronic M1.5
 Omega	ENGINE MANAGEME	3.0 C30LE (.-88)	BOSCH Motronic ML4.1
 Omega-B	ABS	2.0	BOSCH ABS 5.3/5.4(+TC)
 Omega-B	ABS	2.0 16v	BOSCH ABS 5.3/5.4(+TC)
 Omega-B	ABS	2.0 DTI 16v	BOSCH ABS 5.3/5.4(+TC)
 Omega-B	ABS	2.2	BOSCH ABS 5.3/5.4(+TC)
 Omega-B	ABS	2.2 16v DTI	BOSCH ABS 5.3/5.4(+TC)
 Omega-B	ABS	2.5 24v	BOSCH ABS 5.3/5.4(+TC)
 Omega-B	ABS	2.5 DTI	BOSCH ABS 5.3/5.4(+TC)
 Omega-B	ABS	2.5 TD	BOSCH ABS 5.3/5.4(+TC)
 Omega-B	ABS	2.6	BOSCH ABS 5.3/5.4(+TC)
 Omega-B	ABS	2.6	BOSCH ABS 5.3/5.4(+TC)
 Omega-B	ABS	3.0 24v	BOSCH ABS 5.3/5.4(+TC)
 Omega-B	ABS	3.2	BOSCH ABS 5.3/5.4(+TC)
 Omega-B	AIRBAG	2.0 (.-00)	SIEMENS AirBag SAB6
 Omega-B	AIRBAG	2.0 (93-98)	GM AirBag S
 Omega-B	AIRBAG	2.0 16v (.-00)	SIEMENS AirBag SAB6
 Omega-B	AIRBAG	2.0 16v (93-98)	GM AirBag S
 Omega-B	AIRBAG	2.0 DTI 16v (.-00)	SIEMENS AirBag SAB6
 Omega-B	AIRBAG	2.0 DTI 16v (93-98)	GM AirBag S
 Omega-B	AIRBAG	2.2 (.-00)	SIEMENS AirBag SAB6
 Omega-B	AIRBAG	2.2 (93-98)	GM AirBag S
 Omega-B	AIRBAG	2.2 16v DTI (.-00)	SIEMENS AirBag SAB6
 Omega-B	AIRBAG	2.2 16v DTI (93-98)	GM AirBag S
 Omega-B	AIRBAG	2.5 24v (.-00)	SIEMENS AirBag SAB6
 Omega-B	AIRBAG	2.5 24v (93-98)	GM AirBag S
 Omega-B	AIRBAG	2.5 DTI (.-00)	SIEMENS AirBag SAB6
 Omega-B	AIRBAG	2.5 DTI (93-98)	GM AirBag S
 Omega-B	AIRBAG	2.5 TD (.-00)	SIEMENS AirBag SAB6
 Omega-B	AIRBAG	2.5 TD (93-98)	GM AirBag S
 Omega-B	AIRBAG	2.6 (.-00)	SIEMENS AirBag SAB6

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Omega-B	AIRBAG	2.6 (...00)	SIEMENS AirBag SAB6
 Omega-B	AIRBAG	2.6 (93-98)	GM AirBag S
 Omega-B	AIRBAG	2.6 (93-98)	GM AirBag S
 Omega-B	AIRBAG	3.0 24v (...00)	SIEMENS AirBag SAB6
 Omega-B	AIRBAG	3.0 24v (93-98)	GM AirBag S
 Omega-B	AIRBAG	3.2 (...00)	SIEMENS AirBag SAB6
 Omega-B	AIRBAG	3.2 (93-98)	GM AirBag S
 Omega-B	ENGINE MANAGEME	2.0 16v X20XEV (...97)	SIEMENS Simtec 56.0 - 56.1
 Omega-B	ENGINE MANAGEME	2.0 16v X20XEV (96-00)	SIEMENS Simtec 56.5
 Omega-B	ENGINE MANAGEME	2.0 20SE (94-00)	BOSCH Motronic M1.5.4
 Omega-B	ENGINE MANAGEME	2.0 X20SE (94-00)	BOSCH Motronic M1.5.4
 Omega-B	ENGINE MANAGEME	2.2 Y22XE (01-..)	EOBD
 Omega-B	ENGINE MANAGEME	2.2 Z22XE (01-..)	EOBD
 Omega-B	ENGINE MANAGEME	2.5 24v X25XE (94-00)	BOSCH Motronic M2.8.1
 Omega-B	ENGINE MANAGEME	2.6 (01-..)	EOBD
 Omega-B	ENGINE MANAGEME	2.6 Y26SE (01-..)	EOBD
 Omega-B	ENGINE MANAGEME	3.0 24v X30XE (94-00)	BOSCH Motronic M2.8.1
 Omega-B	ENGINE MANAGEME	3.2 Y32SE (01-..)	EOBD
 Omega-B	IMMOBILIZER	2.0 (00-..)	SIEMENS
 Omega-B	IMMOBILIZER	2.0 (96-99)	GM Immobilizer
 Omega-B	IMMOBILIZER	2.0 16v (00-..)	SIEMENS
 Omega-B	IMMOBILIZER	2.0 16v (96-99)	GM Immobilizer
 Omega-B	IMMOBILIZER	2.0 DTI 16v (00-..)	SIEMENS
 Omega-B	IMMOBILIZER	2.0 DTI 16v (96-99)	GM Immobilizer
 Omega-B	IMMOBILIZER	2.2 (00-..)	SIEMENS
 Omega-B	IMMOBILIZER	2.2 (96-99)	GM Immobilizer
 Omega-B	IMMOBILIZER	2.2 16v DTI (00-..)	SIEMENS
 Omega-B	IMMOBILIZER	2.2 16v DTI (96-99)	GM Immobilizer
 Omega-B	IMMOBILIZER	2.5 24v (00-..)	SIEMENS
 Omega-B	IMMOBILIZER	2.5 24v (96-99)	GM Immobilizer
 Omega-B	IMMOBILIZER	2.5 DTI (00-..)	SIEMENS
 Omega-B	IMMOBILIZER	2.5 DTI (96-99)	GM Immobilizer
 Omega-B	IMMOBILIZER	2.5 TD (00-..)	SIEMENS
 Omega-B	IMMOBILIZER	2.5 TD (96-99)	GM Immobilizer
 Omega-B	IMMOBILIZER	2.6 (00-..)	SIEMENS
 Omega-B	IMMOBILIZER	2.6 (00-..)	SIEMENS
 Omega-B	IMMOBILIZER	2.6 (96-99)	GM Immobilizer
 Omega-B	IMMOBILIZER	2.6 (96-99)	GM Immobilizer
 Omega-B	IMMOBILIZER	3.0 24v (00-..)	SIEMENS
 Omega-B	IMMOBILIZER	3.0 24v (96-99)	GM Immobilizer
 Omega-B	IMMOBILIZER	3.2 (00-..)	SIEMENS
 Omega-B	IMMOBILIZER	3.2 (96-99)	GM Immobilizer
 Senator-B	ENGINE MANAGEME	2.6 C26NE (...94)	BOSCH Motronic M1.5
 Senator-B	ENGINE MANAGEME	3.0 C30LE (...89)	BOSCH Motronic ML4.1
 Signum	ABS + TRACT. CONT	1.8 16v	ABS/TC/ESP
 Signum	ABS + TRACT. CONT	1.9 16v CDTI	ABS/TC/ESP
 Signum	ABS + TRACT. CONT	1.9 CDTI	ABS/TC/ESP
 Signum	ABS + TRACT. CONT	2.0 DTI 16v	ABS/TC/ESP
 Signum	ABS + TRACT. CONT	2.0 turbo 16v	ABS/TC/ESP
 Signum	ABS + TRACT. CONT	2.2 16v	ABS/TC/ESP
 Signum	ABS + TRACT. CONT	2.2 16v DTI	ABS/TC/ESP
 Signum	ABS + TRACT. CONT	2.8 T V6	ABS/TC/ESP
 Signum	ABS + TRACT. CONT	3.0 V6 CDTI	ABS/TC/ESP
 Signum	ABS + TRACT. CONT	3.2 V6	ABS/TC/ESP
 Signum	AIRBAG	1.8 16v	SDM
 Signum	AIRBAG	1.9 16v CDTI	SDM
 Signum	AIRBAG	1.9 CDTI	SDM
 Signum	AIRBAG	2.0 DTI 16v	SDM

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Signum	AIRBAG	2.0 turbo 16v	SDM
 Signum	AIRBAG	2.2 16v	SDM
 Signum	AIRBAG	2.2 16v DTI	SDM
 Signum	AIRBAG	2.8 T V6	SDM
 Signum	AIRBAG	3.0 V6 CDTI	SDM
 Signum	AIRBAG	3.2 V6	SDM
 Signum	AUTOM. TRANSMISSI	1.8 16v	A/T AF-23-5/33-5
 Signum	AUTOM. TRANSMISSI	1.9 16v CDTI	A/T AF-23-5/33-5
 Signum	AUTOM. TRANSMISSI	1.9 CDTI	A/T AF-23-5/33-5
 Signum	AUTOM. TRANSMISSI	2.0 DTI 16v	A/T AF-23-5/33-5
 Signum	AUTOM. TRANSMISSI	2.0 turbo 16v	A/T AF-23-5/33-5
 Signum	AUTOM. TRANSMISSI	2.2 16v	A/T AF-23-5/33-5
 Signum	AUTOM. TRANSMISSI	2.2 16v DTI	A/T AF-23-5/33-5
 Signum	AUTOM. TRANSMISSI	2.8 T V6	A/T AF-23-5/33-5
 Signum	AUTOM. TRANSMISSI	3.0 V6 CDTI	A/T AF-23-5/33-5
 Signum	AUTOM. TRANSMISSI	3.2 V6	A/T AF-23-5/33-5
 Signum	CHASSIS NETWORK	1.8 16v	BCM External lightning
 Signum	CHASSIS NETWORK	1.9 16v CDTI	BCM External lightning
 Signum	CHASSIS NETWORK	1.9 CDTI	BCM External lightning
 Signum	CHASSIS NETWORK	2.0 DTI 16v	BCM External lightning
 Signum	CHASSIS NETWORK	2.0 turbo 16v	BCM External lightning
 Signum	CHASSIS NETWORK	2.2 16v	BCM External lightning
 Signum	CHASSIS NETWORK	2.2 16v DTI	BCM External lightning
 Signum	CHASSIS NETWORK	2.8 T V6	BCM External lightning
 Signum	CHASSIS NETWORK	3.0 V6 CDTI	BCM External lightning
 Signum	CHASSIS NETWORK	3.2 V6	BCM External lightning
 Signum	CLIMA	1.8 16v	ECC
 Signum	CLIMA	1.9 16v CDTI	ECC
 Signum	CLIMA	1.9 CDTI	ECC
 Signum	CLIMA	2.0 DTI 16v	ECC
 Signum	CLIMA	2.0 turbo 16v	ECC
 Signum	CLIMA	2.2 16v	ECC
 Signum	CLIMA	2.2 16v DTI	ECC
 Signum	CLIMA	2.8 T V6	ECC
 Signum	CLIMA	3.0 V6 CDTI	ECC
 Signum	CLIMA	3.2 V6	ECC
 Signum	DASHBOARD	1.8 16v	VDO IPC
 Signum	DASHBOARD	1.9 16v CDTI	VDO IPC
 Signum	DASHBOARD	1.9 CDTI	VDO IPC
 Signum	DASHBOARD	2.0 DTI 16v	VDO IPC
 Signum	DASHBOARD	2.0 turbo 16v	VDO IPC
 Signum	DASHBOARD	2.2 16v	VDO IPC
 Signum	DASHBOARD	2.2 16v DTI	VDO IPC
 Signum	DASHBOARD	2.8 T V6	VDO IPC
 Signum	DASHBOARD	3.0 V6 CDTI	VDO IPC
 Signum	DASHBOARD	3.2 V6	VDO IPC
 Signum	ELECTRIC STEERING	1.8 16v	TRW automotive EHPS 0300
 Signum	ELECTRIC STEERING	1.9 16v CDTI	TRW automotive EHPS 0300
 Signum	ELECTRIC STEERING	1.9 CDTI	TRW automotive EHPS 0300
 Signum	ELECTRIC STEERING	2.0 DTI 16v	TRW automotive EHPS 0300
 Signum	ELECTRIC STEERING	2.0 turbo 16v	TRW automotive EHPS 0300
 Signum	ELECTRIC STEERING	2.2 16v	TRW automotive EHPS 0300
 Signum	ELECTRIC STEERING	2.2 16v DTI	TRW automotive EHPS 0300
 Signum	ELECTRIC STEERING	2.8 T V6	TRW automotive EHPS 0300
 Signum	ELECTRIC STEERING	3.0 V6 CDTI	TRW automotive EHPS 0300
 Signum	ELECTRIC STEERING	3.2 V6	TRW automotive EHPS 0300
 Signum	ENGINE MANAGEME	1.8 16v Z18XER	SIEMENS MPI MS75
 Signum	ENGINE MANAGEME	1.9 16v CDTI Z19DT	BOSCH EDC 16 Common Rail

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Signum	ENGINE MANAGEME	1.9 CDTI Z19DTH	BOSCH EDC 16 Common Rail
 Signum	ENGINE MANAGEME	2.0 DTI 16v (04-...)	EOBD
 Signum	ENGINE MANAGEME	2.0 turbo 16v	EOBD
 Signum	ENGINE MANAGEME	2.2 16v	EOBD
 Signum	ENGINE MANAGEME	2.2 16v DTI Y22DTR	BOSCH EDC Common Rail
 Signum	ENGINE MANAGEME	2.8 T V6	EOBD
 Signum	ENGINE MANAGEME	3.0 V6 CDTI Y30DT	DENSO EDC Common Rail
 Signum	ENGINE MANAGEME	3.2 V6	EOBD
 Signum	MAINTENANCE	1.8 16v	MANUAL
 Signum	MAINTENANCE	1.8 16v Z18XER	SIEMENS MPI MS75
 Signum	MAINTENANCE	1.9 16v CDTI	MANUAL
 Signum	MAINTENANCE	1.9 CDTI	MANUAL
 Signum	MAINTENANCE	2.0 DTI 16v	MANUAL
 Signum	MAINTENANCE	2.0 turbo 16v	MANUAL
 Signum	MAINTENANCE	2.2 16v	MANUAL
 Signum	MAINTENANCE	2.2 16v DTI	MANUAL
 Signum	MAINTENANCE	2.2 16v DTI Y22DTR	BOSCH EDC Common Rail
 Signum	MAINTENANCE	2.8 T V6	MANUAL
 Signum	MAINTENANCE	3.0 V6 CDTI	MANUAL
 Signum	MAINTENANCE	3.0 V6 CDTI Y30DT	DENSO EDC Common Rail
 Signum	MAINTENANCE	3.2 V6	MANUAL
 Signum	SERVICE LIGHT RES	1.8 16v	MANUAL
 Signum	SERVICE LIGHT RES	1.9 16v CDTI	MANUAL
 Signum	SERVICE LIGHT RES	1.9 CDTI	MANUAL
 Signum	SERVICE LIGHT RES	2.0 DTI 16v	MANUAL
 Signum	SERVICE LIGHT RES	2.0 turbo 16v	MANUAL
 Signum	SERVICE LIGHT RES	2.2 16v	MANUAL
 Signum	SERVICE LIGHT RES	2.2 16v DTI	MANUAL
 Signum	SERVICE LIGHT RES	2.8 T V6	MANUAL
 Signum	SERVICE LIGHT RES	3.0 V6 CDTI	MANUAL
 Signum	SERVICE LIGHT RES	3.2 V6	MANUAL
 Signum	VISUAL./TELEMATIC	1.8 16v	GID/CID
 Signum	VISUAL./TELEMATIC	1.8 16v	TID
 Signum	VISUAL./TELEMATIC	1.9 16v CDTI	GID/CID
 Signum	VISUAL./TELEMATIC	1.9 16v CDTI	TID
 Signum	VISUAL./TELEMATIC	1.9 CDTI	GID/CID
 Signum	VISUAL./TELEMATIC	1.9 CDTI	TID
 Signum	VISUAL./TELEMATIC	2.0 DTI 16v	GID/CID
 Signum	VISUAL./TELEMATIC	2.0 DTI 16v	TID
 Signum	VISUAL./TELEMATIC	2.0 turbo 16v	GID/CID
 Signum	VISUAL./TELEMATIC	2.0 turbo 16v	TID
 Signum	VISUAL./TELEMATIC	2.2 16v	GID/CID
 Signum	VISUAL./TELEMATIC	2.2 16v	TID
 Signum	VISUAL./TELEMATIC	2.2 16v DTI	GID/CID
 Signum	VISUAL./TELEMATIC	2.2 16v DTI	TID
 Signum	VISUAL./TELEMATIC	2.8 T V6	GID/CID
 Signum	VISUAL./TELEMATIC	2.8 T V6	TID
 Signum	VISUAL./TELEMATIC	3.0 V6 CDTI	GID/CID
 Signum	VISUAL./TELEMATIC	3.0 V6 CDTI	TID
 Signum	VISUAL./TELEMATIC	3.2 V6	GID/CID
 Signum	VISUAL./TELEMATIC	3.2 V6	TID
 Sintra	AIRBAG	2.2 16v (96-97)	SIEMENS AirBag SAE4 (a)
 Sintra	AIRBAG	2.2 16v (96-97)	SIEMENS AirBag SAE4 (b)
 Sintra	AIRBAG	2.2 16v DTI (96-97)	SIEMENS AirBag SAE4 (a)
 Sintra	AIRBAG	2.2 16v DTI (96-97)	SIEMENS AirBag SAE4 (b)
 Sintra	AIRBAG	3.0 24v (96-97)	SIEMENS AirBag SAE4 (a)
 Sintra	AIRBAG	3.0 24v (96-97)	SIEMENS AirBag SAE4 (b)
 Sintra	ENGINE MANAGEME	2.2 16v DTI X22DTH (97-00)	BOSCH EDC MSA 15 M

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sintra	ENGINE MANAGEME	3.0 24v X30XE (97-00)	BOSCH Motronic M2.8.3
 Speedster/VX220	ABS	2.0 T	GM ABS 430
 Speedster/VX220	ABS	2.2	GM ABS 430
 Speedster/VX220	ENGINE MANAGEME	2.0 T (01-...)	EOBD
 Speedster/VX220	ENGINE MANAGEME	2.2 Z22SE (01-...)	EOBD
 Speedster/VX220	IMMOBILIZER	2.0 T (01-...)	SIEMENS
 Speedster/VX220	IMMOBILIZER	2.2 (01-...)	SIEMENS
 Tigra	AIRBAG	1.4 16v (93-00)	GM AirBag S
 Tigra	AIRBAG	1.6 16v (93-00)	GM AirBag S
 Tigra	ENGINE MANAGEME	1.4 16v X14XE (...-95)	GM Multec S
 Tigra	ENGINE MANAGEME	1.4 16v X14XE (96-00)	GM Multec S (F)
 Tigra	ENGINE MANAGEME	1.6 16v X16XE (...-95)	GM Multec S
 Tigra	ENGINE MANAGEME	1.6 16v X16XE (96-00)	GM Multec S (F)
 Tigra	IMMOBILIZER	1.4 16v (96-98)	GM Immobilizer
 Tigra	IMMOBILIZER	1.6 16v (96-98)	GM Immobilizer
 Vectra-A	AIRBAG	1.4 (93-95)	GM AirBag S
 Vectra-A	AIRBAG	1.6 (93-95)	GM AirBag S
 Vectra-A	AIRBAG	1.6 Kat (93-95)	GM AirBag S
 Vectra-A	AIRBAG	1.7 D (93-95)	GM AirBag S
 Vectra-A	AIRBAG	1.7 TD (93-95)	GM AirBag S
 Vectra-A	AIRBAG	1.8 (93-95)	GM AirBag S
 Vectra-A	AIRBAG	2.0 (93-95)	GM AirBag S
 Vectra-A	AIRBAG	2.0 16v (93-95)	GM AirBag S
 Vectra-A	AIRBAG	2.0 T (93-95)	GM AirBag S
 Vectra-A	AIRBAG	2.5 24v (93-95)	GM AirBag S
 Vectra-A	ENGINE MANAGEME	1.6 16LZ2 (...-95)	GM Multec TBI
 Vectra-A	ENGINE MANAGEME	1.6 16LZ2 (...-95)	GM Multec TBI + Immob.
 Vectra-A	ENGINE MANAGEME	1.6 C16NZ2 (...-94)	GM Multec TBI
 Vectra-A	ENGINE MANAGEME	1.6 C16NZ2 (94-...)	GM Multec TBI + Immob.
 Vectra-A	ENGINE MANAGEME	1.6 E16NZ (89-95)	GM Multec TBI MANUAL
 Vectra-A	ENGINE MANAGEME	1.6 Kat C16NZ (89-95)	GM Multec TBI MANUAL
 Vectra-A	ENGINE MANAGEME	1.6 X16SZ (...-94)	GM Multec SZ
 Vectra-A	ENGINE MANAGEME	1.6 X16SZ (94-00)	GM Multec SZ
 Vectra-A	ENGINE MANAGEME	1.8 C18NZ (...-95)	GM Multec TBI + Immob.
 Vectra-A	ENGINE MANAGEME	1.8 C18NZ (91-94)	GM Multec TBI
 Vectra-A	ENGINE MANAGEME	2.0 16v 20XEJ (89-...)	BOSCH Motronic M2.5
 Vectra-A	ENGINE MANAGEME	2.0 16v C20XE (...-92)	BOSCH Motronic M2.5
 Vectra-A	ENGINE MANAGEME	2.0 16v C20XE (92-...)	BOSCH Motronic M2.8
 Vectra-A	ENGINE MANAGEME	2.0 16v X20XEV (...-95)	SIEMENS Simtec 56.0 - 56.1
 Vectra-A	ENGINE MANAGEME	2.0 20NE (...-89)	BOSCH Motronic ML4.1
 Vectra-A	ENGINE MANAGEME	2.0 20NE (89-...)	BOSCH Motronic M1.5
 Vectra-A	ENGINE MANAGEME	2.0 20SEH (...-89)	BOSCH Motronic ML4.1
 Vectra-A	ENGINE MANAGEME	2.0 20SEH (89-...)	BOSCH Motronic M1.5
 Vectra-A	ENGINE MANAGEME	2.0 C20NE (...-89)	BOSCH Motronic ML4.1
 Vectra-A	ENGINE MANAGEME	2.0 C20NE (89-...)	BOSCH Motronic M1.5
 Vectra-A	ENGINE MANAGEME	2.0 T C20LET (...-95)	BOSCH Motronic M2.7
 Vectra-A	ENGINE MANAGEME	2.5 24v C25XE (93-95)	BOSCH Motronic M2.8
 Vectra-A	MAINTENANCE	1.6 E16NZ (89-95)	GM Multec TBI MANUAL
 Vectra-A	MAINTENANCE	1.6 Kat C16NZ (89-95)	GM Multec TBI MANUAL
 Vectra-B	ABS	1.6	BOSCH ABS 5.3/5.4(+TC)
 Vectra-B	ABS	1.6	GM ABS 415
 Vectra-B	ABS	1.6	GM ABS 430
 Vectra-B	ABS	1.6 16v	BOSCH ABS 5.3/5.4(+TC)
 Vectra-B	ABS	1.6 16v	GM ABS 415
 Vectra-B	ABS	1.6 16v	GM ABS 430
 Vectra-B	ABS	1.7 TD	BOSCH ABS 5.3/5.4(+TC)
 Vectra-B	ABS	1.7 TD	GM ABS 415

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Vectra-B	ABS	1.7 TD	GM ABS 430
 Vectra-B	ABS	1.8 16v	BOSCH ABS 5.3/5.4(+TC)
 Vectra-B	ABS	1.8 16v	GM ABS 415
 Vectra-B	ABS	1.8 16v	GM ABS 430
 Vectra-B	ABS	2.0	BOSCH ABS 5.3/5.4(+TC)
 Vectra-B	ABS	2.0	GM ABS 415
 Vectra-B	ABS	2.0	GM ABS 430
 Vectra-B	ABS	2.0 16v	BOSCH ABS 5.3/5.4(+TC)
 Vectra-B	ABS	2.0 16v	GM ABS 415
 Vectra-B	ABS	2.0 16v	GM ABS 430
 Vectra-B	ABS	2.0 DI	BOSCH ABS 5.3/5.4(+TC)
 Vectra-B	ABS	2.0 DI	GM ABS 415
 Vectra-B	ABS	2.0 DI	GM ABS 430
 Vectra-B	ABS	2.0 DTI 16v	BOSCH ABS 5.3/5.4(+TC)
 Vectra-B	ABS	2.0 DTI 16v	GM ABS 415
 Vectra-B	ABS	2.0 DTI 16v	GM ABS 430
 Vectra-B	ABS	2.2	BOSCH ABS 5.3/5.4(+TC)
 Vectra-B	ABS	2.2	GM ABS 415
 Vectra-B	ABS	2.2	GM ABS 430
 Vectra-B	ABS	2.2 16v DTI	BOSCH ABS 5.3/5.4(+TC)
 Vectra-B	ABS	2.2 16v DTI	GM ABS 415
 Vectra-B	ABS	2.2 16v DTI	GM ABS 430
 Vectra-B	ABS	2.5 24v	BOSCH ABS 5.3/5.4(+TC)
 Vectra-B	ABS	2.5 24v	GM ABS 415
 Vectra-B	ABS	2.5 24v	GM ABS 430
 Vectra-B	ABS	2.6	BOSCH ABS 5.3/5.4(+TC)
 Vectra-B	ABS	2.6	GM ABS 415
 Vectra-B	ABS	2.6	GM ABS 430
 Vectra-B	AIRBAG	1.6 (...01)	SIEMENS AirBag SAB6
 Vectra-B	AIRBAG	1.6 (96-97)	SIEMENS AirBag SAE4 (a)
 Vectra-B	AIRBAG	1.6 (96-97)	SIEMENS AirBag SAE4 (b)
 Vectra-B	AIRBAG	1.6 16v (...01)	SIEMENS AirBag SAB6
 Vectra-B	AIRBAG	1.6 16v (96-97)	SIEMENS AirBag SAE4 (a)
 Vectra-B	AIRBAG	1.6 16v (96-97)	SIEMENS AirBag SAE4 (b)
 Vectra-B	AIRBAG	1.7 TD (...01)	SIEMENS AirBag SAB6
 Vectra-B	AIRBAG	1.7 TD (96-97)	SIEMENS AirBag SAE4 (a)
 Vectra-B	AIRBAG	1.7 TD (96-97)	SIEMENS AirBag SAE4 (b)
 Vectra-B	AIRBAG	1.8 16v (...01)	SIEMENS AirBag SAB6
 Vectra-B	AIRBAG	1.8 16v (96-97)	SIEMENS AirBag SAE4 (a)
 Vectra-B	AIRBAG	1.8 16v (96-97)	SIEMENS AirBag SAE4 (b)
 Vectra-B	AIRBAG	2.0 (...01)	SIEMENS AirBag SAB6
 Vectra-B	AIRBAG	2.0 (96-97)	SIEMENS AirBag SAE4 (a)
 Vectra-B	AIRBAG	2.0 (96-97)	SIEMENS AirBag SAE4 (b)
 Vectra-B	AIRBAG	2.0 16v (...01)	SIEMENS AirBag SAB6
 Vectra-B	AIRBAG	2.0 16v (96-97)	SIEMENS AirBag SAE4 (a)
 Vectra-B	AIRBAG	2.0 16v (96-97)	SIEMENS AirBag SAE4 (b)
 Vectra-B	AIRBAG	2.0 DI (...01)	SIEMENS AirBag SAB6
 Vectra-B	AIRBAG	2.0 DI (96-97)	SIEMENS AirBag SAE4 (a)
 Vectra-B	AIRBAG	2.0 DI (96-97)	SIEMENS AirBag SAE4 (b)
 Vectra-B	AIRBAG	2.0 DTI 16v (...01)	SIEMENS AirBag SAB6
 Vectra-B	AIRBAG	2.0 DTI 16v (96-97)	SIEMENS AirBag SAE4 (a)
 Vectra-B	AIRBAG	2.0 DTI 16v (96-97)	SIEMENS AirBag SAE4 (b)
 Vectra-B	AIRBAG	2.2 (...01)	SIEMENS AirBag SAB6
 Vectra-B	AIRBAG	2.2 (96-97)	SIEMENS AirBag SAE4 (a)
 Vectra-B	AIRBAG	2.2 (96-97)	SIEMENS AirBag SAE4 (b)
 Vectra-B	AIRBAG	2.2 16v DTI (...01)	SIEMENS AirBag SAB6
 Vectra-B	AIRBAG	2.2 16v DTI (96-97)	SIEMENS AirBag SAE4 (a)
 Vectra-B	AIRBAG	2.2 16v DTI (96-97)	SIEMENS AirBag SAE4 (b)

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Vectra-B	AIRBAG	2.5 24v (...01)	SIEMENS AirBag SAB6
 Vectra-B	AIRBAG	2.5 24v (96-97)	SIEMENS AirBag SAE4 (a)
 Vectra-B	AIRBAG	2.5 24v (96-97)	SIEMENS AirBag SAE4 (b)
 Vectra-B	AIRBAG	2.6 (...01)	SIEMENS AirBag SAB6
 Vectra-B	AIRBAG	2.6 (96-97)	SIEMENS AirBag SAE4 (a)
 Vectra-B	AIRBAG	2.6 (96-97)	SIEMENS AirBag SAE4 (b)
 Vectra-B	CLIMA	1.6 (97-01)	GM Clima ECC
 Vectra-B	CLIMA	1.6 16v (97-01)	GM Clima ECC
 Vectra-B	CLIMA	1.7 TD (97-01)	GM Clima ECC
 Vectra-B	CLIMA	1.8 16v (97-01)	GM Clima ECC
 Vectra-B	CLIMA	2.0 (97-01)	GM Clima ECC
 Vectra-B	CLIMA	2.0 16v (97-01)	GM Clima ECC
 Vectra-B	CLIMA	2.0 DI (97-01)	GM Clima ECC
 Vectra-B	CLIMA	2.0 DTI 16v (97-01)	GM Clima ECC
 Vectra-B	CLIMA	2.2 (97-01)	GM Clima ECC
 Vectra-B	CLIMA	2.2 16v DTI (97-01)	GM Clima ECC
 Vectra-B	CLIMA	2.5 24v (97-01)	GM Clima ECC
 Vectra-B	CLIMA	2.6 (97-01)	GM Clima ECC
 Vectra-B	DASHBOARD	1.6 (98-..)	Dashboard
 Vectra-B	DASHBOARD	1.6 16v (98-..)	Dashboard
 Vectra-B	DASHBOARD	1.7 TD (98-..)	Dashboard
 Vectra-B	DASHBOARD	1.8 16v (98-..)	Dashboard
 Vectra-B	DASHBOARD	2.0 (98-..)	Dashboard
 Vectra-B	DASHBOARD	2.0 16v (98-..)	Dashboard
 Vectra-B	DASHBOARD	2.0 DI (98-..)	Dashboard
 Vectra-B	DASHBOARD	2.0 DTI 16v (98-..)	Dashboard
 Vectra-B	DASHBOARD	2.2 (98-..)	Dashboard
 Vectra-B	DASHBOARD	2.2 16v DTI (98-..)	Dashboard
 Vectra-B	DASHBOARD	2.5 24v (98-..)	Dashboard
 Vectra-B	DASHBOARD	2.6 (98-..)	Dashboard
 Vectra-B	ENGINE MANAGEME	1.6 16LZ2 (...96)	GM Multec TBI
 Vectra-B	ENGINE MANAGEME	1.6 16LZ2 (96-00)	GM Multec TBI + Immob.
 Vectra-B	ENGINE MANAGEME	1.6 16v X16XEL (96-00)	GM Multec (F)
 Vectra-B	ENGINE MANAGEME	1.6 X16SZR (96-00)	GM Multec (F)
 Vectra-B	ENGINE MANAGEME	1.6 Y16XE (00/01-..)	EOBD
 Vectra-B	ENGINE MANAGEME	1.6 Y16XEL (00/01-..)	EOBD
 Vectra-B	ENGINE MANAGEME	1.6 Z16XE (00/01-..)	EOBD
 Vectra-B	ENGINE MANAGEME	1.8 16v X18XE (96-00)	SIEMENS Simtec 56.5
 Vectra-B	ENGINE MANAGEME	1.8 16v X18XE1 (98-00)	SIEMENS Simtec 70
 Vectra-B	ENGINE MANAGEME	2.0 16v X20XEV (96-00)	SIEMENS Simtec 56.5
 Vectra-B	ENGINE MANAGEME	2.0 20NEJ (96-00)	BOSCH Motronic M1.5.4
 Vectra-B	ENGINE MANAGEME	2.0 DI X20DTL (98-00)	BOSCH EDC MSA 15 M
 Vectra-B	ENGINE MANAGEME	2.0 DTI 16v X20DTH (98-00)	BOSCH EDC MSA 15 M
 Vectra-B	ENGINE MANAGEME	2.0 DTI 16v Y20DTH (01-..)	BOSCH EDC MSA 15 M
 Vectra-B	ENGINE MANAGEME	2.2 Z22SE (00/01-..)	EOBD
 Vectra-B	ENGINE MANAGEME	2.5 24v X25XE (96-00)	BOSCH Motronic M2.8.3
 Vectra-B	ENGINE MANAGEME	2.5 24v X25XE1 (98-00)	BOSCH Motronic M2.8.3
 Vectra-B	ENGINE MANAGEME	2.6 Z26SE (00/01-..)	EOBD
 Vectra-B	IMMOBILIZER	1.6 (96-97)	GM Immobilizer
 Vectra-B	IMMOBILIZER	1.6 (98-..)	SIEMENS
 Vectra-B	IMMOBILIZER	1.6 16v (96-97)	GM Immobilizer
 Vectra-B	IMMOBILIZER	1.6 16v (98-..)	SIEMENS
 Vectra-B	IMMOBILIZER	1.7 TD (96-97)	GM Immobilizer
 Vectra-B	IMMOBILIZER	1.7 TD (98-..)	SIEMENS
 Vectra-B	IMMOBILIZER	1.8 16v (96-97)	GM Immobilizer
 Vectra-B	IMMOBILIZER	1.8 16v (98-..)	SIEMENS
 Vectra-B	IMMOBILIZER	2.0 (96-97)	GM Immobilizer
 Vectra-B	IMMOBILIZER	2.0 (98-..)	SIEMENS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Vectra-B	IMMOBILIZER	2.0 16v (96-97)	GM Immobilizer
 Vectra-B	IMMOBILIZER	2.0 16v (98-..)	SIEMENS
 Vectra-B	IMMOBILIZER	2.0 DI (96-97)	GM Immobilizer
 Vectra-B	IMMOBILIZER	2.0 DI (98-..)	SIEMENS
 Vectra-B	IMMOBILIZER	2.0 DTI 16v (96-97)	GM Immobilizer
 Vectra-B	IMMOBILIZER	2.0 DTI 16v (98-..)	SIEMENS
 Vectra-B	IMMOBILIZER	2.2 (96-97)	GM Immobilizer
 Vectra-B	IMMOBILIZER	2.2 (98-..)	SIEMENS
 Vectra-B	IMMOBILIZER	2.2 16v DTI (96-97)	GM Immobilizer
 Vectra-B	IMMOBILIZER	2.2 16v DTI (98-..)	SIEMENS
 Vectra-B	IMMOBILIZER	2.5 24v (96-97)	GM Immobilizer
 Vectra-B	IMMOBILIZER	2.5 24v (98-..)	SIEMENS
 Vectra-B	IMMOBILIZER	2.6 (96-97)	GM Immobilizer
 Vectra-B	IMMOBILIZER	2.6 (98-..)	SIEMENS
 Vectra-B	MAINTENANCE	1.6 (98-00)	GM MANUAL
 Vectra-B	MAINTENANCE	1.6 16v (98-00)	GM MANUAL
 Vectra-B	MAINTENANCE	1.7 TD (98-00)	GM MANUAL
 Vectra-B	MAINTENANCE	1.8 16v (98-00)	GM MANUAL
 Vectra-B	MAINTENANCE	2.0 (98-00)	GM MANUAL
 Vectra-B	MAINTENANCE	2.0 16v (98-00)	GM MANUAL
 Vectra-B	MAINTENANCE	2.0 DI (98-00)	GM MANUAL
 Vectra-B	MAINTENANCE	2.0 DTI 16v (98-00)	GM MANUAL
 Vectra-B	MAINTENANCE	2.2 (98-00)	GM MANUAL
 Vectra-B	MAINTENANCE	2.2 16v DTI (98-00)	GM MANUAL
 Vectra-B	MAINTENANCE	2.5 24v (98-00)	GM MANUAL
 Vectra-B	MAINTENANCE	2.6 (98-00)	GM MANUAL
 Vectra-B	SERVICE LIGHT RES	1.6 (98-00)	GM MANUAL
 Vectra-B	SERVICE LIGHT RES	1.6 16v (98-00)	GM MANUAL
 Vectra-B	SERVICE LIGHT RES	1.7 TD (98-00)	GM MANUAL
 Vectra-B	SERVICE LIGHT RES	1.8 16v (98-00)	GM MANUAL
 Vectra-B	SERVICE LIGHT RES	2.0 (98-00)	GM MANUAL
 Vectra-B	SERVICE LIGHT RES	2.0 16v (98-00)	GM MANUAL
 Vectra-B	SERVICE LIGHT RES	2.0 DI (98-00)	GM MANUAL
 Vectra-B	SERVICE LIGHT RES	2.0 DTI 16v (98-00)	GM MANUAL
 Vectra-B	SERVICE LIGHT RES	2.2 (98-00)	GM MANUAL
 Vectra-B	SERVICE LIGHT RES	2.2 16v DTI (98-00)	GM MANUAL
 Vectra-B	SERVICE LIGHT RES	2.5 24v (98-00)	GM MANUAL
 Vectra-B	SERVICE LIGHT RES	2.6 (98-00)	GM MANUAL
 Vectra-C	ABS + TRACT. CONT	1.6 (02-..)	ABS/TC/ESP
 Vectra-C	ABS + TRACT. CONT	1.6 16v (02-..)	ABS/TC/ESP
 Vectra-C	ABS + TRACT. CONT	1.8 16v (02-..)	ABS/TC/ESP
 Vectra-C	ABS + TRACT. CONT	1.9 16v CDTI (02-..)	ABS/TC/ESP
 Vectra-C	ABS + TRACT. CONT	1.9 CDTI (02-..)	ABS/TC/ESP
 Vectra-C	ABS + TRACT. CONT	2.0 16v DTI (02-..)	ABS/TC/ESP
 Vectra-C	ABS + TRACT. CONT	2.0 T 16v (02-..)	ABS/TC/ESP
 Vectra-C	ABS + TRACT. CONT	2.2 16v (02-..)	ABS/TC/ESP
 Vectra-C	ABS + TRACT. CONT	2.2 16v DTI (02-..)	ABS/TC/ESP
 Vectra-C	ABS + TRACT. CONT	2.8 T V6 (02-..)	ABS/TC/ESP
 Vectra-C	ABS + TRACT. CONT	3.0 CDTI (02-..)	ABS/TC/ESP
 Vectra-C	ABS + TRACT. CONT	3.2 V6 (02-..)	ABS/TC/ESP
 Vectra-C	AIRBAG	1.6 (02-..)	SDM
 Vectra-C	AIRBAG	1.6 16v (02-..)	SDM
 Vectra-C	AIRBAG	1.8 16v (02-..)	SDM
 Vectra-C	AIRBAG	1.9 16v CDTI (02-..)	SDM
 Vectra-C	AIRBAG	1.9 CDTI (02-..)	SDM
 Vectra-C	AIRBAG	2.0 16v DTI (02-..)	SDM
 Vectra-C	AIRBAG	2.0 T 16v (02-..)	SDM
 Vectra-C	AIRBAG	2.2 16v (02-..)	SDM

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Vectra-C	AIRBAG	2.2 16v DTI (02-..)	SDM
 Vectra-C	AIRBAG	2.8 T V6 (02-..)	SDM
 Vectra-C	AIRBAG	3.0 CDTI (02-..)	SDM
 Vectra-C	AIRBAG	3.2 V6 (02-..)	SDM
 Vectra-C	AUTOM. TRANSMISSI	1.6 (02-..)	A/T AF-23-5/33-5
 Vectra-C	AUTOM. TRANSMISSI	1.6 16v (02-..)	A/T AF-23-5/33-5
 Vectra-C	AUTOM. TRANSMISSI	1.8 16v (02-..)	A/T AF-23-5/33-5
 Vectra-C	AUTOM. TRANSMISSI	1.9 16v CDTI (02-..)	A/T AF-23-5/33-5
 Vectra-C	AUTOM. TRANSMISSI	1.9 CDTI (02-..)	A/T AF-23-5/33-5
 Vectra-C	AUTOM. TRANSMISSI	2.0 16v DTI (02-..)	A/T AF-23-5/33-5
 Vectra-C	AUTOM. TRANSMISSI	2.0 T 16v (02-..)	A/T AF-23-5/33-5
 Vectra-C	AUTOM. TRANSMISSI	2.2 16v (02-..)	A/T AF-23-5/33-5
 Vectra-C	AUTOM. TRANSMISSI	2.2 16v DTI (02-..)	A/T AF-23-5/33-5
 Vectra-C	AUTOM. TRANSMISSI	2.8 T V6 (02-..)	A/T AF-23-5/33-5
 Vectra-C	AUTOM. TRANSMISSI	3.0 CDTI (02-..)	A/T AF-23-5/33-5
 Vectra-C	AUTOM. TRANSMISSI	3.2 V6 (02-..)	A/T AF-23-5/33-5
 Vectra-C	CHASSIS NETWORK	1.6 (02-..)	BCM External lightning
 Vectra-C	CHASSIS NETWORK	1.6 16v (02-..)	BCM External lightning
 Vectra-C	CHASSIS NETWORK	1.8 16v (02-..)	BCM External lightning
 Vectra-C	CHASSIS NETWORK	1.9 16v CDTI (02-..)	BCM External lightning
 Vectra-C	CHASSIS NETWORK	1.9 CDTI (02-..)	BCM External lightning
 Vectra-C	CHASSIS NETWORK	2.0 16v DTI (02-..)	BCM External lightning
 Vectra-C	CHASSIS NETWORK	2.0 T 16v (02-..)	BCM External lightning
 Vectra-C	CHASSIS NETWORK	2.2 16v (02-..)	BCM External lightning
 Vectra-C	CHASSIS NETWORK	2.2 16v DTI (02-..)	BCM External lightning
 Vectra-C	CHASSIS NETWORK	2.8 T V6 (02-..)	BCM External lightning
 Vectra-C	CHASSIS NETWORK	3.0 CDTI (02-..)	BCM External lightning
 Vectra-C	CHASSIS NETWORK	3.2 V6 (02-..)	BCM External lightning
 Vectra-C	CLIMA	1.6 (02-..)	ECC
 Vectra-C	CLIMA	1.6 16v (02-..)	ECC
 Vectra-C	CLIMA	1.8 16v (02-..)	ECC
 Vectra-C	CLIMA	1.9 16v CDTI (02-..)	ECC
 Vectra-C	CLIMA	1.9 CDTI (02-..)	ECC
 Vectra-C	CLIMA	2.0 16v DTI (02-..)	ECC
 Vectra-C	CLIMA	2.0 T 16v (02-..)	ECC
 Vectra-C	CLIMA	2.2 16v (02-..)	ECC
 Vectra-C	CLIMA	2.2 16v DTI (02-..)	ECC
 Vectra-C	CLIMA	2.8 T V6 (02-..)	ECC
 Vectra-C	CLIMA	3.0 CDTI (02-..)	ECC
 Vectra-C	CLIMA	3.2 V6 (02-..)	ECC
 Vectra-C	DASHBOARD	1.6 (02-..)	VDO IPC 0400
 Vectra-C	DASHBOARD	1.6 16v (02-..)	VDO IPC 0400
 Vectra-C	DASHBOARD	1.8 16v (02-..)	VDO IPC 0400
 Vectra-C	DASHBOARD	1.9 16v CDTI (02-..)	VDO IPC 0400
 Vectra-C	DASHBOARD	1.9 CDTI (02-..)	VDO IPC 0400
 Vectra-C	DASHBOARD	2.0 16v DTI (02-..)	VDO IPC 0400
 Vectra-C	DASHBOARD	2.0 T 16v (02-..)	VDO IPC 0400
 Vectra-C	DASHBOARD	2.2 16v (02-..)	VDO IPC 0400
 Vectra-C	DASHBOARD	2.2 16v DTI (02-..)	VDO IPC 0400
 Vectra-C	DASHBOARD	2.8 T V6 (02-..)	VDO IPC 0400
 Vectra-C	DASHBOARD	3.0 CDTI (02-..)	VDO IPC 0400
 Vectra-C	DASHBOARD	3.2 V6 (02-..)	VDO IPC 0400
 Vectra-C	ELECTRIC STEERING	1.6 (02-..)	TRW Automotive EHPS 0300
 Vectra-C	ELECTRIC STEERING	1.6 16v (02-..)	TRW Automotive EHPS 0300
 Vectra-C	ELECTRIC STEERING	1.8 16v (02-..)	TRW Automotive EHPS 0300
 Vectra-C	ELECTRIC STEERING	1.9 16v CDTI (02-..)	TRW Automotive EHPS 0300
 Vectra-C	ELECTRIC STEERING	1.9 CDTI (02-..)	TRW Automotive EHPS 0300
 Vectra-C	ELECTRIC STEERING	2.0 16v DTI (02-..)	TRW Automotive EHPS 0300

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Vectra-C	ELECTRIC STEERING	2.0 T 16v (02-..)	TRW Automotive EHPS 0300
 Vectra-C	ELECTRIC STEERING	2.2 16v (02-..)	TRW Automotive EHPS 0300
 Vectra-C	ELECTRIC STEERING	2.2 16v DTI (02-..)	TRW Automotive EHPS 0300
 Vectra-C	ELECTRIC STEERING	2.8 T V6 (02-..)	TRW Automotive EHPS 0300
 Vectra-C	ELECTRIC STEERING	3.0 CDTI (02-..)	TRW Automotive EHPS 0300
 Vectra-C	ELECTRIC STEERING	3.2 V6 (02-..)	TRW Automotive EHPS 0300
 Vectra-C	ENGINE MANAGEME	1.6	EOBD
 Vectra-C	ENGINE MANAGEME	1.6 16v	EOBD
 Vectra-C	ENGINE MANAGEME	1.8 16v Z18XER	SIEMENS MPI MS75
 Vectra-C	ENGINE MANAGEME	1.9 16v CDTI Z19DT	BOSCH EDC 16 Common Rail
 Vectra-C	ENGINE MANAGEME	1.9 CDTI Z19DTH	BOSCH EDC 16 Common Rail
 Vectra-C	ENGINE MANAGEME	2.0 T 16v	EOBD
 Vectra-C	ENGINE MANAGEME	2.2 16v	EOBD
 Vectra-C	ENGINE MANAGEME	2.2 16v Z22YH (02-..)	SIEMENS MPI
 Vectra-C	ENGINE MANAGEME	2.8 T V6	EOBD
 Vectra-C	ENGINE MANAGEME	3.0 CDTI (04-..)	EOBD
 Vectra-C	ENGINE MANAGEME	3.2 V6 Z32SE (02-..)	BOSCH MPI ME3.11C
 Vectra-C	HEADLIGHT LEVEL	3.2 V6 (02-..)	AHL-AFL
 Vectra-C	MAINTENANCE	1.6	MANUAL
 Vectra-C	MAINTENANCE	1.6 16v	MANUAL
 Vectra-C	MAINTENANCE	1.8 16v	MANUAL
 Vectra-C	MAINTENANCE	1.8 16v Z18XER	SIEMENS MPI MS75
 Vectra-C	MAINTENANCE	1.9 16v CDTI	MANUAL
 Vectra-C	MAINTENANCE	1.9 CDTI	MANUAL
 Vectra-C	MAINTENANCE	2.0 16v DTI	MANUAL
 Vectra-C	MAINTENANCE	2.0 T 16v	MANUAL
 Vectra-C	MAINTENANCE	2.2 16v	MANUAL
 Vectra-C	MAINTENANCE	2.2 16v DTI	MANUAL
 Vectra-C	MAINTENANCE	2.2 16v Z22YH (02-..)	SIEMENS MPI
 Vectra-C	MAINTENANCE	2.8 T V6	MANUAL
 Vectra-C	MAINTENANCE	3.0 CDTI	MANUAL
 Vectra-C	MAINTENANCE	3.2 V6	MANUAL
 Vectra-C	MAINTENANCE	3.2 V6 Z32SE (02-..)	BOSCH MPI ME3.11C
 Vectra-C	MAINTENANCE	3.2 V6 Z32SE (02-..)	BOSCH MPI ME3.11C
 Vectra-C	PARKING HELP	1.6	PAS
 Vectra-C	PARKING HELP	1.6 16v	PAS
 Vectra-C	PARKING HELP	1.8 16v	PAS
 Vectra-C	PARKING HELP	1.9 16v CDTI	PAS
 Vectra-C	PARKING HELP	1.9 CDTI	PAS
 Vectra-C	PARKING HELP	2.0 16v DTI	PAS
 Vectra-C	PARKING HELP	2.0 T 16v	PAS
 Vectra-C	PARKING HELP	2.2 16v	PAS
 Vectra-C	PARKING HELP	2.2 16v DTI	PAS
 Vectra-C	PARKING HELP	2.8 T V6	PAS
 Vectra-C	PARKING HELP	3.0 CDTI	PAS
 Vectra-C	PARKING HELP	3.2 V6 (02-..)	PAS
 Vectra-C	SERVICE LIGHT RES	1.6	MANUAL
 Vectra-C	SERVICE LIGHT RES	1.6 16v	MANUAL
 Vectra-C	SERVICE LIGHT RES	1.8 16v	MANUAL
 Vectra-C	SERVICE LIGHT RES	1.9 16v CDTI	MANUAL
 Vectra-C	SERVICE LIGHT RES	1.9 CDTI	MANUAL
 Vectra-C	SERVICE LIGHT RES	2.0 16v DTI	MANUAL
 Vectra-C	SERVICE LIGHT RES	2.0 T 16v	MANUAL
 Vectra-C	SERVICE LIGHT RES	2.2 16v	MANUAL
 Vectra-C	SERVICE LIGHT RES	2.2 16v DTI	MANUAL
 Vectra-C	SERVICE LIGHT RES	2.8 T V6	MANUAL
 Vectra-C	SERVICE LIGHT RES	3.0 CDTI	MANUAL
 Vectra-C	SERVICE LIGHT RES	3.2 V6	MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Vectra-C	VISUAL./TELEMATIC	1.6 (02-..)	TID
 Vectra-C	VISUAL./TELEMATIC	1.6 16v (02-..)	TID
 Vectra-C	VISUAL./TELEMATIC	1.8 16v (02-..)	TID
 Vectra-C	VISUAL./TELEMATIC	1.9 16v CDTI (02-..)	TID
 Vectra-C	VISUAL./TELEMATIC	1.9 CDTI (02-..)	TID
 Vectra-C	VISUAL./TELEMATIC	2.0 16v DTI (02-..)	TID
 Vectra-C	VISUAL./TELEMATIC	2.0 T 16v (02-..)	TID
 Vectra-C	VISUAL./TELEMATIC	2.2 16v (02-..)	TID
 Vectra-C	VISUAL./TELEMATIC	2.2 16v DTI (02-..)	TID
 Vectra-C	VISUAL./TELEMATIC	2.8 T V6 (02-..)	TID
 Vectra-C	VISUAL./TELEMATIC	3.0 CDTI (02-..)	TID
 Vectra-C	VISUAL./TELEMATIC	3.2 V6 (02-..)	TID
 Vivaro	ABS + TRACT. CONT	1.9 dTi 74kw (07-..)	ABS
 Vivaro	ABS + TRACT. CONT	2.0 16v 117cv (07-..)	ABS
 Vivaro	ABS + TRACT. CONT	2.0 CDTI 114 (07-..)	ABS
 Vivaro	ABS + TRACT. CONT	2.0 CDTI 90 (07-..)	ABS
 Vivaro	ABS + TRACT. CONT	2.5 CDTI 146 (07-..)	ABS
 Vivaro	AIRBAG	1.9 DI (02-06)	SAGEM - Autoliv AirBag ACU x.x
 Vivaro	AIRBAG	1.9 dTi 74kw (02-06)	SAGEM - Autoliv AirBag ACU x.x
 Vivaro	AIRBAG	2.0 16v 117cv (02-06)	SAGEM - Autoliv AirBag ACU x.x
 Vivaro	AIRBAG	2.0 CDTI 114 (02-06)	SAGEM - Autoliv AirBag ACU x.x
 Vivaro	AIRBAG	2.0 CDTI 90 (02-06)	SAGEM - Autoliv AirBag ACU x.x
 Vivaro	AIRBAG	2.5 CDTI 146 (02-06)	SAGEM - Autoliv AirBag ACU x.x
 Vivaro	AIRBAG	2.5 DTI (03-06)	SAGEM - Autoliv AirBag ACU x.x
 Vivaro	CHASSIS NETWORK	1.9 dTi 74kw (07-..)	Body Computer
 Vivaro	CHASSIS NETWORK	2.0 16v 117cv (07-..)	Body Computer
 Vivaro	CHASSIS NETWORK	2.0 CDTI 114 (07-..)	Body Computer
 Vivaro	CHASSIS NETWORK	2.0 CDTI 90 (07-..)	Body Computer
 Vivaro	CHASSIS NETWORK	2.5 CDTI 146 (07-..)	Body Computer
 Vivaro	ENGINE MANAGEME	1.9 DI (04-06)	EOBD
 Vivaro	ENGINE MANAGEME	1.9 dTi 74kw (04-06)	EOBD
 Vivaro	ENGINE MANAGEME	1.9 dTi 74kw (07-..)	EOBD
 Vivaro	ENGINE MANAGEME	2.0 16v 117cv (07-..)	EOBD
 Vivaro	ENGINE MANAGEME	2.0 CDTI 114 (07-..)	EOBD
 Vivaro	ENGINE MANAGEME	2.0 CDTI 90 (07-..)	EOBD
 Vivaro	ENGINE MANAGEME	2.5 DTI (04-06)	EOBD
 Vivaro	MAINTENANCE	1.9 dTi 74kw (07-..)	ABS
 Vivaro	MAINTENANCE	1.9 dTi 74kw (07-..)	MANUAL
 Vivaro	MAINTENANCE	2.0 16v 117cv (07-..)	ABS
 Vivaro	MAINTENANCE	2.0 16v 117cv (07-..)	MANUAL
 Vivaro	MAINTENANCE	2.0 CDTI 114 (07-..)	ABS
 Vivaro	MAINTENANCE	2.0 CDTI 114 (07-..)	MANUAL
 Vivaro	MAINTENANCE	2.0 CDTI 90 (07-..)	ABS
 Vivaro	MAINTENANCE	2.0 CDTI 90 (07-..)	MANUAL
 Vivaro	MAINTENANCE	2.5 CDTI 146 (07-..)	ABS
 Vivaro	MAINTENANCE	2.5 CDTI 146 (07-..)	MANUAL
 Vivaro	RADIO / CD	1.9 dTi 74kw (07-..)	EHU Audio Ear
 Vivaro	RADIO / CD	2.0 16v 117cv (07-..)	EHU Audio Ear
 Vivaro	RADIO / CD	2.0 CDTI 114 (07-..)	EHU Audio Ear
 Vivaro	RADIO / CD	2.0 CDTI 90 (07-..)	EHU Audio Ear
 Vivaro	RADIO / CD	2.5 CDTI 146 (07-..)	EHU Audio Ear
 Vivaro	SERVICE LIGHT RES	1.9 dTi 74kw (07-..)	MANUAL
 Vivaro	SERVICE LIGHT RES	2.0 16v 117cv (07-..)	MANUAL
 Vivaro	SERVICE LIGHT RES	2.0 CDTI 114 (07-..)	MANUAL
 Vivaro	SERVICE LIGHT RES	2.0 CDTI 90 (07-..)	MANUAL
 Vivaro	SERVICE LIGHT RES	2.5 CDTI 146 (07-..)	MANUAL
 Vivaro	VISUAL./TELEMATIC	1.9 dTi 74kw (07-..)	Display
 Vivaro	VISUAL./TELEMATIC	2.0 16v 117cv (07-..)	Display

Systems supported by ECUREADER / ECUDECODER (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Vivaro	VISUAL./TELEMATIC	2.0 CDTI 114 (07-..)	Display
 Vivaro	VISUAL./TELEMATIC	2.0 CDTI 90 (07-..)	Display
 Vivaro	VISUAL./TELEMATIC	2.5 CDTI 146 (07-..)	Display
 Zafira	ABS	1.6 16v	BOSCH ABS 5.3/5.4(+TC)
 Zafira	ABS	1.6 16v ECO M	BOSCH ABS 5.3/5.4(+TC)
 Zafira	ABS	1.7 16v CDTI	BOSCH ABS 5.3/5.4(+TC)
 Zafira	ABS	1.8 16v	BOSCH ABS 5.3/5.4(+TC)
 Zafira	ABS	2.0 DI (99-..)	BOSCH ABS 5.3/5.4(+TC)
 Zafira	ABS	2.0 DTI 16v	BOSCH ABS 5.3/5.4(+TC)
 Zafira	ABS	2.0 turbo 16v	BOSCH ABS 5.3/5.4(+TC)
 Zafira	ABS	2.2 (99-..)	BOSCH ABS 5.3/5.4(+TC)
 Zafira	ABS	2.2 16v DTI	BOSCH ABS 5.3/5.4(+TC)
 Zafira	AIRBAG	1.6 16v (...00)	SIEMENS AirBag SAB6
 Zafira	AIRBAG	1.6 16v (01-..)	SIEMENS AirBag SAB8x
 Zafira	AIRBAG	1.6 16v ECO M (...00)	SIEMENS AirBag SAB6
 Zafira	AIRBAG	1.6 16v ECO M (01-..)	SIEMENS AirBag SAB8x
 Zafira	AIRBAG	1.7 16v CDTI (...00)	SIEMENS AirBag SAB6
 Zafira	AIRBAG	1.7 16v CDTI (01-..)	SIEMENS AirBag SAB8x
 Zafira	AIRBAG	1.8 16v (...00)	SIEMENS AirBag SAB6
 Zafira	AIRBAG	1.8 16v (01-..)	SIEMENS AirBag SAB8x
 Zafira	AIRBAG	2.0 DI (...00)	SIEMENS AirBag SAB6
 Zafira	AIRBAG	2.0 DI (01-..)	SIEMENS AirBag SAB8x
 Zafira	AIRBAG	2.0 DTI 16v (...00)	SIEMENS AirBag SAB6
 Zafira	AIRBAG	2.0 DTI 16v (01-..)	SIEMENS AirBag SAB8x
 Zafira	AIRBAG	2.0 turbo 16v (...00)	SIEMENS AirBag SAB6
 Zafira	AIRBAG	2.0 turbo 16v (01-..)	SIEMENS AirBag SAB8x
 Zafira	AIRBAG	2.2 (...00)	SIEMENS AirBag SAB6
 Zafira	AIRBAG	2.2 (01-..)	SIEMENS AirBag SAB8x
 Zafira	AIRBAG	2.2 16v DTI (...00)	SIEMENS AirBag SAB6
 Zafira	AIRBAG	2.2 16v DTI (01-..)	SIEMENS AirBag SAB8x
 Zafira	AUTOM. TRANSMISSI	1.6 16v ECO M	
 Zafira	AUTOM. TRANSMISSI	1.7 16v CDTI	
 Zafira	AUTOM. TRANSMISSI	1.8 16v	
 Zafira	AUTOM. TRANSMISSI	2.0 DI	
 Zafira	AUTOM. TRANSMISSI	2.0 DTI 16v	
 Zafira	AUTOM. TRANSMISSI	2.0 turbo 16v	
 Zafira	AUTOM. TRANSMISSI	2.2	
 Zafira	AUTOM. TRANSMISSI	2.2 16v DTI	
 Zafira	DASHBOARD	1.6 16v	
 Zafira	DASHBOARD	1.6 16v (02-..)	Instrument Cluster
 Zafira	DASHBOARD	1.6 16v ECO M (02-..)	Instrument Cluster
 Zafira	DASHBOARD	1.7 16v CDTI (02-..)	Instrument Cluster
 Zafira	DASHBOARD	1.8 16v (02-..)	Instrument Cluster
 Zafira	DASHBOARD	2.0 DI (02-..)	Instrument Cluster
 Zafira	DASHBOARD	2.0 DTI 16v (02-..)	Instrument Cluster
 Zafira	DASHBOARD	2.0 turbo 16v (02-..)	Instrument Cluster
 Zafira	DASHBOARD	2.2 (02-..)	Instrument Cluster
 Zafira	DASHBOARD	2.2 16v DTI (02-..)	Instrument Cluster
 Zafira	ENGINE COOLING	1.6 16v (98-..)	BOSCH xx
 Zafira	ENGINE COOLING	1.6 16v ECO M (98-..)	BOSCH xx
 Zafira	ENGINE COOLING	1.7 16v CDTI (98-..)	BOSCH xx
 Zafira	ENGINE COOLING	1.8 16v (98-..)	BOSCH xx
 Zafira	ENGINE COOLING	2.0 DI (98-..)	BOSCH xx
 Zafira	ENGINE COOLING	2.0 DTI 16v (98-..)	BOSCH xx
 Zafira	ENGINE COOLING	2.0 turbo 16v (98-..)	BOSCH xx
 Zafira	ENGINE COOLING	2.2 (98-..)	BOSCH xx
 Zafira	ENGINE COOLING	2.2 16v DTI (98-..)	BOSCH xx
 Zafira	ENGINE MANAGEME	1.6 16v ECO M Z16YNG (01-..)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Zafira	ENGINE MANAGEME	1.6 16v X16XEL (98-00)	GM Multec H
 Zafira	ENGINE MANAGEME	1.6 16v Z16XE (01-..)	EOBD
 Zafira	ENGINE MANAGEME	1.7 16v CDTI Z17DTH (04-..)	BOSCH EDC 16 Common Rail
 Zafira	ENGINE MANAGEME	1.8 16v X18XE1 (98-00)	SIEMENS Simtec 70
 Zafira	ENGINE MANAGEME	1.8 16v Z18XE (01-..)	EOBD
 Zafira	ENGINE MANAGEME	2.0 DI (04-..)	EOBD
 Zafira	ENGINE MANAGEME	2.0 DTI 16v X20DTL (99-00)	BOSCH EDC MSA 15 M
 Zafira	ENGINE MANAGEME	2.0 DTI 16v Y20DTH (00-01)	BOSCH EDC MSA 15 M
 Zafira	ENGINE MANAGEME	2.0 turbo 16v Z20LET (01-..)	EOBD
 Zafira	ENGINE MANAGEME	2.2 (01-..)	EOBD
 Zafira	ENGINE MANAGEME	2.2 16v DTI Y22DTR (02-..)	BOSCH EDC
 Zafira	IMMOBILIZER	1.6 16v (99-..)	SIEMENS
 Zafira	IMMOBILIZER	1.6 16v ECO M (99-..)	SIEMENS
 Zafira	IMMOBILIZER	1.7 16v CDTI (99-..)	SIEMENS
 Zafira	IMMOBILIZER	1.8 16v (99-..)	SIEMENS
 Zafira	IMMOBILIZER	2.0 DI (99-..)	SIEMENS
 Zafira	IMMOBILIZER	2.0 DTI 16v (99-..)	SIEMENS
 Zafira	IMMOBILIZER	2.0 turbo 16v (99-..)	SIEMENS
 Zafira	IMMOBILIZER	2.2 (99-..)	SIEMENS
 Zafira	IMMOBILIZER	2.2 16v DTI (99-..)	SIEMENS
 Zafira	MAINTENANCE	1.6 16v (02-..)	Instrument Cluster
 Zafira	MAINTENANCE	1.6 16v (98-00)	GM MANUAL
 Zafira	MAINTENANCE	1.6 16v ECO M (02-..)	Instrument Cluster
 Zafira	MAINTENANCE	1.6 16v ECO M (98-00)	GM MANUAL
 Zafira	MAINTENANCE	1.7 16v CDTI (02-..)	Instrument Cluster
 Zafira	MAINTENANCE	1.7 16v CDTI (98-00)	GM MANUAL
 Zafira	MAINTENANCE	1.8 16v (02-..)	Instrument Cluster
 Zafira	MAINTENANCE	1.8 16v (98-00)	GM MANUAL
 Zafira	MAINTENANCE	2.0 DI (02-..)	Instrument Cluster
 Zafira	MAINTENANCE	2.0 DI (98-00)	GM MANUAL
 Zafira	MAINTENANCE	2.0 DTI 16v (02-..)	Instrument Cluster
 Zafira	MAINTENANCE	2.0 DTI 16v (98-00)	GM MANUAL
 Zafira	MAINTENANCE	2.0 turbo 16v (02-..)	Instrument Cluster
 Zafira	MAINTENANCE	2.0 turbo 16v (98-00)	GM MANUAL
 Zafira	MAINTENANCE	2.2 (02-..)	Instrument Cluster
 Zafira	MAINTENANCE	2.2 (98-00)	GM MANUAL
 Zafira	MAINTENANCE	2.2 16v DTI (02-..)	Instrument Cluster
 Zafira	MAINTENANCE	2.2 16v DTI (98-00)	GM MANUAL
 Zafira	SERVICE LIGHT RES	1.6 16v (98-00)	GM MANUAL
 Zafira	SERVICE LIGHT RES	1.6 16v ECO M (98-00)	GM MANUAL
 Zafira	SERVICE LIGHT RES	1.7 16v CDTI (98-00)	GM MANUAL
 Zafira	SERVICE LIGHT RES	1.8 16v (98-00)	GM MANUAL
 Zafira	SERVICE LIGHT RES	2.0 DI (98-00)	GM MANUAL
 Zafira	SERVICE LIGHT RES	2.0 DTI 16v (98-00)	GM MANUAL
 Zafira	SERVICE LIGHT RES	2.0 turbo 16v (98-00)	GM MANUAL
 Zafira	SERVICE LIGHT RES	2.2 (98-00)	GM MANUAL
 Zafira	SERVICE LIGHT RES	2.2 16v DTI (98-00)	GM MANUAL
 Zafira-B	ABS	1.6 16v (04-..)	TEVES ABS Mk70
 Zafira-B	ABS	1.7 16v CDTI (04-..)	TEVES ABS Mk70
 Zafira-B	ABS	1.8 16v (04-..)	TEVES ABS Mk70
 Zafira-B	ABS	1.9 16v CDTI (04-..)	TEVES ABS Mk70
 Zafira-B	ABS	1.9 16v CDTI FAP (04-..)	TEVES ABS Mk70
 Zafira-B	ABS	1.9 8v CDTI (04-..)	TEVES ABS Mk70
 Zafira-B	ABS	2.0 T 16v (04-..)	TEVES ABS Mk70
 Zafira-B	ABS	2.2 16v (04-..)	TEVES ABS Mk70
 Zafira-B	AIRBAG	1.6 16v (04-..)	TEMIC AirBag MRSZ
 Zafira-B	AIRBAG	1.8 16v (04-..)	TEMIC AirBag MRSZ
 Zafira-B	AIRBAG	1.9 16v CDTI (04-..)	TEMIC AirBag MRSZ

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Zafira-B	AIRBAG	1.9 16v CDTI (04-..)	TEMIC AirBag MRSZ
 Zafira-B	AIRBAG	1.9 16v CDTI FAP (04-..)	TEMIC AirBag MRSZ
 Zafira-B	AIRBAG	1.9 8v CDTI (04-..)	TEMIC AirBag MRSZ
 Zafira-B	AIRBAG	2.0 T 16v (04-..)	TEMIC AirBag MRSZ
 Zafira-B	AIRBAG	2.2 16v (04-..)	TEMIC AirBag MRSZ
 Zafira-B	AUTOM. TRANSMISSI	1.6 16v (04-..)	AISIN AF40-6
 Zafira-B	AUTOM. TRANSMISSI	1.7 16v CDTI (04-..)	AISIN AF40-6
 Zafira-B	AUTOM. TRANSMISSI	1.8 16v (04-..)	AISIN AF40-6
 Zafira-B	AUTOM. TRANSMISSI	1.9 16v CDTI (04-..)	AISIN AF40-6
 Zafira-B	AUTOM. TRANSMISSI	1.9 8v CDTI (04-..)	AISIN AF40-6
 Zafira-B	AUTOM. TRANSMISSI	2.0 T 16v (04-..)	AISIN AF40-6
 Zafira-B	AUTOM. TRANSMISSI	2.2 16v (04-..)	AISIN AF40-6
 Zafira-B	CHASSIS NETWORK	1.6 16v (04-..)	EUC Front Module
 Zafira-B	CHASSIS NETWORK	1.6 16v (04-..)	REC Rear Module
 Zafira-B	CHASSIS NETWORK	1.7 16v CDTI (04-..)	EUC Front Module
 Zafira-B	CHASSIS NETWORK	1.7 16v CDTI (04-..)	REC Rear Module
 Zafira-B	CHASSIS NETWORK	1.8 16v (04-..)	EUC Front Module
 Zafira-B	CHASSIS NETWORK	1.8 16v (04-..)	REC Rear Module
 Zafira-B	CHASSIS NETWORK	1.9 16v CDTI (04-..)	EUC Front Module
 Zafira-B	CHASSIS NETWORK	1.9 16v CDTI (04-..)	REC Rear Module
 Zafira-B	CHASSIS NETWORK	1.9 16v CDTI FAP (04-..)	EUC Front Module
 Zafira-B	CHASSIS NETWORK	1.9 16v CDTI FAP (04-..)	REC Rear Module
 Zafira-B	CHASSIS NETWORK	1.9 8v CDTI (04-..)	EUC Front Module
 Zafira-B	CHASSIS NETWORK	1.9 8v CDTI (04-..)	REC Rear Module
 Zafira-B	CHASSIS NETWORK	2.0 T 16v (04-..)	EUC Front Module
 Zafira-B	CHASSIS NETWORK	2.0 T 16v (04-..)	REC Rear Module
 Zafira-B	CHASSIS NETWORK	2.2 16v (04-..)	EUC Front Module
 Zafira-B	CHASSIS NETWORK	2.2 16v (04-..)	REC Rear Module
 Zafira-B	DASHBOARD	1.6 16v (04-..)	Dashboard
 Zafira-B	DASHBOARD	1.7 16v CDTI (04-..)	Dashboard
 Zafira-B	DASHBOARD	1.8 16v (04-..)	Dashboard
 Zafira-B	DASHBOARD	1.9 16v CDTI (04-..)	Dashboard
 Zafira-B	DASHBOARD	1.9 16v CDTI FAP (04-..)	Dashboard
 Zafira-B	DASHBOARD	1.9 8v CDTI (04-..)	Dashboard
 Zafira-B	DASHBOARD	2.0 T 16v (04-..)	Dashboard
 Zafira-B	DASHBOARD	2.2 16v (04-..)	Dashboard
 Zafira-B	ENGINE MANAGEME	1.6 16v Z16XER (04-..)	SIEMENS MPI MS75
 Zafira-B	ENGINE MANAGEME	1.7 16v CDTI (04-..)	EOBD
 Zafira-B	ENGINE MANAGEME	1.8 16v (04-..)	EOBD
 Zafira-B	ENGINE MANAGEME	1.8 16v Z18XER (04-..)	SIEMENS MPI MS75
 Zafira-B	ENGINE MANAGEME	1.9 16v CDTI Z19DTH (04-..)	BOSCH EDC 16 Common Rail
 Zafira-B	ENGINE MANAGEME	1.9 16v CDTI Z19DTH-FAP (06-..)	BOSCH EDC 16 Common Rail FAP
 Zafira-B	ENGINE MANAGEME	1.9 8v CDTI Z19DT (04-..)	BOSCH EDC 16 Common Rail
 Zafira-B	ENGINE MANAGEME	1.9 8v CDTI Z19DT-FAP (06-..)	BOSCH EDC 16 Common Rail FAP
 Zafira-B	ENGINE MANAGEME	2.0 T 16v (04-..)	EOBD
 Zafira-B	ENGINE MANAGEME	2.2 16v (04-..)	EOBD
 Zafira-B	KEY ENCODE	1.6 16v (04-..)	Valeo CIM
 Zafira-B	KEY ENCODE	1.7 16v CDTI (04-..)	Valeo CIM
 Zafira-B	KEY ENCODE	1.8 16v (04-..)	Valeo CIM
 Zafira-B	KEY ENCODE	1.9 16v CDTI (04-..)	Valeo CIM
 Zafira-B	KEY ENCODE	1.9 16v CDTI FAP (04-..)	Valeo CIM
 Zafira-B	KEY ENCODE	1.9 8v CDTI (04-..)	Valeo CIM
 Zafira-B	KEY ENCODE	2.0 T 16v (04-..)	Valeo CIM
 Zafira-B	KEY ENCODE	2.2 16v (04-..)	Valeo CIM
 Zafira-B	MAINTENANCE	1.6 16v (04-..)	Dashboard
 Zafira-B	MAINTENANCE	1.6 16v (04-..)	Dashboard
 Zafira-B	MAINTENANCE	1.6 16v (04-..)	Dashboard
 Zafira-B	MAINTENANCE	1.6 16v (04-..)	MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Zafira-B	MAINTENANCE	1.6 16v Z16XER (04-..)	SIEMENS MPI MS75
 Zafira-B	MAINTENANCE	1.7 16v CDTI (04-..)	Dashboard
 Zafira-B	MAINTENANCE	1.7 16v CDTI (04-..)	Dashboard
 Zafira-B	MAINTENANCE	1.7 16v CDTI (04-..)	Dashboard
 Zafira-B	MAINTENANCE	1.7 16v CDTI (04-..)	MANUAL
 Zafira-B	MAINTENANCE	1.8 16v (04-..)	Dashboard
 Zafira-B	MAINTENANCE	1.8 16v (04-..)	Dashboard
 Zafira-B	MAINTENANCE	1.8 16v (04-..)	Dashboard
 Zafira-B	MAINTENANCE	1.8 16v (04-..)	MANUAL
 Zafira-B	MAINTENANCE	1.8 16v Z18XER (04-..)	SIEMENS MPI MS75
 Zafira-B	MAINTENANCE	1.9 16v CDTI (04-..)	Dashboard
 Zafira-B	MAINTENANCE	1.9 16v CDTI (04-..)	Dashboard
 Zafira-B	MAINTENANCE	1.9 16v CDTI (04-..)	Dashboard
 Zafira-B	MAINTENANCE	1.9 16v CDTI (04-..)	MANUAL
 Zafira-B	MAINTENANCE	1.9 16v CDTI FAP (04-..)	Dashboard
 Zafira-B	MAINTENANCE	1.9 16v CDTI FAP (04-..)	Dashboard
 Zafira-B	MAINTENANCE	1.9 16v CDTI FAP (04-..)	Dashboard
 Zafira-B	MAINTENANCE	1.9 16v CDTI FAP (04-..)	MANUAL
 Zafira-B	MAINTENANCE	1.9 16v CDTI Z19DTH-FAP (06-..)	BOSCH EDC 16 Common Rail FAP
 Zafira-B	MAINTENANCE	1.9 16v CDTI Z19DTH-FAP (06-..)	BOSCH EDC 16 Common Rail FAP
 Zafira-B	MAINTENANCE	1.9 16v CDTI Z19DTH-FAP (06-..)	BOSCH EDC 16 Common Rail FAP
 Zafira-B	MAINTENANCE	1.9 8v CDTI (04-..)	Dashboard
 Zafira-B	MAINTENANCE	1.9 8v CDTI (04-..)	Dashboard
 Zafira-B	MAINTENANCE	1.9 8v CDTI (04-..)	Dashboard
 Zafira-B	MAINTENANCE	1.9 8v CDTI (04-..)	MANUAL
 Zafira-B	MAINTENANCE	1.9 8v CDTI Z19DT-FAP (06-..)	BOSCH EDC 16 Common Rail FAP
 Zafira-B	MAINTENANCE	1.9 8v CDTI Z19DT-FAP (06-..)	BOSCH EDC 16 Common Rail FAP
 Zafira-B	MAINTENANCE	1.9 8v CDTI Z19DT-FAP (06-..)	BOSCH EDC 16 Common Rail FAP
 Zafira-B	MAINTENANCE	2.0 T 16v (04-..)	Dashboard
 Zafira-B	MAINTENANCE	2.0 T 16v (04-..)	Dashboard
 Zafira-B	MAINTENANCE	2.0 T 16v (04-..)	Dashboard
 Zafira-B	MAINTENANCE	2.0 T 16v (04-..)	MANUAL
 Zafira-B	MAINTENANCE	2.2 16v (04-..)	Dashboard
 Zafira-B	MAINTENANCE	2.2 16v (04-..)	Dashboard
 Zafira-B	MAINTENANCE	2.2 16v (04-..)	Dashboard
 Zafira-B	MAINTENANCE	2.2 16v (04-..)	MANUAL
 Zafira-B	SERVICE LIGHT RES	1.6 16v (04-..)	MANUAL
 Zafira-B	SERVICE LIGHT RES	1.7 16v CDTI (04-..)	MANUAL
 Zafira-B	SERVICE LIGHT RES	1.8 16v (04-..)	MANUAL
 Zafira-B	SERVICE LIGHT RES	1.9 16v CDTI (04-..)	MANUAL
 Zafira-B	SERVICE LIGHT RES	1.9 16v CDTI FAP (04-..)	MANUAL
 Zafira-B	SERVICE LIGHT RES	1.9 8v CDTI (04-..)	MANUAL
 Zafira-B	SERVICE LIGHT RES	2.0 T 16v (04-..)	MANUAL
 Zafira-B	SERVICE LIGHT RES	2.2 16v (04-..)	MANUAL
 Zafira-B	STEERING WHEEL E	1.6 16v (04-..)	Valeo CIM
 Zafira-B	STEERING WHEEL E	1.7 16v CDTI (04-..)	Valeo CIM
 Zafira-B	STEERING WHEEL E	1.8 16v (04-..)	Valeo CIM
 Zafira-B	STEERING WHEEL E	1.9 16v CDTI (04-..)	Valeo CIM
 Zafira-B	STEERING WHEEL E	1.9 16v CDTI FAP (04-..)	Valeo CIM
 Zafira-B	STEERING WHEEL E	1.9 8v CDTI (04-..)	Valeo CIM
 Zafira-B	STEERING WHEEL E	2.0 T 16v (04-..)	Valeo CIM
 Zafira-B	STEERING WHEEL E	2.2 16v (04-..)	Valeo CIM

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 1007	ABS	1.1 44kw HFX	TEVES ABS MK70
 1007	ABS	1.1 44kw HFX	TEVES ABS MK70 2
 1007	ABS	1.4 16v 65kw KFU	TEVES ABS MK70
 1007	ABS	1.4 16v 65kw KFU	TEVES ABS MK70 2
 1007	ABS	1.4 55kw KFU	TEVES ABS MK70
 1007	ABS	1.4 55kw KFU	TEVES ABS MK70 2
 1007	ABS	1.4 55kw KFW	TEVES ABS MK70
 1007	ABS	1.4 55kw KFW	TEVES ABS MK70 2
 1007	ABS	1.4 HDI 50kw 8HX	TEVES ABS MK70
 1007	ABS	1.4 HDI 50kw 8HX	TEVES ABS MK70 2
 1007	ABS	1.4 HDI 50kw 8HZ	TEVES ABS MK70
 1007	ABS	1.4 HDI 50kw 8HZ	TEVES ABS MK70 2
 1007	ABS	1.6 16v 80kw NFU	TEVES ABS MK70
 1007	ABS	1.6 16v 80kw NFU	TEVES ABS MK70 2
 1007	ABS	1.6 HDI 16v 80kw 9HZ-FAP	TEVES ABS MK70
 1007	ABS	1.6 HDI 16v 80kw 9HZ-FAP	TEVES ABS MK70 2
 1007	ABS + TRACT. CONT	1.1 44kw HFX	ATE-TEVES ABS+ESP Mk60
 1007	ABS + TRACT. CONT	1.1 44kw HFX	TEVES ABS MK60 2
 1007	ABS + TRACT. CONT	1.1 44kw HFX	Var.1
 1007	ABS + TRACT. CONT	1.1 44kw HFX	Var.2
 1007	ABS + TRACT. CONT	1.4 16v 65kw KFU	ATE-TEVES ABS+ESP Mk60
 1007	ABS + TRACT. CONT	1.4 16v 65kw KFU	TEVES ABS MK60 2
 1007	ABS + TRACT. CONT	1.4 16v 65kw KFU	Var.1
 1007	ABS + TRACT. CONT	1.4 16v 65kw KFU	Var.2
 1007	ABS + TRACT. CONT	1.4 55kw KFU	ATE-TEVES ABS+ESP Mk60
 1007	ABS + TRACT. CONT	1.4 55kw KFU	TEVES ABS MK60 2
 1007	ABS + TRACT. CONT	1.4 55kw KFU	Var.1
 1007	ABS + TRACT. CONT	1.4 55kw KFU	Var.2
 1007	ABS + TRACT. CONT	1.4 55kw KFW	ATE-TEVES ABS+ESP Mk60
 1007	ABS + TRACT. CONT	1.4 55kw KFW	TEVES ABS MK60 2
 1007	ABS + TRACT. CONT	1.4 55kw KFW	Var.1
 1007	ABS + TRACT. CONT	1.4 55kw KFW	Var.2
 1007	ABS + TRACT. CONT	1.4 HDI 50kw 8HX	ATE-TEVES ABS+ESP Mk60
 1007	ABS + TRACT. CONT	1.4 HDI 50kw 8HX	TEVES ABS MK60 2
 1007	ABS + TRACT. CONT	1.4 HDI 50kw 8HX	Var.1
 1007	ABS + TRACT. CONT	1.4 HDI 50kw 8HX	Var.2
 1007	ABS + TRACT. CONT	1.4 HDI 50kw 8HZ	ATE-TEVES ABS+ESP Mk60
 1007	ABS + TRACT. CONT	1.4 HDI 50kw 8HZ	TEVES ABS MK60 2
 1007	ABS + TRACT. CONT	1.4 HDI 50kw 8HZ	Var.1
 1007	ABS + TRACT. CONT	1.4 HDI 50kw 8HZ	Var.2
 1007	ABS + TRACT. CONT	1.6 16v 80kw NFU	ATE-TEVES ABS+ESP Mk60
 1007	ABS + TRACT. CONT	1.6 16v 80kw NFU	TEVES ABS MK60 2
 1007	ABS + TRACT. CONT	1.6 16v 80kw NFU	Var.1
 1007	ABS + TRACT. CONT	1.6 16v 80kw NFU	Var.2
 1007	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	ATE-TEVES ABS+ESP Mk60
 1007	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	TEVES ABS MK60 2
 1007	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 1007	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 1007	AIRBAG	1.1 44kw HFX	AirBag CENTRAL
 1007	AIRBAG	1.1 44kw HFX	AirBag CENTRAL CAN
 1007	AIRBAG	1.1 44kw HFX	AKF- Autoliv AirBag ACU3
 1007	AIRBAG	1.4 16v 65kw KFU	AirBag CENTRAL
 1007	AIRBAG	1.4 16v 65kw KFU	AirBag CENTRAL CAN
 1007	AIRBAG	1.4 16v 65kw KFU	AKF- Autoliv AirBag ACU3
 1007	AIRBAG	1.4 55kw KFU	AirBag CENTRAL
 1007	AIRBAG	1.4 55kw KFU	AirBag CENTRAL CAN
 1007	AIRBAG	1.4 55kw KFU	AKF- Autoliv AirBag ACU3
 1007	AIRBAG	1.4 55kw KFW	AirBag CENTRAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 1007	AIRBAG	1.4 55kw KFW	AirBag CENTRAL CAN
 1007	AIRBAG	1.4 55kw KFW	AKF- Autoliv AirBag ACU3
 1007	AIRBAG	1.4 HDI 50kw 8HX	AirBag CENTRAL
 1007	AIRBAG	1.4 HDI 50kw 8HX	AirBag CENTRAL CAN
 1007	AIRBAG	1.4 HDI 50kw 8HX	AKF- Autoliv AirBag ACU3
 1007	AIRBAG	1.4 HDI 50kw 8HZ	AirBag CENTRAL
 1007	AIRBAG	1.4 HDI 50kw 8HZ	AirBag CENTRAL CAN
 1007	AIRBAG	1.4 HDI 50kw 8HZ	AKF- Autoliv AirBag ACU3
 1007	AIRBAG	1.6 16v 80kw NFU	AirBag CENTRAL
 1007	AIRBAG	1.6 16v 80kw NFU	AirBag CENTRAL CAN
 1007	AIRBAG	1.6 16v 80kw NFU	AKF- Autoliv AirBag ACU3
 1007	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL
 1007	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL CAN
 1007	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP	AKF- Autoliv AirBag ACU3
 1007	ANTITHEFT	1.1 44kw HFX	Alarm PSA2 Var.1
 1007	ANTITHEFT	1.1 44kw HFX	Alarm PSA2 Var.2
 1007	ANTITHEFT	1.4 16v 65kw KFU	Alarm PSA2 Var.1
 1007	ANTITHEFT	1.4 16v 65kw KFU	Alarm PSA2 Var.2
 1007	ANTITHEFT	1.4 55kw KFU	Alarm PSA2 Var.1
 1007	ANTITHEFT	1.4 55kw KFU	Alarm PSA2 Var.2
 1007	ANTITHEFT	1.4 55kw KFW	Alarm PSA2 Var.1
 1007	ANTITHEFT	1.4 55kw KFW	Alarm PSA2 Var.2
 1007	ANTITHEFT	1.4 HDI 50kw 8HX	Alarm PSA2 Var.1
 1007	ANTITHEFT	1.4 HDI 50kw 8HX	Alarm PSA2 Var.2
 1007	ANTITHEFT	1.4 HDI 50kw 8HZ	Alarm PSA2 Var.1
 1007	ANTITHEFT	1.4 HDI 50kw 8HZ	Alarm PSA2 Var.2
 1007	ANTITHEFT	1.6 16v 80kw NFU	Alarm PSA2 Var.1
 1007	ANTITHEFT	1.6 16v 80kw NFU	Alarm PSA2 Var.2
 1007	ANTITHEFT	1.6 HDI 16v 80kw 9HZ-FAP	Alarm PSA2 Var.1
 1007	ANTITHEFT	1.6 HDI 16v 80kw 9HZ-FAP	Alarm PSA2 Var.2
 1007	AUTOM. TRANSMISSI	1.1 44kw HFX	Var.1
 1007	AUTOM. TRANSMISSI	1.1 44kw HFX	Var.2
 1007	AUTOM. TRANSMISSI	1.4 16v 65kw KFU	Var.1
 1007	AUTOM. TRANSMISSI	1.4 16v 65kw KFU	Var.2
 1007	AUTOM. TRANSMISSI	1.4 55kw KFU	Var.1
 1007	AUTOM. TRANSMISSI	1.4 55kw KFU	Var.2
 1007	AUTOM. TRANSMISSI	1.4 55kw KFW	Var.1
 1007	AUTOM. TRANSMISSI	1.4 55kw KFW	Var.2
 1007	AUTOM. TRANSMISSI	1.4 HDI 50kw 8HX	Var.1
 1007	AUTOM. TRANSMISSI	1.4 HDI 50kw 8HX	Var.2
 1007	AUTOM. TRANSMISSI	1.4 HDI 50kw 8HZ	Var.1
 1007	AUTOM. TRANSMISSI	1.4 HDI 50kw 8HZ	Var.2
 1007	AUTOM. TRANSMISSI	1.6 16v 80kw NFU	Var.1
 1007	AUTOM. TRANSMISSI	1.6 16v 80kw NFU	Var.2
 1007	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 1007	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 1007	CHASSIS NETWORK	1.1 44kw HFX	Body Computer BSI Var.1
 1007	CHASSIS NETWORK	1.1 44kw HFX	Body Computer BSI Var.2
 1007	CHASSIS NETWORK	1.1 44kw HFX	Body Computer BSM
 1007	CHASSIS NETWORK	1.1 44kw HFX	Body Computer BSR
 1007	CHASSIS NETWORK	1.1 44kw HFX	Var.1
 1007	CHASSIS NETWORK	1.1 44kw HFX	Var.2
 1007	CHASSIS NETWORK	1.1 44kw HFX	Var.3
 1007	CHASSIS NETWORK	1.1 44kw HFX	Var.4
 1007	CHASSIS NETWORK	1.4 16v 65kw KFU	Body Computer BSI Var.1
 1007	CHASSIS NETWORK	1.4 16v 65kw KFU	Body Computer BSI Var.2
 1007	CHASSIS NETWORK	1.4 16v 65kw KFU	Body Computer BSM
 1007	CHASSIS NETWORK	1.4 16v 65kw KFU	Body Computer BSR

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 1007	CHASSIS NETWORK	1.4 16v 65kw KFU	Var.1
 1007	CHASSIS NETWORK	1.4 16v 65kw KFU	Var.2
 1007	CHASSIS NETWORK	1.4 16v 65kw KFU	Var.3
 1007	CHASSIS NETWORK	1.4 16v 65kw KFU	Var.4
 1007	CHASSIS NETWORK	1.4 55kw KFV	Body Computer BSI Var.1
 1007	CHASSIS NETWORK	1.4 55kw KFV	Body Computer BSI Var.2
 1007	CHASSIS NETWORK	1.4 55kw KFV	Body Computer BSM
 1007	CHASSIS NETWORK	1.4 55kw KFV	Body Computer BSR
 1007	CHASSIS NETWORK	1.4 55kw KFV	Var.1
 1007	CHASSIS NETWORK	1.4 55kw KFV	Var.2
 1007	CHASSIS NETWORK	1.4 55kw KFV	Var.3
 1007	CHASSIS NETWORK	1.4 55kw KFV	Var.4
 1007	CHASSIS NETWORK	1.4 55kw KFW	Body Computer BSI Var.1
 1007	CHASSIS NETWORK	1.4 55kw KFW	Body Computer BSI Var.2
 1007	CHASSIS NETWORK	1.4 55kw KFW	Body Computer BSM
 1007	CHASSIS NETWORK	1.4 55kw KFW	Body Computer BSR
 1007	CHASSIS NETWORK	1.4 55kw KFW	Var.1
 1007	CHASSIS NETWORK	1.4 55kw KFW	Var.2
 1007	CHASSIS NETWORK	1.4 55kw KFW	Var.3
 1007	CHASSIS NETWORK	1.4 55kw KFW	Var.4
 1007	CHASSIS NETWORK	1.4 HDI 50kw 8HX	Body Computer BSI Var.1
 1007	CHASSIS NETWORK	1.4 HDI 50kw 8HX	Body Computer BSI Var.2
 1007	CHASSIS NETWORK	1.4 HDI 50kw 8HX	Body Computer BSM
 1007	CHASSIS NETWORK	1.4 HDI 50kw 8HX	Body Computer BSR
 1007	CHASSIS NETWORK	1.4 HDI 50kw 8HX	Var.1
 1007	CHASSIS NETWORK	1.4 HDI 50kw 8HX	Var.2
 1007	CHASSIS NETWORK	1.4 HDI 50kw 8HX	Var.3
 1007	CHASSIS NETWORK	1.4 HDI 50kw 8HX	Var.4
 1007	CHASSIS NETWORK	1.4 HDI 50kw 8HZ	Body Computer BSI Var.1
 1007	CHASSIS NETWORK	1.4 HDI 50kw 8HZ	Body Computer BSI Var.2
 1007	CHASSIS NETWORK	1.4 HDI 50kw 8HZ	Body Computer BSM
 1007	CHASSIS NETWORK	1.4 HDI 50kw 8HZ	Body Computer BSR
 1007	CHASSIS NETWORK	1.4 HDI 50kw 8HZ	Var.1
 1007	CHASSIS NETWORK	1.4 HDI 50kw 8HZ	Var.2
 1007	CHASSIS NETWORK	1.4 HDI 50kw 8HZ	Var.3
 1007	CHASSIS NETWORK	1.4 HDI 50kw 8HZ	Var.4
 1007	CHASSIS NETWORK	1.6 16v 80kw NFU	Body Computer BSI Var.1
 1007	CHASSIS NETWORK	1.6 16v 80kw NFU	Body Computer BSI Var.2
 1007	CHASSIS NETWORK	1.6 16v 80kw NFU	Body Computer BSM
 1007	CHASSIS NETWORK	1.6 16v 80kw NFU	Body Computer BSR
 1007	CHASSIS NETWORK	1.6 16v 80kw NFU	Var.1
 1007	CHASSIS NETWORK	1.6 16v 80kw NFU	Var.2
 1007	CHASSIS NETWORK	1.6 16v 80kw NFU	Var.3
 1007	CHASSIS NETWORK	1.6 16v 80kw NFU	Var.4
 1007	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSI Var.1
 1007	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSI Var.2
 1007	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSM
 1007	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSR
 1007	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 1007	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 1007	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Var.3
 1007	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Var.4
 1007	CLIMA	1.1 44kw HFX	CLIMA
 1007	CLIMA	1.1 44kw HFX	CLIMA AUTO
 1007	CLIMA	1.4 16v 65kw KFU	CLIMA
 1007	CLIMA	1.4 16v 65kw KFU	CLIMA AUTO
 1007	CLIMA	1.4 55kw KFV	CLIMA
 1007	CLIMA	1.4 55kw KFV	CLIMA AUTO

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 1007	CLIMA	1.4 55kw KFW	CLIMA
 1007	CLIMA	1.4 55kw KFW	CLIMA AUTO
 1007	CLIMA	1.4 HDI 50kw 8HX	CLIMA
 1007	CLIMA	1.4 HDI 50kw 8HX	CLIMA AUTO
 1007	CLIMA	1.4 HDI 50kw 8HZ	CLIMA
 1007	CLIMA	1.4 HDI 50kw 8HZ	CLIMA AUTO
 1007	CLIMA	1.6 16v 80kw NFU	CLIMA
 1007	CLIMA	1.6 16v 80kw NFU	CLIMA AUTO
 1007	CLIMA	1.6 HDI 16v 80kw 9HZ-FAP	CLIMA
 1007	CLIMA	1.6 HDI 16v 80kw 9HZ-FAP	CLIMA AUTO
 1007	COMFORT SYSTEM	1.1 44kw HFX	Phone Kit
 1007	COMFORT SYSTEM	1.1 44kw HFX	Var.1
 1007	COMFORT SYSTEM	1.1 44kw HFX	Var.2
 1007	COMFORT SYSTEM	1.4 16v 65kw KFU	Phone Kit
 1007	COMFORT SYSTEM	1.4 16v 65kw KFU	Var.1
 1007	COMFORT SYSTEM	1.4 16v 65kw KFU	Var.2
 1007	COMFORT SYSTEM	1.4 55kw KFU	Phone Kit
 1007	COMFORT SYSTEM	1.4 55kw KFU	Var.1
 1007	COMFORT SYSTEM	1.4 55kw KFU	Var.2
 1007	COMFORT SYSTEM	1.4 55kw KFW	Phone Kit
 1007	COMFORT SYSTEM	1.4 55kw KFW	Var.1
 1007	COMFORT SYSTEM	1.4 55kw KFW	Var.2
 1007	COMFORT SYSTEM	1.4 HDI 50kw 8HX	Phone Kit
 1007	COMFORT SYSTEM	1.4 HDI 50kw 8HX	Var.1
 1007	COMFORT SYSTEM	1.4 HDI 50kw 8HX	Var.2
 1007	COMFORT SYSTEM	1.4 HDI 50kw 8HZ	Phone Kit
 1007	COMFORT SYSTEM	1.4 HDI 50kw 8HZ	Var.1
 1007	COMFORT SYSTEM	1.4 HDI 50kw 8HZ	Var.2
 1007	COMFORT SYSTEM	1.6 16v 80kw NFU	Phone Kit
 1007	COMFORT SYSTEM	1.6 16v 80kw NFU	Var.1
 1007	COMFORT SYSTEM	1.6 16v 80kw NFU	Var.2
 1007	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HZ-FAP	Phone Kit
 1007	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 1007	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 1007	DASHBOARD	1.1 44kw HFX	
 1007	DASHBOARD	1.1 44kw HFX	
 1007	DASHBOARD	1.1 44kw HFX	SAGEM Dashboard
 1007	DASHBOARD	1.4 16v 65kw KFU	
 1007	DASHBOARD	1.4 16v 65kw KFU	
 1007	DASHBOARD	1.4 16v 65kw KFU	SAGEM Dashboard
 1007	DASHBOARD	1.4 55kw KFU	
 1007	DASHBOARD	1.4 55kw KFU	
 1007	DASHBOARD	1.4 55kw KFU	SAGEM Dashboard
 1007	DASHBOARD	1.4 55kw KFW	
 1007	DASHBOARD	1.4 55kw KFW	
 1007	DASHBOARD	1.4 55kw KFW	SAGEM Dashboard
 1007	DASHBOARD	1.4 HDI 50kw 8HX	
 1007	DASHBOARD	1.4 HDI 50kw 8HX	
 1007	DASHBOARD	1.4 HDI 50kw 8HX	SAGEM Dashboard
 1007	DASHBOARD	1.4 HDI 50kw 8HZ	
 1007	DASHBOARD	1.4 HDI 50kw 8HZ	
 1007	DASHBOARD	1.4 HDI 50kw 8HZ	SAGEM Dashboard
 1007	DASHBOARD	1.6 16v 80kw NFU	
 1007	DASHBOARD	1.6 16v 80kw NFU	
 1007	DASHBOARD	1.6 16v 80kw NFU	SAGEM Dashboard
 1007	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP	
 1007	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP	
 1007	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP	SAGEM Dashboard

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 1007	ELECTRIC STEERING	1.1 44kw HFX	KOYO EPS
 1007	ELECTRIC STEERING	1.1 44kw HFX	Var.1
 1007	ELECTRIC STEERING	1.1 44kw HFX	Var.2
 1007	ELECTRIC STEERING	1.1 44kw HFX	Var.3
 1007	ELECTRIC STEERING	1.4 16v 65kw KFV	KOYO EPS
 1007	ELECTRIC STEERING	1.4 16v 65kw KFV	Var.1
 1007	ELECTRIC STEERING	1.4 16v 65kw KFV	Var.2
 1007	ELECTRIC STEERING	1.4 16v 65kw KFV	Var.3
 1007	ELECTRIC STEERING	1.4 55kw KFV	KOYO EPS
 1007	ELECTRIC STEERING	1.4 55kw KFV	Var.1
 1007	ELECTRIC STEERING	1.4 55kw KFV	Var.2
 1007	ELECTRIC STEERING	1.4 55kw KFV	Var.3
 1007	ELECTRIC STEERING	1.4 55kw KFW	KOYO EPS
 1007	ELECTRIC STEERING	1.4 55kw KFW	Var.1
 1007	ELECTRIC STEERING	1.4 55kw KFW	Var.2
 1007	ELECTRIC STEERING	1.4 55kw KFW	Var.3
 1007	ELECTRIC STEERING	1.4 HDI 50kw 8HX	KOYO EPS
 1007	ELECTRIC STEERING	1.4 HDI 50kw 8HX	Var.1
 1007	ELECTRIC STEERING	1.4 HDI 50kw 8HX	Var.2
 1007	ELECTRIC STEERING	1.4 HDI 50kw 8HX	Var.3
 1007	ELECTRIC STEERING	1.4 HDI 50kw 8HZ	KOYO EPS
 1007	ELECTRIC STEERING	1.4 HDI 50kw 8HZ	Var.1
 1007	ELECTRIC STEERING	1.4 HDI 50kw 8HZ	Var.2
 1007	ELECTRIC STEERING	1.4 HDI 50kw 8HZ	Var.3
 1007	ELECTRIC STEERING	1.6 16v 80kw NFU	KOYO EPS
 1007	ELECTRIC STEERING	1.6 16v 80kw NFU	Var.1
 1007	ELECTRIC STEERING	1.6 16v 80kw NFU	Var.2
 1007	ELECTRIC STEERING	1.6 16v 80kw NFU	Var.3
 1007	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	KOYO EPS
 1007	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 1007	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 1007	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	Var.3
 1007	ENGINE MANAGEME	1.1 44kw HFX	Marelli MM48P
 1007	ENGINE MANAGEME	1.1 44kw HFX	SAGEM J34P Var.1
 1007	ENGINE MANAGEME	1.1 44kw HFX	SAGEM J34P Var.2
 1007	ENGINE MANAGEME	1.4 16v 65kw KFV	Marelli MM6LP
 1007	ENGINE MANAGEME	1.4 55kw KFV	SAGEM J34P Var.1
 1007	ENGINE MANAGEME	1.4 55kw KFV	SAGEM J34P Var.2
 1007	ENGINE MANAGEME	1.4 55kw KFV	SAGEM S2000 PM1
 1007	ENGINE MANAGEME	1.4 55kw KFV	SAGEM S2000 PM2
 1007	ENGINE MANAGEME	1.4 55kw KFV	SAGEM S2000PM2
 1007	ENGINE MANAGEME	1.4 55kw KFW	SAGEM S2000 PM2
 1007	ENGINE MANAGEME	1.4 HDI 50kw 8HX	SIEMENS SID802 Common Rail
 1007	ENGINE MANAGEME	1.4 HDI 50kw 8HX	SIEMENS SID804 Common Rail
 1007	ENGINE MANAGEME	1.4 HDI 50kw 8HZ	BOSCH EDC 16 C34 Common Rail Var.1
 1007	ENGINE MANAGEME	1.4 HDI 50kw 8HZ	BOSCH EDC 16 C34 Common Rail Var.2
 1007	ENGINE MANAGEME	1.4 HDI 50kw 8HZ	SIEMENS SID804 Common Rail
 1007	ENGINE MANAGEME	1.4 HDI 50kw 8HZ	SIEMENS SID806 Common Rail
 1007	ENGINE MANAGEME	1.6 16v 80kw NFU	BOSCH ME 7.4.4
 1007	ENGINE MANAGEME	1.6 16v 80kw NFU	BOSCH ME 7.4.5 Var.1
 1007	ENGINE MANAGEME	1.6 16v 80kw NFU	BOSCH ME 7.4.5 Var.2
 1007	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 1007	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.2
 1007	MAINTENANCE	1.1 44kw HFX	AirBag CENTRAL CAN
 1007	MAINTENANCE	1.1 44kw HFX	AirBag CENTRAL CAN
 1007	MAINTENANCE	1.1 44kw HFX	AKF- Autoliv AirBag ACU3
 1007	MAINTENANCE	1.1 44kw HFX	ATE-TEVES ABS+ESP Mk60
 1007	MAINTENANCE	1.1 44kw HFX	ATE-TEVES ABS+ESP Mk60

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 1007	MAINTENANCE	1.1 44kw HFX	SAGEM Dashboard
 1007	MAINTENANCE	1.1 44kw HFX	Sagem/xx MANUAL
 1007	MAINTENANCE	1.1 44kw HFX	TEVES ABS MK60 2
 1007	MAINTENANCE	1.1 44kw HFX	TEVES ABS MK60 2
 1007	MAINTENANCE	1.1 44kw HFX	TEVES ABS MK70 2
 1007	MAINTENANCE	1.1 44kw HFX	Var.1
 1007	MAINTENANCE	1.1 44kw HFX	Var.1
 1007	MAINTENANCE	1.1 44kw HFX	Var.2
 1007	MAINTENANCE	1.1 44kw HFX	Var.2
 1007	MAINTENANCE	1.4 16v 65kw KFU	AirBag CENTRAL CAN
 1007	MAINTENANCE	1.4 16v 65kw KFU	AirBag CENTRAL CAN
 1007	MAINTENANCE	1.4 16v 65kw KFU	AKF- Autoliv AirBag ACU3
 1007	MAINTENANCE	1.4 16v 65kw KFU	ATE-TEVES ABS+ESP Mk60
 1007	MAINTENANCE	1.4 16v 65kw KFU	ATE-TEVES ABS+ESP Mk60
 1007	MAINTENANCE	1.4 16v 65kw KFU	SAGEM Dashboard
 1007	MAINTENANCE	1.4 16v 65kw KFU	Sagem/xx MANUAL
 1007	MAINTENANCE	1.4 16v 65kw KFU	TEVES ABS MK60 2
 1007	MAINTENANCE	1.4 16v 65kw KFU	TEVES ABS MK60 2
 1007	MAINTENANCE	1.4 16v 65kw KFU	TEVES ABS MK70 2
 1007	MAINTENANCE	1.4 16v 65kw KFU	Var.1
 1007	MAINTENANCE	1.4 16v 65kw KFU	Var.1
 1007	MAINTENANCE	1.4 16v 65kw KFU	Var.2
 1007	MAINTENANCE	1.4 16v 65kw KFU	Var.2
 1007	MAINTENANCE	1.4 55kw KFU	AirBag CENTRAL CAN
 1007	MAINTENANCE	1.4 55kw KFU	AirBag CENTRAL CAN
 1007	MAINTENANCE	1.4 55kw KFU	AKF- Autoliv AirBag ACU3
 1007	MAINTENANCE	1.4 55kw KFU	ATE-TEVES ABS+ESP Mk60
 1007	MAINTENANCE	1.4 55kw KFU	ATE-TEVES ABS+ESP Mk60
 1007	MAINTENANCE	1.4 55kw KFU	SAGEM Dashboard
 1007	MAINTENANCE	1.4 55kw KFU	Sagem/xx MANUAL
 1007	MAINTENANCE	1.4 55kw KFU	TEVES ABS MK60 2
 1007	MAINTENANCE	1.4 55kw KFU	TEVES ABS MK60 2
 1007	MAINTENANCE	1.4 55kw KFU	TEVES ABS MK70 2
 1007	MAINTENANCE	1.4 55kw KFU	Var.1
 1007	MAINTENANCE	1.4 55kw KFU	Var.1
 1007	MAINTENANCE	1.4 55kw KFU	Var.2
 1007	MAINTENANCE	1.4 55kw KFU	Var.2
 1007	MAINTENANCE	1.4 55kw KFW	AirBag CENTRAL CAN
 1007	MAINTENANCE	1.4 55kw KFW	AirBag CENTRAL CAN
 1007	MAINTENANCE	1.4 55kw KFW	AKF- Autoliv AirBag ACU3
 1007	MAINTENANCE	1.4 55kw KFW	ATE-TEVES ABS+ESP Mk60
 1007	MAINTENANCE	1.4 55kw KFW	ATE-TEVES ABS+ESP Mk60
 1007	MAINTENANCE	1.4 55kw KFW	SAGEM Dashboard
 1007	MAINTENANCE	1.4 55kw KFW	Sagem/xx MANUAL
 1007	MAINTENANCE	1.4 55kw KFW	TEVES ABS MK60 2
 1007	MAINTENANCE	1.4 55kw KFW	TEVES ABS MK60 2
 1007	MAINTENANCE	1.4 55kw KFW	TEVES ABS MK70 2
 1007	MAINTENANCE	1.4 55kw KFW	Var.1
 1007	MAINTENANCE	1.4 55kw KFW	Var.1
 1007	MAINTENANCE	1.4 55kw KFW	Var.2
 1007	MAINTENANCE	1.4 55kw KFW	Var.2
 1007	MAINTENANCE	1.4 HDI 50kw 8HX	AirBag CENTRAL CAN
 1007	MAINTENANCE	1.4 HDI 50kw 8HX	AirBag CENTRAL CAN
 1007	MAINTENANCE	1.4 HDI 50kw 8HX	AKF- Autoliv AirBag ACU3
 1007	MAINTENANCE	1.4 HDI 50kw 8HX	ATE-TEVES ABS+ESP Mk60
 1007	MAINTENANCE	1.4 HDI 50kw 8HX	ATE-TEVES ABS+ESP Mk60
 1007	MAINTENANCE	1.4 HDI 50kw 8HX	SAGEM Dashboard
 1007	MAINTENANCE	1.4 HDI 50kw 8HX	Sagem/xx MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 1007	MAINTENANCE	1.4 HDI 50kw 8HX	TEVES ABS MK60 2
 1007	MAINTENANCE	1.4 HDI 50kw 8HX	TEVES ABS MK60 2
 1007	MAINTENANCE	1.4 HDI 50kw 8HX	TEVES ABS MK70 2
 1007	MAINTENANCE	1.4 HDI 50kw 8HX	Var.1
 1007	MAINTENANCE	1.4 HDI 50kw 8HX	Var.1
 1007	MAINTENANCE	1.4 HDI 50kw 8HX	Var.2
 1007	MAINTENANCE	1.4 HDI 50kw 8HX	Var.2
 1007	MAINTENANCE	1.4 HDI 50kw 8HZ	AirBag CENTRAL CAN
 1007	MAINTENANCE	1.4 HDI 50kw 8HZ	AirBag CENTRAL CAN
 1007	MAINTENANCE	1.4 HDI 50kw 8HZ	AKF- Autoliv AirBag ACU3
 1007	MAINTENANCE	1.4 HDI 50kw 8HZ	ATE-TEVES ABS+ESP Mk60
 1007	MAINTENANCE	1.4 HDI 50kw 8HZ	ATE-TEVES ABS+ESP Mk60
 1007	MAINTENANCE	1.4 HDI 50kw 8HZ	SAGEM Dashboard
 1007	MAINTENANCE	1.4 HDI 50kw 8HZ	Sagem/xx MANUAL
 1007	MAINTENANCE	1.4 HDI 50kw 8HZ	TEVES ABS MK60 2
 1007	MAINTENANCE	1.4 HDI 50kw 8HZ	TEVES ABS MK60 2
 1007	MAINTENANCE	1.4 HDI 50kw 8HZ	TEVES ABS MK70 2
 1007	MAINTENANCE	1.4 HDI 50kw 8HZ	Var.1
 1007	MAINTENANCE	1.4 HDI 50kw 8HZ	Var.1
 1007	MAINTENANCE	1.4 HDI 50kw 8HZ	Var.2
 1007	MAINTENANCE	1.4 HDI 50kw 8HZ	Var.2
 1007	MAINTENANCE	1.6 16v 80kw NFU	AirBag CENTRAL CAN
 1007	MAINTENANCE	1.6 16v 80kw NFU	AirBag CENTRAL CAN
 1007	MAINTENANCE	1.6 16v 80kw NFU	AKF- Autoliv AirBag ACU3
 1007	MAINTENANCE	1.6 16v 80kw NFU	ATE-TEVES ABS+ESP Mk60
 1007	MAINTENANCE	1.6 16v 80kw NFU	ATE-TEVES ABS+ESP Mk60
 1007	MAINTENANCE	1.6 16v 80kw NFU	SAGEM Dashboard
 1007	MAINTENANCE	1.6 16v 80kw NFU	Sagem/xx MANUAL
 1007	MAINTENANCE	1.6 16v 80kw NFU	TEVES ABS MK60 2
 1007	MAINTENANCE	1.6 16v 80kw NFU	TEVES ABS MK60 2
 1007	MAINTENANCE	1.6 16v 80kw NFU	TEVES ABS MK70 2
 1007	MAINTENANCE	1.6 16v 80kw NFU	Var.1
 1007	MAINTENANCE	1.6 16v 80kw NFU	Var.1
 1007	MAINTENANCE	1.6 16v 80kw NFU	Var.2
 1007	MAINTENANCE	1.6 16v 80kw NFU	Var.2
 1007	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL CAN
 1007	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL CAN
 1007	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	AKF- Autoliv AirBag ACU3
 1007	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	ATE-TEVES ABS+ESP Mk60
 1007	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	ATE-TEVES ABS+ESP Mk60
 1007	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 1007	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 1007	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 1007	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 1007	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 1007	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 1007	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.2
 1007	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.2
 1007	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.2
 1007	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.2
 1007	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.2
 1007	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.2
 1007	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	SAGEM Dashboard
 1007	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Sagem/xx MANUAL
 1007	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	TEVES ABS MK60 2
 1007	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	TEVES ABS MK60 2
 1007	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	TEVES ABS MK70 2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 1007	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 1007	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 1007	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 1007	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 1007	NAVIGATION	1.1 44kw HFX	NAVIGATION
 1007	NAVIGATION	1.4 16v 65kw KFU	NAVIGATION
 1007	NAVIGATION	1.4 55kw KFV	NAVIGATION
 1007	NAVIGATION	1.4 55kw KFW	NAVIGATION
 1007	NAVIGATION	1.4 HDI 50kw 8HX	NAVIGATION
 1007	NAVIGATION	1.4 HDI 50kw 8HZ	NAVIGATION
 1007	NAVIGATION	1.6 16v 80kw NFU	NAVIGATION
 1007	NAVIGATION	1.6 HDI 16v 80kw 9HZ-FAP	NAVIGATION
 1007	PARKING HELP	1.1 44kw HFX	Var.1
 1007	PARKING HELP	1.1 44kw HFX	Var.2
 1007	PARKING HELP	1.1 44kw HFX	Var.3
 1007	PARKING HELP	1.1 44kw HFX	Var.4
 1007	PARKING HELP	1.4 16v 65kw KFU	Var.1
 1007	PARKING HELP	1.4 16v 65kw KFU	Var.2
 1007	PARKING HELP	1.4 16v 65kw KFU	Var.3
 1007	PARKING HELP	1.4 16v 65kw KFU	Var.4
 1007	PARKING HELP	1.4 55kw KFV	Var.1
 1007	PARKING HELP	1.4 55kw KFV	Var.2
 1007	PARKING HELP	1.4 55kw KFV	Var.3
 1007	PARKING HELP	1.4 55kw KFV	Var.4
 1007	PARKING HELP	1.4 55kw KFW	Var.1
 1007	PARKING HELP	1.4 55kw KFW	Var.2
 1007	PARKING HELP	1.4 55kw KFW	Var.3
 1007	PARKING HELP	1.4 55kw KFW	Var.4
 1007	PARKING HELP	1.4 HDI 50kw 8HX	Var.1
 1007	PARKING HELP	1.4 HDI 50kw 8HX	Var.2
 1007	PARKING HELP	1.4 HDI 50kw 8HX	Var.3
 1007	PARKING HELP	1.4 HDI 50kw 8HX	Var.4
 1007	PARKING HELP	1.4 HDI 50kw 8HZ	Var.1
 1007	PARKING HELP	1.4 HDI 50kw 8HZ	Var.2
 1007	PARKING HELP	1.4 HDI 50kw 8HZ	Var.3
 1007	PARKING HELP	1.4 HDI 50kw 8HZ	Var.4
 1007	PARKING HELP	1.6 16v 80kw NFU	Var.1
 1007	PARKING HELP	1.6 16v 80kw NFU	Var.2
 1007	PARKING HELP	1.6 16v 80kw NFU	Var.3
 1007	PARKING HELP	1.6 16v 80kw NFU	Var.4
 1007	PARKING HELP	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 1007	PARKING HELP	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 1007	PARKING HELP	1.6 HDI 16v 80kw 9HZ-FAP	Var.3
 1007	PARKING HELP	1.6 HDI 16v 80kw 9HZ-FAP	Var.4
 1007	RADIO / CD	1.1 44kw HFX	CLARION AudioSystem
 1007	RADIO / CD	1.1 44kw HFX	PHILIPS AudioSystem
 1007	RADIO / CD	1.1 44kw HFX	Var.1
 1007	RADIO / CD	1.1 44kw HFX	Var.2
 1007	RADIO / CD	1.1 44kw HFX	Var.3
 1007	RADIO / CD	1.1 44kw HFX	Var.4
 1007	RADIO / CD	1.1 44kw HFX	Var.5
 1007	RADIO / CD	1.1 44kw HFX	Var.6
 1007	RADIO / CD	1.1 44kw HFX	Var.7
 1007	RADIO / CD	1.1 44kw HFX	Var.8
 1007	RADIO / CD	1.1 44kw HFX	VDO AudioSystem
 1007	RADIO / CD	1.4 16v 65kw KFU	CLARION AudioSystem
 1007	RADIO / CD	1.4 16v 65kw KFU	PHILIPS AudioSystem
 1007	RADIO / CD	1.4 16v 65kw KFU	Var.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 1007	RADIO / CD	1.4 16v 65kw KFU	Var.2
 1007	RADIO / CD	1.4 16v 65kw KFU	Var.3
 1007	RADIO / CD	1.4 16v 65kw KFU	Var.4
 1007	RADIO / CD	1.4 16v 65kw KFU	Var.5
 1007	RADIO / CD	1.4 16v 65kw KFU	Var.6
 1007	RADIO / CD	1.4 16v 65kw KFU	Var.7
 1007	RADIO / CD	1.4 16v 65kw KFU	Var.8
 1007	RADIO / CD	1.4 16v 65kw KFU	VDO AudioSystem
 1007	RADIO / CD	1.4 55kw KFU	CLARION AudioSystem
 1007	RADIO / CD	1.4 55kw KFU	PHILIPS AudioSystem
 1007	RADIO / CD	1.4 55kw KFU	Var.1
 1007	RADIO / CD	1.4 55kw KFU	Var.2
 1007	RADIO / CD	1.4 55kw KFU	Var.3
 1007	RADIO / CD	1.4 55kw KFU	Var.4
 1007	RADIO / CD	1.4 55kw KFU	Var.5
 1007	RADIO / CD	1.4 55kw KFU	Var.6
 1007	RADIO / CD	1.4 55kw KFU	Var.7
 1007	RADIO / CD	1.4 55kw KFU	Var.8
 1007	RADIO / CD	1.4 55kw KFU	VDO AudioSystem
 1007	RADIO / CD	1.4 55kw KFW	CLARION AudioSystem
 1007	RADIO / CD	1.4 55kw KFW	PHILIPS AudioSystem
 1007	RADIO / CD	1.4 55kw KFW	Var.1
 1007	RADIO / CD	1.4 55kw KFW	Var.2
 1007	RADIO / CD	1.4 55kw KFW	Var.3
 1007	RADIO / CD	1.4 55kw KFW	Var.4
 1007	RADIO / CD	1.4 55kw KFW	Var.5
 1007	RADIO / CD	1.4 55kw KFW	Var.6
 1007	RADIO / CD	1.4 55kw KFW	Var.7
 1007	RADIO / CD	1.4 55kw KFW	Var.8
 1007	RADIO / CD	1.4 55kw KFW	VDO AudioSystem
 1007	RADIO / CD	1.4 HDI 50kw 8HX	CLARION AudioSystem
 1007	RADIO / CD	1.4 HDI 50kw 8HX	PHILIPS AudioSystem
 1007	RADIO / CD	1.4 HDI 50kw 8HX	Var.1
 1007	RADIO / CD	1.4 HDI 50kw 8HX	Var.2
 1007	RADIO / CD	1.4 HDI 50kw 8HX	Var.3
 1007	RADIO / CD	1.4 HDI 50kw 8HX	Var.4
 1007	RADIO / CD	1.4 HDI 50kw 8HX	Var.5
 1007	RADIO / CD	1.4 HDI 50kw 8HX	Var.6
 1007	RADIO / CD	1.4 HDI 50kw 8HX	Var.7
 1007	RADIO / CD	1.4 HDI 50kw 8HX	Var.8
 1007	RADIO / CD	1.4 HDI 50kw 8HX	VDO AudioSystem
 1007	RADIO / CD	1.4 HDI 50kw 8HZ	CLARION AudioSystem
 1007	RADIO / CD	1.4 HDI 50kw 8HZ	PHILIPS AudioSystem
 1007	RADIO / CD	1.4 HDI 50kw 8HZ	Var.1
 1007	RADIO / CD	1.4 HDI 50kw 8HZ	Var.2
 1007	RADIO / CD	1.4 HDI 50kw 8HZ	Var.3
 1007	RADIO / CD	1.4 HDI 50kw 8HZ	Var.4
 1007	RADIO / CD	1.4 HDI 50kw 8HZ	Var.5
 1007	RADIO / CD	1.4 HDI 50kw 8HZ	Var.6
 1007	RADIO / CD	1.4 HDI 50kw 8HZ	Var.7
 1007	RADIO / CD	1.4 HDI 50kw 8HZ	Var.8
 1007	RADIO / CD	1.4 HDI 50kw 8HZ	VDO AudioSystem
 1007	RADIO / CD	1.6 16v 80kw NFU	CLARION AudioSystem
 1007	RADIO / CD	1.6 16v 80kw NFU	PHILIPS AudioSystem
 1007	RADIO / CD	1.6 16v 80kw NFU	Var.1
 1007	RADIO / CD	1.6 16v 80kw NFU	Var.2
 1007	RADIO / CD	1.6 16v 80kw NFU	Var.3
 1007	RADIO / CD	1.6 16v 80kw NFU	Var.4

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 1007	RADIO / CD	1.6 16v 80kw NFU	Var.5
 1007	RADIO / CD	1.6 16v 80kw NFU	Var.6
 1007	RADIO / CD	1.6 16v 80kw NFU	Var.7
 1007	RADIO / CD	1.6 16v 80kw NFU	Var.8
 1007	RADIO / CD	1.6 16v 80kw NFU	VDO AudioSystem
 1007	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	CLARION AudioSystem
 1007	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	PHILIPS AudioSystem
 1007	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 1007	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 1007	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Var.3
 1007	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Var.4
 1007	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Var.5
 1007	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Var.6
 1007	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Var.7
 1007	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Var.8
 1007	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	VDO AudioSystem
 1007	RAIN-LUMINOSITY S	1.1 44kw HFX	Var.1
 1007	RAIN-LUMINOSITY S	1.1 44kw HFX	Var.2
 1007	RAIN-LUMINOSITY S	1.1 44kw HFX	Var.3
 1007	RAIN-LUMINOSITY S	1.1 44kw HFX	Var.4
 1007	RAIN-LUMINOSITY S	1.4 16v 65kw KFV	Var.1
 1007	RAIN-LUMINOSITY S	1.4 16v 65kw KFV	Var.2
 1007	RAIN-LUMINOSITY S	1.4 16v 65kw KFV	Var.3
 1007	RAIN-LUMINOSITY S	1.4 16v 65kw KFV	Var.4
 1007	RAIN-LUMINOSITY S	1.4 55kw KFV	Var.1
 1007	RAIN-LUMINOSITY S	1.4 55kw KFV	Var.2
 1007	RAIN-LUMINOSITY S	1.4 55kw KFV	Var.3
 1007	RAIN-LUMINOSITY S	1.4 55kw KFV	Var.4
 1007	RAIN-LUMINOSITY S	1.4 55kw KFW	Var.1
 1007	RAIN-LUMINOSITY S	1.4 55kw KFW	Var.2
 1007	RAIN-LUMINOSITY S	1.4 55kw KFW	Var.3
 1007	RAIN-LUMINOSITY S	1.4 55kw KFW	Var.4
 1007	RAIN-LUMINOSITY S	1.4 HDI 50kw 8HX	Var.1
 1007	RAIN-LUMINOSITY S	1.4 HDI 50kw 8HX	Var.2
 1007	RAIN-LUMINOSITY S	1.4 HDI 50kw 8HX	Var.3
 1007	RAIN-LUMINOSITY S	1.4 HDI 50kw 8HX	Var.4
 1007	RAIN-LUMINOSITY S	1.4 HDI 50kw 8HZ	Var.1
 1007	RAIN-LUMINOSITY S	1.4 HDI 50kw 8HZ	Var.2
 1007	RAIN-LUMINOSITY S	1.4 HDI 50kw 8HZ	Var.3
 1007	RAIN-LUMINOSITY S	1.4 HDI 50kw 8HZ	Var.4
 1007	RAIN-LUMINOSITY S	1.6 16v 80kw NFU	Var.1
 1007	RAIN-LUMINOSITY S	1.6 16v 80kw NFU	Var.2
 1007	RAIN-LUMINOSITY S	1.6 16v 80kw NFU	Var.3
 1007	RAIN-LUMINOSITY S	1.6 16v 80kw NFU	Var.4
 1007	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 1007	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 1007	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HZ-FAP	Var.3
 1007	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HZ-FAP	Var.4
 1007	SERVICE LIGHT RES	1.1 44kw HFX	Sagem/xx MANUAL
 1007	SERVICE LIGHT RES	1.4 16v 65kw KFV	Sagem/xx MANUAL
 1007	SERVICE LIGHT RES	1.4 55kw KFV	Sagem/xx MANUAL
 1007	SERVICE LIGHT RES	1.4 55kw KFW	Sagem/xx MANUAL
 1007	SERVICE LIGHT RES	1.4 HDI 50kw 8HX	Sagem/xx MANUAL
 1007	SERVICE LIGHT RES	1.4 HDI 50kw 8HZ	Sagem/xx MANUAL
 1007	SERVICE LIGHT RES	1.6 16v 80kw NFU	Sagem/xx MANUAL
 1007	SERVICE LIGHT RES	1.6 HDI 16v 80kw 9HZ-FAP	Sagem/xx MANUAL
 1007	STEERING COLUMN	1.1 44kw HFX	
 1007	STEERING COLUMN	1.1 44kw HFX	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 1007	STEERING COLUMN	1.4 16v 65kw KFU	
 1007	STEERING COLUMN	1.4 16v 65kw KFU	
 1007	STEERING COLUMN	1.4 55kw KFV	
 1007	STEERING COLUMN	1.4 55kw KFV	
 1007	STEERING COLUMN	1.4 55kw KFW	
 1007	STEERING COLUMN	1.4 55kw KFW	
 1007	STEERING COLUMN	1.4 HDI 50kw 8HX	
 1007	STEERING COLUMN	1.4 HDI 50kw 8HX	
 1007	STEERING COLUMN	1.4 HDI 50kw 8HZ	
 1007	STEERING COLUMN	1.4 HDI 50kw 8HZ	
 1007	STEERING COLUMN	1.6 16v 80kw NFU	
 1007	STEERING COLUMN	1.6 16v 80kw NFU	
 1007	STEERING COLUMN	1.6 HDI 16v 80kw 9HZ-FAP	
 1007	STEERING COLUMN	1.6 HDI 16v 80kw 9HZ-FAP	
 1007	VISUAL./TELEMATIC	1.1 44kw HFX	Display
 1007	VISUAL./TELEMATIC	1.1 44kw HFX	Display A+
 1007	VISUAL./TELEMATIC	1.1 44kw HFX	Display C-
 1007	VISUAL./TELEMATIC	1.1 44kw HFX	SAGEM JCAE
 1007	VISUAL./TELEMATIC	1.4 16v 65kw KFU	Display
 1007	VISUAL./TELEMATIC	1.4 16v 65kw KFU	Display A+
 1007	VISUAL./TELEMATIC	1.4 16v 65kw KFU	Display C-
 1007	VISUAL./TELEMATIC	1.4 16v 65kw KFU	SAGEM JCAE
 1007	VISUAL./TELEMATIC	1.4 55kw KFV	Display
 1007	VISUAL./TELEMATIC	1.4 55kw KFV	Display A+
 1007	VISUAL./TELEMATIC	1.4 55kw KFV	Display C-
 1007	VISUAL./TELEMATIC	1.4 55kw KFV	SAGEM JCAE
 1007	VISUAL./TELEMATIC	1.4 55kw KFW	Display
 1007	VISUAL./TELEMATIC	1.4 55kw KFW	Display A+
 1007	VISUAL./TELEMATIC	1.4 55kw KFW	Display C-
 1007	VISUAL./TELEMATIC	1.4 55kw KFW	SAGEM JCAE
 1007	VISUAL./TELEMATIC	1.4 HDI 50kw 8HX	Display
 1007	VISUAL./TELEMATIC	1.4 HDI 50kw 8HX	Display A+
 1007	VISUAL./TELEMATIC	1.4 HDI 50kw 8HX	Display C-
 1007	VISUAL./TELEMATIC	1.4 HDI 50kw 8HX	SAGEM JCAE
 1007	VISUAL./TELEMATIC	1.4 HDI 50kw 8HZ	Display
 1007	VISUAL./TELEMATIC	1.4 HDI 50kw 8HZ	Display A+
 1007	VISUAL./TELEMATIC	1.4 HDI 50kw 8HZ	Display C-
 1007	VISUAL./TELEMATIC	1.4 HDI 50kw 8HZ	SAGEM JCAE
 1007	VISUAL./TELEMATIC	1.6 16v 80kw NFU	Display
 1007	VISUAL./TELEMATIC	1.6 16v 80kw NFU	Display A+
 1007	VISUAL./TELEMATIC	1.6 16v 80kw NFU	Display C-
 1007	VISUAL./TELEMATIC	1.6 16v 80kw NFU	SAGEM JCAE
 1007	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	Display
 1007	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	Display A+
 1007	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	Display C-
 1007	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	SAGEM JCAE
 106 Restyling	ABS	1.0 33kw CDY	ATE Teves Mk20 E
 106 Restyling	ABS	1.0 37kw CDY	ATE Teves Mk20 E
 106 Restyling	ABS	1.1 40kw HDY	ATE Teves Mk20 E
 106 Restyling	ABS	1.1 44kw HFX	ATE Teves Mk20 E
 106 Restyling	ABS	1.4 55kw KFW	ATE Teves Mk20 E
 106 Restyling	ABS	1.4 55kw KFX	ATE Teves Mk20 E
 106 Restyling	ABS	1.4 D 37kw K9B	ATE Teves Mk20 E
 106 Restyling	ABS	1.5 D 8v 42kw CDY	ATE Teves Mk20 E
 106 Restyling	ABS	1.6 16v 88kw NFX	ATE Teves Mk20 E
 106 Restyling	ABS	1.6 65kw CDY	ATE Teves Mk20 E
 106 Restyling	ABS	1.6 74kw CDY	ATE Teves Mk20 E
 106 Restyling	AIRBAG	1.0 33kw CDY (97-00)	AKF- Autoliv AirBag no SIDE AB

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 106 Restyling	AIRBAG	1.0 37kw CDY (97-00)	AKF- Autoliv AirBag no SIDE AB
 106 Restyling	AIRBAG	1.1 40kw HDY (97-00)	AKF- Autoliv AirBag no SIDE AB
 106 Restyling	AIRBAG	1.1 44kw HFX (97-00)	AKF- Autoliv AirBag no SIDE AB
 106 Restyling	AIRBAG	1.4 55kw KFW (97-00)	AKF- Autoliv AirBag no SIDE AB
 106 Restyling	AIRBAG	1.4 55kw KFX (97-00)	AKF- Autoliv AirBag no SIDE AB
 106 Restyling	AIRBAG	1.4 D 37kw K9B (97-00)	AKF- Autoliv AirBag no SIDE AB
 106 Restyling	AIRBAG	1.5 D 8v 42kw CDY (97-00)	AKF- Autoliv AirBag no SIDE AB
 106 Restyling	AIRBAG	1.6 16v 88kw NFX (97-00)	AKF- Autoliv AirBag no SIDE AB
 106 Restyling	AIRBAG	1.6 65kw CDY (97-00)	AKF- Autoliv AirBag no SIDE AB
 106 Restyling	AIRBAG	1.6 74kw CDY (97-00)	AKF- Autoliv AirBag no SIDE AB
 106 Restyling	ELECTRONIC INJECT	1.1 40kw HDY	BOSCH MonoJetronic A2.2 [Slow]
 106 Restyling	ENGINE MANAGEME	1.0 33kw CDY	BOSCH MonoMotronic MA3.0 [Slow]
 106 Restyling	ENGINE MANAGEME	1.0 33kw CDY	BOSCH MonoMotronic MA3.1
 106 Restyling	ENGINE MANAGEME	1.1 40kw HDY	BOSCH MonoMotronic MA3.1
 106 Restyling	ENGINE MANAGEME	1.1 40kw HDY	Marelli MM G6 [Slow]
 106 Restyling	ENGINE MANAGEME	1.1 44kw HFX	BOSCH BOSCH M 7.4.4
 106 Restyling	ENGINE MANAGEME	1.1 44kw HFX (01-..)	BOSCH Motronic M 7.4.4
 106 Restyling	ENGINE MANAGEME	1.1 44kw HFX (01-..)	EOBD
 106 Restyling	ENGINE MANAGEME	1.4 55kw KFW	SAGEM S2000
 106 Restyling	ENGINE MANAGEME	1.4 55kw KFW	SAGEM S2000
 106 Restyling	ENGINE MANAGEME	1.4 55kw KFX	Marelli MM 1AP.40
 106 Restyling	ENGINE MANAGEME	1.4 55kw KFX	Marelli MM 1AP.81
 106 Restyling	ENGINE MANAGEME	1.6 16v 88kw NFX	Marelli 4.8P
 106 Restyling	ENGINE MANAGEME	1.6 16v 88kw NFX	Marelli MM 1AP.41
 106 Restyling	ENGINE MANAGEME	1.6 16v 88kw NFX	Marelli MM48P
 106 Restyling	MAINTENANCE	1.0 33kw CDY (98-00)	VDO MANUAL
 106 Restyling	MAINTENANCE	1.0 37kw CDY (98-00)	VDO MANUAL
 106 Restyling	MAINTENANCE	1.1 40kw HDY (98-00)	VDO MANUAL
 106 Restyling	MAINTENANCE	1.1 44kw HFX (98-00)	VDO MANUAL
 106 Restyling	MAINTENANCE	1.4 55kw KFW (98-00)	VDO MANUAL
 106 Restyling	MAINTENANCE	1.4 55kw KFX (98-00)	VDO MANUAL
 106 Restyling	MAINTENANCE	1.4 D 37kw K9B (98-00)	VDO MANUAL
 106 Restyling	MAINTENANCE	1.5 D 8v 42kw CDY (98-00)	VDO MANUAL
 106 Restyling	MAINTENANCE	1.6 16v 88kw NFX (98-00)	VDO MANUAL
 106 Restyling	MAINTENANCE	1.6 65kw CDY (98-00)	VDO MANUAL
 106 Restyling	MAINTENANCE	1.6 74kw CDY (98-00)	VDO MANUAL
 106 Restyling	SERVICE LIGHT RES	1.0 33kw CDY (98-00)	VDO MANUAL
 106 Restyling	SERVICE LIGHT RES	1.0 37kw CDY (98-00)	VDO MANUAL
 106 Restyling	SERVICE LIGHT RES	1.1 40kw HDY (98-00)	VDO MANUAL
 106 Restyling	SERVICE LIGHT RES	1.1 44kw HFX (98-00)	VDO MANUAL
 106 Restyling	SERVICE LIGHT RES	1.4 55kw KFW (98-00)	VDO MANUAL
 106 Restyling	SERVICE LIGHT RES	1.4 55kw KFX (98-00)	VDO MANUAL
 106 Restyling	SERVICE LIGHT RES	1.4 D 37kw K9B (98-00)	VDO MANUAL
 106 Restyling	SERVICE LIGHT RES	1.5 D 8v 42kw CDY (98-00)	VDO MANUAL
 106 Restyling	SERVICE LIGHT RES	1.6 16v 88kw NFX (98-00)	VDO MANUAL
 106 Restyling	SERVICE LIGHT RES	1.6 65kw CDY (98-00)	VDO MANUAL
 106 Restyling	SERVICE LIGHT RES	1.6 74kw CDY (98-00)	VDO MANUAL
 106	ABS	1.0 33kw C1A	ATE Teves Mk20 E
 106	ABS	1.0 37kw CDZ	ATE Teves Mk20 E
 106	ABS	1.1 44kw H1A	ATE Teves Mk20 E
 106	ABS	1.1 44kw HDZ	ATE Teves Mk20 E
 106	ABS	1.3 72kw MFZ	ATE Teves Mk20 E
 106	ABS	1.4 55kw K2D	ATE Teves Mk20 E
 106	ABS	1.4 55kw KDX	ATE Teves Mk20 E
 106	ABS	1.4 55kw KDY	ATE Teves Mk20 E
 106	ABS	1.4 70kw KFZ	ATE Teves Mk20 E
 106	ABS	1.4 72kw K6B	ATE Teves Mk20 E
 106	ABS	1.4 D 37kw K6B	ATE Teves Mk20 E

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 106	ABS	1.5 D 43kw VJZ	ATE Teves Mk20 E
 106	ABS	1.6 66kw NFZ	ATE Teves Mk20 E
 106	ABS	1.6 66kw NZW	ATE Teves Mk20 E
 106	ABS	1.6 77kw NFY	ATE Teves Mk20 E
 106	AIRBAG	1.0 33kw C1A (97-00)	AKF- Autoliv AirBag no SIDE AB
 106	AIRBAG	1.0 37kw CDZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 106	AIRBAG	1.1 44kw H1A (97-00)	AKF- Autoliv AirBag no SIDE AB
 106	AIRBAG	1.1 44kw HDZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 106	AIRBAG	1.3 72kw MFZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 106	AIRBAG	1.4 55kw K2D (97-00)	AKF- Autoliv AirBag no SIDE AB
 106	AIRBAG	1.4 55kw KDX (97-00)	AKF- Autoliv AirBag no SIDE AB
 106	AIRBAG	1.4 55kw KDY (97-00)	AKF- Autoliv AirBag no SIDE AB
 106	AIRBAG	1.4 70kw KFZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 106	AIRBAG	1.4 72kw K6B (97-00)	AKF- Autoliv AirBag no SIDE AB
 106	AIRBAG	1.4 D 37kw K6B (97-00)	AKF- Autoliv AirBag no SIDE AB
 106	AIRBAG	1.5 D 43kw VJZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 106	AIRBAG	1.6 66kw NFZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 106	AIRBAG	1.6 66kw NZW (97-00)	AKF- Autoliv AirBag no SIDE AB
 106	AIRBAG	1.6 77kw NFY (97-00)	AKF- Autoliv AirBag no SIDE AB
 106	ELECTRONIC INJECT	1.1 44kw HDZ	BOSCH MonoJetronic A2.2 [Slow]
 106	ELECTRONIC INJECT	1.4 55kw KDY	BOSCH MonoJetronic A2.2 [Slow]
 106	ENGINE MANAGEME	1.0 37kw CDZ	BOSCH MonoMotronic MA3.0 [Slow]
 106	ENGINE MANAGEME	1.0 37kw CDZ	BOSCH MonoMotronic MA3.1
 106	ENGINE MANAGEME	1.1 44kw HDZ	BOSCH MonoMotronic MA3.1
 106	ENGINE MANAGEME	1.1 44kw HDZ	Marelli MMBA G6 [Slow]
 106	ENGINE MANAGEME	1.3 72kw MFZ	Marelli MM 8P [Fast]
 106	ENGINE MANAGEME	1.4 55kw KDX	BOSCH MonoMotronic MA3.0 [Fast]
 106	ENGINE MANAGEME	1.4 55kw KDX	BOSCH MonoMotronic MA3.0 [Slow]
 106	ENGINE MANAGEME	1.4 70kw KFZ	BOSCH Motronic MP3.1 [Slow]
 106	ENGINE MANAGEME	1.4 72kw K6B	BOSCH Motronic MP3.1 [Slow]
 106	ENGINE MANAGEME	1.6 66kw NFZ	BOSCH Motronic MP5.1 [Fast]
 106	ENGINE MANAGEME	1.6 66kw NFZ	BOSCH Motronic MP5.1 [Slow]
 106	ENGINE MANAGEME	1.6 66kw NFZ	BOSCH Motronic MP5.2
 106	ENGINE MANAGEME	1.6 66kw NZW	Marelli MM 8P.10 [Fast]
 106	MAINTENANCE	1.0 33kw C1A (98-00)	VDO MANUAL
 106	MAINTENANCE	1.0 37kw CDZ (98-00)	VDO MANUAL
 106	MAINTENANCE	1.1 44kw H1A (98-00)	VDO MANUAL
 106	MAINTENANCE	1.1 44kw HDZ (98-00)	VDO MANUAL
 106	MAINTENANCE	1.3 72kw MFZ (98-00)	VDO MANUAL
 106	MAINTENANCE	1.4 55kw K2D (98-00)	VDO MANUAL
 106	MAINTENANCE	1.4 55kw KDX (98-00)	VDO MANUAL
 106	MAINTENANCE	1.4 55kw KDY (98-00)	VDO MANUAL
 106	MAINTENANCE	1.4 70kw KFZ (98-00)	VDO MANUAL
 106	MAINTENANCE	1.4 72kw K6B (98-00)	VDO MANUAL
 106	MAINTENANCE	1.4 D 37kw K6B (98-00)	VDO MANUAL
 106	MAINTENANCE	1.5 D 43kw VJZ (98-00)	VDO MANUAL
 106	MAINTENANCE	1.6 66kw NFZ (98-00)	VDO MANUAL
 106	MAINTENANCE	1.6 77kw NFY (98-00)	VDO MANUAL
 106	SERVICE LIGHT RES	1.0 33kw C1A (98-00)	VDO MANUAL
 106	SERVICE LIGHT RES	1.0 37kw CDZ (98-00)	VDO MANUAL
 106	SERVICE LIGHT RES	1.1 44kw H1A (98-00)	VDO MANUAL
 106	SERVICE LIGHT RES	1.1 44kw HDZ (98-00)	VDO MANUAL
 106	SERVICE LIGHT RES	1.3 72kw MFZ (98-00)	VDO MANUAL
 106	SERVICE LIGHT RES	1.4 55kw K2D (98-00)	VDO MANUAL
 106	SERVICE LIGHT RES	1.4 55kw KDX (98-00)	VDO MANUAL
 106	SERVICE LIGHT RES	1.4 55kw KDY (98-00)	VDO MANUAL
 106	SERVICE LIGHT RES	1.4 70kw KFZ (98-00)	VDO MANUAL
 106	SERVICE LIGHT RES	1.4 72kw K6B (98-00)	VDO MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 106	SERVICE LIGHT RES	1.4 D 37kw K6B (98-00)	VDO MANUAL
 106	SERVICE LIGHT RES	1.5 D 43kw VJZ (98-00)	VDO MANUAL
 106	SERVICE LIGHT RES	1.6 66kw NFZ (98-00)	VDO MANUAL
 106	SERVICE LIGHT RES	1.6 77kw NFY (98-00)	VDO MANUAL
 107	ABS	1.0 50kw 1KRFE	BOSCH ABS 8.0
 107	ABS	1.0 50kw 1KRFE	BOSCH ABS 8.0
 107	ABS	1.0 50kw CFAC	BOSCH ABS 8.0
 107	ABS	1.0 50kw CFAC	BOSCH ABS 8.0
 107	ABS	1.4 HDI 40kw 8HT	BOSCH ABS 8.0
 107	ABS	1.4 HDI 40kw 8HT	BOSCH ABS 8.0
 107	AIRBAG	1.0 50kw 1KRFE	TRW SAC
 107	AIRBAG	1.0 50kw 1KRFE	Var.1
 107	AIRBAG	1.0 50kw 1KRFE	Var.2
 107	AIRBAG	1.0 50kw CFAC	TRW SAC
 107	AIRBAG	1.0 50kw CFAC	Var.1
 107	AIRBAG	1.0 50kw CFAC	Var.2
 107	AIRBAG	1.4 HDI 40kw 8HT	TRW SAC
 107	AIRBAG	1.4 HDI 40kw 8HT	Var.1
 107	AIRBAG	1.4 HDI 40kw 8HT	Var.2
 107	ENGINE MANAGEME	1.0 50kw 1KRFE	BOSCH Motronic ME796
 107	ENGINE MANAGEME	1.0 50kw CFAC	BOSCH Motronic ME796
 107	ENGINE MANAGEME	1.4 HDI 40kw 8HT	SIEMENS SID 805 Common Rail
 107	IGNITION SWITCH	1.0 50kw 1KRFE	
 107	IGNITION SWITCH	1.0 50kw CFAC	
 107	IGNITION SWITCH	1.4 HDI 40kw 8HT	
 107	IMMOBILIZER	1.0 50kw 1KRFE	
 107	IMMOBILIZER	1.0 50kw CFAC	
 107	IMMOBILIZER	1.4 HDI 40kw 8HT	
 205	ELECTRONIC INJECT	1.1 44kw HDZ	BOSCH MonoJetronic A2.2 [Slow]
 205	ELECTRONIC INJECT	1.4 Kat 55kw KDY	BOSCH MonoJetronic A2.2 [Slow]
 205	ELECTRONIC INJECT	1.4 Kat 55kw KDZ	BOSCH MonoJetronic A2.2 [Slow]
 205	ENGINE MANAGEME	1.0 Kat 33kw CDY	BOSCH MonoMotronic MA3.0 [Slow]
 205	ENGINE MANAGEME	1.0 Kat 37kw CDZ	BOSCH MonoMotronic MA3.0 [Slow]
 205	ENGINE MANAGEME	1.1 Kat 44kw HDZ	Marelli MMBA G6 [Slow]
 205	ENGINE MANAGEME	1.4 Kat 55kw KDX	BOSCH MonoMotronic MA3.0 [Fast]
 205	ENGINE MANAGEME	1.4 Kat 55kw KDX	BOSCH MonoMotronic MA3.0 [Slow]
 205	ENGINE MANAGEME	1.6 65kw BDY	Marelli MM G6 [Slow]
 205	ENGINE MANAGEME	1.9 GTI Kat 88kw DKZ	BOSCH Motronic M1.3 [Slow]
 206 Plus	ABS	1.1 44kw HFX (09-..)	Valeo ABS
 206 Plus	ABS	1.4 55kw KFW (09-..)	Valeo ABS
 206 Plus	ABS	1.4 HDI 50kw 8HZ (09-..)	Valeo ABS
 206 Plus	AIRBAG	1.1 44kw HFX (09-..)	Valeo AirBag
 206 Plus	AIRBAG	1.4 55kw KFW (09-..)	Valeo AirBag
 206 Plus	AIRBAG	1.4 HDI 50kw 8HZ (09-..)	Valeo AirBag
 206 Plus	CHASSIS NETWORK	1.1 44kw HFX (09-..)	Siemens BSI
 206 Plus	CHASSIS NETWORK	1.4 55kw KFW (09-..)	Siemens BSI
 206 Plus	CHASSIS NETWORK	1.4 HDI 50kw 8HZ (09-..)	Siemens BSI
 206 Plus	DASH LAMPS	1.1 44kw HFX (09-..)	Marelli
 206 Plus	DASH LAMPS	1.4 55kw KFW (09-..)	Marelli
 206 Plus	DASH LAMPS	1.4 HDI 50kw 8HZ (09-..)	Marelli
 206 Plus	ENGINE MANAGEME	1.1 44kw HFV (09-..)	Valeo MPI
 206 Plus	STEERING WHEEL E	1.1 44kw HFX (09-..)	Eaton
 206 Plus	STEERING WHEEL E	1.4 55kw KFW (09-..)	Eaton
 206 Plus	STEERING WHEEL E	1.4 HDI 50kw 8HZ (09-..)	Eaton
 206	ABS	1.1 40kw HFY	ABS
 206	ABS	1.1 40kw HFY	ATE Teves Mk20 E
 206	ABS	1.1 40kw HFY (03-..)	TEVES ABS Mk60

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 206	ABS	1.1 44kw HFX	ABS
 206	ABS	1.1 44kw HFX	ATE Teves Mk20 E
 206	ABS	1.1 44kw HFX (03-..)	TEVES ABS Mk60
 206	ABS	1.1 44kw HFZ	ABS
 206	ABS	1.1 44kw HFZ	ATE Teves Mk20 E
 206	ABS	1.1 44kw HFZ (03-..)	TEVES ABS Mk60
 206	ABS	1.4 16v 66kw KFU	ABS
 206	ABS	1.4 16v 66kw KFU	ATE Teves Mk20 E
 206	ABS	1.4 16v 66kw KFU (03-..)	TEVES ABS Mk60
 206	ABS	1.4 55kw KFW	ABS
 206	ABS	1.4 55kw KFW	ATE Teves Mk20 E
 206	ABS	1.4 55kw KFW (03-..)	TEVES ABS Mk60
 206	ABS	1.4 55kw KFX	ABS
 206	ABS	1.4 55kw KFX	ATE Teves Mk20 E
 206	ABS	1.4 55kw KFX (03-..)	TEVES ABS Mk60
 206	ABS	1.4 HDI 50kw 8HX	ABS
 206	ABS	1.4 HDI 50kw 8HX	ATE Teves Mk20 E
 206	ABS	1.4 HDI 50kw 8HX (03-..)	TEVES ABS Mk60
 206	ABS	1.4 HDI 50kw 8HZ	ABS
 206	ABS	1.4 HDI 50kw 8HZ	ATE Teves Mk20 E
 206	ABS	1.4 HDI 50kw 8HZ (03-..)	TEVES ABS Mk60
 206	ABS	1.6 16v 80kw NFU	ABS
 206	ABS	1.6 16v 80kw NFU	ATE Teves Mk20 E
 206	ABS	1.6 16v 80kw NFU (03-..)	TEVES ABS Mk60
 206	ABS	1.6 66kw NFZ	ABS
 206	ABS	1.6 66kw NFZ	ATE Teves ABS Mk20 E
 206	ABS	1.6 66kw NFZ (03-..)	TEVES ABS Mk60
 206	ABS	1.6 HDI 16v 80kw 9HY	ABS
 206	ABS	1.6 HDI 16v 80kw 9HY	ATE Teves Mk20 E
 206	ABS	1.6 HDI 16v 80kw 9HY (03-..)	TEVES ABS Mk60
 206	ABS	1.6 HDI 16v 80kw 9HZ-FAP	ABS
 206	ABS	1.6 HDI 16v 80kw 9HZ-FAP	ATE Teves Mk20 E
 206	ABS	1.6 HDI 16v 80kw 9HZ-FAP (03-..)	TEVES ABS Mk60
 206	ABS	1.9 D 51kw WJZ	ABS
 206	ABS	1.9 D 51kw WJZ	ATE Teves Mk20 E
 206	ABS	1.9 D 51kw WJZ (03-..)	TEVES ABS Mk60
 206	ABS	1.9 D 52kw WJY	ABS
 206	ABS	1.9 D 52kw WJY	ATE Teves Mk20 E
 206	ABS	1.9 D 52kw WJY (03-..)	TEVES ABS Mk60
 206	ABS	2.0 16v 100kw RFN	ABS
 206	ABS	2.0 16v 100kw RFN	ATE Teves Mk20 E
 206	ABS	2.0 16v 100kw RFN (03-..)	TEVES ABS Mk60
 206	ABS	2.0 16v 102kw RFR	ABS
 206	ABS	2.0 16v 102kw RFR	ATE Teves Mk20 E
 206	ABS	2.0 16v 102kw RFR (03-..)	TEVES ABS Mk60
 206	ABS	2.0 HDI 66kw RHY	ABS
 206	ABS	2.0 HDI 66kw RHY	ATE Teves Mk20 E
 206	ABS	2.0 HDI 66kw RHY (03-..)	TEVES ABS Mk60
 206	ABS + TRACT. CONT	1.1 40kw HFY	Var.1
 206	ABS + TRACT. CONT	1.1 40kw HFY	Var.2
 206	ABS + TRACT. CONT	1.1 40kw HFY (03-..)	ATE-TEVES ESP Mk60
 206	ABS + TRACT. CONT	1.1 44kw HFX	Var.1
 206	ABS + TRACT. CONT	1.1 44kw HFX	Var.2
 206	ABS + TRACT. CONT	1.1 44kw HFX (03-..)	ATE-TEVES ESP Mk60
 206	ABS + TRACT. CONT	1.1 44kw HFZ	Var.1
 206	ABS + TRACT. CONT	1.1 44kw HFZ	Var.2
 206	ABS + TRACT. CONT	1.1 44kw HFZ (03-..)	ATE-TEVES ESP Mk60
 206	ABS + TRACT. CONT	1.4 16v 66kw KFU	Var.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 206	ABS + TRACT. CONT	1.4 16v 66kw KFU	Var.2
 206	ABS + TRACT. CONT	1.4 16v 66kw KFU (03-..)	ATE-TEVES ESP Mk60
 206	ABS + TRACT. CONT	1.4 55kw KFW	Var.1
 206	ABS + TRACT. CONT	1.4 55kw KFW	Var.2
 206	ABS + TRACT. CONT	1.4 55kw KFW (03-..)	ATE-TEVES ESP Mk60
 206	ABS + TRACT. CONT	1.4 55kw KFX	Var.1
 206	ABS + TRACT. CONT	1.4 55kw KFX	Var.2
 206	ABS + TRACT. CONT	1.4 55kw KFX (03-..)	ATE-TEVES ESP Mk60
 206	ABS + TRACT. CONT	1.4 HDI 50kw 8HX	Var.1
 206	ABS + TRACT. CONT	1.4 HDI 50kw 8HX	Var.2
 206	ABS + TRACT. CONT	1.4 HDI 50kw 8HX (03-..)	ATE-TEVES ESP Mk60
 206	ABS + TRACT. CONT	1.4 HDI 50kw 8HZ	Var.1
 206	ABS + TRACT. CONT	1.4 HDI 50kw 8HZ	Var.2
 206	ABS + TRACT. CONT	1.4 HDI 50kw 8HZ (03-..)	ATE-TEVES ESP Mk60
 206	ABS + TRACT. CONT	1.6 16v 80kw NFU	Var.1
 206	ABS + TRACT. CONT	1.6 16v 80kw NFU	Var.2
 206	ABS + TRACT. CONT	1.6 16v 80kw NFU (03-..)	ATE-TEVES ESP Mk60
 206	ABS + TRACT. CONT	1.6 66kw NFZ	Var.1
 206	ABS + TRACT. CONT	1.6 66kw NFZ	Var.2
 206	ABS + TRACT. CONT	1.6 66kw NFZ (03-..)	ATE-TEVES ESP Mk60
 206	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HY	Var.1
 206	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HY	Var.2
 206	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HY (03-..)	ATE-TEVES ESP Mk60
 206	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 206	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 206	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP (03-..)	ATE-TEVES ESP Mk60
 206	ABS + TRACT. CONT	1.9 D 51kw WJZ	Var.1
 206	ABS + TRACT. CONT	1.9 D 51kw WJZ	Var.2
 206	ABS + TRACT. CONT	1.9 D 51kw WJZ (03-..)	ATE-TEVES ESP Mk60
 206	ABS + TRACT. CONT	1.9 D 52kw WJY	Var.1
 206	ABS + TRACT. CONT	1.9 D 52kw WJY	Var.2
 206	ABS + TRACT. CONT	1.9 D 52kw WJY (03-..)	ATE-TEVES ESP Mk60
 206	ABS + TRACT. CONT	2.0 16v 100kw RFN	Var.1
 206	ABS + TRACT. CONT	2.0 16v 100kw RFN	Var.2
 206	ABS + TRACT. CONT	2.0 16v 100kw RFN (03-..)	ATE-TEVES ESP Mk60
 206	ABS + TRACT. CONT	2.0 16v 102kw RFR	Var.1
 206	ABS + TRACT. CONT	2.0 16v 102kw RFR	Var.2
 206	ABS + TRACT. CONT	2.0 16v 102kw RFR (03-..)	ATE-TEVES ESP Mk60
 206	ABS + TRACT. CONT	2.0 HDI 66kw RHY	Var.1
 206	ABS + TRACT. CONT	2.0 HDI 66kw RHY	Var.2
 206	ABS + TRACT. CONT	2.0 HDI 66kw RHY (03-..)	ATE-TEVES ESP Mk60
 206	AIRBAG	1.1 40kw HFY	AirBag CENTRAL
 206	AIRBAG	1.1 40kw HFY (03-..)	AKF- Autoliv AirBag ACU3
 206	AIRBAG	1.1 40kw HFY (03-..)	SIEMENS AirBag SAC CENT
 206	AIRBAG	1.1 40kw HFY (03-..)	TEMIC AirBag
 206	AIRBAG	1.1 40kw HFY (97-00)	AKF- Autoliv AirBag no SIDE AB
 206	AIRBAG	1.1 40kw HFY (97-00)	AKF- Autoliv Side AirBag Left Side
 206	AIRBAG	1.1 40kw HFY (97-00)	AKF- Autoliv Side AirBag Right Side
 206	AIRBAG	1.1 44kw HFX	AirBag CENTRAL
 206	AIRBAG	1.1 44kw HFX (03-..)	AKF- Autoliv AirBag ACU3
 206	AIRBAG	1.1 44kw HFX (03-..)	SIEMENS AirBag SAC CENT
 206	AIRBAG	1.1 44kw HFX (03-..)	TEMIC AirBag
 206	AIRBAG	1.1 44kw HFX (97-00)	AKF- Autoliv AirBag no SIDE AB
 206	AIRBAG	1.1 44kw HFX (97-00)	AKF- Autoliv Side AirBag Left Side
 206	AIRBAG	1.1 44kw HFX (97-00)	AKF- Autoliv Side AirBag Right Side
 206	AIRBAG	1.1 44kw HFZ	AirBag CENTRAL
 206	AIRBAG	1.1 44kw HFZ (03-..)	AKF- Autoliv AirBag ACU3
 206	AIRBAG	1.1 44kw HFZ (03-..)	SIEMENS AirBag SAC CENT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 206	AIRBAG	1.1 44kw HFZ (03-..)	TEMIC AirBag
 206	AIRBAG	1.1 44kw HFZ (97-00)	AKF- Autoliv Side AirBag Left Side
 206	AIRBAG	1.1 44kw HFZ (97-00)	AKF- Autoliv Side AirBag Right Side
 206	AIRBAG	1.1 44kw HFZ (97-01)	AKF- Autoliv AirBag no SIDE AB
 206	AIRBAG	1.1 44kw KFU (03-..)	AKF- Autoliv AirBag ACU3
 206	AIRBAG	1.4 16v 66kw KFU	AirBag CENTRAL
 206	AIRBAG	1.4 16v 66kw KFU (03-..)	SIEMENS AirBag SAC CENT
 206	AIRBAG	1.4 16v 66kw KFU (03-..)	TEMIC AirBag
 206	AIRBAG	1.4 16v 66kw KFU (97-00)	AKF- Autoliv AirBag no SIDE AB
 206	AIRBAG	1.4 16v 66kw KFU (97-00)	AKF- Autoliv Side AirBag Left Side
 206	AIRBAG	1.4 16v 66kw KFU (97-00)	AKF- Autoliv Side AirBag Right Side
 206	AIRBAG	1.4 55kw KFW	AirBag CENTRAL
 206	AIRBAG	1.4 55kw KFW (...01)	AKF- Autoliv AirBag no SIDE AB
 206	AIRBAG	1.4 55kw KFW (03-..)	AKF- Autoliv AirBag ACU3
 206	AIRBAG	1.4 55kw KFW (03-..)	SIEMENS AirBag SAC CENT
 206	AIRBAG	1.4 55kw KFW (03-..)	TEMIC AirBag
 206	AIRBAG	1.4 55kw KFW (97-00)	AKF- Autoliv Side AirBag Left Side
 206	AIRBAG	1.4 55kw KFW (97-00)	AKF- Autoliv Side AirBag Right Side
 206	AIRBAG	1.4 55kw KFX	AirBag CENTRAL
 206	AIRBAG	1.4 55kw KFX (03-..)	AKF- Autoliv AirBag ACU3
 206	AIRBAG	1.4 55kw KFX (03-..)	SIEMENS AirBag SAC CENT
 206	AIRBAG	1.4 55kw KFX (03-..)	TEMIC AirBag
 206	AIRBAG	1.4 55kw KFX (97-00)	AKF- Autoliv AirBag no SIDE AB
 206	AIRBAG	1.4 55kw KFX (97-00)	AKF- Autoliv Side AirBag Left Side
 206	AIRBAG	1.4 55kw KFX (97-00)	AKF- Autoliv Side AirBag Right Side
 206	AIRBAG	1.4 HDI 50kw 8HX	AirBag CENTRAL
 206	AIRBAG	1.4 HDI 50kw 8HX (03-..)	AKF- Autoliv AirBag ACU3
 206	AIRBAG	1.4 HDI 50kw 8HX (03-..)	SIEMENS AirBag SAC CENT
 206	AIRBAG	1.4 HDI 50kw 8HX (03-..)	TEMIC AirBag
 206	AIRBAG	1.4 HDI 50kw 8HX (97-00)	AKF- Autoliv AirBag no SIDE AB
 206	AIRBAG	1.4 HDI 50kw 8HX (97-00)	AKF- Autoliv Side AirBag Left Side
 206	AIRBAG	1.4 HDI 50kw 8HX (97-00)	AKF- Autoliv Side AirBag Right Side
 206	AIRBAG	1.4 HDI 50kw 8HZ	AirBag CENTRAL
 206	AIRBAG	1.4 HDI 50kw 8HZ (03-..)	AKF- Autoliv AirBag ACU3
 206	AIRBAG	1.4 HDI 50kw 8HZ (03-..)	SIEMENS AirBag SAC CENT
 206	AIRBAG	1.4 HDI 50kw 8HZ (03-..)	TEMIC AirBag
 206	AIRBAG	1.4 HDI 50kw 8HZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 206	AIRBAG	1.4 HDI 50kw 8HZ (97-00)	AKF- Autoliv Side AirBag Left Side
 206	AIRBAG	1.4 HDI 50kw 8HZ (97-00)	AKF- Autoliv Side AirBag Right Side
 206	AIRBAG	1.6 16v 80kw NFU	AirBag CENTRAL
 206	AIRBAG	1.6 16v 80kw NFU (...01)	AKF- Autoliv AirBag no SIDE AB
 206	AIRBAG	1.6 16v 80kw NFU (03-..)	AKF- Autoliv AirBag ACU3
 206	AIRBAG	1.6 16v 80kw NFU (03-..)	SIEMENS AirBag SAC CENT
 206	AIRBAG	1.6 16v 80kw NFU (03-..)	TEMIC AirBag
 206	AIRBAG	1.6 16v 80kw NFU (97-00)	AKF- Autoliv Side AirBag Left Side
 206	AIRBAG	1.6 16v 80kw NFU (97-00)	AKF- Autoliv Side AirBag Right Side
 206	AIRBAG	1.6 66kw NFZ	AirBag CENTRAL
 206	AIRBAG	1.6 66kw NFZ (03-..)	AKF- Autoliv AirBag ACU3
 206	AIRBAG	1.6 66kw NFZ (03-..)	SIEMENS AirBag SAC CENT
 206	AIRBAG	1.6 66kw NFZ (03-..)	TEMIC AirBag
 206	AIRBAG	1.6 66kw NFZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 206	AIRBAG	1.6 66kw NFZ (97-00)	AKF- Autoliv Side AirBag Left Side
 206	AIRBAG	1.6 66kw NFZ (97-00)	AKF- Autoliv Side AirBag Right Side
 206	AIRBAG	1.6 HDI 16v 80kw 9HY	AirBag CENTRAL
 206	AIRBAG	1.6 HDI 16v 80kw 9HY (03-..)	AKF- Autoliv AirBag ACU3
 206	AIRBAG	1.6 HDI 16v 80kw 9HY (03-..)	SIEMENS AirBag SAC CENT
 206	AIRBAG	1.6 HDI 16v 80kw 9HY (03-..)	TEMIC AirBag
 206	AIRBAG	1.6 HDI 16v 80kw 9HY (97-00)	AKF- Autoliv AirBag no SIDE AB

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 206	AIRBAG	1.6 HDI 16v 80kw 9HY (97-00)	AKF- Autoliv Side AirBag Left Side
 206	AIRBAG	1.6 HDI 16v 80kw 9HY (97-00)	AKF- Autoliv Side AirBag Right Side
 206	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL
 206	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP (03-..)	AKF- Autoliv AirBag ACU3
 206	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP (03-..)	SIEMENS AirBag SAC CENT
 206	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP (03-..)	TEMIC AirBag
 206	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP (97-00)	AKF- Autoliv AirBag no SIDE AB
 206	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP (97-00)	AKF- Autoliv Side AirBag Left Side
 206	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP (97-00)	AKF- Autoliv Side AirBag Right Side
 206	AIRBAG	1.9 D 51kw WJZ	AirBag CENTRAL
 206	AIRBAG	1.9 D 51kw WJZ (03-..)	AKF- Autoliv AirBag ACU3
 206	AIRBAG	1.9 D 51kw WJZ (03-..)	SIEMENS AirBag SAC CENT
 206	AIRBAG	1.9 D 51kw WJZ (03-..)	TEMIC AirBag
 206	AIRBAG	1.9 D 51kw WJZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 206	AIRBAG	1.9 D 51kw WJZ (97-00)	AKF- Autoliv Side AirBag Left Side
 206	AIRBAG	1.9 D 51kw WJZ (97-00)	AKF- Autoliv Side AirBag Right Side
 206	AIRBAG	1.9 D 52kw WJY	AirBag CENTRAL
 206	AIRBAG	1.9 D 52kw WJY (03-..)	AKF- Autoliv AirBag ACU3
 206	AIRBAG	1.9 D 52kw WJY (03-..)	SIEMENS AirBag SAC CENT
 206	AIRBAG	1.9 D 52kw WJY (03-..)	TEMIC AirBag
 206	AIRBAG	1.9 D 52kw WJY (97-00)	AKF- Autoliv AirBag no SIDE AB
 206	AIRBAG	1.9 D 52kw WJY (97-00)	AKF- Autoliv Side AirBag Left Side
 206	AIRBAG	1.9 D 52kw WJY (97-00)	AKF- Autoliv Side AirBag Right Side
 206	AIRBAG	2.0 16v 100kw RFN	AirBag CENTRAL
 206	AIRBAG	2.0 16v 100kw RFN (03-..)	AKF- Autoliv AirBag ACU3
 206	AIRBAG	2.0 16v 100kw RFN (03-..)	SIEMENS AirBag SAC CENT
 206	AIRBAG	2.0 16v 100kw RFN (03-..)	TEMIC AirBag
 206	AIRBAG	2.0 16v 100kw RFN (97-00)	AKF- Autoliv AirBag no SIDE AB
 206	AIRBAG	2.0 16v 100kw RFN (97-00)	AKF- Autoliv Side AirBag Left Side
 206	AIRBAG	2.0 16v 100kw RFN (97-00)	AKF- Autoliv Side AirBag Right Side
 206	AIRBAG	2.0 16v 102kw RFR	AirBag CENTRAL
 206	AIRBAG	2.0 16v 102kw RFR (03-..)	AKF- Autoliv AirBag ACU3
 206	AIRBAG	2.0 16v 102kw RFR (03-..)	SIEMENS AirBag SAC CENT
 206	AIRBAG	2.0 16v 102kw RFR (03-..)	TEMIC AirBag
 206	AIRBAG	2.0 16v 102kw RFR (97-00)	AKF- Autoliv AirBag no SIDE AB
 206	AIRBAG	2.0 16v 102kw RFR (97-00)	AKF- Autoliv Side AirBag Left Side
 206	AIRBAG	2.0 16v 102kw RFR (97-00)	AKF- Autoliv Side AirBag Right Side
 206	AIRBAG	2.0 HDI 66kw RHY	AirBag CENTRAL
 206	AIRBAG	2.0 HDI 66kw RHY (03-..)	AKF- Autoliv AirBag ACU3
 206	AIRBAG	2.0 HDI 66kw RHY (03-..)	SIEMENS AirBag SAC CENT
 206	AIRBAG	2.0 HDI 66kw RHY (03-..)	TEMIC AirBag
 206	AIRBAG	2.0 HDI 66kw RHY (97-00)	AKF- Autoliv AirBag no SIDE AB
 206	AIRBAG	2.0 HDI 66kw RHY (97-00)	AKF- Autoliv Side AirBag Left Side
 206	AIRBAG	2.0 HDI 66kw RHY (97-00)	AKF- Autoliv Side AirBag Right Side
 206	CHASSIS NETWORK	1.1 40kw HFY	BSI MUX (09/2001 ->)
 206	CHASSIS NETWORK	1.1 40kw HFY (..-01)	SIEMENS Body Computer
 206	CHASSIS NETWORK	1.1 40kw HFY (03-..)	SIEMENS Body Siemens
 206	CHASSIS NETWORK	1.1 44kw HFX	BSI MUX (09/2001 ->)
 206	CHASSIS NETWORK	1.1 44kw HFX	SIEMENS Body Computer
 206	CHASSIS NETWORK	1.1 44kw HFX (03-..)	SIEMENS Body Siemens
 206	CHASSIS NETWORK	1.1 44kw HFZ	BSI MUX (09/2001 ->)
 206	CHASSIS NETWORK	1.1 44kw HFZ	SIEMENS Body Computer
 206	CHASSIS NETWORK	1.1 44kw HFZ (03-..)	SIEMENS Body Siemens
 206	CHASSIS NETWORK	1.4 16v 66kw KFU	BSI MUX (09/2001 ->)
 206	CHASSIS NETWORK	1.4 16v 66kw KFU	SIEMENS Body Computer
 206	CHASSIS NETWORK	1.4 16v 66kw KFU (03-..)	SIEMENS Body Siemens
 206	CHASSIS NETWORK	1.4 55kw KFW	BSI MUX (09/2001 ->)
 206	CHASSIS NETWORK	1.4 55kw KFW (..-01)	SIEMENS Body Computer

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 206	CHASSIS NETWORK	1.4 55kw KFW (03-..)	SIEMENS Body Siemens
 206	CHASSIS NETWORK	1.4 55kw KFX	BSI MUX (09/2001 ->)
 206	CHASSIS NETWORK	1.4 55kw KFX	SIEMENS Body Computer
 206	CHASSIS NETWORK	1.4 55kw KFX (03-..)	SIEMENS Body Siemens
 206	CHASSIS NETWORK	1.4 HDI 50kw 8HX	BSI MUX (09/2001 ->)
 206	CHASSIS NETWORK	1.4 HDI 50kw 8HX	SIEMENS Body Computer
 206	CHASSIS NETWORK	1.4 HDI 50kw 8HX (03-..)	SIEMENS Body Siemens
 206	CHASSIS NETWORK	1.4 HDI 50kw 8HZ	BSI MUX (09/2001 ->)
 206	CHASSIS NETWORK	1.4 HDI 50kw 8HZ	SIEMENS Body Computer
 206	CHASSIS NETWORK	1.4 HDI 50kw 8HZ (03-..)	SIEMENS Body Siemens
 206	CHASSIS NETWORK	1.6 16v 80kw NFU	BSI MUX (09/2001 ->)
 206	CHASSIS NETWORK	1.6 16v 80kw NFU	SIEMENS Body Computer
 206	CHASSIS NETWORK	1.6 16v 80kw NFU (03-..)	SIEMENS Body Siemens
 206	CHASSIS NETWORK	1.6 66kw NFZ	BSI MUX (09/2001 ->)
 206	CHASSIS NETWORK	1.6 66kw NFZ	SIEMENS Body Computer
 206	CHASSIS NETWORK	1.6 66kw NFZ (03-..)	SIEMENS Body Siemens
 206	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY	BSI MUX (09/2001 ->)
 206	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY	SIEMENS Body Computer
 206	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY (03-..)	SIEMENS Body Siemens
 206	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	BSI MUX (09/2001 ->)
 206	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	SIEMENS Body Computer
 206	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP (03-..)	SIEMENS Body Siemens
 206	CHASSIS NETWORK	1.9 D 51kw WJZ	BSI MUX (09/2001 ->)
 206	CHASSIS NETWORK	1.9 D 51kw WJZ	SIEMENS Body Computer
 206	CHASSIS NETWORK	1.9 D 51kw WJZ (03-..)	SIEMENS Body Siemens
 206	CHASSIS NETWORK	1.9 D 52kw WJY	BSI MUX (09/2001 ->)
 206	CHASSIS NETWORK	1.9 D 52kw WJY	SIEMENS Body Computer
 206	CHASSIS NETWORK	1.9 D 52kw WJY (03-..)	SIEMENS Body Siemens
 206	CHASSIS NETWORK	2.0 16v 100kw RFN	BSI MUX (09/2001 ->)
 206	CHASSIS NETWORK	2.0 16v 100kw RFN	SIEMENS Body Computer
 206	CHASSIS NETWORK	2.0 16v 100kw RFN (03-..)	SIEMENS Body Siemens
 206	CHASSIS NETWORK	2.0 16v 102kw RFR	BSI MUX (09/2001 ->)
 206	CHASSIS NETWORK	2.0 16v 102kw RFR	SIEMENS Body Computer
 206	CHASSIS NETWORK	2.0 16v 102kw RFR (03-..)	SIEMENS Body Siemens
 206	CHASSIS NETWORK	2.0 HDI 66kw RHY	BSI MUX (09/2001 ->)
 206	CHASSIS NETWORK	2.0 HDI 66kw RHY	SIEMENS Body Computer
 206	CHASSIS NETWORK	2.0 HDI 66kw RHY (03-..)	SIEMENS Body Siemens
 206	CLIMA	1.1 40kw HFY	CLIMA AUTO
 206	CLIMA	1.1 40kw HFY (03-..)	Klimautomatik x.x
 206	CLIMA	1.1 44kw HFX	CLIMA AUTO
 206	CLIMA	1.1 44kw HFX (03-..)	Klimautomatik x.x
 206	CLIMA	1.1 44kw HFZ	CLIMA AUTO
 206	CLIMA	1.1 44kw HFZ (03-..)	Klimautomatik x.x
 206	CLIMA	1.4 16v 66kw KFU	CLIMA AUTO
 206	CLIMA	1.4 16v 66kw KFU (03-..)	Klimautomatik x.x
 206	CLIMA	1.4 55kw KFW	CLIMA AUTO
 206	CLIMA	1.4 55kw KFW (03-..)	Klimautomatik x.x
 206	CLIMA	1.4 55kw KFX	CLIMA AUTO
 206	CLIMA	1.4 55kw KFX (03-..)	Klimautomatik x.x
 206	CLIMA	1.4 HDI 50kw 8HX	CLIMA AUTO
 206	CLIMA	1.4 HDI 50kw 8HX (03-..)	Klimautomatik x.x
 206	CLIMA	1.4 HDI 50kw 8HZ	CLIMA AUTO
 206	CLIMA	1.4 HDI 50kw 8HZ (03-..)	Klimautomatik x.x
 206	CLIMA	1.6 16v 80kw NFU	CLIMA AUTO
 206	CLIMA	1.6 16v 80kw NFU (03-..)	Klimautomatik x.x
 206	CLIMA	1.6 66kw NFZ	CLIMA AUTO
 206	CLIMA	1.6 66kw NFZ (03-..)	Klimautomatik x.x
 206	CLIMA	1.6 HDI 16v 80kw 9HY	CLIMA AUTO

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 206	CLIMA	1.6 HDI 16v 80kw 9HY (03-..)	Klimautomatik x.x
 206	CLIMA	1.6 HDI 16v 80kw 9HZ-FAP	CLIMA AUTO
 206	CLIMA	1.6 HDI 16v 80kw 9HZ-FAP (03-..)	Klimautomatik x.x
 206	CLIMA	1.9 D 51kw WJZ	CLIMA AUTO
 206	CLIMA	1.9 D 51kw WJZ (03-..)	Klimautomatik x.x
 206	CLIMA	1.9 D 52kw WJY	CLIMA AUTO
 206	CLIMA	1.9 D 52kw WJY (03-..)	Klimautomatik x.x
 206	CLIMA	2.0 16v 100kw RFN	CLIMA AUTO
 206	CLIMA	2.0 16v 100kw RFN (03-..)	Klimautomatik x.x
 206	CLIMA	2.0 16v 102kw RFR	CLIMA AUTO
 206	CLIMA	2.0 16v 102kw RFR (03-..)	Klimautomatik x.x
 206	CLIMA	2.0 HDI 66kw RHY	CLIMA AUTO
 206	CLIMA	2.0 HDI 66kw RHY (03-..)	Klimautomatik x.x
 206	CONV. TOP/SUNROO	1.1 40kw HFY	ROOF
 206	CONV. TOP/SUNROO	1.1 44kw HFX	
 206	CONV. TOP/SUNROO	1.1 44kw HFZ	
 206	CONV. TOP/SUNROO	1.4 16v 66kw KFU	ROOF
 206	CONV. TOP/SUNROO	1.4 55kw KFW	
 206	CONV. TOP/SUNROO	1.4 55kw KFX	
 206	CONV. TOP/SUNROO	1.4 HDI 50kw 8HX	ROOF
 206	CONV. TOP/SUNROO	1.4 HDI 50kw 8HZ	
 206	CONV. TOP/SUNROO	1.6 16v 80kw NFU	
 206	CONV. TOP/SUNROO	1.6 66kw NFZ	ROOF
 206	CONV. TOP/SUNROO	1.6 HDI 16v 80kw 9HY	
 206	CONV. TOP/SUNROO	1.6 HDI 16v 80kw 9HZ-FAP	
 206	CONV. TOP/SUNROO	1.9 D 51kw WJZ	ROOF
 206	CONV. TOP/SUNROO	1.9 D 52kw WJY	
 206	CONV. TOP/SUNROO	2.0 16v 100kw RFN	
 206	CONV. TOP/SUNROO	2.0 16v 102kw RFR	JAEGER Dashboard
 206	CONV. TOP/SUNROO	2.0 HDI 66kw RHY	
 206	DASHBOARD	1.1 40kw HFY	
 206	DASHBOARD	1.1 40kw HFY (03-..)	JAEGER Dashboard
 206	DASHBOARD	1.1 44kw HFX	
 206	DASHBOARD	1.1 44kw HFX (03-..)	
 206	DASHBOARD	1.1 44kw HFZ	JAEGER Dashboard
 206	DASHBOARD	1.1 44kw HFZ (03-..)	
 206	DASHBOARD	1.4 16v 66kw KFU	
 206	DASHBOARD	1.4 16v 66kw KFU (03-..)	JAEGER Dashboard
 206	DASHBOARD	1.4 55kw KFW	
 206	DASHBOARD	1.4 55kw KFW (03-..)	
 206	DASHBOARD	1.4 55kw KFX	JAEGER Dashboard
 206	DASHBOARD	1.4 55kw KFX (03-..)	
 206	DASHBOARD	1.4 HDI 50kw 8HX	
 206	DASHBOARD	1.4 HDI 50kw 8HX (03-..)	JAEGER Dashboard
 206	DASHBOARD	1.4 HDI 50kw 8HZ	
 206	DASHBOARD	1.4 HDI 50kw 8HZ (03-..)	
 206	DASHBOARD	1.6 16v 80kw NFU	JAEGER Dashboard
 206	DASHBOARD	1.6 16v 80kw NFU (03-..)	
 206	DASHBOARD	1.6 66kw NFZ	
 206	DASHBOARD	1.6 66kw NFZ (03-..)	JAEGER Dashboard
 206	DASHBOARD	1.6 HDI 16v 80kw 9HY	
 206	DASHBOARD	1.6 HDI 16v 80kw 9HY (03-..)	
 206	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP	JAEGER Dashboard
 206	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP (03-..)	
 206	DASHBOARD	1.9 D 51kw WJZ	
 206	DASHBOARD	1.9 D 51kw WJZ (03-..)	JAEGER Dashboard
 206	DASHBOARD	1.9 D 52kw WJY	
 206	DASHBOARD	1.9 D 52kw WJY (03-..)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 206	DASHBOARD	2.0 16v 100kw RFN	
 206	DASHBOARD	2.0 16v 100kw RFN (03-..)	JAEGER Dashboard
 206	DASHBOARD	2.0 16v 102kw RFR	
 206	DASHBOARD	2.0 16v 102kw RFR (03-..)	JAEGER Dashboard
 206	DASHBOARD	2.0 HDI 66kw RHY	
 206	DASHBOARD	2.0 HDI 66kw RHY (03-..)	JAEGER Dashboard
 206	DIESEL ADDITION	1.6 HDI 16v 80kw 9HY	MARVAL
 206	DIESEL ADDITION	1.6 HDI 16v 80kw 9HZ-FAP	MARVAL
 206	DIESEL MANAGEMEN	1.9 D 51kw WJZ	LUCAS Diesel DCN2
 206	DIESEL MANAGEMEN	1.9 D 51kw WJZ	LUCAS Diesel DCN2
 206	DIESEL MANAGEMEN	1.9 D 52kw WJY	LUCAS Diesel DCN2
 206	DIESEL MANAGEMEN	1.9 D 52kw WJY	LUCAS Diesel DCN2
 206	ELECTRIC STEERING	1.1 40kw HFY	Var.1
 206	ELECTRIC STEERING	1.1 40kw HFY	Var.2
 206	ELECTRIC STEERING	1.1 40kw HFY	Var.3
 206	ELECTRIC STEERING	1.1 44kw HFX	Var.1
 206	ELECTRIC STEERING	1.1 44kw HFX	Var.2
 206	ELECTRIC STEERING	1.1 44kw HFX	Var.3
 206	ELECTRIC STEERING	1.1 44kw HFZ	Var.1
 206	ELECTRIC STEERING	1.1 44kw HFZ	Var.2
 206	ELECTRIC STEERING	1.1 44kw HFZ	Var.3
 206	ELECTRIC STEERING	1.4 16v 66kw KFU	Var.1
 206	ELECTRIC STEERING	1.4 16v 66kw KFU	Var.2
 206	ELECTRIC STEERING	1.4 16v 66kw KFU	Var.3
 206	ELECTRIC STEERING	1.4 55kw KFW	Var.1
 206	ELECTRIC STEERING	1.4 55kw KFW	Var.2
 206	ELECTRIC STEERING	1.4 55kw KFW	Var.3
 206	ELECTRIC STEERING	1.4 55kw KFX	Var.1
 206	ELECTRIC STEERING	1.4 55kw KFX	Var.2
 206	ELECTRIC STEERING	1.4 55kw KFX	Var.3
 206	ELECTRIC STEERING	1.4 HDI 50kw 8HX	Var.1
 206	ELECTRIC STEERING	1.4 HDI 50kw 8HX	Var.2
 206	ELECTRIC STEERING	1.4 HDI 50kw 8HX	Var.3
 206	ELECTRIC STEERING	1.4 HDI 50kw 8HZ	Var.1
 206	ELECTRIC STEERING	1.4 HDI 50kw 8HZ	Var.2
 206	ELECTRIC STEERING	1.4 HDI 50kw 8HZ	Var.3
 206	ELECTRIC STEERING	1.6 16v 80kw NFU	Var.1
 206	ELECTRIC STEERING	1.6 16v 80kw NFU	Var.2
 206	ELECTRIC STEERING	1.6 16v 80kw NFU	Var.3
 206	ELECTRIC STEERING	1.6 66kw NFZ	Var.1
 206	ELECTRIC STEERING	1.6 66kw NFZ	Var.2
 206	ELECTRIC STEERING	1.6 66kw NFZ	Var.3
 206	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HY	Var.1
 206	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HY	Var.2
 206	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HY	Var.3
 206	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 206	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 206	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	Var.3
 206	ELECTRIC STEERING	1.9 D 51kw WJZ	Var.1
 206	ELECTRIC STEERING	1.9 D 51kw WJZ	Var.2
 206	ELECTRIC STEERING	1.9 D 51kw WJZ	Var.3
 206	ELECTRIC STEERING	1.9 D 52kw WJY	Var.1
 206	ELECTRIC STEERING	1.9 D 52kw WJY	Var.2
 206	ELECTRIC STEERING	1.9 D 52kw WJY	Var.3
 206	ELECTRIC STEERING	2.0 16v 100kw RFN	Var.1
 206	ELECTRIC STEERING	2.0 16v 100kw RFN	Var.2
 206	ELECTRIC STEERING	2.0 16v 100kw RFN	Var.3
 206	ELECTRIC STEERING	2.0 16v 102kw RFR	Var.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 206	ELECTRIC STEERING	2.0 16v 102kw RFR	Var.2
 206	ELECTRIC STEERING	2.0 16v 102kw RFR	Var.3
 206	ELECTRIC STEERING	2.0 HDI 66kw RHY	Var.1
 206	ELECTRIC STEERING	2.0 HDI 66kw RHY	Var.2
 206	ELECTRIC STEERING	2.0 HDI 66kw RHY	Var.3
 206	ENGINE MANAGEME	1.1 40kw HFY	Marelli MM 1AP.80
 206	ENGINE MANAGEME	1.1 44kw HFX	BOSCH M 7.4.4
 206	ENGINE MANAGEME	1.1 44kw HFX	Marelli 4.8P
 206	ENGINE MANAGEME	1.1 44kw HFX	Marelli MM 48P
 206	ENGINE MANAGEME	1.1 44kw HFX (01-..)	EOBD
 206	ENGINE MANAGEME	1.1 44kw HFZ	Marelli MM 1AP.80
 206	ENGINE MANAGEME	1.4 55kw KFW	SAGEM S2000
 206	ENGINE MANAGEME	1.4 55kw KFW	SAGEM S2000
 206	ENGINE MANAGEME	1.4 55kw KFW (01-..)	EOBD
 206	ENGINE MANAGEME	1.4 55kw KFX	Marelli MM 1AP.81
 206	ENGINE MANAGEME	1.4 55kw KFX	SAGEM S2000
 206	ENGINE MANAGEME	1.4 HDI 50kw 8HX	BOSCH EDC 16 C3 Common Rail
 206	ENGINE MANAGEME	1.4 HDI 50kw 8HZ	BOSCH EDC 16 C34 Common Rail
 206	ENGINE MANAGEME	1.6 16v 80kw NFU	BOSCH ME 7.4.4
 206	ENGINE MANAGEME	1.6 16v 80kw NFU	BOSCH Motronic ME7.4.4
 206	ENGINE MANAGEME	1.6 66kw NFZ	BOSCH Motronic MP7.2
 206	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HY	Var.1
 206	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HY	Var.2
 206	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 206	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 206	ENGINE MANAGEME	2.0 16v 100kw RFN	Marelli MM 48P
 206	ENGINE MANAGEME	2.0 16v 102kw RFR	Marelli 4.8P
 206	ENGINE MANAGEME	2.0 HDI 66kw RHY	BOSCH EDC 15C2 DIE25 Common Rail
 206	ENGINE MANAGEME	2.0 HDI 66kw RHY	BOSCH EDC 15C2 DIE29 Common Rail
 206	ENGINE MANAGEME	2.0 HDI 66kw RHY	SIEMENS SID 801 Common Rail
 206	ENGINE MANAGEME	2.0 HDI 66kw RHY (...00)	BOSCH EDC 15 C2 Common Rail
 206	ENGINE MANAGEME	2.0 HDI 66kw RHY (03-..)	BOSCH EDC 15 C2 Common Rail
 206	KEY ENCODE	1.1 40kw HFY (03-..)	VALEO Body Siemens
 206	KEY ENCODE	1.1 44kw HFX (03-..)	VALEO Body Siemens
 206	KEY ENCODE	1.1 44kw HFZ (03-..)	VALEO Body Siemens
 206	KEY ENCODE	1.4 16v 66kw KFU (03-..)	VALEO Body Siemens
 206	KEY ENCODE	1.4 55kw KFW (03-..)	VALEO Body Siemens
 206	KEY ENCODE	1.4 55kw KFX (03-..)	VALEO Body Siemens
 206	KEY ENCODE	1.4 HDI 50kw 8HX (03-..)	VALEO Body Siemens
 206	KEY ENCODE	1.4 HDI 50kw 8HZ (03-..)	VALEO Body Siemens
 206	KEY ENCODE	1.6 16v 80kw NFU (03-..)	VALEO Body Siemens
 206	KEY ENCODE	1.6 66kw NFZ (03-..)	VALEO Body Siemens
 206	KEY ENCODE	1.6 HDI 16v 80kw 9HY (03-..)	VALEO Body Siemens
 206	KEY ENCODE	1.6 HDI 16v 80kw 9HZ-FAP (03-..)	VALEO Body Siemens
 206	KEY ENCODE	1.9 D 51kw WJZ (03-..)	VALEO Body Siemens
 206	KEY ENCODE	1.9 D 52kw WJY (03-..)	VALEO Body Siemens
 206	KEY ENCODE	2.0 16v 100kw RFN (03-..)	VALEO Body Siemens
 206	KEY ENCODE	2.0 16v 102kw RFR (03-..)	VALEO Body Siemens
 206	KEY ENCODE	2.0 HDI 66kw RHY (03-..)	VALEO Body Siemens
 206	MAINTENANCE	1.1 40kw HFY	VALEO Body Computer MANUAL
 206	MAINTENANCE	1.1 40kw HFY	Var.1
 206	MAINTENANCE	1.1 40kw HFY	Var.1
 206	MAINTENANCE	1.1 40kw HFY	Var.2
 206	MAINTENANCE	1.1 40kw HFY	Var.2
 206	MAINTENANCE	1.1 40kw HFY (03-..)	AKF- Autoliv AirBag ACU3
 206	MAINTENANCE	1.1 40kw HFY (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	1.1 40kw HFY (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	1.1 40kw HFY (03-..)	JAEGER Dashboard

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 206	MAINTENANCE	1.1 40kw HFY (03-..)	TEMIC AirBag
 206	MAINTENANCE	1.1 40kw HFY (98-00)	VDO MANUAL
 206	MAINTENANCE	1.1 44kw HFX	VALEO Body Computer MANUAL
 206	MAINTENANCE	1.1 44kw HFX	Var.1
 206	MAINTENANCE	1.1 44kw HFX	Var.1
 206	MAINTENANCE	1.1 44kw HFX	Var.2
 206	MAINTENANCE	1.1 44kw HFX	Var.2
 206	MAINTENANCE	1.1 44kw HFX (03-..)	AKF- Autoliv AirBag ACU3
 206	MAINTENANCE	1.1 44kw HFX (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	1.1 44kw HFX (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	1.1 44kw HFX (03-..)	JAEGER Dashboard
 206	MAINTENANCE	1.1 44kw HFX (03-..)	TEMIC AirBag
 206	MAINTENANCE	1.1 44kw HFX (98-00)	VDO MANUAL
 206	MAINTENANCE	1.1 44kw HFZ	VALEO Body Computer MANUAL
 206	MAINTENANCE	1.1 44kw HFZ	Var.1
 206	MAINTENANCE	1.1 44kw HFZ	Var.1
 206	MAINTENANCE	1.1 44kw HFZ	Var.2
 206	MAINTENANCE	1.1 44kw HFZ	Var.2
 206	MAINTENANCE	1.1 44kw HFZ (03-..)	AKF- Autoliv AirBag ACU3
 206	MAINTENANCE	1.1 44kw HFZ (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	1.1 44kw HFZ (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	1.1 44kw HFZ (03-..)	JAEGER Dashboard
 206	MAINTENANCE	1.1 44kw HFZ (03-..)	TEMIC AirBag
 206	MAINTENANCE	1.1 44kw HFZ (98-00)	VDO MANUAL
 206	MAINTENANCE	1.1 44kw KFU (03-..)	AKF- Autoliv AirBag ACU3
 206	MAINTENANCE	1.4 16v 66kw KFU	VALEO Body Computer MANUAL
 206	MAINTENANCE	1.4 16v 66kw KFU	Var.1
 206	MAINTENANCE	1.4 16v 66kw KFU	Var.1
 206	MAINTENANCE	1.4 16v 66kw KFU	Var.2
 206	MAINTENANCE	1.4 16v 66kw KFU	Var.2
 206	MAINTENANCE	1.4 16v 66kw KFU (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	1.4 16v 66kw KFU (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	1.4 16v 66kw KFU (03-..)	JAEGER Dashboard
 206	MAINTENANCE	1.4 16v 66kw KFU (03-..)	TEMIC AirBag
 206	MAINTENANCE	1.4 16v 66kw KFU (98-00)	VDO MANUAL
 206	MAINTENANCE	1.4 55kw KFW	VALEO Body Computer MANUAL
 206	MAINTENANCE	1.4 55kw KFW	Var.1
 206	MAINTENANCE	1.4 55kw KFW	Var.1
 206	MAINTENANCE	1.4 55kw KFW	Var.2
 206	MAINTENANCE	1.4 55kw KFW	Var.2
 206	MAINTENANCE	1.4 55kw KFW (03-..)	AKF- Autoliv AirBag ACU3
 206	MAINTENANCE	1.4 55kw KFW (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	1.4 55kw KFW (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	1.4 55kw KFW (03-..)	JAEGER Dashboard
 206	MAINTENANCE	1.4 55kw KFW (03-..)	TEMIC AirBag
 206	MAINTENANCE	1.4 55kw KFW (98-00)	VDO MANUAL
 206	MAINTENANCE	1.4 55kw KFX	VALEO Body Computer MANUAL
 206	MAINTENANCE	1.4 55kw KFX	Var.1
 206	MAINTENANCE	1.4 55kw KFX	Var.1
 206	MAINTENANCE	1.4 55kw KFX	Var.2
 206	MAINTENANCE	1.4 55kw KFX	Var.2
 206	MAINTENANCE	1.4 55kw KFX (03-..)	AKF- Autoliv AirBag ACU3
 206	MAINTENANCE	1.4 55kw KFX (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	1.4 55kw KFX (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	1.4 55kw KFX (03-..)	JAEGER Dashboard
 206	MAINTENANCE	1.4 55kw KFX (03-..)	TEMIC AirBag
 206	MAINTENANCE	1.4 55kw KFX (98-00)	VDO MANUAL
 206	MAINTENANCE	1.4 HDI 50kw 8HX	VALEO Body Computer MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 206	MAINTENANCE	1.4 HDI 50kw 8HX	Var.1
 206	MAINTENANCE	1.4 HDI 50kw 8HX	Var.1
 206	MAINTENANCE	1.4 HDI 50kw 8HX	Var.2
 206	MAINTENANCE	1.4 HDI 50kw 8HX	Var.2
 206	MAINTENANCE	1.4 HDI 50kw 8HX (03-..)	AKF- Autoliv AirBag ACU3
 206	MAINTENANCE	1.4 HDI 50kw 8HX (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	1.4 HDI 50kw 8HX (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	1.4 HDI 50kw 8HX (03-..)	JAEGER Dashboard
 206	MAINTENANCE	1.4 HDI 50kw 8HX (03-..)	TEMIC AirBag
 206	MAINTENANCE	1.4 HDI 50kw 8HX (98-00)	VDO MANUAL
 206	MAINTENANCE	1.4 HDI 50kw 8HZ	VALEO Body Computer MANUAL
 206	MAINTENANCE	1.4 HDI 50kw 8HZ	Var.1
 206	MAINTENANCE	1.4 HDI 50kw 8HZ	Var.1
 206	MAINTENANCE	1.4 HDI 50kw 8HZ	Var.2
 206	MAINTENANCE	1.4 HDI 50kw 8HZ	Var.2
 206	MAINTENANCE	1.4 HDI 50kw 8HZ (03-..)	AKF- Autoliv AirBag ACU3
 206	MAINTENANCE	1.4 HDI 50kw 8HZ (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	1.4 HDI 50kw 8HZ (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	1.4 HDI 50kw 8HZ (03-..)	JAEGER Dashboard
 206	MAINTENANCE	1.4 HDI 50kw 8HZ (03-..)	TEMIC AirBag
 206	MAINTENANCE	1.4 HDI 50kw 8HZ (98-00)	VDO MANUAL
 206	MAINTENANCE	1.6 16v 80kw NFU	VALEO Body Computer MANUAL
 206	MAINTENANCE	1.6 16v 80kw NFU	Var.1
 206	MAINTENANCE	1.6 16v 80kw NFU	Var.1
 206	MAINTENANCE	1.6 16v 80kw NFU	Var.2
 206	MAINTENANCE	1.6 16v 80kw NFU	Var.2
 206	MAINTENANCE	1.6 16v 80kw NFU (03-..)	AKF- Autoliv AirBag ACU3
 206	MAINTENANCE	1.6 16v 80kw NFU (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	1.6 16v 80kw NFU (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	1.6 16v 80kw NFU (03-..)	JAEGER Dashboard
 206	MAINTENANCE	1.6 16v 80kw NFU (03-..)	TEMIC AirBag
 206	MAINTENANCE	1.6 16v 80kw NFU (98-00)	VDO MANUAL
 206	MAINTENANCE	1.6 66kw NFZ	VALEO Body Computer MANUAL
 206	MAINTENANCE	1.6 66kw NFZ	Var.1
 206	MAINTENANCE	1.6 66kw NFZ	Var.1
 206	MAINTENANCE	1.6 66kw NFZ	Var.2
 206	MAINTENANCE	1.6 66kw NFZ	Var.2
 206	MAINTENANCE	1.6 66kw NFZ (03-..)	AKF- Autoliv AirBag ACU3
 206	MAINTENANCE	1.6 66kw NFZ (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	1.6 66kw NFZ (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	1.6 66kw NFZ (03-..)	JAEGER Dashboard
 206	MAINTENANCE	1.6 66kw NFZ (03-..)	TEMIC AirBag
 206	MAINTENANCE	1.6 66kw NFZ (98-00)	VDO MANUAL
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HY	MARVAL
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HY	MARVAL
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HY	VALEO Body Computer MANUAL
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.1
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.1
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.1
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.1
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.1
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.1
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.2
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.2
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.2
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.2
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.2
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.2
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.2
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HY (03-..)	AKF- Autoliv AirBag ACU3
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HY (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HY (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HY (03-..)	JAEGER Dashboard
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HY (03-..)	TEMIC AirBag
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HY (98-00)	VDO MANUAL
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	MARVAL
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	MARVAL
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	VALEO Body Computer MANUAL
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (03-..)	AKF- Autoliv AirBag ACU3
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (03-..)	JAEGER Dashboard
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (03-..)	TEMIC AirBag
 206	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (98-00)	VDO MANUAL
 206	MAINTENANCE	1.9 D 51kw WJZ	VALEO Body Computer MANUAL
 206	MAINTENANCE	1.9 D 51kw WJZ	Var.1
 206	MAINTENANCE	1.9 D 51kw WJZ	Var.1
 206	MAINTENANCE	1.9 D 51kw WJZ	Var.2
 206	MAINTENANCE	1.9 D 51kw WJZ	Var.2
 206	MAINTENANCE	1.9 D 51kw WJZ (03-..)	AKF- Autoliv AirBag ACU3
 206	MAINTENANCE	1.9 D 51kw WJZ (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	1.9 D 51kw WJZ (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	1.9 D 51kw WJZ (03-..)	JAEGER Dashboard
 206	MAINTENANCE	1.9 D 51kw WJZ (03-..)	TEMIC AirBag
 206	MAINTENANCE	1.9 D 51kw WJZ (98-00)	VDO MANUAL
 206	MAINTENANCE	1.9 D 52kw WJY	VALEO Body Computer MANUAL
 206	MAINTENANCE	1.9 D 52kw WJY	Var.1
 206	MAINTENANCE	1.9 D 52kw WJY	Var.1
 206	MAINTENANCE	1.9 D 52kw WJY	Var.2
 206	MAINTENANCE	1.9 D 52kw WJY	Var.2
 206	MAINTENANCE	1.9 D 52kw WJY (03-..)	AKF- Autoliv AirBag ACU3
 206	MAINTENANCE	1.9 D 52kw WJY (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	1.9 D 52kw WJY (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	1.9 D 52kw WJY (03-..)	JAEGER Dashboard
 206	MAINTENANCE	1.9 D 52kw WJY (03-..)	TEMIC AirBag

Systems supported by ECUREADER / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 206	MAINTENANCE	1.9 D 52kw WJY (98-00)	VDO MANUAL
 206	MAINTENANCE	2.0 16v 100kw RFN	VALEO Body Computer MANUAL
 206	MAINTENANCE	2.0 16v 100kw RFN	Var.1
 206	MAINTENANCE	2.0 16v 100kw RFN	Var.1
 206	MAINTENANCE	2.0 16v 100kw RFN	Var.2
 206	MAINTENANCE	2.0 16v 100kw RFN	Var.2
 206	MAINTENANCE	2.0 16v 100kw RFN (03-..)	AKF- Autoliv AirBag ACU3
 206	MAINTENANCE	2.0 16v 100kw RFN (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	2.0 16v 100kw RFN (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	2.0 16v 100kw RFN (03-..)	JAEGER Dashboard
 206	MAINTENANCE	2.0 16v 100kw RFN (03-..)	TEMIC AirBag
 206	MAINTENANCE	2.0 16v 100kw RFN (98-00)	VDO MANUAL
 206	MAINTENANCE	2.0 16v 102kw RFR	VALEO Body Computer MANUAL
 206	MAINTENANCE	2.0 16v 102kw RFR	Var.1
 206	MAINTENANCE	2.0 16v 102kw RFR	Var.1
 206	MAINTENANCE	2.0 16v 102kw RFR	Var.2
 206	MAINTENANCE	2.0 16v 102kw RFR	Var.2
 206	MAINTENANCE	2.0 16v 102kw RFR (03-..)	AKF- Autoliv AirBag ACU3
 206	MAINTENANCE	2.0 16v 102kw RFR (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	2.0 16v 102kw RFR (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	2.0 16v 102kw RFR (03-..)	JAEGER Dashboard
 206	MAINTENANCE	2.0 16v 102kw RFR (03-..)	TEMIC AirBag
 206	MAINTENANCE	2.0 16v 102kw RFR (98-00)	VDO MANUAL
 206	MAINTENANCE	2.0 HDI 66kw RHY	BOSCH EDC 15C2 DIE25 Common Rail
 206	MAINTENANCE	2.0 HDI 66kw RHY	BOSCH EDC 15C2 DIE29 Common Rail
 206	MAINTENANCE	2.0 HDI 66kw RHY	VALEO Body Computer MANUAL
 206	MAINTENANCE	2.0 HDI 66kw RHY	Var.1
 206	MAINTENANCE	2.0 HDI 66kw RHY	Var.1
 206	MAINTENANCE	2.0 HDI 66kw RHY	Var.2
 206	MAINTENANCE	2.0 HDI 66kw RHY	Var.2
 206	MAINTENANCE	2.0 HDI 66kw RHY (03-..)	AKF- Autoliv AirBag ACU3
 206	MAINTENANCE	2.0 HDI 66kw RHY (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	2.0 HDI 66kw RHY (03-..)	ATE-TEVES ESP Mk60
 206	MAINTENANCE	2.0 HDI 66kw RHY (03-..)	BOSCH EDC 15 C2 Common Rail
 206	MAINTENANCE	2.0 HDI 66kw RHY (03-..)	JAEGER Dashboard
 206	MAINTENANCE	2.0 HDI 66kw RHY (03-..)	TEMIC AirBag
 206	MAINTENANCE	2.0 HDI 66kw RHY (98-00)	VDO MANUAL
 206	RADIO / CD	1.1 40kw HFY	CLARION AudioSystem
 206	RADIO / CD	1.1 40kw HFY	PHILIPS AudioSystem
 206	RADIO / CD	1.1 40kw HFY	Var.1
 206	RADIO / CD	1.1 40kw HFY	Var.2
 206	RADIO / CD	1.1 40kw HFY	Var.3
 206	RADIO / CD	1.1 40kw HFY	Var.4
 206	RADIO / CD	1.1 40kw HFY	VDO AudioSystem
 206	RADIO / CD	1.1 44kw HFX	CLARION AudioSystem
 206	RADIO / CD	1.1 44kw HFX	PHILIPS AudioSystem
 206	RADIO / CD	1.1 44kw HFX	Var.1
 206	RADIO / CD	1.1 44kw HFX	Var.2
 206	RADIO / CD	1.1 44kw HFX	Var.3
 206	RADIO / CD	1.1 44kw HFX	Var.4
 206	RADIO / CD	1.1 44kw HFX	VDO AudioSystem
 206	RADIO / CD	1.1 44kw HFZ	CLARION AudioSystem
 206	RADIO / CD	1.1 44kw HFZ	PHILIPS AudioSystem
 206	RADIO / CD	1.1 44kw HFZ	Var.1
 206	RADIO / CD	1.1 44kw HFZ	Var.2
 206	RADIO / CD	1.1 44kw HFZ	Var.3
 206	RADIO / CD	1.1 44kw HFZ	Var.4
 206	RADIO / CD	1.1 44kw HFZ	VDO AudioSystem

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 206	RADIO / CD	1.4 16v 66kw KFU	CLARION AudioSystem
 206	RADIO / CD	1.4 16v 66kw KFU	PHILIPS AudioSystem
 206	RADIO / CD	1.4 16v 66kw KFU	Var.1
 206	RADIO / CD	1.4 16v 66kw KFU	Var.2
 206	RADIO / CD	1.4 16v 66kw KFU	Var.3
 206	RADIO / CD	1.4 16v 66kw KFU	Var.4
 206	RADIO / CD	1.4 16v 66kw KFU	VDO AudioSystem
 206	RADIO / CD	1.4 55kw KFW	CLARION AudioSystem
 206	RADIO / CD	1.4 55kw KFW	PHILIPS AudioSystem
 206	RADIO / CD	1.4 55kw KFW	Var.1
 206	RADIO / CD	1.4 55kw KFW	Var.2
 206	RADIO / CD	1.4 55kw KFW	Var.3
 206	RADIO / CD	1.4 55kw KFW	Var.4
 206	RADIO / CD	1.4 55kw KFW	VDO AudioSystem
 206	RADIO / CD	1.4 55kw KFX	CLARION AudioSystem
 206	RADIO / CD	1.4 55kw KFX	PHILIPS AudioSystem
 206	RADIO / CD	1.4 55kw KFX	Var.1
 206	RADIO / CD	1.4 55kw KFX	Var.2
 206	RADIO / CD	1.4 55kw KFX	Var.3
 206	RADIO / CD	1.4 55kw KFX	Var.4
 206	RADIO / CD	1.4 55kw KFX	VDO AudioSystem
 206	RADIO / CD	1.4 HDI 50kw 8HX	CLARION AudioSystem
 206	RADIO / CD	1.4 HDI 50kw 8HX	PHILIPS AudioSystem
 206	RADIO / CD	1.4 HDI 50kw 8HX	Var.1
 206	RADIO / CD	1.4 HDI 50kw 8HX	Var.2
 206	RADIO / CD	1.4 HDI 50kw 8HX	Var.3
 206	RADIO / CD	1.4 HDI 50kw 8HX	Var.4
 206	RADIO / CD	1.4 HDI 50kw 8HX	VDO AudioSystem
 206	RADIO / CD	1.4 HDI 50kw 8HZ	CLARION AudioSystem
 206	RADIO / CD	1.4 HDI 50kw 8HZ	PHILIPS AudioSystem
 206	RADIO / CD	1.4 HDI 50kw 8HZ	Var.1
 206	RADIO / CD	1.4 HDI 50kw 8HZ	Var.2
 206	RADIO / CD	1.4 HDI 50kw 8HZ	Var.3
 206	RADIO / CD	1.4 HDI 50kw 8HZ	Var.4
 206	RADIO / CD	1.4 HDI 50kw 8HZ	VDO AudioSystem
 206	RADIO / CD	1.6 16v 80kw NFU	CLARION AudioSystem
 206	RADIO / CD	1.6 16v 80kw NFU	PHILIPS AudioSystem
 206	RADIO / CD	1.6 16v 80kw NFU	Var.1
 206	RADIO / CD	1.6 16v 80kw NFU	Var.2
 206	RADIO / CD	1.6 16v 80kw NFU	Var.3
 206	RADIO / CD	1.6 16v 80kw NFU	Var.4
 206	RADIO / CD	1.6 16v 80kw NFU	VDO AudioSystem
 206	RADIO / CD	1.6 66kw NFZ	CLARION AudioSystem
 206	RADIO / CD	1.6 66kw NFZ	PHILIPS AudioSystem
 206	RADIO / CD	1.6 66kw NFZ	Var.1
 206	RADIO / CD	1.6 66kw NFZ	Var.2
 206	RADIO / CD	1.6 66kw NFZ	Var.3
 206	RADIO / CD	1.6 66kw NFZ	Var.4
 206	RADIO / CD	1.6 66kw NFZ	VDO AudioSystem
 206	RADIO / CD	1.6 HDI 16v 80kw 9HY	CLARION AudioSystem
 206	RADIO / CD	1.6 HDI 16v 80kw 9HY	PHILIPS AudioSystem
 206	RADIO / CD	1.6 HDI 16v 80kw 9HY	Var.1
 206	RADIO / CD	1.6 HDI 16v 80kw 9HY	Var.2
 206	RADIO / CD	1.6 HDI 16v 80kw 9HY	Var.3
 206	RADIO / CD	1.6 HDI 16v 80kw 9HY	Var.4
 206	RADIO / CD	1.6 HDI 16v 80kw 9HY	VDO AudioSystem
 206	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	CLARION AudioSystem
 206	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	PHILIPS AudioSystem

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 206	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 206	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 206	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Var.3
 206	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Var.4
 206	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	VDO AudioSystem
 206	RADIO / CD	1.9 D 51kw WJZ	CLARION AudioSystem
 206	RADIO / CD	1.9 D 51kw WJZ	PHILIPS AudioSystem
 206	RADIO / CD	1.9 D 51kw WJZ	Var.1
 206	RADIO / CD	1.9 D 51kw WJZ	Var.2
 206	RADIO / CD	1.9 D 51kw WJZ	Var.3
 206	RADIO / CD	1.9 D 51kw WJZ	Var.4
 206	RADIO / CD	1.9 D 51kw WJZ	VDO AudioSystem
 206	RADIO / CD	1.9 D 52kw WJY	CLARION AudioSystem
 206	RADIO / CD	1.9 D 52kw WJY	PHILIPS AudioSystem
 206	RADIO / CD	1.9 D 52kw WJY	Var.1
 206	RADIO / CD	1.9 D 52kw WJY	Var.2
 206	RADIO / CD	1.9 D 52kw WJY	Var.3
 206	RADIO / CD	1.9 D 52kw WJY	Var.4
 206	RADIO / CD	1.9 D 52kw WJY	VDO AudioSystem
 206	RADIO / CD	2.0 16v 100kw RFN	CLARION AudioSystem
 206	RADIO / CD	2.0 16v 100kw RFN	PHILIPS AudioSystem
 206	RADIO / CD	2.0 16v 100kw RFN	Var.1
 206	RADIO / CD	2.0 16v 100kw RFN	Var.2
 206	RADIO / CD	2.0 16v 100kw RFN	Var.3
 206	RADIO / CD	2.0 16v 100kw RFN	Var.4
 206	RADIO / CD	2.0 16v 100kw RFN	VDO AudioSystem
 206	RADIO / CD	2.0 16v 102kw RFR	CLARION AudioSystem
 206	RADIO / CD	2.0 16v 102kw RFR	PHILIPS AudioSystem
 206	RADIO / CD	2.0 16v 102kw RFR	Var.1
 206	RADIO / CD	2.0 16v 102kw RFR	Var.2
 206	RADIO / CD	2.0 16v 102kw RFR	Var.3
 206	RADIO / CD	2.0 16v 102kw RFR	Var.4
 206	RADIO / CD	2.0 16v 102kw RFR	VDO AudioSystem
 206	RADIO / CD	2.0 HDI 66kw RHY	CLARION AudioSystem
 206	RADIO / CD	2.0 HDI 66kw RHY	PHILIPS AudioSystem
 206	RADIO / CD	2.0 HDI 66kw RHY	Var.1
 206	RADIO / CD	2.0 HDI 66kw RHY	Var.2
 206	RADIO / CD	2.0 HDI 66kw RHY	Var.3
 206	RADIO / CD	2.0 HDI 66kw RHY	Var.4
 206	RADIO / CD	2.0 HDI 66kw RHY	VDO AudioSystem
 206	RAIN-LUMINOSITY S	1.1 40kw HFY	KOSTAL WSS
 206	RAIN-LUMINOSITY S	1.1 44kw HFX	KOSTAL WSS
 206	RAIN-LUMINOSITY S	1.1 44kw HFZ	KOSTAL WSS
 206	RAIN-LUMINOSITY S	1.4 16v 66kw KFU	KOSTAL WSS
 206	RAIN-LUMINOSITY S	1.4 55kw KFW	KOSTAL WSS
 206	RAIN-LUMINOSITY S	1.4 55kw KFX	KOSTAL WSS
 206	RAIN-LUMINOSITY S	1.4 HDI 50kw 8HX	KOSTAL WSS
 206	RAIN-LUMINOSITY S	1.4 HDI 50kw 8HZ	KOSTAL WSS
 206	RAIN-LUMINOSITY S	1.6 16v 80kw NFU	KOSTAL WSS
 206	RAIN-LUMINOSITY S	1.6 66kw NFZ	KOSTAL WSS
 206	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HY	KOSTAL WSS
 206	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HZ-FAP	KOSTAL WSS
 206	RAIN-LUMINOSITY S	1.9 D 51kw WJZ	KOSTAL WSS
 206	RAIN-LUMINOSITY S	1.9 D 52kw WJY	KOSTAL WSS
 206	RAIN-LUMINOSITY S	2.0 16v 100kw RFN	KOSTAL WSS
 206	RAIN-LUMINOSITY S	2.0 16v 102kw RFR	KOSTAL WSS
 206	RAIN-LUMINOSITY S	2.0 HDI 66kw RHY	KOSTAL WSS
 206	REMOTE CONTROL E	1.1 40kw HFY	VALEO Body Computer MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 206	REMOTE CONTROL E	1.1 44kw HFX	VALEO Body Computer MANUAL
 206	REMOTE CONTROL E	1.1 44kw HFZ	VALEO Body Computer MANUAL
 206	REMOTE CONTROL E	1.4 16v 66kw KFU	VALEO Body Computer MANUAL
 206	REMOTE CONTROL E	1.4 55kw KFW	VALEO Body Computer MANUAL
 206	REMOTE CONTROL E	1.4 55kw KFX	VALEO Body Computer MANUAL
 206	REMOTE CONTROL E	1.4 HDI 50kw 8HX	VALEO Body Computer MANUAL
 206	REMOTE CONTROL E	1.4 HDI 50kw 8HZ	VALEO Body Computer MANUAL
 206	REMOTE CONTROL E	1.6 16v 80kw NFU	VALEO Body Computer MANUAL
 206	REMOTE CONTROL E	1.6 66kw NFZ	VALEO Body Computer MANUAL
 206	REMOTE CONTROL E	1.6 HDI 16v 80kw 9HY	VALEO Body Computer MANUAL
 206	REMOTE CONTROL E	1.6 HDI 16v 80kw 9HZ-FAP	VALEO Body Computer MANUAL
 206	REMOTE CONTROL E	1.9 D 51kw WJZ	VALEO Body Computer MANUAL
 206	REMOTE CONTROL E	1.9 D 52kw WJY	VALEO Body Computer MANUAL
 206	REMOTE CONTROL E	2.0 16v 100kw RFN	VALEO Body Computer MANUAL
 206	REMOTE CONTROL E	2.0 16v 102kw RFR	VALEO Body Computer MANUAL
 206	REMOTE CONTROL E	2.0 HDI 66kw RHY	VALEO Body Computer MANUAL
 206	SERVICE LIGHT RES	1.1 40kw HFY (98-00)	VDO MANUAL
 206	SERVICE LIGHT RES	1.1 44kw HFX (98-00)	VDO MANUAL
 206	SERVICE LIGHT RES	1.1 44kw HFZ (98-00)	VDO MANUAL
 206	SERVICE LIGHT RES	1.4 16v 66kw KFU (98-00)	VDO MANUAL
 206	SERVICE LIGHT RES	1.4 55kw KFW (98-00)	VDO MANUAL
 206	SERVICE LIGHT RES	1.4 55kw KFX (98-00)	VDO MANUAL
 206	SERVICE LIGHT RES	1.4 HDI 50kw 8HX (98-00)	VDO MANUAL
 206	SERVICE LIGHT RES	1.4 HDI 50kw 8HZ (98-00)	VDO MANUAL
 206	SERVICE LIGHT RES	1.6 16v 80kw NFU (98-00)	VDO MANUAL
 206	SERVICE LIGHT RES	1.6 66kw NFZ (98-00)	VDO MANUAL
 206	SERVICE LIGHT RES	1.6 HDI 16v 80kw 9HY (98-00)	VDO MANUAL
 206	SERVICE LIGHT RES	1.6 HDI 16v 80kw 9HZ-FAP (98-00)	VDO MANUAL
 206	SERVICE LIGHT RES	1.9 D 51kw WJZ (98-00)	VDO MANUAL
 206	SERVICE LIGHT RES	1.9 D 52kw WJY (98-00)	VDO MANUAL
 206	SERVICE LIGHT RES	2.0 16v 100kw RFN (98-00)	VDO MANUAL
 206	SERVICE LIGHT RES	2.0 16v 102kw RFR (98-00)	VDO MANUAL
 206	SERVICE LIGHT RES	2.0 HDI 66kw RHY (98-00)	VDO MANUAL
 206	STEERING COLUMN	1.1 40kw HFY	T
 206	STEERING COLUMN	1.1 44kw HFX	
 206	STEERING COLUMN	1.1 44kw HFZ	
 206	STEERING COLUMN	1.4 16v 66kw KFU	
 206	STEERING COLUMN	1.4 55kw KFW	
 206	STEERING COLUMN	1.4 55kw KFX	
 206	STEERING COLUMN	1.4 HDI 50kw 8HX	
 206	STEERING COLUMN	1.4 HDI 50kw 8HZ	
 206	STEERING COLUMN	1.6 16v 80kw NFU	
 206	STEERING COLUMN	1.6 66kw NFZ	
 206	STEERING COLUMN	1.6 HDI 16v 80kw 9HY	
 206	STEERING COLUMN	1.6 HDI 16v 80kw 9HZ-FAP	
 206	STEERING COLUMN	1.9 D 51kw WJZ	
 206	STEERING COLUMN	1.9 D 52kw WJY	
 206	STEERING COLUMN	2.0 16v 100kw RFN	
 206	STEERING COLUMN	2.0 16v 102kw RFR	
 206	STEERING COLUMN	2.0 HDI 66kw RHY	
 206	SWITCHLIGHT MODU	1.1 40kw HFY	EATON
 206	SWITCHLIGHT MODU	1.1 44kw HFX	EATON
 206	SWITCHLIGHT MODU	1.1 44kw HFZ	EATON
 206	SWITCHLIGHT MODU	1.4 16v 66kw KFU	EATON
 206	SWITCHLIGHT MODU	1.4 55kw KFW	EATON
 206	SWITCHLIGHT MODU	1.4 55kw KFX	EATON
 206	SWITCHLIGHT MODU	1.4 HDI 50kw 8HX	EATON
 206	SWITCHLIGHT MODU	1.4 HDI 50kw 8HZ	EATON

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 206	SWITCHLIGHT MODU	1.6 16v 80kw NFU	EATON
 206	SWITCHLIGHT MODU	1.6 66kw NFZ	EATON
 206	SWITCHLIGHT MODU	1.6 HDI 16v 80kw 9HY	EATON
 206	SWITCHLIGHT MODU	1.6 HDI 16v 80kw 9HZ-FAP	EATON
 206	SWITCHLIGHT MODU	1.9 D 51kw WJZ	EATON
 206	SWITCHLIGHT MODU	1.9 D 52kw WJY	EATON
 206	SWITCHLIGHT MODU	2.0 16v 100kw RFN	EATON
 206	SWITCHLIGHT MODU	2.0 16v 102kw RFR	EATON
 206	SWITCHLIGHT MODU	2.0 HDI 66kw RHY	EATON
 206	VISUAL./TELEMATIC	1.1 40kw HFY	Display
 206	VISUAL./TELEMATIC	1.1 40kw HFY	SAGEM JCAE
 206	VISUAL./TELEMATIC	1.1 44kw HFX	Display
 206	VISUAL./TELEMATIC	1.1 44kw HFX	SAGEM JCAE
 206	VISUAL./TELEMATIC	1.1 44kw HFZ	Display
 206	VISUAL./TELEMATIC	1.1 44kw HFZ	SAGEM JCAE
 206	VISUAL./TELEMATIC	1.4 16v 66kw KFU	Display
 206	VISUAL./TELEMATIC	1.4 16v 66kw KFU	SAGEM JCAE
 206	VISUAL./TELEMATIC	1.4 55kw KFW	Display
 206	VISUAL./TELEMATIC	1.4 55kw KFW	SAGEM JCAE
 206	VISUAL./TELEMATIC	1.4 55kw KFX	Display
 206	VISUAL./TELEMATIC	1.4 55kw KFX	SAGEM JCAE
 206	VISUAL./TELEMATIC	1.4 HDI 50kw 8HX	Display
 206	VISUAL./TELEMATIC	1.4 HDI 50kw 8HX	SAGEM JCAE
 206	VISUAL./TELEMATIC	1.4 HDI 50kw 8HZ	Display
 206	VISUAL./TELEMATIC	1.4 HDI 50kw 8HZ	SAGEM JCAE
 206	VISUAL./TELEMATIC	1.6 16v 80kw NFU	Display
 206	VISUAL./TELEMATIC	1.6 16v 80kw NFU	SAGEM JCAE
 206	VISUAL./TELEMATIC	1.6 66kw NFX	Display
 206	VISUAL./TELEMATIC	1.6 66kw NFX	SAGEM JCAE
 206	VISUAL./TELEMATIC	1.6 66kw NFZ	Display
 206	VISUAL./TELEMATIC	1.6 66kw NFZ	SAGEM JCAE
 206	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HY	Display
 206	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HY	SAGEM JCAE
 206	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	Display
 206	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	SAGEM JCAE
 206	VISUAL./TELEMATIC	1.9 D 51kw WJZ	Display
 206	VISUAL./TELEMATIC	1.9 D 51kw WJZ	SAGEM JCAE
 206	VISUAL./TELEMATIC	1.9 D 52kw WJY	Display
 206	VISUAL./TELEMATIC	1.9 D 52kw WJY	SAGEM JCAE
 206	VISUAL./TELEMATIC	2.0 16v 100kw RFN	Display
 206	VISUAL./TELEMATIC	2.0 16v 100kw RFN	SAGEM JCAE
 206	VISUAL./TELEMATIC	2.0 16v 102kw RFR	Display
 206	VISUAL./TELEMATIC	2.0 16v 102kw RFR	SAGEM JCAE
 206	VISUAL./TELEMATIC	2.0 HDI 66kw RHY	Display
 206	VISUAL./TELEMATIC	2.0 HDI 66kw RHY	SAGEM JCAE
 207	ABS	1.4 16v 66kw KFU	TEVES ABS MK70
 207	ABS	1.4 16v 66kw KFU	TEVES ABS MK70 2
 207	ABS	1.4 16v 66kw KFU	TRW ABS
 207	ABS	1.4 16v 70kw 8FS	TEVES ABS MK70
 207	ABS	1.4 16v 70kw 8FS	TEVES ABS MK70 2
 207	ABS	1.4 16v 70kw 8FS	TRW ABS
 207	ABS	1.4 54kw KFT	TEVES ABS MK70
 207	ABS	1.4 54kw KFT	TEVES ABS MK70 2
 207	ABS	1.4 54kw KFT	TRW ABS
 207	ABS	1.4 55kw KFU	TEVES ABS MK70
 207	ABS	1.4 55kw KFU	TEVES ABS MK70 2
207	ABS	1.4 55kw KFU	TRW ABS
207	ABS	1.4 HDI 50kw 8HZ	TEVES ABS MK70

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 207	ABS	1.4 HDI 50kw 8HZ	TEVES ABS MK70 2
 207	ABS	1.4 HDI 50kw 8HZ	TRW ABS
 207	ABS	1.6 16v 110kw 5FX	TEVES ABS MK70
 207	ABS	1.6 16v 110kw 5FX	TEVES ABS MK70 2
 207	ABS	1.6 16v 110kw 5FX	TRW ABS
 207	ABS	1.6 16v 128kw 5FY	TEVES ABS MK70
 207	ABS	1.6 16v 128kw 5FY	TEVES ABS MK70 2
 207	ABS	1.6 16v 128kw 5FY	TRW ABS
 207	ABS	1.6 16v 80kw NFU	TEVES ABS MK70
 207	ABS	1.6 16v 80kw NFU	TEVES ABS MK70 2
 207	ABS	1.6 16v 80kw NFU	TRW ABS
 207	ABS	1.6 16v 88kw 5FW	TEVES ABS MK70
 207	ABS	1.6 16v 88kw 5FW	TEVES ABS MK70 2
 207	ABS	1.6 16v 88kw 5FW	TRW ABS
 207	ABS	1.6 HDI 16v 66kw 9HV	TEVES ABS MK70
 207	ABS	1.6 HDI 16v 66kw 9HV	TEVES ABS MK70 2
 207	ABS	1.6 HDI 16v 66kw 9HV	TRW ABS
 207	ABS	1.6 HDI 16v 66kw 9HX	TEVES ABS MK70
 207	ABS	1.6 HDI 16v 66kw 9HX	TEVES ABS MK70 2
 207	ABS	1.6 HDI 16v 66kw 9HX	TRW ABS
 207	ABS	1.6 HDI 16v 68kw 9HP	TEVES ABS MK70
 207	ABS	1.6 HDI 16v 68kw 9HP	TEVES ABS MK70 2
 207	ABS	1.6 HDI 16v 68kw 9HP	TRW ABS
 207	ABS	1.6 HDI 16v 80kw 9HY	TEVES ABS MK70
 207	ABS	1.6 HDI 16v 80kw 9HY	TEVES ABS MK70 2
 207	ABS	1.6 HDI 16v 80kw 9HY	TRW ABS
 207	ABS	1.6 HDI 16v 80kw 9HZ-FAP	TEVES ABS MK70
 207	ABS	1.6 HDI 16v 80kw 9HZ-FAP	TEVES ABS MK70 2
 207	ABS	1.6 HDI 16v 80kw 9HZ-FAP	TRW ABS
 207	ABS	1.6 HDI 16v 82kw 9HR	TEVES ABS MK70
 207	ABS	1.6 HDI 16v 82kw 9HR	TEVES ABS MK70 2
 207	ABS	1.6 HDI 16v 82kw 9HR	TRW ABS
 207	ABS + TRACT. CONT	1.4 16v 66kw KFV	TEVES ESP MK60 2
 207	ABS + TRACT. CONT	1.4 16v 66kw KFV	Var.1
 207	ABS + TRACT. CONT	1.4 16v 66kw KFV	Var.2
 207	ABS + TRACT. CONT	1.4 16v 70kw 8FS	TEVES ESP MK60 2
 207	ABS + TRACT. CONT	1.4 16v 70kw 8FS	Var.1
 207	ABS + TRACT. CONT	1.4 16v 70kw 8FS	Var.2
 207	ABS + TRACT. CONT	1.4 54kw KFT	TEVES ESP MK60 2
 207	ABS + TRACT. CONT	1.4 54kw KFT	Var.1
 207	ABS + TRACT. CONT	1.4 54kw KFT	Var.2
 207	ABS + TRACT. CONT	1.4 55kw KFV	TEVES ESP MK60 2
 207	ABS + TRACT. CONT	1.4 55kw KFV	Var.1
 207	ABS + TRACT. CONT	1.4 55kw KFV	Var.2
 207	ABS + TRACT. CONT	1.4 HDI 50kw 8HZ	TEVES ESP MK60 2
 207	ABS + TRACT. CONT	1.4 HDI 50kw 8HZ	Var.1
 207	ABS + TRACT. CONT	1.4 HDI 50kw 8HZ	Var.2
 207	ABS + TRACT. CONT	1.6 16v 110kw 5FX	TEVES ESP MK60 2
 207	ABS + TRACT. CONT	1.6 16v 110kw 5FX	Var.1
 207	ABS + TRACT. CONT	1.6 16v 110kw 5FX	Var.2
 207	ABS + TRACT. CONT	1.6 16v 128kw 5FY	TEVES ESP MK60 2
 207	ABS + TRACT. CONT	1.6 16v 128kw 5FY	Var.1
 207	ABS + TRACT. CONT	1.6 16v 128kw 5FY	Var.2
 207	ABS + TRACT. CONT	1.6 16v 80kw NFU	TEVES ESP MK60 2
 207	ABS + TRACT. CONT	1.6 16v 80kw NFU	Var.1
 207	ABS + TRACT. CONT	1.6 16v 80kw NFU	Var.2
 207	ABS + TRACT. CONT	1.6 16v 88kw 5FW	TEVES ESP MK60 2
 207	ABS + TRACT. CONT	1.6 16v 88kw 5FW	Var.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 207	ABS + TRACT. CONT	1.6 16v 88kw 5FW	Var.2
 207	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HV	TEVES ESP MK60 2
 207	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HV	Var.1
 207	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HV	Var.2
 207	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX	TEVES ESP MK60 2
 207	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX	Var.1
 207	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX	Var.2
 207	ABS + TRACT. CONT	1.6 HDI 16v 68kw 9HP	TEVES ESP MK60 2
 207	ABS + TRACT. CONT	1.6 HDI 16v 68kw 9HP	Var.1
 207	ABS + TRACT. CONT	1.6 HDI 16v 68kw 9HP	Var.2
 207	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HY	TEVES ESP MK60 2
 207	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HY	Var.1
 207	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HY	Var.2
 207	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	TEVES ESP MK60 2
 207	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 207	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 207	ABS + TRACT. CONT	1.6 HDI 16v 82kw 9HR	TEVES ESP MK60 2
 207	ABS + TRACT. CONT	1.6 HDI 16v 82kw 9HR	Var.1
 207	ABS + TRACT. CONT	1.6 HDI 16v 82kw 9HR	Var.2
 207	AIRBAG	1.4 16v 66kw KFJ	AirBag CENTRAL
 207	AIRBAG	1.4 16v 66kw KFJ	TRW Autoliv AirBag
 207	AIRBAG	1.4 16v 70kw 8FS	AirBag CENTRAL
 207	AIRBAG	1.4 16v 70kw 8FS	TRW Autoliv AirBag
 207	AIRBAG	1.4 54kw KFT	AirBag CENTRAL
 207	AIRBAG	1.4 54kw KFT	TRW Autoliv AirBag
 207	AIRBAG	1.4 55kw KFV	AirBag CENTRAL
 207	AIRBAG	1.4 55kw KFV	TRW Autoliv AirBag
 207	AIRBAG	1.4 HDI 50kw 8HZ	AirBag CENTRAL
 207	AIRBAG	1.4 HDI 50kw 8HZ	TRW Autoliv AirBag
 207	AIRBAG	1.6 16v 110kw 5FX	AirBag CENTRAL
 207	AIRBAG	1.6 16v 110kw 5FX	TRW Autoliv AirBag
 207	AIRBAG	1.6 16v 128kw 5FY	AirBag CENTRAL
 207	AIRBAG	1.6 16v 128kw 5FY	TRW Autoliv AirBag
 207	AIRBAG	1.6 16v 80kw NFU	AirBag CENTRAL
 207	AIRBAG	1.6 16v 80kw NFU	TRW Autoliv AirBag
 207	AIRBAG	1.6 16v 88kw 5FW	AirBag CENTRAL
 207	AIRBAG	1.6 16v 88kw 5FW	TRW Autoliv AirBag
 207	AIRBAG	1.6 HDI 16v 66kw 9HV	AirBag CENTRAL
 207	AIRBAG	1.6 HDI 16v 66kw 9HV	TRW Autoliv AirBag
 207	AIRBAG	1.6 HDI 16v 66kw 9HX	AirBag CENTRAL
 207	AIRBAG	1.6 HDI 16v 66kw 9HX	TRW Autoliv AirBag
 207	AIRBAG	1.6 HDI 16v 68kw 9HP	AirBag CENTRAL
 207	AIRBAG	1.6 HDI 16v 68kw 9HP	TRW Autoliv AirBag
 207	AIRBAG	1.6 HDI 16v 80kw 9HY	AirBag CENTRAL
 207	AIRBAG	1.6 HDI 16v 80kw 9HY	TRW Autoliv AirBag
 207	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL
 207	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP	TRW Autoliv AirBag
 207	AIRBAG	1.6 HDI 16v 82kw 9HR	AirBag CENTRAL
 207	AIRBAG	1.6 HDI 16v 82kw 9HR	TRW Autoliv AirBag
 207	ANTITHEFT	1.4 16v 66kw KFJ	Alarm PSA2
 207	ANTITHEFT	1.4 16v 70kw 8FS	Alarm PSA2
 207	ANTITHEFT	1.4 54kw KFT	Alarm PSA2
 207	ANTITHEFT	1.4 55kw KFV	Alarm PSA2
 207	ANTITHEFT	1.4 HDI 50kw 8HZ	Alarm PSA2
 207	ANTITHEFT	1.6 16v 110kw 5FX	Alarm PSA2
 207	ANTITHEFT	1.6 16v 128kw 5FY	Alarm PSA2
 207	ANTITHEFT	1.6 16v 80kw NFU	Alarm PSA2
 207	ANTITHEFT	1.6 16v 88kw 5FW	Alarm PSA2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 207	ANTITHEFT	1.6 HDI 16v 66kw 9HV	Alarm PSA2
 207	ANTITHEFT	1.6 HDI 16v 66kw 9HX	Alarm PSA2
 207	ANTITHEFT	1.6 HDI 16v 68kw 9HP	Alarm PSA2
 207	ANTITHEFT	1.6 HDI 16v 80kw 9HY	Alarm PSA2
 207	ANTITHEFT	1.6 HDI 16v 80kw 9HZ-FAP	Alarm PSA2
 207	ANTITHEFT	1.6 HDI 16v 82kw 9HR	Alarm PSA2
 207	AUTOM. TRANSMISSI	1.4 16v 66kw KFU	A/T AM6
 207	AUTOM. TRANSMISSI	1.4 16v 66kw KFU	A/T MCP
 207	AUTOM. TRANSMISSI	1.4 16v 66kw KFU	Var.1
 207	AUTOM. TRANSMISSI	1.4 16v 66kw KFU	Var.2
 207	AUTOM. TRANSMISSI	1.4 16v 66kw KFU	Var.3
 207	AUTOM. TRANSMISSI	1.4 16v 66kw KFU	Var.4
 207	AUTOM. TRANSMISSI	1.4 16v 66kw KFU	Var.5
 207	AUTOM. TRANSMISSI	1.4 16v 70kw 8FS	A/T AM6
 207	AUTOM. TRANSMISSI	1.4 16v 70kw 8FS	A/T MCP
 207	AUTOM. TRANSMISSI	1.4 16v 70kw 8FS	Var.1
 207	AUTOM. TRANSMISSI	1.4 16v 70kw 8FS	Var.2
 207	AUTOM. TRANSMISSI	1.4 16v 70kw 8FS	Var.3
 207	AUTOM. TRANSMISSI	1.4 16v 70kw 8FS	Var.4
 207	AUTOM. TRANSMISSI	1.4 16v 70kw 8FS	Var.5
 207	AUTOM. TRANSMISSI	1.4 54kw KFT	A/T AM6
 207	AUTOM. TRANSMISSI	1.4 54kw KFT	A/T MCP
 207	AUTOM. TRANSMISSI	1.4 54kw KFT	Var.1
 207	AUTOM. TRANSMISSI	1.4 54kw KFT	Var.2
 207	AUTOM. TRANSMISSI	1.4 54kw KFT	Var.3
 207	AUTOM. TRANSMISSI	1.4 54kw KFT	Var.4
 207	AUTOM. TRANSMISSI	1.4 54kw KFT	Var.5
 207	AUTOM. TRANSMISSI	1.4 55kw KFV	A/T AM6
 207	AUTOM. TRANSMISSI	1.4 55kw KFV	A/T MCP
 207	AUTOM. TRANSMISSI	1.4 55kw KFV	Var.1
 207	AUTOM. TRANSMISSI	1.4 55kw KFV	Var.2
 207	AUTOM. TRANSMISSI	1.4 55kw KFV	Var.3
 207	AUTOM. TRANSMISSI	1.4 55kw KFV	Var.4
 207	AUTOM. TRANSMISSI	1.4 55kw KFV	Var.5
 207	AUTOM. TRANSMISSI	1.4 HDI 50kw 8HZ	A/T AM6
 207	AUTOM. TRANSMISSI	1.4 HDI 50kw 8HZ	A/T MCP
 207	AUTOM. TRANSMISSI	1.4 HDI 50kw 8HZ	Var.1
 207	AUTOM. TRANSMISSI	1.4 HDI 50kw 8HZ	Var.2
 207	AUTOM. TRANSMISSI	1.4 HDI 50kw 8HZ	Var.3
 207	AUTOM. TRANSMISSI	1.4 HDI 50kw 8HZ	Var.4
 207	AUTOM. TRANSMISSI	1.4 HDI 50kw 8HZ	Var.5
 207	AUTOM. TRANSMISSI	1.6 16v 110kw 5FX	A/T AM6
 207	AUTOM. TRANSMISSI	1.6 16v 110kw 5FX	A/T MCP
 207	AUTOM. TRANSMISSI	1.6 16v 110kw 5FX	Var.1
 207	AUTOM. TRANSMISSI	1.6 16v 110kw 5FX	Var.2
 207	AUTOM. TRANSMISSI	1.6 16v 110kw 5FX	Var.3
 207	AUTOM. TRANSMISSI	1.6 16v 110kw 5FX	Var.4
 207	AUTOM. TRANSMISSI	1.6 16v 110kw 5FX	Var.5
 207	AUTOM. TRANSMISSI	1.6 16v 128kw 5FY	A/T AM6
 207	AUTOM. TRANSMISSI	1.6 16v 128kw 5FY	A/T MCP
 207	AUTOM. TRANSMISSI	1.6 16v 128kw 5FY	Var.1
 207	AUTOM. TRANSMISSI	1.6 16v 128kw 5FY	Var.2
 207	AUTOM. TRANSMISSI	1.6 16v 128kw 5FY	Var.3
 207	AUTOM. TRANSMISSI	1.6 16v 128kw 5FY	Var.4
 207	AUTOM. TRANSMISSI	1.6 16v 128kw 5FY	Var.5
 207	AUTOM. TRANSMISSI	1.6 16v 80kw NFU	A/T AM6
 207	AUTOM. TRANSMISSI	1.6 16v 80kw NFU	A/T MCP
 207	AUTOM. TRANSMISSI	1.6 16v 80kw NFU	Var.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 207	AUTOM. TRANSMISSI	1.6 16v 80kw NFU	Var.2
 207	AUTOM. TRANSMISSI	1.6 16v 80kw NFU	Var.3
 207	AUTOM. TRANSMISSI	1.6 16v 80kw NFU	Var.4
 207	AUTOM. TRANSMISSI	1.6 16v 80kw NFU	Var.5
 207	AUTOM. TRANSMISSI	1.6 16v 88kw 5FW	A/T AM6
 207	AUTOM. TRANSMISSI	1.6 16v 88kw 5FW	A/T MCP
 207	AUTOM. TRANSMISSI	1.6 16v 88kw 5FW	Var.1
 207	AUTOM. TRANSMISSI	1.6 16v 88kw 5FW	Var.2
 207	AUTOM. TRANSMISSI	1.6 16v 88kw 5FW	Var.3
 207	AUTOM. TRANSMISSI	1.6 16v 88kw 5FW	Var.4
 207	AUTOM. TRANSMISSI	1.6 16v 88kw 5FW	Var.5
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 66kw 9HV	A/T AM6
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 66kw 9HV	A/T MCP
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 66kw 9HV	Var.1
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 66kw 9HV	Var.2
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 66kw 9HV	Var.3
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 66kw 9HV	Var.4
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 66kw 9HV	Var.5
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 66kw 9HX	A/T AM6
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 66kw 9HX	A/T MCP
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 66kw 9HX	Var.1
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 66kw 9HX	Var.2
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 66kw 9HX	Var.3
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 66kw 9HX	Var.4
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 66kw 9HX	Var.5
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 68kw 9HP	A/T AM6
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 68kw 9HP	A/T MCP
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 68kw 9HP	Var.1
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 68kw 9HP	Var.2
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 68kw 9HP	Var.3
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 68kw 9HP	Var.4
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 68kw 9HP	Var.5
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HY	A/T AM6
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HY	A/T MCP
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HY	Var.1
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HY	Var.2
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HY	Var.3
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HY	Var.4
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HY	Var.5
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP	A/T AM6
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP	A/T MCP
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP	Var.3
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP	Var.4
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP	Var.5
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 82kw 9HR	A/T AM6
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 82kw 9HR	A/T MCP
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 82kw 9HR	Var.1
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 82kw 9HR	Var.2
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 82kw 9HR	Var.3
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 82kw 9HR	Var.4
 207	AUTOM. TRANSMISSI	1.6 HDI 16v 82kw 9HR	Var.5
 207	CHASSIS NETWORK	1.4 16v 66kw KFU	Body Computer BSI
 207	CHASSIS NETWORK	1.4 16v 66kw KFU	Body Computer BSM
 207	CHASSIS NETWORK	1.4 16v 66kw KFU	Body Computer BSR
 207	CHASSIS NETWORK	1.4 16v 66kw KFU	SIEMENS Body Computer BSI
 207	CHASSIS NETWORK	1.4 16v 66kw KFU	SIEMENS Body Computer BSM

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 207	CHASSIS NETWORK	1.4 16v 66kw KFU	Var.1
 207	CHASSIS NETWORK	1.4 16v 66kw KFU	Var.2
 207	CHASSIS NETWORK	1.4 16v 70kw 8FS	Body Computer BSI
 207	CHASSIS NETWORK	1.4 16v 70kw 8FS	Body Computer BSM
 207	CHASSIS NETWORK	1.4 16v 70kw 8FS	Body Computer BSR
 207	CHASSIS NETWORK	1.4 16v 70kw 8FS	SIEMENS Body Computer BSI
 207	CHASSIS NETWORK	1.4 16v 70kw 8FS	SIEMENS Body Computer BSM
 207	CHASSIS NETWORK	1.4 16v 70kw 8FS	Var.1
 207	CHASSIS NETWORK	1.4 16v 70kw 8FS	Var.2
 207	CHASSIS NETWORK	1.4 54kw KFT	Body Computer BSI
 207	CHASSIS NETWORK	1.4 54kw KFT	Body Computer BSM
 207	CHASSIS NETWORK	1.4 54kw KFT	Body Computer BSR
 207	CHASSIS NETWORK	1.4 54kw KFT	SIEMENS Body Computer BSI
 207	CHASSIS NETWORK	1.4 54kw KFT	SIEMENS Body Computer BSM
 207	CHASSIS NETWORK	1.4 54kw KFT	Var.1
 207	CHASSIS NETWORK	1.4 54kw KFT	Var.2
 207	CHASSIS NETWORK	1.4 55kw KFU	Body Computer BSI
 207	CHASSIS NETWORK	1.4 55kw KFU	Body Computer BSM
 207	CHASSIS NETWORK	1.4 55kw KFU	Body Computer BSR
 207	CHASSIS NETWORK	1.4 55kw KFU	SIEMENS Body Computer BSI
 207	CHASSIS NETWORK	1.4 55kw KFU	SIEMENS Body Computer BSM
 207	CHASSIS NETWORK	1.4 55kw KFU	Var.1
 207	CHASSIS NETWORK	1.4 55kw KFU	Var.2
 207	CHASSIS NETWORK	1.4 HDI 50kw 8HZ	Body Computer BSI
 207	CHASSIS NETWORK	1.4 HDI 50kw 8HZ	Body Computer BSM
 207	CHASSIS NETWORK	1.4 HDI 50kw 8HZ	Body Computer BSR
 207	CHASSIS NETWORK	1.4 HDI 50kw 8HZ	SIEMENS Body Computer BSI
 207	CHASSIS NETWORK	1.4 HDI 50kw 8HZ	SIEMENS Body Computer BSM
 207	CHASSIS NETWORK	1.4 HDI 50kw 8HZ	Var.1
 207	CHASSIS NETWORK	1.4 HDI 50kw 8HZ	Var.2
 207	CHASSIS NETWORK	1.6 16v 110kw 5FX	Body Computer BSI
 207	CHASSIS NETWORK	1.6 16v 110kw 5FX	Body Computer BSM
 207	CHASSIS NETWORK	1.6 16v 110kw 5FX	Body Computer BSR
 207	CHASSIS NETWORK	1.6 16v 110kw 5FX	SIEMENS Body Computer BSI
 207	CHASSIS NETWORK	1.6 16v 110kw 5FX	SIEMENS Body Computer BSM
 207	CHASSIS NETWORK	1.6 16v 110kw 5FX	Var.1
 207	CHASSIS NETWORK	1.6 16v 110kw 5FX	Var.2
 207	CHASSIS NETWORK	1.6 16v 128kw 5FY	Body Computer BSI
 207	CHASSIS NETWORK	1.6 16v 128kw 5FY	Body Computer BSM
 207	CHASSIS NETWORK	1.6 16v 128kw 5FY	Body Computer BSR
 207	CHASSIS NETWORK	1.6 16v 128kw 5FY	SIEMENS Body Computer BSI
 207	CHASSIS NETWORK	1.6 16v 128kw 5FY	SIEMENS Body Computer BSM
 207	CHASSIS NETWORK	1.6 16v 128kw 5FY	Var.1
 207	CHASSIS NETWORK	1.6 16v 128kw 5FY	Var.2
 207	CHASSIS NETWORK	1.6 16v 80kw NFU	Body Computer BSI
 207	CHASSIS NETWORK	1.6 16v 80kw NFU	Body Computer BSM
 207	CHASSIS NETWORK	1.6 16v 80kw NFU	Body Computer BSR
 207	CHASSIS NETWORK	1.6 16v 80kw NFU	SIEMENS Body Computer BSI
 207	CHASSIS NETWORK	1.6 16v 80kw NFU	SIEMENS Body Computer BSM
 207	CHASSIS NETWORK	1.6 16v 80kw NFU	Var.1
 207	CHASSIS NETWORK	1.6 16v 80kw NFU	Var.2
 207	CHASSIS NETWORK	1.6 16v 88kw 5FW	Body Computer BSI
 207	CHASSIS NETWORK	1.6 16v 88kw 5FW	Body Computer BSM
 207	CHASSIS NETWORK	1.6 16v 88kw 5FW	Body Computer BSR
 207	CHASSIS NETWORK	1.6 16v 88kw 5FW	SIEMENS Body Computer BSI
 207	CHASSIS NETWORK	1.6 16v 88kw 5FW	SIEMENS Body Computer BSM
 207	CHASSIS NETWORK	1.6 16v 88kw 5FW	Var.1
 207	CHASSIS NETWORK	1.6 16v 88kw 5FW	Var.2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 207	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HV	Body Computer BSI
 207	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HV	Body Computer BSM
 207	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HV	Body Computer BSR
 207	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HV	SIEMENS Body Computer BSI
 207	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HV	SIEMENS Body Computer BSM
 207	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HV	Var.1
 207	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HV	Var.2
 207	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	Body Computer BSI
 207	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	Body Computer BSM
 207	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	Body Computer BSR
 207	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	SIEMENS Body Computer BSI
 207	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	SIEMENS Body Computer BSM
 207	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	Var.1
 207	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	Var.2
 207	CHASSIS NETWORK	1.6 HDI 16v 68kw 9HP	Body Computer BSI
 207	CHASSIS NETWORK	1.6 HDI 16v 68kw 9HP	Body Computer BSM
 207	CHASSIS NETWORK	1.6 HDI 16v 68kw 9HP	Body Computer BSR
 207	CHASSIS NETWORK	1.6 HDI 16v 68kw 9HP	SIEMENS Body Computer BSI
 207	CHASSIS NETWORK	1.6 HDI 16v 68kw 9HP	SIEMENS Body Computer BSM
 207	CHASSIS NETWORK	1.6 HDI 16v 68kw 9HP	Var.1
 207	CHASSIS NETWORK	1.6 HDI 16v 68kw 9HP	Var.2
 207	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY	Body Computer BSI
 207	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY	Body Computer BSM
 207	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY	Body Computer BSR
 207	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY	SIEMENS Body Computer BSI
 207	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY	SIEMENS Body Computer BSM
 207	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY	Var.1
 207	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY	Var.2
 207	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSI
 207	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSM
 207	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSR
 207	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	SIEMENS Body Computer BSI
 207	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	SIEMENS Body Computer BSM
 207	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 207	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 207	CHASSIS NETWORK	1.6 HDI 16v 82kw 9HR	Body Computer BSI
 207	CHASSIS NETWORK	1.6 HDI 16v 82kw 9HR	Body Computer BSM
 207	CHASSIS NETWORK	1.6 HDI 16v 82kw 9HR	Body Computer BSR
 207	CHASSIS NETWORK	1.6 HDI 16v 82kw 9HR	SIEMENS Body Computer BSI
 207	CHASSIS NETWORK	1.6 HDI 16v 82kw 9HR	SIEMENS Body Computer BSM
 207	CHASSIS NETWORK	1.6 HDI 16v 82kw 9HR	Var.1
 207	CHASSIS NETWORK	1.6 HDI 16v 82kw 9HR	Var.2
 207	CLIMA	1.4 16v 66kw KFU	AutoClima X.x
 207	CLIMA	1.4 16v 66kw KFU	CLIMA
 207	CLIMA	1.4 16v 70kw 8FS	AutoClima X.x
 207	CLIMA	1.4 16v 70kw 8FS	CLIMA
 207	CLIMA	1.4 54kw KFT	AutoClima X.x
 207	CLIMA	1.4 54kw KFT	CLIMA
 207	CLIMA	1.4 55kw KFV	AutoClima X.x
 207	CLIMA	1.4 55kw KFV	CLIMA
 207	CLIMA	1.4 HDI 50kw 8HZ	AutoClima X.x
 207	CLIMA	1.4 HDI 50kw 8HZ	CLIMA
 207	CLIMA	1.6 16v 110kw 5FX	AutoClima X.x
 207	CLIMA	1.6 16v 110kw 5FX	CLIMA
 207	CLIMA	1.6 16v 128kw 5FY	AutoClima X.x
 207	CLIMA	1.6 16v 128kw 5FY	CLIMA
 207	CLIMA	1.6 16v 80kw NFU	AutoClima X.x
 207	CLIMA	1.6 16v 80kw NFU	CLIMA

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 207	CLIMA	1.6 16v 88kw 5FW	AutoClima X.x
 207	CLIMA	1.6 16v 88kw 5FW	CLIMA
 207	CLIMA	1.6 HDI 16v 66kw 9HV	AutoClima X.x
 207	CLIMA	1.6 HDI 16v 66kw 9HV	CLIMA
 207	CLIMA	1.6 HDI 16v 66kw 9HX	AutoClima X.x
 207	CLIMA	1.6 HDI 16v 66kw 9HX	CLIMA
 207	CLIMA	1.6 HDI 16v 68kw 9HP	AutoClima X.x
 207	CLIMA	1.6 HDI 16v 68kw 9HP	CLIMA
 207	CLIMA	1.6 HDI 16v 80kw 9HY	AutoClima X.x
 207	CLIMA	1.6 HDI 16v 80kw 9HY	CLIMA
 207	CLIMA	1.6 HDI 16v 80kw 9HZ-FAP	AutoClima X.x
 207	CLIMA	1.6 HDI 16v 80kw 9HZ-FAP	CLIMA
 207	CLIMA	1.6 HDI 16v 82kw 9HR	AutoClima X.x
 207	CLIMA	1.6 HDI 16v 82kw 9HR	CLIMA
 207	COMFORT SYSTEM	1.4 16v 66kw KFU	Phone Kit
 207	COMFORT SYSTEM	1.4 16v 66kw KFU	Var.1
 207	COMFORT SYSTEM	1.4 16v 66kw KFU	Var.2
 207	COMFORT SYSTEM	1.4 16v 66kw KFU	Var.3
 207	COMFORT SYSTEM	1.4 16v 66kw KFU	Var.4
 207	COMFORT SYSTEM	1.4 16v 70kw 8FS	Phone Kit
 207	COMFORT SYSTEM	1.4 16v 70kw 8FS	Var.1
 207	COMFORT SYSTEM	1.4 16v 70kw 8FS	Var.2
 207	COMFORT SYSTEM	1.4 16v 70kw 8FS	Var.3
 207	COMFORT SYSTEM	1.4 16v 70kw 8FS	Var.4
 207	COMFORT SYSTEM	1.4 54kw KFT	Phone Kit
 207	COMFORT SYSTEM	1.4 54kw KFT	Var.1
 207	COMFORT SYSTEM	1.4 54kw KFT	Var.2
 207	COMFORT SYSTEM	1.4 54kw KFT	Var.3
 207	COMFORT SYSTEM	1.4 54kw KFT	Var.4
 207	COMFORT SYSTEM	1.4 55kw KFV	Phone Kit
 207	COMFORT SYSTEM	1.4 55kw KFV	Var.1
 207	COMFORT SYSTEM	1.4 55kw KFV	Var.2
 207	COMFORT SYSTEM	1.4 55kw KFV	Var.3
 207	COMFORT SYSTEM	1.4 55kw KFV	Var.4
 207	COMFORT SYSTEM	1.4 HDI 50kw 8HZ	Phone Kit
 207	COMFORT SYSTEM	1.4 HDI 50kw 8HZ	Var.1
 207	COMFORT SYSTEM	1.4 HDI 50kw 8HZ	Var.2
 207	COMFORT SYSTEM	1.4 HDI 50kw 8HZ	Var.3
 207	COMFORT SYSTEM	1.4 HDI 50kw 8HZ	Var.4
 207	COMFORT SYSTEM	1.6 16v 110kw 5FX	Phone Kit
 207	COMFORT SYSTEM	1.6 16v 110kw 5FX	Var.1
 207	COMFORT SYSTEM	1.6 16v 110kw 5FX	Var.2
 207	COMFORT SYSTEM	1.6 16v 110kw 5FX	Var.3
 207	COMFORT SYSTEM	1.6 16v 110kw 5FX	Var.4
 207	COMFORT SYSTEM	1.6 16v 128kw 5FY	Phone Kit
 207	COMFORT SYSTEM	1.6 16v 128kw 5FY	Var.1
 207	COMFORT SYSTEM	1.6 16v 128kw 5FY	Var.2
 207	COMFORT SYSTEM	1.6 16v 128kw 5FY	Var.3
 207	COMFORT SYSTEM	1.6 16v 128kw 5FY	Var.4
 207	COMFORT SYSTEM	1.6 16v 80kw NFU	Phone Kit
 207	COMFORT SYSTEM	1.6 16v 80kw NFU	Var.1
 207	COMFORT SYSTEM	1.6 16v 80kw NFU	Var.2
 207	COMFORT SYSTEM	1.6 16v 80kw NFU	Var.3
 207	COMFORT SYSTEM	1.6 16v 80kw NFU	Var.4
 207	COMFORT SYSTEM	1.6 16v 88kw 5FW	Phone Kit
 207	COMFORT SYSTEM	1.6 16v 88kw 5FW	Var.1
 207	COMFORT SYSTEM	1.6 16v 88kw 5FW	Var.2
 207	COMFORT SYSTEM	1.6 16v 88kw 5FW	Var.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 207	COMFORT SYSTEM	1.6 16v 88kw 5FW	Var.4
 207	COMFORT SYSTEM	1.6 HDI 16v 66kw 9HV	Phone Kit
 207	COMFORT SYSTEM	1.6 HDI 16v 66kw 9HV	Var.1
 207	COMFORT SYSTEM	1.6 HDI 16v 66kw 9HV	Var.2
 207	COMFORT SYSTEM	1.6 HDI 16v 66kw 9HV	Var.3
 207	COMFORT SYSTEM	1.6 HDI 16v 66kw 9HV	Var.4
 207	COMFORT SYSTEM	1.6 HDI 16v 66kw 9HX	Phone Kit
 207	COMFORT SYSTEM	1.6 HDI 16v 66kw 9HX	Var.1
 207	COMFORT SYSTEM	1.6 HDI 16v 66kw 9HX	Var.2
 207	COMFORT SYSTEM	1.6 HDI 16v 66kw 9HX	Var.3
 207	COMFORT SYSTEM	1.6 HDI 16v 66kw 9HX	Var.4
 207	COMFORT SYSTEM	1.6 HDI 16v 68kw 9HP	Phone Kit
 207	COMFORT SYSTEM	1.6 HDI 16v 68kw 9HP	Var.1
 207	COMFORT SYSTEM	1.6 HDI 16v 68kw 9HP	Var.2
 207	COMFORT SYSTEM	1.6 HDI 16v 68kw 9HP	Var.3
 207	COMFORT SYSTEM	1.6 HDI 16v 68kw 9HP	Var.4
 207	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HY	Phone Kit
 207	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HY	Var.1
 207	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HY	Var.2
 207	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HY	Var.3
 207	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HY	Var.4
 207	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HZ-FAP	Phone Kit
 207	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 207	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 207	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HZ-FAP	Var.3
 207	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HZ-FAP	Var.4
 207	COMFORT SYSTEM	1.6 HDI 16v 82kw 9HR	Phone Kit
 207	COMFORT SYSTEM	1.6 HDI 16v 82kw 9HR	Var.1
 207	COMFORT SYSTEM	1.6 HDI 16v 82kw 9HR	Var.2
 207	COMFORT SYSTEM	1.6 HDI 16v 82kw 9HR	Var.3
 207	COMFORT SYSTEM	1.6 HDI 16v 82kw 9HR	Var.4
 207	DASHBOARD	1.4 16v 66kw KFJ	COMBINE
 207	DASHBOARD	1.4 16v 66kw KFJ	SAGEM Dashboard
 207	DASHBOARD	1.4 16v 70kw 8FS	COMBINE
 207	DASHBOARD	1.4 16v 70kw 8FS	SAGEM Dashboard
 207	DASHBOARD	1.4 54kw KFT	COMBINE
 207	DASHBOARD	1.4 54kw KFT	SAGEM Dashboard
 207	DASHBOARD	1.4 55kw KFV	COMBINE
 207	DASHBOARD	1.4 55kw KFV	SAGEM Dashboard
 207	DASHBOARD	1.4 HDI 50kw 8HZ	COMBINE
 207	DASHBOARD	1.4 HDI 50kw 8HZ	SAGEM Dashboard
 207	DASHBOARD	1.6 16v 110kw 5FX	COMBINE
 207	DASHBOARD	1.6 16v 110kw 5FX	SAGEM Dashboard
 207	DASHBOARD	1.6 16v 128kw 5FY	COMBINE
 207	DASHBOARD	1.6 16v 128kw 5FY	SAGEM Dashboard
 207	DASHBOARD	1.6 16v 80kw NFU	COMBINE
 207	DASHBOARD	1.6 16v 80kw NFU	SAGEM Dashboard
 207	DASHBOARD	1.6 16v 88kw 5FW	COMBINE
 207	DASHBOARD	1.6 16v 88kw 5FW	SAGEM Dashboard
 207	DASHBOARD	1.6 HDI 16v 66kw 9HV	COMBINE
 207	DASHBOARD	1.6 HDI 16v 66kw 9HV	SAGEM Dashboard
 207	DASHBOARD	1.6 HDI 16v 66kw 9HX	COMBINE
 207	DASHBOARD	1.6 HDI 16v 66kw 9HX	SAGEM Dashboard
 207	DASHBOARD	1.6 HDI 16v 68kw 9HP	COMBINE
 207	DASHBOARD	1.6 HDI 16v 68kw 9HP	SAGEM Dashboard
 207	DASHBOARD	1.6 HDI 16v 80kw 9HY	COMBINE
 207	DASHBOARD	1.6 HDI 16v 80kw 9HY	SAGEM Dashboard
 207	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP	COMBINE

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 207	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP	SAGEM Dashboard
 207	DASHBOARD	1.6 HDI 16v 82kw 9HR	COMBINE
 207	DASHBOARD	1.6 HDI 16v 82kw 9HR	SAGEM Dashboard
 207	DIESEL ADDITION	1.4 HDI 50kw 8HZ	
 207	DIESEL ADDITION	1.6 HDI 16v 66kw 9HV	
 207	DIESEL ADDITION	1.6 HDI 16v 68kw 9HP	
 207	DIESEL ADDITION	1.6 HDI 16v 80kw 9HY	
 207	DIESEL ADDITION	1.6 HDI 16v 80kw 9HZ-FAP	
 207	ELECTRIC STEERING	1.4 16v 66kw KFU	KOYO EPS 8401
 207	ELECTRIC STEERING	1.4 16v 66kw KFU	Var.1
 207	ELECTRIC STEERING	1.4 16v 66kw KFU	Var.2
 207	ELECTRIC STEERING	1.4 16v 66kw KFU	Var.3
 207	ELECTRIC STEERING	1.4 16v 70kw 8FS	KOYO EPS 8401
 207	ELECTRIC STEERING	1.4 16v 70kw 8FS	Var.1
 207	ELECTRIC STEERING	1.4 16v 70kw 8FS	Var.2
 207	ELECTRIC STEERING	1.4 16v 70kw 8FS	Var.3
 207	ELECTRIC STEERING	1.4 54kw KFT	KOYO EPS 8401
 207	ELECTRIC STEERING	1.4 54kw KFT	Var.1
 207	ELECTRIC STEERING	1.4 54kw KFT	Var.2
 207	ELECTRIC STEERING	1.4 54kw KFT	Var.3
 207	ELECTRIC STEERING	1.4 54kw KFV	Var.1
 207	ELECTRIC STEERING	1.4 55kw KFV	KOYO EPS 8401
 207	ELECTRIC STEERING	1.4 55kw KFV	Var.2
 207	ELECTRIC STEERING	1.4 55kw KFV	Var.3
 207	ELECTRIC STEERING	1.4 HDI 50kw 8HZ	KOYO EPS 8401
 207	ELECTRIC STEERING	1.4 HDI 50kw 8HZ	Var.1
 207	ELECTRIC STEERING	1.4 HDI 50kw 8HZ	Var.2
 207	ELECTRIC STEERING	1.4 HDI 50kw 8HZ	Var.3
 207	ELECTRIC STEERING	1.6 16v 110kw 5FX	KOYO EPS 8401
 207	ELECTRIC STEERING	1.6 16v 110kw 5FX	Var.1
 207	ELECTRIC STEERING	1.6 16v 110kw 5FX	Var.2
 207	ELECTRIC STEERING	1.6 16v 110kw 5FX	Var.3
 207	ELECTRIC STEERING	1.6 16v 128kw 5FY	KOYO EPS 8401
 207	ELECTRIC STEERING	1.6 16v 128kw 5FY	Var.1
 207	ELECTRIC STEERING	1.6 16v 128kw 5FY	Var.2
 207	ELECTRIC STEERING	1.6 16v 128kw 5FY	Var.3
 207	ELECTRIC STEERING	1.6 16v 80kw NFU	KOYO EPS 8401
 207	ELECTRIC STEERING	1.6 16v 80kw NFU	Var.1
 207	ELECTRIC STEERING	1.6 16v 80kw NFU	Var.2
 207	ELECTRIC STEERING	1.6 16v 80kw NFU	Var.3
 207	ELECTRIC STEERING	1.6 16v 88kw 5FW	KOYO EPS 8401
 207	ELECTRIC STEERING	1.6 16v 88kw 5FW	Var.1
 207	ELECTRIC STEERING	1.6 16v 88kw 5FW	Var.2
 207	ELECTRIC STEERING	1.6 16v 88kw 5FW	Var.3
 207	ELECTRIC STEERING	1.6 HDI 16v 66kw 9HV	KOYO EPS 8401
 207	ELECTRIC STEERING	1.6 HDI 16v 66kw 9HV	Var.1
 207	ELECTRIC STEERING	1.6 HDI 16v 66kw 9HV	Var.2
 207	ELECTRIC STEERING	1.6 HDI 16v 66kw 9HV	Var.3
 207	ELECTRIC STEERING	1.6 HDI 16v 66kw 9HX	KOYO EPS 8401
 207	ELECTRIC STEERING	1.6 HDI 16v 66kw 9HX	Var.1
 207	ELECTRIC STEERING	1.6 HDI 16v 66kw 9HX	Var.2
 207	ELECTRIC STEERING	1.6 HDI 16v 66kw 9HX	Var.3
 207	ELECTRIC STEERING	1.6 HDI 16v 68kw 9HP	KOYO EPS 8401
 207	ELECTRIC STEERING	1.6 HDI 16v 68kw 9HP	Var.1
 207	ELECTRIC STEERING	1.6 HDI 16v 68kw 9HP	Var.2
 207	ELECTRIC STEERING	1.6 HDI 16v 68kw 9HP	Var.3
 207	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HY	KOYO EPS 8401
 207	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HY	Var.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 207	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HY	Var.2
 207	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HY	Var.3
 207	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	KOYO EPS 8401
 207	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 207	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 207	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	Var.3
 207	ELECTRIC STEERING	1.6 HDI 16v 82kw 9HR	KOYO EPS 8401
 207	ELECTRIC STEERING	1.6 HDI 16v 82kw 9HR	Var.1
 207	ELECTRIC STEERING	1.6 HDI 16v 82kw 9HR	Var.2
 207	ELECTRIC STEERING	1.6 HDI 16v 82kw 9HR	Var.3
 207	ENGINE MANAGEME	1.4 16v 66kw KFU	Marelli MM 6LP
 207	ENGINE MANAGEME	1.4 16v 70kw 8FS	EOBD
 207	ENGINE MANAGEME	1.4 55kw KFV	SAGEM J34P Var.1
 207	ENGINE MANAGEME	1.4 55kw KFV	SAGEM J34P Var.2
 207	ENGINE MANAGEME	1.4 55kw KFV	SAGEM S2000 PM2
 207	ENGINE MANAGEME	1.4 HDI 50kw 8HZ	BOSCH EDC 16 C3 Common Rail
 207	ENGINE MANAGEME	1.4 HDI 50kw 8HZ	BOSCH EDC 16 C34 Common Rail Var.1
 207	ENGINE MANAGEME	1.4 HDI 50kw 8HZ	BOSCH EDC 16 C34 Common Rail Var.2
 207	ENGINE MANAGEME	1.4 HDI 50kw 8HZ	SIEMENS SID 806 Common Rail
 207	ENGINE MANAGEME	1.6 16v 110kw 5FX	BOSCH ME 7.4.5 Var.1
 207	ENGINE MANAGEME	1.6 16v 110kw 5FX	BOSCH ME 7.4.5 Var.2
 207	ENGINE MANAGEME	1.6 16v 128kw 5FY	BOSCH ME 7.4.5 Var.1
 207	ENGINE MANAGEME	1.6 16v 128kw 5FY	BOSCH ME 7.4.5 Var.2
 207	ENGINE MANAGEME	1.6 16v 80kw NFU	BOSCH ME 7.4.5 Var.1
 207	ENGINE MANAGEME	1.6 16v 80kw NFU	BOSCH ME 7.4.5 Var.2
 207	ENGINE MANAGEME	1.6 16v 88kw 5FW	BOSCH ME 7.4.5 Var.1
 207	ENGINE MANAGEME	1.6 16v 88kw 5FW	BOSCH ME 7.4.5 Var.2
 207	ENGINE MANAGEME	1.6 HDI 16v 66kw 9HV	BOSCH EDC 16 C34 Common Rail
 207	ENGINE MANAGEME	1.6 HDI 16v 66kw 9HV	BOSCH EDC 16 C34 Common Rail Var.1
 207	ENGINE MANAGEME	1.6 HDI 16v 66kw 9HV	BOSCH EDC 16 C34 Common Rail Var.2
 207	ENGINE MANAGEME	1.6 HDI 16v 66kw 9HX	BOSCH EDC 16 C3 Common Rail
 207	ENGINE MANAGEME	1.6 HDI 16v 66kw 9HX	BOSCH EDC 16 C34 Common Rail Var.1
 207	ENGINE MANAGEME	1.6 HDI 16v 66kw 9HX	BOSCH EDC 16 C34 Common Rail Var.2
 207	ENGINE MANAGEME	1.6 HDI 16v 68kw 9HP	BOSCH EDC 16 C34 Common Rail
 207	ENGINE MANAGEME	1.6 HDI 16v 68kw 9HP	BOSCH EDC 16 C34 Common Rail Var.1
 207	ENGINE MANAGEME	1.6 HDI 16v 68kw 9HP	BOSCH EDC 16 C34 Common Rail Var.2
 207	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail
 207	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.1
 207	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.2
 207	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail
 207	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 207	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.2
 207	ENGINE MANAGEME	1.6 HDI 16v 82kw 9HR	EOBD
 207	MAINTENANCE	1.4 16v 66kw KFU	A/T AM6
 207	MAINTENANCE	1.4 16v 66kw KFU	A/T AM6
 207	MAINTENANCE	1.4 16v 66kw KFU	AirBag CENTRAL
 207	MAINTENANCE	1.4 16v 66kw KFU	AirBag CENTRAL
 207	MAINTENANCE	1.4 16v 66kw KFU	SAGEM Dashboard
 207	MAINTENANCE	1.4 16v 66kw KFU	SIEMENS
 207	MAINTENANCE	1.4 16v 66kw KFU	SIEMENS Body Computer BSI
 207	MAINTENANCE	1.4 16v 66kw KFU	TEVES ABS MK70 2
 207	MAINTENANCE	1.4 16v 66kw KFU	TEVES ESP MK60 2
 207	MAINTENANCE	1.4 16v 66kw KFU	TEVES ESP MK60 2
 207	MAINTENANCE	1.4 16v 66kw KFU	Var.1
 207	MAINTENANCE	1.4 16v 66kw KFU	Var.1
 207	MAINTENANCE	1.4 16v 66kw KFU	Var.1
 207	MAINTENANCE	1.4 16v 66kw KFU	Var.2
 207	MAINTENANCE	1.4 16v 66kw KFU	Var.2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 207	MAINTENANCE	1.4 16v 66kw KFU	Var.2
 207	MAINTENANCE	1.4 16v 66kw KFU	Var.3
 207	MAINTENANCE	1.4 16v 70kw 8FS	A/T AM6
 207	MAINTENANCE	1.4 16v 70kw 8FS	A/T AM6
 207	MAINTENANCE	1.4 16v 70kw 8FS	AirBag CENTRAL
 207	MAINTENANCE	1.4 16v 70kw 8FS	AirBag CENTRAL
 207	MAINTENANCE	1.4 16v 70kw 8FS	SAGEM Dashboard
 207	MAINTENANCE	1.4 16v 70kw 8FS	SIEMENS
 207	MAINTENANCE	1.4 16v 70kw 8FS	SIEMENS Body Computer BSI
 207	MAINTENANCE	1.4 16v 70kw 8FS	TEVES ABS MK70 2
 207	MAINTENANCE	1.4 16v 70kw 8FS	TEVES ESP MK60 2
 207	MAINTENANCE	1.4 16v 70kw 8FS	TEVES ESP MK60 2
 207	MAINTENANCE	1.4 16v 70kw 8FS	Var.1
 207	MAINTENANCE	1.4 16v 70kw 8FS	Var.1
 207	MAINTENANCE	1.4 16v 70kw 8FS	Var.1
 207	MAINTENANCE	1.4 16v 70kw 8FS	Var.2
 207	MAINTENANCE	1.4 16v 70kw 8FS	Var.2
 207	MAINTENANCE	1.4 16v 70kw 8FS	Var.3
 207	MAINTENANCE	1.4 54kw KFT	A/T AM6
 207	MAINTENANCE	1.4 54kw KFT	A/T AM6
 207	MAINTENANCE	1.4 54kw KFT	AirBag CENTRAL
 207	MAINTENANCE	1.4 54kw KFT	AirBag CENTRAL
 207	MAINTENANCE	1.4 54kw KFT	SAGEM Dashboard
 207	MAINTENANCE	1.4 54kw KFT	SIEMENS
 207	MAINTENANCE	1.4 54kw KFT	SIEMENS Body Computer BSI
 207	MAINTENANCE	1.4 54kw KFT	TEVES ABS MK70 2
 207	MAINTENANCE	1.4 54kw KFT	TEVES ESP MK60 2
 207	MAINTENANCE	1.4 54kw KFT	TEVES ESP MK60 2
 207	MAINTENANCE	1.4 54kw KFT	Var.1
 207	MAINTENANCE	1.4 54kw KFT	Var.1
 207	MAINTENANCE	1.4 54kw KFT	Var.1
 207	MAINTENANCE	1.4 54kw KFT	Var.2
 207	MAINTENANCE	1.4 54kw KFT	Var.2
 207	MAINTENANCE	1.4 54kw KFT	Var.2
 207	MAINTENANCE	1.4 54kw KFT	Var.3
 207	MAINTENANCE	1.4 55kw KFV	A/T AM6
 207	MAINTENANCE	1.4 55kw KFV	A/T AM6
 207	MAINTENANCE	1.4 55kw KFV	AirBag CENTRAL
 207	MAINTENANCE	1.4 55kw KFV	AirBag CENTRAL
 207	MAINTENANCE	1.4 55kw KFV	SAGEM Dashboard
 207	MAINTENANCE	1.4 55kw KFV	SIEMENS
 207	MAINTENANCE	1.4 55kw KFV	SIEMENS Body Computer BSI
 207	MAINTENANCE	1.4 55kw KFV	TEVES ABS MK70 2
 207	MAINTENANCE	1.4 55kw KFV	TEVES ESP MK60 2
 207	MAINTENANCE	1.4 55kw KFV	TEVES ESP MK60 2
 207	MAINTENANCE	1.4 55kw KFV	Var.1
 207	MAINTENANCE	1.4 55kw KFV	Var.1
 207	MAINTENANCE	1.4 55kw KFV	Var.1
 207	MAINTENANCE	1.4 55kw KFV	Var.2
 207	MAINTENANCE	1.4 55kw KFV	Var.2
 207	MAINTENANCE	1.4 55kw KFV	Var.2
 207	MAINTENANCE	1.4 55kw KFV	Var.3
 207	MAINTENANCE	1.4 HDI 50kw 8HZ	
 207	MAINTENANCE	1.4 HDI 50kw 8HZ	A/T AM6
 207	MAINTENANCE	1.4 HDI 50kw 8HZ	A/T AM6
 207	MAINTENANCE	1.4 HDI 50kw 8HZ	AirBag CENTRAL
 207	MAINTENANCE	1.4 HDI 50kw 8HZ	AirBag CENTRAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 207	MAINTENANCE	1.4 HDI 50kw 8HZ	SAGEM Dashboard
 207	MAINTENANCE	1.4 HDI 50kw 8HZ	SIEMENS
 207	MAINTENANCE	1.4 HDI 50kw 8HZ	SIEMENS Body Computer BSI
 207	MAINTENANCE	1.4 HDI 50kw 8HZ	TEVES ABS MK70 2
 207	MAINTENANCE	1.4 HDI 50kw 8HZ	TEVES ESP MK60 2
 207	MAINTENANCE	1.4 HDI 50kw 8HZ	TEVES ESP MK60 2
 207	MAINTENANCE	1.4 HDI 50kw 8HZ	Var.1
 207	MAINTENANCE	1.4 HDI 50kw 8HZ	Var.1
 207	MAINTENANCE	1.4 HDI 50kw 8HZ	Var.1
 207	MAINTENANCE	1.4 HDI 50kw 8HZ	Var.2
 207	MAINTENANCE	1.4 HDI 50kw 8HZ	Var.2
 207	MAINTENANCE	1.4 HDI 50kw 8HZ	Var.2
 207	MAINTENANCE	1.4 HDI 50kw 8HZ	Var.3
 207	MAINTENANCE	1.6 16v 110kw 5FX	A/T AM6
 207	MAINTENANCE	1.6 16v 110kw 5FX	A/T AM6
 207	MAINTENANCE	1.6 16v 110kw 5FX	AirBag CENTRAL
 207	MAINTENANCE	1.6 16v 110kw 5FX	AirBag CENTRAL
 207	MAINTENANCE	1.6 16v 110kw 5FX	SAGEM Dashboard
 207	MAINTENANCE	1.6 16v 110kw 5FX	SIEMENS
 207	MAINTENANCE	1.6 16v 110kw 5FX	SIEMENS Body Computer BSI
 207	MAINTENANCE	1.6 16v 110kw 5FX	TEVES ABS MK70 2
 207	MAINTENANCE	1.6 16v 110kw 5FX	TEVES ESP MK60 2
 207	MAINTENANCE	1.6 16v 110kw 5FX	TEVES ESP MK60 2
 207	MAINTENANCE	1.6 16v 110kw 5FX	Var.1
 207	MAINTENANCE	1.6 16v 110kw 5FX	Var.1
 207	MAINTENANCE	1.6 16v 110kw 5FX	Var.1
 207	MAINTENANCE	1.6 16v 110kw 5FX	Var.2
 207	MAINTENANCE	1.6 16v 110kw 5FX	Var.2
 207	MAINTENANCE	1.6 16v 110kw 5FX	Var.2
 207	MAINTENANCE	1.6 16v 110kw 5FX	Var.3
 207	MAINTENANCE	1.6 16v 128kw 5FY	A/T AM6
 207	MAINTENANCE	1.6 16v 128kw 5FY	A/T AM6
 207	MAINTENANCE	1.6 16v 128kw 5FY	AirBag CENTRAL
 207	MAINTENANCE	1.6 16v 128kw 5FY	AirBag CENTRAL
 207	MAINTENANCE	1.6 16v 128kw 5FY	SAGEM Dashboard
 207	MAINTENANCE	1.6 16v 128kw 5FY	SIEMENS
 207	MAINTENANCE	1.6 16v 128kw 5FY	SIEMENS Body Computer BSI
 207	MAINTENANCE	1.6 16v 128kw 5FY	TEVES ABS MK70 2
 207	MAINTENANCE	1.6 16v 128kw 5FY	TEVES ESP MK60 2
 207	MAINTENANCE	1.6 16v 128kw 5FY	TEVES ESP MK60 2
 207	MAINTENANCE	1.6 16v 128kw 5FY	Var.1
 207	MAINTENANCE	1.6 16v 128kw 5FY	Var.1
 207	MAINTENANCE	1.6 16v 128kw 5FY	Var.1
 207	MAINTENANCE	1.6 16v 128kw 5FY	Var.2
 207	MAINTENANCE	1.6 16v 128kw 5FY	Var.2
 207	MAINTENANCE	1.6 16v 128kw 5FY	Var.2
 207	MAINTENANCE	1.6 16v 128kw 5FY	Var.3
 207	MAINTENANCE	1.6 16v 80kw NFU	A/T AM6
 207	MAINTENANCE	1.6 16v 80kw NFU	A/T AM6
 207	MAINTENANCE	1.6 16v 80kw NFU	AirBag CENTRAL
 207	MAINTENANCE	1.6 16v 80kw NFU	AirBag CENTRAL
 207	MAINTENANCE	1.6 16v 80kw NFU	SAGEM Dashboard
 207	MAINTENANCE	1.6 16v 80kw NFU	SIEMENS
 207	MAINTENANCE	1.6 16v 80kw NFU	SIEMENS Body Computer BSI
 207	MAINTENANCE	1.6 16v 80kw NFU	TEVES ABS MK70 2
 207	MAINTENANCE	1.6 16v 80kw NFU	TEVES ESP MK60 2
 207	MAINTENANCE	1.6 16v 80kw NFU	TEVES ESP MK60 2
 207	MAINTENANCE	1.6 16v 80kw NFU	Var.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 207	MAINTENANCE	1.6 16v 80kw NFU	Var.1
 207	MAINTENANCE	1.6 16v 80kw NFU	Var.1
 207	MAINTENANCE	1.6 16v 80kw NFU	Var.2
 207	MAINTENANCE	1.6 16v 80kw NFU	Var.2
 207	MAINTENANCE	1.6 16v 80kw NFU	Var.2
 207	MAINTENANCE	1.6 16v 80kw NFU	Var.3
 207	MAINTENANCE	1.6 16v 88kw 5FW	A/T AM6
 207	MAINTENANCE	1.6 16v 88kw 5FW	A/T AM6
 207	MAINTENANCE	1.6 16v 88kw 5FW	AirBag CENTRAL
 207	MAINTENANCE	1.6 16v 88kw 5FW	AirBag CENTRAL
 207	MAINTENANCE	1.6 16v 88kw 5FW	SAGEM Dashboard
 207	MAINTENANCE	1.6 16v 88kw 5FW	SIEMENS
 207	MAINTENANCE	1.6 16v 88kw 5FW	SIEMENS Body Computer BSI
 207	MAINTENANCE	1.6 16v 88kw 5FW	TEVES ABS MK70 2
 207	MAINTENANCE	1.6 16v 88kw 5FW	TEVES ESP MK60 2
 207	MAINTENANCE	1.6 16v 88kw 5FW	TEVES ESP MK60 2
 207	MAINTENANCE	1.6 16v 88kw 5FW	Var.1
 207	MAINTENANCE	1.6 16v 88kw 5FW	Var.1
 207	MAINTENANCE	1.6 16v 88kw 5FW	Var.1
 207	MAINTENANCE	1.6 16v 88kw 5FW	Var.2
 207	MAINTENANCE	1.6 16v 88kw 5FW	Var.2
 207	MAINTENANCE	1.6 16v 88kw 5FW	Var.2
 207	MAINTENANCE	1.6 16v 88kw 5FW	Var.2
 207	MAINTENANCE	1.6 16v 88kw 5FW	Var.3
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HV	
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HV	A/T AM6
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HV	A/T AM6
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HV	AirBag CENTRAL
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HV	AirBag CENTRAL
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HV	BOSCH EDC 16 C34 Common Rail Var.1
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HV	BOSCH EDC 16 C34 Common Rail Var.1
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HV	BOSCH EDC 16 C34 Common Rail Var.1
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HV	BOSCH EDC 16 C34 Common Rail Var.1
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HV	BOSCH EDC 16 C34 Common Rail Var.1
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HV	BOSCH EDC 16 C34 Common Rail Var.1
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HV	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HV	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HV	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HV	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HV	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HV	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HV	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HV	SAGEM Dashboard
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HV	SIEMENS
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HV	SIEMENS Body Computer BSI
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HV	TEVES ABS MK70 2
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HV	TEVES ESP MK60 2
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HV	TEVES ESP MK60 2
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HV	Var.1
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HV	Var.1
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HV	Var.1
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HV	Var.2
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HV	Var.2
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HV	Var.2
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HV	Var.3
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HX	A/T AM6
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HX	A/T AM6
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HX	AirBag CENTRAL
207	MAINTENANCE	1.6 HDI 16v 66kw 9HX	AirBag CENTRAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC 16 C34 Common Rail Var.1
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC 16 C34 Common Rail Var.1
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC 16 C34 Common Rail Var.1
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC 16 C34 Common Rail Var.1
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC 16 C34 Common Rail Var.1
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC 16 C34 Common Rail Var.1
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HX	SAGEM Dashboard
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HX	SIEMENS
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HX	SIEMENS Body Computer BSI
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HX	TEVES ABS MK70 2
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HX	TEVES ESP MK60 2
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HX	TEVES ESP MK60 2
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Var.1
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Var.1
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Var.1
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Var.2
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Var.2
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Var.2
 207	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Var.3
 207	MAINTENANCE	1.6 HDI 16v 68kw 9HP	
 207	MAINTENANCE	1.6 HDI 16v 68kw 9HP	A/T AM6
 207	MAINTENANCE	1.6 HDI 16v 68kw 9HP	A/T AM6
 207	MAINTENANCE	1.6 HDI 16v 68kw 9HP	AirBag CENTRAL
 207	MAINTENANCE	1.6 HDI 16v 68kw 9HP	AirBag CENTRAL
 207	MAINTENANCE	1.6 HDI 16v 68kw 9HP	BOSCH EDC 16 C34 Common Rail Var.1
 207	MAINTENANCE	1.6 HDI 16v 68kw 9HP	BOSCH EDC 16 C34 Common Rail Var.1
 207	MAINTENANCE	1.6 HDI 16v 68kw 9HP	BOSCH EDC 16 C34 Common Rail Var.1
 207	MAINTENANCE	1.6 HDI 16v 68kw 9HP	BOSCH EDC 16 C34 Common Rail Var.1
 207	MAINTENANCE	1.6 HDI 16v 68kw 9HP	BOSCH EDC 16 C34 Common Rail Var.1
 207	MAINTENANCE	1.6 HDI 16v 68kw 9HP	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 68kw 9HP	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 68kw 9HP	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 68kw 9HP	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 68kw 9HP	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 68kw 9HP	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 68kw 9HP	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 68kw 9HP	SAGEM Dashboard
 207	MAINTENANCE	1.6 HDI 16v 68kw 9HP	SIEMENS
 207	MAINTENANCE	1.6 HDI 16v 68kw 9HP	SIEMENS Body Computer BSI
 207	MAINTENANCE	1.6 HDI 16v 68kw 9HP	TEVES ABS MK70 2
 207	MAINTENANCE	1.6 HDI 16v 68kw 9HP	TEVES ESP MK60 2
 207	MAINTENANCE	1.6 HDI 16v 68kw 9HP	TEVES ESP MK60 2
 207	MAINTENANCE	1.6 HDI 16v 68kw 9HP	Var.1
 207	MAINTENANCE	1.6 HDI 16v 68kw 9HP	Var.1
 207	MAINTENANCE	1.6 HDI 16v 68kw 9HP	Var.1
 207	MAINTENANCE	1.6 HDI 16v 68kw 9HP	Var.2
 207	MAINTENANCE	1.6 HDI 16v 68kw 9HP	Var.2
 207	MAINTENANCE	1.6 HDI 16v 68kw 9HP	Var.2
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HY	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HY	A/T AM6
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HY	A/T AM6
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HY	AirBag CENTRAL
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HY	AirBag CENTRAL
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.1
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.1
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.1
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.1
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.1
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HY	SAGEM Dashboard
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HY	SIEMENS
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HY	SIEMENS Body Computer BSI
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HY	TEVES ABS MK70 2
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HY	TEVES ESP MK60 2
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HY	TEVES ESP MK60 2
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.1
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.1
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.1
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.2
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.2
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.2
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.3
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	A/T AM6
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	A/T AM6
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.2
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	SAGEM Dashboard
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	SIEMENS
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	SIEMENS Body Computer BSI
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	TEVES ABS MK70 2
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	TEVES ESP MK60 2
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	TEVES ESP MK60 2
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 207	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.3
 207	MAINTENANCE	1.6 HDI 16v 82kw 9HR	A/T AM6
 207	MAINTENANCE	1.6 HDI 16v 82kw 9HR	A/T AM6
 207	MAINTENANCE	1.6 HDI 16v 82kw 9HR	AirBag CENTRAL
 207	MAINTENANCE	1.6 HDI 16v 82kw 9HR	AirBag CENTRAL
 207	MAINTENANCE	1.6 HDI 16v 82kw 9HR	SAGEM Dashboard
 207	MAINTENANCE	1.6 HDI 16v 82kw 9HR	SIEMENS
 207	MAINTENANCE	1.6 HDI 16v 82kw 9HR	SIEMENS Body Computer BSI
 207	MAINTENANCE	1.6 HDI 16v 82kw 9HR	TEVES ABS MK70 2
 207	MAINTENANCE	1.6 HDI 16v 82kw 9HR	TEVES ESP MK60 2
 207	MAINTENANCE	1.6 HDI 16v 82kw 9HR	TEVES ESP MK60 2
 207	MAINTENANCE	1.6 HDI 16v 82kw 9HR	Var.1
 207	MAINTENANCE	1.6 HDI 16v 82kw 9HR	Var.1
 207	MAINTENANCE	1.6 HDI 16v 82kw 9HR	Var.1
 207	MAINTENANCE	1.6 HDI 16v 82kw 9HR	Var.2
 207	MAINTENANCE	1.6 HDI 16v 82kw 9HR	Var.2
 207	MAINTENANCE	1.6 HDI 16v 82kw 9HR	Var.2
 207	MAINTENANCE	1.6 HDI 16v 82kw 9HR	Var.3
 207	PARKING HELP	1.4 16v 66kw KFJ	Var.1
 207	PARKING HELP	1.4 16v 66kw KFJ	Var.2
 207	PARKING HELP	1.4 16v 70kw 8FS	Var.1
 207	PARKING HELP	1.4 16v 70kw 8FS	Var.2
 207	PARKING HELP	1.4 54kw KFT	Var.1
 207	PARKING HELP	1.4 54kw KFT	Var.2
 207	PARKING HELP	1.4 55kw KFV	Var.1
 207	PARKING HELP	1.4 55kw KFV	Var.2
 207	PARKING HELP	1.4 HDI 50kw 8HZ	Var.1
 207	PARKING HELP	1.4 HDI 50kw 8HZ	Var.2
 207	PARKING HELP	1.6 16v 110kw 5FX	Var.1
 207	PARKING HELP	1.6 16v 110kw 5FX	Var.2
 207	PARKING HELP	1.6 16v 128kw 5FY	Var.1
 207	PARKING HELP	1.6 16v 128kw 5FY	Var.2
 207	PARKING HELP	1.6 16v 80kw NFU	Var.1
 207	PARKING HELP	1.6 16v 80kw NFU	Var.2
 207	PARKING HELP	1.6 16v 88kw 5FW	Var.1
 207	PARKING HELP	1.6 16v 88kw 5FW	Var.2
 207	PARKING HELP	1.6 HDI 16v 66kw 9HV	Var.1
 207	PARKING HELP	1.6 HDI 16v 66kw 9HV	Var.2
 207	PARKING HELP	1.6 HDI 16v 66kw 9HX	Var.1
 207	PARKING HELP	1.6 HDI 16v 66kw 9HX	Var.2
 207	PARKING HELP	1.6 HDI 16v 68kw 9HP	Var.1
 207	PARKING HELP	1.6 HDI 16v 68kw 9HP	Var.2
 207	PARKING HELP	1.6 HDI 16v 80kw 9HY	Var.1
 207	PARKING HELP	1.6 HDI 16v 80kw 9HY	Var.2
 207	PARKING HELP	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 207	PARKING HELP	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 207	PARKING HELP	1.6 HDI 16v 82kw 9HR	Var.1
 207	PARKING HELP	1.6 HDI 16v 82kw 9HR	Var.2
 207	RADIO / CD	1.4 16v 66kw KFJ	Var.1
 207	RADIO / CD	1.4 16v 66kw KFJ	Var.2
 207	RADIO / CD	1.4 16v 66kw KFJ	Var.3
 207	RADIO / CD	1.4 16v 66kw KFJ	Var.4
 207	RADIO / CD	1.4 16v 70kw 8FS	Var.1
 207	RADIO / CD	1.4 16v 70kw 8FS	Var.2
 207	RADIO / CD	1.4 16v 70kw 8FS	Var.3
 207	RADIO / CD	1.4 16v 70kw 8FS	Var.4

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 207	RADIO / CD	1.4 54kw KFT	Var.1
 207	RADIO / CD	1.4 54kw KFT	Var.2
 207	RADIO / CD	1.4 54kw KFT	Var.3
 207	RADIO / CD	1.4 54kw KFT	Var.4
 207	RADIO / CD	1.4 55kw KfV	Var.1
 207	RADIO / CD	1.4 55kw KfV	Var.2
 207	RADIO / CD	1.4 55kw KfV	Var.3
 207	RADIO / CD	1.4 55kw KfV	Var.4
 207	RADIO / CD	1.4 HDI 50kw 8HZ	Var.1
 207	RADIO / CD	1.4 HDI 50kw 8HZ	Var.2
 207	RADIO / CD	1.4 HDI 50kw 8HZ	Var.3
 207	RADIO / CD	1.4 HDI 50kw 8HZ	Var.4
 207	RADIO / CD	1.6 16v 110kw 5FX	Var.1
 207	RADIO / CD	1.6 16v 110kw 5FX	Var.2
 207	RADIO / CD	1.6 16v 110kw 5FX	Var.3
 207	RADIO / CD	1.6 16v 110kw 5FX	Var.4
 207	RADIO / CD	1.6 16v 128kw 5FY	Var.1
 207	RADIO / CD	1.6 16v 128kw 5FY	Var.2
 207	RADIO / CD	1.6 16v 128kw 5FY	Var.3
 207	RADIO / CD	1.6 16v 128kw 5FY	Var.4
 207	RADIO / CD	1.6 16v 80kw NFU	Var.1
 207	RADIO / CD	1.6 16v 80kw NFU	Var.2
 207	RADIO / CD	1.6 16v 80kw NFU	Var.3
 207	RADIO / CD	1.6 16v 80kw NFU	Var.4
 207	RADIO / CD	1.6 16v 88kw 5FW	Var.1
 207	RADIO / CD	1.6 16v 88kw 5FW	Var.2
 207	RADIO / CD	1.6 16v 88kw 5FW	Var.3
 207	RADIO / CD	1.6 16v 88kw 5FW	Var.4
 207	RADIO / CD	1.6 HDI 16v 66kw 9HV	Var.1
 207	RADIO / CD	1.6 HDI 16v 66kw 9HV	Var.2
 207	RADIO / CD	1.6 HDI 16v 66kw 9HV	Var.3
 207	RADIO / CD	1.6 HDI 16v 66kw 9HV	Var.4
 207	RADIO / CD	1.6 HDI 16v 66kw 9HX	Var.1
 207	RADIO / CD	1.6 HDI 16v 66kw 9HX	Var.2
 207	RADIO / CD	1.6 HDI 16v 66kw 9HX	Var.3
 207	RADIO / CD	1.6 HDI 16v 66kw 9HX	Var.4
 207	RADIO / CD	1.6 HDI 16v 68kw 9HP	Var.1
 207	RADIO / CD	1.6 HDI 16v 68kw 9HP	Var.2
 207	RADIO / CD	1.6 HDI 16v 68kw 9HP	Var.3
 207	RADIO / CD	1.6 HDI 16v 68kw 9HP	Var.4
 207	RADIO / CD	1.6 HDI 16v 80kw 9HY	Var.1
 207	RADIO / CD	1.6 HDI 16v 80kw 9HY	Var.2
 207	RADIO / CD	1.6 HDI 16v 80kw 9HY	Var.3
 207	RADIO / CD	1.6 HDI 16v 80kw 9HY	Var.4
 207	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 207	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 207	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Var.3
 207	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Var.4
 207	RADIO / CD	1.6 HDI 16v 82kw 9HR	Var.1
 207	RADIO / CD	1.6 HDI 16v 82kw 9HR	Var.2
 207	RADIO / CD	1.6 HDI 16v 82kw 9HR	Var.3
 207	RADIO / CD	1.6 HDI 16v 82kw 9HR	Var.4
 207	RAIN-LUMINOSITY S	1.4 16v 66kw KFU	Var.1
 207	RAIN-LUMINOSITY S	1.4 16v 66kw KFU	Var.2
 207	RAIN-LUMINOSITY S	1.4 16v 70kw 8FS	Var.1
 207	RAIN-LUMINOSITY S	1.4 16v 70kw 8FS	Var.2
 207	RAIN-LUMINOSITY S	1.4 54kw KFT	Var.1
 207	RAIN-LUMINOSITY S	1.4 54kw KFT	Var.2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 207	RAIN-LUMINOSITY S	1.4 55kw KFV	Var.1
 207	RAIN-LUMINOSITY S	1.4 55kw KFV	Var.2
 207	RAIN-LUMINOSITY S	1.4 HDI 50kw 8HZ	Var.1
 207	RAIN-LUMINOSITY S	1.4 HDI 50kw 8HZ	Var.2
 207	RAIN-LUMINOSITY S	1.6 16v 110kw 5FX	Var.1
 207	RAIN-LUMINOSITY S	1.6 16v 110kw 5FX	Var.2
 207	RAIN-LUMINOSITY S	1.6 16v 128kw 5FY	Var.1
 207	RAIN-LUMINOSITY S	1.6 16v 128kw 5FY	Var.2
 207	RAIN-LUMINOSITY S	1.6 16v 80kw NFU	Var.1
 207	RAIN-LUMINOSITY S	1.6 16v 80kw NFU	Var.2
 207	RAIN-LUMINOSITY S	1.6 16v 88kw 5FW	Var.1
 207	RAIN-LUMINOSITY S	1.6 16v 88kw 5FW	Var.2
 207	RAIN-LUMINOSITY S	1.6 HDI 16v 66kw 9HV	Var.1
 207	RAIN-LUMINOSITY S	1.6 HDI 16v 66kw 9HV	Var.2
 207	RAIN-LUMINOSITY S	1.6 HDI 16v 66kw 9HX	Var.1
 207	RAIN-LUMINOSITY S	1.6 HDI 16v 66kw 9HX	Var.2
 207	RAIN-LUMINOSITY S	1.6 HDI 16v 68kw 9HP	Var.1
 207	RAIN-LUMINOSITY S	1.6 HDI 16v 68kw 9HP	Var.2
 207	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HY	Var.1
 207	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HY	Var.2
 207	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 207	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 207	RAIN-LUMINOSITY S	1.6 HDI 16v 82kw 9HR	Var.1
 207	RAIN-LUMINOSITY S	1.6 HDI 16v 82kw 9HR	Var.2
 207	SERVICE LIGHT RES	1.4 16v 66kw KFU	SIEMENS
 207	SERVICE LIGHT RES	1.4 16v 70kw 8FS	SIEMENS
 207	SERVICE LIGHT RES	1.4 54kw KFT	SIEMENS
 207	SERVICE LIGHT RES	1.4 55kw KFV	SIEMENS
 207	SERVICE LIGHT RES	1.4 HDI 50kw 8HZ	SIEMENS
 207	SERVICE LIGHT RES	1.6 16v 110kw 5FX	SIEMENS
 207	SERVICE LIGHT RES	1.6 16v 128kw 5FY	SIEMENS
 207	SERVICE LIGHT RES	1.6 16v 80kw NFU	SIEMENS
 207	SERVICE LIGHT RES	1.6 16v 88kw 5FW	SIEMENS
 207	SERVICE LIGHT RES	1.6 HDI 16v 66kw 9HV	SIEMENS
 207	SERVICE LIGHT RES	1.6 HDI 16v 66kw 9HX	SIEMENS
 207	SERVICE LIGHT RES	1.6 HDI 16v 68kw 9HP	SIEMENS
 207	SERVICE LIGHT RES	1.6 HDI 16v 80kw 9HY	SIEMENS
 207	SERVICE LIGHT RES	1.6 HDI 16v 80kw 9HZ-FAP	SIEMENS
 207	SERVICE LIGHT RES	1.6 HDI 16v 82kw 9HR	SIEMENS
 207	STEERING COLUMN	1.4 16v 66kw KFU	
 207	STEERING COLUMN	1.4 16v 70kw 8FS	
 207	STEERING COLUMN	1.4 54kw KFT	
 207	STEERING COLUMN	1.4 55kw KFV	
 207	STEERING COLUMN	1.4 HDI 50kw 8HZ	
 207	STEERING COLUMN	1.6 16v 110kw 5FX	
 207	STEERING COLUMN	1.6 16v 128kw 5FY	
 207	STEERING COLUMN	1.6 16v 80kw NFU	
 207	STEERING COLUMN	1.6 16v 88kw 5FW	
 207	STEERING COLUMN	1.6 HDI 16v 66kw 9HV	
 207	STEERING COLUMN	1.6 HDI 16v 66kw 9HX	
 207	STEERING COLUMN	1.6 HDI 16v 68kw 9HP	
 207	STEERING COLUMN	1.6 HDI 16v 80kw 9HY	
 207	STEERING COLUMN	1.6 HDI 16v 80kw 9HZ-FAP	
 207	STEERING COLUMN	1.6 HDI 16v 82kw 9HR	
 207	SWITCHLIGHT MODU	1.4 16v 66kw KFU	EATON/DELPHI
 207	SWITCHLIGHT MODU	1.4 16v 70kw 8FS	EATON/DELPHI
 207	SWITCHLIGHT MODU	1.4 54kw KFT	EATON/DELPHI
 207	SWITCHLIGHT MODU	1.4 55kw KFV	EATON/DELPHI

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 207	SWITCHLIGHT MODU	1.4 HDI 50kw 8HZ	EATON/DELPHI
 207	SWITCHLIGHT MODU	1.6 16v 110kw 5FX	EATON/DELPHI
 207	SWITCHLIGHT MODU	1.6 16v 128kw 5FY	EATON/DELPHI
 207	SWITCHLIGHT MODU	1.6 16v 80kw NFU	EATON/DELPHI
 207	SWITCHLIGHT MODU	1.6 16v 88kw 5FW	EATON/DELPHI
 207	SWITCHLIGHT MODU	1.6 HDI 16v 66kw 9HV	EATON/DELPHI
 207	SWITCHLIGHT MODU	1.6 HDI 16v 66kw 9HX	EATON/DELPHI
 207	SWITCHLIGHT MODU	1.6 HDI 16v 68kw 9HP	EATON/DELPHI
 207	SWITCHLIGHT MODU	1.6 HDI 16v 80kw 9HY	EATON/DELPHI
 207	SWITCHLIGHT MODU	1.6 HDI 16v 80kw 9HZ-FAP	EATON/DELPHI
 207	SWITCHLIGHT MODU	1.6 HDI 16v 82kw 9HR	EATON/DELPHI
 207	VISUAL./TELEMATIC	1.4 16v 66kw KFU	Display A+
 207	VISUAL./TELEMATIC	1.4 16v 66kw KFU	Display C-
 207	VISUAL./TELEMATIC	1.4 16v 70kw 8FS	Display A+
 207	VISUAL./TELEMATIC	1.4 16v 70kw 8FS	Display C-
 207	VISUAL./TELEMATIC	1.4 54kw KFT	Display A+
 207	VISUAL./TELEMATIC	1.4 54kw KFT	Display C-
 207	VISUAL./TELEMATIC	1.4 55kw KFU	Display A+
 207	VISUAL./TELEMATIC	1.4 55kw KFU	Display C-
 207	VISUAL./TELEMATIC	1.4 HDI 50kw 8HZ	Display A+
 207	VISUAL./TELEMATIC	1.4 HDI 50kw 8HZ	Display C-
 207	VISUAL./TELEMATIC	1.6 16v 110kw 5FX	Display A+
 207	VISUAL./TELEMATIC	1.6 16v 110kw 5FX	Display C-
 207	VISUAL./TELEMATIC	1.6 16v 128kw 5FY	Display A+
 207	VISUAL./TELEMATIC	1.6 16v 128kw 5FY	Display C-
 207	VISUAL./TELEMATIC	1.6 16v 80kw NFU	Display A+
 207	VISUAL./TELEMATIC	1.6 16v 80kw NFU	Display C-
 207	VISUAL./TELEMATIC	1.6 16v 88kw 5FW	Display A+
 207	VISUAL./TELEMATIC	1.6 16v 88kw 5FW	Display C-
 207	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HV	Display A+
 207	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HV	Display C-
 207	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HX	Display A+
 207	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HX	Display C-
 207	VISUAL./TELEMATIC	1.6 HDI 16v 68kw 9HP	Display A+
 207	VISUAL./TELEMATIC	1.6 HDI 16v 68kw 9HP	Display C-
 207	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HY	Display A+
 207	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HY	Display C-
 207	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	Display A+
 207	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	Display C-
 207	VISUAL./TELEMATIC	1.6 HDI 16v 82kw 9HR	Display A+
 207	VISUAL./TELEMATIC	1.6 HDI 16v 82kw 9HR	Display C-
 3008	ABS + TRACT. CONT	1.6 16v 88kw 5FW	
 3008	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	
 3008	ABS + TRACT. CONT	1.6 THP 16v 110kw 5FX	
 3008	ABS + TRACT. CONT	1.6 THP 16v 115kw 5FV	
 3008	ABS + TRACT. CONT	2.0 HDI 16v 110kw RHE-FAP	
 3008	AIRBAG	1.6 16v 88kw 5FW	AirBag CENTRAL
 3008	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL
 3008	AIRBAG	1.6 THP 16v 110kw 5FX	AirBag CENTRAL
 3008	AIRBAG	1.6 THP 16v 115kw 5FV	AirBag CENTRAL
 3008	AIRBAG	2.0 HDI 16v 110kw RHE-FAP	AirBag CENTRAL
 3008	DRIVER SIDE DOOR	1.6 16v 88kw 5FW	
 3008	DRIVER SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	
 3008	DRIVER SIDE DOOR	1.6 THP 16v 110kw 5FX	
 3008	DRIVER SIDE DOOR	1.6 THP 16v 115kw 5FV	
 3008	DRIVER SIDE DOOR	2.0 HDI 16v 110kw RHE-FAP	
 3008	ELECTRIC STEERING	1.6 16v 88kw 5FW	
 3008	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 3008	ELECTRIC STEERING	1.6 THP 16v 110kw 5FX	
 3008	ELECTRIC STEERING	1.6 THP 16v 115kw 5FV	
 3008	ELECTRIC STEERING	2.0 HDI 16v 110kw RHE-FAP	
 3008	ENGINE MANAGEME	1.6 16v 88kw 5FW	EOBD
 3008	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 3008	ENGINE MANAGEME	1.6 THP 16v 110kw 5FX	EOBD
 3008	ENGINE MANAGEME	1.6 THP 16v 115kw 5FV	EOBD
 3008	ENGINE MANAGEME	2.0 HDI 16v 110kw RHE-FAP	EOBD
 3008	MAINTENANCE	1.6 16v 88kw 5FW	
 3008	MAINTENANCE	1.6 16v 88kw 5FW	
 3008	MAINTENANCE	1.6 16v 88kw 5FW	AirBag CENTRAL
 3008	MAINTENANCE	1.6 16v 88kw 5FW	AirBag CENTRAL
 3008	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	
 3008	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	
 3008	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL
 3008	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL
 3008	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 3008	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 3008	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 3008	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 3008	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 3008	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 3008	MAINTENANCE	1.6 THP 16v 110kw 5FX	
 3008	MAINTENANCE	1.6 THP 16v 110kw 5FX	
 3008	MAINTENANCE	1.6 THP 16v 110kw 5FX	AirBag CENTRAL
 3008	MAINTENANCE	1.6 THP 16v 110kw 5FX	AirBag CENTRAL
 3008	MAINTENANCE	1.6 THP 16v 115kw 5FV	
 3008	MAINTENANCE	1.6 THP 16v 115kw 5FV	
 3008	MAINTENANCE	1.6 THP 16v 115kw 5FV	AirBag CENTRAL
 3008	MAINTENANCE	1.6 THP 16v 115kw 5FV	AirBag CENTRAL
 3008	MAINTENANCE	2.0 HDI 16v 110kw RHE-FAP	
 3008	MAINTENANCE	2.0 HDI 16v 110kw RHE-FAP	
 3008	MAINTENANCE	2.0 HDI 16v 110kw RHE-FAP	AirBag CENTRAL
 3008	MAINTENANCE	2.0 HDI 16v 110kw RHE-FAP	AirBag CENTRAL
 3008	RADIO / CD	1.6 16v 88kw 5FW	
 3008	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	
 3008	RADIO / CD	1.6 THP 16v 110kw 5FX	
 3008	RADIO / CD	1.6 THP 16v 115kw 5FV	
 3008	RADIO / CD	2.0 HDI 16v 110kw RHE-FAP	
 3008	STEERING COLUMN	1.6 16v 88kw 5FW	
 3008	STEERING COLUMN	1.6 HDI 16v 80kw 9HZ-FAP	
 3008	STEERING COLUMN	1.6 THP 16v 110kw 5FX	
 3008	STEERING COLUMN	1.6 THP 16v 115kw 5FV	
 3008	STEERING COLUMN	2.0 HDI 16v 110kw RHE-FAP	
 3008	VISUAL./TELEMATIC	1.6 16v 88kw 5FW	Display C-
 3008	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	Display C-
 3008	VISUAL./TELEMATIC	1.6 THP 16v 110kw 5FX	Display C-
 3008	VISUAL./TELEMATIC	1.6 THP 16v 115kw 5FV	Display C-
 3008	VISUAL./TELEMATIC	2.0 HDI 16v 110kw RHE-FAP	Display C-
 306 Restyling	ABS	1.6 74kw NFT	BOSCH ABS ABR 5.3
 306 Restyling	ABS	1.8 16v 80kw LFY	BOSCH ABS ABR 5.3
 306 Restyling	ABS	2.0 16v 97kw RFV	BOSCH ABS ABR 5.3
 306 Restyling	ABS	2.0 HDI 66kw RHY	BOSCH ABS ABR 5.3
 306 Restyling	AIRBAG	1.6 74kw NFT (00-03)	AKF- Autoliv AirBag ACUxx
 306 Restyling	AIRBAG	1.6 74kw NFT (01-..)	AKF- Autoliv AirBag
 306 Restyling	AIRBAG	1.6 74kw NFT (97-00)	AKF- Autoliv AirBag no SIDE AB
306 Restyling	AIRBAG	1.6 74kw NFT (97-00)	AKF- Autoliv Side AirBag Left Side
306 Restyling	AIRBAG	1.6 74kw NFT (97-00)	AKF- Autoliv Side AirBag Right Side

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 306 Restyling	AIRBAG	1.8 16v 80kw LFY (00-03)	AKF- Autoliv AirBag ACUxx
 306 Restyling	AIRBAG	1.8 16v 80kw LFY (01-..)	AKF- Autoliv AirBag
 306 Restyling	AIRBAG	1.8 16v 80kw LFY (97-00)	AKF- Autoliv AirBag no SIDE AB
 306 Restyling	AIRBAG	1.8 16v 80kw LFY (97-00)	AKF- Autoliv Side AirBag Left Side
 306 Restyling	AIRBAG	1.8 16v 80kw LFY (97-00)	AKF- Autoliv Side AirBag Right Side
 306 Restyling	AIRBAG	2.0 16v 97kw RFV (00-03)	AKF- Autoliv AirBag ACUxx
 306 Restyling	AIRBAG	2.0 16v 97kw RFV (01-..)	AKF- Autoliv AirBag
 306 Restyling	AIRBAG	2.0 16v 97kw RFV (97-00)	AKF- Autoliv AirBag no SIDE AB
 306 Restyling	AIRBAG	2.0 16v 97kw RFV (97-00)	AKF- Autoliv Side AirBag Left Side
 306 Restyling	AIRBAG	2.0 16v 97kw RFV (97-00)	AKF- Autoliv Side AirBag Right Side
 306 Restyling	AIRBAG	2.0 HDI 66kw RHY (00-03)	AKF- Autoliv AirBag ACUxx
 306 Restyling	AIRBAG	2.0 HDI 66kw RHY (01-..)	AKF- Autoliv AirBag
 306 Restyling	AIRBAG	2.0 HDI 66kw RHY (97-00)	AKF- Autoliv AirBag no SIDE AB
 306 Restyling	AIRBAG	2.0 HDI 66kw RHY (97-00)	AKF- Autoliv Side AirBag Left Side
 306 Restyling	AIRBAG	2.0 HDI 66kw RHY (97-00)	AKF- Autoliv Side AirBag Right Side
 306 Restyling	CLIMA	1.6 74kw NFT	CLIMA AUTO
 306 Restyling	CLIMA	1.8 16v 80kw LFY	CLIMA AUTO
 306 Restyling	CLIMA	2.0 16v 97kw RFV	CLIMA AUTO
 306 Restyling	CLIMA	2.0 HDI 66kw RHY	CLIMA AUTO
 306 Restyling	ENGINE MANAGEME	1.6 74kw NFT	BOSCH M 7.4.4
 306 Restyling	ENGINE MANAGEME	1.8 16v 80kw LFY	SAGEM SL 96
 306 Restyling	ENGINE MANAGEME	2.0 16v 97kw RFV	BOSCH Motronic MP5.2
 306 Restyling	ENGINE MANAGEME	2.0 HDI 66kw RHY	BOSCH EDC 15 C2 Common Rail
 306 Restyling	ENGINE MANAGEME	2.0 HDI 66kw RHY	BOSCH EDC 15 C2 Common Rail
 306 Restyling	ENGINE MANAGEME	2.0 HDI 66kw RHY	SIEMENS Diesel SID 801 Common Rail
 306 Restyling	ENGINE MANAGEME	2.0 HDI 66kw RHY	SIEMENS SID 801 Common Rail
 306 Restyling	ENGINE MANAGEME	2.0 HDI 66kw RHY (..-00)	BOSCH EDC 15 C2 Common Rail
 306 Restyling	MAINTENANCE	1.6 74kw NFT	BOSCH ABS ABR 5.3
 306 Restyling	MAINTENANCE	1.6 74kw NFT	BOSCH ABS ABR 5.3
 306 Restyling	MAINTENANCE	1.6 74kw NFT	BOSCH ABS ABR 5.3
 306 Restyling	MAINTENANCE	1.6 74kw NFT	BOSCH ABS ABR 5.3
 306 Restyling	MAINTENANCE	1.6 74kw NFT (98-00)	VDO MANUAL
 306 Restyling	MAINTENANCE	1.8 16v 80kw LFY	BOSCH ABS ABR 5.3
 306 Restyling	MAINTENANCE	1.8 16v 80kw LFY	BOSCH ABS ABR 5.3
 306 Restyling	MAINTENANCE	1.8 16v 80kw LFY	BOSCH ABS ABR 5.3
 306 Restyling	MAINTENANCE	1.8 16v 80kw LFY	BOSCH ABS ABR 5.3
 306 Restyling	MAINTENANCE	1.8 16v 80kw LFY (98-00)	VDO MANUAL
 306 Restyling	MAINTENANCE	2.0 16v 97kw RFV	BOSCH ABS ABR 5.3
 306 Restyling	MAINTENANCE	2.0 16v 97kw RFV	BOSCH ABS ABR 5.3
 306 Restyling	MAINTENANCE	2.0 16v 97kw RFV	BOSCH ABS ABR 5.3
 306 Restyling	MAINTENANCE	2.0 16v 97kw RFV	BOSCH ABS ABR 5.3
 306 Restyling	MAINTENANCE	2.0 16v 97kw RFV (98-00)	VDO MANUAL
 306 Restyling	MAINTENANCE	2.0 HDI 66kw RHY	BOSCH ABS ABR 5.3
 306 Restyling	MAINTENANCE	2.0 HDI 66kw RHY	BOSCH ABS ABR 5.3
 306 Restyling	MAINTENANCE	2.0 HDI 66kw RHY	BOSCH ABS ABR 5.3
 306 Restyling	MAINTENANCE	2.0 HDI 66kw RHY	BOSCH ABS ABR 5.3
 306 Restyling	MAINTENANCE	2.0 HDI 66kw RHY	BOSCH EDC 15 C2 Common Rail
 306 Restyling	MAINTENANCE	2.0 HDI 66kw RHY	BOSCH EDC 15 C2 Common Rail
 306 Restyling	MAINTENANCE	2.0 HDI 66kw RHY (98-00)	VDO MANUAL
 306 Restyling	SERVICE LIGHT RES	1.6 74kw NFT (98-00)	VDO MANUAL
 306 Restyling	SERVICE LIGHT RES	1.8 16v 80kw LFY (98-00)	VDO MANUAL
 306 Restyling	SERVICE LIGHT RES	2.0 16v 97kw RFV (98-00)	VDO MANUAL
 306 Restyling	SERVICE LIGHT RES	2.0 HDI 66kw RHY (98-00)	VDO MANUAL
 306	ABS	1.1 44kw HDZ	BOSCH ABS ABR 5.3
 306	ABS	1.1 55kw HDY	BOSCH ABS ABR 5.3
 306	ABS	1.4 55kw KDX	BOSCH ABS ABR 5.3
 306	ABS	1.4 55kw KFX	BOSCH ABS ABR 5.3
 306	ABS	1.6 66kw NFZ	BOSCH ABS ABR 5.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 306	ABS	1.8 74kw LFZ	BOSCH ABS ABR 5.3
 306	ABS	1.8 D 44kw A9A	BOSCH ABS ABR 5.3
 306	ABS	1.9 D 51kw WJY	BOSCH ABS ABR 5.3
 306	ABS	1.9 D 68kw D8A	BOSCH ABS ABR 5.3
 306	ABS	2.0 16v 112kw RFY	BOSCH ABS ABR 5.3
 306	ABS	2.0 16v 122kw RFS	BOSCH ABS ABR 5.3
 306	ABS	2.0 90kw RFX	BOSCH ABS ABR 5.3
 306	AIRBAG	1.1 44kw HDZ (00-03)	AKF- Autoliv AirBag ACUxx
 306	AIRBAG	1.1 44kw HDZ (01-..)	AKF- Autoliv AirBag
 306	AIRBAG	1.1 44kw HDZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 306	AIRBAG	1.1 44kw HDZ (97-00)	AKF- Autoliv Side AirBag Left Side
 306	AIRBAG	1.1 44kw HDZ (97-00)	AKF- Autoliv Side AirBag Right Side
 306	AIRBAG	1.1 55kw HDY (00-03)	AKF- Autoliv AirBag ACUxx
 306	AIRBAG	1.1 55kw HDY (01-..)	AKF- Autoliv AirBag
 306	AIRBAG	1.1 55kw HDY (97-00)	AKF- Autoliv AirBag no SIDE AB
 306	AIRBAG	1.1 55kw HDY (97-00)	AKF- Autoliv Side AirBag Left Side
 306	AIRBAG	1.1 55kw HDY (97-00)	AKF- Autoliv Side AirBag Right Side
 306	AIRBAG	1.4 55kw KDX (00-03)	AKF- Autoliv AirBag ACUxx
 306	AIRBAG	1.4 55kw KDX (01-..)	AKF- Autoliv AirBag
 306	AIRBAG	1.4 55kw KDX (97-00)	AKF- Autoliv AirBag no SIDE AB
 306	AIRBAG	1.4 55kw KDX (97-00)	AKF- Autoliv Side AirBag Left Side
 306	AIRBAG	1.4 55kw KDX (97-00)	AKF- Autoliv Side AirBag Right Side
 306	AIRBAG	1.4 55kw KFX (00-03)	AKF- Autoliv AirBag ACUxx
 306	AIRBAG	1.4 55kw KFX (01-..)	AKF- Autoliv AirBag
 306	AIRBAG	1.4 55kw KFX (97-00)	AKF- Autoliv AirBag no SIDE AB
 306	AIRBAG	1.4 55kw KFX (97-00)	AKF- Autoliv Side AirBag Left Side
 306	AIRBAG	1.4 55kw KFX (97-00)	AKF- Autoliv Side AirBag Right Side
 306	AIRBAG	1.6 66kw NFZ (00-03)	AKF- Autoliv AirBag ACUxx
 306	AIRBAG	1.6 66kw NFZ (01-..)	AKF- Autoliv AirBag
 306	AIRBAG	1.6 66kw NFZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 306	AIRBAG	1.6 66kw NFZ (97-00)	AKF- Autoliv Side AirBag Left Side
 306	AIRBAG	1.6 66kw NFZ (97-00)	AKF- Autoliv Side AirBag Right Side
 306	AIRBAG	1.8 74kw LFZ (00-03)	AKF- Autoliv AirBag ACUxx
 306	AIRBAG	1.8 74kw LFZ (01-..)	AKF- Autoliv AirBag
 306	AIRBAG	1.8 74kw LFZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 306	AIRBAG	1.8 74kw LFZ (97-00)	AKF- Autoliv Side AirBag Left Side
 306	AIRBAG	1.8 74kw LFZ (97-00)	AKF- Autoliv Side AirBag Right Side
 306	AIRBAG	1.8 D 44kw A9A (00-03)	AKF- Autoliv AirBag ACUxx
 306	AIRBAG	1.8 D 44kw A9A (01-..)	AKF- Autoliv AirBag
 306	AIRBAG	1.8 D 44kw A9A (97-00)	AKF- Autoliv AirBag no SIDE AB
 306	AIRBAG	1.8 D 44kw A9A (97-00)	AKF- Autoliv Side AirBag Left Side
 306	AIRBAG	1.8 D 44kw A9A (97-00)	AKF- Autoliv Side AirBag Right Side
 306	AIRBAG	1.9 D 51kw WJY (00-03)	AKF- Autoliv AirBag ACUxx
 306	AIRBAG	1.9 D 51kw WJY (01-..)	AKF- Autoliv AirBag
 306	AIRBAG	1.9 D 51kw WJY (97-00)	AKF- Autoliv AirBag no SIDE AB
 306	AIRBAG	1.9 D 51kw WJY (97-00)	AKF- Autoliv Side AirBag Left Side
 306	AIRBAG	1.9 D 51kw WJY (97-00)	AKF- Autoliv Side AirBag Right Side
 306	AIRBAG	1.9 D 68kw D8A (00-03)	AKF- Autoliv AirBag ACUxx
 306	AIRBAG	1.9 D 68kw D8A (01-..)	AKF- Autoliv AirBag
 306	AIRBAG	1.9 D 68kw D8A (97-00)	AKF- Autoliv AirBag no SIDE AB
 306	AIRBAG	1.9 D 68kw D8A (97-00)	AKF- Autoliv Side AirBag Left Side
 306	AIRBAG	1.9 D 68kw D8A (97-00)	AKF- Autoliv Side AirBag Right Side
 306	AIRBAG	2.0 16v 112kw RFY (00-03)	AKF- Autoliv AirBag ACUxx
 306	AIRBAG	2.0 16v 112kw RFY (01-..)	AKF- Autoliv AirBag
 306	AIRBAG	2.0 16v 112kw RFY (97-00)	AKF- Autoliv AirBag no SIDE AB
 306	AIRBAG	2.0 16v 112kw RFY (97-00)	AKF- Autoliv Side AirBag Left Side
 306	AIRBAG	2.0 16v 112kw RFY (97-00)	AKF- Autoliv Side AirBag Right Side
 306	AIRBAG	2.0 16v 122kw RFS (00-03)	AKF- Autoliv AirBag ACUxx

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 306	AIRBAG	2.0 16v 122kw RFS (01-..)	AKF- Autoliv AirBag
 306	AIRBAG	2.0 16v 122kw RFS (97-00)	AKF- Autoliv AirBag no SIDE AB
 306	AIRBAG	2.0 16v 122kw RFS (97-00)	AKF- Autoliv Side AirBag Left Side
 306	AIRBAG	2.0 16v 122kw RFS (97-00)	AKF- Autoliv Side AirBag Right Side
 306	AIRBAG	2.0 90kw RFX (00-03)	AKF- Autoliv AirBag ACUxx
 306	AIRBAG	2.0 90kw RFX (01-..)	AKF- Autoliv AirBag
 306	AIRBAG	2.0 90kw RFX (97-00)	AKF- Autoliv AirBag no SIDE AB
 306	AIRBAG	2.0 90kw RFX (97-00)	AKF- Autoliv Side AirBag Left Side
 306	AIRBAG	2.0 90kw RFX (97-00)	AKF- Autoliv Side AirBag Right Side
 306	CLIMA	1.1 44kw HDZ	CLIMA AUTO
 306	CLIMA	1.1 55kw HDY	CLIMA AUTO
 306	CLIMA	1.4 55kw KDX	CLIMA AUTO
 306	CLIMA	1.4 55kw KFX	CLIMA AUTO
 306	CLIMA	1.6 66kw NFZ	CLIMA AUTO
 306	CLIMA	1.8 74kw LFZ	CLIMA AUTO
 306	CLIMA	1.8 D 44kw A9A	CLIMA AUTO
 306	CLIMA	1.9 D 51kw WJY	CLIMA AUTO
 306	CLIMA	1.9 D 68kw D8A	CLIMA AUTO
 306	CLIMA	2.0 16v 112kw RFY	CLIMA AUTO
 306	CLIMA	2.0 16v 122kw RFS	CLIMA AUTO
 306	CLIMA	2.0 90kw RFX	CLIMA AUTO
 306	DIESEL MANAGEMEN	1.9 D 51kw WJY	LUCAS Diesel DCN2
 306	DIESEL MANAGEMEN	1.9 D 68kw D8A	BOSCH AS3 VP20
 306	ENGINE MANAGEME	1.1 44kw HDZ	BOSCH MonoMotronic MA3.1
 306	ENGINE MANAGEME	1.1 44kw HDZ	Marelli MMBA G6 [Slow]
 306	ENGINE MANAGEME	1.1 55kw HDY	BOSCH MonoMotronic MA3.1
 306	ENGINE MANAGEME	1.1 55kw HDY	Marelli MMBA G6 [Slow]
 306	ENGINE MANAGEME	1.4 55kw KDX	BOSCH MonoMotronic MA3.0 [Fast]
 306	ENGINE MANAGEME	1.4 55kw KDX	BOSCH MonoMotronic MA3.0 [Slow]
 306	ENGINE MANAGEME	1.4 55kw KFX	Marelli MM 1AP.40
 306	ENGINE MANAGEME	1.4 55kw KFX	SAGEM SL 96
 306	ENGINE MANAGEME	1.6 66kw NFZ	BOSCH Motronic MP5.1 [Fast]
 306	ENGINE MANAGEME	1.6 66kw NFZ	BOSCH Motronic MP5.1 [Slow]
 306	ENGINE MANAGEME	1.6 66kw NFZ	BOSCH Motronic MP5.2
 306	ENGINE MANAGEME	1.6 66kw NFZ	BOSCH Motronic MP7.2
 306	ENGINE MANAGEME	1.8 74kw LFZ	Marelli MM 8P [Slow]
 306	ENGINE MANAGEME	1.8 74kw LFZ	Marelli MM 8P.10 [Fast]
 306	ENGINE MANAGEME	1.9 D 51kw WJY	LUCAS DCN 2
 306	ENGINE MANAGEME	2.0 16v 112kw RFY	BOSCH Motronic MP3.2 [Fast]
 306	ENGINE MANAGEME	2.0 16v 112kw RFY	BOSCH Motronic MP3.2 [Slow]
 306	ENGINE MANAGEME	2.0 16v 122kw RFS	Marelli MM 1AP.10
 306	ENGINE MANAGEME	2.0 90kw RFX	Marelli MM 8P [Slow]
 306	ENGINE MANAGEME	2.0 90kw RFX	Marelli MM 8P.20 [Fast]
 306	MAINTENANCE	1.1 44kw HDZ	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.1 44kw HDZ	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.1 44kw HDZ	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.1 44kw HDZ	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.1 44kw HDZ (98-00)	VDO MANUAL
 306	MAINTENANCE	1.1 55kw HDY	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.1 55kw HDY	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.1 55kw HDY	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.1 55kw HDY	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.1 55kw HDY (98-00)	VDO MANUAL
 306	MAINTENANCE	1.4 55kw KDX	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.4 55kw KDX	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.4 55kw KDX	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.4 55kw KDX	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.4 55kw KDX (98-00)	VDO MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 306	MAINTENANCE	1.4 55kw KFX	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.4 55kw KFX	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.4 55kw KFX	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.4 55kw KFX	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.4 55kw KFX (98-00)	VDO MANUAL
 306	MAINTENANCE	1.6 66kw NFZ	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.6 66kw NFZ	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.6 66kw NFZ	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.6 66kw NFZ	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.6 66kw NFZ (98-00)	VDO MANUAL
 306	MAINTENANCE	1.8 74kw LFZ	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.8 74kw LFZ	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.8 74kw LFZ	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.8 74kw LFZ	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.8 74kw LFZ (98-00)	VDO MANUAL
 306	MAINTENANCE	1.8 D 44kw A9A	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.8 D 44kw A9A	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.8 D 44kw A9A	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.8 D 44kw A9A (98-00)	VDO MANUAL
 306	MAINTENANCE	1.9 D 51kw WJY	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.9 D 51kw WJY	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.9 D 51kw WJY	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.9 D 51kw WJY	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.9 D 51kw WJY (98-00)	VDO MANUAL
 306	MAINTENANCE	1.9 D 68kw D8A	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.9 D 68kw D8A	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.9 D 68kw D8A	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.9 D 68kw D8A	BOSCH ABS ABR 5.3
 306	MAINTENANCE	1.9 D 68kw D8A (98-00)	VDO MANUAL
 306	MAINTENANCE	2.0 16v 112kw RFY	BOSCH ABS ABR 5.3
 306	MAINTENANCE	2.0 16v 112kw RFY	BOSCH ABS ABR 5.3
 306	MAINTENANCE	2.0 16v 112kw RFY	BOSCH ABS ABR 5.3
 306	MAINTENANCE	2.0 16v 112kw RFY	BOSCH ABS ABR 5.3
 306	MAINTENANCE	2.0 16v 112kw RFY (98-00)	VDO MANUAL
 306	MAINTENANCE	2.0 16v 122kw RFS	BOSCH ABS ABR 5.3
 306	MAINTENANCE	2.0 16v 122kw RFS	BOSCH ABS ABR 5.3
 306	MAINTENANCE	2.0 16v 122kw RFS	BOSCH ABS ABR 5.3
 306	MAINTENANCE	2.0 16v 122kw RFS	BOSCH ABS ABR 5.3
 306	MAINTENANCE	2.0 16v 122kw RFS (98-00)	VDO MANUAL
 306	MAINTENANCE	2.0 90kw RFX	BOSCH ABS ABR 5.3
 306	MAINTENANCE	2.0 90kw RFX	BOSCH ABS ABR 5.3
 306	MAINTENANCE	2.0 90kw RFX	BOSCH ABS ABR 5.3
 306	MAINTENANCE	2.0 90kw RFX	BOSCH ABS ABR 5.3
 306	MAINTENANCE	2.0 90kw RFX (98-00)	VDO MANUAL
 306	SERVICE LIGHT RES	1.1 44kw HDZ (98-00)	VDO MANUAL
 306	SERVICE LIGHT RES	1.1 55kw HDY (98-00)	VDO MANUAL
 306	SERVICE LIGHT RES	1.4 55kw KDX (98-00)	VDO MANUAL
 306	SERVICE LIGHT RES	1.4 55kw KFX (98-00)	VDO MANUAL
 306	SERVICE LIGHT RES	1.6 66kw NFZ (98-00)	VDO MANUAL
 306	SERVICE LIGHT RES	1.8 74kw LFZ (98-00)	VDO MANUAL
 306	SERVICE LIGHT RES	1.8 D 44kw A9A (98-00)	VDO MANUAL
 306	SERVICE LIGHT RES	1.9 D 51kw WJY (98-00)	VDO MANUAL
 306	SERVICE LIGHT RES	1.9 D 68kw D8A (98-00)	VDO MANUAL
 306	SERVICE LIGHT RES	2.0 16v 112kw RFY (98-00)	VDO MANUAL
 306	SERVICE LIGHT RES	2.0 16v 122kw RFS (98-00)	VDO MANUAL
 306	SERVICE LIGHT RES	2.0 90kw RFX (98-00)	VDO MANUAL
 307 Restyling (05-08)	ABS	1.4 16v 66kw KFU	BOSCH ABS 8

Systems supported by ECUREADER / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 307 Restyling (05-08)	ABS	1.4 16v 66kw KFU	Var.1
 307 Restyling (05-08)	ABS	1.4 16v 66kw KFU	Var.2
 307 Restyling (05-08)	ABS	1.6 16v 82kw NFU	BOSCH ABS 8
 307 Restyling (05-08)	ABS	1.6 16v 82kw NFU	Var.1
 307 Restyling (05-08)	ABS	1.6 16v 82kw NFU	Var.2
 307 Restyling (05-08)	ABS	1.6 HDI 16v 66kw 9HX	BOSCH ABS 8
 307 Restyling (05-08)	ABS	1.6 HDI 16v 66kw 9HX	Var.1
 307 Restyling (05-08)	ABS	1.6 HDI 16v 66kw 9HX	Var.2
 307 Restyling (05-08)	ABS	1.6 HDI 16v 80kw 9HY	BOSCH ABS 8
 307 Restyling (05-08)	ABS	1.6 HDI 16v 80kw 9HY	Var.1
 307 Restyling (05-08)	ABS	1.6 HDI 16v 80kw 9HY	Var.2
 307 Restyling (05-08)	ABS	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ABS 8
 307 Restyling (05-08)	ABS	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 307 Restyling (05-08)	ABS	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 307 Restyling (05-08)	ABS	2.0 16v 103kw RFJ	BOSCH ABS 8
 307 Restyling (05-08)	ABS	2.0 16v 103kw RFJ	Var.1
 307 Restyling (05-08)	ABS	2.0 16v 103kw RFJ	Var.2
 307 Restyling (05-08)	ABS	2.0 16v 130kw RFK	BOSCH ABS 8
 307 Restyling (05-08)	ABS	2.0 16v 130kw RFK	Var.1
 307 Restyling (05-08)	ABS	2.0 16v 130kw RFK	Var.2
 307 Restyling (05-08)	ABS	2.0 HDI 16v 100kw RHR-FAP	BOSCH ABS 8
 307 Restyling (05-08)	ABS	2.0 HDI 16v 100kw RHR-FAP	Var.1
 307 Restyling (05-08)	ABS	2.0 HDI 16v 100kw RHR-FAP	Var.2
 307 Restyling (05-08)	ABS + TRACT. CONT	1.4 16v 66kw KFU	Var.1
 307 Restyling (05-08)	ABS + TRACT. CONT	1.4 16v 66kw KFU	Var.2
 307 Restyling (05-08)	ABS + TRACT. CONT	1.6 16v 82kw NFU	Var.1
 307 Restyling (05-08)	ABS + TRACT. CONT	1.6 16v 82kw NFU	Var.2
 307 Restyling (05-08)	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX	Var.2
 307 Restyling (05-08)	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HY	Var.1
 307 Restyling (05-08)	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 307 Restyling (05-08)	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 307 Restyling (05-08)	ABS + TRACT. CONT	2.0 16v 103kw RFJ	Var.1
 307 Restyling (05-08)	ABS + TRACT. CONT	2.0 16v 103kw RFJ	Var.2
 307 Restyling (05-08)	ABS + TRACT. CONT	2.0 16v 130kw RFK	Var.1
 307 Restyling (05-08)	ABS + TRACT. CONT	2.0 16v 130kw RFK	Var.2
 307 Restyling (05-08)	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP	Var.1
 307 Restyling (05-08)	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP	Var.2
 307 Restyling (05-08)	AIRBAG	1.4 16v 66kw KFU	AirBag CENTRAL
 307 Restyling (05-08)	AIRBAG	1.4 16v 66kw KFU	Autoliv AirBag
 307 Restyling (05-08)	AIRBAG	1.6 16v 82kw NFU	AirBag CENTRAL
 307 Restyling (05-08)	AIRBAG	1.6 16v 82kw NFU	Autoliv AirBag
 307 Restyling (05-08)	AIRBAG	1.6 HDI 16v 66kw 9HX	AirBag CENTRAL
 307 Restyling (05-08)	AIRBAG	1.6 HDI 16v 66kw 9HX	Autoliv AirBag
 307 Restyling (05-08)	AIRBAG	1.6 HDI 16v 80kw 9HY	AirBag CENTRAL
 307 Restyling (05-08)	AIRBAG	1.6 HDI 16v 80kw 9HY	Autoliv AirBag
 307 Restyling (05-08)	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL
 307 Restyling (05-08)	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP	Autoliv AirBag
 307 Restyling (05-08)	AIRBAG	2.0 16v 103kw RFJ	AirBag CENTRAL
 307 Restyling (05-08)	AIRBAG	2.0 16v 103kw RFJ	Autoliv AirBag
 307 Restyling (05-08)	AIRBAG	2.0 16v 130kw RFK	AirBag CENTRAL
 307 Restyling (05-08)	AIRBAG	2.0 16v 130kw RFK	Autoliv AirBag
 307 Restyling (05-08)	AIRBAG	2.0 HDI 16v 100kw RHR-FAP	AirBag CENTRAL
 307 Restyling (05-08)	AIRBAG	2.0 HDI 16v 100kw RHR-FAP	Autoliv AirBag
 307 Restyling (05-08)	ANTITHEFT	1.4 16v 66kw KFU	Alarm PSA2
 307 Restyling (05-08)	ANTITHEFT	1.6 16v 82kw NFU	Alarm PSA2
 307 Restyling (05-08)	ANTITHEFT	1.6 HDI 16v 66kw 9HX	Alarm PSA2
 307 Restyling (05-08)	ANTITHEFT	1.6 HDI 16v 80kw 9HY	Alarm PSA2
 307 Restyling (05-08)	ANTITHEFT	1.6 HDI 16v 80kw 9HZ-FAP	Alarm PSA2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 307 Restyling (05-08)	ANTITHEFT	2.0 16v 103kw RFJ	Alarm PSA2
 307 Restyling (05-08)	ANTITHEFT	2.0 16v 130kw RFK	Alarm PSA2
 307 Restyling (05-08)	ANTITHEFT	2.0 HDI 16v 100kw RHR-FAP	Alarm PSA2
 307 Restyling (05-08)	AUTOM. TRANSMISSI	1.4 16v 66kw KFU	A/T AM6
 307 Restyling (05-08)	AUTOM. TRANSMISSI	1.4 16v 66kw KFU	A/T MCP
 307 Restyling (05-08)	AUTOM. TRANSMISSI	1.4 16v 66kw KFU	Var.1
 307 Restyling (05-08)	AUTOM. TRANSMISSI	1.4 16v 66kw KFU	Var.2
 307 Restyling (05-08)	AUTOM. TRANSMISSI	1.4 16v 66kw KFU	Var.3
 307 Restyling (05-08)	AUTOM. TRANSMISSI	1.6 16v 82kw NFU	A/T AM6
 307 Restyling (05-08)	AUTOM. TRANSMISSI	1.6 16v 82kw NFU	A/T MCP
 307 Restyling (05-08)	AUTOM. TRANSMISSI	1.6 16v 82kw NFU	Var.1
 307 Restyling (05-08)	AUTOM. TRANSMISSI	1.6 16v 82kw NFU	Var.2
 307 Restyling (05-08)	AUTOM. TRANSMISSI	1.6 16v 82kw NFU	Var.3
 307 Restyling (05-08)	AUTOM. TRANSMISSI	1.6 HDI 16v 66kw 9HX	A/T AM6
 307 Restyling (05-08)	AUTOM. TRANSMISSI	1.6 HDI 16v 66kw 9HX	A/T MCP
 307 Restyling (05-08)	AUTOM. TRANSMISSI	1.6 HDI 16v 66kw 9HX	Var.1
 307 Restyling (05-08)	AUTOM. TRANSMISSI	1.6 HDI 16v 66kw 9HX	Var.2
 307 Restyling (05-08)	AUTOM. TRANSMISSI	1.6 HDI 16v 66kw 9HX	Var.3
 307 Restyling (05-08)	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HY	A/T AM6
 307 Restyling (05-08)	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HY	A/T MCP
 307 Restyling (05-08)	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HY	Var.1
 307 Restyling (05-08)	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HY	Var.2
 307 Restyling (05-08)	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HY	Var.3
 307 Restyling (05-08)	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP	A/T AM6
 307 Restyling (05-08)	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP	A/T MCP
 307 Restyling (05-08)	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 307 Restyling (05-08)	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 307 Restyling (05-08)	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP	Var.3
 307 Restyling (05-08)	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ	A/T AM6
 307 Restyling (05-08)	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ	A/T MCP
 307 Restyling (05-08)	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ	Var.1
 307 Restyling (05-08)	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ	Var.2
 307 Restyling (05-08)	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ	Var.3
 307 Restyling (05-08)	AUTOM. TRANSMISSI	2.0 16v 130kw RFK	A/T AM6
 307 Restyling (05-08)	AUTOM. TRANSMISSI	2.0 16v 130kw RFK	A/T MCP
 307 Restyling (05-08)	AUTOM. TRANSMISSI	2.0 16v 130kw RFK	Var.1
 307 Restyling (05-08)	AUTOM. TRANSMISSI	2.0 16v 130kw RFK	Var.2
 307 Restyling (05-08)	AUTOM. TRANSMISSI	2.0 16v 130kw RFK	Var.3
 307 Restyling (05-08)	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP	A/T AM6
 307 Restyling (05-08)	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP	A/T MCP
 307 Restyling (05-08)	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP	Var.1
 307 Restyling (05-08)	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP	Var.2
 307 Restyling (05-08)	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP	Var.3
 307 Restyling (05-08)	CHASSIS NETWORK	1.4 16v 66kw KFU	Body Computer BSI
 307 Restyling (05-08)	CHASSIS NETWORK	1.4 16v 66kw KFU	Body Computer BSM
 307 Restyling (05-08)	CHASSIS NETWORK	1.4 16v 66kw KFU	Body Computer BSR
 307 Restyling (05-08)	CHASSIS NETWORK	1.4 16v 66kw KFU	JCAE Body Computer BSI
 307 Restyling (05-08)	CHASSIS NETWORK	1.6 16v 82kw NFU	Body Computer BSI
 307 Restyling (05-08)	CHASSIS NETWORK	1.6 16v 82kw NFU	Body Computer BSM
 307 Restyling (05-08)	CHASSIS NETWORK	1.6 16v 82kw NFU	Body Computer BSR
 307 Restyling (05-08)	CHASSIS NETWORK	1.6 16v 82kw NFU	JCAE Body Computer BSI
 307 Restyling (05-08)	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	Body Computer BSI
 307 Restyling (05-08)	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	Body Computer BSM
 307 Restyling (05-08)	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	Body Computer BSR
 307 Restyling (05-08)	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	JCAE Body Computer BSI
 307 Restyling (05-08)	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY	Body Computer BSI
 307 Restyling (05-08)	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY	Body Computer BSM
 307 Restyling (05-08)	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY	Body Computer BSR

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 307 Restyling (05-08)	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY	JCAE Body Computer BSI
 307 Restyling (05-08)	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSI
 307 Restyling (05-08)	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSM
 307 Restyling (05-08)	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSR
 307 Restyling (05-08)	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	JCAE Body Computer BSI
 307 Restyling (05-08)	CHASSIS NETWORK	2.0 16v 103kw RFJ	Body Computer BSI
 307 Restyling (05-08)	CHASSIS NETWORK	2.0 16v 103kw RFJ	Body Computer BSM
 307 Restyling (05-08)	CHASSIS NETWORK	2.0 16v 103kw RFJ	Body Computer BSR
 307 Restyling (05-08)	CHASSIS NETWORK	2.0 16v 103kw RFJ	JCAE Body Computer BSI
 307 Restyling (05-08)	CHASSIS NETWORK	2.0 16v 130kw RFK	Body Computer BSI
 307 Restyling (05-08)	CHASSIS NETWORK	2.0 16v 130kw RFK	Body Computer BSM
 307 Restyling (05-08)	CHASSIS NETWORK	2.0 16v 130kw RFK	Body Computer BSR
 307 Restyling (05-08)	CHASSIS NETWORK	2.0 16v 130kw RFK	JCAE Body Computer BSI
 307 Restyling (05-08)	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	Body Computer BSI
 307 Restyling (05-08)	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	Body Computer BSM
 307 Restyling (05-08)	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	Body Computer BSR
 307 Restyling (05-08)	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	JCAE Body Computer BSI
 307 Restyling (05-08)	CLIMA	1.4 16v 66kw KFU	CLIMA
 307 Restyling (05-08)	CLIMA	1.6 16v 82kw NFU	CLIMA
 307 Restyling (05-08)	CLIMA	1.6 HDI 16v 66kw 9HX	CLIMA
 307 Restyling (05-08)	CLIMA	1.6 HDI 16v 80kw 9HY	CLIMA
 307 Restyling (05-08)	CLIMA	1.6 HDI 16v 80kw 9HZ-FAP	CLIMA
 307 Restyling (05-08)	CLIMA	2.0 16v 103kw RFJ	CLIMA
 307 Restyling (05-08)	CLIMA	2.0 16v 130kw RFK	CLIMA
 307 Restyling (05-08)	CLIMA	2.0 HDI 16v 100kw RHR-FAP	CLIMA
 307 Restyling (05-08)	COMFORT SYSTEM	1.4 16v 66kw KFU	Phone Kit
 307 Restyling (05-08)	COMFORT SYSTEM	1.4 16v 66kw KFU	SV limitation 2
 307 Restyling (05-08)	COMFORT SYSTEM	1.4 16v 66kw KFU	Var.1
 307 Restyling (05-08)	COMFORT SYSTEM	1.4 16v 66kw KFU	Var.2
 307 Restyling (05-08)	COMFORT SYSTEM	1.6 16v 82kw NFU	Phone Kit
 307 Restyling (05-08)	COMFORT SYSTEM	1.6 16v 82kw NFU	SV limitation 2
 307 Restyling (05-08)	COMFORT SYSTEM	1.6 16v 82kw NFU	Var.1
 307 Restyling (05-08)	COMFORT SYSTEM	1.6 16v 82kw NFU	Var.2
 307 Restyling (05-08)	COMFORT SYSTEM	1.6 HDI 16v 66kw 9HX	Phone Kit
 307 Restyling (05-08)	COMFORT SYSTEM	1.6 HDI 16v 66kw 9HX	SV limitation 2
 307 Restyling (05-08)	COMFORT SYSTEM	1.6 HDI 16v 66kw 9HX	Var.1
 307 Restyling (05-08)	COMFORT SYSTEM	1.6 HDI 16v 66kw 9HX	Var.2
 307 Restyling (05-08)	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HY	Phone Kit
 307 Restyling (05-08)	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HY	Var.1
 307 Restyling (05-08)	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HY	Var.2
 307 Restyling (05-08)	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HZ-FAP	Phone Kit
 307 Restyling (05-08)	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 307 Restyling (05-08)	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 307 Restyling (05-08)	COMFORT SYSTEM	2.0 16v 103kw RFJ	Phone Kit
 307 Restyling (05-08)	COMFORT SYSTEM	2.0 16v 103kw RFJ	SV limitation 2
 307 Restyling (05-08)	COMFORT SYSTEM	2.0 16v 103kw RFJ	Var.1
 307 Restyling (05-08)	COMFORT SYSTEM	2.0 16v 103kw RFJ	Var.2
 307 Restyling (05-08)	COMFORT SYSTEM	2.0 16v 130kw RFK	Phone Kit
 307 Restyling (05-08)	COMFORT SYSTEM	2.0 16v 130kw RFK	SV limitation 2
 307 Restyling (05-08)	COMFORT SYSTEM	2.0 16v 130kw RFK	Var.1
 307 Restyling (05-08)	COMFORT SYSTEM	2.0 16v 130kw RFK	Var.2
 307 Restyling (05-08)	COMFORT SYSTEM	2.0 HDI 16v 100kw RHR-FAP	Phone Kit
 307 Restyling (05-08)	COMFORT SYSTEM	2.0 HDI 16v 100kw RHR-FAP	SV limitation 2
 307 Restyling (05-08)	COMFORT SYSTEM	2.0 HDI 16v 100kw RHR-FAP	Var.1
 307 Restyling (05-08)	COMFORT SYSTEM	2.0 HDI 16v 100kw RHR-FAP	Var.2
 307 Restyling (05-08)	CONV. TOP/SUNROO	1.4 16v 66kw KFU	Var.1
 307 Restyling (05-08)	CONV. TOP/SUNROO	1.4 16v 66kw KFU	Var.2
 307 Restyling (05-08)	CONV. TOP/SUNROO	1.6 16v 82kw NFU	Var.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 307 Restyling (05-08)	CONV. TOP/SUNROO	1.6 16v 82kw NFU	Var.2
 307 Restyling (05-08)	CONV. TOP/SUNROO	1.6 HDI 16v 66kw 9HX	Var.1
 307 Restyling (05-08)	CONV. TOP/SUNROO	1.6 HDI 16v 66kw 9HX	Var.2
 307 Restyling (05-08)	CONV. TOP/SUNROO	1.6 HDI 16v 80kw 9HY	Var.1
 307 Restyling (05-08)	CONV. TOP/SUNROO	1.6 HDI 16v 80kw 9HY	Var.2
 307 Restyling (05-08)	CONV. TOP/SUNROO	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 307 Restyling (05-08)	CONV. TOP/SUNROO	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 307 Restyling (05-08)	CONV. TOP/SUNROO	2.0 16v 103kw RFJ	Var.1
 307 Restyling (05-08)	CONV. TOP/SUNROO	2.0 16v 103kw RFJ	Var.2
 307 Restyling (05-08)	CONV. TOP/SUNROO	2.0 16v 130kw RFK	Var.1
 307 Restyling (05-08)	CONV. TOP/SUNROO	2.0 16v 130kw RFK	Var.2
 307 Restyling (05-08)	CONV. TOP/SUNROO	2.0 HDI 16v 100kw RHR-FAP	Var.1
 307 Restyling (05-08)	CONV. TOP/SUNROO	2.0 HDI 16v 100kw RHR-FAP	Var.2
 307 Restyling (05-08)	DASH LAMPS	1.4 16v 66kw KFU	Compte-Tours
 307 Restyling (05-08)	DASH LAMPS	1.4 16v 66kw KFU	
 307 Restyling (05-08)	DASH LAMPS	1.6 16v 82kw NFU	
 307 Restyling (05-08)	DASH LAMPS	1.6 16v 82kw NFU	Compte-Tours
 307 Restyling (05-08)	DASH LAMPS	1.6 HDI 16v 66kw 9HX	Compte-Tours
 307 Restyling (05-08)	DASH LAMPS	1.6 HDI 16v 66kw 9HX	
 307 Restyling (05-08)	DASH LAMPS	1.6 HDI 16v 80kw 9HY	
 307 Restyling (05-08)	DASH LAMPS	1.6 HDI 16v 80kw 9HY	Compte-Tours
 307 Restyling (05-08)	DASH LAMPS	1.6 HDI 16v 80kw 9HZ-FAP	Compte-Tours
 307 Restyling (05-08)	DASH LAMPS	1.6 HDI 16v 80kw 9HZ-FAP	
 307 Restyling (05-08)	DASH LAMPS	2.0 16v 103kw RFJ	
 307 Restyling (05-08)	DASH LAMPS	2.0 16v 103kw RFJ	Compte-Tours
 307 Restyling (05-08)	DASH LAMPS	2.0 16v 130kw RFK	Compte-Tours
 307 Restyling (05-08)	DASH LAMPS	2.0 16v 130kw RFK	
 307 Restyling (05-08)	DASH LAMPS	2.0 HDI 16v 100kw RHR-FAP	
 307 Restyling (05-08)	DASH LAMPS	2.0 HDI 16v 100kw RHR-FAP	Compte-Tours
 307 Restyling (05-08)	DASHBOARD	1.4 16v 66kw KFU	JCAE Dashboard
 307 Restyling (05-08)	DASHBOARD	1.4 16v 66kw KFU	
 307 Restyling (05-08)	DASHBOARD	1.6 16v 82kw NFU	
 307 Restyling (05-08)	DASHBOARD	1.6 16v 82kw NFU	JCAE Dashboard
 307 Restyling (05-08)	DASHBOARD	1.6 HDI 16v 66kw 9HX	JCAE Dashboard
 307 Restyling (05-08)	DASHBOARD	1.6 HDI 16v 66kw 9HX	
 307 Restyling (05-08)	DASHBOARD	1.6 HDI 16v 80kw 9HY	
 307 Restyling (05-08)	DASHBOARD	1.6 HDI 16v 80kw 9HY	JCAE Dashboard
 307 Restyling (05-08)	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP	JCAE Dashboard
 307 Restyling (05-08)	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP	
 307 Restyling (05-08)	DASHBOARD	2.0 16v 103kw RFJ	
 307 Restyling (05-08)	DASHBOARD	2.0 16v 103kw RFJ	JCAE Dashboard
 307 Restyling (05-08)	DASHBOARD	2.0 16v 130kw RFK	JCAE Dashboard
 307 Restyling (05-08)	DASHBOARD	2.0 16v 130kw RFK	
 307 Restyling (05-08)	DASHBOARD	2.0 HDI 16v 100kw RHR-FAP	
 307 Restyling (05-08)	DASHBOARD	2.0 HDI 16v 100kw RHR-FAP	JCAE Dashboard
 307 Restyling (05-08)	DIESEL ADDITION	1.6 HDI 16v 66kw 9HX	Var.1
 307 Restyling (05-08)	DIESEL ADDITION	1.6 HDI 16v 66kw 9HX	Var.2
 307 Restyling (05-08)	DIESEL ADDITION	1.6 HDI 16v 80kw 9HY	SV limitation 2
 307 Restyling (05-08)	DIESEL ADDITION	1.6 HDI 16v 80kw 9HY	Var.1
 307 Restyling (05-08)	DIESEL ADDITION	1.6 HDI 16v 80kw 9HY	Var.2
 307 Restyling (05-08)	DIESEL ADDITION	1.6 HDI 16v 80kw 9HZ-FAP	SV limitation 2
 307 Restyling (05-08)	DIESEL ADDITION	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 307 Restyling (05-08)	DIESEL ADDITION	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 307 Restyling (05-08)	DIESEL ADDITION	2.0 HDI 16v 100kw RHR-FAP	Var.1
 307 Restyling (05-08)	DIESEL ADDITION	2.0 HDI 16v 100kw RHR-FAP	Var.2
 307 Restyling (05-08)	DRIVER SEAT CONT	1.4 16v 66kw KFU	
 307 Restyling (05-08)	DRIVER SEAT CONT	1.6 16v 82kw NFU	
 307 Restyling (05-08)	DRIVER SEAT CONT	1.6 HDI 16v 66kw 9HX	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 307 Restyling (05-08)	DRIVER SEAT CONT	1.6 HDI 16v 80kw 9HY	
 307 Restyling (05-08)	DRIVER SEAT CONT	1.6 HDI 16v 80kw 9HZ-FAP	
 307 Restyling (05-08)	DRIVER SEAT CONT	2.0 16v 103kw RFJ	
 307 Restyling (05-08)	DRIVER SEAT CONT	2.0 16v 130kw RFK	
 307 Restyling (05-08)	DRIVER SEAT CONT	2.0 HDI 16v 100kw RHR-FAP	
 307 Restyling (05-08)	DRIVER SIDE DOOR	1.4 16v 66kw KFU	ArvinMeritor DriverDoor
 307 Restyling (05-08)	DRIVER SIDE DOOR	1.4 16v 66kw KFU	Var.1
 307 Restyling (05-08)	DRIVER SIDE DOOR	1.4 16v 66kw KFU	Var.2
 307 Restyling (05-08)	DRIVER SIDE DOOR	1.6 16v 82kw NFU	ArvinMeritor DriverDoor
 307 Restyling (05-08)	DRIVER SIDE DOOR	1.6 16v 82kw NFU	Var.1
 307 Restyling (05-08)	DRIVER SIDE DOOR	1.6 16v 82kw NFU	Var.2
 307 Restyling (05-08)	DRIVER SIDE DOOR	1.6 HDI 16v 66kw 9HX	ArvinMeritor DriverDoor
 307 Restyling (05-08)	DRIVER SIDE DOOR	1.6 HDI 16v 66kw 9HX	Var.1
 307 Restyling (05-08)	DRIVER SIDE DOOR	1.6 HDI 16v 66kw 9HX	Var.2
 307 Restyling (05-08)	DRIVER SIDE DOOR	1.6 HDI 16v 80kw 9HY	ArvinMeritor DriverDoor
 307 Restyling (05-08)	DRIVER SIDE DOOR	1.6 HDI 16v 80kw 9HY	Var.1
 307 Restyling (05-08)	DRIVER SIDE DOOR	1.6 HDI 16v 80kw 9HY	Var.2
 307 Restyling (05-08)	DRIVER SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	ArvinMeritor DriverDoor
 307 Restyling (05-08)	DRIVER SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 307 Restyling (05-08)	DRIVER SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 307 Restyling (05-08)	DRIVER SIDE DOOR	2.0 16v 103kw RFJ	ArvinMeritor DriverDoor
 307 Restyling (05-08)	DRIVER SIDE DOOR	2.0 16v 103kw RFJ	Var.1
 307 Restyling (05-08)	DRIVER SIDE DOOR	2.0 16v 103kw RFJ	Var.2
 307 Restyling (05-08)	DRIVER SIDE DOOR	2.0 16v 130kw RFK	ArvinMeritor DriverDoor
 307 Restyling (05-08)	DRIVER SIDE DOOR	2.0 16v 130kw RFK	Var.1
 307 Restyling (05-08)	DRIVER SIDE DOOR	2.0 16v 130kw RFK	Var.2
 307 Restyling (05-08)	DRIVER SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	ArvinMeritor DriverDoor
 307 Restyling (05-08)	DRIVER SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	Var.1
 307 Restyling (05-08)	DRIVER SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	Var.2
 307 Restyling (05-08)	ELECTRIC STEERING	1.4 16v 66kw KFU	HPI GEP
 307 Restyling (05-08)	ELECTRIC STEERING	1.4 16v 66kw KFU	Var.1
 307 Restyling (05-08)	ELECTRIC STEERING	1.4 16v 66kw KFU	Var.2
 307 Restyling (05-08)	ELECTRIC STEERING	1.6 16v 82kw NFU	HPI GEP
 307 Restyling (05-08)	ELECTRIC STEERING	1.6 16v 82kw NFU	Var.1
 307 Restyling (05-08)	ELECTRIC STEERING	1.6 16v 82kw NFU	Var.2
 307 Restyling (05-08)	ELECTRIC STEERING	1.6 HDI 16v 66kw 9HX	HPI GEP
 307 Restyling (05-08)	ELECTRIC STEERING	1.6 HDI 16v 66kw 9HX	Var.1
 307 Restyling (05-08)	ELECTRIC STEERING	1.6 HDI 16v 66kw 9HX	Var.2
 307 Restyling (05-08)	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HY	HPI GEP
 307 Restyling (05-08)	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HY	Var.1
 307 Restyling (05-08)	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HY	Var.2
 307 Restyling (05-08)	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	HPI GEP
 307 Restyling (05-08)	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 307 Restyling (05-08)	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 307 Restyling (05-08)	ELECTRIC STEERING	2.0 16v 103kw RFJ	HPI GEP
 307 Restyling (05-08)	ELECTRIC STEERING	2.0 16v 103kw RFJ	Var.1
 307 Restyling (05-08)	ELECTRIC STEERING	2.0 16v 103kw RFJ	Var.2
 307 Restyling (05-08)	ELECTRIC STEERING	2.0 16v 130kw RFK	HPI GEP
 307 Restyling (05-08)	ELECTRIC STEERING	2.0 16v 130kw RFK	Var.1
 307 Restyling (05-08)	ELECTRIC STEERING	2.0 16v 130kw RFK	Var.2
 307 Restyling (05-08)	ELECTRIC STEERING	2.0 HDI 16v 100kw RHR-FAP	HPI GEP
 307 Restyling (05-08)	ELECTRIC STEERING	2.0 HDI 16v 100kw RHR-FAP	Var.1
 307 Restyling (05-08)	ELECTRIC STEERING	2.0 HDI 16v 100kw RHR-FAP	Var.2
 307 Restyling (05-08)	ENGINE MANAGEME	1.4 16v 66kw KFU	Marelli MM6LP
 307 Restyling (05-08)	ENGINE MANAGEME	1.6 16v 82kw NFU	BOSCH ME 7.4.5 Var.1
 307 Restyling (05-08)	ENGINE MANAGEME	1.6 16v 82kw NFU	BOSCH ME 7.4.5 Var.2
 307 Restyling (05-08)	ENGINE MANAGEME	1.6 HDI 16v 66kw 9HX	BOSCH EDC 16 C34 Common Rail Var.2
 307 Restyling (05-08)	ENGINE MANAGEME	1.6 HDI 16v 66kw 9HX	BOSCH EDC 16C 34 Common Rail

Systems supported by ECUREADER / ECUDECODER (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 307 Restyling (05-08)	ENGINE MANAGEME	1.6 HDI 16v 66kw 9HX	BOSCH EDC 16C 34 Common Rail Var.1
 307 Restyling (05-08)	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.1
 307 Restyling (05-08)	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.2
 307 Restyling (05-08)	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail
 307 Restyling (05-08)	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 307 Restyling (05-08)	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.2
 307 Restyling (05-08)	ENGINE MANAGEME	2.0 16v 103kw RFJ	Marelli MM6LPB
 307 Restyling (05-08)	ENGINE MANAGEME	2.0 16v 103kw RFJ	Marelli MPI MM6LPB
 307 Restyling (05-08)	ENGINE MANAGEME	2.0 16v 130kw RFK	Marelli MM6LP
 307 Restyling (05-08)	ENGINE MANAGEME	2.0 HDI 16v 100kw RHR-FAP	DELPHI DCM 3.4 Common Rail
 307 Restyling (05-08)	ENGINE MANAGEME	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803 Common Rail Var.1
 307 Restyling (05-08)	ENGINE MANAGEME	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803A Common Rail Var.2
 307 Restyling (05-08)	KEY ENCODE	1.4 16v 66kw KFU	JCAE Body Computer
 307 Restyling (05-08)	KEY ENCODE	1.6 16v 82kw NFU	JCAE Body Computer
 307 Restyling (05-08)	KEY ENCODE	1.6 HDI 16v 66kw 9HX	JCAE Body Computer
 307 Restyling (05-08)	KEY ENCODE	1.6 HDI 16v 80kw 9HY	JCAE Body Computer
 307 Restyling (05-08)	KEY ENCODE	1.6 HDI 16v 80kw 9HZ-FAP	JCAE Body Computer
 307 Restyling (05-08)	KEY ENCODE	2.0 16v 103kw RFJ	JCAE Body Computer
 307 Restyling (05-08)	KEY ENCODE	2.0 16v 130kw RFK	JCAE Body Computer
 307 Restyling (05-08)	KEY ENCODE	2.0 HDI 16v 100kw RHR-FAP	JCAE Body Computer
 307 Restyling (05-08)	MAINTENANCE	1.4 16v 66kw KFU	A/T AM6
 307 Restyling (05-08)	MAINTENANCE	1.4 16v 66kw KFU	A/T AM6
 307 Restyling (05-08)	MAINTENANCE	1.4 16v 66kw KFU	AirBag CENTRAL
 307 Restyling (05-08)	MAINTENANCE	1.4 16v 66kw KFU	AirBag CENTRAL
 307 Restyling (05-08)	MAINTENANCE	1.4 16v 66kw KFU	BOSCH ABS 8
 307 Restyling (05-08)	MAINTENANCE	1.4 16v 66kw KFU	JCAE Body Computer BSI
 307 Restyling (05-08)	MAINTENANCE	1.4 16v 66kw KFU	JCAE Body Computer MANUAL
 307 Restyling (05-08)	MAINTENANCE	1.4 16v 66kw KFU	JCAE Dashboard
 307 Restyling (05-08)	MAINTENANCE	1.4 16v 66kw KFU	Siemens-JCAE AUTODETECT
 307 Restyling (05-08)	MAINTENANCE	1.4 16v 66kw KFU	Siemens-JCAE AUTODETECT
 307 Restyling (05-08)	MAINTENANCE	1.4 16v 66kw KFU	Siemens-JCAE AUTODETECT
 307 Restyling (05-08)	MAINTENANCE	1.4 16v 66kw KFU	Siemens-JCAE AUTODETECT
 307 Restyling (05-08)	MAINTENANCE	1.4 16v 66kw KFU	SV limitation 2
 307 Restyling (05-08)	MAINTENANCE	1.4 16v 66kw KFU	Var.1
 307 Restyling (05-08)	MAINTENANCE	1.4 16v 66kw KFU	Var.1
 307 Restyling (05-08)	MAINTENANCE	1.4 16v 66kw KFU	Var.1
 307 Restyling (05-08)	MAINTENANCE	1.4 16v 66kw KFU	Var.1
 307 Restyling (05-08)	MAINTENANCE	1.4 16v 66kw KFU	Var.1
 307 Restyling (05-08)	MAINTENANCE	1.4 16v 66kw KFU	Var.2
 307 Restyling (05-08)	MAINTENANCE	1.4 16v 66kw KFU	Var.2
 307 Restyling (05-08)	MAINTENANCE	1.4 16v 66kw KFU	Var.2
 307 Restyling (05-08)	MAINTENANCE	1.4 16v 66kw KFU	Var.2
 307 Restyling (05-08)	MAINTENANCE	1.4 16v 66kw KFU	Var.2
 307 Restyling (05-08)	MAINTENANCE	1.4 16v 66kw KFU	Var.2
 307 Restyling (05-08)	MAINTENANCE	1.4 16v 66kw KFU	Var.3
 307 Restyling (05-08)	MAINTENANCE	1.4 16v 66kw KFU	VDO MANUAL
 307 Restyling (05-08)	MAINTENANCE	1.6 16v 82kw NFU	A/T AM6
 307 Restyling (05-08)	MAINTENANCE	1.6 16v 82kw NFU	A/T AM6
 307 Restyling (05-08)	MAINTENANCE	1.6 16v 82kw NFU	AirBag CENTRAL
 307 Restyling (05-08)	MAINTENANCE	1.6 16v 82kw NFU	AirBag CENTRAL
 307 Restyling (05-08)	MAINTENANCE	1.6 16v 82kw NFU	BOSCH ABS 8
 307 Restyling (05-08)	MAINTENANCE	1.6 16v 82kw NFU	JCAE Body Computer BSI
 307 Restyling (05-08)	MAINTENANCE	1.6 16v 82kw NFU	JCAE Body Computer MANUAL
 307 Restyling (05-08)	MAINTENANCE	1.6 16v 82kw NFU	JCAE Dashboard
 307 Restyling (05-08)	MAINTENANCE	1.6 16v 82kw NFU	Siemens-JCAE AUTODETECT
 307 Restyling (05-08)	MAINTENANCE	1.6 16v 82kw NFU	Siemens-JCAE AUTODETECT
 307 Restyling (05-08)	MAINTENANCE	1.6 16v 82kw NFU	Siemens-JCAE AUTODETECT
 307 Restyling (05-08)	MAINTENANCE	1.6 16v 82kw NFU	Siemens-JCAE AUTODETECT
307 Restyling (05-08)	MAINTENANCE	1.6 16v 82kw NFU	SV limitation 2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 307 Restyling (05-08)	MAINTENANCE	1.6 16v 82kw NFU	Var.1
 307 Restyling (05-08)	MAINTENANCE	1.6 16v 82kw NFU	Var.1
 307 Restyling (05-08)	MAINTENANCE	1.6 16v 82kw NFU	Var.1
 307 Restyling (05-08)	MAINTENANCE	1.6 16v 82kw NFU	Var.1
 307 Restyling (05-08)	MAINTENANCE	1.6 16v 82kw NFU	Var.1
 307 Restyling (05-08)	MAINTENANCE	1.6 16v 82kw NFU	Var.2
 307 Restyling (05-08)	MAINTENANCE	1.6 16v 82kw NFU	Var.2
 307 Restyling (05-08)	MAINTENANCE	1.6 16v 82kw NFU	Var.2
 307 Restyling (05-08)	MAINTENANCE	1.6 16v 82kw NFU	Var.2
 307 Restyling (05-08)	MAINTENANCE	1.6 16v 82kw NFU	Var.2
 307 Restyling (05-08)	MAINTENANCE	1.6 16v 82kw NFU	Var.3
 307 Restyling (05-08)	MAINTENANCE	1.6 16v 82kw NFU	VDO MANUAL
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	A/T AM6
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	A/T AM6
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	AirBag CENTRAL
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	AirBag CENTRAL
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH ABS 8
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC 16 C34 Common Rail Var.2
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC 16 C34 Common Rail Var.2
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC 16 C34 Common Rail Var.2
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC 16 C34 Common Rail Var.2
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC 16 C34 Common Rail Var.2
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC 16 C34 Common Rail Var.2
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC 16 C34 Common Rail Var.2
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC 16C 34 Common Rail Var.1
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC 16C 34 Common Rail Var.1
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC 16C 34 Common Rail Var.1
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC 16C 34 Common Rail Var.1
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH EDC 16C 34 Common Rail Var.1
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	JCAE Body Computer BSI
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	JCAE Body Computer MANUAL
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	JCAE Dashboard
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Siemens-JCAE AUTODETECT
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Siemens-JCAE AUTODETECT
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Siemens-JCAE AUTODETECT
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Siemens-JCAE AUTODETECT
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	SV limitation 2
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Var.1
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Var.1
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Var.1
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Var.1
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Var.1
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Var.1
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Var.1
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Var.1
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Var.2
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Var.2
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Var.2
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Var.2
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Var.2
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Var.2
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Var.2
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Var.3
 307 Restyling (05-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	VDO MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

[illegible]

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

[illegible]

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 307 Restyling (05-08)	MAINTENANCE	2.0 16v 103kw RFJ	Var.2
 307 Restyling (05-08)	MAINTENANCE	2.0 16v 103kw RFJ	Var.3
 307 Restyling (05-08)	MAINTENANCE	2.0 16v 103kw RFJ	VDO MANUAL
 307 Restyling (05-08)	MAINTENANCE	2.0 16v 130kw RFK	A/T AM6
 307 Restyling (05-08)	MAINTENANCE	2.0 16v 130kw RFK	A/T AM6
 307 Restyling (05-08)	MAINTENANCE	2.0 16v 130kw RFK	AirBag CENTRAL
 307 Restyling (05-08)	MAINTENANCE	2.0 16v 130kw RFK	AirBag CENTRAL
 307 Restyling (05-08)	MAINTENANCE	2.0 16v 130kw RFK	BOSCH ABS 8
 307 Restyling (05-08)	MAINTENANCE	2.0 16v 130kw RFK	JCAE Body Computer BSI
 307 Restyling (05-08)	MAINTENANCE	2.0 16v 130kw RFK	JCAE Body Computer MANUAL
 307 Restyling (05-08)	MAINTENANCE	2.0 16v 130kw RFK	JCAE Dashboard
 307 Restyling (05-08)	MAINTENANCE	2.0 16v 130kw RFK	Siemens-JCAE AUTODETECT
 307 Restyling (05-08)	MAINTENANCE	2.0 16v 130kw RFK	Siemens-JCAE AUTODETECT
 307 Restyling (05-08)	MAINTENANCE	2.0 16v 130kw RFK	Siemens-JCAE AUTODETECT
 307 Restyling (05-08)	MAINTENANCE	2.0 16v 130kw RFK	Siemens-JCAE AUTODETECT
 307 Restyling (05-08)	MAINTENANCE	2.0 16v 130kw RFK	SV limitation 2
 307 Restyling (05-08)	MAINTENANCE	2.0 16v 130kw RFK	Var.1
 307 Restyling (05-08)	MAINTENANCE	2.0 16v 130kw RFK	Var.1
 307 Restyling (05-08)	MAINTENANCE	2.0 16v 130kw RFK	Var.1
 307 Restyling (05-08)	MAINTENANCE	2.0 16v 130kw RFK	Var.1
 307 Restyling (05-08)	MAINTENANCE	2.0 16v 130kw RFK	Var.1
 307 Restyling (05-08)	MAINTENANCE	2.0 16v 130kw RFK	Var.2
 307 Restyling (05-08)	MAINTENANCE	2.0 16v 130kw RFK	Var.2
 307 Restyling (05-08)	MAINTENANCE	2.0 16v 130kw RFK	Var.2
 307 Restyling (05-08)	MAINTENANCE	2.0 16v 130kw RFK	Var.2
 307 Restyling (05-08)	MAINTENANCE	2.0 16v 130kw RFK	Var.2
 307 Restyling (05-08)	MAINTENANCE	2.0 16v 130kw RFK	Var.2
 307 Restyling (05-08)	MAINTENANCE	2.0 16v 130kw RFK	Var.3
 307 Restyling (05-08)	MAINTENANCE	2.0 16v 130kw RFK	VDO MANUAL
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	A/T AM6
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	A/T AM6
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	AirBag CENTRAL
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	AirBag CENTRAL
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	BOSCH ABS 8
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	DELPHI DCM 3.4 Common Rail
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	JCAE Body Computer BSI
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	JCAE Body Computer MANUAL
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	JCAE Dashboard
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803 Common Rail Var.1
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803 Common Rail Var.1
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803 Common Rail Var.1
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803A Common Rail Var.2
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803A Common Rail Var.2
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803A Common Rail Var.2
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Siemens-JCAE AUTODETECT
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Siemens-JCAE AUTODETECT
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Siemens-JCAE AUTODETECT
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Siemens-JCAE AUTODETECT
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SV limitation 2
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.1
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.1
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.1
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.1
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.1
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.1
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.1
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.2
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.2
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.2
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.2
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.2
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.2
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.2
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.2
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.2
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.2
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.3
 307 Restyling (05-08)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	VDO MANUAL
 307 Restyling (05-08)	PARKING HELP	1.4 16v 66kw KFJ	Var.1
 307 Restyling (05-08)	PARKING HELP	1.4 16v 66kw KFJ	Var.2
 307 Restyling (05-08)	PARKING HELP	1.6 16v 82kw NFJ	Var.1
 307 Restyling (05-08)	PARKING HELP	1.6 16v 82kw NFJ	Var.2
 307 Restyling (05-08)	PARKING HELP	1.6 HDI 16v 66kw 9HX	Var.1
 307 Restyling (05-08)	PARKING HELP	1.6 HDI 16v 66kw 9HX	Var.2
 307 Restyling (05-08)	PARKING HELP	1.6 HDI 16v 80kw 9HY	Var.1
 307 Restyling (05-08)	PARKING HELP	1.6 HDI 16v 80kw 9HY	Var.2
 307 Restyling (05-08)	PARKING HELP	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 307 Restyling (05-08)	PARKING HELP	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 307 Restyling (05-08)	PARKING HELP	2.0 16v 103kw RFJ	Var.1
 307 Restyling (05-08)	PARKING HELP	2.0 16v 103kw RFJ	Var.2
 307 Restyling (05-08)	PARKING HELP	2.0 16v 130kw RFK	Var.1
 307 Restyling (05-08)	PARKING HELP	2.0 16v 130kw RFK	Var.2
 307 Restyling (05-08)	PARKING HELP	2.0 HDI 16v 100kw RHR-FAP	Var.1
 307 Restyling (05-08)	PARKING HELP	2.0 HDI 16v 100kw RHR-FAP	Var.2
 307 Restyling (05-08)	PASS. SIDE DOOR	1.4 16v 66kw KFJ	ArvinMeritor PassengerDoor
 307 Restyling (05-08)	PASS. SIDE DOOR	1.4 16v 66kw KFJ	Var.1
 307 Restyling (05-08)	PASS. SIDE DOOR	1.4 16v 66kw KFJ	Var.2
 307 Restyling (05-08)	PASS. SIDE DOOR	1.6 16v 82kw NFJ	ArvinMeritor PassengerDoor
 307 Restyling (05-08)	PASS. SIDE DOOR	1.6 16v 82kw NFJ	Var.1
 307 Restyling (05-08)	PASS. SIDE DOOR	1.6 16v 82kw NFJ	Var.2
 307 Restyling (05-08)	PASS. SIDE DOOR	1.6 HDI 16v 66kw 9HX	ArvinMeritor PassengerDoor
 307 Restyling (05-08)	PASS. SIDE DOOR	1.6 HDI 16v 66kw 9HX	Var.1
 307 Restyling (05-08)	PASS. SIDE DOOR	1.6 HDI 16v 66kw 9HX	Var.2
 307 Restyling (05-08)	PASS. SIDE DOOR	1.6 HDI 16v 80kw 9HY	ArvinMeritor PassengerDoor
 307 Restyling (05-08)	PASS. SIDE DOOR	1.6 HDI 16v 80kw 9HY	Var.1
 307 Restyling (05-08)	PASS. SIDE DOOR	1.6 HDI 16v 80kw 9HY	Var.2
 307 Restyling (05-08)	PASS. SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	ArvinMeritor PassengerDoor
 307 Restyling (05-08)	PASS. SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 307 Restyling (05-08)	PASS. SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 307 Restyling (05-08)	PASS. SIDE DOOR	2.0 16v 103kw RFJ	ArvinMeritor PassengerDoor
 307 Restyling (05-08)	PASS. SIDE DOOR	2.0 16v 103kw RFJ	Var.1
 307 Restyling (05-08)	PASS. SIDE DOOR	2.0 16v 103kw RFJ	Var.2
 307 Restyling (05-08)	PASS. SIDE DOOR	2.0 16v 130kw RFK	ArvinMeritor PassengerDoor
 307 Restyling (05-08)	PASS. SIDE DOOR	2.0 16v 130kw RFK	Var.1
 307 Restyling (05-08)	PASS. SIDE DOOR	2.0 16v 130kw RFK	Var.2
 307 Restyling (05-08)	PASS. SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	ArvinMeritor PassengerDoor
 307 Restyling (05-08)	PASS. SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	Var.1
 307 Restyling (05-08)	PASS. SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	Var.2
 307 Restyling (05-08)	RADIO / CD	1.4 16v 66kw KFJ	Var.1
 307 Restyling (05-08)	RADIO / CD	1.4 16v 66kw KFJ	Var.2
 307 Restyling (05-08)	RADIO / CD	1.4 16v 66kw KFJ	Var.3
 307 Restyling (05-08)	RADIO / CD	1.4 16v 66kw KFJ	Var.4
 307 Restyling (05-08)	RADIO / CD	1.6 16v 82kw NFJ	Var.1
 307 Restyling (05-08)	RADIO / CD	1.6 16v 82kw NFJ	Var.2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 307 Restyling (05-08)	RADIO / CD	1.6 16v 82kw NFU	Var.3
 307 Restyling (05-08)	RADIO / CD	1.6 16v 82kw NFU	Var.4
 307 Restyling (05-08)	RADIO / CD	1.6 HDI 16v 66kw 9HX	Var.1
 307 Restyling (05-08)	RADIO / CD	1.6 HDI 16v 66kw 9HX	Var.2
 307 Restyling (05-08)	RADIO / CD	1.6 HDI 16v 66kw 9HX	Var.3
 307 Restyling (05-08)	RADIO / CD	1.6 HDI 16v 66kw 9HX	Var.4
 307 Restyling (05-08)	RADIO / CD	1.6 HDI 16v 80kw 9HY	Var.1
 307 Restyling (05-08)	RADIO / CD	1.6 HDI 16v 80kw 9HY	Var.2
 307 Restyling (05-08)	RADIO / CD	1.6 HDI 16v 80kw 9HY	Var.3
 307 Restyling (05-08)	RADIO / CD	1.6 HDI 16v 80kw 9HY	Var.4
 307 Restyling (05-08)	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 307 Restyling (05-08)	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 307 Restyling (05-08)	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Var.3
 307 Restyling (05-08)	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Var.4
 307 Restyling (05-08)	RADIO / CD	2.0 16v 103kw RFJ	Var.1
 307 Restyling (05-08)	RADIO / CD	2.0 16v 103kw RFJ	Var.2
 307 Restyling (05-08)	RADIO / CD	2.0 16v 103kw RFJ	Var.3
 307 Restyling (05-08)	RADIO / CD	2.0 16v 103kw RFJ	Var.4
 307 Restyling (05-08)	RADIO / CD	2.0 16v 130kw RFK	Var.1
 307 Restyling (05-08)	RADIO / CD	2.0 16v 130kw RFK	Var.2
 307 Restyling (05-08)	RADIO / CD	2.0 16v 130kw RFK	Var.3
 307 Restyling (05-08)	RADIO / CD	2.0 16v 130kw RFK	Var.4
 307 Restyling (05-08)	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP	Var.1
 307 Restyling (05-08)	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP	Var.2
 307 Restyling (05-08)	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP	Var.3
 307 Restyling (05-08)	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP	Var.4
 307 Restyling (05-08)	RAIN-LUMINOSITY S	1.4 16v 66kw KFU	BOSCH WSS
 307 Restyling (05-08)	RAIN-LUMINOSITY S	1.4 16v 66kw KFU	Var.1
 307 Restyling (05-08)	RAIN-LUMINOSITY S	1.4 16v 66kw KFU	Var.2
 307 Restyling (05-08)	RAIN-LUMINOSITY S	1.6 16v 82kw NFU	BOSCH WSS
 307 Restyling (05-08)	RAIN-LUMINOSITY S	1.6 16v 82kw NFU	Var.1
 307 Restyling (05-08)	RAIN-LUMINOSITY S	1.6 16v 82kw NFU	Var.2
 307 Restyling (05-08)	RAIN-LUMINOSITY S	1.6 HDI 16v 66kw 9HX	BOSCH WSS
 307 Restyling (05-08)	RAIN-LUMINOSITY S	1.6 HDI 16v 66kw 9HX	Var.1
 307 Restyling (05-08)	RAIN-LUMINOSITY S	1.6 HDI 16v 66kw 9HX	Var.2
 307 Restyling (05-08)	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HY	BOSCH WSS
 307 Restyling (05-08)	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HY	Var.1
 307 Restyling (05-08)	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HY	Var.2
 307 Restyling (05-08)	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH WSS
 307 Restyling (05-08)	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 307 Restyling (05-08)	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 307 Restyling (05-08)	RAIN-LUMINOSITY S	2.0 16v 103kw RFJ	BOSCH WSS
 307 Restyling (05-08)	RAIN-LUMINOSITY S	2.0 16v 103kw RFJ	Var.1
 307 Restyling (05-08)	RAIN-LUMINOSITY S	2.0 16v 103kw RFJ	Var.2
 307 Restyling (05-08)	RAIN-LUMINOSITY S	2.0 16v 130kw RFK	BOSCH WSS
 307 Restyling (05-08)	RAIN-LUMINOSITY S	2.0 16v 130kw RFK	Var.1
 307 Restyling (05-08)	RAIN-LUMINOSITY S	2.0 16v 130kw RFK	Var.2
 307 Restyling (05-08)	RAIN-LUMINOSITY S	2.0 HDI 16v 100kw RHR-FAP	BOSCH WSS
 307 Restyling (05-08)	RAIN-LUMINOSITY S	2.0 HDI 16v 100kw RHR-FAP	Var.1
 307 Restyling (05-08)	RAIN-LUMINOSITY S	2.0 HDI 16v 100kw RHR-FAP	Var.2
 307 Restyling (05-08)	REMOTE CONTROL E	1.4 16v 66kw KFU	JCAE Body Computer MANUAL
 307 Restyling (05-08)	REMOTE CONTROL E	1.6 16v 82kw NFU	JCAE Body Computer MANUAL
 307 Restyling (05-08)	REMOTE CONTROL E	1.6 HDI 16v 66kw 9HX	JCAE Body Computer MANUAL
 307 Restyling (05-08)	REMOTE CONTROL E	1.6 HDI 16v 80kw 9HY	JCAE Body Computer MANUAL
 307 Restyling (05-08)	REMOTE CONTROL E	1.6 HDI 16v 80kw 9HZ-FAP	JCAE Body Computer MANUAL
 307 Restyling (05-08)	REMOTE CONTROL E	2.0 16v 103kw RFJ	JCAE Body Computer MANUAL
 307 Restyling (05-08)	REMOTE CONTROL E	2.0 16v 130kw RFK	JCAE Body Computer MANUAL
 307 Restyling (05-08)	REMOTE CONTROL E	2.0 HDI 16v 100kw RHR-FAP	JCAE Body Computer MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 307 Restyling (05-08)	SERVICE LIGHT RES	1.4 16v 66kw KFU	VDO MANUAL
 307 Restyling (05-08)	SERVICE LIGHT RES	1.6 16v 82kw NFU	VDO MANUAL
 307 Restyling (05-08)	SERVICE LIGHT RES	1.6 HDI 16v 66kw 9HX	VDO MANUAL
 307 Restyling (05-08)	SERVICE LIGHT RES	1.6 HDI 16v 80kw 9HY	VDO MANUAL
 307 Restyling (05-08)	SERVICE LIGHT RES	1.6 HDI 16v 80kw 9HZ-FAP	VDO MANUAL
 307 Restyling (05-08)	SERVICE LIGHT RES	2.0 16v 103kw RFJ	VDO MANUAL
 307 Restyling (05-08)	SERVICE LIGHT RES	2.0 16v 130kw RFK	VDO MANUAL
 307 Restyling (05-08)	SERVICE LIGHT RES	2.0 HDI 16v 100kw RHR-FAP	VDO MANUAL
 307 Restyling (05-08)	STEERING COLUMN	1.4 16v 66kw KFU	
 307 Restyling (05-08)	STEERING COLUMN	1.6 16v 82kw NFU	
 307 Restyling (05-08)	STEERING COLUMN	1.6 HDI 16v 66kw 9HX	
 307 Restyling (05-08)	STEERING COLUMN	1.6 HDI 16v 80kw 9HY	
 307 Restyling (05-08)	STEERING COLUMN	1.6 HDI 16v 80kw 9HZ-FAP	
 307 Restyling (05-08)	STEERING COLUMN	2.0 16v 103kw RFJ	
 307 Restyling (05-08)	STEERING COLUMN	2.0 16v 130kw RFK	
 307 Restyling (05-08)	STEERING COLUMN	2.0 HDI 16v 100kw RHR-FAP	
 307 Restyling (05-08)	SWITCHLIGHT MODU	1.4 16v 66kw KFU	EATON/DELPHI
 307 Restyling (05-08)	SWITCHLIGHT MODU	1.6 16v 82kw NFU	EATON/DELPHI
 307 Restyling (05-08)	SWITCHLIGHT MODU	1.6 HDI 16v 66kw 9HX	EATON/DELPHI
 307 Restyling (05-08)	SWITCHLIGHT MODU	1.6 HDI 16v 80kw 9HY	EATON/DELPHI
 307 Restyling (05-08)	SWITCHLIGHT MODU	1.6 HDI 16v 80kw 9HZ-FAP	EATON/DELPHI
 307 Restyling (05-08)	SWITCHLIGHT MODU	2.0 16v 103kw RFJ	EATON/DELPHI
 307 Restyling (05-08)	SWITCHLIGHT MODU	2.0 16v 130kw RFK	EATON/DELPHI
 307 Restyling (05-08)	SWITCHLIGHT MODU	2.0 HDI 16v 100kw RHR-FAP	EATON/DELPHI
 307 Restyling (05-08)	TIRE PRESSURE	1.4 16v 66kw KFU	Siemens-JCAE AUTODETECT
 307 Restyling (05-08)	TIRE PRESSURE	1.6 16v 82kw NFU	Siemens-JCAE AUTODETECT
 307 Restyling (05-08)	TIRE PRESSURE	1.6 HDI 16v 66kw 9HX	Siemens-JCAE AUTODETECT
 307 Restyling (05-08)	TIRE PRESSURE	1.6 HDI 16v 80kw 9HY	Siemens-JCAE AUTODETECT
 307 Restyling (05-08)	TIRE PRESSURE	1.6 HDI 16v 80kw 9HZ-FAP	Siemens-JCAE AUTODETECT
 307 Restyling (05-08)	TIRE PRESSURE	2.0 16v 103kw RFJ	Siemens-JCAE AUTODETECT
 307 Restyling (05-08)	TIRE PRESSURE	2.0 16v 130kw RFK	Siemens-JCAE AUTODETECT
 307 Restyling (05-08)	TIRE PRESSURE	2.0 HDI 16v 100kw RHR-FAP	Siemens-JCAE AUTODETECT
 307 Restyling (05-08)	VISUAL./TELEMATIC	1.4 16v 66kw KFU	DIS
 307 Restyling (05-08)	VISUAL./TELEMATIC	1.4 16v 66kw KFU	Display C-
 307 Restyling (05-08)	VISUAL./TELEMATIC	1.6 16v 82kw NFU	DIS
 307 Restyling (05-08)	VISUAL./TELEMATIC	1.6 16v 82kw NFU	Display C-
 307 Restyling (05-08)	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HX	DIS
 307 Restyling (05-08)	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HX	Display C-
 307 Restyling (05-08)	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HY	DIS
 307 Restyling (05-08)	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HY	Display C-
 307 Restyling (05-08)	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	DIS
 307 Restyling (05-08)	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	Display C-
 307 Restyling (05-08)	VISUAL./TELEMATIC	2.0 16v 103kw RFJ	DIS
 307 Restyling (05-08)	VISUAL./TELEMATIC	2.0 16v 103kw RFJ	Display C-
 307 Restyling (05-08)	VISUAL./TELEMATIC	2.0 16v 130kw RFK	DIS
 307 Restyling (05-08)	VISUAL./TELEMATIC	2.0 16v 130kw RFK	Display C-
 307 Restyling (05-08)	VISUAL./TELEMATIC	2.0 HDI 16v 100kw RHR-FAP	DIS
 307 Restyling (05-08)	VISUAL./TELEMATIC	2.0 HDI 16v 100kw RHR-FAP	Display C-
 307	ABS	1.4 16v 66kw KFU	TEVES ABS MK60
 307	ABS	1.4 16v 66kw KFU (02-..)	BOSCH ABS 8
 307	ABS	1.4 55kw KFW	TEVES ABS MK60
 307	ABS	1.4 55kw KFW (02-..)	BOSCH ABS 8
 307	ABS	1.4 HDI 50kw 8HZ	TEVES ABS MK60
 307	ABS	1.4 HDI 50kw 8HZ (02-..)	BOSCH ABS 8
 307	ABS	1.6 16v 82kw NFU	TEVES ABS MK60
 307	ABS	1.6 16v 82kw NFU (02-..)	BOSCH ABS 8
 307	ABS	1.6 66kw NFZ	TEVES ABS MK60
 307	ABS	1.6 66kw NFZ (02-..)	BOSCH ABS 8

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 307	ABS	1.6 HDI 16v 80kw 9HY	TEVES ABS MK60
 307	ABS	1.6 HDI 16v 80kw 9HY (02-..)	BOSCH ABS 8
 307	ABS	1.6 HDI 16v 80kw 9HZ-FAP	TEVES ABS MK60
 307	ABS	1.6 HDI 16v 80kw 9HZ-FAP (02-..)	BOSCH ABS 8
 307	ABS	2.0 16v 100kw RFN	TEVES ABS MK60
 307	ABS	2.0 16v 100kw RFN (02-..)	BOSCH ABS 8
 307	ABS	2.0 16v 103kw RFJ	TEVES ABS MK60
 307	ABS	2.0 16v 103kw RFJ (02-..)	BOSCH ABS 8
 307	ABS	2.0 HDI 16v 100kw RHR-FAP	TEVES ABS MK60
 307	ABS	2.0 HDI 16v 100kw RHR-FAP (02-..)	BOSCH ABS 8
 307	ABS	2.0 HDI 16v 66kw RHY	TEVES ABS MK60
 307	ABS	2.0 HDI 16v 66kw RHY (02-..)	BOSCH ABS 8
 307	ABS	2.0 HDI 16v 81kw RHS	TEVES ABS MK60
 307	ABS	2.0 HDI 16v 81kw RHS (02-..)	BOSCH ABS 8
 307	ABS + TRACT. CONT	1.4 16v 66kw KFU	BOSCH ESP 5.7
 307	ABS + TRACT. CONT	1.4 16v 66kw KFU	Var.1
 307	ABS + TRACT. CONT	1.4 16v 66kw KFU	Var.2
 307	ABS + TRACT. CONT	1.4 16v 66kw KFU (02-..)	BOSCH ABS/ESP 5.7
 307	ABS + TRACT. CONT	1.4 55kw KFW	BOSCH ESP 5.7
 307	ABS + TRACT. CONT	1.4 55kw KFW	Var.1
 307	ABS + TRACT. CONT	1.4 55kw KFW	Var.2
 307	ABS + TRACT. CONT	1.4 55kw KFW (02-..)	BOSCH ABS/ESP 5.7
 307	ABS + TRACT. CONT	1.4 HDI 50kw 8HZ	BOSCH ESP 5.7
 307	ABS + TRACT. CONT	1.4 HDI 50kw 8HZ	Var.1
 307	ABS + TRACT. CONT	1.4 HDI 50kw 8HZ	Var.2
 307	ABS + TRACT. CONT	1.4 HDI 50kw 8HZ (02-..)	BOSCH ABS/ESP 5.7
 307	ABS + TRACT. CONT	1.6 16v 82kw NFU	BOSCH ESP 5.7
 307	ABS + TRACT. CONT	1.6 16v 82kw NFU	Var.1
 307	ABS + TRACT. CONT	1.6 16v 82kw NFU	Var.2
 307	ABS + TRACT. CONT	1.6 16v 82kw NFU (02-..)	BOSCH ABS/ESP 5.7
 307	ABS + TRACT. CONT	1.6 66kw NFZ	BOSCH ESP 5.7
 307	ABS + TRACT. CONT	1.6 66kw NFZ	Var.1
 307	ABS + TRACT. CONT	1.6 66kw NFZ	Var.2
 307	ABS + TRACT. CONT	1.6 66kw NFZ (02-..)	BOSCH ABS/ESP 5.7
 307	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HY	BOSCH ESP 5.7
 307	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HY	Var.1
 307	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HY	Var.2
 307	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HY (02-..)	BOSCH ABS/ESP 5.7
 307	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ESP 5.7
 307	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 307	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 307	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP (02-..)	BOSCH ABS/ESP 5.7
 307	ABS + TRACT. CONT	2.0 16v 100kw RFN	BOSCH ESP 5.7
 307	ABS + TRACT. CONT	2.0 16v 100kw RFN	Var.1
 307	ABS + TRACT. CONT	2.0 16v 100kw RFN	Var.2
 307	ABS + TRACT. CONT	2.0 16v 100kw RFN (02-..)	BOSCH ABS/ESP 5.7
 307	ABS + TRACT. CONT	2.0 16v 103kw RFJ	BOSCH ESP 5.7
 307	ABS + TRACT. CONT	2.0 16v 103kw RFJ	Var.1
 307	ABS + TRACT. CONT	2.0 16v 103kw RFJ	Var.2
 307	ABS + TRACT. CONT	2.0 16v 103kw RFJ (02-..)	BOSCH ABS/ESP 5.7
 307	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP	BOSCH ESP 5.7
 307	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP	Var.1
 307	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP	Var.2
 307	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP (02-..)	BOSCH ABS/ESP 5.7
 307	ABS + TRACT. CONT	2.0 HDI 16v 66kw RHY	BOSCH ESP 5.7
 307	ABS + TRACT. CONT	2.0 HDI 16v 66kw RHY	Var.1
 307	ABS + TRACT. CONT	2.0 HDI 16v 66kw RHY	Var.2
 307	ABS + TRACT. CONT	2.0 HDI 16v 66kw RHY (02-..)	BOSCH ABS/ESP 5.7

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 307	ABS + TRACT. CONT	2.0 HDI 16v 81kw RHS	BOSCH ESP 5.7
 307	ABS + TRACT. CONT	2.0 HDI 16v 81kw RHS	Var.1
 307	ABS + TRACT. CONT	2.0 HDI 16v 81kw RHS	Var.2
 307	ABS + TRACT. CONT	2.0 HDI 16v 81kw RHS (02-..)	BOSCH ABS/ESP 5.7
 307	AIRBAG	1.4 16v 66kw KFU	Temic AirBag CENTRAL
 307	AIRBAG	1.4 16v 66kw KFU (02-..)	SIEMENS AirBag SAC CENT
 307	AIRBAG	1.4 55kw KFW	Temic AirBag CENTRAL
 307	AIRBAG	1.4 55kw KFW (02-..)	SIEMENS AirBag SAC CENT
 307	AIRBAG	1.4 HDI 50kw 8HZ	Temic AirBag CENTRAL
 307	AIRBAG	1.4 HDI 50kw 8HZ (02-..)	SIEMENS AirBag SAC CENT
 307	AIRBAG	1.6 16v 82kw NFU	Temic AirBag CENTRAL
 307	AIRBAG	1.6 16v 82kw NFU (02-..)	SIEMENS AirBag SAC CENT
 307	AIRBAG	1.6 66kw NFZ	Temic AirBag CENTRAL
 307	AIRBAG	1.6 66kw NFZ (02-..)	SIEMENS AirBag SAC CENT
 307	AIRBAG	1.6 HDI 16v 80kw 9HY	Temic AirBag CENTRAL
 307	AIRBAG	1.6 HDI 16v 80kw 9HY (02-..)	SIEMENS AirBag SAC CENT
 307	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP	Temic AirBag CENTRAL
 307	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP (02-..)	SIEMENS AirBag SAC CENT
 307	AIRBAG	2.0 16v 100kw RFN	Temic AirBag CENTRAL
 307	AIRBAG	2.0 16v 100kw RFN (02-..)	SIEMENS AirBag SAC CENT
 307	AIRBAG	2.0 16v 103kw RFJ	Temic AirBag CENTRAL
 307	AIRBAG	2.0 16v 103kw RFJ (02-..)	SIEMENS AirBag SAC CENT
 307	AIRBAG	2.0 HDI 16v 100kw RHR-FAP	Temic AirBag CENTRAL
 307	AIRBAG	2.0 HDI 16v 100kw RHR-FAP (02-..)	SIEMENS AirBag SAC CENT
 307	AIRBAG	2.0 HDI 16v 66kw RHY	Temic AirBag CENTRAL
 307	AIRBAG	2.0 HDI 16v 66kw RHY (02-..)	SIEMENS AirBag SAC CENT
 307	AIRBAG	2.0 HDI 16v 81kw RHS	Temic AirBag CENTRAL
 307	AIRBAG	2.0 HDI 16v 81kw RHS (02-..)	SIEMENS AirBag SAC CENT
 307	ANTITHEFT	1.4 16v 66kw KFU	Alarm PSA2
 307	ANTITHEFT	1.4 55kw KFW	Alarm PSA2
 307	ANTITHEFT	1.4 HDI 50kw 8HZ	Alarm PSA2
 307	ANTITHEFT	1.6 16v 82kw NFU	Alarm PSA2
 307	ANTITHEFT	1.6 66kw NFZ	Alarm PSA2
 307	ANTITHEFT	1.6 HDI 16v 80kw 9HY	Alarm PSA2
 307	ANTITHEFT	1.6 HDI 16v 80kw 9HZ-FAP	Alarm PSA2
 307	ANTITHEFT	2.0 16v 100kw RFN	Alarm PSA2
 307	ANTITHEFT	2.0 16v 103kw RFJ	Alarm PSA2
 307	ANTITHEFT	2.0 HDI 16v 100kw RHR-FAP	Alarm PSA2
 307	ANTITHEFT	2.0 HDI 16v 66kw RHY	Alarm PSA2
 307	ANTITHEFT	2.0 HDI 16v 81kw RHS	Alarm PSA2
 307	CHASSIS NETWORK	1.4 16v 66kw KFU	Body Computer BSI
 307	CHASSIS NETWORK	1.4 16v 66kw KFU (...02)	VALEO Body Computer
 307	CHASSIS NETWORK	1.4 55kw KFW	Body Computer BSI
 307	CHASSIS NETWORK	1.4 55kw KFW (...02)	VALEO Body Computer
 307	CHASSIS NETWORK	1.4 HDI 50kw 8HZ	Body Computer BSI
 307	CHASSIS NETWORK	1.4 HDI 50kw 8HZ (...02)	VALEO Body Computer
 307	CHASSIS NETWORK	1.6 16v 82kw NFU	Body Computer BSI
 307	CHASSIS NETWORK	1.6 16v 82kw NFU (...02)	VALEO Body Computer
 307	CHASSIS NETWORK	1.6 66kw NFZ	Body Computer BSI
 307	CHASSIS NETWORK	1.6 66kw NFZ (...02)	VALEO Body Computer
 307	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY	Body Computer BSI
 307	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY (...02)	VALEO Body Computer
 307	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSI
 307	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP (...02)	VALEO Body Computer
 307	CHASSIS NETWORK	2.0 16v 100kw RFN	Body Computer BSI
 307	CHASSIS NETWORK	2.0 16v 100kw RFN (...02)	VALEO Body Computer
 307	CHASSIS NETWORK	2.0 16v 103kw RFJ	Body Computer BSI
 307	CHASSIS NETWORK	2.0 16v 103kw RFJ (...02)	VALEO Body Computer

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 307	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	Body Computer BSI
 307	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP (...02)	VALEO Body Computer
 307	CHASSIS NETWORK	2.0 HDI 16v 66kw RHY	Body Computer BSI
 307	CHASSIS NETWORK	2.0 HDI 16v 66kw RHY (...02)	VALEO Body Computer
 307	CHASSIS NETWORK	2.0 HDI 16v 81kw RHS	Body Computer BSI
 307	CHASSIS NETWORK	2.0 HDI 16v 81kw RHS (...02)	VALEO Body Computer
 307	CLIMA	1.4 16v 66kw KFU	CLAA8
 307	CLIMA	1.4 16v 66kw KFU	VALEO CLAA5 CLIMA 220 RFTD
 307	CLIMA	1.4 16v 66kw KFU (02-..)	BEHR Klimautomatik 1.0
 307	CLIMA	1.4 16v 66kw KFU (02-..)	Klimautomatik x.x
 307	CLIMA	1.4 16v 66kw KFU (02-..)	VALEO Klimautomatik 2.0
 307	CLIMA	1.4 55kw KFW	CLAA8
 307	CLIMA	1.4 55kw KFW	VALEO CLAA5 CLIMA 220 RFTD
 307	CLIMA	1.4 55kw KFW (02-..)	BEHR Klimautomatik 1.0
 307	CLIMA	1.4 55kw KFW (02-..)	Klimautomatik x.x
 307	CLIMA	1.4 55kw KFW (02-..)	VALEO Klimautomatik 2.0
 307	CLIMA	1.4 HDI 50kw 8HZ	CLAA8
 307	CLIMA	1.4 HDI 50kw 8HZ	VALEO CLAA5 CLIMA 220 RFTD
 307	CLIMA	1.4 HDI 50kw 8HZ (02-..)	BEHR Klimautomatik 1.0
 307	CLIMA	1.4 HDI 50kw 8HZ (02-..)	Klimautomatik x.x
 307	CLIMA	1.4 HDI 50kw 8HZ (02-..)	VALEO Klimautomatik 2.0
 307	CLIMA	1.6 16v 82kw NFU	CLAA8
 307	CLIMA	1.6 16v 82kw NFU	VALEO CLAA5 CLIMA 220 RFTD
 307	CLIMA	1.6 16v 82kw NFU (02-..)	BEHR Klimautomatik 1.0
 307	CLIMA	1.6 16v 82kw NFU (02-..)	Klimautomatik x.x
 307	CLIMA	1.6 16v 82kw NFU (02-..)	VALEO Klimautomatik 2.0
 307	CLIMA	1.6 66kw NFZ	CLAA8
 307	CLIMA	1.6 66kw NFZ	VALEO CLAA5 CLIMA 220 RFTD
 307	CLIMA	1.6 66kw NFZ (02-..)	BEHR Klimautomatik 1.0
 307	CLIMA	1.6 66kw NFZ (02-..)	Klimautomatik x.x
 307	CLIMA	1.6 66kw NFZ (02-..)	VALEO Klimautomatik 2.0
 307	CLIMA	1.6 HDI 16v 80kw 9HY	CLAA8
 307	CLIMA	1.6 HDI 16v 80kw 9HY	VALEO CLAA5 CLIMA 220 RFTD
 307	CLIMA	1.6 HDI 16v 80kw 9HY (02-..)	BEHR Klimautomatik 1.0
 307	CLIMA	1.6 HDI 16v 80kw 9HY (02-..)	Klimautomatik x.x
 307	CLIMA	1.6 HDI 16v 80kw 9HY (02-..)	VALEO Klimautomatik 2.0
 307	CLIMA	1.6 HDI 16v 80kw 9HZ-FAP	CLAA8
 307	CLIMA	1.6 HDI 16v 80kw 9HZ-FAP	VALEO CLAA5 CLIMA 220 RFTD
 307	CLIMA	1.6 HDI 16v 80kw 9HZ-FAP (02-..)	BEHR Klimautomatik 1.0
 307	CLIMA	1.6 HDI 16v 80kw 9HZ-FAP (02-..)	Klimautomatik x.x
 307	CLIMA	1.6 HDI 16v 80kw 9HZ-FAP (02-..)	VALEO Klimautomatik 2.0
 307	CLIMA	2.0 16v 100kw RFN	CLAA8
 307	CLIMA	2.0 16v 100kw RFN	VALEO CLAA5 CLIMA 220 RFTD
 307	CLIMA	2.0 16v 100kw RFN (02-..)	BEHR Klimautomatik 1.0
 307	CLIMA	2.0 16v 100kw RFN (02-..)	Klimautomatik x.x
 307	CLIMA	2.0 16v 100kw RFN (02-..)	VALEO Klimautomatik 2.0
 307	CLIMA	2.0 16v 103kw RFJ	CLAA8
 307	CLIMA	2.0 16v 103kw RFJ	VALEO CLAA5 CLIMA 220 RFTD
 307	CLIMA	2.0 16v 103kw RFJ (02-..)	BEHR Klimautomatik 1.0
 307	CLIMA	2.0 16v 103kw RFJ (02-..)	Klimautomatik x.x
 307	CLIMA	2.0 16v 103kw RFJ (02-..)	VALEO Klimautomatik 2.0
 307	CLIMA	2.0 HDI 16v 100kw RHR-FAP	CLAA8
 307	CLIMA	2.0 HDI 16v 100kw RHR-FAP	VALEO CLAA5 CLIMA 220 RFTD
 307	CLIMA	2.0 HDI 16v 100kw RHR-FAP (02-..)	BEHR Klimautomatik 1.0
 307	CLIMA	2.0 HDI 16v 100kw RHR-FAP (02-..)	Klimautomatik x.x
 307	CLIMA	2.0 HDI 16v 100kw RHR-FAP (02-..)	VALEO Klimautomatik 2.0
 307	CLIMA	2.0 HDI 16v 66kw RHY	CLAA8
 307	CLIMA	2.0 HDI 16v 66kw RHY	VALEO CLAA5 CLIMA 220 RFTD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 307	CLIMA	2.0 HDI 16v 66kw RHY (02-..)	BEHR Klimautomatik 1.0
 307	CLIMA	2.0 HDI 16v 66kw RHY (02-..)	Klimautomatik x.x
 307	CLIMA	2.0 HDI 16v 66kw RHY (02-..)	VALEO Klimautomatik 2.0
 307	CLIMA	2.0 HDI 16v 81kw RHS	CLAA8
 307	CLIMA	2.0 HDI 16v 81kw RHS	VALEO CLAA5 CLIMA 220 RFTD
 307	CLIMA	2.0 HDI 16v 81kw RHS (02-..)	BEHR Klimautomatik 1.0
 307	CLIMA	2.0 HDI 16v 81kw RHS (02-..)	Klimautomatik x.x
 307	CLIMA	2.0 HDI 16v 81kw RHS (02-..)	VALEO Klimautomatik 2.0
 307	CONV. TOP/SUNROO	1.4 16v 66kw KFU	Var.1
 307	CONV. TOP/SUNROO	1.4 16v 66kw KFU	Var.2
 307	CONV. TOP/SUNROO	1.4 55kw KFW	Var.1
 307	CONV. TOP/SUNROO	1.4 55kw KFW	Var.2
 307	CONV. TOP/SUNROO	1.4 HDI 50kw 8HZ	Var.1
 307	CONV. TOP/SUNROO	1.4 HDI 50kw 8HZ	Var.2
 307	CONV. TOP/SUNROO	1.6 16v 82kw NFU	Var.1
 307	CONV. TOP/SUNROO	1.6 16v 82kw NFU	Var.2
 307	CONV. TOP/SUNROO	1.6 66kw NFZ	Var.1
 307	CONV. TOP/SUNROO	1.6 66kw NFZ	Var.2
 307	CONV. TOP/SUNROO	1.6 HDI 16v 80kw 9HY	Var.1
 307	CONV. TOP/SUNROO	1.6 HDI 16v 80kw 9HY	Var.2
 307	CONV. TOP/SUNROO	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 307	CONV. TOP/SUNROO	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 307	CONV. TOP/SUNROO	2.0 16v 100kw RFN	Var.1
 307	CONV. TOP/SUNROO	2.0 16v 100kw RFN	Var.2
 307	CONV. TOP/SUNROO	2.0 16v 103kw RFJ	Var.1
 307	CONV. TOP/SUNROO	2.0 16v 103kw RFJ	Var.2
 307	CONV. TOP/SUNROO	2.0 HDI 16v 100kw RHR-FAP	Var.1
 307	CONV. TOP/SUNROO	2.0 HDI 16v 100kw RHR-FAP	Var.2
 307	CONV. TOP/SUNROO	2.0 HDI 16v 66kw RHY	Var.1
 307	CONV. TOP/SUNROO	2.0 HDI 16v 66kw RHY	Var.2
 307	CONV. TOP/SUNROO	2.0 HDI 16v 81kw RHS	Var.1
 307	CONV. TOP/SUNROO	2.0 HDI 16v 81kw RHS	Var.2
 307	DASHBOARD	1.4 16v 66kw KFU	COMBINE
 307	DASHBOARD	1.4 16v 66kw KFU	SAGEM Kombi 1.0
 307	DASHBOARD	1.4 55kw KFW	COMBINE
 307	DASHBOARD	1.4 55kw KFW	SAGEM Kombi 1.0
 307	DASHBOARD	1.4 HDI 50kw 8HZ	COMBINE
 307	DASHBOARD	1.4 HDI 50kw 8HZ	SAGEM Kombi 1.0
 307	DASHBOARD	1.6 16v 82kw NFU	COMBINE
 307	DASHBOARD	1.6 16v 82kw NFU	SAGEM Kombi 1.0
 307	DASHBOARD	1.6 66kw NFZ	COMBINE
 307	DASHBOARD	1.6 66kw NFZ	SAGEM Kombi 1.0
 307	DASHBOARD	1.6 HDI 16v 80kw 9HY	COMBINE
 307	DASHBOARD	1.6 HDI 16v 80kw 9HY	SAGEM Kombi 1.0
 307	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP	COMBINE
 307	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP	SAGEM Kombi 1.0
 307	DASHBOARD	2.0 16v 100kw RFN	COMBINE
 307	DASHBOARD	2.0 16v 100kw RFN	SAGEM Kombi 1.0
 307	DASHBOARD	2.0 16v 103kw RFJ	COMBINE
 307	DASHBOARD	2.0 16v 103kw RFJ	SAGEM Kombi 1.0
 307	DASHBOARD	2.0 HDI 16v 100kw RHR-FAP	COMBINE
 307	DASHBOARD	2.0 HDI 16v 100kw RHR-FAP	SAGEM Kombi 1.0
 307	DASHBOARD	2.0 HDI 16v 66kw RHY	COMBINE
 307	DASHBOARD	2.0 HDI 16v 66kw RHY	SAGEM Kombi 1.0
 307	DASHBOARD	2.0 HDI 16v 81kw RHS	COMBINE
 307	DASHBOARD	2.0 HDI 16v 81kw RHS	SAGEM Kombi 1.0
 307	DIESEL ADDITION	1.6 HDI 16v 80kw 9HZ-FAP	
 307	DIESEL ADDITION	1.6 HDI 16v 80kw 9HZ-FAP	MARWAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 307	DIESEL ADDITION	2.0 HDI 16v 100kw RHR-FAP	
 307	DIESEL ADDITION	2.0 HDI 16v 100kw RHR-FAP	MARWAL
 307	DRIVER SIDE DOOR	1.4 16v 66kw KFU	Marelli MTP CONDUCT
 307	DRIVER SIDE DOOR	1.4 16v 66kw KFU	Var.1
 307	DRIVER SIDE DOOR	1.4 16v 66kw KFU	Var.2
 307	DRIVER SIDE DOOR	1.4 55kw KFW	Marelli MTP CONDUCT
 307	DRIVER SIDE DOOR	1.4 55kw KFW	Var.1
 307	DRIVER SIDE DOOR	1.4 55kw KFW	Var.2
 307	DRIVER SIDE DOOR	1.4 HDI 50kw 8HZ	Marelli MTP CONDUCT
 307	DRIVER SIDE DOOR	1.4 HDI 50kw 8HZ	Var.1
 307	DRIVER SIDE DOOR	1.4 HDI 50kw 8HZ	Var.2
 307	DRIVER SIDE DOOR	1.6 16v 82kw NFU	Marelli MTP CONDUCT
 307	DRIVER SIDE DOOR	1.6 16v 82kw NFU	Var.1
 307	DRIVER SIDE DOOR	1.6 16v 82kw NFU	Var.2
 307	DRIVER SIDE DOOR	1.6 66kw NFZ	Marelli MTP CONDUCT
 307	DRIVER SIDE DOOR	1.6 66kw NFZ	Var.1
 307	DRIVER SIDE DOOR	1.6 66kw NFZ	Var.2
 307	DRIVER SIDE DOOR	1.6 HDI 16v 80kw 9HY	Marelli MTP CONDUCT
 307	DRIVER SIDE DOOR	1.6 HDI 16v 80kw 9HY	Var.1
 307	DRIVER SIDE DOOR	1.6 HDI 16v 80kw 9HY	Var.2
 307	DRIVER SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	Marelli MTP CONDUCT
 307	DRIVER SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 307	DRIVER SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 307	DRIVER SIDE DOOR	2.0 16v 100kw RFN	Marelli MTP CONDUCT
 307	DRIVER SIDE DOOR	2.0 16v 100kw RFN	Var.1
 307	DRIVER SIDE DOOR	2.0 16v 100kw RFN	Var.2
 307	DRIVER SIDE DOOR	2.0 16v 103kw RFJ	Marelli MTP CONDUCT
 307	DRIVER SIDE DOOR	2.0 16v 103kw RFJ	Var.1
 307	DRIVER SIDE DOOR	2.0 16v 103kw RFJ	Var.2
 307	DRIVER SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	Marelli MTP CONDUCT
 307	DRIVER SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	Var.1
 307	DRIVER SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	Var.2
 307	DRIVER SIDE DOOR	2.0 HDI 16v 66kw RHY	Marelli MTP CONDUCT
 307	DRIVER SIDE DOOR	2.0 HDI 16v 66kw RHY	Var.1
 307	DRIVER SIDE DOOR	2.0 HDI 16v 66kw RHY	Var.2
 307	DRIVER SIDE DOOR	2.0 HDI 16v 81kw RHS	Marelli MTP CONDUCT
 307	DRIVER SIDE DOOR	2.0 HDI 16v 81kw RHS	Var.1
 307	DRIVER SIDE DOOR	2.0 HDI 16v 81kw RHS	Var.2
 307	ELECTRIC STEERING	1.4 16v 66kw KFU	Var.1
 307	ELECTRIC STEERING	1.4 16v 66kw KFU	Var.2
 307	ELECTRIC STEERING	1.4 16v 66kw KFU	Var.3
 307	ELECTRIC STEERING	1.4 55kw KFW	Var.1
 307	ELECTRIC STEERING	1.4 55kw KFW	Var.2
 307	ELECTRIC STEERING	1.4 55kw KFW	Var.3
 307	ELECTRIC STEERING	1.4 HDI 50kw 8HZ	Var.1
 307	ELECTRIC STEERING	1.4 HDI 50kw 8HZ	Var.2
 307	ELECTRIC STEERING	1.4 HDI 50kw 8HZ	Var.3
 307	ELECTRIC STEERING	1.6 16v 82kw NFU	Var.1
 307	ELECTRIC STEERING	1.6 16v 82kw NFU	Var.2
 307	ELECTRIC STEERING	1.6 16v 82kw NFU	Var.3
 307	ELECTRIC STEERING	1.6 66kw NFZ	Var.1
 307	ELECTRIC STEERING	1.6 66kw NFZ	Var.2
 307	ELECTRIC STEERING	1.6 66kw NFZ	Var.3
 307	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HY	Var.1
 307	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HY	Var.2
 307	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HY	Var.3
 307	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 307	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	Var.2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 307	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	Var.3
 307	ELECTRIC STEERING	2.0 16v 100kw RFN	Var.1
 307	ELECTRIC STEERING	2.0 16v 100kw RFN	Var.2
 307	ELECTRIC STEERING	2.0 16v 100kw RFN	Var.3
 307	ELECTRIC STEERING	2.0 16v 103kw RFJ	Var.1
 307	ELECTRIC STEERING	2.0 16v 103kw RFJ	Var.2
 307	ELECTRIC STEERING	2.0 16v 103kw RFJ	Var.3
 307	ELECTRIC STEERING	2.0 HDI 16v 100kw RHR-FAP	Var.1
 307	ELECTRIC STEERING	2.0 HDI 16v 100kw RHR-FAP	Var.2
 307	ELECTRIC STEERING	2.0 HDI 16v 100kw RHR-FAP	Var.3
 307	ELECTRIC STEERING	2.0 HDI 16v 66kw RHY	Var.1
 307	ELECTRIC STEERING	2.0 HDI 16v 66kw RHY	Var.2
 307	ELECTRIC STEERING	2.0 HDI 16v 66kw RHY	Var.3
 307	ELECTRIC STEERING	2.0 HDI 16v 81kw RHS	Var.1
 307	ELECTRIC STEERING	2.0 HDI 16v 81kw RHS	Var.2
 307	ELECTRIC STEERING	2.0 HDI 16v 81kw RHS	Var.3
 307	ENGINE MANAGEME	1.4 16v 66kw KFU (01-..)	EOBD
 307	ENGINE MANAGEME	1.4 55kw KFW	SAGEM S2000
 307	ENGINE MANAGEME	1.4 55kw KFW	SAGEM S2000
 307	ENGINE MANAGEME	1.4 55kw KFW (01-..)	EOBD
 307	ENGINE MANAGEME	1.4 HDI 50kw 8HZ	BOSCH EDC 16 C34 Common Rail
 307	ENGINE MANAGEME	1.4 HDI 50kw 8HZ (01-..)	EOBD
 307	ENGINE MANAGEME	1.4 HDI 50kw 8HZ (02-..)	BOSCH EDC 16 C3 Common Rail
 307	ENGINE MANAGEME	1.6 16v 82kw NFU	BOSCH ME 7.4.4
 307	ENGINE MANAGEME	1.6 16v 82kw NFU	BOSCH Motronic ME7.4.4
 307	ENGINE MANAGEME	1.6 16v 82kw NFU (01-..)	EOBD
 307	ENGINE MANAGEME	1.6 66kw NFZ	BOSCH ME 7.4.4
 307	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HY (01-..)	EOBD
 307	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP (01-..)	EOBD
 307	ENGINE MANAGEME	2.0 16v 100kw RFN	Marelli MM48P
 307	ENGINE MANAGEME	2.0 16v 100kw RFN	Marelli MM4MP2
 307	ENGINE MANAGEME	2.0 16v 100kw RFN	Marelli MM6LP
 307	ENGINE MANAGEME	2.0 16v 100kw RFN (01-..)	EOBD
 307	ENGINE MANAGEME	2.0 16v 103kw RFJ	Marelli MM48P
 307	ENGINE MANAGEME	2.0 16v 103kw RFJ	Marelli MM4MP2
 307	ENGINE MANAGEME	2.0 16v 103kw RFJ	Marelli MM6LP
 307	ENGINE MANAGEME	2.0 16v 103kw RFJ (01-..)	EOBD
 307	ENGINE MANAGEME	2.0 HDI 16v 100kw RHR-FAP	BOSCH EDC 15 C2 Common Rail
 307	ENGINE MANAGEME	2.0 HDI 16v 100kw RHR-FAP	BOSCH EDC 15 C2 Common Rail FAP
 307	ENGINE MANAGEME	2.0 HDI 16v 100kw RHR-FAP (01-..)	EOBD
 307	ENGINE MANAGEME	2.0 HDI 16v 66kw RHY	BOSCH EDC 15 C2 Common Rail
 307	ENGINE MANAGEME	2.0 HDI 16v 66kw RHY	BOSCH EDC 15 C2 Common Rail DIE29
 307	ENGINE MANAGEME	2.0 HDI 16v 66kw RHY	SIEMENS Diesel SID 801 Common Rail
 307	ENGINE MANAGEME	2.0 HDI 16v 66kw RHY	SIEMENS SID 801 Common Rail
 307	ENGINE MANAGEME	2.0 HDI 16v 66kw RHY (01-..)	EOBD
 307	ENGINE MANAGEME	2.0 HDI 16v 66kw RHY (03-..)	BOSCH EDC 15 C2 Common Rail
 307	ENGINE MANAGEME	2.0 HDI 16v 81kw RHS	BOSCH EDC 15 C2 Common Rail
 307	ENGINE MANAGEME	2.0 HDI 16v 81kw RHS	BOSCH EDC 15 C2 Common Rail FAP
 307	ENGINE MANAGEME	2.0 HDI 16v 81kw RHS (01-..)	EOBD
 307	KEY ENCODE	1.4 16v 66kw KFU (02-..)	VALEO Body Siemens
 307	KEY ENCODE	1.4 55kw KFW (02-..)	VALEO Body Siemens
 307	KEY ENCODE	1.4 HDI 50kw 8HZ (02-..)	VALEO Body Siemens
 307	KEY ENCODE	1.6 16v 82kw NFU (02-..)	VALEO Body Siemens
 307	KEY ENCODE	1.6 66kw NFZ (02-..)	VALEO Body Siemens
 307	KEY ENCODE	1.6 HDI 16v 80kw 9HY (02-..)	VALEO Body Siemens
 307	KEY ENCODE	1.6 HDI 16v 80kw 9HZ-FAP (02-..)	VALEO Body Siemens
 307	KEY ENCODE	2.0 16v 100kw RFN (02-..)	VALEO Body Siemens
 307	KEY ENCODE	2.0 16v 103kw RFJ (02-..)	VALEO Body Siemens

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 307	KEY ENCODE	2.0 HDI 16v 100kw RHR-FAP (02-..)	VALEO Body Siemens
 307	KEY ENCODE	2.0 HDI 16v 66kw RHY (02-..)	VALEO Body Siemens
 307	KEY ENCODE	2.0 HDI 16v 81kw RHS (02-..)	VALEO Body Siemens
 307	MAINTENANCE	1.4 16v 66kw KFU	Body Computer BSI
 307	MAINTENANCE	1.4 16v 66kw KFU	BOSCH ESP 5.7
 307	MAINTENANCE	1.4 16v 66kw KFU	BOSCH ESP 5.7
 307	MAINTENANCE	1.4 16v 66kw KFU	COMBINE
 307	MAINTENANCE	1.4 16v 66kw KFU	COMBINE
 307	MAINTENANCE	1.4 16v 66kw KFU	SAGEM Kombi 1.0
 307	MAINTENANCE	1.4 16v 66kw KFU	TEVES ABS MK60
 307	MAINTENANCE	1.4 16v 66kw KFU	Var.1
 307	MAINTENANCE	1.4 16v 66kw KFU	Var.1
 307	MAINTENANCE	1.4 16v 66kw KFU	Var.2
 307	MAINTENANCE	1.4 16v 66kw KFU	Var.2
 307	MAINTENANCE	1.4 16v 66kw KFU (..-01)	VDO MANUAL
 307	MAINTENANCE	1.4 16v 66kw KFU (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.4 16v 66kw KFU (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.4 16v 66kw KFU (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.4 16v 66kw KFU (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.4 16v 66kw KFU (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.4 55kw KFW	Body Computer BSI
 307	MAINTENANCE	1.4 55kw KFW	BOSCH ESP 5.7
 307	MAINTENANCE	1.4 55kw KFW	BOSCH ESP 5.7
 307	MAINTENANCE	1.4 55kw KFW	COMBINE
 307	MAINTENANCE	1.4 55kw KFW	COMBINE
 307	MAINTENANCE	1.4 55kw KFW	SAGEM Kombi 1.0
 307	MAINTENANCE	1.4 55kw KFW	TEVES ABS MK60
 307	MAINTENANCE	1.4 55kw KFW	Var.1
 307	MAINTENANCE	1.4 55kw KFW	Var.1
 307	MAINTENANCE	1.4 55kw KFW	Var.2
 307	MAINTENANCE	1.4 55kw KFW	Var.2
 307	MAINTENANCE	1.4 55kw KFW (..-01)	VDO MANUAL
 307	MAINTENANCE	1.4 55kw KFW (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.4 55kw KFW (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.4 55kw KFW (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.4 55kw KFW (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.4 55kw KFW (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.4 HDI 50kw 8HZ	Body Computer BSI
 307	MAINTENANCE	1.4 HDI 50kw 8HZ	BOSCH ESP 5.7
 307	MAINTENANCE	1.4 HDI 50kw 8HZ	BOSCH ESP 5.7
 307	MAINTENANCE	1.4 HDI 50kw 8HZ	COMBINE
 307	MAINTENANCE	1.4 HDI 50kw 8HZ	COMBINE
 307	MAINTENANCE	1.4 HDI 50kw 8HZ	SAGEM Kombi 1.0
 307	MAINTENANCE	1.4 HDI 50kw 8HZ	TEVES ABS MK60
 307	MAINTENANCE	1.4 HDI 50kw 8HZ	Var.1
 307	MAINTENANCE	1.4 HDI 50kw 8HZ	Var.1
 307	MAINTENANCE	1.4 HDI 50kw 8HZ	Var.2
 307	MAINTENANCE	1.4 HDI 50kw 8HZ	Var.2
 307	MAINTENANCE	1.4 HDI 50kw 8HZ (..-01)	VDO MANUAL
 307	MAINTENANCE	1.4 HDI 50kw 8HZ (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.4 HDI 50kw 8HZ (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.4 HDI 50kw 8HZ (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.4 HDI 50kw 8HZ (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.4 HDI 50kw 8HZ (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.6 16v 82kw NFU	Body Computer BSI
 307	MAINTENANCE	1.6 16v 82kw NFU	BOSCH ESP 5.7
 307	MAINTENANCE	1.6 16v 82kw NFU	BOSCH ESP 5.7
 307	MAINTENANCE	1.6 16v 82kw NFU	COMBINE

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 307	MAINTENANCE	1.6 16v 82kw NFU	COMBINE
 307	MAINTENANCE	1.6 16v 82kw NFU	SAGEM Kombi 1.0
 307	MAINTENANCE	1.6 16v 82kw NFU	TEVES ABS MK60
 307	MAINTENANCE	1.6 16v 82kw NFU	Var.1
 307	MAINTENANCE	1.6 16v 82kw NFU	Var.1
 307	MAINTENANCE	1.6 16v 82kw NFU	Var.2
 307	MAINTENANCE	1.6 16v 82kw NFU	Var.2
 307	MAINTENANCE	1.6 16v 82kw NFU (...01)	VDO MANUAL
 307	MAINTENANCE	1.6 16v 82kw NFU (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.6 16v 82kw NFU (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.6 16v 82kw NFU (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.6 16v 82kw NFU (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.6 16v 82kw NFU (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.6 66kw NFZ	Body Computer BSI
 307	MAINTENANCE	1.6 66kw NFZ	BOSCH ESP 5.7
 307	MAINTENANCE	1.6 66kw NFZ	BOSCH ESP 5.7
 307	MAINTENANCE	1.6 66kw NFZ	COMBINE
 307	MAINTENANCE	1.6 66kw NFZ	COMBINE
 307	MAINTENANCE	1.6 66kw NFZ	SAGEM Kombi 1.0
 307	MAINTENANCE	1.6 66kw NFZ	TEVES ABS MK60
 307	MAINTENANCE	1.6 66kw NFZ	Var.1
 307	MAINTENANCE	1.6 66kw NFZ	Var.1
 307	MAINTENANCE	1.6 66kw NFZ	Var.2
 307	MAINTENANCE	1.6 66kw NFZ	Var.2
 307	MAINTENANCE	1.6 66kw NFZ (...01)	VDO MANUAL
 307	MAINTENANCE	1.6 66kw NFZ (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.6 66kw NFZ (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.6 66kw NFZ (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.6 66kw NFZ (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.6 66kw NFZ (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Body Computer BSI
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH ESP 5.7
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH ESP 5.7
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HY	COMBINE
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HY	COMBINE
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HY	SAGEM Kombi 1.0
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HY	TEVES ABS MK60
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.1
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.1
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.2
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.2
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HY (...01)	VDO MANUAL
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HY (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HY (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HY (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HY (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HY (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSI
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ESP 5.7
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ESP 5.7
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	COMBINE
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	COMBINE
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	MARWAL
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	MARWAL
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	SAGEM Kombi 1.0
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	TEVES ABS MK60
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (...01)	VDO MANUAL
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	2.0 16v 100kw RFN	Body Computer BSI
 307	MAINTENANCE	2.0 16v 100kw RFN	BOSCH ESP 5.7
 307	MAINTENANCE	2.0 16v 100kw RFN	BOSCH ESP 5.7
 307	MAINTENANCE	2.0 16v 100kw RFN	COMBINE
 307	MAINTENANCE	2.0 16v 100kw RFN	COMBINE
 307	MAINTENANCE	2.0 16v 100kw RFN	SAGEM Kombi 1.0
 307	MAINTENANCE	2.0 16v 100kw RFN	TEVES ABS MK60
 307	MAINTENANCE	2.0 16v 100kw RFN	Var.1
 307	MAINTENANCE	2.0 16v 100kw RFN	Var.1
 307	MAINTENANCE	2.0 16v 100kw RFN	Var.2
 307	MAINTENANCE	2.0 16v 100kw RFN	Var.2
 307	MAINTENANCE	2.0 16v 100kw RFN (...01)	VDO MANUAL
 307	MAINTENANCE	2.0 16v 100kw RFN (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	2.0 16v 100kw RFN (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	2.0 16v 100kw RFN (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	2.0 16v 100kw RFN (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	2.0 16v 100kw RFN (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	2.0 16v 103kw RFJ	Body Computer BSI
 307	MAINTENANCE	2.0 16v 103kw RFJ	BOSCH ESP 5.7
 307	MAINTENANCE	2.0 16v 103kw RFJ	BOSCH ESP 5.7
 307	MAINTENANCE	2.0 16v 103kw RFJ	COMBINE
 307	MAINTENANCE	2.0 16v 103kw RFJ	COMBINE
 307	MAINTENANCE	2.0 16v 103kw RFJ	SAGEM Kombi 1.0
 307	MAINTENANCE	2.0 16v 103kw RFJ	TEVES ABS MK60
 307	MAINTENANCE	2.0 16v 103kw RFJ	Var.1
 307	MAINTENANCE	2.0 16v 103kw RFJ	Var.1
 307	MAINTENANCE	2.0 16v 103kw RFJ	Var.2
 307	MAINTENANCE	2.0 16v 103kw RFJ	Var.2
 307	MAINTENANCE	2.0 16v 103kw RFJ (...01)	VDO MANUAL
 307	MAINTENANCE	2.0 16v 103kw RFJ (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	2.0 16v 103kw RFJ (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	2.0 16v 103kw RFJ (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	2.0 16v 103kw RFJ (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	2.0 16v 103kw RFJ (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Body Computer BSI
 307	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	BOSCH EDC 15 C2 Common Rail
 307	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	BOSCH ESP 5.7
 307	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	BOSCH ESP 5.7
 307	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	COMBINE
 307	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	COMBINE
 307	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	MARWAL
 307	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	MARWAL
 307	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SAGEM Kombi 1.0
 307	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	TEVES ABS MK60
 307	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.1
 307	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.1
 307	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.2
 307	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.2
 307	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (...01)	VDO MANUAL
 307	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (02-..)	BOSCH ABS/ESP 5.7

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 307	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	2.0 HDI 16v 66kw RHY	Body Computer BSI
 307	MAINTENANCE	2.0 HDI 16v 66kw RHY	BOSCH EDC 15 C2 Common Rail
 307	MAINTENANCE	2.0 HDI 16v 66kw RHY	BOSCH EDC 15 C2 Common Rail DIE29
 307	MAINTENANCE	2.0 HDI 16v 66kw RHY	BOSCH ESP 5.7
 307	MAINTENANCE	2.0 HDI 16v 66kw RHY	BOSCH ESP 5.7
 307	MAINTENANCE	2.0 HDI 16v 66kw RHY	COMBINE
 307	MAINTENANCE	2.0 HDI 16v 66kw RHY	COMBINE
 307	MAINTENANCE	2.0 HDI 16v 66kw RHY	SAGEM Kombi 1.0
 307	MAINTENANCE	2.0 HDI 16v 66kw RHY	TEVES ABS MK60
 307	MAINTENANCE	2.0 HDI 16v 66kw RHY	Var.1
 307	MAINTENANCE	2.0 HDI 16v 66kw RHY	Var.1
 307	MAINTENANCE	2.0 HDI 16v 66kw RHY	Var.2
 307	MAINTENANCE	2.0 HDI 16v 66kw RHY	Var.2
 307	MAINTENANCE	2.0 HDI 16v 66kw RHY (...01)	VDO MANUAL
 307	MAINTENANCE	2.0 HDI 16v 66kw RHY (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	2.0 HDI 16v 66kw RHY (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	2.0 HDI 16v 66kw RHY (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	2.0 HDI 16v 66kw RHY (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	2.0 HDI 16v 66kw RHY (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	2.0 HDI 16v 66kw RHY (03-..)	BOSCH EDC 15 C2 Common Rail
 307	MAINTENANCE	2.0 HDI 16v 81kw RHS	Body Computer BSI
 307	MAINTENANCE	2.0 HDI 16v 81kw RHS	BOSCH EDC 15 C2 Common Rail FAP
 307	MAINTENANCE	2.0 HDI 16v 81kw RHS	BOSCH ESP 5.7
 307	MAINTENANCE	2.0 HDI 16v 81kw RHS	BOSCH ESP 5.7
 307	MAINTENANCE	2.0 HDI 16v 81kw RHS	COMBINE
 307	MAINTENANCE	2.0 HDI 16v 81kw RHS	COMBINE
 307	MAINTENANCE	2.0 HDI 16v 81kw RHS	SAGEM Kombi 1.0
 307	MAINTENANCE	2.0 HDI 16v 81kw RHS	TEVES ABS MK60
 307	MAINTENANCE	2.0 HDI 16v 81kw RHS	Var.1
 307	MAINTENANCE	2.0 HDI 16v 81kw RHS	Var.1
 307	MAINTENANCE	2.0 HDI 16v 81kw RHS	Var.2
 307	MAINTENANCE	2.0 HDI 16v 81kw RHS	Var.2
 307	MAINTENANCE	2.0 HDI 16v 81kw RHS (...01)	VDO MANUAL
 307	MAINTENANCE	2.0 HDI 16v 81kw RHS (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	2.0 HDI 16v 81kw RHS (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	2.0 HDI 16v 81kw RHS (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	2.0 HDI 16v 81kw RHS (02-..)	BOSCH ABS/ESP 5.7
 307	MAINTENANCE	2.0 HDI 16v 81kw RHS (02-..)	BOSCH ABS/ESP 5.7
 307	NAVIGATION	1.4 16v 66kw KFU	
 307	NAVIGATION	1.4 55kw KFW	
 307	NAVIGATION	1.4 HDI 50kw 8HZ	
 307	NAVIGATION	1.6 16v 82kw NFU	
 307	NAVIGATION	1.6 66kw NFZ	
 307	NAVIGATION	1.6 HDI 16v 80kw 9HY	
 307	NAVIGATION	1.6 HDI 16v 80kw 9HZ-FAP	
 307	NAVIGATION	2.0 16v 100kw RFN	
 307	NAVIGATION	2.0 16v 103kw RFJ	
 307	NAVIGATION	2.0 HDI 16v 100kw RHR-FAP	
 307	NAVIGATION	2.0 HDI 16v 66kw RHY	
 307	NAVIGATION	2.0 HDI 16v 81kw RHS	
 307	PASS. SIDE DOOR	1.4 16v 66kw KFU	Marelli MTP PASS
 307	PASS. SIDE DOOR	1.4 16v 66kw KFU	Var.1
 307	PASS. SIDE DOOR	1.4 16v 66kw KFU	Var.2
 307	PASS. SIDE DOOR	1.4 55kw KFW	Marelli MTP PASS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 307	PASS. SIDE DOOR	1.4 55kw KFW	Var.1
 307	PASS. SIDE DOOR	1.4 55kw KFW	Var.2
 307	PASS. SIDE DOOR	1.4 HDI 50kw 8HZ	Marelli MTP PASS
 307	PASS. SIDE DOOR	1.4 HDI 50kw 8HZ	Var.1
 307	PASS. SIDE DOOR	1.4 HDI 50kw 8HZ	Var.2
 307	PASS. SIDE DOOR	1.6 16v 82kw NFU	Marelli MTP PASS
 307	PASS. SIDE DOOR	1.6 16v 82kw NFU	Var.1
 307	PASS. SIDE DOOR	1.6 16v 82kw NFU	Var.2
 307	PASS. SIDE DOOR	1.6 66kw NFZ	Marelli MTP PASS
 307	PASS. SIDE DOOR	1.6 66kw NFZ	Var.1
 307	PASS. SIDE DOOR	1.6 66kw NFZ	Var.2
 307	PASS. SIDE DOOR	1.6 HDI 16v 80kw 9HY	Marelli MTP PASS
 307	PASS. SIDE DOOR	1.6 HDI 16v 80kw 9HY	Var.1
 307	PASS. SIDE DOOR	1.6 HDI 16v 80kw 9HY	Var.2
 307	PASS. SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	Marelli MTP PASS
 307	PASS. SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 307	PASS. SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 307	PASS. SIDE DOOR	2.0 16v 100kw RFN	Marelli MTP PASS
 307	PASS. SIDE DOOR	2.0 16v 100kw RFN	Var.1
 307	PASS. SIDE DOOR	2.0 16v 100kw RFN	Var.2
 307	PASS. SIDE DOOR	2.0 16v 103kw RFJ	Marelli MTP PASS
 307	PASS. SIDE DOOR	2.0 16v 103kw RFJ	Var.1
 307	PASS. SIDE DOOR	2.0 16v 103kw RFJ	Var.2
 307	PASS. SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	Marelli MTP PASS
 307	PASS. SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	Var.1
 307	PASS. SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	Var.2
 307	PASS. SIDE DOOR	2.0 HDI 16v 66kw RHY	Marelli MTP PASS
 307	PASS. SIDE DOOR	2.0 HDI 16v 66kw RHY	Var.1
 307	PASS. SIDE DOOR	2.0 HDI 16v 66kw RHY	Var.2
 307	PASS. SIDE DOOR	2.0 HDI 16v 81kw RHS	Marelli MTP PASS
 307	PASS. SIDE DOOR	2.0 HDI 16v 81kw RHS	Var.1
 307	PASS. SIDE DOOR	2.0 HDI 16v 81kw RHS	Var.2
 307	RADIO / CD	1.4 16v 66kw KFU	Var.1
 307	RADIO / CD	1.4 16v 66kw KFU	Var.2
 307	RADIO / CD	1.4 16v 66kw KFU	Var.3
 307	RADIO / CD	1.4 16v 66kw KFU	Var.4
 307	RADIO / CD	1.4 16v 66kw KFU (02-..)	CLARION AudioSystem
 307	RADIO / CD	1.4 16v 66kw KFU (02-..)	PHILIPS AudioSystem
 307	RADIO / CD	1.4 16v 66kw KFU (02-..)	VDO AudioSystem
 307	RADIO / CD	1.4 55kw KFW	Var.1
 307	RADIO / CD	1.4 55kw KFW	Var.2
 307	RADIO / CD	1.4 55kw KFW	Var.3
 307	RADIO / CD	1.4 55kw KFW	Var.4
 307	RADIO / CD	1.4 55kw KFW (02-..)	CLARION AudioSystem
 307	RADIO / CD	1.4 55kw KFW (02-..)	PHILIPS AudioSystem
 307	RADIO / CD	1.4 55kw KFW (02-..)	VDO AudioSystem
 307	RADIO / CD	1.4 HDI 50kw 8HZ	Var.1
 307	RADIO / CD	1.4 HDI 50kw 8HZ	Var.2
 307	RADIO / CD	1.4 HDI 50kw 8HZ	Var.3
 307	RADIO / CD	1.4 HDI 50kw 8HZ	Var.4
 307	RADIO / CD	1.4 HDI 50kw 8HZ (02-..)	CLARION AudioSystem
 307	RADIO / CD	1.4 HDI 50kw 8HZ (02-..)	PHILIPS AudioSystem
 307	RADIO / CD	1.4 HDI 50kw 8HZ (02-..)	VDO AudioSystem
 307	RADIO / CD	1.6 16v 82kw NFU	Var.1
 307	RADIO / CD	1.6 16v 82kw NFU	Var.2
 307	RADIO / CD	1.6 16v 82kw NFU	Var.3
 307	RADIO / CD	1.6 16v 82kw NFU	Var.4
 307	RADIO / CD	1.6 16v 82kw NFU (02-..)	CLARION AudioSystem

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 307	RADIO / CD	1.6 16v 82kw NFU (02-..)	PHILIPS AudioSystem
 307	RADIO / CD	1.6 16v 82kw NFU (02-..)	VDO AudioSystem
 307	RADIO / CD	1.6 66kw NFZ	Var.1
 307	RADIO / CD	1.6 66kw NFZ	Var.2
 307	RADIO / CD	1.6 66kw NFZ	Var.3
 307	RADIO / CD	1.6 66kw NFZ	Var.4
 307	RADIO / CD	1.6 66kw NFZ (02-..)	CLARION AudioSystem
 307	RADIO / CD	1.6 66kw NFZ (02-..)	PHILIPS AudioSystem
 307	RADIO / CD	1.6 66kw NFZ (02-..)	VDO AudioSystem
 307	RADIO / CD	1.6 HDI 16v 80kw 9HY	Var.1
 307	RADIO / CD	1.6 HDI 16v 80kw 9HY	Var.2
 307	RADIO / CD	1.6 HDI 16v 80kw 9HY	Var.3
 307	RADIO / CD	1.6 HDI 16v 80kw 9HY	Var.4
 307	RADIO / CD	1.6 HDI 16v 80kw 9HY (02-..)	CLARION AudioSystem
 307	RADIO / CD	1.6 HDI 16v 80kw 9HY (02-..)	PHILIPS AudioSystem
 307	RADIO / CD	1.6 HDI 16v 80kw 9HY (02-..)	VDO AudioSystem
 307	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 307	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 307	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Var.3
 307	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Var.4
 307	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP (02-..)	CLARION AudioSystem
 307	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP (02-..)	PHILIPS AudioSystem
 307	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP (02-..)	VDO AudioSystem
 307	RADIO / CD	2.0 16v 100kw RFN	Var.1
 307	RADIO / CD	2.0 16v 100kw RFN	Var.2
 307	RADIO / CD	2.0 16v 100kw RFN	Var.3
 307	RADIO / CD	2.0 16v 100kw RFN	Var.4
 307	RADIO / CD	2.0 16v 100kw RFN (02-..)	CLARION AudioSystem
 307	RADIO / CD	2.0 16v 100kw RFN (02-..)	PHILIPS AudioSystem
 307	RADIO / CD	2.0 16v 100kw RFN (02-..)	VDO AudioSystem
 307	RADIO / CD	2.0 16v 103kw RFJ	Var.1
 307	RADIO / CD	2.0 16v 103kw RFJ	Var.2
 307	RADIO / CD	2.0 16v 103kw RFJ	Var.3
 307	RADIO / CD	2.0 16v 103kw RFJ	Var.4
 307	RADIO / CD	2.0 16v 103kw RFJ (02-..)	CLARION AudioSystem
 307	RADIO / CD	2.0 16v 103kw RFJ (02-..)	PHILIPS AudioSystem
 307	RADIO / CD	2.0 16v 103kw RFJ (02-..)	VDO AudioSystem
 307	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP	Var.1
 307	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP	Var.2
 307	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP	Var.3
 307	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP	Var.4
 307	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP (02-..)	CLARION AudioSystem
 307	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP (02-..)	PHILIPS AudioSystem
 307	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP (02-..)	VDO AudioSystem
 307	RADIO / CD	2.0 HDI 16v 66kw RHY	Var.1
 307	RADIO / CD	2.0 HDI 16v 66kw RHY	Var.2
 307	RADIO / CD	2.0 HDI 16v 66kw RHY	Var.3
 307	RADIO / CD	2.0 HDI 16v 66kw RHY	Var.4
 307	RADIO / CD	2.0 HDI 16v 66kw RHY (02-..)	CLARION AudioSystem
 307	RADIO / CD	2.0 HDI 16v 66kw RHY (02-..)	PHILIPS AudioSystem
 307	RADIO / CD	2.0 HDI 16v 66kw RHY (02-..)	VDO AudioSystem
 307	RADIO / CD	2.0 HDI 16v 81kw RHS	Var.1
 307	RADIO / CD	2.0 HDI 16v 81kw RHS	Var.2
 307	RADIO / CD	2.0 HDI 16v 81kw RHS	Var.3
 307	RADIO / CD	2.0 HDI 16v 81kw RHS	Var.4
 307	RADIO / CD	2.0 HDI 16v 81kw RHS (02-..)	CLARION AudioSystem
 307	RADIO / CD	2.0 HDI 16v 81kw RHS (02-..)	PHILIPS AudioSystem
 307	RADIO / CD	2.0 HDI 16v 81kw RHS (02-..)	VDO AudioSystem

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 307	RAIN-LUMINOSITY S	1.4 16v 66kw KFU	Var.1
 307	RAIN-LUMINOSITY S	1.4 16v 66kw KFU	Var.2
 307	RAIN-LUMINOSITY S	1.4 55kw KFW	Var.1
 307	RAIN-LUMINOSITY S	1.4 55kw KFW	Var.2
 307	RAIN-LUMINOSITY S	1.4 HDI 50kw 8HZ	Var.1
 307	RAIN-LUMINOSITY S	1.4 HDI 50kw 8HZ	Var.2
 307	RAIN-LUMINOSITY S	1.6 16v 82kw NFU	Var.1
 307	RAIN-LUMINOSITY S	1.6 16v 82kw NFU	Var.2
 307	RAIN-LUMINOSITY S	1.6 66kw NFZ	Var.1
 307	RAIN-LUMINOSITY S	1.6 66kw NFZ	Var.2
 307	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HY	Var.1
 307	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HY	Var.2
 307	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 307	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 307	RAIN-LUMINOSITY S	2.0 16v 100kw RFN	Var.1
 307	RAIN-LUMINOSITY S	2.0 16v 100kw RFN	Var.2
 307	RAIN-LUMINOSITY S	2.0 16v 103kw RFJ	Var.1
 307	RAIN-LUMINOSITY S	2.0 16v 103kw RFJ	Var.2
 307	RAIN-LUMINOSITY S	2.0 HDI 16v 100kw RHR-FAP	Var.1
 307	RAIN-LUMINOSITY S	2.0 HDI 16v 100kw RHR-FAP	Var.2
 307	RAIN-LUMINOSITY S	2.0 HDI 16v 66kw RHY	Var.1
 307	RAIN-LUMINOSITY S	2.0 HDI 16v 66kw RHY	Var.2
 307	RAIN-LUMINOSITY S	2.0 HDI 16v 81kw RHS	Var.1
 307	RAIN-LUMINOSITY S	2.0 HDI 16v 81kw RHS	Var.2
 307	SERVICE LIGHT RES	1.4 16v 66kw KFU (...01)	VDO MANUAL
 307	SERVICE LIGHT RES	1.4 55kw KFW (...01)	VDO MANUAL
 307	SERVICE LIGHT RES	1.4 HDI 50kw 8HZ (...01)	VDO MANUAL
 307	SERVICE LIGHT RES	1.6 16v 82kw NFU (...01)	VDO MANUAL
 307	SERVICE LIGHT RES	1.6 66kw NFZ (...01)	VDO MANUAL
 307	SERVICE LIGHT RES	1.6 HDI 16v 80kw 9HY (...01)	VDO MANUAL
 307	SERVICE LIGHT RES	1.6 HDI 16v 80kw 9HZ-FAP (...01)	VDO MANUAL
 307	SERVICE LIGHT RES	2.0 16v 100kw RFN (...01)	VDO MANUAL
 307	SERVICE LIGHT RES	2.0 16v 103kw RFJ (...01)	VDO MANUAL
 307	SERVICE LIGHT RES	2.0 HDI 16v 100kw RHR-FAP (...01)	VDO MANUAL
 307	SERVICE LIGHT RES	2.0 HDI 16v 66kw RHY (...01)	VDO MANUAL
 307	SERVICE LIGHT RES	2.0 HDI 16v 81kw RHS (...01)	VDO MANUAL
 307	STEERING COLUMN	1.4 16v 66kw KFU	
 307	STEERING COLUMN	1.4 55kw KFW	
 307	STEERING COLUMN	1.4 HDI 50kw 8HZ	
 307	STEERING COLUMN	1.6 16v 82kw NFU	
 307	STEERING COLUMN	1.6 66kw NFZ	
 307	STEERING COLUMN	1.6 HDI 16v 80kw 9HY	
 307	STEERING COLUMN	1.6 HDI 16v 80kw 9HZ-FAP	
 307	STEERING COLUMN	2.0 16v 100kw RFN	
 307	STEERING COLUMN	2.0 16v 103kw RFJ	
 307	STEERING COLUMN	2.0 HDI 16v 100kw RHR-FAP	
 307	STEERING COLUMN	2.0 HDI 16v 66kw RHY	
 307	STEERING COLUMN	2.0 HDI 16v 81kw RHS	
 307	SWITCHLIGHT MODU	1.4 16v 66kw KFU	EATON
 307	SWITCHLIGHT MODU	1.4 55kw KFW	EATON
 307	SWITCHLIGHT MODU	1.4 HDI 50kw 8HZ	EATON
 307	SWITCHLIGHT MODU	1.6 16v 82kw NFU	EATON
 307	SWITCHLIGHT MODU	1.6 66kw NFZ	EATON
 307	SWITCHLIGHT MODU	1.6 HDI 16v 80kw 9HY	EATON
 307	SWITCHLIGHT MODU	1.6 HDI 16v 80kw 9HZ-FAP	EATON
 307	SWITCHLIGHT MODU	2.0 16v 100kw RFN	EATON
 307	SWITCHLIGHT MODU	2.0 16v 103kw RFJ	EATON
 307	SWITCHLIGHT MODU	2.0 HDI 16v 100kw RHR-FAP	EATON

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 307	SWITCHLIGHT MODU	2.0 HDI 16v 66kw RHY	EATON
 307	SWITCHLIGHT MODU	2.0 HDI 16v 81kw RHS	EATON
 307	VISUAL./TELEMATIC	1.4 16v 66kw KFU	Display
 307	VISUAL./TELEMATIC	1.4 16v 66kw KFU	SAGEM JCAE
 307	VISUAL./TELEMATIC	1.4 55kw KFW	Display
 307	VISUAL./TELEMATIC	1.4 55kw KFW	SAGEM JCAE
 307	VISUAL./TELEMATIC	1.4 HDI 50kw 8HZ	Display
 307	VISUAL./TELEMATIC	1.4 HDI 50kw 8HZ	SAGEM JCAE
 307	VISUAL./TELEMATIC	1.6 16v 82kw NFU	Display
 307	VISUAL./TELEMATIC	1.6 16v 82kw NFU	SAGEM JCAE
 307	VISUAL./TELEMATIC	1.6 66kw NFZ	Display
 307	VISUAL./TELEMATIC	1.6 66kw NFZ	SAGEM JCAE
 307	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HY	Display
 307	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HY	SAGEM JCAE
 307	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	Display
 307	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	SAGEM JCAE
 307	VISUAL./TELEMATIC	2.0 16v 100kw RFN	Display
 307	VISUAL./TELEMATIC	2.0 16v 100kw RFN	SAGEM JCAE
 307	VISUAL./TELEMATIC	2.0 16v 103kw RFJ	Display
 307	VISUAL./TELEMATIC	2.0 16v 103kw RFJ	SAGEM JCAE
 307	VISUAL./TELEMATIC	2.0 HDI 16v 100kw RHR-FAP	Display
 307	VISUAL./TELEMATIC	2.0 HDI 16v 100kw RHR-FAP	SAGEM JCAE
 307	VISUAL./TELEMATIC	2.0 HDI 16v 66kw RHY	Display
 307	VISUAL./TELEMATIC	2.0 HDI 16v 66kw RHY	SAGEM JCAE
 307	VISUAL./TELEMATIC	2.0 HDI 16v 81kw RHS	Display
 307	VISUAL./TELEMATIC	2.0 HDI 16v 81kw RHS	SAGEM JCAE
 308	ABS + TRACT. CONT	1.4 16v 70kw 8FS	
 308	ABS + TRACT. CONT	1.6 16v 80kw NFU	
 308	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HV-FAP	
 308	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX	
 308	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	
 308	ABS + TRACT. CONT	1.6 THP 16v 103kw 5FT	
 308	ABS + TRACT. CONT	1.6 THP 16v 110kw 5FX	
 308	ABS + TRACT. CONT	1.6 THP 16v 128kw 5FY	
 308	ABS + TRACT. CONT	1.6 THP 16v 88kw 5FW	
 308	ABS + TRACT. CONT	2.0 16v 103kw RFJ	
 308	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHF	
 308	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP	
 308	ABS + TRACT. CONT	2.0 HDI 16v 103kw RHF	
 308	AIRBAG	1.4 16v 70kw 8FS	
 308	AIRBAG	1.4 16v 70kw 8FS	
 308	AIRBAG	1.6 16v 80kw NFU	
 308	AIRBAG	1.6 16v 80kw NFU	
 308	AIRBAG	1.6 HDI 16v 66kw 9HV-FAP	
 308	AIRBAG	1.6 HDI 16v 66kw 9HV-FAP	
 308	AIRBAG	1.6 HDI 16v 66kw 9HX	
 308	AIRBAG	1.6 HDI 16v 66kw 9HX	
 308	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP	
 308	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP	
 308	AIRBAG	1.6 THP 16v 103kw 5FT	
 308	AIRBAG	1.6 THP 16v 103kw 5FT	
 308	AIRBAG	1.6 THP 16v 110kw 5FX	
 308	AIRBAG	1.6 THP 16v 110kw 5FX	
 308	AIRBAG	1.6 THP 16v 128kw 5FY	
 308	AIRBAG	1.6 THP 16v 128kw 5FY	
 308	AIRBAG	1.6 THP 16v 88kw 5FW	
 308	AIRBAG	1.6 THP 16v 88kw 5FW	
 308	AIRBAG	2.0 16v 103kw RFJ	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 308	AIRBAG	2.0 16v 103kw RFJ	
 308	AIRBAG	2.0 HDI 16v 100kw RHF	
 308	AIRBAG	2.0 HDI 16v 100kw RHF	
 308	AIRBAG	2.0 HDI 16v 100kw RHR-FAP	
 308	AIRBAG	2.0 HDI 16v 100kw RHR-FAP	
 308	AIRBAG	2.0 HDI 16v 103kw RHF	
 308	AIRBAG	2.0 HDI 16v 103kw RHF	
 308	CHASSIS NETWORK	1.4 16v 70kw 8FS	AIRBAG CONTROL LIGHT
 308	CHASSIS NETWORK	1.4 16v 70kw 8FS	DELPHI BSI 1
 308	CHASSIS NETWORK	1.4 16v 70kw 8FS	DELPHI BSI 2
 308	CHASSIS NETWORK	1.4 16v 70kw 8FS	DELPHI BSI 3
 308	CHASSIS NETWORK	1.4 16v 70kw 8FS	RAIN SENSOR
 308	CHASSIS NETWORK	1.6 16v 80kw NFU	AIRBAG CONTROL LIGHT
 308	CHASSIS NETWORK	1.6 16v 80kw NFU	DELPHI BSI 1
 308	CHASSIS NETWORK	1.6 16v 80kw NFU	DELPHI BSI 2
 308	CHASSIS NETWORK	1.6 16v 80kw NFU	DELPHI BSI 3
 308	CHASSIS NETWORK	1.6 16v 80kw NFU	RAIN SENSOR
 308	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HV-FAP	AIRBAG CONTROL LIGHT
 308	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HV-FAP	DELPHI BSI 1
 308	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HV-FAP	DELPHI BSI 2
 308	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HV-FAP	DELPHI BSI 3
 308	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HV-FAP	RAIN SENSOR
 308	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	AIRBAG CONTROL LIGHT
 308	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	DELPHI BSI 1
 308	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	DELPHI BSI 2
 308	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	DELPHI BSI 3
 308	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	RAIN SENSOR
 308	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	AIRBAG CONTROL LIGHT
 308	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	DELPHI BSI 1
 308	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	DELPHI BSI 2
 308	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	DELPHI BSI 3
 308	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	RAIN SENSOR
 308	CHASSIS NETWORK	1.6 THP 16v 103kw 5FT	AIRBAG CONTROL LIGHT
 308	CHASSIS NETWORK	1.6 THP 16v 103kw 5FT	DELPHI BSI 1
 308	CHASSIS NETWORK	1.6 THP 16v 103kw 5FT	DELPHI BSI 2
 308	CHASSIS NETWORK	1.6 THP 16v 103kw 5FT	DELPHI BSI 3
 308	CHASSIS NETWORK	1.6 THP 16v 103kw 5FT	RAIN SENSOR
 308	CHASSIS NETWORK	1.6 THP 16v 110kw 5FX	AIRBAG CONTROL LIGHT
 308	CHASSIS NETWORK	1.6 THP 16v 110kw 5FX	DELPHI BSI 1
 308	CHASSIS NETWORK	1.6 THP 16v 110kw 5FX	DELPHI BSI 2
 308	CHASSIS NETWORK	1.6 THP 16v 110kw 5FX	DELPHI BSI 3
 308	CHASSIS NETWORK	1.6 THP 16v 110kw 5FX	RAIN SENSOR
 308	CHASSIS NETWORK	1.6 THP 16v 128kw 5FY	AIRBAG CONTROL LIGHT
 308	CHASSIS NETWORK	1.6 THP 16v 128kw 5FY	DELPHI BSI 1
 308	CHASSIS NETWORK	1.6 THP 16v 128kw 5FY	DELPHI BSI 2
 308	CHASSIS NETWORK	1.6 THP 16v 128kw 5FY	DELPHI BSI 3
 308	CHASSIS NETWORK	1.6 THP 16v 128kw 5FY	RAIN SENSOR
 308	CHASSIS NETWORK	1.6 THP 16v 88kw 5FW	AIRBAG CONTROL LIGHT
 308	CHASSIS NETWORK	1.6 THP 16v 88kw 5FW	DELPHI BSI 1
 308	CHASSIS NETWORK	1.6 THP 16v 88kw 5FW	DELPHI BSI 2
 308	CHASSIS NETWORK	1.6 THP 16v 88kw 5FW	DELPHI BSI 3
 308	CHASSIS NETWORK	1.6 THP 16v 88kw 5FW	RAIN SENSOR
 308	CHASSIS NETWORK	2.0 16v 103kw RFJ	AIRBAG CONTROL LIGHT
 308	CHASSIS NETWORK	2.0 16v 103kw RFJ	DELPHI BSI 1
 308	CHASSIS NETWORK	2.0 16v 103kw RFJ	DELPHI BSI 2
 308	CHASSIS NETWORK	2.0 16v 103kw RFJ	DELPHI BSI 3
 308	CHASSIS NETWORK	2.0 16v 103kw RFJ	RAIN SENSOR
 308	CHASSIS NETWORK	2.0 HDI 16v 100kw RHF	AIRBAG CONTROL LIGHT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 308	CHASSIS NETWORK	2.0 HDI 16v 100kw RHF	DELPHI BSI 1
 308	CHASSIS NETWORK	2.0 HDI 16v 100kw RHF	DELPHI BSI 2
 308	CHASSIS NETWORK	2.0 HDI 16v 100kw RHF	DELPHI BSI 3
 308	CHASSIS NETWORK	2.0 HDI 16v 100kw RHF	RAIN SENSOR
 308	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	AIRBAG CONTROL LIGHT
 308	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	DELPHI BSI 1
 308	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	DELPHI BSI 2
 308	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	DELPHI BSI 3
 308	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	RAIN SENSOR
 308	CHASSIS NETWORK	2.0 HDI 16v 103kw RHF	AIRBAG CONTROL LIGHT
 308	CHASSIS NETWORK	2.0 HDI 16v 103kw RHF	DELPHI BSI 1
 308	CHASSIS NETWORK	2.0 HDI 16v 103kw RHF	DELPHI BSI 2
 308	CHASSIS NETWORK	2.0 HDI 16v 103kw RHF	DELPHI BSI 3
 308	CHASSIS NETWORK	2.0 HDI 16v 103kw RHF	RAIN SENSOR
 308	CLIMA	1.4 16v 70kw 8FS	
 308	CLIMA	1.6 16v 80kw NFU	
 308	CLIMA	1.6 HDI 16v 66kw 9HV-FAP	
 308	CLIMA	1.6 HDI 16v 80kw 9HZ-FAP	
 308	CLIMA	1.6 THP 16v 103kw 5FT	
 308	CLIMA	1.6 THP 16v 110kw 5FX	
 308	CLIMA	1.6 THP 16v 128kw 5FY	
 308	CLIMA	1.6 THP 16v 88kw 5FW	
 308	CLIMA	2.0 16v 103kw RFJ	
 308	CLIMA	2.0 HDI 16v 100kw RHR-FAP	
 308	CLIMA	2.0 HDI 16v 103kw RHF	
 308	DASHBOARD	1.4 16v 70kw 8FS	Var.1
 308	DASHBOARD	1.4 16v 70kw 8FS	Var.2
 308	DASHBOARD	1.6 16v 80kw NFU	Var.1
 308	DASHBOARD	1.6 16v 80kw NFU	Var.2
 308	DASHBOARD	1.6 HDI 16v 66kw 9HV-FAP	Var.1
 308	DASHBOARD	1.6 HDI 16v 66kw 9HV-FAP	Var.2
 308	DASHBOARD	1.6 HDI 16v 66kw 9HX	Var.1
 308	DASHBOARD	1.6 HDI 16v 66kw 9HX	Var.2
 308	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 308	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 308	DASHBOARD	1.6 THP 16v 103kw 5FT	Var.1
 308	DASHBOARD	1.6 THP 16v 103kw 5FT	Var.2
 308	DASHBOARD	1.6 THP 16v 110kw 5FX	Var.1
 308	DASHBOARD	1.6 THP 16v 110kw 5FX	Var.2
 308	DASHBOARD	1.6 THP 16v 128kw 5FY	Var.1
 308	DASHBOARD	1.6 THP 16v 128kw 5FY	Var.2
 308	DASHBOARD	1.6 THP 16v 88kw 5FW	Var.1
 308	DASHBOARD	1.6 THP 16v 88kw 5FW	Var.2
 308	DASHBOARD	2.0 16v 103kw RFJ	Var.1
 308	DASHBOARD	2.0 16v 103kw RFJ	Var.2
 308	DASHBOARD	2.0 HDI 16v 100kw RHF	Var.1
 308	DASHBOARD	2.0 HDI 16v 100kw RHF	Var.2
 308	DASHBOARD	2.0 HDI 16v 100kw RHR-FAP	Var.1
 308	DASHBOARD	2.0 HDI 16v 100kw RHR-FAP	Var.2
 308	DASHBOARD	2.0 HDI 16v 103kw RHF	Var.1
 308	DASHBOARD	2.0 HDI 16v 103kw RHF	Var.2
 308	DIESEL ADDITION	1.6 HDI 16v 66kw 9HV-FAP	
 308	DIESEL ADDITION	1.6 HDI 16v 66kw 9HX	
 308	DIESEL ADDITION	1.6 HDI 16v 80kw 9HZ-FAP	
 308	DIESEL ADDITION	2.0 HDI 16v 100kw RHF	
 308	DIESEL ADDITION	2.0 HDI 16v 100kw RHR-FAP	
 308	DIESEL ADDITION	2.0 HDI 16v 103kw RHF	
 308	DRIVER SIDE DOOR	1.4 16v 70kw 8FS	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 308	DRIVER SIDE DOOR	1.6 16v 80kw NFU	
 308	DRIVER SIDE DOOR	1.6 HDI 16v 66kw 9HV-FAP	
 308	DRIVER SIDE DOOR	1.6 HDI 16v 66kw 9HX	
 308	DRIVER SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	
 308	DRIVER SIDE DOOR	1.6 THP 16v 103kw 5FT	
 308	DRIVER SIDE DOOR	1.6 THP 16v 110kw 5FX	
 308	DRIVER SIDE DOOR	1.6 THP 16v 128kw 5FY	
 308	DRIVER SIDE DOOR	1.6 THP 16v 88kw 5FW	
 308	DRIVER SIDE DOOR	2.0 16v 103kw RFJ	
 308	DRIVER SIDE DOOR	2.0 HDI 16v 100kw RHF	
 308	DRIVER SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	
 308	DRIVER SIDE DOOR	2.0 HDI 16v 103kw RHF	
 308	ELECTRIC STEERING	1.4 16v 70kw 8FS	
 308	ELECTRIC STEERING	1.6 16v 80kw NFU	
 308	ELECTRIC STEERING	1.6 HDI 16v 66kw 9HV-FAP	
 308	ELECTRIC STEERING	1.6 HDI 16v 66kw 9HX	
 308	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	
 308	ELECTRIC STEERING	1.6 THP 16v 103kw 5FT	
 308	ELECTRIC STEERING	1.6 THP 16v 110kw 5FX	
 308	ELECTRIC STEERING	1.6 THP 16v 128kw 5FY	
 308	ELECTRIC STEERING	1.6 THP 16v 88kw 5FW	
 308	ELECTRIC STEERING	2.0 16v 103kw RFJ	
 308	ELECTRIC STEERING	2.0 HDI 16v 100kw RHF	
 308	ELECTRIC STEERING	2.0 HDI 16v 100kw RHR-FAP	
 308	ELECTRIC STEERING	2.0 HDI 16v 103kw RHF	
 308	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH Var. 1 EDC 16 C4 Common Rail
 308	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH Var. 2 EDC 16 C4 Common Rail
 308	KEY ENCODE	1.4 16v 70kw 8FS	JCAE Body Computer
 308	KEY ENCODE	1.6 16v 80kw NFU	JCAE Body Computer
 308	KEY ENCODE	1.6 HDI 16v 66kw 9HV-FAP	JCAE Body Computer
 308	KEY ENCODE	1.6 HDI 16v 66kw 9HX	JCAE Body Computer
 308	KEY ENCODE	1.6 HDI 16v 80kw 9HZ-FAP	JCAE Body Computer
 308	KEY ENCODE	1.6 THP 16v 103kw 5FT	JCAE Body Computer
 308	KEY ENCODE	1.6 THP 16v 110kw 5FX	JCAE Body Computer
 308	KEY ENCODE	1.6 THP 16v 128kw 5FY	JCAE Body Computer
 308	KEY ENCODE	1.6 THP 16v 88kw 5FW	JCAE Body Computer
 308	KEY ENCODE	2.0 16v 103kw RFJ	JCAE Body Computer
 308	KEY ENCODE	2.0 HDI 16v 100kw RHF	JCAE Body Computer
 308	KEY ENCODE	2.0 HDI 16v 100kw RHR-FAP	JCAE Body Computer
 308	KEY ENCODE	2.0 HDI 16v 103kw RHF	JCAE Body Computer
 308	MAINTENANCE	1.4 16v 70kw 8FS	
 308	MAINTENANCE	1.4 16v 70kw 8FS	
 308	MAINTENANCE	1.4 16v 70kw 8FS	
 308	MAINTENANCE	1.4 16v 70kw 8FS	
 308	MAINTENANCE	1.4 16v 70kw 8FS	
 308	MAINTENANCE	1.4 16v 70kw 8FS	JCAE Body Computer MANUAL
 308	MAINTENANCE	1.4 16v 70kw 8FS	Var.2
 308	MAINTENANCE	1.6 16v 80kw NFU	
 308	MAINTENANCE	1.6 16v 80kw NFU	
 308	MAINTENANCE	1.6 16v 80kw NFU	
 308	MAINTENANCE	1.6 16v 80kw NFU	
 308	MAINTENANCE	1.6 16v 80kw NFU	JCAE Body Computer MANUAL
 308	MAINTENANCE	1.6 16v 80kw NFU	Var.2
 308	MAINTENANCE	1.6 HDI 16v 66kw 9HV-FAP	
 308	MAINTENANCE	1.6 HDI 16v 66kw 9HV-FAP	
 308	MAINTENANCE	1.6 HDI 16v 66kw 9HV-FAP	
 308	MAINTENANCE	1.6 HDI 16v 66kw 9HV-FAP	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 308	MAINTENANCE	1.6 HDI 16v 66kw 9HV-FAP	
 308	MAINTENANCE	1.6 HDI 16v 66kw 9HV-FAP	JCAE Body Computer MANUAL
 308	MAINTENANCE	1.6 HDI 16v 66kw 9HV-FAP	Var.2
 308	MAINTENANCE	1.6 HDI 16v 66kw 9HX	
 308	MAINTENANCE	1.6 HDI 16v 66kw 9HX	
 308	MAINTENANCE	1.6 HDI 16v 66kw 9HX	
 308	MAINTENANCE	1.6 HDI 16v 66kw 9HX	
 308	MAINTENANCE	1.6 HDI 16v 66kw 9HX	
 308	MAINTENANCE	1.6 HDI 16v 66kw 9HX	JCAE Body Computer MANUAL
 308	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Var.2
 308	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	
 308	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	
 308	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	
 308	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	
 308	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	
 308	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH Var. 1 EDC 16 C4 Common Rail
 308	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH Var. 1 EDC 16 C4 Common Rail
 308	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH Var. 1 EDC 16 C4 Common Rail
 308	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH Var. 1 EDC 16 C4 Common Rail
 308	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH Var. 1 EDC 16 C4 Common Rail
 308	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH Var. 1 EDC 16 C4 Common Rail
 308	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	JCAE Body Computer MANUAL
 308	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 308	MAINTENANCE	1.6 THP 16v 103kw 5FT	
 308	MAINTENANCE	1.6 THP 16v 103kw 5FT	
 308	MAINTENANCE	1.6 THP 16v 103kw 5FT	
 308	MAINTENANCE	1.6 THP 16v 103kw 5FT	
 308	MAINTENANCE	1.6 THP 16v 103kw 5FT	
 308	MAINTENANCE	1.6 THP 16v 103kw 5FT	JCAE Body Computer MANUAL
 308	MAINTENANCE	1.6 THP 16v 103kw 5FT	Var.2
 308	MAINTENANCE	1.6 THP 16v 110kw 5FX	
 308	MAINTENANCE	1.6 THP 16v 110kw 5FX	
 308	MAINTENANCE	1.6 THP 16v 110kw 5FX	
 308	MAINTENANCE	1.6 THP 16v 110kw 5FX	
 308	MAINTENANCE	1.6 THP 16v 110kw 5FX	
 308	MAINTENANCE	1.6 THP 16v 110kw 5FX	
 308	MAINTENANCE	1.6 THP 16v 110kw 5FX	JCAE Body Computer MANUAL
 308	MAINTENANCE	1.6 THP 16v 110kw 5FX	Var.2
 308	MAINTENANCE	1.6 THP 16v 128kw 5FY	
 308	MAINTENANCE	1.6 THP 16v 128kw 5FY	
 308	MAINTENANCE	1.6 THP 16v 128kw 5FY	
 308	MAINTENANCE	1.6 THP 16v 128kw 5FY	
 308	MAINTENANCE	1.6 THP 16v 128kw 5FY	
 308	MAINTENANCE	1.6 THP 16v 128kw 5FY	JCAE Body Computer MANUAL
 308	MAINTENANCE	1.6 THP 16v 128kw 5FY	Var.2
 308	MAINTENANCE	1.6 THP 16v 88kw 5FW	
 308	MAINTENANCE	1.6 THP 16v 88kw 5FW	
 308	MAINTENANCE	1.6 THP 16v 88kw 5FW	
 308	MAINTENANCE	1.6 THP 16v 88kw 5FW	
 308	MAINTENANCE	1.6 THP 16v 88kw 5FW	JCAE Body Computer MANUAL
 308	MAINTENANCE	1.6 THP 16v 88kw 5FW	Var.2
 308	MAINTENANCE	2.0 16v 103kw RFJ	
 308	MAINTENANCE	2.0 16v 103kw RFJ	
 308	MAINTENANCE	2.0 16v 103kw RFJ	
 308	MAINTENANCE	2.0 16v 103kw RFJ	
 308	MAINTENANCE	2.0 16v 103kw RFJ	JCAE Body Computer MANUAL
 308	MAINTENANCE	2.0 16v 103kw RFJ	Var.2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 308	MAINTENANCE	2.0 HDI 16v 100kw RHF	
 308	MAINTENANCE	2.0 HDI 16v 100kw RHF	
 308	MAINTENANCE	2.0 HDI 16v 100kw RHF	
 308	MAINTENANCE	2.0 HDI 16v 100kw RHF	
 308	MAINTENANCE	2.0 HDI 16v 100kw RHF	
 308	MAINTENANCE	2.0 HDI 16v 100kw RHF	JCAE Body Computer MANUAL
 308	MAINTENANCE	2.0 HDI 16v 100kw RHF	Var.2
 308	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	
 308	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	
 308	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	
 308	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	
 308	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	JCAE Body Computer MANUAL
 308	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.2
 308	MAINTENANCE	2.0 HDI 16v 103kw RHF	
 308	MAINTENANCE	2.0 HDI 16v 103kw RHF	
 308	MAINTENANCE	2.0 HDI 16v 103kw RHF	
 308	MAINTENANCE	2.0 HDI 16v 103kw RHF	
 308	MAINTENANCE	2.0 HDI 16v 103kw RHF	JCAE Body Computer MANUAL
 308	MAINTENANCE	2.0 HDI 16v 103kw RHF	Var.2
 308	PARKING HELP	1.4 16v 70kw 8FS	
 308	PARKING HELP	1.6 16v 80kw NFU	
 308	PARKING HELP	1.6 HDI 16v 66kw 9HV-FAP	
 308	PARKING HELP	1.6 HDI 16v 66kw 9HX	
 308	PARKING HELP	1.6 HDI 16v 80kw 9HZ-FAP	
 308	PARKING HELP	1.6 THP 16v 103kw 5FT	
 308	PARKING HELP	1.6 THP 16v 110kw 5FX	
 308	PARKING HELP	1.6 THP 16v 128kw 5FY	
 308	PARKING HELP	1.6 THP 16v 88kw 5FW	
 308	PARKING HELP	2.0 16v 103kw RFJ	
 308	PARKING HELP	2.0 HDI 16v 100kw RHF	
 308	PARKING HELP	2.0 HDI 16v 100kw RHR-FAP	
 308	PARKING HELP	2.0 HDI 16v 103kw RHF	
 308	RADIO / CD	1.4 16v 70kw 8FS	
 308	RADIO / CD	1.6 16v 80kw NFU	
 308	RADIO / CD	1.6 HDI 16v 66kw 9HV-FAP	
 308	RADIO / CD	1.6 HDI 16v 66kw 9HX	
 308	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	
 308	RADIO / CD	1.6 THP 16v 103kw 5FT	
 308	RADIO / CD	1.6 THP 16v 110kw 5FX	
 308	RADIO / CD	1.6 THP 16v 128kw 5FY	
 308	RADIO / CD	1.6 THP 16v 88kw 5FW	
 308	RADIO / CD	2.0 16v 103kw RFJ	
 308	RADIO / CD	2.0 HDI 16v 100kw RHF	
 308	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP	
 308	RADIO / CD	2.0 HDI 16v 103kw RHF	
 308	REMOTE CONTROL E	1.4 16v 70kw 8FS	JCAE Body Computer MANUAL
 308	REMOTE CONTROL E	1.6 16v 80kw NFU	JCAE Body Computer MANUAL
 308	REMOTE CONTROL E	1.6 HDI 16v 66kw 9HV-FAP	JCAE Body Computer MANUAL
 308	REMOTE CONTROL E	1.6 HDI 16v 66kw 9HX	JCAE Body Computer MANUAL
 308	REMOTE CONTROL E	1.6 HDI 16v 80kw 9HZ-FAP	JCAE Body Computer MANUAL
 308	REMOTE CONTROL E	1.6 THP 16v 103kw 5FT	JCAE Body Computer MANUAL
 308	REMOTE CONTROL E	1.6 THP 16v 110kw 5FX	JCAE Body Computer MANUAL
 308	REMOTE CONTROL E	1.6 THP 16v 128kw 5FY	JCAE Body Computer MANUAL
 308	REMOTE CONTROL E	1.6 THP 16v 88kw 5FW	JCAE Body Computer MANUAL
 308	REMOTE CONTROL E	2.0 16v 103kw RFJ	JCAE Body Computer MANUAL
 308	REMOTE CONTROL E	2.0 HDI 16v 100kw RHF	JCAE Body Computer MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 308	REMOTE CONTROL E	2.0 HDI 16v 100kw RHR-FAP	JCAE Body Computer MANUAL
 308	REMOTE CONTROL E	2.0 HDI 16v 103kw RHF	JCAE Body Computer MANUAL
 308	SERVICE LIGHT RES	1.4 16v 70kw 8FS	
 308	SERVICE LIGHT RES	1.6 16v 80kw NFU	
 308	SERVICE LIGHT RES	1.6 HDI 16v 66kw 9HV-FAP	
 308	SERVICE LIGHT RES	1.6 HDI 16v 66kw 9HX	
 308	SERVICE LIGHT RES	1.6 HDI 16v 80kw 9HZ-FAP	
 308	SERVICE LIGHT RES	1.6 THP 16v 103kw 5FT	
 308	SERVICE LIGHT RES	1.6 THP 16v 110kw 5FX	
 308	SERVICE LIGHT RES	1.6 THP 16v 128kw 5FY	
 308	SERVICE LIGHT RES	1.6 THP 16v 88kw 5FW	
 308	SERVICE LIGHT RES	2.0 16v 103kw RFJ	
 308	SERVICE LIGHT RES	2.0 HDI 16v 100kw RHF	
 308	SERVICE LIGHT RES	2.0 HDI 16v 100kw RHR-FAP	
 308	SERVICE LIGHT RES	2.0 HDI 16v 103kw RHF	
 308	STEERING COLUMN	1.4 16v 70kw 8FS	
 308	STEERING COLUMN	1.6 16v 80kw NFU	
 308	STEERING COLUMN	1.6 HDI 16v 66kw 9HV-FAP	
 308	STEERING COLUMN	1.6 HDI 16v 66kw 9HX	
 308	STEERING COLUMN	1.6 HDI 16v 80kw 9HZ-FAP	
 308	STEERING COLUMN	1.6 THP 16v 103kw 5FT	
 308	STEERING COLUMN	1.6 THP 16v 110kw 5FX	
 308	STEERING COLUMN	1.6 THP 16v 128kw 5FY	
 308	STEERING COLUMN	1.6 THP 16v 88kw 5FW	
 308	STEERING COLUMN	2.0 16v 103kw RFJ	
 308	STEERING COLUMN	2.0 HDI 16v 100kw RHF	
 308	STEERING COLUMN	2.0 HDI 16v 100kw RHR-FAP	
 308	STEERING COLUMN	2.0 HDI 16v 103kw RHF	
 308	VISUAL./TELEMATIC	1.4 16v 70kw 8FS	Display C-
 308	VISUAL./TELEMATIC	1.4 16v 70kw 8FS	Display C-
 308	VISUAL./TELEMATIC	1.6 16v 80kw NFU	Display C-
 308	VISUAL./TELEMATIC	1.6 16v 80kw NFU	Display C-
 308	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HV-FAP	Display C-
 308	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HV-FAP	Display C-
 308	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HX	Display C-
 308	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HX	Display C-
 308	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	Display C-
 308	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	Display C-
 308	VISUAL./TELEMATIC	1.6 THP 16v 103kw 5FT	Display C-
 308	VISUAL./TELEMATIC	1.6 THP 16v 103kw 5FT	Display C-
 308	VISUAL./TELEMATIC	1.6 THP 16v 110kw 5FX	Display C-
 308	VISUAL./TELEMATIC	1.6 THP 16v 110kw 5FX	Display C-
 308	VISUAL./TELEMATIC	1.6 THP 16v 128kw 5FY	Display C-
 308	VISUAL./TELEMATIC	1.6 THP 16v 128kw 5FY	Display C-
 308	VISUAL./TELEMATIC	1.6 THP 16v 88kw 5FW	Display C-
 308	VISUAL./TELEMATIC	1.6 THP 16v 88kw 5FW	Display C-
 308	VISUAL./TELEMATIC	2.0 16v 103kw RFJ	Display C-
 308	VISUAL./TELEMATIC	2.0 16v 103kw RFJ	Display C-
 308	VISUAL./TELEMATIC	2.0 HDI 16v 100kw RHF	Display C-
 308	VISUAL./TELEMATIC	2.0 HDI 16v 100kw RHF	Display C-
 308	VISUAL./TELEMATIC	2.0 HDI 16v 100kw RHR-FAP	Display C-
 308	VISUAL./TELEMATIC	2.0 HDI 16v 100kw RHR-FAP	Display C-
 308	VISUAL./TELEMATIC	2.0 HDI 16v 103kw RHF	Display C-
 308	VISUAL./TELEMATIC	2.0 HDI 16v 103kw RHF	Display C-
 309	ELECTRONIC INJECT	1.1 44kw HDZ	BOSCH MonoJetronic A2.2 [Slow]
 309	ELECTRONIC INJECT	1.4 55kw KDY	BOSCH MonoJetronic A2.2 [Slow]
 309	ELECTRONIC INJECT	1.4 58kw KDZ	BOSCH MonoJetronic A2.2 [Slow]
 309	ENGINE MANAGEME	1.6 65kw BDY	Marelli MM G5 [Slow]

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 309	ENGINE MANAGEME	1.6 65kw BDY	Marelli MM G6 [Slow]
 309	ENGINE MANAGEME	1.6 65kw BDZ	Marelli MM G5 [Slow]
 309	ENGINE MANAGEME	1.9 16v 108kw DFW	BOSCH Motronic M1.3 [Slow]
 309	ENGINE MANAGEME	1.9 88kw DKZ	BOSCH Motronic M1.3 [Slow]
 309	ENGINE MANAGEME	1.9 94kw D6C	BOSCH Motronic ML4.1 [Slow]
 4007	ABS + TRACT. CONT	2.2 HDI 16v 115kw 4HN-FAP	TEVES ABS/ESP 0801
 4007	ABS + TRACT. CONT	2.4 16v 125kw 4B12	TEVES ABS/ESP 0801
 4007	AIRBAG	2.2 HDI 16v 115kw 4HN-FAP	TRW AirBag 4148
 4007	AIRBAG	2.4 16v 125kw 4B12	TRW AirBag 4148
 4007	CLIMA	2.2 HDI 16v 115kw 4HN-FAP	MITSUBISHI Clima 00.01
 4007	CLIMA	2.4 16v 125kw 4B12	MITSUBISHI Clima 00.01
 4007	DASHBOARD	2.2 HDI 16v 115kw 4HN-FAP	YASAKI Dashboard 0201
 4007	DASHBOARD	2.4 16v 125kw 4B12	YASAKI Dashboard 0201
 4007	MAINTENANCE	2.2 HDI 16v 115kw 4HN-FAP	TEVES ABS/ESP 0801
 4007	MAINTENANCE	2.2 HDI 16v 115kw 4HN-FAP	YASAKI Dashboard 0201
 4007	MAINTENANCE	2.4 16v 125kw 4B12	TEVES ABS/ESP 0801
 4007	MAINTENANCE	2.4 16v 125kw 4B12	YASAKI Dashboard 0201
 405	ENGINE MANAGEME	1.4 55kw KDX	BOSCH MonoMotronic MA3.0 [Fast]
 405	ENGINE MANAGEME	1.4 55kw KDX	BOSCH MonoMotronic MA3.0 [Slow]
 405	ENGINE MANAGEME	1.6 65kw BDY	Marelli MMBA G5 [Slow]
 405	ENGINE MANAGEME	1.6 65kw BDY	Marelli MMBA G6 [Slow]
 405	ENGINE MANAGEME	1.6 65kw BDZ	Marelli MMBA G5 [Slow]
 405	ENGINE MANAGEME	1.6 65kw BFZ	Marelli MM 8P [Slow]
 405	ENGINE MANAGEME	1.8 74kw L6A	Marelli MM 8P [Slow]
 405	ENGINE MANAGEME	1.8 74kw LFZ	BOSCH Motronic MP5.1 [Slow]
 405	ENGINE MANAGEME	1.8 74kw LFZ	Marelli MM 8P [Slow]
 405	ENGINE MANAGEME	1.9 16v 89kw DFW	BOSCH Motronic M1.3 [Slow]
 405	ENGINE MANAGEME	1.9 Kat 89kw D6D	BOSCH Motronic MP3.1 [Slow]
 405	ENGINE MANAGEME	1.9 Mi16 89kw D6D	BOSCH Motronic ML4.1 [Slow]
 405	ENGINE MANAGEME	1.9 Mi16 Kat 88kw DKZ	BOSCH Motronic M1.3 [Slow]
 405	ENGINE MANAGEME	1.9 Mi16 Kat DFW	BOSCH Motronic M1.3 [Slow]
 405	ENGINE MANAGEME	2.0 16v 110kw RFY	BOSCH Motronic MP3.2 [Slow]
 405	ENGINE MANAGEME	2.0 16v V.I.S. 110kw RFY	BOSCH Motronic MP3.2 [Fast]
 405	ENGINE MANAGEME	2.0 89kw R6D	Marelli MM 8P [Slow]
 405	ENGINE MANAGEME	2.0 89kw RFX	Marelli MM 8P [Slow]
 406 Coupe'	ABS	2.0 16v 101kw RFN (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	ABS	2.0 16v 101kw RFR (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	ABS	2.0 16v 97kw RFV (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	ABS	2.2 16v 118kw 3FZ (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	ABS	2.2 HDI 16v 98kw 4HX (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	ABS	3.0 V6 24v 143kw XFZ (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	ABS	3.0 V6 24v 152kw XFX (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	AIRBAG	2.0 16v 101kw RFN (97-05)	AKF- Autoliv AirBag no SIDE AB
 406 Coupe'	AIRBAG	2.0 16v 101kw RFN (97-05)	Temic AirBag CENTRAL
 406 Coupe'	AIRBAG	2.0 16v 101kw RFR (97-05)	AKF- Autoliv AirBag no SIDE AB
 406 Coupe'	AIRBAG	2.0 16v 101kw RFR (97-05)	Temic AirBag CENTRAL
 406 Coupe'	AIRBAG	2.0 16v 97kw RFV (97-05)	AKF- Autoliv AirBag no SIDE AB
 406 Coupe'	AIRBAG	2.0 16v 97kw RFV (97-05)	Temic AirBag CENTRAL
 406 Coupe'	AIRBAG	2.2 16v 118kw 3FZ (97-05)	AKF- Autoliv AirBag no SIDE AB
 406 Coupe'	AIRBAG	2.2 16v 118kw 3FZ (97-05)	Temic AirBag CENTRAL
 406 Coupe'	AIRBAG	2.2 HDI 16v 98kw 4HX (97-05)	AKF- Autoliv AirBag no SIDE AB
 406 Coupe'	AIRBAG	2.2 HDI 16v 98kw 4HX (97-05)	Temic AirBag CENTRAL
 406 Coupe'	AIRBAG	3.0 V6 24v 143kw XFZ (97-05)	AKF- Autoliv AirBag no SIDE AB
 406 Coupe'	AIRBAG	3.0 V6 24v 143kw XFZ (97-05)	Temic AirBag CENTRAL
 406 Coupe'	AIRBAG	3.0 V6 24v 152kw XFX (97-05)	AKF- Autoliv AirBag no SIDE AB
 406 Coupe'	AIRBAG	3.0 V6 24v 152kw XFX (97-05)	Temic AirBag CENTRAL
 406 Coupe'	AUX. HEATING	2.0 16v 101kw RFN (97-05)	Var.1
 406 Coupe'	AUX. HEATING	2.0 16v 101kw RFN (97-05)	Var.2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 406 Coupe'	AUX. HEATING	2.0 16v 101kw RFN (97-05)	Var.3
 406 Coupe'	AUX. HEATING	2.0 16v 101kw RFR (97-05)	Var.1
 406 Coupe'	AUX. HEATING	2.0 16v 101kw RFR (97-05)	Var.2
 406 Coupe'	AUX. HEATING	2.0 16v 101kw RFR (97-05)	Var.3
 406 Coupe'	AUX. HEATING	2.0 16v 97kw RFV (97-05)	Var.1
 406 Coupe'	AUX. HEATING	2.0 16v 97kw RFV (97-05)	Var.2
 406 Coupe'	AUX. HEATING	2.0 16v 97kw RFV (97-05)	Var.3
 406 Coupe'	AUX. HEATING	2.2 16v 118kw 3FZ (97-05)	Var.1
 406 Coupe'	AUX. HEATING	2.2 16v 118kw 3FZ (97-05)	Var.2
 406 Coupe'	AUX. HEATING	2.2 16v 118kw 3FZ (97-05)	Var.3
 406 Coupe'	AUX. HEATING	2.2 HDI 16v 98kw 4HX (97-05)	Var.1
 406 Coupe'	AUX. HEATING	2.2 HDI 16v 98kw 4HX (97-05)	Var.2
 406 Coupe'	AUX. HEATING	2.2 HDI 16v 98kw 4HX (97-05)	Var.3
 406 Coupe'	AUX. HEATING	3.0 V6 24v 143kw XFZ (97-05)	Var.1
 406 Coupe'	AUX. HEATING	3.0 V6 24v 143kw XFZ (97-05)	Var.2
 406 Coupe'	AUX. HEATING	3.0 V6 24v 143kw XFZ (97-05)	Var.3
 406 Coupe'	AUX. HEATING	3.0 V6 24v 152kw XFX (97-05)	Var.1
 406 Coupe'	AUX. HEATING	3.0 V6 24v 152kw XFX (97-05)	Var.2
 406 Coupe'	AUX. HEATING	3.0 V6 24v 152kw XFX (97-05)	Var.3
 406 Coupe'	CLIMA	2.0 16v 101kw RFN (97-05)	VALEO CLAA5 CLIMA 220 RFTD
 406 Coupe'	CLIMA	2.0 16v 101kw RFR (97-05)	VALEO CLAA5 CLIMA 220 RFTD
 406 Coupe'	CLIMA	2.0 16v 97kw RFV (97-05)	VALEO CLAA5 CLIMA 220 RFTD
 406 Coupe'	CLIMA	2.2 16v 118kw 3FZ (97-05)	VALEO CLAA5 CLIMA 220 RFTD
 406 Coupe'	CLIMA	2.2 HDI 16v 98kw 4HX (97-05)	VALEO CLAA5 CLIMA 220 RFTD
 406 Coupe'	CLIMA	3.0 V6 24v 143kw XFZ (97-05)	VALEO CLAA5 CLIMA 220 RFTD
 406 Coupe'	CLIMA	3.0 V6 24v 152kw XFX (97-05)	VALEO CLAA5 CLIMA 220 RFTD
 406 Coupe'	COMFORT SYSTEM	2.0 16v 101kw RFN (97-05)	ACTIVA
 406 Coupe'	COMFORT SYSTEM	2.0 16v 101kw RFR (97-05)	ACTIVA
 406 Coupe'	COMFORT SYSTEM	2.0 16v 97kw RFV (97-05)	ACTIVA
 406 Coupe'	COMFORT SYSTEM	2.2 16v 118kw 3FZ (97-05)	ACTIVA
 406 Coupe'	COMFORT SYSTEM	2.2 HDI 16v 98kw 4HX (97-05)	ACTIVA
 406 Coupe'	COMFORT SYSTEM	3.0 V6 24v 143kw XFZ (97-05)	ACTIVA
 406 Coupe'	COMFORT SYSTEM	3.0 V6 24v 152kw XFX (97-05)	ACTIVA
 406 Coupe'	ENGINE MANAGEME	2.0 16v 101kw RFN (97-05)	Marelli 4.8P
 406 Coupe'	ENGINE MANAGEME	2.0 16v 101kw RFR (97-05)	Marelli 4.8P
 406 Coupe'	ENGINE MANAGEME	2.0 16v 97kw RFV (97-05)	BOSCH Motronic MP5.1.1 [Fast]
 406 Coupe'	ENGINE MANAGEME	2.0 16v 97kw RFV (97-05)	BOSCH Motronic MP5.2
 406 Coupe'	ENGINE MANAGEME	2.0 16v 97kw RFV (97-05)	BOSCH Motronic MP5.2
 406 Coupe'	ENGINE MANAGEME	2.2 16v 118kw 3FZ (01-05)	EOBD
 406 Coupe'	ENGINE MANAGEME	2.2 HDI 16v 98kw 4HX (04-05)	EOBD
 406 Coupe'	ENGINE MANAGEME	3.0 V6 24v 143kw XFZ (01-05)	EOBD
 406 Coupe'	ENGINE MANAGEME	3.0 V6 24v 152kw XFX (01-05)	EOBD
 406 Coupe'	MAINTENANCE	2.0 16v 101kw RFN (97-05)	ACTIVA
 406 Coupe'	MAINTENANCE	2.0 16v 101kw RFN (97-05)	ACTIVA
 406 Coupe'	MAINTENANCE	2.0 16v 101kw RFN (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	MAINTENANCE	2.0 16v 101kw RFN (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	MAINTENANCE	2.0 16v 101kw RFN (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	MAINTENANCE	2.0 16v 101kw RFN (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	MAINTENANCE	2.0 16v 101kw RFR (97-05)	ACTIVA
 406 Coupe'	MAINTENANCE	2.0 16v 101kw RFR (97-05)	ACTIVA
 406 Coupe'	MAINTENANCE	2.0 16v 101kw RFR (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	MAINTENANCE	2.0 16v 101kw RFR (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	MAINTENANCE	2.0 16v 101kw RFR (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	MAINTENANCE	2.0 16v 97kw RFV (97-05)	ACTIVA
 406 Coupe'	MAINTENANCE	2.0 16v 97kw RFV (97-05)	ACTIVA
 406 Coupe'	MAINTENANCE	2.0 16v 97kw RFV (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	MAINTENANCE	2.0 16v 97kw RFV (97-05)	BOSCH ABS ABR 5.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 406 Coupe'	MAINTENANCE	2.0 16v 97kw RFV (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	MAINTENANCE	2.0 16v 97kw RFV (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	MAINTENANCE	2.2 16v 118kw 3FZ (97-05)	ACTIVA
 406 Coupe'	MAINTENANCE	2.2 16v 118kw 3FZ (97-05)	ACTIVA
 406 Coupe'	MAINTENANCE	2.2 16v 118kw 3FZ (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	MAINTENANCE	2.2 16v 118kw 3FZ (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	MAINTENANCE	2.2 16v 118kw 3FZ (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	MAINTENANCE	2.2 16v 118kw 3FZ (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	MAINTENANCE	2.2 HDI 16v 98kw 4HX (97-05)	ACTIVA
 406 Coupe'	MAINTENANCE	2.2 HDI 16v 98kw 4HX (97-05)	ACTIVA
 406 Coupe'	MAINTENANCE	2.2 HDI 16v 98kw 4HX (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	MAINTENANCE	2.2 HDI 16v 98kw 4HX (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	MAINTENANCE	2.2 HDI 16v 98kw 4HX (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	MAINTENANCE	2.2 HDI 16v 98kw 4HX (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	MAINTENANCE	3.0 V6 24v 143kw XFZ (97-05)	ACTIVA
 406 Coupe'	MAINTENANCE	3.0 V6 24v 143kw XFZ (97-05)	ACTIVA
 406 Coupe'	MAINTENANCE	3.0 V6 24v 143kw XFZ (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	MAINTENANCE	3.0 V6 24v 143kw XFZ (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	MAINTENANCE	3.0 V6 24v 143kw XFZ (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	MAINTENANCE	3.0 V6 24v 143kw XFZ (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	MAINTENANCE	3.0 V6 24v 143kw XFZ (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	MAINTENANCE	3.0 V6 24v 152kw XFX (97-05)	ACTIVA
 406 Coupe'	MAINTENANCE	3.0 V6 24v 152kw XFX (97-05)	ACTIVA
 406 Coupe'	MAINTENANCE	3.0 V6 24v 152kw XFX (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	MAINTENANCE	3.0 V6 24v 152kw XFX (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	MAINTENANCE	3.0 V6 24v 152kw XFX (97-05)	BOSCH ABS ABR 5.3
 406 Coupe'	MAINTENANCE	3.0 V6 24v 152kw XFX (97-05)	BOSCH ABS ABR 5.3
 406	ABS	1.6 66kw BFZ (95-99)	BOSCH ABS ABR 5.3
 406	ABS	1.8 16v 81kw LFY (99-05)	BOSCH ABS ABR 5.3
 406	ABS	1.8 16v 86kw 6FZ (99-05)	BOSCH ABS ABR 5.3
 406	ABS	1.8 74kw L6A (95-99)	BOSCH ABS ABR 5.3
 406	ABS	1.8 GPL 16v 81kw LFY (95-99)	BOSCH ABS ABR 5.3
 406	ABS	1.9 TD 55kw DHW (95-99)	BOSCH ABS ABR 5.3
 406	ABS	1.9 TD 66kw DHX (95-99)	BOSCH ABS ABR 5.3
 406	ABS	1.9 TD 68kw D8B (95-99)	BOSCH ABS ABR 5.3
 406	ABS	2.0 16v 101kw RFN (95-99)	BOSCH ABS ABR 5.3
 406	ABS	2.0 16v 97kw RFV (95-99)	BOSCH ABS ABR 5.3
 406	ABS	2.0 HDI 16v 81kw RHS-FAP (99-05)	BOSCH ABS ABR 5.3
 406	ABS	2.0 HDI 66kw RHY (99-05)	BOSCH ABS ABR 5.3
 406	ABS	2.0 HDI 81kw RHZ (99-05)	BOSCH ABS ABR 5.3
 406	ABS	2.0 HPI 16v 105kw RLZ (99-05)	BOSCH ABS ABR 5.3
 406	ABS	2.0 T 108kw RGX (95-99)	BOSCH ABS ABR 5.3
 406	ABS	2.1 TD 12v 81kw P8C (95-99)	BOSCH ABS ABR 5.3
 406	ABS	2.2 16v 118kw 3FZ (95-99)	BOSCH ABS ABR 5.3
 406	ABS	2.2 HDI 16v 98kw 4HX-FAP (99-05)	BOSCH ABS ABR 5.3
 406	ABS	3.0 V6 24v 143kw XFZ (95-99)	BOSCH ABS ABR 5.3
 406	ABS	3.0 V6 24v 152kw XFX (99-05)	BOSCH ABS ABR 5.3
 406	AIRBAG	1.6 66kw BFZ (95-99)	Temic AirBag CENTRAL
 406	AIRBAG	1.6 66kw BFZ (97-99)	AKF- Autoliv AirBag no SIDE AB
 406	AIRBAG	1.8 16v 81kw LFY (95-99)	Temic AirBag CENTRAL
 406	AIRBAG	1.8 16v 81kw LFY (99-00)	AKF- Autoliv AirBag no SIDE AB
406	AIRBAG	1.8 16v 86kw 6FZ (99-00)	AKF- Autoliv AirBag no SIDE AB
406	AIRBAG	1.8 16v 86kw 6FZ (99-05)	Temic AirBag CENTRAL
406	AIRBAG	1.8 74kw L6A (95-99)	Temic AirBag CENTRAL
406	AIRBAG	1.8 74kw L6A (97-99)	AKF- Autoliv AirBag no SIDE AB
406	AIRBAG	1.8 GPL 16v 81kw LFY (95-99)	Temic AirBag CENTRAL
406	AIRBAG	1.8 GPL 16v 81kw LFY (97-99)	AKF- Autoliv AirBag no SIDE AB
406	AIRBAG	1.9 TD 55kw DHW (95-99)	Temic AirBag CENTRAL
406	AIRBAG	1.9 TD 55kw DHW (97-99)	AKF- Autoliv AirBag no SIDE AB

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 406	AIRBAG	1.9 TD 66kw DHX (95-99)	Temic AirBag CENTRAL
 406	AIRBAG	1.9 TD 66kw DHX (97-99)	AKF- Autoliv AirBag no SIDE AB
 406	AIRBAG	1.9 TD 68kw D8B (95-99)	Temic AirBag CENTRAL
 406	AIRBAG	1.9 TD 68kw D8B (97-99)	AKF- Autoliv AirBag no SIDE AB
 406	AIRBAG	2.0 16v 101kw RFN (95-99)	Temic AirBag CENTRAL
 406	AIRBAG	2.0 16v 101kw RFN (97-99)	AKF- Autoliv AirBag no SIDE AB
 406	AIRBAG	2.0 16v 97kw RFV (95-99)	Temic AirBag CENTRAL
 406	AIRBAG	2.0 16v 97kw RFV (97-99)	AKF- Autoliv AirBag no SIDE AB
 406	AIRBAG	2.0 HDI 16v 81kw RHS-FAP (99-00)	AKF- Autoliv AirBag no SIDE AB
 406	AIRBAG	2.0 HDI 16v 81kw RHS-FAP (99-05)	Temic AirBag CENTRAL
 406	AIRBAG	2.0 HDI 66kw RHY (99-00)	AKF- Autoliv AirBag no SIDE AB
 406	AIRBAG	2.0 HDI 66kw RHY (99-05)	Temic AirBag CENTRAL
 406	AIRBAG	2.0 HDI 81kw RHZ (99-00)	AKF- Autoliv AirBag no SIDE AB
 406	AIRBAG	2.0 HDI 81kw RHZ (99-05)	Temic AirBag CENTRAL
 406	AIRBAG	2.0 HPI 16v 105kw RLZ (99-00)	AKF- Autoliv AirBag no SIDE AB
 406	AIRBAG	2.0 HPI 16v 105kw RLZ (99-05)	Temic AirBag CENTRAL
 406	AIRBAG	2.0 T 108kw RGX (95-99)	Temic AirBag CENTRAL
 406	AIRBAG	2.0 T 108kw RGX (97-99)	AKF- Autoliv AirBag no SIDE AB
 406	AIRBAG	2.1 TD 12v 81kw P8C (95-99)	Temic AirBag CENTRAL
 406	AIRBAG	2.1 TD 12v 81kw P8C (97-99)	AKF- Autoliv AirBag no SIDE AB
 406	AIRBAG	2.2 16v 118kw 3FZ (95-99)	Temic AirBag CENTRAL
 406	AIRBAG	2.2 16v 118kw 3FZ (97-99)	AKF- Autoliv AirBag no SIDE AB
 406	AIRBAG	2.2 HDI 16v 98kw 4HX-FAP (99-00)	AKF- Autoliv AirBag no SIDE AB
 406	AIRBAG	2.2 HDI 16v 98kw 4HX-FAP (99-05)	Temic AirBag CENTRAL
 406	AIRBAG	3.0 V6 24v 143kw XFZ (95-99)	Temic AirBag CENTRAL
 406	AIRBAG	3.0 V6 24v 143kw XFZ (97-99)	AKF- Autoliv AirBag no SIDE AB
 406	AIRBAG	3.0 V6 24v 152kw XFX (97-00)	AKF- Autoliv AirBag no SIDE AB
 406	AIRBAG	3.0 V6 24v 152kw XFX (99-05)	Temic AirBag CENTRAL
 406	AUX. HEATING	1.6 66kw BFZ (95-99)	Var.1
 406	AUX. HEATING	1.6 66kw BFZ (95-99)	Var.2
 406	AUX. HEATING	1.6 66kw BFZ (95-99)	Var.3
 406	AUX. HEATING	1.8 16v 81kw LFY (95-99)	Var.1
 406	AUX. HEATING	1.8 16v 81kw LFY (95-99)	Var.2
 406	AUX. HEATING	1.8 16v 81kw LFY (95-99)	Var.3
 406	AUX. HEATING	1.8 16v 86kw 6FZ (99-05)	Var.1
 406	AUX. HEATING	1.8 16v 86kw 6FZ (99-05)	Var.2
 406	AUX. HEATING	1.8 16v 86kw 6FZ (99-05)	Var.3
 406	AUX. HEATING	1.8 74kw L6A (95-99)	Var.1
 406	AUX. HEATING	1.8 74kw L6A (95-99)	Var.2
 406	AUX. HEATING	1.8 74kw L6A (95-99)	Var.3
 406	AUX. HEATING	1.8 GPL 16v 81kw LFY (95-99)	Var.1
 406	AUX. HEATING	1.8 GPL 16v 81kw LFY (95-99)	Var.2
 406	AUX. HEATING	1.8 GPL 16v 81kw LFY (95-99)	Var.3
 406	AUX. HEATING	1.9 TD 55kw DHW (95-99)	Var.1
 406	AUX. HEATING	1.9 TD 55kw DHW (95-99)	Var.2
 406	AUX. HEATING	1.9 TD 55kw DHW (95-99)	Var.3
 406	AUX. HEATING	1.9 TD 66kw DHX (95-99)	Var.1
 406	AUX. HEATING	1.9 TD 66kw DHX (95-99)	Var.2
 406	AUX. HEATING	1.9 TD 66kw DHX (95-99)	Var.3
 406	AUX. HEATING	1.9 TD 68kw D8B (95-99)	Var.1
 406	AUX. HEATING	1.9 TD 68kw D8B (95-99)	Var.2
 406	AUX. HEATING	1.9 TD 68kw D8B (95-99)	Var.3
 406	AUX. HEATING	2.0 16v 101kw RFN (95-99)	Var.1
 406	AUX. HEATING	2.0 16v 101kw RFN (95-99)	Var.3
 406	AUX. HEATING	2.0 16v 101kw RFN (99-05)	Var.2
 406	AUX. HEATING	2.0 16v 97kw RFV (95-99)	Var.1
 406	AUX. HEATING	2.0 16v 97kw RFV (95-99)	Var.2
 406	AUX. HEATING	2.0 16v 97kw RFV (95-99)	Var.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 406	AUX. HEATING	2.0 HDI 16v 81kw RHS-FAP (99-05)	Var.1
 406	AUX. HEATING	2.0 HDI 16v 81kw RHS-FAP (99-05)	Var.2
 406	AUX. HEATING	2.0 HDI 16v 81kw RHS-FAP (99-05)	Var.3
 406	AUX. HEATING	2.0 HDI 66kw RHY (99-05)	Var.1
 406	AUX. HEATING	2.0 HDI 66kw RHY (99-05)	Var.2
 406	AUX. HEATING	2.0 HDI 66kw RHY (99-05)	Var.3
 406	AUX. HEATING	2.0 HDI 81kw RHZ (99-05)	Var.1
 406	AUX. HEATING	2.0 HDI 81kw RHZ (99-05)	Var.2
 406	AUX. HEATING	2.0 HDI 81kw RHZ (99-05)	Var.3
 406	AUX. HEATING	2.0 HPI 16v 105kw RLZ (99-05)	Var.1
 406	AUX. HEATING	2.0 HPI 16v 105kw RLZ (99-05)	Var.2
 406	AUX. HEATING	2.0 HPI 16v 105kw RLZ (99-05)	Var.3
 406	AUX. HEATING	2.0 T 108kw RGX (95-99)	Var.1
 406	AUX. HEATING	2.0 T 108kw RGX (95-99)	Var.2
 406	AUX. HEATING	2.0 T 108kw RGX (95-99)	Var.3
 406	AUX. HEATING	2.1 TD 12v 81kw P8C (95-99)	Var.1
 406	AUX. HEATING	2.1 TD 12v 81kw P8C (95-99)	Var.2
 406	AUX. HEATING	2.1 TD 12v 81kw P8C (95-99)	Var.3
 406	AUX. HEATING	2.2 16v 118kw 3FZ (95-99)	Var.1
 406	AUX. HEATING	2.2 16v 118kw 3FZ (95-99)	Var.2
 406	AUX. HEATING	2.2 16v 118kw 3FZ (99-05)	Var.3
 406	AUX. HEATING	2.2 HDI 16v 98kw 4HX-FAP (99-05)	Var.1
 406	AUX. HEATING	2.2 HDI 16v 98kw 4HX-FAP (99-05)	Var.2
 406	AUX. HEATING	2.2 HDI 16v 98kw 4HX-FAP (99-05)	Var.3
 406	AUX. HEATING	3.0 V6 24v 143kw XFZ (95-99)	Var.1
 406	AUX. HEATING	3.0 V6 24v 143kw XFZ (95-99)	Var.2
 406	AUX. HEATING	3.0 V6 24v 143kw XFZ (95-99)	Var.3
 406	AUX. HEATING	3.0 V6 24v 152kw XFX (99-05)	Var.1
 406	AUX. HEATING	3.0 V6 24v 152kw XFX (99-05)	Var.2
 406	AUX. HEATING	3.0 V6 24v 152kw XFX (99-05)	Var.3
 406	CLIMA	1.6 66kw BFZ (95-99)	VALEO CLAA5 CLIMA 220 RFTD
 406	CLIMA	1.8 16v 81kw LFY (95-99)	VALEO CLAA5 CLIMA 220 RFTD
 406	CLIMA	1.8 16v 86kw 6FZ (99-05)	VALEO CLAA5 CLIMA 220 RFTD
 406	CLIMA	1.8 74kw L6A (95-99)	VALEO CLAA5 CLIMA 220 RFTD
 406	CLIMA	1.8 GPL 16v 81kw LFY (95-99)	VALEO CLAA5 CLIMA 220 RFTD
 406	CLIMA	1.9 TD 55kw DHW (95-99)	VALEO CLAA5 CLIMA 220 RFTD
 406	CLIMA	1.9 TD 66kw DHX (95-99)	VALEO CLAA5 CLIMA 220 RFTD
 406	CLIMA	1.9 TD 68kw D8B (95-99)	VALEO CLAA5 CLIMA 220 RFTD
 406	CLIMA	2.0 16v 101kw RFN (99-05)	VALEO CLAA5 CLIMA 220 RFTD
 406	CLIMA	2.0 16v 97kw RFV (95-99)	VALEO CLAA5 CLIMA 220 RFTD
 406	CLIMA	2.0 HDI 16v 81kw RHS-FAP (99-05)	VALEO CLAA5 CLIMA 220 RFTD
 406	CLIMA	2.0 HDI 66kw RHY (99-05)	VALEO CLAA5 CLIMA 220 RFTD
 406	CLIMA	2.0 HDI 81kw RHZ (99-05)	VALEO CLAA5 CLIMA 220 RFTD
 406	CLIMA	2.0 HPI 16v 105kw RLZ (99-05)	VALEO CLAA5 CLIMA 220 RFTD
 406	CLIMA	2.0 T 108kw RGX (95-99)	VALEO CLAA5 CLIMA 220 RFTD
 406	CLIMA	2.1 TD 12v 81kw P8C (95-99)	VALEO CLAA5 CLIMA 220 RFTD
 406	CLIMA	2.2 16v 118kw 3FZ (99-05)	VALEO CLAA5 CLIMA 220 RFTD
 406	CLIMA	2.2 HDI 16v 98kw 4HX-FAP (99-05)	VALEO CLAA5 CLIMA 220 RFTD
 406	CLIMA	3.0 V6 24v 143kw XFZ (95-99)	VALEO CLAA5 CLIMA 220 RFTD
 406	CLIMA	3.0 V6 24v 152kw XFX (99-05)	VALEO CLAA5 CLIMA 220 RFTD
 406	COMFORT SYSTEM	1.6 66kw BFZ (95-99)	ACTIVA
 406	COMFORT SYSTEM	1.8 16v 81kw LFY (95-99)	ACTIVA
 406	COMFORT SYSTEM	1.8 16v 86kw 6FZ (99-05)	ACTIVA
 406	COMFORT SYSTEM	1.8 74kw L6A (95-99)	ACTIVA
 406	COMFORT SYSTEM	1.8 GPL 16v 81kw LFY (95-99)	ACTIVA
 406	COMFORT SYSTEM	1.9 TD 55kw DHW (95-99)	ACTIVA
 406	COMFORT SYSTEM	1.9 TD 66kw DHX (95-99)	ACTIVA
 406	COMFORT SYSTEM	1.9 TD 68kw D8B (95-99)	ACTIVA

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 406	COMFORT SYSTEM	2.0 16v 101kw RFN (95-99)	ACTIVA
 406	COMFORT SYSTEM	2.0 16v 97kw RFV (95-99)	ACTIVA
 406	COMFORT SYSTEM	2.0 HDI 16v 81kw RHS-FAP (99-05)	ACTIVA
 406	COMFORT SYSTEM	2.0 HDI 66kw RHY (99-05)	ACTIVA
 406	COMFORT SYSTEM	2.0 HDI 81kw RHZ (99-05)	ACTIVA
 406	COMFORT SYSTEM	2.0 HPI 16v 105kw RLZ (99-05)	ACTIVA
 406	COMFORT SYSTEM	2.0 T 108kw RGX (95-99)	ACTIVA
 406	COMFORT SYSTEM	2.1 TD 12v 81kw P8C (95-99)	ACTIVA
 406	COMFORT SYSTEM	2.2 16v 118kw 3FZ (95-99)	ACTIVA
 406	COMFORT SYSTEM	2.2 HDI 16v 98kw 4HX-FAP (99-05)	ACTIVA
 406	COMFORT SYSTEM	3.0 V6 24v 143kw XFZ (95-99)	ACTIVA
 406	COMFORT SYSTEM	3.0 V6 24v 143kw XFZ (95-99)	SAGEM
 406	COMFORT SYSTEM	3.0 V6 24v 152kw XFX (99-05)	ACTIVA
 406	DIESEL ADDITION	2.0 HDI 16v 81kw RHS-FAP (99-05)	
 406	DIESEL ADDITION	2.2 HDI 16v 98kw 4HX-FAP (99-05)	
 406	DIESEL MANAGEMEN	1.9 TD 55kw DHW (95-99)	BOSCH AS3 VP20
 406	DIESEL MANAGEMEN	1.9 TD 66kw DHX (95-99)	BOSCH AS3 VP20
 406	ENGINE MANAGEME	1.8 16v 81kw LFY (99-05)	BOSCH Motronic MP5.2
 406	ENGINE MANAGEME	1.8 16v 81kw LFY (99-05)	SAGEM SL 96
 406	ENGINE MANAGEME	1.8 16v 86kw 6FZ (99-05)	SAGEM S2000
 406	ENGINE MANAGEME	1.8 74kw L6A (95-99)	Marelli MM 8P [Fast]
 406	ENGINE MANAGEME	1.8 GPL 16v 81kw LFY (95-99)	BOSCH Motronic MP5.1.1 [Fast]
 406	ENGINE MANAGEME	1.8 GPL 16v 81kw LFY (95-99)	BOSCH Motronic MP5.2
 406	ENGINE MANAGEME	1.8 GPL 16v 81kw LFY (95-99)	SAGEM SL 96
 406	ENGINE MANAGEME	2.0 16v 101kw RFN (95-99)	Marelli 4.8P
 406	ENGINE MANAGEME	2.0 16v 101kw RFN (99-05)	Marelli 2.0L RFN MM48P
 406	ENGINE MANAGEME	2.0 16v 101kw RFN (99-05)	Marelli 4.8P
 406	ENGINE MANAGEME	2.0 16v 97kw RFV (95-99)	BOSCH Motronic MP5.1.1 [Fast]
 406	ENGINE MANAGEME	2.0 16v 97kw RFV (95-99)	BOSCH Motronic MP5.2
 406	ENGINE MANAGEME	2.0 HDI 16v 81kw RHS-FAP (01-04)	BOSCH EDC 15 C2 Common Rail
 406	ENGINE MANAGEME	2.0 HDI 66kw RHY (03-05)	BOSCH EDC 15 C2 Common Rail
 406	ENGINE MANAGEME	2.0 HDI 66kw RHY (99-00)	BOSCH EDC 15 C2 Common Rail
 406	ENGINE MANAGEME	2.0 HDI 66kw RHY (99-05)	BOSCH EDC 15 C2 Common Rail
 406	ENGINE MANAGEME	2.0 HDI 66kw RHY (99-05)	EDC 15 C2 Common Rail
 406	ENGINE MANAGEME	2.0 HDI 66kw RHY (99-05)	SIEMENS Diesel SID 801 Common Rail
 406	ENGINE MANAGEME	2.0 HDI 66kw RHY (99-05)	SIEMENS SID 801 Common Rail
 406	ENGINE MANAGEME	2.0 HDI 81kw RHZ (03-05)	BOSCH EDC 15 C2 Common Rail
 406	ENGINE MANAGEME	2.0 HDI 81kw RHZ (99-00)	BOSCH EDC 15 C2 Common Rail
 406	ENGINE MANAGEME	2.0 HDI 81kw RHZ (99-00)	BOSCH EDC 15 C2 Common Rail
 406	ENGINE MANAGEME	2.0 HDI 81kw RHZ (99-05)	BOSCH EDC 15 C2 Common Rail
 406	ENGINE MANAGEME	2.0 HPI 16v 105kw RLZ (99-05)	EOBD
 406	ENGINE MANAGEME	2.0 T 108kw RGX (95-99)	BOSCH Motronic MP3.2 [Fast]
 406	ENGINE MANAGEME	2.1 TD 12v 81kw P8C (95-99)	LUCAS Diesel EPIC
 406	ENGINE MANAGEME	2.2 16v 118kw 3FZ (95-99)	Marelli MM4MP2
 406	ENGINE MANAGEME	2.2 16v 118kw 3FZ (99-05)	Marelli MM4MP2
 406	ENGINE MANAGEME	2.2 HDI 16v 98kw 4HX-FAP (99-05)	BOSCH EDC 15 C2 Common Rail
 406	ENGINE MANAGEME	2.2 HDI 16v 98kw 4HX-FAP (99-05)	BOSCH EDC 15 C2 Common Rail
 406	ENGINE MANAGEME	3.0 V6 24v 152kw XFX (99-05)	BOSCH ME 7.4.6
 406	KEY ENCODE	1.6 66kw BFZ (99-05)	VALEO Body Siemens
 406	KEY ENCODE	1.8 16v 81kw LFY (99-05)	VALEO Body Siemens
 406	KEY ENCODE	1.8 16v 86kw 6FZ (99-05)	VALEO Body Siemens
 406	KEY ENCODE	1.8 74kw L6A (99-05)	VALEO Body Siemens
 406	KEY ENCODE	1.8 GPL 16v 81kw LFY (99-05)	VALEO Body Siemens
 406	KEY ENCODE	1.9 TD 55kw DHW (99-05)	VALEO Body Siemens
 406	KEY ENCODE	1.9 TD 66kw DHX (99-05)	VALEO Body Siemens
 406	KEY ENCODE	1.9 TD 68kw D8B (99-05)	VALEO Body Siemens
 406	KEY ENCODE	2.0 16v 101kw RFN (99-05)	VALEO Body Siemens
 406	KEY ENCODE	2.0 16v 97kw RFV (99-05)	VALEO Body Siemens

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 406	KEY ENCODE	2.0 HDI 16v 81kw RHS-FAP (99-05)	VALEO Body Siemens
 406	KEY ENCODE	2.0 HDI 66kw RHY (99-05)	VALEO Body Siemens
 406	KEY ENCODE	2.0 HDI 81kw RHZ (99-05)	VALEO Body Siemens
 406	KEY ENCODE	2.0 HPI 16v 105kw RLZ (99-05)	VALEO Body Siemens
 406	KEY ENCODE	2.0 T 108kw RGX (99-05)	VALEO Body Siemens
 406	KEY ENCODE	2.1 TD 12v 81kw P8C (99-05)	VALEO Body Siemens
 406	KEY ENCODE	2.2 16v 118kw 3FZ (99-05)	VALEO Body Siemens
 406	KEY ENCODE	2.2 HDI 16v 98kw 4HX-FAP (99-05)	VALEO Body Siemens
 406	KEY ENCODE	3.0 V6 24v 152kw XFX (99-05)	VALEO Body Siemens
 406	MAINTENANCE	1.6 66kw BFZ (95-99)	ACTIVA
 406	MAINTENANCE	1.6 66kw BFZ (95-99)	ACTIVA
 406	MAINTENANCE	1.6 66kw BFZ (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	1.6 66kw BFZ (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	1.6 66kw BFZ (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	1.6 66kw BFZ (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	1.8 16v 81kw LFY (95-99)	ACTIVA
 406	MAINTENANCE	1.8 16v 81kw LFY (95-99)	ACTIVA
 406	MAINTENANCE	1.8 16v 81kw LFY (99-05)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	1.8 16v 81kw LFY (99-05)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	1.8 16v 81kw LFY (99-05)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	1.8 16v 81kw LFY (99-05)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	1.8 16v 86kw 6FZ (99-05)	ACTIVA
 406	MAINTENANCE	1.8 16v 86kw 6FZ (99-05)	ACTIVA
 406	MAINTENANCE	1.8 16v 86kw 6FZ (99-05)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	1.8 16v 86kw 6FZ (99-05)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	1.8 16v 86kw 6FZ (99-05)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	1.8 16v 86kw 6FZ (99-05)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	1.8 74kw L6A (95-99)	ACTIVA
 406	MAINTENANCE	1.8 74kw L6A (95-99)	ACTIVA
 406	MAINTENANCE	1.8 74kw L6A (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	1.8 74kw L6A (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	1.8 74kw L6A (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	1.8 74kw L6A (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	1.8 GPL 16v 81kw LFY (95-99)	ACTIVA
 406	MAINTENANCE	1.8 GPL 16v 81kw LFY (95-99)	ACTIVA
 406	MAINTENANCE	1.8 GPL 16v 81kw LFY (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	1.8 GPL 16v 81kw LFY (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	1.8 GPL 16v 81kw LFY (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	1.8 GPL 16v 81kw LFY (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	1.9 TD 55kw DHW (95-99)	ACTIVA
 406	MAINTENANCE	1.9 TD 55kw DHW (95-99)	ACTIVA
 406	MAINTENANCE	1.9 TD 55kw DHW (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	1.9 TD 55kw DHW (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	1.9 TD 55kw DHW (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	1.9 TD 55kw DHW (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	1.9 TD 66kw DHX (95-99)	ACTIVA
 406	MAINTENANCE	1.9 TD 66kw DHX (95-99)	ACTIVA
 406	MAINTENANCE	1.9 TD 66kw DHX (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	1.9 TD 66kw DHX (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	1.9 TD 66kw DHX (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	1.9 TD 66kw DHX (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	1.9 TD 68kw D8B (95-99)	ACTIVA
 406	MAINTENANCE	1.9 TD 68kw D8B (95-99)	ACTIVA
 406	MAINTENANCE	1.9 TD 68kw D8B (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	1.9 TD 68kw D8B (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	1.9 TD 68kw D8B (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	1.9 TD 68kw D8B (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.0 16v 101kw RFN (95-99)	ACTIVA

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 406	MAINTENANCE	2.0 16v 101kw RFN (95-99)	ACTIVA
 406	MAINTENANCE	2.0 16v 101kw RFN (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.0 16v 101kw RFN (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.0 16v 101kw RFN (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.0 16v 101kw RFN (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.0 16v 97kw RFV (95-99)	ACTIVA
 406	MAINTENANCE	2.0 16v 97kw RFV (95-99)	ACTIVA
 406	MAINTENANCE	2.0 16v 97kw RFV (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.0 16v 97kw RFV (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.0 16v 97kw RFV (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.0 16v 97kw RFV (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.0 HDI 16v 81kw RHS-FAP (01-04)	BOSCH EDC 15 C2 Common Rail
 406	MAINTENANCE	2.0 HDI 16v 81kw RHS-FAP (99-05)	ACTIVA
 406	MAINTENANCE	2.0 HDI 16v 81kw RHS-FAP (99-05)	ACTIVA
 406	MAINTENANCE	2.0 HDI 16v 81kw RHS-FAP (99-05)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.0 HDI 16v 81kw RHS-FAP (99-05)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.0 HDI 16v 81kw RHS-FAP (99-05)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.0 HDI 16v 81kw RHS-FAP (99-05)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.0 HDI 66kw RHY (03-05)	BOSCH EDC 15 C2 Common Rail
 406	MAINTENANCE	2.0 HDI 66kw RHY (99-05)	ACTIVA
 406	MAINTENANCE	2.0 HDI 66kw RHY (99-05)	ACTIVA
 406	MAINTENANCE	2.0 HDI 66kw RHY (99-05)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.0 HDI 66kw RHY (99-05)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.0 HDI 66kw RHY (99-05)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.0 HDI 66kw RHY (99-05)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.0 HDI 66kw RHY (99-05)	BOSCH EDC 15 C2 Common Rail
 406	MAINTENANCE	2.0 HDI 66kw RHY (99-05)	EDC 15 C2 Common Rail
 406	MAINTENANCE	2.0 HDI 81kw RHZ (03-05)	BOSCH EDC 15 C2 Common Rail
 406	MAINTENANCE	2.0 HDI 81kw RHZ (99-05)	ACTIVA
 406	MAINTENANCE	2.0 HDI 81kw RHZ (99-05)	ACTIVA
 406	MAINTENANCE	2.0 HDI 81kw RHZ (99-05)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.0 HDI 81kw RHZ (99-05)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.0 HDI 81kw RHZ (99-05)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.0 HDI 81kw RHZ (99-05)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.0 HDI 81kw RHZ (99-05)	BOSCH EDC 15 C2 Common Rail
 406	MAINTENANCE	2.0 HPI 16v 105kw RLZ (99-05)	ACTIVA
 406	MAINTENANCE	2.0 HPI 16v 105kw RLZ (99-05)	ACTIVA
 406	MAINTENANCE	2.0 HPI 16v 105kw RLZ (99-05)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.0 HPI 16v 105kw RLZ (99-05)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.0 HPI 16v 105kw RLZ (99-05)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.0 HPI 16v 105kw RLZ (99-05)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.0 T 108kw RGX (95-99)	ACTIVA
 406	MAINTENANCE	2.0 T 108kw RGX (95-99)	ACTIVA
 406	MAINTENANCE	2.0 T 108kw RGX (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.0 T 108kw RGX (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.0 T 108kw RGX (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.0 T 108kw RGX (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.1 TD 12v 81kw P8C (95-99)	ACTIVA
 406	MAINTENANCE	2.1 TD 12v 81kw P8C (95-99)	ACTIVA
 406	MAINTENANCE	2.1 TD 12v 81kw P8C (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.1 TD 12v 81kw P8C (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.1 TD 12v 81kw P8C (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.1 TD 12v 81kw P8C (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.2 16v 118kw 3FZ (95-99)	ACTIVA
 406	MAINTENANCE	2.2 16v 118kw 3FZ (95-99)	ACTIVA
 406	MAINTENANCE	2.2 16v 118kw 3FZ (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.2 16v 118kw 3FZ (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.2 16v 118kw 3FZ (95-99)	BOSCH ABS ABR 5.3

Systems supported by ECUREADER / ECUDECODER (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 406	MAINTENANCE	2.2 16v 118kw 3FZ (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP (99-05)	ACTIVA
 406	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP (99-05)	ACTIVA
 406	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP (99-05)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP (99-05)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP (99-05)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP (99-05)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP (99-05)	BOSCH EDC 15 C2 Common Rail
 406	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP (99-05)	BOSCH EDC 15 C2 Common Rail
 406	MAINTENANCE	3.0 V6 24v 143kw XFZ (95-99)	ACTIVA
 406	MAINTENANCE	3.0 V6 24v 143kw XFZ (95-99)	ACTIVA
 406	MAINTENANCE	3.0 V6 24v 143kw XFZ (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	3.0 V6 24v 143kw XFZ (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	3.0 V6 24v 143kw XFZ (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	3.0 V6 24v 143kw XFZ (95-99)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	3.0 V6 24v 152kw XFX (99-05)	ACTIVA
 406	MAINTENANCE	3.0 V6 24v 152kw XFX (99-05)	ACTIVA
 406	MAINTENANCE	3.0 V6 24v 152kw XFX (99-05)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	3.0 V6 24v 152kw XFX (99-05)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	3.0 V6 24v 152kw XFX (99-05)	BOSCH ABS ABR 5.3
 406	MAINTENANCE	3.0 V6 24v 152kw XFX (99-05)	BOSCH ABS ABR 5.3
 406	RADIO / CD	1.6 66kw BFZ (99-05)	CLARION AudioSystem
 406	RADIO / CD	1.6 66kw BFZ (99-05)	PHILIPS AudioSystem
 406	RADIO / CD	1.6 66kw BFZ (99-05)	VDO AudioSystem
 406	RADIO / CD	1.8 16v 81kw LFY (99-05)	CLARION AudioSystem
 406	RADIO / CD	1.8 16v 81kw LFY (99-05)	PHILIPS AudioSystem
 406	RADIO / CD	1.8 16v 81kw LFY (99-05)	VDO AudioSystem
 406	RADIO / CD	1.8 16v 86kw 6FZ (99-05)	CLARION AudioSystem
 406	RADIO / CD	1.8 16v 86kw 6FZ (99-05)	PHILIPS AudioSystem
 406	RADIO / CD	1.8 16v 86kw 6FZ (99-05)	VDO AudioSystem
 406	RADIO / CD	1.8 74kw L6A (99-05)	CLARION AudioSystem
 406	RADIO / CD	1.8 74kw L6A (99-05)	PHILIPS AudioSystem
 406	RADIO / CD	1.8 74kw L6A (99-05)	VDO AudioSystem
 406	RADIO / CD	1.8 GPL 16v 81kw LFY (99-05)	CLARION AudioSystem
 406	RADIO / CD	1.8 GPL 16v 81kw LFY (99-05)	PHILIPS AudioSystem
 406	RADIO / CD	1.8 GPL 16v 81kw LFY (99-05)	VDO AudioSystem
 406	RADIO / CD	1.9 TD 55kw DHW (99-05)	CLARION AudioSystem
 406	RADIO / CD	1.9 TD 55kw DHW (99-05)	PHILIPS AudioSystem
 406	RADIO / CD	1.9 TD 55kw DHW (99-05)	VDO AudioSystem
 406	RADIO / CD	1.9 TD 66kw DHX (99-05)	CLARION AudioSystem
 406	RADIO / CD	1.9 TD 66kw DHX (99-05)	PHILIPS AudioSystem
 406	RADIO / CD	1.9 TD 66kw DHX (99-05)	VDO AudioSystem
 406	RADIO / CD	1.9 TD 68kw D8B (99-05)	CLARION AudioSystem
 406	RADIO / CD	1.9 TD 68kw D8B (99-05)	PHILIPS AudioSystem
 406	RADIO / CD	1.9 TD 68kw D8B (99-05)	VDO AudioSystem
 406	RADIO / CD	2.0 16v 101kw RFN (99-05)	CLARION AudioSystem
 406	RADIO / CD	2.0 16v 101kw RFN (99-05)	PHILIPS AudioSystem
 406	RADIO / CD	2.0 16v 101kw RFN (99-05)	VDO AudioSystem
 406	RADIO / CD	2.0 16v 97kw RFV (99-05)	CLARION AudioSystem
 406	RADIO / CD	2.0 16v 97kw RFV (99-05)	PHILIPS AudioSystem
 406	RADIO / CD	2.0 16v 97kw RFV (99-05)	VDO AudioSystem
 406	RADIO / CD	2.0 HDI 16v 81kw RHS-FAP (99-05)	CLARION AudioSystem
 406	RADIO / CD	2.0 HDI 16v 81kw RHS-FAP (99-05)	PHILIPS AudioSystem
 406	RADIO / CD	2.0 HDI 16v 81kw RHS-FAP (99-05)	VDO AudioSystem
 406	RADIO / CD	2.0 HDI 66kw RHY (99-05)	CLARION AudioSystem
 406	RADIO / CD	2.0 HDI 66kw RHY (99-05)	PHILIPS AudioSystem
 406	RADIO / CD	2.0 HDI 66kw RHY (99-05)	VDO AudioSystem
 406	RADIO / CD	2.0 HDI 81kw RHZ (99-05)	CLARION AudioSystem

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 406	RADIO / CD	2.0 HDI 81kw RHZ (99-05)	PHILIPS AudioSystem
 406	RADIO / CD	2.0 HDI 81kw RHZ (99-05)	VDO AudioSystem
 406	RADIO / CD	2.0 HPI 16v 105kw RLZ (99-05)	CLARION AudioSystem
 406	RADIO / CD	2.0 HPI 16v 105kw RLZ (99-05)	PHILIPS AudioSystem
 406	RADIO / CD	2.0 HPI 16v 105kw RLZ (99-05)	VDO AudioSystem
 406	RADIO / CD	2.0 T 108kw RGX (99-05)	CLARION AudioSystem
 406	RADIO / CD	2.0 T 108kw RGX (99-05)	PHILIPS AudioSystem
 406	RADIO / CD	2.0 T 108kw RGX (99-05)	VDO AudioSystem
 406	RADIO / CD	2.1 TD 12v 81kw P8C (99-05)	CLARION AudioSystem
 406	RADIO / CD	2.1 TD 12v 81kw P8C (99-05)	PHILIPS AudioSystem
 406	RADIO / CD	2.1 TD 12v 81kw P8C (99-05)	VDO AudioSystem
 406	RADIO / CD	2.2 16v 118kw 3FZ (99-05)	CLARION AudioSystem
 406	RADIO / CD	2.2 16v 118kw 3FZ (99-05)	PHILIPS AudioSystem
 406	RADIO / CD	2.2 16v 118kw 3FZ (99-05)	VDO AudioSystem
 406	RADIO / CD	2.2 HDI 16v 98kw 4HX-FAP (99-05)	CLARION AudioSystem
 406	RADIO / CD	2.2 HDI 16v 98kw 4HX-FAP (99-05)	PHILIPS AudioSystem
 406	RADIO / CD	2.2 HDI 16v 98kw 4HX-FAP (99-05)	VDO AudioSystem
 406	RADIO / CD	3.0 V6 24v 152kw XFX (99-05)	CLARION AudioSystem
 406	RADIO / CD	3.0 V6 24v 152kw XFX (99-05)	PHILIPS AudioSystem
 406	RADIO / CD	3.0 V6 24v 152kw XFX (99-05)	VDO AudioSystem
 406	VISUAL./TELEMATIC	1.6 66kw BFZ (99-05)	SAGEM
 406	VISUAL./TELEMATIC	1.8 16v 81kw LFY (99-05)	SAGEM
 406	VISUAL./TELEMATIC	1.8 16v 86kw 6FZ (99-05)	SAGEM
 406	VISUAL./TELEMATIC	1.8 74kw L6A (99-05)	SAGEM
 406	VISUAL./TELEMATIC	1.8 GPL 16v 81kw LFY (99-05)	SAGEM
 406	VISUAL./TELEMATIC	1.9 TD 55kw DHW (99-05)	SAGEM
 406	VISUAL./TELEMATIC	1.9 TD 66kw DHX (99-05)	SAGEM
 406	VISUAL./TELEMATIC	1.9 TD 68kw D8B (99-05)	SAGEM
 406	VISUAL./TELEMATIC	2.0 16v 101kw RFN (99-05)	SAGEM
 406	VISUAL./TELEMATIC	2.0 16v 97kw RFV (99-05)	SAGEM
 406	VISUAL./TELEMATIC	2.0 HDI 16v 81kw RHS-FAP (99-05)	SAGEM
 406	VISUAL./TELEMATIC	2.0 HDI 66kw RHY (99-05)	SAGEM
 406	VISUAL./TELEMATIC	2.0 HDI 81kw RHZ (99-05)	SAGEM
 406	VISUAL./TELEMATIC	2.0 HPI 16v 105kw RLZ (99-05)	SAGEM
 406	VISUAL./TELEMATIC	2.0 T 108kw RGX (99-05)	SAGEM
 406	VISUAL./TELEMATIC	2.1 TD 12v 81kw P8C (99-05)	SAGEM
 406	VISUAL./TELEMATIC	2.2 16v 118kw 3FZ (99-05)	SAGEM
 406	VISUAL./TELEMATIC	2.2 HDI 16v 98kw 4HX-FAP (99-05)	SAGEM
 406	VISUAL./TELEMATIC	3.0 V6 24v 152kw XFX (99-05)	SAGEM
 407	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HY	TEVES ABS Mk60
 407	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HY	Var.1
 407	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HY	Var.2
 407	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	TEVES ABS Mk60
 407	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 407	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 407	ABS + TRACT. CONT	1.8 16v 86kw 6FZ	TEVES ABS Mk60
 407	ABS + TRACT. CONT	1.8 16v 86kw 6FZ	Var.1
 407	ABS + TRACT. CONT	1.8 16v 86kw 6FZ	Var.2
 407	ABS + TRACT. CONT	1.8 16v 92kw 6FY	TEVES ABS Mk60
 407	ABS + TRACT. CONT	1.8 16v 92kw 6FY	Var.1
 407	ABS + TRACT. CONT	1.8 16v 92kw 6FY	Var.2
 407	ABS + TRACT. CONT	2.0 16v 103kw RFJ	TEVES ABS Mk60
 407	ABS + TRACT. CONT	2.0 16v 103kw RFJ	Var.1
 407	ABS + TRACT. CONT	2.0 16v 103kw RFJ	Var.2
 407	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP	TEVES ABS Mk60
407	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP	Var.1
407	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP	Var.2
407	ABS + TRACT. CONT	2.0 HDI 16v 103kw RHF-FAP	TEVES ABS Mk60

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 407	ABS + TRACT. CONT	2.0 HDI 16v 103kw RHF-FAP	Var.1
 407	ABS + TRACT. CONT	2.0 HDI 16v 103kw RHF-FAP	Var.2
 407	ABS + TRACT. CONT	2.0 HDI 16v 110kw RFN	TEVES ABS Mk60
 407	ABS + TRACT. CONT	2.0 HDI 16v 110kw RFN	Var.1
 407	ABS + TRACT. CONT	2.0 HDI 16v 110kw RFN	Var.2
 407	ABS + TRACT. CONT	2.0 HDI 16v 110kw RHE	TEVES ABS Mk60
 407	ABS + TRACT. CONT	2.0 HDI 16v 110kw RHE	Var.1
 407	ABS + TRACT. CONT	2.0 HDI 16v 110kw RHE	Var.2
 407	ABS + TRACT. CONT	2.0 HDI 16v 120kw RHH	TEVES ABS Mk60
 407	ABS + TRACT. CONT	2.0 HDI 16v 120kw RHH	Var.1
 407	ABS + TRACT. CONT	2.0 HDI 16v 120kw RHH	Var.2
 407	ABS + TRACT. CONT	2.0 HDI 16v 93kw RHL-FAP	TEVES ABS Mk60
 407	ABS + TRACT. CONT	2.0 HDI 16v 93kw RHL-FAP	Var.1
 407	ABS + TRACT. CONT	2.0 HDI 16v 93kw RHL-FAP	Var.2
 407	ABS + TRACT. CONT	2.2 16v 116kw 3FZ	TEVES ABS Mk60
 407	ABS + TRACT. CONT	2.2 16v 116kw 3FZ	Var.1
 407	ABS + TRACT. CONT	2.2 16v 116kw 3FZ	Var.2
 407	ABS + TRACT. CONT	2.2 16v 120kw 3FY	TEVES ABS Mk60
 407	ABS + TRACT. CONT	2.2 16v 120kw 3FY	Var.1
 407	ABS + TRACT. CONT	2.2 16v 120kw 3FY	Var.2
 407	ABS + TRACT. CONT	2.2 HDI 16v 120kw 4HP	TEVES ABS Mk60
 407	ABS + TRACT. CONT	2.2 HDI 16v 120kw 4HP	Var.1
 407	ABS + TRACT. CONT	2.2 HDI 16v 120kw 4HP	Var.2
 407	ABS + TRACT. CONT	2.2 HDI 16v 125kw 4HT-FAP	TEVES ABS Mk60
 407	ABS + TRACT. CONT	2.2 HDI 16v 125kw 4HT-FAP	Var.1
 407	ABS + TRACT. CONT	2.2 HDI 16v 125kw 4HT-FAP	Var.2
 407	ABS + TRACT. CONT	2.2 HDI 16v 98kw 4HX-FAP	TEVES ABS Mk60
 407	ABS + TRACT. CONT	2.2 HDI 16v 98kw 4HX-FAP	Var.1
 407	ABS + TRACT. CONT	2.2 HDI 16v 98kw 4HX-FAP	Var.2
 407	ABS + TRACT. CONT	2.7 HDI V6 24v 150kw UHZ-FAP	TEVES ABS Mk60
 407	ABS + TRACT. CONT	2.7 HDI V6 24v 150kw UHZ-FAP	Var.1
 407	ABS + TRACT. CONT	2.7 HDI V6 24v 150kw UHZ-FAP	Var.2
 407	ABS + TRACT. CONT	3.0 HDI V6 16v 177kw X8Z	TEVES ABS Mk60
 407	ABS + TRACT. CONT	3.0 HDI V6 16v 177kw X8Z	Var.1
 407	ABS + TRACT. CONT	3.0 HDI V6 16v 177kw X8Z	Var.2
 407	ABS + TRACT. CONT	3.0 V6 24v 155kw XFU	TEVES ABS Mk60
 407	ABS + TRACT. CONT	3.0 V6 24v 155kw XFU	Var.1
 407	ABS + TRACT. CONT	3.0 V6 24v 155kw XFU	Var.2
 407	ABS + TRACT. CONT	3.0 V6 24v 155kw XFU	TEVES ABS Mk60
 407	ABS + TRACT. CONT	3.0 V6 24v 155kw XFU	Var.1
 407	ABS + TRACT. CONT	3.0 V6 24v 155kw XFU	Var.2
 407	AIRBAG	1.6 HDI 16v 80kw 9HY	AirBag CENTRAL
 407	AIRBAG	1.6 HDI 16v 80kw 9HY	TRW Autoliv AirBag
 407	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL
 407	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP	TRW Autoliv AirBag
 407	AIRBAG	1.8 16v 86kw 6FZ	AirBag CENTRAL
 407	AIRBAG	1.8 16v 86kw 6FZ	TRW Autoliv AirBag
 407	AIRBAG	1.8 16v 92kw 6FY	AirBag CENTRAL
 407	AIRBAG	1.8 16v 92kw 6FY	TRW Autoliv AirBag
 407	AIRBAG	2.0 16v 103kw RFJ	AirBag CENTRAL
 407	AIRBAG	2.0 16v 103kw RFJ	TRW Autoliv AirBag
 407	AIRBAG	2.0 HDI 16v 100kw RHR-FAP	AirBag CENTRAL
 407	AIRBAG	2.0 HDI 16v 100kw RHR-FAP	TRW Autoliv AirBag
 407	AIRBAG	2.0 HDI 16v 103kw RHF-FAP	AirBag CENTRAL
 407	AIRBAG	2.0 HDI 16v 103kw RHF-FAP	TRW Autoliv AirBag
 407	AIRBAG	2.0 HDI 16v 110kw RFN	AirBag CENTRAL
 407	AIRBAG	2.0 HDI 16v 110kw RFN	TRW Autoliv AirBag
 407	AIRBAG	2.0 HDI 16v 110kw RHE	AirBag CENTRAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 407	AIRBAG	2.0 HDI 16v 110kw RHE	TRW Autoliv AirBag
 407	AIRBAG	2.0 HDI 16v 120kw RHH	AirBag CENTRAL
 407	AIRBAG	2.0 HDI 16v 120kw RHH	TRW Autoliv AirBag
 407	AIRBAG	2.0 HDI 16v 93kw RHL-FAP	AirBag CENTRAL
 407	AIRBAG	2.0 HDI 16v 93kw RHL-FAP	TRW Autoliv AirBag
 407	AIRBAG	2.2 16v 116kw 3FZ	AirBag CENTRAL
 407	AIRBAG	2.2 16v 116kw 3FZ	TRW Autoliv AirBag
 407	AIRBAG	2.2 16v 120kw 3FY	AirBag CENTRAL
 407	AIRBAG	2.2 16v 120kw 3FY	TRW Autoliv AirBag
 407	AIRBAG	2.2 HDI 16v 120kw 4HP	AirBag CENTRAL
 407	AIRBAG	2.2 HDI 16v 120kw 4HP	TRW Autoliv AirBag
 407	AIRBAG	2.2 HDI 16v 125kw 4HT-FAP	AirBag CENTRAL
 407	AIRBAG	2.2 HDI 16v 125kw 4HT-FAP	TRW Autoliv AirBag
 407	AIRBAG	2.2 HDI 16v 98kw 4HX-FAP	AirBag CENTRAL
 407	AIRBAG	2.2 HDI 16v 98kw 4HX-FAP	TRW Autoliv AirBag
 407	AIRBAG	2.7 HDI V6 24v 150kw UHZ-FAP	AirBag CENTRAL
 407	AIRBAG	2.7 HDI V6 24v 150kw UHZ-FAP	TRW Autoliv AirBag
 407	AIRBAG	3.0 HDI V6 16v 177kw X8Z	AirBag CENTRAL
 407	AIRBAG	3.0 HDI V6 16v 177kw X8Z	TRW Autoliv AirBag
 407	AIRBAG	3.0 V6 24v 155kw XFU	AirBag CENTRAL
 407	AIRBAG	3.0 V6 24v 155kw XFU	TRW Autoliv AirBag
 407	AIRBAG	3.0 V6 24v 155kw XFV	AirBag CENTRAL
 407	AIRBAG	3.0 V6 24v 155kw XFV	TRW Autoliv AirBag
 407	ANTITHEFT	1.6 HDI 16v 80kw 9HY	Alarm PSA2
 407	ANTITHEFT	1.6 HDI 16v 80kw 9HZ-FAP	Alarm PSA2
 407	ANTITHEFT	1.8 16v 86kw 6FZ	Alarm PSA2
 407	ANTITHEFT	1.8 16v 92kw 6FY	Alarm PSA2
 407	ANTITHEFT	2.0 16v 103kw RFJ	Alarm PSA2
 407	ANTITHEFT	2.0 HDI 16v 100kw RHR-FAP	Alarm PSA2
 407	ANTITHEFT	2.0 HDI 16v 103kw RHF-FAP	Alarm PSA2
 407	ANTITHEFT	2.0 HDI 16v 110kw RFN	Alarm PSA2
 407	ANTITHEFT	2.0 HDI 16v 110kw RHE	Alarm PSA2
 407	ANTITHEFT	2.0 HDI 16v 120kw RHH	Alarm PSA2
 407	ANTITHEFT	2.0 HDI 16v 93kw RHL-FAP	Alarm PSA2
 407	ANTITHEFT	2.2 16v 116kw 3FZ	Alarm PSA2
 407	ANTITHEFT	2.2 16v 120kw 3FY	Alarm PSA2
 407	ANTITHEFT	2.2 HDI 16v 120kw 4HP	Alarm PSA2
 407	ANTITHEFT	2.2 HDI 16v 125kw 4HT-FAP	Alarm PSA2
 407	ANTITHEFT	2.2 HDI 16v 98kw 4HX-FAP	Alarm PSA2
 407	ANTITHEFT	2.7 HDI V6 24v 150kw UHZ-FAP	Alarm PSA2
 407	ANTITHEFT	3.0 HDI V6 16v 177kw X8Z	Alarm PSA2
 407	ANTITHEFT	3.0 V6 24v 155kw XFU	Alarm PSA2
 407	ANTITHEFT	3.0 V6 24v 155kw XFV	Alarm PSA2
 407	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HY	A/T 4HP20
 407	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HY	A/T AM6
 407	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HY	Var.1
 407	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HY	Var.2
 407	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HY	Var.3
 407	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP	A/T 4HP20
 407	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP	A/T AM6
 407	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 407	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 407	AUTOM. TRANSMISSI	1.6 HDI 16v 80kw 9HZ-FAP	Var.3
 407	AUTOM. TRANSMISSI	1.8 16v 86kw 6FZ	A/T 4HP20
 407	AUTOM. TRANSMISSI	1.8 16v 86kw 6FZ	A/T AM6
 407	AUTOM. TRANSMISSI	1.8 16v 86kw 6FZ	Var.1
 407	AUTOM. TRANSMISSI	1.8 16v 86kw 6FZ	Var.2
 407	AUTOM. TRANSMISSI	1.8 16v 86kw 6FZ	Var.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 407	AUTOM. TRANSMISSI	1.8 16v 92kw 6FY	A/T 4HP20
 407	AUTOM. TRANSMISSI	1.8 16v 92kw 6FY	A/T AM6
 407	AUTOM. TRANSMISSI	1.8 16v 92kw 6FY	Var.1
 407	AUTOM. TRANSMISSI	1.8 16v 92kw 6FY	Var.2
 407	AUTOM. TRANSMISSI	1.8 16v 92kw 6FY	Var.3
 407	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ	A/T 4HP20
 407	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ	A/T AM6
 407	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ	Var.1
 407	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ	Var.2
 407	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ	Var.3
 407	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP	A/T 4HP20
 407	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP	A/T AM6
 407	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP	Var.1
 407	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP	Var.2
 407	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP	Var.3
 407	AUTOM. TRANSMISSI	2.0 HDI 16v 103kw RHF-FAP	A/T 4HP20
 407	AUTOM. TRANSMISSI	2.0 HDI 16v 103kw RHF-FAP	A/T AM6
 407	AUTOM. TRANSMISSI	2.0 HDI 16v 103kw RHF-FAP	Var.1
 407	AUTOM. TRANSMISSI	2.0 HDI 16v 103kw RHF-FAP	Var.2
 407	AUTOM. TRANSMISSI	2.0 HDI 16v 103kw RHF-FAP	Var.3
 407	AUTOM. TRANSMISSI	2.0 HDI 16v 110kw RFN	A/T 4HP20
 407	AUTOM. TRANSMISSI	2.0 HDI 16v 110kw RFN	A/T AM6
 407	AUTOM. TRANSMISSI	2.0 HDI 16v 110kw RFN	Var.1
 407	AUTOM. TRANSMISSI	2.0 HDI 16v 110kw RFN	Var.2
 407	AUTOM. TRANSMISSI	2.0 HDI 16v 110kw RFN	Var.3
 407	AUTOM. TRANSMISSI	2.0 HDI 16v 110kw RHE	A/T 4HP20
 407	AUTOM. TRANSMISSI	2.0 HDI 16v 110kw RHE	A/T AM6
 407	AUTOM. TRANSMISSI	2.0 HDI 16v 110kw RHE	Var.1
 407	AUTOM. TRANSMISSI	2.0 HDI 16v 110kw RHE	Var.2
 407	AUTOM. TRANSMISSI	2.0 HDI 16v 110kw RHE	Var.3
 407	AUTOM. TRANSMISSI	2.0 HDI 16v 120kw RHH	A/T 4HP20
 407	AUTOM. TRANSMISSI	2.0 HDI 16v 120kw RHH	A/T AM6
 407	AUTOM. TRANSMISSI	2.0 HDI 16v 120kw RHH	Var.1
 407	AUTOM. TRANSMISSI	2.0 HDI 16v 120kw RHH	Var.2
 407	AUTOM. TRANSMISSI	2.0 HDI 16v 120kw RHH	Var.3
 407	AUTOM. TRANSMISSI	2.0 HDI 16v 93kw RHL-FAP	A/T 4HP20
 407	AUTOM. TRANSMISSI	2.0 HDI 16v 93kw RHL-FAP	A/T AM6
 407	AUTOM. TRANSMISSI	2.0 HDI 16v 93kw RHL-FAP	Var.1
 407	AUTOM. TRANSMISSI	2.0 HDI 16v 93kw RHL-FAP	Var.2
 407	AUTOM. TRANSMISSI	2.0 HDI 16v 93kw RHL-FAP	Var.3
 407	AUTOM. TRANSMISSI	2.2 16v 116kw 3FZ	A/T 4HP20
 407	AUTOM. TRANSMISSI	2.2 16v 116kw 3FZ	A/T AM6
 407	AUTOM. TRANSMISSI	2.2 16v 116kw 3FZ	Var.1
 407	AUTOM. TRANSMISSI	2.2 16v 116kw 3FZ	Var.2
 407	AUTOM. TRANSMISSI	2.2 16v 116kw 3FZ	Var.3
 407	AUTOM. TRANSMISSI	2.2 16v 120kw 3FY	A/T 4HP20
 407	AUTOM. TRANSMISSI	2.2 16v 120kw 3FY	A/T AM6
 407	AUTOM. TRANSMISSI	2.2 16v 120kw 3FY	Var.1
 407	AUTOM. TRANSMISSI	2.2 16v 120kw 3FY	Var.2
 407	AUTOM. TRANSMISSI	2.2 16v 120kw 3FY	Var.3
 407	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HP	A/T 4HP20
 407	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HP	A/T AM6
 407	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HP	Var.1
 407	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HP	Var.2
 407	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HP	Var.3
 407	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HT-FAP	A/T 4HP20
 407	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HT-FAP	A/T AM6
 407	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HT-FAP	Var.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 407	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HT-FAP	Var.2
 407	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HT-FAP	Var.3
 407	AUTOM. TRANSMISSI	2.2 HDI 16v 98kw 4HX-FAP	A/T 4HP20
 407	AUTOM. TRANSMISSI	2.2 HDI 16v 98kw 4HX-FAP	A/T AM6
 407	AUTOM. TRANSMISSI	2.2 HDI 16v 98kw 4HX-FAP	Var.1
 407	AUTOM. TRANSMISSI	2.2 HDI 16v 98kw 4HX-FAP	Var.2
 407	AUTOM. TRANSMISSI	2.2 HDI 16v 98kw 4HX-FAP	Var.3
 407	AUTOM. TRANSMISSI	2.7 HDI V6 24v 150kw UHZ-FAP	A/T 4HP20
 407	AUTOM. TRANSMISSI	2.7 HDI V6 24v 150kw UHZ-FAP	A/T AM6
 407	AUTOM. TRANSMISSI	2.7 HDI V6 24v 150kw UHZ-FAP	Var.1
 407	AUTOM. TRANSMISSI	2.7 HDI V6 24v 150kw UHZ-FAP	Var.2
 407	AUTOM. TRANSMISSI	2.7 HDI V6 24v 150kw UHZ-FAP	Var.3
 407	AUTOM. TRANSMISSI	3.0 HDI V6 16v 177kw X8Z	A/T 4HP20
 407	AUTOM. TRANSMISSI	3.0 HDI V6 16v 177kw X8Z	A/T AM6
 407	AUTOM. TRANSMISSI	3.0 HDI V6 16v 177kw X8Z	Var.1
 407	AUTOM. TRANSMISSI	3.0 HDI V6 16v 177kw X8Z	Var.2
 407	AUTOM. TRANSMISSI	3.0 HDI V6 16v 177kw X8Z	Var.3
 407	AUTOM. TRANSMISSI	3.0 V6 24v 155kw XFU	A/T 4HP20
 407	AUTOM. TRANSMISSI	3.0 V6 24v 155kw XFU	A/T AM6
 407	AUTOM. TRANSMISSI	3.0 V6 24v 155kw XFU	Var.1
 407	AUTOM. TRANSMISSI	3.0 V6 24v 155kw XFU	Var.2
 407	AUTOM. TRANSMISSI	3.0 V6 24v 155kw XFU	Var.3
 407	AUTOM. TRANSMISSI	3.0 V6 24v 155kw XFV	A/T 4HP20
 407	AUTOM. TRANSMISSI	3.0 V6 24v 155kw XFV	A/T AM6
 407	AUTOM. TRANSMISSI	3.0 V6 24v 155kw XFV	Var.1
 407	AUTOM. TRANSMISSI	3.0 V6 24v 155kw XFV	Var.2
 407	AUTOM. TRANSMISSI	3.0 V6 24v 155kw XFV	Var.3
 407	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY	Body Computer BSI
 407	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY	Body Computer BSM
 407	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY	Body Computer BSR
 407	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY	BSI
 407	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY	JCAE BSI
 407	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HY	SIEMENS BSM
 407	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSI
 407	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSM
 407	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Body Computer BSR
 407	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	BSI
 407	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	JCAE BSI
 407	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	SIEMENS BSM
 407	CHASSIS NETWORK	1.8 16v 86kw 6FZ	Body Computer BSI
 407	CHASSIS NETWORK	1.8 16v 86kw 6FZ	Body Computer BSM
 407	CHASSIS NETWORK	1.8 16v 86kw 6FZ	Body Computer BSR
 407	CHASSIS NETWORK	1.8 16v 86kw 6FZ	BSI
 407	CHASSIS NETWORK	1.8 16v 86kw 6FZ	JCAE BSI
 407	CHASSIS NETWORK	1.8 16v 86kw 6FZ	SIEMENS BSM
 407	CHASSIS NETWORK	1.8 16v 92kw 6FY	Body Computer BSI
 407	CHASSIS NETWORK	1.8 16v 92kw 6FY	Body Computer BSM
 407	CHASSIS NETWORK	1.8 16v 92kw 6FY	Body Computer BSR
 407	CHASSIS NETWORK	1.8 16v 92kw 6FY	BSI
 407	CHASSIS NETWORK	1.8 16v 92kw 6FY	JCAE BSI
 407	CHASSIS NETWORK	1.8 16v 92kw 6FY	SIEMENS BSM
 407	CHASSIS NETWORK	2.0 16v 103kw RFJ	Body Computer BSI
 407	CHASSIS NETWORK	2.0 16v 103kw RFJ	Body Computer BSM
 407	CHASSIS NETWORK	2.0 16v 103kw RFJ	Body Computer BSR
 407	CHASSIS NETWORK	2.0 16v 103kw RFJ	BSI
 407	CHASSIS NETWORK	2.0 16v 103kw RFJ	JCAE BSI
 407	CHASSIS NETWORK	2.0 16v 103kw RFJ	SIEMENS BSM
 407	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	Body Computer BSI

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 407	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	Body Computer BSM
 407	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	Body Computer BSR
 407	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	BSI
 407	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	JCAE BSI
 407	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	SIEMENS BSM
 407	CHASSIS NETWORK	2.0 HDI 16v 103kw RHF-FAP	Body Computer BSI
 407	CHASSIS NETWORK	2.0 HDI 16v 103kw RHF-FAP	Body Computer BSM
 407	CHASSIS NETWORK	2.0 HDI 16v 103kw RHF-FAP	Body Computer BSR
 407	CHASSIS NETWORK	2.0 HDI 16v 103kw RHF-FAP	BSI
 407	CHASSIS NETWORK	2.0 HDI 16v 103kw RHF-FAP	JCAE BSI
 407	CHASSIS NETWORK	2.0 HDI 16v 103kw RHF-FAP	SIEMENS BSM
 407	CHASSIS NETWORK	2.0 HDI 16v 110kw RFN	Body Computer BSI
 407	CHASSIS NETWORK	2.0 HDI 16v 110kw RFN	Body Computer BSM
 407	CHASSIS NETWORK	2.0 HDI 16v 110kw RFN	Body Computer BSR
 407	CHASSIS NETWORK	2.0 HDI 16v 110kw RFN	BSI
 407	CHASSIS NETWORK	2.0 HDI 16v 110kw RFN	JCAE BSI
 407	CHASSIS NETWORK	2.0 HDI 16v 110kw RFN	SIEMENS BSM
 407	CHASSIS NETWORK	2.0 HDI 16v 110kw RHE	Body Computer BSI
 407	CHASSIS NETWORK	2.0 HDI 16v 110kw RHE	Body Computer BSM
 407	CHASSIS NETWORK	2.0 HDI 16v 110kw RHE	Body Computer BSR
 407	CHASSIS NETWORK	2.0 HDI 16v 110kw RHE	BSI
 407	CHASSIS NETWORK	2.0 HDI 16v 110kw RHE	JCAE BSI
 407	CHASSIS NETWORK	2.0 HDI 16v 110kw RHE	SIEMENS BSM
 407	CHASSIS NETWORK	2.0 HDI 16v 120kw RHH	Body Computer BSI
 407	CHASSIS NETWORK	2.0 HDI 16v 120kw RHH	Body Computer BSM
 407	CHASSIS NETWORK	2.0 HDI 16v 120kw RHH	Body Computer BSR
 407	CHASSIS NETWORK	2.0 HDI 16v 120kw RHH	BSI
 407	CHASSIS NETWORK	2.0 HDI 16v 120kw RHH	JCAE BSI
 407	CHASSIS NETWORK	2.0 HDI 16v 120kw RHH	SIEMENS BSM
 407	CHASSIS NETWORK	2.0 HDI 16v 93kw RHL-FAP	Body Computer BSI
 407	CHASSIS NETWORK	2.0 HDI 16v 93kw RHL-FAP	Body Computer BSM
 407	CHASSIS NETWORK	2.0 HDI 16v 93kw RHL-FAP	Body Computer BSR
 407	CHASSIS NETWORK	2.0 HDI 16v 93kw RHL-FAP	BSI
 407	CHASSIS NETWORK	2.0 HDI 16v 93kw RHL-FAP	JCAE BSI
 407	CHASSIS NETWORK	2.0 HDI 16v 93kw RHL-FAP	SIEMENS BSM
 407	CHASSIS NETWORK	2.2 16v 116kw 3FZ	Body Computer BSI
 407	CHASSIS NETWORK	2.2 16v 116kw 3FZ	Body Computer BSM
 407	CHASSIS NETWORK	2.2 16v 116kw 3FZ	Body Computer BSR
 407	CHASSIS NETWORK	2.2 16v 116kw 3FZ	BSI
 407	CHASSIS NETWORK	2.2 16v 116kw 3FZ	JCAE BSI
 407	CHASSIS NETWORK	2.2 16v 116kw 3FZ	SIEMENS BSM
 407	CHASSIS NETWORK	2.2 16v 120kw 3FY	Body Computer BSI
 407	CHASSIS NETWORK	2.2 16v 120kw 3FY	Body Computer BSM
 407	CHASSIS NETWORK	2.2 16v 120kw 3FY	Body Computer BSR
 407	CHASSIS NETWORK	2.2 16v 120kw 3FY	BSI
 407	CHASSIS NETWORK	2.2 16v 120kw 3FY	JCAE BSI
 407	CHASSIS NETWORK	2.2 16v 120kw 3FY	SIEMENS BSM
 407	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP	Body Computer BSI
 407	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP	Body Computer BSM
 407	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP	Body Computer BSR
 407	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP	BSI
 407	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP	JCAE BSI
 407	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP	SIEMENS BSM
 407	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP	Body Computer BSI
 407	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP	Body Computer BSM
 407	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP	Body Computer BSR
 407	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP	BSI
 407	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP	JCAE BSI

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 407	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP	SIEMENS BSM
 407	CHASSIS NETWORK	2.2 HDI 16v 98kw 4HX-FAP	Body Computer BSI
 407	CHASSIS NETWORK	2.2 HDI 16v 98kw 4HX-FAP	Body Computer BSM
 407	CHASSIS NETWORK	2.2 HDI 16v 98kw 4HX-FAP	Body Computer BSR
 407	CHASSIS NETWORK	2.2 HDI 16v 98kw 4HX-FAP	BSI
 407	CHASSIS NETWORK	2.2 HDI 16v 98kw 4HX-FAP	JCAE BSI
 407	CHASSIS NETWORK	2.2 HDI 16v 98kw 4HX-FAP	SIEMENS BSM
 407	CHASSIS NETWORK	2.7 HDI V6 24v 150kw UHZ-FAP	Body Computer BSI
 407	CHASSIS NETWORK	2.7 HDI V6 24v 150kw UHZ-FAP	Body Computer BSM
 407	CHASSIS NETWORK	2.7 HDI V6 24v 150kw UHZ-FAP	Body Computer BSR
 407	CHASSIS NETWORK	2.7 HDI V6 24v 150kw UHZ-FAP	BSI
 407	CHASSIS NETWORK	2.7 HDI V6 24v 150kw UHZ-FAP	JCAE BSI
 407	CHASSIS NETWORK	2.7 HDI V6 24v 150kw UHZ-FAP	SIEMENS BSM
 407	CHASSIS NETWORK	3.0 HDI V6 16v 177kw X8Z	Body Computer BSI
 407	CHASSIS NETWORK	3.0 HDI V6 16v 177kw X8Z	Body Computer BSM
 407	CHASSIS NETWORK	3.0 HDI V6 16v 177kw X8Z	Body Computer BSR
 407	CHASSIS NETWORK	3.0 HDI V6 16v 177kw X8Z	BSI
 407	CHASSIS NETWORK	3.0 HDI V6 16v 177kw X8Z	JCAE BSI
 407	CHASSIS NETWORK	3.0 HDI V6 16v 177kw X8Z	SIEMENS BSM
 407	CHASSIS NETWORK	3.0 V6 24v 155kw XFU	Body Computer BSI
 407	CHASSIS NETWORK	3.0 V6 24v 155kw XFU	Body Computer BSM
 407	CHASSIS NETWORK	3.0 V6 24v 155kw XFU	Body Computer BSR
 407	CHASSIS NETWORK	3.0 V6 24v 155kw XFU	BSI
 407	CHASSIS NETWORK	3.0 V6 24v 155kw XFU	JCAE BSI
 407	CHASSIS NETWORK	3.0 V6 24v 155kw XFU	SIEMENS BSM
 407	CHASSIS NETWORK	3.0 V6 24v 155kw XFV	Body Computer BSI
 407	CHASSIS NETWORK	3.0 V6 24v 155kw XFV	Body Computer BSM
 407	CHASSIS NETWORK	3.0 V6 24v 155kw XFV	Body Computer BSR
 407	CHASSIS NETWORK	3.0 V6 24v 155kw XFV	BSI
 407	CHASSIS NETWORK	3.0 V6 24v 155kw XFV	JCAE BSI
 407	CHASSIS NETWORK	3.0 V6 24v 155kw XFV	SIEMENS BSM
 407	CLIMA	1.6 HDI 16v 80kw 9HY	CLIMA
 407	CLIMA	1.6 HDI 16v 80kw 9HY	DAV Clima Bizone
 407	CLIMA	1.6 HDI 16v 80kw 9HY	VISTEON SAC Monozone
 407	CLIMA	1.6 HDI 16v 80kw 9HZ-FAP	CLIMA
 407	CLIMA	1.6 HDI 16v 80kw 9HZ-FAP	DAV Clima Bizone
 407	CLIMA	1.6 HDI 16v 80kw 9HZ-FAP	VISTEON SAC Monozone
 407	CLIMA	1.8 16v 86kw 6FZ	CLIMA
 407	CLIMA	1.8 16v 86kw 6FZ	DAV Clima Bizone
 407	CLIMA	1.8 16v 86kw 6FZ	VISTEON SAC Monozone
 407	CLIMA	1.8 16v 92kw 6FY	CLIMA
 407	CLIMA	1.8 16v 92kw 6FY	DAV Clima Bizone
 407	CLIMA	1.8 16v 92kw 6FY	VISTEON SAC Monozone
 407	CLIMA	2.0 16v 103kw RFJ	CLIMA
 407	CLIMA	2.0 16v 103kw RFJ	DAV Clima Bizone
 407	CLIMA	2.0 16v 103kw RFJ	VISTEON SAC Monozone
 407	CLIMA	2.0 HDI 16v 100kw RHR-FAP	CLIMA
 407	CLIMA	2.0 HDI 16v 100kw RHR-FAP	DAV Clima Bizone
 407	CLIMA	2.0 HDI 16v 100kw RHR-FAP	VISTEON SAC Monozone
 407	CLIMA	2.0 HDI 16v 103kw RHF-FAP	CLIMA
 407	CLIMA	2.0 HDI 16v 103kw RHF-FAP	DAV Clima Bizone
 407	CLIMA	2.0 HDI 16v 103kw RHF-FAP	VISTEON SAC Monozone
 407	CLIMA	2.0 HDI 16v 110kw RFN	CLIMA
 407	CLIMA	2.0 HDI 16v 110kw RFN	DAV Clima Bizone
 407	CLIMA	2.0 HDI 16v 110kw RFN	VISTEON SAC Monozone
 407	CLIMA	2.0 HDI 16v 110kw RHE	CLIMA
 407	CLIMA	2.0 HDI 16v 110kw RHE	DAV Clima Bizone
 407	CLIMA	2.0 HDI 16v 110kw RHE	VISTEON SAC Monozone

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 407	CLIMA	2.0 HDI 16v 120kw RHH	CLIMA
 407	CLIMA	2.0 HDI 16v 120kw RHH	DAV Clima Bizone
 407	CLIMA	2.0 HDI 16v 120kw RHH	VISTEON SAC Monozone
 407	CLIMA	2.0 HDI 16v 93kw RHL-FAP	CLIMA
 407	CLIMA	2.0 HDI 16v 93kw RHL-FAP	DAV Clima Bizone
 407	CLIMA	2.0 HDI 16v 93kw RHL-FAP	VISTEON SAC Monozone
 407	CLIMA	2.2 16v 116kw 3FZ	CLIMA
 407	CLIMA	2.2 16v 116kw 3FZ	DAV Clima Bizone
 407	CLIMA	2.2 16v 116kw 3FZ	VISTEON SAC Monozone
 407	CLIMA	2.2 16v 120kw 3FY	CLIMA
 407	CLIMA	2.2 16v 120kw 3FY	DAV Clima Bizone
 407	CLIMA	2.2 16v 120kw 3FY	VISTEON SAC Monozone
 407	CLIMA	2.2 HDI 16v 120kw 4HP	CLIMA
 407	CLIMA	2.2 HDI 16v 120kw 4HP	DAV Clima Bizone
 407	CLIMA	2.2 HDI 16v 120kw 4HP	VISTEON SAC Monozone
 407	CLIMA	2.2 HDI 16v 125kw 4HT-FAP	CLIMA
 407	CLIMA	2.2 HDI 16v 125kw 4HT-FAP	DAV Clima Bizone
 407	CLIMA	2.2 HDI 16v 125kw 4HT-FAP	VISTEON SAC Monozone
 407	CLIMA	2.2 HDI 16v 98kw 4HX-FAP	CLIMA
 407	CLIMA	2.2 HDI 16v 98kw 4HX-FAP	DAV Clima Bizone
 407	CLIMA	2.2 HDI 16v 98kw 4HX-FAP	VISTEON SAC Monozone
 407	CLIMA	2.7 HDI V6 24v 150kw UHZ-FAP	CLIMA
 407	CLIMA	2.7 HDI V6 24v 150kw UHZ-FAP	DAV Clima Bizone
 407	CLIMA	2.7 HDI V6 24v 150kw UHZ-FAP	VISTEON SAC Monozone
 407	CLIMA	3.0 HDI V6 16v 177kw X8Z	CLIMA
 407	CLIMA	3.0 HDI V6 16v 177kw X8Z	DAV Clima Bizone
 407	CLIMA	3.0 HDI V6 16v 177kw X8Z	VISTEON SAC Monozone
 407	CLIMA	3.0 V6 24v 155kw XFU	CLIMA
 407	CLIMA	3.0 V6 24v 155kw XFU	DAV Clima Bizone
 407	CLIMA	3.0 V6 24v 155kw XFU	VISTEON SAC Monozone
 407	CLIMA	3.0 V6 24v 155kw XFV	CLIMA
 407	CLIMA	3.0 V6 24v 155kw XFV	DAV Clima Bizone
 407	CLIMA	3.0 V6 24v 155kw XFV	VISTEON SAC Monozone
 407	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HY	Phone Kit
 407	COMFORT SYSTEM	1.6 HDI 16v 80kw 9HZ-FAP	Phone Kit
 407	COMFORT SYSTEM	1.8 16v 86kw 6FZ	Phone Kit
 407	COMFORT SYSTEM	1.8 16v 92kw 6FY	Phone Kit
 407	COMFORT SYSTEM	2.0 16v 103kw RFJ	Phone Kit
 407	COMFORT SYSTEM	2.0 HDI 16v 100kw RHR-FAP	Phone Kit
 407	COMFORT SYSTEM	2.0 HDI 16v 103kw RHF-FAP	Phone Kit
 407	COMFORT SYSTEM	2.0 HDI 16v 110kw RFN	Phone Kit
 407	COMFORT SYSTEM	2.0 HDI 16v 110kw RHE	Phone Kit
 407	COMFORT SYSTEM	2.0 HDI 16v 120kw RHH	Phone Kit
 407	COMFORT SYSTEM	2.0 HDI 16v 93kw RHL-FAP	Phone Kit
 407	COMFORT SYSTEM	2.2 16v 116kw 3FZ	Phone Kit
 407	COMFORT SYSTEM	2.2 16v 120kw 3FY	Phone Kit
 407	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HP	Phone Kit
 407	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HT-FAP	Phone Kit
 407	COMFORT SYSTEM	2.2 HDI 16v 98kw 4HX-FAP	Phone Kit
 407	COMFORT SYSTEM	2.7 HDI V6 24v 150kw UHZ-FAP	Phone Kit
 407	COMFORT SYSTEM	3.0 HDI V6 16v 177kw X8Z	Phone Kit
 407	COMFORT SYSTEM	3.0 V6 24v 155kw XFU	Phone Kit
 407	COMFORT SYSTEM	3.0 V6 24v 155kw XFV	Phone Kit
 407	CONV. TOP/SUNROO	1.6 HDI 16v 80kw 9HY	Var.1
 407	CONV. TOP/SUNROO	1.6 HDI 16v 80kw 9HY	Var.2
 407	CONV. TOP/SUNROO	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 407	CONV. TOP/SUNROO	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 407	CONV. TOP/SUNROO	1.8 16v 86kw 6FZ	Var.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 407	CONV. TOP/SUNROO	1.8 16v 86kw 6FZ	Var.2
 407	CONV. TOP/SUNROO	1.8 16v 92kw 6FY	Var.1
 407	CONV. TOP/SUNROO	1.8 16v 92kw 6FY	Var.2
 407	CONV. TOP/SUNROO	2.0 16v 103kw RFJ	Var.1
 407	CONV. TOP/SUNROO	2.0 16v 103kw RFJ	Var.2
 407	CONV. TOP/SUNROO	2.0 HDI 16v 100kw RHR-FAP	Var.1
 407	CONV. TOP/SUNROO	2.0 HDI 16v 100kw RHR-FAP	Var.2
 407	CONV. TOP/SUNROO	2.0 HDI 16v 103kw RHF-FAP	Var.1
 407	CONV. TOP/SUNROO	2.0 HDI 16v 103kw RHF-FAP	Var.2
 407	CONV. TOP/SUNROO	2.0 HDI 16v 110kw RFN	Var.1
 407	CONV. TOP/SUNROO	2.0 HDI 16v 110kw RFN	Var.2
 407	CONV. TOP/SUNROO	2.0 HDI 16v 110kw RHE	Var.1
 407	CONV. TOP/SUNROO	2.0 HDI 16v 110kw RHE	Var.2
 407	CONV. TOP/SUNROO	2.0 HDI 16v 120kw RHH	Var.1
 407	CONV. TOP/SUNROO	2.0 HDI 16v 120kw RHH	Var.2
 407	CONV. TOP/SUNROO	2.0 HDI 16v 93kw RHL-FAP	Var.1
 407	CONV. TOP/SUNROO	2.0 HDI 16v 93kw RHL-FAP	Var.2
 407	CONV. TOP/SUNROO	2.2 16v 116kw 3FZ	Var.1
 407	CONV. TOP/SUNROO	2.2 16v 116kw 3FZ	Var.2
 407	CONV. TOP/SUNROO	2.2 16v 120kw 3FY	Var.1
 407	CONV. TOP/SUNROO	2.2 16v 120kw 3FY	Var.2
 407	CONV. TOP/SUNROO	2.2 HDI 16v 120kw 4HP	Var.1
 407	CONV. TOP/SUNROO	2.2 HDI 16v 120kw 4HP	Var.2
 407	CONV. TOP/SUNROO	2.2 HDI 16v 125kw 4HT-FAP	Var.1
 407	CONV. TOP/SUNROO	2.2 HDI 16v 125kw 4HT-FAP	Var.2
 407	CONV. TOP/SUNROO	2.2 HDI 16v 98kw 4HX-FAP	Var.1
 407	CONV. TOP/SUNROO	2.2 HDI 16v 98kw 4HX-FAP	Var.2
 407	CONV. TOP/SUNROO	2.7 HDI V6 24v 150kw UHZ-FAP	Var.1
 407	CONV. TOP/SUNROO	2.7 HDI V6 24v 150kw UHZ-FAP	Var.2
 407	CONV. TOP/SUNROO	3.0 HDI V6 16v 177kw X8Z	Var.1
 407	CONV. TOP/SUNROO	3.0 HDI V6 16v 177kw X8Z	Var.2
 407	CONV. TOP/SUNROO	3.0 V6 24v 155kw XFU	Var.1
 407	CONV. TOP/SUNROO	3.0 V6 24v 155kw XFU	Var.2
 407	CONV. TOP/SUNROO	3.0 V6 24v 155kw XFV	Var.1
 407	CONV. TOP/SUNROO	3.0 V6 24v 155kw XFV	Var.2
 407	DASHBOARD	1.6 HDI 16v 80kw 9HY	
 407	DASHBOARD	1.6 HDI 16v 80kw 9HY	Marelli IPC 03.00
 407	DASHBOARD	1.6 HDI 16v 80kw 9HY	VDO Dashboard
 407	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP	
 407	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP	Marelli IPC 03.00
 407	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP	VDO Dashboard
 407	DASHBOARD	1.8 16v 86kw 6FZ	
 407	DASHBOARD	1.8 16v 86kw 6FZ	Marelli IPC 03.00
 407	DASHBOARD	1.8 16v 86kw 6FZ	VDO Dashboard
 407	DASHBOARD	1.8 16v 92kw 6FY	
 407	DASHBOARD	1.8 16v 92kw 6FY	Marelli IPC 03.00
 407	DASHBOARD	1.8 16v 92kw 6FY	VDO Dashboard
 407	DASHBOARD	2.0 16v 103kw RFJ	
 407	DASHBOARD	2.0 16v 103kw RFJ	Marelli IPC 03.00
 407	DASHBOARD	2.0 16v 103kw RFJ	VDO Dashboard
 407	DASHBOARD	2.0 HDI 16v 100kw RHR-FAP	
 407	DASHBOARD	2.0 HDI 16v 100kw RHR-FAP	Marelli IPC 03.00
 407	DASHBOARD	2.0 HDI 16v 100kw RHR-FAP	VDO Dashboard
 407	DASHBOARD	2.0 HDI 16v 103kw RHF-FAP	
 407	DASHBOARD	2.0 HDI 16v 103kw RHF-FAP	Marelli IPC 03.00
 407	DASHBOARD	2.0 HDI 16v 103kw RHF-FAP	VDO Dashboard
 407	DASHBOARD	2.0 HDI 16v 110kw RFN	
 407	DASHBOARD	2.0 HDI 16v 110kw RFN	Marelli IPC 03.00

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 407	DASHBOARD	2.0 HDI 16v 110kw RFN	VDO Dashboard
 407	DASHBOARD	2.0 HDI 16v 110kw RHE	
 407	DASHBOARD	2.0 HDI 16v 110kw RHE	Marelli IPC 03.00
 407	DASHBOARD	2.0 HDI 16v 110kw RHE	VDO Dashboard
 407	DASHBOARD	2.0 HDI 16v 120kw RHH	
 407	DASHBOARD	2.0 HDI 16v 120kw RHH	Marelli IPC 03.00
 407	DASHBOARD	2.0 HDI 16v 120kw RHH	VDO Dashboard
 407	DASHBOARD	2.0 HDI 16v 93kw RHL-FAP	
 407	DASHBOARD	2.0 HDI 16v 93kw RHL-FAP	Marelli IPC 03.00
 407	DASHBOARD	2.0 HDI 16v 93kw RHL-FAP	VDO Dashboard
 407	DASHBOARD	2.2 16v 116kw 3FZ	
 407	DASHBOARD	2.2 16v 116kw 3FZ	Marelli IPC 03.00
 407	DASHBOARD	2.2 16v 116kw 3FZ	VDO Dashboard
 407	DASHBOARD	2.2 16v 120kw 3FY	
 407	DASHBOARD	2.2 16v 120kw 3FY	Marelli IPC 03.00
 407	DASHBOARD	2.2 16v 120kw 3FY	VDO Dashboard
 407	DASHBOARD	2.2 HDI 16v 120kw 4HP	
 407	DASHBOARD	2.2 HDI 16v 120kw 4HP	Marelli IPC 03.00
 407	DASHBOARD	2.2 HDI 16v 120kw 4HP	VDO Dashboard
 407	DASHBOARD	2.2 HDI 16v 125kw 4HT-FAP	
 407	DASHBOARD	2.2 HDI 16v 125kw 4HT-FAP	Marelli IPC 03.00
 407	DASHBOARD	2.2 HDI 16v 125kw 4HT-FAP	VDO Dashboard
 407	DASHBOARD	2.2 HDI 16v 98kw 4HX-FAP	
 407	DASHBOARD	2.2 HDI 16v 98kw 4HX-FAP	Marelli IPC 03.00
 407	DASHBOARD	2.2 HDI 16v 98kw 4HX-FAP	VDO Dashboard
 407	DASHBOARD	2.7 HDI V6 24v 150kw UHZ-FAP	
 407	DASHBOARD	2.7 HDI V6 24v 150kw UHZ-FAP	Marelli IPC 03.00
 407	DASHBOARD	2.7 HDI V6 24v 150kw UHZ-FAP	VDO Dashboard
 407	DASHBOARD	3.0 HDI V6 16v 177kw X8Z	
 407	DASHBOARD	3.0 HDI V6 16v 177kw X8Z	Marelli IPC 03.00
 407	DASHBOARD	3.0 HDI V6 16v 177kw X8Z	VDO Dashboard
 407	DASHBOARD	3.0 V6 24v 155kw XFU	
 407	DASHBOARD	3.0 V6 24v 155kw XFU	Marelli IPC 03.00
 407	DASHBOARD	3.0 V6 24v 155kw XFU	VDO Dashboard
 407	DASHBOARD	3.0 V6 24v 155kw XFV	
 407	DASHBOARD	3.0 V6 24v 155kw XFV	Marelli IPC 03.00
 407	DASHBOARD	3.0 V6 24v 155kw XFV	VDO Dashboard
 407	DIESEL ADDITION	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 407	DIESEL ADDITION	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 407	DIESEL ADDITION	2.0 HDI 16v 100kw RHR-FAP	Var.1
 407	DIESEL ADDITION	2.0 HDI 16v 100kw RHR-FAP	Var.2
 407	DIESEL ADDITION	2.0 HDI 16v 103kw RHF-FAP	Var.1
 407	DIESEL ADDITION	2.0 HDI 16v 103kw RHF-FAP	Var.2
 407	DIESEL ADDITION	2.0 HDI 16v 93kw RHL-FAP	Var.1
 407	DIESEL ADDITION	2.0 HDI 16v 93kw RHL-FAP	Var.2
 407	DIESEL ADDITION	2.2 HDI 16v 98kw 4HX-FAP	Var.1
 407	DIESEL ADDITION	2.2 HDI 16v 98kw 4HX-FAP	Var.2
 407	DIESEL ADDITION	2.7 HDI V6 24v 150kw UHZ-FAP	Var.1
 407	DIESEL ADDITION	2.7 HDI V6 24v 150kw UHZ-FAP	Var.2
 407	DIESEL ADDITION	3.0 HDI V6 16v 177kw X8Z	Var.1
 407	DIESEL ADDITION	3.0 HDI V6 16v 177kw X8Z	Var.2
 407	DRIVER SIDE DOOR	1.6 HDI 16v 80kw 9HY	Brose DriverDoor
 407	DRIVER SIDE DOOR	1.6 HDI 16v 80kw 9HY	Var.1
 407	DRIVER SIDE DOOR	1.6 HDI 16v 80kw 9HY	Var.2
 407	DRIVER SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	Brose DriverDoor
 407	DRIVER SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 407	DRIVER SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 407	DRIVER SIDE DOOR	1.8 16v 86kw 6FZ	Brose DriverDoor

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 407	DRIVER SIDE DOOR	1.8 16v 86kw 6FZ	Var.1
 407	DRIVER SIDE DOOR	1.8 16v 86kw 6FZ	Var.2
 407	DRIVER SIDE DOOR	1.8 16v 92kw 6FY	Brose DriverDoor
 407	DRIVER SIDE DOOR	1.8 16v 92kw 6FY	Var.1
 407	DRIVER SIDE DOOR	1.8 16v 92kw 6FY	Var.2
 407	DRIVER SIDE DOOR	2.0 16v 103kw RFJ	Brose DriverDoor
 407	DRIVER SIDE DOOR	2.0 16v 103kw RFJ	Var.1
 407	DRIVER SIDE DOOR	2.0 16v 103kw RFJ	Var.2
 407	DRIVER SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	Brose DriverDoor
 407	DRIVER SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	Var.1
 407	DRIVER SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	Var.2
 407	DRIVER SIDE DOOR	2.0 HDI 16v 103kw RHF-FAP	Brose DriverDoor
 407	DRIVER SIDE DOOR	2.0 HDI 16v 103kw RHF-FAP	Var.1
 407	DRIVER SIDE DOOR	2.0 HDI 16v 103kw RHF-FAP	Var.2
 407	DRIVER SIDE DOOR	2.0 HDI 16v 110kw RFN	Brose DriverDoor
 407	DRIVER SIDE DOOR	2.0 HDI 16v 110kw RFN	Var.1
 407	DRIVER SIDE DOOR	2.0 HDI 16v 110kw RFN	Var.2
 407	DRIVER SIDE DOOR	2.0 HDI 16v 110kw RHE	Brose DriverDoor
 407	DRIVER SIDE DOOR	2.0 HDI 16v 110kw RHE	Var.1
 407	DRIVER SIDE DOOR	2.0 HDI 16v 110kw RHE	Var.2
 407	DRIVER SIDE DOOR	2.0 HDI 16v 120kw RHH	Brose DriverDoor
 407	DRIVER SIDE DOOR	2.0 HDI 16v 120kw RHH	Var.1
 407	DRIVER SIDE DOOR	2.0 HDI 16v 120kw RHH	Var.2
 407	DRIVER SIDE DOOR	2.0 HDI 16v 93kw RHL-FAP	Brose DriverDoor
 407	DRIVER SIDE DOOR	2.0 HDI 16v 93kw RHL-FAP	Var.1
 407	DRIVER SIDE DOOR	2.0 HDI 16v 93kw RHL-FAP	Var.2
 407	DRIVER SIDE DOOR	2.2 16v 116kw 3FZ	Brose DriverDoor
 407	DRIVER SIDE DOOR	2.2 16v 116kw 3FZ	Var.1
 407	DRIVER SIDE DOOR	2.2 16v 116kw 3FZ	Var.2
 407	DRIVER SIDE DOOR	2.2 16v 120kw 3FY	Brose DriverDoor
 407	DRIVER SIDE DOOR	2.2 16v 120kw 3FY	Var.1
 407	DRIVER SIDE DOOR	2.2 16v 120kw 3FY	Var.2
 407	DRIVER SIDE DOOR	2.2 HDI 16v 120kw 4HP	Brose DriverDoor
 407	DRIVER SIDE DOOR	2.2 HDI 16v 120kw 4HP	Var.1
 407	DRIVER SIDE DOOR	2.2 HDI 16v 120kw 4HP	Var.2
 407	DRIVER SIDE DOOR	2.2 HDI 16v 125kw 4HT-FAP	Brose DriverDoor
 407	DRIVER SIDE DOOR	2.2 HDI 16v 125kw 4HT-FAP	Var.1
 407	DRIVER SIDE DOOR	2.2 HDI 16v 125kw 4HT-FAP	Var.2
 407	DRIVER SIDE DOOR	2.2 HDI 16v 98kw 4HX-FAP	Brose DriverDoor
 407	DRIVER SIDE DOOR	2.2 HDI 16v 98kw 4HX-FAP	Var.1
 407	DRIVER SIDE DOOR	2.2 HDI 16v 98kw 4HX-FAP	Var.2
 407	DRIVER SIDE DOOR	2.7 HDI V6 24v 150kw UHZ-FAP	Brose DriverDoor
 407	DRIVER SIDE DOOR	2.7 HDI V6 24v 150kw UHZ-FAP	Var.1
 407	DRIVER SIDE DOOR	2.7 HDI V6 24v 150kw UHZ-FAP	Var.2
 407	DRIVER SIDE DOOR	3.0 HDI V6 16v 177kw X8Z	Brose DriverDoor
 407	DRIVER SIDE DOOR	3.0 HDI V6 16v 177kw X8Z	Var.1
 407	DRIVER SIDE DOOR	3.0 HDI V6 16v 177kw X8Z	Var.2
 407	DRIVER SIDE DOOR	3.0 V6 24v 155kw XFU	Brose DriverDoor
 407	DRIVER SIDE DOOR	3.0 V6 24v 155kw XFU	Var.1
 407	DRIVER SIDE DOOR	3.0 V6 24v 155kw XFU	Var.2
 407	DRIVER SIDE DOOR	3.0 V6 24v 155kw XFV	Brose DriverDoor
 407	DRIVER SIDE DOOR	3.0 V6 24v 155kw XFV	Var.1
 407	DRIVER SIDE DOOR	3.0 V6 24v 155kw XFV	Var.2
 407	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HY	HPI EPS GEP
 407	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HY	Var.1
 407	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HY	Var.2
 407	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	HPI EPS GEP
 407	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	Var.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 407	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 407	ELECTRIC STEERING	1.8 16v 86kw 6FZ	HPI EPS GEP
 407	ELECTRIC STEERING	1.8 16v 86kw 6FZ	Var.1
 407	ELECTRIC STEERING	1.8 16v 86kw 6FZ	Var.2
 407	ELECTRIC STEERING	1.8 16v 92kw 6FY	HPI EPS GEP
 407	ELECTRIC STEERING	1.8 16v 92kw 6FY	Var.1
 407	ELECTRIC STEERING	1.8 16v 92kw 6FY	Var.2
 407	ELECTRIC STEERING	2.0 16v 103kw RFJ	HPI EPS GEP
 407	ELECTRIC STEERING	2.0 16v 103kw RFJ	Var.1
 407	ELECTRIC STEERING	2.0 16v 103kw RFJ	Var.2
 407	ELECTRIC STEERING	2.0 HDI 16v 100kw RHR-FAP	HPI EPS GEP
 407	ELECTRIC STEERING	2.0 HDI 16v 100kw RHR-FAP	Var.1
 407	ELECTRIC STEERING	2.0 HDI 16v 100kw RHR-FAP	Var.2
 407	ELECTRIC STEERING	2.0 HDI 16v 103kw RHF-FAP	HPI EPS GEP
 407	ELECTRIC STEERING	2.0 HDI 16v 103kw RHF-FAP	Var.1
 407	ELECTRIC STEERING	2.0 HDI 16v 103kw RHF-FAP	Var.2
 407	ELECTRIC STEERING	2.0 HDI 16v 110kw RFN	HPI EPS GEP
 407	ELECTRIC STEERING	2.0 HDI 16v 110kw RFN	Var.1
 407	ELECTRIC STEERING	2.0 HDI 16v 110kw RFN	Var.2
 407	ELECTRIC STEERING	2.0 HDI 16v 110kw RHE	HPI EPS GEP
 407	ELECTRIC STEERING	2.0 HDI 16v 110kw RHE	Var.1
 407	ELECTRIC STEERING	2.0 HDI 16v 110kw RHE	Var.2
 407	ELECTRIC STEERING	2.0 HDI 16v 120kw RHH	HPI EPS GEP
 407	ELECTRIC STEERING	2.0 HDI 16v 120kw RHH	Var.1
 407	ELECTRIC STEERING	2.0 HDI 16v 120kw RHH	Var.2
 407	ELECTRIC STEERING	2.0 HDI 16v 93kw RHL-FAP	HPI EPS GEP
 407	ELECTRIC STEERING	2.0 HDI 16v 93kw RHL-FAP	Var.1
 407	ELECTRIC STEERING	2.0 HDI 16v 93kw RHL-FAP	Var.2
 407	ELECTRIC STEERING	2.2 16v 116kw 3FZ	HPI EPS GEP
 407	ELECTRIC STEERING	2.2 16v 116kw 3FZ	Var.1
 407	ELECTRIC STEERING	2.2 16v 116kw 3FZ	Var.2
 407	ELECTRIC STEERING	2.2 16v 120kw 3FY	HPI EPS GEP
 407	ELECTRIC STEERING	2.2 16v 120kw 3FY	Var.1
 407	ELECTRIC STEERING	2.2 16v 120kw 3FY	Var.2
 407	ELECTRIC STEERING	2.2 HDI 16v 120kw 4HP	HPI EPS GEP
 407	ELECTRIC STEERING	2.2 HDI 16v 120kw 4HP	Var.1
 407	ELECTRIC STEERING	2.2 HDI 16v 120kw 4HP	Var.2
 407	ELECTRIC STEERING	2.2 HDI 16v 125kw 4HT-FAP	HPI EPS GEP
 407	ELECTRIC STEERING	2.2 HDI 16v 125kw 4HT-FAP	Var.1
 407	ELECTRIC STEERING	2.2 HDI 16v 125kw 4HT-FAP	Var.2
 407	ELECTRIC STEERING	2.2 HDI 16v 98kw 4HX-FAP	HPI EPS GEP
 407	ELECTRIC STEERING	2.2 HDI 16v 98kw 4HX-FAP	Var.1
 407	ELECTRIC STEERING	2.2 HDI 16v 98kw 4HX-FAP	Var.2
 407	ELECTRIC STEERING	2.7 HDI V6 24v 150kw UHZ-FAP	HPI EPS GEP
 407	ELECTRIC STEERING	2.7 HDI V6 24v 150kw UHZ-FAP	Var.1
 407	ELECTRIC STEERING	2.7 HDI V6 24v 150kw UHZ-FAP	Var.2
 407	ELECTRIC STEERING	3.0 HDI V6 16v 177kw X8Z	HPI EPS GEP
 407	ELECTRIC STEERING	3.0 HDI V6 16v 177kw X8Z	Var.1
 407	ELECTRIC STEERING	3.0 HDI V6 16v 177kw X8Z	Var.2
 407	ELECTRIC STEERING	3.0 V6 24v 155kw XFU	HPI EPS GEP
 407	ELECTRIC STEERING	3.0 V6 24v 155kw XFU	Var.1
 407	ELECTRIC STEERING	3.0 V6 24v 155kw XFU	Var.2
 407	ELECTRIC STEERING	3.0 V6 24v 155kw XFV	HPI EPS GEP
 407	ELECTRIC STEERING	3.0 V6 24v 155kw XFV	Var.1
 407	ELECTRIC STEERING	3.0 V6 24v 155kw XFV	Var.2
 407	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail
 407	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.1
 407	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 407	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail
 407	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 407	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.2
 407	ENGINE MANAGEME	1.8 16v 86kw 6FZ	SAGEM S2000 PM1
 407	ENGINE MANAGEME	1.8 16v 92kw 6FY	Marelli MM6LPB
 407	ENGINE MANAGEME	1.8 16v 92kw 6FY	Marelli MPI MM6LPB
 407	ENGINE MANAGEME	2.0 16v 103kw RFJ	Marelli MM6LPB
 407	ENGINE MANAGEME	2.0 16v 103kw RFJ	Marelli MPI MM6LPB
 407	ENGINE MANAGEME	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803 Common Rail Var.1
 407	ENGINE MANAGEME	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803 Common Rail Var.2
 407	ENGINE MANAGEME	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803A Common Rail Var.1
 407	ENGINE MANAGEME	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803A Common Rail Var.2
 407	ENGINE MANAGEME	2.0 HDI 16v 103kw RHF-FAP	SIEMENS SID 803 Common Rail Var.1
 407	ENGINE MANAGEME	2.0 HDI 16v 103kw RHF-FAP	SIEMENS SID 803 Common Rail Var.2
 407	ENGINE MANAGEME	2.0 HDI 16v 103kw RHF-FAP	SIEMENS SID 803A Common Rail Var.1
 407	ENGINE MANAGEME	2.0 HDI 16v 103kw RHF-FAP	SIEMENS SID 803A Common Rail Var.2
 407	ENGINE MANAGEME	2.0 HDI 16v 110kw RFN	EOBD
 407	ENGINE MANAGEME	2.0 HDI 16v 110kw RHE	EOBD
 407	ENGINE MANAGEME	2.0 HDI 16v 120kw RHH	EOBD
 407	ENGINE MANAGEME	2.0 HDI 16v 93kw RHL-FAP	SIEMENS SID 803 Common Rail Var.1
 407	ENGINE MANAGEME	2.0 HDI 16v 93kw RHL-FAP	SIEMENS SID 803 Common Rail Var.2
 407	ENGINE MANAGEME	2.0 HDI 16v 93kw RHL-FAP	SIEMENS SID 803A Common Rail Var.1
 407	ENGINE MANAGEME	2.0 HDI 16v 93kw RHL-FAP	SIEMENS SID 803A Common Rail Var.2
 407	ENGINE MANAGEME	2.2 16v 116kw 3FZ	EOBD
 407	ENGINE MANAGEME	2.2 16v 120kw 3FY	EOBD
 407	ENGINE MANAGEME	2.2 HDI 16v 120kw 4HP	EOBD
 407	ENGINE MANAGEME	2.2 HDI 16v 125kw 4HT-FAP	EOBD
 407	ENGINE MANAGEME	2.2 HDI 16v 98kw 4HX-FAP	BOSCH EDC 15 C2 Common Rail
 407	ENGINE MANAGEME	2.7 HDI V6 24v 150kw UHZ-FAP	EOBD
 407	ENGINE MANAGEME	3.0 HDI V6 16v 177kw X8Z	EOBD
 407	ENGINE MANAGEME	3.0 V6 24v 155kw XFU	BOSCH ME 7.4.7
 407	ENGINE MANAGEME	3.0 V6 24v 155kw XFV	BOSCH ME 7.4.7
 407	HEADLIGHT LEVEL	1.6 HDI 16v 80kw 9HY	
 407	HEADLIGHT LEVEL	1.6 HDI 16v 80kw 9HZ-FAP	
 407	HEADLIGHT LEVEL	1.8 16v 86kw 6FZ	
 407	HEADLIGHT LEVEL	1.8 16v 92kw 6FY	
 407	HEADLIGHT LEVEL	2.0 16v 103kw RFJ	
 407	HEADLIGHT LEVEL	2.0 HDI 16v 100kw RHR-FAP	
 407	HEADLIGHT LEVEL	2.0 HDI 16v 103kw RHF-FAP	
 407	HEADLIGHT LEVEL	2.0 HDI 16v 110kw RFN	
 407	HEADLIGHT LEVEL	2.0 HDI 16v 110kw RHE	
 407	HEADLIGHT LEVEL	2.0 HDI 16v 120kw RHH	
 407	HEADLIGHT LEVEL	2.0 HDI 16v 93kw RHL-FAP	
 407	HEADLIGHT LEVEL	2.2 16v 116kw 3FZ	
 407	HEADLIGHT LEVEL	2.2 16v 120kw 3FY	
 407	HEADLIGHT LEVEL	2.2 HDI 16v 120kw 4HP	
 407	HEADLIGHT LEVEL	2.2 HDI 16v 125kw 4HT-FAP	
 407	HEADLIGHT LEVEL	2.2 HDI 16v 98kw 4HX-FAP	
 407	HEADLIGHT LEVEL	2.7 HDI V6 24v 150kw UHZ-FAP	
 407	HEADLIGHT LEVEL	3.0 HDI V6 16v 177kw X8Z	
 407	HEADLIGHT LEVEL	3.0 V6 24v 155kw XFU	
 407	HEADLIGHT LEVEL	3.0 V6 24v 155kw XFV	
 407	KEY ENCODE	1.6 HDI 16v 80kw 9HY	JCAE Body Computer
 407	KEY ENCODE	1.6 HDI 16v 80kw 9HZ-FAP	JCAE Body Computer
 407	KEY ENCODE	1.8 16v 86kw 6FZ	JCAE Body Computer
 407	KEY ENCODE	1.8 16v 92kw 6FY	JCAE Body Computer
 407	KEY ENCODE	2.0 16v 103kw RFJ	JCAE Body Computer
 407	KEY ENCODE	2.0 HDI 16v 100kw RHR-FAP	JCAE Body Computer

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 407	KEY ENCODE	2.0 HDI 16v 103kw RHF-FAP	JCAE Body Computer
 407	KEY ENCODE	2.0 HDI 16v 110kw RFN	JCAE Body Computer
 407	KEY ENCODE	2.0 HDI 16v 110kw RHE	JCAE Body Computer
 407	KEY ENCODE	2.0 HDI 16v 120kw RHH	JCAE Body Computer
 407	KEY ENCODE	2.0 HDI 16v 93kw RHL-FAP	JCAE Body Computer
 407	KEY ENCODE	2.2 16v 116kw 3FZ	JCAE Body Computer
 407	KEY ENCODE	2.2 16v 120kw 3FY	JCAE Body Computer
 407	KEY ENCODE	2.2 HDI 16v 120kw 4HP	JCAE Body Computer
 407	KEY ENCODE	2.2 HDI 16v 125kw 4HT-FAP	JCAE Body Computer
 407	KEY ENCODE	2.2 HDI 16v 98kw 4HX-FAP	JCAE Body Computer
 407	KEY ENCODE	2.7 HDI V6 24v 150kw UHZ-FAP	JCAE Body Computer
 407	KEY ENCODE	3.0 HDI V6 16v 177kw X8Z	JCAE Body Computer
 407	KEY ENCODE	3.0 V6 24v 155kw XFU	JCAE Body Computer
 407	KEY ENCODE	3.0 V6 24v 155kw Xfv	JCAE Body Computer
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	A/T AM6
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	A/T AM6
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	AirBag CENTRAL
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	AirBag CENTRAL
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.1
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.1
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.1
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.1
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.1
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.1
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.1
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.2
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.2
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.2
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.2
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.2
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.2
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.2
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.2
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.2
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.2
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.2
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BOSCH EDC 16 C34 Common Rail Var.2
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BSI
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	BSI
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	JCAE Body Computer MANUAL
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.1
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.1
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.1
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.2
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.2
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.2
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.2
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	Var.3
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	VDO Dashboard
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HY	VDO Dashboard
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	A/T AM6
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	A/T AM6
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL
 407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL
407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL		SYSTEM TYPE	ENGINE / SYSTEM	ECU
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.2
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.2
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.2
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.2
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.2
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.2
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BSI
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BSI
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	JCAE Body Computer MANUAL
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Siemens-JCAE AUTODETECT
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Siemens-JCAE AUTODETECT
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Siemens-JCAE AUTODETECT
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Siemens-JCAE AUTODETECT
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.3
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	VDO Dashboard
	407	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	VDO Dashboard
	407	MAINTENANCE	1.8 16v 86kw 6FZ	A/T AM6
	407	MAINTENANCE	1.8 16v 86kw 6FZ	A/T AM6
	407	MAINTENANCE	1.8 16v 86kw 6FZ	AirBag CENTRAL
	407	MAINTENANCE	1.8 16v 86kw 6FZ	AirBag CENTRAL
	407	MAINTENANCE	1.8 16v 86kw 6FZ	BSI
	407	MAINTENANCE	1.8 16v 86kw 6FZ	BSI
	407	MAINTENANCE	1.8 16v 86kw 6FZ	JCAE Body Computer MANUAL
	407	MAINTENANCE	1.8 16v 86kw 6FZ	Siemens-JCAE AUTODETECT
	407	MAINTENANCE	1.8 16v 86kw 6FZ	Siemens-JCAE AUTODETECT
	407	MAINTENANCE	1.8 16v 86kw 6FZ	Siemens-JCAE AUTODETECT
	407	MAINTENANCE	1.8 16v 86kw 6FZ	Siemens-JCAE AUTODETECT
	407	MAINTENANCE	1.8 16v 86kw 6FZ	Var.1
	407	MAINTENANCE	1.8 16v 86kw 6FZ	Var.1
	407	MAINTENANCE	1.8 16v 86kw 6FZ	Var.1
	407	MAINTENANCE	1.8 16v 86kw 6FZ	Var.2
	407	MAINTENANCE	1.8 16v 86kw 6FZ	Var.2
	407	MAINTENANCE	1.8 16v 86kw 6FZ	Var.2
	407	MAINTENANCE	1.8 16v 86kw 6FZ	Var.3
	407	MAINTENANCE	1.8 16v 86kw 6FZ	VDO Dashboard
	407	MAINTENANCE	1.8 16v 86kw 6FZ	VDO Dashboard
	407	MAINTENANCE	1.8 16v 92kw 6FY	A/T AM6
	407	MAINTENANCE	1.8 16v 92kw 6FY	A/T AM6
	407	MAINTENANCE	1.8 16v 92kw 6FY	AirBag CENTRAL
	407	MAINTENANCE	1.8 16v 92kw 6FY	AirBag CENTRAL
	407	MAINTENANCE	1.8 16v 92kw 6FY	BSI
	407	MAINTENANCE	1.8 16v 92kw 6FY	BSI

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 407	MAINTENANCE	1.8 16v 92kw 6FY	JCAE Body Computer MANUAL
 407	MAINTENANCE	1.8 16v 92kw 6FY	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	1.8 16v 92kw 6FY	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	1.8 16v 92kw 6FY	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	1.8 16v 92kw 6FY	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	1.8 16v 92kw 6FY	Var.1
 407	MAINTENANCE	1.8 16v 92kw 6FY	Var.1
 407	MAINTENANCE	1.8 16v 92kw 6FY	Var.1
 407	MAINTENANCE	1.8 16v 92kw 6FY	Var.2
 407	MAINTENANCE	1.8 16v 92kw 6FY	Var.2
 407	MAINTENANCE	1.8 16v 92kw 6FY	Var.2
 407	MAINTENANCE	1.8 16v 92kw 6FY	Var.3
 407	MAINTENANCE	1.8 16v 92kw 6FY	VDO Dashboard
 407	MAINTENANCE	1.8 16v 92kw 6FY	VDO Dashboard
 407	MAINTENANCE	2.0 16v 103kw RFJ	A/T AM6
 407	MAINTENANCE	2.0 16v 103kw RFJ	A/T AM6
 407	MAINTENANCE	2.0 16v 103kw RFJ	AirBag CENTRAL
 407	MAINTENANCE	2.0 16v 103kw RFJ	AirBag CENTRAL
 407	MAINTENANCE	2.0 16v 103kw RFJ	BSI
 407	MAINTENANCE	2.0 16v 103kw RFJ	BSI
 407	MAINTENANCE	2.0 16v 103kw RFJ	JCAE Body Computer MANUAL
 407	MAINTENANCE	2.0 16v 103kw RFJ	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.0 16v 103kw RFJ	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.0 16v 103kw RFJ	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.0 16v 103kw RFJ	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.0 16v 103kw RFJ	Var.1
 407	MAINTENANCE	2.0 16v 103kw RFJ	Var.1
 407	MAINTENANCE	2.0 16v 103kw RFJ	Var.1
 407	MAINTENANCE	2.0 16v 103kw RFJ	Var.2
 407	MAINTENANCE	2.0 16v 103kw RFJ	Var.2
 407	MAINTENANCE	2.0 16v 103kw RFJ	Var.2
 407	MAINTENANCE	2.0 16v 103kw RFJ	Var.2
 407	MAINTENANCE	2.0 16v 103kw RFJ	Var.3
 407	MAINTENANCE	2.0 16v 103kw RFJ	VDO Dashboard
 407	MAINTENANCE	2.0 16v 103kw RFJ	VDO Dashboard
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	A/T AM6
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	A/T AM6
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	AirBag CENTRAL
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	AirBag CENTRAL
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	BSI
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	BSI
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	JCAE Body Computer MANUAL
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803 Common Rail Var.1
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803 Common Rail Var.1
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803 Common Rail Var.1
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803 Common Rail Var.2
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803 Common Rail Var.2
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803 Common Rail Var.2
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803A Common Rail Var.1
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803A Common Rail Var.1
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803A Common Rail Var.1
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803A Common Rail Var.2
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803A Common Rail Var.2
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803A Common Rail Var.2
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.1
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.1
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.1
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.1
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.1
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.1
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.1
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.2
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.2
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.2
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.2
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.2
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.2
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.2
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.2
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Var.3
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	VDO Dashboard
 407	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	VDO Dashboard
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	A/T AM6
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	A/T AM6
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	AirBag CENTRAL
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	AirBag CENTRAL
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	BSI
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	BSI
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	JCAE Body Computer MANUAL
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	SIEMENS SID 803 Common Rail Var.1
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	SIEMENS SID 803 Common Rail Var.1
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	SIEMENS SID 803 Common Rail Var.1
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	SIEMENS SID 803 Common Rail Var.2
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	SIEMENS SID 803 Common Rail Var.2
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	SIEMENS SID 803 Common Rail Var.2
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	SIEMENS SID 803A Common Rail Var.1
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	SIEMENS SID 803A Common Rail Var.1
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	SIEMENS SID 803A Common Rail Var.1
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	SIEMENS SID 803A Common Rail Var.2
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	SIEMENS SID 803A Common Rail Var.2
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	SIEMENS SID 803A Common Rail Var.2
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	Var.1
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	Var.1
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	Var.1
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	Var.1
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	Var.1
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	Var.1
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	Var.1
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	Var.2
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	Var.2
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	Var.2
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	Var.2
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	Var.2
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	Var.2
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	Var.2
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	Var.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	VDO Dashboard
 407	MAINTENANCE	2.0 HDI 16v 103kw RHF-FAP	VDO Dashboard
 407	MAINTENANCE	2.0 HDI 16v 110kw RFN	A/T AM6
 407	MAINTENANCE	2.0 HDI 16v 110kw RFN	A/T AM6
 407	MAINTENANCE	2.0 HDI 16v 110kw RFN	AirBag CENTRAL
 407	MAINTENANCE	2.0 HDI 16v 110kw RFN	AirBag CENTRAL
 407	MAINTENANCE	2.0 HDI 16v 110kw RFN	BSI
 407	MAINTENANCE	2.0 HDI 16v 110kw RFN	BSI
 407	MAINTENANCE	2.0 HDI 16v 110kw RFN	JCAE Body Computer MANUAL
 407	MAINTENANCE	2.0 HDI 16v 110kw RFN	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.0 HDI 16v 110kw RFN	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.0 HDI 16v 110kw RFN	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.0 HDI 16v 110kw RFN	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.0 HDI 16v 110kw RFN	Var.1
 407	MAINTENANCE	2.0 HDI 16v 110kw RFN	Var.1
 407	MAINTENANCE	2.0 HDI 16v 110kw RFN	Var.1
 407	MAINTENANCE	2.0 HDI 16v 110kw RFN	Var.2
 407	MAINTENANCE	2.0 HDI 16v 110kw RFN	Var.2
 407	MAINTENANCE	2.0 HDI 16v 110kw RFN	Var.2
 407	MAINTENANCE	2.0 HDI 16v 110kw RFN	Var.3
 407	MAINTENANCE	2.0 HDI 16v 110kw RFN	VDO Dashboard
 407	MAINTENANCE	2.0 HDI 16v 110kw RFN	VDO Dashboard
 407	MAINTENANCE	2.0 HDI 16v 110kw RHE	A/T AM6
 407	MAINTENANCE	2.0 HDI 16v 110kw RHE	A/T AM6
 407	MAINTENANCE	2.0 HDI 16v 110kw RHE	AirBag CENTRAL
 407	MAINTENANCE	2.0 HDI 16v 110kw RHE	AirBag CENTRAL
 407	MAINTENANCE	2.0 HDI 16v 110kw RHE	BSI
 407	MAINTENANCE	2.0 HDI 16v 110kw RHE	BSI
 407	MAINTENANCE	2.0 HDI 16v 110kw RHE	JCAE Body Computer MANUAL
 407	MAINTENANCE	2.0 HDI 16v 110kw RHE	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.0 HDI 16v 110kw RHE	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.0 HDI 16v 110kw RHE	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.0 HDI 16v 110kw RHE	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.0 HDI 16v 110kw RHE	Var.1
 407	MAINTENANCE	2.0 HDI 16v 110kw RHE	Var.1
 407	MAINTENANCE	2.0 HDI 16v 110kw RHE	Var.1
 407	MAINTENANCE	2.0 HDI 16v 110kw RHE	Var.2
 407	MAINTENANCE	2.0 HDI 16v 110kw RHE	Var.2
 407	MAINTENANCE	2.0 HDI 16v 110kw RHE	Var.2
 407	MAINTENANCE	2.0 HDI 16v 110kw RHE	Var.2
 407	MAINTENANCE	2.0 HDI 16v 110kw RHE	Var.3
 407	MAINTENANCE	2.0 HDI 16v 110kw RHE	VDO Dashboard
 407	MAINTENANCE	2.0 HDI 16v 110kw RHE	VDO Dashboard
 407	MAINTENANCE	2.0 HDI 16v 120kw RHH	A/T AM6
 407	MAINTENANCE	2.0 HDI 16v 120kw RHH	A/T AM6
 407	MAINTENANCE	2.0 HDI 16v 120kw RHH	AirBag CENTRAL
 407	MAINTENANCE	2.0 HDI 16v 120kw RHH	AirBag CENTRAL
 407	MAINTENANCE	2.0 HDI 16v 120kw RHH	BSI
 407	MAINTENANCE	2.0 HDI 16v 120kw RHH	BSI
 407	MAINTENANCE	2.0 HDI 16v 120kw RHH	JCAE Body Computer MANUAL
 407	MAINTENANCE	2.0 HDI 16v 120kw RHH	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.0 HDI 16v 120kw RHH	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.0 HDI 16v 120kw RHH	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.0 HDI 16v 120kw RHH	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.0 HDI 16v 120kw RHH	Var.1
 407	MAINTENANCE	2.0 HDI 16v 120kw RHH	Var.1
 407	MAINTENANCE	2.0 HDI 16v 120kw RHH	Var.1
 407	MAINTENANCE	2.0 HDI 16v 120kw RHH	Var.2
407	MAINTENANCE	2.0 HDI 16v 120kw RHH	Var.2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 407	MAINTENANCE	2.0 HDI 16v 120kw RHH	Var.2
 407	MAINTENANCE	2.0 HDI 16v 120kw RHH	Var.3
 407	MAINTENANCE	2.0 HDI 16v 120kw RHH	VDO Dashboard
 407	MAINTENANCE	2.0 HDI 16v 120kw RHH	VDO Dashboard
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	A/T AM6
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	A/T AM6
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	AirBag CENTRAL
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	AirBag CENTRAL
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	BSI
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	BSI
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	JCAE Body Computer MANUAL
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	SIEMENS SID 803 Common Rail Var.1
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	SIEMENS SID 803 Common Rail Var.1
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	SIEMENS SID 803 Common Rail Var.1
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	SIEMENS SID 803 Common Rail Var.2
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	SIEMENS SID 803 Common Rail Var.2
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	SIEMENS SID 803 Common Rail Var.2
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	SIEMENS SID 803A Common Rail Var.1
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	SIEMENS SID 803A Common Rail Var.1
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	SIEMENS SID 803A Common Rail Var.1
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	SIEMENS SID 803A Common Rail Var.2
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	SIEMENS SID 803A Common Rail Var.2
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	SIEMENS SID 803A Common Rail Var.2
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	Var.1
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	Var.1
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	Var.1
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	Var.1
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	Var.1
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	Var.1
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	Var.1
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	Var.2
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	Var.2
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	Var.2
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	Var.2
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	Var.2
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	Var.2
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	Var.2
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	Var.2
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	Var.3
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	VDO Dashboard
 407	MAINTENANCE	2.0 HDI 16v 93kw RHL-FAP	VDO Dashboard
 407	MAINTENANCE	2.2 16v 116kw 3FZ	A/T AM6
 407	MAINTENANCE	2.2 16v 116kw 3FZ	A/T AM6
 407	MAINTENANCE	2.2 16v 116kw 3FZ	AirBag CENTRAL
 407	MAINTENANCE	2.2 16v 116kw 3FZ	AirBag CENTRAL
 407	MAINTENANCE	2.2 16v 116kw 3FZ	BSI
 407	MAINTENANCE	2.2 16v 116kw 3FZ	BSI
 407	MAINTENANCE	2.2 16v 116kw 3FZ	JCAE Body Computer MANUAL
 407	MAINTENANCE	2.2 16v 116kw 3FZ	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.2 16v 116kw 3FZ	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.2 16v 116kw 3FZ	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.2 16v 116kw 3FZ	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.2 16v 116kw 3FZ	Var.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 407	MAINTENANCE	2.2 16v 116kw 3FZ	Var.1
 407	MAINTENANCE	2.2 16v 116kw 3FZ	Var.1
 407	MAINTENANCE	2.2 16v 116kw 3FZ	Var.2
 407	MAINTENANCE	2.2 16v 116kw 3FZ	Var.2
 407	MAINTENANCE	2.2 16v 116kw 3FZ	Var.2
 407	MAINTENANCE	2.2 16v 116kw 3FZ	Var.3
 407	MAINTENANCE	2.2 16v 116kw 3FZ	VDO Dashboard
 407	MAINTENANCE	2.2 16v 116kw 3FZ	VDO Dashboard
 407	MAINTENANCE	2.2 16v 120kw 3FY	A/T AM6
 407	MAINTENANCE	2.2 16v 120kw 3FY	A/T AM6
 407	MAINTENANCE	2.2 16v 120kw 3FY	AirBag CENTRAL
 407	MAINTENANCE	2.2 16v 120kw 3FY	AirBag CENTRAL
 407	MAINTENANCE	2.2 16v 120kw 3FY	BSI
 407	MAINTENANCE	2.2 16v 120kw 3FY	BSI
 407	MAINTENANCE	2.2 16v 120kw 3FY	JCAE Body Computer MANUAL
 407	MAINTENANCE	2.2 16v 120kw 3FY	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.2 16v 120kw 3FY	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.2 16v 120kw 3FY	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.2 16v 120kw 3FY	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.2 16v 120kw 3FY	Var.1
 407	MAINTENANCE	2.2 16v 120kw 3FY	Var.1
 407	MAINTENANCE	2.2 16v 120kw 3FY	Var.1
 407	MAINTENANCE	2.2 16v 120kw 3FY	Var.2
 407	MAINTENANCE	2.2 16v 120kw 3FY	Var.2
 407	MAINTENANCE	2.2 16v 120kw 3FY	Var.2
 407	MAINTENANCE	2.2 16v 120kw 3FY	Var.3
 407	MAINTENANCE	2.2 16v 120kw 3FY	VDO Dashboard
 407	MAINTENANCE	2.2 16v 120kw 3FY	VDO Dashboard
 407	MAINTENANCE	2.2 HDI 16v 120kw 4HP	A/T AM6
 407	MAINTENANCE	2.2 HDI 16v 120kw 4HP	A/T AM6
 407	MAINTENANCE	2.2 HDI 16v 120kw 4HP	AirBag CENTRAL
 407	MAINTENANCE	2.2 HDI 16v 120kw 4HP	AirBag CENTRAL
 407	MAINTENANCE	2.2 HDI 16v 120kw 4HP	BSI
 407	MAINTENANCE	2.2 HDI 16v 120kw 4HP	BSI
 407	MAINTENANCE	2.2 HDI 16v 120kw 4HP	JCAE Body Computer MANUAL
 407	MAINTENANCE	2.2 HDI 16v 120kw 4HP	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.2 HDI 16v 120kw 4HP	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.2 HDI 16v 120kw 4HP	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.2 HDI 16v 120kw 4HP	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.2 HDI 16v 120kw 4HP	Var.1
 407	MAINTENANCE	2.2 HDI 16v 120kw 4HP	Var.1
 407	MAINTENANCE	2.2 HDI 16v 120kw 4HP	Var.1
 407	MAINTENANCE	2.2 HDI 16v 120kw 4HP	Var.2
 407	MAINTENANCE	2.2 HDI 16v 120kw 4HP	Var.2
 407	MAINTENANCE	2.2 HDI 16v 120kw 4HP	Var.2
 407	MAINTENANCE	2.2 HDI 16v 120kw 4HP	Var.3
 407	MAINTENANCE	2.2 HDI 16v 120kw 4HP	VDO Dashboard
 407	MAINTENANCE	2.2 HDI 16v 120kw 4HP	VDO Dashboard
 407	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	A/T AM6
 407	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	A/T AM6
 407	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	AirBag CENTRAL
 407	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	AirBag CENTRAL
 407	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	BSI
 407	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	BSI
 407	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	JCAE Body Computer MANUAL
 407	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	Siemens-JCAE AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 407	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	Var.1
 407	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	Var.1
 407	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	Var.1
 407	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	Var.2
 407	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	Var.2
 407	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	Var.2
 407	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	Var.3
 407	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	VDO Dashboard
 407	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	VDO Dashboard
 407	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	A/T AM6
 407	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	A/T AM6
 407	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	AirBag CENTRAL
 407	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	AirBag CENTRAL
 407	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	BOSCH EDC 15 C2 Common Rail
 407	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	BSI
 407	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	BSI
 407	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	JCAE Body Computer MANUAL
 407	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	Var.1
 407	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	Var.1
 407	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	Var.1
 407	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	Var.1
 407	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	Var.1
 407	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	Var.1
 407	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	Var.1
 407	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	Var.2
 407	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	Var.2
 407	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	Var.2
 407	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	Var.2
 407	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	Var.2
 407	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	Var.2
 407	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	Var.2
 407	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	Var.2
 407	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	Var.2
 407	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	Var.3
 407	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	VDO Dashboard
 407	MAINTENANCE	2.2 HDI 16v 98kw 4HX-FAP	VDO Dashboard
 407	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	A/T AM6
 407	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	A/T AM6
 407	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	AirBag CENTRAL
 407	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	AirBag CENTRAL
 407	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	BSI
 407	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	BSI
 407	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	JCAE Body Computer MANUAL
 407	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Var.1
 407	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Var.1
 407	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Var.1
 407	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Var.1
 407	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Var.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 407	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Var.1
 407	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Var.1
 407	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Var.2
 407	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Var.2
 407	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Var.2
 407	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Var.2
 407	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Var.2
 407	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Var.2
 407	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Var.2
 407	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Var.2
 407	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Var.2
 407	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Var.3
 407	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	VDO Dashboard
 407	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	VDO Dashboard
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	A/T AM6
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	A/T AM6
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	AirBag CENTRAL
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	AirBag CENTRAL
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	BSI
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	BSI
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	JCAE Body Computer MANUAL
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	Var.1
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	Var.1
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	Var.1
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	Var.1
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	Var.1
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	Var.1
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	Var.1
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	Var.1
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	Var.1
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	Var.1
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	Var.1
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	Var.1
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	Var.1
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	Var.2
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	Var.2
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	Var.2
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	Var.2
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	Var.2
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	Var.2
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	Var.2
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	Var.2
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	Var.2
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	Var.2
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	Var.2
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	Var.2
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	Var.3
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	VDO Dashboard
 407	MAINTENANCE	3.0 HDI V6 16v 177kw X8Z	VDO Dashboard
 407	MAINTENANCE	3.0 V6 24v 155kw XFU	A/T AM6
 407	MAINTENANCE	3.0 V6 24v 155kw XFU	A/T AM6
 407	MAINTENANCE	3.0 V6 24v 155kw XFU	AirBag CENTRAL
 407	MAINTENANCE	3.0 V6 24v 155kw XFU	AirBag CENTRAL
407	MAINTENANCE	3.0 V6 24v 155kw XFU	BSI
407	MAINTENANCE	3.0 V6 24v 155kw XFU	BSI
407	MAINTENANCE	3.0 V6 24v 155kw XFU	JCAE Body Computer MANUAL
407	MAINTENANCE	3.0 V6 24v 155kw XFU	Siemens-JCAE AUTODETECT
407	MAINTENANCE	3.0 V6 24v 155kw XFU	Siemens-JCAE AUTODETECT
407	MAINTENANCE	3.0 V6 24v 155kw XFU	Siemens-JCAE AUTODETECT
407	MAINTENANCE	3.0 V6 24v 155kw XFU	Siemens-JCAE AUTODETECT
407	MAINTENANCE	3.0 V6 24v 155kw XFU	Siemens-JCAE AUTODETECT
407	MAINTENANCE	3.0 V6 24v 155kw XFU	Var.1
407	MAINTENANCE	3.0 V6 24v 155kw XFU	Var.1
407	MAINTENANCE	3.0 V6 24v 155kw XFU	Var.1
407	MAINTENANCE	3.0 V6 24v 155kw XFU	Var.1
407	MAINTENANCE	3.0 V6 24v 155kw XFU	Var.2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 407	MAINTENANCE	3.0 V6 24v 155kw XFU	Var.2
 407	MAINTENANCE	3.0 V6 24v 155kw XFU	Var.2
 407	MAINTENANCE	3.0 V6 24v 155kw XFU	Var.3
 407	MAINTENANCE	3.0 V6 24v 155kw XFU	VDO Dashboard
 407	MAINTENANCE	3.0 V6 24v 155kw XFU	VDO Dashboard
 407	MAINTENANCE	3.0 V6 24v 155kw XFU	A/T AM6
 407	MAINTENANCE	3.0 V6 24v 155kw XFU	A/T AM6
 407	MAINTENANCE	3.0 V6 24v 155kw XFU	AirBag CENTRAL
 407	MAINTENANCE	3.0 V6 24v 155kw XFU	AirBag CENTRAL
 407	MAINTENANCE	3.0 V6 24v 155kw XFU	BSI
 407	MAINTENANCE	3.0 V6 24v 155kw XFU	BSI
 407	MAINTENANCE	3.0 V6 24v 155kw XFU	JCAE Body Computer MANUAL
 407	MAINTENANCE	3.0 V6 24v 155kw XFU	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	3.0 V6 24v 155kw XFU	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	3.0 V6 24v 155kw XFU	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	3.0 V6 24v 155kw XFU	Siemens-JCAE AUTODETECT
 407	MAINTENANCE	3.0 V6 24v 155kw XFU	Var.1
 407	MAINTENANCE	3.0 V6 24v 155kw XFU	Var.1
 407	MAINTENANCE	3.0 V6 24v 155kw XFU	Var.1
 407	MAINTENANCE	3.0 V6 24v 155kw XFU	Var.2
 407	MAINTENANCE	3.0 V6 24v 155kw XFU	Var.2
 407	MAINTENANCE	3.0 V6 24v 155kw XFU	Var.2
 407	MAINTENANCE	3.0 V6 24v 155kw XFU	Var.2
 407	MAINTENANCE	3.0 V6 24v 155kw XFU	Var.3
 407	MAINTENANCE	3.0 V6 24v 155kw XFU	VDO Dashboard
 407	MAINTENANCE	3.0 V6 24v 155kw XFU	VDO Dashboard
 407	PARKING HELP	1.6 HDI 16v 80kw 9HY	BOSCH PDC
 407	PARKING HELP	1.6 HDI 16v 80kw 9HY	Var.1
 407	PARKING HELP	1.6 HDI 16v 80kw 9HY	Var.2
 407	PARKING HELP	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH PDC
 407	PARKING HELP	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 407	PARKING HELP	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 407	PARKING HELP	1.8 16v 86kw 6FZ	BOSCH PDC
 407	PARKING HELP	1.8 16v 86kw 6FZ	Var.1
 407	PARKING HELP	1.8 16v 86kw 6FZ	Var.2
 407	PARKING HELP	1.8 16v 92kw 6FY	BOSCH PDC
 407	PARKING HELP	1.8 16v 92kw 6FY	Var.1
 407	PARKING HELP	1.8 16v 92kw 6FY	Var.2
 407	PARKING HELP	2.0 16v 103kw RFJ	BOSCH PDC
 407	PARKING HELP	2.0 16v 103kw RFJ	Var.1
 407	PARKING HELP	2.0 16v 103kw RFJ	Var.2
 407	PARKING HELP	2.0 HDI 16v 100kw RHR-FAP	BOSCH PDC
 407	PARKING HELP	2.0 HDI 16v 100kw RHR-FAP	Var.1
 407	PARKING HELP	2.0 HDI 16v 100kw RHR-FAP	Var.2
 407	PARKING HELP	2.0 HDI 16v 103kw RHF-FAP	BOSCH PDC
 407	PARKING HELP	2.0 HDI 16v 103kw RHF-FAP	Var.1
 407	PARKING HELP	2.0 HDI 16v 103kw RHF-FAP	Var.2
 407	PARKING HELP	2.0 HDI 16v 110kw RFN	BOSCH PDC
 407	PARKING HELP	2.0 HDI 16v 110kw RFN	Var.1
 407	PARKING HELP	2.0 HDI 16v 110kw RFN	Var.2
 407	PARKING HELP	2.0 HDI 16v 110kw RHE	BOSCH PDC
 407	PARKING HELP	2.0 HDI 16v 110kw RHE	Var.1
 407	PARKING HELP	2.0 HDI 16v 110kw RHE	Var.2
 407	PARKING HELP	2.0 HDI 16v 120kw RHH	BOSCH PDC
 407	PARKING HELP	2.0 HDI 16v 120kw RHH	Var.1
 407	PARKING HELP	2.0 HDI 16v 120kw RHH	Var.2
 407	PARKING HELP	2.0 HDI 16v 93kw RHL-FAP	BOSCH PDC
 407	PARKING HELP	2.0 HDI 16v 93kw RHL-FAP	Var.1
 407	PARKING HELP	2.0 HDI 16v 93kw RHL-FAP	Var.2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 407	PARKING HELP	2.2 16v 116kw 3FZ	BOSCH PDC
 407	PARKING HELP	2.2 16v 116kw 3FZ	Var.1
 407	PARKING HELP	2.2 16v 116kw 3FZ	Var.2
 407	PARKING HELP	2.2 16v 120kw 3FY	BOSCH PDC
 407	PARKING HELP	2.2 16v 120kw 3FY	Var.1
 407	PARKING HELP	2.2 16v 120kw 3FY	Var.2
 407	PARKING HELP	2.2 HDI 16v 120kw 4HP	BOSCH PDC
 407	PARKING HELP	2.2 HDI 16v 120kw 4HP	Var.1
 407	PARKING HELP	2.2 HDI 16v 120kw 4HP	Var.2
 407	PARKING HELP	2.2 HDI 16v 125kw 4HT-FAP	BOSCH PDC
 407	PARKING HELP	2.2 HDI 16v 125kw 4HT-FAP	Var.1
 407	PARKING HELP	2.2 HDI 16v 125kw 4HT-FAP	Var.2
 407	PARKING HELP	2.2 HDI 16v 98kw 4HX-FAP	BOSCH PDC
 407	PARKING HELP	2.2 HDI 16v 98kw 4HX-FAP	Var.1
 407	PARKING HELP	2.2 HDI 16v 98kw 4HX-FAP	Var.2
 407	PARKING HELP	2.7 HDI V6 24v 150kw UHZ-FAP	BOSCH PDC
 407	PARKING HELP	2.7 HDI V6 24v 150kw UHZ-FAP	Var.1
 407	PARKING HELP	2.7 HDI V6 24v 150kw UHZ-FAP	Var.2
 407	PARKING HELP	3.0 HDI V6 16v 177kw X8Z	BOSCH PDC
 407	PARKING HELP	3.0 HDI V6 16v 177kw X8Z	Var.1
 407	PARKING HELP	3.0 HDI V6 16v 177kw X8Z	Var.2
 407	PARKING HELP	3.0 V6 24v 155kw XFU	BOSCH PDC
 407	PARKING HELP	3.0 V6 24v 155kw XFU	Var.1
 407	PARKING HELP	3.0 V6 24v 155kw XFU	Var.2
 407	PARKING HELP	3.0 V6 24v 155kw XFV	BOSCH PDC
 407	PARKING HELP	3.0 V6 24v 155kw XFV	Var.1
 407	PARKING HELP	3.0 V6 24v 155kw XFV	Var.2
 407	PASS. SIDE DOOR	1.6 HDI 16v 80kw 9HY	Brose PassengerDoor
 407	PASS. SIDE DOOR	1.6 HDI 16v 80kw 9HY	Var.1
 407	PASS. SIDE DOOR	1.6 HDI 16v 80kw 9HY	Var.2
 407	PASS. SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	Brose PassengerDoor
 407	PASS. SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 407	PASS. SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 407	PASS. SIDE DOOR	1.8 16v 86kw 6FZ	Brose PassengerDoor
 407	PASS. SIDE DOOR	1.8 16v 86kw 6FZ	Var.1
 407	PASS. SIDE DOOR	1.8 16v 86kw 6FZ	Var.2
 407	PASS. SIDE DOOR	1.8 16v 92kw 6FY	Brose PassengerDoor
 407	PASS. SIDE DOOR	1.8 16v 92kw 6FY	Var.1
 407	PASS. SIDE DOOR	1.8 16v 92kw 6FY	Var.2
 407	PASS. SIDE DOOR	2.0 16v 103kw RFJ	Brose PassengerDoor
 407	PASS. SIDE DOOR	2.0 16v 103kw RFJ	Var.1
 407	PASS. SIDE DOOR	2.0 16v 103kw RFJ	Var.2
 407	PASS. SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	Brose PassengerDoor
 407	PASS. SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	Var.1
 407	PASS. SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	Var.2
 407	PASS. SIDE DOOR	2.0 HDI 16v 103kw RHF-FAP	Brose PassengerDoor
 407	PASS. SIDE DOOR	2.0 HDI 16v 103kw RHF-FAP	Var.1
 407	PASS. SIDE DOOR	2.0 HDI 16v 103kw RHF-FAP	Var.2
 407	PASS. SIDE DOOR	2.0 HDI 16v 110kw RFN	Brose PassengerDoor
 407	PASS. SIDE DOOR	2.0 HDI 16v 110kw RFN	Var.1
 407	PASS. SIDE DOOR	2.0 HDI 16v 110kw RFN	Var.2
 407	PASS. SIDE DOOR	2.0 HDI 16v 110kw RHE	Brose PassengerDoor
 407	PASS. SIDE DOOR	2.0 HDI 16v 110kw RHE	Var.1
 407	PASS. SIDE DOOR	2.0 HDI 16v 110kw RHE	Var.2
 407	PASS. SIDE DOOR	2.0 HDI 16v 120kw RHH	Brose PassengerDoor
 407	PASS. SIDE DOOR	2.0 HDI 16v 120kw RHH	Var.1
 407	PASS. SIDE DOOR	2.0 HDI 16v 120kw RHH	Var.2
 407	PASS. SIDE DOOR	2.0 HDI 16v 93kw RHL-FAP	Brose PassengerDoor

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 407	PASS. SIDE DOOR	2.0 HDI 16v 93kw RHL-FAP	Var.1
 407	PASS. SIDE DOOR	2.0 HDI 16v 93kw RHL-FAP	Var.2
 407	PASS. SIDE DOOR	2.2 16v 116kw 3FZ	Brose PassengerDoor
 407	PASS. SIDE DOOR	2.2 16v 116kw 3FZ	Var.1
 407	PASS. SIDE DOOR	2.2 16v 116kw 3FZ	Var.2
 407	PASS. SIDE DOOR	2.2 16v 120kw 3FY	Brose PassengerDoor
 407	PASS. SIDE DOOR	2.2 16v 120kw 3FY	Var.1
 407	PASS. SIDE DOOR	2.2 16v 120kw 3FY	Var.2
 407	PASS. SIDE DOOR	2.2 HDI 16v 120kw 4HP	Brose PassengerDoor
 407	PASS. SIDE DOOR	2.2 HDI 16v 120kw 4HP	Var.1
 407	PASS. SIDE DOOR	2.2 HDI 16v 120kw 4HP	Var.2
 407	PASS. SIDE DOOR	2.2 HDI 16v 125kw 4HT-FAP	Brose PassengerDoor
 407	PASS. SIDE DOOR	2.2 HDI 16v 125kw 4HT-FAP	Var.1
 407	PASS. SIDE DOOR	2.2 HDI 16v 125kw 4HT-FAP	Var.2
 407	PASS. SIDE DOOR	2.2 HDI 16v 98kw 4HX-FAP	Brose PassengerDoor
 407	PASS. SIDE DOOR	2.2 HDI 16v 98kw 4HX-FAP	Var.1
 407	PASS. SIDE DOOR	2.2 HDI 16v 98kw 4HX-FAP	Var.2
 407	PASS. SIDE DOOR	2.7 HDI V6 24v 150kw UHZ-FAP	Brose PassengerDoor
 407	PASS. SIDE DOOR	2.7 HDI V6 24v 150kw UHZ-FAP	Var.1
 407	PASS. SIDE DOOR	2.7 HDI V6 24v 150kw UHZ-FAP	Var.2
 407	PASS. SIDE DOOR	3.0 HDI V6 16v 177kw X8Z	Brose PassengerDoor
 407	PASS. SIDE DOOR	3.0 HDI V6 16v 177kw X8Z	Var.1
 407	PASS. SIDE DOOR	3.0 HDI V6 16v 177kw X8Z	Var.2
 407	PASS. SIDE DOOR	3.0 V6 24v 155kw XFU	Brose PassengerDoor
 407	PASS. SIDE DOOR	3.0 V6 24v 155kw XFU	Var.1
 407	PASS. SIDE DOOR	3.0 V6 24v 155kw XFU	Var.2
 407	PASS. SIDE DOOR	3.0 V6 24v 155kw XFV	Brose PassengerDoor
 407	PASS. SIDE DOOR	3.0 V6 24v 155kw XFV	Var.1
 407	PASS. SIDE DOOR	3.0 V6 24v 155kw XFV	Var.2
 407	RADIO / CD	1.6 HDI 16v 80kw 9HY	Var.1
 407	RADIO / CD	1.6 HDI 16v 80kw 9HY	Var.2
 407	RADIO / CD	1.6 HDI 16v 80kw 9HY	Var.3
 407	RADIO / CD	1.6 HDI 16v 80kw 9HY	Var.4
 407	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 407	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 407	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Var.3
 407	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Var.4
 407	RADIO / CD	1.8 16v 86kw 6FZ	Var.1
 407	RADIO / CD	1.8 16v 86kw 6FZ	Var.2
 407	RADIO / CD	1.8 16v 86kw 6FZ	Var.3
 407	RADIO / CD	1.8 16v 86kw 6FZ	Var.4
 407	RADIO / CD	1.8 16v 92kw 6FY	Var.1
 407	RADIO / CD	1.8 16v 92kw 6FY	Var.2
 407	RADIO / CD	1.8 16v 92kw 6FY	Var.3
 407	RADIO / CD	1.8 16v 92kw 6FY	Var.4
 407	RADIO / CD	2.0 16v 103kw RFJ	Var.1
 407	RADIO / CD	2.0 16v 103kw RFJ	Var.2
 407	RADIO / CD	2.0 16v 103kw RFJ	Var.3
 407	RADIO / CD	2.0 16v 103kw RFJ	Var.4
 407	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP	Var.1
 407	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP	Var.2
 407	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP	Var.3
 407	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP	Var.4
 407	RADIO / CD	2.0 HDI 16v 103kw RHF-FAP	Var.1
 407	RADIO / CD	2.0 HDI 16v 103kw RHF-FAP	Var.2
 407	RADIO / CD	2.0 HDI 16v 103kw RHF-FAP	Var.3
 407	RADIO / CD	2.0 HDI 16v 103kw RHF-FAP	Var.4
 407	RADIO / CD	2.0 HDI 16v 110kw RFN	Var.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 407	RADIO / CD	2.0 HDI 16v 110kw RFN	Var.2
 407	RADIO / CD	2.0 HDI 16v 110kw RFN	Var.3
 407	RADIO / CD	2.0 HDI 16v 110kw RFN	Var.4
 407	RADIO / CD	2.0 HDI 16v 110kw RHE	Var.1
 407	RADIO / CD	2.0 HDI 16v 110kw RHE	Var.2
 407	RADIO / CD	2.0 HDI 16v 110kw RHE	Var.3
 407	RADIO / CD	2.0 HDI 16v 110kw RHE	Var.4
 407	RADIO / CD	2.0 HDI 16v 120kw RHH	Var.1
 407	RADIO / CD	2.0 HDI 16v 120kw RHH	Var.2
 407	RADIO / CD	2.0 HDI 16v 120kw RHH	Var.3
 407	RADIO / CD	2.0 HDI 16v 120kw RHH	Var.4
 407	RADIO / CD	2.0 HDI 16v 93kw RHL-FAP	Var.1
 407	RADIO / CD	2.0 HDI 16v 93kw RHL-FAP	Var.2
 407	RADIO / CD	2.0 HDI 16v 93kw RHL-FAP	Var.3
 407	RADIO / CD	2.0 HDI 16v 93kw RHL-FAP	Var.4
 407	RADIO / CD	2.2 16v 116kw 3FZ	Var.1
 407	RADIO / CD	2.2 16v 116kw 3FZ	Var.2
 407	RADIO / CD	2.2 16v 116kw 3FZ	Var.3
 407	RADIO / CD	2.2 16v 116kw 3FZ	Var.4
 407	RADIO / CD	2.2 16v 120kw 3FY	Var.1
 407	RADIO / CD	2.2 16v 120kw 3FY	Var.2
 407	RADIO / CD	2.2 16v 120kw 3FY	Var.3
 407	RADIO / CD	2.2 16v 120kw 3FY	Var.4
 407	RADIO / CD	2.2 HDI 16v 120kw 4HP	Var.1
 407	RADIO / CD	2.2 HDI 16v 120kw 4HP	Var.2
 407	RADIO / CD	2.2 HDI 16v 120kw 4HP	Var.3
 407	RADIO / CD	2.2 HDI 16v 120kw 4HP	Var.4
 407	RADIO / CD	2.2 HDI 16v 125kw 4HT-FAP	Var.1
 407	RADIO / CD	2.2 HDI 16v 125kw 4HT-FAP	Var.2
 407	RADIO / CD	2.2 HDI 16v 125kw 4HT-FAP	Var.3
 407	RADIO / CD	2.2 HDI 16v 125kw 4HT-FAP	Var.4
 407	RADIO / CD	2.2 HDI 16v 98kw 4HX-FAP	Var.1
 407	RADIO / CD	2.2 HDI 16v 98kw 4HX-FAP	Var.2
 407	RADIO / CD	2.2 HDI 16v 98kw 4HX-FAP	Var.3
 407	RADIO / CD	2.2 HDI 16v 98kw 4HX-FAP	Var.4
 407	RADIO / CD	2.7 HDI V6 24v 150kw UHZ-FAP	Var.1
 407	RADIO / CD	2.7 HDI V6 24v 150kw UHZ-FAP	Var.2
 407	RADIO / CD	2.7 HDI V6 24v 150kw UHZ-FAP	Var.3
 407	RADIO / CD	2.7 HDI V6 24v 150kw UHZ-FAP	Var.4
 407	RADIO / CD	3.0 HDI V6 16v 177kw X8Z	Var.1
 407	RADIO / CD	3.0 HDI V6 16v 177kw X8Z	Var.2
 407	RADIO / CD	3.0 HDI V6 16v 177kw X8Z	Var.3
 407	RADIO / CD	3.0 HDI V6 16v 177kw X8Z	Var.4
 407	RADIO / CD	3.0 V6 24v 155kw XFU	Var.1
 407	RADIO / CD	3.0 V6 24v 155kw XFU	Var.2
 407	RADIO / CD	3.0 V6 24v 155kw XFU	Var.3
 407	RADIO / CD	3.0 V6 24v 155kw XFU	Var.4
 407	RADIO / CD	3.0 V6 24v 155kw XFV	Var.1
 407	RADIO / CD	3.0 V6 24v 155kw XFV	Var.2
 407	RADIO / CD	3.0 V6 24v 155kw XFV	Var.3
 407	RADIO / CD	3.0 V6 24v 155kw XFV	Var.4
 407	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HY	BOSCH WSS
 407	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HY	Var.1
 407	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HY	Var.2
 407	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH WSS
 407	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 407	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 407	RAIN-LUMINOSITY S	1.8 16v 86kw 6FZ	BOSCH WSS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 407	RAIN-LUMINOSITY S	1.8 16v 86kw 6FZ	Var.1
 407	RAIN-LUMINOSITY S	1.8 16v 86kw 6FZ	Var.2
 407	RAIN-LUMINOSITY S	1.8 16v 92kw 6FY	BOSCH WSS
 407	RAIN-LUMINOSITY S	1.8 16v 92kw 6FY	Var.1
 407	RAIN-LUMINOSITY S	1.8 16v 92kw 6FY	Var.2
 407	RAIN-LUMINOSITY S	2.0 16v 103kw RFJ	BOSCH WSS
 407	RAIN-LUMINOSITY S	2.0 16v 103kw RFJ	Var.1
 407	RAIN-LUMINOSITY S	2.0 16v 103kw RFJ	Var.2
 407	RAIN-LUMINOSITY S	2.0 HDI 16v 100kw RHR-FAP	BOSCH WSS
 407	RAIN-LUMINOSITY S	2.0 HDI 16v 100kw RHR-FAP	Var.1
 407	RAIN-LUMINOSITY S	2.0 HDI 16v 100kw RHR-FAP	Var.2
 407	RAIN-LUMINOSITY S	2.0 HDI 16v 103kw RHF-FAP	BOSCH WSS
 407	RAIN-LUMINOSITY S	2.0 HDI 16v 103kw RHF-FAP	Var.1
 407	RAIN-LUMINOSITY S	2.0 HDI 16v 103kw RHF-FAP	Var.2
 407	RAIN-LUMINOSITY S	2.0 HDI 16v 110kw RFN	BOSCH WSS
 407	RAIN-LUMINOSITY S	2.0 HDI 16v 110kw RFN	Var.1
 407	RAIN-LUMINOSITY S	2.0 HDI 16v 110kw RFN	Var.2
 407	RAIN-LUMINOSITY S	2.0 HDI 16v 110kw RHE	BOSCH WSS
 407	RAIN-LUMINOSITY S	2.0 HDI 16v 110kw RHE	Var.1
 407	RAIN-LUMINOSITY S	2.0 HDI 16v 110kw RHE	Var.2
 407	RAIN-LUMINOSITY S	2.0 HDI 16v 120kw RHH	BOSCH WSS
 407	RAIN-LUMINOSITY S	2.0 HDI 16v 120kw RHH	Var.1
 407	RAIN-LUMINOSITY S	2.0 HDI 16v 120kw RHH	Var.2
 407	RAIN-LUMINOSITY S	2.0 HDI 16v 93kw RHL-FAP	BOSCH WSS
 407	RAIN-LUMINOSITY S	2.0 HDI 16v 93kw RHL-FAP	Var.1
 407	RAIN-LUMINOSITY S	2.0 HDI 16v 93kw RHL-FAP	Var.2
 407	RAIN-LUMINOSITY S	2.2 16v 116kw 3FZ	BOSCH WSS
 407	RAIN-LUMINOSITY S	2.2 16v 116kw 3FZ	Var.1
 407	RAIN-LUMINOSITY S	2.2 16v 116kw 3FZ	Var.2
 407	RAIN-LUMINOSITY S	2.2 16v 120kw 3FY	BOSCH WSS
 407	RAIN-LUMINOSITY S	2.2 16v 120kw 3FY	Var.1
 407	RAIN-LUMINOSITY S	2.2 16v 120kw 3FY	Var.2
 407	RAIN-LUMINOSITY S	2.2 HDI 16v 120kw 4HP	BOSCH WSS
 407	RAIN-LUMINOSITY S	2.2 HDI 16v 120kw 4HP	Var.1
 407	RAIN-LUMINOSITY S	2.2 HDI 16v 120kw 4HP	Var.2
 407	RAIN-LUMINOSITY S	2.2 HDI 16v 125kw 4HT-FAP	BOSCH WSS
 407	RAIN-LUMINOSITY S	2.2 HDI 16v 125kw 4HT-FAP	Var.1
 407	RAIN-LUMINOSITY S	2.2 HDI 16v 125kw 4HT-FAP	Var.2
 407	RAIN-LUMINOSITY S	2.2 HDI 16v 98kw 4HX-FAP	BOSCH WSS
 407	RAIN-LUMINOSITY S	2.2 HDI 16v 98kw 4HX-FAP	Var.1
 407	RAIN-LUMINOSITY S	2.2 HDI 16v 98kw 4HX-FAP	Var.2
 407	RAIN-LUMINOSITY S	2.7 HDI V6 24v 150kw UHZ-FAP	BOSCH WSS
 407	RAIN-LUMINOSITY S	2.7 HDI V6 24v 150kw UHZ-FAP	Var.1
 407	RAIN-LUMINOSITY S	2.7 HDI V6 24v 150kw UHZ-FAP	Var.2
 407	RAIN-LUMINOSITY S	3.0 HDI V6 16v 177kw X8Z	BOSCH WSS
 407	RAIN-LUMINOSITY S	3.0 HDI V6 16v 177kw X8Z	Var.1
 407	RAIN-LUMINOSITY S	3.0 HDI V6 16v 177kw X8Z	Var.2
 407	RAIN-LUMINOSITY S	3.0 V6 24v 155kw XFU	BOSCH WSS
 407	RAIN-LUMINOSITY S	3.0 V6 24v 155kw XFU	Var.1
 407	RAIN-LUMINOSITY S	3.0 V6 24v 155kw XFU	Var.2
 407	RAIN-LUMINOSITY S	3.0 V6 24v 155kw XFV	BOSCH WSS
 407	RAIN-LUMINOSITY S	3.0 V6 24v 155kw XFV	Var.1
 407	RAIN-LUMINOSITY S	3.0 V6 24v 155kw XFV	Var.2
 407	REMOTE CONTROL E	1.6 HDI 16v 80kw 9HY	JCAE Body Computer MANUAL
 407	REMOTE CONTROL E	1.6 HDI 16v 80kw 9HZ-FAP	JCAE Body Computer MANUAL
 407	REMOTE CONTROL E	1.8 16v 86kw 6FZ	JCAE Body Computer MANUAL
 407	REMOTE CONTROL E	1.8 16v 92kw 6FY	JCAE Body Computer MANUAL
 407	REMOTE CONTROL E	2.0 16v 103kw RFJ	JCAE Body Computer MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 407	REMOTE CONTROL E	2.0 HDI 16v 100kw RHR-FAP	JCAE Body Computer MANUAL
 407	REMOTE CONTROL E	2.0 HDI 16v 103kw RHF-FAP	JCAE Body Computer MANUAL
 407	REMOTE CONTROL E	2.0 HDI 16v 110kw RFN	JCAE Body Computer MANUAL
 407	REMOTE CONTROL E	2.0 HDI 16v 110kw RHE	JCAE Body Computer MANUAL
 407	REMOTE CONTROL E	2.0 HDI 16v 120kw RHH	JCAE Body Computer MANUAL
 407	REMOTE CONTROL E	2.0 HDI 16v 93kw RHL-FAP	JCAE Body Computer MANUAL
 407	REMOTE CONTROL E	2.2 16v 116kw 3FZ	JCAE Body Computer MANUAL
 407	REMOTE CONTROL E	2.2 16v 120kw 3FY	JCAE Body Computer MANUAL
 407	REMOTE CONTROL E	2.2 HDI 16v 120kw 4HP	JCAE Body Computer MANUAL
 407	REMOTE CONTROL E	2.2 HDI 16v 125kw 4HT-FAP	JCAE Body Computer MANUAL
 407	REMOTE CONTROL E	2.2 HDI 16v 98kw 4HX-FAP	JCAE Body Computer MANUAL
 407	REMOTE CONTROL E	2.7 HDI V6 24v 150kw UHZ-FAP	JCAE Body Computer MANUAL
 407	REMOTE CONTROL E	3.0 HDI V6 16v 177kw X8Z	JCAE Body Computer MANUAL
 407	REMOTE CONTROL E	3.0 V6 24v 155kw XFU	JCAE Body Computer MANUAL
 407	REMOTE CONTROL E	3.0 V6 24v 155kw XFV	JCAE Body Computer MANUAL
 407	STEERING COLUMN	1.6 HDI 16v 80kw 9HY	
 407	STEERING COLUMN	1.6 HDI 16v 80kw 9HZ-FAP	
 407	STEERING COLUMN	1.8 16v 86kw 6FZ	
 407	STEERING COLUMN	1.8 16v 92kw 6FY	
 407	STEERING COLUMN	2.0 16v 103kw RFJ	
 407	STEERING COLUMN	2.0 HDI 16v 100kw RHR-FAP	
 407	STEERING COLUMN	2.0 HDI 16v 103kw RHF-FAP	
 407	STEERING COLUMN	2.0 HDI 16v 110kw RFN	
 407	STEERING COLUMN	2.0 HDI 16v 110kw RHE	
 407	STEERING COLUMN	2.0 HDI 16v 120kw RHH	
 407	STEERING COLUMN	2.0 HDI 16v 93kw RHL-FAP	
 407	STEERING COLUMN	2.2 16v 116kw 3FZ	
 407	STEERING COLUMN	2.2 16v 120kw 3FY	
 407	STEERING COLUMN	2.2 HDI 16v 120kw 4HP	
 407	STEERING COLUMN	2.2 HDI 16v 125kw 4HT-FAP	
 407	STEERING COLUMN	2.2 HDI 16v 98kw 4HX-FAP	
 407	STEERING COLUMN	2.7 HDI V6 24v 150kw UHZ-FAP	
 407	STEERING COLUMN	3.0 HDI V6 16v 177kw X8Z	
 407	STEERING COLUMN	3.0 V6 24v 155kw XFU	
 407	STEERING COLUMN	3.0 V6 24v 155kw XFV	
 407	SWITCHLIGHT MODU	1.6 HDI 16v 80kw 9HY	Valeo
 407	SWITCHLIGHT MODU	1.6 HDI 16v 80kw 9HZ-FAP	Valeo
 407	SWITCHLIGHT MODU	1.8 16v 86kw 6FZ	Valeo
 407	SWITCHLIGHT MODU	1.8 16v 92kw 6FY	Valeo
 407	SWITCHLIGHT MODU	2.0 16v 103kw RFJ	Valeo
 407	SWITCHLIGHT MODU	2.0 HDI 16v 100kw RHR-FAP	Valeo
 407	SWITCHLIGHT MODU	2.0 HDI 16v 103kw RHF-FAP	Valeo
 407	SWITCHLIGHT MODU	2.0 HDI 16v 110kw RFN	Valeo
 407	SWITCHLIGHT MODU	2.0 HDI 16v 110kw RHE	Valeo
 407	SWITCHLIGHT MODU	2.0 HDI 16v 120kw RHH	Valeo
 407	SWITCHLIGHT MODU	2.0 HDI 16v 93kw RHL-FAP	Valeo
 407	SWITCHLIGHT MODU	2.2 16v 116kw 3FZ	Valeo
 407	SWITCHLIGHT MODU	2.2 16v 120kw 3FY	Valeo
 407	SWITCHLIGHT MODU	2.2 HDI 16v 120kw 4HP	Valeo
 407	SWITCHLIGHT MODU	2.2 HDI 16v 125kw 4HT-FAP	Valeo
 407	SWITCHLIGHT MODU	2.2 HDI 16v 98kw 4HX-FAP	Valeo
 407	SWITCHLIGHT MODU	2.7 HDI V6 24v 150kw UHZ-FAP	Valeo
 407	SWITCHLIGHT MODU	3.0 HDI V6 16v 177kw X8Z	Valeo
 407	SWITCHLIGHT MODU	3.0 V6 24v 155kw XFU	Valeo
 407	SWITCHLIGHT MODU	3.0 V6 24v 155kw XFV	Valeo
 407	TIRE PRESSURE	1.6 HDI 16v 80kw 9HY	Siemens-JCAE AUTODETECT
 407	TIRE PRESSURE	1.6 HDI 16v 80kw 9HZ-FAP	Siemens-JCAE AUTODETECT
 407	TIRE PRESSURE	1.8 16v 86kw 6FZ	Siemens-JCAE AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 407	TIRE PRESSURE	1.8 16v 92kw 6FY	Siemens-JCAE AUTODETECT
 407	TIRE PRESSURE	2.0 16v 103kw RFJ	Siemens-JCAE AUTODETECT
 407	TIRE PRESSURE	2.0 HDI 16v 100kw RHR-FAP	Siemens-JCAE AUTODETECT
 407	TIRE PRESSURE	2.0 HDI 16v 103kw RHF-FAP	Siemens-JCAE AUTODETECT
 407	TIRE PRESSURE	2.0 HDI 16v 110kw RFN	Siemens-JCAE AUTODETECT
 407	TIRE PRESSURE	2.0 HDI 16v 110kw RHE	Siemens-JCAE AUTODETECT
 407	TIRE PRESSURE	2.0 HDI 16v 120kw RHH	Siemens-JCAE AUTODETECT
 407	TIRE PRESSURE	2.0 HDI 16v 93kw RHL-FAP	Siemens-JCAE AUTODETECT
 407	TIRE PRESSURE	2.2 16v 116kw 3FZ	Siemens-JCAE AUTODETECT
 407	TIRE PRESSURE	2.2 16v 120kw 3FY	Siemens-JCAE AUTODETECT
 407	TIRE PRESSURE	2.2 HDI 16v 120kw 4HP	Siemens-JCAE AUTODETECT
 407	TIRE PRESSURE	2.2 HDI 16v 125kw 4HT-FAP	Siemens-JCAE AUTODETECT
 407	TIRE PRESSURE	2.2 HDI 16v 98kw 4HX-FAP	Siemens-JCAE AUTODETECT
 407	TIRE PRESSURE	2.7 HDI V6 24v 150kw UHZ-FAP	Siemens-JCAE AUTODETECT
 407	TIRE PRESSURE	3.0 HDI V6 16v 177kw X8Z	Siemens-JCAE AUTODETECT
 407	TIRE PRESSURE	3.0 V6 24v 155kw XFU	Siemens-JCAE AUTODETECT
 407	TIRE PRESSURE	3.0 V6 24v 155kw Xfv	Siemens-JCAE AUTODETECT
 407	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HY	Display C-
 407	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HY	JCAE DIS
 407	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	Display C-
 407	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	JCAE DIS
 407	VISUAL./TELEMATIC	1.8 16v 86kw 6FZ	Display C-
 407	VISUAL./TELEMATIC	1.8 16v 86kw 6FZ	JCAE DIS
 407	VISUAL./TELEMATIC	1.8 16v 92kw 6FY	Display C-
 407	VISUAL./TELEMATIC	1.8 16v 92kw 6FY	JCAE DIS
 407	VISUAL./TELEMATIC	2.0 16v 103kw RFJ	Display C-
 407	VISUAL./TELEMATIC	2.0 16v 103kw RFJ	JCAE DIS
 407	VISUAL./TELEMATIC	2.0 HDI 16v 100kw RHR-FAP	Display C-
 407	VISUAL./TELEMATIC	2.0 HDI 16v 100kw RHR-FAP	JCAE DIS
 407	VISUAL./TELEMATIC	2.0 HDI 16v 103kw RHF-FAP	Display C-
 407	VISUAL./TELEMATIC	2.0 HDI 16v 103kw RHF-FAP	JCAE DIS
 407	VISUAL./TELEMATIC	2.0 HDI 16v 110kw RFN	Display C-
 407	VISUAL./TELEMATIC	2.0 HDI 16v 110kw RFN	JCAE DIS
 407	VISUAL./TELEMATIC	2.0 HDI 16v 110kw RHE	Display C-
 407	VISUAL./TELEMATIC	2.0 HDI 16v 110kw RHE	JCAE DIS
 407	VISUAL./TELEMATIC	2.0 HDI 16v 120kw RHH	Display C-
 407	VISUAL./TELEMATIC	2.0 HDI 16v 120kw RHH	JCAE DIS
 407	VISUAL./TELEMATIC	2.0 HDI 16v 93kw RHL-FAP	Display C-
 407	VISUAL./TELEMATIC	2.0 HDI 16v 93kw RHL-FAP	JCAE DIS
 407	VISUAL./TELEMATIC	2.2 16v 116kw 3FZ	Display C-
 407	VISUAL./TELEMATIC	2.2 16v 116kw 3FZ	JCAE DIS
 407	VISUAL./TELEMATIC	2.2 16v 120kw 3FY	Display C-
 407	VISUAL./TELEMATIC	2.2 16v 120kw 3FY	JCAE DIS
 407	VISUAL./TELEMATIC	2.2 HDI 16v 120kw 4HP	Display C-
 407	VISUAL./TELEMATIC	2.2 HDI 16v 120kw 4HP	JCAE DIS
 407	VISUAL./TELEMATIC	2.2 HDI 16v 125kw 4HT-FAP	Display C-
 407	VISUAL./TELEMATIC	2.2 HDI 16v 125kw 4HT-FAP	JCAE DIS
 407	VISUAL./TELEMATIC	2.2 HDI 16v 98kw 4HX-FAP	Display C-
 407	VISUAL./TELEMATIC	2.2 HDI 16v 98kw 4HX-FAP	JCAE DIS
 407	VISUAL./TELEMATIC	2.7 HDI V6 24v 150kw UHZ-FAP	Display C-
 407	VISUAL./TELEMATIC	2.7 HDI V6 24v 150kw UHZ-FAP	JCAE DIS
 407	VISUAL./TELEMATIC	3.0 HDI V6 16v 177kw X8Z	Display C-
 407	VISUAL./TELEMATIC	3.0 HDI V6 16v 177kw X8Z	JCAE DIS
 407	VISUAL./TELEMATIC	3.0 V6 24v 155kw XFU	Display C-
 407	VISUAL./TELEMATIC	3.0 V6 24v 155kw XFU	JCAE DIS
 407	VISUAL./TELEMATIC	3.0 V6 24v 155kw Xfv	Display C-
 407	VISUAL./TELEMATIC	3.0 V6 24v 155kw Xfv	JCAE DIS
 5008	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 5008	ABS + TRACT. CONT	1.6 THP 16v 115kw 5FV	
 5008	ABS + TRACT. CONT	1.6 THP 16v 88kw 5FX	
 5008	ABS + TRACT. CONT	1.6 VTI 16v 88kw 5FW	
 5008	ABS + TRACT. CONT	2.0 HDI 16v 100kw	
 5008	ABS + TRACT. CONT	2.0 HDI 16v 110kw RHE-FAP	
 5008	ABS + TRACT. CONT	2.0 HDI 16v 120kw	
 5008	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL
 5008	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP	
 5008	AIRBAG	1.6 THP 16v 115kw 5FV	AirBag CENTRAL
 5008	AIRBAG	1.6 THP 16v 115kw 5FV	
 5008	AIRBAG	1.6 THP 16v 88kw 5FX	AirBag CENTRAL
 5008	AIRBAG	1.6 THP 16v 88kw 5FX	
 5008	AIRBAG	1.6 VTI 16v 88kw 5FW	AirBag CENTRAL
 5008	AIRBAG	1.6 VTI 16v 88kw 5FW	
 5008	AIRBAG	2.0 HDI 16v 100kw	AirBag CENTRAL
 5008	AIRBAG	2.0 HDI 16v 100kw	
 5008	AIRBAG	2.0 HDI 16v 110kw RHE-FAP	AirBag CENTRAL
 5008	AIRBAG	2.0 HDI 16v 110kw RHE-FAP	
 5008	AIRBAG	2.0 HDI 16v 120kw	AirBag CENTRAL
 5008	AIRBAG	2.0 HDI 16v 120kw RHE-FAP	
 5008	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	BSI 1
 5008	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	BSI 2
 5008	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	BSI 3
 5008	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Front windscreen wiper
 5008	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	SAFETY BELT LIGHTS
 5008	CHASSIS NETWORK	1.6 THP 16v 115kw 5FV	BSI 1
 5008	CHASSIS NETWORK	1.6 THP 16v 115kw 5FV	BSI 2
 5008	CHASSIS NETWORK	1.6 THP 16v 115kw 5FV	BSI 3
 5008	CHASSIS NETWORK	1.6 THP 16v 115kw 5FV	Front windscreen wiper
 5008	CHASSIS NETWORK	1.6 THP 16v 115kw 5FV	SAFETY BELT LIGHTS
 5008	CHASSIS NETWORK	1.6 THP 16v 88kw 5FX	BSI 1
 5008	CHASSIS NETWORK	1.6 THP 16v 88kw 5FX	BSI 2
 5008	CHASSIS NETWORK	1.6 THP 16v 88kw 5FX	BSI 3
 5008	CHASSIS NETWORK	1.6 THP 16v 88kw 5FX	Front windscreen wiper
 5008	CHASSIS NETWORK	1.6 THP 16v 88kw 5FX	SAFETY BELT LIGHTS
 5008	CHASSIS NETWORK	1.6 VTI 16v 88kw 5FW	BSI 1
 5008	CHASSIS NETWORK	1.6 VTI 16v 88kw 5FW	BSI 2
 5008	CHASSIS NETWORK	1.6 VTI 16v 88kw 5FW	BSI 3
 5008	CHASSIS NETWORK	1.6 VTI 16v 88kw 5FW	Front windscreen wiper
 5008	CHASSIS NETWORK	1.6 VTI 16v 88kw 5FW	SAFETY BELT LIGHTS
 5008	CHASSIS NETWORK	2.0 HDI 16v 100kw	BSI 1
 5008	CHASSIS NETWORK	2.0 HDI 16v 100kw	BSI 2
 5008	CHASSIS NETWORK	2.0 HDI 16v 100kw	BSI 3
 5008	CHASSIS NETWORK	2.0 HDI 16v 100kw	Front windscreen wiper
 5008	CHASSIS NETWORK	2.0 HDI 16v 100kw	SAFETY BELT LIGHTS
 5008	CHASSIS NETWORK	2.0 HDI 16v 110kw RHE-FAP	BSI 1
 5008	CHASSIS NETWORK	2.0 HDI 16v 110kw RHE-FAP	BSI 2
 5008	CHASSIS NETWORK	2.0 HDI 16v 110kw RHE-FAP	BSI 3
 5008	CHASSIS NETWORK	2.0 HDI 16v 110kw RHE-FAP	Front windscreen wiper
 5008	CHASSIS NETWORK	2.0 HDI 16v 110kw RHE-FAP	SAFETY BELT LIGHTS
 5008	CHASSIS NETWORK	2.0 HDI 16v 120kw RHE-FAP	BSI 1
 5008	CHASSIS NETWORK	2.0 HDI 16v 120kw RHE-FAP	BSI 2
 5008	CHASSIS NETWORK	2.0 HDI 16v 120kw RHE-FAP	BSI 3
 5008	CHASSIS NETWORK	2.0 HDI 16v 120kw RHE-FAP	Front windscreen wiper
 5008	CHASSIS NETWORK	2.0 HDI 16v 120kw RHE-FAP	SAFETY BELT LIGHTS
 5008	CLIMA	1.6 HDI 16v 80kw 9HZ-FAP	
 5008	CLIMA	1.6 THP 16v 115kw 5FV	
 5008	CLIMA	1.6 THP 16v 88kw 5FX	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 5008	CLIMA	1.6 VTI 16v 88kw 5FW	
 5008	CLIMA	2.0 HDI 16v 100kw	
 5008	CLIMA	2.0 HDI 16v 110kw RHE-FAP	
 5008	CLIMA	2.0 HDI 16v 120kw RHE-FAP	
 5008	DASH LAMPS	1.6 HDI 16v 80kw 9HZ-FAP	Warning Lights Panel
 5008	DASH LAMPS	1.6 THP 16v 115kw 5FV	Warning Lights Panel
 5008	DASH LAMPS	1.6 THP 16v 88kw 5FX	Warning Lights Panel
 5008	DASH LAMPS	1.6 VTI 16v 88kw 5FW	Warning Lights Panel
 5008	DASH LAMPS	2.0 HDI 16v 100kw	Warning Lights Panel
 5008	DASH LAMPS	2.0 HDI 16v 110kw RHE-FAP	Warning Lights Panel
 5008	DASH LAMPS	2.0 HDI 16v 120kw RHE-FAP	Warning Lights Panel
 5008	DRIVER SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	
 5008	DRIVER SIDE DOOR	1.6 HDI 16v 80kw 9HZ-FAP	FRONT DOOR
 5008	DRIVER SIDE DOOR	1.6 THP 16v 115kw 5FV	
 5008	DRIVER SIDE DOOR	1.6 THP 16v 115kw 5FV	FRONT DOOR
 5008	DRIVER SIDE DOOR	1.6 THP 16v 88kw 5FX	
 5008	DRIVER SIDE DOOR	1.6 THP 16v 88kw 5FX	FRONT DOOR
 5008	DRIVER SIDE DOOR	1.6 VTI 16v 88kw 5FW	
 5008	DRIVER SIDE DOOR	1.6 VTI 16v 88kw 5FW	FRONT DOOR
 5008	DRIVER SIDE DOOR	2.0 HDI 16v 100kw	
 5008	DRIVER SIDE DOOR	2.0 HDI 16v 100kw	FRONT DOOR
 5008	DRIVER SIDE DOOR	2.0 HDI 16v 110kw RHE-FAP	
 5008	DRIVER SIDE DOOR	2.0 HDI 16v 110kw RHE-FAP	FRONT DOOR
 5008	DRIVER SIDE DOOR	2.0 HDI 16v 120kw	
 5008	DRIVER SIDE DOOR	2.0 HDI 16v 120kw RHE-FAP	FRONT DOOR
 5008	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	
 5008	ELECTRIC STEERING	1.6 HDI 16v 80kw 9HZ-FAP	EPS
 5008	ELECTRIC STEERING	1.6 THP 16v 115kw 5FV	
 5008	ELECTRIC STEERING	1.6 THP 16v 115kw 5FV	EPS
 5008	ELECTRIC STEERING	1.6 THP 16v 88kw 5FX	
 5008	ELECTRIC STEERING	1.6 THP 16v 88kw 5FX	EPS
 5008	ELECTRIC STEERING	1.6 VTI 16v 88kw 5FW	
 5008	ELECTRIC STEERING	1.6 VTI 16v 88kw 5FW	EPS
 5008	ELECTRIC STEERING	2.0 HDI 16v 100kw	
 5008	ELECTRIC STEERING	2.0 HDI 16v 100kw	EPS
 5008	ELECTRIC STEERING	2.0 HDI 16v 110kw RHE-FAP	
 5008	ELECTRIC STEERING	2.0 HDI 16v 110kw RHE-FAP	EPS
 5008	ELECTRIC STEERING	2.0 HDI 16v 120kw	
 5008	ELECTRIC STEERING	2.0 HDI 16v 120kw RHE-FAP	EPS
 5008	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HR-FAP	
 5008	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 5008	ENGINE MANAGEME	2.0 HDI 16v 110kw	EOBD
 5008	ENGINE MANAGEME	2.0 HDI 16v 120kw	EOBD
 5008	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	
 5008	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	
 5008	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL
 5008	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	AirBag CENTRAL
 5008	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 5008	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 5008	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 5008	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 5008	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 5008	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 5008	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Warning Lights Panel
 5008	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Warning Lights Panel
 5008	MAINTENANCE	1.6 THP 16v 115kw 5FV	
 5008	MAINTENANCE	1.6 THP 16v 115kw 5FV	
 5008	MAINTENANCE	1.6 THP 16v 115kw 5FV	AirBag CENTRAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 5008	MAINTENANCE	1.6 THP 16v 115kw 5FV	AirBag CENTRAL
 5008	MAINTENANCE	1.6 THP 16v 115kw 5FV	Warning Lights Panel
 5008	MAINTENANCE	1.6 THP 16v 115kw 5FV	Warning Lights Panel
 5008	MAINTENANCE	1.6 THP 16v 88kw 5FX	
 5008	MAINTENANCE	1.6 THP 16v 88kw 5FX	
 5008	MAINTENANCE	1.6 THP 16v 88kw 5FX	AirBag CENTRAL
 5008	MAINTENANCE	1.6 THP 16v 88kw 5FX	AirBag CENTRAL
 5008	MAINTENANCE	1.6 THP 16v 88kw 5FX	Warning Lights Panel
 5008	MAINTENANCE	1.6 THP 16v 88kw 5FX	Warning Lights Panel
 5008	MAINTENANCE	1.6 VTI 16v 88kw 5FW	
 5008	MAINTENANCE	1.6 VTI 16v 88kw 5FW	
 5008	MAINTENANCE	1.6 VTI 16v 88kw 5FW	AirBag CENTRAL
 5008	MAINTENANCE	1.6 VTI 16v 88kw 5FW	AirBag CENTRAL
 5008	MAINTENANCE	1.6 VTI 16v 88kw 5FW	Warning Lights Panel
 5008	MAINTENANCE	1.6 VTI 16v 88kw 5FW	Warning Lights Panel
 5008	MAINTENANCE	2.0 HDI 16v 100kw	
 5008	MAINTENANCE	2.0 HDI 16v 100kw	
 5008	MAINTENANCE	2.0 HDI 16v 100kw	AirBag CENTRAL
 5008	MAINTENANCE	2.0 HDI 16v 100kw	AirBag CENTRAL
 5008	MAINTENANCE	2.0 HDI 16v 100kw	Warning Lights Panel
 5008	MAINTENANCE	2.0 HDI 16v 100kw	Warning Lights Panel
 5008	MAINTENANCE	2.0 HDI 16v 110kw RHE-FAP	
 5008	MAINTENANCE	2.0 HDI 16v 110kw RHE-FAP	
 5008	MAINTENANCE	2.0 HDI 16v 110kw RHE-FAP	AirBag CENTRAL
 5008	MAINTENANCE	2.0 HDI 16v 110kw RHE-FAP	AirBag CENTRAL
 5008	MAINTENANCE	2.0 HDI 16v 110kw RHE-FAP	Warning Lights Panel
 5008	MAINTENANCE	2.0 HDI 16v 110kw RHE-FAP	Warning Lights Panel
 5008	MAINTENANCE	2.0 HDI 16v 120kw	
 5008	MAINTENANCE	2.0 HDI 16v 120kw	
 5008	MAINTENANCE	2.0 HDI 16v 120kw	AirBag CENTRAL
 5008	MAINTENANCE	2.0 HDI 16v 120kw	AirBag CENTRAL
 5008	MAINTENANCE	2.0 HDI 16v 120kw RHE-FAP	Warning Lights Panel
 5008	MAINTENANCE	2.0 HDI 16v 120kw RHE-FAP	Warning Lights Panel
 5008	PARK.BRAKE	1.6 HDI 16v 80kw 9HZ-FAP	EPB
 5008	PARK.BRAKE	1.6 THP 16v 115kw 5FV	EPB
 5008	PARK.BRAKE	1.6 THP 16v 88kw 5FX	EPB
 5008	PARK.BRAKE	1.6 VTI 16v 88kw 5FW	EPB
 5008	PARK.BRAKE	2.0 HDI 16v 100kw	EPB
 5008	PARK.BRAKE	2.0 HDI 16v 110kw RHE-FAP	EPB
 5008	PARK.BRAKE	2.0 HDI 16v 120kw RHE-FAP	EPB
 5008	PARKING HELP	1.6 HDI 16v 80kw 9HZ-FAP	PDC
 5008	PARKING HELP	1.6 THP 16v 115kw 5FV	PDC
 5008	PARKING HELP	1.6 THP 16v 88kw 5FX	PDC
 5008	PARKING HELP	1.6 VTI 16v 88kw 5FW	PDC
 5008	PARKING HELP	2.0 HDI 16v 100kw	PDC
 5008	PARKING HELP	2.0 HDI 16v 110kw RHE-FAP	PDC
 5008	PARKING HELP	2.0 HDI 16v 120kw RHE-FAP	PDC
 5008	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	
 5008	RADIO / CD	1.6 THP 16v 115kw 5FV	
 5008	RADIO / CD	1.6 THP 16v 88kw 5FX	
 5008	RADIO / CD	1.6 VTI 16v 88kw 5FW	
 5008	RADIO / CD	2.0 HDI 16v 100kw	
 5008	RADIO / CD	2.0 HDI 16v 110kw RHE-FAP	
 5008	RADIO / CD	2.0 HDI 16v 120kw	
 5008	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HZ-FAP	RAIN SENSOR
 5008	RAIN-LUMINOSITY S	1.6 THP 16v 115kw 5FV	RAIN SENSOR
 5008	RAIN-LUMINOSITY S	1.6 THP 16v 88kw 5FX	RAIN SENSOR
 5008	RAIN-LUMINOSITY S	1.6 VTI 16v 88kw 5FW	RAIN SENSOR

Systems supported by ECUREADER / ECUDECODER (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 5008	RAIN-LUMINOSITY S	2.0 HDI 16v 100kw	RAIN SENSOR
 5008	RAIN-LUMINOSITY S	2.0 HDI 16v 110kw RHE-FAP	RAIN SENSOR
 5008	RAIN-LUMINOSITY S	2.0 HDI 16v 120kw RHE-FAP	RAIN SENSOR
 5008	STEERING COLUMN	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 5008	STEERING COLUMN	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 5008	STEERING COLUMN	1.6 THP 16v 115kw 5FV	Var.1
 5008	STEERING COLUMN	1.6 THP 16v 115kw 5FV	Var.2
 5008	STEERING COLUMN	1.6 THP 16v 88kw 5FX	Var.1
 5008	STEERING COLUMN	1.6 THP 16v 88kw 5FX	Var.2
 5008	STEERING COLUMN	1.6 VTI 16v 88kw 5FW	Var.1
 5008	STEERING COLUMN	1.6 VTI 16v 88kw 5FW	Var.2
 5008	STEERING COLUMN	2.0 HDI 16v 100kw	Var.1
 5008	STEERING COLUMN	2.0 HDI 16v 100kw	Var.2
 5008	STEERING COLUMN	2.0 HDI 16v 110kw RHE-FAP	Var.1
 5008	STEERING COLUMN	2.0 HDI 16v 110kw RHE-FAP	Var.2
 5008	STEERING COLUMN	2.0 HDI 16v 120kw RHE-FAP	Var.1
 5008	STEERING COLUMN	2.0 HDI 16v 120kw RHE-FAP	Var.2
 5008	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	Display C-
 5008	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	Info Display
 5008	VISUAL./TELEMATIC	1.6 THP 16v 115kw 5FV	Display C-
 5008	VISUAL./TELEMATIC	1.6 THP 16v 115kw 5FV	Info Display
 5008	VISUAL./TELEMATIC	1.6 THP 16v 88kw 5FX	Display C-
 5008	VISUAL./TELEMATIC	1.6 THP 16v 88kw 5FX	Info Display
 5008	VISUAL./TELEMATIC	1.6 VTI 16v 88kw 5FW	Display C-
 5008	VISUAL./TELEMATIC	1.6 VTI 16v 88kw 5FW	Info Display
 5008	VISUAL./TELEMATIC	2.0 HDI 16v 100kw	Display C-
 5008	VISUAL./TELEMATIC	2.0 HDI 16v 100kw	Info Display
 5008	VISUAL./TELEMATIC	2.0 HDI 16v 110kw RHE-FAP	Display C-
 5008	VISUAL./TELEMATIC	2.0 HDI 16v 110kw RHE-FAP	Info Display
 5008	VISUAL./TELEMATIC	2.0 HDI 16v 120kw	Display C-
 5008	VISUAL./TELEMATIC	2.0 HDI 16v 120kw RHE-FAP	Info Display
 605	DIESEL MANAGEMEN	2.5 TD 12v 94kw THY	BOSCH MSA11 VP36
 605	ENGINE MANAGEME	2.0 94kw R6A	Marelli MM G5 [Slow]
 605	ENGINE MANAGEME	3.0 V6 12v 123kw SFZ	BENDIX FENIX 3B [Slow]
 605	ENGINE MANAGEME	3.0 V6 12v 123kw UFZ	BENDIX FENIX 3B [Slow]
 605	ENGINE MANAGEME	3.0 V6 12v 123kw UKZ	BENDIX FENIX 3B [Slow]
 605	ENGINE MANAGEME	3.0 V6 12v 123kw ZPJ	BENDIX FENIX 3B [Slow]
 605	ENGINE MANAGEME	3.0 V6 24v 143kw XFZ	BENDIX FENIX 3B [Slow]
 605	ENGINE MANAGEME	3.0 V6 24v 147kw SKZ	BENDIX FENIX 4 [Slow]
 605	ENGINE MANAGEME	3.0 V6 24v 147kw UKZ	BENDIX FENIX 4 [Slow]
 605	MAINTENANCE	2.5 TD 12v 94kw THY	BOSCH MSA11 VP36
 607	ABS + TRACT. CONT	2.0 16v 100kw RFN	ABS/ESP
 607	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP	ABS/ESP
 607	ABS + TRACT. CONT	2.0 HDI 16v 79kw RHT	ABS/ESP
 607	ABS + TRACT. CONT	2.0 HDI 16v 80kw RHW	ABS/ESP
 607	ABS + TRACT. CONT	2.0 HDI 16v 81kw RHS	ABS/ESP
 607	ABS + TRACT. CONT	2.0 HDI 16v 93kw RHL	ABS/ESP
 607	ABS + TRACT. CONT	2.0 HDI 81kw RHZ	ABS/ESP
 607	ABS + TRACT. CONT	2.2 16v 118kw 3FZ	ABS/ESP
 607	ABS + TRACT. CONT	2.2 16v 120kw 3FY	ABS/ESP
 607	ABS + TRACT. CONT	2.2 HDI 16v 120kw 4HP	ABS/ESP
 607	ABS + TRACT. CONT	2.2 HDI 16v 125kw 4HT-FAP	ABS/ESP
 607	ABS + TRACT. CONT	2.2 HDI 16v 98kw 4HX	ABS/ESP
 607	ABS + TRACT. CONT	2.7 HDI V6 24v 150kw UHZ-FAP	ABS/ESP
 607	ABS + TRACT. CONT	3.0 V6 24v 152kw XFX	ABS/ESP
 607	ABS + TRACT. CONT	3.0 V6 24v 155kw Xfv	ABS/ESP
 607	AIRBAG	2.0 16v 100kw RFN	AirBag CENTRAL
 607	AIRBAG	2.0 HDI 16v 100kw RHR-FAP	AirBag CENTRAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 607	AIRBAG	2.0 HDI 16v 79kw RHT	AirBag CENTRAL
 607	AIRBAG	2.0 HDI 16v 80kw RHW	AirBag CENTRAL
 607	AIRBAG	2.0 HDI 16v 81kw RHS	AirBag CENTRAL
 607	AIRBAG	2.0 HDI 16v 93kw RHL	AirBag CENTRAL
 607	AIRBAG	2.0 HDI 81kw RHZ	AirBag CENTRAL
 607	AIRBAG	2.2 16v 118kw 3FZ	AirBag CENTRAL
 607	AIRBAG	2.2 16v 120kw 3FY	AirBag CENTRAL
 607	AIRBAG	2.2 HDI 16v 120kw 4HP	AirBag CENTRAL
 607	AIRBAG	2.2 HDI 16v 125kw 4HT-FAP	AirBag CENTRAL
 607	AIRBAG	2.2 HDI 16v 98kw 4HX	AirBag CENTRAL
 607	AIRBAG	2.7 HDI V6 24v 150kw UHZ-FAP	AirBag CENTRAL
 607	AIRBAG	3.0 V6 24v 152kw XFX	AirBag CENTRAL
 607	AIRBAG	3.0 V6 24v 155kw XFX	AirBag CENTRAL
 607	ANTITHEFT	2.0 16v 100kw RFN	Alarm PSA2
 607	ANTITHEFT	2.0 HDI 16v 100kw RHR-FAP	Alarm PSA2
 607	ANTITHEFT	2.0 HDI 16v 79kw RHT	Alarm PSA2
 607	ANTITHEFT	2.0 HDI 16v 80kw RHW	Alarm PSA2
 607	ANTITHEFT	2.0 HDI 16v 81kw RHS	Alarm PSA2
 607	ANTITHEFT	2.0 HDI 16v 93kw RHL	Alarm PSA2
 607	ANTITHEFT	2.0 HDI 81kw RHZ	Alarm PSA2
 607	ANTITHEFT	2.2 16v 118kw 3FZ	Alarm PSA2
 607	ANTITHEFT	2.2 16v 120kw 3FY	Alarm PSA2
 607	ANTITHEFT	2.2 HDI 16v 120kw 4HP	Alarm PSA2
 607	ANTITHEFT	2.2 HDI 16v 125kw 4HT-FAP	Alarm PSA2
 607	ANTITHEFT	2.2 HDI 16v 98kw 4HX	Alarm PSA2
 607	ANTITHEFT	2.7 HDI V6 24v 150kw UHZ-FAP	Alarm PSA2
 607	ANTITHEFT	3.0 V6 24v 152kw XFX	Alarm PSA2
 607	ANTITHEFT	3.0 V6 24v 155kw XFX	Alarm PSA2
 607	AUTOM. TRANSMISSI	2.0 16v 100kw RFN	A/T AM6
 607	AUTOM. TRANSMISSI	2.0 16v 100kw RFN	A7T 4HP20
 607	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP	A/T AM6
 607	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP	A7T 4HP20
 607	AUTOM. TRANSMISSI	2.0 HDI 16v 79kw RHT	A/T AM6
 607	AUTOM. TRANSMISSI	2.0 HDI 16v 79kw RHT	A7T 4HP20
 607	AUTOM. TRANSMISSI	2.0 HDI 16v 80kw RHW	A/T AM6
 607	AUTOM. TRANSMISSI	2.0 HDI 16v 80kw RHW	A7T 4HP20
 607	AUTOM. TRANSMISSI	2.0 HDI 16v 81kw RHS	A/T AM6
 607	AUTOM. TRANSMISSI	2.0 HDI 16v 81kw RHS	A7T 4HP20
 607	AUTOM. TRANSMISSI	2.0 HDI 16v 93kw RHL	A/T AM6
 607	AUTOM. TRANSMISSI	2.0 HDI 16v 93kw RHL	A7T 4HP20
 607	AUTOM. TRANSMISSI	2.0 HDI 81kw RHZ	A/T AM6
 607	AUTOM. TRANSMISSI	2.0 HDI 81kw RHZ	A7T 4HP20
 607	AUTOM. TRANSMISSI	2.2 16v 118kw 3FZ	A/T AM6
 607	AUTOM. TRANSMISSI	2.2 16v 118kw 3FZ	A7T 4HP20
 607	AUTOM. TRANSMISSI	2.2 16v 120kw 3FY	A/T AM6
 607	AUTOM. TRANSMISSI	2.2 16v 120kw 3FY	A7T 4HP20
 607	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HP	A/T AM6
 607	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HP	A7T 4HP20
 607	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HT-FAP	A/T AM6
 607	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HT-FAP	A7T 4HP20
 607	AUTOM. TRANSMISSI	2.2 HDI 16v 98kw 4HX	A/T AM6
 607	AUTOM. TRANSMISSI	2.2 HDI 16v 98kw 4HX	A7T 4HP20
 607	AUTOM. TRANSMISSI	2.7 HDI V6 24v 150kw UHZ-FAP	A/T AM6
 607	AUTOM. TRANSMISSI	2.7 HDI V6 24v 150kw UHZ-FAP	A7T 4HP20
 607	AUTOM. TRANSMISSI	3.0 V6 24v 152kw XFX	A/T AM6
 607	AUTOM. TRANSMISSI	3.0 V6 24v 152kw XFX	A7T 4HP20
 607	AUTOM. TRANSMISSI	3.0 V6 24v 155kw XFX	A/T AM6
 607	AUTOM. TRANSMISSI	3.0 V6 24v 155kw XFX	A7T 4HP20

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 607	AUX. HEATING	2.0 16v 100kw RFN	Var.1
 607	AUX. HEATING	2.0 16v 100kw RFN	Var.2
 607	AUX. HEATING	2.0 16v 100kw RFN	Var.3
 607	AUX. HEATING	2.0 HDI 16v 100kw RHR-FAP	Var.1
 607	AUX. HEATING	2.0 HDI 16v 100kw RHR-FAP	Var.2
 607	AUX. HEATING	2.0 HDI 16v 100kw RHR-FAP	Var.3
 607	AUX. HEATING	2.0 HDI 16v 79kw RHT	Var.1
 607	AUX. HEATING	2.0 HDI 16v 79kw RHT	Var.2
 607	AUX. HEATING	2.0 HDI 16v 79kw RHT	Var.3
 607	AUX. HEATING	2.0 HDI 16v 80kw RHW	Var.1
 607	AUX. HEATING	2.0 HDI 16v 80kw RHW	Var.2
 607	AUX. HEATING	2.0 HDI 16v 80kw RHW	Var.3
 607	AUX. HEATING	2.0 HDI 16v 81kw RHS	Var.1
 607	AUX. HEATING	2.0 HDI 16v 81kw RHS	Var.2
 607	AUX. HEATING	2.0 HDI 16v 81kw RHS	Var.3
 607	AUX. HEATING	2.0 HDI 16v 93kw RHL	Var.1
 607	AUX. HEATING	2.0 HDI 16v 93kw RHL	Var.2
 607	AUX. HEATING	2.0 HDI 16v 93kw RHL	Var.3
 607	AUX. HEATING	2.0 HDI 81kw RHZ	Var.1
 607	AUX. HEATING	2.0 HDI 81kw RHZ	Var.2
 607	AUX. HEATING	2.0 HDI 81kw RHZ	Var.3
 607	AUX. HEATING	2.2 16v 118kw 3FZ	Var.1
 607	AUX. HEATING	2.2 16v 118kw 3FZ	Var.2
 607	AUX. HEATING	2.2 16v 118kw 3FZ	Var.3
 607	AUX. HEATING	2.2 16v 120kw 3FY	Var.1
 607	AUX. HEATING	2.2 16v 120kw 3FY	Var.2
 607	AUX. HEATING	2.2 16v 120kw 3FY	Var.3
 607	AUX. HEATING	2.2 HDI 16v 120kw 4HP	Var.1
 607	AUX. HEATING	2.2 HDI 16v 120kw 4HP	Var.2
 607	AUX. HEATING	2.2 HDI 16v 120kw 4HP	Var.3
 607	AUX. HEATING	2.2 HDI 16v 125kw 4HT-FAP	Var.1
 607	AUX. HEATING	2.2 HDI 16v 125kw 4HT-FAP	Var.2
 607	AUX. HEATING	2.2 HDI 16v 125kw 4HT-FAP	Var.3
 607	AUX. HEATING	2.2 HDI 16v 98kw 4HX	Var.1
 607	AUX. HEATING	2.2 HDI 16v 98kw 4HX	Var.2
 607	AUX. HEATING	2.2 HDI 16v 98kw 4HX	Var.3
 607	AUX. HEATING	2.7 HDI V6 24v 150kw UHZ-FAP	Var.1
 607	AUX. HEATING	2.7 HDI V6 24v 150kw UHZ-FAP	Var.2
 607	AUX. HEATING	2.7 HDI V6 24v 150kw UHZ-FAP	Var.3
 607	AUX. HEATING	3.0 V6 24v 152kw XFX	Var.1
 607	AUX. HEATING	3.0 V6 24v 152kw XFX	Var.2
 607	AUX. HEATING	3.0 V6 24v 152kw XFX	Var.3
 607	AUX. HEATING	3.0 V6 24v 155kw XFX	Var.1
 607	AUX. HEATING	3.0 V6 24v 155kw XFX	Var.2
 607	AUX. HEATING	3.0 V6 24v 155kw XFX	Var.3
 607	CHASSIS NETWORK	2.0 16v 100kw RFN	Back memory module
 607	CHASSIS NETWORK	2.0 16v 100kw RFN	Body Computer BSC
 607	CHASSIS NETWORK	2.0 16v 100kw RFN	Body Computer BSI
 607	CHASSIS NETWORK	2.0 16v 100kw RFN	Body Computer BSM
 607	CHASSIS NETWORK	2.0 16v 100kw RFN	Body Computer BSR Var.1
 607	CHASSIS NETWORK	2.0 16v 100kw RFN	Body Computer BSR Var.2
 607	CHASSIS NETWORK	2.0 16v 100kw RFN	Var.1
 607	CHASSIS NETWORK	2.0 16v 100kw RFN	Var.2
 607	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	Back memory module
 607	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	Body Computer BSC
 607	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	Body Computer BSI
 607	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	Body Computer BSM
 607	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	Body Computer BSR Var.1

Systems supported by ECUREADER / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 607	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	Body Computer BSR Var.2
 607	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	Var.1
 607	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP	Var.2
 607	CHASSIS NETWORK	2.0 HDI 16v 79kw RHT	Back memory module
 607	CHASSIS NETWORK	2.0 HDI 16v 79kw RHT	Body Computer BSC
 607	CHASSIS NETWORK	2.0 HDI 16v 79kw RHT	Body Computer BSI
 607	CHASSIS NETWORK	2.0 HDI 16v 79kw RHT	Body Computer BSM
 607	CHASSIS NETWORK	2.0 HDI 16v 79kw RHT	Body Computer BSR Var.1
 607	CHASSIS NETWORK	2.0 HDI 16v 79kw RHT	Body Computer BSR Var.2
 607	CHASSIS NETWORK	2.0 HDI 16v 79kw RHT	Var.1
 607	CHASSIS NETWORK	2.0 HDI 16v 79kw RHT	Var.2
 607	CHASSIS NETWORK	2.0 HDI 16v 80kw RHW	Back memory module
 607	CHASSIS NETWORK	2.0 HDI 16v 80kw RHW	Body Computer BSC
 607	CHASSIS NETWORK	2.0 HDI 16v 80kw RHW	Body Computer BSI
 607	CHASSIS NETWORK	2.0 HDI 16v 80kw RHW	Body Computer BSM
 607	CHASSIS NETWORK	2.0 HDI 16v 80kw RHW	Body Computer BSR Var.1
 607	CHASSIS NETWORK	2.0 HDI 16v 80kw RHW	Body Computer BSR Var.2
 607	CHASSIS NETWORK	2.0 HDI 16v 80kw RHW	Var.1
 607	CHASSIS NETWORK	2.0 HDI 16v 80kw RHW	Var.2
 607	CHASSIS NETWORK	2.0 HDI 16v 81kw RHS	Back memory module
 607	CHASSIS NETWORK	2.0 HDI 16v 81kw RHS	Body Computer BSC
 607	CHASSIS NETWORK	2.0 HDI 16v 81kw RHS	Body Computer BSI
 607	CHASSIS NETWORK	2.0 HDI 16v 81kw RHS	Body Computer BSM
 607	CHASSIS NETWORK	2.0 HDI 16v 81kw RHS	Body Computer BSR Var.1
 607	CHASSIS NETWORK	2.0 HDI 16v 81kw RHS	Body Computer BSR Var.2
 607	CHASSIS NETWORK	2.0 HDI 16v 81kw RHS	Var.1
 607	CHASSIS NETWORK	2.0 HDI 16v 81kw RHS	Var.2
 607	CHASSIS NETWORK	2.0 HDI 16v 93kw RHL	Back memory module
 607	CHASSIS NETWORK	2.0 HDI 16v 93kw RHL	Body Computer BSC
 607	CHASSIS NETWORK	2.0 HDI 16v 93kw RHL	Body Computer BSI
 607	CHASSIS NETWORK	2.0 HDI 16v 93kw RHL	Body Computer BSM
 607	CHASSIS NETWORK	2.0 HDI 16v 93kw RHL	Body Computer BSR Var.1
 607	CHASSIS NETWORK	2.0 HDI 16v 93kw RHL	Body Computer BSR Var.2
 607	CHASSIS NETWORK	2.0 HDI 16v 93kw RHL	Var.1
 607	CHASSIS NETWORK	2.0 HDI 16v 93kw RHL	Var.2
 607	CHASSIS NETWORK	2.0 HDI 81kw RHZ	Back memory module
 607	CHASSIS NETWORK	2.0 HDI 81kw RHZ	Body Computer BSC
 607	CHASSIS NETWORK	2.0 HDI 81kw RHZ	Body Computer BSI
 607	CHASSIS NETWORK	2.0 HDI 81kw RHZ	Body Computer BSM
 607	CHASSIS NETWORK	2.0 HDI 81kw RHZ	Body Computer BSR Var.1
 607	CHASSIS NETWORK	2.0 HDI 81kw RHZ	Body Computer BSR Var.2
 607	CHASSIS NETWORK	2.0 HDI 81kw RHZ	Var.1
 607	CHASSIS NETWORK	2.0 HDI 81kw RHZ	Var.2
 607	CHASSIS NETWORK	2.2 16v 118kw 3FZ	Back memory module
 607	CHASSIS NETWORK	2.2 16v 118kw 3FZ	Body Computer BSC
 607	CHASSIS NETWORK	2.2 16v 118kw 3FZ	Body Computer BSI
 607	CHASSIS NETWORK	2.2 16v 118kw 3FZ	Body Computer BSM
 607	CHASSIS NETWORK	2.2 16v 118kw 3FZ	Body Computer BSR Var.1
 607	CHASSIS NETWORK	2.2 16v 118kw 3FZ	Body Computer BSR Var.2
 607	CHASSIS NETWORK	2.2 16v 118kw 3FZ	Var.1
 607	CHASSIS NETWORK	2.2 16v 118kw 3FZ	Var.2
 607	CHASSIS NETWORK	2.2 16v 120kw 3FY	Back memory module
 607	CHASSIS NETWORK	2.2 16v 120kw 3FY	Body Computer BSC
 607	CHASSIS NETWORK	2.2 16v 120kw 3FY	Body Computer BSI
 607	CHASSIS NETWORK	2.2 16v 120kw 3FY	Body Computer BSM
 607	CHASSIS NETWORK	2.2 16v 120kw 3FY	Body Computer BSR Var.1
 607	CHASSIS NETWORK	2.2 16v 120kw 3FY	Body Computer BSR Var.2
 607	CHASSIS NETWORK	2.2 16v 120kw 3FY	Var.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 607	CHASSIS NETWORK	2.2 16v 120kw 3FY	Var.2
 607	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP	Back memory module
 607	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP	Body Computer BSC
 607	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP	Body Computer BSI
 607	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP	Body Computer BSM
 607	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP	Body Computer BSR Var.1
 607	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP	Body Computer BSR Var.2
 607	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP	Var.1
 607	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP	Var.2
 607	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP	Back memory module
 607	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP	Body Computer BSC
 607	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP	Body Computer BSI
 607	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP	Body Computer BSM
 607	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP	Body Computer BSR Var.1
 607	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP	Body Computer BSR Var.2
 607	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP	Var.1
 607	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP	Var.2
 607	CHASSIS NETWORK	2.2 HDI 16v 98kw 4HX	Back memory module
 607	CHASSIS NETWORK	2.2 HDI 16v 98kw 4HX	Body Computer BSC
 607	CHASSIS NETWORK	2.2 HDI 16v 98kw 4HX	Body Computer BSI
 607	CHASSIS NETWORK	2.2 HDI 16v 98kw 4HX	Body Computer BSM
 607	CHASSIS NETWORK	2.2 HDI 16v 98kw 4HX	Body Computer BSR Var.1
 607	CHASSIS NETWORK	2.2 HDI 16v 98kw 4HX	Body Computer BSR Var.2
 607	CHASSIS NETWORK	2.2 HDI 16v 98kw 4HX	Var.1
 607	CHASSIS NETWORK	2.2 HDI 16v 98kw 4HX	Var.2
 607	CHASSIS NETWORK	2.7 HDI V6 24v 150kw UHZ-FAP	Back memory module
 607	CHASSIS NETWORK	2.7 HDI V6 24v 150kw UHZ-FAP	Body Computer BSC
 607	CHASSIS NETWORK	2.7 HDI V6 24v 150kw UHZ-FAP	Body Computer BSI
 607	CHASSIS NETWORK	2.7 HDI V6 24v 150kw UHZ-FAP	Body Computer BSM
 607	CHASSIS NETWORK	2.7 HDI V6 24v 150kw UHZ-FAP	Body Computer BSR Var.1
 607	CHASSIS NETWORK	2.7 HDI V6 24v 150kw UHZ-FAP	Body Computer BSR Var.2
 607	CHASSIS NETWORK	2.7 HDI V6 24v 150kw UHZ-FAP	Var.1
 607	CHASSIS NETWORK	2.7 HDI V6 24v 150kw UHZ-FAP	Var.2
 607	CHASSIS NETWORK	3.0 V6 24v 152kw XFX	Back memory module
 607	CHASSIS NETWORK	3.0 V6 24v 152kw XFX	Body Computer BSC
 607	CHASSIS NETWORK	3.0 V6 24v 152kw XFX	Body Computer BSI
 607	CHASSIS NETWORK	3.0 V6 24v 152kw XFX	Body Computer BSM
 607	CHASSIS NETWORK	3.0 V6 24v 152kw XFX	Body Computer BSR Var.1
 607	CHASSIS NETWORK	3.0 V6 24v 152kw XFX	Body Computer BSR Var.2
 607	CHASSIS NETWORK	3.0 V6 24v 152kw XFX	Var.1
 607	CHASSIS NETWORK	3.0 V6 24v 152kw XFX	Var.2
 607	CHASSIS NETWORK	3.0 V6 24v 155kw XFV	Back memory module
 607	CHASSIS NETWORK	3.0 V6 24v 155kw XFV	Body Computer BSC
 607	CHASSIS NETWORK	3.0 V6 24v 155kw XFV	Body Computer BSI
 607	CHASSIS NETWORK	3.0 V6 24v 155kw XFV	Body Computer BSM
 607	CHASSIS NETWORK	3.0 V6 24v 155kw XFV	Body Computer BSR Var.1
 607	CHASSIS NETWORK	3.0 V6 24v 155kw XFV	Body Computer BSR Var.2
 607	CHASSIS NETWORK	3.0 V6 24v 155kw XFV	Var.1
 607	CHASSIS NETWORK	3.0 V6 24v 155kw XFV	Var.2
 607	CLIMA	2.0 16v 100kw RFN	CLIMA
 607	CLIMA	2.0 16v 100kw RFN	VALEO Klimautomatik 2.0
 607	CLIMA	2.0 HDI 16v 100kw RHR-FAP	CLIMA
 607	CLIMA	2.0 HDI 16v 100kw RHR-FAP	VALEO Klimautomatik 2.0
 607	CLIMA	2.0 HDI 16v 79kw RHT	CLIMA
 607	CLIMA	2.0 HDI 16v 79kw RHT	VALEO Klimautomatik 2.0
 607	CLIMA	2.0 HDI 16v 80kw RHW	CLIMA
 607	CLIMA	2.0 HDI 16v 80kw RHW	VALEO Klimautomatik 2.0
 607	CLIMA	2.0 HDI 16v 81kw RHS	CLIMA

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 607	CLIMA	2.0 HDI 16v 81kw RHS	VALEO Klimautomatik 2.0
 607	CLIMA	2.0 HDI 16v 93kw RHL	CLIMA
 607	CLIMA	2.0 HDI 16v 93kw RHL	VALEO Klimautomatik 2.0
 607	CLIMA	2.0 HDI 81kw RHZ	CLIMA
 607	CLIMA	2.0 HDI 81kw RHZ	VALEO Klimautomatik 2.0
 607	CLIMA	2.2 16v 118kw 3FZ	CLIMA
 607	CLIMA	2.2 16v 118kw 3FZ	VALEO Klimautomatik 2.0
 607	CLIMA	2.2 16v 120kw 3FY	CLIMA
 607	CLIMA	2.2 16v 120kw 3FY	VALEO Klimautomatik 2.0
 607	CLIMA	2.2 HDI 16v 120kw 4HP	CLIMA
 607	CLIMA	2.2 HDI 16v 120kw 4HP	VALEO Klimautomatik 2.0
 607	CLIMA	2.2 HDI 16v 125kw 4HT-FAP	CLIMA
 607	CLIMA	2.2 HDI 16v 125kw 4HT-FAP	VALEO Klimautomatik 2.0
 607	CLIMA	2.2 HDI 16v 98kw 4HX	CLIMA
 607	CLIMA	2.2 HDI 16v 98kw 4HX	VALEO Klimautomatik 2.0
 607	CLIMA	2.7 HDI V6 24v 150kw UHZ-FAP	CLIMA
 607	CLIMA	2.7 HDI V6 24v 150kw UHZ-FAP	VALEO Klimautomatik 2.0
 607	CLIMA	3.0 V6 24v 152kw XFX	CLIMA
 607	CLIMA	3.0 V6 24v 152kw XFX	VALEO Klimautomatik 2.0
 607	CLIMA	3.0 V6 24v 155kw XFX	CLIMA
 607	CLIMA	3.0 V6 24v 155kw XFX	VALEO Klimautomatik 2.0
 607	COMFORT SYSTEM	2.0 16v 100kw RFN	Left seat keyboard
 607	COMFORT SYSTEM	2.0 16v 100kw RFN	Phone Kit
 607	COMFORT SYSTEM	2.0 16v 100kw RFN	Windshield info projector
 607	COMFORT SYSTEM	2.0 HDI 16v 100kw RHR-FAP	Left seat keyboard
 607	COMFORT SYSTEM	2.0 HDI 16v 100kw RHR-FAP	Phone Kit
 607	COMFORT SYSTEM	2.0 HDI 16v 100kw RHR-FAP	Windshield info projector
 607	COMFORT SYSTEM	2.0 HDI 16v 79kw RHT	Phone Kit
 607	COMFORT SYSTEM	2.0 HDI 16v 79kw RHT	Right seat keyboard
 607	COMFORT SYSTEM	2.0 HDI 16v 79kw RHT	Windshield info projector
 607	COMFORT SYSTEM	2.0 HDI 16v 80kw RHW	Phone Kit
 607	COMFORT SYSTEM	2.0 HDI 16v 80kw RHW	Seat keyboard
 607	COMFORT SYSTEM	2.0 HDI 16v 80kw RHW	Windshield info projector
 607	COMFORT SYSTEM	2.0 HDI 16v 81kw RHS	Phone Kit
 607	COMFORT SYSTEM	2.0 HDI 16v 81kw RHS	Seat keyboard
 607	COMFORT SYSTEM	2.0 HDI 16v 81kw RHS	Windshield info projector
 607	COMFORT SYSTEM	2.0 HDI 16v 93kw RHL	Phone Kit
 607	COMFORT SYSTEM	2.0 HDI 16v 93kw RHL	Seat keyboard
 607	COMFORT SYSTEM	2.0 HDI 16v 93kw RHL	Windshield info projector
 607	COMFORT SYSTEM	2.0 HDI 81kw RHZ	Phone Kit
 607	COMFORT SYSTEM	2.0 HDI 81kw RHZ	Seat keyboard
 607	COMFORT SYSTEM	2.0 HDI 81kw RHZ	Windshield info projector
 607	COMFORT SYSTEM	2.2 16v 118kw 3FZ	Phone Kit
 607	COMFORT SYSTEM	2.2 16v 118kw 3FZ	Seat keyboard
 607	COMFORT SYSTEM	2.2 16v 118kw 3FZ	Windshield info projector
 607	COMFORT SYSTEM	2.2 16v 120kw 3FY	Phone Kit
 607	COMFORT SYSTEM	2.2 16v 120kw 3FY	Seat keyboard
 607	COMFORT SYSTEM	2.2 16v 120kw 3FY	Windshield info projector
 607	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HP	Phone Kit
 607	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HP	Seat keyboard
 607	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HP	Windshield info projector
 607	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HT-FAP	Phone Kit
 607	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HT-FAP	Seat keyboard
 607	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HT-FAP	Windshield info projector
 607	COMFORT SYSTEM	2.2 HDI 16v 98kw 4HX	Phone Kit
 607	COMFORT SYSTEM	2.2 HDI 16v 98kw 4HX	Seat keyboard
 607	COMFORT SYSTEM	2.2 HDI 16v 98kw 4HX	Windshield info projector
 607	COMFORT SYSTEM	2.7 HDI V6 24v 150kw UHZ-FAP	Phone Kit

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 607	COMFORT SYSTEM	2.7 HDI V6 24v 150kw UHZ-FAP	Seat keyboard
 607	COMFORT SYSTEM	2.7 HDI V6 24v 150kw UHZ-FAP	Windshield info projector
 607	COMFORT SYSTEM	3.0 V6 24v 152kw XFX	Phone Kit
 607	COMFORT SYSTEM	3.0 V6 24v 152kw XFX	Seat keyboard
 607	COMFORT SYSTEM	3.0 V6 24v 152kw XFX	Windshield info projector
 607	COMFORT SYSTEM	3.0 V6 24v 155kw XFX	Phone Kit
 607	COMFORT SYSTEM	3.0 V6 24v 155kw XFX	Seat keyboard
 607	COMFORT SYSTEM	3.0 V6 24v 155kw XFX	Windshield info projector
 607	DASHBOARD	2.0 16v 100kw RFN	
 607	DASHBOARD	2.0 HDI 16v 100kw RHR-FAP	
 607	DASHBOARD	2.0 HDI 16v 79kw RHT	
 607	DASHBOARD	2.0 HDI 16v 80kw RHW	
 607	DASHBOARD	2.0 HDI 16v 81kw RHS	
 607	DASHBOARD	2.0 HDI 16v 93kw RHL	
 607	DASHBOARD	2.0 HDI 81kw RHZ	
 607	DASHBOARD	2.2 16v 118kw 3FZ	
 607	DASHBOARD	2.2 16v 120kw 3FY	
 607	DASHBOARD	2.2 HDI 16v 120kw 4HP	
 607	DASHBOARD	2.2 HDI 16v 125kw 4HT-FAP	
 607	DASHBOARD	2.2 HDI 16v 98kw 4HX	
 607	DASHBOARD	2.7 HDI V6 24v 150kw UHZ-FAP	
 607	DASHBOARD	3.0 V6 24v 152kw XFX	
 607	DASHBOARD	3.0 V6 24v 155kw XFX	
 607	DIESEL ADDITION	2.0 HDI 16v 100kw RHR-FAP	
 607	DIESEL ADDITION	2.0 HDI 16v 79kw RHT	
 607	DIESEL ADDITION	2.0 HDI 16v 80kw RHW	
 607	DIESEL ADDITION	2.0 HDI 16v 81kw RHS	
 607	DIESEL ADDITION	2.0 HDI 16v 93kw RHL	
 607	DIESEL ADDITION	2.0 HDI 81kw RHZ	
 607	DIESEL ADDITION	2.2 HDI 16v 120kw 4HP	
 607	DIESEL ADDITION	2.2 HDI 16v 125kw 4HT-FAP	
 607	DIESEL ADDITION	2.2 HDI 16v 98kw 4HX	
 607	DIESEL ADDITION	2.7 HDI V6 24v 150kw UHZ-FAP	
 607	DRIVER SEAT CONT	2.0 16v 100kw RFN	
 607	DRIVER SEAT CONT	2.0 HDI 16v 100kw RHR-FAP	
 607	DRIVER SEAT CONT	2.0 HDI 16v 79kw RHT	
 607	DRIVER SEAT CONT	2.0 HDI 16v 80kw RHW	
 607	DRIVER SEAT CONT	2.0 HDI 16v 81kw RHS	
 607	DRIVER SEAT CONT	2.0 HDI 16v 93kw RHL	
 607	DRIVER SEAT CONT	2.0 HDI 81kw RHZ	
 607	DRIVER SEAT CONT	2.2 16v 118kw 3FZ	
 607	DRIVER SEAT CONT	2.2 16v 120kw 3FY	
 607	DRIVER SEAT CONT	2.2 HDI 16v 120kw 4HP	
 607	DRIVER SEAT CONT	2.2 HDI 16v 125kw 4HT-FAP	
 607	DRIVER SEAT CONT	2.2 HDI 16v 98kw 4HX	
 607	DRIVER SEAT CONT	2.7 HDI V6 24v 150kw UHZ-FAP	
 607	DRIVER SEAT CONT	3.0 V6 24v 152kw 4HX	
 607	DRIVER SEAT CONT	3.0 V6 24v 155kw UHZ-FAP	
 607	DRIVER SIDE DOOR	2.0 16v 100kw RFN	Marelli MTP CONDUCT
 607	DRIVER SIDE DOOR	2.0 16v 100kw RFN	Var.1
 607	DRIVER SIDE DOOR	2.0 16v 100kw RFN	Var.2
 607	DRIVER SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	Marelli MTP CONDUCT
 607	DRIVER SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	Var.1
 607	DRIVER SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	Var.2
 607	DRIVER SIDE DOOR	2.0 HDI 16v 79kw RHT	Marelli MTP CONDUCT
 607	DRIVER SIDE DOOR	2.0 HDI 16v 79kw RHT	Var.1
 607	DRIVER SIDE DOOR	2.0 HDI 16v 79kw RHT	Var.2
 607	DRIVER SIDE DOOR	2.0 HDI 16v 80kw RHW	Marelli MTP CONDUCT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 607	DRIVER SIDE DOOR	2.0 HDI 16v 80kw RHW	Var.1
 607	DRIVER SIDE DOOR	2.0 HDI 16v 80kw RHW	Var.2
 607	DRIVER SIDE DOOR	2.0 HDI 16v 81kw RHS	Marelli MTP CONDUCT
 607	DRIVER SIDE DOOR	2.0 HDI 16v 81kw RHS	Var.1
 607	DRIVER SIDE DOOR	2.0 HDI 16v 81kw RHS	Var.2
 607	DRIVER SIDE DOOR	2.0 HDI 16v 93kw RHL	Marelli MTP CONDUCT
 607	DRIVER SIDE DOOR	2.0 HDI 16v 93kw RHL	Var.1
 607	DRIVER SIDE DOOR	2.0 HDI 16v 93kw RHL	Var.2
 607	DRIVER SIDE DOOR	2.0 HDI 81kw RHZ	Marelli MTP CONDUCT
 607	DRIVER SIDE DOOR	2.0 HDI 81kw RHZ	Var.1
 607	DRIVER SIDE DOOR	2.0 HDI 81kw RHZ	Var.2
 607	DRIVER SIDE DOOR	2.2 16v 118kw 3FZ	Marelli MTP CONDUCT
 607	DRIVER SIDE DOOR	2.2 16v 118kw 3FZ	Var.1
 607	DRIVER SIDE DOOR	2.2 16v 118kw 3FZ	Var.2
 607	DRIVER SIDE DOOR	2.2 16v 120kw 3FY	Marelli MTP CONDUCT
 607	DRIVER SIDE DOOR	2.2 16v 120kw 3FY	Var.1
 607	DRIVER SIDE DOOR	2.2 16v 120kw 3FY	Var.2
 607	DRIVER SIDE DOOR	2.2 HDI 16v 120kw 4HP	Marelli MTP CONDUCT
 607	DRIVER SIDE DOOR	2.2 HDI 16v 120kw 4HP	Var.1
 607	DRIVER SIDE DOOR	2.2 HDI 16v 120kw 4HP	Var.2
 607	DRIVER SIDE DOOR	2.2 HDI 16v 125kw 4HT-FAP	Marelli MTP CONDUCT
 607	DRIVER SIDE DOOR	2.2 HDI 16v 125kw 4HT-FAP	Var.1
 607	DRIVER SIDE DOOR	2.2 HDI 16v 125kw 4HT-FAP	Var.2
 607	DRIVER SIDE DOOR	2.2 HDI 16v 98kw 4HX	Marelli MTP CONDUCT
 607	DRIVER SIDE DOOR	2.2 HDI 16v 98kw 4HX	Var.1
 607	DRIVER SIDE DOOR	2.2 HDI 16v 98kw 4HX	Var.2
 607	DRIVER SIDE DOOR	2.7 HDI V6 24v 150kw UHZ-FAP	Marelli MTP CONDUCT
 607	DRIVER SIDE DOOR	2.7 HDI V6 24v 150kw UHZ-FAP	Var.1
 607	DRIVER SIDE DOOR	2.7 HDI V6 24v 150kw UHZ-FAP	Var.2
 607	DRIVER SIDE DOOR	3.0 V6 24v 152kw XFX	Marelli MTP CONDUCT
 607	DRIVER SIDE DOOR	3.0 V6 24v 152kw XFX	Var.1
 607	DRIVER SIDE DOOR	3.0 V6 24v 152kw XFX	Var.2
 607	DRIVER SIDE DOOR	3.0 V6 24v 155kw XFV	Marelli MTP CONDUCT
 607	DRIVER SIDE DOOR	3.0 V6 24v 155kw XFV	Var.1
 607	DRIVER SIDE DOOR	3.0 V6 24v 155kw XFV	Var.2
 607	ELECTRIC STEERING	2.0 16v 100kw RFN	Var.1
 607	ELECTRIC STEERING	2.0 16v 100kw RFN	Var.2
 607	ELECTRIC STEERING	2.0 HDI 16v 100kw RHR-FAP	Var.1
 607	ELECTRIC STEERING	2.0 HDI 16v 100kw RHR-FAP	Var.2
 607	ELECTRIC STEERING	2.0 HDI 16v 79kw RHT	Var.1
 607	ELECTRIC STEERING	2.0 HDI 16v 79kw RHT	Var.2
 607	ELECTRIC STEERING	2.0 HDI 16v 80kw RHW	Var.1
 607	ELECTRIC STEERING	2.0 HDI 16v 80kw RHW	Var.2
 607	ELECTRIC STEERING	2.0 HDI 16v 81kw RHS	Var.1
 607	ELECTRIC STEERING	2.0 HDI 16v 81kw RHS	Var.2
 607	ELECTRIC STEERING	2.0 HDI 16v 93kw RHL	Var.1
 607	ELECTRIC STEERING	2.0 HDI 16v 93kw RHL	Var.2
 607	ELECTRIC STEERING	2.0 HDI 81kw RHZ	Var.1
 607	ELECTRIC STEERING	2.0 HDI 81kw RHZ	Var.2
 607	ELECTRIC STEERING	2.2 16v 118kw 3FZ	Var.1
 607	ELECTRIC STEERING	2.2 16v 118kw 3FZ	Var.2
 607	ELECTRIC STEERING	2.2 16v 120kw 3FY	Var.1
 607	ELECTRIC STEERING	2.2 16v 120kw 3FY	Var.2
 607	ELECTRIC STEERING	2.2 HDI 16v 120kw 4HP	Var.1
 607	ELECTRIC STEERING	2.2 HDI 16v 120kw 4HP	Var.2
 607	ELECTRIC STEERING	2.2 HDI 16v 125kw 4HT-FAP	Var.1
 607	ELECTRIC STEERING	2.2 HDI 16v 125kw 4HT-FAP	Var.2
 607	ELECTRIC STEERING	2.2 HDI 16v 98kw 4HX	Var.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 607	ELECTRIC STEERING	2.2 HDI 16v 98kw 4HX	Var.2
 607	ELECTRIC STEERING	2.7 HDI V6 24v 150kw UHZ-FAP	Var.1
 607	ELECTRIC STEERING	2.7 HDI V6 24v 150kw UHZ-FAP	Var.2
 607	ELECTRIC STEERING	3.0 V6 24v 152kw XFX	Var.1
 607	ELECTRIC STEERING	3.0 V6 24v 152kw XFX	Var.2
 607	ELECTRIC STEERING	3.0 V6 24v 155kw XFX	Var.1
 607	ELECTRIC STEERING	3.0 V6 24v 155kw XFX	Var.2
 607	ENGINE MANAGEME	2.0 16v 100kw RFN	Marelli MM48P
 607	ENGINE MANAGEME	2.0 16v 100kw RFN	Marelli MM4MP2
 607	ENGINE MANAGEME	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803 Common Rail
 607	ENGINE MANAGEME	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803A-CAN Common Rail
 607	ENGINE MANAGEME	2.0 HDI 16v 79kw RHT	BOSCH EDC 15 C2 Common Rail
 607	ENGINE MANAGEME	2.0 HDI 16v 80kw RHW	BOSCH EDC 15 C2 Common Rail
 607	ENGINE MANAGEME	2.0 HDI 16v 81kw RHS	BOSCH EDC 15 C2 Common Rail
 607	ENGINE MANAGEME	2.0 HDI 16v 81kw RHS (01-06)	BOSCH EDC 15 C2 Common Rail
 607	ENGINE MANAGEME	2.0 HDI 16v 93kw RHL (04-..)	EOBD
 607	ENGINE MANAGEME	2.0 HDI 81kw RHZ	BOSCH EDC 15 C2 Common Rail
 607	ENGINE MANAGEME	2.0 HDI 81kw RHZ	BOSCH EDC 15 C2 Common Rail
 607	ENGINE MANAGEME	2.0 HDI 81kw RHZ (03-..)	BOSCH EDC 15 C2 Common Rail
 607	ENGINE MANAGEME	2.2 16v 118kw 3FZ	Marelli MM4MP2
 607	ENGINE MANAGEME	2.2 16v 120kw 3FY	EOBD
 607	ENGINE MANAGEME	2.2 HDI 16v 120kw 4HP	BOSCH EDC 15 C2 Common Rail
 607	ENGINE MANAGEME	2.2 HDI 16v 120kw 4HP	BOSCH EDC 15 C2 Common Rail
 607	ENGINE MANAGEME	2.2 HDI 16v 120kw 4HP	BOSCH EDC 15 C2 Common Rail
 607	ENGINE MANAGEME	2.2 HDI 16v 125kw 4HT-FAP	BOSCH EDC 15 C2 Common Rail
 607	ENGINE MANAGEME	2.2 HDI 16v 125kw 4HT-FAP	BOSCH EDC 15 C2 Common Rail
 607	ENGINE MANAGEME	2.2 HDI 16v 125kw 4HT-FAP	BOSCH EDC 15 C2 Common Rail
 607	ENGINE MANAGEME	2.2 HDI 16v 98kw 4HX	BOSCH EDC 15 C2 Common Rail
 607	ENGINE MANAGEME	2.2 HDI 16v 98kw 4HX	BOSCH EDC 15 C2 Common Rail
 607	ENGINE MANAGEME	2.7 HDI V6 24v 150kw UHZ-FAP	SIEMENS SID 201 Common Rail
 607	ENGINE MANAGEME	3.0 V6 24v 152kw XFX	BOSCH ME7.4.6
 607	ENGINE MANAGEME	3.0 V6 24v 155kw XFX	BOSCH ME7.4.7
 607	HEADLIGHT LEVEL	2.0 16v 100kw RFN	
 607	HEADLIGHT LEVEL	2.0 HDI 16v 100kw RHR-FAP	
 607	HEADLIGHT LEVEL	2.0 HDI 16v 79kw RHT	
 607	HEADLIGHT LEVEL	2.0 HDI 16v 80kw RHW	
 607	HEADLIGHT LEVEL	2.0 HDI 16v 81kw RHS	
 607	HEADLIGHT LEVEL	2.0 HDI 16v 93kw RHL	
 607	HEADLIGHT LEVEL	2.0 HDI 81kw RHZ	
 607	HEADLIGHT LEVEL	2.2 16v 118kw 3FZ	
 607	HEADLIGHT LEVEL	2.2 16v 120kw 3FY	
 607	HEADLIGHT LEVEL	2.2 HDI 16v 120kw 4HP	
 607	HEADLIGHT LEVEL	2.2 HDI 16v 125kw 4HT-FAP	
 607	HEADLIGHT LEVEL	2.2 HDI 16v 98kw 4HX	
 607	HEADLIGHT LEVEL	2.7 HDI V6 24v 150kw UHZ-FAP	
 607	HEADLIGHT LEVEL	3.0 V6 24v 152kw XFX	
 607	HEADLIGHT LEVEL	3.0 V6 24v 155kw XFX	
 607	LH RIGHT MODULATI	2.0 16v 100kw RFN	
 607	LH RIGHT MODULATI	2.0 HDI 16v 100kw RHR-FAP	
 607	LH RIGHT MODULATI	2.0 HDI 16v 79kw RHT	
 607	LH RIGHT MODULATI	2.0 HDI 16v 80kw RHW	
 607	LH RIGHT MODULATI	2.0 HDI 16v 81kw RHS	
 607	LH RIGHT MODULATI	2.0 HDI 16v 93kw RHL	
 607	LH RIGHT MODULATI	2.0 HDI 81kw RHZ	
 607	LH RIGHT MODULATI	2.2 16v 118kw 3FZ	
 607	LH RIGHT MODULATI	2.2 16v 120kw 3FY	
 607	LH RIGHT MODULATI	2.2 HDI 16v 120kw 4HP	
 607	LH RIGHT MODULATI	2.2 HDI 16v 125kw 4HT-FAP	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 607	LH RIGHT MODULATI	2.2 HDI 16v 98kw 4HX	
 607	LH RIGHT MODULATI	2.7 HDI V6 24v 150kw UHZ-FAP	
 607	LH RIGHT MODULATI	3.0 V6 24v 152kw XFX	
 607	LH RIGHT MODULATI	3.0 V6 24v 155kw XFV	
 607	MAINTENANCE	2.0 16v 100kw RFN	A/T AM6
 607	MAINTENANCE	2.0 16v 100kw RFN	A/T AM6
 607	MAINTENANCE	2.0 16v 100kw RFN	ABS/ESP
 607	MAINTENANCE	2.0 16v 100kw RFN	ABS/ESP
 607	MAINTENANCE	2.0 16v 100kw RFN	AirBag CENTRAL
 607	MAINTENANCE	2.0 16v 100kw RFN	AirBag CENTRAL
 607	MAINTENANCE	2.0 16v 100kw RFN	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.0 16v 100kw RFN	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.0 16v 100kw RFN	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.0 16v 100kw RFN	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	A/T AM6
 607	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	A/T AM6
 607	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	ABS/ESP
 607	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	ABS/ESP
 607	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	AirBag CENTRAL
 607	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	AirBag CENTRAL
 607	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803 Common Rail
 607	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803 Common Rail
 607	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803 Common Rail
 607	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803A-CAN Common Rail
 607	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803A-CAN Common Rail
 607	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	SIEMENS SID 803A-CAN Common Rail
 607	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.0 HDI 16v 79kw RHT	A/T AM6
 607	MAINTENANCE	2.0 HDI 16v 79kw RHT	A/T AM6
 607	MAINTENANCE	2.0 HDI 16v 79kw RHT	ABS/ESP
 607	MAINTENANCE	2.0 HDI 16v 79kw RHT	ABS/ESP
 607	MAINTENANCE	2.0 HDI 16v 79kw RHT	AirBag CENTRAL
 607	MAINTENANCE	2.0 HDI 16v 79kw RHT	AirBag CENTRAL
 607	MAINTENANCE	2.0 HDI 16v 79kw RHT	BOSCH EDC 15 C2 Common Rail
 607	MAINTENANCE	2.0 HDI 16v 79kw RHT	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.0 HDI 16v 79kw RHT	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.0 HDI 16v 79kw RHT	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.0 HDI 16v 79kw RHT	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.0 HDI 16v 80kw RHW	A/T AM6
 607	MAINTENANCE	2.0 HDI 16v 80kw RHW	A/T AM6
 607	MAINTENANCE	2.0 HDI 16v 80kw RHW	ABS/ESP
 607	MAINTENANCE	2.0 HDI 16v 80kw RHW	ABS/ESP
 607	MAINTENANCE	2.0 HDI 16v 80kw RHW	AirBag CENTRAL
 607	MAINTENANCE	2.0 HDI 16v 80kw RHW	AirBag CENTRAL
 607	MAINTENANCE	2.0 HDI 16v 80kw RHW	BOSCH EDC 15 C2 Common Rail
 607	MAINTENANCE	2.0 HDI 16v 80kw RHW	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.0 HDI 16v 80kw RHW	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.0 HDI 16v 80kw RHW	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.0 HDI 16v 80kw RHW	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.0 HDI 16v 81kw RHS	A/T AM6
 607	MAINTENANCE	2.0 HDI 16v 81kw RHS	A/T AM6
 607	MAINTENANCE	2.0 HDI 16v 81kw RHS	ABS/ESP
 607	MAINTENANCE	2.0 HDI 16v 81kw RHS	ABS/ESP
 607	MAINTENANCE	2.0 HDI 16v 81kw RHS	AirBag CENTRAL
 607	MAINTENANCE	2.0 HDI 16v 81kw RHS	AirBag CENTRAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 607	MAINTENANCE	2.0 HDI 16v 81kw RHS	BOSCH EDC 15 C2 Common Rail
 607	MAINTENANCE	2.0 HDI 16v 81kw RHS	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.0 HDI 16v 81kw RHS	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.0 HDI 16v 81kw RHS	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.0 HDI 16v 81kw RHS	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.0 HDI 16v 81kw RHS (01-06)	BOSCH EDC 15 C2 Common Rail
 607	MAINTENANCE	2.0 HDI 16v 93kw RHL	A/T AM6
 607	MAINTENANCE	2.0 HDI 16v 93kw RHL	A/T AM6
 607	MAINTENANCE	2.0 HDI 16v 93kw RHL	ABS/ESP
 607	MAINTENANCE	2.0 HDI 16v 93kw RHL	ABS/ESP
 607	MAINTENANCE	2.0 HDI 16v 93kw RHL	AirBag CENTRAL
 607	MAINTENANCE	2.0 HDI 16v 93kw RHL	AirBag CENTRAL
 607	MAINTENANCE	2.0 HDI 16v 93kw RHL	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.0 HDI 16v 93kw RHL	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.0 HDI 16v 93kw RHL	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.0 HDI 16v 93kw RHL	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.0 HDI 81kw RHZ	A/T AM6
 607	MAINTENANCE	2.0 HDI 81kw RHZ	A/T AM6
 607	MAINTENANCE	2.0 HDI 81kw RHZ	ABS/ESP
 607	MAINTENANCE	2.0 HDI 81kw RHZ	ABS/ESP
 607	MAINTENANCE	2.0 HDI 81kw RHZ	AirBag CENTRAL
 607	MAINTENANCE	2.0 HDI 81kw RHZ	AirBag CENTRAL
 607	MAINTENANCE	2.0 HDI 81kw RHZ	BOSCH EDC 15 C2 Common Rail
 607	MAINTENANCE	2.0 HDI 81kw RHZ	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.0 HDI 81kw RHZ	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.0 HDI 81kw RHZ	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.0 HDI 81kw RHZ	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.0 HDI 81kw RHZ (03-...)	BOSCH EDC 15 C2 Common Rail
 607	MAINTENANCE	2.2 16v 118kw 3FZ	A/T AM6
 607	MAINTENANCE	2.2 16v 118kw 3FZ	A/T AM6
 607	MAINTENANCE	2.2 16v 118kw 3FZ	ABS/ESP
 607	MAINTENANCE	2.2 16v 118kw 3FZ	ABS/ESP
 607	MAINTENANCE	2.2 16v 118kw 3FZ	AirBag CENTRAL
 607	MAINTENANCE	2.2 16v 118kw 3FZ	AirBag CENTRAL
 607	MAINTENANCE	2.2 16v 118kw 3FZ	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.2 16v 118kw 3FZ	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.2 16v 118kw 3FZ	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.2 16v 118kw 3FZ	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.2 16v 120kw 3FY	A/T AM6
 607	MAINTENANCE	2.2 16v 120kw 3FY	A/T AM6
 607	MAINTENANCE	2.2 16v 120kw 3FY	ABS/ESP
 607	MAINTENANCE	2.2 16v 120kw 3FY	ABS/ESP
 607	MAINTENANCE	2.2 16v 120kw 3FY	AirBag CENTRAL
 607	MAINTENANCE	2.2 16v 120kw 3FY	AirBag CENTRAL
 607	MAINTENANCE	2.2 16v 120kw 3FY	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.2 16v 120kw 3FY	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.2 16v 120kw 3FY	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.2 HDI 16v 120kw 4HP	A/T AM6
 607	MAINTENANCE	2.2 HDI 16v 120kw 4HP	A/T AM6
 607	MAINTENANCE	2.2 HDI 16v 120kw 4HP	ABS/ESP
 607	MAINTENANCE	2.2 HDI 16v 120kw 4HP	ABS/ESP
 607	MAINTENANCE	2.2 HDI 16v 120kw 4HP	AirBag CENTRAL
 607	MAINTENANCE	2.2 HDI 16v 120kw 4HP	AirBag CENTRAL
 607	MAINTENANCE	2.2 HDI 16v 120kw 4HP	BOSCH EDC 15 C2 Common Rail
 607	MAINTENANCE	2.2 HDI 16v 120kw 4HP	BOSCH EDC 15 C2 Common Rail
 607	MAINTENANCE	2.2 HDI 16v 120kw 4HP	BOSCH EDC 15 C2 Common Rail
 607	MAINTENANCE	2.2 HDI 16v 120kw 4HP	Siemens-JCAE AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 607	MAINTENANCE	2.2 HDI 16v 120kw 4HP	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.2 HDI 16v 120kw 4HP	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.2 HDI 16v 120kw 4HP	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	A/T AM6
 607	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	A/T AM6
 607	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	ABS/ESP
 607	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	ABS/ESP
 607	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	AirBag CENTRAL
 607	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	AirBag CENTRAL
 607	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	BOSCH EDC 15 C2 Common Rail
 607	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	BOSCH EDC 15 C2 Common Rail
 607	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	BOSCH EDC 15 C2 Common Rail
 607	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.2 HDI 16v 98kw 4HX	A/T AM6
 607	MAINTENANCE	2.2 HDI 16v 98kw 4HX	A/T AM6
 607	MAINTENANCE	2.2 HDI 16v 98kw 4HX	ABS/ESP
 607	MAINTENANCE	2.2 HDI 16v 98kw 4HX	ABS/ESP
 607	MAINTENANCE	2.2 HDI 16v 98kw 4HX	AirBag CENTRAL
 607	MAINTENANCE	2.2 HDI 16v 98kw 4HX	AirBag CENTRAL
 607	MAINTENANCE	2.2 HDI 16v 98kw 4HX	BOSCH EDC 15 C2 Common Rail
 607	MAINTENANCE	2.2 HDI 16v 98kw 4HX	BOSCH EDC 15 C2 Common Rail
 607	MAINTENANCE	2.2 HDI 16v 98kw 4HX	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.2 HDI 16v 98kw 4HX	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.2 HDI 16v 98kw 4HX	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.2 HDI 16v 98kw 4HX	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	A/T AM6
 607	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	A/T AM6
 607	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	ABS/ESP
 607	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	ABS/ESP
 607	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	AirBag CENTRAL
 607	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	AirBag CENTRAL
 607	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	SIEMENS SID 201 Common Rail
 607	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	SIEMENS SID 201 Common Rail
 607	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	SIEMENS SID 201 Common Rail
 607	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	SIEMENS SID 201 Common Rail
 607	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	SIEMENS SID 201 Common Rail
 607	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	2.7 HDI V6 24v 150kw UHZ-FAP	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	3.0 V6 24v 152kw XFX	A/T AM6
 607	MAINTENANCE	3.0 V6 24v 152kw XFX	A/T AM6
 607	MAINTENANCE	3.0 V6 24v 152kw XFX	ABS/ESP
 607	MAINTENANCE	3.0 V6 24v 152kw XFX	ABS/ESP
 607	MAINTENANCE	3.0 V6 24v 152kw XFX	AirBag CENTRAL
 607	MAINTENANCE	3.0 V6 24v 152kw XFX	AirBag CENTRAL
 607	MAINTENANCE	3.0 V6 24v 152kw XFX	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	3.0 V6 24v 152kw XFX	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	3.0 V6 24v 152kw XFX	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	3.0 V6 24v 152kw XFX	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	3.0 V6 24v 155kw XFX	A/T AM6
 607	MAINTENANCE	3.0 V6 24v 155kw XFX	A/T AM6
 607	MAINTENANCE	3.0 V6 24v 155kw XFX	ABS/ESP
 607	MAINTENANCE	3.0 V6 24v 155kw XFX	ABS/ESP
 607	MAINTENANCE	3.0 V6 24v 155kw XFX	AirBag CENTRAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 607	MAINTENANCE	3.0 V6 24v 155kw XFV	AirBag CENTRAL
 607	MAINTENANCE	3.0 V6 24v 155kw XFV	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	3.0 V6 24v 155kw XFV	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	3.0 V6 24v 155kw XFV	Siemens-JCAE AUTODETECT
 607	MAINTENANCE	3.0 V6 24v 155kw XFV	Siemens-JCAE AUTODETECT
 607	PARK.BRAKE	2.0 16v 100kw RFN	Electrobrake
 607	PARK.BRAKE	2.0 HDI 16v 100kw RHR-FAP	Electrobrake
 607	PARK.BRAKE	2.0 HDI 16v 79kw RHT	Electrobrake
 607	PARK.BRAKE	2.0 HDI 16v 80kw RHW	Electrobrake
 607	PARK.BRAKE	2.0 HDI 16v 81kw RHS	Electrobrake
 607	PARK.BRAKE	2.0 HDI 16v 93kw RHL	Electrobrake
 607	PARK.BRAKE	2.0 HDI 81kw RHZ	Electrobrake
 607	PARK.BRAKE	2.2 16v 118kw 3FZ	Electrobrake
 607	PARK.BRAKE	2.2 16v 120kw 3FY	Electrobrake
 607	PARK.BRAKE	2.2 HDI 16v 120kw 4HP	Electrobrake
 607	PARK.BRAKE	2.2 HDI 16v 125kw 4HT-FAP	Electrobrake
 607	PARK.BRAKE	2.2 HDI 16v 98kw 4HX	Electrobrake
 607	PARK.BRAKE	2.7 HDI V6 24v 150kw UHZ-FAP	Electrobrake
 607	PARK.BRAKE	3.0 V6 24v 152kw XFX	Electrobrake
 607	PARK.BRAKE	3.0 V6 24v 155kw XFV	Electrobrake
 607	PARKING HELP	2.0 16v 100kw RFN	Var.1
 607	PARKING HELP	2.0 16v 100kw RFN	Var.2
 607	PARKING HELP	2.0 16v 100kw RFN	Var.3
 607	PARKING HELP	2.0 16v 100kw RFN	Var.4
 607	PARKING HELP	2.0 HDI 16v 100kw RHR-FAP	Var.1
 607	PARKING HELP	2.0 HDI 16v 100kw RHR-FAP	Var.2
 607	PARKING HELP	2.0 HDI 16v 100kw RHR-FAP	Var.3
 607	PARKING HELP	2.0 HDI 16v 100kw RHR-FAP	Var.4
 607	PARKING HELP	2.0 HDI 16v 79kw RHT	Var.1
 607	PARKING HELP	2.0 HDI 16v 79kw RHT	Var.2
 607	PARKING HELP	2.0 HDI 16v 79kw RHT	Var.3
 607	PARKING HELP	2.0 HDI 16v 79kw RHT	Var.4
 607	PARKING HELP	2.0 HDI 16v 80kw RHW	Var.1
 607	PARKING HELP	2.0 HDI 16v 80kw RHW	Var.2
 607	PARKING HELP	2.0 HDI 16v 80kw RHW	Var.3
 607	PARKING HELP	2.0 HDI 16v 80kw RHW	Var.4
 607	PARKING HELP	2.0 HDI 16v 81kw RHS	Var.1
 607	PARKING HELP	2.0 HDI 16v 81kw RHS	Var.2
 607	PARKING HELP	2.0 HDI 16v 81kw RHS	Var.3
 607	PARKING HELP	2.0 HDI 16v 81kw RHS	Var.4
 607	PARKING HELP	2.0 HDI 16v 93kw RHL	Var.1
 607	PARKING HELP	2.0 HDI 16v 93kw RHL	Var.2
 607	PARKING HELP	2.0 HDI 16v 93kw RHL	Var.3
 607	PARKING HELP	2.0 HDI 16v 93kw RHL	Var.4
 607	PARKING HELP	2.0 HDI 81kw RHZ	Var.1
 607	PARKING HELP	2.0 HDI 81kw RHZ	Var.2
 607	PARKING HELP	2.0 HDI 81kw RHZ	Var.3
 607	PARKING HELP	2.0 HDI 81kw RHZ	Var.4
 607	PARKING HELP	2.2 16v 118kw 3FZ	Var.1
 607	PARKING HELP	2.2 16v 118kw 3FZ	Var.2
 607	PARKING HELP	2.2 16v 118kw 3FZ	Var.3
 607	PARKING HELP	2.2 16v 118kw 3FZ	Var.4
 607	PARKING HELP	2.2 16v 120kw 3FY	Var.1
 607	PARKING HELP	2.2 16v 120kw 3FY	Var.2
 607	PARKING HELP	2.2 16v 120kw 3FY	Var.3
 607	PARKING HELP	2.2 16v 120kw 3FY	Var.4
 607	PARKING HELP	2.2 HDI 16v 120kw 4HP	Var.1
 607	PARKING HELP	2.2 HDI 16v 120kw 4HP	Var.2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 607	PARKING HELP	2.2 HDI 16v 120kw 4HP	Var.3
 607	PARKING HELP	2.2 HDI 16v 120kw 4HP	Var.4
 607	PARKING HELP	2.2 HDI 16v 125kw 4HT-FAP	Var.1
 607	PARKING HELP	2.2 HDI 16v 125kw 4HT-FAP	Var.2
 607	PARKING HELP	2.2 HDI 16v 125kw 4HT-FAP	Var.3
 607	PARKING HELP	2.2 HDI 16v 125kw 4HT-FAP	Var.4
 607	PARKING HELP	2.2 HDI 16v 98kw 4HX	Var.1
 607	PARKING HELP	2.2 HDI 16v 98kw 4HX	Var.2
 607	PARKING HELP	2.2 HDI 16v 98kw 4HX	Var.3
 607	PARKING HELP	2.2 HDI 16v 98kw 4HX	Var.4
 607	PARKING HELP	2.7 HDI V6 24v 150kw UHZ-FAP	Var.1
 607	PARKING HELP	2.7 HDI V6 24v 150kw UHZ-FAP	Var.2
 607	PARKING HELP	2.7 HDI V6 24v 150kw UHZ-FAP	Var.3
 607	PARKING HELP	2.7 HDI V6 24v 150kw UHZ-FAP	Var.4
 607	PARKING HELP	3.0 V6 24v 152kw XFX	Var.1
 607	PARKING HELP	3.0 V6 24v 152kw XFX	Var.2
 607	PARKING HELP	3.0 V6 24v 152kw XFX	Var.3
 607	PARKING HELP	3.0 V6 24v 152kw XFX	Var.4
 607	PARKING HELP	3.0 V6 24v 155kw XFX	Var.1
 607	PARKING HELP	3.0 V6 24v 155kw XFX	Var.2
 607	PARKING HELP	3.0 V6 24v 155kw XFX	Var.3
 607	PARKING HELP	3.0 V6 24v 155kw XFX	Var.4
 607	PASS. SIDE DOOR	2.0 16v 100kw RFN	Marelli MTP PASS
 607	PASS. SIDE DOOR	2.0 16v 100kw RFN	Var.1
 607	PASS. SIDE DOOR	2.0 16v 100kw RFN	Var.2
 607	PASS. SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	Marelli MTP PASS
 607	PASS. SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	Var.1
 607	PASS. SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP	Var.2
 607	PASS. SIDE DOOR	2.0 HDI 16v 79kw RHT	Marelli MTP PASS
 607	PASS. SIDE DOOR	2.0 HDI 16v 79kw RHT	Var.1
 607	PASS. SIDE DOOR	2.0 HDI 16v 79kw RHT	Var.2
 607	PASS. SIDE DOOR	2.0 HDI 16v 80kw RHW	Marelli MTP PASS
 607	PASS. SIDE DOOR	2.0 HDI 16v 80kw RHW	Var.1
 607	PASS. SIDE DOOR	2.0 HDI 16v 80kw RHW	Var.2
 607	PASS. SIDE DOOR	2.0 HDI 16v 81kw RHS	Marelli MTP PASS
 607	PASS. SIDE DOOR	2.0 HDI 16v 81kw RHS	Var.1
 607	PASS. SIDE DOOR	2.0 HDI 16v 81kw RHS	Var.2
 607	PASS. SIDE DOOR	2.0 HDI 16v 93kw RHL	Marelli MTP PASS
 607	PASS. SIDE DOOR	2.0 HDI 16v 93kw RHL	Var.1
 607	PASS. SIDE DOOR	2.0 HDI 16v 93kw RHL	Var.2
 607	PASS. SIDE DOOR	2.0 HDI 81kw RHZ	Marelli MTP PASS
 607	PASS. SIDE DOOR	2.0 HDI 81kw RHZ	Var.1
 607	PASS. SIDE DOOR	2.0 HDI 81kw RHZ	Var.2
 607	PASS. SIDE DOOR	2.2 16v 118kw 3FZ	Marelli MTP PASS
 607	PASS. SIDE DOOR	2.2 16v 118kw 3FZ	Var.1
 607	PASS. SIDE DOOR	2.2 16v 118kw 3FZ	Var.2
 607	PASS. SIDE DOOR	2.2 16v 120kw 3FY	Marelli MTP PASS
 607	PASS. SIDE DOOR	2.2 16v 120kw 3FY	Var.1
 607	PASS. SIDE DOOR	2.2 16v 120kw 3FY	Var.2
 607	PASS. SIDE DOOR	2.2 HDI 16v 120kw 4HP	Marelli MTP PASS
 607	PASS. SIDE DOOR	2.2 HDI 16v 120kw 4HP	Var.1
 607	PASS. SIDE DOOR	2.2 HDI 16v 120kw 4HP	Var.2
 607	PASS. SIDE DOOR	2.2 HDI 16v 125kw 4HT-FAP	Marelli MTP PASS
 607	PASS. SIDE DOOR	2.2 HDI 16v 125kw 4HT-FAP	Var.1
 607	PASS. SIDE DOOR	2.2 HDI 16v 125kw 4HT-FAP	Var.2
 607	PASS. SIDE DOOR	2.2 HDI 16v 98kw 4HX	Marelli MTP PASS
 607	PASS. SIDE DOOR	2.2 HDI 16v 98kw 4HX	Var.1
 607	PASS. SIDE DOOR	2.2 HDI 16v 98kw 4HX	Var.2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 607	PASS. SIDE DOOR	2.7 HDI V6 24v 150kw UHZ-FAP	Marelli MTP PASS
 607	PASS. SIDE DOOR	2.7 HDI V6 24v 150kw UHZ-FAP	Var.1
 607	PASS. SIDE DOOR	2.7 HDI V6 24v 150kw UHZ-FAP	Var.2
 607	PASS. SIDE DOOR	3.0 V6 24v 152kw XFX	Marelli MTP PASS
 607	PASS. SIDE DOOR	3.0 V6 24v 152kw XFX	Var.1
 607	PASS. SIDE DOOR	3.0 V6 24v 152kw XFX	Var.2
 607	PASS. SIDE DOOR	3.0 V6 24v 155kw XFX	Marelli MTP PASS
 607	PASS. SIDE DOOR	3.0 V6 24v 155kw XFX	Var.1
 607	PASS. SIDE DOOR	3.0 V6 24v 155kw XFX	Var.2
 607	PASSENGER SEAT R	2.0 16v 100kw RFN	Var.1
 607	PASSENGER SEAT R	2.0 16v 100kw RFN	Var.2
 607	PASSENGER SEAT R	2.0 HDI 16v 100kw RHR-FAP	Var.1
 607	PASSENGER SEAT R	2.0 HDI 16v 100kw RHR-FAP	Var.2
 607	PASSENGER SEAT R	2.0 HDI 16v 79kw RHT	Var.1
 607	PASSENGER SEAT R	2.0 HDI 16v 79kw RHT	Var.2
 607	PASSENGER SEAT R	2.0 HDI 16v 80kw RHW	Var.1
 607	PASSENGER SEAT R	2.0 HDI 16v 80kw RHW	Var.2
 607	PASSENGER SEAT R	2.0 HDI 16v 81kw RHS	Var.1
 607	PASSENGER SEAT R	2.0 HDI 16v 81kw RHS	Var.2
 607	PASSENGER SEAT R	2.0 HDI 16v 93kw RHL	Var.1
 607	PASSENGER SEAT R	2.0 HDI 16v 93kw RHL	Var.2
 607	PASSENGER SEAT R	2.0 HDI 81kw RHZ	Var.1
 607	PASSENGER SEAT R	2.0 HDI 81kw RHZ	Var.2
 607	PASSENGER SEAT R	2.2 16v 118kw 3FZ	Var.1
 607	PASSENGER SEAT R	2.2 16v 118kw 3FZ	Var.2
 607	PASSENGER SEAT R	2.2 16v 120kw 3FY	Var.1
 607	PASSENGER SEAT R	2.2 16v 120kw 3FY	Var.2
 607	PASSENGER SEAT R	2.2 HDI 16v 120kw 4HP	Var.1
 607	PASSENGER SEAT R	2.2 HDI 16v 120kw 4HP	Var.2
 607	PASSENGER SEAT R	2.2 HDI 16v 125kw 4HT-FAP	Var.1
 607	PASSENGER SEAT R	2.2 HDI 16v 125kw 4HT-FAP	Var.2
 607	PASSENGER SEAT R	2.2 HDI 16v 98kw 4HX	Var.1
 607	PASSENGER SEAT R	2.2 HDI 16v 98kw 4HX	Var.2
 607	PASSENGER SEAT R	2.7 HDI V6 24v 150kw UHZ-FAP	Var.1
 607	PASSENGER SEAT R	2.7 HDI V6 24v 150kw UHZ-FAP	Var.2
 607	PASSENGER SEAT R	3.0 V6 24v 152kw XFX	Var.1
 607	PASSENGER SEAT R	3.0 V6 24v 152kw XFX	Var.2
 607	PASSENGER SEAT R	3.0 V6 24v 155kw XFX	Var.1
 607	PASSENGER SEAT R	3.0 V6 24v 155kw XFX	Var.2
 607	RADIO / CD	2.0 16v 100kw RFN	CLARION AudioSystem
 607	RADIO / CD	2.0 16v 100kw RFN	PHILIPS AudioSystem
 607	RADIO / CD	2.0 16v 100kw RFN	Var.1
 607	RADIO / CD	2.0 16v 100kw RFN	Var.2
 607	RADIO / CD	2.0 16v 100kw RFN	Var.3
 607	RADIO / CD	2.0 16v 100kw RFN	Var.4
 607	RADIO / CD	2.0 16v 100kw RFN	VDO AudioSystem
 607	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP	CLARION AudioSystem
 607	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP	PHILIPS AudioSystem
 607	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP	Var.1
 607	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP	Var.2
 607	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP	Var.3
 607	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP	Var.4
 607	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP	VDO AudioSystem
 607	RADIO / CD	2.0 HDI 16v 79kw RHT	CLARION AudioSystem
 607	RADIO / CD	2.0 HDI 16v 79kw RHT	PHILIPS AudioSystem
 607	RADIO / CD	2.0 HDI 16v 79kw RHT	Var.1
 607	RADIO / CD	2.0 HDI 16v 79kw RHT	Var.2
 607	RADIO / CD	2.0 HDI 16v 79kw RHT	Var.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 607	RADIO / CD	2.0 HDI 16v 79kw RHT	Var.4
 607	RADIO / CD	2.0 HDI 16v 79kw RHT	VDO AudioSystem
 607	RADIO / CD	2.0 HDI 16v 80kw RHW	CLARION AudioSystem
 607	RADIO / CD	2.0 HDI 16v 80kw RHW	PHILIPS AudioSystem
 607	RADIO / CD	2.0 HDI 16v 80kw RHW	Var.1
 607	RADIO / CD	2.0 HDI 16v 80kw RHW	Var.2
 607	RADIO / CD	2.0 HDI 16v 80kw RHW	Var.3
 607	RADIO / CD	2.0 HDI 16v 80kw RHW	Var.4
 607	RADIO / CD	2.0 HDI 16v 80kw RHW	VDO AudioSystem
 607	RADIO / CD	2.0 HDI 16v 81kw RHS	CLARION AudioSystem
 607	RADIO / CD	2.0 HDI 16v 81kw RHS	PHILIPS AudioSystem
 607	RADIO / CD	2.0 HDI 16v 81kw RHS	Var.1
 607	RADIO / CD	2.0 HDI 16v 81kw RHS	Var.2
 607	RADIO / CD	2.0 HDI 16v 81kw RHS	Var.3
 607	RADIO / CD	2.0 HDI 16v 81kw RHS	Var.4
 607	RADIO / CD	2.0 HDI 16v 81kw RHS	VDO AudioSystem
 607	RADIO / CD	2.0 HDI 16v 93kw RHL	CLARION AudioSystem
 607	RADIO / CD	2.0 HDI 16v 93kw RHL	PHILIPS AudioSystem
 607	RADIO / CD	2.0 HDI 16v 93kw RHL	Var.1
 607	RADIO / CD	2.0 HDI 16v 93kw RHL	Var.2
 607	RADIO / CD	2.0 HDI 16v 93kw RHL	Var.3
 607	RADIO / CD	2.0 HDI 16v 93kw RHL	Var.4
 607	RADIO / CD	2.0 HDI 16v 93kw RHL	VDO AudioSystem
 607	RADIO / CD	2.0 HDI 81kw RHZ	CLARION AudioSystem
 607	RADIO / CD	2.0 HDI 81kw RHZ	PHILIPS AudioSystem
 607	RADIO / CD	2.0 HDI 81kw RHZ	Var.1
 607	RADIO / CD	2.0 HDI 81kw RHZ	Var.2
 607	RADIO / CD	2.0 HDI 81kw RHZ	Var.3
 607	RADIO / CD	2.0 HDI 81kw RHZ	Var.4
 607	RADIO / CD	2.0 HDI 81kw RHZ	VDO AudioSystem
 607	RADIO / CD	2.2 16v 118kw 3FZ	CLARION AudioSystem
 607	RADIO / CD	2.2 16v 118kw 3FZ	PHILIPS AudioSystem
 607	RADIO / CD	2.2 16v 118kw 3FZ	Var.1
 607	RADIO / CD	2.2 16v 118kw 3FZ	Var.2
 607	RADIO / CD	2.2 16v 118kw 3FZ	Var.3
 607	RADIO / CD	2.2 16v 118kw 3FZ	Var.4
 607	RADIO / CD	2.2 16v 118kw 3FZ	VDO AudioSystem
 607	RADIO / CD	2.2 16v 120kw 3FY	CLARION AudioSystem
 607	RADIO / CD	2.2 16v 120kw 3FY	PHILIPS AudioSystem
 607	RADIO / CD	2.2 16v 120kw 3FY	Var.1
 607	RADIO / CD	2.2 16v 120kw 3FY	Var.2
 607	RADIO / CD	2.2 16v 120kw 3FY	Var.3
 607	RADIO / CD	2.2 16v 120kw 3FY	Var.4
 607	RADIO / CD	2.2 16v 120kw 3FY	VDO AudioSystem
 607	RADIO / CD	2.2 HDI 16v 120kw 4HP	CLARION AudioSystem
 607	RADIO / CD	2.2 HDI 16v 120kw 4HP	PHILIPS AudioSystem
 607	RADIO / CD	2.2 HDI 16v 120kw 4HP	Var.1
 607	RADIO / CD	2.2 HDI 16v 120kw 4HP	Var.2
 607	RADIO / CD	2.2 HDI 16v 120kw 4HP	Var.3
 607	RADIO / CD	2.2 HDI 16v 120kw 4HP	Var.4
 607	RADIO / CD	2.2 HDI 16v 120kw 4HP	VDO AudioSystem
 607	RADIO / CD	2.2 HDI 16v 125kw 4HT-FAP	CLARION AudioSystem
 607	RADIO / CD	2.2 HDI 16v 125kw 4HT-FAP	PHILIPS AudioSystem
 607	RADIO / CD	2.2 HDI 16v 125kw 4HT-FAP	Var.1
 607	RADIO / CD	2.2 HDI 16v 125kw 4HT-FAP	Var.2
 607	RADIO / CD	2.2 HDI 16v 125kw 4HT-FAP	Var.3
 607	RADIO / CD	2.2 HDI 16v 125kw 4HT-FAP	Var.4
 607	RADIO / CD	2.2 HDI 16v 125kw 4HT-FAP	VDO AudioSystem

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 607	RADIO / CD	2.2 HDI 16v 98kw 4HX	CLARION AudioSystem
 607	RADIO / CD	2.2 HDI 16v 98kw 4HX	PHILIPS AudioSystem
 607	RADIO / CD	2.2 HDI 16v 98kw 4HX	Var.1
 607	RADIO / CD	2.2 HDI 16v 98kw 4HX	Var.2
 607	RADIO / CD	2.2 HDI 16v 98kw 4HX	Var.3
 607	RADIO / CD	2.2 HDI 16v 98kw 4HX	Var.4
 607	RADIO / CD	2.2 HDI 16v 98kw 4HX	VDO AudioSystem
 607	RADIO / CD	2.7 HDI V6 24v 150kw UHZ-FAP	CLARION AudioSystem
 607	RADIO / CD	2.7 HDI V6 24v 150kw UHZ-FAP	PHILIPS AudioSystem
 607	RADIO / CD	2.7 HDI V6 24v 150kw UHZ-FAP	Var.1
 607	RADIO / CD	2.7 HDI V6 24v 150kw UHZ-FAP	Var.2
 607	RADIO / CD	2.7 HDI V6 24v 150kw UHZ-FAP	Var.3
 607	RADIO / CD	2.7 HDI V6 24v 150kw UHZ-FAP	Var.4
 607	RADIO / CD	2.7 HDI V6 24v 150kw UHZ-FAP	VDO AudioSystem
 607	RADIO / CD	3.0 V6 24v 152kw XFX	CLARION AudioSystem
 607	RADIO / CD	3.0 V6 24v 152kw XFX	PHILIPS AudioSystem
 607	RADIO / CD	3.0 V6 24v 152kw XFX	Var.1
 607	RADIO / CD	3.0 V6 24v 152kw XFX	Var.2
 607	RADIO / CD	3.0 V6 24v 152kw XFX	Var.3
 607	RADIO / CD	3.0 V6 24v 152kw XFX	Var.4
 607	RADIO / CD	3.0 V6 24v 152kw XFX	VDO AudioSystem
 607	RADIO / CD	3.0 V6 24v 155kw XFX	CLARION AudioSystem
 607	RADIO / CD	3.0 V6 24v 155kw XFX	PHILIPS AudioSystem
 607	RADIO / CD	3.0 V6 24v 155kw XFX	Var.1
 607	RADIO / CD	3.0 V6 24v 155kw XFX	Var.2
 607	RADIO / CD	3.0 V6 24v 155kw XFX	Var.3
 607	RADIO / CD	3.0 V6 24v 155kw XFX	Var.4
 607	RADIO / CD	3.0 V6 24v 155kw XFX	VDO AudioSystem
 607	RAIN-LUMINOSITY S	2.0 16v 100kw RFN	Var.1
 607	RAIN-LUMINOSITY S	2.0 16v 100kw RFN	Var.2
 607	RAIN-LUMINOSITY S	2.0 HDI 16v 100kw RHR-FAP	Var.1
 607	RAIN-LUMINOSITY S	2.0 HDI 16v 100kw RHR-FAP	Var.2
 607	RAIN-LUMINOSITY S	2.0 HDI 16v 79kw RHT	Var.1
 607	RAIN-LUMINOSITY S	2.0 HDI 16v 79kw RHT	Var.2
 607	RAIN-LUMINOSITY S	2.0 HDI 16v 80kw RHW	Var.1
 607	RAIN-LUMINOSITY S	2.0 HDI 16v 80kw RHW	Var.2
 607	RAIN-LUMINOSITY S	2.0 HDI 16v 81kw RHS	Var.1
 607	RAIN-LUMINOSITY S	2.0 HDI 16v 81kw RHS	Var.2
 607	RAIN-LUMINOSITY S	2.0 HDI 16v 93kw RHL	Var.1
 607	RAIN-LUMINOSITY S	2.0 HDI 16v 93kw RHL	Var.2
 607	RAIN-LUMINOSITY S	2.0 HDI 81kw RHZ	Var.1
 607	RAIN-LUMINOSITY S	2.0 HDI 81kw RHZ	Var.2
 607	RAIN-LUMINOSITY S	2.2 16v 118kw 3FZ	Var.1
 607	RAIN-LUMINOSITY S	2.2 16v 118kw 3FZ	Var.2
 607	RAIN-LUMINOSITY S	2.2 16v 120kw 3FY	Var.1
 607	RAIN-LUMINOSITY S	2.2 16v 120kw 3FY	Var.2
 607	RAIN-LUMINOSITY S	2.2 HDI 16v 120kw 4HP	Var.1
 607	RAIN-LUMINOSITY S	2.2 HDI 16v 120kw 4HP	Var.2
 607	RAIN-LUMINOSITY S	2.2 HDI 16v 125kw 4HT-FAP	Var.1
 607	RAIN-LUMINOSITY S	2.2 HDI 16v 125kw 4HT-FAP	Var.2
 607	RAIN-LUMINOSITY S	2.2 HDI 16v 98kw 4HX	Var.1
 607	RAIN-LUMINOSITY S	2.2 HDI 16v 98kw 4HX	Var.2
 607	RAIN-LUMINOSITY S	2.7 HDI V6 24v 150kw UHZ-FAP	Var.1
 607	RAIN-LUMINOSITY S	2.7 HDI V6 24v 150kw UHZ-FAP	Var.2
 607	RAIN-LUMINOSITY S	3.0 V6 24v 152kw XFX	Var.1
 607	RAIN-LUMINOSITY S	3.0 V6 24v 152kw XFX	Var.2
 607	RAIN-LUMINOSITY S	3.0 V6 24v 155kw XFX	Var.1
 607	RAIN-LUMINOSITY S	3.0 V6 24v 155kw XFX	Var.2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 607	REAR CLIMA	2.0 16v 100kw RFN	
 607	REAR CLIMA	2.0 HDI 16v 100kw RHR-FAP	
 607	REAR CLIMA	2.0 HDI 16v 79kw RHT	
 607	REAR CLIMA	2.0 HDI 16v 80kw RHW	
 607	REAR CLIMA	2.0 HDI 16v 81kw RHS	
 607	REAR CLIMA	2.0 HDI 16v 93kw RHL	
 607	REAR CLIMA	2.0 HDI 81kw RHZ	
 607	REAR CLIMA	2.2 16v 118kw 3FZ	
 607	REAR CLIMA	2.2 16v 120kw 3FY	
 607	REAR CLIMA	2.2 HDI 16v 120kw 4HP	
 607	REAR CLIMA	2.2 HDI 16v 125kw 4HT-FAP	
 607	REAR CLIMA	2.2 HDI 16v 98kw 4HX	
 607	REAR CLIMA	2.7 HDI V6 24v 150kw UHZ-FAP	
 607	REAR CLIMA	3.0 V6 24v 152kw XFX	
 607	REAR CLIMA	3.0 V6 24v 155kw XFV	
 607	RH LIGHT MODULATI	2.0 16v 100kw RFN	
 607	RH LIGHT MODULATI	2.0 HDI 16v 100kw RHR-FAP	
 607	RH LIGHT MODULATI	2.0 HDI 16v 79kw RHT	
 607	RH LIGHT MODULATI	2.0 HDI 16v 80kw RHW	
 607	RH LIGHT MODULATI	2.0 HDI 16v 81kw RHS	
 607	RH LIGHT MODULATI	2.0 HDI 16v 93kw RHL	
 607	RH LIGHT MODULATI	2.0 HDI 81kw RHZ	
 607	RH LIGHT MODULATI	2.2 16v 118kw 3FZ	
 607	RH LIGHT MODULATI	2.2 16v 120kw 3FY	
 607	RH LIGHT MODULATI	2.2 HDI 16v 120kw 4HP	
 607	RH LIGHT MODULATI	2.2 HDI 16v 125kw 4HT-FAP	
 607	RH LIGHT MODULATI	2.2 HDI 16v 98kw 4HX	
 607	RH LIGHT MODULATI	2.7 HDI V6 24v 150kw UHZ-FAP	
 607	RH LIGHT MODULATI	3.0 V6 24v 152kw XFX	
 607	RH LIGHT MODULATI	3.0 V6 24v 155kw XFV	
 607	SPOILER CONTROL	2.0 16v 100kw RFN	
 607	SPOILER CONTROL	2.0 HDI 16v 100kw RHR-FAP	
 607	SPOILER CONTROL	2.0 HDI 16v 79kw RHT	
 607	SPOILER CONTROL	2.0 HDI 16v 80kw RHW	
 607	SPOILER CONTROL	2.0 HDI 16v 81kw RHS	
 607	SPOILER CONTROL	2.0 HDI 16v 93kw RHL	
 607	SPOILER CONTROL	2.0 HDI 81kw RHZ	
 607	SPOILER CONTROL	2.2 16v 118kw 3FZ	
 607	SPOILER CONTROL	2.2 16v 120kw 3FY	
 607	SPOILER CONTROL	2.2 HDI 16v 120kw 4HP	
 607	SPOILER CONTROL	2.2 HDI 16v 125kw 4HT-FAP	
 607	SPOILER CONTROL	2.2 HDI 16v 98kw 4HX	
 607	SPOILER CONTROL	2.7 HDI V6 24v 150kw UHZ-FAP	
 607	SPOILER CONTROL	3.0 V6 24v 152kw XFX	
 607	SPOILER CONTROL	3.0 V6 24v 155kw XFV	
 607	STEERING COLUMN	2.0 16v 100kw RFN	
 607	STEERING COLUMN	2.0 HDI 16v 100kw RHR-FAP	
 607	STEERING COLUMN	2.0 HDI 16v 79kw RHT	
 607	STEERING COLUMN	2.0 HDI 16v 80kw RHW	
 607	STEERING COLUMN	2.0 HDI 16v 81kw RHS	
 607	STEERING COLUMN	2.0 HDI 16v 93kw RHL	
 607	STEERING COLUMN	2.0 HDI 81kw RHZ	
 607	STEERING COLUMN	2.2 16v 118kw 3FZ	
 607	STEERING COLUMN	2.2 16v 120kw 3FY	
 607	STEERING COLUMN	2.2 HDI 16v 120kw 4HP	
 607	STEERING COLUMN	2.2 HDI 16v 125kw 4HT-FAP	
 607	STEERING COLUMN	2.2 HDI 16v 98kw 4HX	
 607	STEERING COLUMN	2.7 HDI V6 24v 150kw UHZ-FAP	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 607	STEERING COLUMN	3.0 V6 24v 152kw XFX	
 607	STEERING COLUMN	3.0 V6 24v 155kw XFX	
 607	TIRE PRESSURE	2.0 16v 100kw RFN	Siemens-JCAE AUTODETECT
 607	TIRE PRESSURE	2.0 HDI 16v 100kw RHR-FAP	Siemens-JCAE AUTODETECT
 607	TIRE PRESSURE	2.0 HDI 16v 79kw RHT	Siemens-JCAE AUTODETECT
 607	TIRE PRESSURE	2.0 HDI 16v 80kw RHW	Siemens-JCAE AUTODETECT
 607	TIRE PRESSURE	2.0 HDI 16v 81kw RHS	Siemens-JCAE AUTODETECT
 607	TIRE PRESSURE	2.0 HDI 16v 93kw RHL	Siemens-JCAE AUTODETECT
 607	TIRE PRESSURE	2.0 HDI 81kw RHZ	Siemens-JCAE AUTODETECT
 607	TIRE PRESSURE	2.2 16v 118kw 3FZ	Siemens-JCAE AUTODETECT
 607	TIRE PRESSURE	2.2 16v 120kw 3FY	Siemens-JCAE AUTODETECT
 607	TIRE PRESSURE	2.2 HDI 16v 120kw 4HP	Siemens-JCAE AUTODETECT
 607	TIRE PRESSURE	2.2 HDI 16v 125kw 4HT-FAP	Siemens-JCAE AUTODETECT
 607	TIRE PRESSURE	2.2 HDI 16v 98kw 4HX	Siemens-JCAE AUTODETECT
 607	TIRE PRESSURE	2.7 HDI V6 24v 150kw UHZ-FAP	Siemens-JCAE AUTODETECT
 607	TIRE PRESSURE	3.0 V6 24v 152kw XFX	Siemens-JCAE AUTODETECT
 607	TIRE PRESSURE	3.0 V6 24v 155kw XFX	Siemens-JCAE AUTODETECT
 607	VISUAL./TELEMATIC	2.0 16v 100kw RFN	Display C- Color
 607	VISUAL./TELEMATIC	2.0 HDI 16v 100kw RHR-FAP	Display C- Color
 607	VISUAL./TELEMATIC	2.0 HDI 16v 79kw RHT	Display C- Color
 607	VISUAL./TELEMATIC	2.0 HDI 16v 80kw RHW	Display C- Color
 607	VISUAL./TELEMATIC	2.0 HDI 16v 81kw RHS	Display C- Color
 607	VISUAL./TELEMATIC	2.0 HDI 16v 93kw RHL	Display C- Color
 607	VISUAL./TELEMATIC	2.0 HDI 81kw RHZ	Display C- Color
 607	VISUAL./TELEMATIC	2.2 16v 118kw 3FZ	Display C- Color
 607	VISUAL./TELEMATIC	2.2 16v 120kw 3FY	Display C- Color
 607	VISUAL./TELEMATIC	2.2 HDI 16v 120kw 4HP	Display C- Color
 607	VISUAL./TELEMATIC	2.2 HDI 16v 125kw 4HT-FAP	Display C- Color
 607	VISUAL./TELEMATIC	2.2 HDI 16v 98kw 4HX	Display C- Color
 607	VISUAL./TELEMATIC	2.7 HDI V6 24v 150kw UHZ-FAP	Display C- Color
 607	VISUAL./TELEMATIC	3.0 V6 24v 152kw XFX	Display C- Color
 607	VISUAL./TELEMATIC	3.0 V6 24v 155kw XFX	Display C- Color
 607	WIPERS	2.0 16v 100kw RFN	
 607	WIPERS	2.0 HDI 16v 100kw RHR-FAP	
 607	WIPERS	2.0 HDI 16v 79kw RHT	
 607	WIPERS	2.0 HDI 16v 80kw RHW	
 607	WIPERS	2.0 HDI 16v 81kw RHS	
 607	WIPERS	2.0 HDI 16v 93kw RHL	
 607	WIPERS	2.0 HDI 81kw RHZ	
 607	WIPERS	2.2 16v 118kw 3FZ	
 607	WIPERS	2.2 16v 120kw 3FY	
 607	WIPERS	2.2 HDI 16v 120kw 4HP	
 607	WIPERS	2.2 HDI 16v 125kw 4HT-FAP	
 607	WIPERS	2.2 HDI 16v 98kw 4HX	
 607	WIPERS	2.7 HDI V6 24v 150kw UHZ-FAP	
 607	WIPERS	3.0 V6 24v 152kw XFX	
 607	WIPERS	3.0 V6 24v 155kw XFX	
 806	ABS	1.8 74kw LFW (94-97)	BENDIX ABS
 806	ABS	1.8 74kw LFW (98-02)	BOSCH ABS ABR 5.3
 806	ABS	1.9 TD 66kw LFW (94-97)	BENDIX ABS
 806	ABS	1.9 TD 66kw LFW (98-02)	BOSCH ABS ABR 5.3
 806	ABS	1.9 TD 68kw D8B (94-97)	BENDIX ABS
 806	ABS	1.9 TD 68kw D8B (98-02)	BOSCH ABS ABR 5.3
 806	ABS	1.9 TD 68kw DHX (94-97)	BENDIX ABS
 806	ABS	1.9 TD 68kw DHX (98-02)	BOSCH ABS ABR 5.3
 806	ABS	2.0 16v 100kw RFN (94-97)	BENDIX ABS
806	ABS	2.0 16v 100kw RFN (98-02)	BOSCH ABS ABR 5.3
806	ABS	2.0 16v 97kw RFV (94-97)	BENDIX ABS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 806	ABS	2.0 16v 97kw RFV (98-02)	BOSCH ABS ABR 5.3
 806	ABS	2.0 89kw RFU (94-97)	BENDIX ABS
 806	ABS	2.0 89kw RFU (98-02)	BOSCH ABS ABR 5.3
 806	ABS	2.0 HDI 16v 80kw RHW (94-97)	BENDIX ABS
 806	ABS	2.0 HDI 16v 80kw RHW (98-02)	BOSCH ABS ABR 5.3
 806	ABS	2.0 HDI 16v 81kw RHS (94-97)	BENDIX ABS
 806	ABS	2.0 HDI 16v 81kw RHS (98-02)	BOSCH ABS ABR 5.3
 806	ABS	2.0 HDI 81kw RHZ (94-97)	BENDIX ABS
 806	ABS	2.0 HDI 81kw RHZ (98-02)	BOSCH ABS ABR 5.3
 806	ABS	2.0 T 108kw RGX (94-97)	BENDIX ABS
 806	ABS	2.0 T 108kw RGX (98-02)	BOSCH ABS ABR 5.3
 806	ABS	2.1 TD 12v 81kw P8C (94-97)	BENDIX ABS
 806	ABS	2.1 TD 12v 81kw P8C (98-02)	BOSCH ABS ABR 5.3
 806	AUTOM. TRANSMISSI	1.8 74kw LFW (94-02)	Var.1
 806	AUTOM. TRANSMISSI	1.8 74kw LFW (94-02)	Var.2
 806	AUTOM. TRANSMISSI	1.8 74kw LFW (94-02)	Var.3
 806	AUTOM. TRANSMISSI	1.9 TD 66kw LFW (94-02)	Var.1
 806	AUTOM. TRANSMISSI	1.9 TD 66kw LFW (94-02)	Var.2
 806	AUTOM. TRANSMISSI	1.9 TD 66kw LFW (94-02)	Var.3
 806	AUTOM. TRANSMISSI	1.9 TD 68kw D8B (94-02)	Var.1
 806	AUTOM. TRANSMISSI	1.9 TD 68kw D8B (94-02)	Var.2
 806	AUTOM. TRANSMISSI	1.9 TD 68kw D8B (94-02)	Var.3
 806	AUTOM. TRANSMISSI	1.9 TD 68kw DHX (94-02)	Var.1
 806	AUTOM. TRANSMISSI	1.9 TD 68kw DHX (94-02)	Var.2
 806	AUTOM. TRANSMISSI	1.9 TD 68kw DHX (94-02)	Var.3
 806	AUTOM. TRANSMISSI	2.0 16v 100kw RFN (94-02)	Var.1
 806	AUTOM. TRANSMISSI	2.0 16v 100kw RFN (94-02)	Var.2
 806	AUTOM. TRANSMISSI	2.0 16v 100kw RFN (94-02)	Var.3
 806	AUTOM. TRANSMISSI	2.0 16v 97kw RFV (94-02)	Var.1
 806	AUTOM. TRANSMISSI	2.0 16v 97kw RFV (94-02)	Var.2
 806	AUTOM. TRANSMISSI	2.0 16v 97kw RFV (94-02)	Var.3
 806	AUTOM. TRANSMISSI	2.0 89kw RFU (94-02)	Var.1
 806	AUTOM. TRANSMISSI	2.0 89kw RFU (94-02)	Var.2
 806	AUTOM. TRANSMISSI	2.0 89kw RFU (94-02)	Var.3
 806	AUTOM. TRANSMISSI	2.0 HDI 16v 80kw RHW (94-02)	Var.1
 806	AUTOM. TRANSMISSI	2.0 HDI 16v 80kw RHW (94-02)	Var.2
 806	AUTOM. TRANSMISSI	2.0 HDI 16v 80kw RHW (94-02)	Var.3
 806	AUTOM. TRANSMISSI	2.0 HDI 16v 81kw RHS (94-02)	Var.1
 806	AUTOM. TRANSMISSI	2.0 HDI 16v 81kw RHS (94-02)	Var.2
 806	AUTOM. TRANSMISSI	2.0 HDI 16v 81kw RHS (94-02)	Var.3
 806	AUTOM. TRANSMISSI	2.0 HDI 81kw RHZ (94-02)	Var.1
 806	AUTOM. TRANSMISSI	2.0 HDI 81kw RHZ (94-02)	Var.2
 806	AUTOM. TRANSMISSI	2.0 HDI 81kw RHZ (94-02)	Var.3
 806	AUTOM. TRANSMISSI	2.0 T 108kw RGX (94-02)	Var.1
 806	AUTOM. TRANSMISSI	2.0 T 108kw RGX (94-02)	Var.2
 806	AUTOM. TRANSMISSI	2.0 T 108kw RGX (94-02)	Var.3
 806	AUTOM. TRANSMISSI	2.1 TD 12v 81kw P8C (94-02)	Var.1
 806	AUTOM. TRANSMISSI	2.1 TD 12v 81kw P8C (94-02)	Var.2
 806	AUTOM. TRANSMISSI	2.1 TD 12v 81kw P8C (94-02)	Var.3
 806	DIESEL MANAGEMEN	1.9 TD 68kw DHX (94-02)	BOSCH AS3 VP20
 806	ENGINE MANAGEME	1.8 74kw LFW (01-02)	EOBD
 806	ENGINE MANAGEME	2.0 16v 100kw RFN (94-02)	Marelli MM48P
 806	ENGINE MANAGEME	2.0 16v 97kw RFV (94-02)	EOBD
 806	ENGINE MANAGEME	2.0 89kw RFU (94-02)	Marelli MM 8P.22 [Fast]
 806	ENGINE MANAGEME	2.0 HDI 16v 80kw RHW (94-02)	BOSCH EDC 15 C2 Common Rail
 806	ENGINE MANAGEME	2.0 HDI 16v 81kw RHS (94-02)	BOSCH EDC 15 C2 Common Rail
 806	ENGINE MANAGEME	2.0 HDI 81kw RHZ (94-00)	BOSCH EDC 15 C2 Common Rail
 806	ENGINE MANAGEME	2.0 HDI 81kw RHZ (94-02)	BOSCH EDC 15 C2 Common Rail

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 806	ENGINE MANAGEME	2.0 T 108kw RGX (94-02)	BOSCH Motronic MP3.2 [Fast]
 806	ENGINE MANAGEME	2.1 TD 12v 81kw P8C (94-02)	LUCAS Diesel EPIC
 806	MAINTENANCE	1.8 74kw LFW (94-02)	Var.1
 806	MAINTENANCE	1.8 74kw LFW (94-02)	Var.2
 806	MAINTENANCE	1.8 74kw LFW (94-02)	Var.3
 806	MAINTENANCE	1.8 74kw LFW (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	1.8 74kw LFW (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	1.8 74kw LFW (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	1.8 74kw LFW (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	1.8 74kw LFW (98-02)	MANUAL
 806	MAINTENANCE	1.9 TD 66kw LFW (94-02)	Var.1
 806	MAINTENANCE	1.9 TD 66kw LFW (94-02)	Var.2
 806	MAINTENANCE	1.9 TD 66kw LFW (94-02)	Var.3
 806	MAINTENANCE	1.9 TD 66kw LFW (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	1.9 TD 66kw LFW (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	1.9 TD 66kw LFW (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	1.9 TD 66kw LFW (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	1.9 TD 66kw LFW (98-02)	MANUAL
 806	MAINTENANCE	1.9 TD 68kw D8B (94-02)	Var.1
 806	MAINTENANCE	1.9 TD 68kw D8B (94-02)	Var.2
 806	MAINTENANCE	1.9 TD 68kw D8B (94-02)	Var.3
 806	MAINTENANCE	1.9 TD 68kw D8B (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	1.9 TD 68kw D8B (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	1.9 TD 68kw D8B (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	1.9 TD 68kw D8B (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	1.9 TD 68kw D8B (98-02)	MANUAL
 806	MAINTENANCE	1.9 TD 68kw DHX (94-02)	Var.1
 806	MAINTENANCE	1.9 TD 68kw DHX (94-02)	Var.2
 806	MAINTENANCE	1.9 TD 68kw DHX (94-02)	Var.3
 806	MAINTENANCE	1.9 TD 68kw DHX (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	1.9 TD 68kw DHX (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	1.9 TD 68kw DHX (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	1.9 TD 68kw DHX (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	1.9 TD 68kw DHX (98-02)	MANUAL
 806	MAINTENANCE	2.0 16v 100kw RFN (94-02)	Var.1
 806	MAINTENANCE	2.0 16v 100kw RFN (94-02)	Var.2
 806	MAINTENANCE	2.0 16v 100kw RFN (94-02)	Var.3
 806	MAINTENANCE	2.0 16v 100kw RFN (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	2.0 16v 100kw RFN (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	2.0 16v 100kw RFN (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	2.0 16v 100kw RFN (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	2.0 16v 100kw RFN (98-02)	MANUAL
 806	MAINTENANCE	2.0 16v 97kw RFV (94-02)	Var.1
 806	MAINTENANCE	2.0 16v 97kw RFV (94-02)	Var.2
 806	MAINTENANCE	2.0 16v 97kw RFV (94-02)	Var.3
 806	MAINTENANCE	2.0 16v 97kw RFV (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	2.0 16v 97kw RFV (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	2.0 16v 97kw RFV (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	2.0 16v 97kw RFV (98-02)	BOSCH ABS ABR 5.3
806	MAINTENANCE	2.0 16v 97kw RFV (98-02)	MANUAL
806	MAINTENANCE	2.0 89kw RFU (94-02)	Var.1
806	MAINTENANCE	2.0 89kw RFU (94-02)	Var.2
806	MAINTENANCE	2.0 89kw RFU (94-02)	Var.3
806	MAINTENANCE	2.0 89kw RFU (98-02)	BOSCH ABS ABR 5.3
806	MAINTENANCE	2.0 89kw RFU (98-02)	BOSCH ABS ABR 5.3
806	MAINTENANCE	2.0 89kw RFU (98-02)	BOSCH ABS ABR 5.3
806	MAINTENANCE	2.0 89kw RFU (98-02)	BOSCH ABS ABR 5.3
806	MAINTENANCE	2.0 89kw RFU (98-02)	MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 806	MAINTENANCE	2.0 HDI 16v 80kw RHW (94-02)	BOSCH EDC 15 C2 Common Rail
 806	MAINTENANCE	2.0 HDI 16v 80kw RHW (94-02)	Var.1
 806	MAINTENANCE	2.0 HDI 16v 80kw RHW (94-02)	Var.2
 806	MAINTENANCE	2.0 HDI 16v 80kw RHW (94-02)	Var.3
 806	MAINTENANCE	2.0 HDI 16v 80kw RHW (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	2.0 HDI 16v 80kw RHW (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	2.0 HDI 16v 80kw RHW (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	2.0 HDI 16v 80kw RHW (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	2.0 HDI 16v 80kw RHW (98-02)	MANUAL
 806	MAINTENANCE	2.0 HDI 16v 81kw RHS (94-02)	BOSCH EDC 15 C2 Common Rail
 806	MAINTENANCE	2.0 HDI 16v 81kw RHS (94-02)	Var.1
 806	MAINTENANCE	2.0 HDI 16v 81kw RHS (94-02)	Var.2
 806	MAINTENANCE	2.0 HDI 16v 81kw RHS (94-02)	Var.3
 806	MAINTENANCE	2.0 HDI 16v 81kw RHS (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	2.0 HDI 16v 81kw RHS (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	2.0 HDI 16v 81kw RHS (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	2.0 HDI 16v 81kw RHS (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	2.0 HDI 16v 81kw RHS (98-02)	MANUAL
 806	MAINTENANCE	2.0 HDI 81kw RHZ (94-02)	BOSCH EDC 15 C2 Common Rail
 806	MAINTENANCE	2.0 HDI 81kw RHZ (94-02)	Var.1
 806	MAINTENANCE	2.0 HDI 81kw RHZ (94-02)	Var.2
 806	MAINTENANCE	2.0 HDI 81kw RHZ (94-02)	Var.3
 806	MAINTENANCE	2.0 HDI 81kw RHZ (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	2.0 HDI 81kw RHZ (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	2.0 HDI 81kw RHZ (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	2.0 HDI 81kw RHZ (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	2.0 HDI 81kw RHZ (98-02)	MANUAL
 806	MAINTENANCE	2.0 T 108kw RGX (94-02)	Var.1
 806	MAINTENANCE	2.0 T 108kw RGX (94-02)	Var.2
 806	MAINTENANCE	2.0 T 108kw RGX (94-02)	Var.3
 806	MAINTENANCE	2.0 T 108kw RGX (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	2.0 T 108kw RGX (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	2.0 T 108kw RGX (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	2.0 T 108kw RGX (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	2.0 T 108kw RGX (98-02)	MANUAL
 806	MAINTENANCE	2.1 TD 12v 81kw P8C (94-02)	Var.1
 806	MAINTENANCE	2.1 TD 12v 81kw P8C (94-02)	Var.2
 806	MAINTENANCE	2.1 TD 12v 81kw P8C (94-02)	Var.3
 806	MAINTENANCE	2.1 TD 12v 81kw P8C (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	2.1 TD 12v 81kw P8C (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	2.1 TD 12v 81kw P8C (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	2.1 TD 12v 81kw P8C (98-02)	BOSCH ABS ABR 5.3
 806	MAINTENANCE	2.1 TD 12v 81kw P8C (98-02)	MANUAL
 806	SERVICE LIGHT RES	1.8 74kw LFW (98-02)	MANUAL
 806	SERVICE LIGHT RES	1.9 TD 66kw LFW (98-02)	MANUAL
 806	SERVICE LIGHT RES	1.9 TD 68kw D8B (98-02)	MANUAL
 806	SERVICE LIGHT RES	1.9 TD 68kw DHX (98-02)	MANUAL
 806	SERVICE LIGHT RES	2.0 16v 100kw RFN (98-02)	MANUAL
 806	SERVICE LIGHT RES	2.0 16v 97kw RFV (98-02)	MANUAL
 806	SERVICE LIGHT RES	2.0 89kw RFU (98-02)	MANUAL
 806	SERVICE LIGHT RES	2.0 HDI 16v 80kw RHW (98-02)	MANUAL
 806	SERVICE LIGHT RES	2.0 HDI 16v 81kw RHS (98-02)	MANUAL
 806	SERVICE LIGHT RES	2.0 HDI 81kw RHZ (98-02)	MANUAL
 806	SERVICE LIGHT RES	2.0 T 108kw RGX (98-02)	MANUAL
 806	SERVICE LIGHT RES	2.1 TD 12v 81kw P8C (98-02)	MANUAL
 807	ABS	2.0 16v 100kw RFN (...-05)	BOSCH ABS ABR 5.7
 807	ABS	2.0 16v 100kw RFN (05-..)	BOSCH ABS/ESP 8.0
 807	ABS	2.0 16v 103kw RFJ (...-05)	BOSCH ABS ABR 5.7

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 807	ABS	2.0 16v 103kw RFJ (05-..)	BOSCH ABS/ESP 8.0
 807	ABS	2.0 HDI 16v 100kw RHR-FAP (...05)	BOSCH ABS ABR 5.7
 807	ABS	2.0 HDI 16v 100kw RHR-FAP (05-..)	BOSCH ABS/ESP 8.0
 807	ABS	2.0 HDI 16v 79kw RHM-FAP (...05)	BOSCH ABS ABR 5.7
 807	ABS	2.0 HDI 16v 79kw RHM-FAP (05-..)	BOSCH ABS/ESP 8.0
 807	ABS	2.0 HDI 16v 79kw RHT-FAP (...05)	BOSCH ABS ABR 5.7
 807	ABS	2.0 HDI 16v 79kw RHT-FAP (05-..)	BOSCH ABS/ESP 8.0
 807	ABS	2.0 HDI 16v 80kw RHW (...05)	BOSCH ABS ABR 5.7
 807	ABS	2.0 HDI 16v 80kw RHW (05-..)	BOSCH ABS/ESP 8.0
 807	ABS	2.0 HDI 16v 88kw RHK (...05)	BOSCH ABS ABR 5.7
 807	ABS	2.0 HDI 16v 88kw RHK (05-..)	BOSCH ABS/ESP 8.0
 807	ABS	2.2 16v 118kw 3FZ (...05)	BOSCH ABS ABR 5.7
 807	ABS	2.2 16v 118kw 3FZ (05-..)	BOSCH ABS/ESP 8.0
 807	ABS	2.2 HDI 16v 120kw 4HP (...05)	BOSCH ABS ABR 5.7
 807	ABS	2.2 HDI 16v 120kw 4HP (05-..)	BOSCH ABS/ESP 8.0
 807	ABS	2.2 HDI 16v 120kw 4HR (...05)	BOSCH ABS ABR 5.7
 807	ABS	2.2 HDI 16v 120kw 4HR (05-..)	BOSCH ABS/ESP 8.0
 807	ABS	2.2 HDI 16v 125kw 4HS-FAP (...05)	BOSCH ABS ABR 5.7
 807	ABS	2.2 HDI 16v 125kw 4HS-FAP (05-..)	BOSCH ABS/ESP 8.0
 807	ABS	2.2 HDI 16v 125kw 4HT-FAP (...05)	BOSCH ABS ABR 5.7
 807	ABS	2.2 HDI 16v 125kw 4HT-FAP (05-..)	BOSCH ABS/ESP 8.0
 807	ABS	2.2 HDI 16v 94kw 4HW-FAP (...05)	BOSCH ABS ABR 5.7
 807	ABS	2.2 HDI 16v 94kw 4HW-FAP (05-..)	BOSCH ABS/ESP 8.0
 807	ABS	3.0 V6 24v 150kw XFW (...05)	BOSCH ABS ABR 5.7
 807	ABS	3.0 V6 24v 150kw XFW (05-..)	BOSCH ABS/ESP 8.0
 807	ABS + TRACT. CONT	2.0 16v 100kw RFN (...05)	BOSCH ABS/ESP 5.7
 807	ABS + TRACT. CONT	2.0 16v 100kw RFN (...05)	BOSCH ESP 5.7
 807	ABS + TRACT. CONT	2.0 16v 100kw RFN (...05)	Var.1
 807	ABS + TRACT. CONT	2.0 16v 100kw RFN (...05)	Var.2
 807	ABS + TRACT. CONT	2.0 16v 103kw RFJ (...05)	BOSCH ABS/ESP 5.7
 807	ABS + TRACT. CONT	2.0 16v 103kw RFJ (...05)	BOSCH ESP 5.7
 807	ABS + TRACT. CONT	2.0 16v 103kw RFJ (...05)	Var.1
 807	ABS + TRACT. CONT	2.0 16v 103kw RFJ (...05)	Var.2
 807	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP (...05)	BOSCH ABS/ESP 5.7
 807	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP (...05)	BOSCH ESP 5.7
 807	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP (...05)	Var.1
 807	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP (...05)	Var.2
 807	ABS + TRACT. CONT	2.0 HDI 16v 79kw RHM-FAP (...05)	BOSCH ABS/ESP 5.7
 807	ABS + TRACT. CONT	2.0 HDI 16v 79kw RHM-FAP (...05)	BOSCH ESP 5.7
 807	ABS + TRACT. CONT	2.0 HDI 16v 79kw RHM-FAP (...05)	Var.1
 807	ABS + TRACT. CONT	2.0 HDI 16v 79kw RHM-FAP (...05)	Var.2
 807	ABS + TRACT. CONT	2.0 HDI 16v 79kw RHT-FAP (...05)	BOSCH ABS/ESP 5.7
 807	ABS + TRACT. CONT	2.0 HDI 16v 79kw RHT-FAP (...05)	BOSCH ESP 5.7
 807	ABS + TRACT. CONT	2.0 HDI 16v 79kw RHT-FAP (...05)	Var.1
 807	ABS + TRACT. CONT	2.0 HDI 16v 79kw RHT-FAP (...05)	Var.2
 807	ABS + TRACT. CONT	2.0 HDI 16v 80kw RHW (...05)	BOSCH ABS/ESP 5.7
 807	ABS + TRACT. CONT	2.0 HDI 16v 80kw RHW (...05)	BOSCH ESP 5.7
 807	ABS + TRACT. CONT	2.0 HDI 16v 80kw RHW (...05)	Var.1
 807	ABS + TRACT. CONT	2.0 HDI 16v 80kw RHW (...05)	Var.2
 807	ABS + TRACT. CONT	2.0 HDI 16v 88kw RHK (...05)	BOSCH ABS/ESP 5.7
 807	ABS + TRACT. CONT	2.0 HDI 16v 88kw RHK (...05)	BOSCH ESP 5.7
 807	ABS + TRACT. CONT	2.0 HDI 16v 88kw RHK (...05)	Var.1
 807	ABS + TRACT. CONT	2.0 HDI 16v 88kw RHK (...05)	Var.2
 807	ABS + TRACT. CONT	2.2 16v 118kw 3FZ (...05)	BOSCH ABS/ESP 5.7
 807	ABS + TRACT. CONT	2.2 16v 118kw 3FZ (...05)	BOSCH ESP 5.7
 807	ABS + TRACT. CONT	2.2 16v 118kw 3FZ (...05)	Var.1
 807	ABS + TRACT. CONT	2.2 16v 118kw 3FZ (...05)	Var.2
 807	ABS + TRACT. CONT	2.2 HDI 16v 120kw 4HP (...05)	BOSCH ABS/ESP 5.7

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 807	ABS + TRACT. CONT	2.2 HDI 16v 120kw 4HP (...-05)	BOSCH ESP 5.7
 807	ABS + TRACT. CONT	2.2 HDI 16v 120kw 4HP (...-05)	Var.1
 807	ABS + TRACT. CONT	2.2 HDI 16v 120kw 4HP (...-05)	Var.2
 807	ABS + TRACT. CONT	2.2 HDI 16v 120kw 4HR (...-05)	BOSCH ABS/ESP 5.7
 807	ABS + TRACT. CONT	2.2 HDI 16v 120kw 4HR (...-05)	BOSCH ESP 5.7
 807	ABS + TRACT. CONT	2.2 HDI 16v 120kw 4HR (...-05)	Var.1
 807	ABS + TRACT. CONT	2.2 HDI 16v 120kw 4HR (...-05)	Var.2
 807	ABS + TRACT. CONT	2.2 HDI 16v 125kw 4HS-FAP (...-05)	BOSCH ABS/ESP 5.7
 807	ABS + TRACT. CONT	2.2 HDI 16v 125kw 4HS-FAP (...-05)	BOSCH ESP 5.7
 807	ABS + TRACT. CONT	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.1
 807	ABS + TRACT. CONT	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.2
 807	ABS + TRACT. CONT	2.2 HDI 16v 125kw 4HT-FAP (...-05)	BOSCH ABS/ESP 5.7
 807	ABS + TRACT. CONT	2.2 HDI 16v 125kw 4HT-FAP (...-05)	BOSCH ESP 5.7
 807	ABS + TRACT. CONT	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.1
 807	ABS + TRACT. CONT	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.2
 807	ABS + TRACT. CONT	2.2 HDI 16v 94kw 4HW-FAP (...-05)	BOSCH ABS/ESP 5.7
 807	ABS + TRACT. CONT	2.2 HDI 16v 94kw 4HW-FAP (...-05)	BOSCH ESP 5.7
 807	ABS + TRACT. CONT	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.1
 807	ABS + TRACT. CONT	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.2
 807	ABS + TRACT. CONT	3.0 V6 24v 150kw XFW (...-05)	BOSCH ABS/ESP 5.7
 807	ABS + TRACT. CONT	3.0 V6 24v 150kw XFW (...-05)	BOSCH ESP 5.7
 807	ABS + TRACT. CONT	3.0 V6 24v 150kw XFW (...-05)	Var.1
 807	ABS + TRACT. CONT	3.0 V6 24v 150kw XFW (...-05)	Var.2
 807	AIRBAG	2.0 16v 100kw RFN (...-05)	AirBag CENTRAL
 807	AIRBAG	2.0 16v 100kw RFN (...-05)	AirBag CENTRAL
 807	AIRBAG	2.0 16v 100kw RFN (...-05)	TEMIC AirBag
 807	AIRBAG	2.0 16v 100kw RFN (05-..)	TEMIC AirBag
 807	AIRBAG	2.0 16v 103kw RFJ (...-05)	AirBag CENTRAL
 807	AIRBAG	2.0 16v 103kw RFJ (...-05)	AirBag CENTRAL
 807	AIRBAG	2.0 16v 103kw RFJ (...-05)	TEMIC AirBag
 807	AIRBAG	2.0 16v 103kw RFJ (05-..)	TEMIC AirBag
 807	AIRBAG	2.0 HDI 16v 100kw RHR-FAP (...-05)	AirBag CENTRAL
 807	AIRBAG	2.0 HDI 16v 100kw RHR-FAP (...-05)	AirBag CENTRAL
 807	AIRBAG	2.0 HDI 16v 100kw RHR-FAP (...-05)	TEMIC AirBag
 807	AIRBAG	2.0 HDI 16v 100kw RHR-FAP (05-..)	TEMIC AirBag
 807	AIRBAG	2.0 HDI 16v 79kw RHM-FAP (...-05)	AirBag CENTRAL
 807	AIRBAG	2.0 HDI 16v 79kw RHM-FAP (...-05)	AirBag CENTRAL
 807	AIRBAG	2.0 HDI 16v 79kw RHM-FAP (...-05)	TEMIC AirBag
 807	AIRBAG	2.0 HDI 16v 79kw RHM-FAP (05-..)	TEMIC AirBag
 807	AIRBAG	2.0 HDI 16v 79kw RHT-FAP (...-05)	AirBag CENTRAL
 807	AIRBAG	2.0 HDI 16v 79kw RHT-FAP (...-05)	AirBag CENTRAL
 807	AIRBAG	2.0 HDI 16v 79kw RHT-FAP (...-05)	TEMIC AirBag
 807	AIRBAG	2.0 HDI 16v 79kw RHT-FAP (05-..)	TEMIC AirBag
 807	AIRBAG	2.0 HDI 16v 80kw RHW (...-05)	AirBag CENTRAL
 807	AIRBAG	2.0 HDI 16v 80kw RHW (...-05)	AirBag CENTRAL
 807	AIRBAG	2.0 HDI 16v 80kw RHW (...-05)	TEMIC AirBag
 807	AIRBAG	2.0 HDI 16v 80kw RHW (05-..)	TEMIC AirBag
 807	AIRBAG	2.0 HDI 16v 88kw RHK (...-05)	AirBag CENTRAL
 807	AIRBAG	2.0 HDI 16v 88kw RHK (...-05)	AirBag CENTRAL
 807	AIRBAG	2.0 HDI 16v 88kw RHK (...-05)	TEMIC AirBag
 807	AIRBAG	2.0 HDI 16v 88kw RHK (05-..)	TEMIC AirBag
 807	AIRBAG	2.2 16v 118kw 3FZ (...-05)	AirBag CENTRAL
 807	AIRBAG	2.2 16v 118kw 3FZ (...-05)	AirBag CENTRAL
 807	AIRBAG	2.2 16v 118kw 3FZ (...-05)	TEMIC AirBag
 807	AIRBAG	2.2 16v 118kw 3FZ (05-..)	TEMIC AirBag
 807	AIRBAG	2.2 HDI 16v 120kw 4HP (...-05)	AirBag CENTRAL
 807	AIRBAG	2.2 HDI 16v 120kw 4HP (...-05)	AirBag CENTRAL
 807	AIRBAG	2.2 HDI 16v 120kw 4HP (...-05)	TEMIC AirBag

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 807	AIRBAG	2.2 HDI 16v 120kw 4HP (05-..)	TEMIC AirBag
 807	AIRBAG	2.2 HDI 16v 120kw 4HR (..-05)	AirBag CENTRAL
 807	AIRBAG	2.2 HDI 16v 120kw 4HR (..-05)	AirBag CENTRAL
 807	AIRBAG	2.2 HDI 16v 120kw 4HR (..-05)	TEMIC AirBag
 807	AIRBAG	2.2 HDI 16v 120kw 4HR (05-..)	TEMIC AirBag
 807	AIRBAG	2.2 HDI 16v 125kw 4HS-FAP (..-05)	AirBag CENTRAL
 807	AIRBAG	2.2 HDI 16v 125kw 4HS-FAP (..-05)	AirBag CENTRAL
 807	AIRBAG	2.2 HDI 16v 125kw 4HS-FAP (..-05)	TEMIC AirBag
 807	AIRBAG	2.2 HDI 16v 125kw 4HS-FAP (05-..)	TEMIC AirBag
 807	AIRBAG	2.2 HDI 16v 125kw 4HT-FAP (..-05)	AirBag CENTRAL
 807	AIRBAG	2.2 HDI 16v 125kw 4HT-FAP (..-05)	AirBag CENTRAL
 807	AIRBAG	2.2 HDI 16v 125kw 4HT-FAP (..-05)	TEMIC AirBag
 807	AIRBAG	2.2 HDI 16v 125kw 4HT-FAP (05-..)	TEMIC AirBag
 807	AIRBAG	2.2 HDI 16v 94kw 4HW-FAP (..-05)	AirBag CENTRAL
 807	AIRBAG	2.2 HDI 16v 94kw 4HW-FAP (..-05)	AirBag CENTRAL
 807	AIRBAG	2.2 HDI 16v 94kw 4HW-FAP (..-05)	TEMIC AirBag
 807	AIRBAG	2.2 HDI 16v 94kw 4HW-FAP (05-..)	TEMIC AirBag
 807	AIRBAG	3.0 V6 24v 150kw XFW (..-05)	AirBag CENTRAL
 807	AIRBAG	3.0 V6 24v 150kw XFW (..-05)	AirBag CENTRAL
 807	AIRBAG	3.0 V6 24v 150kw XFW (..-05)	TEMIC AirBag
 807	AIRBAG	3.0 V6 24v 150kw XFW (05-..)	TEMIC AirBag
 807	ANTITHEFT	2.0 16v 100kw RFN (..-05)	Alarm PSA1
 807	ANTITHEFT	2.0 16v 100kw RFN (..-05)	Alarm PSA2
 807	ANTITHEFT	2.0 16v 103kw RFJ (..-05)	Alarm PSA1
 807	ANTITHEFT	2.0 16v 103kw RFJ (..-05)	Alarm PSA2
 807	ANTITHEFT	2.0 HDI 16v 100kw RHR-FAP (..-05)	Alarm PSA1
 807	ANTITHEFT	2.0 HDI 16v 100kw RHR-FAP (..-05)	Alarm PSA2
 807	ANTITHEFT	2.0 HDI 16v 79kw RHM-FAP (..-05)	Alarm PSA1
 807	ANTITHEFT	2.0 HDI 16v 79kw RHM-FAP (..-05)	Alarm PSA2
 807	ANTITHEFT	2.0 HDI 16v 79kw RHT-FAP (..-05)	Alarm PSA1
 807	ANTITHEFT	2.0 HDI 16v 79kw RHT-FAP (..-05)	Alarm PSA2
 807	ANTITHEFT	2.0 HDI 16v 80kw RHW (..-05)	Alarm PSA1
 807	ANTITHEFT	2.0 HDI 16v 80kw RHW (..-05)	Alarm PSA2
 807	ANTITHEFT	2.0 HDI 16v 88kw RHK (..-05)	Alarm PSA1
 807	ANTITHEFT	2.0 HDI 16v 88kw RHK (..-05)	Alarm PSA2
 807	ANTITHEFT	2.2 16v 118kw 3FZ (..-05)	Alarm PSA1
 807	ANTITHEFT	2.2 16v 118kw 3FZ (..-05)	Alarm PSA2
 807	ANTITHEFT	2.2 HDI 16v 120kw 4HP (..-05)	Alarm PSA1
 807	ANTITHEFT	2.2 HDI 16v 120kw 4HP (..-05)	Alarm PSA2
 807	ANTITHEFT	2.2 HDI 16v 120kw 4HR (..-05)	Alarm PSA1
 807	ANTITHEFT	2.2 HDI 16v 120kw 4HR (..-05)	Alarm PSA2
 807	ANTITHEFT	2.2 HDI 16v 125kw 4HS-FAP (..-05)	Alarm PSA1
 807	ANTITHEFT	2.2 HDI 16v 125kw 4HS-FAP (..-05)	Alarm PSA2
 807	ANTITHEFT	2.2 HDI 16v 125kw 4HT-FAP (..-05)	Alarm PSA1
 807	ANTITHEFT	2.2 HDI 16v 125kw 4HT-FAP (..-05)	Alarm PSA2
 807	ANTITHEFT	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Alarm PSA1
 807	ANTITHEFT	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Alarm PSA2
 807	ANTITHEFT	3.0 V6 24v 150kw XFW (..-05)	Alarm PSA1
 807	ANTITHEFT	3.0 V6 24v 150kw XFW (..-05)	Alarm PSA2
 807	AUTOM. TRANSMISSI	2.0 16v 100kw RFN (..-05)	A/T 4HP20
 807	AUTOM. TRANSMISSI	2.0 16v 100kw RFN (..-05)	A/T AM6
 807	AUTOM. TRANSMISSI	2.0 16v 100kw RFN (..-05)	Var.1
 807	AUTOM. TRANSMISSI	2.0 16v 100kw RFN (..-05)	Var.2
 807	AUTOM. TRANSMISSI	2.0 16v 100kw RFN (..-05)	Var.3
 807	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ (..-05)	A/T 4HP20
 807	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ (..-05)	A/T AM6
 807	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ (..-05)	Var.1
 807	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ (..-05)	Var.2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 807	AUTOM. TRANSMISSI	2.0 16v 103kw RFJ (...-05)	Var.3
 807	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP (...-05)	A/T 4HP20
 807	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP (...-05)	A/T AM6
 807	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.1
 807	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.2
 807	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.3
 807	AUTOM. TRANSMISSI	2.0 HDI 16v 79kw RHM-FAP (...-05)	A/T 4HP20
 807	AUTOM. TRANSMISSI	2.0 HDI 16v 79kw RHM-FAP (...-05)	A/T AM6
 807	AUTOM. TRANSMISSI	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.1
 807	AUTOM. TRANSMISSI	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.2
 807	AUTOM. TRANSMISSI	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.3
 807	AUTOM. TRANSMISSI	2.0 HDI 16v 79kw RHT-FAP (...-05)	A/T 4HP20
 807	AUTOM. TRANSMISSI	2.0 HDI 16v 79kw RHT-FAP (...-05)	A/T AM6
 807	AUTOM. TRANSMISSI	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.1
 807	AUTOM. TRANSMISSI	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.2
 807	AUTOM. TRANSMISSI	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.3
 807	AUTOM. TRANSMISSI	2.0 HDI 16v 80kw RHW (...-05)	A/T 4HP20
 807	AUTOM. TRANSMISSI	2.0 HDI 16v 80kw RHW (...-05)	A/T AM6
 807	AUTOM. TRANSMISSI	2.0 HDI 16v 80kw RHW (...-05)	Var.1
 807	AUTOM. TRANSMISSI	2.0 HDI 16v 80kw RHW (...-05)	Var.2
 807	AUTOM. TRANSMISSI	2.0 HDI 16v 80kw RHW (...-05)	Var.3
 807	AUTOM. TRANSMISSI	2.0 HDI 16v 88kw RHK (...-05)	A/T 4HP20
 807	AUTOM. TRANSMISSI	2.0 HDI 16v 88kw RHK (...-05)	A/T AM6
 807	AUTOM. TRANSMISSI	2.0 HDI 16v 88kw RHK (...-05)	Var.1
 807	AUTOM. TRANSMISSI	2.0 HDI 16v 88kw RHK (...-05)	Var.2
 807	AUTOM. TRANSMISSI	2.0 HDI 16v 88kw RHK (...-05)	Var.3
 807	AUTOM. TRANSMISSI	2.2 16v 118kw 3FZ (...-05)	A/T 4HP20
 807	AUTOM. TRANSMISSI	2.2 16v 118kw 3FZ (...-05)	A/T AM6
 807	AUTOM. TRANSMISSI	2.2 16v 118kw 3FZ (...-05)	Var.1
 807	AUTOM. TRANSMISSI	2.2 16v 118kw 3FZ (...-05)	Var.2
 807	AUTOM. TRANSMISSI	2.2 16v 118kw 3FZ (...-05)	Var.3
 807	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HP (...-05)	A/T 4HP20
 807	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HP (...-05)	A/T AM6
 807	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HP (...-05)	Var.1
 807	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HP (...-05)	Var.2
 807	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HP (...-05)	Var.3
 807	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HR (...-05)	A/T 4HP20
 807	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HR (...-05)	A/T AM6
 807	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HR (...-05)	Var.1
 807	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HR (...-05)	Var.2
 807	AUTOM. TRANSMISSI	2.2 HDI 16v 120kw 4HR (...-05)	Var.3
 807	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HS-FAP (...-05)	A/T 4HP20
 807	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HS-FAP (...-05)	A/T AM6
 807	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.1
 807	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.2
 807	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.3
 807	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HT-FAP (...-05)	A/T 4HP20
 807	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HT-FAP (...-05)	A/T AM6
 807	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.1
 807	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.2
 807	AUTOM. TRANSMISSI	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.3
 807	AUTOM. TRANSMISSI	2.2 HDI 16v 94kw 4HW-FAP (...-05)	A/T 4HP20
 807	AUTOM. TRANSMISSI	2.2 HDI 16v 94kw 4HW-FAP (...-05)	A/T AM6
 807	AUTOM. TRANSMISSI	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.1
 807	AUTOM. TRANSMISSI	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.2
 807	AUTOM. TRANSMISSI	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.3
 807	AUTOM. TRANSMISSI	3.0 V6 24v 150kw XFW (...-05)	A/T 4HP20
 807	AUTOM. TRANSMISSI	3.0 V6 24v 150kw XFW (...-05)	A/T AM6

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 807	AUTOM. TRANSMISSI	3.0 V6 24v 150kw XFW (...-05)	Var.1
 807	AUTOM. TRANSMISSI	3.0 V6 24v 150kw XFW (...-05)	Var.2
 807	AUTOM. TRANSMISSI	3.0 V6 24v 150kw XFW (...-05)	Var.3
 807	AUX. HEATING	2.0 16v 100kw RFN (...-05)	Var.1
 807	AUX. HEATING	2.0 16v 100kw RFN (...-05)	Var.2
 807	AUX. HEATING	2.0 16v 100kw RFN (...-05)	Var.3
 807	AUX. HEATING	2.0 16v 103kw RFJ (...-05)	Var.1
 807	AUX. HEATING	2.0 16v 103kw RFJ (...-05)	Var.2
 807	AUX. HEATING	2.0 16v 103kw RFJ (...-05)	Var.3
 807	AUX. HEATING	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.1
 807	AUX. HEATING	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.2
 807	AUX. HEATING	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.3
 807	AUX. HEATING	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.1
 807	AUX. HEATING	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.2
 807	AUX. HEATING	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.3
 807	AUX. HEATING	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.1
 807	AUX. HEATING	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.2
 807	AUX. HEATING	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.3
 807	AUX. HEATING	2.0 HDI 16v 80kw RHW (...-05)	Var.1
 807	AUX. HEATING	2.0 HDI 16v 80kw RHW (...-05)	Var.2
 807	AUX. HEATING	2.0 HDI 16v 80kw RHW (...-05)	Var.3
 807	AUX. HEATING	2.0 HDI 16v 88kw RHK (...-05)	Var.1
 807	AUX. HEATING	2.0 HDI 16v 88kw RHK (...-05)	Var.2
 807	AUX. HEATING	2.0 HDI 16v 88kw RHK (...-05)	Var.3
 807	AUX. HEATING	2.2 16v 118kw 3FZ (...-05)	Var.1
 807	AUX. HEATING	2.2 16v 118kw 3FZ (...-05)	Var.2
 807	AUX. HEATING	2.2 16v 118kw 3FZ (...-05)	Var.3
 807	AUX. HEATING	2.2 HDI 16v 120kw 4HP (...-05)	Var.1
 807	AUX. HEATING	2.2 HDI 16v 120kw 4HP (...-05)	Var.2
 807	AUX. HEATING	2.2 HDI 16v 120kw 4HP (...-05)	Var.3
 807	AUX. HEATING	2.2 HDI 16v 120kw 4HR (...-05)	Var.1
 807	AUX. HEATING	2.2 HDI 16v 120kw 4HR (...-05)	Var.2
 807	AUX. HEATING	2.2 HDI 16v 120kw 4HR (...-05)	Var.3
 807	AUX. HEATING	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.1
 807	AUX. HEATING	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.2
 807	AUX. HEATING	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.3
 807	AUX. HEATING	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.1
 807	AUX. HEATING	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.2
 807	AUX. HEATING	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.3
 807	AUX. HEATING	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.1
 807	AUX. HEATING	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.2
 807	AUX. HEATING	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.3
 807	AUX. HEATING	3.0 V6 24v 150kw XFW (...-05)	Var.1
 807	AUX. HEATING	3.0 V6 24v 150kw XFW (...-05)	Var.2
 807	AUX. HEATING	3.0 V6 24v 150kw XFW (...-05)	Var.3
 807	CHASSIS NETWORK	2.0 16v 100kw RFN (...-05)	Body Computer BSI
 807	CHASSIS NETWORK	2.0 16v 100kw RFN (...-05)	Body Computer BSI
 807	CHASSIS NETWORK	2.0 16v 100kw RFN (...-05)	Body Computer BSM
 807	CHASSIS NETWORK	2.0 16v 100kw RFN (...-05)	Body Computer BSR
 807	CHASSIS NETWORK	2.0 16v 100kw RFN (...-05)	Memory Module
 807	CHASSIS NETWORK	2.0 16v 100kw RFN (...-05)	SAGEM Body Computer
 807	CHASSIS NETWORK	2.0 16v 100kw RFN (...-05)	Var.1
 807	CHASSIS NETWORK	2.0 16v 100kw RFN (...-05)	Var.2
 807	CHASSIS NETWORK	2.0 16v 100kw RFN (...-05)	Var.3
 807	CHASSIS NETWORK	2.0 16v 100kw RFN (...-05)	Var.4
 807	CHASSIS NETWORK	2.0 16v 100kw RFN (...-05)	Var.5
 807	CHASSIS NETWORK	2.0 16v 100kw RFN (...-05)	Var.6
 807	CHASSIS NETWORK	2.0 16v 100kw RFN (...-05)	Var.7

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 807	CHASSIS NETWORK	2.0 16v 103kw RFJ (...-05)	Body Computer BSI
 807	CHASSIS NETWORK	2.0 16v 103kw RFJ (...-05)	Body Computer BSI
 807	CHASSIS NETWORK	2.0 16v 103kw RFJ (...-05)	Body Computer BSM
 807	CHASSIS NETWORK	2.0 16v 103kw RFJ (...-05)	Body Computer BSR
 807	CHASSIS NETWORK	2.0 16v 103kw RFJ (...-05)	Memory Module
 807	CHASSIS NETWORK	2.0 16v 103kw RFJ (...-05)	SAGEM Body Computer
 807	CHASSIS NETWORK	2.0 16v 103kw RFJ (...-05)	Var.1
 807	CHASSIS NETWORK	2.0 16v 103kw RFJ (...-05)	Var.2
 807	CHASSIS NETWORK	2.0 16v 103kw RFJ (...-05)	Var.3
 807	CHASSIS NETWORK	2.0 16v 103kw RFJ (...-05)	Var.4
 807	CHASSIS NETWORK	2.0 16v 103kw RFJ (...-05)	Var.5
 807	CHASSIS NETWORK	2.0 16v 103kw RFJ (...-05)	Var.6
 807	CHASSIS NETWORK	2.0 16v 103kw RFJ (...-05)	Var.7
 807	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP (...-05)	Body Computer BSI
 807	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP (...-05)	Body Computer BSI
 807	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP (...-05)	Body Computer BSM
 807	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP (...-05)	Body Computer BSR
 807	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP (...-05)	Memory Module
 807	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP (...-05)	SAGEM Body Computer
 807	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.1
 807	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.2
 807	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.3
 807	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.4
 807	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.5
 807	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.6
 807	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.7
 807	CHASSIS NETWORK	2.0 HDI 16v 79kw RHM-FAP (...-05)	Body Computer BSI
 807	CHASSIS NETWORK	2.0 HDI 16v 79kw RHM-FAP (...-05)	Body Computer BSI
 807	CHASSIS NETWORK	2.0 HDI 16v 79kw RHM-FAP (...-05)	Body Computer BSM
 807	CHASSIS NETWORK	2.0 HDI 16v 79kw RHM-FAP (...-05)	Body Computer BSR
 807	CHASSIS NETWORK	2.0 HDI 16v 79kw RHM-FAP (...-05)	Memory Module
 807	CHASSIS NETWORK	2.0 HDI 16v 79kw RHM-FAP (...-05)	SAGEM Body Computer
 807	CHASSIS NETWORK	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.1
 807	CHASSIS NETWORK	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.2
 807	CHASSIS NETWORK	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.3
 807	CHASSIS NETWORK	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.4
 807	CHASSIS NETWORK	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.5
 807	CHASSIS NETWORK	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.6
 807	CHASSIS NETWORK	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.7
 807	CHASSIS NETWORK	2.0 HDI 16v 79kw RHT-FAP (...-05)	Body Computer BSI
 807	CHASSIS NETWORK	2.0 HDI 16v 79kw RHT-FAP (...-05)	Body Computer BSI
 807	CHASSIS NETWORK	2.0 HDI 16v 79kw RHT-FAP (...-05)	Body Computer BSM
 807	CHASSIS NETWORK	2.0 HDI 16v 79kw RHT-FAP (...-05)	Body Computer BSR
 807	CHASSIS NETWORK	2.0 HDI 16v 79kw RHT-FAP (...-05)	Memory Module
 807	CHASSIS NETWORK	2.0 HDI 16v 79kw RHT-FAP (...-05)	SAGEM Body Computer
 807	CHASSIS NETWORK	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.1
 807	CHASSIS NETWORK	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.2
 807	CHASSIS NETWORK	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.3
 807	CHASSIS NETWORK	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.4
 807	CHASSIS NETWORK	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.5
 807	CHASSIS NETWORK	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.6
 807	CHASSIS NETWORK	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.7
 807	CHASSIS NETWORK	2.0 HDI 16v 80kw RHW (...-05)	Body Computer BSI
 807	CHASSIS NETWORK	2.0 HDI 16v 80kw RHW (...-05)	Body Computer BSI
 807	CHASSIS NETWORK	2.0 HDI 16v 80kw RHW (...-05)	Body Computer BSM
 807	CHASSIS NETWORK	2.0 HDI 16v 80kw RHW (...-05)	Body Computer BSR
 807	CHASSIS NETWORK	2.0 HDI 16v 80kw RHW (...-05)	Memory Module
 807	CHASSIS NETWORK	2.0 HDI 16v 80kw RHW (...-05)	SAGEM Body Computer

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 807	CHASSIS NETWORK	2.0 HDI 16v 80kw RHW (...-05)	Var.1
 807	CHASSIS NETWORK	2.0 HDI 16v 80kw RHW (...-05)	Var.2
 807	CHASSIS NETWORK	2.0 HDI 16v 80kw RHW (...-05)	Var.3
 807	CHASSIS NETWORK	2.0 HDI 16v 80kw RHW (...-05)	Var.4
 807	CHASSIS NETWORK	2.0 HDI 16v 80kw RHW (...-05)	Var.5
 807	CHASSIS NETWORK	2.0 HDI 16v 80kw RHW (...-05)	Var.6
 807	CHASSIS NETWORK	2.0 HDI 16v 80kw RHW (...-05)	Var.7
 807	CHASSIS NETWORK	2.0 HDI 16v 88kw RHK (...-05)	Body Computer BSI
 807	CHASSIS NETWORK	2.0 HDI 16v 88kw RHK (...-05)	Body Computer BSI
 807	CHASSIS NETWORK	2.0 HDI 16v 88kw RHK (...-05)	Body Computer BSM
 807	CHASSIS NETWORK	2.0 HDI 16v 88kw RHK (...-05)	Body Computer BSR
 807	CHASSIS NETWORK	2.0 HDI 16v 88kw RHK (...-05)	Memory Module
 807	CHASSIS NETWORK	2.0 HDI 16v 88kw RHK (...-05)	SAGEM Body Computer
 807	CHASSIS NETWORK	2.0 HDI 16v 88kw RHK (...-05)	Var.1
 807	CHASSIS NETWORK	2.0 HDI 16v 88kw RHK (...-05)	Var.2
 807	CHASSIS NETWORK	2.0 HDI 16v 88kw RHK (...-05)	Var.3
 807	CHASSIS NETWORK	2.0 HDI 16v 88kw RHK (...-05)	Var.4
 807	CHASSIS NETWORK	2.0 HDI 16v 88kw RHK (...-05)	Var.5
 807	CHASSIS NETWORK	2.0 HDI 16v 88kw RHK (...-05)	Var.6
 807	CHASSIS NETWORK	2.0 HDI 16v 88kw RHK (...-05)	Var.7
 807	CHASSIS NETWORK	2.2 16v 118kw 3FZ (...-05)	Body Computer BSI
 807	CHASSIS NETWORK	2.2 16v 118kw 3FZ (...-05)	Body Computer BSI
 807	CHASSIS NETWORK	2.2 16v 118kw 3FZ (...-05)	Body Computer BSM
 807	CHASSIS NETWORK	2.2 16v 118kw 3FZ (...-05)	Body Computer BSR
 807	CHASSIS NETWORK	2.2 16v 118kw 3FZ (...-05)	Memory Module
 807	CHASSIS NETWORK	2.2 16v 118kw 3FZ (...-05)	SAGEM Body Computer
 807	CHASSIS NETWORK	2.2 16v 118kw 3FZ (...-05)	Var.1
 807	CHASSIS NETWORK	2.2 16v 118kw 3FZ (...-05)	Var.2
 807	CHASSIS NETWORK	2.2 16v 118kw 3FZ (...-05)	Var.3
 807	CHASSIS NETWORK	2.2 16v 118kw 3FZ (...-05)	Var.4
 807	CHASSIS NETWORK	2.2 16v 118kw 3FZ (...-05)	Var.5
 807	CHASSIS NETWORK	2.2 16v 118kw 3FZ (...-05)	Var.6
 807	CHASSIS NETWORK	2.2 16v 118kw 3FZ (...-05)	Var.7
 807	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP (...-05)	Body Computer BSI
 807	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP (...-05)	Body Computer BSI
 807	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP (...-05)	Body Computer BSM
 807	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP (...-05)	Body Computer BSR
 807	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP (...-05)	Memory Module
 807	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP (...-05)	SAGEM Body Computer
 807	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP (...-05)	Var.1
 807	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP (...-05)	Var.2
 807	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP (...-05)	Var.3
 807	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP (...-05)	Var.4
 807	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP (...-05)	Var.5
 807	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP (...-05)	Var.6
 807	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HP (...-05)	Var.7
 807	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HR (...-05)	Body Computer BSI
 807	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HR (...-05)	Body Computer BSI
 807	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HR (...-05)	Body Computer BSM
 807	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HR (...-05)	Body Computer BSR
 807	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HR (...-05)	Memory Module
 807	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HR (...-05)	SAGEM Body Computer
 807	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HR (...-05)	Var.1
 807	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HR (...-05)	Var.2
 807	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HR (...-05)	Var.3
 807	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HR (...-05)	Var.4
 807	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HR (...-05)	Var.5
 807	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HR (...-05)	Var.6

Systems supported by ECUREADER / ECUDECODER (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 807	CHASSIS NETWORK	2.2 HDI 16v 120kw 4HR (.-05)	Var.7
 807	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HS-FAP (.-05)	Body Computer BSI
 807	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HS-FAP (.-05)	Body Computer BSI
 807	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HS-FAP (.-05)	Body Computer BSM
 807	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HS-FAP (.-05)	Body Computer BSR
 807	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HS-FAP (.-05)	Memory Module
 807	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HS-FAP (.-05)	SAGEM Body Computer
 807	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HS-FAP (.-05)	Var.1
 807	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HS-FAP (.-05)	Var.2
 807	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HS-FAP (.-05)	Var.3
 807	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HS-FAP (.-05)	Var.4
 807	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HS-FAP (.-05)	Var.5
 807	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HS-FAP (.-05)	Var.6
 807	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HS-FAP (.-05)	Var.7
 807	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP (.-05)	Body Computer BSI
 807	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP (.-05)	Body Computer BSI
 807	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP (.-05)	Body Computer BSM
 807	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP (.-05)	Body Computer BSR
 807	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP (.-05)	Memory Module
 807	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP (.-05)	SAGEM Body Computer
 807	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP (.-05)	Var.1
 807	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP (.-05)	Var.2
 807	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP (.-05)	Var.3
 807	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP (.-05)	Var.4
 807	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP (.-05)	Var.5
 807	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP (.-05)	Var.6
 807	CHASSIS NETWORK	2.2 HDI 16v 125kw 4HT-FAP (.-05)	Var.7
 807	CHASSIS NETWORK	2.2 HDI 16v 94kw 4HW-FAP (.-05)	Body Computer BSI
 807	CHASSIS NETWORK	2.2 HDI 16v 94kw 4HW-FAP (.-05)	Body Computer BSI
 807	CHASSIS NETWORK	2.2 HDI 16v 94kw 4HW-FAP (.-05)	Body Computer BSM
 807	CHASSIS NETWORK	2.2 HDI 16v 94kw 4HW-FAP (.-05)	Body Computer BSR
 807	CHASSIS NETWORK	2.2 HDI 16v 94kw 4HW-FAP (.-05)	Memory Module
 807	CHASSIS NETWORK	2.2 HDI 16v 94kw 4HW-FAP (.-05)	SAGEM Body Computer
 807	CHASSIS NETWORK	2.2 HDI 16v 94kw 4HW-FAP (.-05)	Var.1
 807	CHASSIS NETWORK	2.2 HDI 16v 94kw 4HW-FAP (.-05)	Var.2
 807	CHASSIS NETWORK	2.2 HDI 16v 94kw 4HW-FAP (.-05)	Var.3
 807	CHASSIS NETWORK	2.2 HDI 16v 94kw 4HW-FAP (.-05)	Var.4
 807	CHASSIS NETWORK	2.2 HDI 16v 94kw 4HW-FAP (.-05)	Var.5
 807	CHASSIS NETWORK	2.2 HDI 16v 94kw 4HW-FAP (.-05)	Var.6
 807	CHASSIS NETWORK	2.2 HDI 16v 94kw 4HW-FAP (.-05)	Var.7
 807	CHASSIS NETWORK	3.0 V6 24v 150kw XFW (.-05)	Body Computer BSI
 807	CHASSIS NETWORK	3.0 V6 24v 150kw XFW (.-05)	Body Computer BSI
 807	CHASSIS NETWORK	3.0 V6 24v 150kw XFW (.-05)	Body Computer BSM
 807	CHASSIS NETWORK	3.0 V6 24v 150kw XFW (.-05)	Body Computer BSR
 807	CHASSIS NETWORK	3.0 V6 24v 150kw XFW (.-05)	Memory Module
 807	CHASSIS NETWORK	3.0 V6 24v 150kw XFW (.-05)	SAGEM Body Computer
 807	CHASSIS NETWORK	3.0 V6 24v 150kw XFW (.-05)	Var.1
 807	CHASSIS NETWORK	3.0 V6 24v 150kw XFW (.-05)	Var.2
 807	CHASSIS NETWORK	3.0 V6 24v 150kw XFW (.-05)	Var.3
 807	CHASSIS NETWORK	3.0 V6 24v 150kw XFW (.-05)	Var.4
 807	CHASSIS NETWORK	3.0 V6 24v 150kw XFW (.-05)	Var.5
 807	CHASSIS NETWORK	3.0 V6 24v 150kw XFW (.-05)	Var.6
 807	CHASSIS NETWORK	3.0 V6 24v 150kw XFW (.-05)	Var.7
 807	CLIMA	2.0 16v 100kw RFN (.-05)	CLIMA
 807	CLIMA	2.0 16v 100kw RFN (.-05)	CLIMA AUTO
 807	CLIMA	2.0 16v 100kw RFN (.-05)	Marelli Klima
 807	CLIMA	2.0 16v 103kw RFJ (.-05)	CLIMA
 807	CLIMA	2.0 16v 103kw RFJ (.-05)	CLIMA AUTO

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 807	CLIMA	2.0 16v 103kw RFJ (...-05)	Marelli Klima
 807	CLIMA	2.0 HDI 16v 100kw RHR-FAP (...-05)	CLIMA
 807	CLIMA	2.0 HDI 16v 100kw RHR-FAP (...-05)	CLIMA AUTO
 807	CLIMA	2.0 HDI 16v 100kw RHR-FAP (...-05)	Marelli Klima
 807	CLIMA	2.0 HDI 16v 79kw RHM-FAP (...-05)	CLIMA
 807	CLIMA	2.0 HDI 16v 79kw RHM-FAP (...-05)	CLIMA AUTO
 807	CLIMA	2.0 HDI 16v 79kw RHM-FAP (...-05)	Marelli Klima
 807	CLIMA	2.0 HDI 16v 79kw RHT-FAP (...-05)	CLIMA
 807	CLIMA	2.0 HDI 16v 79kw RHT-FAP (...-05)	CLIMA AUTO
 807	CLIMA	2.0 HDI 16v 79kw RHT-FAP (...-05)	Marelli Klima
 807	CLIMA	2.0 HDI 16v 80kw RHW (...-05)	CLIMA
 807	CLIMA	2.0 HDI 16v 80kw RHW (...-05)	CLIMA AUTO
 807	CLIMA	2.0 HDI 16v 80kw RHW (...-05)	Marelli Klima
 807	CLIMA	2.0 HDI 16v 88kw RHK (...-05)	CLIMA
 807	CLIMA	2.0 HDI 16v 88kw RHK (...-05)	CLIMA AUTO
 807	CLIMA	2.0 HDI 16v 88kw RHK (...-05)	Marelli Klima
 807	CLIMA	2.2 16v 118kw 3FZ (...-05)	CLIMA
 807	CLIMA	2.2 16v 118kw 3FZ (...-05)	CLIMA AUTO
 807	CLIMA	2.2 16v 118kw 3FZ (...-05)	Marelli Klima
 807	CLIMA	2.2 HDI 16v 120kw 4HP (...-05)	CLIMA
 807	CLIMA	2.2 HDI 16v 120kw 4HP (...-05)	CLIMA AUTO
 807	CLIMA	2.2 HDI 16v 120kw 4HP (...-05)	Marelli Klima
 807	CLIMA	2.2 HDI 16v 120kw 4HR (...-05)	CLIMA
 807	CLIMA	2.2 HDI 16v 120kw 4HR (...-05)	CLIMA AUTO
 807	CLIMA	2.2 HDI 16v 120kw 4HR (...-05)	Marelli Klima
 807	CLIMA	2.2 HDI 16v 125kw 4HS (...-05)	CLIMA
 807	CLIMA	2.2 HDI 16v 125kw 4HS (...-05)	CLIMA AUTO
 807	CLIMA	2.2 HDI 16v 125kw 4HS (...-05)	Marelli Klima
 807	CLIMA	2.2 HDI 16v 125kw 4HT-FAP (...-05)	CLIMA
 807	CLIMA	2.2 HDI 16v 125kw 4HT-FAP (...-05)	CLIMA AUTO
 807	CLIMA	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Marelli Klima
 807	CLIMA	2.2 HDI 16v 94kw 4HW-FAP (...-05)	CLIMA
 807	CLIMA	2.2 HDI 16v 94kw 4HW-FAP (...-05)	CLIMA AUTO
 807	CLIMA	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Marelli Klima
 807	CLIMA	3.0 V6 24v 150kw XFW (...-05)	CLIMA
 807	CLIMA	3.0 V6 24v 150kw XFW (...-05)	CLIMA AUTO
 807	CLIMA	3.0 V6 24v 150kw XFW (...-05)	Marelli Klima
 807	COMFORT SYSTEM	2.0 16v 100kw RFN (...-05)	Phone Kit
 807	COMFORT SYSTEM	2.0 16v 100kw RFN (...-05)	Var.1
 807	COMFORT SYSTEM	2.0 16v 100kw RFN (...-05)	Var.2
 807	COMFORT SYSTEM	2.0 16v 100kw RFN (...-05)	Var.3
 807	COMFORT SYSTEM	2.0 16v 100kw RFN (...-05)	Var.4
 807	COMFORT SYSTEM	2.0 16v 100kw RFN (...-05)	Var.5
 807	COMFORT SYSTEM	2.0 16v 100kw RFN (...-05)	Var.6
 807	COMFORT SYSTEM	2.0 16v 100kw RFN (...-05)	Var.7
 807	COMFORT SYSTEM	2.0 16v 100kw RFN (...-05)	Var.8
 807	COMFORT SYSTEM	2.0 16v 103kw RFJ (...-05)	Phone Kit
 807	COMFORT SYSTEM	2.0 16v 103kw RFJ (...-05)	Var.1
 807	COMFORT SYSTEM	2.0 16v 103kw RFJ (...-05)	Var.2
 807	COMFORT SYSTEM	2.0 16v 103kw RFJ (...-05)	Var.3
 807	COMFORT SYSTEM	2.0 16v 103kw RFJ (...-05)	Var.4
 807	COMFORT SYSTEM	2.0 16v 103kw RFJ (...-05)	Var.5
 807	COMFORT SYSTEM	2.0 16v 103kw RFJ (...-05)	Var.6
 807	COMFORT SYSTEM	2.0 16v 103kw RFJ (...-05)	Var.7
 807	COMFORT SYSTEM	2.0 16v 103kw RFJ (...-05)	Var.8
 807	COMFORT SYSTEM	2.0 HDI 16v 100kw RHR-FAP (...-05)	Phone Kit
 807	COMFORT SYSTEM	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.1
 807	COMFORT SYSTEM	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 807	COMFORT SYSTEM	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.3
 807	COMFORT SYSTEM	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.4
 807	COMFORT SYSTEM	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.5
 807	COMFORT SYSTEM	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.6
 807	COMFORT SYSTEM	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.7
 807	COMFORT SYSTEM	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.8
 807	COMFORT SYSTEM	2.0 HDI 16v 79kw RHM-FAP (...-05)	Phone Kit
 807	COMFORT SYSTEM	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.1
 807	COMFORT SYSTEM	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.2
 807	COMFORT SYSTEM	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.3
 807	COMFORT SYSTEM	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.4
 807	COMFORT SYSTEM	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.5
 807	COMFORT SYSTEM	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.6
 807	COMFORT SYSTEM	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.7
 807	COMFORT SYSTEM	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.8
 807	COMFORT SYSTEM	2.0 HDI 16v 79kw RHT-FAP (...-05)	Phone Kit
 807	COMFORT SYSTEM	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.1
 807	COMFORT SYSTEM	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.2
 807	COMFORT SYSTEM	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.3
 807	COMFORT SYSTEM	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.4
 807	COMFORT SYSTEM	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.5
 807	COMFORT SYSTEM	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.6
 807	COMFORT SYSTEM	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.7
 807	COMFORT SYSTEM	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.8
 807	COMFORT SYSTEM	2.0 HDI 16v 80kw RHW (...-05)	Phone Kit
 807	COMFORT SYSTEM	2.0 HDI 16v 80kw RHW (...-05)	Var.1
 807	COMFORT SYSTEM	2.0 HDI 16v 80kw RHW (...-05)	Var.2
 807	COMFORT SYSTEM	2.0 HDI 16v 80kw RHW (...-05)	Var.3
 807	COMFORT SYSTEM	2.0 HDI 16v 80kw RHW (...-05)	Var.4
 807	COMFORT SYSTEM	2.0 HDI 16v 80kw RHW (...-05)	Var.5
 807	COMFORT SYSTEM	2.0 HDI 16v 80kw RHW (...-05)	Var.6
 807	COMFORT SYSTEM	2.0 HDI 16v 80kw RHW (...-05)	Var.7
 807	COMFORT SYSTEM	2.0 HDI 16v 80kw RHW (...-05)	Var.8
 807	COMFORT SYSTEM	2.0 HDI 16v 88kw RHK (...-05)	Phone Kit
 807	COMFORT SYSTEM	2.0 HDI 16v 88kw RHK (...-05)	Var.1
 807	COMFORT SYSTEM	2.0 HDI 16v 88kw RHK (...-05)	Var.2
 807	COMFORT SYSTEM	2.0 HDI 16v 88kw RHK (...-05)	Var.3
 807	COMFORT SYSTEM	2.0 HDI 16v 88kw RHK (...-05)	Var.4
 807	COMFORT SYSTEM	2.0 HDI 16v 88kw RHK (...-05)	Var.5
 807	COMFORT SYSTEM	2.0 HDI 16v 88kw RHK (...-05)	Var.6
 807	COMFORT SYSTEM	2.0 HDI 16v 88kw RHK (...-05)	Var.7
 807	COMFORT SYSTEM	2.0 HDI 16v 88kw RHK (...-05)	Var.8
 807	COMFORT SYSTEM	2.2 16v 118kw 3FZ (...-05)	Phone Kit
 807	COMFORT SYSTEM	2.2 16v 118kw 3FZ (...-05)	Var.1
 807	COMFORT SYSTEM	2.2 16v 118kw 3FZ (...-05)	Var.2
 807	COMFORT SYSTEM	2.2 16v 118kw 3FZ (...-05)	Var.3
 807	COMFORT SYSTEM	2.2 16v 118kw 3FZ (...-05)	Var.4
 807	COMFORT SYSTEM	2.2 16v 118kw 3FZ (...-05)	Var.5
 807	COMFORT SYSTEM	2.2 16v 118kw 3FZ (...-05)	Var.6
 807	COMFORT SYSTEM	2.2 16v 118kw 3FZ (...-05)	Var.7
 807	COMFORT SYSTEM	2.2 16v 118kw 3FZ (...-05)	Var.8
 807	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HP (...-05)	Phone Kit
 807	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HP (...-05)	Var.1
 807	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HP (...-05)	Var.2
 807	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HP (...-05)	Var.3
 807	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HP (...-05)	Var.4
 807	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HP (...-05)	Var.5
 807	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HP (...-05)	Var.6

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 807	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HP (...-05)	Var.7
 807	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HP (...-05)	Var.8
 807	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HR (...-05)	Phone Kit
 807	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HR (...-05)	Var.1
 807	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HR (...-05)	Var.2
 807	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HR (...-05)	Var.3
 807	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HR (...-05)	Var.4
 807	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HR (...-05)	Var.5
 807	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HR (...-05)	Var.6
 807	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HR (...-05)	Var.7
 807	COMFORT SYSTEM	2.2 HDI 16v 120kw 4HR (...-05)	Var.8
 807	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Phone Kit
 807	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.1
 807	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.2
 807	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.3
 807	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.4
 807	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.5
 807	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.6
 807	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.7
 807	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.8
 807	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Phone Kit
 807	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.1
 807	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.2
 807	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.3
 807	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.4
 807	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.5
 807	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.6
 807	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.7
 807	COMFORT SYSTEM	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.8
 807	COMFORT SYSTEM	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Phone Kit
 807	COMFORT SYSTEM	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.1
 807	COMFORT SYSTEM	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.2
 807	COMFORT SYSTEM	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.3
 807	COMFORT SYSTEM	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.4
 807	COMFORT SYSTEM	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.5
 807	COMFORT SYSTEM	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.6
 807	COMFORT SYSTEM	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.7
 807	COMFORT SYSTEM	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.8
 807	COMFORT SYSTEM	3.0 V6 24v 150kw XFW (...-05)	Phone Kit
 807	COMFORT SYSTEM	3.0 V6 24v 150kw XFW (...-05)	Var.1
 807	COMFORT SYSTEM	3.0 V6 24v 150kw XFW (...-05)	Var.2
 807	COMFORT SYSTEM	3.0 V6 24v 150kw XFW (...-05)	Var.3
 807	COMFORT SYSTEM	3.0 V6 24v 150kw XFW (...-05)	Var.4
 807	COMFORT SYSTEM	3.0 V6 24v 150kw XFW (...-05)	Var.5
 807	COMFORT SYSTEM	3.0 V6 24v 150kw XFW (...-05)	Var.6
 807	COMFORT SYSTEM	3.0 V6 24v 150kw XFW (...-05)	Var.7
 807	COMFORT SYSTEM	3.0 V6 24v 150kw XFW (...-05)	Var.8
 807	CONV. TOP/SUNROO	2.0 16v 100kw RFN (...-05)	Var.1
 807	CONV. TOP/SUNROO	2.0 16v 100kw RFN (...-05)	Var.2
 807	CONV. TOP/SUNROO	2.0 16v 100kw RFN (...-05)	Var.3
 807	CONV. TOP/SUNROO	2.0 16v 100kw RFN (...-05)	Var.4
 807	CONV. TOP/SUNROO	2.0 16v 103kw RFJ (...-05)	Var.1
 807	CONV. TOP/SUNROO	2.0 16v 103kw RFJ (...-05)	Var.2
 807	CONV. TOP/SUNROO	2.0 16v 103kw RFJ (...-05)	Var.3
 807	CONV. TOP/SUNROO	2.0 16v 103kw RFJ (...-05)	Var.4
 807	CONV. TOP/SUNROO	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.1
 807	CONV. TOP/SUNROO	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.2
 807	CONV. TOP/SUNROO	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 807	CONV. TOP/SUNROO	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.4
 807	CONV. TOP/SUNROO	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.1
 807	CONV. TOP/SUNROO	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.2
 807	CONV. TOP/SUNROO	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.3
 807	CONV. TOP/SUNROO	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.4
 807	CONV. TOP/SUNROO	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.1
 807	CONV. TOP/SUNROO	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.2
 807	CONV. TOP/SUNROO	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.3
 807	CONV. TOP/SUNROO	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.4
 807	CONV. TOP/SUNROO	2.0 HDI 16v 80kw RHW (...-05)	Var.1
 807	CONV. TOP/SUNROO	2.0 HDI 16v 80kw RHW (...-05)	Var.2
 807	CONV. TOP/SUNROO	2.0 HDI 16v 80kw RHW (...-05)	Var.3
 807	CONV. TOP/SUNROO	2.0 HDI 16v 80kw RHW (...-05)	Var.4
 807	CONV. TOP/SUNROO	2.0 HDI 16v 88kw RHK (...-05)	Var.1
 807	CONV. TOP/SUNROO	2.0 HDI 16v 88kw RHK (...-05)	Var.2
 807	CONV. TOP/SUNROO	2.0 HDI 16v 88kw RHK (...-05)	Var.3
 807	CONV. TOP/SUNROO	2.0 HDI 16v 88kw RHK (...-05)	Var.4
 807	CONV. TOP/SUNROO	2.2 16v 118kw 3FZ (...-05)	Var.1
 807	CONV. TOP/SUNROO	2.2 16v 118kw 3FZ (...-05)	Var.2
 807	CONV. TOP/SUNROO	2.2 16v 118kw 3FZ (...-05)	Var.3
 807	CONV. TOP/SUNROO	2.2 16v 118kw 3FZ (...-05)	Var.4
 807	CONV. TOP/SUNROO	2.2 16v 120kw 4HP (...-05)	Var.1
 807	CONV. TOP/SUNROO	2.2 16v 120kw 4HP (...-05)	Var.2
 807	CONV. TOP/SUNROO	2.2 16v 120kw 4HP (...-05)	Var.3
 807	CONV. TOP/SUNROO	2.2 16v 120kw 4HP (...-05)	Var.4
 807	CONV. TOP/SUNROO	2.2 16v 120kw 4HR (...-05)	Var.1
 807	CONV. TOP/SUNROO	2.2 16v 120kw 4HR (...-05)	Var.2
 807	CONV. TOP/SUNROO	2.2 16v 120kw 4HR (...-05)	Var.3
 807	CONV. TOP/SUNROO	2.2 16v 120kw 4HR (...-05)	Var.4
 807	CONV. TOP/SUNROO	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.1
 807	CONV. TOP/SUNROO	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.2
 807	CONV. TOP/SUNROO	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.3
 807	CONV. TOP/SUNROO	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.4
 807	CONV. TOP/SUNROO	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.1
 807	CONV. TOP/SUNROO	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.2
 807	CONV. TOP/SUNROO	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.3
 807	CONV. TOP/SUNROO	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.4
 807	CONV. TOP/SUNROO	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.1
 807	CONV. TOP/SUNROO	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.2
 807	CONV. TOP/SUNROO	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.3
 807	CONV. TOP/SUNROO	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.4
 807	CONV. TOP/SUNROO	3.0 V6 24v 150kw XFW (...-05)	Var.1
 807	CONV. TOP/SUNROO	3.0 V6 24v 150kw XFW (...-05)	Var.2
 807	CONV. TOP/SUNROO	3.0 V6 24v 150kw XFW (...-05)	Var.3
 807	CONV. TOP/SUNROO	3.0 V6 24v 150kw XFW (...-05)	Var.4
 807	DASH LAMPS	2.0 16v 100kw RFN (...-05)	BTO_MM
 807	DASH LAMPS	2.0 16v 100kw RFN (05-..)	Marelli
 807	DASH LAMPS	2.0 16v 103kw RFJ (...-05)	BTO_MM
 807	DASH LAMPS	2.0 16v 103kw RFJ (05-..)	Marelli
 807	DASH LAMPS	2.0 HDI 16v 100kw RHR-FAP (...-05)	BTO_MM
 807	DASH LAMPS	2.0 HDI 16v 100kw RHR-FAP (05-..)	Marelli
 807	DASH LAMPS	2.0 HDI 16v 79kw RHM-FAP (...-05)	BTO_MM
 807	DASH LAMPS	2.0 HDI 16v 79kw RHM-FAP (05-..)	Marelli
 807	DASH LAMPS	2.0 HDI 16v 79kw RHT-FAP (...-05)	BTO_MM
 807	DASH LAMPS	2.0 HDI 16v 79kw RHT-FAP (05-..)	Marelli
 807	DASH LAMPS	2.0 HDI 16v 80kw RHW (...-05)	BTO_MM
 807	DASH LAMPS	2.0 HDI 16v 80kw RHW (05-..)	Marelli
 807	DASH LAMPS	2.0 HDI 16v 88kw RHK (...-05)	BTO_MM

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 807	DASH LAMPS	2.0 HDI 16v 88kw RHK (05-..)	Marelli
 807	DASH LAMPS	2.2 16v 118kw 3FZ (..-05)	BTO_MM
 807	DASH LAMPS	2.2 16v 118kw 3FZ (05-..)	Marelli
 807	DASH LAMPS	2.2 HDI 16v 120kw 4HP (..-05)	BTO_MM
 807	DASH LAMPS	2.2 HDI 16v 120kw 4HP (05-..)	Marelli
 807	DASH LAMPS	2.2 HDI 16v 120kw 4HR (..-05)	BTO_MM
 807	DASH LAMPS	2.2 HDI 16v 120kw 4HR (05-..)	Marelli
 807	DASH LAMPS	2.2 HDI 16v 125kw 4HS-FAP (..-05)	BTO_MM
 807	DASH LAMPS	2.2 HDI 16v 125kw 4HS-FAP (05-..)	Marelli
 807	DASH LAMPS	2.2 HDI 16v 125kw 4HT-FAP (..-05)	BTO_MM
 807	DASH LAMPS	2.2 HDI 16v 125kw 4HT-FAP (05-..)	Marelli
 807	DASH LAMPS	2.2 HDI 16v 94kw 4HW-FAP (..-05)	BTO_MM
 807	DASH LAMPS	2.2 HDI 16v 94kw 4HW-FAP (05-..)	Marelli
 807	DASH LAMPS	2.2 HDI 16v 94kw XFW (05-..)	Marelli
 807	DASH LAMPS	3.0 V6 24v 150kw XFW (..-05)	BTO_MM
 807	DASHBOARD	2.0 16v 100kw RFN (..-05)	Marelli Dashboard
 807	DASHBOARD	2.0 16v 100kw RFN (..-05)	Var.1
 807	DASHBOARD	2.0 16v 100kw RFN (..-05)	Var.2
 807	DASHBOARD	2.0 16v 100kw RFN (05-..)	Marelli Dashboard
 807	DASHBOARD	2.0 16v 103kw RFJ (..-05)	Marelli Dashboard
 807	DASHBOARD	2.0 16v 103kw RFJ (..-05)	Var.1
 807	DASHBOARD	2.0 16v 103kw RFJ (..-05)	Var.2
 807	DASHBOARD	2.0 16v 103kw RFJ (05-..)	Marelli Dashboard
 807	DASHBOARD	2.0 HDI 16v 100kw RHR-FAP (..-05)	Marelli Dashboard
 807	DASHBOARD	2.0 HDI 16v 100kw RHR-FAP (..-05)	Var.1
 807	DASHBOARD	2.0 HDI 16v 100kw RHR-FAP (..-05)	Var.2
 807	DASHBOARD	2.0 HDI 16v 100kw RHR-FAP (05-..)	Marelli Dashboard
 807	DASHBOARD	2.0 HDI 16v 79kw RHM-FAP (..-05)	Marelli Dashboard
 807	DASHBOARD	2.0 HDI 16v 79kw RHM-FAP (..-05)	Var.1
 807	DASHBOARD	2.0 HDI 16v 79kw RHM-FAP (..-05)	Var.2
 807	DASHBOARD	2.0 HDI 16v 79kw RHM-FAP (05-..)	Marelli Dashboard
 807	DASHBOARD	2.0 HDI 16v 79kw RHT-FAP (..-05)	Marelli Dashboard
 807	DASHBOARD	2.0 HDI 16v 79kw RHT-FAP (..-05)	Var.1
 807	DASHBOARD	2.0 HDI 16v 79kw RHT-FAP (..-05)	Var.2
 807	DASHBOARD	2.0 HDI 16v 79kw RHT-FAP (05-..)	Marelli Dashboard
 807	DASHBOARD	2.0 HDI 16v 80kw RHW (..-05)	Marelli Dashboard
 807	DASHBOARD	2.0 HDI 16v 80kw RHW (..-05)	Var.1
 807	DASHBOARD	2.0 HDI 16v 80kw RHW (..-05)	Var.2
 807	DASHBOARD	2.0 HDI 16v 80kw RHW (05-..)	Marelli Dashboard
 807	DASHBOARD	2.0 HDI 16v 88kw RHK (..-05)	Marelli Dashboard
 807	DASHBOARD	2.0 HDI 16v 88kw RHK (..-05)	Var.1
 807	DASHBOARD	2.0 HDI 16v 88kw RHK (..-05)	Var.2
 807	DASHBOARD	2.0 HDI 16v 88kw RHK (05-..)	Marelli Dashboard
 807	DASHBOARD	2.2 16v 118kw 3FZ (..-05)	Marelli Dashboard
 807	DASHBOARD	2.2 16v 118kw 3FZ (..-05)	Var.1
 807	DASHBOARD	2.2 16v 118kw 3FZ (..-05)	Var.2
 807	DASHBOARD	2.2 16v 118kw 3FZ (05-..)	Marelli Dashboard
 807	DASHBOARD	2.2 HDI 16v 120kw 4HP (..-05)	Marelli Dashboard
 807	DASHBOARD	2.2 HDI 16v 120kw 4HP (..-05)	Var.1
 807	DASHBOARD	2.2 HDI 16v 120kw 4HP (..-05)	Var.2
 807	DASHBOARD	2.2 HDI 16v 120kw 4HP (05-..)	Marelli Dashboard
 807	DASHBOARD	2.2 HDI 16v 120kw 4HR (..-05)	Marelli Dashboard
 807	DASHBOARD	2.2 HDI 16v 120kw 4HR (..-05)	Var.1
 807	DASHBOARD	2.2 HDI 16v 120kw 4HR (..-05)	Var.2
 807	DASHBOARD	2.2 HDI 16v 120kw 4HR (05-..)	Marelli Dashboard
 807	DASHBOARD	2.2 HDI 16v 125kw 4HS-FAP (..-05)	Marelli Dashboard
 807	DASHBOARD	2.2 HDI 16v 125kw 4HS-FAP (..-05)	Var.1
 807	DASHBOARD	2.2 HDI 16v 125kw 4HS-FAP (..-05)	Var.2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 807	DASHBOARD	2.2 HDI 16v 125kw 4HS-FAP (05-..)	Marelli Dashboard
 807	DASHBOARD	2.2 HDI 16v 125kw 4HT-FAP (..-05)	Marelli Dashboard
 807	DASHBOARD	2.2 HDI 16v 125kw 4HT-FAP (..-05)	Var.1
 807	DASHBOARD	2.2 HDI 16v 125kw 4HT-FAP (..-05)	Var.2
 807	DASHBOARD	2.2 HDI 16v 125kw 4HT-FAP (05-..)	Marelli Dashboard
 807	DASHBOARD	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Marelli Dashboard
 807	DASHBOARD	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Var.1
 807	DASHBOARD	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Var.2
 807	DASHBOARD	2.2 HDI 16v 94kw 4HW-FAP (05-..)	Marelli Dashboard
 807	DASHBOARD	2.2 HDI 16v 94kw XFW (05-..)	Marelli Dashboard
 807	DASHBOARD	3.0 V6 24v 150kw XFW (..-05)	Marelli Dashboard
 807	DASHBOARD	3.0 V6 24v 150kw XFW (..-05)	Var.1
 807	DASHBOARD	3.0 V6 24v 150kw XFW (..-05)	Var.2
 807	DIESEL ADDITION	2.0 HDI 16v 79kw RHM-FAP (..-05)	
 807	DIESEL ADDITION	2.0 HDI 16v 79kw RHM-FAP (..-05)	Var.1
 807	DIESEL ADDITION	2.0 HDI 16v 79kw RHM-FAP (..-05)	Var.2
 807	DIESEL ADDITION	2.0 HDI 16v 79kw RHT-FAP (..-05)	
 807	DIESEL ADDITION	2.0 HDI 16v 79kw RHT-FAP (..-05)	Var.1
 807	DIESEL ADDITION	2.0 HDI 16v 79kw RHT-FAP (..-05)	Var.2
 807	DIESEL ADDITION	2.2 HDI 16v 94kw 4HW-FAP (..-05)	
 807	DIESEL ADDITION	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Var.1
 807	DIESEL ADDITION	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Var.2
 807	DRIVER SEAT CONT	2.0 16v 100kw RFN (..-05)	
 807	DRIVER SEAT CONT	2.0 16v 103kw RFJ (..-05)	
 807	DRIVER SEAT CONT	2.0 HDI 16v 100kw RHR-FAP (..-05)	
 807	DRIVER SEAT CONT	2.0 HDI 16v 79kw RHM-FAP (..-05)	
 807	DRIVER SEAT CONT	2.0 HDI 16v 79kw RHT-FAP (..-05)	
 807	DRIVER SEAT CONT	2.0 HDI 16v 80kw RHW (..-05)	
 807	DRIVER SEAT CONT	2.0 HDI 16v 88kw RHK (..-05)	
 807	DRIVER SEAT CONT	2.2 16v 118kw 3FZ (..-05)	
 807	DRIVER SEAT CONT	2.2 HDI 16v 120kw 4HP (..-05)	
 807	DRIVER SEAT CONT	2.2 HDI 16v 120kw 4HR (..-05)	
 807	DRIVER SEAT CONT	2.2 HDI 16v 125kw 4HS-FAP (..-05)	
 807	DRIVER SEAT CONT	2.2 HDI 16v 125kw 4HT-FAP (..-05)	
 807	DRIVER SEAT CONT	2.2 HDI 16v 94kw 4HW-FAP (..-05)	
 807	DRIVER SEAT CONT	3.0 V6 24v 150kw XFW (..-05)	
 807	DRIVER SIDE DOOR	2.0 16v 100kw RFN (..-05)	Marelli MTP CONDUCT
 807	DRIVER SIDE DOOR	2.0 16v 100kw RFN (..-05)	Var.1
 807	DRIVER SIDE DOOR	2.0 16v 100kw RFN (..-05)	Var.2
 807	DRIVER SIDE DOOR	2.0 16v 100kw RFN (..-05)	Var.3
 807	DRIVER SIDE DOOR	2.0 16v 100kw RFN (..-05)	Var.4
 807	DRIVER SIDE DOOR	2.0 16v 103kw RFJ (..-05)	Marelli MTP CONDUCT
 807	DRIVER SIDE DOOR	2.0 16v 103kw RFJ (..-05)	Var.1
 807	DRIVER SIDE DOOR	2.0 16v 103kw RFJ (..-05)	Var.2
 807	DRIVER SIDE DOOR	2.0 16v 103kw RFJ (..-05)	Var.3
 807	DRIVER SIDE DOOR	2.0 16v 103kw RFJ (..-05)	Var.4
 807	DRIVER SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP (..-05)	Marelli MTP CONDUCT
 807	DRIVER SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP (..-05)	Var.1
 807	DRIVER SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP (..-05)	Var.2
 807	DRIVER SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP (..-05)	Var.3
 807	DRIVER SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP (..-05)	Var.4
 807	DRIVER SIDE DOOR	2.0 HDI 16v 79kw RHM-FAP (..-05)	Marelli MTP CONDUCT
 807	DRIVER SIDE DOOR	2.0 HDI 16v 79kw RHM-FAP (..-05)	Var.1
 807	DRIVER SIDE DOOR	2.0 HDI 16v 79kw RHM-FAP (..-05)	Var.2
 807	DRIVER SIDE DOOR	2.0 HDI 16v 79kw RHM-FAP (..-05)	Var.3
 807	DRIVER SIDE DOOR	2.0 HDI 16v 79kw RHM-FAP (..-05)	Var.4
 807	DRIVER SIDE DOOR	2.0 HDI 16v 79kw RHT-FAP (..-05)	Marelli MTP CONDUCT
 807	DRIVER SIDE DOOR	2.0 HDI 16v 79kw RHT-FAP (..-05)	Var.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 807	DRIVER SIDE DOOR	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.2
 807	DRIVER SIDE DOOR	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.3
 807	DRIVER SIDE DOOR	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.4
 807	DRIVER SIDE DOOR	2.0 HDI 16v 80kw RHW (...-05)	Marelli MTP CONDUCT
 807	DRIVER SIDE DOOR	2.0 HDI 16v 80kw RHW (...-05)	Var.1
 807	DRIVER SIDE DOOR	2.0 HDI 16v 80kw RHW (...-05)	Var.2
 807	DRIVER SIDE DOOR	2.0 HDI 16v 80kw RHW (...-05)	Var.3
 807	DRIVER SIDE DOOR	2.0 HDI 16v 80kw RHW (...-05)	Var.4
 807	DRIVER SIDE DOOR	2.0 HDI 16v 88kw RHK (...-05)	Marelli MTP CONDUCT
 807	DRIVER SIDE DOOR	2.0 HDI 16v 88kw RHK (...-05)	Var.1
 807	DRIVER SIDE DOOR	2.0 HDI 16v 88kw RHK (...-05)	Var.2
 807	DRIVER SIDE DOOR	2.0 HDI 16v 88kw RHK (...-05)	Var.3
 807	DRIVER SIDE DOOR	2.0 HDI 16v 88kw RHK (...-05)	Var.4
 807	DRIVER SIDE DOOR	2.2 16v 118kw 3FZ (...-05)	Marelli MTP CONDUCT
 807	DRIVER SIDE DOOR	2.2 16v 118kw 3FZ (...-05)	Var.1
 807	DRIVER SIDE DOOR	2.2 16v 118kw 3FZ (...-05)	Var.2
 807	DRIVER SIDE DOOR	2.2 16v 118kw 3FZ (...-05)	Var.3
 807	DRIVER SIDE DOOR	2.2 16v 118kw 3FZ (...-05)	Var.4
 807	DRIVER SIDE DOOR	2.2 HDI 16v 120kw 4HP (...-05)	Marelli MTP CONDUCT
 807	DRIVER SIDE DOOR	2.2 HDI 16v 120kw 4HP (...-05)	Var.1
 807	DRIVER SIDE DOOR	2.2 HDI 16v 120kw 4HP (...-05)	Var.2
 807	DRIVER SIDE DOOR	2.2 HDI 16v 120kw 4HP (...-05)	Var.3
 807	DRIVER SIDE DOOR	2.2 HDI 16v 120kw 4HP (...-05)	Var.4
 807	DRIVER SIDE DOOR	2.2 HDI 16v 120kw 4HR (...-05)	Marelli MTP CONDUCT
 807	DRIVER SIDE DOOR	2.2 HDI 16v 120kw 4HR (...-05)	Var.1
 807	DRIVER SIDE DOOR	2.2 HDI 16v 120kw 4HR (...-05)	Var.2
 807	DRIVER SIDE DOOR	2.2 HDI 16v 120kw 4HR (...-05)	Var.3
 807	DRIVER SIDE DOOR	2.2 HDI 16v 120kw 4HR (...-05)	Var.4
 807	DRIVER SIDE DOOR	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Marelli MTP CONDUCT
 807	DRIVER SIDE DOOR	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.1
 807	DRIVER SIDE DOOR	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.2
 807	DRIVER SIDE DOOR	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.3
 807	DRIVER SIDE DOOR	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.4
 807	DRIVER SIDE DOOR	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Marelli MTP CONDUCT
 807	DRIVER SIDE DOOR	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.1
 807	DRIVER SIDE DOOR	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.2
 807	DRIVER SIDE DOOR	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.3
 807	DRIVER SIDE DOOR	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.4
 807	DRIVER SIDE DOOR	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Marelli MTP CONDUCT
 807	DRIVER SIDE DOOR	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.1
 807	DRIVER SIDE DOOR	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.2
 807	DRIVER SIDE DOOR	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.3
 807	DRIVER SIDE DOOR	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.4
 807	DRIVER SIDE DOOR	3.0 V6 24v 150kw XFW (...-05)	Marelli MTP CONDUCT
 807	DRIVER SIDE DOOR	3.0 V6 24v 150kw XFW (...-05)	Var.1
 807	DRIVER SIDE DOOR	3.0 V6 24v 150kw XFW (...-05)	Var.2
 807	DRIVER SIDE DOOR	3.0 V6 24v 150kw XFW (...-05)	Var.3
 807	DRIVER SIDE DOOR	3.0 V6 24v 150kw XFW (...-05)	Var.4
 807	ELECTRIC STEERING	2.0 16v 100kw RFN (...-05)	Var.1
 807	ELECTRIC STEERING	2.0 16v 100kw RFN (...-05)	Var.2
 807	ELECTRIC STEERING	2.0 16v 100kw RFN (05-..)	HPI EPS GEP
 807	ELECTRIC STEERING	2.0 16v 103kw RFJ (...-05)	Var.1
 807	ELECTRIC STEERING	2.0 16v 103kw RFJ (...-05)	Var.2
 807	ELECTRIC STEERING	2.0 16v 103kw RFJ (05-..)	HPI EPS GEP
 807	ELECTRIC STEERING	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.1
 807	ELECTRIC STEERING	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.2
 807	ELECTRIC STEERING	2.0 HDI 16v 100kw RHR-FAP (05-..)	HPI EPS GEP
 807	ELECTRIC STEERING	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 807	ELECTRIC STEERING	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.2
 807	ELECTRIC STEERING	2.0 HDI 16v 79kw RHM-FAP (05-..)	HPI EPS GEP
 807	ELECTRIC STEERING	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.1
 807	ELECTRIC STEERING	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.2
 807	ELECTRIC STEERING	2.0 HDI 16v 79kw RHT-FAP (05-..)	HPI EPS GEP
 807	ELECTRIC STEERING	2.0 HDI 16v 80kw RHW (...-05)	Var.1
 807	ELECTRIC STEERING	2.0 HDI 16v 80kw RHW (...-05)	Var.2
 807	ELECTRIC STEERING	2.0 HDI 16v 80kw RHW (05-..)	HPI EPS GEP
 807	ELECTRIC STEERING	2.0 HDI 16v 88kw RHK (...-05)	Var.1
 807	ELECTRIC STEERING	2.0 HDI 16v 88kw RHK (...-05)	Var.2
 807	ELECTRIC STEERING	2.0 HDI 16v 88kw RHK (05-..)	HPI EPS GEP
 807	ELECTRIC STEERING	2.2 16v 118kw 3FZ (...-05)	Var.1
 807	ELECTRIC STEERING	2.2 16v 118kw 3FZ (...-05)	Var.2
 807	ELECTRIC STEERING	2.2 16v 118kw RFZ (05-..)	HPI EPS GEP
 807	ELECTRIC STEERING	2.2 HDI 16v 120kw 4HP (...-05)	Var.1
 807	ELECTRIC STEERING	2.2 HDI 16v 120kw 4HP (...-05)	Var.2
 807	ELECTRIC STEERING	2.2 HDI 16v 120kw 4HP (05-..)	HPI EPS GEP
 807	ELECTRIC STEERING	2.2 HDI 16v 120kw 4HR (...-05)	Var.1
 807	ELECTRIC STEERING	2.2 HDI 16v 120kw 4HR (...-05)	Var.2
 807	ELECTRIC STEERING	2.2 HDI 16v 120kw 4HR (05-..)	HPI EPS GEP
 807	ELECTRIC STEERING	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.1
 807	ELECTRIC STEERING	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.2
 807	ELECTRIC STEERING	2.2 HDI 16v 125kw 4HS-FAP (05-..)	HPI EPS GEP
 807	ELECTRIC STEERING	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.1
 807	ELECTRIC STEERING	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.2
 807	ELECTRIC STEERING	2.2 HDI 16v 125kw 4HT-FAP (05-..)	HPI EPS GEP
 807	ELECTRIC STEERING	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.1
 807	ELECTRIC STEERING	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.2
 807	ELECTRIC STEERING	2.2 HDI 16v 94kw 4HW-FAP (05-..)	HPI EPS GEP
 807	ELECTRIC STEERING	3.0 V6 24v 150kw XFW (...-05)	Var.1
 807	ELECTRIC STEERING	3.0 V6 24v 150kw XFW (...-05)	Var.2
 807	ELECTRIC STEERING	3.0 V6 24v 150kw XFW (05-..)	HPI EPS GEP
 807	ENGINE MANAGEME	2.0 16v 100kw RFN (...-05)	Marelli MM4MP2
 807	ENGINE MANAGEME	2.0 16v 100kw RFN (...-05)	Marelli MM6LP
 807	ENGINE MANAGEME	2.0 16v 103kw RFJ (05-..)	EOBD
 807	ENGINE MANAGEME	2.0 HDI 16v 100kw RHR-FAP (05-..)	SIEMENS EDC SID 803A Common Rail
 807	ENGINE MANAGEME	2.0 HDI 16v 79kw RHM-FAP (...-05)	BOSCH EDC 15 C2 Common Rail
 807	ENGINE MANAGEME	2.0 HDI 16v 79kw RHM-FAP (...-05)	BOSCH EDC 15 C2 Common Rail
 807	ENGINE MANAGEME	2.0 HDI 16v 79kw RHT-FAP (...-05)	BOSCH EDC 15 C2 Common Rail
 807	ENGINE MANAGEME	2.0 HDI 16v 79kw RHT-FAP (...-05)	BOSCH EDC 15 C2 Common Rail
 807	ENGINE MANAGEME	2.0 HDI 16v 80kw RHW (...-05)	BOSCH EDC 15 C2 Common Rail
 807	ENGINE MANAGEME	2.0 HDI 16v 88kw RHK (05-..)	EOBD
 807	ENGINE MANAGEME	2.2 16v 118kw 3FZ (...-05)	Marelli MM4MP2
 807	ENGINE MANAGEME	2.2 16v 118kw 3FZ (...-05)	Marelli MM6LP
 807	ENGINE MANAGEME	2.2 HDI 16v 120kw 4HP (05-..)	EOBD
 807	ENGINE MANAGEME	2.2 HDI 16v 120kw 4HR (05-..)	EOBD
 807	ENGINE MANAGEME	2.2 HDI 16v 125kw 4HS-FAP (05-..)	EOBD
 807	ENGINE MANAGEME	2.2 HDI 16v 125kw 4HT-FAP (05-..)	EOBD
 807	ENGINE MANAGEME	2.2 HDI 16v 94kw 4HW-FAP (...-05)	BOSCH EDC 15 C2 Common Rail
 807	ENGINE MANAGEME	2.2 HDI 16v 94kw 4HW-FAP (...-05)	BOSCH EDC 15 C2 Common Rail
 807	ENGINE MANAGEME	2.2 HDI 16v 94kw 4HW-FAP (05-..)	EOBD
 807	ENGINE MANAGEME	3.0 V6 24v 150kw XFW (...-05)	BOSCH ME7.4.6
 807	LH RIGHT MODULATI	2.0 16v 100kw RFN (...-05)	
 807	LH RIGHT MODULATI	2.0 16v 103kw RFJ (...-05)	
 807	LH RIGHT MODULATI	2.0 HDI 16v 100kw RHR-FAP (...-05)	
 807	LH RIGHT MODULATI	2.0 HDI 16v 79kw RHM-FAP (...-05)	
 807	LH RIGHT MODULATI	2.0 HDI 16v 79kw RHT-FAP (...-05)	
 807	LH RIGHT MODULATI	2.0 HDI 16v 80kw RHW (...-05)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 807	LH RIGHT MODULATI	2.0 HDI 16v 88kw RHK (...-05)	
 807	LH RIGHT MODULATI	2.2 16v 118kw 3FZ (...-05)	
 807	LH RIGHT MODULATI	2.2 HDI 16v 120kw 4HP (...-05)	
 807	LH RIGHT MODULATI	2.2 HDI 16v 120kw 4HR (...-05)	
 807	LH RIGHT MODULATI	2.2 HDI 16v 125kw 4HS-FAP (...-05)	
 807	LH RIGHT MODULATI	2.2 HDI 16v 125kw 4HT-FAP (...-05)	
 807	LH RIGHT MODULATI	2.2 HDI 16v 94kw 4HW-FAP (...-05)	
 807	LH RIGHT MODULATI	3.0 V6 24v 150kw XFW (...-05)	
 807	MAINTENANCE	2.0 16v 100kw RFN (...-05)	
 807	MAINTENANCE	2.0 16v 100kw RFN (...-05)	
 807	MAINTENANCE	2.0 16v 100kw RFN (...-05)	A/T AM6
 807	MAINTENANCE	2.0 16v 100kw RFN (...-05)	A/T AM6
 807	MAINTENANCE	2.0 16v 100kw RFN (...-05)	AirBag CENTRAL
 807	MAINTENANCE	2.0 16v 100kw RFN (...-05)	AirBag CENTRAL
 807	MAINTENANCE	2.0 16v 100kw RFN (...-05)	Body Computer BSI
 807	MAINTENANCE	2.0 16v 100kw RFN (...-05)	Body Computer BSI
 807	MAINTENANCE	2.0 16v 100kw RFN (...-05)	Body Computer BSI
 807	MAINTENANCE	2.0 16v 100kw RFN (...-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.0 16v 100kw RFN (...-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.0 16v 100kw RFN (...-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.0 16v 100kw RFN (...-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.0 16v 100kw RFN (...-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.0 16v 100kw RFN (...-05)	BOSCH ESP 5.7
 807	MAINTENANCE	2.0 16v 100kw RFN (...-05)	BOSCH ESP 5.7
 807	MAINTENANCE	2.0 16v 100kw RFN (...-05)	BTO_MM
 807	MAINTENANCE	2.0 16v 100kw RFN (...-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.0 16v 100kw RFN (...-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.0 16v 100kw RFN (...-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.0 16v 100kw RFN (...-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.0 16v 100kw RFN (...-05)	Var.1
 807	MAINTENANCE	2.0 16v 100kw RFN (...-05)	Var.1
 807	MAINTENANCE	2.0 16v 100kw RFN (...-05)	Var.1
 807	MAINTENANCE	2.0 16v 100kw RFN (...-05)	Var.1
 807	MAINTENANCE	2.0 16v 100kw RFN (...-05)	Var.2
 807	MAINTENANCE	2.0 16v 100kw RFN (...-05)	Var.2
 807	MAINTENANCE	2.0 16v 100kw RFN (...-05)	Var.2
 807	MAINTENANCE	2.0 16v 100kw RFN (...-05)	Var.2
 807	MAINTENANCE	2.0 16v 100kw RFN (...-05)	Var.3
 807	MAINTENANCE	2.0 16v 100kw RFN (...-05)	Var.4
 807	MAINTENANCE	2.0 16v 100kw RFN (...-05)	Var.7
 807	MAINTENANCE	2.0 16v 100kw RFN (05-..)	Marelli
 807	MAINTENANCE	2.0 16v 103kw RFJ (...-05)	
 807	MAINTENANCE	2.0 16v 103kw RFJ (...-05)	
 807	MAINTENANCE	2.0 16v 103kw RFJ (...-05)	A/T AM6
 807	MAINTENANCE	2.0 16v 103kw RFJ (...-05)	A/T AM6
 807	MAINTENANCE	2.0 16v 103kw RFJ (...-05)	AirBag CENTRAL
 807	MAINTENANCE	2.0 16v 103kw RFJ (...-05)	AirBag CENTRAL
 807	MAINTENANCE	2.0 16v 103kw RFJ (...-05)	Body Computer BSI
 807	MAINTENANCE	2.0 16v 103kw RFJ (...-05)	Body Computer BSI
 807	MAINTENANCE	2.0 16v 103kw RFJ (...-05)	Body Computer BSI
 807	MAINTENANCE	2.0 16v 103kw RFJ (...-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.0 16v 103kw RFJ (...-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.0 16v 103kw RFJ (...-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.0 16v 103kw RFJ (...-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.0 16v 103kw RFJ (...-05)	BOSCH ESP 5.7
 807	MAINTENANCE	2.0 16v 103kw RFJ (...-05)	BOSCH ESP 5.7
 807	MAINTENANCE	2.0 16v 103kw RFJ (...-05)	BTO_MM

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 807	MAINTENANCE	2.0 16v 103kw RFJ (.-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.0 16v 103kw RFJ (.-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.0 16v 103kw RFJ (.-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.0 16v 103kw RFJ (.-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.0 16v 103kw RFJ (.-05)	Var.1
 807	MAINTENANCE	2.0 16v 103kw RFJ (.-05)	Var.1
 807	MAINTENANCE	2.0 16v 103kw RFJ (.-05)	Var.1
 807	MAINTENANCE	2.0 16v 103kw RFJ (.-05)	Var.1
 807	MAINTENANCE	2.0 16v 103kw RFJ (.-05)	Var.2
 807	MAINTENANCE	2.0 16v 103kw RFJ (.-05)	Var.2
 807	MAINTENANCE	2.0 16v 103kw RFJ (.-05)	Var.2
 807	MAINTENANCE	2.0 16v 103kw RFJ (.-05)	Var.2
 807	MAINTENANCE	2.0 16v 103kw RFJ (.-05)	Var.3
 807	MAINTENANCE	2.0 16v 103kw RFJ (.-05)	Var.4
 807	MAINTENANCE	2.0 16v 103kw RFJ (.-05)	Var.7
 807	MAINTENANCE	2.0 16v 103kw RFJ (05-..)	Marelli
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR (.-05)	
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR (.-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR (.-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR (.-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR (.-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (.-05)	
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (.-05)	A/T AM6
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (.-05)	A/T AM6
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (.-05)	AirBag CENTRAL
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (.-05)	AirBag CENTRAL
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (.-05)	Body Computer BSI
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (.-05)	Body Computer BSI
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (.-05)	Body Computer BSI
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (.-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (.-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (.-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (.-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (.-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (.-05)	BOSCH ESP 5.7
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (.-05)	BOSCH ESP 5.7
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (.-05)	BTO_MM
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (.-05)	Var.1
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (.-05)	Var.1
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (.-05)	Var.1
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (.-05)	Var.1
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (.-05)	Var.2
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (.-05)	Var.2
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (.-05)	Var.2
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (.-05)	Var.2
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (.-05)	Var.2
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (.-05)	Var.3
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (.-05)	Var.4
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (.-05)	Var.7
 807	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (05-..)	Marelli
 807	MAINTENANCE	2.0 HDI 16v 79kw RHM-FAP (.-05)	
 807	MAINTENANCE	2.0 HDI 16v 79kw RHM-FAP (.-05)	
 807	MAINTENANCE	2.0 HDI 16v 79kw RHM-FAP (.-05)	A/T AM6
 807	MAINTENANCE	2.0 HDI 16v 79kw RHM-FAP (.-05)	A/T AM6
 807	MAINTENANCE	2.0 HDI 16v 79kw RHM-FAP (.-05)	AirBag CENTRAL
 807	MAINTENANCE	2.0 HDI 16v 79kw RHM-FAP (.-05)	AirBag CENTRAL
 807	MAINTENANCE	2.0 HDI 16v 79kw RHM-FAP (.-05)	Body Computer BSI
 807	MAINTENANCE	2.0 HDI 16v 79kw RHM-FAP (.-05)	Body Computer BSI
 807	MAINTENANCE	2.0 HDI 16v 79kw RHM-FAP (.-05)	Body Computer BSI

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

[illegible]

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 807	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...05)	Var.1
 807	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...05)	Var.1
 807	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...05)	Var.1
 807	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...05)	Var.1
 807	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...05)	Var.1
 807	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...05)	Var.1
 807	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...05)	Var.1
 807	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...05)	Var.1
 807	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...05)	Var.2
 807	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...05)	Var.2
 807	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...05)	Var.2
 807	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...05)	Var.2
 807	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...05)	Var.2
 807	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...05)	Var.2
 807	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...05)	Var.2
 807	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...05)	Var.2
 807	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...05)	Var.2
 807	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...05)	Var.3
 807	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...05)	Var.4
 807	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (...05)	Var.7
 807	MAINTENANCE	2.0 HDI 16v 79kw RHT-FAP (05-..)	Marelli
 807	MAINTENANCE	2.0 HDI 16v 80kw RHW (...05)	
 807	MAINTENANCE	2.0 HDI 16v 80kw RHW (...05)	
 807	MAINTENANCE	2.0 HDI 16v 80kw RHW (...05)	A/T AM6
 807	MAINTENANCE	2.0 HDI 16v 80kw RHW (...05)	A/T AM6
 807	MAINTENANCE	2.0 HDI 16v 80kw RHW (...05)	AirBag CENTRAL
 807	MAINTENANCE	2.0 HDI 16v 80kw RHW (...05)	AirBag CENTRAL
 807	MAINTENANCE	2.0 HDI 16v 80kw RHW (...05)	Body Computer BSI
 807	MAINTENANCE	2.0 HDI 16v 80kw RHW (...05)	Body Computer BSI
 807	MAINTENANCE	2.0 HDI 16v 80kw RHW (...05)	Body Computer BSI
 807	MAINTENANCE	2.0 HDI 16v 80kw RHW (...05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.0 HDI 16v 80kw RHW (...05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.0 HDI 16v 80kw RHW (...05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.0 HDI 16v 80kw RHW (...05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.0 HDI 16v 80kw RHW (...05)	BOSCH EDC 15 C2 Common Rail
 807	MAINTENANCE	2.0 HDI 16v 80kw RHW (...05)	BOSCH ESP 5.7
 807	MAINTENANCE	2.0 HDI 16v 80kw RHW (...05)	BOSCH ESP 5.7
 807	MAINTENANCE	2.0 HDI 16v 80kw RHW (...05)	BTO_MM
 807	MAINTENANCE	2.0 HDI 16v 80kw RHW (...05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.0 HDI 16v 80kw RHW (...05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.0 HDI 16v 80kw RHW (...05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.0 HDI 16v 80kw RHW (...05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.0 HDI 16v 80kw RHW (...05)	Var.1
 807	MAINTENANCE	2.0 HDI 16v 80kw RHW (...05)	Var.1
 807	MAINTENANCE	2.0 HDI 16v 80kw RHW (...05)	Var.1
 807	MAINTENANCE	2.0 HDI 16v 80kw RHW (...05)	Var.1
 807	MAINTENANCE	2.0 HDI 16v 80kw RHW (...05)	Var.2
 807	MAINTENANCE	2.0 HDI 16v 80kw RHW (...05)	Var.2
 807	MAINTENANCE	2.0 HDI 16v 80kw RHW (...05)	Var.2
 807	MAINTENANCE	2.0 HDI 16v 80kw RHW (...05)	Var.2
 807	MAINTENANCE	2.0 HDI 16v 80kw RHW (...05)	Var.3
 807	MAINTENANCE	2.0 HDI 16v 80kw RHW (...05)	Var.4
 807	MAINTENANCE	2.0 HDI 16v 80kw RHW (05-..)	Marelli
 807	MAINTENANCE	2.0 HDI 16v 88kw RHK (...05)	
 807	MAINTENANCE	2.0 HDI 16v 88kw RHK (...05)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 807	MAINTENANCE	2.0 HDI 16v 88kw RHK (...-05)	A/T AM6
 807	MAINTENANCE	2.0 HDI 16v 88kw RHK (...-05)	A/T AM6
 807	MAINTENANCE	2.0 HDI 16v 88kw RHK (...-05)	AirBag CENTRAL
 807	MAINTENANCE	2.0 HDI 16v 88kw RHK (...-05)	AirBag CENTRAL
 807	MAINTENANCE	2.0 HDI 16v 88kw RHK (...-05)	Body Computer BSI
 807	MAINTENANCE	2.0 HDI 16v 88kw RHK (...-05)	Body Computer BSI
 807	MAINTENANCE	2.0 HDI 16v 88kw RHK (...-05)	Body Computer BSI
 807	MAINTENANCE	2.0 HDI 16v 88kw RHK (...-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.0 HDI 16v 88kw RHK (...-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.0 HDI 16v 88kw RHK (...-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.0 HDI 16v 88kw RHK (...-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.0 HDI 16v 88kw RHK (...-05)	BOSCH ESP 5.7
 807	MAINTENANCE	2.0 HDI 16v 88kw RHK (...-05)	BOSCH ESP 5.7
 807	MAINTENANCE	2.0 HDI 16v 88kw RHK (...-05)	BTO_MM
 807	MAINTENANCE	2.0 HDI 16v 88kw RHK (...-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.0 HDI 16v 88kw RHK (...-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.0 HDI 16v 88kw RHK (...-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.0 HDI 16v 88kw RHK (...-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.0 HDI 16v 88kw RHK (...-05)	Var.1
 807	MAINTENANCE	2.0 HDI 16v 88kw RHK (...-05)	Var.1
 807	MAINTENANCE	2.0 HDI 16v 88kw RHK (...-05)	Var.1
 807	MAINTENANCE	2.0 HDI 16v 88kw RHK (...-05)	Var.1
 807	MAINTENANCE	2.0 HDI 16v 88kw RHK (...-05)	Var.2
 807	MAINTENANCE	2.0 HDI 16v 88kw RHK (...-05)	Var.2
 807	MAINTENANCE	2.0 HDI 16v 88kw RHK (...-05)	Var.2
 807	MAINTENANCE	2.0 HDI 16v 88kw RHK (...-05)	Var.2
 807	MAINTENANCE	2.0 HDI 16v 88kw RHK (...-05)	Var.2
 807	MAINTENANCE	2.0 HDI 16v 88kw RHK (...-05)	Var.3
 807	MAINTENANCE	2.0 HDI 16v 88kw RHK (...-05)	Var.4
 807	MAINTENANCE	2.0 HDI 16v 88kw RHK (05-..)	Marelli
 807	MAINTENANCE	2.2 16v 118kw 3FZ (...-05)	
 807	MAINTENANCE	2.2 16v 118kw 3FZ (...-05)	
 807	MAINTENANCE	2.2 16v 118kw 3FZ (...-05)	A/T AM6
 807	MAINTENANCE	2.2 16v 118kw 3FZ (...-05)	A/T AM6
 807	MAINTENANCE	2.2 16v 118kw 3FZ (...-05)	AirBag CENTRAL
 807	MAINTENANCE	2.2 16v 118kw 3FZ (...-05)	AirBag CENTRAL
 807	MAINTENANCE	2.2 16v 118kw 3FZ (...-05)	Body Computer BSI
 807	MAINTENANCE	2.2 16v 118kw 3FZ (...-05)	Body Computer BSI
 807	MAINTENANCE	2.2 16v 118kw 3FZ (...-05)	Body Computer BSI
 807	MAINTENANCE	2.2 16v 118kw 3FZ (...-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.2 16v 118kw 3FZ (...-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.2 16v 118kw 3FZ (...-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.2 16v 118kw 3FZ (...-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.2 16v 118kw 3FZ (...-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.2 16v 118kw 3FZ (...-05)	BOSCH ESP 5.7
 807	MAINTENANCE	2.2 16v 118kw 3FZ (...-05)	BOSCH ESP 5.7
 807	MAINTENANCE	2.2 16v 118kw 3FZ (...-05)	BTO_MM
 807	MAINTENANCE	2.2 16v 118kw 3FZ (...-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.2 16v 118kw 3FZ (...-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.2 16v 118kw 3FZ (...-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.2 16v 118kw 3FZ (...-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.2 16v 118kw 3FZ (...-05)	Var.1
 807	MAINTENANCE	2.2 16v 118kw 3FZ (...-05)	Var.1
 807	MAINTENANCE	2.2 16v 118kw 3FZ (...-05)	Var.1
 807	MAINTENANCE	2.2 16v 118kw 3FZ (...-05)	Var.1
 807	MAINTENANCE	2.2 16v 118kw 3FZ (...-05)	Var.2
 807	MAINTENANCE	2.2 16v 118kw 3FZ (...-05)	Var.2
 807	MAINTENANCE	2.2 16v 118kw 3FZ (...-05)	Var.2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 807	MAINTENANCE	2.2 16v 118kw 3FZ (.-05)	Var.2
 807	MAINTENANCE	2.2 16v 118kw 3FZ (.-05)	Var.3
 807	MAINTENANCE	2.2 16v 118kw 3FZ (.-05)	Var.4
 807	MAINTENANCE	2.2 16v 118kw 3FZ (05-..)	Marelli
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HP (.-05)	
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HP (.-05)	
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HP (.-05)	A/T AM6
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HP (.-05)	A/T AM6
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HP (.-05)	AirBag CENTRAL
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HP (.-05)	AirBag CENTRAL
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HP (.-05)	Body Computer BSI
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HP (.-05)	Body Computer BSI
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HP (.-05)	Body Computer BSI
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HP (.-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HP (.-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HP (.-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HP (.-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HP (.-05)	BOSCH ESP 5.7
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HP (.-05)	BOSCH ESP 5.7
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HP (.-05)	BTO_MM
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HP (.-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HP (.-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HP (.-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HP (.-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HP (.-05)	Var.1
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HP (.-05)	Var.1
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HP (.-05)	Var.1
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HP (.-05)	Var.1
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HP (.-05)	Var.2
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HP (.-05)	Var.2
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HP (.-05)	Var.2
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HP (.-05)	Var.2
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HP (.-05)	Var.2
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HP (.-05)	Var.3
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HP (.-05)	Var.4
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HP (05-..)	Marelli
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HR (.-05)	
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HR (.-05)	
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HR (.-05)	A/T AM6
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HR (.-05)	A/T AM6
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HR (.-05)	AirBag CENTRAL
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HR (.-05)	AirBag CENTRAL
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HR (.-05)	Body Computer BSI
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HR (.-05)	Body Computer BSI
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HR (.-05)	Body Computer BSI
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HR (.-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HR (.-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HR (.-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HR (.-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HR (.-05)	BOSCH ESP 5.7
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HR (.-05)	BOSCH ESP 5.7
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HR (.-05)	BTO_MM
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HR (.-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HR (.-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HR (.-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HR (.-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HR (.-05)	Var.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HR (.-05)	Var.1
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HR (.-05)	Var.1
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HR (.-05)	Var.1
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HR (.-05)	Var.2
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HR (.-05)	Var.2
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HR (.-05)	Var.2
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HR (.-05)	Var.2
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HR (.-05)	Var.3
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HR (.-05)	Var.4
 807	MAINTENANCE	2.2 HDI 16v 120kw 4HR (05-..)	Marelli
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP (.-05)	
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP (.-05)	
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP (.-05)	A/T AM6
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP (.-05)	A/T AM6
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP (.-05)	AirBag CENTRAL
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP (.-05)	AirBag CENTRAL
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP (.-05)	Body Computer BSI
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP (.-05)	Body Computer BSI
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP (.-05)	Body Computer BSI
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP (.-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP (.-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP (.-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP (.-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP (.-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP (.-05)	BOSCH ESP 5.7
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP (.-05)	BOSCH ESP 5.7
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP (.-05)	BTO_MM
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP (.-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP (.-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP (.-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP (.-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP (.-05)	Var.1
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP (.-05)	Var.1
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP (.-05)	Var.1
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP (.-05)	Var.1
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP (.-05)	Var.2
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP (.-05)	Var.2
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP (.-05)	Var.2
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP (.-05)	Var.2
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP (.-05)	Var.3
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP (.-05)	Var.4
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HS-FAP (05-..)	Marelli
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (.-05)	
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (.-05)	
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (.-05)	A/T AM6
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (.-05)	A/T AM6
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (.-05)	AirBag CENTRAL
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (.-05)	AirBag CENTRAL
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (.-05)	Body Computer BSI
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (.-05)	Body Computer BSI
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (.-05)	Body Computer BSI
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (.-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (.-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (.-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (.-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (.-05)	BOSCH ESP 5.7
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (.-05)	BOSCH ESP 5.7

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (..-05)	BTO_MM
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (..-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (..-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (..-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (..-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (..-05)	Var.1
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (..-05)	Var.1
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (..-05)	Var.1
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (..-05)	Var.1
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (..-05)	Var.2
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (..-05)	Var.2
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (..-05)	Var.2
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (..-05)	Var.2
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (..-05)	Var.3
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (..-05)	Var.4
 807	MAINTENANCE	2.2 HDI 16v 125kw 4HT-FAP (05-..)	Marelli
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	A/T AM6
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	A/T AM6
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	AirBag CENTRAL
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	AirBag CENTRAL
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Body Computer BSI
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Body Computer BSI
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Body Computer BSI
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	BOSCH EDC 15 C2 Common Rail
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	BOSCH EDC 15 C2 Common Rail
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	BOSCH ESP 5.7
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	BOSCH ESP 5.7
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	BTO_MM
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Var.1
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Var.1
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Var.1
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Var.1
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Var.1
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Var.1
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Var.1
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Var.1
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Var.2
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Var.2
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Var.2
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Var.2
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Var.2
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Var.2
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Var.2
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Var.2
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Var.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.4
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.7
 807	MAINTENANCE	2.2 HDI 16v 94kw 4HW-FAP (05-...)	Marelli
 807	MAINTENANCE	2.2 HDI 16v 94kw XFW (05-...)	Marelli
 807	MAINTENANCE	3.0 V6 24v 150kw XFW (...-05)	
 807	MAINTENANCE	3.0 V6 24v 150kw XFW (...-05)	
 807	MAINTENANCE	3.0 V6 24v 150kw XFW (...-05)	A/T AM6
 807	MAINTENANCE	3.0 V6 24v 150kw XFW (...-05)	A/T AM6
 807	MAINTENANCE	3.0 V6 24v 150kw XFW (...-05)	AirBag CENTRAL
 807	MAINTENANCE	3.0 V6 24v 150kw XFW (...-05)	AirBag CENTRAL
 807	MAINTENANCE	3.0 V6 24v 150kw XFW (...-05)	Body Computer BSI
 807	MAINTENANCE	3.0 V6 24v 150kw XFW (...-05)	Body Computer BSI
 807	MAINTENANCE	3.0 V6 24v 150kw XFW (...-05)	Body Computer BSI
 807	MAINTENANCE	3.0 V6 24v 150kw XFW (...-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	3.0 V6 24v 150kw XFW (...-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	3.0 V6 24v 150kw XFW (...-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	3.0 V6 24v 150kw XFW (...-05)	BOSCH ABS/ESP 5.7
 807	MAINTENANCE	3.0 V6 24v 150kw XFW (...-05)	BOSCH ESP 5.7
 807	MAINTENANCE	3.0 V6 24v 150kw XFW (...-05)	BOSCH ESP 5.7
 807	MAINTENANCE	3.0 V6 24v 150kw XFW (...-05)	BTO_MM
 807	MAINTENANCE	3.0 V6 24v 150kw XFW (...-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	3.0 V6 24v 150kw XFW (...-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	3.0 V6 24v 150kw XFW (...-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	3.0 V6 24v 150kw XFW (...-05)	Siemens-JCAE AUTODETECT
 807	MAINTENANCE	3.0 V6 24v 150kw XFW (...-05)	Var.1
 807	MAINTENANCE	3.0 V6 24v 150kw XFW (...-05)	Var.1
 807	MAINTENANCE	3.0 V6 24v 150kw XFW (...-05)	Var.1
 807	MAINTENANCE	3.0 V6 24v 150kw XFW (...-05)	Var.1
 807	MAINTENANCE	3.0 V6 24v 150kw XFW (...-05)	Var.2
 807	MAINTENANCE	3.0 V6 24v 150kw XFW (...-05)	Var.2
 807	MAINTENANCE	3.0 V6 24v 150kw XFW (...-05)	Var.2
 807	MAINTENANCE	3.0 V6 24v 150kw XFW (...-05)	Var.2
 807	MAINTENANCE	3.0 V6 24v 150kw XFW (...-05)	Var.2
 807	MAINTENANCE	3.0 V6 24v 150kw XFW (...-05)	Var.3
 807	MAINTENANCE	3.0 V6 24v 150kw XFW (...-05)	Var.7
 807	PARKING HELP	2.0 16v 100kw RFN (...-05)	VALEO
 807	PARKING HELP	2.0 16v 100kw RFN (...-05)	Var.1
 807	PARKING HELP	2.0 16v 100kw RFN (...-05)	Var.2
 807	PARKING HELP	2.0 16v 100kw RFN (...-05)	Var.3
 807	PARKING HELP	2.0 16v 100kw RFN (...-05)	Var.4
 807	PARKING HELP	2.0 16v 103kw RFJ (...-05)	VALEO
 807	PARKING HELP	2.0 16v 103kw RFJ (...-05)	Var.1
 807	PARKING HELP	2.0 16v 103kw RFJ (...-05)	Var.2
 807	PARKING HELP	2.0 16v 103kw RFJ (...-05)	Var.3
 807	PARKING HELP	2.0 16v 103kw RFJ (...-05)	Var.4
 807	PARKING HELP	2.0 HDI 16v 100kw RHR-FAP (...-05)	VALEO
 807	PARKING HELP	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.1
 807	PARKING HELP	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.2
 807	PARKING HELP	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.3
 807	PARKING HELP	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.4
 807	PARKING HELP	2.0 HDI 16v 79kw RHM-FAP (...-05)	VALEO
 807	PARKING HELP	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.1
 807	PARKING HELP	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.2
 807	PARKING HELP	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.3
 807	PARKING HELP	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.4
 807	PARKING HELP	2.0 HDI 16v 79kw RHT-FAP (...-05)	VALEO
 807	PARKING HELP	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.1
 807	PARKING HELP	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 807	PARKING HELP	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.3
 807	PARKING HELP	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.4
 807	PARKING HELP	2.0 HDI 16v 80kw RHW (...-05)	VALEO
 807	PARKING HELP	2.0 HDI 16v 80kw RHW (...-05)	Var.1
 807	PARKING HELP	2.0 HDI 16v 80kw RHW (...-05)	Var.2
 807	PARKING HELP	2.0 HDI 16v 80kw RHW (...-05)	Var.3
 807	PARKING HELP	2.0 HDI 16v 80kw RHW (...-05)	Var.4
 807	PARKING HELP	2.0 HDI 16v 88kw RHK (...-05)	VALEO
 807	PARKING HELP	2.0 HDI 16v 88kw RHK (...-05)	Var.1
 807	PARKING HELP	2.0 HDI 16v 88kw RHK (...-05)	Var.2
 807	PARKING HELP	2.0 HDI 16v 88kw RHK (...-05)	Var.3
 807	PARKING HELP	2.0 HDI 16v 88kw RHK (...-05)	Var.4
 807	PARKING HELP	2.2 16v 118kw 3FZ (...-05)	VALEO
 807	PARKING HELP	2.2 16v 118kw 3FZ (...-05)	Var.1
 807	PARKING HELP	2.2 16v 118kw 3FZ (...-05)	Var.2
 807	PARKING HELP	2.2 16v 118kw 3FZ (...-05)	Var.3
 807	PARKING HELP	2.2 16v 118kw 3FZ (...-05)	Var.4
 807	PARKING HELP	2.2 HDI 16v 120kw 4HP (...-05)	VALEO
 807	PARKING HELP	2.2 HDI 16v 120kw 4HP (...-05)	Var.1
 807	PARKING HELP	2.2 HDI 16v 120kw 4HP (...-05)	Var.2
 807	PARKING HELP	2.2 HDI 16v 120kw 4HP (...-05)	Var.3
 807	PARKING HELP	2.2 HDI 16v 120kw 4HP (...-05)	Var.4
 807	PARKING HELP	2.2 HDI 16v 120kw 4HR (...-05)	VALEO
 807	PARKING HELP	2.2 HDI 16v 120kw 4HR (...-05)	Var.1
 807	PARKING HELP	2.2 HDI 16v 120kw 4HR (...-05)	Var.2
 807	PARKING HELP	2.2 HDI 16v 120kw 4HR (...-05)	Var.3
 807	PARKING HELP	2.2 HDI 16v 120kw 4HR (...-05)	Var.4
 807	PARKING HELP	2.2 HDI 16v 125kw 4HS-FAP (...-05)	VALEO
 807	PARKING HELP	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.1
 807	PARKING HELP	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.2
 807	PARKING HELP	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.3
 807	PARKING HELP	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.4
 807	PARKING HELP	2.2 HDI 16v 125kw 4HT-FAP (...-05)	VALEO
 807	PARKING HELP	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.1
 807	PARKING HELP	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.2
 807	PARKING HELP	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.3
 807	PARKING HELP	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.4
 807	PARKING HELP	2.2 HDI 16v 94kw 4HW-FAP (...-05)	VALEO
 807	PARKING HELP	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.1
 807	PARKING HELP	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.2
 807	PARKING HELP	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.3
 807	PARKING HELP	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.4
 807	PARKING HELP	3.0 V6 24v 150kw XFW (...-05)	VALEO
 807	PARKING HELP	3.0 V6 24v 150kw XFW (...-05)	Var.1
 807	PARKING HELP	3.0 V6 24v 150kw XFW (...-05)	Var.2
 807	PARKING HELP	3.0 V6 24v 150kw XFW (...-05)	Var.3
 807	PARKING HELP	3.0 V6 24v 150kw XFW (...-05)	Var.4
 807	PASS. SIDE DOOR	2.0 16v 100kw RFN (...-05)	Marelli MTP PASS
 807	PASS. SIDE DOOR	2.0 16v 100kw RFN (...-05)	Var.1
 807	PASS. SIDE DOOR	2.0 16v 100kw RFN (...-05)	Var.2
 807	PASS. SIDE DOOR	2.0 16v 100kw RFN (...-05)	Var.3
 807	PASS. SIDE DOOR	2.0 16v 100kw RFN (...-05)	Var.4
 807	PASS. SIDE DOOR	2.0 16v 103kw RFJ (...-05)	Marelli MTP PASS
 807	PASS. SIDE DOOR	2.0 16v 103kw RFJ (...-05)	Var.1
 807	PASS. SIDE DOOR	2.0 16v 103kw RFJ (...-05)	Var.2
 807	PASS. SIDE DOOR	2.0 16v 103kw RFJ (...-05)	Var.3
 807	PASS. SIDE DOOR	2.0 16v 103kw RFJ (...-05)	Var.4
 807	PASS. SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP (...-05)	Marelli MTP PASS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 807	PASS. SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.1
 807	PASS. SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.2
 807	PASS. SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.3
 807	PASS. SIDE DOOR	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.4
 807	PASS. SIDE DOOR	2.0 HDI 16v 79kw RHM-FAP (...-05)	Marelli MTP PASS
 807	PASS. SIDE DOOR	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.1
 807	PASS. SIDE DOOR	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.2
 807	PASS. SIDE DOOR	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.3
 807	PASS. SIDE DOOR	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.4
 807	PASS. SIDE DOOR	2.0 HDI 16v 79kw RHT-FAP (...-05)	Marelli MTP PASS
 807	PASS. SIDE DOOR	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.1
 807	PASS. SIDE DOOR	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.2
 807	PASS. SIDE DOOR	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.3
 807	PASS. SIDE DOOR	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.4
 807	PASS. SIDE DOOR	2.0 HDI 16v 80kw RHW (...-05)	Marelli MTP PASS
 807	PASS. SIDE DOOR	2.0 HDI 16v 80kw RHW (...-05)	Var.1
 807	PASS. SIDE DOOR	2.0 HDI 16v 80kw RHW (...-05)	Var.2
 807	PASS. SIDE DOOR	2.0 HDI 16v 80kw RHW (...-05)	Var.3
 807	PASS. SIDE DOOR	2.0 HDI 16v 80kw RHW (...-05)	Var.4
 807	PASS. SIDE DOOR	2.0 HDI 16v 88kw RHK (...-05)	Marelli MTP PASS
 807	PASS. SIDE DOOR	2.0 HDI 16v 88kw RHK (...-05)	Var.1
 807	PASS. SIDE DOOR	2.0 HDI 16v 88kw RHK (...-05)	Var.2
 807	PASS. SIDE DOOR	2.0 HDI 16v 88kw RHK (...-05)	Var.3
 807	PASS. SIDE DOOR	2.0 HDI 16v 88kw RHK (...-05)	Var.4
 807	PASS. SIDE DOOR	2.2 16v 118kw 3FZ (...-05)	Marelli MTP PASS
 807	PASS. SIDE DOOR	2.2 16v 118kw 3FZ (...-05)	Var.1
 807	PASS. SIDE DOOR	2.2 16v 118kw 3FZ (...-05)	Var.2
 807	PASS. SIDE DOOR	2.2 16v 118kw 3FZ (...-05)	Var.3
 807	PASS. SIDE DOOR	2.2 16v 118kw 3FZ (...-05)	Var.4
 807	PASS. SIDE DOOR	2.2 HDI 16v 120kw 4HP (...-05)	Marelli MTP PASS
 807	PASS. SIDE DOOR	2.2 HDI 16v 120kw 4HP (...-05)	Var.1
 807	PASS. SIDE DOOR	2.2 HDI 16v 120kw 4HP (...-05)	Var.2
 807	PASS. SIDE DOOR	2.2 HDI 16v 120kw 4HP (...-05)	Var.3
 807	PASS. SIDE DOOR	2.2 HDI 16v 120kw 4HP (...-05)	Var.4
 807	PASS. SIDE DOOR	2.2 HDI 16v 120kw 4HR (...-05)	Marelli MTP PASS
 807	PASS. SIDE DOOR	2.2 HDI 16v 120kw 4HR (...-05)	Var.1
 807	PASS. SIDE DOOR	2.2 HDI 16v 120kw 4HR (...-05)	Var.2
 807	PASS. SIDE DOOR	2.2 HDI 16v 120kw 4HR (...-05)	Var.3
 807	PASS. SIDE DOOR	2.2 HDI 16v 120kw 4HR (...-05)	Var.4
 807	PASS. SIDE DOOR	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Marelli MTP PASS
 807	PASS. SIDE DOOR	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.1
 807	PASS. SIDE DOOR	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.2
 807	PASS. SIDE DOOR	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.3
 807	PASS. SIDE DOOR	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.4
 807	PASS. SIDE DOOR	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Marelli MTP PASS
 807	PASS. SIDE DOOR	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.1
 807	PASS. SIDE DOOR	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.2
 807	PASS. SIDE DOOR	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.3
 807	PASS. SIDE DOOR	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.4
 807	PASS. SIDE DOOR	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Marelli MTP PASS
 807	PASS. SIDE DOOR	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.1
 807	PASS. SIDE DOOR	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.2
 807	PASS. SIDE DOOR	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.3
 807	PASS. SIDE DOOR	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.4
 807	PASS. SIDE DOOR	3.0 V6 24v 150kw XFW (...-05)	Marelli MTP PASS
 807	PASS. SIDE DOOR	3.0 V6 24v 150kw XFW (...-05)	Var.1
 807	PASS. SIDE DOOR	3.0 V6 24v 150kw XFW (...-05)	Var.2
 807	PASS. SIDE DOOR	3.0 V6 24v 150kw XFW (...-05)	Var.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 807	PASS. SIDE DOOR	3.0 V6 24v 150kw XFW (...-05)	Var.4
 807	RADIO / CD	2.0 16v 100kw RFN (...-05)	CLARION AudioSystem
 807	RADIO / CD	2.0 16v 100kw RFN (...-05)	PHILIPS AudioSystem
 807	RADIO / CD	2.0 16v 100kw RFN (...-05)	Var.1
 807	RADIO / CD	2.0 16v 100kw RFN (...-05)	Var.2
 807	RADIO / CD	2.0 16v 100kw RFN (...-05)	Var.3
 807	RADIO / CD	2.0 16v 100kw RFN (...-05)	Var.4
 807	RADIO / CD	2.0 16v 100kw RFN (...-05)	Var.5
 807	RADIO / CD	2.0 16v 100kw RFN (...-05)	Var.6
 807	RADIO / CD	2.0 16v 100kw RFN (...-05)	Var.7
 807	RADIO / CD	2.0 16v 100kw RFN (...-05)	Var.8
 807	RADIO / CD	2.0 16v 100kw RFN (...-05)	VDO AudioSystem
 807	RADIO / CD	2.0 16v 103kw RFJ (...-05)	CLARION AudioSystem
 807	RADIO / CD	2.0 16v 103kw RFJ (...-05)	PHILIPS AudioSystem
 807	RADIO / CD	2.0 16v 103kw RFJ (...-05)	Var.1
 807	RADIO / CD	2.0 16v 103kw RFJ (...-05)	Var.2
 807	RADIO / CD	2.0 16v 103kw RFJ (...-05)	Var.3
 807	RADIO / CD	2.0 16v 103kw RFJ (...-05)	Var.4
 807	RADIO / CD	2.0 16v 103kw RFJ (...-05)	Var.5
 807	RADIO / CD	2.0 16v 103kw RFJ (...-05)	Var.6
 807	RADIO / CD	2.0 16v 103kw RFJ (...-05)	Var.7
 807	RADIO / CD	2.0 16v 103kw RFJ (...-05)	Var.8
 807	RADIO / CD	2.0 16v 103kw RFJ (...-05)	VDO AudioSystem
 807	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP (...-05)	CLARION AudioSystem
 807	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP (...-05)	PHILIPS AudioSystem
 807	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.1
 807	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.2
 807	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.3
 807	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.4
 807	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.5
 807	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.6
 807	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.7
 807	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP (...-05)	Var.8
 807	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP (...-05)	VDO AudioSystem
 807	RADIO / CD	2.0 HDI 16v 79kw RHM-FAP (...-05)	CLARION AudioSystem
 807	RADIO / CD	2.0 HDI 16v 79kw RHM-FAP (...-05)	PHILIPS AudioSystem
 807	RADIO / CD	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.1
 807	RADIO / CD	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.2
 807	RADIO / CD	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.3
 807	RADIO / CD	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.4
 807	RADIO / CD	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.5
 807	RADIO / CD	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.6
 807	RADIO / CD	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.7
 807	RADIO / CD	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.8
 807	RADIO / CD	2.0 HDI 16v 79kw RHM-FAP (...-05)	VDO AudioSystem
 807	RADIO / CD	2.0 HDI 16v 79kw RHT-FAP (...-05)	CLARION AudioSystem
 807	RADIO / CD	2.0 HDI 16v 79kw RHT-FAP (...-05)	PHILIPS AudioSystem
 807	RADIO / CD	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.1
 807	RADIO / CD	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.2
 807	RADIO / CD	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.3
 807	RADIO / CD	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.4
 807	RADIO / CD	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.5
 807	RADIO / CD	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.6
 807	RADIO / CD	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.7
 807	RADIO / CD	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.8
 807	RADIO / CD	2.0 HDI 16v 79kw RHT-FAP (...-05)	VDO AudioSystem
 807	RADIO / CD	2.0 HDI 16v 80kw RHW (...-05)	CLARION AudioSystem
 807	RADIO / CD	2.0 HDI 16v 80kw RHW (...-05)	PHILIPS AudioSystem

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 807	RADIO / CD	2.0 HDI 16v 80kw RHW (...-05)	Var.1
 807	RADIO / CD	2.0 HDI 16v 80kw RHW (...-05)	Var.2
 807	RADIO / CD	2.0 HDI 16v 80kw RHW (...-05)	Var.3
 807	RADIO / CD	2.0 HDI 16v 80kw RHW (...-05)	Var.4
 807	RADIO / CD	2.0 HDI 16v 80kw RHW (...-05)	Var.5
 807	RADIO / CD	2.0 HDI 16v 80kw RHW (...-05)	Var.6
 807	RADIO / CD	2.0 HDI 16v 80kw RHW (...-05)	Var.7
 807	RADIO / CD	2.0 HDI 16v 80kw RHW (...-05)	Var.8
 807	RADIO / CD	2.0 HDI 16v 80kw RHW (...-05)	VDO AudioSystem
 807	RADIO / CD	2.0 HDI 16v 88kw RHK (...-05)	CLARION AudioSystem
 807	RADIO / CD	2.0 HDI 16v 88kw RHK (...-05)	PHILIPS AudioSystem
 807	RADIO / CD	2.0 HDI 16v 88kw RHK (...-05)	Var.1
 807	RADIO / CD	2.0 HDI 16v 88kw RHK (...-05)	Var.2
 807	RADIO / CD	2.0 HDI 16v 88kw RHK (...-05)	Var.3
 807	RADIO / CD	2.0 HDI 16v 88kw RHK (...-05)	Var.4
 807	RADIO / CD	2.0 HDI 16v 88kw RHK (...-05)	Var.5
 807	RADIO / CD	2.0 HDI 16v 88kw RHK (...-05)	Var.6
 807	RADIO / CD	2.0 HDI 16v 88kw RHK (...-05)	Var.7
 807	RADIO / CD	2.0 HDI 16v 88kw RHK (...-05)	Var.8
 807	RADIO / CD	2.0 HDI 16v 88kw RHK (...-05)	VDO AudioSystem
 807	RADIO / CD	2.2 16v 118kw 3FZ (...-05)	CLARION AudioSystem
 807	RADIO / CD	2.2 16v 118kw 3FZ (...-05)	PHILIPS AudioSystem
 807	RADIO / CD	2.2 16v 118kw 3FZ (...-05)	Var.1
 807	RADIO / CD	2.2 16v 118kw 3FZ (...-05)	Var.2
 807	RADIO / CD	2.2 16v 118kw 3FZ (...-05)	Var.3
 807	RADIO / CD	2.2 16v 118kw 3FZ (...-05)	Var.4
 807	RADIO / CD	2.2 16v 118kw 3FZ (...-05)	Var.5
 807	RADIO / CD	2.2 16v 118kw 3FZ (...-05)	Var.6
 807	RADIO / CD	2.2 16v 118kw 3FZ (...-05)	Var.7
 807	RADIO / CD	2.2 16v 118kw 3FZ (...-05)	Var.8
 807	RADIO / CD	2.2 16v 118kw 3FZ (...-05)	VDO AudioSystem
 807	RADIO / CD	2.2 HDI 16v 120kw 4HP (...-05)	CLARION AudioSystem
 807	RADIO / CD	2.2 HDI 16v 120kw 4HP (...-05)	PHILIPS AudioSystem
 807	RADIO / CD	2.2 HDI 16v 120kw 4HP (...-05)	Var.1
 807	RADIO / CD	2.2 HDI 16v 120kw 4HP (...-05)	Var.2
 807	RADIO / CD	2.2 HDI 16v 120kw 4HP (...-05)	Var.3
 807	RADIO / CD	2.2 HDI 16v 120kw 4HP (...-05)	Var.4
 807	RADIO / CD	2.2 HDI 16v 120kw 4HP (...-05)	Var.5
 807	RADIO / CD	2.2 HDI 16v 120kw 4HP (...-05)	Var.6
 807	RADIO / CD	2.2 HDI 16v 120kw 4HP (...-05)	Var.7
 807	RADIO / CD	2.2 HDI 16v 120kw 4HP (...-05)	Var.8
 807	RADIO / CD	2.2 HDI 16v 120kw 4HP (...-05)	VDO AudioSystem
 807	RADIO / CD	2.2 HDI 16v 120kw 4HR (...-05)	CLARION AudioSystem
 807	RADIO / CD	2.2 HDI 16v 120kw 4HR (...-05)	PHILIPS AudioSystem
 807	RADIO / CD	2.2 HDI 16v 120kw 4HR (...-05)	Var.1
 807	RADIO / CD	2.2 HDI 16v 120kw 4HR (...-05)	Var.2
 807	RADIO / CD	2.2 HDI 16v 120kw 4HR (...-05)	Var.3
 807	RADIO / CD	2.2 HDI 16v 120kw 4HR (...-05)	Var.4
 807	RADIO / CD	2.2 HDI 16v 120kw 4HR (...-05)	Var.5
 807	RADIO / CD	2.2 HDI 16v 120kw 4HR (...-05)	Var.6
 807	RADIO / CD	2.2 HDI 16v 120kw 4HR (...-05)	Var.7
 807	RADIO / CD	2.2 HDI 16v 120kw 4HR (...-05)	Var.8
 807	RADIO / CD	2.2 HDI 16v 120kw 4HR (...-05)	VDO AudioSystem
 807	RADIO / CD	2.2 HDI 16v 125kw 4HS-FAP (...-05)	CLARION AudioSystem
 807	RADIO / CD	2.2 HDI 16v 125kw 4HS-FAP (...-05)	PHILIPS AudioSystem
 807	RADIO / CD	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.1
 807	RADIO / CD	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.2
 807	RADIO / CD	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 807	RADIO / CD	2.2 HDI 16v 125kw 4HS-FAP (..-05)	Var.4
 807	RADIO / CD	2.2 HDI 16v 125kw 4HS-FAP (..-05)	Var.5
 807	RADIO / CD	2.2 HDI 16v 125kw 4HS-FAP (..-05)	Var.6
 807	RADIO / CD	2.2 HDI 16v 125kw 4HS-FAP (..-05)	Var.7
 807	RADIO / CD	2.2 HDI 16v 125kw 4HS-FAP (..-05)	Var.8
 807	RADIO / CD	2.2 HDI 16v 125kw 4HS-FAP (..-05)	VDO AudioSystem
 807	RADIO / CD	2.2 HDI 16v 125kw 4HT-FAP (..-05)	CLARION AudioSystem
 807	RADIO / CD	2.2 HDI 16v 125kw 4HT-FAP (..-05)	PHILIPS AudioSystem
 807	RADIO / CD	2.2 HDI 16v 125kw 4HT-FAP (..-05)	Var.1
 807	RADIO / CD	2.2 HDI 16v 125kw 4HT-FAP (..-05)	Var.2
 807	RADIO / CD	2.2 HDI 16v 125kw 4HT-FAP (..-05)	Var.3
 807	RADIO / CD	2.2 HDI 16v 125kw 4HT-FAP (..-05)	Var.4
 807	RADIO / CD	2.2 HDI 16v 125kw 4HT-FAP (..-05)	Var.5
 807	RADIO / CD	2.2 HDI 16v 125kw 4HT-FAP (..-05)	Var.6
 807	RADIO / CD	2.2 HDI 16v 125kw 4HT-FAP (..-05)	Var.7
 807	RADIO / CD	2.2 HDI 16v 125kw 4HT-FAP (..-05)	Var.8
 807	RADIO / CD	2.2 HDI 16v 125kw 4HT-FAP (..-05)	VDO AudioSystem
 807	RADIO / CD	2.2 HDI 16v 94kw 4HW-FAP (..-05)	CLARION AudioSystem
 807	RADIO / CD	2.2 HDI 16v 94kw 4HW-FAP (..-05)	PHILIPS AudioSystem
 807	RADIO / CD	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Var.1
 807	RADIO / CD	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Var.2
 807	RADIO / CD	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Var.3
 807	RADIO / CD	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Var.4
 807	RADIO / CD	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Var.5
 807	RADIO / CD	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Var.6
 807	RADIO / CD	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Var.7
 807	RADIO / CD	2.2 HDI 16v 94kw 4HW-FAP (..-05)	Var.8
 807	RADIO / CD	2.2 HDI 16v 94kw 4HW-FAP (..-05)	VDO AudioSystem
 807	RADIO / CD	3.0 V6 24v 150kw XFW (..-05)	CLARION AudioSystem
 807	RADIO / CD	3.0 V6 24v 150kw XFW (..-05)	PHILIPS AudioSystem
 807	RADIO / CD	3.0 V6 24v 150kw XFW (..-05)	Var.1
 807	RADIO / CD	3.0 V6 24v 150kw XFW (..-05)	Var.2
 807	RADIO / CD	3.0 V6 24v 150kw XFW (..-05)	Var.3
 807	RADIO / CD	3.0 V6 24v 150kw XFW (..-05)	Var.4
 807	RADIO / CD	3.0 V6 24v 150kw XFW (..-05)	Var.5
 807	RADIO / CD	3.0 V6 24v 150kw XFW (..-05)	Var.6
 807	RADIO / CD	3.0 V6 24v 150kw XFW (..-05)	Var.7
 807	RADIO / CD	3.0 V6 24v 150kw XFW (..-05)	Var.8
 807	RADIO / CD	3.0 V6 24v 150kw XFW (..-05)	VDO AudioSystem
 807	RAIN-LUMINOSITY S	2.0 16v 100kw RFN (..-05)	Var.1
 807	RAIN-LUMINOSITY S	2.0 16v 100kw RFN (..-05)	Var.2
 807	RAIN-LUMINOSITY S	2.0 16v 103kw RFJ (..-05)	Var.1
 807	RAIN-LUMINOSITY S	2.0 16v 103kw RFJ (..-05)	Var.2
 807	RAIN-LUMINOSITY S	2.0 HDI 16v 100kw RHR-FAP (..-05)	Var.1
 807	RAIN-LUMINOSITY S	2.0 HDI 16v 100kw RHR-FAP (..-05)	Var.2
 807	RAIN-LUMINOSITY S	2.0 HDI 16v 79kw RHM-FAP (..-05)	Var.1
 807	RAIN-LUMINOSITY S	2.0 HDI 16v 79kw RHM-FAP (..-05)	Var.2
 807	RAIN-LUMINOSITY S	2.0 HDI 16v 79kw RHT-FAP (..-05)	Var.1
 807	RAIN-LUMINOSITY S	2.0 HDI 16v 79kw RHT-FAP (..-05)	Var.2
 807	RAIN-LUMINOSITY S	2.0 HDI 16v 80kw RHW (..-05)	Var.1
 807	RAIN-LUMINOSITY S	2.0 HDI 16v 80kw RHW (..-05)	Var.2
 807	RAIN-LUMINOSITY S	2.0 HDI 16v 88kw RHK (..-05)	Var.1
 807	RAIN-LUMINOSITY S	2.0 HDI 16v 88kw RHK (..-05)	Var.2
 807	RAIN-LUMINOSITY S	2.2 16v 118kw 3FZ (..-05)	Var.1
 807	RAIN-LUMINOSITY S	2.2 16v 118kw 3FZ (..-05)	Var.2
 807	RAIN-LUMINOSITY S	2.2 HDI 16v 120kw 4HP (..-05)	Var.1
 807	RAIN-LUMINOSITY S	2.2 HDI 16v 120kw 4HP (..-05)	Var.2
 807	RAIN-LUMINOSITY S	2.2 HDI 16v 120kw 4HR (..-05)	Var.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 807	RAIN-LUMINOSITY S	2.2 HDI 16v 120kw 4HR (...-05)	Var.2
 807	RAIN-LUMINOSITY S	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.1
 807	RAIN-LUMINOSITY S	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.2
 807	RAIN-LUMINOSITY S	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.1
 807	RAIN-LUMINOSITY S	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.2
 807	RAIN-LUMINOSITY S	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.1
 807	RAIN-LUMINOSITY S	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.2
 807	RAIN-LUMINOSITY S	3.0 V6 24v 150kw XFW (...-05)	Var.1
 807	RAIN-LUMINOSITY S	3.0 V6 24v 150kw XFW (...-05)	Var.2
 807	RH LIGHT MODULATI	2.0 16v 100kw RFN (...-05)	
 807	RH LIGHT MODULATI	2.0 16v 103kw RFJ (...-05)	
 807	RH LIGHT MODULATI	2.0 HDI 16v 100kw RHR (...-05)	
 807	RH LIGHT MODULATI	2.0 HDI 16v 79kw RHM-FAP (...-05)	
 807	RH LIGHT MODULATI	2.0 HDI 16v 79kw RHT-FAP (...-05)	
 807	RH LIGHT MODULATI	2.0 HDI 16v 80kw RHW (...-05)	
 807	RH LIGHT MODULATI	2.0 HDI 16v 88kw RHK (...-05)	
 807	RH LIGHT MODULATI	2.2 16v 118kw 3FZ (...-05)	
 807	RH LIGHT MODULATI	2.2 HDI 16v 120kw 4HP (...-05)	
 807	RH LIGHT MODULATI	2.2 HDI 16v 120kw 4HR (...-05)	
 807	RH LIGHT MODULATI	2.2 HDI 16v 125kw 4HS-FAP (...-05)	
 807	RH LIGHT MODULATI	2.2 HDI 16v 125kw 4HT-FAP (...-05)	
 807	RH LIGHT MODULATI	2.2 HDI 16v 94kw 4HW-FAP (...-05)	
 807	RH LIGHT MODULATI	3.0 V6 24v 150kw XFW (...-05)	
 807	STEERING COLUMN	2.0 16v 100kw RFN (...-05)	Var.1
 807	STEERING COLUMN	2.0 16v 100kw RFN (...-05)	Var.2
 807	STEERING COLUMN	2.0 16v 103kw RFJ (...-05)	Var.1
 807	STEERING COLUMN	2.0 16v 103kw RFJ (...-05)	Var.2
 807	STEERING COLUMN	2.0 HDI 16v 100kw RHR (...-05)	Var.1
 807	STEERING COLUMN	2.0 HDI 16v 100kw RHR (...-05)	Var.2
 807	STEERING COLUMN	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.1
 807	STEERING COLUMN	2.0 HDI 16v 79kw RHM-FAP (...-05)	Var.2
 807	STEERING COLUMN	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.1
 807	STEERING COLUMN	2.0 HDI 16v 79kw RHT-FAP (...-05)	Var.2
 807	STEERING COLUMN	2.0 HDI 16v 80kw RHW (...-05)	Var.1
 807	STEERING COLUMN	2.0 HDI 16v 80kw RHW (...-05)	Var.2
 807	STEERING COLUMN	2.0 HDI 16v 88kw RHK (...-05)	Var.1
 807	STEERING COLUMN	2.0 HDI 16v 88kw RHK (...-05)	Var.2
 807	STEERING COLUMN	2.2 16v 118kw 3FZ (...-05)	Var.1
 807	STEERING COLUMN	2.2 16v 118kw 3FZ (...-05)	Var.2
 807	STEERING COLUMN	2.2 HDI 16v 120kw 4HP (...-05)	Var.1
 807	STEERING COLUMN	2.2 HDI 16v 120kw 4HP (...-05)	Var.2
 807	STEERING COLUMN	2.2 HDI 16v 120kw 4HR (...-05)	Var.1
 807	STEERING COLUMN	2.2 HDI 16v 120kw 4HR (...-05)	Var.2
 807	STEERING COLUMN	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.1
 807	STEERING COLUMN	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Var.2
 807	STEERING COLUMN	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.1
 807	STEERING COLUMN	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Var.2
 807	STEERING COLUMN	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.1
 807	STEERING COLUMN	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Var.2
 807	STEERING COLUMN	3.0 V6 24v 150kw XFW (...-05)	Var.1
 807	STEERING COLUMN	3.0 V6 24v 150kw XFW (...-05)	Var.2
 807	SWITCHLIGHT MODU	2.0 16v 100kw RFN (...-05)	EATON COM 2000
 807	SWITCHLIGHT MODU	2.0 16v 103kw RFJ (...-05)	EATON COM 2000
 807	SWITCHLIGHT MODU	2.0 HDI 16v 100kw RHR-FAP (...-05)	EATON COM 2000
 807	SWITCHLIGHT MODU	2.0 HDI 16v 79kw RHM-FAP (...-05)	EATON COM 2000
 807	SWITCHLIGHT MODU	2.0 HDI 16v 79kw RHT-FAP (...-05)	EATON COM 2000
 807	SWITCHLIGHT MODU	2.0 HDI 16v 80kw RHW (...-05)	EATON COM 2000
 807	SWITCHLIGHT MODU	2.0 HDI 16v 88kw RHK (...-05)	EATON COM 2000

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 807	SWITCHLIGHT MODU	2.2 16v 118kw 3FZ (...-05)	EATON COM 2000
 807	SWITCHLIGHT MODU	2.2 HDI 16v 120kw 4HP (...-05)	EATON COM 2000
 807	SWITCHLIGHT MODU	2.2 HDI 16v 120kw 4HR (...-05)	EATON COM 2000
 807	SWITCHLIGHT MODU	2.2 HDI 16v 125kw 4HS-FAP (...-05)	EATON COM 2000
 807	SWITCHLIGHT MODU	2.2 HDI 16v 125kw 4HT-FAP (...-05)	EATON COM 2000
 807	SWITCHLIGHT MODU	2.2 HDI 16v 94kw 4HW-FAP (...-05)	EATON COM 2000
 807	SWITCHLIGHT MODU	3.0 V6 24v 150kw XFW (...-05)	EATON COM 2000
 807	TIRE PRESSURE	2.0 16v 100kw RFN (...-05)	Siemens-JCAE AUTODETECT
 807	TIRE PRESSURE	2.0 16v 103kw RFJ (...-05)	Siemens-JCAE AUTODETECT
 807	TIRE PRESSURE	2.0 HDI 16v 100kw RHR (...-05)	Siemens-JCAE AUTODETECT
 807	TIRE PRESSURE	2.0 HDI 16v 79kw RHM-FAP (...-05)	Siemens-JCAE AUTODETECT
 807	TIRE PRESSURE	2.0 HDI 16v 79kw RHT-FAP (...-05)	Siemens-JCAE AUTODETECT
 807	TIRE PRESSURE	2.0 HDI 16v 80kw RHW (...-05)	Siemens-JCAE AUTODETECT
 807	TIRE PRESSURE	2.0 HDI 16v 88kw RHK (...-05)	Siemens-JCAE AUTODETECT
 807	TIRE PRESSURE	2.2 16v 118kw 3FZ (...-05)	Siemens-JCAE AUTODETECT
 807	TIRE PRESSURE	2.2 HDI 16v 120kw 4HP (...-05)	Siemens-JCAE AUTODETECT
 807	TIRE PRESSURE	2.2 HDI 16v 120kw 4HR (...-05)	Siemens-JCAE AUTODETECT
 807	TIRE PRESSURE	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Siemens-JCAE AUTODETECT
 807	TIRE PRESSURE	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Siemens-JCAE AUTODETECT
 807	TIRE PRESSURE	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Siemens-JCAE AUTODETECT
 807	TIRE PRESSURE	3.0 V6 24v 150kw XFW (...-05)	Siemens-JCAE AUTODETECT
 807	VISUAL./TELEMATIC	2.0 16v 100kw RFN (...-05)	Display
 807	VISUAL./TELEMATIC	2.0 16v 100kw RFN (...-05)	Display C-
 807	VISUAL./TELEMATIC	2.0 16v 100kw RFN (...-05)	Display C- Color
 807	VISUAL./TELEMATIC	2.0 16v 103kw RFJ (...-05)	Display
 807	VISUAL./TELEMATIC	2.0 16v 103kw RFJ (...-05)	Display C-
 807	VISUAL./TELEMATIC	2.0 16v 103kw RFJ (...-05)	Display C- Color
 807	VISUAL./TELEMATIC	2.0 HDI 16v 100kw RHR-FAP (...-05)	Display
 807	VISUAL./TELEMATIC	2.0 HDI 16v 100kw RHR-FAP (...-05)	Display C-
 807	VISUAL./TELEMATIC	2.0 HDI 16v 100kw RHR-FAP (...-05)	Display C- Color
 807	VISUAL./TELEMATIC	2.0 HDI 16v 79kw RHM-FAP (...-05)	Display
 807	VISUAL./TELEMATIC	2.0 HDI 16v 79kw RHM-FAP (...-05)	Display C-
 807	VISUAL./TELEMATIC	2.0 HDI 16v 79kw RHM-FAP (...-05)	Display C- Color
 807	VISUAL./TELEMATIC	2.0 HDI 16v 79kw RHT-FAP (...-05)	Display
 807	VISUAL./TELEMATIC	2.0 HDI 16v 79kw RHT-FAP (...-05)	Display C-
 807	VISUAL./TELEMATIC	2.0 HDI 16v 79kw RHT-FAP (...-05)	Display C- Color
 807	VISUAL./TELEMATIC	2.0 HDI 16v 80kw RHW (...-05)	Display
 807	VISUAL./TELEMATIC	2.0 HDI 16v 80kw RHW (...-05)	Display C-
 807	VISUAL./TELEMATIC	2.0 HDI 16v 80kw RHW (...-05)	Display C- Color
 807	VISUAL./TELEMATIC	2.0 HDI 16v 88kw RHK (...-05)	Display
 807	VISUAL./TELEMATIC	2.0 HDI 16v 88kw RHK (...-05)	Display C-
 807	VISUAL./TELEMATIC	2.0 HDI 16v 88kw RHK (...-05)	Display C- Color
 807	VISUAL./TELEMATIC	2.2 16v 118kw 3FZ (...-05)	Display
 807	VISUAL./TELEMATIC	2.2 16v 118kw 3FZ (...-05)	Display C-
 807	VISUAL./TELEMATIC	2.2 16v 118kw 3FZ (...-05)	Display C- Color
 807	VISUAL./TELEMATIC	2.2 HDI 16v 120kw 4HP (...-05)	Display
 807	VISUAL./TELEMATIC	2.2 HDI 16v 120kw 4HP (...-05)	Display C-
 807	VISUAL./TELEMATIC	2.2 HDI 16v 120kw 4HP (...-05)	Display C- Color
 807	VISUAL./TELEMATIC	2.2 HDI 16v 120kw 4HR (...-05)	Display
 807	VISUAL./TELEMATIC	2.2 HDI 16v 120kw 4HR (...-05)	Display C-
 807	VISUAL./TELEMATIC	2.2 HDI 16v 120kw 4HR (...-05)	Display C- Color
 807	VISUAL./TELEMATIC	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Display
 807	VISUAL./TELEMATIC	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Display C-
 807	VISUAL./TELEMATIC	2.2 HDI 16v 125kw 4HS-FAP (...-05)	Display C- Color
 807	VISUAL./TELEMATIC	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Display
 807	VISUAL./TELEMATIC	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Display C-
 807	VISUAL./TELEMATIC	2.2 HDI 16v 125kw 4HT-FAP (...-05)	Display C- Color
 807	VISUAL./TELEMATIC	2.2 HDI 16v 94kw 4HW-FAP (...-05)	Display

Systems supported by ECUREADER / ECUDECODER (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 807	VISUAL./TELEMATIC	2.2 HDI 16v 94kw 4HW-FAP (.-05)	Display C-
 807	VISUAL./TELEMATIC	2.2 HDI 16v 94kw 4HW-FAP (.-05)	Display C- Color
 807	VISUAL./TELEMATIC	3.0 V6 24v 150kw XFW (.-05)	Display
 807	VISUAL./TELEMATIC	3.0 V6 24v 150kw XFW (.-05)	Display C-
 807	VISUAL./TELEMATIC	3.0 V6 24v 150kw XFW (.-05)	Display C- Color
 Bipper	ABS + TRACT. CONT	1.4 HDI 8HS	ABS BOSCH 8.1 AUTODETECT
 Bipper	ABS + TRACT. CONT	1.4 HDI 8HS	BOSCH ESP 8
 Bipper	ABS + TRACT. CONT	1.4 KfV	ABS BOSCH 8.1 AUTODETECT
 Bipper	ABS + TRACT. CONT	1.4 KfV	BOSCH ESP 8
 Bipper	AIRBAG	1.4 HDI 8HS	AUTOLIV AirBag CENTRAL AUTODETECT
 Bipper	AIRBAG	1.4 HDI 8HS	TRW SRS EP
 Bipper	AIRBAG	1.4 KfV	AUTOLIV AirBag CENTRAL AUTODETECT
 Bipper	AIRBAG	1.4 KfV	TRW SRS EP
 Bipper	AUTOM. TRANSMISSI	1.4 HDI 8HS	A/T MAP AUTODETECT
 Bipper	AUTOM. TRANSMISSI	1.4 KfV	A/T MAP AUTODETECT
 Bipper	CHASSIS NETWORK	1.4 HDI 8HS	Body Computer BSI AUTODETECT
 Bipper	CHASSIS NETWORK	1.4 HDI 8HS	DELPHI Body Computer
 Bipper	CHASSIS NETWORK	1.4 HDI 8HS	DELPHI Body Computer CAN Info
 Bipper	CHASSIS NETWORK	1.4 HDI 8HS	DELPHI EP
 Bipper	CHASSIS NETWORK	1.4 KfV	Body Computer BSI AUTODETECT
 Bipper	CHASSIS NETWORK	1.4 KfV	DELPHI Body Computer
 Bipper	CHASSIS NETWORK	1.4 KfV	DELPHI Body Computer CAN Info
 Bipper	CHASSIS NETWORK	1.4 KfV	DELPHI EP
 Bipper	DASHBOARD	1.4 (08-..)	Marelli Dashboard Comfort
 Bipper	DASHBOARD	1.4 HDI (08-..)	Marelli Dashboard Comfort
 Bipper	DASHBOARD	1.4 HDI 8HS	AUTODETECT
 Bipper	DASHBOARD	1.4 HDI 8HS	Marelli Dashboard Modale
 Bipper	DASHBOARD	1.4 KfV	AUTODETECT
 Bipper	DASHBOARD	1.4 KfV	Marelli Dashboard Modale
 Bipper	ENGINE MANAGEME	1.4 HDI 8HS	AUTODETECT
 Bipper	ENGINE MANAGEME	1.4 HDI 8HS	Marelli EDC 6F3
 Bipper	ENGINE MANAGEME	1.4 KfV	AUTODETECT
 Bipper	FAP OIL PARAMETER	1.4 HDI 8HS (08-..)	Marelli
 Bipper	MAINTENANCE	1.4 (08-..)	Marelli Dashboard
 Bipper	MAINTENANCE	1.4 (08-..)	Marelli Dashboard Comfort
 Bipper	MAINTENANCE	1.4 (08-..)	Marelli Dashboard Comfort
 Bipper	MAINTENANCE	1.4 (08-..)	Marelli Dashboard Comfort
 Bipper	MAINTENANCE	1.4 (09-..)	Marelli Dashboard
 Bipper	MAINTENANCE	1.4 HDI (08-..)	Marelli Dashboard
 Bipper	MAINTENANCE	1.4 HDI (08-..)	Marelli Dashboard Comfort
 Bipper	MAINTENANCE	1.4 HDI (08-..)	Marelli Dashboard Comfort
 Bipper	MAINTENANCE	1.4 HDI (08-..)	Marelli Dashboard Comfort
 Bipper	MAINTENANCE	1.4 HDI (09-..)	Marelli Dashboard
 Bipper	MAINTENANCE	1.4 HDI 8HS	BOSCH ESP 8
 Bipper	MAINTENANCE	1.4 HDI 8HS	Marelli Dashboard Modale
 Bipper	MAINTENANCE	1.4 HDI 8HS	Marelli Dashboard Modale
 Bipper	MAINTENANCE	1.4 HDI 8HS	Marelli EDC 6F3
 Bipper	MAINTENANCE	1.4 HDI 8HS (08-..)	Marelli
 Bipper	MAINTENANCE	1.4 KfV	BOSCH ESP 8
 Bipper	MAINTENANCE	1.4 KfV	Marelli Dashboard Modale
 Bipper	MAINTENANCE	1.4 KfV	Marelli Dashboard Modale
 Bipper	PARKING HELP	1.4 HDI 8HS	AUTODETECT
 Bipper	PARKING HELP	1.4 KfV	AUTODETECT
 Bipper	SERVICE LIGHT RES	1.4 (08-..)	Marelli Dashboard
 Bipper	SERVICE LIGHT RES	1.4 (09-..)	Marelli Dashboard
 Bipper	SERVICE LIGHT RES	1.4 HDI (08-..)	Marelli Dashboard
 Bipper	SERVICE LIGHT RES	1.4 HDI (09-..)	Marelli Dashboard
 Boxer 1 (94-06)	ABS	1.9 D 51kw D9B (94-02)	BOSCH ABS ABR 5.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Boxer 1 (94-06)	ABS	1.9 D 52kw DJY (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	ABS	1.9 TD 66kw DHX (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	ABS	1.9 TD 68kw D8C (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	ABS	2.0 81kw RFL (02-06)	BOSCH ABS 8
 Boxer 1 (94-06)	ABS	2.0 81kw RFL (02-06)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	ABS	2.0 81kw RFL (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	ABS	2.0 81kw RFW (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	ABS	2.0 HDI 63kw RHV	BOSCH ABS 5.3
 Boxer 1 (94-06)	ABS	2.2 HDI 74kw 4HY	BOSCH ABS 5.3
 Boxer 1 (94-06)	ABS	2.2 HDI 74kw 4HY (02-06)	BOSCH ABS 8
 Boxer 1 (94-06)	ABS	2.2 HDI 74kw 4HY (02-06)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	ABS	2.3 HDI 16v 81kw F1AE0481C (02-0	BOSCH ABS 8
 Boxer 1 (94-06)	ABS	2.3 HDI 16v 81kw F1AE0481C (02-0	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	ABS	2.5 D 63kw T9A (02-06)	BOSCH ABS 8
 Boxer 1 (94-06)	ABS	2.5 D 63kw T9A (02-06)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	ABS	2.5 D 63kw T9A (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	ABS	2.5 TD 12V 76kw T8A (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	ABS	2.5 TD 12V 76kw THZ (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	ABS	2.5 TDI 12v 79kw THX (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	ABS	2.8 D 64kw 8140.63 (02-06)	BOSCH ABS 8
 Boxer 1 (94-06)	ABS	2.8 D 64kw 8140.63 (02-06)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	ABS	2.8 HDI 108kw 43N (02-06)	BOSCH ABS 8
 Boxer 1 (94-06)	ABS	2.8 HDI 108kw 43N (02-06)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	ABS	2.8 HDI 90kw 43 (02-06)	BOSCH ABS 8
 Boxer 1 (94-06)	ABS	2.8 HDI 90kw 43 (02-06)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	ABS	2.8 HDI 93kw 43S (02-06)	BOSCH ABS 8
 Boxer 1 (94-06)	ABS	2.8 HDI 93kw 43S (02-06)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	ABS	2.8 HDI 93kw 43S (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	ABS	2.8 HDI 93kw SOFIM	BOSCH ABS 5.3
 Boxer 1 (94-06)	AIRBAG	2.0 81kw RFL (02-06)	SIEMENS AirBag
 Boxer 1 (94-06)	AIRBAG	2.0 81kw RFL (02-06)	TRW SRS 1
 Boxer 1 (94-06)	AIRBAG	2.0 HDI 63kw RHV	SIEMENS AirBag
 Boxer 1 (94-06)	AIRBAG	2.2 HDI 74kw 4HY	SIEMENS AirBag
 Boxer 1 (94-06)	AIRBAG	2.2 HDI 74kw 4HY (02-06)	TRW SRS 1
 Boxer 1 (94-06)	AIRBAG	2.3 HDI 16v 81kw F1AE0481C (02-0	SIEMENS AirBag
 Boxer 1 (94-06)	AIRBAG	2.3 HDI 16v 81kw F1AE0481C (02-0	TRW SRS 1
 Boxer 1 (94-06)	AIRBAG	2.5 D 63kw T9A (02-06)	SIEMENS AirBag
 Boxer 1 (94-06)	AIRBAG	2.5 D 63kw T9A (02-06)	TRW SRS 1
 Boxer 1 (94-06)	AIRBAG	2.8 D 64kw 8140.63 (02-06)	SIEMENS AirBag
 Boxer 1 (94-06)	AIRBAG	2.8 D 64kw 8140.63 (02-06)	TRW SRS 1
 Boxer 1 (94-06)	AIRBAG	2.8 HDI 108kw 43N (02-06)	SIEMENS AirBag
 Boxer 1 (94-06)	AIRBAG	2.8 HDI 108kw 43N (02-06)	TRW SRS 1
 Boxer 1 (94-06)	AIRBAG	2.8 HDI 90kw 43 (02-06)	SIEMENS AirBag
 Boxer 1 (94-06)	AIRBAG	2.8 HDI 90kw 43 (02-06)	TRW SRS 1
 Boxer 1 (94-06)	AIRBAG	2.8 HDI 93kw 43S (02-06)	SIEMENS AirBag
 Boxer 1 (94-06)	AIRBAG	2.8 HDI 93kw 43S (02-06)	TRW SRS 1
 Boxer 1 (94-06)	AIRBAG	2.8 HDI 93kw SOFIM	SIEMENS AirBag
 Boxer 1 (94-06)	AUTOM. TRANSMISSI	2.0 81kw RFL	A/T 4HP20
 Boxer 1 (94-06)	AUTOM. TRANSMISSI	2.0 HDI 63kw RHV	A/T 4HP20
 Boxer 1 (94-06)	AUTOM. TRANSMISSI	2.2 HDI 74kw 4HY	A/T 4HP20
 Boxer 1 (94-06)	AUTOM. TRANSMISSI	2.3 HDI 16v 81kw F1AE0481C (02-0	A/T 4HP20 AUTODETECT
 Boxer 1 (94-06)	AUTOM. TRANSMISSI	2.5 D 63kw T9A (02-06)	A/T 4HP20 AUTODETECT
 Boxer 1 (94-06)	AUTOM. TRANSMISSI	2.8 D 64kw 8140.63 (02-06)	A/T 4HP20 AUTODETECT
 Boxer 1 (94-06)	AUTOM. TRANSMISSI	2.8 HDI 108kw 43N (02-06)	A/T 4HP20 AUTODETECT
 Boxer 1 (94-06)	AUTOM. TRANSMISSI	2.8 HDI 90kw 43 (02-06)	A/T 4HP20 AUTODETECT
 Boxer 1 (94-06)	AUTOM. TRANSMISSI	2.8 HDI 93kw 43S (02-06)	A/T 4HP20 AUTODETECT
 Boxer 1 (94-06)	AUTOM. TRANSMISSI	2.8 HDI 93kw SOFIM	A/T 4HP20
 Boxer 1 (94-06)	AUX. HEATING	2.0 81kw RFL	Var.1

Systems supported by ECUREADER / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Boxer 1 (94-06)	AUX. HEATING	2.0 81kw RFL	Var.2
 Boxer 1 (94-06)	AUX. HEATING	2.0 81kw RFL	Var.3
 Boxer 1 (94-06)	AUX. HEATING	2.0 81kw RFL (02-06)	AUTODETECT
 Boxer 1 (94-06)	AUX. HEATING	2.0 HDI 63kw RHV	Var.1
 Boxer 1 (94-06)	AUX. HEATING	2.0 HDI 63kw RHV	Var.2
 Boxer 1 (94-06)	AUX. HEATING	2.0 HDI 63kw RHV	Var.3
 Boxer 1 (94-06)	AUX. HEATING	2.0 HDI 63kw RHV (02-06)	AUTODETECT
 Boxer 1 (94-06)	AUX. HEATING	2.2 HDI 74kw 4HY	Var.1
 Boxer 1 (94-06)	AUX. HEATING	2.2 HDI 74kw 4HY	Var.2
 Boxer 1 (94-06)	AUX. HEATING	2.2 HDI 74kw 4HY	Var.3
 Boxer 1 (94-06)	AUX. HEATING	2.2 HDI 74kw 4HY (02-06)	AUTODETECT
 Boxer 1 (94-06)	AUX. HEATING	2.3 HDI 16v 81kw F1AE0481C (02-0	AUTODETECT
 Boxer 1 (94-06)	AUX. HEATING	2.3 HDI 16v 81kw F1AE0481C (02-0	Var.1
 Boxer 1 (94-06)	AUX. HEATING	2.3 HDI 16v 81kw F1AE0481C (02-0	Var.2
 Boxer 1 (94-06)	AUX. HEATING	2.3 HDI 16v 81kw F1AE0481C (02-0	Var.3
 Boxer 1 (94-06)	AUX. HEATING	2.5 D 63kw T9A (02-06)	AUTODETECT
 Boxer 1 (94-06)	AUX. HEATING	2.5 D 63kw T9A (02-06)	Var.1
 Boxer 1 (94-06)	AUX. HEATING	2.5 D 63kw T9A (02-06)	Var.2
 Boxer 1 (94-06)	AUX. HEATING	2.5 D 63kw T9A (02-06)	Var.3
 Boxer 1 (94-06)	AUX. HEATING	2.8 D 64kw 8140.63 (02-06)	AUTODETECT
 Boxer 1 (94-06)	AUX. HEATING	2.8 D 64kw 8140.63 (02-06)	Var.1
 Boxer 1 (94-06)	AUX. HEATING	2.8 D 64kw 8140.63 (02-06)	Var.2
 Boxer 1 (94-06)	AUX. HEATING	2.8 D 64kw 8140.63 (02-06)	Var.3
 Boxer 1 (94-06)	AUX. HEATING	2.8 HDI 108kw 43N (02-06)	AUTODETECT
 Boxer 1 (94-06)	AUX. HEATING	2.8 HDI 108kw 43N (02-06)	Var.1
 Boxer 1 (94-06)	AUX. HEATING	2.8 HDI 108kw 43N (02-06)	Var.2
 Boxer 1 (94-06)	AUX. HEATING	2.8 HDI 108kw 43N (02-06)	Var.3
 Boxer 1 (94-06)	AUX. HEATING	2.8 HDI 90kw 43 (02-06)	AUTODETECT
 Boxer 1 (94-06)	AUX. HEATING	2.8 HDI 90kw 43 (02-06)	Var.1
 Boxer 1 (94-06)	AUX. HEATING	2.8 HDI 90kw 43 (02-06)	Var.2
 Boxer 1 (94-06)	AUX. HEATING	2.8 HDI 90kw 43 (02-06)	Var.3
 Boxer 1 (94-06)	AUX. HEATING	2.8 HDI 93kw 43S (02-06)	AUTODETECT
 Boxer 1 (94-06)	AUX. HEATING	2.8 HDI 93kw 43S (02-06)	Var.1
 Boxer 1 (94-06)	AUX. HEATING	2.8 HDI 93kw 43S (02-06)	Var.2
 Boxer 1 (94-06)	AUX. HEATING	2.8 HDI 93kw 43S (02-06)	Var.3
 Boxer 1 (94-06)	AUX. HEATING	2.8 HDI 93kw SOFIM (02-06)	AUTODETECT
 Boxer 1 (94-06)	AUX. HEATING	2.8 HDI 93kw SOFIM (02-06)	Var.1
 Boxer 1 (94-06)	AUX. HEATING	2.8 HDI 93kw SOFIM (02-06)	Var.2
 Boxer 1 (94-06)	AUX. HEATING	2.8 HDI 93kw SOFIM (02-06)	Var.3
 Boxer 1 (94-06)	CHASSIS NETWORK	2.0 81kw RFL (02-06)	Marelli Body Computer 6
 Boxer 1 (94-06)	CHASSIS NETWORK	2.0 HDI 63kw RHV (02-06)	Marelli Body Computer 6
 Boxer 1 (94-06)	CHASSIS NETWORK	2.2 HDI 74kw 4HY (02-06)	Marelli Body Computer 6
 Boxer 1 (94-06)	CHASSIS NETWORK	2.2 HDI 74kw 4HY (02-06)	Marelli Body Computer 6
 Boxer 1 (94-06)	CHASSIS NETWORK	2.3 HDI 16v 81kw F1AE0481C (02-0	Marelli Body Computer 6
 Boxer 1 (94-06)	CHASSIS NETWORK	2.5 D 63kw T9A (02-06)	Marelli Body Computer 6
 Boxer 1 (94-06)	CHASSIS NETWORK	2.8 D 64kw 8140.63 (02-06)	Marelli Body Computer 6
 Boxer 1 (94-06)	CHASSIS NETWORK	2.8 HDI 108kw 43N (02-06)	Marelli Body Computer 6
 Boxer 1 (94-06)	CHASSIS NETWORK	2.8 HDI 90kw 43 (02-06)	Marelli Body Computer 6
 Boxer 1 (94-06)	CHASSIS NETWORK	2.8 HDI 93kw 43S (02-06)	Marelli Body Computer 6
 Boxer 1 (94-06)	DASHBOARD	2.0 81kw RFL (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	DASHBOARD	2.0 HDI 63kw RHV (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	DASHBOARD	2.2 HDI 74kw 4HY (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	DASHBOARD	2.2 HDI 74kw 4HY (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	DASHBOARD	2.3 HDI 16v 81kw F1AE0481C (02-0	Marelli Dashboard
 Boxer 1 (94-06)	DASHBOARD	2.5 D 63kw T9A (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	DASHBOARD	2.8 D 64kw 8140.63 (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	DASHBOARD	2.8 HDI 108kw 43N (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	DASHBOARD	2.8 HDI 90kw 43 (02-06)	Marelli Dashboard

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Boxer 1 (94-06)	DASHBOARD	2.8 HDI 93kw 43S (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	ENGINE MANAGEME	2.0 81kw RFL	Marelli MM48P
 Boxer 1 (94-06)	ENGINE MANAGEME	2.0 81kw RFW (01-02)	EOBD
 Boxer 1 (94-06)	ENGINE MANAGEME	2.0 HDI 63kw RHV	
 Boxer 1 (94-06)	ENGINE MANAGEME	2.0 HDI 63kw RHV (02-06)	BOSCH EDC 15 Common Rail (JTD '99)
 Boxer 1 (94-06)	ENGINE MANAGEME	2.2 HDI 74kw 4HY	VISTEON PUMA AUTODETECT
 Boxer 1 (94-06)	ENGINE MANAGEME	2.2 HDI 74kw 4HY (02-06)	BOSCH EDC 15 Common Rail (JTD '99)
 Boxer 1 (94-06)	ENGINE MANAGEME	2.2 HDI 74kw 4HY (02-06)	BOSCH EDC 16 Common Rail
 Boxer 1 (94-06)	ENGINE MANAGEME	2.3 HDI 16v 81kw F1AE0481C (02-0	EOBD
 Boxer 1 (94-06)	ENGINE MANAGEME	2.5 D 63kw T9A (02-06)	EOBD
 Boxer 1 (94-06)	ENGINE MANAGEME	2.8 D 64kw 8140.63 (02-06)	EOBD
 Boxer 1 (94-06)	ENGINE MANAGEME	2.8 HDI 108kw 43N (02-06)	BOSCH EDC 15 Common Rail (JTD '99)
 Boxer 1 (94-06)	ENGINE MANAGEME	2.8 HDI 108kw 43N (02-06)	DIESEL AUTODETECT
 Boxer 1 (94-06)	ENGINE MANAGEME	2.8 HDI 93kw 43S (02-06)	BOSCH EDC 15 Common Rail (JTD '99)
 Boxer 1 (94-06)	ENGINE MANAGEME	2.8 HDI 93kw 43S (02-06)	DIESEL AUTODETECT
 Boxer 1 (94-06)	ENGINE MANAGEME	2.8 HDI 93kw 43S (94-02)	DIESEL AUTODETECT
 Boxer 1 (94-06)	ENGINE MANAGEME	2.8 HDI 93kw SOFIM	BOSCH EDC Common Rail
 Boxer 1 (94-06)	ENGINE MANAGEME	2.8 HDI 93kw SOFIM (02-06)	BOSCH EDC 15 Common Rail (JTD '99)
 Boxer 1 (94-06)	IMMOBILIZER	2.0 HDI 63kw RHV	DELPHI Code 2
 Boxer 1 (94-06)	IMMOBILIZER	2.2 HDI 74kw 4HY	DELPHI Code 2
 Boxer 1 (94-06)	IMMOBILIZER	2.8 HDI 93kw SOFIM	DELPHI Code 2
 Boxer 1 (94-06)	MAINTENANCE	1.9 D 51kw D9B (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	1.9 D 51kw D9B (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	1.9 D 51kw D9B (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	1.9 D 51kw D9B (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	1.9 D 52kw DJY (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	1.9 D 52kw DJY (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	1.9 D 52kw DJY (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	1.9 D 52kw DJY (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	1.9 TD 66kw DHX (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	1.9 TD 66kw DHX (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	1.9 TD 66kw DHX (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	1.9 TD 66kw DHX (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	1.9 TD 68kw D8C (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	1.9 TD 68kw D8C (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	1.9 TD 68kw D8C (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	1.9 TD 68kw D8C (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	2.0 81kw RFL (02-06)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	2.0 81kw RFL (02-06)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	2.0 81kw RFL (02-06)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	2.0 81kw RFL (02-06)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	2.0 81kw RFL (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	MAINTENANCE	2.0 81kw RFL (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	MAINTENANCE	2.0 81kw RFL (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	MAINTENANCE	2.0 81kw RFL (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	MAINTENANCE	2.0 81kw RFL (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	MAINTENANCE	2.0 81kw RFL (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	MAINTENANCE	2.0 81kw RFL (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	2.0 81kw RFL (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	2.0 81kw RFL (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	2.0 81kw RFL (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	2.0 81kw RFL (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	2.0 81kw RFW (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	2.0 81kw RFW (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	2.0 81kw RFW (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	2.0 81kw RFW (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	2.0 HDI 63kw RHV (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	MAINTENANCE	2.0 HDI 63kw RHV (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	MAINTENANCE	2.0 HDI 63kw RHV (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	MAINTENANCE	2.0 HDI 63kw RHV (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	MAINTENANCE	2.2 HDI 74kw 4HY	VISTEON PUMA AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

[illegible]

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Boxer 1 (94-06)	MAINTENANCE	2.8 HDI 90kw 43 (02-06)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	2.8 HDI 90kw 43 (02-06)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	2.8 HDI 90kw 43 (02-06)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	2.8 HDI 90kw 43 (02-06)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	2.8 HDI 90kw 43 (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	MAINTENANCE	2.8 HDI 90kw 43 (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	MAINTENANCE	2.8 HDI 90kw 43 (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	MAINTENANCE	2.8 HDI 90kw 43 (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	MAINTENANCE	2.8 HDI 93kw 43S (02-06)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	2.8 HDI 93kw 43S (02-06)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	2.8 HDI 93kw 43S (02-06)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	2.8 HDI 93kw 43S (02-06)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	2.8 HDI 93kw 43S (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	MAINTENANCE	2.8 HDI 93kw 43S (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	MAINTENANCE	2.8 HDI 93kw 43S (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	MAINTENANCE	2.8 HDI 93kw 43S (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	MAINTENANCE	2.8 HDI 93kw 43S (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	2.8 HDI 93kw 43S (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	2.8 HDI 93kw 43S (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	MAINTENANCE	2.8 HDI 93kw 43S (94-02)	BOSCH ABS ABR 5.3
 Boxer 1 (94-06)	SERVICE LIGHT RES	2.0 81kw RFL (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	SERVICE LIGHT RES	2.0 HDI 63kw RHV (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	SERVICE LIGHT RES	2.2 HDI 74kw 4HY (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	SERVICE LIGHT RES	2.3 HDI 16v 81kw F1AE0481C (02-0	Marelli Dashboard
 Boxer 1 (94-06)	SERVICE LIGHT RES	2.5 D 63kw T9A (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	SERVICE LIGHT RES	2.8 D 64kw 8140.63 (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	SERVICE LIGHT RES	2.8 HDI 108kw 43N (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	SERVICE LIGHT RES	2.8 HDI 90kw 43 (02-06)	Marelli Dashboard
 Boxer 1 (94-06)	SERVICE LIGHT RES	2.8 HDI 93kw 43S (02-06)	Marelli Dashboard
 Boxer 2 (06-..)	ABS	2.2 HDI 16v 74kw 4HV (06-..)	BOSCH ABS 8.0 AUTODETECT
 Boxer 2 (06-..)	ABS	2.2 HDI 16v 88kw 4HU (06-..)	BOSCH ABS 8.0 AUTODETECT
 Boxer 2 (06-..)	ABS	2.3 HDI 16v 110kw F1AE0481D (06-..)	BOSCH ABS 8.0 AUTODETECT
 Boxer 2 (06-..)	ABS	2.3 HDI 16v 115kw F1AE0481D (06-..)	BOSCH ABS 8.0 AUTODETECT
 Boxer 2 (06-..)	ABS	2.3 HDI 16v 88kw F1AE0481D (06-..)	BOSCH ABS 8.0 AUTODETECT
 Boxer 2 (06-..)	ABS	2.3 HDI 16v 95kw F1AE0481N (06-..)	BOSCH ABS 8.0 AUTODETECT
 Boxer 2 (06-..)	ABS	3.0 HDI 16v 115kw F1CE0481D (06-..)	BOSCH ABS 8.0 AUTODETECT
 Boxer 2 (06-..)	ABS + TRACT. CONT	2.2 HDI 16v 74kw 4HV (06-..)	ABS+TC AUTODETECT
 Boxer 2 (06-..)	ABS + TRACT. CONT	2.2 HDI 16v 74kw 4HV (06-..)	ESP AUTODETECT
 Boxer 2 (06-..)	ABS + TRACT. CONT	2.2 HDI 16v 88kw 4HU (06-..)	ABS+TC AUTODETECT
 Boxer 2 (06-..)	ABS + TRACT. CONT	2.2 HDI 16v 88kw 4HU (06-..)	BOSCH ESP AUTODETECT
 Boxer 2 (06-..)	ABS + TRACT. CONT	2.3 HDI 16v 110kw F1AE0481D (06-..)	ABS+TC AUTODETECT
 Boxer 2 (06-..)	ABS + TRACT. CONT	2.3 HDI 16v 110kw F1AE0481D (06-..)	BOSCH ESP AUTODETECT
 Boxer 2 (06-..)	ABS + TRACT. CONT	2.3 HDI 16v 115kw F1AE0481D (06-..)	ABS+TC AUTODETECT
 Boxer 2 (06-..)	ABS + TRACT. CONT	2.3 HDI 16v 115kw F1AE0481D (06-..)	BOSCH ESP AUTODETECT
 Boxer 2 (06-..)	ABS + TRACT. CONT	2.3 HDI 16v 88kw F1AE0481D (06-..)	ABS+TC AUTODETECT
 Boxer 2 (06-..)	ABS + TRACT. CONT	2.3 HDI 16v 88kw F1AE0481D (06-..)	BOSCH ESP AUTODETECT
 Boxer 2 (06-..)	ABS + TRACT. CONT	2.3 HDI 16v 95kw F1AE0481N (06-..)	ABS+TC AUTODETECT
 Boxer 2 (06-..)	ABS + TRACT. CONT	2.3 HDI 16v 95kw F1AE0481N (06-..)	BOSCH ESP AUTODETECT
 Boxer 2 (06-..)	ABS + TRACT. CONT	3.0 HDI 16v 115kw F1CE0481D (06-..)	ABS+TC AUTODETECT
 Boxer 2 (06-..)	ABS + TRACT. CONT	3.0 HDI 16v 115kw F1CE0481D (06-..)	BOSCH ESP AUTODETECT
 Boxer 2 (06-..)	AIRBAG	2.2 HDI 16v 74kw 4HV (06-..)	AirBag CENTRAL AUTODETECT
 Boxer 2 (06-..)	AIRBAG	2.2 HDI 16v 88kw 4HU (06-..)	AirBag CENTRAL AUTODETECT
 Boxer 2 (06-..)	AIRBAG	2.3 HDI 16v 110kw F1AE0481D (06-..)	AirBag CENTRAL AUTODETECT
 Boxer 2 (06-..)	AIRBAG	2.3 HDI 16v 115kw F1AE0481D (06-..)	AirBag CENTRAL AUTODETECT
 Boxer 2 (06-..)	AIRBAG	2.3 HDI 16v 88kw F1AE0481D (06-..)	AirBag CENTRAL AUTODETECT
 Boxer 2 (06-..)	AIRBAG	2.3 HDI 16v 95kw F1AE0481N (06-..)	AirBag CENTRAL AUTODETECT
 Boxer 2 (06-..)	AIRBAG	3.0 HDI 16v 115kw F1CE0481D (06-..)	AirBag CENTRAL AUTODETECT
 Boxer 2 (06-..)	AUX. HEATING	2.2 HDI 16v 74kw 4HV (06-..)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Boxer 2 (06-..)	AUX. HEATING	2.2 HDI 16v 88kw 4HU (06-..)	AUTODETECT
 Boxer 2 (06-..)	AUX. HEATING	2.3 HDI 16v 110kw F1AE0481D (06-..)	AUTODETECT
 Boxer 2 (06-..)	AUX. HEATING	2.3 HDI 16v 115kw F1AE0481D (06-..)	AUTODETECT
 Boxer 2 (06-..)	AUX. HEATING	2.3 HDI 16v 88kw F1AE0481D (06-..)	AUTODETECT
 Boxer 2 (06-..)	AUX. HEATING	2.3 HDI 16v 95kw F1AE0481N (06-..)	AUTODETECT
 Boxer 2 (06-..)	AUX. HEATING	3.0 HDI 16v 115kw F1CE0481D (06-..)	AUTODETECT
 Boxer 2 (06-..)	CHASSIS NETWORK	2.2 HDI 16v 74kw 4HV (06-..)	Body Computer BSI AUTODETECT
 Boxer 2 (06-..)	CHASSIS NETWORK	2.2 HDI 16v 88kw 4HU (06-..)	Body Computer BSI AUTODETECT
 Boxer 2 (06-..)	CHASSIS NETWORK	2.3 HDI 16v 110kw F1AE0481D (06-..)	Body Computer BSI AUTODETECT
 Boxer 2 (06-..)	CHASSIS NETWORK	2.3 HDI 16v 115kw F1AE0481D (06-..)	Body Computer BSI AUTODETECT
 Boxer 2 (06-..)	CHASSIS NETWORK	2.3 HDI 16v 88kw F1AE0481D (06-..)	Body Computer BSI AUTODETECT
 Boxer 2 (06-..)	CHASSIS NETWORK	2.3 HDI 16v 95kw F1AE0481N (06-..)	Body Computer BSI AUTODETECT
 Boxer 2 (06-..)	CHASSIS NETWORK	3.0 HDI 16v 115kw F1CE0481D (06-..)	Body Computer BSI AUTODETECT
 Boxer 2 (06-..)	CHRONOTACHOGRA	2.2 HDI 16v 74kw 4HV (06-..)	AUTODETECT
 Boxer 2 (06-..)	CHRONOTACHOGRA	2.2 HDI 16v 88kw 4HU (06-..)	AUTODETECT
 Boxer 2 (06-..)	CHRONOTACHOGRA	2.3 HDI 16v 110kw F1AE0481D (06-..)	AUTODETECT
 Boxer 2 (06-..)	CHRONOTACHOGRA	2.3 HDI 16v 115kw F1AE0481D (06-..)	AUTODETECT
 Boxer 2 (06-..)	CHRONOTACHOGRA	2.3 HDI 16v 88kw F1AE0481D (06-..)	AUTODETECT
 Boxer 2 (06-..)	CHRONOTACHOGRA	2.3 HDI 16v 95kw F1AE0481N (06-..)	AUTODETECT
 Boxer 2 (06-..)	CHRONOTACHOGRA	3.0 HDI 16v 115kw F1CE0481D (06-..)	AUTODETECT
 Boxer 2 (06-..)	CLIMA	2.2 HDI 16v 74kw 4HV (06-..)	CLIMA AUTODETECT
 Boxer 2 (06-..)	CLIMA	2.2 HDI 16v 88kw 4HU (06-..)	CLIMA AUTODETECT
 Boxer 2 (06-..)	CLIMA	2.3 HDI 16v 110kw F1AE0481D (06-..)	CLIMA AUTODETECT
 Boxer 2 (06-..)	CLIMA	2.3 HDI 16v 115kw F1AE0481D (06-..)	CLIMA AUTODETECT
 Boxer 2 (06-..)	CLIMA	2.3 HDI 16v 88kw F1AE0481D (06-..)	CLIMA AUTODETECT
 Boxer 2 (06-..)	CLIMA	2.3 HDI 16v 95kw F1AE0481N (06-..)	CLIMA AUTODETECT
 Boxer 2 (06-..)	CLIMA	3.0 HDI 16v 115kw F1CE0481D (06-..)	CLIMA AUTODETECT
 Boxer 2 (06-..)	DASHBOARD	2.2 HDI 16v 74kw 4HV (06-..)	AUTODETECT
 Boxer 2 (06-..)	DASHBOARD	2.2 HDI 16v 88kw 4HU (06-..)	AUTODETECT
 Boxer 2 (06-..)	DASHBOARD	2.3 HDI 16v 110kw F1AE0481D (06-..)	AUTODETECT
 Boxer 2 (06-..)	DASHBOARD	2.3 HDI 16v 115kw F1AE0481D (06-..)	AUTODETECT
 Boxer 2 (06-..)	DASHBOARD	2.3 HDI 16v 88kw F1AE0481D (06-..)	AUTODETECT
 Boxer 2 (06-..)	DASHBOARD	2.3 HDI 16v 95kw F1AE0481N (06-..)	AUTODETECT
 Boxer 2 (06-..)	DASHBOARD	3.0 HDI 16v 115kw F1CE0481D (06-..)	AUTODETECT
 Boxer 2 (06-..)	ELECTRIC STEERING	2.2 HDI 16v 74kw 4HV (06-..)	AUTODETECT
 Boxer 2 (06-..)	ELECTRIC STEERING	2.2 HDI 16v 88kw 4HU (06-..)	AUTODETECT
 Boxer 2 (06-..)	ELECTRIC STEERING	2.3 HDI 16v 110kw F1AE0481D (06-..)	AUTODETECT
 Boxer 2 (06-..)	ELECTRIC STEERING	2.3 HDI 16v 115kw F1AE0481D (06-..)	AUTODETECT
 Boxer 2 (06-..)	ELECTRIC STEERING	2.3 HDI 16v 88kw F1AE0481D (06-..)	AUTODETECT
 Boxer 2 (06-..)	ELECTRIC STEERING	2.3 HDI 16v 95kw F1AE0481N (06-..)	AUTODETECT
 Boxer 2 (06-..)	ELECTRIC STEERING	3.0 HDI 16v 115kw F1CE0481D (06-..)	AUTODETECT
 Boxer 2 (06-..)	ENGINE MANAGEME	2.2 HDI 16v 74kw 4HV (06-..)	VISTEON PUMA AUTODETECT
 Boxer 2 (06-..)	ENGINE MANAGEME	2.2 HDI 16v 88kw 4HU (06-..)	VISTEON PUMA AUTODETECT
 Boxer 2 (06-..)	ENGINE MANAGEME	2.3 HDI 16v 110kw F1AE0481D (06-..)	EOBD
 Boxer 2 (06-..)	ENGINE MANAGEME	2.3 HDI 16v 115kw F1AE0481D (06-..)	EOBD
 Boxer 2 (06-..)	ENGINE MANAGEME	2.3 HDI 16v 88kw F1AE0481D (06-..)	EOBD
 Boxer 2 (06-..)	ENGINE MANAGEME	2.3 HDI 16v 95kw F1AE0481N (06-..)	EOBD
 Boxer 2 (06-..)	ENGINE MANAGEME	3.0 HDI 16v 115kw F1CE0481D (06-..)	BOSCH EDC16 C39 Common Rail AUTOD
 Boxer 2 (06-..)	MAINTENANCE	2.2 HDI 16v 74kw (06-..)	Marelli Dashboard
 Boxer 2 (06-..)	MAINTENANCE	2.2 HDI 16v 74kw 4HV (06-..)	AUTODETECT
 Boxer 2 (06-..)	MAINTENANCE	2.2 HDI 16v 74kw 4HV (06-..)	ESP AUTODETECT
 Boxer 2 (06-..)	MAINTENANCE	2.2 HDI 16v 74kw 4HV (06-..)	ESP AUTODETECT
 Boxer 2 (06-..)	MAINTENANCE	2.2 HDI 16v 74kw 4HV (06-..)	VISTEON PUMA AUTODETECT
 Boxer 2 (06-..)	MAINTENANCE	2.2 HDI 16v 88kw (06-..)	Marelli Dashboard
 Boxer 2 (06-..)	MAINTENANCE	2.2 HDI 16v 88kw 4HU (06-..)	AUTODETECT
 Boxer 2 (06-..)	MAINTENANCE	2.2 HDI 16v 88kw 4HU (06-..)	BOSCH ESP AUTODETECT
 Boxer 2 (06-..)	MAINTENANCE	2.2 HDI 16v 88kw 4HU (06-..)	BOSCH ESP AUTODETECT
 Boxer 2 (06-..)	MAINTENANCE	2.2 HDI 16v 88kw 4HU (06-..)	VISTEON PUMA AUTODETECT

Systems supported by ECUREADER / ECUDECODER (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Boxer 2 (06-..)	MAINTENANCE	2.3 HDI 16v 110kw (06-..)	Marelli Dashboard
 Boxer 2 (06-..)	MAINTENANCE	2.3 HDI 16v 110kw F1AE0481D (06-..)	AUTODETECT
 Boxer 2 (06-..)	MAINTENANCE	2.3 HDI 16v 110kw F1AE0481D (06-..)	BOSCH ESP AUTODETECT
 Boxer 2 (06-..)	MAINTENANCE	2.3 HDI 16v 110kw F1AE0481D (06-..)	BOSCH ESP AUTODETECT
 Boxer 2 (06-..)	MAINTENANCE	2.3 HDI 16v 115kw (06-..)	Marelli Dashboard
 Boxer 2 (06-..)	MAINTENANCE	2.3 HDI 16v 115kw F1AE0481D (06-..)	AUTODETECT
 Boxer 2 (06-..)	MAINTENANCE	2.3 HDI 16v 115kw F1AE0481D (06-..)	BOSCH ESP AUTODETECT
 Boxer 2 (06-..)	MAINTENANCE	2.3 HDI 16v 115kw F1AE0481D (06-..)	BOSCH ESP AUTODETECT
 Boxer 2 (06-..)	MAINTENANCE	2.3 HDI 16v 88kw (06-..)	Marelli Dashboard
 Boxer 2 (06-..)	MAINTENANCE	2.3 HDI 16v 88kw F1AE0481D (06-..)	AUTODETECT
 Boxer 2 (06-..)	MAINTENANCE	2.3 HDI 16v 88kw F1AE0481D (06-..)	BOSCH ESP AUTODETECT
 Boxer 2 (06-..)	MAINTENANCE	2.3 HDI 16v 88kw F1AE0481D (06-..)	BOSCH ESP AUTODETECT
 Boxer 2 (06-..)	MAINTENANCE	2.3 HDI 16v 95kw (06-..)	Marelli Dashboard
 Boxer 2 (06-..)	MAINTENANCE	2.3 HDI 16v 95kw F1AE0481N (06-..)	AUTODETECT
 Boxer 2 (06-..)	MAINTENANCE	2.3 HDI 16v 95kw F1AE0481N (06-..)	BOSCH ESP AUTODETECT
 Boxer 2 (06-..)	MAINTENANCE	2.3 HDI 16v 95kw F1AE0481N (06-..)	BOSCH ESP AUTODETECT
 Boxer 2 (06-..)	MAINTENANCE	3.0 HDI 16v 115kw (06-..)	Marelli Dashboard
 Boxer 2 (06-..)	MAINTENANCE	3.0 HDI 16v 115kw F1CE0481D (06-..)	AUTODETECT
 Boxer 2 (06-..)	MAINTENANCE	3.0 HDI 16v 115kw F1CE0481D (06-..)	BOSCH EDC16 C39 Common Rail AUTOD
 Boxer 2 (06-..)	MAINTENANCE	3.0 HDI 16v 115kw F1CE0481D (06-..)	BOSCH ESP AUTODETECT
 Boxer 2 (06-..)	MAINTENANCE	3.0 HDI 16v 115kw F1CE0481D (06-..)	BOSCH ESP AUTODETECT
 Boxer 2 (06-..)	NAVIGATION	2.2 HDI 16v 74kw 4HV (06-..)	AUTODETECT
 Boxer 2 (06-..)	NAVIGATION	2.2 HDI 16v 88kw 4HU (06-..)	AUTODETECT
 Boxer 2 (06-..)	NAVIGATION	2.3 HDI 16v 110kw F1AE0481D (06-..)	AUTODETECT
 Boxer 2 (06-..)	NAVIGATION	2.3 HDI 16v 115kw F1AE0481D (06-..)	AUTODETECT
 Boxer 2 (06-..)	NAVIGATION	2.3 HDI 16v 88kw F1AE0481D (06-..)	AUTODETECT
 Boxer 2 (06-..)	NAVIGATION	2.3 HDI 16v 95kw F1AE0481N (06-..)	AUTODETECT
 Boxer 2 (06-..)	NAVIGATION	3.0 HDI 16v 115kw F1CE0481D (06-..)	AUTODETECT
 Boxer 2 (06-..)	PARKING HELP	2.2 HDI 16v 74kw 4HV (06-..)	AUTODETECT
 Boxer 2 (06-..)	PARKING HELP	2.2 HDI 16v 88kw 4HU (06-..)	AUTODETECT
 Boxer 2 (06-..)	PARKING HELP	2.3 HDI 16v 110kw F1AE0481D (06-..)	AUTODETECT
 Boxer 2 (06-..)	PARKING HELP	2.3 HDI 16v 115kw F1AE0481D (06-..)	AUTODETECT
 Boxer 2 (06-..)	PARKING HELP	2.3 HDI 16v 88kw F1AE0481D (06-..)	AUTODETECT
 Boxer 2 (06-..)	PARKING HELP	2.3 HDI 16v 95kw F1AE0481N (06-..)	AUTODETECT
 Boxer 2 (06-..)	PARKING HELP	3.0 HDI 16v 115kw F1CE0481D (06-..)	AUTODETECT
 Boxer 2 (06-..)	SERVICE LIGHT RES	2.2 HDI 16v 74kw (06-..)	Marelli Dashboard
 Boxer 2 (06-..)	SERVICE LIGHT RES	2.2 HDI 16v 88kw (06-..)	Marelli Dashboard
 Boxer 2 (06-..)	SERVICE LIGHT RES	2.3 HDI 16v 110kw (06-..)	Marelli Dashboard
 Boxer 2 (06-..)	SERVICE LIGHT RES	2.3 HDI 16v 115kw (06-..)	Marelli Dashboard
 Boxer 2 (06-..)	SERVICE LIGHT RES	2.3 HDI 16v 88kw (06-..)	Marelli Dashboard
 Boxer 2 (06-..)	SERVICE LIGHT RES	2.3 HDI 16v 95kw (06-..)	Marelli Dashboard
 Boxer 2 (06-..)	SERVICE LIGHT RES	3.0 HDI 16v 115kw (06-..)	Marelli Dashboard
 Boxer 2 (06-..)	SUSPENSION CONTR	2.2 HDI 16v 74kw 4HV (06-..)	AUTODETECT
 Boxer 2 (06-..)	SUSPENSION CONTR	2.2 HDI 16v 88kw 4HU (06-..)	AUTODETECT
 Boxer 2 (06-..)	SUSPENSION CONTR	2.3 HDI 16v 110kw F1AE0481D (06-..)	AUTODETECT
 Boxer 2 (06-..)	SUSPENSION CONTR	2.3 HDI 16v 115kw F1AE0481D (06-..)	AUTODETECT
 Boxer 2 (06-..)	SUSPENSION CONTR	2.3 HDI 16v 88kw F1AE0481D (06-..)	AUTODETECT
 Boxer 2 (06-..)	SUSPENSION CONTR	2.3 HDI 16v 95kw F1AE0481N (06-..)	AUTODETECT
 Boxer 2 (06-..)	SUSPENSION CONTR	3.0 HDI 16v 115kw F1CE0481D (06-..)	AUTODETECT
 Expert 1 (95-06)	ABS	1.6 8v 58kw 220A2 (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	ABS	1.9 D 8v 51kw WJY	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	ABS	1.9 D 8v 51kw WJY (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	ABS	1.9 D 8v 52kw WJY	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	ABS	1.9 D 8v 52kw WJY (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	ABS	1.9 TD 8v 66kw DHX	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	ABS	1.9 TD 8v 68kw D8B (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	ABS	2.0 8v 89kw RFU (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	ABS	2.0 16v 100kw RFN	BOSCH ABS ABR 5.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Expert 1 (95-06)	ABS	2.0 HDI 16v 80kw RHW (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	ABS	2.0 HDI 8v 69kw RHY (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	ABS	2.0 HDI 8v 70kw RHX	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	ABS	2.0 HDI 8v 81kw RHZ	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	ABS	2.0T 8v 108kw RGX (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	ABS	2.1 TD 12v 81kw P8C (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	AIRBAG	1.6 8v 58kw 220A2 (95-03)	AUTOLIV AirBag CENTRAL ACU AUTODE
 Expert 1 (95-06)	AIRBAG	1.9 D 8v 51kw WJY (04-06)	AirBag CENTRAL AUTODETECT
 Expert 1 (95-06)	AIRBAG	1.9 D 8v 51kw WJY (95-03)	AUTOLIV AirBag CENTRAL ACU AUTODE
 Expert 1 (95-06)	AIRBAG	1.9 D 8v 52kw WJY (04-06)	AirBag CENTRAL AUTODETECT
 Expert 1 (95-06)	AIRBAG	1.9 D 8v 52kw WJY (95-03)	AUTOLIV AirBag CENTRAL ACU AUTODE
 Expert 1 (95-06)	AIRBAG	1.9 TD 8v 66kw DHX (95-03)	AUTOLIV AirBag CENTRAL ACU AUTODE
 Expert 1 (95-06)	AIRBAG	1.9 TD 8v 68kw D8B (95-03)	AUTOLIV AirBag CENTRAL ACU AUTODE
 Expert 1 (95-06)	AIRBAG	2.0 8v 89kw RFU (95-03)	AUTOLIV AirBag CENTRAL ACU AUTODE
 Expert 1 (95-06)	AIRBAG	2.0 HDI 8v 69kw RHY (04-06)	AirBag CENTRAL AUTODETECT
 Expert 1 (95-06)	AIRBAG	2.0 HDI 8v 69kw RHY (95-03)	AUTOLIV AirBag CENTRAL ACU AUTODE
 Expert 1 (95-06)	AIRBAG	2.0T 8v 108kw RGX (95-03)	AUTOLIV AirBag CENTRAL ACU AUTODE
 Expert 1 (95-06)	AIRBAG	2.1 TD 12v 81kw P8C (95-03)	AUTOLIV AirBag CENTRAL ACU AUTODE
 Expert 1 (95-06)	AUTOM. TRANSMISSI	1.6 8v 58kw 220A2 (95-03)	A/T AL4 AUTODETECT
 Expert 1 (95-06)	AUTOM. TRANSMISSI	1.9 D 8v 51kw WJY	Var.1
 Expert 1 (95-06)	AUTOM. TRANSMISSI	1.9 D 8v 51kw WJY	Var.2
 Expert 1 (95-06)	AUTOM. TRANSMISSI	1.9 D 8v 51kw WJY	Var.3
 Expert 1 (95-06)	AUTOM. TRANSMISSI	1.9 D 8v 51kw WJY (95-03)	A/T AL4 AUTODETECT
 Expert 1 (95-06)	AUTOM. TRANSMISSI	1.9 D 8v 52kw WJY	Var.1
 Expert 1 (95-06)	AUTOM. TRANSMISSI	1.9 D 8v 52kw WJY	Var.2
 Expert 1 (95-06)	AUTOM. TRANSMISSI	1.9 D 8v 52kw WJY	Var.3
 Expert 1 (95-06)	AUTOM. TRANSMISSI	1.9 D 8v 52kw WJY (95-03)	A/T AL4 AUTODETECT
 Expert 1 (95-06)	AUTOM. TRANSMISSI	1.9 TD 8v 66kw DHX	Var.1
 Expert 1 (95-06)	AUTOM. TRANSMISSI	1.9 TD 8v 66kw DHX	Var.2
 Expert 1 (95-06)	AUTOM. TRANSMISSI	1.9 TD 8v 66kw DHX	Var.3
 Expert 1 (95-06)	AUTOM. TRANSMISSI	1.9 TD 8v 68kw D8B (95-03)	A/T AL4 AUTODETECT
 Expert 1 (95-06)	AUTOM. TRANSMISSI	2.0 8v 89kw RFU (95-03)	A/T AL4 AUTODETECT
 Expert 1 (95-06)	AUTOM. TRANSMISSI	2.0 16v 100kw RFN	Var.1
 Expert 1 (95-06)	AUTOM. TRANSMISSI	2.0 16v 100kw RFN	Var.2
 Expert 1 (95-06)	AUTOM. TRANSMISSI	2.0 16v 100kw RFN	Var.3
 Expert 1 (95-06)	AUTOM. TRANSMISSI	2.0 HDI 16v 80kw RHW	Var.1
 Expert 1 (95-06)	AUTOM. TRANSMISSI	2.0 HDI 16v 80kw RHW	Var.2
 Expert 1 (95-06)	AUTOM. TRANSMISSI	2.0 HDI 16v 80kw RHW	Var.3
 Expert 1 (95-06)	AUTOM. TRANSMISSI	2.0 HDI 8v 69kw RHY (04-06)	A/T AL4 AUTODETECT
 Expert 1 (95-06)	AUTOM. TRANSMISSI	2.0 HDI 8v 69kw RHY (95-03)	A/T AL4 AUTODETECT
 Expert 1 (95-06)	AUTOM. TRANSMISSI	2.0 HDI 8v 70kw RHX	Var.1
 Expert 1 (95-06)	AUTOM. TRANSMISSI	2.0 HDI 8v 70kw RHX	Var.2
 Expert 1 (95-06)	AUTOM. TRANSMISSI	2.0 HDI 8v 70kw RHX	Var.3
 Expert 1 (95-06)	AUTOM. TRANSMISSI	2.0 HDI 8v 81kw RHZ	Var.1
 Expert 1 (95-06)	AUTOM. TRANSMISSI	2.0 HDI 8v 81kw RHZ	Var.2
 Expert 1 (95-06)	AUTOM. TRANSMISSI	2.0 HDI 8v 81kw RHZ	Var.3
 Expert 1 (95-06)	AUTOM. TRANSMISSI	2.0T 8v 108kw RGX (95-03)	A/T AL4 AUTODETECT
 Expert 1 (95-06)	AUTOM. TRANSMISSI	2.1 TD 12v 81kw P8C (95-03)	A/T AL4 AUTODETECT
 Expert 1 (95-06)	DIESEL MANAGEMEN	1.9 D 8v 51kw WJY	LUCAS Diesel DCN2
 Expert 1 (95-06)	DIESEL MANAGEMEN	1.9 D 8v 52kw WJY	LUCAS Diesel DCN2
 Expert 1 (95-06)	DIESEL MANAGEMEN	1.9 TD 8v 66kw DHX	BOSCH AS3 VP20
 Expert 1 (95-06)	ENGINE MANAGEME	1.6 8v 58kw 220A2 (01-03)	EOBD
 Expert 1 (95-06)	ENGINE MANAGEME	1.9 D 8v 51kw WJY	LUCAS Diesel DCN2
 Expert 1 (95-06)	ENGINE MANAGEME	1.9 D 8v 52kw WJY	LUCAS Diesel DCN2
 Expert 1 (95-06)	ENGINE MANAGEME	2.0 8v 89kw RFU (01-03)	EOBD
 Expert 1 (95-06)	ENGINE MANAGEME	2.0 16v 100kw RFN	Marelli MM48P
 Expert 1 (95-06)	ENGINE MANAGEME	2.0 HDI 16v 80kw RHW	BOSCH EDC 15 C2 Common Rail
 Expert 1 (95-06)	ENGINE MANAGEME	2.0 HDI 8v 69kw RHY (04-06)	EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Expert 1 (95-06)	ENGINE MANAGEME	2.0 HDI 8v 70kw RHX	BOSCH EDC 15 C2 Common Rail
 Expert 1 (95-06)	ENGINE MANAGEME	2.0 HDI 8v 81kw RHZ	BOSCH EDC 15 C2 Common Rail
 Expert 1 (95-06)	ENGINE MANAGEME	2.0 HDI 8v 81kw RHZ (03-06)	BOSCH EDC 15 C2 Common Rail
 Expert 1 (95-06)	ENGINE MANAGEME	2.0 HDI 8v 81kw RHZ (95-03)	BOSCH EDC 15 C2 Common Rail
 Expert 1 (95-06)	MAINTENANCE	1.6 8v 58kw 220A2 (95-03)	A/T AL4 AUTODETECT
 Expert 1 (95-06)	MAINTENANCE	1.6 8v 58kw 220A2 (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	1.6 8v 58kw 220A2 (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	1.6 8v 58kw 220A2 (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	1.6 8v 58kw 220A2 (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	1.9 D 8v 51kw WJY	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	1.9 D 8v 51kw WJY	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	1.9 D 8v 51kw WJY	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	1.9 D 8v 51kw WJY	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	1.9 D 8v 51kw WJY	Var.1
 Expert 1 (95-06)	MAINTENANCE	1.9 D 8v 51kw WJY	Var.2
 Expert 1 (95-06)	MAINTENANCE	1.9 D 8v 51kw WJY	Var.3
 Expert 1 (95-06)	MAINTENANCE	1.9 D 8v 51kw WJY (04-06)	AirBag CENTRAL AUTODETECT
 Expert 1 (95-06)	MAINTENANCE	1.9 D 8v 51kw WJY (04-06)	AirBag CENTRAL AUTODETECT
 Expert 1 (95-06)	MAINTENANCE	1.9 D 8v 51kw WJY (95-03)	A/T AL4 AUTODETECT
 Expert 1 (95-06)	MAINTENANCE	1.9 D 8v 51kw WJY (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	1.9 D 8v 51kw WJY (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	1.9 D 8v 51kw WJY (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	1.9 D 8v 51kw WJY (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	1.9 D 8v 51kw WJY (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	1.9 D 8v 52kw WJY	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	1.9 D 8v 52kw WJY	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	1.9 D 8v 52kw WJY	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	1.9 D 8v 52kw WJY	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	1.9 D 8v 52kw WJY	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	1.9 D 8v 52kw WJY	Var.1
 Expert 1 (95-06)	MAINTENANCE	1.9 D 8v 52kw WJY	Var.2
 Expert 1 (95-06)	MAINTENANCE	1.9 D 8v 52kw WJY	Var.3
 Expert 1 (95-06)	MAINTENANCE	1.9 D 8v 52kw WJY (04-06)	AirBag CENTRAL AUTODETECT
 Expert 1 (95-06)	MAINTENANCE	1.9 D 8v 52kw WJY (04-06)	AirBag CENTRAL AUTODETECT
 Expert 1 (95-06)	MAINTENANCE	1.9 D 8v 52kw WJY (95-03)	A/T AL4 AUTODETECT
 Expert 1 (95-06)	MAINTENANCE	1.9 D 8v 52kw WJY (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	1.9 D 8v 52kw WJY (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	1.9 D 8v 52kw WJY (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	1.9 D 8v 52kw WJY (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	1.9 TD 8v 66kw DHX	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	1.9 TD 8v 66kw DHX	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	1.9 TD 8v 66kw DHX	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	1.9 TD 8v 66kw DHX	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	1.9 TD 8v 66kw DHX	Var.1
 Expert 1 (95-06)	MAINTENANCE	1.9 TD 8v 66kw DHX	Var.2
 Expert 1 (95-06)	MAINTENANCE	1.9 TD 8v 66kw DHX	Var.3
 Expert 1 (95-06)	MAINTENANCE	1.9 TD 8v 66kw DHX (95-06)	MANUAL
 Expert 1 (95-06)	MAINTENANCE	1.9 TD 8v 68kw D8B (95-03)	A/T AL4 AUTODETECT
 Expert 1 (95-06)	MAINTENANCE	1.9 TD 8v 68kw D8B (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	1.9 TD 8v 68kw D8B (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	1.9 TD 8v 68kw D8B (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	1.9 TD 8v 68kw D8B (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	2.0 8v 89kw RFU (95-03)	A/T AL4 AUTODETECT
 Expert 1 (95-06)	MAINTENANCE	2.0 8v 89kw RFU (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	2.0 8v 89kw RFU (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	2.0 8v 89kw RFU (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	2.0 8v 89kw RFU (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	2.0 16v 100kw RFN	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	2.0 16v 100kw RFN	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	2.0 16v 100kw RFN	BOSCH ABS ABR 5.3

Systems supported by ECUREADER / ECUDECODER (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Expert 1 (95-06)	MAINTENANCE	2.0 16v 100kw RFN	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	2.0 16v 100kw RFN	Var.1
 Expert 1 (95-06)	MAINTENANCE	2.0 16v 100kw RFN	Var.2
 Expert 1 (95-06)	MAINTENANCE	2.0 16v 100kw RFN	Var.3
 Expert 1 (95-06)	MAINTENANCE	2.0 16v 100kw RFN (95-06)	MANUAL
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 16v 80kw RHW	BOSCH EDC 15 C2 Common Rail
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 16v 80kw RHW	Var.1
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 16v 80kw RHW	Var.2
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 16v 80kw RHW	Var.3
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 16v 80kw RHW (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 16v 80kw RHW (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 16v 80kw RHW (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 16v 80kw RHW (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 8v 69kw RHY (04-06)	A/T AL4 AUTODETECT
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 8v 69kw RHY (04-06)	AirBag CENTRAL AUTODETECT
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 8v 69kw RHY (04-06)	AirBag CENTRAL AUTODETECT
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 8v 69kw RHY (95-03)	A/T AL4 AUTODETECT
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 8v 69kw RHY (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 8v 69kw RHY (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 8v 69kw RHY (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 8v 69kw RHY (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 8v 70kw RHX	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 8v 70kw RHX	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 8v 70kw RHX	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 8v 70kw RHX	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 8v 70kw RHX	BOSCH EDC 15 C2 Common Rail
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 8v 70kw RHX	Var.1
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 8v 70kw RHX	Var.2
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 8v 70kw RHX	Var.3
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 8v 81kw RHZ	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 8v 81kw RHZ	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 8v 81kw RHZ	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 8v 81kw RHZ	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 8v 81kw RHZ	BOSCH EDC 15 C2 Common Rail
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 8v 81kw RHZ	Var.1
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 8v 81kw RHZ	Var.2
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 8v 81kw RHZ	Var.3
 Expert 1 (95-06)	MAINTENANCE	2.0 HDI 8v 81kw RHZ (03-06)	BOSCH EDC 15 C2 Common Rail
 Expert 1 (95-06)	MAINTENANCE	2.0T 8v 108kw RGX (95-03)	A/T AL4 AUTODETECT
 Expert 1 (95-06)	MAINTENANCE	2.0T 8v 108kw RGX (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	2.0T 8v 108kw RGX (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	2.0T 8v 108kw RGX (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	2.0T 8v 108kw RGX (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	2.1 TD 12v 81kw P8C (95-03)	A/T AL4 AUTODETECT
 Expert 1 (95-06)	MAINTENANCE	2.1 TD 12v 81kw P8C (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	2.1 TD 12v 81kw P8C (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	2.1 TD 12v 81kw P8C (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	MAINTENANCE	2.1 TD 12v 81kw P8C (95-03)	BOSCH ABS ABR 5.3
 Expert 1 (95-06)	SERVICE LIGHT RES	1.9 TD 8v 66kw DHX (95-06)	MANUAL
 Expert 1 (95-06)	SERVICE LIGHT RES	2.0 16v 100kw RFN (95-06)	MANUAL
 Expert 2 (07-..)	ABS	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH ABS 8
 Expert 2 (07-..)	ABS	2.0 16v 103kw RFH (07-..)	BOSCH ABS 8
 Expert 2 (07-..)	ABS	2.0 HDI 16v 100kw RHR-FAP (07-..)	BOSCH ABS 8
 Expert 2 (07-..)	ABS	2.0 HDI 16v 88kw RHG (07-..)	BOSCH ABS 8
 Expert 2 (07-..)	ABS	2.0 HDI 16v 88kw RHK (07-..)	BOSCH ABS 8
 Expert 2 (07-..)	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH ABS 8.0 AUTODETECT
 Expert 2 (07-..)	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH ABS 8.1 AUTODETECT
 Expert 2 (07-..)	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH ESP 8.0 AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Expert 2 (07-..)	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH ESP 8.1 AUTODETECT
 Expert 2 (07-..)	ABS + TRACT. CONT	2.0 16v 103kw RFH (07-..)	BOSCH ABS 8.0 AUTODETECT
 Expert 2 (07-..)	ABS + TRACT. CONT	2.0 16v 103kw RFH (07-..)	BOSCH ABS 8.1 AUTODETECT
 Expert 2 (07-..)	ABS + TRACT. CONT	2.0 16v 103kw RFH (07-..)	BOSCH ESP 8.0 AUTODETECT
 Expert 2 (07-..)	ABS + TRACT. CONT	2.0 16v 103kw RFH (07-..)	BOSCH ESP 8.1 AUTODETECT
 Expert 2 (07-..)	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP (07-..)	BOSCH ABS 8.0 AUTODETECT
 Expert 2 (07-..)	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP (07-..)	BOSCH ABS 8.1 AUTODETECT
 Expert 2 (07-..)	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP (07-..)	BOSCH ESP 8.0 AUTODETECT
 Expert 2 (07-..)	ABS + TRACT. CONT	2.0 HDI 16v 100kw RHR-FAP (07-..)	BOSCH ESP 8.1 AUTODETECT
 Expert 2 (07-..)	ABS + TRACT. CONT	2.0 HDI 16v 88kw RHG (07-..)	BOSCH ABS 8.0 AUTODETECT
 Expert 2 (07-..)	ABS + TRACT. CONT	2.0 HDI 16v 88kw RHG (07-..)	BOSCH ABS 8.1 AUTODETECT
 Expert 2 (07-..)	ABS + TRACT. CONT	2.0 HDI 16v 88kw RHG (07-..)	BOSCH ESP 8.0 AUTODETECT
 Expert 2 (07-..)	ABS + TRACT. CONT	2.0 HDI 16v 88kw RHG (07-..)	BOSCH ESP 8.1 AUTODETECT
 Expert 2 (07-..)	ABS + TRACT. CONT	2.0 HDI 16v 88kw RHK (07-..)	BOSCH ABS 8.0 AUTODETECT
 Expert 2 (07-..)	ABS + TRACT. CONT	2.0 HDI 16v 88kw RHK (07-..)	BOSCH ABS 8.1 AUTODETECT
 Expert 2 (07-..)	ABS + TRACT. CONT	2.0 HDI 16v 88kw RHK (07-..)	BOSCH ESP 8.0 AUTODETECT
 Expert 2 (07-..)	ABS + TRACT. CONT	2.0 HDI 16v 88kw RHK (07-..)	BOSCH ESP 8.1 AUTODETECT
 Expert 2 (07-..)	AIRBAG	1.6 HDI 16v 66kw 9HU (07-..)	AirBag CENTRAL AUTODETECT
 Expert 2 (07-..)	AIRBAG	1.6 HDI 16v 66kw 9HU (07-..)	Temic SRS
 Expert 2 (07-..)	AIRBAG	2.0 16v 103kw RFH (07-..)	AirBag CENTRAL AUTODETECT
 Expert 2 (07-..)	AIRBAG	2.0 16v 103kw RFH (07-..)	Temic SRS
 Expert 2 (07-..)	AIRBAG	2.0 HDI 16v 100kw RHR-FAP (07-..)	AirBag CENTRAL AUTODETECT
 Expert 2 (07-..)	AIRBAG	2.0 HDI 16v 100kw RHR-FAP (07-..)	Temic SRS
 Expert 2 (07-..)	AIRBAG	2.0 HDI 16v 88kw RHG (07-..)	AirBag CENTRAL AUTODETECT
 Expert 2 (07-..)	AIRBAG	2.0 HDI 16v 88kw RHK (07-..)	AirBag CENTRAL AUTODETECT
 Expert 2 (07-..)	AIRBAG	2.0 HDI 16v 88kw RHK (07-..)	Temic SRS
 Expert 2 (07-..)	ANTITHEFT	1.6 HDI 16v 66kw 9HU (07-..)	Alarm PSA2 AUTODETECT
 Expert 2 (07-..)	ANTITHEFT	2.0 16v 103kw RFH (07-..)	Alarm PSA2 AUTODETECT
 Expert 2 (07-..)	ANTITHEFT	2.0 HDI 16v 100kw RHR-FAP (07-..)	Alarm PSA2 AUTODETECT
 Expert 2 (07-..)	ANTITHEFT	2.0 HDI 16v 88kw RHG (07-..)	Alarm PSA2 AUTODETECT
 Expert 2 (07-..)	ANTITHEFT	2.0 HDI 16v 88kw RHK (07-..)	Alarm PSA2 AUTODETECT
 Expert 2 (07-..)	AUTOM. TRANSMISSI	1.6 HDI 16v 66kw 9HU (07-..)	Var.1
 Expert 2 (07-..)	AUTOM. TRANSMISSI	1.6 HDI 16v 66kw 9HU (07-..)	Var.2
 Expert 2 (07-..)	AUTOM. TRANSMISSI	1.6 HDI 16v 66kw 9HU (07-..)	Var.3
 Expert 2 (07-..)	AUTOM. TRANSMISSI	2.0 16v 103kw RFH (07-..)	Var.1
 Expert 2 (07-..)	AUTOM. TRANSMISSI	2.0 16v 103kw RFH (07-..)	Var.2
 Expert 2 (07-..)	AUTOM. TRANSMISSI	2.0 16v 103kw RFH (07-..)	Var.3
 Expert 2 (07-..)	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP (07-..)	Var.1
 Expert 2 (07-..)	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP (07-..)	Var.2
 Expert 2 (07-..)	AUTOM. TRANSMISSI	2.0 HDI 16v 100kw RHR-FAP (07-..)	Var.3
 Expert 2 (07-..)	AUTOM. TRANSMISSI	2.0 HDI 16v 88kw RHG (07-..)	Var.1
 Expert 2 (07-..)	AUTOM. TRANSMISSI	2.0 HDI 16v 88kw RHG (07-..)	Var.2
 Expert 2 (07-..)	AUTOM. TRANSMISSI	2.0 HDI 16v 88kw RHG (07-..)	Var.3
 Expert 2 (07-..)	AUTOM. TRANSMISSI	2.0 HDI 16v 88kw RHK (07-..)	Var.1
 Expert 2 (07-..)	AUTOM. TRANSMISSI	2.0 HDI 16v 88kw RHK (07-..)	Var.2
 Expert 2 (07-..)	AUTOM. TRANSMISSI	2.0 HDI 16v 88kw RHK (07-..)	Var.3
 Expert 2 (07-..)	AUX. HEATING	1.6 HDI 16v 66kw 9HU (07-..)	AUTODETECT
 Expert 2 (07-..)	AUX. HEATING	2.0 16v 103kw RFH (07-..)	AUTODETECT
 Expert 2 (07-..)	AUX. HEATING	2.0 HDI 16v 100kw RHR-FAP (07-..)	AUTODETECT
 Expert 2 (07-..)	AUX. HEATING	2.0 HDI 16v 88kw RHG (07-..)	AUTODETECT
 Expert 2 (07-..)	AUX. HEATING	2.0 HDI 16v 88kw RHK (07-..)	AUTODETECT
 Expert 2 (07-..)	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HU (07-..)	Body Computer BSI AUTODETECT
 Expert 2 (07-..)	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HU (07-..)	Body Computer BSM AUTODETECT
 Expert 2 (07-..)	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HU (07-..)	Body Computer BSR AUTODETECT
 Expert 2 (07-..)	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HU (07-..)	Body Computer Chassis AUTODETECT
 Expert 2 (07-..)	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HU (07-..)	Valeo 2 1/2
 Expert 2 (07-..)	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HU (07-..)	Valeo 2 2/2
 Expert 2 (07-..)	CHASSIS NETWORK	2.0 16v 103kw RFH (07-..)	Body Computer BSI AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Expert 2 (07-..)	CHASSIS NETWORK	2.0 16v 103kw RFH (07-..)	Body Computer BSM AUTODETECT
 Expert 2 (07-..)	CHASSIS NETWORK	2.0 16v 103kw RFH (07-..)	Body Computer BSR AUTODETECT
 Expert 2 (07-..)	CHASSIS NETWORK	2.0 16v 103kw RFH (07-..)	Body Computer Chassis AUTODETECT
 Expert 2 (07-..)	CHASSIS NETWORK	2.0 16v 103kw RFH (07-..)	Valeo 2 1/2
 Expert 2 (07-..)	CHASSIS NETWORK	2.0 16v 103kw RFH (07-..)	Valeo 2 2/2
 Expert 2 (07-..)	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP (07-..)	Body Computer BSI AUTODETECT
 Expert 2 (07-..)	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP (07-..)	Body Computer BSM AUTODETECT
 Expert 2 (07-..)	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP (07-..)	Body Computer BSR AUTODETECT
 Expert 2 (07-..)	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP (07-..)	Body Computer Chassis AUTODETECT
 Expert 2 (07-..)	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP (07-..)	Valeo 2 1/2
 Expert 2 (07-..)	CHASSIS NETWORK	2.0 HDI 16v 100kw RHR-FAP (07-..)	Valeo 2 2/2
 Expert 2 (07-..)	CHASSIS NETWORK	2.0 HDI 16v 88kw RHG (07-..)	Body Computer BSI AUTODETECT
 Expert 2 (07-..)	CHASSIS NETWORK	2.0 HDI 16v 88kw RHG (07-..)	Body Computer BSM AUTODETECT
 Expert 2 (07-..)	CHASSIS NETWORK	2.0 HDI 16v 88kw RHG (07-..)	Body Computer BSR AUTODETECT
 Expert 2 (07-..)	CHASSIS NETWORK	2.0 HDI 16v 88kw RHG (07-..)	Body Computer Chassis AUTODETECT
 Expert 2 (07-..)	CHASSIS NETWORK	2.0 HDI 16v 88kw RHG (07-..)	Valeo 2 1/2
 Expert 2 (07-..)	CHASSIS NETWORK	2.0 HDI 16v 88kw RHG (07-..)	Valeo 2 2/2
 Expert 2 (07-..)	CHASSIS NETWORK	2.0 HDI 16v 88kw RHK (07-..)	Body Computer BSI AUTODETECT
 Expert 2 (07-..)	CHASSIS NETWORK	2.0 HDI 16v 88kw RHK (07-..)	Body Computer BSM AUTODETECT
 Expert 2 (07-..)	CHASSIS NETWORK	2.0 HDI 16v 88kw RHK (07-..)	Body Computer BSR AUTODETECT
 Expert 2 (07-..)	CHASSIS NETWORK	2.0 HDI 16v 88kw RHK (07-..)	Body Computer Chassis AUTODETECT
 Expert 2 (07-..)	CHASSIS NETWORK	2.0 HDI 16v 88kw RHK (07-..)	Valeo 2 1/2
 Expert 2 (07-..)	CHASSIS NETWORK	2.0 HDI 16v 88kw RHK (07-..)	Valeo 2 2/2
 Expert 2 (07-..)	CLIMA	1.6 HDI 16v 66kw 9HU (07-..)	CLIMA AUTODETECT
 Expert 2 (07-..)	CLIMA	2.0 16v 103kw RFH (07-..)	CLIMA AUTODETECT
 Expert 2 (07-..)	CLIMA	2.0 HDI 16v 100kw RHR-FAP (07-..)	CLIMA AUTODETECT
 Expert 2 (07-..)	CLIMA	2.0 HDI 16v 88kw RHG (07-..)	CLIMA AUTODETECT
 Expert 2 (07-..)	CLIMA	2.0 HDI 16v 88kw RHK (07-..)	CLIMA AUTODETECT
 Expert 2 (07-..)	DASHBOARD	1.6 HDI 16v 66kw 9HU (07-..)	AUTODETECT
 Expert 2 (07-..)	DASHBOARD	1.6 HDI 16v 66kw 9HU (07-..)	Marelli Dashboard PSA
 Expert 2 (07-..)	DASHBOARD	2.0 16v 103kw RFH (07-..)	AUTODETECT
 Expert 2 (07-..)	DASHBOARD	2.0 16v 103kw RFH (07-..)	Marelli Dashboard PSA
 Expert 2 (07-..)	DASHBOARD	2.0 HDI 16v 100kw RHR-FAP (07-..)	AUTODETECT
 Expert 2 (07-..)	DASHBOARD	2.0 HDI 16v 100kw RHR-FAP (07-..)	Marelli Dashboard PSA
 Expert 2 (07-..)	DASHBOARD	2.0 HDI 16v 88kw RHG (07-..)	AUTODETECT
 Expert 2 (07-..)	DASHBOARD	2.0 HDI 16v 88kw RHG (07-..)	Marelli Dashboard PSA
 Expert 2 (07-..)	DASHBOARD	2.0 HDI 16v 88kw RHK (07-..)	AUTODETECT
 Expert 2 (07-..)	DASHBOARD	2.0 HDI 16v 88kw RHK (07-..)	Marelli Dashboard PSA
 Expert 2 (07-..)	ELECTRIC STEERING	1.6 HDI 16v 66kw 9HU (07-..)	AUTODETECT
 Expert 2 (07-..)	ELECTRIC STEERING	2.0 16v 103kw RFH (07-..)	AUTODETECT
 Expert 2 (07-..)	ELECTRIC STEERING	2.0 HDI 16v 100kw RHR-FAP (07-..)	AUTODETECT
 Expert 2 (07-..)	ELECTRIC STEERING	2.0 HDI 16v 88kw RHG (07-..)	AUTODETECT
 Expert 2 (07-..)	ELECTRIC STEERING	2.0 HDI 16v 88kw RHK (07-..)	AUTODETECT
 Expert 2 (07-..)	ENGINE MANAGEME	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH EDC 16 34 Common Rail
 Expert 2 (07-..)	ENGINE MANAGEME	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH EDC16 C34 Common Rail AUTOD
 Expert 2 (07-..)	ENGINE MANAGEME	2.0 16v 103kw RFH (07-..)	Marelli MM6KP AUTODETECT
 Expert 2 (07-..)	ENGINE MANAGEME	2.0 HDI 16v 100kw RHR-FAP (07-..)	SIEMENS SID 803A Common Rail AUTOD
 Expert 2 (07-..)	ENGINE MANAGEME	2.0 HDI 16v 88kw RHG (07-..)	SIEMENS SID 803A Common Rail AUTOD
 Expert 2 (07-..)	ENGINE MANAGEME	2.0 HDI 16v 88kw RHK (07-..)	SIEMENS SID 803A Common Rail AUTOD
 Expert 2 (07-..)	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	AirBag CENTRAL AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	AirBag CENTRAL AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH ABS 8.0 AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH ABS 8.0 AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH EDC16 C34 Common Rail AUTOD
 Expert 2 (07-..)	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH EDC16 C34 Common Rail AUTOD
 Expert 2 (07-..)	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH EDC16 C34 Common Rail AUTOD
 Expert 2 (07-..)	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH EDC16 C34 Common Rail AUTOD
 Expert 2 (07-..)	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH EDC16 C34 Common Rail AUTOD
 Expert 2 (07-..)	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH EDC16 C34 Common Rail AUTOD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Expert 2 (07-..)	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH EDC16 C34 Common Rail AUTOD
 Expert 2 (07-..)	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH ESP 8.0 AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH ESP 8.0 AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH ESP 8.1 AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	BOSCH ESP 8.1 AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	MANUAL
 Expert 2 (07-..)	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	Marelli Dashboard PSA
 Expert 2 (07-..)	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	Valeo 2 1/2
 Expert 2 (07-..)	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	Valeo 2 1/2
 Expert 2 (07-..)	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	Var.1
 Expert 2 (07-..)	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	Var.2
 Expert 2 (07-..)	MAINTENANCE	1.6 HDI 16v 66kw 9HU (07-..)	Var.3
 Expert 2 (07-..)	MAINTENANCE	2.0 16v 103kw RFH (07-..)	AirBag CENTRAL AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	2.0 16v 103kw RFH (07-..)	AirBag CENTRAL AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	2.0 16v 103kw RFH (07-..)	BOSCH ABS 8.0 AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	2.0 16v 103kw RFH (07-..)	BOSCH ABS 8.0 AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	2.0 16v 103kw RFH (07-..)	BOSCH ESP 8.0 AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	2.0 16v 103kw RFH (07-..)	BOSCH ESP 8.0 AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	2.0 16v 103kw RFH (07-..)	BOSCH ESP 8.1 AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	2.0 16v 103kw RFH (07-..)	BOSCH ESP 8.1 AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	2.0 16v 103kw RFH (07-..)	MANUAL
 Expert 2 (07-..)	MAINTENANCE	2.0 16v 103kw RFH (07-..)	Marelli Dashboard PSA
 Expert 2 (07-..)	MAINTENANCE	2.0 16v 103kw RFH (07-..)	Valeo 2 1/2
 Expert 2 (07-..)	MAINTENANCE	2.0 16v 103kw RFH (07-..)	Valeo 2 1/2
 Expert 2 (07-..)	MAINTENANCE	2.0 16v 103kw RFH (07-..)	Var.1
 Expert 2 (07-..)	MAINTENANCE	2.0 16v 103kw RFH (07-..)	Var.2
 Expert 2 (07-..)	MAINTENANCE	2.0 16v 103kw RFH (07-..)	Var.3
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	AirBag CENTRAL AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	AirBag CENTRAL AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	BOSCH ABS 8.0 AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	BOSCH ABS 8.0 AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	BOSCH ESP 8.0 AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	BOSCH ESP 8.0 AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	BOSCH ESP 8.1 AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	BOSCH ESP 8.1 AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	MANUAL
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	Marelli Dashboard PSA
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	SIEMENS SID 803A Common Rail AUTOD
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	SIEMENS SID 803A Common Rail AUTOD
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	SIEMENS SID 803A Common Rail AUTOD
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	Valeo 2 1/2
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	Valeo 2 1/2
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	Var.1
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	Var.2
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 100kw RHR-FAP (07-..)	Var.3
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	AirBag CENTRAL AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	AirBag CENTRAL AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	BOSCH ABS 8.0 AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	BOSCH ABS 8.0 AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	BOSCH ESP 8.0 AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	BOSCH ESP 8.0 AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	BOSCH ESP 8.1 AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	BOSCH ESP 8.1 AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	MANUAL
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	Marelli Dashboard PSA
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	SIEMENS SID 803A Common Rail AUTOD
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	SIEMENS SID 803A Common Rail AUTOD
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	SIEMENS SID 803A Common Rail AUTOD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	Valeo 2 1/2
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	Valeo 2 1/2
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	Var.1
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	Var.2
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHG (07-..)	Var.3
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	AirBag CENTRAL AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	AirBag CENTRAL AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	BOSCH ABS 8.0 AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	BOSCH ABS 8.0 AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	BOSCH ESP 8.0 AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	BOSCH ESP 8.0 AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	BOSCH ESP 8.1 AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	BOSCH ESP 8.1 AUTODETECT
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	MANUAL
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	Marelli Dashboard PSA
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	SIEMENS SID 803A Common Rail AUTOD
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	SIEMENS SID 803A Common Rail AUTOD
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	SIEMENS SID 803A Common Rail AUTOD
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	Valeo 2 1/2
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	Valeo 2 1/2
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	Var.1
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	Var.2
 Expert 2 (07-..)	MAINTENANCE	2.0 HDI 16v 88kw RHK (07-..)	Var.3
 Expert 2 (07-..)	NAVIGATION	1.6 HDI 16v 66kw 9HU (07-..)	AUTODETECT
 Expert 2 (07-..)	NAVIGATION	1.6 HDI 16v 66kw 9HU (07-..)	AUTODETECT
 Expert 2 (07-..)	NAVIGATION	2.0 16v 103kw RFH (07-..)	AUTODETECT
 Expert 2 (07-..)	NAVIGATION	2.0 16v 103kw RFH (07-..)	AUTODETECT
 Expert 2 (07-..)	NAVIGATION	2.0 HDI 16v 100kw RHR-FAP (07-..)	AUTODETECT
 Expert 2 (07-..)	NAVIGATION	2.0 HDI 16v 100kw RHR-FAP (07-..)	AUTODETECT
 Expert 2 (07-..)	NAVIGATION	2.0 HDI 16v 88kw RHG (07-..)	AUTODETECT
 Expert 2 (07-..)	NAVIGATION	2.0 HDI 16v 88kw RHG (07-..)	AUTODETECT
 Expert 2 (07-..)	NAVIGATION	2.0 HDI 16v 88kw RHK (07-..)	AUTODETECT
 Expert 2 (07-..)	NAVIGATION	2.0 HDI 16v 88kw RHK (07-..)	AUTODETECT
 Expert 2 (07-..)	NAVIGATION	2.0 HDI 16v 88kw RHK (07-..)	AUTODETECT
 Expert 2 (07-..)	PARKING HELP	1.6 HDI 16v 66kw 9HU (07-..)	AUTODETECT
 Expert 2 (07-..)	PARKING HELP	2.0 16v 103kw RFH (07-..)	AUTODETECT
 Expert 2 (07-..)	PARKING HELP	2.0 HDI 16v 100kw RHR-FAP (07-..)	AUTODETECT
 Expert 2 (07-..)	PARKING HELP	2.0 HDI 16v 88kw RHG (07-..)	AUTODETECT
 Expert 2 (07-..)	PARKING HELP	2.0 HDI 16v 88kw RHK (07-..)	AUTODETECT
 Expert 2 (07-..)	PHONE	1.6 HDI 16v 66kw 9HU (07-..)	AUTODETECT
 Expert 2 (07-..)	PHONE	2.0 16v 103kw RFH (07-..)	AUTODETECT
 Expert 2 (07-..)	PHONE	2.0 HDI 16v 100kw RHR-FAP (07-..)	AUTODETECT
 Expert 2 (07-..)	PHONE	2.0 HDI 16v 88kw RHG (07-..)	AUTODETECT
 Expert 2 (07-..)	PHONE	2.0 HDI 16v 88kw RHK (07-..)	AUTODETECT
 Expert 2 (07-..)	RADIO / CD	1.6 HDI 16v 66kw 9HU (07-..)	AudioSystem AUTODETECT
 Expert 2 (07-..)	RADIO / CD	1.6 HDI 16v 66kw 9HU (07-..)	Blaupunkt AudioSystem
 Expert 2 (07-..)	RADIO / CD	1.6 HDI 16v 66kw 9HU (07-..)	CD Changer AUTODETECT
 Expert 2 (07-..)	RADIO / CD	2.0 16v 103kw RFH (07-..)	AudioSystem AUTODETECT
 Expert 2 (07-..)	RADIO / CD	2.0 16v 103kw RFH (07-..)	Blaupunkt AudioSystem
 Expert 2 (07-..)	RADIO / CD	2.0 16v 103kw RFH (07-..)	CD Changer AUTODETECT
 Expert 2 (07-..)	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP (07-..)	AudioSystem AUTODETECT
 Expert 2 (07-..)	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP (07-..)	Blaupunkt AudioSystem
 Expert 2 (07-..)	RADIO / CD	2.0 HDI 16v 100kw RHR-FAP (07-..)	CD Changer AUTODETECT
 Expert 2 (07-..)	RADIO / CD	2.0 HDI 16v 88kw RHG (07-..)	AudioSystem AUTODETECT
 Expert 2 (07-..)	RADIO / CD	2.0 HDI 16v 88kw RHG (07-..)	Blaupunkt AudioSystem
 Expert 2 (07-..)	RADIO / CD	2.0 HDI 16v 88kw RHG (07-..)	CD Changer AUTODETECT
 Expert 2 (07-..)	RADIO / CD	2.0 HDI 16v 88kw RHK (07-..)	AudioSystem AUTODETECT
 Expert 2 (07-..)	RADIO / CD	2.0 HDI 16v 88kw RHK (07-..)	Blaupunkt AudioSystem
 Expert 2 (07-..)	RADIO / CD	2.0 HDI 16v 88kw RHK (07-..)	CD Changer AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Expert 2 (07-..)	RAIN-LUMINOSITY S	1.6 HDI 16v 66kw 9HU (07-..)	AUTODETECT
 Expert 2 (07-..)	RAIN-LUMINOSITY S	2.0 16v 103kw RFH (07-..)	AUTODETECT
 Expert 2 (07-..)	RAIN-LUMINOSITY S	2.0 HDI 16v 100kw RHR-FAP (07-..)	AUTODETECT
 Expert 2 (07-..)	RAIN-LUMINOSITY S	2.0 HDI 16v 88kw RHG (07-..)	AUTODETECT
 Expert 2 (07-..)	RAIN-LUMINOSITY S	2.0 HDI 16v 88kw RHK (07-..)	AUTODETECT
 Expert 2 (07-..)	REAR CLIMA	1.6 HDI 16v 66kw 9HU (07-..)	AUTODETECT
 Expert 2 (07-..)	REAR CLIMA	2.0 16v 103kw RFH (07-..)	AUTODETECT
 Expert 2 (07-..)	REAR CLIMA	2.0 HDI 16v 100kw RHR-FAP (07-..)	AUTODETECT
 Expert 2 (07-..)	REAR CLIMA	2.0 HDI 16v 88kw RHG (07-..)	AUTODETECT
 Expert 2 (07-..)	REAR CLIMA	2.0 HDI 16v 88kw RHK (07-..)	AUTODETECT
 Expert 2 (07-..)	SERVICE LIGHT RES	1.6 HDI 16v 66kw 9HU (07-..)	MANUAL
 Expert 2 (07-..)	SERVICE LIGHT RES	2.0 16v 103kw RFH (07-..)	MANUAL
 Expert 2 (07-..)	SERVICE LIGHT RES	2.0 HDI 16v 100kw RHR-FAP (07-..)	MANUAL
 Expert 2 (07-..)	SERVICE LIGHT RES	2.0 HDI 16v 88kw RHG (07-..)	MANUAL
 Expert 2 (07-..)	SERVICE LIGHT RES	2.0 HDI 16v 88kw RHK (07-..)	MANUAL
 Expert 2 (07-..)	STEERING COLUMN	1.6 HDI 16v 66kw 9HU (07-..)	AUTODETECT
 Expert 2 (07-..)	STEERING COLUMN	2.0 16v 103kw RFH (07-..)	AUTODETECT
 Expert 2 (07-..)	STEERING COLUMN	2.0 HDI 16v 100kw RHR-FAP (07-..)	AUTODETECT
 Expert 2 (07-..)	STEERING COLUMN	2.0 HDI 16v 88kw RHG (07-..)	AUTODETECT
 Expert 2 (07-..)	STEERING COLUMN	2.0 HDI 16v 88kw RHK (07-..)	AUTODETECT
 Expert 2 (07-..)	SUSPENSION CONTR	1.6 HDI 16v 66kw 9HU (07-..)	AUTODETECT
 Expert 2 (07-..)	SUSPENSION CONTR	2.0 16v 103kw RFH (07-..)	AUTODETECT
 Expert 2 (07-..)	SUSPENSION CONTR	2.0 HDI 16v 100kw RHR-FAP (07-..)	AUTODETECT
 Expert 2 (07-..)	SUSPENSION CONTR	2.0 HDI 16v 88kw RHG (07-..)	AUTODETECT
 Expert 2 (07-..)	SUSPENSION CONTR	2.0 HDI 16v 88kw RHK (07-..)	AUTODETECT
 Expert 2 (07-..)	SWITCHLIGHT MODU	1.6 HDI 16v 66kw 9HU (07-..)	DELPHI
 Expert 2 (07-..)	SWITCHLIGHT MODU	2.0 16v 103kw RFH (07-..)	DELPHI
 Expert 2 (07-..)	SWITCHLIGHT MODU	2.0 HDI 16v 100kw RHR-FAP (07-..)	DELPHI
 Expert 2 (07-..)	SWITCHLIGHT MODU	2.0 HDI 16v 88kw RHG (07-..)	DELPHI
 Expert 2 (07-..)	SWITCHLIGHT MODU	2.0 HDI 16v 88kw RHK (07-..)	DELPHI
 Expert 2 (07-..)	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HU (07-..)	Display A+ AUTODETECT
 Expert 2 (07-..)	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HU (07-..)	Display C- AUTODETECT
 Expert 2 (07-..)	VISUAL./TELEMATIC	2.0 16v 103kw RFH (07-..)	Display A+ AUTODETECT
 Expert 2 (07-..)	VISUAL./TELEMATIC	2.0 16v 103kw RFH (07-..)	Display C- AUTODETECT
 Expert 2 (07-..)	VISUAL./TELEMATIC	2.0 HDI 16v 100kw RHR-FAP (07-..)	Display A+ AUTODETECT
 Expert 2 (07-..)	VISUAL./TELEMATIC	2.0 HDI 16v 100kw RHR-FAP (07-..)	Display A+ AUTODETECT
 Expert 2 (07-..)	VISUAL./TELEMATIC	2.0 HDI 16v 88kw RHG (07-..)	Display A+ AUTODETECT
 Expert 2 (07-..)	VISUAL./TELEMATIC	2.0 HDI 16v 88kw RHG (07-..)	Display C- AUTODETECT
 Expert 2 (07-..)	VISUAL./TELEMATIC	2.0 HDI 16v 88kw RHK (07-..)	Display A+ AUTODETECT
 Expert 2 (07-..)	VISUAL./TELEMATIC	2.0 HDI 16v 88kw RHK (07-..)	Display C- AUTODETECT
 Partner 1 (96-02)	ABS	1.1 44kw HDZ	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	ABS	1.4 55kw KFW	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	ABS	1.4 55kw KFX	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	ABS	1.6 16v 80kw NFU	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	ABS	1.6 16v 82kw NFU	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	ABS	1.8 66kw LFX	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	ABS	1.8 D 44kw A9A	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	ABS	1.9 D 51kw DJY	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	ABS	1.9 D 51kw WJZ	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	ABS	1.9 D 52kw D9B	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	ABS	1.9 D 52kw WJY	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	ABS	2.0 HDI 66kw RHY	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	AIRBAG	1.1 44kw HDZ	AKF- Autoliv AirBag no SIDE AB
 Partner 1 (96-02)	AIRBAG	1.4 55kw KFW	AKF- Autoliv AirBag no SIDE AB
 Partner 1 (96-02)	AIRBAG	1.4 55kw KFX	AKF- Autoliv AirBag no SIDE AB
 Partner 1 (96-02)	AIRBAG	1.6 16v 80kw NFU	AKF- Autoliv AirBag no SIDE AB
 Partner 1 (96-02)	AIRBAG	1.6 16v 82kw NFU	AKF- Autoliv AirBag no SIDE AB
 Partner 1 (96-02)	AIRBAG	1.8 66kw LFX	AKF- Autoliv AirBag no SIDE AB

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Partner 1 (96-02)	AIRBAG	1.8 D 44kw A9A	AKF- Autoliv AirBag no SIDE AB
 Partner 1 (96-02)	AIRBAG	1.9 D 51kw DJY	AKF- Autoliv AirBag no SIDE AB
 Partner 1 (96-02)	AIRBAG	1.9 D 51kw WJZ	AKF- Autoliv AirBag no SIDE AB
 Partner 1 (96-02)	AIRBAG	1.9 D 52kw D9B	AKF- Autoliv AirBag no SIDE AB
 Partner 1 (96-02)	AIRBAG	1.9 D 52kw WJY	AKF- Autoliv AirBag no SIDE AB
 Partner 1 (96-02)	AIRBAG	2.0 HDI 66kw RHY	AKF- Autoliv AirBag no SIDE AB
 Partner 1 (96-02)	CHASSIS NETWORK	1.1 44kw HDZ	Body Computer BSI
 Partner 1 (96-02)	CHASSIS NETWORK	1.1 44kw HFX	Body Computer BSI
 Partner 1 (96-02)	CHASSIS NETWORK	1.4 55kw KFW	Body Computer BSI
 Partner 1 (96-02)	CHASSIS NETWORK	1.4 55kw KFX	Body Computer BSI
 Partner 1 (96-02)	CHASSIS NETWORK	1.6 16v 80kw NFU	Body Computer BSI
 Partner 1 (96-02)	CHASSIS NETWORK	1.6 16v 82kw NFU	Body Computer BSI
 Partner 1 (96-02)	CHASSIS NETWORK	1.8 66kw LFX	Body Computer BSI
 Partner 1 (96-02)	CHASSIS NETWORK	1.8 D 44kw A9A	Body Computer BSI
 Partner 1 (96-02)	CHASSIS NETWORK	1.9 D 51kw DJY	Body Computer BSI
 Partner 1 (96-02)	CHASSIS NETWORK	1.9 D 51kw WJZ	Body Computer BSI
 Partner 1 (96-02)	CHASSIS NETWORK	1.9 D 52kw D9B	Body Computer BSI
 Partner 1 (96-02)	CHASSIS NETWORK	1.9 D 52kw WJY	Body Computer BSI
 Partner 1 (96-02)	CHASSIS NETWORK	2.0 HDI 66kw RHY	Body Computer BSI
 Partner 1 (96-02)	DASHBOARD	1.1 44kw HDZ	
 Partner 1 (96-02)	DASHBOARD	1.1 44kw HFX	
 Partner 1 (96-02)	DASHBOARD	1.4 55kw KFW	
 Partner 1 (96-02)	DASHBOARD	1.4 55kw KFX	
 Partner 1 (96-02)	DASHBOARD	1.6 16v 80kw NFU	
 Partner 1 (96-02)	DASHBOARD	1.6 16v 82kw NFU	
 Partner 1 (96-02)	DASHBOARD	1.8 66kw LFX	
 Partner 1 (96-02)	DASHBOARD	1.8 D 44kw A9A	
 Partner 1 (96-02)	DASHBOARD	1.9 D 51kw DJY	
 Partner 1 (96-02)	DASHBOARD	1.9 D 51kw WJZ	
 Partner 1 (96-02)	DASHBOARD	1.9 D 52kw D9B	
 Partner 1 (96-02)	DASHBOARD	1.9 D 52kw WJY	
 Partner 1 (96-02)	DASHBOARD	2.0 HDI 66kw RHY	
 Partner 1 (96-02)	DIESEL MANAGEME	1.9 D 52kw WJY	LUCAS Diesel DCN2
 Partner 1 (96-02)	ENGINE MANAGEME	1.1 44kw HDZ	BOSCH MonoMotronic MA3.1
 Partner 1 (96-02)	ENGINE MANAGEME	1.1 44kw HFX	BOSCH M7.4.4
 Partner 1 (96-02)	ENGINE MANAGEME	1.4 55kw KFW	SAGEM S2000
 Partner 1 (96-02)	ENGINE MANAGEME	1.4 55kw KFX	Marelli MM 1AP.81
 Partner 1 (96-02)	ENGINE MANAGEME	1.4 55kw KFX	SAGEM SL 96
 Partner 1 (96-02)	ENGINE MANAGEME	1.6 16v 80kw NFU	BOSCH ME7.4.4
 Partner 1 (96-02)	ENGINE MANAGEME	1.6 16v 82kw NFU	BOSCH ME7.4.4
 Partner 1 (96-02)	ENGINE MANAGEME	1.9 D 52kw WJY	LUCAS Diesel DCN2
 Partner 1 (96-02)	ENGINE MANAGEME	2.0 HDI 66kw RHY	BOSCH EDC 15 C2 Common Rail
 Partner 1 (96-02)	ENGINE MANAGEME	2.0 HDI 66kw RHY	SIEMENS Diesel SID 801 Common Rail
 Partner 1 (96-02)	ENGINE MANAGEME	2.0 HDI 66kw RHY	SIEMENS SID 801 Common Rail
 Partner 1 (96-02)	ENGINE MANAGEME	2.0 HDI 66kw RHY (...00)	BOSCH EDC 15 C2 Common Rail
 Partner 1 (96-02)	ENGINE MANAGEME	2.0 HDI 66kw RHY (03-..)	BOSCH EDC 15 C2 Common Rail
 Partner 1 (96-02)	KEY ENCODE	1.1 44kw HDZ (...02)	Valeo/Siemens
 Partner 1 (96-02)	KEY ENCODE	1.1 44kw HDZ (03-..)	VALEO Body Siemens
 Partner 1 (96-02)	KEY ENCODE	1.4 55kw KFW (...02)	Valeo/Siemens
 Partner 1 (96-02)	KEY ENCODE	1.4 55kw KFW (03-..)	VALEO Body Siemens
 Partner 1 (96-02)	KEY ENCODE	1.4 55kw KFX (...02)	Valeo/Siemens
 Partner 1 (96-02)	KEY ENCODE	1.4 55kw KFX (03-..)	VALEO Body Siemens
 Partner 1 (96-02)	KEY ENCODE	1.6 16v 80kw NFU (...02)	Valeo/Siemens
 Partner 1 (96-02)	KEY ENCODE	1.6 16v 80kw NFU (03-..)	VALEO Body Siemens
 Partner 1 (96-02)	KEY ENCODE	1.6 16v 82kw NFU (...02)	Valeo/Siemens
 Partner 1 (96-02)	KEY ENCODE	1.6 16v 82kw NFU (03-..)	VALEO Body Siemens
 Partner 1 (96-02)	KEY ENCODE	1.8 66kw LFX (...02)	Valeo/Siemens
 Partner 1 (96-02)	KEY ENCODE	1.8 66kw LFX (03-..)	VALEO Body Siemens

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Partner 1 (96-02)	KEY ENCODE	1.8 D 44kw A9A (.-02)	Valeo/Siemens
 Partner 1 (96-02)	KEY ENCODE	1.8 D 44kw A9A (03-..)	VALEO Body Siemens
 Partner 1 (96-02)	KEY ENCODE	1.9 D 51kw DJY (.-02)	Valeo/Siemens
 Partner 1 (96-02)	KEY ENCODE	1.9 D 51kw DJY (03-..)	VALEO Body Siemens
 Partner 1 (96-02)	KEY ENCODE	1.9 D 51kw WJZ (.-02)	Valeo/Siemens
 Partner 1 (96-02)	KEY ENCODE	1.9 D 51kw WJZ (03-..)	VALEO Body Siemens
 Partner 1 (96-02)	KEY ENCODE	1.9 D 52kw D9B (.-02)	Valeo/Siemens
 Partner 1 (96-02)	KEY ENCODE	1.9 D 52kw D9B (03-..)	VALEO Body Siemens
 Partner 1 (96-02)	KEY ENCODE	1.9 D 52kw WJY (.-02)	Valeo/Siemens
 Partner 1 (96-02)	KEY ENCODE	1.9 D 52kw WJY (03-..)	VALEO Body Siemens
 Partner 1 (96-02)	KEY ENCODE	2.0 HDI 66kw RHY (.-02)	Valeo/Siemens
 Partner 1 (96-02)	KEY ENCODE	2.0 HDI 66kw RHY (03-..)	VALEO Body Siemens
 Partner 1 (96-02)	MAINTENANCE	1.1 44kw HDZ	
 Partner 1 (96-02)	MAINTENANCE	1.1 44kw HDZ	
 Partner 1 (96-02)	MAINTENANCE	1.1 44kw HDZ	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.1 44kw HDZ	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.1 44kw HDZ	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.1 44kw HDZ	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.1 44kw HFX	
 Partner 1 (96-02)	MAINTENANCE	1.1 44kw HFX	
 Partner 1 (96-02)	MAINTENANCE	1.4 55kw KFW	
 Partner 1 (96-02)	MAINTENANCE	1.4 55kw KFW	
 Partner 1 (96-02)	MAINTENANCE	1.4 55kw KFW	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.4 55kw KFW	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.4 55kw KFW	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.4 55kw KFW	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.4 55kw KFX	
 Partner 1 (96-02)	MAINTENANCE	1.4 55kw KFX	
 Partner 1 (96-02)	MAINTENANCE	1.4 55kw KFX	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.4 55kw KFX	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.4 55kw KFX	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.4 55kw KFX	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.6 16v 80kw NFU	
 Partner 1 (96-02)	MAINTENANCE	1.6 16v 80kw NFU	
 Partner 1 (96-02)	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.6 16v 82kw NFU	
 Partner 1 (96-02)	MAINTENANCE	1.6 16v 82kw NFU	
 Partner 1 (96-02)	MAINTENANCE	1.6 16v 82kw NFU	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.6 16v 82kw NFU	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.6 16v 82kw NFU	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.6 16v 82kw NFU	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.8 66kw LFX	
 Partner 1 (96-02)	MAINTENANCE	1.8 66kw LFX	
 Partner 1 (96-02)	MAINTENANCE	1.8 66kw LFX	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.8 66kw LFX	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.8 66kw LFX	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.8 66kw LFX	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.8 D 44kw A9A	
 Partner 1 (96-02)	MAINTENANCE	1.8 D 44kw A9A	
 Partner 1 (96-02)	MAINTENANCE	1.8 D 44kw A9A	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.8 D 44kw A9A	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.8 D 44kw A9A	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.8 D 44kw A9A	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.9 D 51kw DJY	
 Partner 1 (96-02)	MAINTENANCE	1.9 D 51kw DJY	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Partner 1 (96-02)	MAINTENANCE	1.9 D 51kw DJY	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.9 D 51kw DJY	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.9 D 51kw DJY	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.9 D 51kw DJY	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.9 D 51kw WJZ	
 Partner 1 (96-02)	MAINTENANCE	1.9 D 51kw WJZ	
 Partner 1 (96-02)	MAINTENANCE	1.9 D 51kw WJZ	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.9 D 51kw WJZ	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.9 D 51kw WJZ	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.9 D 51kw WJZ	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.9 D 52kw D9B	
 Partner 1 (96-02)	MAINTENANCE	1.9 D 52kw D9B	
 Partner 1 (96-02)	MAINTENANCE	1.9 D 52kw D9B	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.9 D 52kw D9B	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.9 D 52kw D9B	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.9 D 52kw D9B	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.9 D 52kw WJY	
 Partner 1 (96-02)	MAINTENANCE	1.9 D 52kw WJY	
 Partner 1 (96-02)	MAINTENANCE	1.9 D 52kw WJY	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.9 D 52kw WJY	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.9 D 52kw WJY	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	1.9 D 52kw WJY	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	2.0 HDI 66kw RHY	
 Partner 1 (96-02)	MAINTENANCE	2.0 HDI 66kw RHY	
 Partner 1 (96-02)	MAINTENANCE	2.0 HDI 66kw RHY	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	2.0 HDI 66kw RHY	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	2.0 HDI 66kw RHY	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	2.0 HDI 66kw RHY	BOSCH ABS ABR 5.3
 Partner 1 (96-02)	MAINTENANCE	2.0 HDI 66kw RHY	BOSCH EDC 15 C2 Common Rail
 Partner 1 (96-02)	MAINTENANCE	2.0 HDI 66kw RHY (03-..)	BOSCH EDC 15 C2 Common Rail
 Partner 1 (96-02)	RADIO / CD	1.1 44kw HDZ	Var.1
 Partner 1 (96-02)	RADIO / CD	1.1 44kw HDZ	Var.2
 Partner 1 (96-02)	RADIO / CD	1.1 44kw HDZ	Var.3
 Partner 1 (96-02)	RADIO / CD	1.1 44kw HDZ	Var.4
 Partner 1 (96-02)	RADIO / CD	1.1 44kw HFX	Var.1
 Partner 1 (96-02)	RADIO / CD	1.1 44kw HFX	Var.2
 Partner 1 (96-02)	RADIO / CD	1.1 44kw HFX	Var.3
 Partner 1 (96-02)	RADIO / CD	1.1 44kw HFX	Var.4
 Partner 1 (96-02)	RADIO / CD	1.4 55kw KFW	Var.1
 Partner 1 (96-02)	RADIO / CD	1.4 55kw KFW	Var.2
 Partner 1 (96-02)	RADIO / CD	1.4 55kw KFW	Var.3
 Partner 1 (96-02)	RADIO / CD	1.4 55kw KFW	Var.4
 Partner 1 (96-02)	RADIO / CD	1.4 55kw KFX	Var.1
 Partner 1 (96-02)	RADIO / CD	1.4 55kw KFX	Var.2
 Partner 1 (96-02)	RADIO / CD	1.4 55kw KFX	Var.3
 Partner 1 (96-02)	RADIO / CD	1.4 55kw KFX	Var.4
 Partner 1 (96-02)	RADIO / CD	1.6 16v 80kw NFU	Var.1
 Partner 1 (96-02)	RADIO / CD	1.6 16v 80kw NFU	Var.2
 Partner 1 (96-02)	RADIO / CD	1.6 16v 80kw NFU	Var.3
 Partner 1 (96-02)	RADIO / CD	1.6 16v 80kw NFU	Var.4
 Partner 1 (96-02)	RADIO / CD	1.6 16v 82kw NFU	Var.1
 Partner 1 (96-02)	RADIO / CD	1.6 16v 82kw NFU	Var.2
 Partner 1 (96-02)	RADIO / CD	1.6 16v 82kw NFU	Var.3
 Partner 1 (96-02)	RADIO / CD	1.6 16v 82kw NFU	Var.4
 Partner 1 (96-02)	RADIO / CD	1.8 66kw LFX	Var.1
 Partner 1 (96-02)	RADIO / CD	1.8 66kw LFX	Var.2
 Partner 1 (96-02)	RADIO / CD	1.8 66kw LFX	Var.3
 Partner 1 (96-02)	RADIO / CD	1.8 66kw LFX	Var.4

Systems supported by ECUREADER / ECUDECODER (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Partner 1 (96-02)	RADIO / CD	1.8 D 44kw A9A	Var.1
 Partner 1 (96-02)	RADIO / CD	1.8 D 44kw A9A	Var.2
 Partner 1 (96-02)	RADIO / CD	1.8 D 44kw A9A	Var.3
 Partner 1 (96-02)	RADIO / CD	1.8 D 44kw A9A	Var.4
 Partner 1 (96-02)	RADIO / CD	1.9 D 51kw DJY	Var.1
 Partner 1 (96-02)	RADIO / CD	1.9 D 51kw DJY	Var.2
 Partner 1 (96-02)	RADIO / CD	1.9 D 51kw DJY	Var.3
 Partner 1 (96-02)	RADIO / CD	1.9 D 51kw DJY	Var.4
 Partner 1 (96-02)	RADIO / CD	1.9 D 51kw WJZ	Var.1
 Partner 1 (96-02)	RADIO / CD	1.9 D 51kw WJZ	Var.2
 Partner 1 (96-02)	RADIO / CD	1.9 D 51kw WJZ	Var.3
 Partner 1 (96-02)	RADIO / CD	1.9 D 51kw WJZ	Var.4
 Partner 1 (96-02)	RADIO / CD	1.9 D 52kw D9B	Var.1
 Partner 1 (96-02)	RADIO / CD	1.9 D 52kw D9B	Var.2
 Partner 1 (96-02)	RADIO / CD	1.9 D 52kw D9B	Var.3
 Partner 1 (96-02)	RADIO / CD	1.9 D 52kw D9B	Var.4
 Partner 1 (96-02)	RADIO / CD	1.9 D 52kw WJY	Var.1
 Partner 1 (96-02)	RADIO / CD	1.9 D 52kw WJY	Var.2
 Partner 1 (96-02)	RADIO / CD	1.9 D 52kw WJY	Var.3
 Partner 1 (96-02)	RADIO / CD	1.9 D 52kw WJY	Var.4
 Partner 1 (96-02)	RADIO / CD	2.0 HDI 66kw RHY	Var.1
 Partner 1 (96-02)	RADIO / CD	2.0 HDI 66kw RHY	Var.2
 Partner 1 (96-02)	RADIO / CD	2.0 HDI 66kw RHY	Var.3
 Partner 1 (96-02)	RADIO / CD	2.0 HDI 66kw RHY	Var.4
 Partner 1 Restyling (02-08)	ABS	1.1 44kw HFX	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	ABS	1.4 55kw KFW	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	ABS	1.6 16v 82kw N6A	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	ABS	1.6 16v 82kw NFU	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	ABS	1.6 HDI 16v 55kw 9HW	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	ABS	1.6 HDI 16v 66kw 9HX	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	ABS	1.9 D 51kw WJY	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	ABS	1.9 D 52kw D9B	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	ABS	1.9 D 52kw WJY	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	ABS	2.0 HDI 66kw RHY	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	AIRBAG	1.1 44kw HFX	AKF- Autoliv AirBag no SIDE AB
 Partner 1 Restyling (02-08)	AIRBAG	1.4 55kw KFW	AKF- Autoliv AirBag no SIDE AB
 Partner 1 Restyling (02-08)	AIRBAG	1.6 16v 82kw N6A	AKF- Autoliv AirBag no SIDE AB
 Partner 1 Restyling (02-08)	AIRBAG	1.6 16v 82kw NFU	AKF- Autoliv AirBag no SIDE AB
 Partner 1 Restyling (02-08)	AIRBAG	1.6 HDI 16v 55kw 9HW	AKF- Autoliv AirBag no SIDE AB
 Partner 1 Restyling (02-08)	AIRBAG	1.6 HDI 16v 66kw 9HX	AKF- Autoliv AirBag no SIDE AB
 Partner 1 Restyling (02-08)	AIRBAG	1.9 D 51kw WJY	AKF- Autoliv AirBag no SIDE AB
 Partner 1 Restyling (02-08)	AIRBAG	1.9 D 52kw D9B	AKF- Autoliv AirBag no SIDE AB
 Partner 1 Restyling (02-08)	AIRBAG	1.9 D 52kw WJY	AKF- Autoliv AirBag no SIDE AB
 Partner 1 Restyling (02-08)	AIRBAG	2.0 HDI 66kw RHY	AKF- Autoliv AirBag no SIDE AB
 Partner 1 Restyling (02-08)	CHASSIS NETWORK	1.1 44kw HFX	Body Computer BSI
 Partner 1 Restyling (02-08)	CHASSIS NETWORK	1.4 55kw KFW	Body Computer BSI
 Partner 1 Restyling (02-08)	CHASSIS NETWORK	1.6 16v 82kw N6A	Body Computer BSI
 Partner 1 Restyling (02-08)	CHASSIS NETWORK	1.6 16v 82kw NFU	Body Computer BSI
 Partner 1 Restyling (02-08)	CHASSIS NETWORK	1.6 HDI 16v 55kw 9HW	Body Computer BSI
 Partner 1 Restyling (02-08)	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	Body Computer BSI
 Partner 1 Restyling (02-08)	CHASSIS NETWORK	1.9 D 52kw D9B	Body Computer BSI
 Partner 1 Restyling (02-08)	CHASSIS NETWORK	1.9 D 52kw WJY	Body Computer BSI
 Partner 1 Restyling (02-08)	CHASSIS NETWORK	2.0 HDI 66kw RHY	Body Computer BSI
 Partner 1 Restyling (02-08)	DASHBOARD	1.1 44kw HFX	
 Partner 1 Restyling (02-08)	DASHBOARD	1.4 55kw KFW	
 Partner 1 Restyling (02-08)	DASHBOARD	1.6 16v 82kw N6A	
 Partner 1 Restyling (02-08)	DASHBOARD	1.6 16v 82kw NFU	
 Partner 1 Restyling (02-08)	DASHBOARD	1.6 HDI 16v 55kw 9HW	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Partner 1 Restyling (02-08)	DASHBOARD	1.6 HDI 16v 66kw 9HX	
 Partner 1 Restyling (02-08)	DASHBOARD	1.9 D 51kw WJY	
 Partner 1 Restyling (02-08)	DASHBOARD	1.9 D 52kw D9B	
 Partner 1 Restyling (02-08)	DASHBOARD	1.9 D 52kw WJY	
 Partner 1 Restyling (02-08)	DASHBOARD	2.0 HDI 66kw RHY	
 Partner 1 Restyling (02-08)	DIESEL MANAGEMEN	1.9 D 52kw WJY	LUCAS Diesel DCN2
 Partner 1 Restyling (02-08)	ENGINE MANAGEME	1.1 44kw HFX	BOSCH M7.4.4
 Partner 1 Restyling (02-08)	ENGINE MANAGEME	1.4 55kw KFW	SAGEM S2000
 Partner 1 Restyling (02-08)	ENGINE MANAGEME	1.6 16v 82kw N6A	BOSCH ME7.4.4
 Partner 1 Restyling (02-08)	ENGINE MANAGEME	1.6 16v 82kw NFU	BOSCH ME7.4.4
 Partner 1 Restyling (02-08)	ENGINE MANAGEME	1.6 HDI 16v 55kw 9HW (04-08)	EOBD
 Partner 1 Restyling (02-08)	ENGINE MANAGEME	1.9 D 52kw WJY	LUCAS Diesel DCN2
 Partner 1 Restyling (02-08)	ENGINE MANAGEME	2.0 HDI 66kw RHY	BOSCH EDC 15 C2 Common Rail
 Partner 1 Restyling (02-08)	ENGINE MANAGEME	2.0 HDI 66kw RHY	SIEMENS Diesel SID 801 Common Rail
 Partner 1 Restyling (02-08)	ENGINE MANAGEME	2.0 HDI 66kw RHY	SIEMENS SID 801 Common Rail
 Partner 1 Restyling (02-08)	ENGINE MANAGEME	2.0 HDI 66kw RHY (...00)	BOSCH EDC 15 C2 Common Rail
 Partner 1 Restyling (02-08)	ENGINE MANAGEME	2.0 HDI 66kw RHY (03-..)	BOSCH EDC 15 C2 Common Rail
 Partner 1 Restyling (02-08)	KEY ENCODE	1.1 44kw HFX (...02)	Valeo/Siemens
 Partner 1 Restyling (02-08)	KEY ENCODE	1.1 44kw HFX (03-..)	VALEO Body Siemens
 Partner 1 Restyling (02-08)	KEY ENCODE	1.4 55kw KFW (...02)	Valeo/Siemens
 Partner 1 Restyling (02-08)	KEY ENCODE	1.4 55kw KFW (03-..)	VALEO Body Siemens
 Partner 1 Restyling (02-08)	KEY ENCODE	1.6 16v 82kw N6A (...02)	Valeo/Siemens
 Partner 1 Restyling (02-08)	KEY ENCODE	1.6 16v 82kw N6A (03-..)	VALEO Body Siemens
 Partner 1 Restyling (02-08)	KEY ENCODE	1.6 16v 82kw NFU (...02)	Valeo/Siemens
 Partner 1 Restyling (02-08)	KEY ENCODE	1.6 16v 82kw NFU (03-..)	VALEO Body Siemens
 Partner 1 Restyling (02-08)	KEY ENCODE	1.6 HDI 16v 55kw 9HW (...03)	Valeo/Siemens
 Partner 1 Restyling (02-08)	KEY ENCODE	1.6 HDI 16v 55kw 9HW (03-..)	VALEO Body Siemens
 Partner 1 Restyling (02-08)	KEY ENCODE	1.6 HDI 16v 66kw 9HX (...02)	Valeo/Siemens
 Partner 1 Restyling (02-08)	KEY ENCODE	1.6 HDI 16v 66kw 9HX (03-..)	VALEO Body Siemens
 Partner 1 Restyling (02-08)	KEY ENCODE	1.9 D 51kw WJY (...02)	Valeo/Siemens
 Partner 1 Restyling (02-08)	KEY ENCODE	1.9 D 51kw WJY (03-..)	VALEO Body Siemens
 Partner 1 Restyling (02-08)	KEY ENCODE	1.9 D 52kw D9B (...02)	Valeo/Siemens
 Partner 1 Restyling (02-08)	KEY ENCODE	1.9 D 52kw D9B (03-..)	VALEO Body Siemens
 Partner 1 Restyling (02-08)	KEY ENCODE	1.9 D 52kw WJY (...02)	Valeo/Siemens
 Partner 1 Restyling (02-08)	KEY ENCODE	1.9 D 52kw WJY (03-..)	VALEO Body Siemens
 Partner 1 Restyling (02-08)	KEY ENCODE	2.0 HDI 66kw RHY (...02)	Valeo/Siemens
 Partner 1 Restyling (02-08)	KEY ENCODE	2.0 HDI 66kw RHY (03-..)	VALEO Body Siemens
 Partner 1 Restyling (02-08)	MAINTENANCE	1.1 44kw HFX	
 Partner 1 Restyling (02-08)	MAINTENANCE	1.1 44kw HFX	
 Partner 1 Restyling (02-08)	MAINTENANCE	1.1 44kw HFX	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.1 44kw HFX	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.1 44kw HFX	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.1 44kw HFX	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.4 55kw KFW	
 Partner 1 Restyling (02-08)	MAINTENANCE	1.4 55kw KFW	
 Partner 1 Restyling (02-08)	MAINTENANCE	1.4 55kw KFW	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.4 55kw KFW	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.4 55kw KFW	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.4 55kw KFW	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.6 16v 82kw N6A	
 Partner 1 Restyling (02-08)	MAINTENANCE	1.6 16v 82kw N6A	
 Partner 1 Restyling (02-08)	MAINTENANCE	1.6 16v 82kw N6A	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.6 16v 82kw N6A	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.6 16v 82kw N6A	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.6 16v 82kw N6A	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.6 16v 82kw NFU	
 Partner 1 Restyling (02-08)	MAINTENANCE	1.6 16v 82kw NFU	
 Partner 1 Restyling (02-08)	MAINTENANCE	1.6 16v 82kw NFU	BOSCH ABS ABR 5.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Partner 1 Restyling (02-08)	MAINTENANCE	1.6 16v 82kw NFU	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.6 16v 82kw NFU	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.6 16v 82kw NFU	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.6 HDI 16v 55kw 9HW	
 Partner 1 Restyling (02-08)	MAINTENANCE	1.6 HDI 16v 55kw 9HW	
 Partner 1 Restyling (02-08)	MAINTENANCE	1.6 HDI 16v 55kw 9HW	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.6 HDI 16v 55kw 9HW	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.6 HDI 16v 55kw 9HW	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.6 HDI 16v 55kw 9HW	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.6 HDI 16v 55kw 9HW	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	
 Partner 1 Restyling (02-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	
 Partner 1 Restyling (02-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.9 D 51kw WJY	
 Partner 1 Restyling (02-08)	MAINTENANCE	1.9 D 51kw WJY	
 Partner 1 Restyling (02-08)	MAINTENANCE	1.9 D 51kw WJY	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.9 D 51kw WJY	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.9 D 51kw WJY	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.9 D 51kw WJY	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.9 D 52kw D9B	
 Partner 1 Restyling (02-08)	MAINTENANCE	1.9 D 52kw D9B	
 Partner 1 Restyling (02-08)	MAINTENANCE	1.9 D 52kw D9B	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.9 D 52kw D9B	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.9 D 52kw D9B	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.9 D 52kw D9B	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.9 D 52kw WJY	
 Partner 1 Restyling (02-08)	MAINTENANCE	1.9 D 52kw WJY	
 Partner 1 Restyling (02-08)	MAINTENANCE	1.9 D 52kw WJY	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.9 D 52kw WJY	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.9 D 52kw WJY	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	1.9 D 52kw WJY	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	2.0 HDI 66kw RHY	
 Partner 1 Restyling (02-08)	MAINTENANCE	2.0 HDI 66kw RHY	
 Partner 1 Restyling (02-08)	MAINTENANCE	2.0 HDI 66kw RHY	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	2.0 HDI 66kw RHY	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	2.0 HDI 66kw RHY	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	2.0 HDI 66kw RHY	BOSCH ABS ABR 5.3
 Partner 1 Restyling (02-08)	MAINTENANCE	2.0 HDI 66kw RHY	BOSCH EDC 15 C2 Common Rail
 Partner 1 Restyling (02-08)	MAINTENANCE	2.0 HDI 66kw RHY (03-..)	BOSCH EDC 15 C2 Common Rail
 Partner 1 Restyling (02-08)	RADIO / CD	1.1 44kw HFX	Var.1
 Partner 1 Restyling (02-08)	RADIO / CD	1.1 44kw HFX	Var.2
 Partner 1 Restyling (02-08)	RADIO / CD	1.1 44kw HFX	Var.3
 Partner 1 Restyling (02-08)	RADIO / CD	1.1 44kw HFX	Var.4
 Partner 1 Restyling (02-08)	RADIO / CD	1.4 55kw KFW	Var.1
 Partner 1 Restyling (02-08)	RADIO / CD	1.4 55kw KFW	Var.2
 Partner 1 Restyling (02-08)	RADIO / CD	1.4 55kw KFW	Var.3
 Partner 1 Restyling (02-08)	RADIO / CD	1.4 55kw KFW	Var.4
 Partner 1 Restyling (02-08)	RADIO / CD	1.6 16v 82kw N6A	Var.1
 Partner 1 Restyling (02-08)	RADIO / CD	1.6 16v 82kw N6A	Var.2
 Partner 1 Restyling (02-08)	RADIO / CD	1.6 16v 82kw N6A	Var.3
 Partner 1 Restyling (02-08)	RADIO / CD	1.6 16v 82kw N6A	Var.4
 Partner 1 Restyling (02-08)	RADIO / CD	1.6 16v 82kw NFU	Var.1
 Partner 1 Restyling (02-08)	RADIO / CD	1.6 16v 82kw NFU	Var.2
 Partner 1 Restyling (02-08)	RADIO / CD	1.6 16v 82kw NFU	Var.3
 Partner 1 Restyling (02-08)	RADIO / CD	1.6 16v 82kw NFU	Var.4
 Partner 1 Restyling (02-08)	RADIO / CD	1.6 HDI 16v 55kw 9HW	Var.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Partner 1 Restyling (02-08)	RADIO / CD	1.6 HDI 16v 55kw 9HW	Var.2
 Partner 1 Restyling (02-08)	RADIO / CD	1.6 HDI 16v 55kw 9HW	Var.3
 Partner 1 Restyling (02-08)	RADIO / CD	1.6 HDI 16v 55kw 9HW	Var.4
 Partner 1 Restyling (02-08)	RADIO / CD	1.6 HDI 16v 66kw 9HX	Var.1
 Partner 1 Restyling (02-08)	RADIO / CD	1.6 HDI 16v 66kw 9HX	Var.2
 Partner 1 Restyling (02-08)	RADIO / CD	1.6 HDI 16v 66kw 9HX	Var.3
 Partner 1 Restyling (02-08)	RADIO / CD	1.6 HDI 16v 66kw 9HX	Var.4
 Partner 1 Restyling (02-08)	RADIO / CD	1.9 D 51kw WJY	Var.1
 Partner 1 Restyling (02-08)	RADIO / CD	1.9 D 51kw WJY	Var.2
 Partner 1 Restyling (02-08)	RADIO / CD	1.9 D 51kw WJY	Var.3
 Partner 1 Restyling (02-08)	RADIO / CD	1.9 D 51kw WJY	Var.4
 Partner 1 Restyling (02-08)	RADIO / CD	1.9 D 52kw D9B	Var.1
 Partner 1 Restyling (02-08)	RADIO / CD	1.9 D 52kw D9B	Var.2
 Partner 1 Restyling (02-08)	RADIO / CD	1.9 D 52kw D9B	Var.3
 Partner 1 Restyling (02-08)	RADIO / CD	1.9 D 52kw D9B	Var.4
 Partner 1 Restyling (02-08)	RADIO / CD	1.9 D 52kw WJY	Var.1
 Partner 1 Restyling (02-08)	RADIO / CD	1.9 D 52kw WJY	Var.2
 Partner 1 Restyling (02-08)	RADIO / CD	1.9 D 52kw WJY	Var.3
 Partner 1 Restyling (02-08)	RADIO / CD	1.9 D 52kw WJY	Var.4
 Partner 1 Restyling (02-08)	RADIO / CD	2.0 HDI 66kw RHY	Var.1
 Partner 1 Restyling (02-08)	RADIO / CD	2.0 HDI 66kw RHY	Var.2
 Partner 1 Restyling (02-08)	RADIO / CD	2.0 HDI 66kw RHY	Var.3
 Partner 1 Restyling (02-08)	RADIO / CD	2.0 HDI 66kw RHY	Var.4
 Partner 2	ABS	1.6 16v 66kw NFR	TEVES MK60
 Partner 2	ABS	1.6 16v 66kw NFR (08-..)	BOSCH ABS 8.1
 Partner 2	ABS	1.6 16v 80kw NFU	MK60
 Partner 2	ABS	1.6 16v 80kw NFU (08-..)	BOSCH ABS 8.1
 Partner 2	ABS	1.6 16v 82kw N6A	TEVES MK60
 Partner 2	ABS	1.6 16v 82kw NFA (08-..)	BOSCH ABS 8.1
 Partner 2	ABS	1.6 HDI 16v 55kw 9HT	TEVES MK60
 Partner 2	ABS	1.6 HDI 16v 55kw 9HT (08-..)	BOSCH ABS 8.1
 Partner 2	ABS	1.6 HDI 16v 55kw 9HW	TEVES MK60
 Partner 2	ABS	1.6 HDI 16v 55kw 9HW (08-..)	BOSCH ABS 8.1
 Partner 2	ABS	1.6 HDI 16v 66kw 9HS	TEVES MK60
 Partner 2	ABS	1.6 HDI 16v 66kw 9HS (08-..)	BOSCH ABS 8.1
 Partner 2	ABS	1.6 HDI 16v 66kw 9HV-FAP	TEVES MK60
 Partner 2	ABS	1.6 HDI 16v 66kw 9HV-FAP (08-..)	BOSCH ABS 8.1
 Partner 2	ABS	1.6 HDI 16v 66kw 9HX	TEVES MK60
 Partner 2	ABS	1.6 HDI 16v 66kw 9HX (08-..)	BOSCH ABS 8.1
 Partner 2	ABS	1.6 HDI 16v 80kw 9HZ-FAP	TEVES MK60
 Partner 2	ABS	1.6 HDI 16v 80kw 9HZ-FAP (08-..)	BOSCH ABS 8.1
 Partner 2	ABS + TRACT. CONT	1.6 16v 66kw NFR	BOSCH ESP 5.7
 Partner 2	ABS + TRACT. CONT	1.6 16v 66kw NFR	Var.1
 Partner 2	ABS + TRACT. CONT	1.6 16v 66kw NFR	Var.2
 Partner 2	ABS + TRACT. CONT	1.6 16v 80kw NFU	BOSCH ESP 5.7
 Partner 2	ABS + TRACT. CONT	1.6 16v 80kw NFU	Var.1
 Partner 2	ABS + TRACT. CONT	1.6 16v 80kw NFU	Var.2
 Partner 2	ABS + TRACT. CONT	1.6 16v 82kw N6A	BOSCH ESP 5.7
 Partner 2	ABS + TRACT. CONT	1.6 16v 82kw N6A	Var.1
 Partner 2	ABS + TRACT. CONT	1.6 16v 82kw N6A	Var.2
 Partner 2	ABS + TRACT. CONT	1.6 HDI 16v 55kw 9HT	ESP 5.7
 Partner 2	ABS + TRACT. CONT	1.6 HDI 16v 55kw 9HT	Var.1
 Partner 2	ABS + TRACT. CONT	1.6 HDI 16v 55kw 9HT	Var.2
 Partner 2	ABS + TRACT. CONT	1.6 HDI 16v 55kw 9HW	BOSCH ESP 5.7
 Partner 2	ABS + TRACT. CONT	1.6 HDI 16v 55kw 9HW	Var.1
 Partner 2	ABS + TRACT. CONT	1.6 HDI 16v 55kw 9HW	Var.2
 Partner 2	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HS	BOSCH ESP 5.7
 Partner 2	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HS	Var.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Partner 2	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HS	Var.2
 Partner 2	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HV-FAP	BOSCH ESP 5.7
 Partner 2	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HV-FAP	Var.1
 Partner 2	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HV-FAP	Var.2
 Partner 2	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX	BOSCH ESP 5.7
 Partner 2	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX	Var.1
 Partner 2	ABS + TRACT. CONT	1.6 HDI 16v 66kw 9HX	Var.2
 Partner 2	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ESP 5.7
 Partner 2	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 Partner 2	ABS + TRACT. CONT	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 Partner 2	AIRBAG	1.6 16v 66kw NFR	Temic AirBag CENTRAL
 Partner 2	AIRBAG	1.6 16v 66kw NFR (08-..)	Autoliv AirBag
 Partner 2	AIRBAG	1.6 16v 80kw NFU	Temic AirBag CENTRAL
 Partner 2	AIRBAG	1.6 16v 80kw NFU (08-..)	Autoliv AirBag
 Partner 2	AIRBAG	1.6 16v 82kw N6A	Temic AirBag CENTRAL
 Partner 2	AIRBAG	1.6 16v 82kw NFA (08-..)	Autoliv AirBag
 Partner 2	AIRBAG	1.6 HDI 16v 55kw 9HT	Temic AirBag CENTRAL
 Partner 2	AIRBAG	1.6 HDI 16v 55kw 9HT (08-..)	Autoliv
 Partner 2	AIRBAG	1.6 HDI 16v 55kw 9HW	Temic AirBag CENTRAL
 Partner 2	AIRBAG	1.6 HDI 16v 55kw 9HW (08-..)	Autoliv AirBag
 Partner 2	AIRBAG	1.6 HDI 16v 66kw 9HS	Temic AirBag CENTRAL
 Partner 2	AIRBAG	1.6 HDI 16v 66kw 9HS (08-..)	Autoliv
 Partner 2	AIRBAG	1.6 HDI 16v 66kw 9HV-FAP	Temic AirBag CENTRAL
 Partner 2	AIRBAG	1.6 HDI 16v 66kw 9HV-FAP (08-..)	Autoliv AirBag
 Partner 2	AIRBAG	1.6 HDI 16v 66kw 9HX	Temic AirBag CENTRAL
 Partner 2	AIRBAG	1.6 HDI 16v 66kw 9HX (08-..)	Autoliv
 Partner 2	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP	Temic AirBag CENTRAL
 Partner 2	AIRBAG	1.6 HDI 16v 80kw 9HZ-FAP (08-..)	Autoliv AirBag
 Partner 2	ANTITHEFT	1.6 16v 66kw NFR	Alarm PSA2
 Partner 2	ANTITHEFT	1.6 16v 80kw NFU	Alarm PSA2
 Partner 2	ANTITHEFT	1.6 16v 82kw N6A	Alarm PSA2
 Partner 2	ANTITHEFT	1.6 HDI 16v 55kw 9HT	Alarm PSA2
 Partner 2	ANTITHEFT	1.6 HDI 16v 55kw 9HW	Alarm PSA2
 Partner 2	ANTITHEFT	1.6 HDI 16v 66kw 9HS	Alarm PSA2
 Partner 2	ANTITHEFT	1.6 HDI 16v 66kw 9HV-FAP	Alarm PSA2
 Partner 2	ANTITHEFT	1.6 HDI 16v 66kw 9HX	Alarm PSA2
 Partner 2	ANTITHEFT	1.6 HDI 16v 80kw 9HZ-FAP	Alarm PSA2
 Partner 2	CHASSIS NETWORK	1.6 16v 66kw NFR	BodyComputer BSI
 Partner 2	CHASSIS NETWORK	1.6 16v 66kw NFR	Var.1
 Partner 2	CHASSIS NETWORK	1.6 16v 66kw NFR (08-..)	DELPHI BSM
 Partner 2	CHASSIS NETWORK	1.6 16v 66kw NFR (08-..)	JCAE BSI 5.20
 Partner 2	CHASSIS NETWORK	1.6 16v 80kw NFU	BodyComputer BSI
 Partner 2	CHASSIS NETWORK	1.6 16v 80kw NFU	Var.1
 Partner 2	CHASSIS NETWORK	1.6 16v 80kw NFU (08-..)	DELPHI BSM
 Partner 2	CHASSIS NETWORK	1.6 16v 80kw NFU (08-..)	JCAE BSI 5.20
 Partner 2	CHASSIS NETWORK	1.6 16v 82kw N6A	BodyComputer BSI
 Partner 2	CHASSIS NETWORK	1.6 16v 82kw N6A	Var.1
 Partner 2	CHASSIS NETWORK	1.6 16v 82kw N6A (08-..)	DELPHI BSM
 Partner 2	CHASSIS NETWORK	1.6 16v 82kw N6A (08-..)	JCAE BSI 5.20
 Partner 2	CHASSIS NETWORK	1.6 HDI 16v 55kw 9HT	BodyComputer BSI
 Partner 2	CHASSIS NETWORK	1.6 HDI 16v 55kw 9HT	Var.1
 Partner 2	CHASSIS NETWORK	1.6 HDI 16v 55kw 9HT (08-..)	DELPHI BSM
 Partner 2	CHASSIS NETWORK	1.6 HDI 16v 55kw 9HT (08-..)	JCAE BSI 5.20
 Partner 2	CHASSIS NETWORK	1.6 HDI 16v 55kw 9HW	BodyComputer BSI
 Partner 2	CHASSIS NETWORK	1.6 HDI 16v 55kw 9HW	Var.1
 Partner 2	CHASSIS NETWORK	1.6 HDI 16v 55kw 9HW (08-..)	DELPHI BSM
 Partner 2	CHASSIS NETWORK	1.6 HDI 16v 55kw 9HW (08-..)	JCAE BSI 5.20
 Partner 2	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HS	BodyComputer BSI

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Partner 2	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HS	Var.1
 Partner 2	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HS (08-..)	DELPHI BSM
 Partner 2	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HS (08-..)	JCAE BSI 5.20
 Partner 2	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HV-FAP	BodyComputer BSI
 Partner 2	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HV-FAP	Var.1
 Partner 2	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HV-FAP (08-..)	DELPHI BSM
 Partner 2	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HV-FAP (08-..)	JCAE BSI 5.20
 Partner 2	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	BodyComputer BSI
 Partner 2	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX	Var.1
 Partner 2	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX (08-..)	DELPHI BSM
 Partner 2	CHASSIS NETWORK	1.6 HDI 16v 66kw 9HX (08-..)	JCAE BSI 5.20
 Partner 2	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	BodyComputer BSI
 Partner 2	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 Partner 2	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP (08-..)	DELPHI BSM
 Partner 2	CHASSIS NETWORK	1.6 HDI 16v 80kw 9HZ-FAP (08-..)	JCAE BSI 5.20
 Partner 2	DASHBOARD	1.6 16v 66kw NFR	
 Partner 2	DASHBOARD	1.6 16v 66kw NFR (08-..)	Marelli
 Partner 2	DASHBOARD	1.6 16v 80kw NFU	
 Partner 2	DASHBOARD	1.6 16v 80kw NFU (08-..)	Marelli
 Partner 2	DASHBOARD	1.6 16v 82kw N6A	
 Partner 2	DASHBOARD	1.6 16v 82kw N6A (08-..)	Marelli
 Partner 2	DASHBOARD	1.6 HDI 16v 55kw 9HT	
 Partner 2	DASHBOARD	1.6 HDI 16v 55kw 9HT (08-..)	Marelli
 Partner 2	DASHBOARD	1.6 HDI 16v 55kw 9HW	
 Partner 2	DASHBOARD	1.6 HDI 16v 55kw 9HW (08-..)	Marelli
 Partner 2	DASHBOARD	1.6 HDI 16v 66kw 9HS	
 Partner 2	DASHBOARD	1.6 HDI 16v 66kw 9HS (08-..)	Marelli
 Partner 2	DASHBOARD	1.6 HDI 16v 66kw 9HV-FAP	
 Partner 2	DASHBOARD	1.6 HDI 16v 66kw 9HV-FAP (08-..)	Marelli
 Partner 2	DASHBOARD	1.6 HDI 16v 66kw 9HX	
 Partner 2	DASHBOARD	1.6 HDI 16v 66kw 9HX (08-..)	Marelli
 Partner 2	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP	
 Partner 2	DASHBOARD	1.6 HDI 16v 80kw 9HZ-FAP (08-..)	Marelli
 Partner 2	DIESEL ADDITION	1.6 HDI 16v 66kw 9HV-FAP	AUTODETECT
 Partner 2	DIESEL ADDITION	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 Partner 2	ENGINE MANAGEME	1.6 16v 66kw NFR (08-..)	BOSCH Motronic ME 7.4.5
 Partner 2	ENGINE MANAGEME	1.6 16v 80kw NFU	BOSCH ME7.4.4
 Partner 2	ENGINE MANAGEME	1.6 16v 82kw N6A	BOSCH ME7.4.4
 Partner 2	ENGINE MANAGEME	1.6 HDI 16v 55kw 9HW	BOSCH EDC 16 C34 Common Rail Var.1
 Partner 2	ENGINE MANAGEME	1.6 HDI 16v 55kw 9HW	BOSCH EDC 16 C34 Common Rail Var.2
 Partner 2	ENGINE MANAGEME	1.6 HDI 16v 66kw 9HV-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 Partner 2	ENGINE MANAGEME	1.6 HDI 16v 66kw 9HV-FAP	BOSCH EDC 16 C34 Common Rail Var.2
 Partner 2	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 Partner 2	ENGINE MANAGEME	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.2
 Partner 2	MAINTENANCE	1.6 16v 66kw NFR	BOSCH ESP 5.7
 Partner 2	MAINTENANCE	1.6 16v 66kw NFR	BOSCH ESP 5.7
 Partner 2	MAINTENANCE	1.6 16v 66kw NFR	TEVES MK60
 Partner 2	MAINTENANCE	1.6 16v 66kw NFR	Var.1
 Partner 2	MAINTENANCE	1.6 16v 66kw NFR	Var.1
 Partner 2	MAINTENANCE	1.6 16v 66kw NFR	Var.2
 Partner 2	MAINTENANCE	1.6 16v 66kw NFR	Var.2
 Partner 2	MAINTENANCE	1.6 16v 66kw NFR (08-..)	Marelli
 Partner 2	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ESP 5.7
 Partner 2	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ESP 5.7
 Partner 2	MAINTENANCE	1.6 16v 80kw NFU	MK60
 Partner 2	MAINTENANCE	1.6 16v 80kw NFU	Var.1
 Partner 2	MAINTENANCE	1.6 16v 80kw NFU	Var.1
 Partner 2	MAINTENANCE	1.6 16v 80kw NFU	Var.2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Partner 2	MAINTENANCE	1.6 16v 80kw NFU	Var.2
 Partner 2	MAINTENANCE	1.6 16v 80kw NFU (08-...)	Marelli
 Partner 2	MAINTENANCE	1.6 16v 82kw N6A	BOSCH ESP 5.7
 Partner 2	MAINTENANCE	1.6 16v 82kw N6A	BOSCH ESP 5.7
 Partner 2	MAINTENANCE	1.6 16v 82kw N6A	TEVES MK60
 Partner 2	MAINTENANCE	1.6 16v 82kw N6A	Var.1
 Partner 2	MAINTENANCE	1.6 16v 82kw N6A	Var.1
 Partner 2	MAINTENANCE	1.6 16v 82kw N6A	Var.2
 Partner 2	MAINTENANCE	1.6 16v 82kw N6A	Var.2
 Partner 2	MAINTENANCE	1.6 16v 82kw N6A (08-...)	Marelli
 Partner 2	MAINTENANCE	1.6 HDI 16v 55kw 9HT	ESP 5.7
 Partner 2	MAINTENANCE	1.6 HDI 16v 55kw 9HT	ESP 5.7
 Partner 2	MAINTENANCE	1.6 HDI 16v 55kw 9HT	TEVES MK60
 Partner 2	MAINTENANCE	1.6 HDI 16v 55kw 9HT	Var.1
 Partner 2	MAINTENANCE	1.6 HDI 16v 55kw 9HT	Var.1
 Partner 2	MAINTENANCE	1.6 HDI 16v 55kw 9HT	Var.2
 Partner 2	MAINTENANCE	1.6 HDI 16v 55kw 9HT	Var.2
 Partner 2	MAINTENANCE	1.6 HDI 16v 55kw 9HT (08-...)	Marelli
 Partner 2	MAINTENANCE	1.6 HDI 16v 55kw 9HW	BOSCH EDC 16 C34 Common Rail Var.1
 Partner 2	MAINTENANCE	1.6 HDI 16v 55kw 9HW	BOSCH EDC 16 C34 Common Rail Var.1
 Partner 2	MAINTENANCE	1.6 HDI 16v 55kw 9HW	BOSCH EDC 16 C34 Common Rail Var.1
 Partner 2	MAINTENANCE	1.6 HDI 16v 55kw 9HW	BOSCH EDC 16 C34 Common Rail Var.1
 Partner 2	MAINTENANCE	1.6 HDI 16v 55kw 9HW	BOSCH EDC 16 C34 Common Rail Var.1
 Partner 2	MAINTENANCE	1.6 HDI 16v 55kw 9HW	BOSCH EDC 16 C34 Common Rail Var.1
 Partner 2	MAINTENANCE	1.6 HDI 16v 55kw 9HW	BOSCH EDC 16 C34 Common Rail Var.2
 Partner 2	MAINTENANCE	1.6 HDI 16v 55kw 9HW	BOSCH EDC 16 C34 Common Rail Var.2
 Partner 2	MAINTENANCE	1.6 HDI 16v 55kw 9HW	BOSCH EDC 16 C34 Common Rail Var.2
 Partner 2	MAINTENANCE	1.6 HDI 16v 55kw 9HW	BOSCH EDC 16 C34 Common Rail Var.2
 Partner 2	MAINTENANCE	1.6 HDI 16v 55kw 9HW	BOSCH EDC 16 C34 Common Rail Var.2
 Partner 2	MAINTENANCE	1.6 HDI 16v 55kw 9HW	BOSCH EDC 16 C34 Common Rail Var.2
 Partner 2	MAINTENANCE	1.6 HDI 16v 55kw 9HW	BOSCH EDC 16 C34 Common Rail Var.2
 Partner 2	MAINTENANCE	1.6 HDI 16v 55kw 9HW	BOSCH EDC 16 C34 Common Rail Var.2
 Partner 2	MAINTENANCE	1.6 HDI 16v 55kw 9HW	BOSCH ESP 5.7
 Partner 2	MAINTENANCE	1.6 HDI 16v 55kw 9HW	BOSCH ESP 5.7
 Partner 2	MAINTENANCE	1.6 HDI 16v 55kw 9HW	TEVES MK60
 Partner 2	MAINTENANCE	1.6 HDI 16v 55kw 9HW	Var.1
 Partner 2	MAINTENANCE	1.6 HDI 16v 55kw 9HW	Var.1
 Partner 2	MAINTENANCE	1.6 HDI 16v 55kw 9HW	Var.2
 Partner 2	MAINTENANCE	1.6 HDI 16v 55kw 9HW	Var.2
 Partner 2	MAINTENANCE	1.6 HDI 16v 55kw 9HW (08-...)	Marelli
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HS	BOSCH ESP 5.7
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HS	BOSCH ESP 5.7
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HS	TEVES MK60
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HS	Var.1
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HS	Var.1
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HS	Var.2
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HS	Var.2
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HS (08-...)	Marelli
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HV-FAP	AUTODETECT
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HV-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HV-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HV-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HV-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HV-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HV-FAP	BOSCH EDC 16 C34 Common Rail Var.2
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HV-FAP	BOSCH EDC 16 C34 Common Rail Var.2
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HV-FAP	BOSCH EDC 16 C34 Common Rail Var.2
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HV-FAP	BOSCH EDC 16 C34 Common Rail Var.2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HV-FAP	BOSCH EDC 16 C34 Common Rail Var.2
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HV-FAP	BOSCH EDC 16 C34 Common Rail Var.2
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HV-FAP	BOSCH ESP 5.7
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HV-FAP	BOSCH ESP 5.7
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HV-FAP	TEVES MK60
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HV-FAP	Var.1
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HV-FAP	Var.1
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HV-FAP	Var.2
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HV-FAP	Var.2
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HV-FAP (08-..)	Marelli
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH ESP 5.7
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HX	BOSCH ESP 5.7
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HX	TEVES MK60
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Var.1
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Var.1
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Var.2
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HX	Var.2
 Partner 2	MAINTENANCE	1.6 HDI 16v 66kw 9HX (08-..)	Marelli
 Partner 2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	AUTODETECT
 Partner 2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 Partner 2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 Partner 2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 Partner 2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 Partner 2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 Partner 2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.1
 Partner 2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.2
 Partner 2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.2
 Partner 2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.2
 Partner 2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.2
 Partner 2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.2
 Partner 2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH EDC 16 C34 Common Rail Var.2
 Partner 2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ESP 5.7
 Partner 2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	BOSCH ESP 5.7
 Partner 2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	TEVES MK60
 Partner 2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 Partner 2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 Partner 2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 Partner 2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 Partner 2	MAINTENANCE	1.6 HDI 16v 80kw 9HZ-FAP (08-..)	Marelli
 Partner 2	PARKING HELP	1.6 16v 66kw NFR	Var.1
 Partner 2	PARKING HELP	1.6 16v 66kw NFR	Var.2
 Partner 2	PARKING HELP	1.6 16v 80kw NFU	Var.1
 Partner 2	PARKING HELP	1.6 16v 80kw NFU	Var.2
 Partner 2	PARKING HELP	1.6 16v 82kw N6A	Var.1
 Partner 2	PARKING HELP	1.6 16v 82kw N6A	Var.2
 Partner 2	PARKING HELP	1.6 HDI 16v 55kw 9HT	Var.1
 Partner 2	PARKING HELP	1.6 HDI 16v 55kw 9HT	Var.2
 Partner 2	PARKING HELP	1.6 HDI 16v 55kw 9HW	Var.1
 Partner 2	PARKING HELP	1.6 HDI 16v 55kw 9HW	Var.2
 Partner 2	PARKING HELP	1.6 HDI 16v 66kw 9HS	Var.1
 Partner 2	PARKING HELP	1.6 HDI 16v 66kw 9HS	Var.2
 Partner 2	PARKING HELP	1.6 HDI 16v 66kw 9HV-FAP	Var.1
 Partner 2	PARKING HELP	1.6 HDI 16v 66kw 9HV-FAP	Var.2
 Partner 2	PARKING HELP	1.6 HDI 16v 66kw 9HX	Var.1
 Partner 2	PARKING HELP	1.6 HDI 16v 66kw 9HX	Var.2
 Partner 2	PARKING HELP	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 Partner 2	PARKING HELP	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 Partner 2	RADIO / CD	1.6 16v 66kw NFR	Var.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Partner 2	RADIO / CD	1.6 16v 66kw NFR	Var.2
 Partner 2	RADIO / CD	1.6 16v 66kw NFR	Var.3
 Partner 2	RADIO / CD	1.6 16v 66kw NFR	Var.4
 Partner 2	RADIO / CD	1.6 16v 80kw NFU	Var.1
 Partner 2	RADIO / CD	1.6 16v 80kw NFU	Var.2
 Partner 2	RADIO / CD	1.6 16v 80kw NFU	Var.3
 Partner 2	RADIO / CD	1.6 16v 80kw NFU	Var.4
 Partner 2	RADIO / CD	1.6 16v 82kw N6A	Var.1
 Partner 2	RADIO / CD	1.6 16v 82kw N6A	Var.2
 Partner 2	RADIO / CD	1.6 16v 82kw N6A	Var.3
 Partner 2	RADIO / CD	1.6 16v 82kw N6A	Var.4
 Partner 2	RADIO / CD	1.6 HDI 16v 55kw 9HT	Var.1
 Partner 2	RADIO / CD	1.6 HDI 16v 55kw 9HT	Var.2
 Partner 2	RADIO / CD	1.6 HDI 16v 55kw 9HT	Var.3
 Partner 2	RADIO / CD	1.6 HDI 16v 55kw 9HT	Var.4
 Partner 2	RADIO / CD	1.6 HDI 16v 55kw 9HW	Var.1
 Partner 2	RADIO / CD	1.6 HDI 16v 55kw 9HW	Var.2
 Partner 2	RADIO / CD	1.6 HDI 16v 55kw 9HW	Var.3
 Partner 2	RADIO / CD	1.6 HDI 16v 55kw 9HW	Var.4
 Partner 2	RADIO / CD	1.6 HDI 16v 66kw 9HS	Var.1
 Partner 2	RADIO / CD	1.6 HDI 16v 66kw 9HS	Var.2
 Partner 2	RADIO / CD	1.6 HDI 16v 66kw 9HS	Var.3
 Partner 2	RADIO / CD	1.6 HDI 16v 66kw 9HS	Var.4
 Partner 2	RADIO / CD	1.6 HDI 16v 66kw 9HV-FAP	Var.1
 Partner 2	RADIO / CD	1.6 HDI 16v 66kw 9HV-FAP	Var.2
 Partner 2	RADIO / CD	1.6 HDI 16v 66kw 9HV-FAP	Var.3
 Partner 2	RADIO / CD	1.6 HDI 16v 66kw 9HV-FAP	Var.4
 Partner 2	RADIO / CD	1.6 HDI 16v 66kw 9HX	Var.1
 Partner 2	RADIO / CD	1.6 HDI 16v 66kw 9HX	Var.2
 Partner 2	RADIO / CD	1.6 HDI 16v 66kw 9HX	Var.3
 Partner 2	RADIO / CD	1.6 HDI 16v 66kw 9HX	Var.4
 Partner 2	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 Partner 2	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 Partner 2	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Var.3
 Partner 2	RADIO / CD	1.6 HDI 16v 80kw 9HZ-FAP	Var.4
 Partner 2	RAIN-LUMINOSITY S	1.6 16v 66kw NFR	Var.1
 Partner 2	RAIN-LUMINOSITY S	1.6 16v 66kw NFR	Var.2
 Partner 2	RAIN-LUMINOSITY S	1.6 16v 80kw NFU	Var.1
 Partner 2	RAIN-LUMINOSITY S	1.6 16v 80kw NFU	Var.2
 Partner 2	RAIN-LUMINOSITY S	1.6 16v 82kw N6A	Var.1
 Partner 2	RAIN-LUMINOSITY S	1.6 16v 82kw N6A	Var.2
 Partner 2	RAIN-LUMINOSITY S	1.6 HDI 16v 55kw 9HT	Var.1
 Partner 2	RAIN-LUMINOSITY S	1.6 HDI 16v 55kw 9HT	Var.2
 Partner 2	RAIN-LUMINOSITY S	1.6 HDI 16v 55kw 9HW	Var.1
 Partner 2	RAIN-LUMINOSITY S	1.6 HDI 16v 55kw 9HW	Var.2
 Partner 2	RAIN-LUMINOSITY S	1.6 HDI 16v 66kw 9HS	Var.1
 Partner 2	RAIN-LUMINOSITY S	1.6 HDI 16v 66kw 9HS	Var.2
 Partner 2	RAIN-LUMINOSITY S	1.6 HDI 16v 66kw 9HV-FAP	Var.1
 Partner 2	RAIN-LUMINOSITY S	1.6 HDI 16v 66kw 9HV-FAP	Var.2
 Partner 2	RAIN-LUMINOSITY S	1.6 HDI 16v 66kw 9HX	Var.1
 Partner 2	RAIN-LUMINOSITY S	1.6 HDI 16v 66kw 9HX	Var.2
 Partner 2	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HZ-FAP	Var.1
 Partner 2	RAIN-LUMINOSITY S	1.6 HDI 16v 80kw 9HZ-FAP	Var.2
 Partner 2	STEERING COLUMN	1.6 16v 66kw NFR	
 Partner 2	STEERING COLUMN	1.6 16v 80kw NFU	
 Partner 2	STEERING COLUMN	1.6 16v 82kw N6A	
 Partner 2	STEERING COLUMN	1.6 HDI 16v 55kw 9HT	
 Partner 2	STEERING COLUMN	1.6 HDI 16v 55kw 9HW	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Partner 2	STEERING COLUMN	1.6 HDI 16v 66kw 9HS	
 Partner 2	STEERING COLUMN	1.6 HDI 16v 66kw 9HV-FAP	
 Partner 2	STEERING COLUMN	1.6 HDI 16v 66kw 9HX	
 Partner 2	STEERING COLUMN	1.6 HDI 16v 80kw 9HZ-FAP	
 Partner 2	SWITCHLIGHT MODU	1.6 16v 66kw NFR (08-..)	DELPHI
 Partner 2	SWITCHLIGHT MODU	1.6 16v 80kw NFU (08-..)	DELPHI
 Partner 2	SWITCHLIGHT MODU	1.6 16v 82kw N6A (08-..)	DELPHI
 Partner 2	SWITCHLIGHT MODU	1.6 HDI 16v 55kw 9HT (08-..)	DELPHI
 Partner 2	SWITCHLIGHT MODU	1.6 HDI 16v 55kw 9HW (08-..)	DELPHI
 Partner 2	SWITCHLIGHT MODU	1.6 HDI 16v 66kw 9HS (08-..)	DELPHI
 Partner 2	SWITCHLIGHT MODU	1.6 HDI 16v 66kw 9HV-FAP (08-..)	DELPHI
 Partner 2	SWITCHLIGHT MODU	1.6 HDI 16v 66kw 9HX (08-..)	DELPHI
 Partner 2	SWITCHLIGHT MODU	1.6 HDI 16v 80kw 9HZ-FAP (08-..)	DELPHI
 Partner 2	VISUAL./TELEMATIC	1.6 16v 66kw NFR	Display
 Partner 2	VISUAL./TELEMATIC	1.6 16v 80kw NFU	Display
 Partner 2	VISUAL./TELEMATIC	1.6 16v 82kw N6A	
 Partner 2	VISUAL./TELEMATIC	1.6 HDI 16v 55kw 9HT	
 Partner 2	VISUAL./TELEMATIC	1.6 HDI 16v 55kw 9HW	
 Partner 2	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HS	
 Partner 2	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HV-FAP	
 Partner 2	VISUAL./TELEMATIC	1.6 HDI 16v 66kw 9HX	
 Partner 2	VISUAL./TELEMATIC	1.6 HDI 16v 80kw 9HZ-FAP	
 Ranch	ABS	1.1 40kw HDY	BOSCH ABS ABR 5.3
 Ranch	ABS	1.1 40kw HDZ	BOSCH ABS ABR 5.3
 Ranch	ABS	1.4 55kw KFW	BOSCH ABS ABR 5.3
 Ranch	ABS	1.4 55kw KFX	BOSCH ABS ABR 5.3
 Ranch	ABS	1.6 16v 80kw NFU	BOSCH ABS ABR 5.3
 Ranch	ABS	1.9 D 52kw WJY	BOSCH ABS ABR 5.3
 Ranch	ABS	2.0 HDI 66kw RHY	BOSCH ABS ABR 5.3
 Ranch	ABS	2.0 HDI 81kw RHZ	BOSCH ABS ABR 5.3
 Ranch	AIRBAG	1.1 40kw HDY (97-00)	AKF- Autoliv AirBag no SIDE AB
 Ranch	AIRBAG	1.1 40kw HDZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 Ranch	AIRBAG	1.4 55kw KFW (97-00)	AKF- Autoliv AirBag no SIDE AB
 Ranch	AIRBAG	1.4 55kw KFX (97-00)	AKF- Autoliv AirBag no SIDE AB
 Ranch	AIRBAG	1.6 16v 80kw NFU (97-00)	AKF- Autoliv AirBag no SIDE AB
 Ranch	AIRBAG	1.9 D 52kw WJY (97-00)	AKF- Autoliv AirBag no SIDE AB
 Ranch	AIRBAG	2.0 HDI 66kw RHY (97-00)	AKF- Autoliv AirBag no SIDE AB
 Ranch	AIRBAG	2.0 HDI 81kw RHZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 Ranch	CHASSIS NETWORK	1.1 40kw HDY (...-01)	VALEO Body Computer
 Ranch	CHASSIS NETWORK	1.1 40kw HDZ (...-01)	VALEO Body Computer
 Ranch	CHASSIS NETWORK	1.4 55kw KFW (...-01)	VALEO Body Computer
 Ranch	CHASSIS NETWORK	1.4 55kw KFX (...-01)	VALEO Body Computer
 Ranch	CHASSIS NETWORK	1.6 16v 80kw NFU (...-01)	VALEO Body Computer
 Ranch	CHASSIS NETWORK	1.9 D 52kw WJY (...-01)	VALEO Body Computer
 Ranch	CHASSIS NETWORK	2.0 HDI 66kw RHY (...-01)	VALEO Body Computer
 Ranch	CHASSIS NETWORK	2.0 HDI 81kw RHZ (...-01)	VALEO Body Computer
 Ranch	DIESEL MANAGEMEN	1.9 D 52kw WJY	LUCAS Diesel DCN2
 Ranch	ENGINE MANAGEME	1.1 40kw HDY	BOSCH MonoMotronic MA3.1
 Ranch	ENGINE MANAGEME	1.1 40kw HDZ	BOSCH MonoMotronic MA3.1
 Ranch	ENGINE MANAGEME	1.4 55kw KFW	SAGEM S2000
 Ranch	ENGINE MANAGEME	1.4 55kw KFX	Marelli MM 1AP.40
 Ranch	ENGINE MANAGEME	1.6 16v 80kw NFU	BOSCH Motronic ME7.4.4
 Ranch	ENGINE MANAGEME	2.0 HDI 66kw RHY	SIEMENS Diesel SID 801 Common Rail
 Ranch	ENGINE MANAGEME	2.0 HDI 66kw RHY (...-00)	BOSCH EDC 15 C2 Common Rail
 Ranch	ENGINE MANAGEME	2.0 HDI 81kw RHZ (...-99)	BOSCH EDC 15 C2 Common Rail
 Ranch	MAINTENANCE	1.1 40kw HDY	BOSCH ABS ABR 5.3
 Ranch	MAINTENANCE	1.1 40kw HDY	BOSCH ABS ABR 5.3
 Ranch	MAINTENANCE	1.1 40kw HDY	BOSCH ABS ABR 5.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Ranch	MAINTENANCE	1.1 40kw HDY	BOSCH ABS ABR 5.3
 Ranch	MAINTENANCE	1.1 40kw HDY (98-00)	VDO MANUAL
 Ranch	MAINTENANCE	1.1 40kw HDZ	BOSCH ABS ABR 5.3
 Ranch	MAINTENANCE	1.1 40kw HDZ	BOSCH ABS ABR 5.3
 Ranch	MAINTENANCE	1.1 40kw HDZ	BOSCH ABS ABR 5.3
 Ranch	MAINTENANCE	1.1 40kw HDZ	BOSCH ABS ABR 5.3
 Ranch	MAINTENANCE	1.1 40kw HDZ (98-00)	VDO MANUAL
 Ranch	MAINTENANCE	1.4 55kw KFW	BOSCH ABS ABR 5.3
 Ranch	MAINTENANCE	1.4 55kw KFW	BOSCH ABS ABR 5.3
 Ranch	MAINTENANCE	1.4 55kw KFW	BOSCH ABS ABR 5.3
 Ranch	MAINTENANCE	1.4 55kw KFW	BOSCH ABS ABR 5.3
 Ranch	MAINTENANCE	1.4 55kw KFW (98-00)	VDO MANUAL
 Ranch	MAINTENANCE	1.4 55kw KFX	BOSCH ABS ABR 5.3
 Ranch	MAINTENANCE	1.4 55kw KFX	BOSCH ABS ABR 5.3
 Ranch	MAINTENANCE	1.4 55kw KFX	BOSCH ABS ABR 5.3
 Ranch	MAINTENANCE	1.4 55kw KFX	BOSCH ABS ABR 5.3
 Ranch	MAINTENANCE	1.4 55kw KFX (98-00)	VDO MANUAL
 Ranch	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ABS ABR 5.3
 Ranch	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ABS ABR 5.3
 Ranch	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ABS ABR 5.3
 Ranch	MAINTENANCE	1.6 16v 80kw NFU	BOSCH ABS ABR 5.3
 Ranch	MAINTENANCE	1.6 16v 80kw NFU (98-00)	VDO MANUAL
 Ranch	MAINTENANCE	1.9 D 52kw WJY	BOSCH ABS ABR 5.3
 Ranch	MAINTENANCE	1.9 D 52kw WJY	BOSCH ABS ABR 5.3
 Ranch	MAINTENANCE	1.9 D 52kw WJY	BOSCH ABS ABR 5.3
 Ranch	MAINTENANCE	1.9 D 52kw WJY	BOSCH ABS ABR 5.3
 Ranch	MAINTENANCE	1.9 D 52kw WJY (98-00)	VDO MANUAL
 Ranch	MAINTENANCE	2.0 HDI 66kw RHY	BOSCH ABS ABR 5.3
 Ranch	MAINTENANCE	2.0 HDI 66kw RHY	BOSCH ABS ABR 5.3
 Ranch	MAINTENANCE	2.0 HDI 66kw RHY	BOSCH ABS ABR 5.3
 Ranch	MAINTENANCE	2.0 HDI 66kw RHY	BOSCH ABS ABR 5.3
 Ranch	MAINTENANCE	2.0 HDI 66kw RHY (98-00)	VDO MANUAL
 Ranch	MAINTENANCE	2.0 HDI 81kw RHZ	BOSCH ABS ABR 5.3
 Ranch	MAINTENANCE	2.0 HDI 81kw RHZ	BOSCH ABS ABR 5.3
 Ranch	MAINTENANCE	2.0 HDI 81kw RHZ	BOSCH ABS ABR 5.3
 Ranch	MAINTENANCE	2.0 HDI 81kw RHZ	BOSCH ABS ABR 5.3
 Ranch	MAINTENANCE	2.0 HDI 81kw RHZ (98-00)	VDO MANUAL
 Ranch	RADIO / CD	1.1 40kw HDY	CLARION AudioSystem
 Ranch	RADIO / CD	1.1 40kw HDY	PHILIPS AudioSystem
 Ranch	RADIO / CD	1.1 40kw HDY	VDO AudioSystem
 Ranch	RADIO / CD	1.1 40kw HDZ	CLARION AudioSystem
 Ranch	RADIO / CD	1.1 40kw HDZ	PHILIPS AudioSystem
 Ranch	RADIO / CD	1.1 40kw HDZ	VDO AudioSystem
 Ranch	RADIO / CD	1.4 55kw KFW	CLARION AudioSystem
 Ranch	RADIO / CD	1.4 55kw KFW	PHILIPS AudioSystem
 Ranch	RADIO / CD	1.4 55kw KFW	VDO AudioSystem
 Ranch	RADIO / CD	1.4 55kw KFX	CLARION AudioSystem
 Ranch	RADIO / CD	1.4 55kw KFX	PHILIPS AudioSystem
 Ranch	RADIO / CD	1.4 55kw KFX	VDO AudioSystem
 Ranch	RADIO / CD	1.6 16v 80kw NFU	CLARION AudioSystem
 Ranch	RADIO / CD	1.6 16v 80kw NFU	PHILIPS AudioSystem
 Ranch	RADIO / CD	1.6 16v 80kw NFU	VDO AudioSystem
 Ranch	RADIO / CD	1.9 D 52kw WJY	CLARION AudioSystem
 Ranch	RADIO / CD	1.9 D 52kw WJY	PHILIPS AudioSystem
 Ranch	RADIO / CD	1.9 D 52kw WJY	VDO AudioSystem
 Ranch	RADIO / CD	2.0 HDI 66kw RHY	CLARION AudioSystem
 Ranch	RADIO / CD	2.0 HDI 66kw RHY	PHILIPS AudioSystem
 Ranch	RADIO / CD	2.0 HDI 66kw RHY	VDO AudioSystem

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Ranch	RADIO / CD	2.0 HDI 81kw RHZ	CLARION AudioSystem
 Ranch	RADIO / CD	2.0 HDI 81kw RHZ	PHILIPS AudioSystem
 Ranch	RADIO / CD	2.0 HDI 81kw RHZ	VDO AudioSystem
 Ranch	SERVICE LIGHT RES	1.1 40kw HDY (98-00)	VDO MANUAL
 Ranch	SERVICE LIGHT RES	1.1 40kw HDZ (98-00)	VDO MANUAL
 Ranch	SERVICE LIGHT RES	1.4 55kw KFW (98-00)	VDO MANUAL
 Ranch	SERVICE LIGHT RES	1.4 55kw KFX (98-00)	VDO MANUAL
 Ranch	SERVICE LIGHT RES	1.6 16v 80kw NFU (98-00)	VDO MANUAL
 Ranch	SERVICE LIGHT RES	1.9 D 52kw WJY (98-00)	VDO MANUAL
 Ranch	SERVICE LIGHT RES	2.0 HDI 66kw RHY (98-00)	VDO MANUAL
 Ranch	SERVICE LIGHT RES	2.0 HDI 81kw RHZ (98-00)	VDO MANUAL
 Ranch	SWITCHLIGHT MODU	1.1 40kw HDY	EATON
 Ranch	SWITCHLIGHT MODU	1.1 40kw HDZ	EATON
 Ranch	SWITCHLIGHT MODU	1.4 55kw KFW	EATON
 Ranch	SWITCHLIGHT MODU	1.4 55kw KFX	EATON
 Ranch	SWITCHLIGHT MODU	1.6 16v 80kw NFU	EATON
 Ranch	SWITCHLIGHT MODU	1.9 D 52kw WJY	EATON
 Ranch	SWITCHLIGHT MODU	2.0 HDI 66kw RHY	EATON
 Ranch	SWITCHLIGHT MODU	2.0 HDI 81kw RHZ	EATON
 Ranch	VISUAL./TELEMATIC	1.1 40kw HDY	SAGEM
 Ranch	VISUAL./TELEMATIC	1.1 40kw HDZ	SAGEM
 Ranch	VISUAL./TELEMATIC	1.4 55kw KFW	SAGEM
 Ranch	VISUAL./TELEMATIC	1.4 55kw KFX	SAGEM
 Ranch	VISUAL./TELEMATIC	1.6 16v 80kw NFU	SAGEM
 Ranch	VISUAL./TELEMATIC	1.9 D 52kw WJY	SAGEM
 Ranch	VISUAL./TELEMATIC	2.0 HDI 66kw RHY	SAGEM
 Ranch	VISUAL./TELEMATIC	2.0 HDI 81kw RHZ	SAGEM

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Polonez

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 1.4 MPI	ENGINE MANAGEME	1.4	ROVER MEMS 1.4

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Porsche

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 911 Carrera	ENGINE MANAGEME	3.6 235kw (01-..)	EOBD
 911 GT2	ENGINE MANAGEME	3.6 340kw (01-..)	EOBD
 911 Turbo	ENGINE MANAGEME	3.6 309kw (01-..)	EOBD
 Boxster	ENGINE MANAGEME	2.7 162kw (01-..)	EOBD
 Boxster	ENGINE MANAGEME	3.2 185kw (01-..)	EOBD
 Cayenne	4WD ELECTRONICS	(..-07)	No CAN
 Cayenne	ABS	(..-07)	No CAN
 Cayenne	AIRBAG	(..-07)	No CAN
 Cayenne	AUTOM. TRANSMISSI	(..-07)	No CAN
 Cayenne	CENTRAL ELECTRIC	(..-07)	No CAN
 Cayenne	CLIMA	(..-07)	No CAN
 Cayenne	DASHBOARD	(..-07)	No CAN
 Cayenne	ELECTRONIC TRIM	(..-07)	No CAN
 Cayenne	ENGINE MANAGEME	(..-07)	No CAN
 Cayenne	MAINTENANCE	(..-07)	MANUAL
 Cayenne	MAINTENANCE	(..-07)	No CAN
 Cayenne	MAINTENANCE	(..-07)	No CAN
 Cayenne	MAINTENANCE	(..-07)	No CAN
 Cayenne	MAINTENANCE	(..-07)	No CAN
 Cayenne	MAINTENANCE	(..-07)	No CAN
 Cayenne	MAINTENANCE	(..-07)	No CAN
 Cayenne	MAINTENANCE	(..-07)	No CAN
 Cayenne	MAINTENANCE	(..-07)	No CAN
 Cayenne	MAINTENANCE	(..-07)	No CAN
 Cayenne	MAINTENANCE	(..-07)	No CAN
 Cayenne	PARKING HELP	(..-07)	No CAN
 Cayenne	SERVICE LIGHT RES	(..-07)	MANUAL
 Cayenne	SERVICE LIGHT RES	(..-07)	No CAN
 Cayenne	STEERING WHEEL E	(..-07)	No CAN
 Cayenne	TIRE PRESSURE	(..-07)	No CAN
 Cayenne	TOW FUNCTION	(..-07)	No CAN
 Cayenne	VEICHLE POSITION R	(..-07)	No CAN
 Cayenne	WIPERS	(..-07)	No CAN

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Proton

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 1.3	ENGINE MANAGEME	1.3 55kw (01-..)	EOBD
 1.6	ENGINE MANAGEME	1.6 70kw (01-..)	EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 11	ENGINE MANAGEME	1.7 54kw F3N-708	SIEMENS RENIX-BENDIX MPI
 11	ENGINE MANAGEME	1.7 54kw F3N-708	SIEMENS RENIX-BENDIX MPI
 11	ENGINE MANAGEME	1.7 54kw F3N-708	SIEMENS RENIX-BENDIX MPI
 11	ENGINE MANAGEME	1.7 54kw F3N-718	SIEMENS RENIX SPI
 11	ENGINE MANAGEME	1.7 54kw F3N-718	SIEMENS RENIX SPI
 11	ENGINE MANAGEME	1.7 54kw F3N-718	SIEMENS RENIX SPI
 11	ENGINE MANAGEME	1.7 54kw F3N-719	SIEMENS RENIX SPI
 11	ENGINE MANAGEME	1.7 54kw F3N-719	SIEMENS RENIX SPI
 19	ENGINE MANAGEME	1.2 43kw E7F-730	SIEMENS BOSCH SPI
 19	ENGINE MANAGEME	1.2 43kw E7F-730	SIEMENS BOSCH SPI
 19	ENGINE MANAGEME	1.2 43kw E7F-730	SIEMENS BOSCH SPI
 19	ENGINE MANAGEME	1.4 44kw C3J-710	SIEMENS RENIX SPI
 19	ENGINE MANAGEME	1.4 57kw C3J-710	SIEMENS RENIX SPI
 19	ENGINE MANAGEME	1.4 57kw E7J-700	SIEMENS BOSCH SPI
 19	ENGINE MANAGEME	1.4 57kw E7J-700	SIEMENS BOSCH SPI
 19	ENGINE MANAGEME	1.4 57kw E7J-700	SIEMENS BOSCH SPI
 19	ENGINE MANAGEME	1.4 57kw E7J-700	SIEMENS BOSCH SPI
 19	ENGINE MANAGEME	1.4 57kw E7J-702	SIEMENS BOSCH SPI
 19	ENGINE MANAGEME	1.4 57kw E7J-702	SIEMENS BOSCH SPI
 19	ENGINE MANAGEME	1.4 57kw E7J-702	SIEMENS BOSCH SPI
 19	ENGINE MANAGEME	1.4 57kw E7J-702	SIEMENS BOSCH SPI
 19	ENGINE MANAGEME	1.4 57kw E7J-702	SIEMENS BOSCH SPI
 19	ENGINE MANAGEME	1.4 57kw E7J-742	SIEMENS BOSCH SPI
 19	ENGINE MANAGEME	1.4 57kw E7J-742	SIEMENS BOSCH SPI
 19	ENGINE MANAGEME	1.4 57kw E7J-742	SIEMENS BOSCH SPI
 19	ENGINE MANAGEME	1.4 57kw E7J-745	SIEMENS BOSCH SPI
 19	ENGINE MANAGEME	1.4 57kw E7J-745	SIEMENS BOSCH SPI
 19	ENGINE MANAGEME	1.4 57kw E7J-745	SIEMENS BOSCH SPI
 19	ENGINE MANAGEME	1.4 57kw E7J-745	SIEMENS BOSCH SPI
 19	ENGINE MANAGEME	1.7 44kw F3N-742	SIEMENS RENIX MPI
 19	ENGINE MANAGEME	1.7 54kw F3N-740	SIEMENS RENIX SPI
 19	ENGINE MANAGEME	1.7 54kw F3N-740	SIEMENS RENIX SPI
 19	ENGINE MANAGEME	1.7 54kw F3N-741	SIEMENS RENIX SPI
 19	ENGINE MANAGEME	1.7 54kw F3N-741	SIEMENS RENIX SPI
 19	ENGINE MANAGEME	1.7 68kw F3N-743	SIEMENS RENIX MPI
 19	ENGINE MANAGEME	1.7 68kw F3N-743	SIEMENS RENIX MPI
 19	ENGINE MANAGEME	1.7 69kw F3N-742	SIEMENS RENIX MPI
 19	ENGINE MANAGEME	1.7 69kw F3N-742	SIEMENS RENIX MPI
 19	ENGINE MANAGEME	1.7 77kw F3N-746	SIEMENS RENIX MPI
 19	ENGINE MANAGEME	1.8 16v 101kw F7P-700	SIEMENS RENIX-BENDIX MPI
 19	ENGINE MANAGEME	1.8 16v 101kw F7P-700	SIEMENS RENIX-BENDIX MPI
 19	ENGINE MANAGEME	1.8 16v 99kw F7P-704	SIEMENS RENIX-BENDIX MPI
 19	ENGINE MANAGEME	1.8 16v 99kw F7P-704	SIEMENS RENIX-BENDIX MPI
 19	ENGINE MANAGEME	1.8 16v 99kw F7P-704	SIEMENS RENIX-BENDIX MPI
 19	ENGINE MANAGEME	1.8 16v 99kw F7P-704	SIEMENS RENIX-BENDIX MPI
 19	ENGINE MANAGEME	1.8 16v 99kw F7P-704	SIEMENS RENIX-BENDIX MPI
 19	ENGINE MANAGEME	1.8 16v 99kw F7P-704	SIEMENS RENIX-BENDIX MPI
 19	ENGINE MANAGEME	1.8 66kw F3P-706	SIEMENS BOSCH SPI
 19	ENGINE MANAGEME	1.8 66kw F3P-706	SIEMENS BOSCH SPI
 19	ENGINE MANAGEME	1.8 66kw F3P-706	SIEMENS BOSCH SPI
 19	ENGINE MANAGEME	1.8 66kw F3P-706	SIEMENS BOSCH SPI
 19	ENGINE MANAGEME	1.8 66kw F3P-707	SIEMENS BOSCH SPI
 19	ENGINE MANAGEME	1.8 66kw F3P-760	Marelli IAW 6R
 19	ENGINE MANAGEME	1.8 66kw F3P-760	Marelli IAW 6R
 19	ENGINE MANAGEME	1.8 66kw F3P-760	Marelli IAW 6R
 19	ENGINE MANAGEME	1.8 66kw F3P-765	SIEMENS MPI
 19	ENGINE MANAGEME	1.8 68kw F3P-704	SIEMENS BOSCH SPI
 19	ENGINE MANAGEME	1.8 68kw F3P-704	SIEMENS BOSCH SPI

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

[illegible]

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

[illegible]

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 25	ENGINE MANAGEME	2.5 V6 151kw Z7U-700	SIEMENS RENIX-BENDIX MPI
 25	ENGINE MANAGEME	2.8 V6 104kw Z7W-709	SIEMENS RENIX-BENDIX MPI
 25	ENGINE MANAGEME	2.8 V6 104kw Z7W-709	SIEMENS RENIX-BENDIX MPI
 25	ENGINE MANAGEME	2.8 V6 113kw Z7W-706	SIEMENS RENIX-BENDIX MPI
 25	ENGINE MANAGEME	2.8 V6 113kw Z7W-706	SIEMENS RENIX-BENDIX MPI
 25	ENGINE MANAGEME	2.8 V6 113kw Z7W-706	SIEMENS RENIX-BENDIX MPI
 25	ENGINE MANAGEME	2.8 V6 113kw Z7W-706	SIEMENS RENIX-BENDIX MPI
 25	ENGINE MANAGEME	2.8 V6 113kw Z7W-707	SIEMENS RENIX-BENDIX MPI
 25	ENGINE MANAGEME	2.8 V6 113kw Z7W-707	SIEMENS RENIX-BENDIX MPI
 25	ENGINE MANAGEME	2.8 V6 113kw Z7W-707	SIEMENS RENIX-BENDIX MPI
 25	ENGINE MANAGEME	2.8 V6 113kw Z7W-707	SIEMENS RENIX-BENDIX MPI
 25	ENGINE MANAGEME	2.8 V6 118kw Z7W-700	SIEMENS RENIX-BENDIX MPI
 25	ENGINE MANAGEME	2.8 V6 118kw Z7W-700	SIEMENS RENIX-BENDIX MPI
 25	ENGINE MANAGEME	2.8 V6 118kw Z7W-701	SIEMENS RENIX-BENDIX MPI
 25	ENGINE MANAGEME	2.8 V6 118kw Z7W-701	SIEMENS RENIX-BENDIX MPI
 25	ENGINE MANAGEME	2.8 V6 118kw Z7W-701	SIEMENS RENIX-BENDIX MPI
 9	ENGINE MANAGEME	1.7 54kw F3N-718	SIEMENS RENIX-BENDIX SPI
 9	ENGINE MANAGEME	1.7 54kw F3N-718	SIEMENS RENIX-BENDIX SPI
 9	ENGINE MANAGEME	1.7 54kw F3N-719	SIEMENS RENIX-BENDIX SPI
 9	ENGINE MANAGEME	1.7 54kw F3N-719	SIEMENS RENIX-BENDIX SPI
 ALPINE	ENGINE MANAGEME	2.5 V6 134kw Z7U-730	SIEMENS RENIX-BENDIX MPI
 ALPINE	ENGINE MANAGEME	2.5 V6 134kw Z7U-730	SIEMENS RENIX-BENDIX MPI
 ALPINE	ENGINE MANAGEME	2.5 V6 134kw Z7U-730	SIEMENS RENIX-BENDIX MPI
 ALPINE	ENGINE MANAGEME	2.5 V6 134kw Z7U-734	SIEMENS RENIX-BENDIX MPI
 ALPINE	ENGINE MANAGEME	2.5 V6 134kw Z7U-734	SIEMENS RENIX-BENDIX MPI
 ALPINE	ENGINE MANAGEME	2.5 V6 134kw Z7X-744	SIEMENS RENIX-BENDIX MPI
 Avantime	AIRBAG	2.0 Turbo 16v 121kw	SAGEM - Autoliv AirBag ACU 3
 Avantime	AIRBAG	2.2 16v dCi 110kw	SAGEM - Autoliv AirBag ACU 3
 Avantime	AIRBAG	3.0 V6 24v 154kw	SAGEM - Autoliv AirBag ACU 3
 Avantime	ENGINE MANAGEME	2.0 Turbo 16v 121kw F4R-760	EOBD
 Avantime	ENGINE MANAGEME	2.2 16v dCi 110kw G9T-712	BOSCH EDC 15 C3 Common Rail
 Avantime	ENGINE MANAGEME	3.0 V6 24v 154kw L7X-721	EOBD
 Avantime	ENGINE MANAGEME	3.0 V6 24v 154kw L7X-722	EOBD
 Clio II p2-3-4	ENGINE MANAGEME	1.2 44kw D7F-G7	SIEMENS Sirius 32 AUTODETECT
 Clio II p2-3-4	ENGINE MANAGEME	1.4 55kw E7J-780	SIEMENS Sirius 32 AUTODETECT
 Clio II p2-3-4	ENGINE MANAGEME	1.6 16v 77kw K4M-734/48	SIEMENS Sirius 32 AUTODETECT
 Clio II p2-3-4	ENGINE MANAGEME	1.6 16v 81kw K4M-700	SIEMENS Sirius 32 AUTODETECT
 Clio II p2-3-4	ENGINE MANAGEME	2.0 16v 120kw F4R-732	SIEMENS Sirius 32 AUTODETECT
 Clio II p2-3-4	ENGINE MANAGEME	2.0 16v 124kw F4R-730	SIEMENS Sirius 32 AUTODETECT
 Clio II p2-3-4	ENGINE MANAGEME	2.0 16v 134kw F4R-738	SIEMENS Sirius 32 AUTODETECT
 Clio II	ABS	1.2 16v 55kw	BOSCH ABS 5.3
 Clio II	ABS	1.2 16v 55kw (04-..)	BOSCH ABS 8.0
 Clio II	ABS	1.2 44kw	BOSCH ABS 5.3
 Clio II	ABS	1.2 44kw	BOSCH ABS 5.3 T
 Clio II	ABS	1.2 44kw (04-..)	BOSCH ABS 8.0
 Clio II	ABS	1.2 GPL 44kw	BOSCH ABS 5.3
 Clio II	ABS	1.2 GPL 44kw	BOSCH ABS 5.3 T
 Clio II	ABS	1.2 GPL 44kw (04-..)	BOSCH ABS 8.0
 Clio II	ABS	1.4 16v 72kw	BOSCH ABS 5.3
 Clio II	ABS	1.4 16v 72kw	BOSCH ABS 5.3 T
 Clio II	ABS	1.4 16v 72kw (04-..)	BOSCH ABS 8.0
 Clio II	ABS	1.4 55kw	BOSCH ABS 5.3
 Clio II	ABS	1.4 55kw	BOSCH ABS 5.3 T
 Clio II	ABS	1.4 55kw (04-..)	BOSCH ABS 8.0
 Clio II	ABS	1.5 dCi 42kw	BOSCH ABS 5.3
 Clio II	ABS	1.5 dCi 42kw	BOSCH ABS 5.3 T
 Clio II	ABS	1.5 dCi 42kw (04-..)	BOSCH ABS 8.0

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Clio II	ABS	1.5 dCi 45kw	BOSCH ABS 5.3
 Clio II	ABS	1.5 dCi 45kw	BOSCH ABS 5.3 T
 Clio II	ABS	1.5 dCi 45kw (04-..)	BOSCH ABS 8.0
 Clio II	ABS	1.5 dCi 48kw	BOSCH ABS 5.3
 Clio II	ABS	1.5 dCi 48kw	BOSCH ABS 5.3 T
 Clio II	ABS	1.5 dCi 48kw (04-..)	BOSCH ABS 8.0
 Clio II	ABS	1.5 dCi 50kw	BOSCH ABS 5.3
 Clio II	ABS	1.5 dCi 50kw	BOSCH ABS 5.3 T
 Clio II	ABS	1.5 dCi 50kw (04-..)	BOSCH ABS 8.0
 Clio II	ABS	1.5 dCi 60kw	BOSCH ABS 5.3
 Clio II	ABS	1.5 dCi 60kw	BOSCH ABS 5.3 T
 Clio II	ABS	1.5 dCi 60kw (04-..)	BOSCH ABS 8.0
 Clio II	ABS	1.5 dCi 62kw	BOSCH ABS 5.3
 Clio II	ABS	1.5 dCi 62kw	BOSCH ABS 5.3 T
 Clio II	ABS	1.5 dCi 62kw (04-..)	BOSCH ABS 8.0
 Clio II	ABS	1.5 dCi 74kw	BOSCH ABS 5.3
 Clio II	ABS	1.5 dCi 74kw	BOSCH ABS 5.3 T
 Clio II	ABS	1.5 dCi 74kw (04-..)	BOSCH ABS 8.0
 Clio II	ABS	1.6 16v 77kw	BOSCH ABS 5.3
 Clio II	ABS	1.6 16v 77kw	BOSCH ABS 5.3 T
 Clio II	ABS	1.6 16v 77kw (04-..)	BOSCH ABS 8.0
 Clio II	ABS	1.6 16v 81kw	BOSCH ABS 5.3
 Clio II	ABS	1.6 16v 81kw	BOSCH ABS 5.3 T
 Clio II	ABS	1.6 16v 81kw (04-..)	BOSCH ABS 8.0
 Clio II	ABS	1.6 66kw	BOSCH ABS 5.3
 Clio II	ABS	1.6 66kw	BOSCH ABS 5.3 T
 Clio II	ABS	1.6 66kw (04-..)	BOSCH ABS 8.0
 Clio II	ABS	1.9 D 48kw	BOSCH ABS 5.3
 Clio II	ABS	1.9 D 48kw	BOSCH ABS 5.3 T
 Clio II	ABS	1.9 D 48kw (04-..)	BOSCH ABS 8.0
 Clio II	ABS	1.9 dTi 59kw	BOSCH ABS 5.3
 Clio II	ABS	1.9 dTi 59kw	BOSCH ABS 5.3 T
 Clio II	ABS	1.9 dTi 59kw (04-..)	BOSCH ABS 8.0
 Clio II	ABS	2.0 16v 120kw	BOSCH ABS 5.3
 Clio II	ABS	2.0 16v 120kw	BOSCH ABS 5.3 T
 Clio II	ABS	2.0 16v 120kw (04-..)	BOSCH ABS 8.0
 Clio II	ABS	2.0 16v 134kw	BOSCH ABS 5.3
 Clio II	ABS	2.0 16v 134kw	BOSCH ABS 5.3 T
 Clio II	ABS	2.0 16v 134kw (04-..)	BOSCH ABS 8.0
 Clio II	ABS	3.0 V6 24v 169kw	BOSCH ABS 5.3
 Clio II	ABS	3.0 V6 24v 169kw	BOSCH ABS 5.3 T
 Clio II	ABS	3.0 V6 24v 169kw (04-..)	BOSCH ABS 8.0
 Clio II	ABS	3.0 V6 24v 188kw	BOSCH ABS 5.3
 Clio II	ABS	3.0 V6 24v 188kw	BOSCH ABS 5.3 T
 Clio II	ABS	3.0 V6 24v 188kw (04-..)	BOSCH ABS 8.0
 Clio II	AIRBAG	1.2 16v 55kw	BOSCH AirBag AB8 (No CAN)
 Clio II	AIRBAG	1.2 16v 55kw	BOSCH AirBag AB8.2.E (CAN)
 Clio II	AIRBAG	1.2 44kw	BOSCH AirBag AB8 (No CAN)
 Clio II	AIRBAG	1.2 44kw	BOSCH AirBag AB8.2.E (CAN)
 Clio II	AIRBAG	1.2 GPL 44kw	BOSCH AirBag AB8 (No CAN)
 Clio II	AIRBAG	1.2 GPL 44kw	BOSCH AirBag AB8.2.E (CAN)
 Clio II	AIRBAG	1.4 16v 72kw	BOSCH AirBag AB8 (No CAN)
 Clio II	AIRBAG	1.4 16v 72kw	BOSCH AirBag AB8.2.E (CAN)
 Clio II	AIRBAG	1.4 55kw	BOSCH AirBag AB8 (No CAN)
 Clio II	AIRBAG	1.4 55kw	BOSCH AirBag AB8.2.E (CAN)
 Clio II	AIRBAG	1.5 dCi 42kw	BOSCH AirBag AB8 (No CAN)
 Clio II	AIRBAG	1.5 dCi 42kw	BOSCH AirBag AB8.2.E (CAN)
 Clio II	AIRBAG	1.5 dCi 45kw	BOSCH AirBag AB8 (No CAN)

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Clio II	AIRBAG	1.5 dCi 45kw	BOSCH AirBag AB8.2.E (CAN)
 Clio II	AIRBAG	1.5 dCi 48kw	BOSCH AirBag AB8 (No CAN)
 Clio II	AIRBAG	1.5 dCi 48kw	BOSCH AirBag AB8.2.E (CAN)
 Clio II	AIRBAG	1.5 dCi 50kw	BOSCH AirBag AB8 (No CAN)
 Clio II	AIRBAG	1.5 dCi 50kw	BOSCH AirBag AB8.2.E (CAN)
 Clio II	AIRBAG	1.5 dCi 60kw	BOSCH AirBag AB8 (No CAN)
 Clio II	AIRBAG	1.5 dCi 60kw	BOSCH AirBag AB8.2.E (CAN)
 Clio II	AIRBAG	1.5 dCi 62kw	BOSCH AirBag AB8 (No CAN)
 Clio II	AIRBAG	1.5 dCi 62kw	BOSCH AirBag AB8.2.E (CAN)
 Clio II	AIRBAG	1.5 dCi 74kw	BOSCH AirBag AB8 (No CAN)
 Clio II	AIRBAG	1.5 dCi 74kw	BOSCH AirBag AB8.2.E (CAN)
 Clio II	AIRBAG	1.6 16v 77kw	BOSCH AirBag AB8 (No CAN)
 Clio II	AIRBAG	1.6 16v 77kw	BOSCH AirBag AB8.2.E (CAN)
 Clio II	AIRBAG	1.6 16v 81kw	BOSCH AirBag AB8 (No CAN)
 Clio II	AIRBAG	1.6 16v 81kw	BOSCH AirBag AB8.2.E (CAN)
 Clio II	AIRBAG	1.6 66kw	BOSCH AirBag AB8 (No CAN)
 Clio II	AIRBAG	1.6 66kw	BOSCH AirBag AB8.2.E (CAN)
 Clio II	AIRBAG	1.9 D 48kw	BOSCH AirBag AB8 (No CAN)
 Clio II	AIRBAG	1.9 D 48kw	BOSCH AirBag AB8.2.E (CAN)
 Clio II	AIRBAG	1.9 dTi 59kw	BOSCH AirBag AB8 (No CAN)
 Clio II	AIRBAG	1.9 dTi 59kw	BOSCH AirBag AB8.2.E (CAN)
 Clio II	AIRBAG	2.0 16v 120kw	BOSCH AirBag AB8 (No CAN)
 Clio II	AIRBAG	2.0 16v 120kw	BOSCH AirBag AB8.2.E (CAN)
 Clio II	AIRBAG	2.0 16v 124kw	BOSCH AirBag AB8 (No CAN)
 Clio II	AIRBAG	2.0 16v 124kw	BOSCH AirBag AB8.2.E (CAN)
 Clio II	AIRBAG	2.0 16v 134kw	BOSCH AirBag AB8 (No CAN)
 Clio II	AIRBAG	2.0 16v 134kw	BOSCH AirBag AB8.2.E (CAN)
 Clio II	AIRBAG	3.0 V6 24v 188kw	BOSCH AirBag AB8 (No CAN)
 Clio II	AIRBAG	3.0 V6 24v 188kw	BOSCH AirBag AB8.2.E (CAN)
 Clio II	CHASSIS NETWORK	1.2 16v 55kw	SAGEM Body Computer
 Clio II	CHASSIS NETWORK	1.2 44kw	SAGEM Body Computer
 Clio II	CHASSIS NETWORK	1.2 GPL 44kw	SAGEM Body Computer
 Clio II	CHASSIS NETWORK	1.4 16v 72kw	SAGEM Body Computer
 Clio II	CHASSIS NETWORK	1.4 55kw	SAGEM Body Computer
 Clio II	CHASSIS NETWORK	1.5 dCi 42kw	SAGEM Body Computer
 Clio II	CHASSIS NETWORK	1.5 dCi 45kw	SAGEM Body Computer
 Clio II	CHASSIS NETWORK	1.5 dCi 48kw	SAGEM Body Computer
 Clio II	CHASSIS NETWORK	1.5 dCi 50kw	SAGEM Body Computer
 Clio II	CHASSIS NETWORK	1.5 dCi 60kw	SAGEM Body Computer
 Clio II	CHASSIS NETWORK	1.5 dCi 62kw	SAGEM Body Computer
 Clio II	CHASSIS NETWORK	1.5 dCi 74kw	SAGEM Body Computer
 Clio II	CHASSIS NETWORK	1.6 16v 77kw	SAGEM Body Computer
 Clio II	CHASSIS NETWORK	1.6 16v 81kw	SAGEM Body Computer
 Clio II	CHASSIS NETWORK	1.6 66kw	SAGEM Body Computer
 Clio II	CHASSIS NETWORK	1.9 D 48kw	SAGEM Body Computer
 Clio II	CHASSIS NETWORK	1.9 dTi 59kw	SAGEM Body Computer
 Clio II	CHASSIS NETWORK	2.0 16v 120kw	SAGEM Body Computer
 Clio II	CHASSIS NETWORK	2.0 16v 124kw	SAGEM Body Computer
 Clio II	CHASSIS NETWORK	2.0 16v 134kw	SAGEM Body Computer
 Clio II	CHASSIS NETWORK	3.0 V6 24v 169kw	SAGEM Body Computer
 Clio II	CHASSIS NETWORK	3.0 V6 24v 188kw	SAGEM Body Computer
 Clio II	DIESEL MANAGEMEN	1.9 dTi 59kw F9Q-782 (...01)	BOSCH MSA 15
 Clio II	ELECTRIC STEERING	1.2 16v 55kw	KOYO SEICO D.A.E. 65
 Clio II	ELECTRIC STEERING	1.2 44kw	KOYO SEICO D.A.E. 65
 Clio II	ELECTRIC STEERING	1.2 GPL 44kw	KOYO SEICO D.A.E. 65
 Clio II	ELECTRIC STEERING	1.4 16v 72kw	KOYO SEICO D.A.E. 65
 Clio II	ELECTRIC STEERING	1.4 55kw	KOYO SEICO D.A.E. 65
 Clio II	ELECTRIC STEERING	1.5 dCi 42kw	KOYO SEICO D.A.E. 65

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Clio II	ELECTRIC STEERING	1.5 dCi 45kw	KOYO SEICO D.A.E. 65
 Clio II	ELECTRIC STEERING	1.5 dCi 48kw	KOYO SEICO D.A.E. 65
 Clio II	ELECTRIC STEERING	1.5 dCi 50kw	KOYO SEICO D.A.E. 65
 Clio II	ELECTRIC STEERING	1.5 dCi 60kw	KOYO SEICO D.A.E. 65
 Clio II	ELECTRIC STEERING	1.5 dCi 62kw	KOYO SEICO D.A.E. 65
 Clio II	ELECTRIC STEERING	1.5 dCi 74kw	KOYO SEICO D.A.E. 65
 Clio II	ELECTRIC STEERING	1.6 16v 77kw	KOYO SEICO D.A.E. 65
 Clio II	ELECTRIC STEERING	1.6 16v 81kw	KOYO SEICO D.A.E. 65
 Clio II	ELECTRIC STEERING	1.6 66kw	KOYO SEICO D.A.E. 65
 Clio II	ELECTRIC STEERING	1.9 D 48kw	KOYO SEICO D.A.E. 65
 Clio II	ELECTRIC STEERING	1.9 dTi 59kw	KOYO SEICO D.A.E. 65
 Clio II	ELECTRIC STEERING	2.0 16v 120kw	KOYO SEICO D.A.E. 65
 Clio II	ELECTRIC STEERING	2.0 16v 124kw	KOYO SEICO D.A.E. 65
 Clio II	ELECTRIC STEERING	2.0 16v 134kw	KOYO SEICO D.A.E. 65
 Clio II	ELECTRIC STEERING	3.0 V6 24v 169kw	KOYO SEICO D.A.E. 65
 Clio II	ELECTRIC STEERING	3.0 V6 24v 188kw	KOYO SEICO D.A.E. 65
 Clio II	ENGINE MANAGEME	1.2 16v 55kw D4F-712	Marelli 5NR
 Clio II	ENGINE MANAGEME	1.2 16v 55kw D4F-712 (01-..)	EOBD
 Clio II	ENGINE MANAGEME	1.2 44kw D7F-730	SAGEM SAFIR MPI
 Clio II	ENGINE MANAGEME	1.2 44kw D7F-730	SAGEM SAFIR MPI
 Clio II	ENGINE MANAGEME	1.2 44kw D7F-730	SAGEM SAFIR MPI
 Clio II	ENGINE MANAGEME	1.2 44kw D7F-730	SAGEM SAFIR MPI
 Clio II	ENGINE MANAGEME	1.2 44kw D7F-730	SAGEM SAFIR MPI
 Clio II	ENGINE MANAGEME	1.2 44kw D7F-730	SAGEM SAFIR MPI
 Clio II	ENGINE MANAGEME	1.2 44kw D7F-G7	SIEMENS Sirius 32
 Clio II	ENGINE MANAGEME	1.2 44kw D7F-G7	SIEMENS Sirius 32 AUTODETECT
 Clio II	ENGINE MANAGEME	1.2 GPL 44kw D7F-720/22	SIEMENS Sirius 32
 Clio II	ENGINE MANAGEME	1.2 GPL 44kw D7F-720/22 (01-..)	EOBD
 Clio II	ENGINE MANAGEME	1.2 GPL 44kw D7F-722	SIEMENS Sirius 32
 Clio II	ENGINE MANAGEME	1.2 GPL 44kw D7F-722 (01-..)	EOBD
 Clio II	ENGINE MANAGEME	1.4 16v 72kw K4J-712	SIEMENS Sirius 32
 Clio II	ENGINE MANAGEME	1.4 16v 72kw K4J-712 (01-..)	EOBD
 Clio II	ENGINE MANAGEME	1.4 55kw E7J-780	SIEMENS FENIX 5
 Clio II	ENGINE MANAGEME	1.4 55kw E7J-780	SIEMENS Sirius 32
 Clio II	ENGINE MANAGEME	1.4 55kw E7J-780	SIEMENS Sirius 32 AUTODETECT
 Clio II	ENGINE MANAGEME	1.5 dCi 45kw K9K-716 (..-04)	DELPHI LUCAS LVCR Common Rail
 Clio II	ENGINE MANAGEME	1.5 dCi 45kw K9K-716 (05-..)	DELPHI LUCAS LVCR Common Rail
 Clio II	ENGINE MANAGEME	1.5 dCi 48kw K9K-700 (..-04)	DELPHI LUCAS LVCR Common Rail
 Clio II	ENGINE MANAGEME	1.5 dCi 48kw K9K-700 (05-..)	DELPHI LUCAS LVCR Common Rail
 Clio II	ENGINE MANAGEME	1.5 dCi 50kw K9K-714 (..-04)	DELPHI LUCAS LVCR Common Rail
 Clio II	ENGINE MANAGEME	1.5 dCi 50kw K9K-714 (05-..)	DELPHI LUCAS LVCR Common Rail
 Clio II	ENGINE MANAGEME	1.5 dCi 60kw K9K-702 (..-04)	DELPHI LUCAS LVCR Common Rail
 Clio II	ENGINE MANAGEME	1.5 dCi 60kw K9K-702 (05-..)	DELPHI LUCAS LVCR Common Rail
 Clio II	ENGINE MANAGEME	1.5 dCi 62kw K9K-718 (..-04)	DELPHI LUCAS LVCR Common Rail
 Clio II	ENGINE MANAGEME	1.5 dCi 62kw K9K-718 (05-..)	DELPHI LUCAS LVCR Common Rail
 Clio II	ENGINE MANAGEME	1.5 dCi 74kw K9K-714 (..-04)	DELPHI LUCAS LVCR Common Rail
 Clio II	ENGINE MANAGEME	1.5 dCi 74kw K9K-714 (05-..)	DELPHI LUCAS LVCR Common Rail
 Clio II	ENGINE MANAGEME	1.6 16v 77kw K4M-734/48	SIEMENS Sirius 32
 Clio II	ENGINE MANAGEME	1.6 16v 77kw K4M-734/48	SIEMENS Sirius 32 AUTODETECT
 Clio II	ENGINE MANAGEME	1.6 16v 81kw K4M-700	SIEMENS Sirius 32
 Clio II	ENGINE MANAGEME	1.6 16v 81kw K4M-700	SIEMENS Sirius 32 AUTODETECT
 Clio II	ENGINE MANAGEME	1.6 66kw K7M-744	SIEMENS FENIX 5
 Clio II	ENGINE MANAGEME	1.6 66kw K7M-745	SIEMENS FENIX 5
 Clio II	ENGINE MANAGEME	1.9 D 48kw F8Q-630	LUCAS Diesel DCU3R
 Clio II	ENGINE MANAGEME	2.0 16v 120kw F4R-732	SIEMENS Sirius 32 AUTODETECT
 Clio II	ENGINE MANAGEME	2.0 16v 120kw F4R-732	SIEMENS Sirius 32x
 Clio II	ENGINE MANAGEME	2.0 16v 124kw F4R-730	SIEMENS Sirius 32 AUTODETECT
 Clio II	ENGINE MANAGEME	2.0 16v 124kw F4R-730	SIEMENS Sirius 32x

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Clio II	ENGINE MANAGEME	2.0 16v 134kw F4R-738	SIEMENS Sirius 32 AUTODETECT
 Clio II	ENGINE MANAGEME	2.0 16v 134kw F4R-738	SIEMENS Sirius 32x
 Clio II	IMMOBILIZER	1.2 16v 55kw	SAGEM Immobilizer Key encoding
 Clio II	IMMOBILIZER	1.2 44kw	SAGEM Immobilizer Key encoding
 Clio II	IMMOBILIZER	1.2 GPL 44kw	SAGEM Immobilizer Key encoding
 Clio II	IMMOBILIZER	1.4 16v 72kw	SAGEM Immobilizer Key encoding
 Clio II	IMMOBILIZER	1.4 55kw	SAGEM Immobilizer Key encoding
 Clio II	IMMOBILIZER	1.5 dCi 42kw	SAGEM Immobilizer Key encoding
 Clio II	IMMOBILIZER	1.5 dCi 45kw	SAGEM Immobilizer Key encoding
 Clio II	IMMOBILIZER	1.5 dCi 48kw	SAGEM Immobilizer Key encoding
 Clio II	IMMOBILIZER	1.5 dCi 50kw	SAGEM Immobilizer Key encoding
 Clio II	IMMOBILIZER	1.5 dCi 60kw	SAGEM Immobilizer Key encoding
 Clio II	IMMOBILIZER	1.5 dCi 62kw	SAGEM Immobilizer Key encoding
 Clio II	IMMOBILIZER	1.5 dCi 74kw	SAGEM Immobilizer Key encoding
 Clio II	IMMOBILIZER	1.6 16v 77kw	SAGEM Immobilizer Key encoding
 Clio II	IMMOBILIZER	1.6 16v 81kw	SAGEM Immobilizer Key encoding
 Clio II	IMMOBILIZER	1.6 66kw	SAGEM Immobilizer Key encoding
 Clio II	IMMOBILIZER	1.9 D 48kw	SAGEM Immobilizer Key encoding
 Clio II	IMMOBILIZER	1.9 dTi 59kw	SAGEM Immobilizer Key encoding
 Clio II	IMMOBILIZER	2.0 16v 120kw	SAGEM Immobilizer Key encoding
 Clio II	IMMOBILIZER	2.0 16v 124kw	SAGEM Immobilizer Key encoding
 Clio II	IMMOBILIZER	2.0 16v 134kw	SAGEM Immobilizer Key encoding
 Clio II	IMMOBILIZER	3.0 V6 24v 169kw	SAGEM Immobilizer Key encoding
 Clio II	IMMOBILIZER	3.0 V6 24v 188kw	SAGEM Immobilizer Key encoding
 Clio II	MAINTENANCE	1.2 16v 55kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.2 16v 55kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.2 16v 55kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.2 16v 55kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.2 44kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.2 44kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.2 44kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.2 44kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.2 GPL 44kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.2 GPL 44kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.2 GPL 44kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.2 GPL 44kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.4 16v 72kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.4 16v 72kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.4 16v 72kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.4 55kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.4 55kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.4 55kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.4 55kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.5 dCi 42kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.5 dCi 42kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.5 dCi 42kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.5 dCi 42kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.5 dCi 45kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.5 dCi 45kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.5 dCi 45kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.5 dCi 45kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.5 dCi 45kw K9K-716 (05-..)	DELPHI LUCAS LVCR Common Rail
 Clio II	MAINTENANCE	1.5 dCi 48kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.5 dCi 48kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.5 dCi 48kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.5 dCi 48kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.5 dCi 48kw K9K-700 (05-..)	DELPHI LUCAS LVCR Common Rail

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Clio II	MAINTENANCE	1.5 dCi 50kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.5 dCi 50kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.5 dCi 50kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.5 dCi 50kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.5 dCi 50kw K9K-714 (05-..)	DELPHI LUCAS LVCR Common Rail
 Clio II	MAINTENANCE	1.5 dCi 60kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.5 dCi 60kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.5 dCi 60kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.5 dCi 60kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.5 dCi 60kw K9K-702 (05-..)	DELPHI LUCAS LVCR Common Rail
 Clio II	MAINTENANCE	1.5 dCi 62kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.5 dCi 62kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.5 dCi 62kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.5 dCi 62kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.5 dCi 62kw K9K-718 (05-..)	DELPHI LUCAS LVCR Common Rail
 Clio II	MAINTENANCE	1.5 dCi 74kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.5 dCi 74kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.5 dCi 74kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.5 dCi 74kw K9K-714 (05-..)	DELPHI LUCAS LVCR Common Rail
 Clio II	MAINTENANCE	1.6 16v 77kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.6 16v 77kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.6 16v 77kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.6 16v 77kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.6 16v 81kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.6 16v 81kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.6 16v 81kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.6 16v 81kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.6 66kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.6 66kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.6 66kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.6 66kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.9 D 48kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.9 D 48kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.9 D 48kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.9 D 48kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.9 dTi 59kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.9 dTi 59kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.9 dTi 59kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	1.9 dTi 59kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	2.0 16v 120kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	2.0 16v 120kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	2.0 16v 120kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	2.0 16v 120kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	2.0 16v 134kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	2.0 16v 134kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	2.0 16v 134kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	2.0 16v 134kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	3.0 V6 24v 169kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	3.0 V6 24v 169kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	3.0 V6 24v 169kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	3.0 V6 24v 169kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	3.0 V6 24v 188kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	3.0 V6 24v 188kw (04-..)	BOSCH ABS 8.0
 Clio II	MAINTENANCE	3.0 V6 24v 188kw (04-..)	BOSCH ABS 8.0
 Clio III	ABS	1.2 16v 48kw	AUTODETECT
 Clio III	ABS	1.2 16v 48kw	BOSCH ABS 8.0

Systems supported by ECUREADER / ECUDECODER (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Clio III	ABS	1.2 16v 55kw	AUTODETECT
 Clio III	ABS	1.2 16v 55kw	BOSCH ABS 8.0
 Clio III	ABS	1.2 16v 58kw	AUTODETECT
 Clio III	ABS	1.2 16v 58kw	BOSCH ABS 8.0
 Clio III	ABS	1.2 16v 74kw	AUTODETECT
 Clio III	ABS	1.2 16v 74kw	BOSCH ABS 8.0
 Clio III	ABS	1.2 16v GPL 55kw	AUTODETECT
 Clio III	ABS	1.2 16v GPL 55kw	BOSCH ABS 8.0
 Clio III	ABS	1.4 16v 72kw	AUTODETECT
 Clio III	ABS	1.4 16v 72kw	BOSCH ABS 8.0
 Clio III	ABS	1.5 dCi 48kw	AUTODETECT
 Clio III	ABS	1.5 dCi 48kw	BOSCH ABS 8.0
 Clio III	ABS	1.5 dCi 50kw	AUTODETECT
 Clio III	ABS	1.5 dCi 50kw	BOSCH ABS 8.0
 Clio III	ABS	1.5 dCi 63kw	AUTODETECT
 Clio III	ABS	1.5 dCi 63kw	BOSCH ABS 8.0
 Clio III	ABS	1.5 dCi 76kw FAP	AUTODETECT
 Clio III	ABS	1.5 dCi 76kw FAP	BOSCH ABS 8.0
 Clio III	ABS	1.5 dCi 78kw	AUTODETECT
 Clio III	ABS	1.5 dCi 78kw	BOSCH ABS 8.0
 Clio III	ABS	1.6 16v 65kw	AUTODETECT
 Clio III	ABS	1.6 16v 65kw	BOSCH ABS 8.0
 Clio III	ABS	1.6 16v 82kw	AUTODETECT
 Clio III	ABS	1.6 16v 82kw	BOSCH ABS 8.0
 Clio III	ABS	1.6 16v 94kw	AUTODETECT
 Clio III	ABS	1.6 16v 94kw	BOSCH ABS 8.0
 Clio III	ABS	2.0 16v 100kw	AUTODETECT
 Clio III	ABS	2.0 16v 100kw	BOSCH ABS 8.0
 Clio III	ABS	2.0 16v 101kw	AUTODETECT
 Clio III	ABS	2.0 16v 101kw	BOSCH ABS 8.0
 Clio III	ABS	2.0 16v 145kw	AUTODETECT
 Clio III	ABS	2.0 16v 145kw	BOSCH ABS 8.0
 Clio III	ABS	2.0 16v 147kw	AUTODETECT
 Clio III	ABS	2.0 16v 147kw	BOSCH ABS 8.0
 Clio III	AIRBAG	1.2 16v 48kw	AUTODETECT
 Clio III	AIRBAG	1.2 16v 48kw	BOSCH AirBag AB9
 Clio III	AIRBAG	1.2 16v 55kw	AUTODETECT
 Clio III	AIRBAG	1.2 16v 55kw	BOSCH AirBag AB9
 Clio III	AIRBAG	1.2 16v 58kw	AUTODETECT
 Clio III	AIRBAG	1.2 16v 58kw	BOSCH AirBag AB9
 Clio III	AIRBAG	1.2 16v 74kw	AUTODETECT
 Clio III	AIRBAG	1.2 16v 74kw	BOSCH AirBag AB9
 Clio III	AIRBAG	1.2 16v GPL 55kw	AUTODETECT
 Clio III	AIRBAG	1.2 16v GPL 55kw	BOSCH AirBag AB9
 Clio III	AIRBAG	1.4 16v 72kw	AUTODETECT
 Clio III	AIRBAG	1.4 16v 72kw	BOSCH AirBag AB9
 Clio III	AIRBAG	1.5 dCi 48kw	AUTODETECT
 Clio III	AIRBAG	1.5 dCi 48kw	BOSCH AirBag AB9
 Clio III	AIRBAG	1.5 dCi 50kw	AUTODETECT
 Clio III	AIRBAG	1.5 dCi 50kw	BOSCH AirBag AB9
 Clio III	AIRBAG	1.5 dCi 63kw	AUTODETECT
 Clio III	AIRBAG	1.5 dCi 63kw	BOSCH AirBag AB9
 Clio III	AIRBAG	1.5 dCi 76kw FAP	AUTODETECT
 Clio III	AIRBAG	1.5 dCi 76kw FAP	BOSCH AirBag AB9
 Clio III	AIRBAG	1.5 dCi 78kw	AUTODETECT
 Clio III	AIRBAG	1.5 dCi 78kw	BOSCH AirBag AB9
 Clio III	AIRBAG	1.6 16v 65kw	AUTODETECT
 Clio III	AIRBAG	1.6 16v 65kw	BOSCH AirBag AB9

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Clio III	AIRBAG	1.6 16v 82kw	AUTODETECT
 Clio III	AIRBAG	1.6 16v 82kw	BOSCH AirBag AB9
 Clio III	AIRBAG	1.6 16v 94kw	AUTODETECT
 Clio III	AIRBAG	1.6 16v 94kw	BOSCH AirBag AB9
 Clio III	AIRBAG	2.0 16v 100kw	AUTODETECT
 Clio III	AIRBAG	2.0 16v 100kw	BOSCH AirBag AB9
 Clio III	AIRBAG	2.0 16v 101kw	AUTODETECT
 Clio III	AIRBAG	2.0 16v 101kw	BOSCH AirBag AB9
 Clio III	AIRBAG	2.0 16v 145kw	AUTODETECT
 Clio III	AIRBAG	2.0 16v 145kw	BOSCH AirBag AB9
 Clio III	AIRBAG	2.0 16v 147kw	AUTODETECT
 Clio III	AIRBAG	2.0 16v 147kw	BOSCH AirBag AB9
 Clio III	AUTOM. TRANSMISSI	1.2 16v 48kw	AUTODETECT
 Clio III	AUTOM. TRANSMISSI	1.2 16v 55kw	AUTODETECT
 Clio III	AUTOM. TRANSMISSI	1.2 16v 58kw	AUTODETECT
 Clio III	AUTOM. TRANSMISSI	1.2 16v 74kw	AUTODETECT
 Clio III	AUTOM. TRANSMISSI	1.2 16v GPL 55kw	AUTODETECT
 Clio III	AUTOM. TRANSMISSI	1.4 16v 72kw	AUTODETECT
 Clio III	AUTOM. TRANSMISSI	1.5 dCi 48kw	AUTODETECT
 Clio III	AUTOM. TRANSMISSI	1.5 dCi 50kw	AUTODETECT
 Clio III	AUTOM. TRANSMISSI	1.5 dCi 63kw	AUTODETECT
 Clio III	AUTOM. TRANSMISSI	1.5 dCi 76kw FAP	AUTODETECT
 Clio III	AUTOM. TRANSMISSI	1.5 dCi 78kw	AUTODETECT
 Clio III	AUTOM. TRANSMISSI	1.6 16v 65kw	AUTODETECT
 Clio III	AUTOM. TRANSMISSI	1.6 16v 82kw	AUTODETECT
 Clio III	AUTOM. TRANSMISSI	1.6 16v 94kw	AUTODETECT
 Clio III	AUTOM. TRANSMISSI	2.0 16v 100kw	AUTODETECT
 Clio III	AUTOM. TRANSMISSI	2.0 16v 101kw	AUTODETECT
 Clio III	AUTOM. TRANSMISSI	2.0 16v 145kw	AUTODETECT
 Clio III	AUTOM. TRANSMISSI	2.0 16v 147kw	AUTODETECT
 Clio III	CHASSIS NETWORK	1.2 16v 48kw	Body Computer UCH
 Clio III	CHASSIS NETWORK	1.2 16v 48kw	Body Computer UPC
 Clio III	CHASSIS NETWORK	1.2 16v 48kw	UCH AUTODETECT
 Clio III	CHASSIS NETWORK	1.2 16v 48kw	UPC AUTODETECT
 Clio III	CHASSIS NETWORK	1.2 16v 55kw	Body Computer UCH
 Clio III	CHASSIS NETWORK	1.2 16v 55kw	Body Computer UPC
 Clio III	CHASSIS NETWORK	1.2 16v 55kw	UCH AUTODETECT
 Clio III	CHASSIS NETWORK	1.2 16v 55kw	UPC AUTODETECT
 Clio III	CHASSIS NETWORK	1.2 16v 58kw	Body Computer UCH
 Clio III	CHASSIS NETWORK	1.2 16v 58kw	Body Computer UPC
 Clio III	CHASSIS NETWORK	1.2 16v 58kw	UCH AUTODETECT
 Clio III	CHASSIS NETWORK	1.2 16v 58kw	UPC AUTODETECT
 Clio III	CHASSIS NETWORK	1.2 16v 74kw	Body Computer UCH
 Clio III	CHASSIS NETWORK	1.2 16v 74kw	Body Computer UPC
 Clio III	CHASSIS NETWORK	1.2 16v 74kw	UCH AUTODETECT
 Clio III	CHASSIS NETWORK	1.2 16v 74kw	UPC AUTODETECT
 Clio III	CHASSIS NETWORK	1.2 16v GPL 55kw	Body Computer UCH
 Clio III	CHASSIS NETWORK	1.2 16v GPL 55kw	Body Computer UPC
 Clio III	CHASSIS NETWORK	1.2 16v GPL 55kw	UCH AUTODETECT
 Clio III	CHASSIS NETWORK	1.2 16v GPL 55kw	UPC AUTODETECT
 Clio III	CHASSIS NETWORK	1.4 16v 72kw	Body Computer UCH
 Clio III	CHASSIS NETWORK	1.4 16v 72kw	Body Computer UPC
 Clio III	CHASSIS NETWORK	1.4 16v 72kw	UCH AUTODETECT
 Clio III	CHASSIS NETWORK	1.4 16v 72kw	UPC AUTODETECT
 Clio III	CHASSIS NETWORK	1.5 dCi 48kw	Body Computer UCH
 Clio III	CHASSIS NETWORK	1.5 dCi 48kw	Body Computer UPC
 Clio III	CHASSIS NETWORK	1.5 dCi 48kw	UCH AUTODETECT
 Clio III	CHASSIS NETWORK	1.5 dCi 48kw	UPC AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Clio III	CHASSIS NETWORK	1.5 dCi 50kw	Body Computer UCH
 Clio III	CHASSIS NETWORK	1.5 dCi 50kw	Body Computer UPC
 Clio III	CHASSIS NETWORK	1.5 dCi 50kw	UCH AUTODETECT
 Clio III	CHASSIS NETWORK	1.5 dCi 50kw	UPC AUTODETECT
 Clio III	CHASSIS NETWORK	1.5 dCi 63kw	Body Computer UCH
 Clio III	CHASSIS NETWORK	1.5 dCi 63kw	Body Computer UPC
 Clio III	CHASSIS NETWORK	1.5 dCi 63kw	UCH AUTODETECT
 Clio III	CHASSIS NETWORK	1.5 dCi 63kw	UPC AUTODETECT
 Clio III	CHASSIS NETWORK	1.5 dCi 76kw FAP	Body Computer UCH
 Clio III	CHASSIS NETWORK	1.5 dCi 76kw FAP	Body Computer UPC
 Clio III	CHASSIS NETWORK	1.5 dCi 76kw FAP	UCH AUTODETECT
 Clio III	CHASSIS NETWORK	1.5 dCi 76kw FAP	UPC AUTODETECT
 Clio III	CHASSIS NETWORK	1.5 dCi 78kw	Body Computer UCH
 Clio III	CHASSIS NETWORK	1.5 dCi 78kw	Body Computer UPC
 Clio III	CHASSIS NETWORK	1.5 dCi 78kw	UCH AUTODETECT
 Clio III	CHASSIS NETWORK	1.5 dCi 78kw	UPC AUTODETECT
 Clio III	CHASSIS NETWORK	1.6 16v 65kw	Body Computer UCH
 Clio III	CHASSIS NETWORK	1.6 16v 65kw	Body Computer UPC
 Clio III	CHASSIS NETWORK	1.6 16v 65kw	UCH AUTODETECT
 Clio III	CHASSIS NETWORK	1.6 16v 65kw	UPC AUTODETECT
 Clio III	CHASSIS NETWORK	1.6 16v 82kw	Body Computer UCH
 Clio III	CHASSIS NETWORK	1.6 16v 82kw	Body Computer UPC
 Clio III	CHASSIS NETWORK	1.6 16v 82kw	UCH AUTODETECT
 Clio III	CHASSIS NETWORK	1.6 16v 82kw	UPC AUTODETECT
 Clio III	CHASSIS NETWORK	1.6 16v 94kw	Body Computer UCH
 Clio III	CHASSIS NETWORK	1.6 16v 94kw	Body Computer UPC
 Clio III	CHASSIS NETWORK	1.6 16v 94kw	UCH AUTODETECT
 Clio III	CHASSIS NETWORK	1.6 16v 94kw	UPC AUTODETECT
 Clio III	CHASSIS NETWORK	2.0 16v 100kw	Body Computer UCH
 Clio III	CHASSIS NETWORK	2.0 16v 100kw	Body Computer UPC
 Clio III	CHASSIS NETWORK	2.0 16v 100kw	UCH AUTODETECT
 Clio III	CHASSIS NETWORK	2.0 16v 100kw	UPC AUTODETECT
 Clio III	CHASSIS NETWORK	2.0 16v 101kw	Body Computer UCH
 Clio III	CHASSIS NETWORK	2.0 16v 101kw	Body Computer UPC
 Clio III	CHASSIS NETWORK	2.0 16v 101kw	UCH AUTODETECT
 Clio III	CHASSIS NETWORK	2.0 16v 101kw	UPC AUTODETECT
 Clio III	CHASSIS NETWORK	2.0 16v 145kw	Body Computer UCH
 Clio III	CHASSIS NETWORK	2.0 16v 145kw	Body Computer UPC
 Clio III	CHASSIS NETWORK	2.0 16v 145kw	UCH AUTODETECT
 Clio III	CHASSIS NETWORK	2.0 16v 145kw	UPC AUTODETECT
 Clio III	CHASSIS NETWORK	2.0 16v 147kw	Body Computer UCH
 Clio III	CHASSIS NETWORK	2.0 16v 147kw	Body Computer UPC
 Clio III	CHASSIS NETWORK	2.0 16v 147kw	UCH AUTODETECT
 Clio III	CHASSIS NETWORK	2.0 16v 147kw	UPC AUTODETECT
 Clio III	CLIMA	1.2 16v 48kw	AUTODETECT
 Clio III	CLIMA	1.2 16v 55kw	AUTODETECT
 Clio III	CLIMA	1.2 16v 58kw	AUTODETECT
 Clio III	CLIMA	1.2 16v 74kw	AUTODETECT
 Clio III	CLIMA	1.2 16v GPL 55kw	AUTODETECT
 Clio III	CLIMA	1.4 16v 72kw	AUTODETECT
 Clio III	CLIMA	1.5 dCi 48kw	AUTODETECT
 Clio III	CLIMA	1.5 dCi 50kw	AUTODETECT
 Clio III	CLIMA	1.5 dCi 63kw	AUTODETECT
 Clio III	CLIMA	1.5 dCi 76kw FAP	AUTODETECT
 Clio III	CLIMA	1.5 dCi 78kw	AUTODETECT
 Clio III	CLIMA	1.6 16v 65kw	AUTODETECT
 Clio III	CLIMA	1.6 16v 82kw	AUTODETECT
 Clio III	CLIMA	1.6 16v 94kw	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Clio III	CLIMA	2.0 16v 100kw	AUTODETECT
 Clio III	CLIMA	2.0 16v 101kw	AUTODETECT
 Clio III	CLIMA	2.0 16v 145kw	AUTODETECT
 Clio III	CLIMA	2.0 16v 147kw	AUTODETECT
 Clio III	DASHBOARD	1.2 16v 48kw	AUTODETECT
 Clio III	DASHBOARD	1.2 16v 48kw	SAGEM Kombi
 Clio III	DASHBOARD	1.2 16v 55kw	AUTODETECT
 Clio III	DASHBOARD	1.2 16v 55kw	SAGEM Kombi
 Clio III	DASHBOARD	1.2 16v 58kw	AUTODETECT
 Clio III	DASHBOARD	1.2 16v 58kw	SAGEM Kombi
 Clio III	DASHBOARD	1.2 16v 74kw	AUTODETECT
 Clio III	DASHBOARD	1.2 16v 74kw	SAGEM Kombi
 Clio III	DASHBOARD	1.2 16v GPL 55kw	AUTODETECT
 Clio III	DASHBOARD	1.2 16v GPL 55kw	SAGEM Kombi
 Clio III	DASHBOARD	1.4 16v 72kw	AUTODETECT
 Clio III	DASHBOARD	1.4 16v 72kw	SAGEM Kombi
 Clio III	DASHBOARD	1.5 dCi 48kw	AUTODETECT
 Clio III	DASHBOARD	1.5 dCi 48kw	SAGEM Kombi
 Clio III	DASHBOARD	1.5 dCi 50kw	AUTODETECT
 Clio III	DASHBOARD	1.5 dCi 50kw	SAGEM Kombi
 Clio III	DASHBOARD	1.5 dCi 63kw	AUTODETECT
 Clio III	DASHBOARD	1.5 dCi 63kw	SAGEM Kombi
 Clio III	DASHBOARD	1.5 dCi 76kw FAP	AUTODETECT
 Clio III	DASHBOARD	1.5 dCi 76kw FAP	SAGEM Kombi
 Clio III	DASHBOARD	1.5 dCi 78kw	AUTODETECT
 Clio III	DASHBOARD	1.5 dCi 78kw	SAGEM Kombi
 Clio III	DASHBOARD	1.6 16v 65kw	AUTODETECT
 Clio III	DASHBOARD	1.6 16v 65kw	SAGEM Kombi
 Clio III	DASHBOARD	1.6 16v 82kw	AUTODETECT
 Clio III	DASHBOARD	1.6 16v 82kw	SAGEM Kombi
 Clio III	DASHBOARD	1.6 16v 94kw	AUTODETECT
 Clio III	DASHBOARD	1.6 16v 94kw	SAGEM Kombi
 Clio III	DASHBOARD	2.0 16v 100kw	AUTODETECT
 Clio III	DASHBOARD	2.0 16v 100kw	SAGEM Kombi
 Clio III	DASHBOARD	2.0 16v 101kw	AUTODETECT
 Clio III	DASHBOARD	2.0 16v 101kw	SAGEM Kombi
 Clio III	DASHBOARD	2.0 16v 145kw	AUTODETECT
 Clio III	DASHBOARD	2.0 16v 145kw	SAGEM Kombi
 Clio III	DASHBOARD	2.0 16v 147kw	AUTODETECT
 Clio III	DASHBOARD	2.0 16v 147kw	SAGEM Kombi
 Clio III	ELECTRIC STEERING	1.2 16v 48kw	AUTODETECT
 Clio III	ELECTRIC STEERING	1.2 16v 48kw	KOYO EPS
 Clio III	ELECTRIC STEERING	1.2 16v 55kw	AUTODETECT
 Clio III	ELECTRIC STEERING	1.2 16v 55kw	KOYO EPS
 Clio III	ELECTRIC STEERING	1.2 16v 58kw	AUTODETECT
 Clio III	ELECTRIC STEERING	1.2 16v 58kw	KOYO EPS
 Clio III	ELECTRIC STEERING	1.2 16v 74kw	AUTODETECT
 Clio III	ELECTRIC STEERING	1.2 16v 74kw	KOYO EPS
 Clio III	ELECTRIC STEERING	1.2 16v GPL 55kw	AUTODETECT
 Clio III	ELECTRIC STEERING	1.2 16v GPL 55kw	KOYO EPS
 Clio III	ELECTRIC STEERING	1.4 16v 72kw	AUTODETECT
 Clio III	ELECTRIC STEERING	1.4 16v 72kw	KOYO EPS
 Clio III	ELECTRIC STEERING	1.5 dCi 48kw	AUTODETECT
 Clio III	ELECTRIC STEERING	1.5 dCi 48kw	KOYO EPS
 Clio III	ELECTRIC STEERING	1.5 dCi 50kw	AUTODETECT
 Clio III	ELECTRIC STEERING	1.5 dCi 50kw	KOYO EPS
 Clio III	ELECTRIC STEERING	1.5 dCi 63kw	AUTODETECT
 Clio III	ELECTRIC STEERING	1.5 dCi 63kw	KOYO EPS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Clio III	ELECTRIC STEERING	1.5 dCi 76kw FAP	AUTODETECT
 Clio III	ELECTRIC STEERING	1.5 dCi 76kw FAP	KOYO EPS
 Clio III	ELECTRIC STEERING	1.5 dCi 78kw	AUTODETECT
 Clio III	ELECTRIC STEERING	1.5 dCi 78kw	KOYO EPS
 Clio III	ELECTRIC STEERING	1.6 16v 65kw	AUTODETECT
 Clio III	ELECTRIC STEERING	1.6 16v 65kw	KOYO EPS
 Clio III	ELECTRIC STEERING	1.6 16v 82kw	AUTODETECT
 Clio III	ELECTRIC STEERING	1.6 16v 82kw	KOYO EPS
 Clio III	ELECTRIC STEERING	1.6 16v 94kw	AUTODETECT
 Clio III	ELECTRIC STEERING	1.6 16v 94kw	KOYO EPS
 Clio III	ELECTRIC STEERING	2.0 16v 100kw	AUTODETECT
 Clio III	ELECTRIC STEERING	2.0 16v 100kw	KOYO EPS
 Clio III	ELECTRIC STEERING	2.0 16v 101kw	AUTODETECT
 Clio III	ELECTRIC STEERING	2.0 16v 101kw	KOYO EPS
 Clio III	ELECTRIC STEERING	2.0 16v 145kw	AUTODETECT
 Clio III	ELECTRIC STEERING	2.0 16v 145kw	KOYO EPS
 Clio III	ELECTRIC STEERING	2.0 16v 147kw	AUTODETECT
 Clio III	ELECTRIC STEERING	2.0 16v 147kw	KOYO EPS
 Clio III	ENGINE MANAGEME	1.2 16v 48kw	AUTODETECT
 Clio III	ENGINE MANAGEME	1.2 16v 48kw D4F-740	SIEMENS SIM 32
 Clio III	ENGINE MANAGEME	1.2 16v 55kw	AUTODETECT
 Clio III	ENGINE MANAGEME	1.2 16v 55kw D4F-740	SIEMENS SIM 32
 Clio III	ENGINE MANAGEME	1.2 16v 58kw	AUTODETECT
 Clio III	ENGINE MANAGEME	1.2 16v 74kw	AUTODETECT
 Clio III	ENGINE MANAGEME	1.2 16v GPL 55kw D4F-7	EOBD
 Clio III	ENGINE MANAGEME	1.4 16v 72kw K4J-780	EOBD
 Clio III	ENGINE MANAGEME	1.5 dCi 48kw	AUTODETECT
 Clio III	ENGINE MANAGEME	1.5 dCi 48kw K9K-764	DELPHI EDC Common Rail
 Clio III	ENGINE MANAGEME	1.5 dCi 50kw	AUTODETECT
 Clio III	ENGINE MANAGEME	1.5 dCi 50kw K9K-764	DELPHI EDC Common Rail
 Clio III	ENGINE MANAGEME	1.5 dCi 63kw	AUTODETECT
 Clio III	ENGINE MANAGEME	1.5 dCi 63kw K9K-764	DELPHI EDC Common Rail
 Clio III	ENGINE MANAGEME	1.5 dCi 76kw FAP	AUTODETECT
 Clio III	ENGINE MANAGEME	1.5 dCi 76kw FAP K9K-764	DELPHI EDC Common Rail
 Clio III	ENGINE MANAGEME	1.5 dCi 78kw	AUTODETECT
 Clio III	ENGINE MANAGEME	1.5 dCi 78kw K9K-764	DELPHI EDC Common Rail
 Clio III	ENGINE MANAGEME	1.6 16v 65kw	AUTODETECT
 Clio III	ENGINE MANAGEME	1.6 16v 82kw	AUTODETECT
 Clio III	ENGINE MANAGEME	1.6 16v 94kw	AUTODETECT
 Clio III	ENGINE MANAGEME	2.0 16v 100kw M4R-7	EOBD
 Clio III	ENGINE MANAGEME	2.0 16v 100kw M4R-700	EOBD
 Clio III	ENGINE MANAGEME	2.0 16v 101kw M4R-7	EOBD
 Clio III	ENGINE MANAGEME	2.0 16v 101kw M4R-701	EOBD
 Clio III	ENGINE MANAGEME	2.0 16v 145kw F4R-830	EOBD
 Clio III	ENGINE MANAGEME	2.0 16v 147kw F4R-8	EOBD
 Clio III	ENGINE MANAGEME	2.0 16v 147kw F4R-813	EOBD
 Clio III	HEADLIGHT LEVEL	1.2 16v 48kw	CAN AUTODETECT
 Clio III	HEADLIGHT LEVEL	1.2 16v 55kw	CAN AUTODETECT
 Clio III	HEADLIGHT LEVEL	1.2 16v 58kw	CAN AUTODETECT
 Clio III	HEADLIGHT LEVEL	1.2 16v 74kw	CAN AUTODETECT
 Clio III	HEADLIGHT LEVEL	1.2 16v GPL 55kw	CAN AUTODETECT
 Clio III	HEADLIGHT LEVEL	1.4 16v 72kw	CAN AUTODETECT
 Clio III	HEADLIGHT LEVEL	1.5 dCi 48kw	CAN AUTODETECT
 Clio III	HEADLIGHT LEVEL	1.5 dCi 50kw	CAN AUTODETECT
 Clio III	HEADLIGHT LEVEL	1.5 dCi 63kw	CAN AUTODETECT
 Clio III	HEADLIGHT LEVEL	1.5 dCi 76kw FAP	CAN AUTODETECT
 Clio III	HEADLIGHT LEVEL	1.5 dCi 78kw	CAN AUTODETECT
 Clio III	HEADLIGHT LEVEL	1.6 16v 65kw	CAN AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Clio III	HEADLIGHT LEVEL	1.6 16v 82kw	CAN AUTODETECT
 Clio III	HEADLIGHT LEVEL	1.6 16v 94kw	CAN AUTODETECT
 Clio III	HEADLIGHT LEVEL	2.0 16v 100kw	CAN AUTODETECT
 Clio III	HEADLIGHT LEVEL	2.0 16v 101kw	CAN AUTODETECT
 Clio III	HEADLIGHT LEVEL	2.0 16v 145kw	CAN AUTODETECT
 Clio III	HEADLIGHT LEVEL	2.0 16v 147kw	CAN AUTODETECT
 Clio III	MAINTENANCE	1.2 16v 48kw	
 Clio III	MAINTENANCE	1.2 16v 48kw	KOYO EPS
 Clio III	MAINTENANCE	1.2 16v 48kw	KOYO EPS
 Clio III	MAINTENANCE	1.2 16v 55kw	
 Clio III	MAINTENANCE	1.2 16v 55kw	KOYO EPS
 Clio III	MAINTENANCE	1.2 16v 55kw	KOYO EPS
 Clio III	MAINTENANCE	1.2 16v 58kw	
 Clio III	MAINTENANCE	1.2 16v 58kw	KOYO EPS
 Clio III	MAINTENANCE	1.2 16v 58kw	KOYO EPS
 Clio III	MAINTENANCE	1.2 16v 74kw	
 Clio III	MAINTENANCE	1.2 16v 74kw	KOYO EPS
 Clio III	MAINTENANCE	1.2 16v 74kw	KOYO EPS
 Clio III	MAINTENANCE	1.2 16v GPL 55kw	
 Clio III	MAINTENANCE	1.2 16v GPL 55kw	KOYO EPS
 Clio III	MAINTENANCE	1.2 16v GPL 55kw	KOYO EPS
 Clio III	MAINTENANCE	1.4 16v 72kw	
 Clio III	MAINTENANCE	1.4 16v 72kw	KOYO EPS
 Clio III	MAINTENANCE	1.4 16v 72kw	KOYO EPS
 Clio III	MAINTENANCE	1.5 dCi 48kw	
 Clio III	MAINTENANCE	1.5 dCi 48kw	KOYO EPS
 Clio III	MAINTENANCE	1.5 dCi 48kw	KOYO EPS
 Clio III	MAINTENANCE	1.5 dCi 48kw K9K-764	DELPHI EDC Common Rail
 Clio III	MAINTENANCE	1.5 dCi 50kw	
 Clio III	MAINTENANCE	1.5 dCi 50kw	KOYO EPS
 Clio III	MAINTENANCE	1.5 dCi 50kw	KOYO EPS
 Clio III	MAINTENANCE	1.5 dCi 50kw K9K-764	DELPHI EDC Common Rail
 Clio III	MAINTENANCE	1.5 dCi 63kw	
 Clio III	MAINTENANCE	1.5 dCi 63kw	KOYO EPS
 Clio III	MAINTENANCE	1.5 dCi 63kw	KOYO EPS
 Clio III	MAINTENANCE	1.5 dCi 63kw K9K-764	DELPHI EDC Common Rail
 Clio III	MAINTENANCE	1.5 dCi 76kw FAP	
 Clio III	MAINTENANCE	1.5 dCi 76kw FAP	KOYO EPS
 Clio III	MAINTENANCE	1.5 dCi 76kw FAP	KOYO EPS
 Clio III	MAINTENANCE	1.5 dCi 76kw FAP K9K-764	DELPHI EDC Common Rail
 Clio III	MAINTENANCE	1.5 dCi 78kw	
 Clio III	MAINTENANCE	1.5 dCi 78kw	KOYO EPS
 Clio III	MAINTENANCE	1.5 dCi 78kw	KOYO EPS
 Clio III	MAINTENANCE	1.5 dCi 78kw K9K-764	DELPHI EDC Common Rail
 Clio III	MAINTENANCE	1.6 16v 65kw	
 Clio III	MAINTENANCE	1.6 16v 65kw	KOYO EPS
 Clio III	MAINTENANCE	1.6 16v 65kw	KOYO EPS
 Clio III	MAINTENANCE	1.6 16v 82kw	
 Clio III	MAINTENANCE	1.6 16v 82kw	KOYO EPS
 Clio III	MAINTENANCE	1.6 16v 82kw	KOYO EPS
 Clio III	MAINTENANCE	1.6 16v 94kw	
 Clio III	MAINTENANCE	1.6 16v 94kw	KOYO EPS
 Clio III	MAINTENANCE	1.6 16v 94kw	KOYO EPS
 Clio III	MAINTENANCE	2.0 16v 100kw	
 Clio III	MAINTENANCE	2.0 16v 100kw	KOYO EPS
 Clio III	MAINTENANCE	2.0 16v 100kw	KOYO EPS
 Clio III	MAINTENANCE	2.0 16v 101kw	
 Clio III	MAINTENANCE	2.0 16v 101kw	KOYO EPS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Clio III	MAINTENANCE	2.0 16v 101kw	KOYO EPS
 Clio III	MAINTENANCE	2.0 16v 145kw	
 Clio III	MAINTENANCE	2.0 16v 145kw	KOYO EPS
 Clio III	MAINTENANCE	2.0 16v 145kw	KOYO EPS
 Clio III	MAINTENANCE	2.0 16v 147kw	
 Clio III	MAINTENANCE	2.0 16v 147kw	KOYO EPS
 Clio III	MAINTENANCE	2.0 16v 147kw	KOYO EPS
 Clio III	PARKING HELP	1.2 16v 48kw	AUTODETECT
 Clio III	PARKING HELP	1.2 16v 55kw	AUTODETECT
 Clio III	PARKING HELP	1.2 16v 58kw	AUTODETECT
 Clio III	PARKING HELP	1.2 16v 74kw	AUTODETECT
 Clio III	PARKING HELP	1.2 16v GPL 55kw	AUTODETECT
 Clio III	PARKING HELP	1.4 16v 72kw	AUTODETECT
 Clio III	PARKING HELP	1.5 dCi 48kw	AUTODETECT
 Clio III	PARKING HELP	1.5 dCi 50kw	AUTODETECT
 Clio III	PARKING HELP	1.5 dCi 63kw	AUTODETECT
 Clio III	PARKING HELP	1.5 dCi 76kw FAP	AUTODETECT
 Clio III	PARKING HELP	1.5 dCi 78kw	AUTODETECT
 Clio III	PARKING HELP	1.6 16v 65kw	AUTODETECT
 Clio III	PARKING HELP	1.6 16v 82kw	AUTODETECT
 Clio III	PARKING HELP	1.6 16v 94kw	AUTODETECT
 Clio III	PARKING HELP	2.0 16v 100kw	AUTODETECT
 Clio III	PARKING HELP	2.0 16v 101kw	AUTODETECT
 Clio III	PARKING HELP	2.0 16v 145kw	AUTODETECT
 Clio III	PARKING HELP	2.0 16v 147kw	AUTODETECT
 Clio III	SERVICE LIGHT RES	1.2 16v 48kw	
 Clio III	SERVICE LIGHT RES	1.2 16v 55kw	
 Clio III	SERVICE LIGHT RES	1.2 16v 58kw	
 Clio III	SERVICE LIGHT RES	1.2 16v 74kw	
 Clio III	SERVICE LIGHT RES	1.2 16v GPL 55kw	
 Clio III	SERVICE LIGHT RES	1.4 16v 72kw	
 Clio III	SERVICE LIGHT RES	1.5 dCi 48kw	
 Clio III	SERVICE LIGHT RES	1.5 dCi 50kw	
 Clio III	SERVICE LIGHT RES	1.5 dCi 63kw	
 Clio III	SERVICE LIGHT RES	1.5 dCi 76kw FAP	
 Clio III	SERVICE LIGHT RES	1.5 dCi 78kw	
 Clio III	SERVICE LIGHT RES	1.6 16v 65kw	
 Clio III	SERVICE LIGHT RES	1.6 16v 82kw	
 Clio III	SERVICE LIGHT RES	1.6 16v 94kw	
 Clio III	SERVICE LIGHT RES	2.0 16v 100kw	
 Clio III	SERVICE LIGHT RES	2.0 16v 101kw	
 Clio III	SERVICE LIGHT RES	2.0 16v 145kw	
 Clio III	SERVICE LIGHT RES	2.0 16v 147kw	
 Clio III	TIRE PRESSURE	1.2 16v 48kw	AUTODETECT
 Clio III	TIRE PRESSURE	1.2 16v 55kw	AUTODETECT
 Clio III	TIRE PRESSURE	1.2 16v 58kw	AUTODETECT
 Clio III	TIRE PRESSURE	1.2 16v 74kw	AUTODETECT
 Clio III	TIRE PRESSURE	1.2 16v GPL 55kw	AUTODETECT
 Clio III	TIRE PRESSURE	1.4 16v 72kw	AUTODETECT
 Clio III	TIRE PRESSURE	1.5 dCi 48kw	AUTODETECT
 Clio III	TIRE PRESSURE	1.5 dCi 50kw	AUTODETECT
 Clio III	TIRE PRESSURE	1.5 dCi 63kw	AUTODETECT
 Clio III	TIRE PRESSURE	1.5 dCi 76kw FAP	AUTODETECT
 Clio III	TIRE PRESSURE	1.5 dCi 78kw	AUTODETECT
 Clio III	TIRE PRESSURE	1.6 16v 65kw	AUTODETECT
 Clio III	TIRE PRESSURE	1.6 16v 82kw	AUTODETECT
 Clio III	TIRE PRESSURE	1.6 16v 94kw	AUTODETECT
 Clio III	TIRE PRESSURE	2.0 16v 100kw	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Clio III	TIRE PRESSURE	2.0 16v 101kw	AUTODETECT
 Clio III	TIRE PRESSURE	2.0 16v 145kw	AUTODETECT
 Clio III	TIRE PRESSURE	2.0 16v 147kw	AUTODETECT
 Clio	ABS	1.1 36kw	BOSCH ABS 5.3
 Clio	ABS	1.2 40kw	BOSCH ABS 5.3
 Clio	ABS	1.2 43kw	BOSCH ABS 5.3
 Clio	ABS	1.2 44kw	BOSCH ABS 5.3
 Clio	ABS	1.4 55kw	BOSCH ABS 5.3
 Clio	ABS	1.4 57kw	BOSCH ABS 5.3
 Clio	ABS	1.7 66kw	BOSCH ABS 5.3
 Clio	ABS	1.8 101kw	BOSCH ABS 5.3
 Clio	ABS	1.8 16v 101kw	BOSCH ABS 5.3
 Clio	ABS	1.8 66kw	BOSCH ABS 5.3
 Clio	ABS	1.8 68kw	BOSCH ABS 5.3
 Clio	ABS	1.8 70kw	BOSCH ABS 5.3
 Clio	ABS	1.8 79kw	BOSCH ABS 5.3
 Clio	ABS	1.9 D 40kw	BOSCH ABS 5.3
 Clio	ABS	1.9 D 47kw	BOSCH ABS 5.3
 Clio	ABS	2.0 16v WILLIAMS 108kw	BOSCH ABS 5.3
 Clio	AIRBAG	1.1 36kw	SIEMENS - Autoliv AirBag EC5
 Clio	AIRBAG	1.2 40kw	SIEMENS - Autoliv AirBag EC5
 Clio	AIRBAG	1.2 43kw	SIEMENS - Autoliv AirBag EC5
 Clio	AIRBAG	1.2 44kw	SIEMENS - Autoliv AirBag EC5
 Clio	AIRBAG	1.4 55kw	SIEMENS - Autoliv AirBag EC5
 Clio	AIRBAG	1.4 57kw	SIEMENS - Autoliv AirBag EC5
 Clio	AIRBAG	1.7 66kw	SIEMENS - Autoliv AirBag EC5
 Clio	AIRBAG	1.8 101kw	SIEMENS - Autoliv AirBag EC5
 Clio	AIRBAG	1.8 16v 101kw	SIEMENS - Autoliv AirBag EC5
 Clio	AIRBAG	1.8 66kw	SIEMENS - Autoliv AirBag EC5
 Clio	AIRBAG	1.8 68kw	SIEMENS - Autoliv AirBag EC5
 Clio	AIRBAG	1.8 70kw	SIEMENS - Autoliv AirBag EC5
 Clio	AIRBAG	1.8 79kw	SIEMENS - Autoliv AirBag EC5
 Clio	AIRBAG	1.9 D 40kw	SIEMENS - Autoliv AirBag EC5
 Clio	AIRBAG	1.9 D 47kw	SIEMENS - Autoliv AirBag EC5
 Clio	AIRBAG	2.0 16v WILLIAMS 108kw	SIEMENS - Autoliv AirBag EC5
 Clio	DIESEL MANAGEMEN	1.9 D 40kw F8Q-672/92 (...99)	LUCAS Diesel DPCN1
 Clio	DIESEL MANAGEMEN	1.9 D 40kw F8Q-674/78 (...99)	LUCAS Diesel DPCN1
 Clio	DIESEL MANAGEMEN	1.9 D 47kw F8Q-676/96 (...99)	LUCAS Diesel DPCN1
 Clio	DIESEL MANAGEMEN	1.9 D 47kw F8Q-714 (...99)	LUCAS Diesel DPCN1
 Clio	DIESEL MANAGEMEN	1.9 D 47kw F8Q-714/30 (...99)	LUCAS Diesel DPCN1
 Clio	DIESEL MANAGEMEN	1.9 D 47kw F8Q-732 (...99)	LUCAS Diesel DPCN1
 Clio	ENGINE MANAGEME	1.2 40kw C3G-720	Marelli IAW 6R
 Clio	ENGINE MANAGEME	1.2 40kw C3G-720	Marelli IAW 6R
 Clio	ENGINE MANAGEME	1.2 40kw C3G-720	Marelli IAW 6R
 Clio	ENGINE MANAGEME	1.2 40kw C3G-720	Marelli IAW 6R
 Clio	ENGINE MANAGEME	1.2 40kw C3G-720	Marelli IAW 6R
 Clio	ENGINE MANAGEME	1.2 40kw C3G-720	SIEMENS BOSCH SPI
 Clio	ENGINE MANAGEME	1.2 40kw C3G-720	SIEMENS BOSCH SPI
 Clio	ENGINE MANAGEME	1.2 40kw C3G-720	SIEMENS BOSCH SPI
 Clio	ENGINE MANAGEME	1.2 40kw C3G-720	SIEMENS BOSCH SPI
 Clio	ENGINE MANAGEME	1.2 40kw C3G-720	SIEMENS BOSCH SPI
 Clio	ENGINE MANAGEME	1.2 40kw C3G-720	SIEMENS BOSCH SPI
 Clio	ENGINE MANAGEME	1.2 40kw C3G-720	SIEMENS BOSCH SPI
 Clio	ENGINE MANAGEME	1.2 40kw C3G-720	SIEMENS BOSCH SPI
 Clio	ENGINE MANAGEME	1.2 43kw D7F-730	SAGEM SAFIR MPI
 Clio	ENGINE MANAGEME	1.2 43kw D7F-730	SAGEM SAFIR MPI
 Clio	ENGINE MANAGEME	1.2 43kw D7F-730	SAGEM SAFIR MPI
 Clio	ENGINE MANAGEME	1.2 43kw D7F-730	SAGEM SAFIR MPI
 Clio	ENGINE MANAGEME	1.2 43kw D7F-730	SAGEM SAFIR MPI

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

[illegible]

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

[illegible]

Renault

[illegible]

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Espace III	ABS	2.0 83kw	BOSCH ABS 5.3 T
 Espace III	ABS	2.0 GPL 79kw	BOSCH ABS 5.0
 Espace III	ABS	2.0 GPL 79kw	BOSCH ABS 5.3
 Espace III	ABS	2.0 GPL 79kw	BOSCH ABS 5.3 T
 Espace III	ABS	2.2 16v dCi 84kw	BOSCH ABS 5.0
 Espace III	ABS	2.2 16v dCi 84kw	BOSCH ABS 5.3
 Espace III	ABS	2.2 16v dCi 84kw	BOSCH ABS 5.3 T
 Espace III	ABS	2.2 16v dCi 84kw	TEVES ABS Mk60
 Espace III	ABS	2.2 16v dCi 95kw	BOSCH ABS 5.0
 Espace III	ABS	2.2 16v dCi 95kw	BOSCH ABS 5.3
 Espace III	ABS	2.2 16v dCi 95kw	BOSCH ABS 5.3 T
 Espace III	ABS	2.2 16v dCi 95kw	TEVES ABS Mk60
 Espace III	ABS	2.2 TD 81kw	BOSCH ABS 5.0
 Espace III	ABS	2.2 TD 81kw	BOSCH ABS 5.3
 Espace III	ABS	2.2 TD 81kw	BOSCH ABS 5.3 T
 Espace III	ABS	2.2 TD 83kw	BOSCH ABS 5.0
 Espace III	ABS	2.2 TD 83kw	BOSCH ABS 5.3
 Espace III	ABS	2.2 TD 83kw	BOSCH ABS 5.3 T
 Espace III	ABS	3.0 V6 125kw	BOSCH ABS 5.0
 Espace III	ABS	3.0 V6 125kw	BOSCH ABS 5.3
 Espace III	ABS	3.0 V6 125kw	BOSCH ABS 5.3 T
 Espace III	ABS	3.0 V6 24v 143kw	BOSCH ABS 5.0
 Espace III	ABS	3.0 V6 24v 143kw	BOSCH ABS 5.3
 Espace III	ABS	3.0 V6 24v 143kw	BOSCH ABS 5.3 T
 Espace III	AIRBAG	1.9 dTi 74kw	SIEMENS - Autoliv AirBag EC5
 Espace III	AIRBAG	2.0 16v 103kw	SIEMENS - Autoliv AirBag EC5
 Espace III	AIRBAG	2.0 83kw	SIEMENS - Autoliv AirBag EC5
 Espace III	AIRBAG	2.0 GPL 79kw	SIEMENS - Autoliv AirBag EC5
 Espace III	AIRBAG	2.2 16v dCi 84kw	SAGEM - Autoliv AirBag ACU 3
 Espace III	AIRBAG	2.2 16v dCi 84kw	SIEMENS - Autoliv AirBag EC5
 Espace III	AIRBAG	2.2 16v dCi 95kw	SAGEM - Autoliv AirBag ACU 3
 Espace III	AIRBAG	2.2 16v dCi 95kw	SIEMENS - Autoliv AirBag EC5
 Espace III	AIRBAG	2.2 TD 81kw	SIEMENS - Autoliv AirBag EC5
 Espace III	AIRBAG	2.2 TD 83kw	SIEMENS - Autoliv AirBag EC5
 Espace III	AIRBAG	3.0 V6 125kw	SIEMENS - Autoliv AirBag EC5
 Espace III	AIRBAG	3.0 V6 24v 143kw	SIEMENS - Autoliv AirBag EC5
 Espace III	DIESEL MANAGEMEN	1.9 dTi 74kw F9Q-722 (...01)	BOSCH MSA 15
 Espace III	DIESEL MANAGEMEN	2.2 TD 81kw G8T-716	SAGEM EGR Diesel
 Espace III	DIESEL MANAGEMEN	2.2 TD 81kw G8T-716	SAGEM EGR Diesel
 Espace III	DIESEL MANAGEMEN	2.2 TD 81kw G8T-716	SAGEM EGR Diesel
 Espace III	DIESEL MANAGEMEN	2.2 TD 81kw G8T-716	SAGEM EGR Diesel
 Espace III	DIESEL MANAGEMEN	2.2 TD 81kw G8T-716	SAGEM EGR Diesel
 Espace III	DIESEL MANAGEMEN	2.2 TD 81kw G8T-716	SAGEM EGR Diesel
 Espace III	DIESEL MANAGEMEN	2.2 TD 83kw G8T-714	SAGEM EGR Diesel
 Espace III	DIESEL MANAGEMEN	2.2 TD 83kw G8T-714	SAGEM EGR Diesel
 Espace III	DIESEL MANAGEMEN	2.2 TD 83kw G8T-714	SAGEM EGR Diesel
 Espace III	DIESEL MANAGEMEN	2.2 TD 83kw G8T-714	SAGEM EGR Diesel
 Espace III	DIESEL MANAGEMEN	2.2 TD 83kw G8T-716	SAGEM EGR Diesel
 Espace III	DIESEL MANAGEMEN	2.2 TD 83kw G8T-716	SAGEM EGR Diesel
 Espace III	DIESEL MANAGEMEN	2.2 TD 83kw G8T-716	SAGEM EGR Diesel
 Espace III	DIESEL MANAGEMEN	2.2 TD 83kw G8T-716	SAGEM EGR Diesel
 Espace III	DIESEL MANAGEMEN	2.2 TD 83kw G8T-716	SAGEM EGR Diesel
 Espace III	DIESEL MANAGEMEN	2.2 TD 83kw G8T-716	SAGEM EGR Diesel
 Espace III	ENGINE MANAGEME	2.0 83kw F3R-728	SIEMENS FENIX 5
 Espace III	ENGINE MANAGEME	2.0 83kw F3R-728	SIEMENS FENIX 5
 Espace III	ENGINE MANAGEME	2.0 83kw F3R-729	SIEMENS FENIX 5

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Espace III	ENGINE MANAGEME	2.0 83kw F3R-729	SIEMENS FENIX 5
 Espace III	ENGINE MANAGEME	2.2 16v dCi 84kw G9T-710	BOSCH EDC 15 C3 Common Rail
 Espace III	ENGINE MANAGEME	2.2 16v dCi 95kw G9T-710	BOSCH EDC 15 C3 Common Rail
 Espace III	ENGINE MANAGEME	3.0 V6 125kw Z7X-775	SIEMENS MPI
 Espace III	IMMOBILIZER	2.2 16v dCi 84kw	Immobilizer Body Computer
 Espace III	IMMOBILIZER	2.2 16v dCi 95kw	Immobilizer Body Computer
 Espace III	MAINTENANCE	1.9 dTi 74kw (02-..)	MANUAL
 Espace III	MAINTENANCE	2.0 16v 103kw (02-..)	MANUAL
 Espace III	MAINTENANCE	2.0 83kw (02-..)	MANUAL
 Espace III	MAINTENANCE	2.0 GPL 79kw (02-..)	MANUAL
 Espace III	MAINTENANCE	2.2 16v dCi 84kw (02-..)	MANUAL
 Espace III	MAINTENANCE	2.2 16v dCi 95kw (02-..)	MANUAL
 Espace III	MAINTENANCE	2.2 TD 81kw (02-..)	MANUAL
 Espace III	MAINTENANCE	2.2 TD 83kw (02-..)	MANUAL
 Espace III	MAINTENANCE	3.0 V6 125kw (02-..)	MANUAL
 Espace III	MAINTENANCE	3.0 V6 24v 143kw (02-..)	MANUAL
 Espace III	SERVICE LIGHT RES	1.9 dTi 74kw (02-..)	MANUAL
 Espace III	SERVICE LIGHT RES	2.0 16v 103kw (02-..)	MANUAL
 Espace III	SERVICE LIGHT RES	2.0 83kw (02-..)	MANUAL
 Espace III	SERVICE LIGHT RES	2.0 GPL 79kw (02-..)	MANUAL
 Espace III	SERVICE LIGHT RES	2.2 16v dCi 84kw (02-..)	MANUAL
 Espace III	SERVICE LIGHT RES	2.2 16v dCi 95kw (02-..)	MANUAL
 Espace III	SERVICE LIGHT RES	2.2 TD 81kw (02-..)	MANUAL
 Espace III	SERVICE LIGHT RES	2.2 TD 83kw (02-..)	MANUAL
 Espace III	SERVICE LIGHT RES	3.0 V6 125kw (02-..)	MANUAL
 Espace III	SERVICE LIGHT RES	3.0 V6 24v 143kw (02-..)	MANUAL
 Espace IV ph2	ABS	1.9 dCi 85kw (06-..)	AUTODETECT
 Espace IV ph2	ABS	1.9 dCi 88kw (06-..)	AUTODETECT
 Espace IV ph2	ABS	2.0 16v 125kw (06-..)	AUTODETECT
 Espace IV ph2	ABS	2.0 16v dCi 110kw (06-..)	AUTODETECT
 Espace IV ph2	ABS	2.0 16v dCi 127kw (06-..)	AUTODETECT
 Espace IV ph2	ABS	2.0 16v dCi 96kw (06-..)	AUTODETECT
 Espace IV ph2	ABS	2.0 16v dCi FAP 110kw (06-..)	AUTODETECT
 Espace IV ph2	ABS	2.0 16v dCi FAP 127kw (06-..)	AUTODETECT
 Espace IV ph2	ABS	2.2 16v dCi 110kw (06-..)	AUTODETECT
 Espace IV ph2	ABS	2.2 16v dCi FAP 102kw (06-..)	AUTODETECT
 Espace IV ph2	ABS	3.0 V6 24v dCi 120kw (06-..)	AUTODETECT
 Espace IV ph2	ABS	3.5 V6 24v 177kw (06-..)	AUTODETECT
 Espace IV ph2	AIRBAG	1.9 dCi 85kw (06-..)	AUTODETECT
 Espace IV ph2	AIRBAG	1.9 dCi 88kw (06-..)	AUTODETECT
 Espace IV ph2	AIRBAG	2.0 16v 125kw (06-..)	AUTODETECT
 Espace IV ph2	AIRBAG	2.0 16v dCi 110kw (06-..)	AUTODETECT
 Espace IV ph2	AIRBAG	2.0 16v dCi 127kw (06-..)	AUTODETECT
 Espace IV ph2	AIRBAG	2.0 16v dCi 96kw (06-..)	AUTODETECT
 Espace IV ph2	AIRBAG	2.0 16v dCi FAP 110kw (06-..)	AUTODETECT
 Espace IV ph2	AIRBAG	2.0 16v dCi FAP 127kw (06-..)	AUTODETECT
 Espace IV ph2	AIRBAG	2.2 16v dCi 110kw (06-..)	AUTODETECT
 Espace IV ph2	AIRBAG	2.2 16v dCi FAP 102kw (06-..)	AUTODETECT
 Espace IV ph2	AIRBAG	3.0 V6 24v dCi 120kw (06-..)	AUTODETECT
 Espace IV ph2	AIRBAG	3.5 V6 24v 177kw (06-..)	AUTODETECT
 Espace IV ph2	AUTOM. TRANSMISSI	1.9 dCi 85kw (06-..)	AUTODETECT
 Espace IV ph2	AUTOM. TRANSMISSI	1.9 dCi 88kw (06-..)	AUTODETECT
 Espace IV ph2	AUTOM. TRANSMISSI	2.0 16v 125kw (06-..)	AUTODETECT
 Espace IV ph2	AUTOM. TRANSMISSI	2.0 16v dCi 110kw (06-..)	AUTODETECT
 Espace IV ph2	AUTOM. TRANSMISSI	2.0 16v dCi 127kw (06-..)	AUTODETECT
 Espace IV ph2	AUTOM. TRANSMISSI	2.0 16v dCi 96kw (06-..)	AUTODETECT
 Espace IV ph2	AUTOM. TRANSMISSI	2.0 16v dCi FAP 110kw (06-..)	AUTODETECT
 Espace IV ph2	AUTOM. TRANSMISSI	2.0 16v dCi FAP 127kw (06-..)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Espace IV ph2	AUTOM. TRANSMISSI	2.2 16v dCi 110kw (06-..)	AUTODETECT
 Espace IV ph2	AUTOM. TRANSMISSI	2.2 16v dCi FAP 102kw (06-..)	AUTODETECT
 Espace IV ph2	AUTOM. TRANSMISSI	3.0 V6 24v dCi 120kw (06-..)	AUTODETECT
 Espace IV ph2	AUTOM. TRANSMISSI	3.5 V6 24v 177kw (06-..)	AUTODETECT
 Espace IV ph2	CHASSIS NETWORK	1.9 dCi 85kw (06-..)	UCC AUTODETECT
 Espace IV ph2	CHASSIS NETWORK	1.9 dCi 85kw (06-..)	UCH AUTODETECT
 Espace IV ph2	CHASSIS NETWORK	1.9 dCi 88kw (06-..)	UCC AUTODETECT
 Espace IV ph2	CHASSIS NETWORK	1.9 dCi 88kw (06-..)	UCH AUTODETECT
 Espace IV ph2	CHASSIS NETWORK	2.0 16v 125kw (06-..)	UCC AUTODETECT
 Espace IV ph2	CHASSIS NETWORK	2.0 16v 125kw (06-..)	UCH AUTODETECT
 Espace IV ph2	CHASSIS NETWORK	2.0 16v dCi 110kw (06-..)	UCC AUTODETECT
 Espace IV ph2	CHASSIS NETWORK	2.0 16v dCi 110kw (06-..)	UCH AUTODETECT
 Espace IV ph2	CHASSIS NETWORK	2.0 16v dCi 127kw (06-..)	UCC AUTODETECT
 Espace IV ph2	CHASSIS NETWORK	2.0 16v dCi 127kw (06-..)	UCH AUTODETECT
 Espace IV ph2	CHASSIS NETWORK	2.0 16v dCi 96kw (06-..)	UCC AUTODETECT
 Espace IV ph2	CHASSIS NETWORK	2.0 16v dCi 96kw (06-..)	UCH AUTODETECT
 Espace IV ph2	CHASSIS NETWORK	2.0 16v dCi FAP 110kw (06-..)	UCC AUTODETECT
 Espace IV ph2	CHASSIS NETWORK	2.0 16v dCi FAP 110kw (06-..)	UCH AUTODETECT
 Espace IV ph2	CHASSIS NETWORK	2.0 16v dCi FAP 127kw (06-..)	UCC AUTODETECT
 Espace IV ph2	CHASSIS NETWORK	2.0 16v dCi FAP 127kw (06-..)	UCH AUTODETECT
 Espace IV ph2	CHASSIS NETWORK	2.2 16v dCi 110kw (06-..)	UCC AUTODETECT
 Espace IV ph2	CHASSIS NETWORK	2.2 16v dCi 110kw (06-..)	UCH AUTODETECT
 Espace IV ph2	CHASSIS NETWORK	2.2 16v dCi FAP 102kw (06-..)	UCC AUTODETECT
 Espace IV ph2	CHASSIS NETWORK	2.2 16v dCi FAP 102kw (06-..)	UCH AUTODETECT
 Espace IV ph2	CHASSIS NETWORK	3.0 V6 24v dCi 120kw (06-..)	UCC AUTODETECT
 Espace IV ph2	CHASSIS NETWORK	3.0 V6 24v dCi 120kw (06-..)	UCH AUTODETECT
 Espace IV ph2	CHASSIS NETWORK	3.5 V6 24v 177kw (06-..)	UCC AUTODETECT
 Espace IV ph2	CHASSIS NETWORK	3.5 V6 24v 177kw (06-..)	UCH AUTODETECT
 Espace IV ph2	CLIMA	1.9 dCi 85kw (06-..)	AUTODETECT
 Espace IV ph2	CLIMA	1.9 dCi 88kw (06-..)	AUTODETECT
 Espace IV ph2	CLIMA	2.0 16v 125kw (06-..)	AUTODETECT
 Espace IV ph2	CLIMA	2.0 16v dCi 110kw (06-..)	AUTODETECT
 Espace IV ph2	CLIMA	2.0 16v dCi 127kw (06-..)	AUTODETECT
 Espace IV ph2	CLIMA	2.0 16v dCi 96kw (06-..)	AUTODETECT
 Espace IV ph2	CLIMA	2.0 16v dCi FAP 110kw (06-..)	AUTODETECT
 Espace IV ph2	CLIMA	2.0 16v dCi FAP 127kw (06-..)	AUTODETECT
 Espace IV ph2	CLIMA	2.2 16v dCi 110kw (06-..)	AUTODETECT
 Espace IV ph2	CLIMA	2.2 16v dCi FAP 102kw (06-..)	AUTODETECT
 Espace IV ph2	CLIMA	3.0 V6 24v dCi 120kw (06-..)	AUTODETECT
 Espace IV ph2	CLIMA	3.5 V6 24v 177kw (06-..)	AUTODETECT
 Espace IV ph2	DASHBOARD	1.9 dCi 85kw (06-..)	AUTODETECT
 Espace IV ph2	DASHBOARD	1.9 dCi 88kw (06-..)	AUTODETECT
 Espace IV ph2	DASHBOARD	2.0 16v 125kw (06-..)	AUTODETECT
 Espace IV ph2	DASHBOARD	2.0 16v dCi 110kw (06-..)	AUTODETECT
 Espace IV ph2	DASHBOARD	2.0 16v dCi 127kw (06-..)	AUTODETECT
 Espace IV ph2	DASHBOARD	2.0 16v dCi 96kw (06-..)	AUTODETECT
 Espace IV ph2	DASHBOARD	2.0 16v dCi FAP 110kw (06-..)	AUTODETECT
 Espace IV ph2	DASHBOARD	2.0 16v dCi FAP 127kw (06-..)	AUTODETECT
 Espace IV ph2	DASHBOARD	2.2 16v dCi 110kw (06-..)	AUTODETECT
 Espace IV ph2	DASHBOARD	2.2 16v dCi FAP 102kw (06-..)	AUTODETECT
 Espace IV ph2	DASHBOARD	3.0 V6 24v dCi 120kw (06-..)	AUTODETECT
 Espace IV ph2	DASHBOARD	3.5 V6 24v 177kw (06-..)	AUTODETECT
 Espace IV ph2	ENGINE MANAGEME	1.9 dCi 85kw (06-..)	AUTODETECT
 Espace IV ph2	ENGINE MANAGEME	1.9 dCi 88kw (06-..)	AUTODETECT
 Espace IV ph2	ENGINE MANAGEME	2.0 16v 103kw (06-..)	AUTODETECT
 Espace IV ph2	ENGINE MANAGEME	2.0 16v 125kw (06-..)	AUTODETECT
 Espace IV ph2	ENGINE MANAGEME	2.0 16v dCi 110kw (06-..)	AUTODETECT
 Espace IV ph2	ENGINE MANAGEME	2.0 16v dCi 127kw (06-..)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Espace IV ph2	ENGINE MANAGEME	2.0 16v dCi 96kw (06-..)	AUTODETECT
 Espace IV ph2	ENGINE MANAGEME	2.0 16v dCi FAP 110kw (06-..)	AUTODETECT
 Espace IV ph2	ENGINE MANAGEME	2.0 16v dCi FAP 127kw (06-..)	AUTODETECT
 Espace IV ph2	ENGINE MANAGEME	2.2 16v dCi 110kw (06-..)	AUTODETECT
 Espace IV ph2	ENGINE MANAGEME	2.2 16v dCi FAP 102kw (06-..)	AUTODETECT
 Espace IV ph2	ENGINE MANAGEME	3.0 V6 24v dCi 120kw (06-..)	AUTODETECT
 Espace IV ph2	ENGINE MANAGEME	3.0 V6 24v dCi 133kw (06-..)	AUTODETECT
 Espace IV ph2	ENGINE MANAGEME	3.5 V6 24v 177kw (06-..)	SAGEM S3000 AUTODETECT
 Espace IV ph2	HEADLIGHT LEVEL	1.9 dCi 85kw (06-..)	can AUTODETECT
 Espace IV ph2	HEADLIGHT LEVEL	1.9 dCi 88kw (06-..)	can AUTODETECT
 Espace IV ph2	HEADLIGHT LEVEL	2.0 16v 125kw (06-..)	can AUTODETECT
 Espace IV ph2	HEADLIGHT LEVEL	2.0 16v dCi 110kw (06-..)	can AUTODETECT
 Espace IV ph2	HEADLIGHT LEVEL	2.0 16v dCi 127kw (06-..)	can AUTODETECT
 Espace IV ph2	HEADLIGHT LEVEL	2.0 16v dCi 96kw (06-..)	can AUTODETECT
 Espace IV ph2	HEADLIGHT LEVEL	2.0 16v dCi FAP 110kw (06-..)	can AUTODETECT
 Espace IV ph2	HEADLIGHT LEVEL	2.0 16v dCi FAP 127kw (06-..)	can AUTODETECT
 Espace IV ph2	HEADLIGHT LEVEL	2.2 16v dCi 110kw (06-..)	can AUTODETECT
 Espace IV ph2	HEADLIGHT LEVEL	2.2 16v dCi FAP 102kw (06-..)	can AUTODETECT
 Espace IV ph2	HEADLIGHT LEVEL	3.0 V6 24v dCi 120kw (06-..)	can AUTODETECT
 Espace IV ph2	HEADLIGHT LEVEL	3.5 V6 24v 177kw (06-..)	can AUTODETECT
 Espace IV ph2	PARK.BRAKE	1.9 dCi 85kw (06-..)	Electrobrake AUTODETECT
 Espace IV ph2	PARK.BRAKE	1.9 dCi 88kw (06-..)	Electrobrake AUTODETECT
 Espace IV ph2	PARK.BRAKE	2.0 16v 125kw (06-..)	Electrobrake AUTODETECT
 Espace IV ph2	PARK.BRAKE	2.0 16v dCi 110kw (06-..)	Electrobrake AUTODETECT
 Espace IV ph2	PARK.BRAKE	2.0 16v dCi 96kw (06-..)	Electrobrake AUTODETECT
 Espace IV ph2	PARK.BRAKE	2.0 16v dCi FAP 110kw (06-..)	Electrobrake AUTODETECT
 Espace IV ph2	PARK.BRAKE	2.0 16v dCi FAP 127kw (06-..)	Electrobrake AUTODETECT
 Espace IV ph2	PARK.BRAKE	2.2 16v dCi 110kw (06-..)	Electrobrake AUTODETECT
 Espace IV ph2	PARK.BRAKE	2.2 16v dCi FAP 102kw (06-..)	Electrobrake AUTODETECT
 Espace IV ph2	PARK.BRAKE	3.0 V6 24v dCi 120kw (06-..)	Electrobrake AUTODETECT
 Espace IV ph2	PARK.BRAKE	3.5 V6 24v 177kw (06-..)	Electrobrake AUTODETECT
 Espace IV ph2	PARKING HELP	1.9 dCi 85kw (06-..)	AUTODETECT
 Espace IV ph2	PARKING HELP	1.9 dCi 85kw (06-..)	can AUTODETECT
 Espace IV ph2	PARKING HELP	1.9 dCi 88kw (06-..)	AUTODETECT
 Espace IV ph2	PARKING HELP	1.9 dCi 88kw (06-..)	can AUTODETECT
 Espace IV ph2	PARKING HELP	2.0 16v 125kw (06-..)	AUTODETECT
 Espace IV ph2	PARKING HELP	2.0 16v 125kw (06-..)	can AUTODETECT
 Espace IV ph2	PARKING HELP	2.0 16v dCi 110kw (06-..)	AUTODETECT
 Espace IV ph2	PARKING HELP	2.0 16v dCi 110kw (06-..)	can AUTODETECT
 Espace IV ph2	PARKING HELP	2.0 16v dCi 127kw (06-..)	AUTODETECT
 Espace IV ph2	PARKING HELP	2.0 16v dCi 127kw (06-..)	can AUTODETECT
 Espace IV ph2	PARKING HELP	2.0 16v dCi 96kw (06-..)	AUTODETECT
 Espace IV ph2	PARKING HELP	2.0 16v dCi 96kw (06-..)	can AUTODETECT
 Espace IV ph2	PARKING HELP	2.0 16v dCi FAP 110kw (06-..)	AUTODETECT
 Espace IV ph2	PARKING HELP	2.0 16v dCi FAP 110kw (06-..)	can AUTODETECT
 Espace IV ph2	PARKING HELP	2.0 16v dCi FAP 127kw (06-..)	AUTODETECT
 Espace IV ph2	PARKING HELP	2.0 16v dCi FAP 127kw (06-..)	can AUTODETECT
 Espace IV ph2	PARKING HELP	2.2 16v dCi 110kw (06-..)	can AUTODETECT
 Espace IV ph2	PARKING HELP	2.2 16v dCi FAP 102kw (06-..)	AUTODETECT
 Espace IV ph2	PARKING HELP	2.2 16v dCi FAP 102kw (06-..)	can AUTODETECT
 Espace IV ph2	PARKING HELP	3.0 V6 24v dCi 120kw (06-..)	can AUTODETECT
 Espace IV ph2	PARKING HELP	3.5 V6 24v 177kw (06-..)	AUTODETECT
 Espace IV ph2	PARKING HELP	3.5 V6 24v 177kw (06-..)	can AUTODETECT
 Espace IV ph2	SUPP HEATER/AUTO	1.9 dCi 85kw (06-..)	AUTODETECT
 Espace IV ph2	SUPP HEATER/AUTO	1.9 dCi 88kw (06-..)	AUTODETECT
 Espace IV ph2	SUPP HEATER/AUTO	2.0 16v 125kw (06-..)	AUTODETECT
 Espace IV ph2	SUPP HEATER/AUTO	2.0 16v dCi 110kw (06-..)	AUTODETECT
 Espace IV ph2	SUPP HEATER/AUTO	2.0 16v dCi 127kw (06-..)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Espace IV ph2	SUPP HEATER/AUTO	2.0 16v dCi 96kw (06-..)	AUTODETECT
 Espace IV ph2	SUPP HEATER/AUTO	2.0 16v dCi FAP 110kw (06-..)	AUTODETECT
 Espace IV ph2	SUPP HEATER/AUTO	2.0 16v dCi FAP 127kw (06-..)	AUTODETECT
 Espace IV ph2	SUPP HEATER/AUTO	2.2 16v dCi 102kw (06-..)	AUTODETECT
 Espace IV ph2	SUPP HEATER/AUTO	2.2 16v dCi 110kw (06-..)	AUTODETECT
 Espace IV ph2	SUPP HEATER/AUTO	3.0 V6 24v dCi 120kw (06-..)	AUTODETECT
 Espace IV ph2	SUPP HEATER/AUTO	3.5 V6 24v 177kw (06-..)	AUTODETECT
 Espace IV	ABS	1.9 dCi 85kw (02-06)	AUTODETECT
 Espace IV	ABS	1.9 dCi 85kw (06-..)	AUTODETECT
 Espace IV	ABS	1.9 dCi 88kw (02-06)	AUTODETECT
 Espace IV	ABS	1.9 dCi 88kw (06-..)	AUTODETECT
 Espace IV	ABS	2.0 16v 103kw (02-06)	AUTODETECT
 Espace IV	ABS	2.0 16v 103kw (06-..)	AUTODETECT
 Espace IV	ABS	2.0 16v 125kw (06-..)	AUTODETECT
 Espace IV	ABS	2.0 16v dCi 110kw (02-06)	AUTODETECT
 Espace IV	ABS	2.0 16v dCi 110kw (06-..)	AUTODETECT
 Espace IV	ABS	2.0 16v dCi 127kw (06-..)	AUTODETECT
 Espace IV	ABS	2.0 16v dCi 96kw (02-06)	AUTODETECT
 Espace IV	ABS	2.0 16v dCi 96kw (06-..)	AUTODETECT
 Espace IV	ABS	2.0 16v dCi FAP 110kw (02-06)	AUTODETECT
 Espace IV	ABS	2.0 16v dCi FAP 110kw (06-..)	AUTODETECT
 Espace IV	ABS	2.0 16v dCi FAP 127kw (02-06)	AUTODETECT
 Espace IV	ABS	2.0 16v dCi FAP 127kw (06-..)	AUTODETECT
 Espace IV	ABS	2.0 16v T 121kw (02-06)	AUTODETECT
 Espace IV	ABS	2.0 16v T 125kw (02-06)	AUTODETECT
 Espace IV	ABS	2.2 16v dCi 102kw (02-06)	AUTODETECT
 Espace IV	ABS	2.2 16v dCi 110kw (02-06)	AUTODETECT
 Espace IV	ABS	2.2 16v dCi 110kw (06-..)	AUTODETECT
 Espace IV	ABS	2.2 16v dCi FAP 102kw (06-..)	AUTODETECT
 Espace IV	ABS	3.0 V6 24v dCi 120kw (02-06)	AUTODETECT
 Espace IV	ABS	3.0 V6 24v dCi 120kw (06-..)	AUTODETECT
 Espace IV	ABS	3.0 V6 24v dCi 130kw (02-06)	AUTODETECT
 Espace IV	ABS	3.0 V6 24v dCi 133kw (06-..)	AUTODETECT
 Espace IV	ABS	3.5 V6 24v 177kw (02-06)	AUTODETECT
 Espace IV	ABS	3.5 V6 24v 177kw (06-..)	AUTODETECT
 Espace IV	AIRBAG	1.9 dCi 85kw (02-06)	AUTODETECT
 Espace IV	AIRBAG	1.9 dCi 85kw (06-..)	AUTODETECT
 Espace IV	AIRBAG	1.9 dCi 88kw (02-06)	AUTODETECT
 Espace IV	AIRBAG	1.9 dCi 88kw (06-..)	AUTODETECT
 Espace IV	AIRBAG	2.0 16v 103kw (02-06)	AUTODETECT
 Espace IV	AIRBAG	2.0 16v 103kw (06-..)	AUTODETECT
 Espace IV	AIRBAG	2.0 16v 125kw (06-..)	AUTODETECT
 Espace IV	AIRBAG	2.0 16v dCi 110kw (06-..)	AUTODETECT
 Espace IV	AIRBAG	2.0 16v dCi 127kw (06-..)	AUTODETECT
 Espace IV	AIRBAG	2.0 16v dCi 96kw (02-06)	AUTODETECT
 Espace IV	AIRBAG	2.0 16v dCi 96kw (06-..)	AUTODETECT
 Espace IV	AIRBAG	2.0 16v dCi FAP 110kw (02-06)	AUTODETECT
 Espace IV	AIRBAG	2.0 16v dCi FAP 110kw (06-..)	AUTODETECT
 Espace IV	AIRBAG	2.0 16v dCi FAP 127kw (02-06)	AUTODETECT
 Espace IV	AIRBAG	2.0 16v dCi FAP 127kw (06-..)	AUTODETECT
 Espace IV	AIRBAG	2.0 16v T 121kw (02-06)	AUTODETECT
 Espace IV	AIRBAG	2.0 16v T 125kw (02-06)	AUTODETECT
 Espace IV	AIRBAG	2.2 16v dCi 102kw (02-06)	AUTODETECT
 Espace IV	AIRBAG	2.2 16v dCi 110kw (02-06)	AUTODETECT
 Espace IV	AIRBAG	2.2 16v dCi 110kw (06-..)	AUTODETECT
 Espace IV	AIRBAG	2.2 16v dCi FAP 102kw (06-..)	AUTODETECT
 Espace IV	AIRBAG	3.0 V6 24v dCi 120kw (02-06)	AUTODETECT
 Espace IV	AIRBAG	3.0 V6 24v dCi 120kw (06-..)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Espace IV	AIRBAG	3.0 V6 24v dCi 130kw (02-06)	AUTODETECT
 Espace IV	AIRBAG	3.0 V6 24v dCi 133kw (06-..)	AUTODETECT
 Espace IV	AIRBAG	3.5 V6 24v 177kw (02-06)	AUTODETECT
 Espace IV	AIRBAG	3.5 V6 24v 177kw (06-..)	AUTODETECT
 Espace IV	AUTOM. TRANSMISSI	1.9 dCi 85kw (02-06)	AUTODETECT
 Espace IV	AUTOM. TRANSMISSI	1.9 dCi 85kw (06-..)	AUTODETECT
 Espace IV	AUTOM. TRANSMISSI	1.9 dCi 88kw (06-..)	AUTODETECT
 Espace IV	AUTOM. TRANSMISSI	2.0 16v 103kw (02-06)	AUTODETECT
 Espace IV	AUTOM. TRANSMISSI	2.0 16v 103kw (06-..)	AUTODETECT
 Espace IV	AUTOM. TRANSMISSI	2.0 16v 125kw (06-..)	AUTODETECT
 Espace IV	AUTOM. TRANSMISSI	2.0 16v dCi 110kw (06-..)	AUTODETECT
 Espace IV	AUTOM. TRANSMISSI	2.0 16v dCi 127kw (06-..)	AUTODETECT
 Espace IV	AUTOM. TRANSMISSI	2.0 16v dCi 96kw (02-06)	AUTODETECT
 Espace IV	AUTOM. TRANSMISSI	2.0 16v dCi 96kw (06-..)	AUTODETECT
 Espace IV	AUTOM. TRANSMISSI	2.0 16v dCi FAP 110kw (02-06)	AUTODETECT
 Espace IV	AUTOM. TRANSMISSI	2.0 16v dCi FAP 110kw (06-..)	AUTODETECT
 Espace IV	AUTOM. TRANSMISSI	2.0 16v dCi FAP 127kw (02-06)	AUTODETECT
 Espace IV	AUTOM. TRANSMISSI	2.0 16v dCi FAP 127kw (06-..)	AUTODETECT
 Espace IV	AUTOM. TRANSMISSI	2.0 16v T 121kw (02-06)	AUTODETECT
 Espace IV	AUTOM. TRANSMISSI	2.0 16v T 125kw (02-06)	AUTODETECT
 Espace IV	AUTOM. TRANSMISSI	2.2 16v dCi 102kw (02-06)	AUTODETECT
 Espace IV	AUTOM. TRANSMISSI	2.2 16v dCi 110kw (02-06)	AUTODETECT
 Espace IV	AUTOM. TRANSMISSI	2.2 16v dCi 110kw (06-..)	AUTODETECT
 Espace IV	AUTOM. TRANSMISSI	2.2 16v dCi FAP 102kw (06-..)	AUTODETECT
 Espace IV	AUTOM. TRANSMISSI	3.0 V6 24v dCi 120kw (02-06)	AUTODETECT
 Espace IV	AUTOM. TRANSMISSI	3.0 V6 24v dCi 120kw (06-..)	AUTODETECT
 Espace IV	AUTOM. TRANSMISSI	3.0 V6 24v dCi 130kw (02-06)	AUTODETECT
 Espace IV	AUTOM. TRANSMISSI	3.0 V6 24v dCi 133kw (06-..)	AUTODETECT
 Espace IV	AUTOM. TRANSMISSI	3.5 V6 24v 177kw (02-06)	AUTODETECT
 Espace IV	AUTOM. TRANSMISSI	3.5 V6 24v 177kw (06-..)	AUTODETECT
 Espace IV	CHASSIS NETWORK	1.9 dCi 85kw (02-06)	UCH AUTODETECT
 Espace IV	CHASSIS NETWORK	1.9 dCi 85kw (06-..)	UCC AUTODETECT
 Espace IV	CHASSIS NETWORK	1.9 dCi 85kw (06-..)	UCH AUTODETECT
 Espace IV	CHASSIS NETWORK	1.9 dCi 88kw (02-06)	UCH AUTODETECT
 Espace IV	CHASSIS NETWORK	1.9 dCi 88kw (06-..)	UCC AUTODETECT
 Espace IV	CHASSIS NETWORK	1.9 dCi 88kw (06-..)	UCH AUTODETECT
 Espace IV	CHASSIS NETWORK	2.0 16v 103kw (02-06)	UCH AUTODETECT
 Espace IV	CHASSIS NETWORK	2.0 16v 103kw (06-..)	UCC AUTODETECT
 Espace IV	CHASSIS NETWORK	2.0 16v 103kw (06-..)	UCH AUTODETECT
 Espace IV	CHASSIS NETWORK	2.0 16v 125kw (06-..)	UCC AUTODETECT
 Espace IV	CHASSIS NETWORK	2.0 16v 125kw (06-..)	UCH AUTODETECT
 Espace IV	CHASSIS NETWORK	2.0 16v dCi 110kw (06-..)	UCC AUTODETECT
 Espace IV	CHASSIS NETWORK	2.0 16v dCi 110kw (06-..)	UCH AUTODETECT
 Espace IV	CHASSIS NETWORK	2.0 16v dCi 127kw (06-..)	UCC AUTODETECT
 Espace IV	CHASSIS NETWORK	2.0 16v dCi 127kw (06-..)	UCH AUTODETECT
 Espace IV	CHASSIS NETWORK	2.0 16v dCi 96kw (02-06)	UCH AUTODETECT
 Espace IV	CHASSIS NETWORK	2.0 16v dCi 96kw (06-..)	UCC AUTODETECT
 Espace IV	CHASSIS NETWORK	2.0 16v dCi 96kw (06-..)	UCH AUTODETECT
 Espace IV	CHASSIS NETWORK	2.0 16v dCi FAP 110kw (02-06)	UCH AUTODETECT
 Espace IV	CHASSIS NETWORK	2.0 16v dCi FAP 110kw (06-..)	UCC AUTODETECT
 Espace IV	CHASSIS NETWORK	2.0 16v dCi FAP 110kw (06-..)	UCH AUTODETECT
 Espace IV	CHASSIS NETWORK	2.0 16v dCi FAP 127kw (02-06)	UCH AUTODETECT
 Espace IV	CHASSIS NETWORK	2.0 16v dCi FAP 127kw (06-..)	UCC AUTODETECT
 Espace IV	CHASSIS NETWORK	2.0 16v dCi FAP 127kw (06-..)	UCH AUTODETECT
 Espace IV	CHASSIS NETWORK	2.0 16v T 121kw (02-06)	UCH AUTODETECT
 Espace IV	CHASSIS NETWORK	2.0 16v T 125kw (02-06)	UCH AUTODETECT
 Espace IV	CHASSIS NETWORK	2.2 16v dCi 102kw (02-06)	UCH AUTODETECT
 Espace IV	CHASSIS NETWORK	2.2 16v dCi 110kw (02-06)	UCH AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Espace IV	CHASSIS NETWORK	2.2 16v dCi 110kw (06-..)	UCC AUTODETECT
 Espace IV	CHASSIS NETWORK	2.2 16v dCi 110kw (06-..)	UCH AUTODETECT
 Espace IV	CHASSIS NETWORK	2.2 16v dCi FAP 102kw (06-..)	UCC AUTODETECT
 Espace IV	CHASSIS NETWORK	2.2 16v dCi FAP 102kw (06-..)	UCH AUTODETECT
 Espace IV	CHASSIS NETWORK	3.0 V6 24v dCi 120kw (02-06)	UCH AUTODETECT
 Espace IV	CHASSIS NETWORK	3.0 V6 24v dCi 120kw (06-..)	UCC AUTODETECT
 Espace IV	CHASSIS NETWORK	3.0 V6 24v dCi 120kw (06-..)	UCH AUTODETECT
 Espace IV	CHASSIS NETWORK	3.0 V6 24v dCi 130kw (02-06)	UCH AUTODETECT
 Espace IV	CHASSIS NETWORK	3.0 V6 24v dCi 133kw (06-..)	UCC AUTODETECT
 Espace IV	CHASSIS NETWORK	3.0 V6 24v dCi 133kw (06-..)	UCH AUTODETECT
 Espace IV	CHASSIS NETWORK	3.5 V6 24v 177kw (02-06)	UCH AUTODETECT
 Espace IV	CHASSIS NETWORK	3.5 V6 24v 177kw (06-..)	UCC AUTODETECT
 Espace IV	CHASSIS NETWORK	3.5 V6 24v 177kw (06-..)	UCH AUTODETECT
 Espace IV	CLIMA	1.9 dCi 85kw (02-06)	AUTODETECT
 Espace IV	CLIMA	1.9 dCi 85kw (06-..)	AUTODETECT
 Espace IV	CLIMA	1.9 dCi 88kw (02-06)	AUTODETECT
 Espace IV	CLIMA	1.9 dCi 88kw (06-..)	AUTODETECT
 Espace IV	CLIMA	2.0 16v 103kw (02-06)	AUTODETECT
 Espace IV	CLIMA	2.0 16v 103kw (06-..)	AUTODETECT
 Espace IV	CLIMA	2.0 16v 125kw (06-..)	AUTODETECT
 Espace IV	CLIMA	2.0 16v dCi 110kw (06-..)	AUTODETECT
 Espace IV	CLIMA	2.0 16v dCi 127kw (06-..)	AUTODETECT
 Espace IV	CLIMA	2.0 16v dCi 96kw (02-06)	AUTODETECT
 Espace IV	CLIMA	2.0 16v dCi 96kw (06-..)	AUTODETECT
 Espace IV	CLIMA	2.0 16v dCi FAP 110kw (02-06)	AUTODETECT
 Espace IV	CLIMA	2.0 16v dCi FAP 110kw (06-..)	AUTODETECT
 Espace IV	CLIMA	2.0 16v dCi FAP 127kw (02-06)	AUTODETECT
 Espace IV	CLIMA	2.0 16v dCi FAP 127kw (06-..)	AUTODETECT
 Espace IV	CLIMA	2.0 16v T 121kw (02-06)	AUTODETECT
 Espace IV	CLIMA	2.0 16v T 125kw (02-06)	AUTODETECT
 Espace IV	CLIMA	2.2 16v dCi 102kw (02-06)	AUTODETECT
 Espace IV	CLIMA	2.2 16v dCi 110kw (02-06)	AUTODETECT
 Espace IV	CLIMA	2.2 16v dCi 110kw (06-..)	AUTODETECT
 Espace IV	CLIMA	2.2 16v dCi FAP 102kw (06-..)	AUTODETECT
 Espace IV	CLIMA	3.0 V6 24v dCi 120kw (02-06)	AUTODETECT
 Espace IV	CLIMA	3.0 V6 24v dCi 120kw (06-..)	AUTODETECT
 Espace IV	CLIMA	3.0 V6 24v dCi 130kw (02-06)	AUTODETECT
 Espace IV	CLIMA	3.0 V6 24v dCi 133kw (06-..)	AUTODETECT
 Espace IV	CLIMA	3.5 V6 24v 177kw (02-06)	AUTODETECT
 Espace IV	CLIMA	3.5 V6 24v 177kw (06-..)	AUTODETECT
 Espace IV	DASHBOARD	1.9 dCi 85kw (02-06)	AUTODETECT
 Espace IV	DASHBOARD	1.9 dCi 85kw (06-..)	AUTODETECT
 Espace IV	DASHBOARD	1.9 dCi 88kw (02-06)	AUTODETECT
 Espace IV	DASHBOARD	1.9 dCi 88kw (06-..)	AUTODETECT
 Espace IV	DASHBOARD	2.0 16v 103kw (02-06)	AUTODETECT
 Espace IV	DASHBOARD	2.0 16v 103kw (06-..)	AUTODETECT
 Espace IV	DASHBOARD	2.0 16v 125kw (06-..)	AUTODETECT
 Espace IV	DASHBOARD	2.0 16v dCi 110kw (06-..)	AUTODETECT
 Espace IV	DASHBOARD	2.0 16v dCi 127kw (06-..)	AUTODETECT
 Espace IV	DASHBOARD	2.0 16v dCi 96kw (02-06)	AUTODETECT
 Espace IV	DASHBOARD	2.0 16v dCi 96kw (06-..)	AUTODETECT
 Espace IV	DASHBOARD	2.0 16v dCi FAP 110kw (02-06)	AUTODETECT
 Espace IV	DASHBOARD	2.0 16v dCi FAP 110kw (06-..)	AUTODETECT
 Espace IV	DASHBOARD	2.0 16v dCi FAP 127kw (02-06)	AUTODETECT
 Espace IV	DASHBOARD	2.0 16v dCi FAP 127kw (06-..)	AUTODETECT
 Espace IV	DASHBOARD	2.0 16v T 121kw (02-06)	AUTODETECT
 Espace IV	DASHBOARD	2.0 16v T 125kw (02-06)	AUTODETECT
 Espace IV	DASHBOARD	2.2 16v dCi 102kw (02-06)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Espace IV	DASHBOARD	2.2 16v dCi 110kw (02-06)	AUTODETECT
 Espace IV	DASHBOARD	2.2 16v dCi 110kw (06-..)	AUTODETECT
 Espace IV	DASHBOARD	2.2 16v dCi FAP 102kw (06-..)	AUTODETECT
 Espace IV	DASHBOARD	3.0 V6 24v dCi 120kw (02-06)	AUTODETECT
 Espace IV	DASHBOARD	3.0 V6 24v dCi 120kw (06-..)	AUTODETECT
 Espace IV	DASHBOARD	3.0 V6 24v dCi 130kw (02-06)	AUTODETECT
 Espace IV	DASHBOARD	3.0 V6 24v dCi 133kw (06-..)	AUTODETECT
 Espace IV	DASHBOARD	3.5 V6 24v 177kw (02-06)	AUTODETECT
 Espace IV	DASHBOARD	3.5 V6 24v 177kw (06-..)	AUTODETECT
 Espace IV	ENGINE MANAGEME	1.9 dCi 85kw (02-06)	BOSCH EDC15 Common Rail AUTODETE
 Espace IV	ENGINE MANAGEME	1.9 dCi 88kw (02-06)	AUTODETECT
 Espace IV	ENGINE MANAGEME	2.0 16v 103kw (02-06)	AUTODETECT
 Espace IV	ENGINE MANAGEME	2.0 16v 121kw (02-06)	AUTODETECT
 Espace IV	ENGINE MANAGEME	2.0 16v 125kw (02-06)	AUTODETECT
 Espace IV	ENGINE MANAGEME	2.0 16v dCi FAP 110kw M9R-760 (02	EOBD
 Espace IV	ENGINE MANAGEME	2.0 16v dCi FAP 110kw M9R-761 (02	EOBD
 Espace IV	ENGINE MANAGEME	2.0 16v dCi FAP 127kw M9R-760 (02	EOBD
 Espace IV	ENGINE MANAGEME	2.0 16v dCi FAP 127kw M9R-761 (02	EOBD
 Espace IV	ENGINE MANAGEME	2.0 16v dCi FAP 127kw M9R-762 (02	EOBD
 Espace IV	ENGINE MANAGEME	2.0 16v dCi FAP 127kw M9R-763 (02	EOBD
 Espace IV	ENGINE MANAGEME	2.0 16v T 121kw (02-06)	AUTODETECT
 Espace IV	ENGINE MANAGEME	2.0 16v T 125kw (02-06)	AUTODETECT
 Espace IV	ENGINE MANAGEME	2.2 16v dCi 102kw (02-06)	AUTODETECT
 Espace IV	ENGINE MANAGEME	2.2 16v dCi 110kw (02-06)	AUTODETECT
 Espace IV	ENGINE MANAGEME	2.2 16v dCi 110kw G9T-642 (02-06)	BOSCH EDC 15 C3 Common Rail
 Espace IV	ENGINE MANAGEME	2.2 16v dCi 110kw G9T-644 (02-06)	BOSCH EDC 15 C3 Common Rail
 Espace IV	ENGINE MANAGEME	2.2 16v dCi 110kw G9T-742 (06-..)	BOSCH EDC 15 C3 Common Rail
 Espace IV	ENGINE MANAGEME	2.2 16v dCi 110kw G9T-743 (06-..)	BOSCH EDC 15 C3 Common Rail
 Espace IV	ENGINE MANAGEME	3.0 V6 24v dCi 120kw (02-06)	AUTODETECT
 Espace IV	ENGINE MANAGEME	3.0 V6 24v dCi 120kw P9X-715 (02-0	EOBD
 Espace IV	ENGINE MANAGEME	3.0 V6 24v dCi 130kw (02-06)	AUTODETECT
 Espace IV	ENGINE MANAGEME	3.5 V6 24v 177kw V4Y-711 (02-06)	EOBD
 Espace IV	HEADLIGHT LEVEL	1.9 dCi 85kw (02-06)	AUTODETECT
 Espace IV	HEADLIGHT LEVEL	1.9 dCi 85kw (06-..)	can AUTODETECT
 Espace IV	HEADLIGHT LEVEL	1.9 dCi 88kw (02-06)	AUTODETECT
 Espace IV	HEADLIGHT LEVEL	1.9 dCi 88kw (06-..)	can AUTODETECT
 Espace IV	HEADLIGHT LEVEL	2.0 16v 103kw (02-06)	AUTODETECT
 Espace IV	HEADLIGHT LEVEL	2.0 16v 103kw (06-..)	can AUTODETECT
 Espace IV	HEADLIGHT LEVEL	2.0 16v 125kw (06-..)	can AUTODETECT
 Espace IV	HEADLIGHT LEVEL	2.0 16v dCi 110kw (06-..)	can AUTODETECT
 Espace IV	HEADLIGHT LEVEL	2.0 16v dCi 127kw (06-..)	can AUTODETECT
 Espace IV	HEADLIGHT LEVEL	2.0 16v dCi 96kw (02-06)	AUTODETECT
 Espace IV	HEADLIGHT LEVEL	2.0 16v dCi 96kw (06-..)	can AUTODETECT
 Espace IV	HEADLIGHT LEVEL	2.0 16v dCi FAP 110kw (02-06)	AUTODETECT
 Espace IV	HEADLIGHT LEVEL	2.0 16v dCi FAP 110kw (06-..)	can AUTODETECT
 Espace IV	HEADLIGHT LEVEL	2.0 16v dCi FAP 127kw (02-06)	AUTODETECT
 Espace IV	HEADLIGHT LEVEL	2.0 16v dCi FAP 127kw (06-..)	can AUTODETECT
 Espace IV	HEADLIGHT LEVEL	2.0 16v T 121kw (02-06)	AUTODETECT
 Espace IV	HEADLIGHT LEVEL	2.0 16v T 125kw (02-06)	AUTODETECT
 Espace IV	HEADLIGHT LEVEL	2.2 16v dCi 102kw (02-06)	AUTODETECT
 Espace IV	HEADLIGHT LEVEL	2.2 16v dCi 110kw (02-06)	AUTODETECT
 Espace IV	HEADLIGHT LEVEL	2.2 16v dCi 110kw (06-..)	can AUTODETECT
 Espace IV	HEADLIGHT LEVEL	2.2 16v dCi FAP 102kw (06-..)	can AUTODETECT
 Espace IV	HEADLIGHT LEVEL	3.0 V6 24v dCi 120kw (02-06)	AUTODETECT
 Espace IV	HEADLIGHT LEVEL	3.0 V6 24v dCi 120kw (06-..)	can AUTODETECT
 Espace IV	HEADLIGHT LEVEL	3.0 V6 24v dCi 130kw (02-06)	AUTODETECT
 Espace IV	HEADLIGHT LEVEL	3.0 V6 24v dCi 133kw (06-..)	can AUTODETECT
 Espace IV	HEADLIGHT LEVEL	3.5 V6 24v 177kw (02-06)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Espace IV	HEADLIGHT LEVEL	3.5 V6 24v 177kw (06-..)	can AUTODETECT
 Espace IV	PARK.BRAKE	1.9 dCi 85kw (02-06)	Electrobrake AUTODETECT
 Espace IV	PARK.BRAKE	1.9 dCi 85kw (06-..)	Electrobrake AUTODETECT
 Espace IV	PARK.BRAKE	1.9 dCi 88kw (02-06)	Electrobrake AUTODETECT
 Espace IV	PARK.BRAKE	1.9 dCi 88kw (06-..)	Electrobrake AUTODETECT
 Espace IV	PARK.BRAKE	2.0 16v 103kw (02-06)	Electrobrake AUTODETECT
 Espace IV	PARK.BRAKE	2.0 16v 103kw (06-..)	Electrobrake AUTODETECT
 Espace IV	PARK.BRAKE	2.0 16v 125kw (06-..)	Electrobrake AUTODETECT
 Espace IV	PARK.BRAKE	2.0 16v dCi 110kw (06-..)	Electrobrake AUTODETECT
 Espace IV	PARK.BRAKE	2.0 16v dCi 127kw (06-..)	Electrobrake AUTODETECT
 Espace IV	PARK.BRAKE	2.0 16v dCi 96kw (02-06)	Electrobrake AUTODETECT
 Espace IV	PARK.BRAKE	2.0 16v dCi 96kw (06-..)	Electrobrake AUTODETECT
 Espace IV	PARK.BRAKE	2.0 16v dCi FAP 110kw (02-06)	Electrobrake AUTODETECT
 Espace IV	PARK.BRAKE	2.0 16v dCi FAP 110kw (06-..)	Electrobrake AUTODETECT
 Espace IV	PARK.BRAKE	2.0 16v dCi FAP 127kw (02-06)	Electrobrake AUTODETECT
 Espace IV	PARK.BRAKE	2.0 16v dCi FAP 127kw (06-..)	Electrobrake AUTODETECT
 Espace IV	PARK.BRAKE	2.0 16v T 121kw (02-06)	Electrobrake AUTODETECT
 Espace IV	PARK.BRAKE	2.0 16v T 125kw (02-06)	Electrobrake AUTODETECT
 Espace IV	PARK.BRAKE	2.2 16v dCi 102kw (02-06)	Electrobrake AUTODETECT
 Espace IV	PARK.BRAKE	2.2 16v dCi 110kw (02-06)	Electrobrake AUTODETECT
 Espace IV	PARK.BRAKE	2.2 16v dCi 110kw (06-..)	Electrobrake AUTODETECT
 Espace IV	PARK.BRAKE	2.2 16v dCi FAP 102kw (06-..)	Electrobrake AUTODETECT
 Espace IV	PARK.BRAKE	3.0 V6 24v dCi 120kw (02-06)	Electrobrake AUTODETECT
 Espace IV	PARK.BRAKE	3.0 V6 24v dCi 120kw (06-..)	Electrobrake AUTODETECT
 Espace IV	PARK.BRAKE	3.0 V6 24v dCi 133kw (06-..)	Electrobrake AUTODETECT
 Espace IV	PARK.BRAKE	3.5 V6 24v 177kw (02-06)	Electrobrake AUTODETECT
 Espace IV	PARK.BRAKE	3.5 V6 24v 177kw (06-..)	Electrobrake AUTODETECT
 Espace IV	PARKING HELP	1.9 dCi 85kw (02-06)	AUTODETECT
 Espace IV	PARKING HELP	1.9 dCi 85kw (06-..)	can AUTODETECT
 Espace IV	PARKING HELP	1.9 dCi 88kw (02-06)	AUTODETECT
 Espace IV	PARKING HELP	1.9 dCi 88kw (06-..)	AUTODETECT
 Espace IV	PARKING HELP	1.9 dCi 88kw (06-..)	can AUTODETECT
 Espace IV	PARKING HELP	2.0 16v 103kw (02-06)	AUTODETECT
 Espace IV	PARKING HELP	2.0 16v 103kw (06-..)	AUTODETECT
 Espace IV	PARKING HELP	2.0 16v 103kw (06-..)	can AUTODETECT
 Espace IV	PARKING HELP	2.0 16v 125kw (06-..)	AUTODETECT
 Espace IV	PARKING HELP	2.0 16v 125kw (06-..)	can AUTODETECT
 Espace IV	PARKING HELP	2.0 16v dCi 110kw (06-..)	AUTODETECT
 Espace IV	PARKING HELP	2.0 16v dCi 110kw (06-..)	can AUTODETECT
 Espace IV	PARKING HELP	2.0 16v dCi 127kw (06-..)	AUTODETECT
 Espace IV	PARKING HELP	2.0 16v dCi 127kw (06-..)	can AUTODETECT
 Espace IV	PARKING HELP	2.0 16v dCi 96kw (02-06)	AUTODETECT
 Espace IV	PARKING HELP	2.0 16v dCi 96kw (06-..)	AUTODETECT
 Espace IV	PARKING HELP	2.0 16v dCi 96kw (06-..)	can AUTODETECT
 Espace IV	PARKING HELP	2.0 16v dCi FAP 110kw (02-06)	AUTODETECT
 Espace IV	PARKING HELP	2.0 16v dCi FAP 110kw (06-..)	AUTODETECT
 Espace IV	PARKING HELP	2.0 16v dCi FAP 110kw (06-..)	can AUTODETECT
 Espace IV	PARKING HELP	2.0 16v dCi FAP 127kw (02-06)	AUTODETECT
 Espace IV	PARKING HELP	2.0 16v dCi FAP 127kw (06-..)	AUTODETECT
 Espace IV	PARKING HELP	2.0 16v T 121kw (02-06)	AUTODETECT
 Espace IV	PARKING HELP	2.0 16v T 125kw (02-06)	AUTODETECT
 Espace IV	PARKING HELP	2.2 16v dCi 102kw (02-06)	AUTODETECT
 Espace IV	PARKING HELP	2.2 16v dCi 110kw (02-06)	AUTODETECT
 Espace IV	PARKING HELP	2.2 16v dCi 110kw (06-..)	AUTODETECT
 Espace IV	PARKING HELP	2.2 16v dCi 110kw (06-..)	can AUTODETECT
 Espace IV	PARKING HELP	2.2 16v dCi FAP 102kw (06-..)	AUTODETECT
 Espace IV	PARKING HELP	2.2 16v dCi FAP 102kw (06-..)	can AUTODETECT
 Espace IV	PARKING HELP	3.0 V6 24v dCi 120kw (02-06)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Espace IV	PARKING HELP	3.0 V6 24v dCi 120kw (06-..)	AUTODETECT
 Espace IV	PARKING HELP	3.0 V6 24v dCi 120kw (06-..)	can AUTODETECT
 Espace IV	PARKING HELP	3.0 V6 24v dCi 130kw (02-06)	AUTODETECT
 Espace IV	PARKING HELP	3.0 V6 24v dCi 133kw (06-..)	AUTODETECT
 Espace IV	PARKING HELP	3.0 V6 24v dCi 133kw (06-..)	can AUTODETECT
 Espace IV	PARKING HELP	3.5 V6 24v 177kw (02-06)	AUTODETECT
 Espace IV	PARKING HELP	3.5 V6 24v 177kw (06-..)	AUTODETECT
 Espace IV	PARKING HELP	3.5 V6 24v 177kw (06-..)	can AUTODETECT
 Espace IV	STEERING WHEEL E	1.9 dCi 85kw (06-..)	AUTODETECT
 Espace IV	STEERING WHEEL E	1.9 dCi 88kw (06-..)	AUTODETECT
 Espace IV	STEERING WHEEL E	2.0 16v 103kw (06-..)	AUTODETECT
 Espace IV	STEERING WHEEL E	2.0 16v 125kw (06-..)	AUTODETECT
 Espace IV	STEERING WHEEL E	2.0 16v dCi 110kw (06-..)	AUTODETECT
 Espace IV	STEERING WHEEL E	2.0 16v dCi 127kw (06-..)	AUTODETECT
 Espace IV	STEERING WHEEL E	2.0 16v dCi 96kw (06-..)	AUTODETECT
 Espace IV	STEERING WHEEL E	2.0 16v dCi FAP 110kw (06-..)	AUTODETECT
 Espace IV	STEERING WHEEL E	2.0 16v dCi FAP 127kw (06-..)	AUTODETECT
 Espace IV	STEERING WHEEL E	2.2 16v dCi 110kw (06-..)	AUTODETECT
 Espace IV	STEERING WHEEL E	2.2 16v dCi FAP 102kw (06-..)	AUTODETECT
 Espace IV	STEERING WHEEL E	3.0 V6 24v dCi 133kw (06-..)	AUTODETECT
 Espace IV	STEERING WHEEL E	3.0 V6 24v dCi 133kw (06-..)	AUTODETECT
 Espace IV	STEERING WHEEL E	3.5 V6 24v 177kw (06-..)	AUTODETECT
 Espace IV	SUPP HEATER/AUTO	1.9 dCi 85kw (02-06)	AUTODETECT
 Espace IV	SUPP HEATER/AUTO	1.9 dCi 85kw (06-..)	AUTODETECT
 Espace IV	SUPP HEATER/AUTO	2.0 16v 103kw (02-06)	AUTODETECT
 Espace IV	SUPP HEATER/AUTO	2.0 16v 103kw (06-..)	AUTODETECT
 Espace IV	SUPP HEATER/AUTO	2.0 16v 125kw (06-..)	AUTODETECT
 Espace IV	SUPP HEATER/AUTO	2.0 16v dCi 110kw (06-..)	AUTODETECT
 Espace IV	SUPP HEATER/AUTO	2.0 16v dCi 127kw (06-..)	AUTODETECT
 Espace IV	SUPP HEATER/AUTO	2.0 16v dCi 96kw (02-06)	AUTODETECT
 Espace IV	SUPP HEATER/AUTO	2.0 16v dCi 96kw (06-..)	AUTODETECT
 Espace IV	SUPP HEATER/AUTO	2.0 16v dCi FAP 110kw (02-06)	AUTODETECT
 Espace IV	SUPP HEATER/AUTO	2.0 16v dCi FAP 110kw (06-..)	AUTODETECT
 Espace IV	SUPP HEATER/AUTO	2.0 16v dCi FAP 127kw (02-06)	AUTODETECT
 Espace IV	SUPP HEATER/AUTO	2.0 16v dCi FAP 127kw (06-..)	AUTODETECT
 Espace IV	SUPP HEATER/AUTO	2.0 16v T 125kw (02-06)	AUTODETECT
 Espace IV	SUPP HEATER/AUTO	2.2 16v dCi 102kw (02-06)	AUTODETECT
 Espace IV	SUPP HEATER/AUTO	2.2 16v dCi 110kw (02-06)	AUTODETECT
 Espace IV	SUPP HEATER/AUTO	2.2 16v dCi 110kw (06-..)	AUTODETECT
 Espace IV	SUPP HEATER/AUTO	2.2 16v dCi FAP 102kw (06-..)	AUTODETECT
 Espace IV	SUPP HEATER/AUTO	3.0 V6 24v dCi 120kw (02-06)	AUTODETECT
 Espace IV	SUPP HEATER/AUTO	3.0 V6 24v dCi 120kw (06-..)	AUTODETECT
 Espace IV	SUPP HEATER/AUTO	3.0 V6 24v dCi 130kw (02-06)	AUTODETECT
 Espace IV	SUPP HEATER/AUTO	3.0 V6 24v dCi 133kw (06-..)	AUTODETECT
 Espace IV	SUPP HEATER/AUTO	3.5 V6 24v 177kw (02-06)	AUTODETECT
 Espace IV	SUPP HEATER/AUTO	3.5 V6 24v 177kw (06-..)	AUTODETECT
 Express	AIRBAG	1.2 40kw	SIEMENS - Autoliv AirBag AC4
 Express	AIRBAG	1.2 40kw	SIEMENS - Autoliv AirBag EC5
 Express	AIRBAG	1.4 44kw	SIEMENS - Autoliv AirBag AC4
 Express	AIRBAG	1.4 44kw	SIEMENS - Autoliv AirBag EC5
 Express	AIRBAG	1.4 55kw	SIEMENS - Autoliv AirBag AC4
 Express	AIRBAG	1.4 55kw	SIEMENS - Autoliv AirBag EC5
 Express	AIRBAG	1.4 57kw	SIEMENS - Autoliv AirBag AC4
 Express	AIRBAG	1.4 57kw	SIEMENS - Autoliv AirBag EC5
 Express	AIRBAG	1.9 D 40kw	SIEMENS - Autoliv AirBag AC4
 Express	AIRBAG	1.9 D 40kw	SIEMENS - Autoliv AirBag EC5
Express	AIRBAG	1.9 D 48kw	SIEMENS - Autoliv AirBag AC4
Express	AIRBAG	1.9 D 48kw	SIEMENS - Autoliv AirBag EC5

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Express	ENGINE MANAGEME	1.2 40kw C3G-702	Marelli IAW 6R
 Express	ENGINE MANAGEME	1.2 40kw C3G-710	Marelli IAW 6R
 Express	ENGINE MANAGEME	1.2 40kw C3G-710	Marelli IAW 6R
 Express	ENGINE MANAGEME	1.2 40kw C3G-710	Marelli IAW 6R
 Express	ENGINE MANAGEME	1.2 40kw C3G-710	Marelli IAW 6R
 Express	ENGINE MANAGEME	1.2 40kw C3G-710	Marelli IAW 6R
 Express	ENGINE MANAGEME	1.2 40kw C3G-710	Marelli IAW 6R
 Express	ENGINE MANAGEME	1.4 44kw C3J-702	SIEMENS RENIX SPI
 Express	ENGINE MANAGEME	1.4 44kw C3J-760	SIEMENS RENIX SPI
 Express	ENGINE MANAGEME	1.4 44kw C3J-762	SIEMENS RENIX SPI
 Express	ENGINE MANAGEME	1.4 55kw E7J-720	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 55kw E7J-720	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 55kw E7J-720	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 55kw E7J-720	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 55kw E7J-720	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 55kw E7J-728	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 55kw E7J-728	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 55kw E7J-728	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 55kw E7J-728	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 55kw E7J-770	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 57kw E7J-724	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 57kw E7J-724	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 57kw E7J-724	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 57kw E7J-724	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 57kw E7J-724	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 57kw E7J-724	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 57kw E7J-773	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 57kw E7J-773	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 57kw E7J-773	SIEMENS BOSCH SPI
 Fluence	ABS	1.5 dCi 62kw (09-..)	AUTODETECT
 Fluence	ABS	1.5 dCi 66kw (09-..)	AUTODETECT
 Fluence	ABS	1.5 dCi 78kw (09-..)	AUTODETECT
 Fluence	ABS	1.5 dCi 81kw (09-..)	AUTODETECT
 Fluence	ABS	1.6 81kw (09-..)	AUTODETECT
 Fluence	ABS	2.0 103kw (09-..)	AUTODETECT
 Fluence	CHASSIS NETWORK	1.5 dCi 62kw (09-..)	UCC AUTODETECT
 Fluence	CHASSIS NETWORK	1.5 dCi 66kw (09-..)	UCC AUTODETECT
 Fluence	CHASSIS NETWORK	1.5 dCi 78kw (09-..)	UCC AUTODETECT
 Fluence	CHASSIS NETWORK	1.5 dCi 81kw (09-..)	UCC AUTODETECT
 Fluence	CHASSIS NETWORK	1.6 81kw (09-..)	UCC AUTODETECT
 Fluence	CHASSIS NETWORK	2.0 103kw (09-..)	UCC AUTODETECT
 Fluence	DASHBOARD	1.5 dCi 62kw (09-..)	AUTODETECT
 Fluence	DASHBOARD	1.5 dCi 66kw (09-..)	AUTODETECT
 Fluence	DASHBOARD	1.5 dCi 78kw (09-..)	AUTODETECT
 Fluence	DASHBOARD	1.5 dCi 81kw (09-..)	AUTODETECT
 Fluence	DASHBOARD	1.6 81kw (09-..)	AUTODETECT
 Fluence	DASHBOARD	2.0 103kw (09-..)	AUTODETECT
 Fluence	ELECTRIC STEERING	1.5 dCi 62kw (09-..)	AUTODETECT
 Fluence	ELECTRIC STEERING	1.5 dCi 66kw (09-..)	AUTODETECT
 Fluence	ELECTRIC STEERING	1.5 dCi 78kw (09-..)	AUTODETECT
 Fluence	ELECTRIC STEERING	1.5 dCi 81kw (09-..)	AUTODETECT
 Fluence	ELECTRIC STEERING	1.6 81kw (09-..)	AUTODETECT
 Fluence	ELECTRIC STEERING	2.0 103kw (09-..)	AUTODETECT
 Fluence	ENGINE MANAGEME	1.5 dCi 62kw (09-..)	AUTODETECT
 Fluence	ENGINE MANAGEME	1.5 dCi 66kw (09-..)	AUTODETECT
 Fluence	ENGINE MANAGEME	1.5 dCi 78kw (09-..)	AUTODETECT
 Fluence	ENGINE MANAGEME	1.5 dCi 81kw (09-..)	AUTODETECT
 Fluence	ENGINE MANAGEME	1.6 81kw (09-..)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Fluence	ENGINE MANAGEME	2.0 103kw (09-..)	AUTODETECT
 Fluence	PARK.BRAKE	1.5 dCi 62kw (09-..)	AUTODETECT
 Fluence	PARK.BRAKE	1.5 dCi 66kw (09-..)	AUTODETECT
 Fluence	PARK.BRAKE	1.5 dCi 78kw (09-..)	AUTODETECT
 Fluence	PARK.BRAKE	1.5 dCi 81kw (09-..)	AUTODETECT
 Fluence	PARK.BRAKE	1.6 81kw (09-..)	AUTODETECT
 Fluence	PARK.BRAKE	2.0 103kw (09-..)	AUTODETECT
 Fluence	PARKING HELP	1.5 dCi 62kw (09-..)	can AUTODETECT
 Fluence	PARKING HELP	1.5 dCi 66kw (09-..)	can AUTODETECT
 Fluence	PARKING HELP	1.5 dCi 78kw (09-..)	can AUTODETECT
 Fluence	PARKING HELP	1.5 dCi 81kw (09-..)	can AUTODETECT
 Fluence	PARKING HELP	1.6 81kw (09-..)	can AUTODETECT
 Fluence	PARKING HELP	2.0 103kw (09-..)	can AUTODETECT
 Fluence	RADIO / CD	1.5 dCi 62kw (09-..)	AUTODETECT
 Fluence	RADIO / CD	1.5 dCi 66kw (09-..)	AUTODETECT
 Fluence	RADIO / CD	1.5 dCi 78kw (09-..)	AUTODETECT
 Fluence	RADIO / CD	1.5 dCi 81kw (09-..)	AUTODETECT
 Fluence	RADIO / CD	1.6 81kw (09-..)	AUTODETECT
 Fluence	RADIO / CD	2.0 103kw (09-..)	AUTODETECT
 Fluence	VISUAL./TELEMATIC	1.5 dCi 62kw (09-..)	USB AUTODETECT
 Fluence	VISUAL./TELEMATIC	1.5 dCi 66kw (09-..)	USB AUTODETECT
 Fluence	VISUAL./TELEMATIC	1.5 dCi 78kw (09-..)	USB AUTODETECT
 Fluence	VISUAL./TELEMATIC	1.5 dCi 81kw (09-..)	USB AUTODETECT
 Fluence	VISUAL./TELEMATIC	1.6 81kw (09-..)	USB AUTODETECT
 Fluence	VISUAL./TELEMATIC	2.0 103kw (09-..)	USB AUTODETECT
 Grand Espace IV	ABS	1.9 dCi 85kw (02-06)	AUTODETECT
 Grand Espace IV	ABS	1.9 dCi 85kw (06-..)	AUTODETECT
 Grand Espace IV	ABS	1.9 dCi 88kw (02-06)	AUTODETECT
 Grand Espace IV	ABS	1.9 dCi 88kw (06-..)	AUTODETECT
 Grand Espace IV	ABS	2.0 16v 103kw (02-06)	AUTODETECT
 Grand Espace IV	ABS	2.0 16v 125kw (06-..)	AUTODETECT
 Grand Espace IV	ABS	2.0 16v dCi 110kw (06-..)	AUTODETECT
 Grand Espace IV	ABS	2.0 16v dCi 127kw (06-..)	AUTODETECT
 Grand Espace IV	ABS	2.0 16v dCi 96kw (06-..)	AUTODETECT
 Grand Espace IV	ABS	2.0 16v dCi FAP 110kw (06-..)	AUTODETECT
 Grand Espace IV	ABS	2.0 16v dCi FAP 127kw (06-..)	AUTODETECT
 Grand Espace IV	ABS	2.0 16v T 121kw (02-06)	AUTODETECT
 Grand Espace IV	ABS	2.0 16v T 125kw (02-06)	AUTODETECT
 Grand Espace IV	ABS	2.2 16v dCi 102kw (02-06)	AUTODETECT
 Grand Espace IV	ABS	2.2 16v dCi 110kw (02-06)	AUTODETECT
 Grand Espace IV	ABS	2.2 16v dCi 110kw (06-..)	AUTODETECT
 Grand Espace IV	ABS	2.2 16v dCi FAP 102kw (06-..)	AUTODETECT
 Grand Espace IV	ABS	3.0 V6 24v dCi 120kw (02-06)	AUTODETECT
 Grand Espace IV	ABS	3.0 V6 24v dCi 120kw (06-..)	AUTODETECT
 Grand Espace IV	ABS	3.0 V6 24v dCi 130kw (02-06)	AUTODETECT
 Grand Espace IV	ABS	3.0 V6 24v dCi 133kw (02-06)	AUTODETECT
 Grand Espace IV	ABS	3.5 V6 24v 177kw (02-06)	AUTODETECT
 Grand Espace IV	ABS	3.5 V6 24v 177kw (06-..)	AUTODETECT
 Grand Espace IV	AIRBAG	1.9 dCi 85kw (02-06)	AUTODETECT
 Grand Espace IV	AIRBAG	1.9 dCi 85kw (06-..)	AUTODETECT
 Grand Espace IV	AIRBAG	1.9 dCi 88kw (02-06)	AUTODETECT
 Grand Espace IV	AIRBAG	1.9 dCi 88kw (06-..)	AUTODETECT
 Grand Espace IV	AIRBAG	2.0 16v 103kw (02-06)	AUTODETECT
 Grand Espace IV	AIRBAG	2.0 16v 125kw (06-..)	AUTODETECT
 Grand Espace IV	AIRBAG	2.0 16v dCi 110kw (06-..)	AUTODETECT
 Grand Espace IV	AIRBAG	2.0 16v dCi 127kw (06-..)	AUTODETECT
 Grand Espace IV	AIRBAG	2.0 16v dCi 96kw (06-..)	AUTODETECT
 Grand Espace IV	AIRBAG	2.0 16v dCi FAP 110kw (06-..)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Grand Espace IV	AIRBAG	2.0 16v dCi FAP 127kw (06-..)	AUTODETECT
 Grand Espace IV	AIRBAG	2.0 16v T 121kw (02-06)	AUTODETECT
 Grand Espace IV	AIRBAG	2.0 16v T 125kw (02-06)	AUTODETECT
 Grand Espace IV	AIRBAG	2.2 16v dCi 102kw (02-06)	AUTODETECT
 Grand Espace IV	AIRBAG	2.2 16v dCi 110kw (02-06)	AUTODETECT
 Grand Espace IV	AIRBAG	2.2 16v dCi 110kw (06-..)	AUTODETECT
 Grand Espace IV	AIRBAG	2.2 16v dCi FAP 102kw (06-..)	AUTODETECT
 Grand Espace IV	AIRBAG	3.0 V6 24v dCi 120kw (02-06)	AUTODETECT
 Grand Espace IV	AIRBAG	3.0 V6 24v dCi 120kw (06-..)	AUTODETECT
 Grand Espace IV	AIRBAG	3.0 V6 24v dCi 130kw (02-06)	AUTODETECT
 Grand Espace IV	AIRBAG	3.0 V6 24v dCi 133kw (02-06)	AUTODETECT
 Grand Espace IV	AIRBAG	3.5 V6 24v 177kw (02-06)	AUTODETECT
 Grand Espace IV	AIRBAG	3.5 V6 24v 177kw (06-..)	AUTODETECT
 Grand Espace IV	AUTOM. TRANSMISSI	1.9 dCi 85kw (02-06)	AUTODETECT
 Grand Espace IV	AUTOM. TRANSMISSI	1.9 dCi 85kw (06-..)	AUTODETECT
 Grand Espace IV	AUTOM. TRANSMISSI	1.9 dCi 88kw (02-06)	AUTODETECT
 Grand Espace IV	AUTOM. TRANSMISSI	1.9 dCi 88kw (06-..)	AUTODETECT
 Grand Espace IV	AUTOM. TRANSMISSI	2.0 16v 103kw (02-06)	AUTODETECT
 Grand Espace IV	AUTOM. TRANSMISSI	2.0 16v 125kw (06-..)	AUTODETECT
 Grand Espace IV	AUTOM. TRANSMISSI	2.0 16v dCi 110kw (06-..)	AUTODETECT
 Grand Espace IV	AUTOM. TRANSMISSI	2.0 16v dCi 127kw (06-..)	AUTODETECT
 Grand Espace IV	AUTOM. TRANSMISSI	2.0 16v dCi 96kw (06-..)	AUTODETECT
 Grand Espace IV	AUTOM. TRANSMISSI	2.0 16v dCi FAP 110kw (06-..)	AUTODETECT
 Grand Espace IV	AUTOM. TRANSMISSI	2.0 16v dCi FAP 127kw (06-..)	AUTODETECT
 Grand Espace IV	AUTOM. TRANSMISSI	2.0 16v T 121kw (02-06)	AUTODETECT
 Grand Espace IV	AUTOM. TRANSMISSI	2.0 16v T 125kw (02-06)	AUTODETECT
 Grand Espace IV	AUTOM. TRANSMISSI	2.2 16v dCi 102kw (02-06)	AUTODETECT
 Grand Espace IV	AUTOM. TRANSMISSI	2.2 16v dCi 110kw (02-06)	AUTODETECT
 Grand Espace IV	AUTOM. TRANSMISSI	2.2 16v dCi 110kw (06-..)	AUTODETECT
 Grand Espace IV	AUTOM. TRANSMISSI	2.2 16v dCi FAP 102kw (06-..)	AUTODETECT
 Grand Espace IV	AUTOM. TRANSMISSI	3.0 V6 24v dCi 120kw (02-06)	AUTODETECT
 Grand Espace IV	AUTOM. TRANSMISSI	3.0 V6 24v dCi 120kw (06-..)	AUTODETECT
 Grand Espace IV	AUTOM. TRANSMISSI	3.0 V6 24v dCi 130kw (02-06)	AUTODETECT
 Grand Espace IV	AUTOM. TRANSMISSI	3.0 V6 24v dCi 133kw (02-06)	AUTODETECT
 Grand Espace IV	AUTOM. TRANSMISSI	3.5 V6 24v 177kw (02-06)	AUTODETECT
 Grand Espace IV	AUTOM. TRANSMISSI	3.5 V6 24v 177kw (06-..)	AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	1.9 dCi 85kw (06-..)	UCC AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	1.9 dCi 85kw (06-..)	UCH AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	1.9 dCi 88kw (02-06)	UCH AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	1.9 dCi 88kw (06-..)	UCC AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	1.9 dCi 88kw (06-..)	UCH AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	2.0 16v 103kw (02-06)	UCH AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	2.0 16v 125kw (06-..)	UCC AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	2.0 16v 125kw (06-..)	UCH AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	2.0 16v dCi 110kw (06-..)	UCC AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	2.0 16v dCi 110kw (06-..)	UCH AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	2.0 16v dCi 127kw (06-..)	UCC AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	2.0 16v dCi 127kw (06-..)	UCH AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	2.0 16v dCi 96kw (06-..)	UCC AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	2.0 16v dCi 96kw (06-..)	UCH AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	2.0 16v dCi FAP 110kw (06-..)	UCC AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	2.0 16v dCi FAP 110kw (06-..)	UCH AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	2.0 16v dCi FAP 127kw (06-..)	UCC AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	2.0 16v dCi FAP 127kw (06-..)	UCH AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	2.0 16v T 121kw (02-06)	UCH AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	2.0 16v T 125kw (02-06)	UCH AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	2.2 16v dCi 102kw (02-06)	UCH AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	2.2 16v dCi 110kw (02-06)	UCH AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Grand Espace IV	CHASSIS NETWORK	2.2 16v dCi 110kw (06-..)	UCC AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	2.2 16v dCi 110kw (06-..)	UCH AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	2.2 16v dCi FAP 102kw (06-..)	UCC AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	2.2 16v dCi FAP 102kw (06-..)	UCH AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	3.0 V6 24v dCi 120kw (02-06)	UCH AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	3.0 V6 24v dCi 120kw (06-..)	UCC AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	3.0 V6 24v dCi 120kw (06-..)	UCH AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	3.0 V6 24v dCi 130kw (02-06)	UCH AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	3.0 V6 24v dCi 133kw (02-06)	UCH AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	3.5 V6 24v 177kw (02-06)	UCH AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	3.5 V6 24v 177kw (06-..)	UCC AUTODETECT
 Grand Espace IV	CHASSIS NETWORK	3.5 V6 24v 177kw (06-..)	UCH AUTODETECT
 Grand Espace IV	CLIMA	1.9 dCi 85kw (02-06)	AUTODETECT
 Grand Espace IV	CLIMA	1.9 dCi 85kw (06-..)	AUTODETECT
 Grand Espace IV	CLIMA	1.9 dCi 88kw (02-06)	AUTODETECT
 Grand Espace IV	CLIMA	1.9 dCi 88kw (06-..)	AUTODETECT
 Grand Espace IV	CLIMA	2.0 16v 103kw (02-06)	AUTODETECT
 Grand Espace IV	CLIMA	2.0 16v 125kw (06-..)	AUTODETECT
 Grand Espace IV	CLIMA	2.0 16v dCi 110kw (06-..)	AUTODETECT
 Grand Espace IV	CLIMA	2.0 16v dCi 127kw (06-..)	AUTODETECT
 Grand Espace IV	CLIMA	2.0 16v dCi 96kw (06-..)	AUTODETECT
 Grand Espace IV	CLIMA	2.0 16v dCi FAP 110kw (06-..)	AUTODETECT
 Grand Espace IV	CLIMA	2.0 16v dCi FAP 127kw (06-..)	AUTODETECT
 Grand Espace IV	CLIMA	2.0 16v T 121kw (02-06)	AUTODETECT
 Grand Espace IV	CLIMA	2.0 16v T 125kw (02-06)	AUTODETECT
 Grand Espace IV	CLIMA	2.2 16v dCi 102kw (02-06)	AUTODETECT
 Grand Espace IV	CLIMA	2.2 16v dCi 110kw (02-06)	AUTODETECT
 Grand Espace IV	CLIMA	2.2 16v dCi 110kw (06-..)	AUTODETECT
 Grand Espace IV	CLIMA	2.2 16v dCi FAP 102kw (06-..)	AUTODETECT
 Grand Espace IV	CLIMA	3.0 V6 24v dCi 120kw (02-06)	AUTODETECT
 Grand Espace IV	CLIMA	3.0 V6 24v dCi 120kw (06-..)	AUTODETECT
 Grand Espace IV	CLIMA	3.0 V6 24v dCi 130kw (02-06)	AUTODETECT
 Grand Espace IV	CLIMA	3.0 V6 24v dCi 133kw (02-06)	AUTODETECT
 Grand Espace IV	CLIMA	3.5 V6 24v 177kw (02-06)	AUTODETECT
 Grand Espace IV	CLIMA	3.5 V6 24v 177kw (06-..)	AUTODETECT
 Grand Espace IV	DASHBOARD	1.9 dCi 85kw (02-06)	AUTODETECT
 Grand Espace IV	DASHBOARD	1.9 dCi 85kw (06-..)	AUTODETECT
 Grand Espace IV	DASHBOARD	1.9 dCi 88kw (02-06)	AUTODETECT
 Grand Espace IV	DASHBOARD	1.9 dCi 88kw (06-..)	AUTODETECT
 Grand Espace IV	DASHBOARD	2.0 16v 103kw (02-06)	AUTODETECT
 Grand Espace IV	DASHBOARD	2.0 16v 125kw (06-..)	AUTODETECT
 Grand Espace IV	DASHBOARD	2.0 16v dCi 110kw (06-..)	AUTODETECT
 Grand Espace IV	DASHBOARD	2.0 16v dCi 127kw (06-..)	AUTODETECT
 Grand Espace IV	DASHBOARD	2.0 16v dCi 96kw (06-..)	AUTODETECT
 Grand Espace IV	DASHBOARD	2.0 16v dCi FAP 110kw (06-..)	AUTODETECT
 Grand Espace IV	DASHBOARD	2.0 16v dCi FAP 127kw (06-..)	AUTODETECT
 Grand Espace IV	DASHBOARD	2.0 16v T 121kw (02-06)	AUTODETECT
 Grand Espace IV	DASHBOARD	2.0 16v T 125kw (02-06)	AUTODETECT
 Grand Espace IV	DASHBOARD	2.2 16v dCi 102kw (02-06)	AUTODETECT
 Grand Espace IV	DASHBOARD	2.2 16v dCi 110kw (02-06)	AUTODETECT
 Grand Espace IV	DASHBOARD	2.2 16v dCi 110kw (06-..)	AUTODETECT
 Grand Espace IV	DASHBOARD	2.2 16v dCi FAP 102kw (06-..)	AUTODETECT
 Grand Espace IV	DASHBOARD	3.0 V6 24v dCi 120kw (02-06)	AUTODETECT
 Grand Espace IV	DASHBOARD	3.0 V6 24v dCi 120kw (06-..)	AUTODETECT
 Grand Espace IV	DASHBOARD	3.0 V6 24v dCi 130kw (02-06)	AUTODETECT
 Grand Espace IV	DASHBOARD	3.0 V6 24v dCi 133kw (02-06)	AUTODETECT
 Grand Espace IV	DASHBOARD	3.5 V6 24v 177kw (02-06)	AUTODETECT
 Grand Espace IV	DASHBOARD	3.5 V6 24v 177kw (06-..)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Grand Espace IV	ENGINE MANAGEME	1.9 dCi 85kw (04-06)	EOBD
 Grand Espace IV	ENGINE MANAGEME	1.9 dCi 85kw (06-..)	AUTODETECT
 Grand Espace IV	ENGINE MANAGEME	1.9 dCi 88kw (02-06)	AUTODETECT
 Grand Espace IV	ENGINE MANAGEME	1.9 dCi 88kw (06-..)	AUTODETECT
 Grand Espace IV	ENGINE MANAGEME	2.0 16v 125kw (06-..)	AUTODETECT
 Grand Espace IV	ENGINE MANAGEME	2.0 16v dCi 110kw (06-..)	AUTODETECT
 Grand Espace IV	ENGINE MANAGEME	2.0 16v dCi 127kw (06-..)	EOBD
 Grand Espace IV	ENGINE MANAGEME	2.0 16v dCi 96kw (06-..)	AUTODETECT
 Grand Espace IV	ENGINE MANAGEME	2.0 16v dCi FAP 110kw (06-..)	AUTODETECT
 Grand Espace IV	ENGINE MANAGEME	2.0 16v dCi FAP 127kw (06-..)	EOBD
 Grand Espace IV	ENGINE MANAGEME	2.0 16v T 121kw (02-06)	AUTODETECT
 Grand Espace IV	ENGINE MANAGEME	2.0 16v T 125kw (02-06)	AUTODETECT
 Grand Espace IV	ENGINE MANAGEME	2.2 16v dCi 102kw (02-06)	AUTODETECT
 Grand Espace IV	ENGINE MANAGEME	2.2 16v dCi 110kw (02-06)	AUTODETECT
 Grand Espace IV	ENGINE MANAGEME	2.2 16v dCi 110kw (06-..)	AUTODETECT
 Grand Espace IV	ENGINE MANAGEME	2.2 16v dCi 110kw G9T-742 (02-06)	BOSCH EDC 15 C3 Common Rail
 Grand Espace IV	ENGINE MANAGEME	2.2 16v dCi 110kw G9T-742 (06-..)	BOSCH EDC 15 C3 Common Rail
 Grand Espace IV	ENGINE MANAGEME	2.2 16v dCi 110kw G9T-743 (02-06)	BOSCH EDC 15 C3 Common Rail
 Grand Espace IV	ENGINE MANAGEME	2.2 16v dCi 110kw G9T-743 (06-..)	BOSCH EDC 15 C3 Common Rail
 Grand Espace IV	ENGINE MANAGEME	2.2 16v dCi FAP 102kw (06-..)	AUTODETECT
 Grand Espace IV	ENGINE MANAGEME	3.0 V6 24v dCi 120kw (02-06)	AUTODETECT
 Grand Espace IV	ENGINE MANAGEME	3.0 V6 24v dCi 120kw (02-06)	EOBD
 Grand Espace IV	ENGINE MANAGEME	3.0 V6 24v dCi 120kw (06-..)	AUTODETECT
 Grand Espace IV	ENGINE MANAGEME	3.0 V6 24v dCi 130kw (02-06)	AUTODETECT
 Grand Espace IV	ENGINE MANAGEME	3.0 V6 24v dCi 133kw (02-06)	AUTODETECT
 Grand Espace IV	ENGINE MANAGEME	3.5 V6 24v 177kw (02-06)	EOBD
 Grand Espace IV	ENGINE MANAGEME	3.5 V6 24v 177kw (06-..)	AUTODETECT
 Grand Espace IV	ENGINE MANAGEME	3.5 V6 24v 177kw (06-..)	SAGEM S3000 AUTODETECT
 Grand Espace IV	HEADLIGHT LEVEL	1.9 dCi 85kw (02-06)	AUTODETECT
 Grand Espace IV	HEADLIGHT LEVEL	1.9 dCi 85kw (06-..)	can AUTODETECT
 Grand Espace IV	HEADLIGHT LEVEL	1.9 dCi 88kw (02-06)	AUTODETECT
 Grand Espace IV	HEADLIGHT LEVEL	1.9 dCi 88kw (06-..)	can AUTODETECT
 Grand Espace IV	HEADLIGHT LEVEL	2.0 16v 103kw (02-06)	AUTODETECT
 Grand Espace IV	HEADLIGHT LEVEL	2.0 16v 125kw (06-..)	can AUTODETECT
 Grand Espace IV	HEADLIGHT LEVEL	2.0 16v dCi 110kw (06-..)	can AUTODETECT
 Grand Espace IV	HEADLIGHT LEVEL	2.0 16v dCi 127kw (06-..)	can AUTODETECT
 Grand Espace IV	HEADLIGHT LEVEL	2.0 16v dCi 96kw (06-..)	can AUTODETECT
 Grand Espace IV	HEADLIGHT LEVEL	2.0 16v dCi FAP 110kw (06-..)	can AUTODETECT
 Grand Espace IV	HEADLIGHT LEVEL	2.0 16v dCi FAP 127kw (06-..)	can AUTODETECT
 Grand Espace IV	HEADLIGHT LEVEL	2.0 16v T 121kw (02-06)	AUTODETECT
 Grand Espace IV	HEADLIGHT LEVEL	2.0 16v T 125kw (02-06)	AUTODETECT
 Grand Espace IV	HEADLIGHT LEVEL	2.2 16v dCi 102kw (02-06)	AUTODETECT
 Grand Espace IV	HEADLIGHT LEVEL	2.2 16v dCi 110kw (02-06)	AUTODETECT
 Grand Espace IV	HEADLIGHT LEVEL	2.2 16v dCi 110kw (06-..)	can AUTODETECT
 Grand Espace IV	HEADLIGHT LEVEL	2.2 16v dCi FAP 102kw (06-..)	can AUTODETECT
 Grand Espace IV	HEADLIGHT LEVEL	3.0 V6 24v dCi 120kw (02-06)	AUTODETECT
 Grand Espace IV	HEADLIGHT LEVEL	3.0 V6 24v dCi 120kw (06-..)	can AUTODETECT
 Grand Espace IV	HEADLIGHT LEVEL	3.0 V6 24v dCi 130kw (02-06)	AUTODETECT
 Grand Espace IV	HEADLIGHT LEVEL	3.0 V6 24v dCi 133kw (02-06)	AUTODETECT
 Grand Espace IV	HEADLIGHT LEVEL	3.5 V6 24v 177kw (02-06)	AUTODETECT
 Grand Espace IV	HEADLIGHT LEVEL	3.5 V6 24v 177kw (06-..)	can AUTODETECT
 Grand Espace IV	PARK.BRAKE	1.9 dCi 85kw (02-06)	Electrobrake AUTODETECT
 Grand Espace IV	PARK.BRAKE	1.9 dCi 85kw (06-..)	Electrobrake AUTODETECT
 Grand Espace IV	PARK.BRAKE	1.9 dCi 88kw (02-06)	Electrobrake AUTODETECT
 Grand Espace IV	PARK.BRAKE	1.9 dCi 88kw (06-..)	Electrobrake AUTODETECT
 Grand Espace IV	PARK.BRAKE	2.0 16v 103kw (02-06)	Electrobrake AUTODETECT
 Grand Espace IV	PARK.BRAKE	2.0 16v 125kw (06-..)	Electrobrake AUTODETECT
 Grand Espace IV	PARK.BRAKE	2.0 16v dCi 110kw (06-..)	Electrobrake AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Grand Espace IV	PARK.BRAKE	2.0 16v dCi 96kw (06-..)	Electrobrake AUTODETECT
 Grand Espace IV	PARK.BRAKE	2.0 16v dCi FAP 110kw (06-..)	Electrobrake AUTODETECT
 Grand Espace IV	PARK.BRAKE	2.0 16v dCi FAP 127kw (06-..)	Electrobrake AUTODETECT
 Grand Espace IV	PARK.BRAKE	2.0 16v T 121kw (02-06)	Electrobrake AUTODETECT
 Grand Espace IV	PARK.BRAKE	2.0 16v T 125kw (02-06)	Electrobrake AUTODETECT
 Grand Espace IV	PARK.BRAKE	2.2 16v dCi 102kw (02-06)	Electrobrake AUTODETECT
 Grand Espace IV	PARK.BRAKE	2.2 16v dCi 110kw (02-06)	Electrobrake AUTODETECT
 Grand Espace IV	PARK.BRAKE	2.2 16v dCi 110kw (06-..)	Electrobrake AUTODETECT
 Grand Espace IV	PARK.BRAKE	2.2 16v dCi FAP 102kw (06-..)	Electrobrake AUTODETECT
 Grand Espace IV	PARK.BRAKE	3.0 V6 24v dCi 120kw (02-06)	Electrobrake AUTODETECT
 Grand Espace IV	PARK.BRAKE	3.0 V6 24v dCi 120kw (06-..)	Electrobrake AUTODETECT
 Grand Espace IV	PARK.BRAKE	3.0 V6 24v dCi 130kw (02-06)	Electrobrake AUTODETECT
 Grand Espace IV	PARK.BRAKE	3.0 V6 24v dCi 133kw (02-06)	Electrobrake AUTODETECT
 Grand Espace IV	PARK.BRAKE	3.5 V6 24v 177kw (02-06)	Electrobrake AUTODETECT
 Grand Espace IV	PARK.BRAKE	3.5 V6 24v 177kw (06-..)	Electrobrake AUTODETECT
 Grand Espace IV	PARKING HELP	1.9 dCi 85kw (02-06)	AUTODETECT
 Grand Espace IV	PARKING HELP	1.9 dCi 85kw (06-..)	can AUTODETECT
 Grand Espace IV	PARKING HELP	1.9 dCi 88kw (02-06)	AUTODETECT
 Grand Espace IV	PARKING HELP	1.9 dCi 88kw (06-..)	AUTODETECT
 Grand Espace IV	PARKING HELP	1.9 dCi 88kw (06-..)	can AUTODETECT
 Grand Espace IV	PARKING HELP	2.0 16v 103kw (02-06)	AUTODETECT
 Grand Espace IV	PARKING HELP	2.0 16v 125kw (06-..)	AUTODETECT
 Grand Espace IV	PARKING HELP	2.0 16v 125kw (06-..)	can AUTODETECT
 Grand Espace IV	PARKING HELP	2.0 16v dCi 110kw (06-..)	AUTODETECT
 Grand Espace IV	PARKING HELP	2.0 16v dCi 110kw (06-..)	can AUTODETECT
 Grand Espace IV	PARKING HELP	2.0 16v dCi 127kw (06-..)	AUTODETECT
 Grand Espace IV	PARKING HELP	2.0 16v dCi 127kw (06-..)	can AUTODETECT
 Grand Espace IV	PARKING HELP	2.0 16v dCi 96kw (06-..)	AUTODETECT
 Grand Espace IV	PARKING HELP	2.0 16v dCi 96kw (06-..)	can AUTODETECT
 Grand Espace IV	PARKING HELP	2.0 16v dCi FAP 110kw (06-..)	AUTODETECT
 Grand Espace IV	PARKING HELP	2.0 16v dCi FAP 110kw (06-..)	can AUTODETECT
 Grand Espace IV	PARKING HELP	2.0 16v dCi FAP 127kw (06-..)	AUTODETECT
 Grand Espace IV	PARKING HELP	2.0 16v dCi FAP 127kw (06-..)	can AUTODETECT
 Grand Espace IV	PARKING HELP	2.0 16v T 121kw (02-06)	AUTODETECT
 Grand Espace IV	PARKING HELP	2.0 16v T 125kw (02-06)	AUTODETECT
 Grand Espace IV	PARKING HELP	2.2 16v dCi 102kw (02-06)	AUTODETECT
 Grand Espace IV	PARKING HELP	2.2 16v dCi 110kw (02-06)	AUTODETECT
 Grand Espace IV	PARKING HELP	2.2 16v dCi 110kw (06-..)	can AUTODETECT
 Grand Espace IV	PARKING HELP	2.2 16v dCi FAP 102kw (06-..)	AUTODETECT
 Grand Espace IV	PARKING HELP	2.2 16v dCi FAP 102kw (06-..)	can AUTODETECT
 Grand Espace IV	PARKING HELP	3.0 V6 24v dCi 120kw (02-06)	AUTODETECT
 Grand Espace IV	PARKING HELP	3.0 V6 24v dCi 120kw (06-..)	can AUTODETECT
 Grand Espace IV	PARKING HELP	3.0 V6 24v dCi 130kw (02-06)	AUTODETECT
 Grand Espace IV	PARKING HELP	3.5 V6 24v 177kw (02-06)	AUTODETECT
 Grand Espace IV	PARKING HELP	3.5 V6 24v 177kw (06-..)	AUTODETECT
 Grand Espace IV	PARKING HELP	3.5 V6 24v 177kw (06-..)	can AUTODETECT
 Grand Espace IV	SUPP HEATER/AUTO	1.9 dCi 85kw (02-06)	AUTODETECT
 Grand Espace IV	SUPP HEATER/AUTO	1.9 dCi 85kw (06-..)	AUTODETECT
 Grand Espace IV	SUPP HEATER/AUTO	1.9 dCi 88kw (02-06)	AUTODETECT
 Grand Espace IV	SUPP HEATER/AUTO	1.9 dCi 88kw (06-..)	AUTODETECT
 Grand Espace IV	SUPP HEATER/AUTO	2.0 16v 103kw (02-06)	AUTODETECT
 Grand Espace IV	SUPP HEATER/AUTO	2.0 16v 125kw (06-..)	AUTODETECT
 Grand Espace IV	SUPP HEATER/AUTO	2.0 16v dCi 110kw (06-..)	AUTODETECT
 Grand Espace IV	SUPP HEATER/AUTO	2.0 16v dCi 127kw (06-..)	AUTODETECT
 Grand Espace IV	SUPP HEATER/AUTO	2.0 16v dCi 96kw (06-..)	AUTODETECT
 Grand Espace IV	SUPP HEATER/AUTO	2.0 16v dCi FAP 110kw (06-..)	AUTODETECT
 Grand Espace IV	SUPP HEATER/AUTO	2.0 16v dCi FAP 127kw (06-..)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Grand Espace IV	SUPP HEATER/AUTO	2.0 16v T 121kw (02-06)	AUTODETECT
 Grand Espace IV	SUPP HEATER/AUTO	2.0 16v T 125kw (02-06)	AUTODETECT
 Grand Espace IV	SUPP HEATER/AUTO	2.2 16v dCi 102kw (02-06)	AUTODETECT
 Grand Espace IV	SUPP HEATER/AUTO	2.2 16v dCi 110kw (02-06)	AUTODETECT
 Grand Espace IV	SUPP HEATER/AUTO	2.2 16v dCi 110kw (06-..)	AUTODETECT
 Grand Espace IV	SUPP HEATER/AUTO	2.2 16v dCi FAP 102kw (06-..)	AUTODETECT
 Grand Espace IV	SUPP HEATER/AUTO	3.0 V6 24v dCi 120kw (02-06)	AUTODETECT
 Grand Espace IV	SUPP HEATER/AUTO	3.0 V6 24v dCi 120kw (06-..)	AUTODETECT
 Grand Espace IV	SUPP HEATER/AUTO	3.0 V6 24v dCi 130kw (02-06)	AUTODETECT
 Grand Espace IV	SUPP HEATER/AUTO	3.0 V6 24v dCi 133kw (02-06)	AUTODETECT
 Grand Espace IV	SUPP HEATER/AUTO	3.5 V6 24v 177kw (02-06)	AUTODETECT
 Grand Espace IV	SUPP HEATER/AUTO	3.5 V6 24v 177kw (06-..)	AUTODETECT
 Kangoo II	ABS	1.5 dCi 50kw (08-..)	BOSCH ABS 8.0
 Kangoo II	ABS	1.5 dCi 63kw (08-..)	BOSCH ABS 8.0
 Kangoo II	ABS	1.5 dCi 66kw (08-..)	BOSCH ABS 8.0
 Kangoo II	ABS	1.5 dCi 78kw (08-..)	BOSCH ABS 8.0
 Kangoo II	ABS	1.5 dCi FAP 76kw (08-..)	BOSCH ABS 8.0
 Kangoo II	ABS	1.6 16v 78kw (08-..)	BOSCH ABS 8.0
 Kangoo II	ABS	1.6 64kw (08-..)	BOSCH ABS 8.0
 Kangoo II	AIRBAG	1.5 dCi 50kw (08-..)	BOSCH AirBag AB9
 Kangoo II	AIRBAG	1.5 dCi 63kw (08-..)	BOSCH AirBag AB9
 Kangoo II	AIRBAG	1.5 dCi 66kw (08-..)	BOSCH AirBag AB9
 Kangoo II	AIRBAG	1.5 dCi 78kw (08-..)	BOSCH AirBag AB9
 Kangoo II	AIRBAG	1.5 dCi FAP 76kw (08-..)	BOSCH AirBag AB9
 Kangoo II	AIRBAG	1.6 16v 78kw (08-..)	BOSCH AirBag AB9
 Kangoo II	AIRBAG	1.6 64kw (08-..)	BOSCH AirBag AB9
 Kangoo II	AUTOM. TRANSMISSI	1.5 dCi 50kw	AUTODETECT
 Kangoo II	AUTOM. TRANSMISSI	1.5 dCi 63kw	AUTODETECT
 Kangoo II	AUTOM. TRANSMISSI	1.5 dCi 66kw	AUTODETECT
 Kangoo II	AUTOM. TRANSMISSI	1.5 dCi 78kw	AUTODETECT
 Kangoo II	AUTOM. TRANSMISSI	1.5 dCi FAP 76kw	AUTODETECT
 Kangoo II	AUTOM. TRANSMISSI	1.6 16v 78kw	AUTODETECT
 Kangoo II	AUTOM. TRANSMISSI	1.6 64kw	AUTODETECT
 Kangoo II	CHASSIS NETWORK	1.5 dCi 50kw (08-..)	Body Computer UCH
 Kangoo II	CHASSIS NETWORK	1.5 dCi 50kw (08-..)	Body Computer UPC
 Kangoo II	CHASSIS NETWORK	1.5 dCi 63kw (08-..)	Body Computer UCH
 Kangoo II	CHASSIS NETWORK	1.5 dCi 63kw (08-..)	Body Computer UPC
 Kangoo II	CHASSIS NETWORK	1.5 dCi 66kw (08-..)	Body Computer UCH
 Kangoo II	CHASSIS NETWORK	1.5 dCi 66kw (08-..)	Body Computer UPC
 Kangoo II	CHASSIS NETWORK	1.5 dCi 78kw (08-..)	Body Computer UCH
 Kangoo II	CHASSIS NETWORK	1.5 dCi 78kw (08-..)	Body Computer UPC
 Kangoo II	CHASSIS NETWORK	1.5 dCi FAP 76kw (08-..)	Body Computer UCH
 Kangoo II	CHASSIS NETWORK	1.5 dCi FAP 76kw (08-..)	Body Computer UPC
 Kangoo II	CHASSIS NETWORK	1.6 16v 78kw (08-..)	Body Computer UCH
 Kangoo II	CHASSIS NETWORK	1.6 16v 78kw (08-..)	Body Computer UPC
 Kangoo II	CHASSIS NETWORK	1.6 64kw (08-..)	Body Computer UCH
 Kangoo II	CHASSIS NETWORK	1.6 64kw (08-..)	Body Computer UPC
 Kangoo II	DASHBOARD	1.5 dCi 50kw	AUTODETECT
 Kangoo II	DASHBOARD	1.5 dCi 50kw (08-..)	SAGEM Kombi
 Kangoo II	DASHBOARD	1.5 dCi 63kw	AUTODETECT
 Kangoo II	DASHBOARD	1.5 dCi 63kw (08-..)	SAGEM Kombi
 Kangoo II	DASHBOARD	1.5 dCi 66kw	AUTODETECT
 Kangoo II	DASHBOARD	1.5 dCi 66kw (08-..)	SAGEM Kombi
 Kangoo II	DASHBOARD	1.5 dCi 78kw	AUTODETECT
 Kangoo II	DASHBOARD	1.5 dCi 78kw (08-..)	SAGEM Kombi
 Kangoo II	DASHBOARD	1.5 dCi FAP 76kw	AUTODETECT
 Kangoo II	DASHBOARD	1.5 dCi FAP 76kw (08-..)	SAGEM Kombi
 Kangoo II	DASHBOARD	1.6 16v 78kw	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kangoo II	DASHBOARD	1.6 16v 78kw (08-..)	SAGEM Kombi
 Kangoo II	DASHBOARD	1.6 64kw	AUTODETECT
 Kangoo II	DASHBOARD	1.6 64kw (08-..)	SAGEM Kombi
 Kangoo II	ELECTRIC STEERING	1.5 dCi 50kw (08-..)	KOYO EPS
 Kangoo II	ELECTRIC STEERING	1.5 dCi 66kw (08-..)	KOYO EPS
 Kangoo II	ELECTRIC STEERING	1.5 dCi 78kw (08-..)	KOYO EPS
 Kangoo II	ELECTRIC STEERING	1.5 dCi FAP 76kw (08-..)	KOYO EPS
 Kangoo II	ELECTRIC STEERING	1.6 16v 78kw (08-..)	KOYO EPS
 Kangoo II	ELECTRIC STEERING	1.6 64kw (08-..)	KOYO EPS
 Kangoo II	ENGINE MANAGEME	1.5 dCi 50kw	AUTODETECT
 Kangoo II	ENGINE MANAGEME	1.5 dCi 63kw	AUTODETECT
 Kangoo II	ENGINE MANAGEME	1.5 dCi 66kw	AUTODETECT
 Kangoo II	ENGINE MANAGEME	1.5 dCi 66kw K9K-808 (08-..)	DELPHI EDC Common Rail
 Kangoo II	ENGINE MANAGEME	1.5 dCi 78kw	AUTODETECT
 Kangoo II	ENGINE MANAGEME	1.5 dCi 78kw K9K-804 (08-..)	DELPHI EDC Common Rail
 Kangoo II	ENGINE MANAGEME	1.5 dCi FAP 76kw	AUTODETECT
 Kangoo II	ENGINE MANAGEME	1.6 16v 78kw	AUTODETECT
 Kangoo II	ENGINE MANAGEME	1.6 64kw	AUTODETECT
 Kangoo II	MAINTENANCE	1.5 dCi 50kw (08-..)	KOYO EPS
 Kangoo II	MAINTENANCE	1.5 dCi 50kw (08-..)	KOYO EPS
 Kangoo II	MAINTENANCE	1.5 dCi 50kw (08-..)	MANUAL
 Kangoo II	MAINTENANCE	1.5 dCi 63kw (08-..)	MANUAL
 Kangoo II	MAINTENANCE	1.5 dCi 66kw (08-..)	KOYO EPS
 Kangoo II	MAINTENANCE	1.5 dCi 66kw (08-..)	KOYO EPS
 Kangoo II	MAINTENANCE	1.5 dCi 66kw (08-..)	MANUAL
 Kangoo II	MAINTENANCE	1.5 dCi 78kw (08-..)	KOYO EPS
 Kangoo II	MAINTENANCE	1.5 dCi 78kw (08-..)	KOYO EPS
 Kangoo II	MAINTENANCE	1.5 dCi 78kw (08-..)	MANUAL
 Kangoo II	MAINTENANCE	1.5 dCi FAP 76kw (08-..)	KOYO EPS
 Kangoo II	MAINTENANCE	1.5 dCi FAP 76kw (08-..)	KOYO EPS
 Kangoo II	MAINTENANCE	1.5 dCi FAP 76kw (08-..)	MANUAL
 Kangoo II	MAINTENANCE	1.6 16v 78kw (08-..)	KOYO EPS
 Kangoo II	MAINTENANCE	1.6 16v 78kw (08-..)	KOYO EPS
 Kangoo II	MAINTENANCE	1.6 16v 78kw (08-..)	MANUAL
 Kangoo II	MAINTENANCE	1.6 64kw (08-..)	KOYO EPS
 Kangoo II	MAINTENANCE	1.6 64kw (08-..)	KOYO EPS
 Kangoo II	MAINTENANCE	1.6 64kw (08-..)	MANUAL
 Kangoo II	SERVICE LIGHT RES	1.5 dCi 50kw (08-..)	MANUAL
 Kangoo II	SERVICE LIGHT RES	1.5 dCi 63kw (08-..)	MANUAL
 Kangoo II	SERVICE LIGHT RES	1.5 dCi 66kw (08-..)	MANUAL
 Kangoo II	SERVICE LIGHT RES	1.5 dCi 78kw (08-..)	MANUAL
 Kangoo II	SERVICE LIGHT RES	1.5 dCi FAP 76kw (08-..)	MANUAL
 Kangoo II	SERVICE LIGHT RES	1.6 16v 78kw (08-..)	MANUAL
 Kangoo II	SERVICE LIGHT RES	1.6 64kw (08-..)	MANUAL
 Kangoo Z.E./Stop&Start Ph	ABS	ELEC. 2.4	AUTODETECT
 Kangoo Z.E./Stop&Start Ph	AIRBAG	ELEC. 2.4	AUTODETECT
 Kangoo Z.E./Stop&Start Ph	CHASSIS NETWORK	ELEC. 2.4	UCC AUTODETECT
 Kangoo Z.E./Stop&Start Ph	CHASSIS NETWORK	ELEC. 2.4	UCH AUTODETECT
 Kangoo Z.E./Stop&Start Ph	CHASSIS NETWORK	ELEC. 2.4	UPC AUTODETECT
 Kangoo Z.E./Stop&Start Ph	DASHBOARD	ELEC. 2.4	AUTODETECT
 Kangoo Z.E./Stop&Start Ph	ELECTRIC STEERING	ELEC. 2.4	AUTODETECT
 Kangoo Z.E./Stop&Start Ph	ENGINE MANAGEME	ELEC. 2.4	AUTODETECT
 Kangoo Z.E./Stop&Start Ph	PARKING HELP	ELEC. 2.4	AUTODETECT
 Kangoo Z.E./Stop&Start Ph	PARKING HELP	ELEC. 2.4	can AUTODETECT
 Kangoo Z.E./Stop&Start Ph	RADIO / CD	ELEC. 2.4	AUTODETECT
 Kangoo Z.E./Stop&Start Ph	STEERING WHEEL E	ELEC. 2.4	AUTODETECT
 Kangoo Z.E./Stop&Start Ph	SUPP HEATER/AUTO	ELEC. 2.4	AUTODETECT
 Kangoo Z.E./Stop&Start Ph	VISUAL./TELEMATIC	ELEC. 2.4	USB AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kangoo Z.E.	ABS + TRACT. CONT	ELEC. 2.4	ABS AUTODETECT
 Kangoo Z.E.	AIRBAG	ELEC. 2.4	AirBag AUTODETECT
 Kangoo Z.E.	CHASSIS NETWORK	ELEC. 2.4	UCC AUTODETECT
 Kangoo Z.E.	CHASSIS NETWORK	ELEC. 2.4	UCH AUTODETECT
 Kangoo Z.E.	CHASSIS NETWORK	ELEC. 2.4	UPC AUTODETECT
 Kangoo Z.E.	DASHBOARD	ELEC. 2.4	AUTODETECT
 Kangoo Z.E.	ELECTRIC STEERING	ELEC. 2.4	AUTODETECT
 Kangoo Z.E.	PARKING HELP	ELEC. 2.4	AUTODETECT
 Kangoo Z.E.	RADIO / CD	ELEC. 2.4	AUTODETECT
 Kangoo Z.E.	SUPP HEATER/AUTO	ELEC. 2.4	AUTODETECT
 Kangoo Z.E.	VISUAL./TELEMATIC	ELEC. 2.4	BLUETOOTH AUTODETECT
 Kangoo Z.E.	VISUAL./TELEMATIC	ELEC. 2.4	USB AUTODETECT
 Kangoo Z.E.	VISUAL./TELEMATIC	ELEC. 2.4	USB-MULTIMEDIA AUTODETECT
 Kangoo	ABS	1.2 16v 55kw	BOSCH ABS 5.3
 Kangoo	ABS	1.2 16v 55kw	BOSCH ABS 5.3 T
 Kangoo	ABS	1.2 44kw	BOSCH ABS 5.3
 Kangoo	ABS	1.2 44kw	BOSCH ABS 5.3 T
 Kangoo	ABS	1.2 GPL 44kw	BOSCH ABS 5.3
 Kangoo	ABS	1.2 GPL 44kw	BOSCH ABS 5.3 T
 Kangoo	ABS	1.4 55kw	BOSCH ABS 5.3
 Kangoo	ABS	1.4 55kw	BOSCH ABS 5.3 T
 Kangoo	ABS	1.5 dCi 42kw	BOSCH ABS 5.3
 Kangoo	ABS	1.5 dCi 42kw	BOSCH ABS 5.3 T
 Kangoo	ABS	1.5 dCi 45kw	BOSCH ABS 5.3
 Kangoo	ABS	1.5 dCi 45kw	BOSCH ABS 5.3 T
 Kangoo	ABS	1.5 dCi 48kw	BOSCH ABS 5.3
 Kangoo	ABS	1.5 dCi 48kw	BOSCH ABS 5.3 T
 Kangoo	ABS	1.5 dCi 50kw	BOSCH ABS 5.3
 Kangoo	ABS	1.5 dCi 50kw	BOSCH ABS 5.3 T
 Kangoo	ABS	1.5 dCi 60kw	BOSCH ABS 5.3
 Kangoo	ABS	1.5 dCi 60kw	BOSCH ABS 5.3 T
 Kangoo	ABS	1.5 dCi 62kw	BOSCH ABS 5.3
 Kangoo	ABS	1.5 dCi 62kw	BOSCH ABS 5.3 T
 Kangoo	ABS	1.6 16v 70kw	BOSCH ABS 5.3
 Kangoo	ABS	1.6 16v 70kw	BOSCH ABS 5.3 T
 Kangoo	ABS	1.6 16v GNV 60kw	BOSCH ABS 5.3
 Kangoo	ABS	1.6 16v GNV 60kw	BOSCH ABS 5.3 T
 Kangoo	ABS	1.9 D 40kw	BOSCH ABS 5.3
 Kangoo	ABS	1.9 D 40kw	BOSCH ABS 5.3 T
 Kangoo	ABS	1.9 D 48kw	BOSCH ABS 5.3
 Kangoo	ABS	1.9 D 48kw	BOSCH ABS 5.3 T
 Kangoo	ABS	1.9 dCi 59kw	BOSCH ABS 5.3
 Kangoo	ABS	1.9 dCi 59kw	BOSCH ABS 5.3 T
 Kangoo	ABS	1.9 dCi 62kw	BOSCH ABS 5.3
 Kangoo	ABS	1.9 dCi 62kw	BOSCH ABS 5.3 T
 Kangoo	ABS	1.9 dTi 59kw	BOSCH ABS 5.3
 Kangoo	ABS	1.9 dTi 59kw	BOSCH ABS 5.3 T
 Kangoo	AIRBAG	1.2 16v 55kw	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.2 16v 55kw	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.2 16v 55kw	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.2 16v 55kw	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.2 44kw	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.2 44kw	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.2 44kw	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.2 44kw	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.2 GPL 44kw	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.2 GPL 44kw	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.2 GPL 44kw	SIEMENS - Autoliv AirBag AC6

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kangoo	AIRBAG	1.2 GPL 44kw	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.4 55kw	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.4 55kw	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.4 55kw	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.4 55kw	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.5 dCi 42kw	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.5 dCi 42kw	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.5 dCi 42kw	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.5 dCi 42kw	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.5 dCi 45kw	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.5 dCi 45kw	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.5 dCi 45kw	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.5 dCi 45kw	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.5 dCi 48kw	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.5 dCi 48kw	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.5 dCi 48kw	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.5 dCi 48kw	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.5 dCi 50kw	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.5 dCi 50kw	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.5 dCi 50kw	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.5 dCi 50kw	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.5 dCi 60kw	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.5 dCi 60kw	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.5 dCi 60kw	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.5 dCi 60kw	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.5 dCi 62kw	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.5 dCi 62kw	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.5 dCi 62kw	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.5 dCi 62kw	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.6 16v 70kw	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.6 16v 70kw	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.6 16v 70kw	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.6 16v 70kw	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.6 16v GNV 60kw	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.6 16v GNV 60kw	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.6 16v GNV 60kw	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.6 16v GNV 60kw	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.9 D 40kw	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.9 D 40kw	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.9 D 40kw	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.9 D 40kw	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.9 D 48kw	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.9 D 48kw	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.9 D 48kw	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.9 D 48kw	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.9 dCi 59kw	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.9 dCi 59kw	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.9 dCi 59kw	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.9 dCi 59kw	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.9 dCi 62kw	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.9 dCi 62kw	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.9 dCi 62kw	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.9 dCi 62kw	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.9 dTi 59kw	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.9 dTi 59kw	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.9 dTi 59kw	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.9 dTi 59kw	SIEMENS - Autoliv AirBag EC5
 Kangoo	DIESEL MANAGEMEN	1.9 D 40kw F8Q-662	SIEMENS Diesel DCU3R

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kangoo	DIESEL MANAGEMEN	1.9 D 40kw F8Q-662 (...99)	LUCAS Diesel DPCN1
 Kangoo	DIESEL MANAGEMEN	1.9 D 48kw F8Q-630	SIEMENS Diesel DCU3R
 Kangoo	DIESEL MANAGEMEN	1.9 D 48kw F8Q-630 (...99)	LUCAS Diesel DPCN1
 Kangoo	DIESEL MANAGEMEN	1.9 D 48kw F8Q-632	SIEMENS Diesel DCU3R
 Kangoo	DIESEL MANAGEMEN	1.9 D 48kw F8Q-632 (...99)	LUCAS Diesel DPCN1
 Kangoo	DIESEL MANAGEMEN	1.9 D 48kw F8Q-660	SIEMENS Diesel DCU3R
 Kangoo	DIESEL MANAGEMEN	1.9 D 48kw F8Q-660 (...99)	LUCAS Diesel DPCN1
 Kangoo	DIESEL MANAGEMEN	1.9 dTi 59kw F9Q-780 (...01)	BOSCH MSA 15
 Kangoo	DIESEL MANAGEMEN	1.9 dTi 59kw F9Q-782 (...01)	BOSCH MSA 15
 Kangoo	ENGINE MANAGEME	1.2 16v 55kw	SIEMENS Sirius 32 AUTODETECT
 Kangoo	ENGINE MANAGEME	1.2 16v 55kw D4F-712	Marelli 5NR
 Kangoo	ENGINE MANAGEME	1.2 16v 55kw D4F-712	SIEMENS Sirius 32 MUX AUTODETECT
 Kangoo	ENGINE MANAGEME	1.2 44kw	SIEMENS Sirius 32 AUTODETECT
 Kangoo	ENGINE MANAGEME	1.2 44kw	SIEMENS Sirius 32 MUX AUTODETECT
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-726	SAGEM SAFIR MPI
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-726	SAGEM SAFIR MPI
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-726	SAGEM SAFIR MPI
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-726	SAGEM SAFIR MPI
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-726	SAGEM SAFIR MPI
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-726	SAGEM SAFIR MPI
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-726	SAGEM SAFIR MPI
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-726	SIEMENS Sirius 32
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-746	SAGEM SAFIR MPI
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-746	SAGEM SAFIR MPI
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-746	SAGEM SAFIR MPI
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-746	SAGEM SAFIR MPI
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-746	SAGEM SAFIR MPI
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-746	SAGEM SAFIR MPI
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-746	SAGEM SAFIR MPI
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-746	SAGEM SAFIR MPI
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-746	SAGEM SAFIR MPI
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-746	SIEMENS Sirius 32
 Kangoo	ENGINE MANAGEME	1.2 GPL 44kw	SIEMENS Sirius 32 AUTODETECT
 Kangoo	ENGINE MANAGEME	1.2 GPL 44kw	SIEMENS Sirius 32 MUX AUTODETECT
 Kangoo	ENGINE MANAGEME	1.4 55kw	SIEMENS Sirius 32 AUTODETECT
 Kangoo	ENGINE MANAGEME	1.4 55kw	SIEMENS Sirius 32 MUX AUTODETECT
 Kangoo	ENGINE MANAGEME	1.4 55kw E7J-634	SIEMENS FENIX 5
 Kangoo	ENGINE MANAGEME	1.4 55kw E7J-634	SIEMENS Sirius 32
 Kangoo	ENGINE MANAGEME	1.4 55kw E7J-634 (01-..)	EOBD
 Kangoo	ENGINE MANAGEME	1.4 55kw E7J-635	SIEMENS FENIX 5
 Kangoo	ENGINE MANAGEME	1.4 55kw E7J-635	SIEMENS Sirius 32
 Kangoo	ENGINE MANAGEME	1.4 55kw E7J-635 (01-..)	EOBD
 Kangoo	ENGINE MANAGEME	1.4 55kw E7J-780	SIEMENS FENIX 5
 Kangoo	ENGINE MANAGEME	1.4 55kw E7J-780	SIEMENS Sirius 32
 Kangoo	ENGINE MANAGEME	1.4 55kw E7J-780 (01-..)	EOBD
 Kangoo	ENGINE MANAGEME	1.5 dCi 42kw K9K-710	DELPHI LUCAS LVCR Common Rail
 Kangoo	ENGINE MANAGEME	1.5 dCi 42kw K9K-710 (04-..)	SIEMENS EDC SID
 Kangoo	ENGINE MANAGEME	1.5 dCi 42kw K9K-710 (05-..)	SIEMENS EDC SID
 Kangoo	ENGINE MANAGEME	1.5 dCi 42kw K9K-710 (06-..)	SIEMENS EDC SID 301 Common Rail
 Kangoo	ENGINE MANAGEME	1.5 dCi 45kw K9K-716 (04-..)	EOBD
 Kangoo	ENGINE MANAGEME	1.5 dCi 48kw K9K-700	DELPHI LUCAS LVCR Common Rail
 Kangoo	ENGINE MANAGEME	1.5 dCi 48kw K9K-700 (04-..)	SIEMENS EDC SID
 Kangoo	ENGINE MANAGEME	1.5 dCi 48kw K9K-700 (05-..)	SIEMENS EDC SID
 Kangoo	ENGINE MANAGEME	1.5 dCi 48kw K9K-700 (06-..)	SIEMENS EDC SID 301 Common Rail
 Kangoo	ENGINE MANAGEME	1.5 dCi 48kw K9K-704	DELPHI LUCAS LVCR Common Rail
 Kangoo	ENGINE MANAGEME	1.5 dCi 48kw K9K-704 (04-..)	SIEMENS EDC SID
 Kangoo	ENGINE MANAGEME	1.5 dCi 48kw K9K-704 (05-..)	SIEMENS EDC SID
 Kangoo	ENGINE MANAGEME	1.5 dCi 48kw K9K-704 (06-..)	SIEMENS EDC SID 301 Common Rail

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kangoo	ENGINE MANAGEME	1.5 dCi 50kw K9K-714 (04-..)	EOBD
 Kangoo	ENGINE MANAGEME	1.5 dCi 60kw K9K-702	DELPHI LUCAS LVCR Common Rail
 Kangoo	ENGINE MANAGEME	1.5 dCi 60kw K9K-702 (04-..)	SIEMENS EDC SID
 Kangoo	ENGINE MANAGEME	1.5 dCi 60kw K9K-702 (05-..)	SIEMENS EDC SID
 Kangoo	ENGINE MANAGEME	1.5 dCi 60kw K9K-702 (06-..)	SIEMENS EDC SID 301 Common Rail
 Kangoo	ENGINE MANAGEME	1.5 dCi 60kw K9K-706	DELPHI LUCAS LVCR Common Rail
 Kangoo	ENGINE MANAGEME	1.5 dCi 60kw K9K-706 (04-..)	SIEMENS EDC SID
 Kangoo	ENGINE MANAGEME	1.5 dCi 60kw K9K-706 (05-..)	SIEMENS EDC SID
 Kangoo	ENGINE MANAGEME	1.5 dCi 60kw K9K-706 (06-..)	SIEMENS EDC SID 301 Common Rail
 Kangoo	ENGINE MANAGEME	1.5 dCi 62kw K9K-718 (04-..)	EOBD
 Kangoo	ENGINE MANAGEME	1.6 16v 70kw	SIEMENS Sirius 32 AUTODETECT
 Kangoo	ENGINE MANAGEME	1.6 16v 70kw	SIEMENS Sirius 32 MUX AUTODETECT
 Kangoo	ENGINE MANAGEME	1.6 16v 70kw K4M-750	SIEMENS Sirius 32
 Kangoo	ENGINE MANAGEME	1.6 16v GNV 60kw K4M-754	EOBD
 Kangoo	ENGINE MANAGEME	1.9 D 40kw F8Q-662	LUCAS Diesel DCU3R
 Kangoo	ENGINE MANAGEME	1.9 D 48kw F8Q-630	LUCAS Diesel DCU3R
 Kangoo	ENGINE MANAGEME	1.9 D 48kw F8Q-632	LUCAS Diesel DCU3R
 Kangoo	ENGINE MANAGEME	1.9 D 48kw F8Q-660	LUCAS Diesel DCU3R
 Kangoo	ENGINE MANAGEME	1.9 dCi 59kw F9Q-790 (...00)	BOSCH EDC 15 C3 Common Rail
 Kangoo	ENGINE MANAGEME	1.9 dCi 59kw F9Q-790 (01-..)	BOSCH EDC 15 C3 Common Rail
 Kangoo	ENGINE MANAGEME	1.9 dCi 62kw K4M-754 (04-..)	EOBD
 Kangoo	IMMOBILIZER	1.2 16v 55kw	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.2 44kw	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.2 GPL 44kw	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.4 55kw	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.5 dCi 42kw	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.5 dCi 45kw	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.5 dCi 48kw	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.5 dCi 50kw	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.5 dCi 60kw	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.5 dCi 62kw	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.6 16v 70kw	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.6 16v GNV 60kw	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.9 D 40kw	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.9 D 48kw	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.9 dCi 59kw	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.9 dCi 62kw	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.9 dTi 59kw	Immobilizer Body Computer
 Kangoo	MAINTENANCE	1.5 dCi 42kw K9K-710 (04-..)	SIEMENS EDC SID
 Kangoo	MAINTENANCE	1.5 dCi 42kw K9K-710 (05-..)	SIEMENS EDC SID
 Kangoo	MAINTENANCE	1.5 dCi 42kw K9K-710 (05-..)	SIEMENS EDC SID
 Kangoo	MAINTENANCE	1.5 dCi 42kw K9K-710 (06-..)	SIEMENS EDC SID 301 Common Rail
 Kangoo	MAINTENANCE	1.5 dCi 48kw K9K-700 (04-..)	SIEMENS EDC SID
 Kangoo	MAINTENANCE	1.5 dCi 48kw K9K-700 (05-..)	SIEMENS EDC SID
 Kangoo	MAINTENANCE	1.5 dCi 48kw K9K-700 (05-..)	SIEMENS EDC SID
 Kangoo	MAINTENANCE	1.5 dCi 48kw K9K-700 (06-..)	SIEMENS EDC SID 301 Common Rail
 Kangoo	MAINTENANCE	1.5 dCi 48kw K9K-704 (04-..)	SIEMENS EDC SID
 Kangoo	MAINTENANCE	1.5 dCi 48kw K9K-704 (05-..)	SIEMENS EDC SID
 Kangoo	MAINTENANCE	1.5 dCi 48kw K9K-704 (05-..)	SIEMENS EDC SID
 Kangoo	MAINTENANCE	1.5 dCi 48kw K9K-704 (06-..)	SIEMENS EDC SID 301 Common Rail
 Kangoo	MAINTENANCE	1.5 dCi 60kw K9K-702 (04-..)	SIEMENS EDC SID
 Kangoo	MAINTENANCE	1.5 dCi 60kw K9K-702 (05-..)	SIEMENS EDC SID
 Kangoo	MAINTENANCE	1.5 dCi 60kw K9K-702 (05-..)	SIEMENS EDC SID
 Kangoo	MAINTENANCE	1.5 dCi 60kw K9K-702 (06-..)	SIEMENS EDC SID 301 Common Rail
 Kangoo	MAINTENANCE	1.5 dCi 60kw K9K-706 (04-..)	SIEMENS EDC SID
 Kangoo	MAINTENANCE	1.5 dCi 60kw K9K-706 (05-..)	SIEMENS EDC SID
 Kangoo	MAINTENANCE	1.5 dCi 60kw K9K-706 (05-..)	SIEMENS EDC SID
 Kangoo	MAINTENANCE	1.5 dCi 60kw K9K-706 (06-..)	SIEMENS EDC SID 301 Common Rail

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Koleos QM5	AUTOM. TRANSMISSI	2.0 dCi 16v 110kw (11-..)	AUTODETECT
 Koleos QM5	AUTOM. TRANSMISSI	2.0 dCi 16v 125Kw (11-..)	AUTODETECT
 Koleos QM5	DASHBOARD	2.0 dCi 16v 110kw (11-..)	AUTODETECT
 Koleos QM5	DASHBOARD	2.0 dCi 16v 125Kw (11-..)	AUTODETECT
 Koleos QM5	ENGINE MANAGEME	2.0 dCi 16v 110kw (11-..)	AUTODETECT
 Koleos QM5	ENGINE MANAGEME	2.0 dCi 16v 125Kw (11-..)	AUTODETECT
 Koleos QM5	HEADLIGHT LEVEL	2.0 dCi 16v 110kw (11-..)	AUTODETECT
 Koleos QM5	HEADLIGHT LEVEL	2.0 dCi 16v 125Kw (11-..)	AUTODETECT
 Laguna II ph2	ABS	1.6 16v 82kw (05-07)	AUTODETECT
 Laguna II ph2	ABS	1.6 16v GPL 79kw (05-07)	AUTODETECT
 Laguna II ph2	ABS	1.8 16v 88kw (05-07)	AUTODETECT
 Laguna II ph2	ABS	1.9 dCi 68kw (05-07)	AUTODETECT
 Laguna II ph2	ABS	1.9 dCi 74kw (05-07)	AUTODETECT
 Laguna II ph2	ABS	1.9 dCi 81kw (05-07)	AUTODETECT
 Laguna II ph2	ABS	1.9 dCi 85kw (05-07)	AUTODETECT
 Laguna II ph2	ABS	1.9 dCi 88kw (05-07)	AUTODETECT
 Laguna II ph2	ABS	1.9 dCi 96kw (05-07)	AUTODETECT
 Laguna II ph2	ABS	1.9 dCi FAP 81kw (05-07)	AUTODETECT
 Laguna II ph2	ABS	1.9 dCi FAP 85kw (05-07)	AUTODETECT
 Laguna II ph2	ABS	1.9 dCi FAP 92kw (05-07)	AUTODETECT
 Laguna II ph2	ABS	1.9 dCi FAP 96kw (05-07)	AUTODETECT
 Laguna II ph2	ABS	2.0 16v 103kw (05-07)	AUTODETECT
 Laguna II ph2	ABS	2.0 16v 99kw (05-07)	AUTODETECT
 Laguna II ph2	ABS	2.0 16v dCi 110kw (05-07)	AUTODETECT
 Laguna II ph2	ABS	2.0 16v dCi FAP 127kw (05-07)	AUTODETECT
 Laguna II ph2	ABS	2.0 16v T 121kw (05-07)	AUTODETECT
 Laguna II ph2	ABS	2.0 16v T 125kw (05-07)	AUTODETECT
 Laguna II ph2	ABS	2.0 16v T 150kw (05-07)	AUTODETECT
 Laguna II ph2	ABS	2.2 16v dCi 102kw (05-07)	AUTODETECT
 Laguna II ph2	ABS	2.2 16v dCi 110kw (05-07)	AUTODETECT
 Laguna II ph2	ABS	2.2 16v dCi FAP 102kw (05-07)	AUTODETECT
 Laguna II ph2	ABS	3.0 V6 24v 152kw (05-07)	AUTODETECT
 Laguna II ph2	AIRBAG	1.6 16v 82kw (05-07)	AUTODETECT
 Laguna II ph2	AIRBAG	1.6 16v GPL 79kw (05-07)	AUTODETECT
 Laguna II ph2	AIRBAG	1.8 16v 88kw (05-07)	AUTODETECT
 Laguna II ph2	AIRBAG	1.9 dCi 68kw (05-07)	AUTODETECT
 Laguna II ph2	AIRBAG	1.9 dCi 74kw (05-07)	AUTODETECT
 Laguna II ph2	AIRBAG	1.9 dCi 81kw (05-07)	AUTODETECT
 Laguna II ph2	AIRBAG	1.9 dCi 85kw (05-07)	AUTODETECT
 Laguna II ph2	AIRBAG	1.9 dCi 88kw (05-07)	AUTODETECT
 Laguna II ph2	AIRBAG	1.9 dCi FAP 81kw (05-07)	AUTODETECT
 Laguna II ph2	AIRBAG	1.9 dCi FAP 85kw (05-07)	AUTODETECT
 Laguna II ph2	AIRBAG	1.9 dCi FAP 92kw (05-07)	AUTODETECT
 Laguna II ph2	AIRBAG	1.9 dCi FAP 96kw (05-07)	AUTODETECT
 Laguna II ph2	AIRBAG	2.0 16v 103kw (05-07)	AUTODETECT
 Laguna II ph2	AIRBAG	2.0 16v 99kw (05-07)	AUTODETECT
 Laguna II ph2	AIRBAG	2.0 16v dCi 110kw (05-07)	AUTODETECT
 Laguna II ph2	AIRBAG	2.0 16v dCi FAP 127kw (05-07)	AUTODETECT
 Laguna II ph2	AIRBAG	2.0 16v T 121kw (05-07)	AUTODETECT
 Laguna II ph2	AIRBAG	2.0 16v T 125kw (05-07)	AUTODETECT
 Laguna II ph2	AIRBAG	2.0 16v T 150kw (05-07)	AUTODETECT
 Laguna II ph2	AIRBAG	2.2 16v dCi 102kw (05-07)	AUTODETECT
 Laguna II ph2	AIRBAG	2.2 16v dCi 110kw (05-07)	AUTODETECT
 Laguna II ph2	AIRBAG	2.2 16v dCi FAP 102kw (05-07)	AUTODETECT
 Laguna II ph2	AIRBAG	3.0 V6 24v 152kw (05-07)	AUTODETECT
 Laguna II ph2	AUTOM. TRANSMISSI	1.6 16v 82kw (05-07)	AUTODETECT
 Laguna II ph2	AUTOM. TRANSMISSI	1.6 16v GPL 79kw (05-07)	AUTODETECT
 Laguna II ph2	AUTOM. TRANSMISSI	1.8 16v 88kw (05-07)	AUTODETECT

Systems supported by ECUREADER / ECUDECODER (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Laguna II ph2	AUTOM. TRANSMISSI	1.9 dCi 68kw (05-07)	AUTODETECT
 Laguna II ph2	AUTOM. TRANSMISSI	1.9 dCi 74kw (05-07)	AUTODETECT
 Laguna II ph2	AUTOM. TRANSMISSI	1.9 dCi 81kw (05-07)	AUTODETECT
 Laguna II ph2	AUTOM. TRANSMISSI	1.9 dCi 85kw (05-07)	AUTODETECT
 Laguna II ph2	AUTOM. TRANSMISSI	1.9 dCi 88kw (05-07)	AUTODETECT
 Laguna II ph2	AUTOM. TRANSMISSI	1.9 dCi 96kw (05-07)	AUTODETECT
 Laguna II ph2	AUTOM. TRANSMISSI	1.9 dCi FAP 81kw (05-07)	AUTODETECT
 Laguna II ph2	AUTOM. TRANSMISSI	1.9 dCi FAP 85kw (05-07)	AUTODETECT
 Laguna II ph2	AUTOM. TRANSMISSI	1.9 dCi FAP 92kw (05-07)	AUTODETECT
 Laguna II ph2	AUTOM. TRANSMISSI	1.9 dCi FAP 96kw (05-07)	AUTODETECT
 Laguna II ph2	AUTOM. TRANSMISSI	2.0 16v 103kw (05-07)	AUTODETECT
 Laguna II ph2	AUTOM. TRANSMISSI	2.0 16v 99kw (05-07)	AUTODETECT
 Laguna II ph2	AUTOM. TRANSMISSI	2.0 16v dCi 110kw (05-07)	AUTODETECT
 Laguna II ph2	AUTOM. TRANSMISSI	2.0 16v dCi FAP 127kw (05-07)	AUTODETECT
 Laguna II ph2	AUTOM. TRANSMISSI	2.0 16v T 121kw (05-07)	AUTODETECT
 Laguna II ph2	AUTOM. TRANSMISSI	2.0 16v T 125kw (05-07)	AUTODETECT
 Laguna II ph2	AUTOM. TRANSMISSI	2.0 16v T 150kw (05-07)	AUTODETECT
 Laguna II ph2	AUTOM. TRANSMISSI	2.2 16v dCi 102kw (05-07)	AUTODETECT
 Laguna II ph2	AUTOM. TRANSMISSI	2.2 16v dCi 110kw (05-07)	AUTODETECT
 Laguna II ph2	AUTOM. TRANSMISSI	2.2 16v dCi FAP 102kw (05-07)	AUTODETECT
 Laguna II ph2	AUTOM. TRANSMISSI	3.0 V6 24v 152kw (05-07)	AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	1.6 16v 82kw (05-07)	UCC AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	1.6 16v 82kw (05-07)	UCH AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	1.6 16v GPL 79kw (05-07)	UCC AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	1.6 16v GPL 79kw (05-07)	UCH AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	1.8 16v 88kw (05-07)	UCC AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	1.8 16v 88kw (05-07)	UCH AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	1.9 dCi 68kw (05-07)	UCC AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	1.9 dCi 68kw (05-07)	UCH AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	1.9 dCi 74kw (05-07)	UCC AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	1.9 dCi 74kw (05-07)	UCH AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	1.9 dCi 81kw (05-07)	UCC AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	1.9 dCi 81kw (05-07)	UCH AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	1.9 dCi 85kw (05-07)	UCC AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	1.9 dCi 85kw (05-07)	UCH AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	1.9 dCi 88kw (05-07)	UCC AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	1.9 dCi 88kw (05-07)	UCH AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	1.9 dCi 96kw (05-07)	UCC AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	1.9 dCi 96kw (05-07)	UCH AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	1.9 dCi FAP 81kw (05-07)	UCC AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	1.9 dCi FAP 81kw (05-07)	UCH AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	1.9 dCi FAP 85kw (05-07)	UCC AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	1.9 dCi FAP 85kw (05-07)	UCH AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	1.9 dCi FAP 92kw (05-07)	UCC AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	1.9 dCi FAP 92kw (05-07)	UCH AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	1.9 dCi FAP 96kw (05-07)	UCC AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	1.9 dCi FAP 96kw (05-07)	UCH AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	2.0 16v 103kw (05-07)	UCC AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	2.0 16v 103kw (05-07)	UCH AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	2.0 16v 99kw (05-07)	UCC AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	2.0 16v 99kw (05-07)	UCH AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	2.0 16v dCi 110kw (05-07)	UCC AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	2.0 16v dCi 110kw (05-07)	UCH AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	2.0 16v dCi FAP 127kw (05-07)	UCC AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	2.0 16v dCi FAP 127kw (05-07)	UCH AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	2.0 16v T 121kw (05-07)	UCC AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	2.0 16v T 121kw (05-07)	UCH AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	2.0 16v T 125kw (05-07)	UCC AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Laguna II ph2	CHASSIS NETWORK	2.0 16v T 125kw (05-07)	UCH AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	2.0 16v T 150kw (05-07)	UCC AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	2.0 16v T 150kw (05-07)	UCH AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	2.2 16v dCi 102kw (05-07)	UCC AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	2.2 16v dCi 102kw (05-07)	UCH AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	2.2 16v dCi 110kw (05-07)	UCC AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	2.2 16v dCi 110kw (05-07)	UCH AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	2.2 16v dCi FAP 102kw (05-07)	UCC AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	2.2 16v dCi FAP 102kw (05-07)	UCH AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	3.0 V6 24v 152kw (05-07)	UCC AUTODETECT
 Laguna II ph2	CHASSIS NETWORK	3.0 V6 24v 152kw (05-07)	UCH AUTODETECT
 Laguna II ph2	CLIMA	1.6 16v 82kw (05-07)	AUTODETECT
 Laguna II ph2	CLIMA	1.6 16v GPL 79kw (05-07)	AUTODETECT
 Laguna II ph2	CLIMA	1.8 16v 88kw (05-07)	AUTODETECT
 Laguna II ph2	CLIMA	1.9 dCi 68kw (05-07)	AUTODETECT
 Laguna II ph2	CLIMA	1.9 dCi 74kw (05-07)	AUTODETECT
 Laguna II ph2	CLIMA	1.9 dCi 81kw (05-07)	AUTODETECT
 Laguna II ph2	CLIMA	1.9 dCi 85kw (05-07)	AUTODETECT
 Laguna II ph2	CLIMA	1.9 dCi 88kw (05-07)	AUTODETECT
 Laguna II ph2	CLIMA	1.9 dCi 96kw (05-07)	AUTODETECT
 Laguna II ph2	CLIMA	1.9 dCi FAP 81kw (05-07)	AUTODETECT
 Laguna II ph2	CLIMA	1.9 dCi FAP 85kw (05-07)	AUTODETECT
 Laguna II ph2	CLIMA	1.9 dCi FAP 92kw (05-07)	AUTODETECT
 Laguna II ph2	CLIMA	1.9 dCi FAP 96kw (05-07)	AUTODETECT
 Laguna II ph2	CLIMA	2.0 16v 103kw (05-07)	AUTODETECT
 Laguna II ph2	CLIMA	2.0 16v 99kw (05-07)	AUTODETECT
 Laguna II ph2	CLIMA	2.0 16v dCi 110kw (05-07)	AUTODETECT
 Laguna II ph2	CLIMA	2.0 16v dCi FAP 127kw (05-07)	AUTODETECT
 Laguna II ph2	CLIMA	2.0 16v T 121kw (05-07)	AUTODETECT
 Laguna II ph2	CLIMA	2.0 16v T 125kw (05-07)	AUTODETECT
 Laguna II ph2	CLIMA	2.0 16v T 150kw (05-07)	AUTODETECT
 Laguna II ph2	CLIMA	2.2 16v dCi 102kw (05-07)	AUTODETECT
 Laguna II ph2	CLIMA	2.2 16v dCi 110kw (05-07)	AUTODETECT
 Laguna II ph2	CLIMA	2.2 16v dCi FAP 102kw (05-07)	AUTODETECT
 Laguna II ph2	CLIMA	3.0 V6 24v 152kw (05-07)	AUTODETECT
 Laguna II ph2	DASHBOARD	1.6 16v 82kw (05-07)	AUTODETECT
 Laguna II ph2	DASHBOARD	1.6 16v GPL 79kw (05-07)	AUTODETECT
 Laguna II ph2	DASHBOARD	1.8 16v 88kw (05-07)	AUTODETECT
 Laguna II ph2	DASHBOARD	1.9 dCi 68kw (05-07)	AUTODETECT
 Laguna II ph2	DASHBOARD	1.9 dCi 74kw (05-07)	AUTODETECT
 Laguna II ph2	DASHBOARD	1.9 dCi 81kw (05-07)	AUTODETECT
 Laguna II ph2	DASHBOARD	1.9 dCi 85kw (05-07)	AUTODETECT
 Laguna II ph2	DASHBOARD	1.9 dCi 88kw (05-07)	AUTODETECT
 Laguna II ph2	DASHBOARD	1.9 dCi 96kw (05-07)	AUTODETECT
 Laguna II ph2	DASHBOARD	1.9 dCi FAP 81kw (05-07)	AUTODETECT
 Laguna II ph2	DASHBOARD	1.9 dCi FAP 85kw (05-07)	AUTODETECT
 Laguna II ph2	DASHBOARD	1.9 dCi FAP 92kw (05-07)	AUTODETECT
 Laguna II ph2	DASHBOARD	1.9 dCi FAP 96kw (05-07)	AUTODETECT
 Laguna II ph2	DASHBOARD	2.0 16v 103kw (05-07)	AUTODETECT
 Laguna II ph2	DASHBOARD	2.0 16v 99kw (05-07)	AUTODETECT
 Laguna II ph2	DASHBOARD	2.0 16v dCi 110kw (05-07)	AUTODETECT
 Laguna II ph2	DASHBOARD	2.0 16v dCi FAP 127kw (05-07)	AUTODETECT
 Laguna II ph2	DASHBOARD	2.0 16v T 121kw (05-07)	AUTODETECT
 Laguna II ph2	DASHBOARD	2.0 16v T 125kw (05-07)	AUTODETECT
 Laguna II ph2	DASHBOARD	2.0 16v T 150kw (05-07)	AUTODETECT
 Laguna II ph2	DASHBOARD	2.2 16v dCi 102kw (05-07)	AUTODETECT
 Laguna II ph2	DASHBOARD	2.2 16v dCi 110kw (05-07)	AUTODETECT
 Laguna II ph2	DASHBOARD	2.2 16v dCi FAP 102kw (05-07)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Laguna II ph2	DASHBOARD	3.0 V6 24v 152kw (05-07)	AUTODETECT
 Laguna II ph2	ENGINE MANAGEME	1.6 16v 82kw (05-07)	AUTODETECT
 Laguna II ph2	ENGINE MANAGEME	1.8 16v 88kw (05-07)	AUTODETECT
 Laguna II ph2	ENGINE MANAGEME	1.9 dCi 68kw (05-07)	AUTODETECT
 Laguna II ph2	ENGINE MANAGEME	1.9 dCi 74kw (05-07)	AUTODETECT
 Laguna II ph2	ENGINE MANAGEME	1.9 dCi 85kw (05-07)	AUTODETECT
 Laguna II ph2	ENGINE MANAGEME	1.9 dCi 88kw F9Q-764 (05-07)	AUTODETECT
 Laguna II ph2	ENGINE MANAGEME	1.9 dCi 96kw (05-07)	AUTODETECT
 Laguna II ph2	ENGINE MANAGEME	1.9 dCi FAP 81kw (05-07)	AUTODETECT
 Laguna II ph2	ENGINE MANAGEME	1.9 dCi FAP 85kw (05-07)	AUTODETECT
 Laguna II ph2	ENGINE MANAGEME	1.9 dCi FAP 92kw (05-07)	AUTODETECT
 Laguna II ph2	ENGINE MANAGEME	1.9 dCi FAP 96kw (05-07)	AUTODETECT
 Laguna II ph2	ENGINE MANAGEME	2.0 16v 103kw (05-07)	AUTODETECT
 Laguna II ph2	ENGINE MANAGEME	2.0 16v 99kw (05-07)	AUTODETECT
 Laguna II ph2	ENGINE MANAGEME	2.0 16v dCi 110kw (05-07)	AUTODETECT
 Laguna II ph2	ENGINE MANAGEME	2.0 16v dCi FAP 127kw (05-07)	AUTODETECT
 Laguna II ph2	ENGINE MANAGEME	2.0 16v T 121kw (05-07)	AUTODETECT
 Laguna II ph2	ENGINE MANAGEME	2.0 16v T 125kw (05-07)	AUTODETECT
 Laguna II ph2	ENGINE MANAGEME	2.0 16v T 150kw (05-07)	AUTODETECT
 Laguna II ph2	ENGINE MANAGEME	2.2 16v dCi 102kw (05-07)	AUTODETECT
 Laguna II ph2	ENGINE MANAGEME	2.2 16v dCi 110kw (05-07)	AUTODETECT
 Laguna II ph2	ENGINE MANAGEME	2.2 16v dCi FAP 102kw (05-07)	AUTODETECT
 Laguna II ph2	ENGINE MANAGEME	3.0 V6 24v 152kw (05-07)	AUTODETECT
 Laguna II ph2	HEADLIGHT LEVEL	1.6 16v 82kw (05-07)	can AUTODETECT
 Laguna II ph2	HEADLIGHT LEVEL	1.6 16v GPL 79kw (05-07)	can AUTODETECT
 Laguna II ph2	HEADLIGHT LEVEL	1.8 16v 88kw (05-07)	can AUTODETECT
 Laguna II ph2	HEADLIGHT LEVEL	1.9 dCi 68kw (05-07)	can AUTODETECT
 Laguna II ph2	HEADLIGHT LEVEL	1.9 dCi 74kw (05-07)	can AUTODETECT
 Laguna II ph2	HEADLIGHT LEVEL	1.9 dCi 81kw (05-07)	can AUTODETECT
 Laguna II ph2	HEADLIGHT LEVEL	1.9 dCi 85kw (05-07)	can AUTODETECT
 Laguna II ph2	HEADLIGHT LEVEL	1.9 dCi 88kw (05-07)	can AUTODETECT
 Laguna II ph2	HEADLIGHT LEVEL	1.9 dCi 96kw (05-07)	can AUTODETECT
 Laguna II ph2	HEADLIGHT LEVEL	1.9 dCi FAP 81kw (05-07)	can AUTODETECT
 Laguna II ph2	HEADLIGHT LEVEL	1.9 dCi FAP 85kw (05-07)	can AUTODETECT
 Laguna II ph2	HEADLIGHT LEVEL	1.9 dCi FAP 92kw (05-07)	can AUTODETECT
 Laguna II ph2	HEADLIGHT LEVEL	1.9 dCi FAP 96kw (05-07)	can AUTODETECT
 Laguna II ph2	HEADLIGHT LEVEL	2.0 16v 103kw (05-07)	can AUTODETECT
 Laguna II ph2	HEADLIGHT LEVEL	2.0 16v 99kw (05-07)	can AUTODETECT
 Laguna II ph2	HEADLIGHT LEVEL	2.0 16v dCi 110kw (05-07)	can AUTODETECT
 Laguna II ph2	HEADLIGHT LEVEL	2.0 16v dCi FAP 127kw (05-07)	can AUTODETECT
 Laguna II ph2	HEADLIGHT LEVEL	2.0 16v T 121kw (05-07)	can AUTODETECT
 Laguna II ph2	HEADLIGHT LEVEL	2.0 16v T 125kw (05-07)	can AUTODETECT
 Laguna II ph2	HEADLIGHT LEVEL	2.0 16v T 150kw (05-07)	can AUTODETECT
 Laguna II ph2	HEADLIGHT LEVEL	2.2 16v dCi 102kw (05-07)	can AUTODETECT
 Laguna II ph2	HEADLIGHT LEVEL	2.2 16v dCi 110kw (05-07)	can AUTODETECT
 Laguna II ph2	HEADLIGHT LEVEL	2.2 16v dCi FAP 102kw (05-07)	can AUTODETECT
 Laguna II ph2	HEADLIGHT LEVEL	3.0 V6 24v 152kw (05-07)	can AUTODETECT
 Laguna II ph2	PARK.BRAKE	1.6 16v 82kw (05-07)	Electrobrake AUTODETECT
 Laguna II ph2	PARK.BRAKE	1.6 16v GPL 79kw (05-07)	Electrobrake AUTODETECT
 Laguna II ph2	PARK.BRAKE	1.8 16v 88kw (05-07)	Electrobrake AUTODETECT
 Laguna II ph2	PARK.BRAKE	1.9 dCi 68kw (05-07)	Electrobrake AUTODETECT
 Laguna II ph2	PARK.BRAKE	1.9 dCi 74kw (05-07)	Electrobrake AUTODETECT
 Laguna II ph2	PARK.BRAKE	1.9 dCi 81kw (05-07)	Electrobrake AUTODETECT
 Laguna II ph2	PARK.BRAKE	1.9 dCi 85kw (05-07)	Electrobrake AUTODETECT
 Laguna II ph2	PARK.BRAKE	1.9 dCi 88kw (05-07)	Electrobrake AUTODETECT
 Laguna II ph2	PARK.BRAKE	1.9 dCi 96kw (05-07)	Electrobrake AUTODETECT
 Laguna II ph2	PARK.BRAKE	1.9 dCi FAP 81kw (05-07)	Electrobrake AUTODETECT
 Laguna II ph2	PARK.BRAKE	1.9 dCi FAP 85kw (05-07)	Electrobrake AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Laguna II ph2	PARK.BRAKE	1.9 dCi FAP 92kw (05-07)	Electrobrake AUTODETECT
 Laguna II ph2	PARK.BRAKE	1.9 dCi FAP 96kw (05-07)	Electrobrake AUTODETECT
 Laguna II ph2	PARK.BRAKE	2.0 16v 103kw (05-07)	Electrobrake AUTODETECT
 Laguna II ph2	PARK.BRAKE	2.0 16v 99kw (05-07)	Electrobrake AUTODETECT
 Laguna II ph2	PARK.BRAKE	2.0 16v dCi 110kw (05-07)	Electrobrake AUTODETECT
 Laguna II ph2	PARK.BRAKE	2.0 16v dCi FAP 127kw (05-07)	Electrobrake AUTODETECT
 Laguna II ph2	PARK.BRAKE	2.0 16v T 121kw (05-07)	Electrobrake AUTODETECT
 Laguna II ph2	PARK.BRAKE	2.0 16v T 125kw (05-07)	Electrobrake AUTODETECT
 Laguna II ph2	PARK.BRAKE	2.0 16v T 150kw (05-07)	Electrobrake AUTODETECT
 Laguna II ph2	PARK.BRAKE	2.2 16v dCi 102kw (05-07)	Electrobrake AUTODETECT
 Laguna II ph2	PARK.BRAKE	2.2 16v dCi 110kw (05-07)	Electrobrake AUTODETECT
 Laguna II ph2	PARK.BRAKE	2.2 16v dCi FAP 102kw (05-07)	Electrobrake AUTODETECT
 Laguna II ph2	PARK.BRAKE	3.0 V6 24v 152kw (05-07)	Electrobrake AUTODETECT
 Laguna II ph2	PARKING HELP	1.6 16v 82kw (05-07)	AUTODETECT
 Laguna II ph2	PARKING HELP	1.8 16v 88kw (05-07)	AUTODETECT
 Laguna II ph2	PARKING HELP	1.9 dCi 68kw (05-07)	AUTODETECT
 Laguna II ph2	PARKING HELP	1.9 dCi 74kw (05-07)	AUTODETECT
 Laguna II ph2	PARKING HELP	1.9 dCi 81kw (05-07)	AUTODETECT
 Laguna II ph2	PARKING HELP	1.9 dCi 85kw (05-07)	AUTODETECT
 Laguna II ph2	PARKING HELP	1.9 dCi 88kw (05-07)	AUTODETECT
 Laguna II ph2	PARKING HELP	1.9 dCi 96kw (05-07)	AUTODETECT
 Laguna II ph2	PARKING HELP	1.9 dCi FAP 81kw (05-07)	AUTODETECT
 Laguna II ph2	PARKING HELP	1.9 dCi FAP 85kw (05-07)	AUTODETECT
 Laguna II ph2	PARKING HELP	1.9 dCi FAP 92kw (05-07)	AUTODETECT
 Laguna II ph2	PARKING HELP	1.9 dCi FAP 96kw (05-07)	AUTODETECT
 Laguna II ph2	PARKING HELP	2.0 16v 103kw (05-07)	AUTODETECT
 Laguna II ph2	PARKING HELP	2.0 16v 99kw (05-07)	AUTODETECT
 Laguna II ph2	PARKING HELP	2.0 16v dCi 110kw (05-07)	AUTODETECT
 Laguna II ph2	PARKING HELP	2.0 16v dCi FAP 127kw (05-07)	AUTODETECT
 Laguna II ph2	PARKING HELP	2.0 16v T 121kw (05-07)	AUTODETECT
 Laguna II ph2	PARKING HELP	2.0 16v T 125kw (05-07)	AUTODETECT
 Laguna II ph2	PARKING HELP	2.0 16v T 150kw (05-07)	AUTODETECT
 Laguna II ph2	PARKING HELP	2.2 16v dCi 102kw (05-07)	AUTODETECT
 Laguna II ph2	PARKING HELP	2.2 16v dCi 110kw (05-07)	AUTODETECT
 Laguna II ph2	PARKING HELP	2.2 16v dCi FAP 102kw (05-07)	AUTODETECT
 Laguna II ph2	PARKING HELP	3.0 V6 24v 152kw (05-07)	AUTODETECT
 Laguna II ph2	PHONE	1.6 16v 82kw (05-07)	Handsfree Kit AUTODETECT
 Laguna II ph2	PHONE	1.6 16v GPL 79kw (05-07)	Handsfree Kit AUTODETECT
 Laguna II ph2	PHONE	1.8 16v 88kw (05-07)	Handsfree Kit AUTODETECT
 Laguna II ph2	PHONE	1.9 dCi 68kw (05-07)	Handsfree Kit AUTODETECT
 Laguna II ph2	PHONE	1.9 dCi 74kw (05-07)	Handsfree Kit AUTODETECT
 Laguna II ph2	PHONE	1.9 dCi 81kw (05-07)	Handsfree Kit AUTODETECT
 Laguna II ph2	PHONE	1.9 dCi 85kw (05-07)	Handsfree Kit AUTODETECT
 Laguna II ph2	PHONE	1.9 dCi 88kw (05-07)	Handsfree Kit AUTODETECT
 Laguna II ph2	PHONE	1.9 dCi 96kw (05-07)	Handsfree Kit AUTODETECT
 Laguna II ph2	PHONE	1.9 dCi FAP 81kw (05-07)	Handsfree Kit AUTODETECT
 Laguna II ph2	PHONE	1.9 dCi FAP 85kw (05-07)	Handsfree Kit AUTODETECT
 Laguna II ph2	PHONE	1.9 dCi FAP 92kw (05-07)	Handsfree Kit AUTODETECT
 Laguna II ph2	PHONE	1.9 dCi FAP 96kw (05-07)	Handsfree Kit AUTODETECT
 Laguna II ph2	PHONE	2.0 16v 103kw (05-07)	Handsfree Kit AUTODETECT
 Laguna II ph2	PHONE	2.0 16v 99kw (05-07)	Handsfree Kit AUTODETECT
 Laguna II ph2	PHONE	2.0 16v dCi 110kw (05-07)	Handsfree Kit AUTODETECT
 Laguna II ph2	PHONE	2.0 16v dCi FAP 127kw (05-07)	Handsfree Kit AUTODETECT
 Laguna II ph2	PHONE	2.0 16v T 121kw (05-07)	Handsfree Kit AUTODETECT
 Laguna II ph2	PHONE	2.0 16v T 125kw (05-07)	Handsfree Kit AUTODETECT
 Laguna II ph2	PHONE	2.0 16v T 150kw (05-07)	Handsfree Kit AUTODETECT
 Laguna II ph2	PHONE	2.2 16v dCi 102kw (05-07)	Handsfree Kit AUTODETECT
 Laguna II ph2	PHONE	2.2 16v dCi 110kw (05-07)	Handsfree Kit AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Laguna II ph2	PHONE	2.2 16v dCi FAP 102kw (05-07)	Handsfree Kit AUTODETECT
 Laguna II ph2	PHONE	3.0 V6 24v 152kw (05-07)	Handsfree Kit AUTODETECT
 Laguna II ph2	SUPP HEATER/AUTO	1.6 16v 82kw (05-07)	AUTODETECT
 Laguna II ph2	SUPP HEATER/AUTO	1.6 16v GPL 79kw (05-07)	AUTODETECT
 Laguna II ph2	SUPP HEATER/AUTO	1.8 16v 88kw (05-07)	AUTODETECT
 Laguna II ph2	SUPP HEATER/AUTO	1.9 dCi 68kw (05-07)	AUTODETECT
 Laguna II ph2	SUPP HEATER/AUTO	1.9 dCi 74kw (05-07)	AUTODETECT
 Laguna II ph2	SUPP HEATER/AUTO	1.9 dCi 81kw (05-07)	AUTODETECT
 Laguna II ph2	SUPP HEATER/AUTO	1.9 dCi 85kw (05-07)	AUTODETECT
 Laguna II ph2	SUPP HEATER/AUTO	1.9 dCi 88kw (05-07)	AUTODETECT
 Laguna II ph2	SUPP HEATER/AUTO	1.9 dCi 96kw (05-07)	AUTODETECT
 Laguna II ph2	SUPP HEATER/AUTO	1.9 dCi FAP 81kw (05-07)	AUTODETECT
 Laguna II ph2	SUPP HEATER/AUTO	1.9 dCi FAP 85kw (05-07)	AUTODETECT
 Laguna II ph2	SUPP HEATER/AUTO	1.9 dCi FAP 92kw (05-07)	AUTODETECT
 Laguna II ph2	SUPP HEATER/AUTO	1.9 dCi FAP 96kw (05-07)	AUTODETECT
 Laguna II ph2	SUPP HEATER/AUTO	2.0 16v 103kw (05-07)	AUTODETECT
 Laguna II ph2	SUPP HEATER/AUTO	2.0 16v 99kw (05-07)	AUTODETECT
 Laguna II ph2	SUPP HEATER/AUTO	2.0 16v dCi 110kw (05-07)	AUTODETECT
 Laguna II ph2	SUPP HEATER/AUTO	2.0 16v dCi FAP 127kw (05-07)	AUTODETECT
 Laguna II ph2	SUPP HEATER/AUTO	2.0 16v T 121kw (05-07)	AUTODETECT
 Laguna II ph2	SUPP HEATER/AUTO	2.0 16v T 125kw (05-07)	AUTODETECT
 Laguna II ph2	SUPP HEATER/AUTO	2.0 16v T 150kw (05-07)	AUTODETECT
 Laguna II ph2	SUPP HEATER/AUTO	2.2 16v dCi 102kw (05-07)	AUTODETECT
 Laguna II ph2	SUPP HEATER/AUTO	2.2 16v dCi 110kw (05-07)	AUTODETECT
 Laguna II ph2	SUPP HEATER/AUTO	2.2 16v dCi FAP 102kw (05-07)	AUTODETECT
 Laguna II ph2	SUPP HEATER/AUTO	3.0 V6 24v 152kw (05-07)	AUTODETECT
 Laguna II	ABS	1.6 16v 79kw (00-05)	AUTODETECT
 Laguna II	ABS	1.6 16v 79kw (00-05)	BOSCH ABS 5.3 T
 Laguna II	ABS	1.6 16v 79kw (00-05)	TEVES ABS MK20T
 Laguna II	ABS	1.6 16v 79kw (00-05)	TEVES ABS Mk60
 Laguna II	ABS	1.6 16v GPL 79kw (00-05)	AUTODETECT
 Laguna II	ABS	1.6 16v GPL 79kw (00-05)	BOSCH ABS 5.3 T
 Laguna II	ABS	1.6 16v GPL 79kw (00-05)	TEVES ABS MK20T
 Laguna II	ABS	1.6 16v GPL 79kw (00-05)	TEVES ABS Mk60
 Laguna II	ABS	1.8 16v 88kw (00-05)	AUTODETECT
 Laguna II	ABS	1.8 16v 88kw (00-05)	BOSCH ABS 5.3 T
 Laguna II	ABS	1.8 16v 88kw (00-05)	TEVES ABS MK20T
 Laguna II	ABS	1.8 16v 88kw (00-05)	TEVES ABS Mk60
 Laguna II	ABS	1.9 dCi 68kw (00-05)	AUTODETECT
 Laguna II	ABS	1.9 dCi 68kw (00-05)	BOSCH ABS 5.3 T
 Laguna II	ABS	1.9 dCi 68kw (00-05)	TEVES ABS MK20T
 Laguna II	ABS	1.9 dCi 68kw (00-05)	TEVES ABS Mk60
 Laguna II	ABS	1.9 dCi 74kw (00-05)	AUTODETECT
 Laguna II	ABS	1.9 dCi 74kw (00-05)	BOSCH ABS 5.3 T
 Laguna II	ABS	1.9 dCi 74kw (00-05)	TEVES ABS MK20T
 Laguna II	ABS	1.9 dCi 74kw (00-05)	TEVES ABS Mk60
 Laguna II	ABS	1.9 dCi 81kw (00-05)	AUTODETECT
 Laguna II	ABS	1.9 dCi 81kw (00-05)	BOSCH ABS 5.3 T
 Laguna II	ABS	1.9 dCi 81kw (00-05)	TEVES ABS MK20T
 Laguna II	ABS	1.9 dCi 81kw (00-05)	TEVES ABS Mk60
 Laguna II	ABS	1.9 dCi 88kw (00-05)	AUTODETECT
 Laguna II	ABS	1.9 dCi 88kw (00-05)	BOSCH ABS 5.3 T
 Laguna II	ABS	1.9 dCi 88kw (00-05)	TEVES ABS MK20T
 Laguna II	ABS	1.9 dCi 88kw (00-05)	TEVES ABS Mk60
 Laguna II	ABS	2.0 16v 103kw (00-05)	AUTODETECT
 Laguna II	ABS	2.0 16v 103kw (00-05)	BOSCH ABS 5.3 T
 Laguna II	ABS	2.0 16v 103kw (00-05)	TEVES ABS MK20T
 Laguna II	ABS	2.0 16v 103kw (00-05)	TEVES ABS Mk60

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Laguna II	ABS	2.0 16v 99kw (00-05)	BOSCH ABS 5.3 T
 Laguna II	ABS	2.0 16v 99kw (00-05)	TEVES ABS MK20T
 Laguna II	ABS	2.0 16v 99kw F4R-714 (00-05)	AUTODETECT
 Laguna II	ABS	2.0 16v 99kw F4R-714 (00-05)	TEVES ABS Mk60
 Laguna II	ABS	2.0 16v T 121kw (00-05)	AUTODETECT
 Laguna II	ABS	2.0 16v T 121kw (00-05)	BOSCH ABS 5.3 T
 Laguna II	ABS	2.0 16v T 121kw (00-05)	TEVES ABS MK20T
 Laguna II	ABS	2.0 16v T 121kw (00-05)	TEVES ABS Mk60
 Laguna II	ABS	2.2 16v dCi 102kw (00-05)	AUTODETECT
 Laguna II	ABS	2.2 16v dCi 102kw (00-05)	BOSCH ABS 5.3 T
 Laguna II	ABS	2.2 16v dCi 102kw (00-05)	TEVES ABS MK20T
 Laguna II	ABS	2.2 16v dCi 110kw (00-05)	AUTODETECT
 Laguna II	ABS	2.2 16v dCi 110kw (00-05)	BOSCH ABS 5.3 T
 Laguna II	ABS	2.2 16v dCi 110kw (00-05)	TEVES ABS MK20T
 Laguna II	ABS	2.2 16v dCi 110kw (00-05)	TEVES ABS Mk60
 Laguna II	ABS	3.0 V6 24v 152kw (00-05)	AUTODETECT
 Laguna II	ABS	3.0 V6 24v 152kw (00-05)	BOSCH ABS 5.3 T
 Laguna II	ABS	3.0 V6 24v 152kw (00-05)	TEVES ABS MK20T
 Laguna II	ABS	3.0 V6 24v 152kw (00-05)	TEVES ABS Mk60
 Laguna II	AIRBAG	1.6 16v 79kw (00-05)	AUTODETECT
 Laguna II	AIRBAG	1.6 16v 79kw (00-05)	SAGEM - Autoliv AirBag ACU 3
 Laguna II	AIRBAG	1.6 16v GPL 79kw (00-05)	AUTODETECT
 Laguna II	AIRBAG	1.6 16v GPL 79kw (00-05)	SAGEM - Autoliv AirBag ACU 3
 Laguna II	AIRBAG	1.8 16v 88kw (00-05)	AUTODETECT
 Laguna II	AIRBAG	1.8 16v 88kw (00-05)	SAGEM - Autoliv AirBag ACU 3
 Laguna II	AIRBAG	1.9 dCi 68kw (00-05)	AUTODETECT
 Laguna II	AIRBAG	1.9 dCi 68kw (00-05)	SAGEM - Autoliv AirBag ACU 3
 Laguna II	AIRBAG	1.9 dCi 74kw (00-05)	AUTODETECT
 Laguna II	AIRBAG	1.9 dCi 74kw (00-05)	SAGEM - Autoliv AirBag ACU 3
 Laguna II	AIRBAG	1.9 dCi 81kw (00-05)	AUTODETECT
 Laguna II	AIRBAG	1.9 dCi 81kw (00-05)	SAGEM - Autoliv AirBag ACU 3
 Laguna II	AIRBAG	1.9 dCi 88kw (00-05)	AUTODETECT
 Laguna II	AIRBAG	1.9 dCi 88kw (00-05)	SAGEM - Autoliv AirBag ACU 3
 Laguna II	AIRBAG	2.0 16v 103kw (00-05)	AUTODETECT
 Laguna II	AIRBAG	2.0 16v 103kw (00-05)	SAGEM - Autoliv AirBag ACU 3
 Laguna II	AIRBAG	2.0 16v 99kw (00-05)	AUTODETECT
 Laguna II	AIRBAG	2.0 16v 99kw (00-05)	SAGEM - Autoliv AirBag ACU 3
 Laguna II	AIRBAG	2.0 16v T 121kw (00-05)	AUTODETECT
 Laguna II	AIRBAG	2.0 16v T 121kw (00-05)	SAGEM - Autoliv AirBag ACU 3
 Laguna II	AIRBAG	2.2 16v dCi 102kw (00-05)	AUTODETECT
 Laguna II	AIRBAG	2.2 16v dCi 102kw (00-05)	SAGEM - Autoliv AirBag ACU 3
 Laguna II	AIRBAG	2.2 16v dCi 110kw (00-05)	AUTODETECT
 Laguna II	AIRBAG	2.2 16v dCi 110kw (00-05)	SAGEM - Autoliv AirBag ACU 3
 Laguna II	AIRBAG	3.0 V6 24v 152kw (00-05)	AUTODETECT
 Laguna II	AIRBAG	3.0 V6 24v 152kw (00-05)	SAGEM - Autoliv AirBag ACU 3
 Laguna II	AUTOM. TRANSMISSI	1.6 16v 79kw (00-05)	AUTODETECT
 Laguna II	AUTOM. TRANSMISSI	1.6 16v GPL 79kw (00-05)	AUTODETECT
 Laguna II	AUTOM. TRANSMISSI	1.8 16v 88kw (00-05)	AUTODETECT
 Laguna II	AUTOM. TRANSMISSI	1.9 dCi 68kw (00-05)	AUTODETECT
 Laguna II	AUTOM. TRANSMISSI	1.9 dCi 74kw (00-05)	AUTODETECT
 Laguna II	AUTOM. TRANSMISSI	1.9 dCi 81kw (00-05)	AUTODETECT
 Laguna II	AUTOM. TRANSMISSI	1.9 dCi 88kw (00-05)	AUTODETECT
 Laguna II	AUTOM. TRANSMISSI	2.0 16v 103kw (00-05)	AUTODETECT
 Laguna II	AUTOM. TRANSMISSI	2.0 16v 99kw (00-05)	AUTODETECT
 Laguna II	AUTOM. TRANSMISSI	2.0 16v T 121kw (00-05)	AUTODETECT
 Laguna II	AUTOM. TRANSMISSI	2.2 16v dCi 102kw (00-05)	AUTODETECT
 Laguna II	AUTOM. TRANSMISSI	2.2 16v dCi 110kw (00-05)	AUTODETECT
 Laguna II	AUTOM. TRANSMISSI	3.0 V6 24v 152kw (00-05)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Laguna II	CHASSIS NETWORK	1.6 16v 79kw (00-05)	UCH AUTODETECT
 Laguna II	CHASSIS NETWORK	1.6 16v GPL 79kw (00-05)	UCH AUTODETECT
 Laguna II	CHASSIS NETWORK	1.8 16v 88kw (00-05)	UCH AUTODETECT
 Laguna II	CHASSIS NETWORK	1.9 dCi 68kw (00-05)	UCH AUTODETECT
 Laguna II	CHASSIS NETWORK	1.9 dCi 74kw (00-05)	UCH AUTODETECT
 Laguna II	CHASSIS NETWORK	1.9 dCi 81kw (00-05)	UCH AUTODETECT
 Laguna II	CHASSIS NETWORK	1.9 dCi 88kw (00-05)	UCH AUTODETECT
 Laguna II	CHASSIS NETWORK	2.0 16v 103kw (00-05)	UCH AUTODETECT
 Laguna II	CHASSIS NETWORK	2.0 16v 99kw (00-05)	UCH AUTODETECT
 Laguna II	CHASSIS NETWORK	2.0 16v T 121kw (00-05)	UCH AUTODETECT
 Laguna II	CHASSIS NETWORK	2.2 16v dCi 102kw (00-05)	UCH AUTODETECT
 Laguna II	CHASSIS NETWORK	2.2 16v dCi 110kw (00-05)	UCH AUTODETECT
 Laguna II	CHASSIS NETWORK	3.0 V6 24v 152kw (00-05)	UCH AUTODETECT
 Laguna II	CLIMA	1.6 16v 79kw (00-05)	AUTODETECT
 Laguna II	CLIMA	1.6 16v GPL 79kw (00-05)	AUTODETECT
 Laguna II	CLIMA	1.8 16v 88kw (00-05)	AUTODETECT
 Laguna II	CLIMA	1.9 dCi 68kw (00-05)	AUTODETECT
 Laguna II	CLIMA	1.9 dCi 74kw (00-05)	AUTODETECT
 Laguna II	CLIMA	1.9 dCi 81kw (00-05)	AUTODETECT
 Laguna II	CLIMA	1.9 dCi 88kw (00-05)	AUTODETECT
 Laguna II	CLIMA	2.0 16v 103kw (00-05)	AUTODETECT
 Laguna II	CLIMA	2.0 16v 99kw (00-05)	AUTODETECT
 Laguna II	CLIMA	2.0 16v T 121kw (00-05)	AUTODETECT
 Laguna II	CLIMA	2.2 16v dCi 102kw (00-05)	AUTODETECT
 Laguna II	CLIMA	2.2 16v dCi 110kw (00-05)	AUTODETECT
 Laguna II	CLIMA	3.0 V6 24v 152kw (00-05)	AUTODETECT
 Laguna II	DASHBOARD	1.6 16v 79kw (00-05)	AUTODETECT
 Laguna II	DASHBOARD	1.6 16v GPL 79kw (00-05)	AUTODETECT
 Laguna II	DASHBOARD	1.8 16v 88kw (00-05)	AUTODETECT
 Laguna II	DASHBOARD	1.9 dCi 68kw (00-05)	AUTODETECT
 Laguna II	DASHBOARD	1.9 dCi 74kw (00-05)	AUTODETECT
 Laguna II	DASHBOARD	1.9 dCi 81kw (00-05)	AUTODETECT
 Laguna II	DASHBOARD	1.9 dCi 88kw (00-05)	AUTODETECT
 Laguna II	DASHBOARD	2.0 16v 103kw (00-05)	AUTODETECT
 Laguna II	DASHBOARD	2.0 16v 99kw (00-05)	AUTODETECT
 Laguna II	DASHBOARD	2.0 16v T 121kw (00-05)	AUTODETECT
 Laguna II	DASHBOARD	2.2 16v dCi 102kw (00-05)	AUTODETECT
 Laguna II	DASHBOARD	2.2 16v dCi 110kw (00-05)	AUTODETECT
 Laguna II	DASHBOARD	3.0 V6 24v 152kw (00-05)	AUTODETECT
 Laguna II	ENGINE MANAGEME	1.6 16v 79kw (00-05)	AUTODETECT
 Laguna II	ENGINE MANAGEME	1.6 16v 79kw (00-05)	GAS AUTODETECT
 Laguna II	ENGINE MANAGEME	1.6 16v 82kw K4M-716 (05-07)	EOBD
 Laguna II	ENGINE MANAGEME	1.6 16v GPL 79kw (00-05)	AUTODETECT
 Laguna II	ENGINE MANAGEME	1.6 16v GPL 79kw K4M-710 (05-07)	EOBD
 Laguna II	ENGINE MANAGEME	1.8 16v 88kw (00-05)	AUTODETECT
 Laguna II	ENGINE MANAGEME	1.9 dCi 68kw (00-05)	AUTODETECT
 Laguna II	ENGINE MANAGEME	1.9 dCi 68kw F9Q-650 (00-05)	BOSCH EDC 15 C3 Common Rail
 Laguna II	ENGINE MANAGEME	1.9 dCi 74kw (00-05)	AUTODETECT
 Laguna II	ENGINE MANAGEME	1.9 dCi 74kw F9Q-752 (00-05)	BOSCH EDC 15 C3 Common Rail
 Laguna II	ENGINE MANAGEME	1.9 dCi 81kw (00-05)	AUTODETECT
 Laguna II	ENGINE MANAGEME	1.9 dCi 81kw F9Q-754 (00-05)	BOSCH EDC 15 C3 Common Rail
 Laguna II	ENGINE MANAGEME	1.9 dCi 81kw F9Q-757 (00-05)	BOSCH EDC 15 C3 Common Rail
 Laguna II	ENGINE MANAGEME	1.9 dCi 88kw F9Q-670 (00-05)	BOSCH EDC 15 C3 Common Rail
 Laguna II	ENGINE MANAGEME	1.9 dCi 88kw F9Q-674 (00-05)	BOSCH EDC 15 C3 Common Rail
 Laguna II	ENGINE MANAGEME	1.9 dCi 88kw F9Q-750 (00-05)	BOSCH EDC 15 C3 Common Rail
 Laguna II	ENGINE MANAGEME	2.0 16v 103kw F5R-700 (00-05)	EOBD
 Laguna II	ENGINE MANAGEME	2.0 16v 99kw F4R-714 (00-05)	EOBD
 Laguna II	ENGINE MANAGEME	2.0 16v T 121kw F4R-764 (00-05)	EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Laguna II	ENGINE MANAGEME	2.0 16v T 121kw F4R-765 (00-05)	EOBD
 Laguna II	ENGINE MANAGEME	2.2 16v dCi 110kw (00-05)	AUTODETECT
 Laguna II	ENGINE MANAGEME	2.2 16v dCi 110kw G9T-610 (00-05)	BOSCH EDC 15 C3 Common Rail
 Laguna II	ENGINE MANAGEME	2.2 16v dCi 110kw G9T-702 (00-05)	BOSCH EDC 15 C3 Common Rail
 Laguna II	ENGINE MANAGEME	2.2 16v dCi 110kw G9T-703 (00-05)	BOSCH EDC 15 C3 Common Rail
 Laguna II	ENGINE MANAGEME	2.2 16v dCi 110kw G9T-707 (00-05)	BOSCH EDC 15 C3 Common Rail
 Laguna II	ENGINE MANAGEME	3.0 V6 24v 152kw L7X-731 (00-05)	EOBD
 Laguna II	HEADLIGHT LEVEL	1.6 16v 79kw (00-05)	AUTODETECT
 Laguna II	HEADLIGHT LEVEL	1.6 16v GPL 79kw (00-05)	AUTODETECT
 Laguna II	HEADLIGHT LEVEL	1.8 16v 88kw (00-05)	AUTODETECT
 Laguna II	HEADLIGHT LEVEL	1.9 dCi 68kw (00-05)	AUTODETECT
 Laguna II	HEADLIGHT LEVEL	1.9 dCi 74kw (00-05)	AUTODETECT
 Laguna II	HEADLIGHT LEVEL	1.9 dCi 81kw (00-05)	AUTODETECT
 Laguna II	HEADLIGHT LEVEL	1.9 dCi 88kw (00-05)	AUTODETECT
 Laguna II	HEADLIGHT LEVEL	2.0 16v 103kw (00-05)	AUTODETECT
 Laguna II	HEADLIGHT LEVEL	2.0 16v 99kw (00-05)	AUTODETECT
 Laguna II	HEADLIGHT LEVEL	2.0 16v T 121kw (00-05)	AUTODETECT
 Laguna II	HEADLIGHT LEVEL	2.2 16v dCi 102kw (00-05)	AUTODETECT
 Laguna II	HEADLIGHT LEVEL	2.2 16v dCi 110kw (00-05)	AUTODETECT
 Laguna II	HEADLIGHT LEVEL	3.0 V6 24v 152kw (00-05)	AUTODETECT
 Laguna II	IMMOBILIZER	1.6 16v 79kw (00-05)	Immobilizer Body Computer
 Laguna II	IMMOBILIZER	1.6 16v GPL 79kw (00-05)	Immobilizer Body Computer
 Laguna II	IMMOBILIZER	1.8 16v 88kw (00-05)	Immobilizer Body Computer
 Laguna II	IMMOBILIZER	1.9 dCi 68kw (00-05)	Immobilizer Body Computer
 Laguna II	IMMOBILIZER	1.9 dCi 74kw (00-05)	Immobilizer Body Computer
 Laguna II	IMMOBILIZER	1.9 dCi 81kw (00-05)	Immobilizer Body Computer
 Laguna II	IMMOBILIZER	1.9 dCi 88kw (00-05)	Immobilizer Body Computer
 Laguna II	IMMOBILIZER	2.0 16v 103kw (00-05)	Immobilizer Body Computer
 Laguna II	IMMOBILIZER	2.0 16v 99kw (00-05)	Immobilizer Body Computer
 Laguna II	IMMOBILIZER	2.0 16v T 121kw (00-05)	Immobilizer Body Computer
 Laguna II	IMMOBILIZER	2.2 16v dCi 102kw (00-05)	Immobilizer Body Computer
 Laguna II	IMMOBILIZER	2.2 16v dCi 110kw (00-05)	Immobilizer Body Computer
 Laguna II	IMMOBILIZER	3.0 V6 24v 152kw (00-05)	Immobilizer Body Computer
 Laguna II	MAINTENANCE	1.6 16v 79kw (00-05)	Body Computer
 Laguna II	MAINTENANCE	1.6 16v 79kw (00-05)	Body Computer
 Laguna II	MAINTENANCE	1.6 16v 79kw (00-05)	Body Computer
 Laguna II	MAINTENANCE	1.6 16v 79kw (00-05)	Body Computer
 Laguna II	MAINTENANCE	1.6 16v 79kw (00-05)	Body Computer
 Laguna II	MAINTENANCE	1.6 16v 79kw (00-05)	Body Computer
 Laguna II	MAINTENANCE	1.6 16v 79kw (00-05)	Body Computer
 Laguna II	MAINTENANCE	1.6 16v 79kw (00-05)	Body Computer
 Laguna II	MAINTENANCE	1.6 16v 79kw (00-05)	Body Computer
 Laguna II	MAINTENANCE	1.6 16v 79kw (00-05)	Body Computer
 Laguna II	MAINTENANCE	1.6 16v 79kw (00-05)	MANUAL
 Laguna II	MAINTENANCE	1.6 16v GPL 79kw (00-05)	Body Computer
 Laguna II	MAINTENANCE	1.6 16v GPL 79kw (00-05)	Body Computer
 Laguna II	MAINTENANCE	1.6 16v GPL 79kw (00-05)	Body Computer
 Laguna II	MAINTENANCE	1.6 16v GPL 79kw (00-05)	Body Computer
 Laguna II	MAINTENANCE	1.6 16v GPL 79kw (00-05)	Body Computer
 Laguna II	MAINTENANCE	1.6 16v GPL 79kw (00-05)	Body Computer
 Laguna II	MAINTENANCE	1.6 16v GPL 79kw (00-05)	Body Computer
 Laguna II	MAINTENANCE	1.6 16v GPL 79kw (00-05)	MANUAL
 Laguna II	MAINTENANCE	1.8 16v 88kw (00-05)	Body Computer
 Laguna II	MAINTENANCE	1.8 16v 88kw (00-05)	Body Computer
 Laguna II	MAINTENANCE	1.8 16v 88kw (00-05)	Body Computer

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

[illegible]

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

[illegible]

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Laguna II	MAINTENANCE	3.0 V6 24v 152kw (00-05)	Body Computer
 Laguna II	MAINTENANCE	3.0 V6 24v 152kw (00-05)	MANUAL
 Laguna II	PARKING HELP	1.6 16v 79kw (00-05)	AUTODETECT
 Laguna II	PARKING HELP	1.6 16v GPL 79kw (00-05)	AUTODETECT
 Laguna II	PARKING HELP	1.8 16v 88kw (00-05)	AUTODETECT
 Laguna II	PARKING HELP	1.9 dCi 68kw (00-05)	AUTODETECT
 Laguna II	PARKING HELP	1.9 dCi 74kw (00-05)	AUTODETECT
 Laguna II	PARKING HELP	1.9 dCi 81kw (00-05)	AUTODETECT
 Laguna II	PARKING HELP	1.9 dCi 88kw (00-05)	AUTODETECT
 Laguna II	PARKING HELP	2.0 16v 103kw (00-05)	AUTODETECT
 Laguna II	PARKING HELP	2.0 16v 99kw (00-05)	AUTODETECT
 Laguna II	PARKING HELP	2.0 16v T 121kw (00-05)	AUTODETECT
 Laguna II	PARKING HELP	2.2 16v dCi 102kw (00-05)	AUTODETECT
 Laguna II	PARKING HELP	2.2 16v dCi 110kw (00-05)	AUTODETECT
 Laguna II	PARKING HELP	3.0 V6 24v 152kw (00-05)	AUTODETECT
 Laguna II	SERVICE LIGHT RES	1.6 16v 79kw (00-05)	MANUAL
 Laguna II	SERVICE LIGHT RES	1.6 16v GPL 79kw (00-05)	MANUAL
 Laguna II	SERVICE LIGHT RES	1.8 16v 88kw (00-05)	MANUAL
 Laguna II	SERVICE LIGHT RES	1.9 dCi 68kw (00-05)	MANUAL
 Laguna II	SERVICE LIGHT RES	1.9 dCi 74kw (00-05)	MANUAL
 Laguna II	SERVICE LIGHT RES	1.9 dCi 81kw (00-05)	MANUAL
 Laguna II	SERVICE LIGHT RES	1.9 dCi 88kw (00-05)	MANUAL
 Laguna II	SERVICE LIGHT RES	2.0 16v 103kw (00-05)	MANUAL
 Laguna II	SERVICE LIGHT RES	2.0 16v 99kw (00-05)	MANUAL
 Laguna II	SERVICE LIGHT RES	2.0 16v T 121kw (00-05)	MANUAL
 Laguna II	SERVICE LIGHT RES	2.2 16v dCi 102kw (00-05)	MANUAL
 Laguna II	SERVICE LIGHT RES	2.2 16v dCi 110kw (00-05)	MANUAL
 Laguna II	SERVICE LIGHT RES	3.0 V6 24v 152kw (00-05)	MANUAL
 Laguna II	SUPP HEATER/AUTO	1.6 16v 79kw (00-05)	AUTODETECT
 Laguna II	SUPP HEATER/AUTO	1.6 16v GPL 79kw (00-05)	AUTODETECT
 Laguna II	SUPP HEATER/AUTO	1.8 16v 88kw (00-05)	AUTODETECT
 Laguna II	SUPP HEATER/AUTO	1.9 dCi 74kw (00-05)	AUTODETECT
 Laguna II	SUPP HEATER/AUTO	1.9 dCi 81kw (00-05)	AUTODETECT
 Laguna II	SUPP HEATER/AUTO	2.0 16v 103kw (00-05)	AUTODETECT
 Laguna II	SUPP HEATER/AUTO	2.0 16v 99kw (00-05)	AUTODETECT
 Laguna II	SUPP HEATER/AUTO	2.0 16v T 121kw (00-05)	AUTODETECT
 Laguna II	SUPP HEATER/AUTO	2.2 16v dCi 102kw (00-05)	AUTODETECT
 Laguna II	SUPP HEATER/AUTO	3.0 V6 24v 152kw (00-05)	AUTODETECT
 Laguna II	TIRE PRESSURE	1.6 16v 79kw (00-05)	Body Computer
 Laguna II	TIRE PRESSURE	1.6 16v GPL 79kw (00-05)	Body Computer
 Laguna II	TIRE PRESSURE	1.8 16v 88kw (00-05)	Body Computer
 Laguna II	TIRE PRESSURE	1.9 dCi 68kw (00-05)	Body Computer
 Laguna II	TIRE PRESSURE	1.9 dCi 74kw (00-05)	Body Computer
 Laguna II	TIRE PRESSURE	1.9 dCi 81kw (00-05)	Body Computer
 Laguna II	TIRE PRESSURE	1.9 dCi 88kw (00-05)	Body Computer
 Laguna II	TIRE PRESSURE	2.0 16v 103kw (00-05)	Body Computer
 Laguna II	TIRE PRESSURE	2.0 16v 99kw (00-05)	Body Computer
 Laguna II	TIRE PRESSURE	2.0 16v T 121kw (00-05)	Body Computer
 Laguna II	TIRE PRESSURE	2.2 16v dCi 102kw (00-05)	Body Computer
 Laguna II	TIRE PRESSURE	2.2 16v dCi 110kw (00-05)	Body Computer
 Laguna II	TIRE PRESSURE	3.0 V6 24v 152kw (00-05)	Body Computer
 Laguna III	AUTOM. TRANSMISSI	1.5 dCi 81kw	AUTODETECT
 Laguna III	AUTOM. TRANSMISSI	1.6 16v 81kw	AUTODETECT
 Laguna III	AUTOM. TRANSMISSI	2.0 16v 103kw	AUTODETECT
 Laguna III	AUTOM. TRANSMISSI	2.0 16v 150kw	AUTODETECT
 Laguna III	AUTOM. TRANSMISSI	2.0 16v dCi FAP 110kw	AUTODETECT
 Laguna III	AUTOM. TRANSMISSI	2.0 16v dCi FAP 127kw	AUTODETECT
 Laguna III	AUTOM. TRANSMISSI	2.0 16v dCi FAP 130kw	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Laguna III	AUTOM. TRANSMISSI	2.0 16v dCi FAP 96kw	AUTODETECT
 Laguna III	AUTOM. TRANSMISSI	2.0 16v T 125kw	AUTODETECT
 Laguna III	AUTOM. TRANSMISSI	2.0 16v T 150kw	AUTODETECT
 Laguna III	AUTOM. TRANSMISSI	2.0 dCi 16v 110kw	AUTODETECT
 Laguna III	AUTOM. TRANSMISSI	2.0 dCi 16v 96kw	AUTODETECT
 Laguna III	AUTOM. TRANSMISSI	3.5 V6 24v 175kw	AUTODETECT
 Laguna III	CHASSIS NETWORK	1.5 dCi 81kw	UCC AUTODETECT
 Laguna III	CHASSIS NETWORK	2.0 16v 103kw	UCC AUTODETECT
 Laguna III	CHASSIS NETWORK	2.0 16v 150kw	UCC AUTODETECT
 Laguna III	CHASSIS NETWORK	2.0 16v dCi FAP 110kw	UCC AUTODETECT
 Laguna III	CHASSIS NETWORK	2.0 16v dCi FAP 127kw	UCC AUTODETECT
 Laguna III	CHASSIS NETWORK	2.0 16v dCi FAP 130kw	UCC AUTODETECT
 Laguna III	CHASSIS NETWORK	2.0 16v dCi FAP 96kw	UCC AUTODETECT
 Laguna III	CHASSIS NETWORK	2.0 16v T 125kw	UCC AUTODETECT
 Laguna III	CHASSIS NETWORK	2.0 16v T 150kw	UCC AUTODETECT
 Laguna III	CHASSIS NETWORK	2.0 dCi 16v 110kw	UCC AUTODETECT
 Laguna III	CHASSIS NETWORK	2.0 dCi 16v 96kw	UCC AUTODETECT
 Laguna III	CHASSIS NETWORK	3.5 V6 24v 175kw	UCC AUTODETECT
 Laguna III	ENGINE MANAGEME	1.5 dCi 81kw	AUTODETECT
 Laguna III	ENGINE MANAGEME	1.6 16v 81kw	AUTODETECT
 Laguna III	ENGINE MANAGEME	2.0 16v 103kw	AUTODETECT
 Laguna III	ENGINE MANAGEME	2.0 16v 150kw	AUTODETECT
 Laguna III	ENGINE MANAGEME	2.0 16v dCi FAP 110kw	AUTODETECT
 Laguna III	ENGINE MANAGEME	2.0 16v dCi FAP 127kw	AUTODETECT
 Laguna III	ENGINE MANAGEME	2.0 16v dCi FAP 130kw	AUTODETECT
 Laguna III	ENGINE MANAGEME	2.0 16v dCi FAP 96kw	AUTODETECT
 Laguna III	ENGINE MANAGEME	2.0 16v T 125kw	AUTODETECT
 Laguna III	ENGINE MANAGEME	2.0 16v T 150kw	AUTODETECT
 Laguna III	ENGINE MANAGEME	2.0 dCi 16v 110kw	AUTODETECT
 Laguna III	ENGINE MANAGEME	2.0 dCi 16v 96kw	AUTODETECT
 Laguna III	ENGINE MANAGEME	3.0 dCi FAP 173kw	AUTODETECT
 Laguna III	ENGINE MANAGEME	3.5 V6 24v 175kw	AUTODETECT
 Laguna III	PARKING HELP	1.5 dCi 81kw	can AUTODETECT
 Laguna III	PARKING HELP	1.6 16v 81kw	can AUTODETECT
 Laguna III	PARKING HELP	2.0 16v 103kw	can AUTODETECT
 Laguna III	PARKING HELP	2.0 16v 150kw	can AUTODETECT
 Laguna III	PARKING HELP	2.0 16v dCi FAP 110kw	can AUTODETECT
 Laguna III	PARKING HELP	2.0 16v dCi FAP 127kw	can AUTODETECT
 Laguna III	PARKING HELP	2.0 16v dCi FAP 130kw	can AUTODETECT
 Laguna III	PARKING HELP	2.0 16v dCi FAP 96kw	can AUTODETECT
 Laguna III	PARKING HELP	2.0 16v T 125kw	can AUTODETECT
 Laguna III	PARKING HELP	2.0 16v T 150kw	can AUTODETECT
 Laguna III	PARKING HELP	2.0 dCi 16v 110kw	can AUTODETECT
 Laguna III	PARKING HELP	2.0 dCi 16v 96kw	can AUTODETECT
 Laguna III	PARKING HELP	3.0 dCi FAP 173kw	can AUTODETECT
 Laguna III	PARKING HELP	3.5 V6 24v 175kw	can AUTODETECT
 Laguna III	RADIO / CD	1.5 dCi 81kw	AUTODETECT
 Laguna III	RADIO / CD	1.6 16v 81kw	AUTODETECT
 Laguna III	RADIO / CD	2.0 16v 103kw	AUTODETECT
 Laguna III	RADIO / CD	2.0 16v 150kw	AUTODETECT
 Laguna III	RADIO / CD	2.0 16v dCi FAP 110kw	AUTODETECT
 Laguna III	RADIO / CD	2.0 16v dCi FAP 127kw	AUTODETECT
 Laguna III	RADIO / CD	2.0 16v dCi FAP 130kw	AUTODETECT
 Laguna III	RADIO / CD	2.0 16v dCi FAP 96kw	AUTODETECT
 Laguna III	RADIO / CD	2.0 16v T 125kw	AUTODETECT
 Laguna III	RADIO / CD	2.0 16v T 150kw	AUTODETECT
 Laguna III	RADIO / CD	2.0 dCi 16v 110kw	AUTODETECT
 Laguna III	RADIO / CD	2.0 dCi 16v 96kw	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Laguna III	RADIO / CD	3.5 V6 24v 175kw	AUTODETECT
 Laguna III	VISUAL./TELEMATIC	1.5 dCi 81kw	USB AUTODETECT
 Laguna III	VISUAL./TELEMATIC	2.0 16v 103kw	USB AUTODETECT
 Laguna III	VISUAL./TELEMATIC	2.0 16v 150kw	USB AUTODETECT
 Laguna III	VISUAL./TELEMATIC	2.0 16v dCi FAP 110kw	USB AUTODETECT
 Laguna III	VISUAL./TELEMATIC	2.0 16v dCi FAP 127kw	USB AUTODETECT
 Laguna III	VISUAL./TELEMATIC	2.0 16v dCi FAP 130kw	USB AUTODETECT
 Laguna III	VISUAL./TELEMATIC	2.0 16v dCi FAP 96kw	USB AUTODETECT
 Laguna III	VISUAL./TELEMATIC	2.0 16v T 121kw	USB AUTODETECT
 Laguna III	VISUAL./TELEMATIC	2.0 16v T 125kw	USB AUTODETECT
 Laguna III	VISUAL./TELEMATIC	2.0 16v T 150kw	USB AUTODETECT
 Laguna III	VISUAL./TELEMATIC	2.0 dCi 16v 110kw	USB AUTODETECT
 Laguna III	VISUAL./TELEMATIC	2.0 dCi 16v 96kw	USB AUTODETECT
 Laguna III	VISUAL./TELEMATIC	3.5 V6 24v 175kw	USB AUTODETECT
 Laguna	ABS	1.6 16v 81kw	BOSCH ABS 5.3
 Laguna	ABS	1.6 16v 81kw	TEVES ABS Mk20
 Laguna	ABS	1.6 16v 81kw	TEVES ABS MK20T
 Laguna	ABS	1.8 16v 88kw	BOSCH ABS 5.3
 Laguna	ABS	1.8 16v 88kw	TEVES ABS Mk20
 Laguna	ABS	1.8 16v 88kw	TEVES ABS MK20T
 Laguna	ABS	1.8 66kw	BOSCH ABS 5.3
 Laguna	ABS	1.8 66kw	TEVES ABS Mk20
 Laguna	ABS	1.8 66kw	TEVES ABS MK20T
 Laguna	ABS	1.8 68kw	BOSCH ABS 5.3
 Laguna	ABS	1.8 68kw	TEVES ABS Mk20
 Laguna	ABS	1.8 68kw	TEVES ABS MK20T
 Laguna	ABS	1.9 dCi 81kw	BOSCH ABS 5.3
 Laguna	ABS	1.9 dCi 81kw	TEVES ABS Mk20
 Laguna	ABS	1.9 dCi 81kw	TEVES ABS MK20T
 Laguna	ABS	1.9 dTi 74kw	BOSCH ABS 5.3
 Laguna	ABS	1.9 dTi 74kw	TEVES ABS Mk20
 Laguna	ABS	1.9 dTi 74kw	TEVES ABS MK20T
 Laguna	ABS	2.0 16v 103kw	BOSCH ABS 5.3
 Laguna	ABS	2.0 16v 103kw	TEVES ABS Mk20
 Laguna	ABS	2.0 16v 103kw	TEVES ABS MK20T
 Laguna	ABS	2.0 83kw	BOSCH ABS 5.3
 Laguna	ABS	2.0 83kw	TEVES ABS Mk20
 Laguna	ABS	2.0 83kw	TEVES ABS MK20T
 Laguna	ABS	2.2 D 61kw	BOSCH ABS 5.3
 Laguna	ABS	2.2 D 61kw	TEVES ABS Mk20
 Laguna	ABS	2.2 D 61kw	TEVES ABS MK20T
 Laguna	ABS	2.2 TD 83kw	BOSCH ABS 5.3
 Laguna	ABS	2.2 TD 83kw	TEVES ABS Mk20
 Laguna	ABS	2.2 TD 83kw	TEVES ABS MK20T
 Laguna	ABS	3.0 V6 123kw	BOSCH ABS 5.3
 Laguna	ABS	3.0 V6 123kw	TEVES ABS Mk20
 Laguna	ABS	3.0 V6 123kw	TEVES ABS MK20T
 Laguna	ABS	3.0 V6 24v 143kw	BOSCH ABS 5.3
 Laguna	ABS	3.0 V6 24v 143kw	TEVES ABS Mk20
 Laguna	ABS	3.0 V6 24v 143kw	TEVES ABS MK20T
 Laguna	AIRBAG	1.6 16v 81kw	SIEMENS - Autoliv AirBag AC4
 Laguna	AIRBAG	1.6 16v 81kw	SIEMENS - Autoliv AirBag AC6
 Laguna	AIRBAG	1.6 16v 81kw	SIEMENS - Autoliv AirBag EC5
 Laguna	AIRBAG	1.8 16v 88kw	SIEMENS - Autoliv AirBag AC4
 Laguna	AIRBAG	1.8 16v 88kw	SIEMENS - Autoliv AirBag AC6
 Laguna	AIRBAG	1.8 16v 88kw	SIEMENS - Autoliv AirBag EC5
 Laguna	AIRBAG	1.8 66kw	SIEMENS - Autoliv AirBag AC4
 Laguna	AIRBAG	1.8 66kw	SIEMENS - Autoliv AirBag AC6

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Laguna	AIRBAG	1.8 66kw	SIEMENS - Autoliv AirBag EC5
 Laguna	AIRBAG	1.8 68kw	SIEMENS - Autoliv AirBag AC4
 Laguna	AIRBAG	1.8 68kw	SIEMENS - Autoliv AirBag AC6
 Laguna	AIRBAG	1.8 68kw	SIEMENS - Autoliv AirBag EC5
 Laguna	AIRBAG	1.9 dCi 81kw	SIEMENS - Autoliv AirBag AC4
 Laguna	AIRBAG	1.9 dCi 81kw	SIEMENS - Autoliv AirBag AC6
 Laguna	AIRBAG	1.9 dCi 81kw	SIEMENS - Autoliv AirBag EC5
 Laguna	AIRBAG	1.9 dTi 74kw	SIEMENS - Autoliv AirBag AC4
 Laguna	AIRBAG	1.9 dTi 74kw	SIEMENS - Autoliv AirBag AC6
 Laguna	AIRBAG	1.9 dTi 74kw	SIEMENS - Autoliv AirBag EC5
 Laguna	AIRBAG	2.0 16v 103kw	SIEMENS - Autoliv AirBag AC4
 Laguna	AIRBAG	2.0 16v 103kw	SIEMENS - Autoliv AirBag AC6
 Laguna	AIRBAG	2.0 16v 103kw	SIEMENS - Autoliv AirBag EC5
 Laguna	AIRBAG	2.0 83kw	SIEMENS - Autoliv AirBag AC4
 Laguna	AIRBAG	2.0 83kw	SIEMENS - Autoliv AirBag AC6
 Laguna	AIRBAG	2.0 83kw	SIEMENS - Autoliv AirBag EC5
 Laguna	AIRBAG	2.2 D 61kw	SIEMENS - Autoliv AirBag AC4
 Laguna	AIRBAG	2.2 D 61kw	SIEMENS - Autoliv AirBag AC6
 Laguna	AIRBAG	2.2 D 61kw	SIEMENS - Autoliv AirBag EC5
 Laguna	AIRBAG	2.2 TD 83kw	SIEMENS - Autoliv AirBag AC4
 Laguna	AIRBAG	2.2 TD 83kw	SIEMENS - Autoliv AirBag AC6
 Laguna	AIRBAG	2.2 TD 83kw	SIEMENS - Autoliv AirBag EC5
 Laguna	AIRBAG	3.0 V6 123kw	SIEMENS - Autoliv AirBag AC4
 Laguna	AIRBAG	3.0 V6 123kw	SIEMENS - Autoliv AirBag AC6
 Laguna	AIRBAG	3.0 V6 123kw	SIEMENS - Autoliv AirBag EC5
 Laguna	AIRBAG	3.0 V6 24v 143kw	SIEMENS - Autoliv AirBag AC4
 Laguna	AIRBAG	3.0 V6 24v 143kw	SIEMENS - Autoliv AirBag AC6
 Laguna	AIRBAG	3.0 V6 24v 143kw	SIEMENS - Autoliv AirBag EC5
 Laguna	DIESEL MANAGEMEN	1.9 dTi 74kw F9Q-710 (...01)	BOSCH MSA 15
 Laguna	DIESEL MANAGEMEN	1.9 dTi 74kw F9Q-716 (...01)	BOSCH MSA 15
 Laguna	DIESEL MANAGEMEN	2.2 D 61kw G8T-752	SAGEM EGR Diesel
 Laguna	DIESEL MANAGEMEN	2.2 D 61kw G8T-762	SAGEM EGR Diesel
 Laguna	DIESEL MANAGEMEN	2.2 D 61kw G8T-790	SAGEM EGR Diesel
 Laguna	DIESEL MANAGEMEN	2.2 D 61kw G8T-792	SAGEM EGR Diesel
 Laguna	DIESEL MANAGEMEN	2.2 D 61kw G8T-794	SAGEM EGR Diesel
 Laguna	DIESEL MANAGEMEN	2.2 TD 83kw G8T-760	SAGEM EGR Diesel
 Laguna	DIESEL MANAGEMEN	2.2 TD 83kw G8T-760	SAGEM EGR Diesel
 Laguna	DIESEL MANAGEMEN	2.2 TD 83kw G8T-760	SAGEM EGR Diesel
 Laguna	DIESEL MANAGEMEN	2.2 TD 83kw G8T-760	SAGEM EGR Diesel
 Laguna	DIESEL MANAGEMEN	2.2 TD 83kw G8T-760	SAGEM EGR Diesel
 Laguna	DIESEL MANAGEMEN	2.2 TD 83kw G8T-760	SAGEM EGR Diesel
 Laguna	DIESEL MANAGEMEN	2.2 TD 83kw G8T-760	SAGEM EGR Diesel
 Laguna	DIESEL MANAGEMEN	2.2 TD 83kw G8T-760	SAGEM EGR Diesel
 Laguna	ENGINE MANAGEME	1.6 16v 81kw K4M-720	SIEMENS Sirius 32
 Laguna	ENGINE MANAGEME	1.6 16v 81kw K4M-724	SIEMENS Sirius 32
 Laguna	ENGINE MANAGEME	1.8 16v 88kw F4P-760	SIEMENS Sirius 32
 Laguna	ENGINE MANAGEME	1.8 66kw F3P-724	SIEMENS BOSCH SPI
 Laguna	ENGINE MANAGEME	1.8 66kw F3P-724	SIEMENS BOSCH SPI
 Laguna	ENGINE MANAGEME	1.8 66kw F3P-724	SIEMENS BOSCH SPI
 Laguna	ENGINE MANAGEME	1.8 66kw F3P-724	SIEMENS BOSCH SPI
 Laguna	ENGINE MANAGEME	1.8 66kw F3P-724	SIEMENS BOSCH SPI
 Laguna	ENGINE MANAGEME	1.8 66kw F3P-724	SIEMENS BOSCH SPI
 Laguna	ENGINE MANAGEME	1.8 66kw F3P-724	SIEMENS BOSCH SPI
 Laguna	ENGINE MANAGEME	1.8 66kw F3P-760	SIEMENS BOSCH SPI
 Laguna	ENGINE MANAGEME	1.8 66kw F3P-760	SIEMENS BOSCH SPI
 Laguna	ENGINE MANAGEME	1.8 66kw F3P-760	SIEMENS BOSCH SPI

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Laguna	ENGINE MANAGEME	1.8 66kw F3P-760	SIEMENS BOSCH SPI
 Laguna	ENGINE MANAGEME	1.8 66kw F3P-760	SIEMENS BOSCH SPI
 Laguna	ENGINE MANAGEME	1.8 66kw F3P-760	SIEMENS FENIX 5
 Laguna	ENGINE MANAGEME	1.8 68kw F3P-724	SIEMENS BOSCH SPI
 Laguna	ENGINE MANAGEME	1.8 68kw F3P-724	SIEMENS BOSCH SPI
 Laguna	ENGINE MANAGEME	1.8 68kw F3P-724	SIEMENS BOSCH SPI
 Laguna	ENGINE MANAGEME	1.8 68kw F3P-724	SIEMENS BOSCH SPI
 Laguna	ENGINE MANAGEME	1.8 68kw F3P-724	SIEMENS BOSCH SPI
 Laguna	ENGINE MANAGEME	1.8 68kw F3P-724	SIEMENS BOSCH SPI
 Laguna	ENGINE MANAGEME	1.8 68kw F3P-724	SIEMENS FENIX 5
 Laguna	ENGINE MANAGEME	1.9 dCi 81kw F9Q-718	SIEMENS Sirius 32
 Laguna	ENGINE MANAGEME	2.0 16v 103kw N7Q-700	SIEMENS FENIX 5
 Laguna	ENGINE MANAGEME	2.0 16v 103kw N7Q-700	SIEMENS FENIX 5
 Laguna	ENGINE MANAGEME	2.0 16v 103kw N7Q-700	SIEMENS FENIX 5
 Laguna	ENGINE MANAGEME	2.0 16v 103kw N7Q-700	SIEMENS FENIX 5
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-728	SIEMENS FENIX 5
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-728	SIEMENS FENIX 5
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-728	SIEMENS FENIX 5
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-728	SIEMENS FENIX 5
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-728	SIEMENS FENIX 5
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-728	SIEMENS MPI
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-728	SIEMENS MPI
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-728	SIEMENS MPI
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-728	SIEMENS MPI
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-728	SIEMENS MPI
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-729	SIEMENS FENIX 5
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-729	SIEMENS FENIX 5
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-729	SIEMENS FENIX 5
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-729	SIEMENS FENIX 5
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-729	SIEMENS FENIX 5
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-729	SIEMENS MPI
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-729	SIEMENS MPI
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-729	SIEMENS MPI
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-729	SIEMENS MPI
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-729	SIEMENS MPI
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-768	SIEMENS FENIX 5
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-768	SIEMENS FENIX 5
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-768	SIEMENS FENIX 5
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-768	SIEMENS FENIX 5
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-768	SIEMENS FENIX 5
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-768	SIEMENS FENIX 5
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-768	SIEMENS MPI
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-768	SIEMENS MPI
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-768	SIEMENS MPI
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-768	SIEMENS MPI
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-768	SIEMENS MPI
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-769	SIEMENS FENIX 5
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-769	SIEMENS FENIX 5
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-769	SIEMENS FENIX 5
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-769	SIEMENS FENIX 5
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-769	SIEMENS FENIX 5
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-769	SIEMENS FENIX 5
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-769	SIEMENS MPI
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-769	SIEMENS MPI
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-769	SIEMENS MPI
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-769	SIEMENS MPI

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Laguna	ENGINE MANAGEME	2.0 83kw F3R-769	SIEMENS MPI
 Laguna	ENGINE MANAGEME	3.0 V6 123kw Z7X-760	SIEMENS MPI
 Laguna	ENGINE MANAGEME	3.0 V6 123kw Z7X-760	SIEMENS MPI
 Laguna	ENGINE MANAGEME	3.0 V6 123kw Z7X-760	SIEMENS MPI
 Laguna	ENGINE MANAGEME	3.0 V6 123kw Z7X-760	SIEMENS MPI
 Laguna	ENGINE MANAGEME	3.0 V6 123kw Z7X-765	SIEMENS MPI
 Laguna	ENGINE MANAGEME	3.0 V6 123kw Z7X-767	SIEMENS MPI
 Laguna	ENGINE MANAGEME	3.0 V6 24v 143kw L7X-700	SIEMENS MPI
 Laguna	ENGINE MANAGEME	3.0 V6 24v 143kw L7X-700	SIEMENS MPI
 Laguna	ENGINE MANAGEME	3.0 V6 24v 143kw L7X-700	SIEMENS MPI
 Laguna	ENGINE MANAGEME	3.0 V6 24v 143kw L7X-700	SIEMENS MPI
 Laguna	ENGINE MANAGEME	3.0 V6 24v 143kw L7X-700	SIEMENS MPI
 Laguna	ENGINE MANAGEME	3.0 V6 24v 143kw L7X-701	SIEMENS MPI
 Laguna	ENGINE MANAGEME	3.0 V6 24v 143kw L7X-701	SIEMENS MPI
 Laguna	ENGINE MANAGEME	3.0 V6 24v 143kw L7X-701	SIEMENS MPI
 Laguna	ENGINE MANAGEME	3.0 V6 24v 143kw L7X-701	SIEMENS MPI
 Laguna	ENGINE MANAGEME	3.0 V6 24v 143kw L7X-701	SIEMENS MPI
 Laguna	ENGINE MANAGEME	3.0 V6 24v 143kw L7X-701	SIEMENS MPI
 Laguna	MAINTENANCE	1.6 16v 81kw (...95)	MANUAL
 Laguna	MAINTENANCE	1.8 16v 88kw (...95)	MANUAL
 Laguna	MAINTENANCE	1.8 66kw (...95)	MANUAL
 Laguna	MAINTENANCE	1.8 68kw (...95)	MANUAL
 Laguna	MAINTENANCE	1.9 dCi 81kw (...95)	MANUAL
 Laguna	MAINTENANCE	1.9 dTi 74kw (...95)	MANUAL
 Laguna	MAINTENANCE	2.0 16v 103kw (...95)	MANUAL
 Laguna	MAINTENANCE	2.0 83kw (...95)	MANUAL
 Laguna	MAINTENANCE	2.2 D 61kw (...95)	MANUAL
 Laguna	MAINTENANCE	2.2 TD 83kw (...95)	MANUAL
 Laguna	MAINTENANCE	3.0 V6 123kw (...95)	MANUAL
 Laguna	MAINTENANCE	3.0 V6 24v 143kw (...95)	MANUAL
 Laguna	SERVICE LIGHT RES	1.6 16v 81kw (...95)	MANUAL
 Laguna	SERVICE LIGHT RES	1.8 16v 88kw (...95)	MANUAL
 Laguna	SERVICE LIGHT RES	1.8 66kw (...95)	MANUAL
 Laguna	SERVICE LIGHT RES	1.8 68kw (...95)	MANUAL
 Laguna	SERVICE LIGHT RES	1.9 dCi 81kw (...95)	MANUAL
 Laguna	SERVICE LIGHT RES	1.9 dTi 74kw (...95)	MANUAL
 Laguna	SERVICE LIGHT RES	2.0 16v 103kw (...95)	MANUAL
 Laguna	SERVICE LIGHT RES	2.0 83kw (...95)	MANUAL
 Laguna	SERVICE LIGHT RES	2.2 D 61kw (...95)	MANUAL
 Laguna	SERVICE LIGHT RES	2.2 TD 83kw (...95)	MANUAL
 Laguna	SERVICE LIGHT RES	3.0 V6 123kw (...95)	MANUAL
 Laguna	SERVICE LIGHT RES	3.0 V6 24v 143kw (...95)	MANUAL
 Latitude-SM5	ABS	2.0 16v 102kw (10-..)	ABS AUTODETECT
 Latitude-SM5	ABS	2.0 16v 112kw (10-..)	ABS AUTODETECT
 Latitude-SM5	ABS	2.0 16v 130kw (10-..)	ABS AUTODETECT
 Latitude-SM5	ABS	3.0 dCi FAP 173kw (10-..)	ABS AUTODETECT
 Latitude-SM5	AIRBAG	2.0 16v 102kw (10-..)	AIRBAG AUTODETECT
 Latitude-SM5	AIRBAG	2.0 16v 112kw (10-..)	AIRBAG AUTODETECT
 Latitude-SM5	AIRBAG	2.0 16v 130kw (10-..)	AIRBAG AUTODETECT
 Latitude-SM5	AIRBAG	3.0 dCi FAP 173kw (10-..)	AIRBAG AUTODETECT
 Latitude-SM5	AUTOM. TRANSMISSI	2.0 16v 102kw (10-..)	AUTODETECT
 Latitude-SM5	AUTOM. TRANSMISSI	2.0 16v 112kw (10-..)	AUTODETECT
 Latitude-SM5	AUTOM. TRANSMISSI	2.0 16v 130kw (10-..)	AUTODETECT
 Latitude-SM5	AUTOM. TRANSMISSI	3.0 dCi FAP 173kw (10-..)	AUTODETECT
 Latitude-SM5	CHASSIS NETWORK	2.0 16v 102kw (10-..)	UCC AUTODETECT
 Latitude-SM5	CHASSIS NETWORK	2.0 16v 102kw (10-..)	UCH AUTODETECT
 Latitude-SM5	CHASSIS NETWORK	2.0 16v 112kw (10-..)	UCC AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Latitude-SM5	CHASSIS NETWORK	2.0 16v 112kw (10-..)	UCH AUTODETECT
 Latitude-SM5	CHASSIS NETWORK	2.0 16v 130kw (10-..)	UCC AUTODETECT
 Latitude-SM5	CHASSIS NETWORK	2.0 16v 130kw (10-..)	UCH AUTODETECT
 Latitude-SM5	CHASSIS NETWORK	3.0 dCi FAP 173kw (10-..)	UCC AUTODETECT
 Latitude-SM5	CHASSIS NETWORK	3.0 dCi FAP 173kw (10-..)	UCH AUTODETECT
 Latitude-SM5	CLIMA	2.0 16v 102kw (10-..)	AUTODETECT
 Latitude-SM5	CLIMA	2.0 16v 112kw (10-..)	AUTODETECT
 Latitude-SM5	CLIMA	2.0 16v 130kw (10-..)	AUTODETECT
 Latitude-SM5	CLIMA	3.0 dCi FAP 173kw (10-..)	AUTODETECT
 Latitude-SM5	DASHBOARD	2.0 16v 102kw (10-..)	AUTODETECT
 Latitude-SM5	DASHBOARD	2.0 16v 112kw (10-..)	AUTODETECT
 Latitude-SM5	DASHBOARD	2.0 16v 130kw (10-..)	AUTODETECT
 Latitude-SM5	DASHBOARD	3.0 dCi FAP 173kw (10-..)	AUTODETECT
 Latitude-SM5	DRIVER SIDE DOOR	2.0 16v 102kw (10-..)	DRIVER DOOR AUTODETECT
 Latitude-SM5	DRIVER SIDE DOOR	2.0 16v 112kw (10-..)	DRIVER DOOR AUTODETECT
 Latitude-SM5	DRIVER SIDE DOOR	2.0 16v 130kw (10-..)	DRIVER DOOR AUTODETECT
 Latitude-SM5	DRIVER SIDE DOOR	3.0 dCi FAP 173kw (10-..)	DRIVER DOOR AUTODETECT
 Latitude-SM5	ENGINE MANAGEME	2.0 16v 102kw (10-..)	AUTODETECT
 Latitude-SM5	ENGINE MANAGEME	2.0 16v 112kw (10-..)	AUTODETECT
 Latitude-SM5	ENGINE MANAGEME	2.0 16v 130kw (10-..)	AUTODETECT
 Latitude-SM5	ENGINE MANAGEME	3.0 dCi FAP 173kw (10-..)	AUTODETECT
 Latitude-SM5	FRONT DOORS	2.0 16v 102kw (10-..)	FRONT DOORS AUTODETECT
 Latitude-SM5	FRONT DOORS	2.0 16v 112kw (10-..)	FRONT DOORS AUTODETECT
 Latitude-SM5	FRONT DOORS	2.0 16v 130kw (10-..)	FRONT DOORS AUTODETECT
 Latitude-SM5	FRONT DOORS	3.0 dCi FAP 173kw (10-..)	FRONT DOORS AUTODETECT
 Latitude-SM5	HEADLIGHT LEVEL	2.0 16v 102kw (10-..)	AUTODETECT
 Latitude-SM5	HEADLIGHT LEVEL	2.0 16v 112kw (10-..)	AUTODETECT
 Latitude-SM5	HEADLIGHT LEVEL	2.0 16v 130kw (10-..)	AUTODETECT
 Latitude-SM5	HEADLIGHT LEVEL	3.0 dCi FAP 173kw (10-..)	AUTODETECT
 Latitude-SM5	MANAGEMENT SEAT	2.0 16v 102kw (10-..)	MANAGEMENT SEATS AUTODETECT
 Latitude-SM5	MANAGEMENT SEAT	2.0 16v 112kw (10-..)	MANAGEMENT SEATS AUTODETECT
 Latitude-SM5	MANAGEMENT SEAT	2.0 16v 130kw (10-..)	MANAGEMENT SEATS AUTODETECT
 Latitude-SM5	MANAGEMENT SEAT	3.0 dCi FAP 173kw (10-..)	MANAGEMENT SEATS AUTODETECT
 Latitude-SM5	PARK.BRAKE	2.0 16v 102kw (10-..)	AUTODETECT
 Latitude-SM5	PARK.BRAKE	2.0 16v 112kw (10-..)	AUTODETECT
 Latitude-SM5	PARK.BRAKE	2.0 16v 130kw (10-..)	AUTODETECT
 Latitude-SM5	PARK.BRAKE	3.0 dCi FAP 173kw (10-..)	AUTODETECT
 Latitude-SM5	PARKING HELP	2.0 16v 102kw (10-..)	can AUTODETECT
 Latitude-SM5	PARKING HELP	2.0 16v 112kw (10-..)	can AUTODETECT
 Latitude-SM5	PARKING HELP	2.0 16v 130kw (10-..)	can AUTODETECT
 Latitude-SM5	PARKING HELP	3.0 dCi FAP 173kw (10-..)	can AUTODETECT
 Latitude-SM5	PASS. SIDE DOOR	2.0 16v 102kw (10-..)	PASSENGER DOOR AUTODETECT
 Latitude-SM5	PASS. SIDE DOOR	2.0 16v 112kw (10-..)	PASSENGER DOOR AUTODETECT
 Latitude-SM5	PASS. SIDE DOOR	2.0 16v 130kw (10-..)	PASSENGER DOOR AUTODETECT
 Latitude-SM5	PASS. SIDE DOOR	3.0 dCi FAP 173kw (10-..)	PASSENGER DOOR AUTODETECT
 Latitude-SM5	RADIO / CD	2.0 16v 112kw (10-..)	AUTODETECT
 Latitude-SM5	RADIO / CD	2.0 16v 120kw (10-..)	AUTODETECT
 Latitude-SM5	RADIO / CD	2.0 16v 130kw (10-..)	AUTODETECT
 Latitude-SM5	RADIO / CD	3.0 dCi FAP 173kw (10-..)	AUTODETECT
 Latitude-SM5	REAR DOORS	2.0 16v 102kw (10-..)	REAR DOORS AUTODETECT
 Latitude-SM5	REAR DOORS	2.0 16v 112kw (10-..)	REAR DOORS AUTODETECT
 Latitude-SM5	REAR DOORS	2.0 16v 130kw (10-..)	REAR DOORS AUTODETECT
 Latitude-SM5	REAR DOORS	3.0 dCi FAP 173kw (10-..)	REAR DOORS AUTODETECT
 Latitude-SM5	SOUND SYSTEM	2.0 16v 102kw (10-..)	AUTODETECT
 Latitude-SM5	SOUND SYSTEM	2.0 16v 112kw (10-..)	AUTODETECT
 Latitude-SM5	SOUND SYSTEM	2.0 16v 130kw (10-..)	AUTODETECT
 Latitude-SM5	SOUND SYSTEM	3.0 dCi FAP 173kw (10-..)	AUTODETECT
 Latitude-SM5	VISUAL./TELEMATIC	2.0 16v 102kw (10-..)	BLUETOOTH AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Latitude-SM5	VISUAL./TELEMATIC	2.0 16v 102kw (10-..)	USB AUTODETECT
 Latitude-SM5	VISUAL./TELEMATIC	2.0 16v 112kw (10-..)	BLUETOOTH AUTODETECT
 Latitude-SM5	VISUAL./TELEMATIC	2.0 16v 112kw (10-..)	USB AUTODETECT
 Latitude-SM5	VISUAL./TELEMATIC	2.0 16v 130kw (10-..)	BLUETOOTH AUTODETECT
 Latitude-SM5	VISUAL./TELEMATIC	2.0 16v 130kw (10-..)	USB AUTODETECT
 Latitude-SM5	VISUAL./TELEMATIC	3.0 dCi FAP 173kw (10-..)	BLUETOOTH AUTODETECT
 Latitude-SM5	VISUAL./TELEMATIC	3.0 dCi FAP 173kw (10-..)	USB AUTODETECT
 Master III	ABS	2.2 16v dCi 66kw (10-..)	AUTODETECT
 Master III	ABS	2.5 dCi 16v 107kw (10-..)	AUTODETECT
 Master III	ABS	2.5 dCi 74kw (10-..)	AUTODETECT
 Master III	ABS	2.5 dCi 85kw (10-..)	AUTODETECT
 Master III	ABS	3.0 dCi 100Kw (10-..)	AUTODETECT
 Master III	CHASSIS NETWORK	2.2 16v dCi 66kw (10-..)	UCC AUTODETECT
 Master III	CHASSIS NETWORK	2.2 16v dCi 66kw (10-..)	UCH AUTODETECT
 Master III	CHASSIS NETWORK	2.5 dCi 16v 107kw (10-..)	UCC AUTODETECT
 Master III	CHASSIS NETWORK	2.5 dCi 16v 107kw (10-..)	UCH AUTODETECT
 Master III	CHASSIS NETWORK	2.5 dCi 74kw (10-..)	UCC AUTODETECT
 Master III	CHASSIS NETWORK	2.5 dCi 74kw (10-..)	UCH AUTODETECT
 Master III	CHASSIS NETWORK	2.5 dCi 85kw (10-..)	UCC AUTODETECT
 Master III	CHASSIS NETWORK	2.5 dCi 85kw (10-..)	UCH AUTODETECT
 Master III	CHASSIS NETWORK	3.0 dCi 100Kw (10-..)	UCC AUTODETECT
 Master III	CHASSIS NETWORK	3.0 dCi 100Kw (10-..)	UCH AUTODETECT
 Master III	ENGINE MANAGEME	2.2 16v dCi 66kw (10-..)	AUTODETECT
 Master III	ENGINE MANAGEME	2.5 dCi 16v 107kw (10-..)	AUTODETECT
 Master III	ENGINE MANAGEME	2.5 dCi 74kw (10-..)	AUTODETECT
 Master III	ENGINE MANAGEME	2.5 dCi 85kw (10-..)	AUTODETECT
 Master III	ENGINE MANAGEME	3.0 dCi 100Kw (10-..)	AUTODETECT
 Master III	PARKING HELP	2.2 16v dCi 66kw (10-..)	AUTODETECT
 Master III	PARKING HELP	2.5 dCi 16v 107kw (10-..)	AUTODETECT
 Master III	PARKING HELP	2.5 dCi 74kw (10-..)	AUTODETECT
 Master III	PARKING HELP	2.5 dCi 85kw (10-..)	AUTODETECT
 Master III	PARKING HELP	3.0 dCi 100Kw (10-..)	AUTODETECT
 Master III	RADIO / CD	2.2 16v dCi 66kw (10-..)	AUTODETECT
 Master III	RADIO / CD	2.5 dCi 16v 107kw (10-..)	AUTODETECT
 Master III	RADIO / CD	2.5 dCi 74kw (10-..)	AUTODETECT
 Master III	RADIO / CD	2.5 dCi 85kw (10-..)	AUTODETECT
 Master III	RADIO / CD	3.0 dCi 100Kw (10-..)	AUTODETECT
 Master III	STEERING WHEEL E	2.2 16v dCi 66kw (10-..)	AUTODETECT
 Master III	STEERING WHEEL E	2.5 dCi 16v 107kw (10-..)	AUTODETECT
 Master III	STEERING WHEEL E	2.5 dCi 74kw (10-..)	AUTODETECT
 Master III	STEERING WHEEL E	2.5 dCi 85kw (10-..)	AUTODETECT
 Master III	STEERING WHEEL E	3.0 dCi 100Kw (10-..)	AUTODETECT
 Master III	VISUAL./TELEMATIC	2.2 16v dCi 66kw (10-..)	USB AUTODETECT
 Master III	VISUAL./TELEMATIC	2.5 dCi 16v 107kw (10-..)	USB AUTODETECT
 Master III	VISUAL./TELEMATIC	2.5 dCi 74kw (10-..)	USB AUTODETECT
 Master III	VISUAL./TELEMATIC	2.5 dCi 85kw (10-..)	USB AUTODETECT
 Master III	VISUAL./TELEMATIC	3.0 dCi 100Kw (10-..)	USB AUTODETECT
 Master ph3	AUTOM. TRANSMISSI	2.2 16v dCi 66kw (04-09)	AUTODETECT
 Master ph3	AUTOM. TRANSMISSI	2.5 dCi 16v 107kw (04-09)	AUTODETECT
 Master ph3	AUTOM. TRANSMISSI	2.5 dCi 74kw (04-09)	AUTODETECT
 Master ph3	AUTOM. TRANSMISSI	2.5 dCi 85kw (04-09)	AUTODETECT
 Master ph3	AUTOM. TRANSMISSI	3.0 dCi 100Kw (04-09)	AUTODETECT
 Master ph3	CHASSIS NETWORK	2.2 16v dCi 66kw (04-09)	UCC AUTODETECT
 Master ph3	CHASSIS NETWORK	2.2 16v dCi 66kw (04-09)	UCC AUTODETECT
 Master ph3	CHASSIS NETWORK	2.5 dCi 16v 107kw (04-09)	UCC AUTODETECT
 Master ph3	CHASSIS NETWORK	2.5 dCi 16v 107kw (04-09)	UCC AUTODETECT
 Master ph3	CHASSIS NETWORK	2.5 dCi 74kw (04-09)	UCC AUTODETECT
 Master ph3	CHASSIS NETWORK	2.5 dCi 74kw (04-09)	UCC AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Master ph3	CHASSIS NETWORK	2.5 dCi 85kw (04-09)	UCC AUTODETECT
 Master ph3	CHASSIS NETWORK	2.5 dCi 85kw (04-09)	UCC AUTODETECT
 Master ph3	CHASSIS NETWORK	3.0 dCi 100Kw (04-09)	UCC AUTODETECT
 Master ph3	CHASSIS NETWORK	3.0 dCi 100Kw (04-09)	UCC AUTODETECT
 Master ph3	ENGINE MANAGEME	2.2 16v dCi 66kw (04-09)	AUTODETECT
 Master ph3	ENGINE MANAGEME	2.5 dCi 16v 107kw (04-09)	AUTODETECT
 Master ph3	ENGINE MANAGEME	2.5 dCi 74kw (04-09)	AUTODETECT
 Master ph3	ENGINE MANAGEME	2.5 dCi 85kw (04-09)	AUTODETECT
 Master ph3	ENGINE MANAGEME	3.0 dCi 100Kw (04-09)	AUTODETECT
 Master	ABS	1.9 dCi 60kw	TEVES ABS MK20T
 Master	ABS	1.9 dCi 60kw (01-..)	TEVES ABS Mk60
 Master	ABS	1.9 dTi 59kw	TEVES ABS MK20T
 Master	ABS	1.9 dTi 59kw (01-..)	TEVES ABS Mk60
 Master	ABS	2.1 D 60kw	TEVES ABS MK20T
 Master	ABS	2.1 D 60kw (01-..)	TEVES ABS Mk60
 Master	ABS	2.2 16v dCi 66kw	TEVES ABS MK20T
 Master	ABS	2.2 16v dCi 66kw (01-..)	TEVES ABS Mk60
 Master	ABS	2.2 67kw	TEVES ABS MK20T
 Master	ABS	2.2 67kw (01-..)	TEVES ABS Mk60
 Master	ABS	2.2 71kw	TEVES ABS MK20T
 Master	ABS	2.2 71kw (01-..)	TEVES ABS Mk60
 Master	ABS	2.5 D 59kw	TEVES ABS MK20T
 Master	ABS	2.5 D 59kw (01-..)	TEVES ABS Mk60
 Master	ABS	2.5 dCi 16v 107kw	TEVES ABS MK20T
 Master	ABS	2.5 dCi 16v 107kw (01-..)	TEVES ABS Mk60
 Master	ABS	2.5 dCi 74kw	TEVES ABS MK20T
 Master	ABS	2.5 dCi 74kw (01-..)	TEVES ABS Mk60
 Master	ABS	2.5 dCi 85kw	TEVES ABS MK20T
 Master	ABS	2.5 dCi 85kw (01-..)	TEVES ABS Mk60
 Master	ABS	2.5 dCi 88kw	TEVES ABS MK20T
 Master	ABS	2.5 dCi 88kw (01-..)	TEVES ABS Mk60
 Master	ABS	2.8 DTi 84kw	TEVES ABS MK20T
 Master	ABS	2.8 DTi 84kw (01-..)	TEVES ABS Mk60
 Master	ABS	2.8 DTi 85kw	TEVES ABS MK20T
 Master	ABS	2.8 DTi 85kw (01-..)	TEVES ABS Mk60
 Master	ABS	3.0 dCi 100Kw	TEVES ABS MK20T
 Master	ABS	3.0 dCi 100Kw (01-..)	TEVES ABS Mk60
 Master	AIRBAG	1.9 dCi 60kw	SAGEM - Autoliv AirBag ACU 3
 Master	AIRBAG	1.9 dCi 60kw	SIEMENS - Autoliv AirBag AC4
 Master	AIRBAG	1.9 dCi 60kw	SIEMENS - Autoliv AirBag EC5
 Master	AIRBAG	1.9 dTi 59kw	SAGEM - Autoliv AirBag ACU 3
 Master	AIRBAG	1.9 dTi 59kw	SIEMENS - Autoliv AirBag AC4
 Master	AIRBAG	1.9 dTi 59kw	SIEMENS - Autoliv AirBag EC5
 Master	AIRBAG	2.1 D 60kw	SAGEM - Autoliv AirBag ACU 3
 Master	AIRBAG	2.1 D 60kw	SIEMENS - Autoliv AirBag AC4
 Master	AIRBAG	2.1 D 60kw	SIEMENS - Autoliv AirBag EC5
 Master	AIRBAG	2.2 16v dCi 66kw	SAGEM - Autoliv AirBag ACU 3
 Master	AIRBAG	2.2 16v dCi 66kw	SIEMENS - Autoliv AirBag AC4
 Master	AIRBAG	2.2 16v dCi 66kw	SIEMENS - Autoliv AirBag EC5
 Master	AIRBAG	2.2 67kw	SAGEM - Autoliv AirBag ACU 3
 Master	AIRBAG	2.2 67kw	SIEMENS - Autoliv AirBag AC4
 Master	AIRBAG	2.2 67kw	SIEMENS - Autoliv AirBag EC5
 Master	AIRBAG	2.2 71kw	SAGEM - Autoliv AirBag ACU 3
 Master	AIRBAG	2.2 71kw	SIEMENS - Autoliv AirBag AC4
 Master	AIRBAG	2.2 71kw	SIEMENS - Autoliv AirBag EC5
 Master	AIRBAG	2.5 D 59kw	SAGEM - Autoliv AirBag ACU 3
 Master	AIRBAG	2.5 D 59kw	SIEMENS - Autoliv AirBag AC4
 Master	AIRBAG	2.5 D 59kw	SIEMENS - Autoliv AirBag EC5

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Master	AIRBAG	2.5 dCi 16v 107kw	SAGEM - Autoliv AirBag ACU 3
 Master	AIRBAG	2.5 dCi 16v 107kw	SIEMENS - Autoliv AirBag AC4
 Master	AIRBAG	2.5 dCi 16v 107kw	SIEMENS - Autoliv AirBag EC5
 Master	AIRBAG	2.5 dCi 74kw	SAGEM - Autoliv AirBag ACU 3
 Master	AIRBAG	2.5 dCi 74kw	SIEMENS - Autoliv AirBag AC4
 Master	AIRBAG	2.5 dCi 74kw	SIEMENS - Autoliv AirBag EC5
 Master	AIRBAG	2.5 dCi 85kw	SAGEM - Autoliv AirBag ACU 3
 Master	AIRBAG	2.5 dCi 85kw	SIEMENS - Autoliv AirBag AC4
 Master	AIRBAG	2.5 dCi 85kw	SIEMENS - Autoliv AirBag EC5
 Master	AIRBAG	2.5 dCi 88kw	SAGEM - Autoliv AirBag ACU 3
 Master	AIRBAG	2.5 dCi 88kw	SIEMENS - Autoliv AirBag AC4
 Master	AIRBAG	2.5 dCi 88kw	SIEMENS - Autoliv AirBag EC5
 Master	AIRBAG	2.8 DTi 84kw	SAGEM - Autoliv AirBag ACU 3
 Master	AIRBAG	2.8 DTi 84kw	SIEMENS - Autoliv AirBag AC4
 Master	AIRBAG	2.8 DTi 84kw	SIEMENS - Autoliv AirBag EC5
 Master	AIRBAG	2.8 DTi 85kw	SAGEM - Autoliv AirBag ACU 3
 Master	AIRBAG	2.8 DTi 85kw	SIEMENS - Autoliv AirBag AC4
 Master	AIRBAG	2.8 DTi 85kw	SIEMENS - Autoliv AirBag EC5
 Master	AIRBAG	3.0 dCi 100Kw	SAGEM - Autoliv AirBag ACU 3
 Master	AIRBAG	3.0 dCi 100Kw	SIEMENS - Autoliv AirBag AC4
 Master	AIRBAG	3.0 dCi 100Kw	SIEMENS - Autoliv AirBag EC5
 Master	AUTOM. TRANSMISSI	2.2 16v dCi 66kw	AUTODETECT
 Master	AUTOM. TRANSMISSI	2.5 dCi 16v 107kw	AUTODETECT
 Master	AUTOM. TRANSMISSI	2.5 dCi 88kw	AUTODETECT
 Master	AUTOM. TRANSMISSI	3.0 dCi 100Kw	AUTODETECT
 Master	ENGINE MANAGEME	2.2 16v dCi 66kw G9T-722 (01-..)	BOSCH EDC 15 C3 Common Rail
 Master	ENGINE MANAGEME	2.2 67kw J7T-782	SIEMENS MPI
 Master	ENGINE MANAGEME	2.2 71kw J7T-788	SIEMENS MPI
 Master	ENGINE MANAGEME	2.5 dCi 16v 107kw (04-..)	OEBD
 Master	ENGINE MANAGEME	2.5 dCi 88kw G9U-650 (01-..)	BOSCH EDC 15 C3 Common Rail
 Master	ENGINE MANAGEME	3.0 dCi 100Kw (04-..)	OEBD
 Master	IMMOBILIZER	1.9 dCi 60kw	SAGEM Immobilizer Key encoding
 Master	IMMOBILIZER	1.9 dTi 59kw	SAGEM Immobilizer Key encoding
 Master	IMMOBILIZER	2.1 D 60kw	SAGEM Immobilizer Key encoding
 Master	IMMOBILIZER	2.2 16v dCi 66kw	SAGEM Immobilizer Key encoding
 Master	IMMOBILIZER	2.2 67kw	SAGEM Immobilizer Key encoding
 Master	IMMOBILIZER	2.2 71kw	SAGEM Immobilizer Key encoding
 Master	IMMOBILIZER	2.5 D 59kw	SAGEM Immobilizer Key encoding
 Master	IMMOBILIZER	2.5 dCi 16v 107kw	SAGEM Immobilizer Key encoding
 Master	IMMOBILIZER	2.5 dCi 74kw	SAGEM Immobilizer Key encoding
 Master	IMMOBILIZER	2.5 dCi 88kw	SAGEM Immobilizer Key encoding
 Master	IMMOBILIZER	2.8 DTi 84kw	SAGEM Immobilizer Key encoding
 Master	IMMOBILIZER	2.8 DTi 85kw	SAGEM Immobilizer Key encoding
 Master	IMMOBILIZER	3.0 dCi 100Kw	SAGEM Immobilizer Key encoding
 Megane II	ABS	1.4 16v 59kw	AUTODETECT
 Megane II	ABS	1.4 16v 59kw	AUTODETECT
 Megane II	ABS	1.4 16v 59kw (02-..)	BOSCH ABS x.x
 Megane II	ABS	1.4 16v 72kw	AUTODETECT
 Megane II	ABS	1.4 16v 72kw	AUTODETECT
 Megane II	ABS	1.4 16v 72kw (02-..)	BOSCH ABS x.x
 Megane II	ABS	1.5 dCi 59kw	AUTODETECT
 Megane II	ABS	1.5 dCi 59kw	AUTODETECT
 Megane II	ABS	1.5 dCi 59kw (02-..)	BOSCH ABS x.x
 Megane II	ABS	1.5 dCi 63kw	AUTODETECT
 Megane II	ABS	1.5 dCi 63kw	AUTODETECT
 Megane II	ABS	1.5 dCi 63kw (02-..)	BOSCH ABS x.x
 Megane II	ABS	1.5 dCi 74kw	AUTODETECT
 Megane II	ABS	1.5 dCi 74kw	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Megane II	ABS	1.5 dCi 74kw (02-..)	BOSCH ABS x.x
 Megane II	ABS	1.5 dCi 76kw	AUTODETECT
 Megane II	ABS	1.5 dCi 76kw	AUTODETECT
 Megane II	ABS	1.5 dCi 76kw (02-..)	BOSCH ABS x.x
 Megane II	ABS	1.5 dCi 78kw	AUTODETECT
 Megane II	ABS	1.5 dCi 78kw	AUTODETECT
 Megane II	ABS	1.5 dCi 78kw (02-..)	BOSCH ABS x.x
 Megane II	ABS	1.5 dCi FAP 63kw	AUTODETECT
 Megane II	ABS	1.5 dCi FAP 63kw	AUTODETECT
 Megane II	ABS	1.5 dCi FAP 63kw (02-..)	BOSCH ABS x.x
 Megane II	ABS	1.5 dCi FAP 76kw	AUTODETECT
 Megane II	ABS	1.5 dCi FAP 76kw	AUTODETECT
 Megane II	ABS	1.5 dCi FAP 76kw (02-..)	BOSCH ABS x.x
 Megane II	ABS	1.6 16v 82kw	AUTODETECT
 Megane II	ABS	1.6 16v 82kw	AUTODETECT
 Megane II	ABS	1.6 16v 82kw (02-..)	BOSCH ABS x.x
 Megane II	ABS	1.6 16v 83kw	AUTODETECT
 Megane II	ABS	1.6 16v 83kw	AUTODETECT
 Megane II	ABS	1.6 16v 83kw (02-..)	BOSCH ABS x.x
 Megane II	ABS	1.6 16v GPL 77kw	AUTODETECT
 Megane II	ABS	1.6 16v GPL 77kw	AUTODETECT
 Megane II	ABS	1.6 16v GPL 77kw (02-..)	BOSCH ABS x.x
 Megane II	ABS	1.9 dCi 68kw	AUTODETECT
 Megane II	ABS	1.9 dCi 68kw	AUTODETECT
 Megane II	ABS	1.9 dCi 68kw (02-..)	BOSCH ABS x.x
 Megane II	ABS	1.9 dCi 85kw	AUTODETECT
 Megane II	ABS	1.9 dCi 85kw	AUTODETECT
 Megane II	ABS	1.9 dCi 85kw (02-..)	BOSCH ABS x.x
 Megane II	ABS	1.9 dCi 88kw	AUTODETECT
 Megane II	ABS	1.9 dCi 88kw	AUTODETECT
 Megane II	ABS	1.9 dCi 88kw (02-..)	BOSCH ABS x.x
 Megane II	ABS	1.9 dCi 96kw	AUTODETECT
 Megane II	ABS	1.9 dCi 96kw	AUTODETECT
 Megane II	ABS	1.9 dCi 96kw (02-..)	BOSCH ABS x.x
 Megane II	ABS	1.9 dCi FAP 81kw	AUTODETECT
 Megane II	ABS	1.9 dCi FAP 81kw	AUTODETECT
 Megane II	ABS	1.9 dCi FAP 81kw (02-..)	BOSCH ABS x.x
 Megane II	ABS	1.9 dCi FAP 85kw	AUTODETECT
 Megane II	ABS	1.9 dCi FAP 85kw	AUTODETECT
 Megane II	ABS	1.9 dCi FAP 85kw (02-..)	BOSCH ABS x.x
 Megane II	ABS	1.9 dCi FAP 96kw	AUTODETECT
 Megane II	ABS	1.9 dCi FAP 96kw	AUTODETECT
 Megane II	ABS	1.9 dCi FAP 96kw (02-..)	BOSCH ABS x.x
 Megane II	ABS	2.0 16v 100kw	AUTODETECT
 Megane II	ABS	2.0 16v 100kw	AUTODETECT
 Megane II	ABS	2.0 16v 100kw (02-..)	BOSCH ABS x.x
 Megane II	ABS	2.0 16v dCi 110kw	AUTODETECT
 Megane II	ABS	2.0 16v dCi 110kw	AUTODETECT
 Megane II	ABS	2.0 16v dCi 110kw (02-..)	BOSCH ABS x.x
 Megane II	ABS	2.0 16v dCi FAP 110kw	AUTODETECT
 Megane II	ABS	2.0 16v dCi FAP 110kw	AUTODETECT
 Megane II	ABS	2.0 16v dCi FAP 110kw (02-..)	BOSCH ABS x.x
 Megane II	ABS	2.0 16v dCi FAP 127kw	AUTODETECT
 Megane II	ABS	2.0 16v dCi FAP 127kw	AUTODETECT
 Megane II	ABS	2.0 16v dCi FAP 127kw (02-..)	BOSCH ABS x.x
 Megane II	ABS	2.0 T 16v 121kw	AUTODETECT
 Megane II	ABS	2.0 T 16v 121kw	AUTODETECT
 Megane II	ABS	2.0 T 16v 121kw (02-..)	BOSCH ABS x.x

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Megane II	ABS	2.0 T 16v 165kw	AUTODETECT
 Megane II	ABS	2.0 T 16v 165kw	AUTODETECT
 Megane II	ABS	2.0 T 16v 165kw (02-..)	BOSCH ABS x.x
 Megane II	ABS	2.0 T 16v 169kw	AUTODETECT
 Megane II	ABS	2.0 T 16v 169kw	AUTODETECT
 Megane II	ABS	2.0 T 16v 169kw (02-..)	BOSCH ABS x.x
 Megane II	ABS + TRACT. CONT	1.4 16v 59kw (02-..)	BOSCH ESP 8.0
 Megane II	ABS + TRACT. CONT	1.4 16v 72kw (02-..)	BOSCH ESP 8.0
 Megane II	ABS + TRACT. CONT	1.5 dCi 59kw (02-..)	BOSCH ESP 8.0
 Megane II	ABS + TRACT. CONT	1.5 dCi 63kw (02-..)	BOSCH ESP 8.0
 Megane II	ABS + TRACT. CONT	1.5 dCi 74kw (02-..)	BOSCH ESP 8.0
 Megane II	ABS + TRACT. CONT	1.5 dCi 76kw (02-..)	BOSCH ESP 8.0
 Megane II	ABS + TRACT. CONT	1.5 dCi 78kw (02-..)	BOSCH ESP 8.0
 Megane II	ABS + TRACT. CONT	1.5 dCi FAP 63kw (02-..)	BOSCH ESP 8.0
 Megane II	ABS + TRACT. CONT	1.5 dCi FAP 76kw (02-..)	BOSCH ESP 8.0
 Megane II	ABS + TRACT. CONT	1.6 16v 82kw (02-..)	BOSCH ESP 8.0
 Megane II	ABS + TRACT. CONT	1.6 16v 83kw (02-..)	BOSCH ESP 8.0
 Megane II	ABS + TRACT. CONT	1.6 16v GPL 77kw (02-..)	BOSCH ESP 8.0
 Megane II	ABS + TRACT. CONT	1.9 dCi 68kw (02-..)	BOSCH ESP 8.0
 Megane II	ABS + TRACT. CONT	1.9 dCi 85kw (02-..)	BOSCH ESP 8.0
 Megane II	ABS + TRACT. CONT	1.9 dCi 88kw (02-..)	BOSCH ESP 8.0
 Megane II	ABS + TRACT. CONT	1.9 dCi 96kw (02-..)	BOSCH ESP 8.0
 Megane II	ABS + TRACT. CONT	1.9 dCi FAP 81kw (02-..)	BOSCH ESP 8.0
 Megane II	ABS + TRACT. CONT	1.9 dCi FAP 85kw (02-..)	BOSCH ESP 8.0
 Megane II	ABS + TRACT. CONT	1.9 dCi FAP 96kw (02-..)	BOSCH ESP 8.0
 Megane II	ABS + TRACT. CONT	2.0 16v 100kw (02-..)	BOSCH ESP 8.0
 Megane II	ABS + TRACT. CONT	2.0 16v dCi 110kw (02-..)	BOSCH ESP 8.0
 Megane II	ABS + TRACT. CONT	2.0 16v dCi FAP 110kw (02-..)	BOSCH ESP 8.0
 Megane II	ABS + TRACT. CONT	2.0 16v dCi FAP 127kw (02-..)	BOSCH ESP 8.0
 Megane II	ABS + TRACT. CONT	2.0 T 16v 121kw (02-..)	BOSCH ESP 8.0
 Megane II	ABS + TRACT. CONT	2.0 T 16v 165kw (02-..)	BOSCH ESP 8.0
 Megane II	ABS + TRACT. CONT	2.0 T 16v 169kw (02-..)	BOSCH ESP 8.0
 Megane II	AIRBAG	1.4 16v 59kw	AUTODETECT
 Megane II	AIRBAG	1.4 16v 59kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	AIRBAG	1.4 16v 72kw	AUTODETECT
 Megane II	AIRBAG	1.4 16v 72kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	AIRBAG	1.5 dCi 59kw	AUTODETECT
 Megane II	AIRBAG	1.5 dCi 59kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	AIRBAG	1.5 dCi 63kw	AUTODETECT
 Megane II	AIRBAG	1.5 dCi 63kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	AIRBAG	1.5 dCi 74kw	AUTODETECT
 Megane II	AIRBAG	1.5 dCi 74kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	AIRBAG	1.5 dCi 76kw	AUTODETECT
 Megane II	AIRBAG	1.5 dCi 76kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	AIRBAG	1.5 dCi 78kw	AUTODETECT
 Megane II	AIRBAG	1.5 dCi 78kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	AIRBAG	1.5 dCi FAP 63kw	AUTODETECT
 Megane II	AIRBAG	1.5 dCi FAP 63kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	AIRBAG	1.5 dCi FAP 76kw	AUTODETECT
 Megane II	AIRBAG	1.5 dCi FAP 76kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	AIRBAG	1.6 16v 82kw	AUTODETECT
 Megane II	AIRBAG	1.6 16v 82kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	AIRBAG	1.6 16v 83kw	AUTODETECT
 Megane II	AIRBAG	1.6 16v 83kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	AIRBAG	1.6 16v GPL 77kw	AUTODETECT
 Megane II	AIRBAG	1.6 16v GPL 77kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	AIRBAG	1.9 dCi 68kw	AUTODETECT
 Megane II	AIRBAG	1.9 dCi 68kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Megane II	AIRBAG	1.9 dCi 85kw	AUTODETECT
 Megane II	AIRBAG	1.9 dCi 85kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	AIRBAG	1.9 dCi 88kw	AUTODETECT
 Megane II	AIRBAG	1.9 dCi 88kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	AIRBAG	1.9 dCi 96kw	AUTODETECT
 Megane II	AIRBAG	1.9 dCi 96kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	AIRBAG	1.9 dCi FAP 81kw	AUTODETECT
 Megane II	AIRBAG	1.9 dCi FAP 81kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	AIRBAG	1.9 dCi FAP 85kw	AUTODETECT
 Megane II	AIRBAG	1.9 dCi FAP 85kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	AIRBAG	1.9 dCi FAP 96kw	AUTODETECT
 Megane II	AIRBAG	1.9 dCi FAP 96kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	AIRBAG	2.0 16v 100kw	AUTODETECT
 Megane II	AIRBAG	2.0 16v 100kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	AIRBAG	2.0 16v dCi 110kw	AUTODETECT
 Megane II	AIRBAG	2.0 16v dCi 110kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	AIRBAG	2.0 16v dCi FAP 110kw	AUTODETECT
 Megane II	AIRBAG	2.0 16v dCi FAP 110kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	AIRBAG	2.0 16v dCi FAP 127kw	AUTODETECT
 Megane II	AIRBAG	2.0 16v dCi FAP 127kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	AIRBAG	2.0 T 16v 121kw	AUTODETECT
 Megane II	AIRBAG	2.0 T 16v 121kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	AIRBAG	2.0 T 16v 165kw	AUTODETECT
 Megane II	AIRBAG	2.0 T 16v 165kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	AIRBAG	2.0 T 16v 169kw	AUTODETECT
 Megane II	AIRBAG	2.0 T 16v 169kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	AUTOM. TRANSMISSI	1.4 16v 59kw	AUTODETECT
 Megane II	AUTOM. TRANSMISSI	1.4 16v 72kw	AUTODETECT
 Megane II	AUTOM. TRANSMISSI	1.5 dCi 59kw	AUTODETECT
 Megane II	AUTOM. TRANSMISSI	1.5 dCi 63kw	AUTODETECT
 Megane II	AUTOM. TRANSMISSI	1.5 dCi 74kw	AUTODETECT
 Megane II	AUTOM. TRANSMISSI	1.5 dCi 76kw	AUTODETECT
 Megane II	AUTOM. TRANSMISSI	1.5 dCi 78kw	AUTODETECT
 Megane II	AUTOM. TRANSMISSI	1.5 dCi FAP 63kw	AUTODETECT
 Megane II	AUTOM. TRANSMISSI	1.5 dCi FAP 76kw	AUTODETECT
 Megane II	AUTOM. TRANSMISSI	1.6 16v 82kw	AUTODETECT
 Megane II	AUTOM. TRANSMISSI	1.6 16v 83kw	AUTODETECT
 Megane II	AUTOM. TRANSMISSI	1.6 16v GPL 77kw	AUTODETECT
 Megane II	AUTOM. TRANSMISSI	1.9 dCi 68kw	AUTODETECT
 Megane II	AUTOM. TRANSMISSI	1.9 dCi 85kw	AUTODETECT
 Megane II	AUTOM. TRANSMISSI	1.9 dCi 88kw	AUTODETECT
 Megane II	AUTOM. TRANSMISSI	1.9 dCi 96kw	AUTODETECT
 Megane II	AUTOM. TRANSMISSI	1.9 dCi FAP 81kw	AUTODETECT
 Megane II	AUTOM. TRANSMISSI	1.9 dCi FAP 85kw	AUTODETECT
 Megane II	AUTOM. TRANSMISSI	1.9 dCi FAP 96kw	AUTODETECT
 Megane II	AUTOM. TRANSMISSI	2.0 16v 100kw	AUTODETECT
 Megane II	AUTOM. TRANSMISSI	2.0 16v dCi 110kw	AUTODETECT
 Megane II	AUTOM. TRANSMISSI	2.0 16v dCi FAP 110kw	AUTODETECT
 Megane II	AUTOM. TRANSMISSI	2.0 16v dCi FAP 127kw	AUTODETECT
 Megane II	AUTOM. TRANSMISSI	2.0 T 16v 121kw	AUTODETECT
 Megane II	AUTOM. TRANSMISSI	2.0 T 16v 165kw	AUTODETECT
 Megane II	AUTOM. TRANSMISSI	2.0 T 16v 169kw	AUTODETECT
 Megane II	CHASSIS NETWORK	1.4 16v 59kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.4 16v 59kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.4 16v 59kw	UCH AUTODETECT
 Megane II	CHASSIS NETWORK	1.4 16v 59kw	UPC AUTODETECT
 Megane II	CHASSIS NETWORK	1.4 16v 59kw (02-..)	Body Computer UCH
 Megane II	CHASSIS NETWORK	1.4 16v 59kw (02-05)	UPC

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Megane II	CHASSIS NETWORK	1.4 16v 59kw (05-..)	UPC
 Megane II	CHASSIS NETWORK	1.4 16v 72kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.4 16v 72kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.4 16v 72kw	UCH AUTODETECT
 Megane II	CHASSIS NETWORK	1.4 16v 72kw	UPC AUTODETECT
 Megane II	CHASSIS NETWORK	1.4 16v 72kw (02-..)	Body Computer UCH
 Megane II	CHASSIS NETWORK	1.4 16v 72kw (02-05)	UPC
 Megane II	CHASSIS NETWORK	1.4 16v 72kw (05-..)	UPC
 Megane II	CHASSIS NETWORK	1.5 dCi 59kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.5 dCi 59kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.5 dCi 59kw	UCH AUTODETECT
 Megane II	CHASSIS NETWORK	1.5 dCi 59kw	UPC AUTODETECT
 Megane II	CHASSIS NETWORK	1.5 dCi 59kw (02-..)	Body Computer UCH
 Megane II	CHASSIS NETWORK	1.5 dCi 59kw (02-05)	UPC
 Megane II	CHASSIS NETWORK	1.5 dCi 59kw (05-..)	UPC
 Megane II	CHASSIS NETWORK	1.5 dCi 63kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.5 dCi 63kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.5 dCi 63kw	UCH AUTODETECT
 Megane II	CHASSIS NETWORK	1.5 dCi 63kw	UPC AUTODETECT
 Megane II	CHASSIS NETWORK	1.5 dCi 63kw (02-..)	Body Computer UCH
 Megane II	CHASSIS NETWORK	1.5 dCi 63kw (02-05)	UPC
 Megane II	CHASSIS NETWORK	1.5 dCi 63kw (05-..)	UPC
 Megane II	CHASSIS NETWORK	1.5 dCi 74kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.5 dCi 74kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.5 dCi 74kw	UCH AUTODETECT
 Megane II	CHASSIS NETWORK	1.5 dCi 74kw	UPC AUTODETECT
 Megane II	CHASSIS NETWORK	1.5 dCi 74kw (02-..)	Body Computer UCH
 Megane II	CHASSIS NETWORK	1.5 dCi 74kw (02-05)	UPC
 Megane II	CHASSIS NETWORK	1.5 dCi 74kw (05-..)	UPC
 Megane II	CHASSIS NETWORK	1.5 dCi 76kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.5 dCi 76kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.5 dCi 76kw	UCH AUTODETECT
 Megane II	CHASSIS NETWORK	1.5 dCi 76kw	UPC AUTODETECT
 Megane II	CHASSIS NETWORK	1.5 dCi 76kw (02-..)	Body Computer UCH
 Megane II	CHASSIS NETWORK	1.5 dCi 76kw (02-05)	UPC
 Megane II	CHASSIS NETWORK	1.5 dCi 76kw (05-..)	UPC
 Megane II	CHASSIS NETWORK	1.5 dCi 78kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.5 dCi 78kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.5 dCi 78kw	UCH AUTODETECT
 Megane II	CHASSIS NETWORK	1.5 dCi 78kw	UPC AUTODETECT
 Megane II	CHASSIS NETWORK	1.5 dCi 78kw (02-..)	Body Computer UCH
 Megane II	CHASSIS NETWORK	1.5 dCi 78kw (02-05)	UPC
 Megane II	CHASSIS NETWORK	1.5 dCi 78kw (05-..)	UPC
 Megane II	CHASSIS NETWORK	1.5 dCi FAP 63kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.5 dCi FAP 63kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.5 dCi FAP 63kw	UCH AUTODETECT
 Megane II	CHASSIS NETWORK	1.5 dCi FAP 63kw	UPC AUTODETECT
 Megane II	CHASSIS NETWORK	1.5 dCi FAP 63kw (02-..)	Body Computer UCH
 Megane II	CHASSIS NETWORK	1.5 dCi FAP 63kw (02-05)	UPC
 Megane II	CHASSIS NETWORK	1.5 dCi FAP 63kw (05-..)	UPC
 Megane II	CHASSIS NETWORK	1.5 dCi FAP 76kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.5 dCi FAP 76kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.5 dCi FAP 76kw	UCH AUTODETECT
 Megane II	CHASSIS NETWORK	1.5 dCi FAP 76kw	UPC AUTODETECT
 Megane II	CHASSIS NETWORK	1.5 dCi FAP 76kw (02-..)	Body Computer UCH
 Megane II	CHASSIS NETWORK	1.5 dCi FAP 76kw (02-05)	UPC
 Megane II	CHASSIS NETWORK	1.5 dCi FAP 76kw (05-..)	UPC
 Megane II	CHASSIS NETWORK	1.6 16v 82kw	UCC AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Megane II	CHASSIS NETWORK	1.6 16v 82kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.6 16v 82kw	UCH AUTODETECT
 Megane II	CHASSIS NETWORK	1.6 16v 82kw	UPC AUTODETECT
 Megane II	CHASSIS NETWORK	1.6 16v 82kw (02-..)	Body Computer UCH
 Megane II	CHASSIS NETWORK	1.6 16v 82kw (02-05)	UPC
 Megane II	CHASSIS NETWORK	1.6 16v 82kw (05-..)	UPC
 Megane II	CHASSIS NETWORK	1.6 16v 83kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.6 16v 83kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.6 16v 83kw	UCH AUTODETECT
 Megane II	CHASSIS NETWORK	1.6 16v 83kw	UPC AUTODETECT
 Megane II	CHASSIS NETWORK	1.6 16v 83kw (02-..)	Body Computer UCH
 Megane II	CHASSIS NETWORK	1.6 16v 83kw (02-05)	UPC
 Megane II	CHASSIS NETWORK	1.6 16v 83kw (05-..)	UPC
 Megane II	CHASSIS NETWORK	1.6 16v GPL 77kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.6 16v GPL 77kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.6 16v GPL 77kw	UCH AUTODETECT
 Megane II	CHASSIS NETWORK	1.6 16v GPL 77kw	UPC AUTODETECT
 Megane II	CHASSIS NETWORK	1.6 16v GPL 77kw (02-..)	Body Computer UCH
 Megane II	CHASSIS NETWORK	1.6 16v GPL 77kw (02-05)	UPC
 Megane II	CHASSIS NETWORK	1.6 16v GPL 77kw (05-..)	UPC
 Megane II	CHASSIS NETWORK	1.9 dCi 68kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.9 dCi 68kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.9 dCi 68kw	UCH AUTODETECT
 Megane II	CHASSIS NETWORK	1.9 dCi 68kw	UPC AUTODETECT
 Megane II	CHASSIS NETWORK	1.9 dCi 68kw (02-..)	Body Computer UCH
 Megane II	CHASSIS NETWORK	1.9 dCi 68kw (02-05)	UPC
 Megane II	CHASSIS NETWORK	1.9 dCi 68kw (05-..)	UPC
 Megane II	CHASSIS NETWORK	1.9 dCi 85kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.9 dCi 85kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.9 dCi 85kw	UCH AUTODETECT
 Megane II	CHASSIS NETWORK	1.9 dCi 85kw	UPC AUTODETECT
 Megane II	CHASSIS NETWORK	1.9 dCi 85kw (02-..)	Body Computer UCH
 Megane II	CHASSIS NETWORK	1.9 dCi 85kw (02-05)	UPC
 Megane II	CHASSIS NETWORK	1.9 dCi 85kw (05-..)	UPC
 Megane II	CHASSIS NETWORK	1.9 dCi 88kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.9 dCi 88kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.9 dCi 88kw	UCH AUTODETECT
 Megane II	CHASSIS NETWORK	1.9 dCi 88kw	UPC AUTODETECT
 Megane II	CHASSIS NETWORK	1.9 dCi 88kw (02-..)	Body Computer UCH
 Megane II	CHASSIS NETWORK	1.9 dCi 88kw (02-05)	UPC
 Megane II	CHASSIS NETWORK	1.9 dCi 88kw (05-..)	UPC
 Megane II	CHASSIS NETWORK	1.9 dCi 96kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.9 dCi 96kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.9 dCi 96kw	UCH AUTODETECT
 Megane II	CHASSIS NETWORK	1.9 dCi 96kw	UPC AUTODETECT
 Megane II	CHASSIS NETWORK	1.9 dCi 96kw (02-..)	Body Computer UCH
 Megane II	CHASSIS NETWORK	1.9 dCi 96kw (02-05)	UPC
 Megane II	CHASSIS NETWORK	1.9 dCi 96kw (05-..)	UPC
 Megane II	CHASSIS NETWORK	1.9 dCi FAP 81kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.9 dCi FAP 81kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.9 dCi FAP 81kw	UCH AUTODETECT
 Megane II	CHASSIS NETWORK	1.9 dCi FAP 81kw	UPC AUTODETECT
 Megane II	CHASSIS NETWORK	1.9 dCi FAP 81kw (02-..)	Body Computer UCH
 Megane II	CHASSIS NETWORK	1.9 dCi FAP 81kw (02-05)	UPC
 Megane II	CHASSIS NETWORK	1.9 dCi FAP 81kw (05-..)	UPC
 Megane II	CHASSIS NETWORK	1.9 dCi FAP 85kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.9 dCi FAP 85kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.9 dCi FAP 85kw	UCH AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Megane II	CHASSIS NETWORK	1.9 dCi FAP 85kw	UPC AUTODETECT
 Megane II	CHASSIS NETWORK	1.9 dCi FAP 85kw (02-..)	Body Computer UCH
 Megane II	CHASSIS NETWORK	1.9 dCi FAP 85kw (02-05)	UPC
 Megane II	CHASSIS NETWORK	1.9 dCi FAP 85kw (05-..)	UPC
 Megane II	CHASSIS NETWORK	1.9 dCi FAP 96kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.9 dCi FAP 96kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	1.9 dCi FAP 96kw	UCH AUTODETECT
 Megane II	CHASSIS NETWORK	1.9 dCi FAP 96kw	UPC AUTODETECT
 Megane II	CHASSIS NETWORK	1.9 dCi FAP 96kw (02-..)	Body Computer UCH
 Megane II	CHASSIS NETWORK	1.9 dCi FAP 96kw (02-05)	UPC
 Megane II	CHASSIS NETWORK	1.9 dCi FAP 96kw (05-..)	UPC
 Megane II	CHASSIS NETWORK	2.0 16v 100kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	2.0 16v 100kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	2.0 16v 100kw	UCH AUTODETECT
 Megane II	CHASSIS NETWORK	2.0 16v 100kw	UPC AUTODETECT
 Megane II	CHASSIS NETWORK	2.0 16v 100kw (02-..)	Body Computer UCH
 Megane II	CHASSIS NETWORK	2.0 16v 100kw (02-05)	UPC
 Megane II	CHASSIS NETWORK	2.0 16v 100kw (05-..)	UPC
 Megane II	CHASSIS NETWORK	2.0 16v dCi 110kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	2.0 16v dCi 110kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	2.0 16v dCi 110kw	UCH AUTODETECT
 Megane II	CHASSIS NETWORK	2.0 16v dCi 110kw	UPC AUTODETECT
 Megane II	CHASSIS NETWORK	2.0 16v dCi 110kw (02-..)	Body Computer UCH
 Megane II	CHASSIS NETWORK	2.0 16v dCi 110kw (02-05)	UPC
 Megane II	CHASSIS NETWORK	2.0 16v dCi 110kw (05-..)	UPC
 Megane II	CHASSIS NETWORK	2.0 16v dCi FAP 110kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	2.0 16v dCi FAP 110kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	2.0 16v dCi FAP 110kw	UCH AUTODETECT
 Megane II	CHASSIS NETWORK	2.0 16v dCi FAP 110kw	UPC AUTODETECT
 Megane II	CHASSIS NETWORK	2.0 16v dCi FAP 110kw (02-..)	Body Computer UCH
 Megane II	CHASSIS NETWORK	2.0 16v dCi FAP 110kw (02-05)	UPC
 Megane II	CHASSIS NETWORK	2.0 16v dCi FAP 110kw (05-..)	UPC
 Megane II	CHASSIS NETWORK	2.0 16v dCi FAP 127kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	2.0 16v dCi FAP 127kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	2.0 16v dCi FAP 127kw	UCH AUTODETECT
 Megane II	CHASSIS NETWORK	2.0 16v dCi FAP 127kw	UPC AUTODETECT
 Megane II	CHASSIS NETWORK	2.0 16v dCi FAP 127kw (02-..)	Body Computer UCH
 Megane II	CHASSIS NETWORK	2.0 16v dCi FAP 127kw (02-05)	UPC
 Megane II	CHASSIS NETWORK	2.0 16v dCi FAP 127kw (05-..)	UPC
 Megane II	CHASSIS NETWORK	2.0 T 16v 121kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	2.0 T 16v 121kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	2.0 T 16v 121kw	UCH AUTODETECT
 Megane II	CHASSIS NETWORK	2.0 T 16v 121kw	UPC AUTODETECT
 Megane II	CHASSIS NETWORK	2.0 T 16v 121kw (02-..)	Body Computer UCH
 Megane II	CHASSIS NETWORK	2.0 T 16v 121kw (02-05)	UPC
 Megane II	CHASSIS NETWORK	2.0 T 16v 121kw (05-..)	UPC
 Megane II	CHASSIS NETWORK	2.0 T 16v 165kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	2.0 T 16v 165kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	2.0 T 16v 165kw	UCH AUTODETECT
 Megane II	CHASSIS NETWORK	2.0 T 16v 165kw	UPC AUTODETECT
 Megane II	CHASSIS NETWORK	2.0 T 16v 165kw (02-..)	Body Computer UCH
 Megane II	CHASSIS NETWORK	2.0 T 16v 165kw (02-05)	UPC
 Megane II	CHASSIS NETWORK	2.0 T 16v 165kw (05-..)	UPC
 Megane II	CHASSIS NETWORK	2.0 T 16v 169kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	2.0 T 16v 169kw	UCC AUTODETECT
 Megane II	CHASSIS NETWORK	2.0 T 16v 169kw	UCH AUTODETECT
 Megane II	CHASSIS NETWORK	2.0 T 16v 169kw	UPC AUTODETECT
 Megane II	CHASSIS NETWORK	2.0 T 16v 169kw (02-..)	Body Computer UCH

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Megane II	CHASSIS NETWORK	2.0 T 16v 169kw (02-05)	UPC
 Megane II	CHASSIS NETWORK	2.0 T 16v 169kw (05-..)	UPC
 Megane II	CLIMA	1.4 16v 59kw	AUTODETECT
 Megane II	CLIMA	1.4 16v 59kw (02-..)	DELPHI Klima Climautomatic
 Megane II	CLIMA	1.4 16v 72kw	AUTODETECT
 Megane II	CLIMA	1.4 16v 72kw (02-..)	DELPHI Klima Climautomatic
 Megane II	CLIMA	1.5 dCi 59kw	AUTODETECT
 Megane II	CLIMA	1.5 dCi 59kw (02-..)	DELPHI Klima Climautomatic
 Megane II	CLIMA	1.5 dCi 63kw	AUTODETECT
 Megane II	CLIMA	1.5 dCi 63kw (02-..)	DELPHI Klima Climautomatic
 Megane II	CLIMA	1.5 dCi 74kw	AUTODETECT
 Megane II	CLIMA	1.5 dCi 74kw (02-..)	DELPHI Klima Climautomatic
 Megane II	CLIMA	1.5 dCi 76kw	AUTODETECT
 Megane II	CLIMA	1.5 dCi 76kw (02-..)	DELPHI Klima Climautomatic
 Megane II	CLIMA	1.5 dCi 78kw	AUTODETECT
 Megane II	CLIMA	1.5 dCi 78kw (02-..)	DELPHI Klima Climautomatic
 Megane II	CLIMA	1.5 dCi FAP 63kw	AUTODETECT
 Megane II	CLIMA	1.5 dCi FAP 63kw (02-..)	DELPHI Klima Climautomatic
 Megane II	CLIMA	1.5 dCi FAP 76kw	AUTODETECT
 Megane II	CLIMA	1.5 dCi FAP 76kw (02-..)	DELPHI Klima Climautomatic
 Megane II	CLIMA	1.6 16v 82kw	AUTODETECT
 Megane II	CLIMA	1.6 16v 82kw (02-..)	DELPHI Klima Climautomatic
 Megane II	CLIMA	1.6 16v 83kw	AUTODETECT
 Megane II	CLIMA	1.6 16v 83kw (02-..)	DELPHI Klima Climautomatic
 Megane II	CLIMA	1.6 16v GPL 77kw	AUTODETECT
 Megane II	CLIMA	1.6 16v GPL 77kw (02-..)	DELPHI Klima Climautomatic
 Megane II	CLIMA	1.9 dCi 68kw	AUTODETECT
 Megane II	CLIMA	1.9 dCi 68kw (02-..)	DELPHI Klima Climautomatic
 Megane II	CLIMA	1.9 dCi 85kw	AUTODETECT
 Megane II	CLIMA	1.9 dCi 85kw (02-..)	DELPHI Klima Climautomatic
 Megane II	CLIMA	1.9 dCi 88kw	AUTODETECT
 Megane II	CLIMA	1.9 dCi 88kw (02-..)	DELPHI Klima Climautomatic
 Megane II	CLIMA	1.9 dCi 96kw	AUTODETECT
 Megane II	CLIMA	1.9 dCi 96kw (02-..)	DELPHI Klima Climautomatic
 Megane II	CLIMA	1.9 dCi FAP 81kw	AUTODETECT
 Megane II	CLIMA	1.9 dCi FAP 81kw (02-..)	DELPHI Klima Climautomatic
 Megane II	CLIMA	1.9 dCi FAP 85kw	AUTODETECT
 Megane II	CLIMA	1.9 dCi FAP 85kw (02-..)	DELPHI Klima Climautomatic
 Megane II	CLIMA	1.9 dCi FAP 96kw	AUTODETECT
 Megane II	CLIMA	1.9 dCi FAP 96kw (02-..)	DELPHI Klima Climautomatic
 Megane II	CLIMA	2.0 16v 100kw	AUTODETECT
 Megane II	CLIMA	2.0 16v 100kw (02-..)	DELPHI Klima Climautomatic
 Megane II	CLIMA	2.0 16v dCi 110kw	AUTODETECT
 Megane II	CLIMA	2.0 16v dCi 110kw (02-..)	DELPHI Klima Climautomatic
 Megane II	CLIMA	2.0 16v dCi FAP 110kw	AUTODETECT
 Megane II	CLIMA	2.0 16v dCi FAP 110kw (02-..)	DELPHI Klima Climautomatic
 Megane II	CLIMA	2.0 16v dCi FAP 127kw	AUTODETECT
 Megane II	CLIMA	2.0 16v dCi FAP 127kw (02-..)	DELPHI Klima Climautomatic
 Megane II	CLIMA	2.0 T 16v 121kw	AUTODETECT
 Megane II	CLIMA	2.0 T 16v 121kw (02-..)	DELPHI Klima Climautomatic
 Megane II	CLIMA	2.0 T 16v 165kw	AUTODETECT
 Megane II	CLIMA	2.0 T 16v 165kw (02-..)	DELPHI Klima Climautomatic
 Megane II	CLIMA	2.0 T 16v 169kw	AUTODETECT
 Megane II	CLIMA	2.0 T 16v 169kw (02-..)	DELPHI Klima Climautomatic
 Megane II	CONV. TOP/SUNROO	1.4 16v 59kw	AUTODETECT
 Megane II	CONV. TOP/SUNROO	1.4 16v 72kw	AUTODETECT
 Megane II	CONV. TOP/SUNROO	1.5 dCi 59kw	AUTODETECT
 Megane II	CONV. TOP/SUNROO	1.5 dCi 63kw	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Megane II	CONV. TOP/SUNROO	1.5 dCi 74kw	AUTODETECT
 Megane II	CONV. TOP/SUNROO	1.5 dCi 76kw	AUTODETECT
 Megane II	CONV. TOP/SUNROO	1.5 dCi 78kw	AUTODETECT
 Megane II	CONV. TOP/SUNROO	1.5 dCi FAP 63kw	AUTODETECT
 Megane II	CONV. TOP/SUNROO	1.5 dCi FAP 76kw	AUTODETECT
 Megane II	CONV. TOP/SUNROO	1.6 16v 82kw	AUTODETECT
 Megane II	CONV. TOP/SUNROO	1.6 16v 83kw	AUTODETECT
 Megane II	CONV. TOP/SUNROO	1.6 16v GPL 77kw	AUTODETECT
 Megane II	CONV. TOP/SUNROO	1.9 dCi 68kw	AUTODETECT
 Megane II	CONV. TOP/SUNROO	1.9 dCi 85kw	AUTODETECT
 Megane II	CONV. TOP/SUNROO	1.9 dCi 88kw	AUTODETECT
 Megane II	CONV. TOP/SUNROO	1.9 dCi 96kw	AUTODETECT
 Megane II	CONV. TOP/SUNROO	1.9 dCi FAP 81kw	AUTODETECT
 Megane II	CONV. TOP/SUNROO	1.9 dCi FAP 85kw	AUTODETECT
 Megane II	CONV. TOP/SUNROO	1.9 dCi FAP 96kw	AUTODETECT
 Megane II	CONV. TOP/SUNROO	2.0 16v 100kw	AUTODETECT
 Megane II	CONV. TOP/SUNROO	2.0 16v dCi 110kw	AUTODETECT
 Megane II	CONV. TOP/SUNROO	2.0 16v dCi FAP 110kw	AUTODETECT
 Megane II	CONV. TOP/SUNROO	2.0 16v dCi FAP 127kw	AUTODETECT
 Megane II	CONV. TOP/SUNROO	2.0 T 16v 121kw	AUTODETECT
 Megane II	CONV. TOP/SUNROO	2.0 T 16v 165kw	AUTODETECT
 Megane II	CONV. TOP/SUNROO	2.0 T 16v 169kw	AUTODETECT
 Megane II	DASHBOARD	1.4 16v 59kw	AUTODETECT
 Megane II	DASHBOARD	1.4 16v 59kw	AUTODETECT
 Megane II	DASHBOARD	1.4 16v 59kw (02-..)	VISTEON Dashboard LS
 Megane II	DASHBOARD	1.4 16v 72kw	AUTODETECT
 Megane II	DASHBOARD	1.4 16v 72kw	AUTODETECT
 Megane II	DASHBOARD	1.4 16v 72kw (02-..)	VISTEON Dashboard LS
 Megane II	DASHBOARD	1.5 dCi 59kw	AUTODETECT
 Megane II	DASHBOARD	1.5 dCi 59kw	AUTODETECT
 Megane II	DASHBOARD	1.5 dCi 59kw (02-..)	VISTEON Dashboard LS
 Megane II	DASHBOARD	1.5 dCi 63kw	AUTODETECT
 Megane II	DASHBOARD	1.5 dCi 63kw	AUTODETECT
 Megane II	DASHBOARD	1.5 dCi 63kw (02-..)	VISTEON Dashboard LS
 Megane II	DASHBOARD	1.5 dCi 74kw	AUTODETECT
 Megane II	DASHBOARD	1.5 dCi 74kw	AUTODETECT
 Megane II	DASHBOARD	1.5 dCi 74kw (02-..)	VISTEON Dashboard LS
 Megane II	DASHBOARD	1.5 dCi 76kw	AUTODETECT
 Megane II	DASHBOARD	1.5 dCi 76kw	AUTODETECT
 Megane II	DASHBOARD	1.5 dCi 76kw (02-..)	VISTEON Dashboard LS
 Megane II	DASHBOARD	1.5 dCi 78kw	AUTODETECT
 Megane II	DASHBOARD	1.5 dCi 78kw	AUTODETECT
 Megane II	DASHBOARD	1.5 dCi 78kw (02-..)	VISTEON Dashboard LS
 Megane II	DASHBOARD	1.5 dCi FAP 63kw	AUTODETECT
 Megane II	DASHBOARD	1.5 dCi FAP 63kw	AUTODETECT
 Megane II	DASHBOARD	1.5 dCi FAP 63kw (02-..)	VISTEON Dashboard LS
 Megane II	DASHBOARD	1.5 dCi FAP 76kw	AUTODETECT
 Megane II	DASHBOARD	1.5 dCi FAP 76kw	AUTODETECT
 Megane II	DASHBOARD	1.5 dCi FAP 76kw (02-..)	VISTEON Dashboard LS
 Megane II	DASHBOARD	1.6 16v 82kw	AUTODETECT
 Megane II	DASHBOARD	1.6 16v 82kw	AUTODETECT
 Megane II	DASHBOARD	1.6 16v 82kw (02-..)	VISTEON Dashboard LS
 Megane II	DASHBOARD	1.6 16v 83kw	AUTODETECT
 Megane II	DASHBOARD	1.6 16v 83kw	AUTODETECT
 Megane II	DASHBOARD	1.6 16v 83kw (02-..)	VISTEON Dashboard LS
 Megane II	DASHBOARD	1.6 16v GPL 77kw	AUTODETECT
 Megane II	DASHBOARD	1.6 16v GPL 77kw	AUTODETECT
 Megane II	DASHBOARD	1.6 16v GPL 77kw (02-..)	VISTEON Dashboard LS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Megane II	DASHBOARD	1.9 dCi 68kw	AUTODETECT
 Megane II	DASHBOARD	1.9 dCi 68kw	AUTODETECT
 Megane II	DASHBOARD	1.9 dCi 68kw (02-..)	VISTEON Dashboard LS
 Megane II	DASHBOARD	1.9 dCi 85kw	AUTODETECT
 Megane II	DASHBOARD	1.9 dCi 85kw	AUTODETECT
 Megane II	DASHBOARD	1.9 dCi 85kw (02-..)	VISTEON Dashboard LS
 Megane II	DASHBOARD	1.9 dCi 88kw	AUTODETECT
 Megane II	DASHBOARD	1.9 dCi 88kw	AUTODETECT
 Megane II	DASHBOARD	1.9 dCi 88kw (02-..)	VISTEON Dashboard LS
 Megane II	DASHBOARD	1.9 dCi 96kw	AUTODETECT
 Megane II	DASHBOARD	1.9 dCi 96kw	AUTODETECT
 Megane II	DASHBOARD	1.9 dCi 96kw (02-..)	VISTEON Dashboard LS
 Megane II	DASHBOARD	1.9 dCi FAP 81kw	AUTODETECT
 Megane II	DASHBOARD	1.9 dCi FAP 81kw	AUTODETECT
 Megane II	DASHBOARD	1.9 dCi FAP 81kw (02-..)	VISTEON Dashboard LS
 Megane II	DASHBOARD	1.9 dCi FAP 85kw	AUTODETECT
 Megane II	DASHBOARD	1.9 dCi FAP 85kw (02-..)	VISTEON Dashboard LS
 Megane II	DASHBOARD	1.9 dCi FAP 96kw	AUTODETECT
 Megane II	DASHBOARD	1.9 dCi FAP 96kw	AUTODETECT
 Megane II	DASHBOARD	1.9 dCi FAP 96kw (02-..)	VISTEON Dashboard LS
 Megane II	DASHBOARD	2.0 16v 100kw	AUTODETECT
 Megane II	DASHBOARD	2.0 16v 100kw	AUTODETECT
 Megane II	DASHBOARD	2.0 16v 100kw (02-..)	VISTEON Dashboard LS
 Megane II	DASHBOARD	2.0 16v dCi 110kw	AUTODETECT
 Megane II	DASHBOARD	2.0 16v dCi 110kw	AUTODETECT
 Megane II	DASHBOARD	2.0 16v dCi 110kw (02-..)	VISTEON Dashboard LS
 Megane II	DASHBOARD	2.0 16v dCi FAP 110kw	AUTODETECT
 Megane II	DASHBOARD	2.0 16v dCi FAP 110kw	AUTODETECT
 Megane II	DASHBOARD	2.0 16v dCi FAP 110kw (02-..)	VISTEON Dashboard LS
 Megane II	DASHBOARD	2.0 16v dCi FAP 127kw	AUTODETECT
 Megane II	DASHBOARD	2.0 16v dCi FAP 127kw	AUTODETECT
 Megane II	DASHBOARD	2.0 16v dCi FAP 127kw (02-..)	VISTEON Dashboard LS
 Megane II	DASHBOARD	2.0 T 16v 121kw	AUTODETECT
 Megane II	DASHBOARD	2.0 T 16v 121kw	AUTODETECT
 Megane II	DASHBOARD	2.0 T 16v 121kw (02-..)	VISTEON Dashboard LS
 Megane II	DASHBOARD	2.0 T 16v 165kw	AUTODETECT
 Megane II	DASHBOARD	2.0 T 16v 165kw	AUTODETECT
 Megane II	DASHBOARD	2.0 T 16v 165kw (02-..)	VISTEON Dashboard LS
 Megane II	DASHBOARD	2.0 T 16v 169kw	AUTODETECT
 Megane II	DASHBOARD	2.0 T 16v 169kw	AUTODETECT
 Megane II	DASHBOARD	2.0 T 16v 169kw (02-..)	VISTEON Dashboard LS
 Megane II	ELECTRIC STEERING	1.4 16v 59kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.4 16v 59kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.4 16v 59kw (02-..)	KOYO EPS
 Megane II	ELECTRIC STEERING	1.4 16v 72kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.4 16v 72kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.4 16v 72kw (02-..)	KOYO EPS
 Megane II	ELECTRIC STEERING	1.5 dCi 59kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.5 dCi 59kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.5 dCi 59kw (02-..)	KOYO EPS
 Megane II	ELECTRIC STEERING	1.5 dCi 63kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.5 dCi 63kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.5 dCi 63kw (02-..)	KOYO EPS
 Megane II	ELECTRIC STEERING	1.5 dCi 74kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.5 dCi 74kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.5 dCi 74kw (02-..)	KOYO EPS
 Megane II	ELECTRIC STEERING	1.5 dCi 76kw	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Megane II	ELECTRIC STEERING	1.5 dCi 76kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.5 dCi 76kw (02-..)	KOYO EPS
 Megane II	ELECTRIC STEERING	1.5 dCi 78kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.5 dCi 78kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.5 dCi 78kw (02-..)	KOYO EPS
 Megane II	ELECTRIC STEERING	1.5 dCi FAP 63kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.5 dCi FAP 63kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.5 dCi FAP 63kw (02-..)	KOYO EPS
 Megane II	ELECTRIC STEERING	1.5 dCi FAP 76kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.5 dCi FAP 76kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.5 dCi FAP 76kw (02-..)	KOYO EPS
 Megane II	ELECTRIC STEERING	1.6 16v 82kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.6 16v 82kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.6 16v 82kw (02-..)	KOYO EPS
 Megane II	ELECTRIC STEERING	1.6 16v 83kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.6 16v 83kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.6 16v 83kw (02-..)	KOYO EPS
 Megane II	ELECTRIC STEERING	1.6 16v GPL 77kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.6 16v GPL 77kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.6 16v GPL 77kw (02-..)	KOYO EPS
 Megane II	ELECTRIC STEERING	1.9 dCi 68kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.9 dCi 68kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.9 dCi 68kw (02-..)	KOYO EPS
 Megane II	ELECTRIC STEERING	1.9 dCi 85kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.9 dCi 85kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.9 dCi 85kw (02-..)	KOYO EPS
 Megane II	ELECTRIC STEERING	1.9 dCi 88kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.9 dCi 88kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.9 dCi 88kw (02-..)	KOYO EPS
 Megane II	ELECTRIC STEERING	1.9 dCi 96kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.9 dCi 96kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.9 dCi 96kw (02-..)	KOYO EPS
 Megane II	ELECTRIC STEERING	1.9 dCi FAP 81kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.9 dCi FAP 81kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.9 dCi FAP 81kw (02-..)	KOYO EPS
 Megane II	ELECTRIC STEERING	1.9 dCi FAP 85kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.9 dCi FAP 85kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.9 dCi FAP 85kw (02-..)	KOYO EPS
 Megane II	ELECTRIC STEERING	1.9 dCi FAP 96kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.9 dCi FAP 96kw	AUTODETECT
 Megane II	ELECTRIC STEERING	1.9 dCi FAP 96kw (02-..)	KOYO EPS
 Megane II	ELECTRIC STEERING	2.0 16v 100kw	AUTODETECT
 Megane II	ELECTRIC STEERING	2.0 16v 100kw	AUTODETECT
 Megane II	ELECTRIC STEERING	2.0 16v 100kw (02-..)	KOYO EPS
 Megane II	ELECTRIC STEERING	2.0 16v dCi 110kw	AUTODETECT
 Megane II	ELECTRIC STEERING	2.0 16v dCi 110kw	AUTODETECT
 Megane II	ELECTRIC STEERING	2.0 16v dCi 110kw (02-..)	KOYO EPS
 Megane II	ELECTRIC STEERING	2.0 16v dCi FAP 110kw	AUTODETECT
 Megane II	ELECTRIC STEERING	2.0 16v dCi FAP 110kw	AUTODETECT
 Megane II	ELECTRIC STEERING	2.0 16v dCi FAP 110kw (02-..)	KOYO EPS
 Megane II	ELECTRIC STEERING	2.0 16v dCi FAP 127kw	AUTODETECT
 Megane II	ELECTRIC STEERING	2.0 16v dCi FAP 127kw	AUTODETECT
 Megane II	ELECTRIC STEERING	2.0 16v dCi FAP 127kw (02-..)	KOYO EPS
 Megane II	ELECTRIC STEERING	2.0 T 16v 121kw	AUTODETECT
 Megane II	ELECTRIC STEERING	2.0 T 16v 121kw	AUTODETECT
 Megane II	ELECTRIC STEERING	2.0 T 16v 121kw (02-..)	KOYO EPS
 Megane II	ELECTRIC STEERING	2.0 T 16v 165kw	AUTODETECT
 Megane II	ELECTRIC STEERING	2.0 T 16v 165kw	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Megane II	ELECTRIC STEERING	2.0 T 16v 165kw (02-..)	KOYO EPS
 Megane II	ELECTRIC STEERING	2.0 T 16v 169kw	AUTODETECT
 Megane II	ELECTRIC STEERING	2.0 T 16v 169kw	AUTODETECT
 Megane II	ELECTRIC STEERING	2.0 T 16v 169kw (02-..)	KOYO EPS
 Megane II	ENGINE MANAGEME	1.4 16v 59kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.4 16v 59kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.4 16v 59kw K4J-732	SAGEM MPI 3000
 Megane II	ENGINE MANAGEME	1.4 16v 72kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.4 16v 72kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.4 16v 72kw K4J-730	SAGEM MPI 3000
 Megane II	ENGINE MANAGEME	1.5 dCi 59kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.5 dCi 59kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.5 dCi 59kw K9K-722 (05-..)	SIEMENS EDC SID
 Megane II	ENGINE MANAGEME	1.5 dCi 59kw K9K-722 (06-..)	SIEMENS EDC SID 301 Common Rail
 Megane II	ENGINE MANAGEME	1.5 dCi 63kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.5 dCi 63kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.5 dCi 63kw (05-..)	EOBD
 Megane II	ENGINE MANAGEME	1.5 dCi 74kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.5 dCi 74kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.5 dCi 74kw K9K-728 (..-05)	DELPHI
 Megane II	ENGINE MANAGEME	1.5 dCi 74kw K9K-728 (05-..)	SIEMENS EDC SID
 Megane II	ENGINE MANAGEME	1.5 dCi 74kw K9K-728 (06-..)	SIEMENS EDC SID 301 Common Rail
 Megane II	ENGINE MANAGEME	1.5 dCi 76kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.5 dCi 76kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.5 dCi 76kw (05-..)	EOBD
 Megane II	ENGINE MANAGEME	1.5 dCi 78kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.5 dCi 78kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.5 dCi 78kw K9K-732 (..-05)	DELPHI
 Megane II	ENGINE MANAGEME	1.5 dCi 78kw K9K-732 (05-..)	SIEMENS EDC SID
 Megane II	ENGINE MANAGEME	1.5 dCi 78kw K9K-732 (06-..)	SIEMENS EDC SID 301 Common Rail
 Megane II	ENGINE MANAGEME	1.5 dCi FAP 63kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.5 dCi FAP 63kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.5 dCi FAP 63kw (05-..)	EOBD
 Megane II	ENGINE MANAGEME	1.5 dCi FAP 76kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.5 dCi FAP 76kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.5 dCi FAP 76kw (05-..)	EOBD
 Megane II	ENGINE MANAGEME	1.6 16v 82kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.6 16v 82kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.6 16v 82kw	EOBD
 Megane II	ENGINE MANAGEME	1.6 16v 83kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.6 16v 83kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.6 16v 83kw K4M-760	SAGEM MPI 3000
 Megane II	ENGINE MANAGEME	1.6 16v 83kw K4M-761	SAGEM MPI 3000
 Megane II	ENGINE MANAGEME	1.6 16v GPL 77kw	GAS AUTODETECT
 Megane II	ENGINE MANAGEME	1.9 dCi 68kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.9 dCi 68kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.9 dCi 68kw F9Q-808 (02-05)	BOSCH EDC 15 Common Rail
 Megane II	ENGINE MANAGEME	1.9 dCi 85kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.9 dCi 85kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.9 dCi 85kw	EOBD
 Megane II	ENGINE MANAGEME	1.9 dCi 88kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.9 dCi 88kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.9 dCi 88kw F9Q-800 (02-05)	BOSCH EDC 15 Common Rail
 Megane II	ENGINE MANAGEME	1.9 dCi 96kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.9 dCi 96kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.9 dCi 96kw	EOBD
 Megane II	ENGINE MANAGEME	1.9 dCi FAP 81kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.9 dCi FAP 81kw	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Megane II	ENGINE MANAGEME	1.9 dCi FAP 81kw	EOBD
 Megane II	ENGINE MANAGEME	1.9 dCi FAP 85kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.9 dCi FAP 85kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.9 dCi FAP 85kw	EOBD
 Megane II	ENGINE MANAGEME	1.9 dCi FAP 96kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.9 dCi FAP 96kw	AUTODETECT
 Megane II	ENGINE MANAGEME	1.9 dCi FAP 96kw	EOBD
 Megane II	ENGINE MANAGEME	1.9 dCi FAP 96kw F9Q-818	BOSCH EDC 16 Common Rail
 Megane II	ENGINE MANAGEME	2.0 16v 100kw	AUTODETECT
 Megane II	ENGINE MANAGEME	2.0 16v 100kw	AUTODETECT
 Megane II	ENGINE MANAGEME	2.0 16v dCi 110kw	AUTODETECT
 Megane II	ENGINE MANAGEME	2.0 16v dCi 110kw	AUTODETECT
 Megane II	ENGINE MANAGEME	2.0 16v dCi 110kw	EOBD
 Megane II	ENGINE MANAGEME	2.0 16v dCi FAP 110kw	AUTODETECT
 Megane II	ENGINE MANAGEME	2.0 16v dCi FAP 110kw	AUTODETECT
 Megane II	ENGINE MANAGEME	2.0 16v dCi FAP 110kw	EOBD
 Megane II	ENGINE MANAGEME	2.0 16v dCi FAP 127kw	AUTODETECT
 Megane II	ENGINE MANAGEME	2.0 16v dCi FAP 127kw	AUTODETECT
 Megane II	ENGINE MANAGEME	2.0 16v dCi FAP 127kw	EOBD
 Megane II	ENGINE MANAGEME	2.0 T 16v 121kw	AUTODETECT
 Megane II	ENGINE MANAGEME	2.0 T 16v 121kw	AUTODETECT
 Megane II	ENGINE MANAGEME	2.0 T 16v 165kw	AUTODETECT
 Megane II	ENGINE MANAGEME	2.0 T 16v 165kw	AUTODETECT
 Megane II	ENGINE MANAGEME	2.0 T 16v 169kw	AUTODETECT
 Megane II	ENGINE MANAGEME	2.0 T 16v 169kw	AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.4 16v 59kw	AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.4 16v 59kw	can AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.4 16v 72kw	AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.4 16v 72kw	can AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.5 dCi 59kw	AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.5 dCi 59kw	can AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.5 dCi 63kw	AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.5 dCi 63kw	can AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.5 dCi 74kw	AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.5 dCi 74kw	can AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.5 dCi 76kw	AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.5 dCi 76kw	can AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.5 dCi 78kw	AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.5 dCi 78kw	can AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.5 dCi FAP 63kw	AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.5 dCi FAP 63kw	can AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.5 dCi FAP 76kw	AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.5 dCi FAP 76kw	can AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.6 16v 82kw	AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.6 16v 82kw	can AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.6 16v 83kw	AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.6 16v 83kw	can AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.6 16v GPL 77kw	AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.6 16v GPL 77kw	can AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.9 dCi 68kw	AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.9 dCi 68kw	can AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.9 dCi 85kw	AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.9 dCi 85kw	can AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.9 dCi 88kw	AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.9 dCi 88kw	can AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.9 dCi 96kw	AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.9 dCi 96kw	can AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.9 dCi FAP 81kw	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Megane II	HEADLIGHT LEVEL	1.9 dCi FAP 81kw	can AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.9 dCi FAP 85kw	AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.9 dCi FAP 85kw	can AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.9 dCi FAP 96kw	AUTODETECT
 Megane II	HEADLIGHT LEVEL	1.9 dCi FAP 96kw	can AUTODETECT
 Megane II	HEADLIGHT LEVEL	2.0 16v 100kw	AUTODETECT
 Megane II	HEADLIGHT LEVEL	2.0 16v 100kw	can AUTODETECT
 Megane II	HEADLIGHT LEVEL	2.0 16v dCi 110kw	AUTODETECT
 Megane II	HEADLIGHT LEVEL	2.0 16v dCi 110kw	can AUTODETECT
 Megane II	HEADLIGHT LEVEL	2.0 16v dCi FAP 110kw	AUTODETECT
 Megane II	HEADLIGHT LEVEL	2.0 16v dCi FAP 110kw	can AUTODETECT
 Megane II	HEADLIGHT LEVEL	2.0 16v dCi FAP 127kw	AUTODETECT
 Megane II	HEADLIGHT LEVEL	2.0 16v dCi FAP 127kw	can AUTODETECT
 Megane II	HEADLIGHT LEVEL	2.0 T 16v 121kw	AUTODETECT
 Megane II	HEADLIGHT LEVEL	2.0 T 16v 121kw	can AUTODETECT
 Megane II	HEADLIGHT LEVEL	2.0 T 16v 165kw	AUTODETECT
 Megane II	HEADLIGHT LEVEL	2.0 T 16v 165kw	can AUTODETECT
 Megane II	HEADLIGHT LEVEL	2.0 T 16v 169kw	AUTODETECT
 Megane II	HEADLIGHT LEVEL	2.0 T 16v 169kw	can AUTODETECT
 Megane II	KEY ENCODE	1.4 16v 59kw (02-..)	
 Megane II	KEY ENCODE	1.4 16v 72kw (02-..)	
 Megane II	KEY ENCODE	1.5 dCi 59kw (02-..)	
 Megane II	KEY ENCODE	1.5 dCi 63kw (02-..)	
 Megane II	KEY ENCODE	1.5 dCi 74kw (02-..)	
 Megane II	KEY ENCODE	1.5 dCi 76kw (02-..)	
 Megane II	KEY ENCODE	1.5 dCi 78kw (02-..)	
 Megane II	KEY ENCODE	1.5 dCi FAP 63kw (02-..)	
 Megane II	KEY ENCODE	1.5 dCi FAP 76kw (02-..)	
 Megane II	KEY ENCODE	1.6 16v 82kw (02-..)	
 Megane II	KEY ENCODE	1.6 16v 83kw (02-..)	
 Megane II	KEY ENCODE	1.6 16v GPL 77kw (02-..)	
 Megane II	KEY ENCODE	1.9 dCi 68kw (02-..)	
 Megane II	KEY ENCODE	1.9 dCi 85kw (02-..)	
 Megane II	KEY ENCODE	1.9 dCi 88kw (02-..)	
 Megane II	KEY ENCODE	1.9 dCi 96kw (02-..)	
 Megane II	KEY ENCODE	1.9 dCi FAP 81kw (02-..)	
 Megane II	KEY ENCODE	1.9 dCi FAP 85kw (02-..)	
 Megane II	KEY ENCODE	1.9 dCi FAP 96kw (02-..)	
 Megane II	KEY ENCODE	2.0 16v 100kw (02-..)	
 Megane II	KEY ENCODE	2.0 16v dCi 110kw (02-..)	
 Megane II	KEY ENCODE	2.0 16v dCi FAP 110kw (02-..)	
 Megane II	KEY ENCODE	2.0 16v dCi FAP 127kw (02-..)	
 Megane II	KEY ENCODE	2.0 T 16v 121kw (02-..)	
 Megane II	KEY ENCODE	2.0 T 16v 165kw (02-..)	
 Megane II	KEY ENCODE	2.0 T 16v 169kw (02-..)	
 Megane II	LH RIGHT MODULATI	1.4 16v 59kw	AUTODETECT
 Megane II	LH RIGHT MODULATI	1.4 16v 72kw	AUTODETECT
 Megane II	LH RIGHT MODULATI	1.5 dCi 59kw	AUTODETECT
 Megane II	LH RIGHT MODULATI	1.5 dCi 63kw	AUTODETECT
 Megane II	LH RIGHT MODULATI	1.5 dCi 74kw	AUTODETECT
 Megane II	LH RIGHT MODULATI	1.5 dCi 76kw	AUTODETECT
 Megane II	LH RIGHT MODULATI	1.5 dCi 78kw	AUTODETECT
 Megane II	LH RIGHT MODULATI	1.5 dCi FAP 63kw	AUTODETECT
 Megane II	LH RIGHT MODULATI	1.5 dCi FAP 76kw	AUTODETECT
 Megane II	LH RIGHT MODULATI	1.6 16v 82kw	AUTODETECT
 Megane II	LH RIGHT MODULATI	1.6 16v 83kw	AUTODETECT
 Megane II	LH RIGHT MODULATI	1.6 16v GPL 77kw	AUTODETECT
 Megane II	LH RIGHT MODULATI	1.9 dCi 68kw	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Megane II	LH RIGHT MODULATI	1.9 dCi 85kw	AUTODETECT
 Megane II	LH RIGHT MODULATI	1.9 dCi 88kw	AUTODETECT
 Megane II	LH RIGHT MODULATI	1.9 dCi 96kw	AUTODETECT
 Megane II	LH RIGHT MODULATI	1.9 dCi FAP 81kw	AUTODETECT
 Megane II	LH RIGHT MODULATI	1.9 dCi FAP 85kw	AUTODETECT
 Megane II	LH RIGHT MODULATI	1.9 dCi FAP 96kw	AUTODETECT
 Megane II	LH RIGHT MODULATI	2.0 16v 100kw	AUTODETECT
 Megane II	LH RIGHT MODULATI	2.0 16v dCi 110kw	AUTODETECT
 Megane II	LH RIGHT MODULATI	2.0 16v dCi FAP 110kw	AUTODETECT
 Megane II	LH RIGHT MODULATI	2.0 16v dCi FAP 127kw	AUTODETECT
 Megane II	LH RIGHT MODULATI	2.0 T 16v 121kw	AUTODETECT
 Megane II	LH RIGHT MODULATI	2.0 T 16v 165kw	AUTODETECT
 Megane II	LH RIGHT MODULATI	2.0 T 16v 169kw	AUTODETECT
 Megane II	MAINTENANCE	1.4 16v 59kw	MANUAL
 Megane II	MAINTENANCE	1.4 16v 59kw (02-..)	KOYO EPS
 Megane II	MAINTENANCE	1.4 16v 59kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	MAINTENANCE	1.4 16v 59kw (02-..)	VISTEON Dashboard LS
 Megane II	MAINTENANCE	1.4 16v 72kw	MANUAL
 Megane II	MAINTENANCE	1.4 16v 72kw (02-..)	KOYO EPS
 Megane II	MAINTENANCE	1.4 16v 72kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	MAINTENANCE	1.4 16v 72kw (02-..)	VISTEON Dashboard LS
 Megane II	MAINTENANCE	1.5 dCi 59kw	MANUAL
 Megane II	MAINTENANCE	1.5 dCi 59kw (02-..)	KOYO EPS
 Megane II	MAINTENANCE	1.5 dCi 59kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	MAINTENANCE	1.5 dCi 59kw (02-..)	VISTEON Dashboard LS
 Megane II	MAINTENANCE	1.5 dCi 59kw K9K-722 (05-..)	SIEMENS EDC SID
 Megane II	MAINTENANCE	1.5 dCi 59kw K9K-722 (05-..)	SIEMENS EDC SID
 Megane II	MAINTENANCE	1.5 dCi 59kw K9K-722 (06-..)	SIEMENS EDC SID 301 Common Rail
 Megane II	MAINTENANCE	1.5 dCi 63kw (02-..)	KOYO EPS
 Megane II	MAINTENANCE	1.5 dCi 63kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	MAINTENANCE	1.5 dCi 63kw (02-..)	VISTEON Dashboard LS
 Megane II	MAINTENANCE	1.5 dCi 74kw	MANUAL
 Megane II	MAINTENANCE	1.5 dCi 74kw (02-..)	KOYO EPS
 Megane II	MAINTENANCE	1.5 dCi 74kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	MAINTENANCE	1.5 dCi 74kw (02-..)	VISTEON Dashboard LS
 Megane II	MAINTENANCE	1.5 dCi 74kw K9K-728 (..-05)	DELPHI
 Megane II	MAINTENANCE	1.5 dCi 74kw K9K-728 (05-..)	SIEMENS EDC SID
 Megane II	MAINTENANCE	1.5 dCi 74kw K9K-728 (05-..)	SIEMENS EDC SID
 Megane II	MAINTENANCE	1.5 dCi 74kw K9K-728 (06-..)	SIEMENS EDC SID 301 Common Rail
 Megane II	MAINTENANCE	1.5 dCi 76kw (02-..)	KOYO EPS
 Megane II	MAINTENANCE	1.5 dCi 76kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	MAINTENANCE	1.5 dCi 76kw (02-..)	VISTEON Dashboard LS
 Megane II	MAINTENANCE	1.5 dCi 78kw	MANUAL
 Megane II	MAINTENANCE	1.5 dCi 78kw (02-..)	KOYO EPS
 Megane II	MAINTENANCE	1.5 dCi 78kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	MAINTENANCE	1.5 dCi 78kw (02-..)	VISTEON Dashboard LS
 Megane II	MAINTENANCE	1.5 dCi 78kw K9K-732 (..-05)	DELPHI
 Megane II	MAINTENANCE	1.5 dCi 78kw K9K-732 (05-..)	SIEMENS EDC SID
 Megane II	MAINTENANCE	1.5 dCi 78kw K9K-732 (05-..)	SIEMENS EDC SID
 Megane II	MAINTENANCE	1.5 dCi 78kw K9K-732 (06-..)	SIEMENS EDC SID 301 Common Rail
 Megane II	MAINTENANCE	1.5 dCi FAP 63kw (02-..)	KOYO EPS
 Megane II	MAINTENANCE	1.5 dCi FAP 63kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	MAINTENANCE	1.5 dCi FAP 63kw (02-..)	VISTEON Dashboard LS
 Megane II	MAINTENANCE	1.5 dCi FAP 76kw (02-..)	KOYO EPS
 Megane II	MAINTENANCE	1.5 dCi FAP 76kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	MAINTENANCE	1.5 dCi FAP 76kw (02-..)	VISTEON Dashboard LS
 Megane II	MAINTENANCE	1.6 16v 82kw	MANUAL
 Megane II	MAINTENANCE	1.6 16v 82kw (02-..)	KOYO EPS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Megane II	MAINTENANCE	1.6 16v 82kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	MAINTENANCE	1.6 16v 82kw (02-..)	VISTEON Dashboard LS
 Megane II	MAINTENANCE	1.6 16v 83kw	MANUAL
 Megane II	MAINTENANCE	1.6 16v 83kw (02-..)	KOYO EPS
 Megane II	MAINTENANCE	1.6 16v 83kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	MAINTENANCE	1.6 16v 83kw (02-..)	VISTEON Dashboard LS
 Megane II	MAINTENANCE	1.6 16v GPL 77kw	MANUAL
 Megane II	MAINTENANCE	1.6 16v GPL 77kw (02-..)	KOYO EPS
 Megane II	MAINTENANCE	1.6 16v GPL 77kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	MAINTENANCE	1.6 16v GPL 77kw (02-..)	VISTEON Dashboard LS
 Megane II	MAINTENANCE	1.9 dCi 68kw	MANUAL
 Megane II	MAINTENANCE	1.9 dCi 68kw (02-..)	KOYO EPS
 Megane II	MAINTENANCE	1.9 dCi 68kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	MAINTENANCE	1.9 dCi 68kw (02-..)	VISTEON Dashboard LS
 Megane II	MAINTENANCE	1.9 dCi 85kw	MANUAL
 Megane II	MAINTENANCE	1.9 dCi 85kw (02-..)	KOYO EPS
 Megane II	MAINTENANCE	1.9 dCi 85kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	MAINTENANCE	1.9 dCi 85kw (02-..)	VISTEON Dashboard LS
 Megane II	MAINTENANCE	1.9 dCi 88kw	MANUAL
 Megane II	MAINTENANCE	1.9 dCi 88kw (02-..)	KOYO EPS
 Megane II	MAINTENANCE	1.9 dCi 88kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	MAINTENANCE	1.9 dCi 88kw (02-..)	VISTEON Dashboard LS
 Megane II	MAINTENANCE	1.9 dCi 96kw	MANUAL
 Megane II	MAINTENANCE	1.9 dCi 96kw (02-..)	KOYO EPS
 Megane II	MAINTENANCE	1.9 dCi 96kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	MAINTENANCE	1.9 dCi 96kw (02-..)	VISTEON Dashboard LS
 Megane II	MAINTENANCE	1.9 dCi FAP 81kw	MANUAL
 Megane II	MAINTENANCE	1.9 dCi FAP 81kw (02-..)	KOYO EPS
 Megane II	MAINTENANCE	1.9 dCi FAP 81kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	MAINTENANCE	1.9 dCi FAP 81kw (02-..)	VISTEON Dashboard LS
 Megane II	MAINTENANCE	1.9 dCi FAP 85kw	MANUAL
 Megane II	MAINTENANCE	1.9 dCi FAP 85kw (02-..)	KOYO EPS
 Megane II	MAINTENANCE	1.9 dCi FAP 85kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	MAINTENANCE	1.9 dCi FAP 85kw (02-..)	VISTEON Dashboard LS
 Megane II	MAINTENANCE	1.9 dCi FAP 96kw	MANUAL
 Megane II	MAINTENANCE	1.9 dCi FAP 96kw (02-..)	KOYO EPS
 Megane II	MAINTENANCE	1.9 dCi FAP 96kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	MAINTENANCE	1.9 dCi FAP 96kw (02-..)	VISTEON Dashboard LS
 Megane II	MAINTENANCE	1.9 dCi FAP 96kw F9Q-818	BOSCH EDC 16 Common Rail
 Megane II	MAINTENANCE	2.0 16v 100kw	MANUAL
 Megane II	MAINTENANCE	2.0 16v 100kw (02-..)	KOYO EPS
 Megane II	MAINTENANCE	2.0 16v 100kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	MAINTENANCE	2.0 16v 100kw (02-..)	VISTEON Dashboard LS
 Megane II	MAINTENANCE	2.0 16v dCi 110kw	MANUAL
 Megane II	MAINTENANCE	2.0 16v dCi 110kw (02-..)	KOYO EPS
 Megane II	MAINTENANCE	2.0 16v dCi 110kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	MAINTENANCE	2.0 16v dCi 110kw (02-..)	VISTEON Dashboard LS
 Megane II	MAINTENANCE	2.0 16v dCi FAP 110kw	MANUAL
 Megane II	MAINTENANCE	2.0 16v dCi FAP 110kw (02-..)	KOYO EPS
 Megane II	MAINTENANCE	2.0 16v dCi FAP 110kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	MAINTENANCE	2.0 16v dCi FAP 110kw (02-..)	VISTEON Dashboard LS
 Megane II	MAINTENANCE	2.0 16v dCi FAP 127kw	MANUAL
 Megane II	MAINTENANCE	2.0 16v dCi FAP 127kw (02-..)	KOYO EPS
 Megane II	MAINTENANCE	2.0 16v dCi FAP 127kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	MAINTENANCE	2.0 16v dCi FAP 127kw (02-..)	VISTEON Dashboard LS
 Megane II	MAINTENANCE	2.0 T 16v 121kw	MANUAL
 Megane II	MAINTENANCE	2.0 T 16v 121kw (02-..)	KOYO EPS
 Megane II	MAINTENANCE	2.0 T 16v 121kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Megane II	MAINTENANCE	2.0 T 16v 121kw (02-..)	VISTEON Dashboard LS
 Megane II	MAINTENANCE	2.0 T 16v 165kw	MANUAL
 Megane II	MAINTENANCE	2.0 T 16v 165kw (02-..)	KOYO EPS
 Megane II	MAINTENANCE	2.0 T 16v 165kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	MAINTENANCE	2.0 T 16v 165kw (02-..)	VISTEON Dashboard LS
 Megane II	MAINTENANCE	2.0 T 16v 169kw	MANUAL
 Megane II	MAINTENANCE	2.0 T 16v 169kw (02-..)	KOYO EPS
 Megane II	MAINTENANCE	2.0 T 16v 169kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Megane II	MAINTENANCE	2.0 T 16v 169kw (02-..)	VISTEON Dashboard LS
 Megane II	PARK.BRAKE	1.4 16v 59kw	AUTODETECT
 Megane II	PARK.BRAKE	1.4 16v 72kw	AUTODETECT
 Megane II	PARK.BRAKE	1.5 dCi 59kw	AUTODETECT
 Megane II	PARK.BRAKE	1.5 dCi 63kw	AUTODETECT
 Megane II	PARK.BRAKE	1.5 dCi 74kw	AUTODETECT
 Megane II	PARK.BRAKE	1.5 dCi 76kw	AUTODETECT
 Megane II	PARK.BRAKE	1.5 dCi 78kw	AUTODETECT
 Megane II	PARK.BRAKE	1.5 dCi FAP 63kw	AUTODETECT
 Megane II	PARK.BRAKE	1.5 dCi FAP 76kw	AUTODETECT
 Megane II	PARK.BRAKE	1.6 16v 82kw	AUTODETECT
 Megane II	PARK.BRAKE	1.6 16v 83kw	AUTODETECT
 Megane II	PARK.BRAKE	1.6 16v GPL 77kw	AUTODETECT
 Megane II	PARK.BRAKE	1.9 dCi 68kw	AUTODETECT
 Megane II	PARK.BRAKE	1.9 dCi 85kw	AUTODETECT
 Megane II	PARK.BRAKE	1.9 dCi 88kw	AUTODETECT
 Megane II	PARK.BRAKE	1.9 dCi 96kw	AUTODETECT
 Megane II	PARK.BRAKE	1.9 dCi FAP 81kw	AUTODETECT
 Megane II	PARK.BRAKE	1.9 dCi FAP 85kw	AUTODETECT
 Megane II	PARK.BRAKE	1.9 dCi FAP 96kw	AUTODETECT
 Megane II	PARK.BRAKE	2.0 16v 100kw	AUTODETECT
 Megane II	PARK.BRAKE	2.0 16v dCi 110kw	AUTODETECT
 Megane II	PARK.BRAKE	2.0 16v dCi FAP 110kw	AUTODETECT
 Megane II	PARK.BRAKE	2.0 16v dCi FAP 127kw	AUTODETECT
 Megane II	PARK.BRAKE	2.0 T 16v 121kw	AUTODETECT
 Megane II	PARK.BRAKE	2.0 T 16v 165kw	AUTODETECT
 Megane II	PARK.BRAKE	2.0 T 16v 169kw	AUTODETECT
 Megane II	PARKING HELP	1.4 16v 59kw	AUTODETECT
 Megane II	PARKING HELP	1.4 16v 59kw	can AUTODETECT
 Megane II	PARKING HELP	1.4 16v 72kw	AUTODETECT
 Megane II	PARKING HELP	1.4 16v 72kw	can AUTODETECT
 Megane II	PARKING HELP	1.5 dCi 59kw	AUTODETECT
 Megane II	PARKING HELP	1.5 dCi 59kw	can AUTODETECT
 Megane II	PARKING HELP	1.5 dCi 63kw	AUTODETECT
 Megane II	PARKING HELP	1.5 dCi 63kw	can AUTODETECT
 Megane II	PARKING HELP	1.5 dCi 74kw	AUTODETECT
 Megane II	PARKING HELP	1.5 dCi 74kw	can AUTODETECT
 Megane II	PARKING HELP	1.5 dCi 76kw	AUTODETECT
 Megane II	PARKING HELP	1.5 dCi 76kw	can AUTODETECT
 Megane II	PARKING HELP	1.5 dCi 78kw	AUTODETECT
 Megane II	PARKING HELP	1.5 dCi 78kw	can AUTODETECT
 Megane II	PARKING HELP	1.5 dCi FAP 63kw	AUTODETECT
 Megane II	PARKING HELP	1.5 dCi FAP 63kw	can AUTODETECT
 Megane II	PARKING HELP	1.5 dCi FAP 76kw	AUTODETECT
 Megane II	PARKING HELP	1.5 dCi FAP 76kw	can AUTODETECT
 Megane II	PARKING HELP	1.6 16v 82kw	AUTODETECT
 Megane II	PARKING HELP	1.6 16v 82kw	can AUTODETECT
 Megane II	PARKING HELP	1.6 16v 83kw	AUTODETECT
 Megane II	PARKING HELP	1.6 16v 83kw	can AUTODETECT
 Megane II	PARKING HELP	1.6 16v GPL 77kw	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Megane II	PARKING HELP	1.6 16v GPL 77kw	can AUTODETECT
 Megane II	PARKING HELP	1.9 dCi 68kw	AUTODETECT
 Megane II	PARKING HELP	1.9 dCi 68kw	can AUTODETECT
 Megane II	PARKING HELP	1.9 dCi 85kw	AUTODETECT
 Megane II	PARKING HELP	1.9 dCi 85kw	can AUTODETECT
 Megane II	PARKING HELP	1.9 dCi 88kw	AUTODETECT
 Megane II	PARKING HELP	1.9 dCi 88kw	can AUTODETECT
 Megane II	PARKING HELP	1.9 dCi 96kw	AUTODETECT
 Megane II	PARKING HELP	1.9 dCi 96kw	can AUTODETECT
 Megane II	PARKING HELP	1.9 dCi FAP 81kw	AUTODETECT
 Megane II	PARKING HELP	1.9 dCi FAP 81kw	can AUTODETECT
 Megane II	PARKING HELP	1.9 dCi FAP 85kw	AUTODETECT
 Megane II	PARKING HELP	1.9 dCi FAP 85kw	can AUTODETECT
 Megane II	PARKING HELP	1.9 dCi FAP 96kw	AUTODETECT
 Megane II	PARKING HELP	1.9 dCi FAP 96kw	can AUTODETECT
 Megane II	PARKING HELP	2.0 16v 100kw	AUTODETECT
 Megane II	PARKING HELP	2.0 16v 100kw	can AUTODETECT
 Megane II	PARKING HELP	2.0 16v dCi 110kw	AUTODETECT
 Megane II	PARKING HELP	2.0 16v dCi 110kw	can AUTODETECT
 Megane II	PARKING HELP	2.0 16v dCi FAP 110kw	AUTODETECT
 Megane II	PARKING HELP	2.0 16v dCi FAP 110kw	can AUTODETECT
 Megane II	PARKING HELP	2.0 16v dCi FAP 127kw	AUTODETECT
 Megane II	PARKING HELP	2.0 16v dCi FAP 127kw	can AUTODETECT
 Megane II	PARKING HELP	2.0 T 16v 121kw	AUTODETECT
 Megane II	PARKING HELP	2.0 T 16v 121kw	can AUTODETECT
 Megane II	PARKING HELP	2.0 T 16v 165kw	AUTODETECT
 Megane II	PARKING HELP	2.0 T 16v 165kw	can AUTODETECT
 Megane II	PARKING HELP	2.0 T 16v 169kw	AUTODETECT
 Megane II	PARKING HELP	2.0 T 16v 169kw	can AUTODETECT
 Megane II	RADIO / CD	1.4 16v 59kw	AUTODETECT
 Megane II	RADIO / CD	1.4 16v 72kw	AUTODETECT
 Megane II	RADIO / CD	1.5 dCi 59kw	AUTODETECT
 Megane II	RADIO / CD	1.5 dCi 63kw	AUTODETECT
 Megane II	RADIO / CD	1.5 dCi 74kw	AUTODETECT
 Megane II	RADIO / CD	1.5 dCi 76kw	AUTODETECT
 Megane II	RADIO / CD	1.5 dCi 78kw	AUTODETECT
 Megane II	RADIO / CD	1.5 dCi FAP 63kw	AUTODETECT
 Megane II	RADIO / CD	1.5 dCi FAP 76kw	AUTODETECT
 Megane II	RADIO / CD	1.6 16v 82kw	AUTODETECT
 Megane II	RADIO / CD	1.6 16v 83kw	AUTODETECT
 Megane II	RADIO / CD	1.6 16v GPL 77kw	AUTODETECT
 Megane II	RADIO / CD	1.9 dCi 68kw	AUTODETECT
 Megane II	RADIO / CD	1.9 dCi 85kw	AUTODETECT
 Megane II	RADIO / CD	1.9 dCi 88kw	AUTODETECT
 Megane II	RADIO / CD	1.9 dCi 96kw	AUTODETECT
 Megane II	RADIO / CD	1.9 dCi FAP 81kw	AUTODETECT
 Megane II	RADIO / CD	1.9 dCi FAP 85kw	AUTODETECT
 Megane II	RADIO / CD	1.9 dCi FAP 96kw	AUTODETECT
 Megane II	RADIO / CD	2.0 16v 100kw	AUTODETECT
 Megane II	RADIO / CD	2.0 16v dCi 110kw	AUTODETECT
 Megane II	RADIO / CD	2.0 16v dCi FAP 110kw	AUTODETECT
 Megane II	RADIO / CD	2.0 16v dCi FAP 127kw	AUTODETECT
 Megane II	RADIO / CD	2.0 T 16v 121kw	AUTODETECT
 Megane II	RADIO / CD	2.0 T 16v 165kw	AUTODETECT
 Megane II	RADIO / CD	2.0 T 16v 169kw	AUTODETECT
 Megane II	RH LIGHT MODULATI	1.4 16v 59kw	AUTODETECT
 Megane II	RH LIGHT MODULATI	1.4 16v 72kw	AUTODETECT
 Megane II	RH LIGHT MODULATI	1.5 dCi 59kw	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Megane II	RH LIGHT MODULATI	1.5 dCi 63kw	AUTODETECT
 Megane II	RH LIGHT MODULATI	1.5 dCi 74kw	AUTODETECT
 Megane II	RH LIGHT MODULATI	1.5 dCi 76kw	AUTODETECT
 Megane II	RH LIGHT MODULATI	1.5 dCi 78kw	AUTODETECT
 Megane II	RH LIGHT MODULATI	1.5 dCi FAP 63kw	AUTODETECT
 Megane II	RH LIGHT MODULATI	1.5 dCi FAP 76kw	AUTODETECT
 Megane II	RH LIGHT MODULATI	1.6 16v 82kw	AUTODETECT
 Megane II	RH LIGHT MODULATI	1.6 16v 83kw	AUTODETECT
 Megane II	RH LIGHT MODULATI	1.6 16v GPL 77kw	AUTODETECT
 Megane II	RH LIGHT MODULATI	1.9 dCi 68kw	AUTODETECT
 Megane II	RH LIGHT MODULATI	1.9 dCi 85kw	AUTODETECT
 Megane II	RH LIGHT MODULATI	1.9 dCi 88kw	AUTODETECT
 Megane II	RH LIGHT MODULATI	1.9 dCi 96kw	AUTODETECT
 Megane II	RH LIGHT MODULATI	1.9 dCi FAP 81kw	AUTODETECT
 Megane II	RH LIGHT MODULATI	1.9 dCi FAP 85kw	AUTODETECT
 Megane II	RH LIGHT MODULATI	1.9 dCi FAP 96kw	AUTODETECT
 Megane II	RH LIGHT MODULATI	2.0 16v 100kw	AUTODETECT
 Megane II	RH LIGHT MODULATI	2.0 16v dCi 110kw	AUTODETECT
 Megane II	RH LIGHT MODULATI	2.0 16v dCi FAP 110kw	AUTODETECT
 Megane II	RH LIGHT MODULATI	2.0 16v dCi FAP 127kw	AUTODETECT
 Megane II	RH LIGHT MODULATI	2.0 T 16v 121kw	AUTODETECT
 Megane II	RH LIGHT MODULATI	2.0 T 16v 165kw	AUTODETECT
 Megane II	RH LIGHT MODULATI	2.0 T 16v 169kw	AUTODETECT
 Megane II	SERVICE LIGHT RES	1.4 16v 59kw	MANUAL
 Megane II	SERVICE LIGHT RES	1.4 16v 72kw	MANUAL
 Megane II	SERVICE LIGHT RES	1.5 dCi 59kw	MANUAL
 Megane II	SERVICE LIGHT RES	1.5 dCi 74kw	MANUAL
 Megane II	SERVICE LIGHT RES	1.5 dCi 78kw	MANUAL
 Megane II	SERVICE LIGHT RES	1.6 16v 82kw	MANUAL
 Megane II	SERVICE LIGHT RES	1.6 16v 83kw	MANUAL
 Megane II	SERVICE LIGHT RES	1.6 16v GPL 77kw	MANUAL
 Megane II	SERVICE LIGHT RES	1.9 dCi 68kw	MANUAL
 Megane II	SERVICE LIGHT RES	1.9 dCi 85kw	MANUAL
 Megane II	SERVICE LIGHT RES	1.9 dCi 88kw	MANUAL
 Megane II	SERVICE LIGHT RES	1.9 dCi 96kw	MANUAL
 Megane II	SERVICE LIGHT RES	1.9 dCi FAP 81kw	MANUAL
 Megane II	SERVICE LIGHT RES	1.9 dCi FAP 85kw	MANUAL
 Megane II	SERVICE LIGHT RES	1.9 dCi FAP 96kw	MANUAL
 Megane II	SERVICE LIGHT RES	2.0 16v 100kw	MANUAL
 Megane II	SERVICE LIGHT RES	2.0 16v dCi 110kw	MANUAL
 Megane II	SERVICE LIGHT RES	2.0 16v dCi FAP 110kw	MANUAL
 Megane II	SERVICE LIGHT RES	2.0 16v dCi FAP 127kw	MANUAL
 Megane II	SERVICE LIGHT RES	2.0 T 16v 121kw	MANUAL
 Megane II	SERVICE LIGHT RES	2.0 T 16v 165kw	MANUAL
 Megane II	SERVICE LIGHT RES	2.0 T 16v 169kw	MANUAL
 Megane II	VISUAL./TELEMATIC	1.4 16v 59kw	USB AUTODETECT
 Megane II	VISUAL./TELEMATIC	1.4 16v 72kw	USB AUTODETECT
 Megane II	VISUAL./TELEMATIC	1.5 dCi 59kw	USB AUTODETECT
 Megane II	VISUAL./TELEMATIC	1.5 dCi 63kw	USB AUTODETECT
 Megane II	VISUAL./TELEMATIC	1.5 dCi 74kw	USB AUTODETECT
 Megane II	VISUAL./TELEMATIC	1.5 dCi 76kw	USB AUTODETECT
 Megane II	VISUAL./TELEMATIC	1.5 dCi 78kw	USB AUTODETECT
 Megane II	VISUAL./TELEMATIC	1.5 dCi FAP 63kw	USB AUTODETECT
 Megane II	VISUAL./TELEMATIC	1.5 dCi FAP 76kw	USB AUTODETECT
 Megane II	VISUAL./TELEMATIC	1.6 16v 82kw	USB AUTODETECT
 Megane II	VISUAL./TELEMATIC	1.6 16v 83kw	USB AUTODETECT
 Megane II	VISUAL./TELEMATIC	1.6 16v GPL 77kw	USB AUTODETECT
 Megane II	VISUAL./TELEMATIC	1.9 dCi 68kw	USB AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Megane II	VISUAL./TELEMATIC	1.9 dCi 85kw	USB AUTODETECT
 Megane II	VISUAL./TELEMATIC	1.9 dCi 88kw	USB AUTODETECT
 Megane II	VISUAL./TELEMATIC	1.9 dCi 96kw	USB AUTODETECT
 Megane II	VISUAL./TELEMATIC	1.9 dCi FAP 81kw	USB AUTODETECT
 Megane II	VISUAL./TELEMATIC	1.9 dCi FAP 85kw	USB AUTODETECT
 Megane II	VISUAL./TELEMATIC	1.9 dCi FAP 96kw	USB AUTODETECT
 Megane II	VISUAL./TELEMATIC	2.0 16v 100kw	USB AUTODETECT
 Megane II	VISUAL./TELEMATIC	2.0 16v dCi 110kw	USB AUTODETECT
 Megane II	VISUAL./TELEMATIC	2.0 16v dCi FAP 110kw	USB AUTODETECT
 Megane II	VISUAL./TELEMATIC	2.0 16v dCi FAP 127kw	USB AUTODETECT
 Megane II	VISUAL./TELEMATIC	2.0 T 16v 121kw	USB AUTODETECT
 Megane II	VISUAL./TELEMATIC	2.0 T 16v 165kw	USB AUTODETECT
 Megane II	VISUAL./TELEMATIC	2.0 T 16v 169kw	USB AUTODETECT
 Megane III	ABS + TRACT. CONT	1.4 16v 96kw	AUTODETECT
 Megane III	ABS + TRACT. CONT	1.5 dCi 63kw	AUTODETECT
 Megane III	ABS + TRACT. CONT	1.5 dCi 78kw	AUTODETECT
 Megane III	ABS + TRACT. CONT	1.5 dCi FAP 66kw	AUTODETECT
 Megane III	ABS + TRACT. CONT	1.5 dCi FAP 81kw	AUTODETECT
 Megane III	ABS + TRACT. CONT	1.6 16v 74kw	AUTODETECT
 Megane III	ABS + TRACT. CONT	1.6 16v 81kw	AUTODETECT
 Megane III	ABS + TRACT. CONT	1.9 dCi 96kw	AUTODETECT
 Megane III	ABS + TRACT. CONT	1.9 dCi FAP 96kw	AUTODETECT
 Megane III	ABS + TRACT. CONT	2.0 16v 103kw	AUTODETECT
 Megane III	ABS + TRACT. CONT	2.0 16v 132kw	AUTODETECT
 Megane III	ABS + TRACT. CONT	2.0 dCi 16v 110kw	AUTODETECT
 Megane III	ABS + TRACT. CONT	2.0 dCi 16v FAP 118kw	AUTODETECT
 Megane III	AUTOM. TRANSMISSI	1.4 16v 96kw	AUTODETECT
 Megane III	AUTOM. TRANSMISSI	1.5 dCi 63kw	AUTODETECT
 Megane III	AUTOM. TRANSMISSI	1.5 dCi 78kw	AUTODETECT
 Megane III	AUTOM. TRANSMISSI	1.5 dCi FAP 66kw	AUTODETECT
 Megane III	AUTOM. TRANSMISSI	1.5 dCi FAP 81kw	AUTODETECT
 Megane III	AUTOM. TRANSMISSI	1.6 16v 74kw	AUTODETECT
 Megane III	AUTOM. TRANSMISSI	1.6 16v 81kw	AUTODETECT
 Megane III	AUTOM. TRANSMISSI	1.9 dCi 96kw	AUTODETECT
 Megane III	AUTOM. TRANSMISSI	1.9 dCi FAP 96kw	AUTODETECT
 Megane III	AUTOM. TRANSMISSI	2.0 16v 103kw	AUTODETECT
 Megane III	AUTOM. TRANSMISSI	2.0 16v 132kw	AUTODETECT
 Megane III	AUTOM. TRANSMISSI	2.0 dCi 16v 110kw	AUTODETECT
 Megane III	AUTOM. TRANSMISSI	2.0 dCi 16v FAP 118kw	AUTODETECT
 Megane III	CHASSIS NETWORK	1.4 16v 96kw	UCC AUTODETECT
 Megane III	CHASSIS NETWORK	1.5 dCi 63kw	UCC AUTODETECT
 Megane III	CHASSIS NETWORK	1.5 dCi 78kw	UCC AUTODETECT
 Megane III	CHASSIS NETWORK	1.5 dCi FAP 66kw	UCC AUTODETECT
 Megane III	CHASSIS NETWORK	1.5 dCi FAP 81kw	UCC AUTODETECT
 Megane III	CHASSIS NETWORK	1.6 16v 74kw	UCC AUTODETECT
 Megane III	CHASSIS NETWORK	1.6 16v 81kw	UCC AUTODETECT
 Megane III	CHASSIS NETWORK	1.9 dCi 96kw	UCC AUTODETECT
 Megane III	CHASSIS NETWORK	1.9 dCi FAP 96kw	UCC AUTODETECT
 Megane III	CHASSIS NETWORK	2.0 16v 103kw	UCC AUTODETECT
 Megane III	CHASSIS NETWORK	2.0 16v 132kw	UCC AUTODETECT
 Megane III	CHASSIS NETWORK	2.0 dCi 16v 110kw	UCC AUTODETECT
 Megane III	CHASSIS NETWORK	2.0 dCi 16v FAP 118kw	UCC AUTODETECT
 Megane III	CLIMA	1.4 16v 96kw	AUTODETECT
 Megane III	CLIMA	1.5 dCi 63kw	AUTODETECT
 Megane III	CLIMA	1.5 dCi 78kw	AUTODETECT
 Megane III	CLIMA	1.5 dCi FAP 66kw	AUTODETECT
 Megane III	CLIMA	1.5 dCi FAP 81kw	AUTODETECT
 Megane III	CLIMA	1.6 16v 74kw	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Megane III	CLIMA	1.6 16v 81kw	AUTODETECT
 Megane III	CLIMA	1.9 dCi 96kw	AUTODETECT
 Megane III	CLIMA	1.9 dCi FAP 96kw	AUTODETECT
 Megane III	CLIMA	2.0 16v 103kw	AUTODETECT
 Megane III	CLIMA	2.0 16v 132kw	AUTODETECT
 Megane III	CLIMA	2.0 dCi 16v 110kw	AUTODETECT
 Megane III	CLIMA	2.0 dCi 16v FAP 118kw	AUTODETECT
 Megane III	DASHBOARD	1.4 16v 96kw	AUTODETECT
 Megane III	DASHBOARD	1.5 dCi 63kw	AUTODETECT
 Megane III	DASHBOARD	1.5 dCi 78kw	AUTODETECT
 Megane III	DASHBOARD	1.5 dCi FAP 66kw	AUTODETECT
 Megane III	DASHBOARD	1.5 dCi FAP 81kw	AUTODETECT
 Megane III	DASHBOARD	1.6 16v 74kw	AUTODETECT
 Megane III	DASHBOARD	1.6 16v 81kw	AUTODETECT
 Megane III	DASHBOARD	1.9 dCi 96kw	AUTODETECT
 Megane III	DASHBOARD	1.9 dCi FAP 96kw	AUTODETECT
 Megane III	DASHBOARD	2.0 16v 103kw	AUTODETECT
 Megane III	DASHBOARD	2.0 16v 132kw	AUTODETECT
 Megane III	DASHBOARD	2.0 dCi 16v 110kw	AUTODETECT
 Megane III	DASHBOARD	2.0 dCi 16v FAP 118kw	AUTODETECT
 Megane III	ELECTRIC STEERING	1.4 16v 96kw	AUTODETECT
 Megane III	ELECTRIC STEERING	1.5 dCi 63kw	AUTODETECT
 Megane III	ELECTRIC STEERING	1.5 dCi 78kw	AUTODETECT
 Megane III	ELECTRIC STEERING	1.5 dCi FAP 66kw	AUTODETECT
 Megane III	ELECTRIC STEERING	1.5 dCi FAP 81kw	AUTODETECT
 Megane III	ELECTRIC STEERING	1.6 16v 74kw	AUTODETECT
 Megane III	ELECTRIC STEERING	1.6 16v 81kw	AUTODETECT
 Megane III	ELECTRIC STEERING	1.9 dCi 96kw	AUTODETECT
 Megane III	ELECTRIC STEERING	1.9 dCi FAP 96kw	AUTODETECT
 Megane III	ELECTRIC STEERING	2.0 16v 103kw	AUTODETECT
 Megane III	ELECTRIC STEERING	2.0 16v 132kw	AUTODETECT
 Megane III	ELECTRIC STEERING	2.0 dCi 16v 110kw	AUTODETECT
 Megane III	ELECTRIC STEERING	2.0 dCi 16v FAP 118kw	AUTODETECT
 Megane III	ENGINE MANAGEME	1.4 16v 96kw	AUTODETECT
 Megane III	ENGINE MANAGEME	1.5 dCi 63kw	AUTODETECT
 Megane III	ENGINE MANAGEME	1.5 dCi 78kw	AUTODETECT
 Megane III	ENGINE MANAGEME	1.5 dCi FAP 66kw	AUTODETECT
 Megane III	ENGINE MANAGEME	1.5 dCi FAP 81kw	AUTODETECT
 Megane III	ENGINE MANAGEME	1.6 16v 74kw	AUTODETECT
 Megane III	ENGINE MANAGEME	1.6 16v 81kw	AUTODETECT
 Megane III	ENGINE MANAGEME	1.9 dCi 96kw	AUTODETECT
 Megane III	ENGINE MANAGEME	1.9 dCi FAP 96kw	AUTODETECT
 Megane III	ENGINE MANAGEME	2.0 16v 103kw	AUTODETECT
 Megane III	ENGINE MANAGEME	2.0 16v 132kw	AUTODETECT
 Megane III	ENGINE MANAGEME	2.0 dCi 16v 110kw	AUTODETECT
 Megane III	ENGINE MANAGEME	2.0 dCi 16v FAP 118kw	AUTODETECT
 Megane III	PARK.BRAKE	1.4 16v 96kw	AUTODETECT
 Megane III	PARK.BRAKE	1.5 dCi 63kw	AUTODETECT
 Megane III	PARK.BRAKE	1.5 dCi 78kw	AUTODETECT
 Megane III	PARK.BRAKE	1.5 dCi FAP 66kw	AUTODETECT
 Megane III	PARK.BRAKE	1.5 dCi FAP 81kw	AUTODETECT
 Megane III	PARK.BRAKE	1.6 16v 74kw	AUTODETECT
 Megane III	PARK.BRAKE	1.6 16v 81kw	AUTODETECT
 Megane III	PARK.BRAKE	1.9 dCi 96kw	AUTODETECT
 Megane III	PARK.BRAKE	1.9 dCi FAP 96kw	AUTODETECT
 Megane III	PARK.BRAKE	2.0 16v 103kw	AUTODETECT
 Megane III	PARK.BRAKE	2.0 16v 132kw	AUTODETECT
 Megane III	PARK.BRAKE	2.0 dCi 16v 110kw	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Megane III	PARK.BRAKE	2.0 dCi 16v FAP 118kw	AUTODETECT
 Megane III	PARKING HELP	1.4 16v 96kw	AUTODETECT
 Megane III	PARKING HELP	1.5 dCi 63kw	AUTODETECT
 Megane III	PARKING HELP	1.5 dCi 78kw	AUTODETECT
 Megane III	PARKING HELP	1.5 dCi FAP 66kw	AUTODETECT
 Megane III	PARKING HELP	1.5 dCi FAP 81kw	AUTODETECT
 Megane III	PARKING HELP	1.6 16v 74kw	AUTODETECT
 Megane III	PARKING HELP	1.6 16v 81kw	AUTODETECT
 Megane III	PARKING HELP	1.9 dCi 96kw	AUTODETECT
 Megane III	PARKING HELP	1.9 dCi FAP 96kw	AUTODETECT
 Megane III	PARKING HELP	2.0 16v 103kw	AUTODETECT
 Megane III	PARKING HELP	2.0 16v 132kw	AUTODETECT
 Megane III	PARKING HELP	2.0 dCi 16v 110kw	AUTODETECT
 Megane III	PARKING HELP	2.0 dCi 16v FAP 118kw	AUTODETECT
 Megane III	RADIO / CD	1.4 16v 96kw	AUTODETECT
 Megane III	RADIO / CD	1.5 dCi 63kw	AUTODETECT
 Megane III	RADIO / CD	1.5 dCi 78kw	AUTODETECT
 Megane III	RADIO / CD	1.5 dCi FAP 66kw	AUTODETECT
 Megane III	RADIO / CD	1.5 dCi FAP 81kw	AUTODETECT
 Megane III	RADIO / CD	1.6 16v 74kw	AUTODETECT
 Megane III	RADIO / CD	1.6 16v 81kw	AUTODETECT
 Megane III	RADIO / CD	1.9 dCi 96kw	AUTODETECT
 Megane III	RADIO / CD	1.9 dCi FAP 96kw	AUTODETECT
 Megane III	RADIO / CD	2.0 16v 103kw	AUTODETECT
 Megane III	RADIO / CD	2.0 16v 132kw	AUTODETECT
 Megane III	RADIO / CD	2.0 dCi 16v 110kw	AUTODETECT
 Megane III	RADIO / CD	2.0 dCi 16v FAP 118kw	AUTODETECT
 Megane III	VISUAL./TELEMATIC	1.4 16v 96kw	USB AUTODETECT
 Megane III	VISUAL./TELEMATIC	1.5 dCi 63kw	USB AUTODETECT
 Megane III	VISUAL./TELEMATIC	1.5 dCi 78kw	USB AUTODETECT
 Megane III	VISUAL./TELEMATIC	1.5 dCi FAP 66kw	USB AUTODETECT
 Megane III	VISUAL./TELEMATIC	1.5 dCi FAP 81kw	USB AUTODETECT
 Megane III	VISUAL./TELEMATIC	1.6 16v 74kw	USB AUTODETECT
 Megane III	VISUAL./TELEMATIC	1.6 16v 81kw	USB AUTODETECT
 Megane III	VISUAL./TELEMATIC	1.9 dCi 96kw	USB AUTODETECT
 Megane III	VISUAL./TELEMATIC	1.9 dCi FAP 96kw	USB AUTODETECT
 Megane III	VISUAL./TELEMATIC	2.0 16v 103kw	USB AUTODETECT
 Megane III	VISUAL./TELEMATIC	2.0 16v 132kw	USB AUTODETECT
 Megane III	VISUAL./TELEMATIC	2.0 dCi 16v 110kw	USB AUTODETECT
 Megane III	VISUAL./TELEMATIC	2.0 dCi 16v FAP 118kw	USB AUTODETECT
 Megane/Scenic	ABS	1.4 16v 70kw	BOSCH ABS 5.3
 Megane/Scenic	ABS	1.4 16v 70kw	BOSCH ABS 5.3 T
 Megane/Scenic	ABS	1.4 51kw	BOSCH ABS 5.3
 Megane/Scenic	ABS	1.4 51kw	BOSCH ABS 5.3 T
 Megane/Scenic	ABS	1.4 55kw	BOSCH ABS 5.3
 Megane/Scenic	ABS	1.4 55kw	BOSCH ABS 5.3 T
 Megane/Scenic	ABS	1.6 16v 81kw	BOSCH ABS 5.3
 Megane/Scenic	ABS	1.6 16v 81kw	BOSCH ABS 5.3 T
 Megane/Scenic	ABS	1.6 55kw	BOSCH ABS 5.3 T
 Megane/Scenic	ABS	1.6 66kw	BOSCH ABS 5.3
 Megane/Scenic	ABS	1.6 66kw	BOSCH ABS 5.3 T
 Megane/Scenic	ABS	1.6 GPL 66kw	BOSCH ABS 5.3
 Megane/Scenic	ABS	1.6 GPL 66kw	BOSCH ABS 5.3 T
 Megane/Scenic	ABS	1.6 GPL 79kw	BOSCH ABS 5.3 T
 Megane/Scenic	ABS	1.8 16v 87kw	BOSCH ABS 5.3 T
 Megane/Scenic	ABS	1.9 D 48kw	BOSCH ABS 5.3
 Megane/Scenic	ABS	1.9 D 48kw	BOSCH ABS 5.3 T
 Megane/Scenic	ABS	1.9 D 68kw	BOSCH ABS 5.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Megane/Scenic	ABS	1.9 D 68kw	BOSCH ABS 5.3 T
 Megane/Scenic	ABS	1.9 dCi 77kw	BOSCH ABS 5.3
 Megane/Scenic	ABS	1.9 dCi 77kw	BOSCH ABS 5.3 T
 Megane/Scenic	ABS	1.9 dTi 59kw	BOSCH ABS 5.3 T
 Megane/Scenic	ABS	1.9 dTi 68kw	BOSCH ABS 5.3
 Megane/Scenic	ABS	1.9 dTi 68kw	BOSCH ABS 5.3 T
 Megane/Scenic	ABS	1.9 dTi 74kw	BOSCH ABS 5.3
 Megane/Scenic	ABS	1.9 dTi 74kw	BOSCH ABS 5.3 T
 Megane/Scenic	ABS	2.0 16v 101kw	BOSCH ABS 5.3 T
 Megane/Scenic	ABS	2.0 16v 103kw	BOSCH ABS 5.3 T
 Megane/Scenic	ABS	2.0 16v 110kw	BOSCH ABS 5.3
 Megane/Scenic	ABS	2.0 16v 110kw	BOSCH ABS 5.3 T
 Megane/Scenic	ABS	2.0 83kw	BOSCH ABS 5.3
 Megane/Scenic	ABS	2.0 83kw	BOSCH ABS 5.3 T
 Megane/Scenic	AIRBAG	1.4 16v 70kw (...00)	SIEMENS - Autoliv AirBag AC4
 Megane/Scenic	AIRBAG	1.4 16v 70kw (...00)	SIEMENS - Autoliv AirBag AC6
 Megane/Scenic	AIRBAG	1.4 16v 70kw (...00)	SIEMENS - Autoliv AirBag EC5
 Megane/Scenic	AIRBAG	1.4 16v 70kw (01-..)	SAGEM - Autoliv AirBag ACU 3.8
 Megane/Scenic	AIRBAG	1.4 51kw (...00)	SIEMENS - Autoliv AirBag AC4
 Megane/Scenic	AIRBAG	1.4 51kw (...00)	SIEMENS - Autoliv AirBag AC6
 Megane/Scenic	AIRBAG	1.4 51kw (...00)	SIEMENS - Autoliv AirBag EC5
 Megane/Scenic	AIRBAG	1.4 51kw (01-..)	SAGEM - Autoliv AirBag ACU 3.8
 Megane/Scenic	AIRBAG	1.4 55kw (...00)	SIEMENS - Autoliv AirBag AC4
 Megane/Scenic	AIRBAG	1.4 55kw (...00)	SIEMENS - Autoliv AirBag AC6
 Megane/Scenic	AIRBAG	1.4 55kw (...00)	SIEMENS - Autoliv AirBag EC5
 Megane/Scenic	AIRBAG	1.4 55kw (01-..)	SAGEM - Autoliv AirBag ACU 3.8
 Megane/Scenic	AIRBAG	1.6 16v 81kw (...00)	SIEMENS - Autoliv AirBag AC4
 Megane/Scenic	AIRBAG	1.6 16v 81kw (...00)	SIEMENS - Autoliv AirBag AC6
 Megane/Scenic	AIRBAG	1.6 16v 81kw (...00)	SIEMENS - Autoliv AirBag EC5
 Megane/Scenic	AIRBAG	1.6 16v 81kw (01-..)	SAGEM - Autoliv AirBag ACU 3.8
 Megane/Scenic	AIRBAG	1.6 55kw (01-..)	SAGEM - Autoliv AirBag ACU 3.8
 Megane/Scenic	AIRBAG	1.6 66kw (...00)	SIEMENS - Autoliv AirBag AC4
 Megane/Scenic	AIRBAG	1.6 66kw (...00)	SIEMENS - Autoliv AirBag AC6
 Megane/Scenic	AIRBAG	1.6 66kw (...00)	SIEMENS - Autoliv AirBag EC5
 Megane/Scenic	AIRBAG	1.6 66kw (01-..)	SAGEM - Autoliv AirBag ACU 3.8
 Megane/Scenic	AIRBAG	1.6 GPL 66kw (...00)	SIEMENS - Autoliv AirBag AC4
 Megane/Scenic	AIRBAG	1.6 GPL 66kw (...00)	SIEMENS - Autoliv AirBag AC6
 Megane/Scenic	AIRBAG	1.6 GPL 66kw (...00)	SIEMENS - Autoliv AirBag EC5
 Megane/Scenic	AIRBAG	1.6 GPL 66kw (01-..)	SAGEM - Autoliv AirBag ACU 3.8
 Megane/Scenic	AIRBAG	1.6 GPL 79kw (01-..)	SAGEM - Autoliv AirBag ACU 3.8
 Megane/Scenic	AIRBAG	1.8 16v 87kw (01-..)	SAGEM - Autoliv AirBag ACU 3.8
 Megane/Scenic	AIRBAG	1.9 D 48kw (...00)	SIEMENS - Autoliv AirBag AC4
 Megane/Scenic	AIRBAG	1.9 D 48kw (...00)	SIEMENS - Autoliv AirBag AC6
 Megane/Scenic	AIRBAG	1.9 D 48kw (...00)	SIEMENS - Autoliv AirBag EC5
 Megane/Scenic	AIRBAG	1.9 D 48kw (01-..)	SAGEM - Autoliv AirBag ACU 3.8
 Megane/Scenic	AIRBAG	1.9 D 68kw (...00)	SIEMENS - Autoliv AirBag AC4
 Megane/Scenic	AIRBAG	1.9 D 68kw (...00)	SIEMENS - Autoliv AirBag AC6
 Megane/Scenic	AIRBAG	1.9 D 68kw (...00)	SIEMENS - Autoliv AirBag EC5
 Megane/Scenic	AIRBAG	1.9 D 68kw (01-..)	SAGEM - Autoliv AirBag ACU 3.8
 Megane/Scenic	AIRBAG	1.9 dCi 77kw (...00)	SIEMENS - Autoliv AirBag AC4
 Megane/Scenic	AIRBAG	1.9 dCi 77kw (...00)	SIEMENS - Autoliv AirBag AC6
 Megane/Scenic	AIRBAG	1.9 dCi 77kw (...00)	SIEMENS - Autoliv AirBag EC5
 Megane/Scenic	AIRBAG	1.9 dCi 77kw (01-..)	SAGEM - Autoliv AirBag ACU 3.8
 Megane/Scenic	AIRBAG	1.9 dTi 59kw (01-..)	SAGEM - Autoliv AirBag ACU 3.8
 Megane/Scenic	AIRBAG	1.9 dTi 68kw (...00)	SIEMENS - Autoliv AirBag AC4
 Megane/Scenic	AIRBAG	1.9 dTi 68kw (...00)	SIEMENS - Autoliv AirBag AC6
 Megane/Scenic	AIRBAG	1.9 dTi 68kw (...00)	SIEMENS - Autoliv AirBag EC5
 Megane/Scenic	AIRBAG	1.9 dTi 68kw (01-..)	SAGEM - Autoliv AirBag ACU 3.8

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Megane/Scenic	AIRBAG	1.9 dTi 74kw (.-00)	SIEMENS - Autoliv AirBag AC4
 Megane/Scenic	AIRBAG	1.9 dTi 74kw (.-00)	SIEMENS - Autoliv AirBag AC6
 Megane/Scenic	AIRBAG	1.9 dTi 74kw (.-00)	SIEMENS - Autoliv AirBag EC5
 Megane/Scenic	AIRBAG	1.9 dTi 74kw (01-..)	SAGEM - Autoliv AirBag ACU 3.8
 Megane/Scenic	AIRBAG	2.0 16v 101kw (01-..)	SAGEM - Autoliv AirBag ACU 3.8
 Megane/Scenic	AIRBAG	2.0 16v 103kw (01-..)	SAGEM - Autoliv AirBag ACU 3.8
 Megane/Scenic	AIRBAG	2.0 16v 110kw (.-00)	SIEMENS - Autoliv AirBag AC4
 Megane/Scenic	AIRBAG	2.0 16v 110kw (.-00)	SIEMENS - Autoliv AirBag AC6
 Megane/Scenic	AIRBAG	2.0 16v 110kw (.-00)	SIEMENS - Autoliv AirBag EC5
 Megane/Scenic	AIRBAG	2.0 16v 110kw (01-..)	SAGEM - Autoliv AirBag ACU 3.8
 Megane/Scenic	AIRBAG	2.0 83kw (.-00)	SIEMENS - Autoliv AirBag AC4
 Megane/Scenic	AIRBAG	2.0 83kw (.-00)	SIEMENS - Autoliv AirBag AC6
 Megane/Scenic	AIRBAG	2.0 83kw (.-00)	SIEMENS - Autoliv AirBag EC5
 Megane/Scenic	AIRBAG	2.0 83kw (01-..)	SAGEM - Autoliv AirBag ACU 3.8
 Megane/Scenic	CHASSIS NETWORK	1.4 16v 70kw	SAGEM Body Computer
 Megane/Scenic	CHASSIS NETWORK	1.4 51kw	SAGEM Body Computer
 Megane/Scenic	CHASSIS NETWORK	1.4 55kw	SAGEM Body Computer
 Megane/Scenic	CHASSIS NETWORK	1.6 16v 81kw	SAGEM Body Computer
 Megane/Scenic	CHASSIS NETWORK	1.6 55kw	SAGEM Body Computer
 Megane/Scenic	CHASSIS NETWORK	1.6 66kw	SAGEM Body Computer
 Megane/Scenic	CHASSIS NETWORK	1.6 GPL 66kw	SAGEM Body Computer
 Megane/Scenic	CHASSIS NETWORK	1.6 GPL 79kw	SAGEM Body Computer
 Megane/Scenic	CHASSIS NETWORK	1.8 16v 87kw	SAGEM Body Computer
 Megane/Scenic	CHASSIS NETWORK	1.9 D 48kw	SAGEM Body Computer
 Megane/Scenic	CHASSIS NETWORK	1.9 D 68kw	SAGEM Body Computer
 Megane/Scenic	CHASSIS NETWORK	1.9 dCi 77kw	SAGEM Body Computer
 Megane/Scenic	CHASSIS NETWORK	1.9 dTi 59kw	SAGEM Body Computer
 Megane/Scenic	CHASSIS NETWORK	1.9 dTi 68kw	SAGEM Body Computer
 Megane/Scenic	CHASSIS NETWORK	1.9 dTi 74kw	SAGEM Body Computer
 Megane/Scenic	CHASSIS NETWORK	2.0 16v 101kw	SAGEM Body Computer
 Megane/Scenic	CHASSIS NETWORK	2.0 16v 103kw	SAGEM Body Computer
 Megane/Scenic	CHASSIS NETWORK	2.0 16v 110kw	SAGEM Body Computer
 Megane/Scenic	CHASSIS NETWORK	2.0 83kw	SAGEM Body Computer
 Megane/Scenic	DIESEL MANAGEME	1.9 D 48kw F8Q-620	SIEMENS Diesel DCU3R
 Megane/Scenic	DIESEL MANAGEME	1.9 D 48kw F8Q-620 (.-99)	LUCAS Diesel DPCN1
 Megane/Scenic	DIESEL MANAGEME	1.9 dTi 68kw F9Q-730 (.-01)	BOSCH MSA 15
 Megane/Scenic	DIESEL MANAGEME	1.9 dTi 74kw F9Q-734 (.-01)	BOSCH MSA 15
 Megane/Scenic	DIESEL MANAGEME	1.9 dTi 74kw F9Q-736 (.-01)	BOSCH MSA 15
 Megane/Scenic	ENGINE MANAGEME	1.4 16v 70kw K4J-714	SIEMENS Sirius 32
 Megane/Scenic	ENGINE MANAGEME	1.4 51kw E7J-624	SIEMENS BOSCH SPI
 Megane/Scenic	ENGINE MANAGEME	1.4 51kw E7J-624	SIEMENS BOSCH SPI
 Megane/Scenic	ENGINE MANAGEME	1.4 51kw E7J-624	SIEMENS BOSCH SPI
 Megane/Scenic	ENGINE MANAGEME	1.4 51kw E7J-624	SIEMENS BOSCH SPI
 Megane/Scenic	ENGINE MANAGEME	1.4 51kw E7J-624	SIEMENS FENIX 5
 Megane/Scenic	ENGINE MANAGEME	1.4 55kw E7J-664	SIEMENS BOSCH SPI
 Megane/Scenic	ENGINE MANAGEME	1.4 55kw E7J-664	SIEMENS BOSCH SPI
 Megane/Scenic	ENGINE MANAGEME	1.4 55kw E7J-664	SIEMENS BOSCH SPI
 Megane/Scenic	ENGINE MANAGEME	1.4 55kw E7J-664	SIEMENS BOSCH SPI
 Megane/Scenic	ENGINE MANAGEME	1.4 55kw E7J-664	SIEMENS FENIX 5
 Megane/Scenic	ENGINE MANAGEME	1.6 16v 81kw K4M-700	SIEMENS Sirius 32
 Megane/Scenic	ENGINE MANAGEME	1.6 16v 81kw K4M-701	SIEMENS Sirius 32
 Megane/Scenic	ENGINE MANAGEME	1.6 55kw K7M-720	SIEMENS
 Megane/Scenic	ENGINE MANAGEME	1.6 66kw K7M-702	SIEMENS FENIX 5
 Megane/Scenic	ENGINE MANAGEME	1.6 66kw K7M-702	SIEMENS FENIX 5
 Megane/Scenic	ENGINE MANAGEME	1.6 66kw K7M-702	SIEMENS FENIX 5
 Megane/Scenic	ENGINE MANAGEME	1.6 66kw K7M-702	SIEMENS FENIX 5
 Megane/Scenic	ENGINE MANAGEME	1.6 66kw K7M-702	SIEMENS FENIX 5

CARS **Renault**

Page 970 of 1129

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Megane/Scenic	ENGINE MANAGEME	2.0 16v 110kw F7R-710	SIEMENS FENIX 5
 Megane/Scenic	ENGINE MANAGEME	2.0 16v 110kw F7R-710	SIEMENS FENIX 5
 Megane/Scenic	ENGINE MANAGEME	2.0 16v 110kw F7R-714	SIEMENS FENIX 5
 Megane/Scenic	ENGINE MANAGEME	2.0 16v 110kw F7R-714	SIEMENS FENIX 5
 Megane/Scenic	ENGINE MANAGEME	2.0 16v 110kw F7R-714	SIEMENS FENIX 5
 Megane/Scenic	ENGINE MANAGEME	2.0 83kw F3R-750	SIEMENS FENIX 5
 Megane/Scenic	ENGINE MANAGEME	2.0 83kw F3R-750	SIEMENS FENIX 5
 Megane/Scenic	ENGINE MANAGEME	2.0 83kw F3R-750	SIEMENS FENIX 5
 Megane/Scenic	ENGINE MANAGEME	2.0 83kw F3R-750	SIEMENS FENIX 5
 Megane/Scenic	ENGINE MANAGEME	2.0 83kw F3R-750	SIEMENS FENIX 5
 Megane/Scenic	ENGINE MANAGEME	2.0 83kw F3R-750	SIEMENS FENIX 5
 Megane/Scenic	ENGINE MANAGEME	2.0 83kw F3R-751	SIEMENS FENIX 5
 Megane/Scenic	ENGINE MANAGEME	2.0 83kw F3R-751	SIEMENS FENIX 5
 Megane/Scenic	ENGINE MANAGEME	2.0 83kw F3R-751	SIEMENS FENIX 5
 Megane/Scenic	ENGINE MANAGEME	2.0 83kw F3R-751	SIEMENS FENIX 5
 Megane/Scenic	ENGINE MANAGEME	2.0 83kw F3R-751	SIEMENS FENIX 5
 Megane/Scenic	ENGINE MANAGEME	2.0 83kw F3R-751	SIEMENS FENIX 5
 Megane/Scenic	ENGINE MANAGEME	2.0 83kw F3R-751	SIEMENS FENIX 5
 Modus	ABS	1.2 16v 48kw	AUTODETECT
 Modus	ABS	1.2 16v 48kw (04-..)	ABS 8.0
 Modus	ABS	1.2 16v 55kw	AUTODETECT
 Modus	ABS	1.2 16v 55kw (04-..)	ABS 8.0
 Modus	ABS	1.2 16v 58kw	AUTODETECT
 Modus	ABS	1.2 16v 58kw (04-..)	ABS 8.0
 Modus	ABS	1.2 16v 74kw	AUTODETECT
 Modus	ABS	1.2 16v 74kw (04-..)	ABS 8.0
 Modus	ABS	1.4 16v 72kw	AUTODETECT
 Modus	ABS	1.4 16v 72kw (04-..)	ABS 8.0
 Modus	ABS	1.5 dCi 48kw	AUTODETECT
 Modus	ABS	1.5 dCi 48kw (04-..)	ABS 8.0
 Modus	ABS	1.5 dCi 50kw	AUTODETECT
 Modus	ABS	1.5 dCi 50kw (04-..)	ABS 8.0
 Modus	ABS	1.5 dCi 60kw	AUTODETECT
 Modus	ABS	1.5 dCi 60kw (04-..)	ABS 8.0
 Modus	ABS	1.5 dCi 63kw	AUTODETECT
 Modus	ABS	1.5 dCi 63kw (04-..)	ABS 8.0
 Modus	ABS	1.5 dCi 78kw	AUTODETECT
 Modus	ABS	1.5 dCi 78kw (04-..)	ABS 8.0
 Modus	ABS	1.5 dCi FAP 76kw	AUTODETECT
 Modus	ABS	1.5 dCi FAP 76kw (04-..)	ABS 8.0
 Modus	ABS	1.6 16v 65kw	AUTODETECT
 Modus	ABS	1.6 16v 65kw (04-..)	ABS 8.0
 Modus	ABS	1.6 16v 82kw	AUTODETECT
 Modus	ABS	1.6 16v 82kw (04-..)	ABS 8.0
 Modus	AIRBAG	1.2 16v 48kw	AUTODETECT
 Modus	AIRBAG	1.2 16v 48kw	SIEMENS-Autoliv SRP ACU4 MK2
 Modus	AIRBAG	1.2 16v 55kw	AUTODETECT
 Modus	AIRBAG	1.2 16v 55kw	SIEMENS-Autoliv SRP ACU4 MK2
 Modus	AIRBAG	1.2 16v 58kw	AUTODETECT
 Modus	AIRBAG	1.2 16v 58kw	SIEMENS-Autoliv SRP ACU4 MK2
 Modus	AIRBAG	1.2 16v 74kw	AUTODETECT
 Modus	AIRBAG	1.2 16v 74kw	SIEMENS-Autoliv SRP ACU4 MK2
 Modus	AIRBAG	1.4 16v 72kw	AUTODETECT
 Modus	AIRBAG	1.4 16v 72kw	SIEMENS-Autoliv SRP ACU4 MK2
 Modus	AIRBAG	1.5 dCi 48kw	AUTODETECT
 Modus	AIRBAG	1.5 dCi 48kw	SIEMENS-Autoliv SRP ACU4 MK2
 Modus	AIRBAG	1.5 dCi 50kw	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Modus	AIRBAG	1.5 dCi 50kw	SIEMENS-Autoliv SRP ACU4 MK2
 Modus	AIRBAG	1.5 dCi 60kw	AUTODETECT
 Modus	AIRBAG	1.5 dCi 60kw	SIEMENS-Autoliv SRP ACU4 MK2
 Modus	AIRBAG	1.5 dCi 63kw	AUTODETECT
 Modus	AIRBAG	1.5 dCi 63kw	SIEMENS-Autoliv SRP ACU4 MK2
 Modus	AIRBAG	1.5 dCi 78kw	AUTODETECT
 Modus	AIRBAG	1.5 dCi 78kw	SIEMENS-Autoliv SRP ACU4 MK2
 Modus	AIRBAG	1.5 dCi FAP 76kw	AUTODETECT
 Modus	AIRBAG	1.5 dCi FAP 76kw	SIEMENS-Autoliv SRP ACU4 MK2
 Modus	AIRBAG	1.6 16v 65kw	AUTODETECT
 Modus	AIRBAG	1.6 16v 65kw	SIEMENS-Autoliv SRP ACU4 MK2
 Modus	AIRBAG	1.6 16v 82kw	AUTODETECT
 Modus	AIRBAG	1.6 16v 82kw	SIEMENS-Autoliv SRP ACU4 MK2
 Modus	AUTOM. TRANSMISSI	1.2 16v 48kw	AUTODETECT
 Modus	AUTOM. TRANSMISSI	1.2 16v 55kw	AUTODETECT
 Modus	AUTOM. TRANSMISSI	1.2 16v 58kw	AUTODETECT
 Modus	AUTOM. TRANSMISSI	1.2 16v 74kw	AUTODETECT
 Modus	AUTOM. TRANSMISSI	1.4 16v 72kw	AUTODETECT
 Modus	AUTOM. TRANSMISSI	1.5 dCi 48kw	AUTODETECT
 Modus	AUTOM. TRANSMISSI	1.5 dCi 50kw	AUTODETECT
 Modus	AUTOM. TRANSMISSI	1.5 dCi 60kw	AUTODETECT
 Modus	AUTOM. TRANSMISSI	1.5 dCi 63kw	AUTODETECT
 Modus	AUTOM. TRANSMISSI	1.5 dCi 78kw	AUTODETECT
 Modus	AUTOM. TRANSMISSI	1.5 dCi FAP 76kw	AUTODETECT
 Modus	AUTOM. TRANSMISSI	1.6 16v 65kw	AUTODETECT
 Modus	AUTOM. TRANSMISSI	1.6 16v 82kw	AUTODETECT
 Modus	CHASSIS NETWORK	1.2 16v 48kw	UCH AUTODETECT
 Modus	CHASSIS NETWORK	1.2 16v 48kw	UPC AUTODETECT
 Modus	CHASSIS NETWORK	1.2 16v 48kw (04-..)	Body Computer
 Modus	CHASSIS NETWORK	1.2 16v 48kw (04-..)	UPC
 Modus	CHASSIS NETWORK	1.2 16v 55kw	UCH AUTODETECT
 Modus	CHASSIS NETWORK	1.2 16v 55kw	UPC AUTODETECT
 Modus	CHASSIS NETWORK	1.2 16v 55kw (04-..)	Body Computer
 Modus	CHASSIS NETWORK	1.2 16v 55kw (04-..)	UPC
 Modus	CHASSIS NETWORK	1.2 16v 58kw	UCH AUTODETECT
 Modus	CHASSIS NETWORK	1.2 16v 58kw	UPC AUTODETECT
 Modus	CHASSIS NETWORK	1.2 16v 58kw (04-..)	Body Computer
 Modus	CHASSIS NETWORK	1.2 16v 58kw (04-..)	UPC
 Modus	CHASSIS NETWORK	1.2 16v 74kw	UCH AUTODETECT
 Modus	CHASSIS NETWORK	1.2 16v 74kw	UPC AUTODETECT
 Modus	CHASSIS NETWORK	1.2 16v 74kw (04-..)	Body Computer
 Modus	CHASSIS NETWORK	1.2 16v 74kw (04-..)	UPC
 Modus	CHASSIS NETWORK	1.4 16v 72kw	UCH AUTODETECT
 Modus	CHASSIS NETWORK	1.4 16v 72kw	UPC AUTODETECT
 Modus	CHASSIS NETWORK	1.4 16v 72kw (04-..)	Body Computer
 Modus	CHASSIS NETWORK	1.4 16v 72kw (04-..)	UPC
 Modus	CHASSIS NETWORK	1.5 dCi 48kw	UCH AUTODETECT
 Modus	CHASSIS NETWORK	1.5 dCi 48kw	UPC AUTODETECT
 Modus	CHASSIS NETWORK	1.5 dCi 48kw (04-..)	Body Computer
 Modus	CHASSIS NETWORK	1.5 dCi 48kw (04-..)	UPC
 Modus	CHASSIS NETWORK	1.5 dCi 50kw	UCH AUTODETECT
 Modus	CHASSIS NETWORK	1.5 dCi 50kw	UPC AUTODETECT
 Modus	CHASSIS NETWORK	1.5 dCi 50kw (04-..)	Body Computer
 Modus	CHASSIS NETWORK	1.5 dCi 50kw (04-..)	UPC
 Modus	CHASSIS NETWORK	1.5 dCi 60kw	UCH AUTODETECT
 Modus	CHASSIS NETWORK	1.5 dCi 60kw	UPC AUTODETECT
 Modus	CHASSIS NETWORK	1.5 dCi 60kw (04-..)	Body Computer
 Modus	CHASSIS NETWORK	1.5 dCi 60kw (04-..)	UPC

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Modus	CHASSIS NETWORK	1.5 dCi 63kw	UCH AUTODETECT
 Modus	CHASSIS NETWORK	1.5 dCi 63kw	UPC AUTODETECT
 Modus	CHASSIS NETWORK	1.5 dCi 63kw (04-..)	Body Computer
 Modus	CHASSIS NETWORK	1.5 dCi 63kw (04-..)	UPC
 Modus	CHASSIS NETWORK	1.5 dCi 78kw	UCH AUTODETECT
 Modus	CHASSIS NETWORK	1.5 dCi 78kw	UPC AUTODETECT
 Modus	CHASSIS NETWORK	1.5 dCi 78kw (04-..)	Body Computer
 Modus	CHASSIS NETWORK	1.5 dCi 78kw (04-..)	UPC
 Modus	CHASSIS NETWORK	1.5 dCi FAP 76kw	UCH AUTODETECT
 Modus	CHASSIS NETWORK	1.5 dCi FAP 76kw	UPC AUTODETECT
 Modus	CHASSIS NETWORK	1.5 dCi FAP 76kw (04-..)	Body Computer
 Modus	CHASSIS NETWORK	1.5 dCi FAP 76kw (04-..)	UPC
 Modus	CHASSIS NETWORK	1.6 16v 65kw	UCH AUTODETECT
 Modus	CHASSIS NETWORK	1.6 16v 65kw	UPC AUTODETECT
 Modus	CHASSIS NETWORK	1.6 16v 65kw (04-..)	Body Computer
 Modus	CHASSIS NETWORK	1.6 16v 65kw (04-..)	UPC
 Modus	CHASSIS NETWORK	1.6 16v 82kw	UCH AUTODETECT
 Modus	CHASSIS NETWORK	1.6 16v 82kw	UPC AUTODETECT
 Modus	CHASSIS NETWORK	1.6 16v 82kw (04-..)	Body Computer
 Modus	CHASSIS NETWORK	1.6 16v 82kw (04-..)	UPC
 Modus	CLIMA	1.2 16v 48kw	AUTODETECT
 Modus	CLIMA	1.2 16v 55kw	AUTODETECT
 Modus	CLIMA	1.2 16v 58kw	AUTODETECT
 Modus	CLIMA	1.2 16v 74kw	AUTODETECT
 Modus	CLIMA	1.4 16v 72kw	AUTODETECT
 Modus	CLIMA	1.5 dCi 48kw	AUTODETECT
 Modus	CLIMA	1.5 dCi 50kw	AUTODETECT
 Modus	CLIMA	1.5 dCi 60kw	AUTODETECT
 Modus	CLIMA	1.5 dCi 63kw	AUTODETECT
 Modus	CLIMA	1.5 dCi 78kw	AUTODETECT
 Modus	CLIMA	1.5 dCi FAP 76kw	AUTODETECT
 Modus	CLIMA	1.6 16v 65kw	AUTODETECT
 Modus	CLIMA	1.6 16v 82kw	AUTODETECT
 Modus	DASHBOARD	1.2 16v 48kw	AUTODETECT
 Modus	DASHBOARD	1.2 16v 48kw (04-..)	Dashboard
 Modus	DASHBOARD	1.2 16v 55kw	AUTODETECT
 Modus	DASHBOARD	1.2 16v 55kw (04-..)	Dashboard
 Modus	DASHBOARD	1.2 16v 58kw	AUTODETECT
 Modus	DASHBOARD	1.2 16v 58kw (04-..)	Dashboard
 Modus	DASHBOARD	1.2 16v 74kw	AUTODETECT
 Modus	DASHBOARD	1.2 16v 74kw (04-..)	Dashboard
 Modus	DASHBOARD	1.4 16v 72kw	AUTODETECT
 Modus	DASHBOARD	1.4 16v 72kw (04-..)	Dashboard
 Modus	DASHBOARD	1.5 dCi 48kw	AUTODETECT
 Modus	DASHBOARD	1.5 dCi 48kw (04-..)	Dashboard
 Modus	DASHBOARD	1.5 dCi 50kw	AUTODETECT
 Modus	DASHBOARD	1.5 dCi 50kw (04-..)	Dashboard
 Modus	DASHBOARD	1.5 dCi 60kw	AUTODETECT
 Modus	DASHBOARD	1.5 dCi 60kw (04-..)	Dashboard
 Modus	DASHBOARD	1.5 dCi 63kw	AUTODETECT
 Modus	DASHBOARD	1.5 dCi 63kw (04-..)	Dashboard
 Modus	DASHBOARD	1.5 dCi 78kw	AUTODETECT
 Modus	DASHBOARD	1.5 dCi 78kw (04-..)	Dashboard
 Modus	DASHBOARD	1.5 dCi FAP 76kw	AUTODETECT
 Modus	DASHBOARD	1.5 dCi FAP 76kw (04-..)	Dashboard
 Modus	DASHBOARD	1.6 16v 65kw	AUTODETECT
 Modus	DASHBOARD	1.6 16v 65kw (04-..)	Dashboard
 Modus	DASHBOARD	1.6 16v 82kw	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Modus	DASHBOARD	1.6 16v 82kw (04-..)	Dashboard
 Modus	ELECTRIC STEERING	1.2 16v 48kw	AUTODETECT
 Modus	ELECTRIC STEERING	1.2 16v 48kw (04-..)	TRW EPS
 Modus	ELECTRIC STEERING	1.2 16v 55kw	AUTODETECT
 Modus	ELECTRIC STEERING	1.2 16v 55kw (04-..)	TRW EPS
 Modus	ELECTRIC STEERING	1.2 16v 58kw	AUTODETECT
 Modus	ELECTRIC STEERING	1.2 16v 58kw (04-..)	TRW EPS
 Modus	ELECTRIC STEERING	1.2 16v 74kw	AUTODETECT
 Modus	ELECTRIC STEERING	1.2 16v 74kw (04-..)	TRW EPS
 Modus	ELECTRIC STEERING	1.4 16v 72kw	AUTODETECT
 Modus	ELECTRIC STEERING	1.4 16v 72kw (04-..)	TRW EPS
 Modus	ELECTRIC STEERING	1.5 dCi 48kw	AUTODETECT
 Modus	ELECTRIC STEERING	1.5 dCi 48kw (04-..)	TRW EPS
 Modus	ELECTRIC STEERING	1.5 dCi 50kw	AUTODETECT
 Modus	ELECTRIC STEERING	1.5 dCi 50kw (04-..)	TRW EPS
 Modus	ELECTRIC STEERING	1.5 dCi 60kw	AUTODETECT
 Modus	ELECTRIC STEERING	1.5 dCi 60kw (04-..)	TRW EPS
 Modus	ELECTRIC STEERING	1.5 dCi 63kw	AUTODETECT
 Modus	ELECTRIC STEERING	1.5 dCi 63kw (04-..)	TRW EPS
 Modus	ELECTRIC STEERING	1.5 dCi 78kw	AUTODETECT
 Modus	ELECTRIC STEERING	1.5 dCi 78kw (04-..)	TRW EPS
 Modus	ELECTRIC STEERING	1.5 dCi FAP 76kw	AUTODETECT
 Modus	ELECTRIC STEERING	1.5 dCi FAP 76kw (04-..)	TRW EPS
 Modus	ELECTRIC STEERING	1.6 16v 65kw	AUTODETECT
 Modus	ELECTRIC STEERING	1.6 16v 65kw (04-..)	TRW EPS
 Modus	ELECTRIC STEERING	1.6 16v 82kw	AUTODETECT
 Modus	ELECTRIC STEERING	1.6 16v 82kw (04-..)	TRW EPS
 Modus	ENGINE MANAGEME	1.2 16v 48kw D4F-740	EOBD
 Modus	ENGINE MANAGEME	1.2 16v 55kw	AUTODETECT
 Modus	ENGINE MANAGEME	1.2 16v 58kw D4F-764	EOBD
 Modus	ENGINE MANAGEME	1.2 16v 74kw D4F-784	EOBD
 Modus	ENGINE MANAGEME	1.4 16v 72kw	AUTODETECT
 Modus	ENGINE MANAGEME	1.5 dCi 48kw	AUTODETECT
 Modus	ENGINE MANAGEME	1.5 dCi 50kw (04-..)	EOBD
 Modus	ENGINE MANAGEME	1.5 dCi 60kw	AUTODETECT
 Modus	ENGINE MANAGEME	1.5 dCi 60kw K9K-750 (04-..)	SIEMENS EDC SID
 Modus	ENGINE MANAGEME	1.5 dCi 63kw (04-..)	EOBD
 Modus	ENGINE MANAGEME	1.5 dCi 78kw (04-..)	EOBD
 Modus	ENGINE MANAGEME	1.5 dCi FAP 76kw K9K-772	EOBD
 Modus	ENGINE MANAGEME	1.6 16v 65kw	AUTODETECT
 Modus	ENGINE MANAGEME	1.6 16v 82kw	AUTODETECT
 Modus	HEADLIGHT LEVEL	1.2 16v 48kw	can AUTODETECT
 Modus	HEADLIGHT LEVEL	1.2 16v 55kw	can AUTODETECT
 Modus	HEADLIGHT LEVEL	1.2 16v 58kw	can AUTODETECT
 Modus	HEADLIGHT LEVEL	1.2 16v 74kw	can AUTODETECT
 Modus	HEADLIGHT LEVEL	1.4 16v 72kw	can AUTODETECT
 Modus	HEADLIGHT LEVEL	1.5 dCi 48kw	can AUTODETECT
 Modus	HEADLIGHT LEVEL	1.5 dCi 50kw	can AUTODETECT
 Modus	HEADLIGHT LEVEL	1.5 dCi 60kw	can AUTODETECT
 Modus	HEADLIGHT LEVEL	1.5 dCi 63kw	can AUTODETECT
 Modus	HEADLIGHT LEVEL	1.5 dCi 78kw	can AUTODETECT
 Modus	HEADLIGHT LEVEL	1.5 dCi FAP 76kw	can AUTODETECT
 Modus	HEADLIGHT LEVEL	1.6 16v 65kw	can AUTODETECT
 Modus	HEADLIGHT LEVEL	1.6 16v 82kw	can AUTODETECT
 Modus	MAINTENANCE	1.2 16v 48kw	SIEMENS-Autoliv SRP ACU4 MK2
 Modus	MAINTENANCE	1.2 16v 48kw (04-..)	ABS 8.0
 Modus	MAINTENANCE	1.2 16v 48kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.2 16v 48kw (04-..)	Dashboard

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Modus	MAINTENANCE	1.2 16v 48kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.2 16v 48kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.2 16v 48kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.2 16v 48kw (04-..)	TRW EPS
 Modus	MAINTENANCE	1.2 16v 48kw (05-07)	MANUAL
 Modus	MAINTENANCE	1.2 16v 55kw	SIEMENS-Autoliv SRP ACU4 MK2
 Modus	MAINTENANCE	1.2 16v 55kw (04-..)	ABS 8.0
 Modus	MAINTENANCE	1.2 16v 55kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.2 16v 55kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.2 16v 55kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.2 16v 55kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.2 16v 55kw (04-..)	TRW EPS
 Modus	MAINTENANCE	1.2 16v 55kw (05-07)	MANUAL
 Modus	MAINTENANCE	1.2 16v 58kw	SIEMENS-Autoliv SRP ACU4 MK2
 Modus	MAINTENANCE	1.2 16v 58kw (04-..)	ABS 8.0
 Modus	MAINTENANCE	1.2 16v 58kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.2 16v 58kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.2 16v 58kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.2 16v 58kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.2 16v 58kw (04-..)	TRW EPS
 Modus	MAINTENANCE	1.2 16v 58kw (05-07)	MANUAL
 Modus	MAINTENANCE	1.2 16v 74kw	SIEMENS-Autoliv SRP ACU4 MK2
 Modus	MAINTENANCE	1.2 16v 74kw (04-..)	ABS 8.0
 Modus	MAINTENANCE	1.2 16v 74kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.2 16v 74kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.2 16v 74kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.2 16v 74kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.2 16v 74kw (04-..)	TRW EPS
 Modus	MAINTENANCE	1.2 16v 74kw (05-07)	MANUAL
 Modus	MAINTENANCE	1.4 16v 72kw	SIEMENS-Autoliv SRP ACU4 MK2
 Modus	MAINTENANCE	1.4 16v 72kw (04-..)	ABS 8.0
 Modus	MAINTENANCE	1.4 16v 72kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.4 16v 72kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.4 16v 72kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.4 16v 72kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.4 16v 72kw (04-..)	TRW EPS
 Modus	MAINTENANCE	1.4 16v 72kw (05-07)	MANUAL
 Modus	MAINTENANCE	1.5 dCi 48kw	SIEMENS-Autoliv SRP ACU4 MK2
 Modus	MAINTENANCE	1.5 dCi 48kw (04-..)	ABS 8.0
 Modus	MAINTENANCE	1.5 dCi 48kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.5 dCi 48kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.5 dCi 48kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.5 dCi 48kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.5 dCi 48kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.5 dCi 48kw (04-..)	TRW EPS
 Modus	MAINTENANCE	1.5 dCi 48kw (05-07)	MANUAL
 Modus	MAINTENANCE	1.5 dCi 50kw	SIEMENS-Autoliv SRP ACU4 MK2
 Modus	MAINTENANCE	1.5 dCi 50kw (04-..)	ABS 8.0
 Modus	MAINTENANCE	1.5 dCi 50kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.5 dCi 50kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.5 dCi 50kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.5 dCi 50kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.5 dCi 50kw (04-..)	TRW EPS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Modus	MAINTENANCE	1.5 dCi 50kw (05-07)	MANUAL
 Modus	MAINTENANCE	1.5 dCi 60kw	SIEMENS-Autoliv SRP ACU4 MK2
 Modus	MAINTENANCE	1.5 dCi 60kw (04-..)	ABS 8.0
 Modus	MAINTENANCE	1.5 dCi 60kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.5 dCi 60kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.5 dCi 60kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.5 dCi 60kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.5 dCi 60kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.5 dCi 60kw (04-..)	TRW EPS
 Modus	MAINTENANCE	1.5 dCi 60kw (05-07)	MANUAL
 Modus	MAINTENANCE	1.5 dCi 60kw K9K-750 (04-..)	SIEMENS EDC SID
 Modus	MAINTENANCE	1.5 dCi 63kw	SIEMENS-Autoliv SRP ACU4 MK2
 Modus	MAINTENANCE	1.5 dCi 63kw (04-..)	ABS 8.0
 Modus	MAINTENANCE	1.5 dCi 63kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.5 dCi 63kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.5 dCi 63kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.5 dCi 63kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.5 dCi 63kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.5 dCi 63kw (04-..)	TRW EPS
 Modus	MAINTENANCE	1.5 dCi 63kw (05-07)	MANUAL
 Modus	MAINTENANCE	1.5 dCi 78kw	SIEMENS-Autoliv SRP ACU4 MK2
 Modus	MAINTENANCE	1.5 dCi 78kw (04-..)	ABS 8.0
 Modus	MAINTENANCE	1.5 dCi 78kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.5 dCi 78kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.5 dCi 78kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.5 dCi 78kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.5 dCi 78kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.5 dCi 78kw (04-..)	TRW EPS
 Modus	MAINTENANCE	1.5 dCi 78kw (05-07)	MANUAL
 Modus	MAINTENANCE	1.5 dCi FAP 76kw	SIEMENS-Autoliv SRP ACU4 MK2
 Modus	MAINTENANCE	1.5 dCi FAP 76kw (04-..)	ABS 8.0
 Modus	MAINTENANCE	1.5 dCi FAP 76kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.5 dCi FAP 76kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.5 dCi FAP 76kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.5 dCi FAP 76kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.5 dCi FAP 76kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.5 dCi FAP 76kw (04-..)	TRW EPS
 Modus	MAINTENANCE	1.5 dCi FAP 76kw (05-07)	MANUAL
 Modus	MAINTENANCE	1.6 16v 65kw	SIEMENS-Autoliv SRP ACU4 MK2
 Modus	MAINTENANCE	1.6 16v 65kw (04-..)	ABS 8.0
 Modus	MAINTENANCE	1.6 16v 65kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.6 16v 65kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.6 16v 65kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.6 16v 65kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.6 16v 65kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.6 16v 65kw (04-..)	TRW EPS
 Modus	MAINTENANCE	1.6 16v 65kw (05-07)	MANUAL
 Modus	MAINTENANCE	1.6 16v 82kw	SIEMENS-Autoliv SRP ACU4 MK2
 Modus	MAINTENANCE	1.6 16v 82kw (04-..)	ABS 8.0
 Modus	MAINTENANCE	1.6 16v 82kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.6 16v 82kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.6 16v 82kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.6 16v 82kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.6 16v 82kw (04-..)	Dashboard
 Modus	MAINTENANCE	1.6 16v 82kw (04-..)	TRW EPS
 Modus	MAINTENANCE	1.6 16v 82kw (05-07)	MANUAL
 Modus	PHONE	1.2 16v 48kw	Handsfree Kit AUTODETECT
 Modus	PHONE	1.2 16v 55kw	Handsfree Kit AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Modus	PHONE	1.2 16v 58kw	Handsfree Kit AUTODETECT
 Modus	PHONE	1.2 16v 74kw	Handsfree Kit AUTODETECT
 Modus	PHONE	1.4 16v 72kw	Handsfree Kit AUTODETECT
 Modus	PHONE	1.5 dCi 48kw	Handsfree Kit AUTODETECT
 Modus	PHONE	1.5 dCi 50kw	Handsfree Kit AUTODETECT
 Modus	PHONE	1.5 dCi 60kw	Handsfree Kit AUTODETECT
 Modus	PHONE	1.5 dCi 63kw	Handsfree Kit AUTODETECT
 Modus	PHONE	1.5 dCi 78kw	Handsfree Kit AUTODETECT
 Modus	PHONE	1.5 dCi FAP 76kw	Handsfree Kit AUTODETECT
 Modus	PHONE	1.6 16v 65kw	Handsfree Kit AUTODETECT
 Modus	PHONE	1.6 16v 82kw	Handsfree Kit AUTODETECT
 Modus	SERVICE LIGHT RES	1.2 16v 48kw (05-07)	MANUAL
 Modus	SERVICE LIGHT RES	1.2 16v 55kw (05-07)	MANUAL
 Modus	SERVICE LIGHT RES	1.2 16v 58kw (05-07)	MANUAL
 Modus	SERVICE LIGHT RES	1.2 16v 74kw (05-07)	MANUAL
 Modus	SERVICE LIGHT RES	1.4 16v 72kw (05-07)	MANUAL
 Modus	SERVICE LIGHT RES	1.5 dCi 48kw (05-07)	MANUAL
 Modus	SERVICE LIGHT RES	1.5 dCi 50kw (05-07)	MANUAL
 Modus	SERVICE LIGHT RES	1.5 dCi 60kw (05-07)	MANUAL
 Modus	SERVICE LIGHT RES	1.5 dCi 63kw (05-07)	MANUAL
 Modus	SERVICE LIGHT RES	1.5 dCi 78kw (05-07)	MANUAL
 Modus	SERVICE LIGHT RES	1.5 dCi FAP 76kw (05-07)	MANUAL
 Modus	SERVICE LIGHT RES	1.6 16v 65kw (05-07)	MANUAL
 Modus	SERVICE LIGHT RES	1.6 16v 82kw (05-07)	MANUAL
 Modus	TIRE PRESSURE	1.2 16v 48kw	AUTODETECT
 Modus	TIRE PRESSURE	1.2 16v 55kw	AUTODETECT
 Modus	TIRE PRESSURE	1.2 16v 58kw	AUTODETECT
 Modus	TIRE PRESSURE	1.2 16v 74kw	AUTODETECT
 Modus	TIRE PRESSURE	1.4 16v 72kw	AUTODETECT
 Modus	TIRE PRESSURE	1.5 dCi 48kw	AUTODETECT
 Modus	TIRE PRESSURE	1.5 dCi 50kw	AUTODETECT
 Modus	TIRE PRESSURE	1.5 dCi 60kw	AUTODETECT
 Modus	TIRE PRESSURE	1.5 dCi 63kw	AUTODETECT
 Modus	TIRE PRESSURE	1.5 dCi 78kw	AUTODETECT
 Modus	TIRE PRESSURE	1.5 dCi FAP 76kw	AUTODETECT
 Modus	TIRE PRESSURE	1.6 16v 65kw	AUTODETECT
 Modus	TIRE PRESSURE	1.6 16v 82kw	AUTODETECT
 Safrane	ABS	2.0 16v 101kw	BOSCH ABS 5.3
 Safrane	ABS	2.0 16v 101kw	BOSCH ABS 5.3 T
 Safrane	ABS	2.0 77kw	BOSCH ABS 5.3
 Safrane	ABS	2.0 77kw	BOSCH ABS 5.3 T
 Safrane	ABS	2.0 97kw	BOSCH ABS 5.3
 Safrane	ABS	2.0 97kw	BOSCH ABS 5.3 T
 Safrane	ABS	2.2 101kw	BOSCH ABS 5.3
 Safrane	ABS	2.2 101kw	BOSCH ABS 5.3 T
 Safrane	ABS	2.2 81kw	BOSCH ABS 5.3
 Safrane	ABS	2.2 81kw	BOSCH ABS 5.3 T
 Safrane	ABS	2.2 TD 85kw	BOSCH ABS 5.3
 Safrane	ABS	2.2 TD 85kw	BOSCH ABS 5.3 T
 Safrane	ABS	2.5 TD 83Kw	BOSCH ABS 5.3
 Safrane	ABS	2.5 TD 83Kw	BOSCH ABS 5.3 T
 Safrane	ABS	3.0 V6 123kw	BOSCH ABS 5.3
 Safrane	ABS	3.0 V6 123kw	BOSCH ABS 5.3 T
 Safrane	ABS	3.0 V6 193kw	BOSCH ABS 5.3
 Safrane	ABS	3.0 V6 193kw	BOSCH ABS 5.3 T
 Safrane	AIRBAG	2.0 16v 101kw	SIEMENS - Autoliv AirBag AC4
 Safrane	AIRBAG	2.0 16v 101kw	SIEMENS - Autoliv AirBag AC6
 Safrane	AIRBAG	2.0 16v 101kw	SIEMENS - Autoliv AirBag EC5

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Safrane	AIRBAG	2.0 77kw	SIEMENS - Autoliv AirBag AC4
 Safrane	AIRBAG	2.0 77kw	SIEMENS - Autoliv AirBag AC6
 Safrane	AIRBAG	2.0 77kw	SIEMENS - Autoliv AirBag EC5
 Safrane	AIRBAG	2.0 97kw	SIEMENS - Autoliv AirBag AC4
 Safrane	AIRBAG	2.0 97kw	SIEMENS - Autoliv AirBag AC6
 Safrane	AIRBAG	2.0 97kw	SIEMENS - Autoliv AirBag EC5
 Safrane	AIRBAG	2.2 101kw	SIEMENS - Autoliv AirBag AC4
 Safrane	AIRBAG	2.2 101kw	SIEMENS - Autoliv AirBag AC6
 Safrane	AIRBAG	2.2 101kw	SIEMENS - Autoliv AirBag EC5
 Safrane	AIRBAG	2.2 81kw	SIEMENS - Autoliv AirBag AC4
 Safrane	AIRBAG	2.2 81kw	SIEMENS - Autoliv AirBag AC6
 Safrane	AIRBAG	2.2 81kw	SIEMENS - Autoliv AirBag EC5
 Safrane	AIRBAG	2.2 TD 85kw	SIEMENS - Autoliv AirBag AC4
 Safrane	AIRBAG	2.2 TD 85kw	SIEMENS - Autoliv AirBag AC6
 Safrane	AIRBAG	2.2 TD 85kw	SIEMENS - Autoliv AirBag EC5
 Safrane	AIRBAG	2.5 TD 83Kw	SIEMENS - Autoliv AirBag AC4
 Safrane	AIRBAG	2.5 TD 83Kw	SIEMENS - Autoliv AirBag AC6
 Safrane	AIRBAG	2.5 TD 83Kw	SIEMENS - Autoliv AirBag EC5
 Safrane	AIRBAG	3.0 V6 123kw	SIEMENS - Autoliv AirBag AC4
 Safrane	AIRBAG	3.0 V6 123kw	SIEMENS - Autoliv AirBag AC6
 Safrane	AIRBAG	3.0 V6 123kw	SIEMENS - Autoliv AirBag EC5
 Safrane	AIRBAG	3.0 V6 193kw	SIEMENS - Autoliv AirBag AC4
 Safrane	AIRBAG	3.0 V6 193kw	SIEMENS - Autoliv AirBag AC6
 Safrane	AIRBAG	3.0 V6 193kw	SIEMENS - Autoliv AirBag EC5
 Safrane	DIESEL MANAGEMEN	2.2 TD 85kw G8T-740	SAGEM EGR Diesel
 Safrane	DIESEL MANAGEMEN	2.2 TD 85kw G8T-740	SAGEM EGR Diesel
 Safrane	DIESEL MANAGEMEN	2.2 TD 85kw G8T-740	SAGEM EGR Diesel
 Safrane	ENGINE MANAGEME	2.0 16v 101kw N7Q-710	SIEMENS FENIX 5
 Safrane	ENGINE MANAGEME	2.0 16v 101kw N7Q-710	SIEMENS FENIX 5
 Safrane	ENGINE MANAGEME	2.0 16v 101kw N7Q-710	SIEMENS FENIX 5
 Safrane	ENGINE MANAGEME	2.0 16v 101kw N7Q-710	SIEMENS FENIX 5
 Safrane	ENGINE MANAGEME	2.0 16v 101kw N7Q-711	SIEMENS FENIX 5
 Safrane	ENGINE MANAGEME	2.0 16v 101kw N7Q-711	SIEMENS FENIX 5
 Safrane	ENGINE MANAGEME	2.0 16v 101kw N7Q-711	SIEMENS FENIX 5
 Safrane	ENGINE MANAGEME	2.0 16v 101kw N7Q-711	SIEMENS FENIX 5
 Safrane	ENGINE MANAGEME	2.0 77kw J7R-732	SIEMENS BENDIX-FENIX MPI
 Safrane	ENGINE MANAGEME	2.0 77kw J7R-732	SIEMENS BENDIX-FENIX MPI
 Safrane	ENGINE MANAGEME	2.0 77kw J7R-732	SIEMENS BENDIX-FENIX MPI
 Safrane	ENGINE MANAGEME	2.0 77kw J7R-733	SIEMENS BENDIX-FENIX MPI
 Safrane	ENGINE MANAGEME	2.0 77kw J7R-733	SIEMENS BENDIX-FENIX MPI
 Safrane	ENGINE MANAGEME	2.0 77kw J7R-733	SIEMENS BENDIX-FENIX MPI
 Safrane	ENGINE MANAGEME	2.0 77kw J7R-734	SIEMENS BENDIX-FENIX MPI
 Safrane	ENGINE MANAGEME	2.0 77kw J7R-734	SIEMENS BENDIX-FENIX MPI
 Safrane	ENGINE MANAGEME	2.0 77kw J7R-734	SIEMENS BENDIX-FENIX MPI
 Safrane	ENGINE MANAGEME	2.0 77kw J7R-734	SIEMENS BENDIX-FENIX MPI
 Safrane	ENGINE MANAGEME	2.0 77kw J7R-735	SIEMENS BENDIX-FENIX MPI
 Safrane	ENGINE MANAGEME	2.0 77kw J7R-735	SIEMENS BENDIX-FENIX MPI
 Safrane	ENGINE MANAGEME	2.0 77kw J7R-738	SIEMENS BENDIX-FENIX MPI
 Safrane	ENGINE MANAGEME	2.0 77kw J7R-738	SIEMENS BENDIX-FENIX MPI
 Safrane	ENGINE MANAGEME	2.0 77kw J7R-739	SIEMENS BENDIX-FENIX MPI
 Safrane	ENGINE MANAGEME	2.0 77kw J7R-739	SIEMENS BENDIX-FENIX MPI
 Safrane	ENGINE MANAGEME	2.0 97kw J7R-735	SIEMENS BENDIX-FENIX MPI
 Safrane	ENGINE MANAGEME	2.2 101kw J7T-760	SIEMENS BENDIX-FENIX MPI
 Safrane	ENGINE MANAGEME	2.2 101kw J7T-760	SIEMENS BENDIX-FENIX MPI
 Safrane	ENGINE MANAGEME	2.2 101kw J7T-760	SIEMENS BENDIX-FENIX MPI
 Safrane	ENGINE MANAGEME	2.2 101kw J7T-761	SIEMENS BENDIX-FENIX MPI
 Safrane	ENGINE MANAGEME	2.2 101kw J7T-761	SIEMENS BENDIX-FENIX MPI
 Safrane	ENGINE MANAGEME	2.2 101kw J7T-761	SIEMENS BENDIX-FENIX MPI
 Safrane	ENGINE MANAGEME	2.2 81kw J7T-762	SIEMENS BENDIX-FENIX MPI

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

[illegible]

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Safrane	ENGINE MANAGEME	3.0 V6 193kw Z7X-726	SIEMENS BENDIX-FENIX MPI
 Safrane	ENGINE MANAGEME	3.0 V6 193kw Z7X-726	SIEMENS BENDIX-FENIX MPI
 Safrane	ENGINE MANAGEME	3.0 V6 193kw Z7X-726	SIEMENS BENDIX-FENIX MPI
 Safrane	ENGINE MANAGEME	3.0 V6 193kw Z7X-726	SIEMENS BENDIX-FENIX MPI
 Safrane	ENGINE MANAGEME	3.0 V6 193kw Z7X-726	SIEMENS BENDIX-FENIX MPI
 Safrane	ENGINE MANAGEME	3.0 V6 193kw Z7X-726	SIEMENS BENDIX-FENIX MPI
 Safrane	MAINTENANCE	2.0 16v 101kw (...94)	MANUAL
 Safrane	MAINTENANCE	2.0 77kw (...94)	MANUAL
 Safrane	MAINTENANCE	2.0 97kw (...94)	MANUAL
 Safrane	MAINTENANCE	2.2 101kw (...94)	MANUAL
 Safrane	MAINTENANCE	2.2 81kw (...94)	MANUAL
 Safrane	MAINTENANCE	2.2 TD 85kw (...94)	MANUAL
 Safrane	MAINTENANCE	2.5 TD 83Kw (...94)	MANUAL
 Safrane	MAINTENANCE	3.0 V6 123kw (...94)	MANUAL
 Safrane	MAINTENANCE	3.0 V6 193kw (...94)	MANUAL
 Safrane	SERVICE LIGHT RES	2.0 16v 101kw (...94)	MANUAL
 Safrane	SERVICE LIGHT RES	2.0 77kw (...94)	MANUAL
 Safrane	SERVICE LIGHT RES	2.0 97kw (...94)	MANUAL
 Safrane	SERVICE LIGHT RES	2.2 101kw (...94)	MANUAL
 Safrane	SERVICE LIGHT RES	2.2 81kw (...94)	MANUAL
 Safrane	SERVICE LIGHT RES	2.2 TD 85kw (...94)	MANUAL
 Safrane	SERVICE LIGHT RES	2.5 TD 83Kw (...94)	MANUAL
 Safrane	SERVICE LIGHT RES	3.0 V6 123kw (...94)	MANUAL
 Safrane	SERVICE LIGHT RES	3.0 V6 193kw (...94)	MANUAL
 Samsung SM3	ABS	1.6 (09-..)	AUTODETECT
 Samsung SM3	CHASSIS NETWORK	1.6 (09-..)	UCC AUTODETECT
 Samsung SM3	DASHBOARD	1.6 (09-..)	AUTODETECT
 Samsung SM3	ELECTRIC STEERING	1.6 (09-..)	AUTODETECT
 Samsung SM3	ENGINE MANAGEME	1.6 (09-..)	AUTODETECT
 Samsung SM3	PARK.BRAKE	1.6 (09-..)	AUTODETECT
 Samsung SM3	PARKING HELP	1.6 (09-..)	AUTODETECT
 Samsung SM3	RADIO / CD	1.6 (09-..)	AUTODETECT
 Samsung SM3	VISUAL./TELEMATIC	1.6 (09-..)	USB AUTODETECT
 Samsung SM7	ABS	2.5 V6 (11-..)	AUTODETECT
 Samsung SM7	ABS	3.5 V6 (11-..)	AUTODETECT
 Samsung SM7	AIRBAG	2.5 V6 (11-..)	AUTODETECT
 Samsung SM7	AIRBAG	3.5 V6 (11-..)	AUTODETECT
 Samsung SM7	AUTOM. TRANSMISSI	2.5 V6 (11-..)	AUTODETECT
 Samsung SM7	AUTOM. TRANSMISSI	3.5 V6 (11-..)	AUTODETECT
 Samsung SM7	CHASSIS NETWORK	2.5 V6 (11-..)	UCC AUTODETECT
 Samsung SM7	CHASSIS NETWORK	2.5 V6 (11-..)	UCH AUTODETECT
 Samsung SM7	CHASSIS NETWORK	3.5 V6 (11-..)	UCC AUTODETECT
 Samsung SM7	CHASSIS NETWORK	3.5 V6 (11-..)	UCH AUTODETECT
 Samsung SM7	CLIMA	2.5 V6 (11-..)	AUTODETECT
 Samsung SM7	CLIMA	3.5 V6 (11-..)	AUTODETECT
 Samsung SM7	DASHBOARD	2.5 V6 (11-..)	AUTODETECT
 Samsung SM7	DASHBOARD	3.5 V6 (11-..)	AUTODETECT
 Samsung SM7	DRIVER SIDE DOOR	2.5 V6 (11-..)	AUTODETECT
Samsung SM7	DRIVER SIDE DOOR	3.5 V6 (11-..)	AUTODETECT
Samsung SM7	ENGINE MANAGEME	2.5 V6 (11-..)	AUTODETECT
Samsung SM7	ENGINE MANAGEME	3.5 V6 (11-..)	AUTODETECT
Samsung SM7	FRONT DOORS	2.5 V6 (11-..)	AUTODETECT
Samsung SM7	FRONT DOORS	3.5 V6 (11-..)	AUTODETECT
Samsung SM7	HEADLIGHT LEVEL	2.5 V6 (11-..)	AUTODETECT
Samsung SM7	HEADLIGHT LEVEL	3.5 V6 (11-..)	AUTODETECT
Samsung SM7	MANAGEMENT SEAT	2.5 V6 (11-..)	AUTODETECT
Samsung SM7	MANAGEMENT SEAT	3.5 V6 (11-..)	AUTODETECT
Samsung SM7	PARK.BRAKE	2.5 V6 (11-..)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Samsung SM7	PARK.BRAKE	3.5 V6 (11-..)	AUTODETECT
 Samsung SM7	PARKING HELP	2.5 V6 (11-..)	can AUTODETECT
 Samsung SM7	PARKING HELP	3.5 V6 (11-..)	can AUTODETECT
 Samsung SM7	PASS. SIDE DOOR	2.5 V6 (11-..)	AUTODETECT
 Samsung SM7	PASS. SIDE DOOR	3.5 V6 (11-..)	AUTODETECT
 Samsung SM7	RADIO / CD	2.5 V6 (11-..)	AUTODETECT
 Samsung SM7	RADIO / CD	3.5 V6 (11-..)	AUTODETECT
 Samsung SM7	REAR DOORS	2.5 V6 (11-..)	AUTODETECT
 Samsung SM7	REAR DOORS	3.5 V6 (11-..)	AUTODETECT
 Samsung SM7	SOUND SYSTEM	2.5 V6 (11-..)	AUTODETECT
 Samsung SM7	SOUND SYSTEM	3.5 V6 (11-..)	AUTODETECT
 Samsung SM7	VISUAL./TELEMATIC	2.5 V6 (11-..)	BLUETOOTH AUTODETECT
 Samsung SM7	VISUAL./TELEMATIC	2.5 V6 (11-..)	USB AUTODETECT
 Samsung SM7	VISUAL./TELEMATIC	3.5 V6 (11-..)	BLUETOOTH AUTODETECT
 Samsung SM7	VISUAL./TELEMATIC	3.5 V6 (11-..)	USB AUTODETECT
 Scenic II	ABS	1.4 16v 72kw	AUTODETECT
 Scenic II	ABS	1.5 dCi 59kw	AUTODETECT
 Scenic II	ABS	1.5 dCi 63kw	AUTODETECT
 Scenic II	ABS	1.5 dCi 74kw	AUTODETECT
 Scenic II	ABS	1.5 dCi 78kw	AUTODETECT
 Scenic II	ABS	1.5 dCi FAP 76kw	AUTODETECT
 Scenic II	ABS	1.9 dCi 88kw	AUTODETECT
 Scenic II	ABS	1.9 dCi 8v FAP 85kw	AUTODETECT
 Scenic II	ABS	1.9 dCi FAP 81kw	AUTODETECT
 Scenic II	ABS	1.9 dCi FAP 92kw	AUTODETECT
 Scenic II	ABS	1.9 dCi FAP 96kw	AUTODETECT
 Scenic II	ABS	2.0 16v 100kw	AUTODETECT
 Scenic II	ABS	2.0 dCi 16v FAP 110kw	AUTODETECT
 Scenic II	ABS	2.0 T 16v 121kw	AUTODETECT
 Scenic II	ABS + TRACT. CONT	1.4 16v 72kw (02-..)	BOSCH ESP 8.0
 Scenic II	ABS + TRACT. CONT	1.5 dCi 59kw (02-..)	BOSCH ESP 8.0
 Scenic II	ABS + TRACT. CONT	1.5 dCi 63kw (02-..)	BOSCH ESP 8.0
 Scenic II	ABS + TRACT. CONT	1.5 dCi 74kw (02-..)	BOSCH ESP 8.0
 Scenic II	ABS + TRACT. CONT	1.5 dCi 78kw (02-..)	BOSCH ESP 8.0
 Scenic II	ABS + TRACT. CONT	1.5 dCi FAP 76kw (02-..)	BOSCH ESP 8.0
 Scenic II	ABS + TRACT. CONT	1.6 16v 77kw (02-..)	BOSCH ESP 8.0
 Scenic II	ABS + TRACT. CONT	1.6 16v 82kw (02-..)	BOSCH ESP 8.0
 Scenic II	ABS + TRACT. CONT	1.6 16v 83kw (02-..)	BOSCH ESP 8.0
 Scenic II	ABS + TRACT. CONT	1.9 dCi 88kw (02-..)	BOSCH ESP 8.0
 Scenic II	ABS + TRACT. CONT	1.9 dCi 8v FAP 85kw (02-..)	BOSCH ESP 8.0
 Scenic II	ABS + TRACT. CONT	1.9 dCi FAP 81kw (02-..)	BOSCH ESP 8.0
 Scenic II	ABS + TRACT. CONT	1.9 dCi FAP 92kw (02-..)	BOSCH ESP 8.0
 Scenic II	ABS + TRACT. CONT	1.9 dCi FAP 96kw (02-..)	BOSCH ESP 8.0
 Scenic II	ABS + TRACT. CONT	2.0 16v 100kw (02-..)	BOSCH ESP 8.0
 Scenic II	ABS + TRACT. CONT	2.0 dCi 16v FAP 110kw (02-..)	BOSCH ESP 8.0
 Scenic II	ABS + TRACT. CONT	2.0 T 16v 121kw (02-..)	BOSCH ESP 8.0
 Scenic II	AIRBAG	1.4 16v 72kw	
 Scenic II	AIRBAG	1.4 16v 72kw	AUTODETECT
 Scenic II	AIRBAG	1.4 16v 72kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Scenic II	AIRBAG	1.5 dCi 59kw	
 Scenic II	AIRBAG	1.5 dCi 59kw	AUTODETECT
 Scenic II	AIRBAG	1.5 dCi 59kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Scenic II	AIRBAG	1.5 dCi 63kw	
 Scenic II	AIRBAG	1.5 dCi 63kw	AUTODETECT
 Scenic II	AIRBAG	1.5 dCi 63kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Scenic II	AIRBAG	1.5 dCi 74kw	
 Scenic II	AIRBAG	1.5 dCi 74kw	AUTODETECT
 Scenic II	AIRBAG	1.5 dCi 74kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Scenic II	AIRBAG	1.5 dCi 78kw	
 Scenic II	AIRBAG	1.5 dCi 78kw	AUTODETECT
 Scenic II	AIRBAG	1.5 dCi 78kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Scenic II	AIRBAG	1.5 dCi FAP 76kw	
 Scenic II	AIRBAG	1.5 dCi FAP 76kw	AUTODETECT
 Scenic II	AIRBAG	1.5 dCi FAP 76kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Scenic II	AIRBAG	1.6 16v 77kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Scenic II	AIRBAG	1.6 16v 82kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Scenic II	AIRBAG	1.6 16v 83kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Scenic II	AIRBAG	1.9 dCi 88kw	
 Scenic II	AIRBAG	1.9 dCi 88kw	AUTODETECT
 Scenic II	AIRBAG	1.9 dCi 88kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Scenic II	AIRBAG	1.9 dCi 8v FAP 85kw	
 Scenic II	AIRBAG	1.9 dCi 8v FAP 85kw	AUTODETECT
 Scenic II	AIRBAG	1.9 dCi 8v FAP 85kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Scenic II	AIRBAG	1.9 dCi FAP 81kw	
 Scenic II	AIRBAG	1.9 dCi FAP 81kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Scenic II	AIRBAG	1.9 dCi FAP 92kw	
 Scenic II	AIRBAG	1.9 dCi FAP 92kw	AUTODETECT
 Scenic II	AIRBAG	1.9 dCi FAP 92kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Scenic II	AIRBAG	1.9 dCi FAP 96kw	
 Scenic II	AIRBAG	1.9 dCi FAP 96kw	AUTODETECT
 Scenic II	AIRBAG	1.9 dCi FAP 96kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Scenic II	AIRBAG	2.0 16v 100kw	
 Scenic II	AIRBAG	2.0 16v 100kw	AUTODETECT
 Scenic II	AIRBAG	2.0 16v 100kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Scenic II	AIRBAG	2.0 dCi 16v FAP 110kw	
 Scenic II	AIRBAG	2.0 dCi 16v FAP 110kw	AUTODETECT
 Scenic II	AIRBAG	2.0 dCi 16v FAP 110kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Scenic II	AIRBAG	2.0 T 16v 121kw	
 Scenic II	AIRBAG	2.0 T 16v 121kw	AUTODETECT
 Scenic II	AIRBAG	2.0 T 16v 121kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Scenic II	AUTOM. TRANSMISSI	1.4 16v 72kw	AUTODETECT
 Scenic II	AUTOM. TRANSMISSI	1.5 dCi 59kw	AUTODETECT
 Scenic II	AUTOM. TRANSMISSI	1.5 dCi 63kw	AUTODETECT
 Scenic II	AUTOM. TRANSMISSI	1.5 dCi 74kw	AUTODETECT
 Scenic II	AUTOM. TRANSMISSI	1.5 dCi 78kw	AUTODETECT
 Scenic II	AUTOM. TRANSMISSI	1.5 dCi FAP 76kw	AUTODETECT
 Scenic II	AUTOM. TRANSMISSI	1.9 dCi 88kw	AUTODETECT
 Scenic II	AUTOM. TRANSMISSI	1.9 dCi 8v FAP 85kw	AUTODETECT
 Scenic II	AUTOM. TRANSMISSI	1.9 dCi FAP 81kw	AUTODETECT
 Scenic II	AUTOM. TRANSMISSI	1.9 dCi FAP 92kw	AUTODETECT
 Scenic II	AUTOM. TRANSMISSI	1.9 dCi FAP 96kw	AUTODETECT
 Scenic II	AUTOM. TRANSMISSI	2.0 16v 100kw	AUTODETECT
 Scenic II	AUTOM. TRANSMISSI	2.0 dCi 16v FAP 110kw	AUTODETECT
 Scenic II	AUTOM. TRANSMISSI	2.0 T 16v 121kw	AUTODETECT
 Scenic II	CHANGE BRAKE PAD	1.4 16v 72kw (02-..)	MANUAL
 Scenic II	CHANGE BRAKE PAD	1.5 dCi 59kw (02-..)	MANUAL
 Scenic II	CHANGE BRAKE PAD	1.5 dCi 63kw (02-..)	MANUAL
 Scenic II	CHANGE BRAKE PAD	1.5 dCi 74kw (02-..)	MANUAL
 Scenic II	CHANGE BRAKE PAD	1.5 dCi 78kw (02-..)	MANUAL
 Scenic II	CHANGE BRAKE PAD	1.5 dCi FAP 76kw (02-..)	MANUAL
 Scenic II	CHANGE BRAKE PAD	1.6 16v 77kw (02-..)	MANUAL
 Scenic II	CHANGE BRAKE PAD	1.6 16v 82kw (02-..)	MANUAL
 Scenic II	CHANGE BRAKE PAD	1.6 16v 83kw (02-..)	MANUAL
 Scenic II	CHANGE BRAKE PAD	1.9 dCi 88kw (02-..)	MANUAL
 Scenic II	CHANGE BRAKE PAD	1.9 dCi 8v FAP 85kw (02-..)	MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Scenic II	CHANGE BRAKE PAD	1.9 dCi FAP 81kw (02-..)	MANUAL
 Scenic II	CHANGE BRAKE PAD	1.9 dCi FAP 92kw (02-..)	MANUAL
 Scenic II	CHANGE BRAKE PAD	1.9 dCi FAP 96kw (02-..)	MANUAL
 Scenic II	CHANGE BRAKE PAD	2.0 16v 100kw (02-..)	MANUAL
 Scenic II	CHANGE BRAKE PAD	2.0 dCi 16v FAP 110kw (02-..)	MANUAL
 Scenic II	CHANGE BRAKE PAD	2.0 T 16v 121kw (02-..)	MANUAL
 Scenic II	CHASSIS NETWORK	1.4 16v 72kw	UCC AUTODETECT
 Scenic II	CHASSIS NETWORK	1.4 16v 72kw	UCH AUTODETECT
 Scenic II	CHASSIS NETWORK	1.4 16v 72kw	UPC AUTODETECT
 Scenic II	CHASSIS NETWORK	1.4 16v 72kw (02-..)	Body Computer
 Scenic II	CHASSIS NETWORK	1.4 16v 72kw (02-05)	UPC
 Scenic II	CHASSIS NETWORK	1.4 16v 72kw (05-..)	UPC
 Scenic II	CHASSIS NETWORK	1.5 dCi 59kw	UCC AUTODETECT
 Scenic II	CHASSIS NETWORK	1.5 dCi 59kw	UCH AUTODETECT
 Scenic II	CHASSIS NETWORK	1.5 dCi 59kw	UPC AUTODETECT
 Scenic II	CHASSIS NETWORK	1.5 dCi 59kw (02-..)	Body Computer UCH
 Scenic II	CHASSIS NETWORK	1.5 dCi 59kw (02-05)	UPC
 Scenic II	CHASSIS NETWORK	1.5 dCi 59kw (05-..)	UPC
 Scenic II	CHASSIS NETWORK	1.5 dCi 63kw	UCC AUTODETECT
 Scenic II	CHASSIS NETWORK	1.5 dCi 63kw	UCH AUTODETECT
 Scenic II	CHASSIS NETWORK	1.5 dCi 63kw	UPC AUTODETECT
 Scenic II	CHASSIS NETWORK	1.5 dCi 63kw (02-..)	Body Computer UCH
 Scenic II	CHASSIS NETWORK	1.5 dCi 63kw (02-05)	UPC
 Scenic II	CHASSIS NETWORK	1.5 dCi 63kw (05-..)	UPC
 Scenic II	CHASSIS NETWORK	1.5 dCi 74kw	UCC AUTODETECT
 Scenic II	CHASSIS NETWORK	1.5 dCi 74kw	UCH AUTODETECT
 Scenic II	CHASSIS NETWORK	1.5 dCi 74kw	UPC AUTODETECT
 Scenic II	CHASSIS NETWORK	1.5 dCi 74kw (02-..)	Body Computer
 Scenic II	CHASSIS NETWORK	1.5 dCi 74kw (02-05)	UPC
 Scenic II	CHASSIS NETWORK	1.5 dCi 74kw (05-..)	UPC
 Scenic II	CHASSIS NETWORK	1.5 dCi 78kw	UCC AUTODETECT
 Scenic II	CHASSIS NETWORK	1.5 dCi 78kw	UCH AUTODETECT
 Scenic II	CHASSIS NETWORK	1.5 dCi 78kw	UPC AUTODETECT
 Scenic II	CHASSIS NETWORK	1.5 dCi 78kw (02-..)	Body Computer UCH
 Scenic II	CHASSIS NETWORK	1.5 dCi 78kw (02-05)	UPC
 Scenic II	CHASSIS NETWORK	1.5 dCi 78kw (05-..)	UPC
 Scenic II	CHASSIS NETWORK	1.5 dCi FAP 76kw	UCC AUTODETECT
 Scenic II	CHASSIS NETWORK	1.5 dCi FAP 76kw	UCH AUTODETECT
 Scenic II	CHASSIS NETWORK	1.5 dCi FAP 76kw	UPC AUTODETECT
 Scenic II	CHASSIS NETWORK	1.5 dCi FAP 76kw (02-..)	Body Computer UCH
 Scenic II	CHASSIS NETWORK	1.5 dCi FAP 76kw (02-05)	UPC
 Scenic II	CHASSIS NETWORK	1.5 dCi FAP 76kw (05-..)	UPC
 Scenic II	CHASSIS NETWORK	1.6 16v 77kw (02-..)	Body Computer
 Scenic II	CHASSIS NETWORK	1.6 16v 77kw (02-05)	UPC
 Scenic II	CHASSIS NETWORK	1.6 16v 77kw (05-..)	UPC
 Scenic II	CHASSIS NETWORK	1.6 16v 82kw (02-..)	Body Computer UCH
 Scenic II	CHASSIS NETWORK	1.6 16v 82kw (02-05)	UPC
 Scenic II	CHASSIS NETWORK	1.6 16v 82kw (05-..)	UPC
 Scenic II	CHASSIS NETWORK	1.6 16v 83kw (02-..)	Body Computer UCH
 Scenic II	CHASSIS NETWORK	1.6 16v 83kw (02-05)	UPC
 Scenic II	CHASSIS NETWORK	1.6 16v 83kw (05-..)	UPC
 Scenic II	CHASSIS NETWORK	1.9 dCi 88kw	UCC AUTODETECT
 Scenic II	CHASSIS NETWORK	1.9 dCi 88kw	UCH AUTODETECT
 Scenic II	CHASSIS NETWORK	1.9 dCi 88kw	UPC AUTODETECT
 Scenic II	CHASSIS NETWORK	1.9 dCi 88kw (02-..)	Body Computer UCH
 Scenic II	CHASSIS NETWORK	1.9 dCi 88kw (02-05)	UPC
 Scenic II	CHASSIS NETWORK	1.9 dCi 88kw (05-..)	UPC
 Scenic II	CHASSIS NETWORK	1.9 dCi 8v FAP 85kw	UCC AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Scenic II	CHASSIS NETWORK	1.9 dCi 8v FAP 85kw	UCH AUTODETECT
 Scenic II	CHASSIS NETWORK	1.9 dCi 8v FAP 85kw	UPC AUTODETECT
 Scenic II	CHASSIS NETWORK	1.9 dCi 8v FAP 85kw (02-..)	Body Computer UCH
 Scenic II	CHASSIS NETWORK	1.9 dCi 8v FAP 85kw (02-05)	UPC
 Scenic II	CHASSIS NETWORK	1.9 dCi 8v FAP 85kw (05-..)	UPC
 Scenic II	CHASSIS NETWORK	1.9 dCi FAP 81kw	UCC AUTODETECT
 Scenic II	CHASSIS NETWORK	1.9 dCi FAP 81kw	UCH AUTODETECT
 Scenic II	CHASSIS NETWORK	1.9 dCi FAP 81kw	UPC AUTODETECT
 Scenic II	CHASSIS NETWORK	1.9 dCi FAP 81kw (02-..)	Body Computer UCH
 Scenic II	CHASSIS NETWORK	1.9 dCi FAP 81kw (02-05)	UPC
 Scenic II	CHASSIS NETWORK	1.9 dCi FAP 81kw (05-..)	UPC
 Scenic II	CHASSIS NETWORK	1.9 dCi FAP 92kw	UCC AUTODETECT
 Scenic II	CHASSIS NETWORK	1.9 dCi FAP 92kw	UCH AUTODETECT
 Scenic II	CHASSIS NETWORK	1.9 dCi FAP 92kw	UPC AUTODETECT
 Scenic II	CHASSIS NETWORK	1.9 dCi FAP 92kw (02-..)	Body Computer UCH
 Scenic II	CHASSIS NETWORK	1.9 dCi FAP 92kw (02-05)	UPC
 Scenic II	CHASSIS NETWORK	1.9 dCi FAP 92kw (05-..)	UPC
 Scenic II	CHASSIS NETWORK	1.9 dCi FAP 96kw	UCC AUTODETECT
 Scenic II	CHASSIS NETWORK	1.9 dCi FAP 96kw	UCH AUTODETECT
 Scenic II	CHASSIS NETWORK	1.9 dCi FAP 96kw	UPC AUTODETECT
 Scenic II	CHASSIS NETWORK	1.9 dCi FAP 96kw (02-..)	Body Computer UCH
 Scenic II	CHASSIS NETWORK	1.9 dCi FAP 96kw (02-05)	UPC
 Scenic II	CHASSIS NETWORK	1.9 dCi FAP 96kw (05-..)	UPC
 Scenic II	CHASSIS NETWORK	2.0 16v 100kw	UCC AUTODETECT
 Scenic II	CHASSIS NETWORK	2.0 16v 100kw	UCH AUTODETECT
 Scenic II	CHASSIS NETWORK	2.0 16v 100kw	UPC AUTODETECT
 Scenic II	CHASSIS NETWORK	2.0 16v 100kw (02-..)	Body Computer UCH
 Scenic II	CHASSIS NETWORK	2.0 16v 100kw (02-05)	UPC
 Scenic II	CHASSIS NETWORK	2.0 16v 100kw (05-..)	UPC
 Scenic II	CHASSIS NETWORK	2.0 dCi 16v FAP 110kw	UCC AUTODETECT
 Scenic II	CHASSIS NETWORK	2.0 dCi 16v FAP 110kw	UCH AUTODETECT
 Scenic II	CHASSIS NETWORK	2.0 dCi 16v FAP 110kw	UPC AUTODETECT
 Scenic II	CHASSIS NETWORK	2.0 dCi 16v FAP 110kw (02-..)	Body Computer UCH
 Scenic II	CHASSIS NETWORK	2.0 dCi 16v FAP 110kw (02-05)	UPC
 Scenic II	CHASSIS NETWORK	2.0 dCi 16v FAP 110kw (05-..)	UPC
 Scenic II	CHASSIS NETWORK	2.0 T 16v 121kw	UCC AUTODETECT
 Scenic II	CHASSIS NETWORK	2.0 T 16v 121kw	UCH AUTODETECT
 Scenic II	CHASSIS NETWORK	2.0 T 16v 121kw	UPC AUTODETECT
 Scenic II	CHASSIS NETWORK	2.0 T 16v 121kw (02-..)	Body Computer
 Scenic II	CHASSIS NETWORK	2.0 T 16v 121kw (02-05)	UPC
 Scenic II	CHASSIS NETWORK	2.0 T 16v 121kw (05-..)	UPC
 Scenic II	CLIMA	1.4 16v 72kw	AUTODETECT
 Scenic II	CLIMA	1.4 16v 72kw (02-..)	DELPHI klima Climautomatic
 Scenic II	CLIMA	1.5 dCi 59kw	AUTODETECT
 Scenic II	CLIMA	1.5 dCi 59kw (02-..)	DELPHI Klima Climautomatic
 Scenic II	CLIMA	1.5 dCi 63kw	AUTODETECT
 Scenic II	CLIMA	1.5 dCi 63kw (02-..)	DELPHI Klima Climautomatic
 Scenic II	CLIMA	1.5 dCi 74kw	AUTODETECT
 Scenic II	CLIMA	1.5 dCi 74kw (02-..)	DELPHI Klima Climautomatic
 Scenic II	CLIMA	1.5 dCi 78kw	AUTODETECT
 Scenic II	CLIMA	1.5 dCi 78kw (02-..)	DELPHI Klima Climautomatic
 Scenic II	CLIMA	1.5 dCi FAP 76kw	AUTODETECT
 Scenic II	CLIMA	1.5 dCi FAP 76kw (02-..)	DELPHI Klima Climautomatic
 Scenic II	CLIMA	1.6 16v 77kw (02-..)	DELPHI klima Climautomatic
 Scenic II	CLIMA	1.6 16v 82kw (02-..)	DELPHI Klima Climautomatic
 Scenic II	CLIMA	1.6 16v 83kw (02-..)	DELPHI Klima Climautomatic
 Scenic II	CLIMA	1.9 dCi 88kw	AUTODETECT
 Scenic II	CLIMA	1.9 dCi 88kw (02-..)	DELPHI Klima Climautomatic

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Scenic II	CLIMA	1.9 dCi 8v FAP 85kw	AUTODETECT
 Scenic II	CLIMA	1.9 dCi 8v FAP 85kw (02-..)	DELPHI Klima Climautomatic
 Scenic II	CLIMA	1.9 dCi FAP 81kw	AUTODETECT
 Scenic II	CLIMA	1.9 dCi FAP 81kw (02-..)	DELPHI Klima Climautomatic
 Scenic II	CLIMA	1.9 dCi FAP 92kw	AUTODETECT
 Scenic II	CLIMA	1.9 dCi FAP 92kw (02-..)	DELPHI Klima Climautomatic
 Scenic II	CLIMA	1.9 dCi FAP 96kw	AUTODETECT
 Scenic II	CLIMA	1.9 dCi FAP 96kw (02-..)	DELPHI Klima Climautomatic
 Scenic II	CLIMA	2.0 16v 100kw	AUTODETECT
 Scenic II	CLIMA	2.0 16v 100kw (02-..)	DELPHI klima Climautomatic
 Scenic II	CLIMA	2.0 dCi 16v FAP 110kw	AUTODETECT
 Scenic II	CLIMA	2.0 dCi 16v FAP 110kw (02-..)	DELPHI Klima Climautomatic
 Scenic II	CLIMA	2.0 T 16v 121kw	AUTODETECT
 Scenic II	CLIMA	2.0 T 16v 121kw (02-..)	DELPHI Klima Climautomatic
 Scenic II	DASHBOARD	1.4 16v 72kw	AUTODETECT
 Scenic II	DASHBOARD	1.4 16v 72kw (02-..)	JOHNSON Dashboard
 Scenic II	DASHBOARD	1.5 dCi 59kw	AUTODETECT
 Scenic II	DASHBOARD	1.5 dCi 59kw (02-..)	JOHNSON Dashboard
 Scenic II	DASHBOARD	1.5 dCi 63kw	AUTODETECT
 Scenic II	DASHBOARD	1.5 dCi 63kw (02-..)	JOHNSON Dashboard
 Scenic II	DASHBOARD	1.5 dCi 74kw	AUTODETECT
 Scenic II	DASHBOARD	1.5 dCi 74kw (02-..)	JOHNSON Dashboard
 Scenic II	DASHBOARD	1.5 dCi 78kw	AUTODETECT
 Scenic II	DASHBOARD	1.5 dCi 78kw (02-..)	JOHNSON Dashboard
 Scenic II	DASHBOARD	1.5 dCi FAP 76kw	AUTODETECT
 Scenic II	DASHBOARD	1.5 dCi FAP 76kw (02-..)	JOHNSON Dashboard
 Scenic II	DASHBOARD	1.6 16v 77kw (02-..)	JOHNSON Dashboard
 Scenic II	DASHBOARD	1.6 16v 82kw (02-..)	JOHNSON Dashboard
 Scenic II	DASHBOARD	1.6 16v 83kw (02-..)	JOHNSON Dashboard
 Scenic II	DASHBOARD	1.9 dCi 88kw	AUTODETECT
 Scenic II	DASHBOARD	1.9 dCi 88kw (02-..)	JOHNSON Dashboard
 Scenic II	DASHBOARD	1.9 dCi 8v FAP 85kw	AUTODETECT
 Scenic II	DASHBOARD	1.9 dCi 8v FAP 85kw (02-..)	JOHNSON Dashboard
 Scenic II	DASHBOARD	1.9 dCi FAP 81kw	AUTODETECT
 Scenic II	DASHBOARD	1.9 dCi FAP 81kw (02-..)	JOHNSON Dashboard
 Scenic II	DASHBOARD	1.9 dCi FAP 92kw	AUTODETECT
 Scenic II	DASHBOARD	1.9 dCi FAP 92kw (02-..)	JOHNSON Dashboard
 Scenic II	DASHBOARD	1.9 dCi FAP 96kw	AUTODETECT
 Scenic II	DASHBOARD	1.9 dCi FAP 96kw (02-..)	JOHNSON Dashboard
 Scenic II	DASHBOARD	2.0 16v 100kw	AUTODETECT
 Scenic II	DASHBOARD	2.0 16v 100kw (02-..)	JOHNSON Dashboard
 Scenic II	DASHBOARD	2.0 dCi 16v FAP 110kw	AUTODETECT
 Scenic II	DASHBOARD	2.0 dCi 16v FAP 110kw (02-..)	JOHNSON Dashboard
 Scenic II	DASHBOARD	2.0 T 16v 121kw	AUTODETECT
 Scenic II	DASHBOARD	2.0 T 16v 121kw (02-..)	JOHNSON Dashboard
 Scenic II	ELECTRIC STEERING	1.4 16v 72kw	AUTODETECT
 Scenic II	ELECTRIC STEERING	1.4 16v 72kw (02-..)	KOYO EPS
 Scenic II	ELECTRIC STEERING	1.5 dCi 59kw	AUTODETECT
 Scenic II	ELECTRIC STEERING	1.5 dCi 59kw (02-..)	KOYO EPS
 Scenic II	ELECTRIC STEERING	1.5 dCi 63kw	AUTODETECT
 Scenic II	ELECTRIC STEERING	1.5 dCi 63kw (02-..)	KOYO EPS
 Scenic II	ELECTRIC STEERING	1.5 dCi 74kw	AUTODETECT
 Scenic II	ELECTRIC STEERING	1.5 dCi 74kw (02-..)	KOYO EPS
 Scenic II	ELECTRIC STEERING	1.5 dCi 78kw	AUTODETECT
 Scenic II	ELECTRIC STEERING	1.5 dCi 78kw (02-..)	KOYO EPS
 Scenic II	ELECTRIC STEERING	1.5 dCi FAP 76kw	AUTODETECT
 Scenic II	ELECTRIC STEERING	1.5 dCi FAP 76kw (02-..)	KOYO EPS
 Scenic II	ELECTRIC STEERING	1.6 16v 77kw (02-..)	KOYO EPS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Scenic II	ELECTRIC STEERING	1.6 16v 82kw (02-..)	KOYO EPS
 Scenic II	ELECTRIC STEERING	1.6 16v 83kw (02-..)	KOYO EPS
 Scenic II	ELECTRIC STEERING	1.9 dCi 88kw	AUTODETECT
 Scenic II	ELECTRIC STEERING	1.9 dCi 88kw (02-..)	KOYO EPS
 Scenic II	ELECTRIC STEERING	1.9 dCi 8v FAP 85kw	AUTODETECT
 Scenic II	ELECTRIC STEERING	1.9 dCi 8v FAP 85kw (02-..)	KOYO EPS
 Scenic II	ELECTRIC STEERING	1.9 dCi FAP 81kw	AUTODETECT
 Scenic II	ELECTRIC STEERING	1.9 dCi FAP 81kw (02-..)	KOYO EPS
 Scenic II	ELECTRIC STEERING	1.9 dCi FAP 92kw	AUTODETECT
 Scenic II	ELECTRIC STEERING	1.9 dCi FAP 92kw (02-..)	KOYO EPS
 Scenic II	ELECTRIC STEERING	1.9 dCi FAP 96kw	AUTODETECT
 Scenic II	ELECTRIC STEERING	1.9 dCi FAP 96kw (02-..)	KOYO EPS
 Scenic II	ELECTRIC STEERING	2.0 16v 100kw	AUTODETECT
 Scenic II	ELECTRIC STEERING	2.0 16v 100kw (02-..)	KOYO EPS
 Scenic II	ELECTRIC STEERING	2.0 dCi 16v FAP 110kw	AUTODETECT
 Scenic II	ELECTRIC STEERING	2.0 dCi 16v FAP 110kw (02-..)	KOYO EPS
 Scenic II	ELECTRIC STEERING	2.0 T 16v 121kw	AUTODETECT
 Scenic II	ELECTRIC STEERING	2.0 T 16v 121kw (02-..)	KOYO EPS
 Scenic II	ENGINE MANAGEME	1.4 16v 72kw	AUTODETECT
 Scenic II	ENGINE MANAGEME	1.4 16v 72kw K4J-730	SAGEM MPI 3000
 Scenic II	ENGINE MANAGEME	1.5 dCi 59kw	AUTODETECT
 Scenic II	ENGINE MANAGEME	1.5 dCi 59kw K9K-722 (04-..)	DELPHI
 Scenic II	ENGINE MANAGEME	1.5 dCi 59kw K9K-722 (05-..)	SIEMENS EDC SID
 Scenic II	ENGINE MANAGEME	1.5 dCi 59kw K9K-722 (06-..)	SIEMENS EDC SID 301 Common Rail
 Scenic II	ENGINE MANAGEME	1.5 dCi 63kw (04-..)	EOBD
 Scenic II	ENGINE MANAGEME	1.5 dCi 74kw	AUTODETECT
 Scenic II	ENGINE MANAGEME	1.5 dCi 74kw K9K-728 (05-..)	SIEMENS EDC SID
 Scenic II	ENGINE MANAGEME	1.5 dCi 74kw K9K-728 (06-..)	SIEMENS EDC SID 301 Common Rail
 Scenic II	ENGINE MANAGEME	1.5 dCi 78kw (04-..)	EOBD
 Scenic II	ENGINE MANAGEME	1.5 dCi FAP 76kw (04-..)	EOBD
 Scenic II	ENGINE MANAGEME	1.6 16v 77kw	GAS AUTODETECT
 Scenic II	ENGINE MANAGEME	1.6 16v 82kw K4M-782	SAGEM MPI 3000
 Scenic II	ENGINE MANAGEME	1.6 16v 83kw K4M-761	SAGEM MPI 3000
 Scenic II	ENGINE MANAGEME	1.9 dCi 88kw	AUTODETECT
 Scenic II	ENGINE MANAGEME	1.9 dCi 88kw F9Q-812 (02-..)	BOSCH EDC 15 Common Rail
 Scenic II	ENGINE MANAGEME	1.9 dCi 8v FAP 85kw	AUTODETECT
 Scenic II	ENGINE MANAGEME	1.9 dCi FAP 81kw (04-..)	EOBD
 Scenic II	ENGINE MANAGEME	1.9 dCi FAP 92kw	AUTODETECT
 Scenic II	ENGINE MANAGEME	1.9 dCi FAP 92kw F9Q-804	BOSCH EDC 16 Common Rail
 Scenic II	ENGINE MANAGEME	1.9 dCi FAP 92kw F9Q-804 (02-..)	BOSCH EDC 15 Common Rail
 Scenic II	ENGINE MANAGEME	1.9 dCi FAP 96kw	AUTODETECT
 Scenic II	ENGINE MANAGEME	1.9 dCi FAP 96kw F9Q-804	BOSCH EDC 16 Common Rail
 Scenic II	ENGINE MANAGEME	2.0 16v 100kw	AUTODETECT
 Scenic II	ENGINE MANAGEME	2.0 dCi 16v FAP 110kw	AUTODETECT
 Scenic II	ENGINE MANAGEME	2.0 T 16v 121kw	AUTODETECT
 Scenic II	HEADLIGHT LEVEL	1.4 16v 72kw	AUTODETECT
 Scenic II	HEADLIGHT LEVEL	1.5 dCi 59kw	AUTODETECT
 Scenic II	HEADLIGHT LEVEL	1.5 dCi 63kw	AUTODETECT
 Scenic II	HEADLIGHT LEVEL	1.5 dCi 74kw	AUTODETECT
 Scenic II	HEADLIGHT LEVEL	1.5 dCi 78kw	AUTODETECT
 Scenic II	HEADLIGHT LEVEL	1.5 dCi FAP 76kw	AUTODETECT
 Scenic II	HEADLIGHT LEVEL	1.9 dCi 88kw	AUTODETECT
 Scenic II	HEADLIGHT LEVEL	1.9 dCi 8v FAP 85kw	AUTODETECT
 Scenic II	HEADLIGHT LEVEL	1.9 dCi FAP 81kw	AUTODETECT
 Scenic II	HEADLIGHT LEVEL	1.9 dCi FAP 92kw	AUTODETECT
 Scenic II	HEADLIGHT LEVEL	1.9 dCi FAP 96kw	AUTODETECT
 Scenic II	HEADLIGHT LEVEL	2.0 16v 100kw	AUTODETECT
 Scenic II	HEADLIGHT LEVEL	2.0 dCi 16v FAP 110kw	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Scenic II	HEADLIGHT LEVEL	2.0 T 16v 121kw	AUTODETECT
 Scenic II	KEY ENCODE	1.4 16v 72kw (02-..)	
 Scenic II	KEY ENCODE	1.5 dCi 59kw (02-..)	
 Scenic II	KEY ENCODE	1.5 dCi 63kw (02-..)	
 Scenic II	KEY ENCODE	1.5 dCi 74kw (02-..)	
 Scenic II	KEY ENCODE	1.5 dCi 78kw (02-..)	
 Scenic II	KEY ENCODE	1.5 dCi FAP 76kw (02-..)	
 Scenic II	KEY ENCODE	1.6 16v 77kw (02-..)	
 Scenic II	KEY ENCODE	1.6 16v 82kw (02-..)	
 Scenic II	KEY ENCODE	1.6 16v 83kw (02-..)	
 Scenic II	KEY ENCODE	1.9 dCi 88kw (02-..)	
 Scenic II	KEY ENCODE	1.9 dCi 8v FAP 85kw (02-..)	
 Scenic II	KEY ENCODE	1.9 dCi FAP 81kw (02-..)	
 Scenic II	KEY ENCODE	1.9 dCi FAP 92kw (02-..)	
 Scenic II	KEY ENCODE	1.9 dCi FAP 96kw (02-..)	
 Scenic II	KEY ENCODE	2.0 16v 100kw (02-..)	
 Scenic II	KEY ENCODE	2.0 dCi 16v FAP 110kw (02-..)	
 Scenic II	KEY ENCODE	2.0 T 16v 121kw (02-..)	
 Scenic II	MAINTENANCE	1.4 16v 72kw	MANUAL
 Scenic II	MAINTENANCE	1.4 16v 72kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.4 16v 72kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.4 16v 72kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.4 16v 72kw (02-..)	KOYO EPS
 Scenic II	MAINTENANCE	1.4 16v 72kw (02-..)	MANUAL
 Scenic II	MAINTENANCE	1.4 16v 72kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Scenic II	MAINTENANCE	1.5 dCi 59kw	MANUAL
 Scenic II	MAINTENANCE	1.5 dCi 59kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.5 dCi 59kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.5 dCi 59kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.5 dCi 59kw (02-..)	KOYO EPS
 Scenic II	MAINTENANCE	1.5 dCi 59kw (02-..)	MANUAL
 Scenic II	MAINTENANCE	1.5 dCi 59kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Scenic II	MAINTENANCE	1.5 dCi 59kw K9K-722 (04-..)	DELPHI
 Scenic II	MAINTENANCE	1.5 dCi 59kw K9K-722 (05-..)	SIEMENS EDC SID
 Scenic II	MAINTENANCE	1.5 dCi 59kw K9K-722 (05-..)	SIEMENS EDC SID
 Scenic II	MAINTENANCE	1.5 dCi 59kw K9K-722 (06-..)	SIEMENS EDC SID 301 Common Rail
 Scenic II	MAINTENANCE	1.5 dCi 63kw	MANUAL
 Scenic II	MAINTENANCE	1.5 dCi 63kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.5 dCi 63kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.5 dCi 63kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.5 dCi 63kw (02-..)	KOYO EPS
 Scenic II	MAINTENANCE	1.5 dCi 63kw (02-..)	MANUAL
 Scenic II	MAINTENANCE	1.5 dCi 63kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Scenic II	MAINTENANCE	1.5 dCi 74kw	MANUAL
 Scenic II	MAINTENANCE	1.5 dCi 74kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.5 dCi 74kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.5 dCi 74kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.5 dCi 74kw (02-..)	KOYO EPS
 Scenic II	MAINTENANCE	1.5 dCi 74kw (02-..)	MANUAL
 Scenic II	MAINTENANCE	1.5 dCi 74kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Scenic II	MAINTENANCE	1.5 dCi 74kw K9K-728 (05-..)	SIEMENS EDC SID
 Scenic II	MAINTENANCE	1.5 dCi 74kw K9K-728 (05-..)	SIEMENS EDC SID
 Scenic II	MAINTENANCE	1.5 dCi 74kw K9K-728 (06-..)	SIEMENS EDC SID 301 Common Rail
 Scenic II	MAINTENANCE	1.5 dCi 78kw	MANUAL
 Scenic II	MAINTENANCE	1.5 dCi 78kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.5 dCi 78kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.5 dCi 78kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.5 dCi 78kw (02-..)	KOYO EPS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Scenic II	MAINTENANCE	1.5 dCi 78kw (02-..)	MANUAL
 Scenic II	MAINTENANCE	1.5 dCi 78kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Scenic II	MAINTENANCE	1.5 dCi FAP 76kw	MANUAL
 Scenic II	MAINTENANCE	1.5 dCi FAP 76kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.5 dCi FAP 76kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.5 dCi FAP 76kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.5 dCi FAP 76kw (02-..)	KOYO EPS
 Scenic II	MAINTENANCE	1.5 dCi FAP 76kw (02-..)	MANUAL
 Scenic II	MAINTENANCE	1.5 dCi FAP 76kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Scenic II	MAINTENANCE	1.6 16v 77kw	MANUAL
 Scenic II	MAINTENANCE	1.6 16v 77kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.6 16v 77kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.6 16v 77kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.6 16v 77kw (02-..)	KOYO EPS
 Scenic II	MAINTENANCE	1.6 16v 77kw (02-..)	MANUAL
 Scenic II	MAINTENANCE	1.6 16v 77kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Scenic II	MAINTENANCE	1.6 16v 82kw	MANUAL
 Scenic II	MAINTENANCE	1.6 16v 82kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.6 16v 82kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.6 16v 82kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.6 16v 82kw (02-..)	KOYO EPS
 Scenic II	MAINTENANCE	1.6 16v 82kw (02-..)	MANUAL
 Scenic II	MAINTENANCE	1.6 16v 82kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Scenic II	MAINTENANCE	1.6 16v 83kw	MANUAL
 Scenic II	MAINTENANCE	1.6 16v 83kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.6 16v 83kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.6 16v 83kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.6 16v 83kw (02-..)	KOYO EPS
 Scenic II	MAINTENANCE	1.6 16v 83kw (02-..)	MANUAL
 Scenic II	MAINTENANCE	1.6 16v 83kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Scenic II	MAINTENANCE	1.9 dCi 88kw	MANUAL
 Scenic II	MAINTENANCE	1.9 dCi 88kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.9 dCi 88kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.9 dCi 88kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.9 dCi 88kw (02-..)	KOYO EPS
 Scenic II	MAINTENANCE	1.9 dCi 88kw (02-..)	MANUAL
 Scenic II	MAINTENANCE	1.9 dCi 88kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Scenic II	MAINTENANCE	1.9 dCi 8v FAP 85kw	MANUAL
 Scenic II	MAINTENANCE	1.9 dCi 8v FAP 85kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.9 dCi 8v FAP 85kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.9 dCi 8v FAP 85kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.9 dCi 8v FAP 85kw (02-..)	KOYO EPS
 Scenic II	MAINTENANCE	1.9 dCi 8v FAP 85kw (02-..)	MANUAL
 Scenic II	MAINTENANCE	1.9 dCi 8v FAP 85kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Scenic II	MAINTENANCE	1.9 dCi FAP 81kw	MANUAL
 Scenic II	MAINTENANCE	1.9 dCi FAP 81kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.9 dCi FAP 81kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.9 dCi FAP 81kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.9 dCi FAP 81kw (02-..)	KOYO EPS
 Scenic II	MAINTENANCE	1.9 dCi FAP 81kw (02-..)	MANUAL
 Scenic II	MAINTENANCE	1.9 dCi FAP 81kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Scenic II	MAINTENANCE	1.9 dCi FAP 92kw	MANUAL
 Scenic II	MAINTENANCE	1.9 dCi FAP 92kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.9 dCi FAP 92kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.9 dCi FAP 92kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.9 dCi FAP 92kw (02-..)	KOYO EPS
 Scenic II	MAINTENANCE	1.9 dCi FAP 92kw (02-..)	MANUAL
 Scenic II	MAINTENANCE	1.9 dCi FAP 92kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Scenic II	MAINTENANCE	1.9 dCi FAP 92kw F9Q-804	BOSCH EDC 16 Common Rail
 Scenic II	MAINTENANCE	1.9 dCi FAP 96kw	MANUAL
 Scenic II	MAINTENANCE	1.9 dCi FAP 96kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.9 dCi FAP 96kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.9 dCi FAP 96kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	1.9 dCi FAP 96kw (02-..)	KOYO EPS
 Scenic II	MAINTENANCE	1.9 dCi FAP 96kw (02-..)	MANUAL
 Scenic II	MAINTENANCE	1.9 dCi FAP 96kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Scenic II	MAINTENANCE	1.9 dCi FAP 96kw F9Q-804	BOSCH EDC 16 Common Rail
 Scenic II	MAINTENANCE	2.0 16v 100kw	MANUAL
 Scenic II	MAINTENANCE	2.0 16v 100kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	2.0 16v 100kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	2.0 16v 100kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	2.0 16v 100kw (02-..)	KOYO EPS
 Scenic II	MAINTENANCE	2.0 16v 100kw (02-..)	MANUAL
 Scenic II	MAINTENANCE	2.0 16v 100kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Scenic II	MAINTENANCE	2.0 dCi 16v FAP 110kw	MANUAL
 Scenic II	MAINTENANCE	2.0 dCi 16v FAP 110kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	2.0 dCi 16v FAP 110kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	2.0 dCi 16v FAP 110kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	2.0 dCi 16v FAP 110kw (02-..)	KOYO EPS
 Scenic II	MAINTENANCE	2.0 dCi 16v FAP 110kw (02-..)	MANUAL
 Scenic II	MAINTENANCE	2.0 dCi 16v FAP 110kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Scenic II	MAINTENANCE	2.0 T 16v 121kw	MANUAL
 Scenic II	MAINTENANCE	2.0 T 16v 121kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	2.0 T 16v 121kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	2.0 T 16v 121kw (02-..)	JOHNSON Dashboard
 Scenic II	MAINTENANCE	2.0 T 16v 121kw (02-..)	KOYO EPS
 Scenic II	MAINTENANCE	2.0 T 16v 121kw (02-..)	MANUAL
 Scenic II	MAINTENANCE	2.0 T 16v 121kw (02-..)	SIEMENS-Autoliv SRP ACU4 MK2
 Scenic II	PARK.BRAKE	1.4 16v 72kw	Electrobrake AUTODETECT
 Scenic II	PARK.BRAKE	1.4 16v 72kw (05-..)	Electrobrake
 Scenic II	PARK.BRAKE	1.5 dCi 59kw	Electrobrake AUTODETECT
 Scenic II	PARK.BRAKE	1.5 dCi 59kw (05-..)	Electrobrake
 Scenic II	PARK.BRAKE	1.5 dCi 63kw	Electrobrake AUTODETECT
 Scenic II	PARK.BRAKE	1.5 dCi 63kw (05-..)	Electrobrake
 Scenic II	PARK.BRAKE	1.5 dCi 74kw	Electrobrake AUTODETECT
 Scenic II	PARK.BRAKE	1.5 dCi 74kw (05-..)	Electrobrake
 Scenic II	PARK.BRAKE	1.5 dCi 78kw	Electrobrake AUTODETECT
 Scenic II	PARK.BRAKE	1.5 dCi 78kw (05-..)	Electrobrake
 Scenic II	PARK.BRAKE	1.5 dCi FAP 76kw	Electrobrake AUTODETECT
 Scenic II	PARK.BRAKE	1.5 dCi FAP 76kw (05-..)	Electrobrake
 Scenic II	PARK.BRAKE	1.6 16v 77kw (05-..)	Electrobrake
 Scenic II	PARK.BRAKE	1.6 16v 82kw (05-..)	Electrobrake
 Scenic II	PARK.BRAKE	1.6 16v 83kw (05-..)	Electrobrake
 Scenic II	PARK.BRAKE	1.9 dCi 88kw	Electrobrake AUTODETECT
 Scenic II	PARK.BRAKE	1.9 dCi 88kw (05-..)	Electrobrake
 Scenic II	PARK.BRAKE	1.9 dCi 8v FAP 85kw	Electrobrake AUTODETECT
 Scenic II	PARK.BRAKE	1.9 dCi 8v FAP 85kw (05-..)	UPC
 Scenic II	PARK.BRAKE	1.9 dCi FAP 81kw	Electrobrake AUTODETECT
 Scenic II	PARK.BRAKE	1.9 dCi FAP 81kw (05-..)	Electrobrake
 Scenic II	PARK.BRAKE	1.9 dCi FAP 92kw	Electrobrake AUTODETECT
 Scenic II	PARK.BRAKE	1.9 dCi FAP 92kw (05-..)	Electrobrake
 Scenic II	PARK.BRAKE	1.9 dCi FAP 96kw	Electrobrake AUTODETECT
 Scenic II	PARK.BRAKE	1.9 dCi FAP 96kw (05-..)	Electrobrake
 Scenic II	PARK.BRAKE	2.0 16v 100kw	Electrobrake AUTODETECT
 Scenic II	PARK.BRAKE	2.0 16v 100kw (05-..)	Electrobrake
 Scenic II	PARK.BRAKE	2.0 dCi 16v FAP 110kw	Electrobrake AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Scenic II	PARK.BRAKE	2.0 dCi 16v FAP 110kw (05-..)	UPC
 Scenic II	PARK.BRAKE	2.0 T 16v 121kw	Electrobrake AUTODETECT
 Scenic II	PARK.BRAKE	2.0 T 16v 121kw (05-..)	Electrobrake
 Scenic II	PARKING HELP	1.4 16v 72kw	AUTODETECT
 Scenic II	PARKING HELP	1.4 16v 72kw	can AUTODETECT
 Scenic II	PARKING HELP	1.5 dCi 59kw	AUTODETECT
 Scenic II	PARKING HELP	1.5 dCi 59kw	can AUTODETECT
 Scenic II	PARKING HELP	1.5 dCi 63kw	AUTODETECT
 Scenic II	PARKING HELP	1.5 dCi 63kw	can AUTODETECT
 Scenic II	PARKING HELP	1.5 dCi 74kw	AUTODETECT
 Scenic II	PARKING HELP	1.5 dCi 74kw	can AUTODETECT
 Scenic II	PARKING HELP	1.5 dCi 78kw	AUTODETECT
 Scenic II	PARKING HELP	1.5 dCi 78kw	can AUTODETECT
 Scenic II	PARKING HELP	1.5 dCi FAP 76kw	AUTODETECT
 Scenic II	PARKING HELP	1.5 dCi FAP 76kw	can AUTODETECT
 Scenic II	PARKING HELP	1.9 dCi 88kw	AUTODETECT
 Scenic II	PARKING HELP	1.9 dCi 88kw	can AUTODETECT
 Scenic II	PARKING HELP	1.9 dCi 8v FAP 85kw	AUTODETECT
 Scenic II	PARKING HELP	1.9 dCi 8v FAP 85kw	can AUTODETECT
 Scenic II	PARKING HELP	1.9 dCi FAP 81kw	AUTODETECT
 Scenic II	PARKING HELP	1.9 dCi FAP 81kw	can AUTODETECT
 Scenic II	PARKING HELP	1.9 dCi FAP 92kw	AUTODETECT
 Scenic II	PARKING HELP	1.9 dCi FAP 92kw	can AUTODETECT
 Scenic II	PARKING HELP	1.9 dCi FAP 96kw	AUTODETECT
 Scenic II	PARKING HELP	1.9 dCi FAP 96kw	can AUTODETECT
 Scenic II	PARKING HELP	2.0 16v 100kw	AUTODETECT
 Scenic II	PARKING HELP	2.0 16v 100kw	can AUTODETECT
 Scenic II	PARKING HELP	2.0 dCi 16v FAP 110kw	AUTODETECT
 Scenic II	PARKING HELP	2.0 dCi 16v FAP 110kw	can AUTODETECT
 Scenic II	PARKING HELP	2.0 T 16v 121kw	AUTODETECT
 Scenic II	PARKING HELP	2.0 T 16v 121kw	can AUTODETECT
 Scenic II	SERVICE LIGHT RES	1.4 16v 72kw	MANUAL
 Scenic II	SERVICE LIGHT RES	1.5 dCi 59kw	MANUAL
 Scenic II	SERVICE LIGHT RES	1.5 dCi 63kw	MANUAL
 Scenic II	SERVICE LIGHT RES	1.5 dCi 74kw	MANUAL
 Scenic II	SERVICE LIGHT RES	1.5 dCi 78kw	MANUAL
 Scenic II	SERVICE LIGHT RES	1.5 dCi FAP 76kw	MANUAL
 Scenic II	SERVICE LIGHT RES	1.6 16v 77kw	MANUAL
 Scenic II	SERVICE LIGHT RES	1.6 16v 82kw	MANUAL
 Scenic II	SERVICE LIGHT RES	1.6 16v 83kw	MANUAL
 Scenic II	SERVICE LIGHT RES	1.9 dCi 88kw	MANUAL
 Scenic II	SERVICE LIGHT RES	1.9 dCi 8v FAP 85kw	MANUAL
 Scenic II	SERVICE LIGHT RES	1.9 dCi FAP 81kw	MANUAL
 Scenic II	SERVICE LIGHT RES	1.9 dCi FAP 92kw	MANUAL
 Scenic II	SERVICE LIGHT RES	1.9 dCi FAP 96kw	MANUAL
 Scenic II	SERVICE LIGHT RES	2.0 16v 100kw	MANUAL
 Scenic II	SERVICE LIGHT RES	2.0 dCi 16v FAP 110kw	MANUAL
 Scenic II	SERVICE LIGHT RES	2.0 T 16v 121kw	MANUAL
 Scenic III	ABS + TRACT. CONT	1.4 16v 96kw	ABS
 Scenic III	ABS + TRACT. CONT	1.4 16v 96kw	AUTODETECT
 Scenic III	ABS + TRACT. CONT	1.5 dCi 78kw	ABS
 Scenic III	ABS + TRACT. CONT	1.5 dCi 78kw	AUTODETECT
 Scenic III	ABS + TRACT. CONT	1.5 dCi FAP 81kw	ABS
 Scenic III	ABS + TRACT. CONT	1.5 dCi FAP 81kw	AUTODETECT
 Scenic III	ABS + TRACT. CONT	1.6 16v 81kw	ABS
 Scenic III	ABS + TRACT. CONT	1.6 16v 81kw	AUTODETECT
Scenic III	ABS + TRACT. CONT	1.9 dCi 96kw	ABS
Scenic III	ABS + TRACT. CONT	1.9 dCi 96kw	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Scenic III	ABS + TRACT. CONT	1.9 dCi FAP 96kw	ABS
 Scenic III	ABS + TRACT. CONT	1.9 dCi FAP 96kw	AUTODETECT
 Scenic III	ABS + TRACT. CONT	2.0 16v 103kw	ABS
 Scenic III	ABS + TRACT. CONT	2.0 16v 103kw	AUTODETECT
 Scenic III	ABS + TRACT. CONT	2.0 16v dCi FAP 110kw	ABS
 Scenic III	ABS + TRACT. CONT	2.0 16v dCi FAP 110kw	AUTODETECT
 Scenic III	ABS + TRACT. CONT	2.0 16v dCi FAP 118kw	ABS
 Scenic III	ABS + TRACT. CONT	2.0 16v dCi FAP 118kw	AUTODETECT
 Scenic III	AIRBAG	1.4 16v 96kw	SRS
 Scenic III	AIRBAG	1.5 dCi 78kw	SRS
 Scenic III	AIRBAG	1.5 dCi FAP 81kw	SRS
 Scenic III	AIRBAG	1.6 16v 81kw	SRS
 Scenic III	AIRBAG	1.9 dCi 96kw	SRS
 Scenic III	AIRBAG	1.9 dCi FAP 96kw	SRS
 Scenic III	AIRBAG	2.0 16v 103kw	SRS
 Scenic III	AIRBAG	2.0 16v dCi FAP 110kw	SRS
 Scenic III	AIRBAG	2.0 16v dCi FAP 118kw	SRS
 Scenic III	AUTOM. TRANSMISSI	1.4 16v 96kw	AUTODETECT
 Scenic III	AUTOM. TRANSMISSI	1.5 dCi 78kw	AUTODETECT
 Scenic III	AUTOM. TRANSMISSI	1.5 dCi FAP 81kw	AUTODETECT
 Scenic III	AUTOM. TRANSMISSI	1.6 16v 81kw	AUTODETECT
 Scenic III	AUTOM. TRANSMISSI	1.9 dCi 96kw	AUTODETECT
 Scenic III	AUTOM. TRANSMISSI	1.9 dCi FAP 96kw	AUTODETECT
 Scenic III	AUTOM. TRANSMISSI	2.0 16v 103kw	AUTODETECT
 Scenic III	AUTOM. TRANSMISSI	2.0 16v dCi FAP 110kw	AUTODETECT
 Scenic III	AUTOM. TRANSMISSI	2.0 16v dCi FAP 118kw	AUTODETECT
 Scenic III	CHASSIS NETWORK	1.4 16v 96kw	Body Computer UCH
 Scenic III	CHASSIS NETWORK	1.4 16v 96kw	Body Computer UPC
 Scenic III	CHASSIS NETWORK	1.4 16v 96kw	UCC AUTODETECT
 Scenic III	CHASSIS NETWORK	1.5 dCi 78kw	Body Computer UCH
 Scenic III	CHASSIS NETWORK	1.5 dCi 78kw	Body Computer UPC
 Scenic III	CHASSIS NETWORK	1.5 dCi 78kw	UCC AUTODETECT
 Scenic III	CHASSIS NETWORK	1.5 dCi FAP 81kw	Body Computer UCH
 Scenic III	CHASSIS NETWORK	1.5 dCi FAP 81kw	Body Computer UPC
 Scenic III	CHASSIS NETWORK	1.5 dCi FAP 81kw	UCC AUTODETECT
 Scenic III	CHASSIS NETWORK	1.6 16v 81kw	Body Computer UCH
 Scenic III	CHASSIS NETWORK	1.6 16v 81kw	Body Computer UPC
 Scenic III	CHASSIS NETWORK	1.6 16v 81kw	UCC AUTODETECT
 Scenic III	CHASSIS NETWORK	1.9 dCi 96kw	Body Computer UCH
 Scenic III	CHASSIS NETWORK	1.9 dCi 96kw	Body Computer UPC
 Scenic III	CHASSIS NETWORK	1.9 dCi 96kw	UCC AUTODETECT
 Scenic III	CHASSIS NETWORK	1.9 dCi FAP 96kw	Body Computer UCH
 Scenic III	CHASSIS NETWORK	1.9 dCi FAP 96kw	Body Computer UPC
 Scenic III	CHASSIS NETWORK	1.9 dCi FAP 96kw	UCC AUTODETECT
 Scenic III	CHASSIS NETWORK	2.0 16v 103kw	Body Computer UCH
 Scenic III	CHASSIS NETWORK	2.0 16v 103kw	Body Computer UPC
 Scenic III	CHASSIS NETWORK	2.0 16v 103kw	UCC AUTODETECT
 Scenic III	CHASSIS NETWORK	2.0 16v dCi FAP 110kw	Body Computer UCH
 Scenic III	CHASSIS NETWORK	2.0 16v dCi FAP 110kw	Body Computer UPC
 Scenic III	CHASSIS NETWORK	2.0 16v dCi FAP 110kw	UCC AUTODETECT
 Scenic III	CHASSIS NETWORK	2.0 16v dCi FAP 118kw	Body Computer UCH
 Scenic III	CHASSIS NETWORK	2.0 16v dCi FAP 118kw	Body Computer UPC
 Scenic III	CHASSIS NETWORK	2.0 16v dCi FAP 118kw	UCC AUTODETECT
 Scenic III	CLIMA	1.4 16v 96kw	
 Scenic III	CLIMA	1.4 16v 96kw	AUTODETECT
 Scenic III	CLIMA	1.5 dCi 78kw	
 Scenic III	CLIMA	1.5 dCi 78kw	AUTODETECT
 Scenic III	CLIMA	1.5 dCi FAP 81kw	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Scenic III	CLIMA	1.5 dCi FAP 81kw	AUTODETECT
 Scenic III	CLIMA	1.6 16v 81kw	
 Scenic III	CLIMA	1.6 16v 81kw	AUTODETECT
 Scenic III	CLIMA	1.9 dCi 96kw	
 Scenic III	CLIMA	1.9 dCi 96kw	AUTODETECT
 Scenic III	CLIMA	1.9 dCi FAP 96kw	
 Scenic III	CLIMA	1.9 dCi FAP 96kw	AUTODETECT
 Scenic III	CLIMA	2.0 16v 103kw	
 Scenic III	CLIMA	2.0 16v 103kw	AUTODETECT
 Scenic III	CLIMA	2.0 16v dCi FAP 110kw	
 Scenic III	CLIMA	2.0 16v dCi FAP 110kw	AUTODETECT
 Scenic III	CLIMA	2.0 16v dCi FAP 118kw	
 Scenic III	CLIMA	2.0 16v dCi FAP 118kw	AUTODETECT
 Scenic III	DASHBOARD	1.4 16v 96kw	AUTODETECT
 Scenic III	DASHBOARD	1.4 16v 96kw	Dashboard
 Scenic III	DASHBOARD	1.5 dCi 78kw	AUTODETECT
 Scenic III	DASHBOARD	1.5 dCi 78kw	Dashboard
 Scenic III	DASHBOARD	1.5 dCi FAP 81kw	AUTODETECT
 Scenic III	DASHBOARD	1.5 dCi FAP 81kw	Dashboard
 Scenic III	DASHBOARD	1.6 16v 81kw	AUTODETECT
 Scenic III	DASHBOARD	1.6 16v 81kw	Dashboard
 Scenic III	DASHBOARD	1.9 dCi 96kw	AUTODETECT
 Scenic III	DASHBOARD	1.9 dCi 96kw	Dashboard
 Scenic III	DASHBOARD	1.9 dCi FAP 96kw	AUTODETECT
 Scenic III	DASHBOARD	1.9 dCi FAP 96kw	Dashboard
 Scenic III	DASHBOARD	2.0 16v 103kw	AUTODETECT
 Scenic III	DASHBOARD	2.0 16v 103kw	Dashboard
 Scenic III	DASHBOARD	2.0 16v dCi FAP 110kw	AUTODETECT
 Scenic III	DASHBOARD	2.0 16v dCi FAP 110kw	Dashboard
 Scenic III	DASHBOARD	2.0 16v dCi FAP 118kw	AUTODETECT
 Scenic III	DASHBOARD	2.0 16v dCi FAP 118kw	Dashboard
 Scenic III	DRIVER SIDE DOOR	1.4 16v 96kw	
 Scenic III	DRIVER SIDE DOOR	1.5 dCi 78kw	
 Scenic III	DRIVER SIDE DOOR	1.5 dCi FAP 81kw	
 Scenic III	DRIVER SIDE DOOR	1.6 16v 81kw	
 Scenic III	DRIVER SIDE DOOR	1.9 dCi 96kw	
 Scenic III	DRIVER SIDE DOOR	1.9 dCi FAP 96kw	
 Scenic III	DRIVER SIDE DOOR	2.0 16v 103kw	
 Scenic III	DRIVER SIDE DOOR	2.0 16v dCi FAP 110kw	
 Scenic III	DRIVER SIDE DOOR	2.0 16v dCi FAP 118kw	
 Scenic III	ELECTRIC STEERING	1.4 16v 96kw	AUTODETECT
 Scenic III	ELECTRIC STEERING	1.4 16v 96kw	EPS
 Scenic III	ELECTRIC STEERING	1.5 dCi 78kw	AUTODETECT
 Scenic III	ELECTRIC STEERING	1.5 dCi 78kw	EPS
 Scenic III	ELECTRIC STEERING	1.5 dCi FAP 81kw	AUTODETECT
 Scenic III	ELECTRIC STEERING	1.5 dCi FAP 81kw	EPS
 Scenic III	ELECTRIC STEERING	1.6 16v 81kw	AUTODETECT
 Scenic III	ELECTRIC STEERING	1.6 16v 81kw	EPS
 Scenic III	ELECTRIC STEERING	1.9 dCi 96kw	AUTODETECT
 Scenic III	ELECTRIC STEERING	1.9 dCi 96kw	EPS
 Scenic III	ELECTRIC STEERING	1.9 dCi FAP 96kw	AUTODETECT
 Scenic III	ELECTRIC STEERING	1.9 dCi FAP 96kw	EPS
 Scenic III	ELECTRIC STEERING	2.0 16v 103kw	AUTODETECT
 Scenic III	ELECTRIC STEERING	2.0 16v 103kw	EPS
 Scenic III	ELECTRIC STEERING	2.0 16v dCi FAP 110kw	AUTODETECT
 Scenic III	ELECTRIC STEERING	2.0 16v dCi FAP 110kw	EPS
 Scenic III	ELECTRIC STEERING	2.0 16v dCi FAP 118kw	AUTODETECT
 Scenic III	ELECTRIC STEERING	2.0 16v dCi FAP 118kw	EPS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Scenic III	ENGINE MANAGEME	1.4 16v 96kw	AUTODETECT
 Scenic III	ENGINE MANAGEME	1.5 dCi 78kw	AUTODETECT
 Scenic III	ENGINE MANAGEME	1.5 dCi FAP 81kw	AUTODETECT
 Scenic III	ENGINE MANAGEME	1.5 dCi FAP 81kw K9K	EDC Common Rail
 Scenic III	ENGINE MANAGEME	1.6 16v 81kw	AUTODETECT
 Scenic III	ENGINE MANAGEME	1.9 dCi 96kw	AUTODETECT
 Scenic III	ENGINE MANAGEME	1.9 dCi FAP 96kw	AUTODETECT
 Scenic III	ENGINE MANAGEME	2.0 16v 103kw	AUTODETECT
 Scenic III	ENGINE MANAGEME	2.0 16v dCi FAP 110kw	AUTODETECT
 Scenic III	ENGINE MANAGEME	2.0 16v dCi FAP 118kw	AUTODETECT
 Scenic III	MAINTENANCE	1.4 16v 96kw	ABS
 Scenic III	MAINTENANCE	1.4 16v 96kw	Electrobrake
 Scenic III	MAINTENANCE	1.4 16v 96kw	Electrobrake
 Scenic III	MAINTENANCE	1.4 16v 96kw	SRS
 Scenic III	MAINTENANCE	1.4 16v 96kw	SRS
 Scenic III	MAINTENANCE	1.4 16v 96kw	SRS
 Scenic III	MAINTENANCE	1.5 dCi 78kw	ABS
 Scenic III	MAINTENANCE	1.5 dCi 78kw	Electrobrake
 Scenic III	MAINTENANCE	1.5 dCi 78kw	Electrobrake
 Scenic III	MAINTENANCE	1.5 dCi 78kw	SRS
 Scenic III	MAINTENANCE	1.5 dCi 78kw	SRS
 Scenic III	MAINTENANCE	1.5 dCi 78kw	SRS
 Scenic III	MAINTENANCE	1.5 dCi 78kw	SRS
 Scenic III	MAINTENANCE	1.5 dCi FAP 81kw	ABS
 Scenic III	MAINTENANCE	1.5 dCi FAP 81kw	Electrobrake
 Scenic III	MAINTENANCE	1.5 dCi FAP 81kw	Electrobrake
 Scenic III	MAINTENANCE	1.5 dCi FAP 81kw	SRS
 Scenic III	MAINTENANCE	1.5 dCi FAP 81kw	SRS
 Scenic III	MAINTENANCE	1.5 dCi FAP 81kw	SRS
 Scenic III	MAINTENANCE	1.5 dCi FAP 81kw K9K	EDC Common Rail
 Scenic III	MAINTENANCE	1.5 dCi FAP 81kw K9K	EDC Common Rail
 Scenic III	MAINTENANCE	1.6 16v 81kw	ABS
 Scenic III	MAINTENANCE	1.6 16v 81kw	Electrobrake
 Scenic III	MAINTENANCE	1.6 16v 81kw	Electrobrake
 Scenic III	MAINTENANCE	1.6 16v 81kw	SRS
 Scenic III	MAINTENANCE	1.6 16v 81kw	SRS
 Scenic III	MAINTENANCE	1.6 16v 81kw	SRS
 Scenic III	MAINTENANCE	1.9 dCi 96kw	ABS
 Scenic III	MAINTENANCE	1.9 dCi 96kw	Electrobrake
 Scenic III	MAINTENANCE	1.9 dCi 96kw	Electrobrake
 Scenic III	MAINTENANCE	1.9 dCi 96kw	SRS
 Scenic III	MAINTENANCE	1.9 dCi 96kw	SRS
 Scenic III	MAINTENANCE	1.9 dCi 96kw	SRS
 Scenic III	MAINTENANCE	1.9 dCi 96kw	SRS
 Scenic III	MAINTENANCE	1.9 dCi FAP 96kw	ABS
 Scenic III	MAINTENANCE	1.9 dCi FAP 96kw	Electrobrake
 Scenic III	MAINTENANCE	1.9 dCi FAP 96kw	Electrobrake
 Scenic III	MAINTENANCE	1.9 dCi FAP 96kw	SRS
 Scenic III	MAINTENANCE	1.9 dCi FAP 96kw	SRS
 Scenic III	MAINTENANCE	1.9 dCi FAP 96kw	SRS
 Scenic III	MAINTENANCE	2.0 16v 103kw	ABS
 Scenic III	MAINTENANCE	2.0 16v 103kw	Electrobrake
 Scenic III	MAINTENANCE	2.0 16v 103kw	Electrobrake
 Scenic III	MAINTENANCE	2.0 16v 103kw	SRS
 Scenic III	MAINTENANCE	2.0 16v 103kw	SRS
 Scenic III	MAINTENANCE	2.0 16v 103kw	SRS
 Scenic III	MAINTENANCE	2.0 16v dCi FAP 110kw	ABS
 Scenic III	MAINTENANCE	2.0 16v dCi FAP 110kw	Electrobrake
Scenic III	MAINTENANCE	2.0 16v dCi FAP 110kw	Electrobrake
Scenic III	MAINTENANCE	2.0 16v dCi FAP 110kw	SRS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Scenic III	MAINTENANCE	2.0 16v dCi FAP 110kw	SRS
 Scenic III	MAINTENANCE	2.0 16v dCi FAP 110kw	SRS
 Scenic III	MAINTENANCE	2.0 16v dCi FAP 118kw	ABS
 Scenic III	MAINTENANCE	2.0 16v dCi FAP 118kw	Electrobrake
 Scenic III	MAINTENANCE	2.0 16v dCi FAP 118kw	Electrobrake
 Scenic III	MAINTENANCE	2.0 16v dCi FAP 118kw	SRS
 Scenic III	MAINTENANCE	2.0 16v dCi FAP 118kw	SRS
 Scenic III	MAINTENANCE	2.0 16v dCi FAP 118kw	SRS
 Scenic III	PARK.BRAKE	1.4 16v 96kw	AUTODETECT
 Scenic III	PARK.BRAKE	1.4 16v 96kw	Electrobrake
 Scenic III	PARK.BRAKE	1.5 dCi 78kw	AUTODETECT
 Scenic III	PARK.BRAKE	1.5 dCi 78kw	Electrobrake
 Scenic III	PARK.BRAKE	1.5 dCi FAP 81kw	AUTODETECT
 Scenic III	PARK.BRAKE	1.5 dCi FAP 81kw	Electrobrake
 Scenic III	PARK.BRAKE	1.6 16v 81kw	AUTODETECT
 Scenic III	PARK.BRAKE	1.6 16v 81kw	Electrobrake
 Scenic III	PARK.BRAKE	1.9 dCi 96kw	AUTODETECT
 Scenic III	PARK.BRAKE	1.9 dCi 96kw	Electrobrake
 Scenic III	PARK.BRAKE	1.9 dCi FAP 96kw	AUTODETECT
 Scenic III	PARK.BRAKE	1.9 dCi FAP 96kw	Electrobrake
 Scenic III	PARK.BRAKE	2.0 16v 103kw	AUTODETECT
 Scenic III	PARK.BRAKE	2.0 16v 103kw	Electrobrake
 Scenic III	PARK.BRAKE	2.0 16v dCi FAP 110kw	AUTODETECT
 Scenic III	PARK.BRAKE	2.0 16v dCi FAP 110kw	Electrobrake
 Scenic III	PARK.BRAKE	2.0 16v dCi FAP 118kw	AUTODETECT
 Scenic III	PARK.BRAKE	2.0 16v dCi FAP 118kw	Electrobrake
 Scenic III	PARKING HELP	1.4 16v 96kw	AFX PDC
 Scenic III	PARKING HELP	1.4 16v 96kw	AUTODETECT
 Scenic III	PARKING HELP	1.5 dCi 78kw	AFX PDC
 Scenic III	PARKING HELP	1.5 dCi 78kw	AUTODETECT
 Scenic III	PARKING HELP	1.5 dCi FAP 81kw	AFX PDC
 Scenic III	PARKING HELP	1.5 dCi FAP 81kw	AUTODETECT
 Scenic III	PARKING HELP	1.6 16v 81kw	AFX PDC
 Scenic III	PARKING HELP	1.6 16v 81kw	AUTODETECT
 Scenic III	PARKING HELP	1.9 dCi 96kw	AFX PDC
 Scenic III	PARKING HELP	1.9 dCi 96kw	AUTODETECT
 Scenic III	PARKING HELP	1.9 dCi FAP 96kw	AFX PDC
 Scenic III	PARKING HELP	1.9 dCi FAP 96kw	AUTODETECT
 Scenic III	PARKING HELP	2.0 16v 103kw	AFX PDC
 Scenic III	PARKING HELP	2.0 16v 103kw	AUTODETECT
 Scenic III	PARKING HELP	2.0 16v dCi FAP 110kw	AFX PDC
 Scenic III	PARKING HELP	2.0 16v dCi FAP 110kw	AUTODETECT
 Scenic III	PARKING HELP	2.0 16v dCi FAP 118kw	AFX PDC
 Scenic III	PARKING HELP	2.0 16v dCi FAP 118kw	AUTODETECT
 Scenic III	RADIO / CD	1.4 16v 96kw	AUTODETECT
 Scenic III	RADIO / CD	1.4 16v 96kw	BT2 Radio
 Scenic III	RADIO / CD	1.5 dCi 78kw	AUTODETECT
 Scenic III	RADIO / CD	1.5 dCi 78kw	BT2 Radio
 Scenic III	RADIO / CD	1.5 dCi FAP 81kw	AUTODETECT
 Scenic III	RADIO / CD	1.5 dCi FAP 81kw	BT2 Radio
 Scenic III	RADIO / CD	1.6 16v 81kw	AUTODETECT
 Scenic III	RADIO / CD	1.6 16v 81kw	BT2 Radio
 Scenic III	RADIO / CD	1.9 dCi 96kw	AUTODETECT
 Scenic III	RADIO / CD	1.9 dCi 96kw	BT2 Radio
 Scenic III	RADIO / CD	1.9 dCi FAP 96kw	AUTODETECT
 Scenic III	RADIO / CD	1.9 dCi FAP 96kw	BT2 Radio
 Scenic III	RADIO / CD	2.0 16v 103kw	AUTODETECT
 Scenic III	RADIO / CD	2.0 16v 103kw	BT2 Radio

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Scenic III	RADIO / CD	2.0 16v dCi FAP 110kw	AUTODETECT
 Scenic III	RADIO / CD	2.0 16v dCi FAP 110kw	BT2 Radio
 Scenic III	RADIO / CD	2.0 16v dCi FAP 118kw	AUTODETECT
 Scenic III	RADIO / CD	2.0 16v dCi FAP 118kw	BT2 Radio
 Scenic III	VISUAL/TELEMATIC	1.4 16v 96kw	
 Scenic III	VISUAL/TELEMATIC	1.4 16v 96kw	USB AUTODETECT
 Scenic III	VISUAL/TELEMATIC	1.5 dCi 78kw	
 Scenic III	VISUAL/TELEMATIC	1.5 dCi 78kw	USB AUTODETECT
 Scenic III	VISUAL/TELEMATIC	1.5 dCi FAP 81kw	
 Scenic III	VISUAL/TELEMATIC	1.5 dCi FAP 81kw	USB AUTODETECT
 Scenic III	VISUAL/TELEMATIC	1.6 16v 81kw	
 Scenic III	VISUAL/TELEMATIC	1.6 16v 81kw	USB AUTODETECT
 Scenic III	VISUAL/TELEMATIC	1.9 dCi 96kw	
 Scenic III	VISUAL/TELEMATIC	1.9 dCi 96kw	USB AUTODETECT
 Scenic III	VISUAL/TELEMATIC	1.9 dCi FAP 96kw	
 Scenic III	VISUAL/TELEMATIC	1.9 dCi FAP 96kw	USB AUTODETECT
 Scenic III	VISUAL/TELEMATIC	2.0 16v 103kw	
 Scenic III	VISUAL/TELEMATIC	2.0 16v 103kw	USB AUTODETECT
 Scenic III	VISUAL/TELEMATIC	2.0 16v dCi FAP 110kw	
 Scenic III	VISUAL/TELEMATIC	2.0 16v dCi FAP 110kw	USB AUTODETECT
 Scenic III	VISUAL/TELEMATIC	2.0 16v dCi FAP 118kw	
 Scenic III	VISUAL/TELEMATIC	2.0 16v dCi FAP 118kw	USB AUTODETECT
 Super 5	ENGINE MANAGEME	1.4 C3J-702	SIEMENS RENIX SPI
 Super 5	ENGINE MANAGEME	1.4 C3J-760	SIEMENS RENIX SPI
 Super 5	ENGINE MANAGEME	1.4 C3J-760	SIEMENS RENIX SPI
 Super 5	ENGINE MANAGEME	1.4 C3J-760	SIEMENS RENIX SPI
 Super 5	ENGINE MANAGEME	1.4 C3J-762	SIEMENS RENIX SPI
 Super 5	ENGINE MANAGEME	1.4 C3J-762	SIEMENS RENIX SPI
 Super 5	ENGINE MANAGEME	1.4 E7J-720	SIEMENS BOSCH SPI
 Super 5	ENGINE MANAGEME	1.4 E7J-720	SIEMENS BOSCH SPI
 Super 5	ENGINE MANAGEME	1.4 E7J-724	SIEMENS BOSCH SPI
 Super 5	ENGINE MANAGEME	1.4 E7J-724	SIEMENS BOSCH SPI
 Super 5	ENGINE MANAGEME	1.4 E7J-724	SIEMENS BOSCH SPI
 Super 5	ENGINE MANAGEME	1.7 F3N-702	SIEMENS RENIX-BENDIX MPI
 Super 5	ENGINE MANAGEME	1.7 F3N-702	SIEMENS RENIX-BENDIX MPI
 Super 5	ENGINE MANAGEME	1.7 F3N-702	SIEMENS RENIX-BENDIX MPI
 Super 5	ENGINE MANAGEME	1.7 F3N-702	SIEMENS RENIX-BENDIX MPI
 Super 5	ENGINE MANAGEME	1.7 F3N-716	SIEMENS RENIX SPI
 Super 5	ENGINE MANAGEME	1.7 F3N-716	SIEMENS RENIX SPI
 Super 5	ENGINE MANAGEME	1.7 F3N-716	SIEMENS RENIX SPI
 Super 5	ENGINE MANAGEME	1.7 F3N-716	SIEMENS RENIX SPI
 Super 5	ENGINE MANAGEME	1.7 F3N-717	SIEMENS RENIX SPI
 Super 5	ENGINE MANAGEME	1.7 F3N-717	SIEMENS RENIX SPI
 Super 5	ENGINE MANAGEME	1.7 F3N-717	SIEMENS RENIX SPI
 Thalia-Symbol II	CHASSIS NETWORK	1.2 16v 55kw	AUTODETECT
 Thalia-Symbol II	CHASSIS NETWORK	1.4 72kw	AUTODETECT
 Thalia-Symbol II	CHASSIS NETWORK	1.4 8v 55kw	AUTODETECT
 Thalia-Symbol II	CHASSIS NETWORK	1.5 dCi 48kw	AUTODETECT
 Thalia-Symbol II	CHASSIS NETWORK	1.5 dCi 59kw	AUTODETECT
 Thalia-Symbol	ABS	1.2 16v 55kw	BOSCH ABS 8.0
 Thalia-Symbol	ABS	1.4 16v 72kw	BOSCH ABS 8.0
 Thalia-Symbol	ABS	1.4 MPI 55kw	BOSCH ABS 8.0
 Thalia-Symbol	ABS	1.5 dCi 48kw	BOSCH ABS 8.0
 Thalia-Symbol	ABS	1.5 dCi 50kw	BOSCH ABS 8.0
 Thalia-Symbol	ABS	1.5 dCi 60kw	BOSCH ABS 8.0
 Thalia-Symbol	ABS	1.5 dCi 62kw	BOSCH ABS 8.0
 Thalia-Symbol	ABS	1.6 16v 77kw	BOSCH ABS 8.0
 Thalia-Symbol	AIRBAG	1.2 16v 55kw	BOSCH AirBag AB8 (No CAN)

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Thalia-Symbol	AIRBAG	1.4 16v 72kw	BOSCH AirBag AB8 (No CAN)
 Thalia-Symbol	AIRBAG	1.4 MPI 55kw	BOSCH AirBag AB8 (No CAN)
 Thalia-Symbol	AIRBAG	1.5 dCi 48kw	BOSCH AirBag AB8 (No CAN)
 Thalia-Symbol	AIRBAG	1.5 dCi 50kw	BOSCH AirBag AB8 (No CAN)
 Thalia-Symbol	AIRBAG	1.5 dCi 60kw	BOSCH AirBag AB8 (No CAN)
 Thalia-Symbol	AIRBAG	1.5 dCi 62kw	BOSCH AirBag AB8 (No CAN)
 Thalia-Symbol	AIRBAG	1.6 16v 77kw	BOSCH AirBag AB8 (No CAN)
 Thalia-Symbol	ENGINE MANAGEME	1.2 16v 55kw	AUTODETECT
 Thalia-Symbol	ENGINE MANAGEME	1.2 16v 55kw (01-..)	EOBD
 Thalia-Symbol	ENGINE MANAGEME	1.4 16v 72kw (01-..)	EOBD
 Thalia-Symbol	ENGINE MANAGEME	1.4 72kw	AUTODETECT
 Thalia-Symbol	ENGINE MANAGEME	1.4 8v 55kw	AUTODETECT
 Thalia-Symbol	ENGINE MANAGEME	1.4 MPI 55kw	AUTODETECT
 Thalia-Symbol	ENGINE MANAGEME	1.4 MPI 55kw K7J-700	SIEMENS Sirius 32
 Thalia-Symbol	ENGINE MANAGEME	1.5 dCi 48kw	AUTODETECT
 Thalia-Symbol	ENGINE MANAGEME	1.5 dCi 48kw (04-..)	EOBD
 Thalia-Symbol	ENGINE MANAGEME	1.5 dCi 50kw K9K-714	DELPHI LUCAS LVCR Common Rail
 Thalia-Symbol	ENGINE MANAGEME	1.5 dCi 59kw	AUTODETECT
 Thalia-Symbol	ENGINE MANAGEME	1.5 dCi 60kw K9K-702	DELPHI LUCAS LVCR Common Rail
 Thalia-Symbol	ENGINE MANAGEME	1.5 dCi 62kw K9K-718	DELPHI LUCAS LVCR Common Rail
 Thalia-Symbol	ENGINE MANAGEME	1.6 16v 77kw	AUTODETECT
 Thalia-Symbol	ENGINE MANAGEME	1.6 16v 77kw K4M-745	SIEMENS Sirius 32
 Thalia-Symbol	IMMOBILIZER	1.2 16v 55kw	Immobilizer Body Computer
 Thalia-Symbol	IMMOBILIZER	1.4 16v 72kw	Immobilizer Body Computer
 Thalia-Symbol	IMMOBILIZER	1.4 MPI 55kw	Immobilizer Body Computer
 Thalia-Symbol	IMMOBILIZER	1.5 dCi 48kw	Immobilizer Body Computer
 Thalia-Symbol	IMMOBILIZER	1.5 dCi 50kw	Immobilizer Body Computer
 Thalia-Symbol	IMMOBILIZER	1.5 dCi 60kw	Immobilizer Body Computer
 Thalia-Symbol	IMMOBILIZER	1.5 dCi 62kw	Immobilizer Body Computer
 Thalia-Symbol	IMMOBILIZER	1.6 16v 77kw	Immobilizer Body Computer
 Thalia-Symbol	MAINTENANCE	1.2 16v 55kw	BOSCH ABS 8.0
 Thalia-Symbol	MAINTENANCE	1.2 16v 55kw	BOSCH ABS 8.0
 Thalia-Symbol	MAINTENANCE	1.2 16v 55kw	BOSCH ABS 8.0
 Thalia-Symbol	MAINTENANCE	1.2 16v 55kw	BOSCH ABS 8.0
 Thalia-Symbol	MAINTENANCE	1.4 16v 72kw	BOSCH ABS 8.0
 Thalia-Symbol	MAINTENANCE	1.4 16v 72kw	BOSCH ABS 8.0
 Thalia-Symbol	MAINTENANCE	1.4 16v 72kw	BOSCH ABS 8.0
 Thalia-Symbol	MAINTENANCE	1.4 MPI 55kw	BOSCH ABS 8.0
 Thalia-Symbol	MAINTENANCE	1.4 MPI 55kw	BOSCH ABS 8.0
 Thalia-Symbol	MAINTENANCE	1.4 MPI 55kw	BOSCH ABS 8.0
 Thalia-Symbol	MAINTENANCE	1.4 MPI 55kw	BOSCH ABS 8.0
 Thalia-Symbol	MAINTENANCE	1.5 dCi 48kw	BOSCH ABS 8.0
 Thalia-Symbol	MAINTENANCE	1.5 dCi 48kw	BOSCH ABS 8.0
 Thalia-Symbol	MAINTENANCE	1.5 dCi 48kw	BOSCH ABS 8.0
 Thalia-Symbol	MAINTENANCE	1.5 dCi 48kw	BOSCH ABS 8.0
 Thalia-Symbol	MAINTENANCE	1.5 dCi 50kw	BOSCH ABS 8.0
 Thalia-Symbol	MAINTENANCE	1.5 dCi 50kw	BOSCH ABS 8.0
 Thalia-Symbol	MAINTENANCE	1.5 dCi 50kw	BOSCH ABS 8.0
 Thalia-Symbol	MAINTENANCE	1.5 dCi 50kw	BOSCH ABS 8.0
 Thalia-Symbol	MAINTENANCE	1.5 dCi 60kw	BOSCH ABS 8.0
 Thalia-Symbol	MAINTENANCE	1.5 dCi 60kw	BOSCH ABS 8.0
 Thalia-Symbol	MAINTENANCE	1.5 dCi 60kw	BOSCH ABS 8.0
 Thalia-Symbol	MAINTENANCE	1.5 dCi 60kw	BOSCH ABS 8.0
 Thalia-Symbol	MAINTENANCE	1.5 dCi 62kw	BOSCH ABS 8.0
 Thalia-Symbol	MAINTENANCE	1.5 dCi 62kw	BOSCH ABS 8.0
 Thalia-Symbol	MAINTENANCE	1.5 dCi 62kw	BOSCH ABS 8.0

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Thalia-Symbol	MAINTENANCE	1.6 16v 77kw	BOSCH ABS 8.0
 Thalia-Symbol	MAINTENANCE	1.6 16v 77kw	BOSCH ABS 8.0
 Thalia-Symbol	MAINTENANCE	1.6 16v 77kw	BOSCH ABS 8.0
 Thalia-Symbol	MAINTENANCE	1.6 16v 77kw	BOSCH ABS 8.0
 Trafic II p2/3	AUTOM. TRANSMISSI	1.9 dCi 60kw	AUTODETECT
 Trafic II p2/3	AUTOM. TRANSMISSI	1.9 dCi 74kw	AUTODETECT
 Trafic II p2/3	AUTOM. TRANSMISSI	2.0 dCi 16v 66kw	AUTODETECT
 Trafic II p2/3	AUTOM. TRANSMISSI	2.0 dCi 16v 84kw	AUTODETECT
 Trafic II p2/3	AUTOM. TRANSMISSI	2.0i 16v 86kw	AUTODETECT
 Trafic II p2/3	AUTOM. TRANSMISSI	2.0i 16v 88kw	AUTODETECT
 Trafic II p2/3	AUTOM. TRANSMISSI	2.5 dCi 16v 107kw	AUTODETECT
 Trafic II p2/3	AUTOM. TRANSMISSI	2.5 dCi 16v 84kw	AUTODETECT
 Trafic II p2/3	AUTOM. TRANSMISSI	2.5 dCi 16v 99kw	AUTODETECT
 Trafic II p2/3	CHASSIS NETWORK	1.9 dCi 60kw	UCC AUTODETECT
 Trafic II p2/3	CHASSIS NETWORK	1.9 dCi 74kw	UCC AUTODETECT
 Trafic II p2/3	CHASSIS NETWORK	2.0 dCi 16v 66kw	UCC AUTODETECT
 Trafic II p2/3	CHASSIS NETWORK	2.0 dCi 16v 84kw	UCC AUTODETECT
 Trafic II p2/3	CHASSIS NETWORK	2.0i 16v 86kw	UCC AUTODETECT
 Trafic II p2/3	CHASSIS NETWORK	2.0i 16v 88kw	UCC AUTODETECT
 Trafic II p2/3	CHASSIS NETWORK	2.5 dCi 16v 107kw	UCC AUTODETECT
 Trafic II p2/3	CHASSIS NETWORK	2.5 dCi 16v 84kw	UCC AUTODETECT
 Trafic II p2/3	CHASSIS NETWORK	2.5 dCi 16v 99kw	UCC AUTODETECT
 Trafic II p2/3	ENGINE MANAGEME	1.9 dCi 60kw	AUTODETECT
 Trafic II p2/3	ENGINE MANAGEME	1.9 dCi 74kw	AUTODETECT
 Trafic II p2/3	ENGINE MANAGEME	2.0 dCi 16v 66kw	AUTODETECT
 Trafic II p2/3	ENGINE MANAGEME	2.0 dCi 16v 84kw	AUTODETECT
 Trafic II p2/3	ENGINE MANAGEME	2.0i 16v 86kw	AUTODETECT
 Trafic II p2/3	ENGINE MANAGEME	2.5 dCi 16v 107kw	AUTODETECT
 Trafic II p2/3	ENGINE MANAGEME	2.5 dCi 16v 84kw	AUTODETECT
 Trafic II p2/3	ENGINE MANAGEME	2.5 dCi 16v 99kw	AUTODETECT
 Trafic II p2	AUTOM. TRANSMISSI	1.9 dCi 60kw	AUTODETECT
 Trafic II p2	AUTOM. TRANSMISSI	1.9 dCi 74kw	AUTODETECT
 Trafic II p2	AUTOM. TRANSMISSI	2.0 dCi 16v 66kw	AUTODETECT
 Trafic II p2	AUTOM. TRANSMISSI	2.0 dCi 16v 84kw	AUTODETECT
 Trafic II p2	AUTOM. TRANSMISSI	2.0i 16v 86kw	AUTODETECT
 Trafic II p2	AUTOM. TRANSMISSI	2.0i 16v 88kw	AUTODETECT
 Trafic II p2	AUTOM. TRANSMISSI	2.5 dCi 16v 107kw	AUTODETECT
 Trafic II p2	AUTOM. TRANSMISSI	2.5 dCi 16v 84kw	AUTODETECT
 Trafic II p2	AUTOM. TRANSMISSI	2.5 dCi 16v 99kw	AUTODETECT
 Trafic II p2	CHASSIS NETWORK	1.9 dCi 60kw	UCC AUTODETECT
 Trafic II p2	CHASSIS NETWORK	1.9 dCi 74kw	UCC AUTODETECT
 Trafic II p2	CHASSIS NETWORK	2.0 dCi 16v 66kw	UCC AUTODETECT
 Trafic II p2	CHASSIS NETWORK	2.0 dCi 16v 84kw	UCC AUTODETECT
 Trafic II p2	CHASSIS NETWORK	2.0i 16v 86kw	UCC AUTODETECT
 Trafic II p2	CHASSIS NETWORK	2.0i 16v 88kw	UCC AUTODETECT
 Trafic II p2	CHASSIS NETWORK	2.5 dCi 16v 107kw	UCC AUTODETECT
 Trafic II p2	CHASSIS NETWORK	2.5 dCi 16v 84kw	UCC AUTODETECT
 Trafic II p2	CHASSIS NETWORK	2.5 dCi 16v 99kw	UCC AUTODETECT
 Trafic II p2	ENGINE MANAGEME	1.9 dCi 60kw	AUTODETECT
 Trafic II p2	ENGINE MANAGEME	1.9 dCi 74kw	AUTODETECT
 Trafic II p2	ENGINE MANAGEME	2.0 dCi 16v 66kw	AUTODETECT
 Trafic II p2	ENGINE MANAGEME	2.0 dCi 16v 84kw	AUTODETECT
 Trafic II p2	ENGINE MANAGEME	2.0i 16v 86kw	AUTODETECT
 Trafic II p2	ENGINE MANAGEME	2.0i 16v 88kw	AUTODETECT
 Trafic II p2	ENGINE MANAGEME	2.5 dCi 16v 107kw	AUTODETECT
 Trafic II p2	ENGINE MANAGEME	2.5 dCi 16v 84kw	AUTODETECT
 Trafic II p2	ENGINE MANAGEME	2.5 dCi 16v 99kw	AUTODETECT
 Trafic II	IMMOBILIZER	1.9 dCi 60kw	SAGEM Immobilizer Key encoding

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trafic II	IMMOBILIZER	1.9 dCi 74kw	SAGEM Immobilizer Key encoding
 Trafic II	IMMOBILIZER	2.0 dCi 16v 66kw	SAGEM Immobilizer Key encoding
 Trafic II	IMMOBILIZER	2.0 dCi 16v 84kw	SAGEM Immobilizer Key encoding
 Trafic II	IMMOBILIZER	2.0i 16v 86kw	SAGEM Immobilizer Key encoding
 Trafic II	IMMOBILIZER	2.0i 16v 88kw	SAGEM Immobilizer Key encoding
 Trafic II	IMMOBILIZER	2.5 dCi 16v 107kw	SAGEM Immobilizer Key encoding
 Trafic II	IMMOBILIZER	2.5 dCi 16v 84kw	SAGEM Immobilizer Key encoding
 Trafic II	IMMOBILIZER	2.5 dCi 16v 99kw	SAGEM Immobilizer Key encoding
 Trafic II	MAINTENANCE	1.9 dCi 60kw	MANUAL
 Trafic II	MAINTENANCE	1.9 dCi 74kw	MANUAL
 Trafic II	MAINTENANCE	2.0 dCi 16v 66kw	MANUAL
 Trafic II	MAINTENANCE	2.0 dCi 16v 84kw	MANUAL
 Trafic II	MAINTENANCE	2.0i 16v 86kw	MANUAL
 Trafic II	MAINTENANCE	2.0i 16v 88kw	MANUAL
 Trafic II	MAINTENANCE	2.5 dCi 16v 107kw	MANUAL
 Trafic II	MAINTENANCE	2.5 dCi 16v 84kw	MANUAL
 Trafic II	MAINTENANCE	2.5 dCi 16v 99kw	MANUAL
 Trafic II	SERVICE LIGHT RES	1.9 dCi 60kw	MANUAL
 Trafic II	SERVICE LIGHT RES	1.9 dCi 74kw	MANUAL
 Trafic II	SERVICE LIGHT RES	2.0 dCi 16v 66kw	MANUAL
 Trafic II	SERVICE LIGHT RES	2.0 dCi 16v 84kw	MANUAL
 Trafic II	SERVICE LIGHT RES	2.0i 16v 86kw	MANUAL
 Trafic II	SERVICE LIGHT RES	2.0i 16v 88kw	MANUAL
 Trafic II	SERVICE LIGHT RES	2.5 dCi 16v 107kw	MANUAL
 Trafic II	SERVICE LIGHT RES	2.5 dCi 16v 84kw	MANUAL
 Trafic II	SERVICE LIGHT RES	2.5 dCi 16v 99kw	MANUAL
 Trafic	AIRBAG	1.9 dCi 60kw	SIEMENS - Autoliv AirBag AC4
 Trafic	AIRBAG	1.9 dCi 60kw	SIEMENS - Autoliv AirBag EC5
 Trafic	AIRBAG	1.9 dCi 60kw (...02)	SAGEM - Autoliv AirBag ACU x.x
 Trafic	AIRBAG	1.9 dCi 74kw	SIEMENS - Autoliv AirBag AC4
 Trafic	AIRBAG	1.9 dCi 74kw	SIEMENS - Autoliv AirBag EC5
 Trafic	AIRBAG	1.9 dCi 74kw (...02)	SAGEM - Autoliv AirBag ACU x.x
 Trafic	AIRBAG	1.9D 8v 44kw	SIEMENS - Autoliv AirBag AC4
 Trafic	AIRBAG	1.9D 8v 44kw	SIEMENS - Autoliv AirBag EC5
 Trafic	AIRBAG	1.9D 8v 44kw (...02)	SAGEM - Autoliv AirBag ACU x.x
 Trafic	AIRBAG	2.1D 8v 43kw	SIEMENS - Autoliv AirBag AC4
 Trafic	AIRBAG	2.1D 8v 43kw	SIEMENS - Autoliv AirBag EC5
 Trafic	AIRBAG	2.1D 8v 43kw (...02)	SAGEM - Autoliv AirBag ACU x.x
 Trafic	AIRBAG	2.1D 8v 47kw	SIEMENS - Autoliv AirBag AC4
 Trafic	AIRBAG	2.1D 8v 47kw	SIEMENS - Autoliv AirBag EC5
 Trafic	AIRBAG	2.1D 8v 47kw (...02)	SAGEM - Autoliv AirBag ACU x.x
 Trafic	AIRBAG	2.2 74kw	SIEMENS - Autoliv AirBag AC4
 Trafic	AIRBAG	2.2 74kw	SIEMENS - Autoliv AirBag EC5
 Trafic	AIRBAG	2.5D 8v 55kw	SIEMENS - Autoliv AirBag AC4
 Trafic	AIRBAG	2.5D 8v 55kw	SIEMENS - Autoliv AirBag EC5
 Trafic	AIRBAG	2.5D 8v 55kw (...02)	SAGEM - Autoliv AirBag ACU x.x
 Trafic	ENGINE MANAGEME	1.9 dCi 60kw F9Q-762	BOSCH EDC 15 C3 Common Rail
 Trafic	ENGINE MANAGEME	1.9 dCi 74kw F9Q-760	BOSCH EDC 15 C3 Common Rail
 Trafic	ENGINE MANAGEME	1.9D 8v 44kw F8Q	EOBD
 Trafic	ENGINE MANAGEME	2.1D 8v 43kw 852	EOBD
 Trafic	ENGINE MANAGEME	2.1D 8v 47kw J8S	EOBD
 Trafic	ENGINE MANAGEME	2.2 74kw J7T-600	SIEMENS BENDIX-FENIX MPI
 Trafic	ENGINE MANAGEME	2.2 74kw J7T-600	SIEMENS BENDIX-FENIX MPI
 Trafic	ENGINE MANAGEME	2.2 74kw J7T-600	SIEMENS BENDIX-FENIX MPI
 Trafic	ENGINE MANAGEME	2.5D 8v 55kw S8U	EOBD
 Twingo II	ABS + TRACT. CONT	1.2 16v 56kw	ESP
 Twingo II	ABS + TRACT. CONT	1.2 16v Turbo 74kw	ESP
 Twingo II	ABS + TRACT. CONT	1.2 43kw	ESP

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Twingo II	ABS + TRACT. CONT	1.5 dCi 48kw	ESP
 Twingo II	ABS + TRACT. CONT	1.5 DCI 8v Turbo 62kw	ESP
 Twingo II	ABS + TRACT. CONT	1.6 RS 16v 98kw	ESP
 Twingo II	AIRBAG	1.2 16v 56kw	AMR Airbag
 Twingo II	AIRBAG	1.2 16v Turbo 74kw	AMR Airbag
 Twingo II	AIRBAG	1.2 43kw	AMR Airbag
 Twingo II	AIRBAG	1.5 dCi 48kw	AMR Airbag
 Twingo II	AIRBAG	1.5 DCI 8v Turbo 62kw	AMR Airbag
 Twingo II	AIRBAG	1.6 RS 16v 98kw	AMR Airbag
 Twingo II	CHASSIS NETWORK	1.2 16v 56kw	AMR UCA
 Twingo II	CHASSIS NETWORK	1.2 16v 56kw	UCH AUTODETECT
 Twingo II	CHASSIS NETWORK	1.2 16v Turbo 74kw	AMR UCA
 Twingo II	CHASSIS NETWORK	1.2 40kw	UCH AUTODETECT
 Twingo II	CHASSIS NETWORK	1.2 43kw	AMR UCA
 Twingo II	CHASSIS NETWORK	1.2 44kw	UCH AUTODETECT
 Twingo II	CHASSIS NETWORK	1.5 dCi 48kw	AMR UCA
 Twingo II	CHASSIS NETWORK	1.5 DCI 8v Turbo 62kw	AMR UCA
 Twingo II	CHASSIS NETWORK	1.6 RS 16v 98kw	AMR UCA
 Twingo II	DASH INDICAT. UNIT	1.2 16v 56kw	REV Counter AUTODETECT
 Twingo II	DASH INDICAT. UNIT	1.2 40kw	REV Counter AUTODETECT
 Twingo II	DASH INDICAT. UNIT	1.2 44kw	REV Counter AUTODETECT
 Twingo II	DASHBOARD	1.2 16v 56kw	AUTODETECT
 Twingo II	DASHBOARD	1.2 16v 56kw	Combi
 Twingo II	DASHBOARD	1.2 16v 56kw	Combi AUTODETECT
 Twingo II	DASHBOARD	1.2 16v Turbo 74kw	Combi
 Twingo II	DASHBOARD	1.2 40kw	Combi AUTODETECT
 Twingo II	DASHBOARD	1.2 43kw	AUTODETECT
 Twingo II	DASHBOARD	1.2 43kw	Combi
 Twingo II	DASHBOARD	1.2 44kw	Combi AUTODETECT
 Twingo II	DASHBOARD	1.5 dCi 48kw	AUTODETECT
 Twingo II	DASHBOARD	1.5 dCi 48kw	Combi
 Twingo II	DASHBOARD	1.5 DCI 8v Turbo 62kw	Combi
 Twingo II	DASHBOARD	1.6 RS 16v 98kw	Combi
 Twingo II	ELECTRIC STEERING	1.2 16v 56kw	KOYO EPS
 Twingo II	ELECTRIC STEERING	1.2 16v Turbo 74kw	KOYO EPS
 Twingo II	ELECTRIC STEERING	1.2 43kw	KOYO EPS
 Twingo II	ELECTRIC STEERING	1.5 dCi 48kw	KOYO EPS
 Twingo II	ELECTRIC STEERING	1.5 DCI 8v Turbo 62kw	KOYO EPS
 Twingo II	ELECTRIC STEERING	1.6 RS 16v 98kw	KOYO EPS
 Twingo II	ENGINE MANAGEME	1.2 16v 56kw	AUTODETECT
 Twingo II	ENGINE MANAGEME	1.2 16v 56kw	AUTODETECT
 Twingo II	ENGINE MANAGEME	1.2 16v Turbo 74kw D4F-780	EOBD
 Twingo II	ENGINE MANAGEME	1.2 40kw	AUTODETECT
 Twingo II	ENGINE MANAGEME	1.2 43kw	AUTODETECT
 Twingo II	ENGINE MANAGEME	1.2 43kw D7F-800	SIEMENS SIM 32
 Twingo II	ENGINE MANAGEME	1.2 44kw	AUTODETECT
 Twingo II	ENGINE MANAGEME	1.5 dCi 48kw	AUTODETECT
 Twingo II	ENGINE MANAGEME	1.5 DCI 8v Turbo 62kw K9K-718	EOBD
 Twingo II	ENGINE MANAGEME	1.6 RS 16v 98kw K4M-854	EOBD
 Twingo II	MAINTENANCE	1.2 16v 56kw	ESP
 Twingo II	MAINTENANCE	1.2 16v 56kw	ESP
 Twingo II	MAINTENANCE	1.2 16v 56kw	ESP
 Twingo II	MAINTENANCE	1.2 16v 56kw	ESP
 Twingo II	MAINTENANCE	1.2 16v 56kw	KOYO EPS
 Twingo II	MAINTENANCE	1.2 16v 56kw	KOYO EPS
 Twingo II	MAINTENANCE	1.2 16v 56kw	KOYO EPS
 Twingo II	MAINTENANCE	1.2 16v Turbo 74kw	ESP

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Twingo II	MAINTENANCE	1.2 16v Turbo 74kw	ESP
 Twingo II	MAINTENANCE	1.2 16v Turbo 74kw	ESP
 Twingo II	MAINTENANCE	1.2 16v Turbo 74kw	ESP
 Twingo II	MAINTENANCE	1.2 16v Turbo 74kw	ESP
 Twingo II	MAINTENANCE	1.2 16v Turbo 74kw	KOYO EPS
 Twingo II	MAINTENANCE	1.2 16v Turbo 74kw	KOYO EPS
 Twingo II	MAINTENANCE	1.2 16v Turbo 74kw	KOYO EPS
 Twingo II	MAINTENANCE	1.2 43kw	ESP
 Twingo II	MAINTENANCE	1.2 43kw	ESP
 Twingo II	MAINTENANCE	1.2 43kw	ESP
 Twingo II	MAINTENANCE	1.2 43kw	ESP
 Twingo II	MAINTENANCE	1.2 43kw	KOYO EPS
 Twingo II	MAINTENANCE	1.2 43kw	KOYO EPS
 Twingo II	MAINTENANCE	1.2 43kw	KOYO EPS
 Twingo II	MAINTENANCE	1.5 dCi 48kw	ESP
 Twingo II	MAINTENANCE	1.5 dCi 48kw	ESP
 Twingo II	MAINTENANCE	1.5 dCi 48kw	ESP
 Twingo II	MAINTENANCE	1.5 dCi 48kw	ESP
 Twingo II	MAINTENANCE	1.5 dCi 48kw	KOYO EPS
 Twingo II	MAINTENANCE	1.5 dCi 48kw	KOYO EPS
 Twingo II	MAINTENANCE	1.5 dCi 48kw	KOYO EPS
 Twingo II	MAINTENANCE	1.5 DCI 8v Turbo 62kw	ESP
 Twingo II	MAINTENANCE	1.5 DCI 8v Turbo 62kw	ESP
 Twingo II	MAINTENANCE	1.5 DCI 8v Turbo 62kw	ESP
 Twingo II	MAINTENANCE	1.5 DCI 8v Turbo 62kw	ESP
 Twingo II	MAINTENANCE	1.5 DCI 8v Turbo 62kw	ESP
 Twingo II	MAINTENANCE	1.5 DCI 8v Turbo 62kw	KOYO EPS
 Twingo II	MAINTENANCE	1.5 DCI 8v Turbo 62kw	KOYO EPS
 Twingo II	MAINTENANCE	1.5 DCI 8v Turbo 62kw	KOYO EPS
 Twingo II	MAINTENANCE	1.6 RS 16v 98kw	ESP
 Twingo II	MAINTENANCE	1.6 RS 16v 98kw	ESP
 Twingo II	MAINTENANCE	1.6 RS 16v 98kw	ESP
 Twingo II	MAINTENANCE	1.6 RS 16v 98kw	ESP
 Twingo II	MAINTENANCE	1.6 RS 16v 98kw	ESP
 Twingo II	MAINTENANCE	1.6 RS 16v 98kw	KOYO EPS
 Twingo II	MAINTENANCE	1.6 RS 16v 98kw	KOYO EPS
 Twingo II	MAINTENANCE	1.6 RS 16v 98kw	KOYO EPS
 Twingo II	PARKING HELP	1.2 16v 56kw	AUTODETECT
 Twingo II	PARKING HELP	1.2 16v 56kw	AUTODETECT
 Twingo II	PARKING HELP	1.2 40kw	AUTODETECT
 Twingo II	PARKING HELP	1.2 43kw	AUTODETECT
 Twingo II	PARKING HELP	1.2 44kw	AUTODETECT
 Twingo II	PARKING HELP	1.5 dCi 48kw	AUTODETECT
 Twingo ph2	ENGINE MANAGEME	1.2 16v 55kw (07-..)	AUTODETECT
 Twingo ph2	ENGINE MANAGEME	1.2 16v 74kw (07-..)	AUTODETECT
 Twingo ph2	ENGINE MANAGEME	1.5 dCi 59kw (07-..)	AUTODETECT
 Twingo ph2	ENGINE MANAGEME	1.6 16v 94kw (07-..)	AUTODETECT
 Twingo	ABS	1.2 16v 55kw	BOSCH ABS 5.3
 Twingo	ABS	1.2 16v 55kw	BOSCH ABS 5.3 T
 Twingo	ABS	1.2 40kw	BOSCH ABS 5.3
 Twingo	ABS	1.2 40kw	BOSCH ABS 5.3 T
 Twingo	ABS	1.2 44kw	BOSCH ABS 5.3
 Twingo	ABS	1.2 44kw	BOSCH ABS 5.3 T
 Twingo	AIRBAG	1.2 16v 55kw	SIEMENS - Autoliv AirBag AC4
 Twingo	AIRBAG	1.2 16v 55kw	SIEMENS - Autoliv AirBag AC6
 Twingo	AIRBAG	1.2 16v 55kw	SIEMENS - Autoliv AirBag EC5

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Twingo	AIRBAG	1.2 16v 55kw (01-..)	SAGEM - Autoliv AirBag ACU 3.8
 Twingo	AIRBAG	1.2 40kw	SIEMENS - Autoliv AirBag AC4
 Twingo	AIRBAG	1.2 40kw	SIEMENS - Autoliv AirBag AC6
 Twingo	AIRBAG	1.2 40kw	SIEMENS - Autoliv AirBag EC5
 Twingo	AIRBAG	1.2 40kw (01-..)	SAGEM - Autoliv AirBag ACU 3.8
 Twingo	AIRBAG	1.2 44kw	SIEMENS - Autoliv AirBag AC4
 Twingo	AIRBAG	1.2 44kw	SIEMENS - Autoliv AirBag AC6
 Twingo	AIRBAG	1.2 44kw	SIEMENS - Autoliv AirBag EC5
 Twingo	AIRBAG	1.2 44kw (01-..)	SAGEM - Autoliv AirBag ACU 3.8
 Twingo	ENGINE MANAGEME	1.2 16v 55kw	AUTODETECT
 Twingo	ENGINE MANAGEME	1.2 16v 55kw D4F-702	Marelli IAW 5NR
 Twingo	ENGINE MANAGEME	1.2 16v 55kw D4F-702 (01-..)	EOBD
 Twingo	ENGINE MANAGEME	1.2 16v 55kw D4F-708	Marelli IAW 5NR
 Twingo	ENGINE MANAGEME	1.2 16v 55kw D4F-708 (01-..)	EOBD
 Twingo	ENGINE MANAGEME	1.2 40kw	AUTODETECT
 Twingo	ENGINE MANAGEME	1.2 40kw C3G-700	Marelli IAW 6R
 Twingo	ENGINE MANAGEME	1.2 40kw C3G-700	Marelli IAW 6R
 Twingo	ENGINE MANAGEME	1.2 40kw C3G-700	Marelli IAW 6R
 Twingo	ENGINE MANAGEME	1.2 40kw C3G-700	Marelli IAW 6R
 Twingo	ENGINE MANAGEME	1.2 40kw C3G-700	Marelli IAW 6R
 Twingo	ENGINE MANAGEME	1.2 40kw C3G-700	Marelli IAW 6R
 Twingo	ENGINE MANAGEME	1.2 40kw C3G-700	Marelli IAW 6R
 Twingo	ENGINE MANAGEME	1.2 40kw C3G-700	Marelli IAW 6R
 Twingo	ENGINE MANAGEME	1.2 40kw C3G-700	Marelli IAW 6R
 Twingo	ENGINE MANAGEME	1.2 40kw C3G-700	Marelli IAW 6R
 Twingo	ENGINE MANAGEME	1.2 40kw C3G-702	AUTODETECT
 Twingo	ENGINE MANAGEME	1.2 40kw C3G-702	Marelli IAW 6R
 Twingo	ENGINE MANAGEME	1.2 40kw C3G-702	Marelli IAW 6R
 Twingo	ENGINE MANAGEME	1.2 40kw C3G-702	Marelli IAW 6R
 Twingo	ENGINE MANAGEME	1.2 40kw C3G-702	Marelli IAW 6R
 Twingo	ENGINE MANAGEME	1.2 40kw C3G-702	Marelli IAW 6R
 Twingo	ENGINE MANAGEME	1.2 40kw C3G-702	Marelli IAW 6R
 Twingo	ENGINE MANAGEME	1.2 40kw D7F-700	AUTODETECT
 Twingo	ENGINE MANAGEME	1.2 40kw D7F-700	SAGEM SAFIR MPI
 Twingo	ENGINE MANAGEME	1.2 40kw D7F-700	SAGEM SAFIR MPI
 Twingo	ENGINE MANAGEME	1.2 40kw D7F-700	SAGEM SAFIR MPI
 Twingo	ENGINE MANAGEME	1.2 40kw D7F-700	SAGEM SAFIR MPI
 Twingo	ENGINE MANAGEME	1.2 40kw D7F-700	SAGEM SAFIR MPI
 Twingo	ENGINE MANAGEME	1.2 40kw D7F-700	SAGEM SAFIR MPI
 Twingo	ENGINE MANAGEME	1.2 40kw D7F-700	SAGEM SAFIR MPI
 Twingo	ENGINE MANAGEME	1.2 40kw D7F-700	SAGEM SAFIR MPI
 Twingo	ENGINE MANAGEME	1.2 40kw D7F-700	SAGEM SAFIR MPI
 Twingo	ENGINE MANAGEME	1.2 40kw D7F-700	SAGEM SAFIR MPI
 Twingo	ENGINE MANAGEME	1.2 40kw D7F-700	SAGEM SAFIR MPI
 Twingo	ENGINE MANAGEME	1.2 40kw D7F-700	SAGEM SAFIR MPI
 Twingo	ENGINE MANAGEME	1.2 40kw D7F-701	AUTODETECT
 Twingo	ENGINE MANAGEME	1.2 40kw D7F-701	SAGEM SAFIR MPI
 Twingo	ENGINE MANAGEME	1.2 40kw D7F-701	SAGEM SAFIR MPI
 Twingo	ENGINE MANAGEME	1.2 40kw D7F-701	SAGEM SAFIR MPI
 Twingo	ENGINE MANAGEME	1.2 40kw D7F-701	SAGEM SAFIR MPI
 Twingo	ENGINE MANAGEME	1.2 44kw	AUTODETECT
 Twingo	ENGINE MANAGEME	1.2 44kw D7F-700	SAGEM SAFIR MPI
 Twingo	ENGINE MANAGEME	1.2 44kw D7F-700	SAGEM SAFIR MPI
 Twingo	ENGINE MANAGEME	1.2 44kw D7F-700	SAGEM SAFIR MPI
 Twingo	ENGINE MANAGEME	1.2 44kw D7F-700	SAGEM SAFIR MPI
 Twingo	ENGINE MANAGEME	1.2 44kw D7F-700	SAGEM SAFIR MPI

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Twingo	ENGINE MANAGEME	1.2 44kw D7F-700	SAGEM SAFIR MPI
 Twingo	ENGINE MANAGEME	1.2 44kw D7F-700	SAGEM SAFIR MPI
 Twingo	ENGINE MANAGEME	1.2 44kw D7F-700	SAGEM SAFIR MPI
 Twingo	ENGINE MANAGEME	1.2 44kw D7F-700	SAGEM SAFIR MPI
 Twingo	ENGINE MANAGEME	1.2 44kw D7F-700	SAGEM SAFIR MPI
 Twingo	ENGINE MANAGEME	1.2 44kw D7F-700	SAGEM SAFIR MPI
 Twingo	ENGINE MANAGEME	1.2 44kw D7F-700	SAGEM SAFIR MPI
 Twingo	ENGINE MANAGEME	1.2 44kw D7F-701	SAGEM SAFIR MPI
 Twingo	ENGINE MANAGEME	1.2 44kw D7F-701	SAGEM SAFIR MPI
 Twingo	ENGINE MANAGEME	1.2 44kw D7F-701	SAGEM SAFIR MPI
 Twingo	ENGINE MANAGEME	1.2 44kw D7F-701	SAGEM SAFIR MPI
 Twingo	ENGINE MANAGEME	1.2 44kw D7F-703	SAGEM SAFIR MPI
 Twingo	ENGINE MANAGEME	1.2 44kw D7F-703	SIEMENS Sirius 32
 Vel Satis ph2	ABS	2.0 16v dCi FAP 110kw (05-..)	AUTODETECT
 Vel Satis ph2	ABS	2.0 16v dCi FAP 127kw (05-..)	AUTODETECT
 Vel Satis ph2	ABS	2.0 T 16v 121kw (05-..)	AUTODETECT
 Vel Satis ph2	ABS	2.2 16v dCi 110kw (05-..)	AUTODETECT
 Vel Satis ph2	ABS	2.2 16v dCi 83kw (05-..)	AUTODETECT
 Vel Satis ph2	ABS	2.2 16v dCi FAP 102kw (05-..)	AUTODETECT
 Vel Satis ph2	ABS	2.2 16v dCi FAP 78kw (05-..)	AUTODETECT
 Vel Satis ph2	ABS	3.0 V6 24v dCi 130kw (05-..)	AUTODETECT
 Vel Satis ph2	ABS	3.0 V6 24v dCi 133kw (05-..)	AUTODETECT
 Vel Satis ph2	ABS	3.5 V6 24v 177kw (05-..)	AUTODETECT
 Vel Satis ph2	AIRBAG	2.0 16v dCi FAP 110kw (05-..)	AUTODETECT
 Vel Satis ph2	AIRBAG	2.0 16v dCi FAP 127kw (05-..)	AUTODETECT
 Vel Satis ph2	AIRBAG	2.0 T 16v 121kw (05-..)	AUTODETECT
 Vel Satis ph2	AIRBAG	2.2 16v dCi 110kw (05-..)	AUTODETECT
 Vel Satis ph2	AIRBAG	2.2 16v dCi 83kw (05-..)	AUTODETECT
 Vel Satis ph2	AIRBAG	2.2 16v dCi FAP 102kw (05-..)	AUTODETECT
 Vel Satis ph2	AIRBAG	2.2 16v dCi FAP 78kw (05-..)	AUTODETECT
 Vel Satis ph2	AIRBAG	3.0 V6 24v dCi 130kw (05-..)	AUTODETECT
 Vel Satis ph2	AIRBAG	3.0 V6 24v dCi 133kw (05-..)	AUTODETECT
 Vel Satis ph2	AIRBAG	3.5 V6 24v 177kw (05-..)	AUTODETECT
 Vel Satis ph2	AUTOM. TRANSMISSI	2.0 16v dCi FAP 110kw (05-..)	AUTODETECT
 Vel Satis ph2	AUTOM. TRANSMISSI	2.0 16v dCi FAP 127kw (05-..)	AUTODETECT
 Vel Satis ph2	AUTOM. TRANSMISSI	2.0 T 16v 121kw (05-..)	AUTODETECT
 Vel Satis ph2	AUTOM. TRANSMISSI	2.2 16v dCi 110kw (05-..)	AUTODETECT
 Vel Satis ph2	AUTOM. TRANSMISSI	2.2 16v dCi 83kw (05-..)	AUTODETECT
 Vel Satis ph2	AUTOM. TRANSMISSI	2.2 16v dCi FAP 102kw (05-..)	AUTODETECT
 Vel Satis ph2	AUTOM. TRANSMISSI	2.2 16v dCi FAP 78kw (05-..)	AUTODETECT
 Vel Satis ph2	AUTOM. TRANSMISSI	3.0 V6 24v dCi 130kw (05-..)	AUTODETECT
 Vel Satis ph2	AUTOM. TRANSMISSI	3.0 V6 24v dCi 133kw (05-..)	AUTODETECT
 Vel Satis ph2	AUTOM. TRANSMISSI	3.5 V6 24v 177kw (05-..)	AUTODETECT
 Vel Satis ph2	CHASSIS NETWORK	2.0 16v dCi FAP 110kw (05-..)	UCC AUTODETECT
 Vel Satis ph2	CHASSIS NETWORK	2.0 16v dCi FAP 127kw (05-..)	UCC AUTODETECT
 Vel Satis ph2	CHASSIS NETWORK	2.0 T 16v 121kw (05-..)	UCC AUTODETECT
 Vel Satis ph2	CHASSIS NETWORK	2.2 16v dCi 110kw (05-..)	UCC AUTODETECT
 Vel Satis ph2	CHASSIS NETWORK	2.2 16v dCi 83kw (05-..)	UCC AUTODETECT
 Vel Satis ph2	CHASSIS NETWORK	2.2 16v dCi FAP 102kw (05-..)	UCC AUTODETECT
 Vel Satis ph2	CHASSIS NETWORK	2.2 16v dCi FAP 78kw (05-..)	UCC AUTODETECT
 Vel Satis ph2	CHASSIS NETWORK	3.0 V6 24v dCi 130kw (05-..)	UCC AUTODETECT
 Vel Satis ph2	CHASSIS NETWORK	3.0 V6 24v dCi 133kw (05-..)	UCC AUTODETECT
 Vel Satis ph2	CHASSIS NETWORK	3.5 V6 24v 177kw (05-..)	UCC AUTODETECT
 Vel Satis ph2	CLIMA	2.0 16v dCi FAP 110kw (05-..)	AUTODETECT
 Vel Satis ph2	CLIMA	2.0 16v dCi FAP 127kw (05-..)	AUTODETECT
 Vel Satis ph2	CLIMA	2.0 T 16v 121kw (05-..)	AUTODETECT
 Vel Satis ph2	CLIMA	2.2 16v dCi 110kw (05-..)	AUTODETECT
 Vel Satis ph2	CLIMA	2.2 16v dCi 83kw (05-..)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Vel Satis ph2	CLIMA	2.2 16v dCi FAP 102kw (05-..)	AUTODETECT
 Vel Satis ph2	CLIMA	2.2 16v dCi FAP 78kw (05-..)	AUTODETECT
 Vel Satis ph2	CLIMA	3.0 V6 24v dCi 130kw (05-..)	AUTODETECT
 Vel Satis ph2	CLIMA	3.0 V6 24v dCi 133kw (05-..)	AUTODETECT
 Vel Satis ph2	CLIMA	3.5 V6 24v 177kw (05-..)	AUTODETECT
 Vel Satis ph2	DASHBOARD	2.0 16v dCi FAP 110kw (05-..)	AUTODETECT
 Vel Satis ph2	DASHBOARD	2.0 16v dCi FAP 127kw (05-..)	AUTODETECT
 Vel Satis ph2	DASHBOARD	2.0 T 16v 121kw (05-..)	AUTODETECT
 Vel Satis ph2	DASHBOARD	2.2 16v dCi 110kw (05-..)	AUTODETECT
 Vel Satis ph2	DASHBOARD	2.2 16v dCi 83kw (05-..)	AUTODETECT
 Vel Satis ph2	DASHBOARD	2.2 16v dCi FAP 102kw (05-..)	AUTODETECT
 Vel Satis ph2	DASHBOARD	2.2 16v dCi FAP 78kw (05-..)	AUTODETECT
 Vel Satis ph2	DASHBOARD	3.0 V6 24v dCi 130kw (05-..)	AUTODETECT
 Vel Satis ph2	DASHBOARD	3.0 V6 24v dCi 133kw (05-..)	AUTODETECT
 Vel Satis ph2	DASHBOARD	3.5 V6 24v 177kw (05-..)	AUTODETECT
 Vel Satis ph2	ENGINE MANAGEME	2.0 16v dCi FAP 110kw M9R-760 (05-..)	AUTODETECT
 Vel Satis ph2	ENGINE MANAGEME	2.0 16v dCi FAP 110kw M9R-762 (05-..)	AUTODETECT
 Vel Satis ph2	ENGINE MANAGEME	2.0 16v dCi FAP 127kw M9R-760 (05-..)	AUTODETECT
 Vel Satis ph2	ENGINE MANAGEME	2.0 16v dCi FAP 127kw M9R-762 (05-..)	AUTODETECT
 Vel Satis ph2	ENGINE MANAGEME	2.0 16v dCi FAP 127kw M9R-763 (05-..)	AUTODETECT
 Vel Satis ph2	ENGINE MANAGEME	2.0 T 16v 121kw F4R-762 (05-..)	AUTODETECT
 Vel Satis ph2	ENGINE MANAGEME	2.0 T 16v 121kw F4R-763 (05-..)	AUTODETECT
 Vel Satis ph2	ENGINE MANAGEME	2.2 16v dCi 110kw G9T-702 (05-..)	AUTODETECT
 Vel Satis ph2	ENGINE MANAGEME	2.2 16v dCi 110kw G9T-703 (05-..)	AUTODETECT
 Vel Satis ph2	ENGINE MANAGEME	2.2 16v dCi 83kw G9T-702 (05-..)	AUTODETECT
 Vel Satis ph2	ENGINE MANAGEME	2.2 16v dCi FAP 102kw G9T-605 (05-..)	AUTODETECT
 Vel Satis ph2	ENGINE MANAGEME	2.2 16v dCi FAP 102kw G9T-610 (05-..)	AUTODETECT
 Vel Satis ph2	ENGINE MANAGEME	2.2 16v dCi FAP 78kw G9T-610 (05-..)	AUTODETECT
 Vel Satis ph2	ENGINE MANAGEME	3.0 V6 24v dCi 130kw P9X-701 (05-..)	AUTODETECT
 Vel Satis ph2	ENGINE MANAGEME	3.5 V6 24v 177kw V4Y-701 (05-..)	AUTODETECT
 Vel Satis ph2	HEADLIGHT LEVEL	2.0 16v dCi FAP 110kw (05-..)	can AUTODETECT
 Vel Satis ph2	HEADLIGHT LEVEL	2.0 16v dCi FAP 127kw (05-..)	can AUTODETECT
 Vel Satis ph2	HEADLIGHT LEVEL	2.0 T 16v 121kw (05-..)	can AUTODETECT
 Vel Satis ph2	HEADLIGHT LEVEL	2.2 16v dCi 110kw (05-..)	can AUTODETECT
 Vel Satis ph2	HEADLIGHT LEVEL	2.2 16v dCi 83kw (05-..)	can AUTODETECT
 Vel Satis ph2	HEADLIGHT LEVEL	2.2 16v dCi FAP 102kw (05-..)	can AUTODETECT
 Vel Satis ph2	HEADLIGHT LEVEL	2.2 16v dCi FAP 78kw (05-..)	can AUTODETECT
 Vel Satis ph2	HEADLIGHT LEVEL	3.0 V6 24v dCi 130kw (05-..)	can AUTODETECT
 Vel Satis ph2	HEADLIGHT LEVEL	3.0 V6 24v dCi 133kw (05-..)	can AUTODETECT
 Vel Satis ph2	HEADLIGHT LEVEL	3.5 V6 24v 177kw (05-..)	can AUTODETECT
 Vel Satis ph2	PARK.BRAKE	2.0 16v dCi FAP 110kw (05-..)	Electrobrake AUTODETECT
 Vel Satis ph2	PARK.BRAKE	2.0 16v dCi FAP 127kw (05-..)	Electrobrake AUTODETECT
 Vel Satis ph2	PARK.BRAKE	2.0 T 16v 121kw (05-..)	Electrobrake AUTODETECT
 Vel Satis ph2	PARK.BRAKE	2.2 16v dCi 110kw (05-..)	Electrobrake AUTODETECT
 Vel Satis ph2	PARK.BRAKE	2.2 16v dCi 83kw (05-..)	Electrobrake AUTODETECT
 Vel Satis ph2	PARK.BRAKE	2.2 16v dCi FAP 102kw (05-..)	Electrobrake AUTODETECT
 Vel Satis ph2	PARK.BRAKE	2.2 16v dCi FAP 78kw (05-..)	Electrobrake AUTODETECT
 Vel Satis ph2	PARK.BRAKE	3.0 V6 24v dCi 130kw (05-..)	Electrobrake AUTODETECT
 Vel Satis ph2	PARK.BRAKE	3.0 V6 24v dCi 133kw (05-..)	Electrobrake AUTODETECT
 Vel Satis ph2	PARK.BRAKE	3.5 V6 24v 177kw (05-..)	Electrobrake AUTODETECT
 Vel Satis ph2	PARKING HELP	2.0 16v dCi FAP 110kw (05-..)	AUTODETECT
 Vel Satis ph2	PARKING HELP	2.0 16v dCi FAP 110kw (05-..)	can AUTODETECT
 Vel Satis ph2	PARKING HELP	2.0 16v dCi FAP 127kw (05-..)	AUTODETECT
 Vel Satis ph2	PARKING HELP	2.0 16v dCi FAP 127kw (05-..)	can AUTODETECT
 Vel Satis ph2	PARKING HELP	2.0 T 16v 121kw (05-..)	AUTODETECT
 Vel Satis ph2	PARKING HELP	2.0 T 16v 121kw (05-..)	can AUTODETECT
 Vel Satis ph2	PARKING HELP	2.2 16v dCi 110kw (05-..)	AUTODETECT
 Vel Satis ph2	PARKING HELP	2.2 16v dCi 110kw (05-..)	can AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Vel Satis ph2	PARKING HELP	2.2 16v dCi 83kw (05-..)	AUTODETECT
 Vel Satis ph2	PARKING HELP	2.2 16v dCi 83kw (05-..)	can AUTODETECT
 Vel Satis ph2	PARKING HELP	2.2 16v dCi FAP 102kw (05-..)	AUTODETECT
 Vel Satis ph2	PARKING HELP	2.2 16v dCi FAP 102kw (05-..)	can AUTODETECT
 Vel Satis ph2	PARKING HELP	2.2 16v dCi FAP 78kw (05-..)	AUTODETECT
 Vel Satis ph2	PARKING HELP	2.2 16v dCi FAP 78kw (05-..)	can AUTODETECT
 Vel Satis ph2	PARKING HELP	3.0 V6 24v dCi 130kw (05-..)	AUTODETECT
 Vel Satis ph2	PARKING HELP	3.0 V6 24v dCi 130kw (05-..)	can AUTODETECT
 Vel Satis ph2	PARKING HELP	3.0 V6 24v dCi 133kw (05-..)	AUTODETECT
 Vel Satis ph2	PARKING HELP	3.0 V6 24v dCi 133kw (05-..)	can AUTODETECT
 Vel Satis ph2	PARKING HELP	3.5 V6 24v 177kw (05-..)	AUTODETECT
 Vel Satis ph2	STEERING WHEEL E	2.0 16v dCi FAP 110kw (05-..)	AUTODETECT
 Vel Satis ph2	STEERING WHEEL E	2.0 16v dCi FAP 127kw (05-..)	AUTODETECT
 Vel Satis ph2	STEERING WHEEL E	2.0 T 16v 121kw (05-..)	AUTODETECT
 Vel Satis ph2	STEERING WHEEL E	2.2 16v dCi 110kw (05-..)	AUTODETECT
 Vel Satis ph2	STEERING WHEEL E	2.2 16v dCi 83kw (05-..)	AUTODETECT
 Vel Satis ph2	STEERING WHEEL E	2.2 16v dCi FAP 102kw (05-..)	AUTODETECT
 Vel Satis ph2	STEERING WHEEL E	2.2 16v dCi FAP 78kw (05-..)	AUTODETECT
 Vel Satis ph2	STEERING WHEEL E	3.0 V6 24v dCi 130kw (05-..)	AUTODETECT
 Vel Satis ph2	STEERING WHEEL E	3.0 V6 24v dCi 133kw (05-..)	AUTODETECT
 Vel Satis ph2	STEERING WHEEL E	3.5 V6 24v 177kw (05-..)	AUTODETECT
 Vel Satis ph2	SUPP HEATER/AUTO	2.0 16v dCi FAP 110kw (05-..)	AUTODETECT
 Vel Satis ph2	SUPP HEATER/AUTO	2.0 16v dCi FAP 127kw (05-..)	AUTODETECT
 Vel Satis ph2	SUPP HEATER/AUTO	2.0 T 16v 121kw (05-..)	AUTODETECT
 Vel Satis ph2	SUPP HEATER/AUTO	2.2 16v dCi 110kw (05-..)	AUTODETECT
 Vel Satis ph2	SUPP HEATER/AUTO	2.2 16v dCi 83kw (05-..)	AUTODETECT
 Vel Satis ph2	SUPP HEATER/AUTO	2.2 16v dCi FAP 102kw (05-..)	AUTODETECT
 Vel Satis ph2	SUPP HEATER/AUTO	2.2 16v dCi FAP 78kw (05-..)	AUTODETECT
 Vel Satis ph2	SUPP HEATER/AUTO	3.0 V6 24v dCi 130kw (05-..)	AUTODETECT
 Vel Satis ph2	SUPP HEATER/AUTO	3.0 V6 24v dCi 133kw (05-..)	AUTODETECT
 Vel Satis ph2	SUPP HEATER/AUTO	3.5 V6 24v 177kw (05-..)	AUTODETECT
 Vel Satis	ABS	2.0 T 16v 121kw (02-05)	AUTODETECT
 Vel Satis	ABS	2.0 T 16v 125kw (02-05)	AUTODETECT
 Vel Satis	ABS	2.2 16v dCi 110kw (02-05)	AUTODETECT
 Vel Satis	ABS	2.2 16v dCi 83kw (02-05)	AUTODETECT
 Vel Satis	ABS	3.0 V6 24v dCi 130kw (02-05)	AUTODETECT
 Vel Satis	ABS	3.0 V6 24v dCi 133kw (02-05)	AUTODETECT
 Vel Satis	ABS	3.5 V6 24v 177kw (02-05)	AUTODETECT
 Vel Satis	AIRBAG	2.0 T 16v 121kw (02-05)	AUTODETECT
 Vel Satis	AIRBAG	2.0 T 16v 125kw (02-05)	AUTODETECT
 Vel Satis	AIRBAG	2.2 16v dCi 110kw (02-05)	AUTODETECT
 Vel Satis	AIRBAG	2.2 16v dCi 83kw (02-05)	AUTODETECT
 Vel Satis	AIRBAG	3.0 V6 24v dCi 130kw (02-05)	AUTODETECT
 Vel Satis	AIRBAG	3.0 V6 24v dCi 133kw (02-05)	AUTODETECT
 Vel Satis	AIRBAG	3.5 V6 24v 177kw (02-05)	AUTODETECT
 Vel Satis	AUTOM. TRANSMISSI	2.0 T 16v 121kw (02-05)	AUTODETECT
 Vel Satis	AUTOM. TRANSMISSI	2.0 T 16v 125kw (02-05)	AUTODETECT
 Vel Satis	AUTOM. TRANSMISSI	2.2 16v dCi 110kw (02-05)	AUTODETECT
 Vel Satis	AUTOM. TRANSMISSI	2.2 16v dCi 83kw (02-05)	AUTODETECT
 Vel Satis	AUTOM. TRANSMISSI	3.0 V6 24v dCi 130kw (02-05)	AUTODETECT
 Vel Satis	AUTOM. TRANSMISSI	3.0 V6 24v dCi 133kw (02-05)	AUTODETECT
 Vel Satis	AUTOM. TRANSMISSI	3.5 V6 24v 177kw (02-05)	AUTODETECT
 Vel Satis	CHASSIS NETWORK	2.0 T 16v 121kw (02-05)	UCH AUTODETECT
 Vel Satis	CHASSIS NETWORK	2.0 T 16v 125kw (02-05)	UCH AUTODETECT
 Vel Satis	CHASSIS NETWORK	2.2 16v dCi 110kw (02-05)	UCH AUTODETECT
 Vel Satis	CHASSIS NETWORK	2.2 16v dCi 83kw (02-05)	UCH AUTODETECT
 Vel Satis	CHASSIS NETWORK	3.0 V6 24v dCi 130kw (02-05)	UCH AUTODETECT
 Vel Satis	CHASSIS NETWORK	3.0 V6 24v dCi 133kw (02-05)	UCH AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Vel Satis	CHASSIS NETWORK	3.5 V6 24v 177kw (02-05)	UCH AUTODETECT
 Vel Satis	CLIMA	2.0 T 16v 121kw (02-05)	AUTODETECT
 Vel Satis	CLIMA	2.0 T 16v 125kw (02-05)	AUTODETECT
 Vel Satis	CLIMA	2.2 16v dCi 110kw (02-05)	AUTODETECT
 Vel Satis	CLIMA	2.2 16v dCi 83kw (02-05)	AUTODETECT
 Vel Satis	CLIMA	3.0 V6 24v dCi 130kw (02-05)	AUTODETECT
 Vel Satis	CLIMA	3.0 V6 24v dCi 133kw (02-05)	AUTODETECT
 Vel Satis	CLIMA	3.5 V6 24v 177kw (02-05)	AUTODETECT
 Vel Satis	CRUISE CONTROL	2.0 T 16v 121kw (02-05)	AUTODETECT
 Vel Satis	CRUISE CONTROL	2.0 T 16v 125kw (02-05)	AUTODETECT
 Vel Satis	CRUISE CONTROL	2.2 16v dCi 110kw (02-05)	AUTODETECT
 Vel Satis	CRUISE CONTROL	2.2 16v dCi 83kw (02-05)	AUTODETECT
 Vel Satis	CRUISE CONTROL	3.0 V6 24v dCi 130kw (02-05)	AUTODETECT
 Vel Satis	CRUISE CONTROL	3.0 V6 24v dCi 133kw (02-05)	AUTODETECT
 Vel Satis	CRUISE CONTROL	3.5 V6 24v 177kw (02-05)	AUTODETECT
 Vel Satis	DASHBOARD	2.0 T 16v 121kw (02-05)	AUTODETECT
 Vel Satis	DASHBOARD	2.0 T 16v 125kw (02-05)	AUTODETECT
 Vel Satis	DASHBOARD	2.2 16v dCi 110kw (02-05)	AUTODETECT
 Vel Satis	DASHBOARD	2.2 16v dCi 83kw (02-05)	AUTODETECT
 Vel Satis	DASHBOARD	3.0 V6 24v dCi 130kw (02-05)	AUTODETECT
 Vel Satis	DASHBOARD	3.0 V6 24v dCi 133kw (02-05)	AUTODETECT
 Vel Satis	DASHBOARD	3.5 V6 24v 177kw (02-05)	AUTODETECT
 Vel Satis	ENGINE MANAGEME	2.0 T 16v 121kw F4R-762 (02-05)	AUTODETECT
 Vel Satis	ENGINE MANAGEME	2.0 T 16v 121kw F4R-763 (02-05)	AUTODETECT
 Vel Satis	ENGINE MANAGEME	2.0 T 16v 125kw F4R-762 (02-05)	AUTODETECT
 Vel Satis	ENGINE MANAGEME	2.0 T 16v 125kw F4R-763 (02-05)	AUTODETECT
 Vel Satis	ENGINE MANAGEME	2.2 16v dCi 110kw G9T-702 (02-05)	AUTODETECT
 Vel Satis	ENGINE MANAGEME	2.2 16v dCi 110kw G9T-703 (02-05)	AUTODETECT
 Vel Satis	ENGINE MANAGEME	2.2 16v dCi 83kw G9T-702 (02-05)	AUTODETECT
 Vel Satis	ENGINE MANAGEME	2.2 16v dCi 83kw G9T-702 (02-05)	BOSCH EDC 15 C3 Common Rail
 Vel Satis	ENGINE MANAGEME	3.0 V6 24v dCi 130kw P9X-701 (02-05)	AUTODETECT
 Vel Satis	ENGINE MANAGEME	3.0 V6 24v dCi 133kw (04-..)	EOBD
 Vel Satis	ENGINE MANAGEME	3.5 V6 24v 177kw V4Y-701 (02-05)	AUTODETECT
 Vel Satis	HEADLIGHT LEVEL	2.0 T 16v 121kw (02-05)	AUTODETECT
 Vel Satis	HEADLIGHT LEVEL	2.0 T 16v 125kw (02-05)	AUTODETECT
 Vel Satis	HEADLIGHT LEVEL	2.2 16v dCi 110kw (02-05)	AUTODETECT
 Vel Satis	HEADLIGHT LEVEL	2.2 16v dCi 83kw (02-05)	AUTODETECT
 Vel Satis	HEADLIGHT LEVEL	3.0 V6 24v dCi 130kw (02-05)	AUTODETECT
 Vel Satis	HEADLIGHT LEVEL	3.0 V6 24v dCi 133kw (02-05)	AUTODETECT
 Vel Satis	HEADLIGHT LEVEL	3.5 V6 24v 177kw (02-05)	AUTODETECT
 Vel Satis	PARK.BRAKE	2.0 T 16v 121kw (02-05)	Electrobrake AUTODETECT
 Vel Satis	PARK.BRAKE	2.0 T 16v 125kw (02-05)	Electrobrake AUTODETECT
 Vel Satis	PARK.BRAKE	2.2 16v dCi 110kw (02-05)	Electrobrake AUTODETECT
 Vel Satis	PARK.BRAKE	2.2 16v dCi 83kw (02-05)	Electrobrake AUTODETECT
 Vel Satis	PARK.BRAKE	3.0 V6 24v dCi 130kw (02-05)	Electrobrake AUTODETECT
 Vel Satis	PARK.BRAKE	3.0 V6 24v dCi 133kw (02-05)	Electrobrake AUTODETECT
 Vel Satis	PARK.BRAKE	3.5 V6 24v 177kw (02-05)	Electrobrake AUTODETECT
 Vel Satis	PARKING HELP	2.0 T 16v 121kw (02-05)	AUTODETECT
 Vel Satis	PARKING HELP	2.0 T 16v 125kw (02-05)	AUTODETECT
 Vel Satis	PARKING HELP	2.2 16v dCi 110kw (02-05)	AUTODETECT
 Vel Satis	PARKING HELP	2.2 16v dCi 83kw (02-05)	AUTODETECT
 Vel Satis	PARKING HELP	3.0 V6 24v dCi 130kw (02-05)	AUTODETECT
 Vel Satis	PARKING HELP	3.0 V6 24v dCi 133kw (02-05)	AUTODETECT
 Vel Satis	PARKING HELP	3.5 V6 24v 177kw (02-05)	AUTODETECT
 Vel Satis	STEERING WHEEL E	2.0 16v dCi FAP 110kw (05-..)	AUTODETECT
 Vel Satis	STEERING WHEEL E	2.0 16v dCi FAP 127kw (05-..)	AUTODETECT
 Vel Satis	STEERING WHEEL E	2.0 T 16v 121kw (05-..)	AUTODETECT
 Vel Satis	STEERING WHEEL E	2.2 16v dCi 110kw (05-..)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Vel Satis	STEERING WHEEL E	2.2 16v dCi 83kw (05-..)	AUTODETECT
 Vel Satis	STEERING WHEEL E	2.2 16v dCi FAP 102kw (05-..)	AUTODETECT
 Vel Satis	STEERING WHEEL E	2.2 16v dCi FAP 78kw (05-..)	AUTODETECT
 Vel Satis	STEERING WHEEL E	3.0 V6 24v dCi 130kw (05-..)	AUTODETECT
 Vel Satis	STEERING WHEEL E	3.0 V6 24v dCi 133kw (05-..)	AUTODETECT
 Vel Satis	STEERING WHEEL E	3.5 V6 24v 177kw (05-..)	AUTODETECT
 Vel Satis	SUPP HEATER/AUTO	2.0 T 16v 121kw (02-05)	AUTODETECT
 Vel Satis	SUPP HEATER/AUTO	2.0 T 16v 125kw (02-05)	AUTODETECT
 Vel Satis	SUPP HEATER/AUTO	2.2 16v dCi 110kw (02-05)	AUTODETECT
 Vel Satis	SUPP HEATER/AUTO	2.2 16v dCi 83kw (02-05)	AUTODETECT
 Vel Satis	SUPP HEATER/AUTO	3.0 V6 24v dCi 130kw (02-05)	AUTODETECT
 Vel Satis	SUPP HEATER/AUTO	3.0 V6 24v dCi 133kw (02-05)	AUTODETECT
 Vel Satis	SUPP HEATER/AUTO	3.5 V6 24v 177kw (02-05)	AUTODETECT
 Vel Satis	TIRE PRESSURE	2.0 T 16v 121kw (02-05)	AUTODETECT
 Vel Satis	TIRE PRESSURE	2.0 T 16v 125kw (02-05)	AUTODETECT
 Vel Satis	TIRE PRESSURE	2.2 16v dCi 110kw (02-05)	AUTODETECT
 Vel Satis	TIRE PRESSURE	2.2 16v dCi 83kw (02-05)	AUTODETECT
 Vel Satis	TIRE PRESSURE	3.0 V6 24v dCi 130kw (02-05)	AUTODETECT
 Vel Satis	TIRE PRESSURE	3.0 V6 24v dCi 133kw (02-05)	AUTODETECT
 Vel Satis	TIRE PRESSURE	3.5 V6 24v 177kw (02-05)	AUTODETECT

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Rover

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 100	ENGINE MANAGEME	(..-5/96)	ROVER MEMS 1.6 mpi
 100	ENGINE MANAGEME	(..-5/96)	ROVER MEMS 1.6 spi (no kat)
 100	ENGINE MANAGEME	(5/96-99)	ROVER MEMS 1.9
 200 New	ENGINE MANAGEME	K series (95-99)	ROVER MEMS 1.9 mpi
 200	ENGINE MANAGEME	K series (..-96)	ROVER MEMS 1.6 mpi
 200	ENGINE MANAGEME	K series (..-96)	ROVER MEMS 1.6 spi (kat)
 200	ENGINE MANAGEME	K series (95-99)	ROVER MEMS 1.9 mpi
 200	ENGINE MANAGEME	T series (..-96)	ROVER MEMS 1.6 seq. mpi
 214	ENGINE MANAGEME	1.4 (..-93)	ROVER MEMS 1.4
 214	ENGINE MANAGEME	1.4 (..-93)	ROVER MEMS 2.0
 25	ENGINE MANAGEME	1.4 (01-..)	ROVER MEMS 3 EOBD
 25	ENGINE MANAGEME	1.4 (03-03)	Motorola MEMS 3
 25	MAINTENANCE	1.4 (03-03)	Motorola MEMS 3
 400 New	ENGINE MANAGEME	K series (95-99)	ROVER MEMS 1.9 mpi
 400 New	ENGINE MANAGEME	T series (95-99)	ROVER MEMS 1.9 mpi
 400	ENGINE MANAGEME	K series (..-96)	ROVER MEMS 1.6 mpi
 400	ENGINE MANAGEME	K series (..-96)	ROVER MEMS 1.6 spi (kat)
 400	ENGINE MANAGEME	K series (..-96)	ROVER MEMS 1.9 mpi
 400	ENGINE MANAGEME	T series (..-96)	ROVER MEMS 1.6 seq. mpi
 414	ENGINE MANAGEME	1.4 (..-93)	ROVER MEMS 1.4
 414	ENGINE MANAGEME	1.4 (..-93)	ROVER MEMS 2.0
 45	ENGINE MANAGEME	(01-..)	ROVER MEMS 3 EOBD
 600 New	ENGINE MANAGEME	T series (95-99)	ROVER MEMS 1.9 mpi
 600	ENGINE MANAGEME	T series (..-96)	ROVER MEMS 1.6 seq. mpi
 75	ABS	1.8	ABS TCS
 75	ABS	2.0 CDTI	ABS TCS
 75	ABS	2.5 V6	ABS TCS
 75	AIRBAG	1.8	TEMIC AirBag
 75	AIRBAG	2.0 CDTI	TEMIC AirBag
 75	AIRBAG	2.5 V6	TEMIC AirBag
 75	ENGINE MANAGEME	1.8 (01-..)	ROVER MEMS 3 EOBD
 75	ENGINE MANAGEME	2.0 CDTI	BOSCH ED 15 C4 DDE 4.0 Common Rail
 75	ENGINE MANAGEME	2.0 CDTI (01-..)	ROVER MEMS 3 EOBD
 75	ENGINE MANAGEME	2.5 V6	EMS 2000
 75	ENGINE MANAGEME	2.5 V6 (01-..)	ROVER MEMS 3 EOBD
 75	MAINTENANCE	1.8	MANUAL
 75	MAINTENANCE	2.0 CDTI	MANUAL
 75	MAINTENANCE	2.5 V6	MANUAL
 75	SERVICE LIGHT RES	1.8	MANUAL
 75	SERVICE LIGHT RES	2.0 CDTI	MANUAL
 75	SERVICE LIGHT RES	2.5 V6	MANUAL
 800	ENGINE MANAGEME	(..-93)	ROVER MEMS 1.6 mpi
 800	ENGINE MANAGEME	(94-95)	ROVER MEMS 1.6 mpi
 800	ENGINE MANAGEME	(95-99)	ROVER MEMS 1.9
 820	ENGINE MANAGEME	(..-93)	ROVER MEMS 1.4
 820	ENGINE MANAGEME	(..-93)	ROVER MEMS 2.0
 Maestro	ELECTRONIC IGNITI	2.0 T MG (..-93)	ROVER ERIC
 Metro	ENGINE MANAGEME	(..-93)	ROVER MEMS 1.4
 Metro	ENGINE MANAGEME	(..-95)	ROVER MEMS 1.6 mpi
 Metro	ENGINE MANAGEME	(..-95)	ROVER MEMS 1.6 spi (no kat)
 Metro	ENGINE MANAGEME	(5/96-99)	ROVER MEMS 1.9
 MG ZR 160	ENGINE MANAGEME	1.8 VVC K-serie (01-..)	EOBD
 MG ZS 180	ENGINE MANAGEME	2.5 KV6 (01-..)	EOBD
 MG ZT, ZT-T	ENGINE MANAGEME	2.5 KV6 (01-..)	EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS			Rover
MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 MGF	ENGINE MANAGEME	1.8	ROVER MEMS 1.9
 MGF	ENGINE MANAGEME	1.8 K-serie (01-..)	EOBD
 MGF	ENGINE MANAGEME	1.8 VVC K-serie (01-..)	EOBD
 Mini	ENGINE MANAGEME	1.3 i (...5/96)	ROVER MEMS 1.6 spi (no kat)
 Mini	ENGINE MANAGEME	1.3 i (...93)	ROVER MEMS 1.4
 Montego	ELECTRONIC IGNITI	(..93)	ROVER ERIC
 Montego	ENGINE MANAGEME	(..93)	ROVER MEMS 1.4
 Montego	ENGINE MANAGEME	(..95)	ROVER MEMS 1.6 mpi
 Range	ENGINE MANAGEME	4.6 (00-..)	EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Saab

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 9000	ENGINE MANAGEME	2.3 16v T B234 (92-..)	Trionic MANUAL SFI
 9000	MAINTENANCE	2.3 16v T	MANUAL
 9000	MAINTENANCE	2.3 16v T B234 (92-..)	Trionic MANUAL SFI
 9000	SERVICE LIGHT RES	2.3 16v T	MANUAL
 900i	ENGINE MANAGEME	2.0 16v B202 (90-93)	Lucas MANUAL CU 14
 900i	MAINTENANCE	2.0 16v	MANUAL
 900i	MAINTENANCE	2.0 16v B202 (90-93)	Lucas MANUAL CU 14
 900i	SERVICE LIGHT RES	2.0 16v	MANUAL
 9-3	ENGINE MANAGEME	1.9 16v TiD Z19DT	BOSCH EDC 16 Common Rail
 9-3	ENGINE MANAGEME	1.9 TiD Z19DTH	BOSCH EDC 16 Common Rail
 9-3	ENGINE MANAGEME	2.0 Turbo B205E (01-..)	EOBD
 9-3	ENGINE MANAGEME	2.0 Turbo B205L (01-..)	EOBD
 9-3	ENGINE MANAGEME	2.0 Turbo B205R (01-..)	EOBD
 9-3	ENGINE MANAGEME	2.0 Turbo Plus B205E (01-..)	EOBD
 9-3	ENGINE MANAGEME	2.2 TiD Turbodiesel D223L (04-..)	EOBD
 9-3	ENGINE MANAGEME	2.2 TiD X22DTH (98-00)	BOSCH EDC MSA 15 M
 9-3	MAINTENANCE	1.9 16v TiD (...01)	MANUAL
 9-3	MAINTENANCE	1.9 16v TiD (02-..)	MANUAL
 9-3	MAINTENANCE	1.9 TiD (...01)	MANUAL
 9-3	MAINTENANCE	1.9 TiD (02-..)	MANUAL
 9-3	MAINTENANCE	2.0 Turbo (...01)	MANUAL
 9-3	MAINTENANCE	2.0 Turbo (02-..)	MANUAL
 9-3	MAINTENANCE	2.0 Turbo Plus (...01)	MANUAL
 9-3	MAINTENANCE	2.0 Turbo Plus (02-..)	MANUAL
 9-3	MAINTENANCE	2.2 TiD (...01)	MANUAL
 9-3	MAINTENANCE	2.2 TiD (02-..)	MANUAL
 9-3	MAINTENANCE	2.2 TiD Turbodiesel (...01)	MANUAL
 9-3	MAINTENANCE	2.2 TiD Turbodiesel (02-..)	MANUAL
 9-3	SERVICE LIGHT RES	1.9 16v TiD (...01)	MANUAL
 9-3	SERVICE LIGHT RES	1.9 16v TiD (02-..)	MANUAL
 9-3	SERVICE LIGHT RES	1.9 TiD (...01)	MANUAL
 9-3	SERVICE LIGHT RES	1.9 TiD (02-..)	MANUAL
 9-3	SERVICE LIGHT RES	2.0 Turbo (...01)	MANUAL
 9-3	SERVICE LIGHT RES	2.0 Turbo (02-..)	MANUAL
 9-3	SERVICE LIGHT RES	2.0 Turbo Plus (...01)	MANUAL
 9-3	SERVICE LIGHT RES	2.0 Turbo Plus (02-..)	MANUAL
 9-3	SERVICE LIGHT RES	2.2 TiD (...01)	MANUAL
 9-3	SERVICE LIGHT RES	2.2 TiD (02-..)	MANUAL
 9-3	SERVICE LIGHT RES	2.2 TiD Turbodiesel (...01)	MANUAL
 9-3	SERVICE LIGHT RES	2.2 TiD Turbodiesel (02-..)	MANUAL
 9-5	ENGINE MANAGEME	2.0 Turbo B205E/F (01-..)	EOBD
 9-5	ENGINE MANAGEME	2.3 Aero B235R (01-..)	EOBD
 9-5	ENGINE MANAGEME	2.3 Turbo 125kw B235E (01-..)	EOBD
 9-5	ENGINE MANAGEME	2.3 Turbo 136kw B235E (01-..)	EOBD
 9-5	ENGINE MANAGEME	3.0 V6 B308E (01-..)	EOBD
 9-5	MAINTENANCE	2.0 Turbo (...01)	MANUAL
 9-5	MAINTENANCE	2.0 Turbo (02-..)	MANUAL
 9-5	MAINTENANCE	2.3 Aero (...01)	MANUAL
 9-5	MAINTENANCE	2.3 Aero (02-..)	MANUAL
 9-5	MAINTENANCE	2.3 Turbo 125kw (...01)	MANUAL
 9-5	MAINTENANCE	2.3 Turbo 125kw (02-..)	MANUAL
 9-5	MAINTENANCE	2.3 Turbo 136kw (...01)	MANUAL
 9-5	MAINTENANCE	2.3 Turbo 136kw (02-..)	MANUAL
 9-5	MAINTENANCE	3.0 V6 (...01)	MANUAL
 9-5	MAINTENANCE	3.0 V6 (02-..)	MANUAL
 9-5	SERVICE LIGHT RES	2.0 Turbo (...01)	MANUAL
 9-5	SERVICE LIGHT RES	2.0 Turbo (02-..)	MANUAL
 9-5	SERVICE LIGHT RES	2.3 Aero (...01)	MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Saab

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 9-5	SERVICE LIGHT RES	2.3 Aero (02-..)	MANUAL
 9-5	SERVICE LIGHT RES	2.3 Turbo 125kw (..-01)	MANUAL
 9-5	SERVICE LIGHT RES	2.3 Turbo 125kw (02-..)	MANUAL
 9-5	SERVICE LIGHT RES	2.3 Turbo 136kw (..-01)	MANUAL
 9-5	SERVICE LIGHT RES	2.3 Turbo 136kw (02-..)	MANUAL
 9-5	SERVICE LIGHT RES	3.0 V6 (..-01)	MANUAL
 9-5	SERVICE LIGHT RES	3.0 V6 (02-..)	MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Seat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Alhambra (7M) (96-..)	ABS	(01-04)	ATE TEVES Mk60 No ASR
 Alhambra (7M) (96-..)	ABS	(96-04)	
 Alhambra (7M) (96-..)	AIRBAG	(96-04)	
 Alhambra (7M) (96-..)	AUTOM. TRANSMISSI	(96-04)	
 Alhambra (7M) (96-..)	AUX. HEATING	(96-04)	
 Alhambra (7M) (96-..)	CHASSIS NETWORK	(96-04)	
 Alhambra (7M) (96-..)	CLIMA	(96-04)	
 Alhambra (7M) (96-..)	DASHBOARD	(96-04)	
 Alhambra (7M) (96-..)	ENGINE MANAGEME	(96-04)	
 Alhambra (7M) (96-..)	ENGINE MANAGEME	(96-04)	
 Alhambra (7M) (96-..)	ENGINE MANAGEME	(96-04)	
 Alhambra (7M) (96-..)	IMMOBILIZER	(96-04)	
 Alhambra (7M) (96-..)	MAINTENANCE	(01-04)	
 Alhambra (7M) (96-..)	MAINTENANCE	(96-04)	
 Alhambra (7M) (96-..)	MAINTENANCE	(96-04)	
 Alhambra (7M) (96-..)	MAINTENANCE	(96-04)	
 Alhambra (7M) (96-..)	MAINTENANCE	(96-6/98)	
 Alhambra (7M) (96-..)	MAINTENANCE	(96-6/98)	
 Alhambra (7M) (96-..)	MAINTENANCE	(99-04)	
 Alhambra (7M) (96-..)	NAVIGATION	(96-04)	ATE TEVES Mk60 No ASR
 Alhambra (7M) (96-..)	PARKING HELP	(96-04)	
 Alhambra (7M) (96-..)	RADIO / CD	(96-04)	
 Alhambra (7M) (96-..)	SERVICE LIGHT RES	(96-6/98)	
 Alhambra (7M) (96-..)	SERVICE LIGHT RES	(99-04)	
 Alhambra (7M) (96-..)	STEERING WHEEL E	(96-04)	
 Altea (5P) (04-..)	ABS	(04-09)	
 Altea (5P) (04-..)	AIRBAG	(04-09)	
 Altea (5P) (04-..)	AUTOM. TRANSMISSI	(04-09)	
 Altea (5P) (04-..)	AUX. HEATING	(04-09)	
 Altea (5P) (04-..)	CENTRAL ELECTRIC	(04-09)	
 Altea (5P) (04-..)	CHASSIS NETWORK	(04-09)	
 Altea (5P) (04-..)	CLIMA	(04-09)	
 Altea (5P) (04-..)	COMFORT SYSTEM	(04-09)	
 Altea (5P) (04-..)	DASHBOARD	(04-09)	
 Altea (5P) (04-..)	DRIVER SIDE DOOR	(04-09)	
 Altea (5P) (04-..)	ELECTRIC STEERING	(04-09)	
 Altea (5P) (04-..)	ENGINE MANAGEME	(04-09)	
 Altea (5P) (04-..)	HEADLIGHT LEVEL	(04-09)	
 Altea (5P) (04-..)	IMMOBILIZER	(04-09)	CAN
 Altea (5P) (04-..)	LEFT REAR DOOR	(04-09)	
 Altea (5P) (04-..)	MAINTENANCE	(04-09)	
 Altea (5P) (04-..)	MAINTENANCE	(04-09)	
 Altea (5P) (04-..)	MAINTENANCE	(04-09)	
 Altea (5P) (04-..)	MAINTENANCE	(04-09)	
 Altea (5P) (04-..)	MAINTENANCE	(04-09)	
 Altea (5P) (04-..)	MAINTENANCE	(04-09)	
 Altea (5P) (04-..)	MAINTENANCE	(04-09)	
 Altea (5P) (04-..)	MAINTENANCE	(04-09)	
 Altea (5P) (04-..)	MAINTENANCE	(04-09)	
 Altea (5P) (04-..)	MAINTENANCE	(04-09)	
 Altea (5P) (04-..)	MAINTENANCE	(04-09)	
 Altea (5P) (04-..)	MAINTENANCE	(04-09)	
 Altea (5P) (04-..)	MAINTENANCE	(04-09)	CAN CAN
 Altea (5P) (04-..)	NAVIGATION	(04-09)	
 Altea (5P) (04-..)	PARKING HELP	(04-09)	
 Altea (5P) (04-..)	PASS. SIDE DOOR	(04-09)	
 Altea (5P) (04-..)	PHONE	(04-09)	
 Altea (5P) (04-..)	RADIO / CD	(04-09)	
 Altea (5P) (04-..)	RIGHT REAR DOOR	(04-09)	
 Altea (5P) (04-..)	SERVICE LIGHT RES	(04-09)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Seat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Altea (5P) (04-..)	SOUND SYSTEM	(04-09)	
 Altea (5P) (04-..)	SPECIAL FUNCTION	(04-09)	
 Altea (5P) (04-..)	STEERING WHEEL E	(04-09)	
 Altea (5P) (04-..)	SUPP HEATER/AUTO	(04-09)	
 Altea (5P) (04-..)	TOW FUNCTION	(04-09)	
 Arosa (6H) (97-04)	ABS	(..-04)	
 Arosa (6H) (97-04)	ABS	(01-04)	ATE TEVES Mk60 No ASR
 Arosa (6H) (97-04)	AIRBAG	(..-04)	
 Arosa (6H) (97-04)	AUTOM. TRANSMISSI	(..-04)	
 Arosa (6H) (97-04)	CHASSIS NETWORK	(97-04)	
 Arosa (6H) (97-04)	DASHBOARD	(97-04)	
 Arosa (6H) (97-04)	ENGINE MANAGEME	(..-04)	
 Arosa (6H) (97-04)	ENGINE MANAGEME	(..-04)	
 Arosa (6H) (97-04)	ENGINE MANAGEME	(..-04)	
 Arosa (6H) (97-04)	HEADLIGHT LEVEL	(97-04)	
 Arosa (6H) (97-04)	MAINTENANCE	(..-04)	
 Arosa (6H) (97-04)	MAINTENANCE	(..-04)	
 Arosa (6H) (97-04)	MAINTENANCE	(..-04)	
 Arosa (6H) (97-04)	MAINTENANCE	(..-04)	
 Arosa (6H) (97-04)	MAINTENANCE	(01-04)	ATE TEVES Mk60 No ASR
 Arosa (6H) (97-04)	RADIO / CD	(..-04)	
 Arosa (6H) (97-04)	SERVICE LIGHT RES	(..-04)	
 Cordoba (6K) (93-02)	ABS	(93-02)	
 Cordoba (6K) (93-02)	ABS	(93-02)	ATE TEVES Mk60 No ASR
 Cordoba (6K) (93-02)	AIRBAG	(93-02)	
 Cordoba (6K) (93-02)	AUTOM. TRANSMISSI	(93-02)	
 Cordoba (6K) (93-02)	CHASSIS NETWORK	(93-02)	
 Cordoba (6K) (93-02)	CLIMA	(93-02)	
 Cordoba (6K) (93-02)	DASHBOARD	(93-02)	
 Cordoba (6K) (93-02)	ENGINE MANAGEME	(93-02)	
 Cordoba (6K) (93-02)	ENGINE MANAGEME	(93-02)	
 Cordoba (6K) (93-02)	ENGINE MANAGEME	(93-02)	
 Cordoba (6K) (93-02)	HEADLIGHT LEVEL	(93-02)	
 Cordoba (6K) (93-02)	MAINTENANCE	(93-02)	
 Cordoba (6K) (93-02)	MAINTENANCE	(93-02)	
 Cordoba (6K) (93-02)	MAINTENANCE	(93-02)	
 Cordoba (6K) (93-02)	MAINTENANCE	(93-02)	ATE TEVES Mk60 No ASR
 Cordoba (6K) (93-02)	MAINTENANCE	(93-02)	MANUAL
 Cordoba (6K) (93-02)	MAINTENANCE	(99-02)	
 Cordoba (6K) (93-02)	SERVICE LIGHT RES	(93-02)	MANUAL
 Cordoba (6K) (93-02)	SERVICE LIGHT RES	(99-02)	
 Cordoba (6L) (03-09)	ABS	(03-09)	
 Cordoba (6L) (03-09)	ABS	(03-09)	ATE TEVES Mk60 No ASR
 Cordoba (6L) (03-09)	AIRBAG	(03-09)	
 Cordoba (6L) (03-09)	AUTOM. TRANSMISSI	(03-09)	
 Cordoba (6L) (03-09)	CHASSIS NETWORK	(03-09)	
 Cordoba (6L) (03-09)	CLIMA	(03-09)	
 Cordoba (6L) (03-09)	COMFORT SYSTEM	(03-09)	
 Cordoba (6L) (03-09)	DASHBOARD	(03-09)	
 Cordoba (6L) (03-09)	ELECTRIC STEERING	(03-09)	
 Cordoba (6L) (03-09)	ENGINE MANAGEME	(03-09)	
 Cordoba (6L) (03-09)	ENGINE MANAGEME	(03-09)	
 Cordoba (6L) (03-09)	ENGINE MANAGEME	(03-09)	
 Cordoba (6L) (03-09)	MAINTENANCE	(03-09)	
 Cordoba (6L) (03-09)	MAINTENANCE	(03-09)	
 Cordoba (6L) (03-09)	MAINTENANCE	(03-09)	
 Cordoba (6L) (03-09)	MAINTENANCE	(03-09)	
 Cordoba (6L) (03-09)	MAINTENANCE	(03-09)	ATE TEVES Mk60 No ASR

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Seat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Cordoba (6L) (03-09)	MAINTENANCE	(03-09)	MANUAL
 Cordoba (6L) (03-09)	NAVIGATION	(03-09)	
 Cordoba (6L) (03-09)	RADIO / CD	(03-09)	
 Cordoba (6L) (03-09)	SERVICE LIGHT RES	(03-09)	
 Cordoba (6L) (03-09)	SERVICE LIGHT RES	(03-09)	
 Exeo (3R) (09-..)	ABS + TRACT. CONT	(09-11)	
 Exeo (3R) (09-..)	AIRBAG	(09-11)	
 Exeo (3R) (09-..)	ANTITHEFT	(09-11)	
 Exeo (3R) (09-..)	CLIMA	(09-11)	
 Exeo (3R) (09-..)	COMFORT SYSTEM	(09-11)	
 Exeo (3R) (09-..)	DASHBOARD	(09-11)	
 Exeo (3R) (09-..)	ENGINE MANAGEME	2.0 TDI 103 KW CAGA (09-11)	
 Exeo (3R) (09-..)	MAINTENANCE	(09-11)	
 Exeo (3R) (09-..)	MAINTENANCE	(09-11)	
 Exeo (3R) (09-..)	MAINTENANCE	(09-11)	
 Exeo (3R) (09-..)	MAINTENANCE	(09-11)	
 Exeo (3R) (09-..)	MAINTENANCE	(09-11)	
 Exeo (3R) (09-..)	MAINTENANCE	(09-11)	
 Exeo (3R) (09-..)	MAINTENANCE	2.0 TDI 103 KW CAGA (09-11)	
 Exeo (3R) (09-..)	PHONE	(09-11)	
 Exeo (3R) (09-..)	STEERING WHEEL E	(09-11)	
 Ibiza (6J) (09-..)	AIRBAG	(09-10)	Diagnostic bus interface Climatic
 Ibiza (6J) (09-..)	CENTRAL ELECTRIC	(09-10)	
 Ibiza (6J) (09-..)	CHASSIS NETWORK	(09-10)	
 Ibiza (6J) (09-..)	CLIMA	(09-10)	
 Ibiza (6J) (09-..)	DASHBOARD	(09-10)	
 Ibiza (6J) (09-..)	DASHBOARD	(09-10)	
 Ibiza (6J) (09-..)	ENGINE MANAGEME	(09-10)	
 Ibiza (6J) (09-..)	ENGINE MANAGEME	1.2 (09-10)	
 Ibiza (6J) (09-..)	ENGINE MANAGEME	1.2 CGPA (09-10)	
 Ibiza (6J) (09-..)	MAINTENANCE	(09-10)	
 Ibiza (6J) (09-..)	MAINTENANCE	(09-10)	
 Ibiza (6J) (09-..)	MAINTENANCE	(09-10)	
 Ibiza (6J) (09-..)	MAINTENANCE	(09-10)	
 Ibiza (6J) (09-..)	MAINTENANCE	(09-10)	
 Ibiza (6J) (09-..)	SERVICE LIGHT RES	(09-10)	
 Ibiza (6K) (93-02)	ABS	(01-03)	ATE TEVES Mk60 No ASR
 Ibiza (6K) (93-02)	ABS	(93-02)	
 Ibiza (6K) (93-02)	AIRBAG	(93-02)	
 Ibiza (6K) (93-02)	AUTOM. TRANSMISSI	(93-02)	
 Ibiza (6K) (93-02)	CHASSIS NETWORK	(93-02)	
 Ibiza (6K) (93-02)	CLIMA	(93-02)	
 Ibiza (6K) (93-02)	DASHBOARD	(93-02)	
 Ibiza (6K) (93-02)	ENGINE MANAGEME	(93-02)	
 Ibiza (6K) (93-02)	ENGINE MANAGEME	(93-02)	
 Ibiza (6K) (93-02)	ENGINE MANAGEME	(93-02)	
 Ibiza (6K) (93-02)	HEADLIGHT LEVEL	(93-02)	ATE TEVES Mk60 No ASR
 Ibiza (6K) (93-02)	MAINTENANCE	(01-03)	
 Ibiza (6K) (93-02)	MAINTENANCE	(93-02)	
 Ibiza (6K) (93-02)	MAINTENANCE	(93-02)	MANUAL
 Ibiza (6K) (93-02)	MAINTENANCE	(93-02)	
 Ibiza (6K) (93-02)	MAINTENANCE	(99-02)	
 Ibiza (6K) (93-02)	RADIO / CD	(93-02)	MANUAL
 Ibiza (6K) (93-02)	SERVICE LIGHT RES	(93-02)	
 Ibiza (6K) (93-02)	SERVICE LIGHT RES	(99-02)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Seat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Ibiza (6L) (02-09)	ABS	(02-09)	ATE TEVES Mk60 No ASR
 Ibiza (6L) (02-09)	ABS	(02-09)	
 Ibiza (6L) (02-09)	AIRBAG	(02-09)	
 Ibiza (6L) (02-09)	CHASSIS NETWORK	(02-09)	CLIMATIC CLIMATRONIC
 Ibiza (6L) (02-09)	CLIMA	(02-09)	
 Ibiza (6L) (02-09)	CLIMA	(02-09)	
 Ibiza (6L) (02-09)	COMFORT SYSTEM	(02-09)	ATE TEVES Mk60 No ASR MANUAL
 Ibiza (6L) (02-09)	DASHBOARD	(02-09)	
 Ibiza (6L) (02-09)	ELECTRIC STEERING	(02-09)	
 Ibiza (6L) (02-09)	ENGINE MANAGEME	(02-09)	
 Ibiza (6L) (02-09)	ENGINE MANAGEME	(02-09)	
 Ibiza (6L) (02-09)	ENGINE MANAGEME	(02-09)	
 Ibiza (6L) (02-09)	MAINTENANCE	(02-09)	
 Ibiza (6L) (02-09)	MAINTENANCE	(02-09)	
 Ibiza (6L) (02-09)	MAINTENANCE	(02-09)	
 Ibiza (6L) (02-09)	MAINTENANCE	(02-09)	
 Ibiza (6L) (02-09)	MAINTENANCE	(02-09)	
 Ibiza (6L) (02-09)	NAVIGATION	(02-09)	
 Ibiza (6L) (02-09)	RADIO / CD	(02-09)	
 Ibiza (6L) (02-09)	SERVICE LIGHT RES	(02-09)	
 Ibiza (6L) (02-09)	SERVICE LIGHT RES	(02-09)	MANUAL
 Inca (9K) (96-03)	ABS	(96-03)	MANUAL MANUAL
 Inca (9K) (96-03)	AIRBAG	(96-03)	
 Inca (9K) (96-03)	AUTOM. TRANSMISSI	(96-03)	
 Inca (9K) (96-03)	CHASSIS NETWORK	(96-03)	
 Inca (9K) (96-03)	CLIMA	(96-03)	
 Inca (9K) (96-03)	DASHBOARD	(96-03)	
 Inca (9K) (96-03)	ENGINE MANAGEME	(96-03)	
 Inca (9K) (96-03)	ENGINE MANAGEME	(96-03)	
 Inca (9K) (96-03)	ENGINE MANAGEME	(96-03)	
 Inca (9K) (96-03)	HEADLIGHT LEVEL	(96-03)	
 Inca (9K) (96-03)	MAINTENANCE	(96-03)	
 Inca (9K) (96-03)	MAINTENANCE	(96-03)	
 Inca (9K) (96-03)	MAINTENANCE	(96-03)	
 Inca (9K) (96-03)	MAINTENANCE	(96-03)	
 Inca (9K) (96-03)	SERVICE LIGHT RES	(96-03)	
 Leon (1M) (99-06)	4WD ELECTRONICS	(99-05)	ATE TEVES Mk60 No ASR (no trip comp.) ATE TEVES Mk60 No ASR MANUAL
 Leon (1M) (99-06)	ABS	(99-05)	
 Leon (1M) (99-06)	ABS	(99-05)	
 Leon (1M) (99-06)	AIRBAG	(99-05)	
 Leon (1M) (99-06)	AUTOM. TRANSMISSI	(99-05)	
 Leon (1M) (99-06)	CENTRAL LOCKING	(99-05)	
 Leon (1M) (99-06)	CHASSIS NETWORK	(99-05)	
 Leon (1M) (99-06)	CLIMA	(99-05)	
 Leon (1M) (99-06)	COMFORT SYSTEM	(99-05)	
 Leon (1M) (99-06)	DASHBOARD	(99-05)	
 Leon (1M) (99-06)	ENGINE MANAGEME	(99-05)	
 Leon (1M) (99-06)	ENGINE MANAGEME	(99-05)	
 Leon (1M) (99-06)	ENGINE MANAGEME	(99-05)	
 Leon (1M) (99-06)	HEADLIGHT LEVEL	(99-05)	
 Leon (1M) (99-06)	MAINTENANCE	(99-05)	
 Leon (1M) (99-06)	MAINTENANCE	(99-05)	
 Leon (1M) (99-06)	MAINTENANCE	(99-05)	
 Leon (1M) (99-06)	MAINTENANCE	(99-05)	
 Leon (1M) (99-06)	MAINTENANCE	(99-05)	
 Leon (1M) (99-06)	MAINTENANCE	(99-05)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Seat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Leon (1M) (99-06)	NAVIGATION	(99-05)	MANUAL (no trip comp.)
 Leon (1M) (99-06)	PARKING HELP	(99-05)	
 Leon (1M) (99-06)	RADIO / CD	(99-05)	
 Leon (1M) (99-06)	REMOTE CONTROL E	(99-05)	
 Leon (1M) (99-06)	SERVICE LIGHT RES	(99-05)	
 Leon (1M) (99-06)	SERVICE LIGHT RES	(99-05)	
 Leon (1M) (99-06)	STEERING WHEEL E	(99-05)	
 Leon (1P) (05-..)	ABS	(05-10)	Electric central system CAN Gateway
 Leon (1P) (05-..)	AIRBAG	(05-10)	
 Leon (1P) (05-..)	AUTOM. TRANSMISSI	(05-10)	
 Leon (1P) (05-..)	AUX. HEATING	(05-10)	
 Leon (1P) (05-..)	CENTRAL ELECTRIC	(05-10)	
 Leon (1P) (05-..)	CHASSIS NETWORK	(05-10)	
 Leon (1P) (05-..)	CLIMA	(05-10)	
 Leon (1P) (05-..)	COMFORT SYSTEM	(05-10)	Comfort system
 Leon (1P) (05-..)	DASHBOARD	(05-10)	
 Leon (1P) (05-..)	DRIVER SIDE DOOR	(05-10)	
 Leon (1P) (05-..)	ELECTRIC STEERING	(05-10)	
 Leon (1P) (05-..)	ENGINE MANAGEME	(05-10)	
 Leon (1P) (05-..)	HEADLIGHT LEVEL	(05-10)	
 Leon (1P) (05-..)	IMMOBILIZER	(05-10)	CAN
 Leon (1P) (05-..)	LEFT REAR DOOR	(05-10)	
 Leon (1P) (05-..)	MAINTENANCE	(05-10)	
 Leon (1P) (05-..)	MAINTENANCE	(05-10)	
 Leon (1P) (05-..)	MAINTENANCE	(05-10)	
 Leon (1P) (05-..)	MAINTENANCE	(05-10)	
 Leon (1P) (05-..)	MAINTENANCE	(05-10)	
 Leon (1P) (05-..)	MAINTENANCE	(05-10)	CAN CAN
 Leon (1P) (05-..)	MAINTENANCE	(05-10)	
 Leon (1P) (05-..)	MAINTENANCE	(05-10)	
 Leon (1P) (05-..)	MAINTENANCE	(05-10)	
 Leon (1P) (05-..)	MAINTENANCE	(05-10)	
 Leon (1P) (05-..)	MAINTENANCE	(05-10)	
 Leon (1P) (05-..)	NAVIGATION	(05-10)	
 Leon (1P) (05-..)	PARKING HELP	(05-10)	
 Leon (1P) (05-..)	PASS. SIDE DOOR	(05-10)	
 Leon (1P) (05-..)	PHONE	(05-10)	
 Leon (1P) (05-..)	RADIO / CD	(05-10)	
 Leon (1P) (05-..)	RIGHT REAR DOOR	(05-10)	
 Leon (1P) (05-..)	SERVICE LIGHT RES	(05-10)	
 Leon (1P) (05-..)	SOUND SYSTEM	(05-10)	
 Leon (1P) (05-..)	SPECIAL FUNCTION	(05-10)	
 Leon (1P) (05-..)	STEERING WHEEL E	(05-10)	
 Leon (1P) (05-..)	SUPP HEATER/AUTO	(05-10)	
 Leon (1P) (05-..)	TOW FUNCTION	(05-10)	
 Leon (1P) (05-..)	TRANSPORT MODALI	(05-10)	
 Toledo (1L) (92-99)	ABS	(92-99)	ATE TEVES Mk60 No ASR
 Toledo (1L) (92-99)	ABS	(92-99)	
 Toledo (1L) (92-99)	AIRBAG	(92-99)	
 Toledo (1L) (92-99)	AUTOM. TRANSMISSI	(92-99)	
 Toledo (1L) (92-99)	CLIMA	(92-99)	
 Toledo (1L) (92-99)	CLUTCH ELECTRONI	(92-99)	
 Toledo (1L) (92-99)	ENGINE MANAGEME	(92-99)	
 Toledo (1L) (92-99)	ENGINE MANAGEME	(92-99)	
 Toledo (1L) (92-99)	ENGINE MANAGEME	(92-99)	
 Toledo (1L) (92-99)	ENGINE MANAGEME	(92-99)	
 Toledo (1L) (92-99)	IMMOBILIZER	(92-99)	
 Toledo (1L) (92-99)	MAINTENANCE	(92-99)	
Toledo (1L) (92-99)	MAINTENANCE	(92-99)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Seat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Toledo (1L) (92-99)	MAINTENANCE	(92-99)	ATE TEVES Mk60 No ASR MANUAL
 Toledo (1L) (92-99)	MAINTENANCE	(92-99)	
 Toledo (1L) (92-99)	MAINTENANCE	(92-99)	
 Toledo (1L) (92-99)	MAINTENANCE	(92-99)	
 Toledo (1L) (92-99)	RADIO / CD	(92-99)	
 Toledo (1L) (92-99)	SERVICE LIGHT RES	(92-99)	
 Toledo (1L) (92-99)	SERVICE LIGHT RES	(92-99)	
 Toledo (1M) (99-06)	4WD ELECTRONICS	(99-06)	ATE TEVES Mk60 No ASR
 Toledo (1M) (99-06)	ABS	(01-06)	
 Toledo (1M) (99-06)	ABS	(99-06)	
 Toledo (1M) (99-06)	AIRBAG	(99-06)	
 Toledo (1M) (99-06)	AUTOM. TRANSMISSI	(99-06)	
 Toledo (1M) (99-06)	CENTRAL LOCKING	(99-06)	
 Toledo (1M) (99-06)	CHASSIS NETWORK	(99-06)	
 Toledo (1M) (99-06)	CLIMA	(99-06)	
 Toledo (1M) (99-06)	COMFORT SYSTEM	(99-06)	
 Toledo (1M) (99-06)	DASHBOARD	(99-06)	
 Toledo (1M) (99-06)	ENGINE MANAGEME	(99-06)	
 Toledo (1M) (99-06)	ENGINE MANAGEME	(99-06)	
 Toledo (1M) (99-06)	ENGINE MANAGEME	(99-06)	
 Toledo (1M) (99-06)	HEADLIGHT LEVEL	(99-06)	
 Toledo (1M) (99-06)	MAINTENANCE	(01-06)	
 Toledo (1M) (99-06)	MAINTENANCE	(99-03)	
 Toledo (1M) (99-06)	MAINTENANCE	(99-06)	
 Toledo (1M) (99-06)	MAINTENANCE	(99-06)	
 Toledo (1M) (99-06)	MAINTENANCE	(99-06)	
 Toledo (1M) (99-06)	MAINTENANCE	(99-06)	
 Toledo (1M) (99-06)	NAVIGATION	(99-06)	MANUAL
 Toledo (1M) (99-06)	PARKING HELP	(99-06)	
 Toledo (1M) (99-06)	RADIO / CD	(99-06)	MANUAL
 Toledo (1M) (99-06)	SERVICE LIGHT RES	(99-03)	
 Toledo (1M) (99-06)	SERVICE LIGHT RES	(99-06)	
 Toledo (1M) (99-06)	STEERING WHEEL E	(99-06)	
 Toledo (5P) (05-09)	ABS	(05-09)	Electric central system CAN Gateway Comfort system CAN CAN
 Toledo (5P) (05-09)	AIRBAG	(05-09)	
 Toledo (5P) (05-09)	AUTOM. TRANSMISSI	(05-09)	
 Toledo (5P) (05-09)	AUX. HEATING	(05-09)	
 Toledo (5P) (05-09)	CENTRAL ELECTRIC	(05-09)	
 Toledo (5P) (05-09)	CHASSIS NETWORK	(05-09)	
 Toledo (5P) (05-09)	CLIMA	(05-09)	
 Toledo (5P) (05-09)	COMFORT SYSTEM	(05-09)	
 Toledo (5P) (05-09)	DASHBOARD	(05-09)	
 Toledo (5P) (05-09)	DRIVER SIDE DOOR	(05-09)	
 Toledo (5P) (05-09)	ELECTRIC STEERING	(05-09)	
 Toledo (5P) (05-09)	ENGINE MANAGEME	(05-09)	
 Toledo (5P) (05-09)	HEADLIGHT LEVEL	(05-09)	
 Toledo (5P) (05-09)	IMMOBILIZER	(05-09)	
 Toledo (5P) (05-09)	LEFT REAR DOOR	(05-09)	
 Toledo (5P) (05-09)	MAINTENANCE	(05-09)	
 Toledo (5P) (05-09)	MAINTENANCE	(05-09)	
 Toledo (5P) (05-09)	MAINTENANCE	(05-09)	
 Toledo (5P) (05-09)	MAINTENANCE	(05-09)	
 Toledo (5P) (05-09)	MAINTENANCE	(05-09)	
 Toledo (5P) (05-09)	MAINTENANCE	(05-09)	
 Toledo (5P) (05-09)	MAINTENANCE	(05-09)	
 Toledo (5P) (05-09)	MAINTENANCE	(05-09)	
 Toledo (5P) (05-09)	MAINTENANCE	(05-09)	
 Toledo (5P) (05-09)	MAINTENANCE	(05-09)	
 Toledo (5P) (05-09)	MAINTENANCE	(05-09)	
 Toledo (5P) (05-09)	MAINTENANCE	(05-09)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Seat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Toledo (5P) (05-09)	MAINTENANCE	(05-09)	CAN
 Toledo (5P) (05-09)	NAVIGATION	(05-09)	
 Toledo (5P) (05-09)	PARKING HELP	(05-09)	
 Toledo (5P) (05-09)	PASS. SIDE DOOR	(05-09)	
 Toledo (5P) (05-09)	PHONE	(05-09)	
 Toledo (5P) (05-09)	RADIO / CD	(05-09)	
 Toledo (5P) (05-09)	RIGHT REAR DOOR	(05-09)	
 Toledo (5P) (05-09)	SERVICE LIGHT RES	(05-09)	
 Toledo (5P) (05-09)	SOUND SYSTEM	(05-09)	
 Toledo (5P) (05-09)	SPECIAL FUNCTION	(05-09)	
 Toledo (5P) (05-09)	STEERING WHEEL E	(05-09)	
 Toledo (5P) (05-09)	TOW FUNCTION	(05-09)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Skoda

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Fabia (5J) (07-..)	AIRBAG	(08-..)	
 Fabia (5J) (07-..)	DASHBOARD	(09-..)	
 Fabia (5J) (07-..)	ENGINE MANAGEME	(09-..)	
 Fabia (5J) (07-..)	MAINTENANCE	(09-..)	
 Fabia (5J) (07-..)	MAINTENANCE	(09-..)	
 Fabia (5J) (07-..)	MAINTENANCE	(09-..)	
 Fabia (5J) (07-..)	SERVICE LIGHT RES	(09-..)	
 Fabia (6Y) (00-07)	ABS	(..-07)	
 Fabia (6Y) (00-07)	ABS	(..-07)	ATE TEVES Mk60 No ASR
 Fabia (6Y) (00-07)	AIRBAG	(..-07)	
 Fabia (6Y) (00-07)	AUTOM. TRANSMISSI	(..-07)	
 Fabia (6Y) (00-07)	CHASSIS NETWORK	(..-07)	
 Fabia (6Y) (00-07)	CLIMA	(..-07)	CLIMATIC
 Fabia (6Y) (00-07)	CLIMA	(..-07)	CLIMATRONIC
 Fabia (6Y) (00-07)	COMFORT SYSTEM	(..-07)	
 Fabia (6Y) (00-07)	ELECTRIC STEERING	(..-07)	
 Fabia (6Y) (00-07)	ENGINE MANAGEME	(..-07)	
 Fabia (6Y) (00-07)	ENGINE MANAGEME	(..-07)	
 Fabia (6Y) (00-07)	ENGINE MANAGEME	(..-07)	
 Fabia (6Y) (00-07)	ENGINE MANAGEME	(..-07)	
 Fabia (6Y) (00-07)	HEADLIGHT LEVEL	(..-07)	
 Fabia (6Y) (00-07)	MAINTENANCE	(..-07)	
 Fabia (6Y) (00-07)	MAINTENANCE	(..-07)	
 Fabia (6Y) (00-07)	MAINTENANCE	(..-07)	
 Fabia (6Y) (00-07)	MAINTENANCE	(..-07)	
 Fabia (6Y) (00-07)	MAINTENANCE	(..-07)	ATE TEVES Mk60 No ASR
 Fabia (6Y) (00-07)	NAVIGATION	(..-07)	
 Fabia (6Y) (00-07)	PARKING HELP	(..-07)	
 Fabia (6Y) (00-07)	RADIO / CD	(..-07)	
 Fabia (6Y) (00-07)	SERVICE LIGHT RES	(..-07)	
 Favorit (13) (88-95)	ENGINE MANAGEME	(..-95)	
 Favorit (13) (88-95)	ENGINE MANAGEME	(..-95)	
 Favorit (13) (88-95)	ENGINE MANAGEME	(..-95)	
 Felicia (4x-6x) (95-01)	ABS	(..-01)	
 Felicia (4x-6x) (95-01)	AIRBAG	(..-01)	
 Felicia (4x-6x) (95-01)	AUTOM. TRANSMISSI	(..-01)	
 Felicia (4x-6x) (95-01)	CENTRAL LOCKING	(..-01)	
 Felicia (4x-6x) (95-01)	CHASSIS NETWORK	(..-01)	
 Felicia (4x-6x) (95-01)	CLIMA	(..-01)	
 Felicia (4x-6x) (95-01)	DASHBOARD	(..-01)	
 Felicia (4x-6x) (95-01)	ENGINE MANAGEME	(..-01)	
 Felicia (4x-6x) (95-01)	ENGINE MANAGEME	(..-01)	
 Felicia (4x-6x) (95-01)	ENGINE MANAGEME	(..-01)	
 Felicia (4x-6x) (95-01)	IMMOBILIZER	(..-01)	
 Felicia (4x-6x) (95-01)	MAINTENANCE	(..-01)	
 Felicia (4x-6x) (95-01)	MAINTENANCE	(..-01)	
 Felicia (4x-6x) (95-01)	MAINTENANCE	(..-01)	
 Forman (13) (88-95)	ENGINE MANAGEME	(..-95)	
 Forman (13) (88-95)	ENGINE MANAGEME	(..-95)	
 Forman (13) (88-95)	ENGINE MANAGEME	(..-95)	
 Octavia (1U) (97-04)	4WD ELECTRONICS	(..-04)	
 Octavia (1U) (97-04)	ABS	(..-04)	
 Octavia (1U) (97-04)	ABS	(..-04)	ATE TEVES Mk60 No ASR
 Octavia (1U) (97-04)	AIRBAG	(..-04)	
 Octavia (1U) (97-04)	AUTOM. TRANSMISSI	(..-04)	
 Octavia (1U) (97-04)	CENTRAL LOCKING	(..-04)	
 Octavia (1U) (97-04)	CHASSIS NETWORK	(..-04)	
 Octavia (1U) (97-04)	CLIMA	(..-04)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Skoda

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Octavia (1U) (97-04)	COMFORT SYSTEM	(..-04)	
 Octavia (1U) (97-04)	DASHBOARD	(..-04)	
 Octavia (1U) (97-04)	ENGINE MANAGEME	(..-04)	
 Octavia (1U) (97-04)	ENGINE MANAGEME	(..-04)	
 Octavia (1U) (97-04)	ENGINE MANAGEME	(..-04)	
 Octavia (1U) (97-04)	HEADLIGHT LEVEL	(..-04)	
 Octavia (1U) (97-04)	MAINTENANCE	(..-00)	
 Octavia (1U) (97-04)	MAINTENANCE	(..-00)	
 Octavia (1U) (97-04)	MAINTENANCE	(..-04)	
 Octavia (1U) (97-04)	MAINTENANCE	(..-04)	
 Octavia (1U) (97-04)	MAINTENANCE	(..-04)	
 Octavia (1U) (97-04)	MAINTENANCE	(..-04)	ATE TEVES Mk60 No ASR
 Octavia (1U) (97-04)	MAINTENANCE	(99-04)	
 Octavia (1U) (97-04)	NAVIGATION	(..-04)	
 Octavia (1U) (97-04)	PARKING HELP	(..-04)	
 Octavia (1U) (97-04)	RADIO / CD	(..-04)	
 Octavia (1U) (97-04)	SERVICE LIGHT RES	(..-00)	
 Octavia (1U) (97-04)	SERVICE LIGHT RES	(99-04)	
 Octavia (1U) (97-04)	STEERING WHEEL E	(..-04)	
 Octavia (1Z) (04-..)	4WD ELECTRONICS	(04-10)	
 Octavia (1Z) (04-..)	ABS	(04-10)	
 Octavia (1Z) (04-..)	AIRBAG	(04-10)	
 Octavia (1Z) (04-..)	AUTOM. TRANSMISSI	(04-10)	
 Octavia (1Z) (04-..)	AUX. HEATING	(04-10)	
 Octavia (1Z) (04-..)	CENTRAL ELECTRIC	(04-10)	Electric central system
 Octavia (1Z) (04-..)	CHASSIS NETWORK	(04-10)	CAN Gateway
 Octavia (1Z) (04-..)	CLIMA	(04-09)	
 Octavia (1Z) (04-..)	CLIMA	(09-10)	Climatronic
 Octavia (1Z) (04-..)	COLUMN/SEAT REG.	(04-10)	
 Octavia (1Z) (04-..)	COMFORT SYSTEM	(04-10)	Comfort system
 Octavia (1Z) (04-..)	CONV. TOP/SUNROO	(04-10)	
 Octavia (1Z) (04-..)	DASHBOARD	(04-08)	
 Octavia (1Z) (04-..)	DASHBOARD	(09-10)	
 Octavia (1Z) (04-..)	DRIVER SIDE DOOR	(04-10)	
 Octavia (1Z) (04-..)	ELECTRIC STEERING	(04-10)	
 Octavia (1Z) (04-..)	ENGINE MANAGEME	(04-10)	CAN
 Octavia (1Z) (04-..)	ENGINE MANAGEME	1.4 TSI 90 Kw (08-12)	CAXA
 Octavia (1Z) (04-..)	HEADLIGHT LEVEL	(04-10)	
 Octavia (1Z) (04-..)	IMMOBILIZER	(04-10)	
 Octavia (1Z) (04-..)	LEFT REAR DOOR	(04-10)	
 Octavia (1Z) (04-..)	MAINTENANCE	(04-08)	
 Octavia (1Z) (04-..)	MAINTENANCE	(04-08)	
 Octavia (1Z) (04-..)	MAINTENANCE	(04-08)	
 Octavia (1Z) (04-..)	MAINTENANCE	(04-10)	
 Octavia (1Z) (04-..)	MAINTENANCE	(04-10)	
 Octavia (1Z) (04-..)	MAINTENANCE	(04-10)	
 Octavia (1Z) (04-..)	MAINTENANCE	(04-10)	
 Octavia (1Z) (04-..)	MAINTENANCE	(04-10)	
 Octavia (1Z) (04-..)	MAINTENANCE	(04-10)	
 Octavia (1Z) (04-..)	MAINTENANCE	(04-10)	CAN
 Octavia (1Z) (04-..)	MAINTENANCE	(04-10)	CAN
 Octavia (1Z) (04-..)	MAINTENANCE	(09-10)	
 Octavia (1Z) (04-..)	MAINTENANCE	(09-10)	
 Octavia (1Z) (04-..)	MAINTENANCE	(09-10)	
 Octavia (1Z) (04-..)	NAVIGATION	(04-10)	
 Octavia (1Z) (04-..)	PARKING HELP	(04-10)	
 Octavia (1Z) (04-..)	PASS. SIDE DOOR	(04-10)	
 Octavia (1Z) (04-..)	PHONE	(04-10)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Skoda

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Octavia (1Z) (04-..)	RADIO / CD	(04-10)	
 Octavia (1Z) (04-..)	RIGHT REAR DOOR	(04-10)	
 Octavia (1Z) (04-..)	SERVICE LIGHT RES	(04-08)	
 Octavia (1Z) (04-..)	SERVICE LIGHT RES	(09-10)	
 Octavia (1Z) (04-..)	SOUND SYSTEM	(04-10)	
 Octavia (1Z) (04-..)	SPECIAL FUNCTION	(04-10)	
 Octavia (1Z) (04-..)	STEERING WHEEL E	(04-10)	
 Octavia (1Z) (04-..)	SUPP HEATER/AUTO	(04-10)	
 Octavia (1Z) (04-..)	TOW FUNCTION	(04-10)	
 Pick-up (67) (96-01)	ABS	(..-01)	
 Pick-up (67) (96-01)	AIRBAG	(..-01)	
 Pick-up (67) (96-01)	CENTRAL LOCKING	(..-01)	
 Pick-up (67) (96-01)	DASHBOARD	(..-01)	
 Pick-up (67) (96-01)	ENGINE MANAGEME	(..-01)	
 Pick-up (67) (96-01)	ENGINE MANAGEME	(..-01)	
 Pick-up (67) (96-01)	ENGINE MANAGEME	(..-01)	
 Pick-up (67) (96-01)	IMMOBILIZER	(..-01)	
 Pick-up (67) (96-01)	MAINTENANCE	(..-01)	
 Pick-up (67) (96-01)	MAINTENANCE	(..-01)	
 Pick-up (67) (96-01)	MAINTENANCE	(..-01)	
 Pick-up (67) (96-01)	RADIO / CD	(..-01)	
 Praktik (5J) (10-..)	AIRBAG	(10-..)	
 Praktik (5J) (10-..)	CENTRAL ELECTRIC	(10-..)	
 Praktik (5J) (10-..)	CHASSIS NETWORK	(10-..)	Diagnostic bus interface
 Praktik (5J) (10-..)	CLIMA	(10-..)	Climatic
 Praktik (5J) (10-..)	DASHBOARD	(10-..)	
 Praktik (5J) (10-..)	MAINTENANCE	(10-..)	
 Praktik (5J) (10-..)	MAINTENANCE	(10-..)	
 Praktik (5J) (10-..)	MAINTENANCE	(10-..)	
 Praktik (5J) (10-..)	SERVICE LIGHT RES	(10-..)	
 Roomster (5J) (10-..)	AIRBAG	(10-..)	
 Roomster (5J) (10-..)	CENTRAL ELECTRIC	(10-..)	
 Roomster (5J) (10-..)	CHASSIS NETWORK	(10-..)	Diagnostic bus interface
 Roomster (5J) (10-..)	CLIMA	(10-..)	Climatic
 Roomster (5J) (10-..)	DASHBOARD	(10-..)	
 Roomster (5J) (10-..)	ELECTRIC STEERING	(08-10)	
 Roomster (5J) (10-..)	ENGINE MANAGEME	Gasoline (06-10)	
 Roomster (5J) (10-..)	MAINTENANCE	(10-..)	
 Roomster (5J) (10-..)	MAINTENANCE	(10-..)	
 Roomster (5J) (10-..)	MAINTENANCE	(10-..)	
 Roomster (5J) (10-..)	MAINTENANCE	Gasoline (06-10)	
 Roomster (5J) (10-..)	SERVICE LIGHT RES	(10-..)	
 Superb (3T) (08-..)	ABS	(08-10)	
 Superb (3T) (08-..)	AIRBAG	(08-10)	
 Superb (3T) (08-..)	AUTOM. TRANSMISSI	(08-10)	
 Superb (3T) (08-..)	AUX. HEATING	(08-10)	
 Superb (3T) (08-..)	CENTRAL ELECTRIC	(08-10)	Electric central system
 Superb (3T) (08-..)	CHANGE BRAKE PAD	(08-10)	
 Superb (3T) (08-..)	CLIMA	(08-10)	
 Superb (3T) (08-..)	COMFORT SYSTEM	(08-10)	Comfort system
 Superb (3T) (08-..)	CONV. TOP/SUNROO	(08-10)	
 Superb (3T) (08-..)	DASHBOARD	(08-09)	
 Superb (3T) (08-..)	DASHBOARD	(09-10)	
 Superb (3T) (08-..)	DRIVER SIDE DOOR	(08-10)	
 Superb (3T) (08-..)	ELECTRIC STEERING	(08-10)	
 Superb (3T) (08-..)	ENGINE MANAGEME	(08-10)	CAN
 Superb (3T) (08-..)	ENGINE MANAGEME	2.0 TDI 125 Kw (08-10)	CBBB

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Skoda

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Superb (3T) (08-..)	HEADLIGHT LEVEL	(08-10)	
 Superb (3T) (08-..)	IMMOBILIZER	(08-10)	
 Superb (3T) (08-..)	LEFT REAR DOOR	(08-10)	
 Superb (3T) (08-..)	MAINTENANCE	(08-09)	
 Superb (3T) (08-..)	MAINTENANCE	(08-09)	
 Superb (3T) (08-..)	MAINTENANCE	(08-09)	
 Superb (3T) (08-..)	MAINTENANCE	(08-10)	
 Superb (3T) (08-..)	MAINTENANCE	(08-10)	
 Superb (3T) (08-..)	MAINTENANCE	(08-10)	
 Superb (3T) (08-..)	MAINTENANCE	(08-10)	
 Superb (3T) (08-..)	MAINTENANCE	(08-10)	
 Superb (3T) (08-..)	MAINTENANCE	(08-10)	
 Superb (3T) (08-..)	MAINTENANCE	(08-10)	
 Superb (3T) (08-..)	MAINTENANCE	(08-10)	
 Superb (3T) (08-..)	MAINTENANCE	(08-10)	
 Superb (3T) (08-..)	MAINTENANCE	(08-10)	CAN
 Superb (3T) (08-..)	MAINTENANCE	(08-10)	CAN
 Superb (3T) (08-..)	MAINTENANCE	(09-10)	
 Superb (3T) (08-..)	MAINTENANCE	(09-10)	
 Superb (3T) (08-..)	MAINTENANCE	2.0 TDI 125 Kw (08-10)	CBBB
 Superb (3T) (08-..)	MAINTENANCE	2.0 TDI 125 Kw (08-10)	CBBB
 Superb (3T) (08-..)	MAINTENANCE	2.0 TDI 125 Kw (08-10)	CBBB
 Superb (3T) (08-..)	PARK.BRAKE	(08-10)	
 Superb (3T) (08-..)	PASS. SIDE DOOR	(08-10)	
 Superb (3T) (08-..)	RADIO / CD	(08-10)	
 Superb (3T) (08-..)	RIGHT REAR DOOR	(08-10)	
 Superb (3T) (08-..)	SERVICE LIGHT RES	(08-09)	
 Superb (3T) (08-..)	STEERING WHEEL E	(08-10)	
 Superb (3T) (08-..)	TRANSPORT MODALI	(08-10)	
 Superb (3U) (02-08)	ABS	(..-08)	ATE TEVES Mk60 No ASR
 Superb (3U) (02-08)	ABS	(..-08)	No CAN
 Superb (3U) (02-08)	AIRBAG	(..-08)	No CAN
 Superb (3U) (02-08)	AIRBAG	(..-08)	No CAN - KW 2000
 Superb (3U) (02-08)	ANTITHEFT	(..-08)	No CAN
 Superb (3U) (02-08)	AUTOM. LIGHT SWIT	(..-08)	No CAN
 Superb (3U) (02-08)	AUTOM. TRANSMISSI	(..-08)	No CAN
 Superb (3U) (02-08)	AUX. HEATING	(..-08)	No CAN
 Superb (3U) (02-08)	BRAKE POWER SUP	(..-08)	No CAN
 Superb (3U) (02-08)	CENTRAL LOCKING	(..-08)	No CAN
 Superb (3U) (02-08)	CHASSIS NETWORK	(..-08)	No CAN
 Superb (3U) (02-08)	CLIMA	(..-08)	No CAN
 Superb (3U) (02-08)	COLUMN/SEAT REG.	(..-08)	No CAN
 Superb (3U) (02-08)	COMFORT SYSTEM	(..-08)	No CAN
 Superb (3U) (02-08)	CONV. TOP/SUNROO	(..-08)	No CAN
 Superb (3U) (02-08)	DASHBOARD	(..-08)	No CAN
 Superb (3U) (02-08)	DASHBOARD	(..-08)	No CAN - KW 2000
 Superb (3U) (02-08)	DRIVER SEAT CONT	(..-08)	No CAN
 Superb (3U) (02-08)	DRIVER SIDE DOOR	(..-08)	No CAN
 Superb (3U) (02-08)	ELECTRIC ACTUATIO	(..-08)	No CAN
 Superb (3U) (02-08)	ELECTRIC STEERING	(..-08)	No CAN
 Superb (3U) (02-08)	EMERGENCY MODUL	(..-08)	No CAN
 Superb (3U) (02-08)	ENGINE MANAGEME	(..-08)	
 Superb (3U) (02-08)	ENGINE MANAGEME	(..-08)	
 Superb (3U) (02-08)	ENGINE MANAGEME	(..-08)	
 Superb (3U) (02-08)	HEADLIGHT LEVEL	(..-08)	No CAN
 Superb (3U) (02-08)	HEADLIGHT LEVEL	(..-08)	No CAN - KW 2000
 Superb (3U) (02-08)	IMMOBILIZER	(..-08)	No CAN

Systems supported by ECUREADER / ECUdecoder (up to V6.90)

CARS

Skoda

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Superb (3U) (02-08)	LEFT REAR DOOR	(..-08)	No CAN
 Superb (3U) (02-08)	LH RIGHT MODULATI	(..-08)	No CAN
 Superb (3U) (02-08)	MAINTENANCE	(..-08)	ATE TEVES Mk60 No ASR
 Superb (3U) (02-08)	MAINTENANCE	(..-08)	No CAN
 Superb (3U) (02-08)	MAINTENANCE	(..-08)	No CAN
 Superb (3U) (02-08)	MAINTENANCE	(..-08)	No CAN
 Superb (3U) (02-08)	MAINTENANCE	(..-08)	No CAN
 Superb (3U) (02-08)	MAINTENANCE	(..-08)	No CAN - KW 2000
 Superb (3U) (02-08)	MAINTENANCE	(..-08)	No CAN - KW 2000
 Superb (3U) (02-08)	MAINTENANCE	(..-08)	No CAN - KW 2000
 Superb (3U) (02-08)	MAINTENANCE	(..-08)	No CAN - KW 2000
 Superb (3U) (02-08)	PARKING HELP	(..-08)	No CAN
 Superb (3U) (02-08)	PASS. SIDE DOOR	(..-08)	No CAN
 Superb (3U) (02-08)	PASSIVE ENTRY	(..-08)	No CAN
 Superb (3U) (02-08)	PHONE	(..-08)	No CAN
 Superb (3U) (02-08)	POWER BRAKE	(..-08)	No CAN
 Superb (3U) (02-08)	RADIO / CD	(..-08)	No CAN
 Superb (3U) (02-08)	RH LIGHT MODULATI	(..-08)	No CAN
 Superb (3U) (02-08)	RIGHT REAR DOOR	(..-08)	No CAN
 Superb (3U) (02-08)	SEAT/MIRROR POS.	(..-08)	No CAN
 Superb (3U) (02-08)	SERVICE LIGHT RES	(..-08)	No CAN
 Superb (3U) (02-08)	SERVICE LIGHT RES	(..-08)	No CAN - KW 2000
 Superb (3U) (02-08)	STEERING WHEEL E	(..-08)	No CAN
 Superb (3U) (02-08)	SUPP HEATER/AUTO	(..-08)	No CAN
 Superb (3U) (02-08)	SUSPENSION CONTR	(..-08)	No CAN
 Superb (3U) (02-08)	TIRE PRESSURE	(..-08)	No CAN
 Superb (3U) (02-08)	TIRE PRESSURE	(..-08)	No CAN - KW 2000
 Superb (3U) (02-08)	TRACTION CONTROL	(..-08)	No CAN
 Yeti (5L) (10-..)	CENTRAL ELECTRIC	(10-..)	Diagnostic bus interface
 Yeti (5L) (10-..)	CHASSIS NETWORK	(10-..)	
 Yeti (5L) (10-..)	DASHBOARD	(10-..)	
 Yeti (5L) (10-..)	ENGINE MANAGEME	1.4 TSI 90 Kw (10-..)	CAXA
 Yeti (5L) (10-..)	MAINTENANCE	(10-..)	
 Yeti (5L) (10-..)	MAINTENANCE	(10-..)	
 Yeti (5L) (10-..)	MAINTENANCE	(10-..)	
 Yeti (5L) (10-..)	SERVICE LIGHT RES	(10-..)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Smart

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 forfour	ABS + TRACT. CONT	1.1 (04-..)	BOSCH ESP 00/01
 forfour	ABS + TRACT. CONT	1.3 (04-..)	BOSCH ESP 00/01
 forfour	ABS + TRACT. CONT	1.5 (04-..)	BOSCH ESP 00/01
 forfour	ABS + TRACT. CONT	1.5 cdi (04-..)	BOSCH ESP 00/01
 forfour	AIRBAG	1.1 (04-..)	TEMIC SRS No CAN
 forfour	AIRBAG	1.3 (04-..)	TEMIC SRS No CAN
 forfour	AIRBAG	1.5 (04-..)	TEMIC SRS No CAN
 forfour	AIRBAG	1.5 cdi (04-..)	TEMIC SRS No CAN
 forfour	ENGINE MANAGEME	1.1 (01-..)	EOBD
 forfour	ENGINE MANAGEME	1.3 (01-..)	EOBD
 forfour	ENGINE MANAGEME	1.5 (04-..)	EOBD
 forfour	ENGINE MANAGEME	1.5 cdi (01-..)	EOBD
 forfour	MAINTENANCE	1.1 (04-..)	BOSCH ESP 00/01
 forfour	MAINTENANCE	1.1 (98-06)	MANUAL
 forfour	MAINTENANCE	1.3 (04-..)	BOSCH ESP 00/01
 forfour	MAINTENANCE	1.3 (98-06)	MANUAL
 forfour	MAINTENANCE	1.5 (04-..)	BOSCH ESP 00/01
 forfour	MAINTENANCE	1.5 (98-06)	MANUAL
 forfour	MAINTENANCE	1.5 cdi (04-..)	BOSCH ESP 00/01
 forfour	MAINTENANCE	1.5 cdi (98-06)	MANUAL
 forfour	SERVICE LIGHT RES	1.1 (98-06)	MANUAL
 forfour	SERVICE LIGHT RES	1.3 (98-06)	MANUAL
 forfour	SERVICE LIGHT RES	1.5 (98-06)	MANUAL
 forfour	SERVICE LIGHT RES	1.5 cdi (98-06)	MANUAL
 fortwo 450 (98-06)	ABS	0.6 33 kw (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	ABS	0.6 45 kw (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	ABS	0.7 40 kw EURO 3 (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	ABS	0.7 40 kw EURO 4 (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	ABS	0.7 45 kw EURO 3 (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	ABS	0.7 45 kw EURO 4 (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	ABS	0.8 cdi 30 kw (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	ABS + TRACT. CONT	0.6 33 kw (03-05)	BOSCH ESP 450
 fortwo 450 (98-06)	ABS + TRACT. CONT	0.6 33 kw (06-..)	BOSCH ESP 00/01
 fortwo 450 (98-06)	ABS + TRACT. CONT	0.6 45 kw (03-05)	BOSCH ESP 450
 fortwo 450 (98-06)	ABS + TRACT. CONT	0.6 45 kw (06-..)	BOSCH ESP 00/01
 fortwo 450 (98-06)	ABS + TRACT. CONT	0.7 40 kw EURO 3 (03-05)	BOSCH ESP 450
 fortwo 450 (98-06)	ABS + TRACT. CONT	0.7 40 kw EURO 3 (06-..)	BOSCH ESP 00/01
 fortwo 450 (98-06)	ABS + TRACT. CONT	0.7 40 kw EURO 4 (03-05)	BOSCH ESP 450
 fortwo 450 (98-06)	ABS + TRACT. CONT	0.7 40 kw EURO 4 (06-..)	BOSCH ESP 00/01
 fortwo 450 (98-06)	ABS + TRACT. CONT	0.7 45 kw EURO 3 (03-05)	BOSCH ESP 450
 fortwo 450 (98-06)	ABS + TRACT. CONT	0.7 45 kw EURO 3 (06-..)	BOSCH ESP 00/01
 fortwo 450 (98-06)	ABS + TRACT. CONT	0.7 45 kw EURO 4 (03-05)	BOSCH ESP 450
 fortwo 450 (98-06)	ABS + TRACT. CONT	0.7 45 kw EURO 4 (06-..)	BOSCH ESP 00/01
 fortwo 450 (98-06)	ABS + TRACT. CONT	0.8 cdi 30 kw (03-05)	BOSCH ESP 450
 fortwo 450 (98-06)	ABS + TRACT. CONT	0.8 cdi 30 kw (06-..)	BOSCH ESP 00/01
 fortwo 450 (98-06)	AIRBAG	0.6 33 kw (98-..)	TEMIC SRS No CAN
 fortwo 450 (98-06)	AIRBAG	0.6 45 kw (98-..)	TEMIC SRS No CAN
 fortwo 450 (98-06)	AIRBAG	0.7 40 kw EURO 3 (98-..)	TEMIC SRS No CAN
 fortwo 450 (98-06)	AIRBAG	0.7 40 kw EURO 4 (98-..)	TEMIC SRS No CAN
 fortwo 450 (98-06)	AIRBAG	0.7 45 kw EURO 3 (98-..)	TEMIC SRS No CAN
 fortwo 450 (98-06)	AIRBAG	0.7 45 kw EURO 4 (98-..)	TEMIC SRS No CAN
 fortwo 450 (98-06)	AIRBAG	0.8 cdi 30 kw (98-..)	TEMIC SRS No CAN
 fortwo 450 (98-06)	AUTOM. TRANSMISSI	0.6 33 kw (04-06)	EDG Getriebe
 fortwo 450 (98-06)	AUTOM. TRANSMISSI	0.6 33 kw (04-06)	EDG Selector Lever
 fortwo 450 (98-06)	AUTOM. TRANSMISSI	0.6 45 kw (04-06)	EDG Getriebe
 fortwo 450 (98-06)	AUTOM. TRANSMISSI	0.6 45 kw (04-06)	EDG Selector Lever
 fortwo 450 (98-06)	AUTOM. TRANSMISSI	0.7 40 kw EURO 3 (04-06)	EDG Getriebe
 fortwo 450 (98-06)	AUTOM. TRANSMISSI	0.7 40 kw EURO 3 (04-06)	EDG Selector Lever

Systems supported by ECUREADER / ECUDECODER (up to V6.90)

CARS

Smart

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 fortwo 450 (98-06)	AUTOM. TRANSMISSI	0.7 40 kw EURO 4 (04-06)	EDG Getriebe
 fortwo 450 (98-06)	AUTOM. TRANSMISSI	0.7 40 kw EURO 4 (04-06)	EDG Selector Lever
 fortwo 450 (98-06)	AUTOM. TRANSMISSI	0.7 45 kw EURO 3 (04-06)	EDG Getriebe
 fortwo 450 (98-06)	AUTOM. TRANSMISSI	0.7 45 kw EURO 3 (04-06)	EDG Selector Lever
 fortwo 450 (98-06)	AUTOM. TRANSMISSI	0.7 45 kw EURO 4 (04-06)	EDG Getriebe
 fortwo 450 (98-06)	AUTOM. TRANSMISSI	0.7 45 kw EURO 4 (04-06)	EDG Selector Lever
 fortwo 450 (98-06)	AUTOM. TRANSMISSI	0.8 cdi 30 kw (04-06)	EDG Getriebe
 fortwo 450 (98-06)	AUTOM. TRANSMISSI	0.8 cdi 30 kw (04-06)	EDG Selector Lever
 fortwo 450 (98-06)	CHASSIS NETWORK	0.6 33 kw (04-..)	Central Electronic SAM
 fortwo 450 (98-06)	CHASSIS NETWORK	0.6 33 kw (98-..)	Body Computer ZEE
 fortwo 450 (98-06)	CHASSIS NETWORK	0.6 45 kw (04-..)	Central Electronic SAM
 fortwo 450 (98-06)	CHASSIS NETWORK	0.6 45 kw (98-..)	Body Computer ZEE
 fortwo 450 (98-06)	CHASSIS NETWORK	0.7 40 kw EURO 3 (04-..)	Central Electronic SAM
 fortwo 450 (98-06)	CHASSIS NETWORK	0.7 40 kw EURO 3 (98-..)	Body Computer ZEE
 fortwo 450 (98-06)	CHASSIS NETWORK	0.7 40 kw EURO 4 (04-..)	Central Electronic SAM
 fortwo 450 (98-06)	CHASSIS NETWORK	0.7 40 kw EURO 4 (98-..)	Body Computer ZEE
 fortwo 450 (98-06)	CHASSIS NETWORK	0.7 45 kw EURO 3 (04-..)	Central Electronic SAM
 fortwo 450 (98-06)	CHASSIS NETWORK	0.7 45 kw EURO 3 (98-..)	Body Computer ZEE
 fortwo 450 (98-06)	CHASSIS NETWORK	0.7 45 kw EURO 4 (04-..)	Central Electronic SAM
 fortwo 450 (98-06)	CHASSIS NETWORK	0.7 45 kw EURO 4 (98-..)	Body Computer ZEE
 fortwo 450 (98-06)	CHASSIS NETWORK	0.8 cdi 30 kw (04-..)	Central Electronic SAM
 fortwo 450 (98-06)	CHASSIS NETWORK	0.8 cdi 30 kw (98-..)	Body Computer ZEE
 fortwo 450 (98-06)	CLIMA	0.6 33 kw (04-06)	
 fortwo 450 (98-06)	CLIMA	0.6 45 kw (04-06)	
 fortwo 450 (98-06)	CLIMA	0.7 40 kw EURO 3 (04-06)	
 fortwo 450 (98-06)	CLIMA	0.7 40 kw EURO 4 (04-06)	
 fortwo 450 (98-06)	CLIMA	0.7 45 kw EURO 3 (04-06)	
 fortwo 450 (98-06)	CLIMA	0.7 45 kw EURO 4 (04-06)	
 fortwo 450 (98-06)	CLIMA	0.8 cdi 30 kw (04-06)	
 fortwo 450 (98-06)	CLUTCH ELECTRONI	0.6 33 kw (04-06)	EDG Electronic Clutch
 fortwo 450 (98-06)	CLUTCH ELECTRONI	0.6 45 kw (04-06)	EDG Electronic Clutch
 fortwo 450 (98-06)	CLUTCH ELECTRONI	0.7 40 kw EURO 3 (04-06)	EDG Electronic Clutch
 fortwo 450 (98-06)	CLUTCH ELECTRONI	0.7 40 kw EURO 4 (04-06)	EDG Electronic Clutch
 fortwo 450 (98-06)	CLUTCH ELECTRONI	0.7 45 kw EURO 3 (04-06)	EDG Electronic Clutch
 fortwo 450 (98-06)	CLUTCH ELECTRONI	0.7 45 kw EURO 4 (04-06)	EDG Electronic Clutch
 fortwo 450 (98-06)	CLUTCH ELECTRONI	0.8 cdi 30 kw (04-06)	EDG Electronic Clutch
 fortwo 450 (98-06)	DASHBOARD	0.6 33 kw (98-..)	Kombinstrum. x.x
 fortwo 450 (98-06)	DASHBOARD	0.6 45 kw (98-..)	Kombinstrum. x.x
 fortwo 450 (98-06)	DASHBOARD	0.7 40 kw EURO 3 (98-..)	Kombinstrum. x.x
 fortwo 450 (98-06)	DASHBOARD	0.7 40 kw EURO 4 (98-..)	Kombinstrum. x.x
 fortwo 450 (98-06)	DASHBOARD	0.7 45 kw EURO 3 (98-..)	Kombinstrum. x.x
 fortwo 450 (98-06)	DASHBOARD	0.7 45 kw EURO 4 (98-..)	Kombinstrum. x.x
 fortwo 450 (98-06)	DASHBOARD	0.8 cdi 30 kw (98-..)	Kombinstrum. x.x
 fortwo 450 (98-06)	ENGINE MANAGEME	0.6 33 kw (00-..)	EOBD
 fortwo 450 (98-06)	ENGINE MANAGEME	0.6 33 kw (98-03)	BOSCH MPI 1 MEG
 fortwo 450 (98-06)	ENGINE MANAGEME	0.6 33 kw (98-03)	BOSCH MPI 2 MEG
 fortwo 450 (98-06)	ENGINE MANAGEME	0.6 45 kw (01-..)	EOBD
 fortwo 450 (98-06)	ENGINE MANAGEME	0.6 45 kw (98-03)	BOSCH MPI 1 MEG
 fortwo 450 (98-06)	ENGINE MANAGEME	0.6 45 kw (98-03)	BOSCH MPI 2 MEG
 fortwo 450 (98-06)	ENGINE MANAGEME	0.7 40 kw EURO 3 (04-..)	BOSCH MPI 1 MEG
 fortwo 450 (98-06)	ENGINE MANAGEME	0.7 40 kw EURO 3 (04-..)	BOSCH MPI 2 MEG
 fortwo 450 (98-06)	ENGINE MANAGEME	0.7 40 kw EURO 4 (04-..)	BOSCH MPI 1 MEG
 fortwo 450 (98-06)	ENGINE MANAGEME	0.7 40 kw EURO 4 (04-..)	BOSCH MPI 2 MEG
 fortwo 450 (98-06)	ENGINE MANAGEME	0.7 45 kw EURO 3 (04-..)	BOSCH MPI 1 MEG
 fortwo 450 (98-06)	ENGINE MANAGEME	0.7 45 kw EURO 3 (04-..)	BOSCH MPI 2 MEG
 fortwo 450 (98-06)	ENGINE MANAGEME	0.7 45 kw EURO 4 (04-..)	BOSCH MPI 1 MEG
 fortwo 450 (98-06)	ENGINE MANAGEME	0.7 45 kw EURO 4 (04-..)	BOSCH MPI 2 MEG
 fortwo 450 (98-06)	ENGINE MANAGEME	0.8 cdi 30 kw (04-06)	BOSCH EDG Common Rail

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Smart

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 fortwo 450 (98-06)	MAINTENANCE	0.6 33 kw	MANUAL
 fortwo 450 (98-06)	MAINTENANCE	0.6 33 kw (03-05)	BOSCH ESP 450
 fortwo 450 (98-06)	MAINTENANCE	0.6 33 kw (06-..)	BOSCH ESP 00/01
 fortwo 450 (98-06)	MAINTENANCE	0.6 33 kw (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	MAINTENANCE	0.6 33 kw (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	MAINTENANCE	0.6 33 kw (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	MAINTENANCE	0.6 33 kw (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	MAINTENANCE	0.6 33 kw (98-06)	MANUAL
 fortwo 450 (98-06)	MAINTENANCE	0.6 45 kw	MANUAL
 fortwo 450 (98-06)	MAINTENANCE	0.6 45 kw (03-05)	BOSCH ESP 450
 fortwo 450 (98-06)	MAINTENANCE	0.6 45 kw (06-..)	BOSCH ESP 00/01
 fortwo 450 (98-06)	MAINTENANCE	0.6 45 kw (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	MAINTENANCE	0.6 45 kw (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	MAINTENANCE	0.6 45 kw (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	MAINTENANCE	0.6 45 kw (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	MAINTENANCE	0.6 45 kw (98-06)	MANUAL
 fortwo 450 (98-06)	MAINTENANCE	0.7 40 kw EURO 3	MANUAL
 fortwo 450 (98-06)	MAINTENANCE	0.7 40 kw EURO 3 (03-05)	BOSCH ESP 450
 fortwo 450 (98-06)	MAINTENANCE	0.7 40 kw EURO 3 (06-..)	BOSCH ESP 00/01
 fortwo 450 (98-06)	MAINTENANCE	0.7 40 kw EURO 3 (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	MAINTENANCE	0.7 40 kw EURO 3 (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	MAINTENANCE	0.7 40 kw EURO 3 (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	MAINTENANCE	0.7 40 kw EURO 3 (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	MAINTENANCE	0.7 40 kw EURO 3 (98-06)	MANUAL
 fortwo 450 (98-06)	MAINTENANCE	0.7 40 kw EURO 4	MANUAL
 fortwo 450 (98-06)	MAINTENANCE	0.7 40 kw EURO 4 (03-05)	BOSCH ESP 450
 fortwo 450 (98-06)	MAINTENANCE	0.7 40 kw EURO 4 (06-..)	BOSCH ESP 00/01
 fortwo 450 (98-06)	MAINTENANCE	0.7 40 kw EURO 4 (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	MAINTENANCE	0.7 40 kw EURO 4 (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	MAINTENANCE	0.7 40 kw EURO 4 (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	MAINTENANCE	0.7 40 kw EURO 4 (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	MAINTENANCE	0.7 40 kw EURO 4 (98-06)	MANUAL
 fortwo 450 (98-06)	MAINTENANCE	0.7 45 kw EURO 3	MANUAL
 fortwo 450 (98-06)	MAINTENANCE	0.7 45 kw EURO 3 (03-05)	BOSCH ESP 450
 fortwo 450 (98-06)	MAINTENANCE	0.7 45 kw EURO 3 (06-..)	BOSCH ESP 00/01
 fortwo 450 (98-06)	MAINTENANCE	0.7 45 kw EURO 3 (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	MAINTENANCE	0.7 45 kw EURO 3 (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	MAINTENANCE	0.7 45 kw EURO 3 (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	MAINTENANCE	0.7 45 kw EURO 3 (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	MAINTENANCE	0.7 45 kw EURO 3 (98-06)	MANUAL
 fortwo 450 (98-06)	MAINTENANCE	0.7 45 kw EURO 4	MANUAL
 fortwo 450 (98-06)	MAINTENANCE	0.7 45 kw EURO 4 (03-05)	BOSCH ESP 450
 fortwo 450 (98-06)	MAINTENANCE	0.7 45 kw EURO 4 (06-..)	BOSCH ESP 00/01
 fortwo 450 (98-06)	MAINTENANCE	0.7 45 kw EURO 4 (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	MAINTENANCE	0.7 45 kw EURO 4 (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	MAINTENANCE	0.7 45 kw EURO 4 (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	MAINTENANCE	0.7 45 kw EURO 4 (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	MAINTENANCE	0.7 45 kw EURO 4 (98-06)	MANUAL
 fortwo 450 (98-06)	MAINTENANCE	0.8 cdi 30 kw	MANUAL
 fortwo 450 (98-06)	MAINTENANCE	0.8 cdi 30 kw (03-05)	BOSCH ESP 450
 fortwo 450 (98-06)	MAINTENANCE	0.8 cdi 30 kw (06-..)	BOSCH ESP 00/01
 fortwo 450 (98-06)	MAINTENANCE	0.8 cdi 30 kw (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	MAINTENANCE	0.8 cdi 30 kw (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	MAINTENANCE	0.8 cdi 30 kw (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	MAINTENANCE	0.8 cdi 30 kw (98-04)	BOSCH ABS 450
 fortwo 450 (98-06)	MAINTENANCE	0.8 cdi 30 kw (98-06)	MANUAL
 fortwo 450 (98-06)	SERVICE LIGHT RES	0.6 33 kw	MANUAL
 fortwo 450 (98-06)	SERVICE LIGHT RES	0.6 33 kw (98-06)	MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Smart

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 fortwo 450 (98-06)	SERVICE LIGHT RES	0.6 45 kw	MANUAL
 fortwo 450 (98-06)	SERVICE LIGHT RES	0.6 45 kw (98-06)	MANUAL
 fortwo 450 (98-06)	SERVICE LIGHT RES	0.7 40 kw EURO 3	MANUAL
 fortwo 450 (98-06)	SERVICE LIGHT RES	0.7 40 kw EURO 3 (98-06)	MANUAL
 fortwo 450 (98-06)	SERVICE LIGHT RES	0.7 40 kw EURO 4	MANUAL
 fortwo 450 (98-06)	SERVICE LIGHT RES	0.7 40 kw EURO 4 (98-06)	MANUAL
 fortwo 450 (98-06)	SERVICE LIGHT RES	0.7 45 kw EURO 3	MANUAL
 fortwo 450 (98-06)	SERVICE LIGHT RES	0.7 45 kw EURO 3 (98-06)	MANUAL
 fortwo 450 (98-06)	SERVICE LIGHT RES	0.7 45 kw EURO 4	MANUAL
 fortwo 450 (98-06)	SERVICE LIGHT RES	0.7 45 kw EURO 4 (98-06)	MANUAL
 fortwo 450 (98-06)	SERVICE LIGHT RES	0.8 cdi 30 kw	MANUAL
 fortwo 450 (98-06)	SERVICE LIGHT RES	0.8 cdi 30 kw (98-06)	MANUAL
 fortwo 451 (07-..)	ABS + TRACT. CONT	0.8 cdi FAP 33 kw	BOSCH ESP 00/01
 fortwo 451 (07-..)	ABS + TRACT. CONT	1.0 52kw	BOSCH ESP 00/01
 fortwo 451 (07-..)	ABS + TRACT. CONT	1.0 62 kw EURO 4	BOSCH ESP 00/01
 fortwo 451 (07-..)	ABS + TRACT. CONT	1.0 62kw	BOSCH ESP 00/01
 fortwo 451 (07-..)	AIRBAG	0.8 cdi FAP 33 kw	TRW SRS 31/34
 fortwo 451 (07-..)	AIRBAG	1.0 52kw	TRW SRS 31/34
 fortwo 451 (07-..)	AIRBAG	1.0 62 kw EURO 4	TRW SRS 31/34
 fortwo 451 (07-..)	AIRBAG	1.0 62kw	TRW SRS 31/34
 fortwo 451 (07-..)	CLIMA	0.8 cdi FAP 33 kw	HELLA KLA 07/00
 fortwo 451 (07-..)	CLIMA	1.0 52kw	HELLA KLA 07/00
 fortwo 451 (07-..)	CLIMA	1.0 62 kw EURO 4	HELLA KLA 07/00
 fortwo 451 (07-..)	CLIMA	1.0 62kw	HELLA KLA 07/00
 fortwo 451 (07-..)	ENGINE MANAGEME	0.8 cdi FAP 33 kw	EOBD
 fortwo 451 (07-..)	ENGINE MANAGEME	1.0 52kw	BOSCH MPI
 fortwo 451 (07-..)	ENGINE MANAGEME	1.0 62 kw EURO 4	BOSCH MPI
 fortwo 451 (07-..)	ENGINE MANAGEME	1.0 62kw	EOBD
 fortwo 451 (07-..)	MAINTENANCE	0.8 cdi FAP 33 kw	BOSCH ESP 00/01
 fortwo 451 (07-..)	MAINTENANCE	0.8 cdi FAP 33 kw	MANUAL
 fortwo 451 (07-..)	MAINTENANCE	1.0 52kw	BOSCH ESP 00/01
 fortwo 451 (07-..)	MAINTENANCE	1.0 52kw	MANUAL
 fortwo 451 (07-..)	MAINTENANCE	1.0 62 kw EURO 4	BOSCH ESP 00/01
 fortwo 451 (07-..)	MAINTENANCE	1.0 62 kw EURO 4	MANUAL
 fortwo 451 (07-..)	MAINTENANCE	1.0 62kw	BOSCH ESP 00/01
 fortwo 451 (07-..)	MAINTENANCE	1.0 62kw	MANUAL
 fortwo 451 (07-..)	SERVICE LIGHT RES	0.8 cdi FAP 33 kw	MANUAL
 fortwo 451 (07-..)	SERVICE LIGHT RES	1.0 52kw	MANUAL
 fortwo 451 (07-..)	SERVICE LIGHT RES	1.0 62 kw EURO 4	MANUAL
 fortwo 451 (07-..)	SERVICE LIGHT RES	1.0 62kw	MANUAL
 roadster	ABS + TRACT. CONT	0.7 (03-05)	BOSCH ESP 450
 roadster	ENGINE MANAGEME	0.7 (03-05)	EOBD
 roadster	MAINTENANCE	0.7 (03-05)	BOSCH ESP 450
 roadster	MAINTENANCE	0.7 (98-06)	MANUAL
 roadster	SERVICE LIGHT RES	0.7 (98-06)	MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS			Subaru
MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Forester	ENGINE MANAGEME	2.0 130kw ST (01-...)	EOBD
 Forester	ENGINE MANAGEME	2.0 92kw (01-..)	EOBD
 Impreza	ENGINE MANAGEME	1.6 70kw (01-..)	EOBD
 Impreza	ENGINE MANAGEME	2.0 92kw (01-..)	EOBD
 Impreza	ENGINE MANAGEME	2.0 WRX 160kw (01-..)	EOBD
 Impreza	ENGINE MANAGEME	2.0 WRX Sti 195kw (01-..)	EOBD
 Justy	ENGINE MANAGEME	1.2 i.e. EF12 (91-95)	Subaru MFI-s MANUAL MPFI
 Justy	ENGINE MANAGEME	1.3 63kw (01-..)	EOBD
 Justy	MAINTENANCE	1.2 i.e. EF12 (91-95)	Subaru MFI-s MANUAL MPFI
 Legacy	ENGINE MANAGEME	2.0 92kw (01-..)	EOBD
 Legacy	ENGINE MANAGEME	2.5 115kw (01-..)	EOBD
 Outback	ENGINE MANAGEME	2.5 115kw (01-..)	EOBD
 Outback	ENGINE MANAGEME	3.0 154kw (01-..)	EOBD

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Suzuki

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Alto	ENGINE MANAGEME	1.1 Maruti (02-..)	EOBD
 Baleno	ENGINE MANAGEME	1.3 (01-..)	EOBD
 Baleno	ENGINE MANAGEME	1.6 (01-..)	EOBD
 Carry	ENGINE MANAGEME	1.3 (01-..)	EOBD
 Grand Vitara	4WD ELECTRONICS	1.6 VVT 16v (05-..)	4WD
 Grand Vitara	4WD ELECTRONICS	1.9 DDiS (05-..)	4WD
 Grand Vitara	4WD ELECTRONICS	2.0 L (05-..)	4WD
 Grand Vitara	ABS	1.6 VVT 16v (05-..)	ATE ABS
 Grand Vitara	ABS	1.9 DDiS (05-..)	ATE ABS
 Grand Vitara	ABS	2.0 L (05-..)	ATE ABS
 Grand Vitara	AIRBAG	1.6 VVT 16v (05-..)	AirBag No side AirBag
 Grand Vitara	AIRBAG	1.6 VVT 16v (05-..)	AirBag Side AirBag
 Grand Vitara	AIRBAG	1.9 DDiS (05-..)	AirBag No side AirBag
 Grand Vitara	AIRBAG	1.9 DDiS (05-..)	AirBag Side AirBag
 Grand Vitara	AIRBAG	2.0 L (05-..)	AirBag No side AirBag
 Grand Vitara	AIRBAG	2.0 L (05-..)	AirBag Side AirBag
 Grand Vitara	CHASSIS NETWORK	1.6 VVT 16v (05-..)	Body Computer BCM
 Grand Vitara	CHASSIS NETWORK	1.9 DDiS (05-..)	Body Computer BCM
 Grand Vitara	CHASSIS NETWORK	2.0 L (05-..)	Body Computer BCM
 Grand Vitara	CLIMA	1.6 VVT 16v (05-..)	Header Klima Manual HVAC
 Grand Vitara	CLIMA	1.6 VVT 16v (05-..)	Header Klimautomatik HVAC
 Grand Vitara	CLIMA	1.9 DDiS (05-..)	Header Klima Manual HVAC
 Grand Vitara	CLIMA	1.9 DDiS (05-..)	Header Klimautomatik HVAC
 Grand Vitara	CLIMA	2.0 L (05-..)	Header Klima Manual HVAC
 Grand Vitara	CLIMA	2.0 L (05-..)	Header Klimautomatik HVAC
 Grand Vitara	ENGINE MANAGEME	1.6 VVT 16v (05-..)	EOBD
 Grand Vitara	ENGINE MANAGEME	1.9 DDiS F9Q (05-..)	BOSCH EDC Common Rail
 Grand Vitara	ENGINE MANAGEME	2.0 L (01-..)	EOBD
 Grand Vitara	ENGINE MANAGEME	2.0 L J20A (01-..)	EOBD
 Grand Vitara	ENGINE MANAGEME	2.0 TD Common Rail RHZ (01-..)	BOSCH EDC Common Rail
 Grand Vitara	ENGINE MANAGEME	2.0 TD Common Rail RHZ (01-..)	SIEMENS Diesel SID 801 Common Rail
 Grand Vitara	ENGINE MANAGEME	2.5 V6 106kw (01-..)	EOBD
 Grand Vitara	ENGINE MANAGEME	2.7 V6 127kw (01-..)	EOBD
 Grand Vitara	IMMOBILIZER	1.6 VVT 16v (05-..)	
 Grand Vitara	IMMOBILIZER	1.9 DDiS (05-..)	
 Grand Vitara	IMMOBILIZER	2.0 L (05-..)	
 Grand Vitara	MAINTENANCE	1.6 VVT 16v (05-..)	ATE ESP 2WD
 Grand Vitara	MAINTENANCE	1.6 VVT 16v (05-..)	ATE ESP 4WD
 Grand Vitara	MAINTENANCE	1.9 DDiS (05-..)	ATE ESP 2WD
 Grand Vitara	MAINTENANCE	1.9 DDiS (05-..)	ATE ESP 4WD
 Grand Vitara	MAINTENANCE	2.0 L (05-..)	ATE ESP 2WD
 Grand Vitara	MAINTENANCE	2.0 L (05-..)	ATE ESP 4WD
 Grand Vitara	TRACTION CONTROL	1.6 VVT 16v (05-..)	ATE ESP 2WD
 Grand Vitara	TRACTION CONTROL	1.6 VVT 16v (05-..)	ATE ESP 4WD
 Grand Vitara	TRACTION CONTROL	1.9 DDiS (05-..)	ATE ESP 2WD
 Grand Vitara	TRACTION CONTROL	1.9 DDiS (05-..)	ATE ESP 4WD
 Grand Vitara	TRACTION CONTROL	2.0 L (05-..)	ATE ESP 2WD
 Grand Vitara	TRACTION CONTROL	2.0 L (05-..)	ATE ESP 4WD
 Ignis	ENGINE MANAGEME	1.3 61 kw (01-..)	EOBD
 Ignis	ENGINE MANAGEME	1.3 DDiS 16v Z13DT (04-05)	Marelli 6JF Common Rail
 Ignis	ENGINE MANAGEME	1.3 DDiS 16v Z13DT (06-..)	Marelli 6JF Common Rail
 Ignis	ENGINE MANAGEME	1.3 Rallye Sport M13A (02-..)	EOBD
 Jimny	ABS	1.3 59kw (04-06)	ABS
 Jimny	ABS	1.3 60kw (04-06)	ABS
 Jimny	ABS	1.3 i 16v (04-06)	ABS
 Jimny	ABS	1.5 DDiS (04-06)	ABS
 Jimny	AIRBAG	1.3 i 16v (04-06)	AirBag

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Suzuki

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Jimny	AIRBAG	1.5 DDiS (04-06)	AirBag
 Jimny	ENGINE MANAGEME	1.3 59kw (01-..)	EOBD
 Jimny	ENGINE MANAGEME	1.3 60kw (01-..)	EOBD
 Jimny	ENGINE MANAGEME	1.3 i 16v (04-06)	EOBD
 Jimny	ENGINE MANAGEME	1.5 DDiS K9K (04-06)	DELPHI LUCAS LVCR Common Rail
 Jimny	IMMOBILIZER	1.3 i 16v (04-06)	
 Jimny	IMMOBILIZER	1.5 DDiS (04-06)	
 Liana	ABS	1.3 66kw	Nissinbo ABS ABS/EBD
 Liana	ABS	1.4 DDiS 16v	Nissinbo ABS ABS/EBD
 Liana	ABS	1.6	Nissinbo ABS ABS/EBD
 Liana	ENGINE MANAGEME	1.3 66kw (01-..)	EOBD
 Liana	ENGINE MANAGEME	1.4 DDiS 16v 8HY (04-..)	DELPHI C6 Common Rail
 Liana	ENGINE MANAGEME	1.6 M16A	DENSO EU MT 2WD
 Liana	ENGINE MANAGEME	1.6 M16A (01-..)	EOBD
 Samurai	ENGINE MANAGEME	1.9 D	LUCAS Diesel DCU3R
 Splash	ABS + TRACT. CONT	1.0 12v (08-..)	
 Splash	ABS + TRACT. CONT	1.2 16v (08-..)	
 Splash	ABS + TRACT. CONT	1.3 DDiS (08-..)	
 Splash	AIRBAG	1.0 12v (08-..)	
 Splash	AIRBAG	1.2 16v (08-..)	
 Splash	AIRBAG	1.3 DDiS (08-..)	
 Splash	CHASSIS NETWORK	1.0 12v (08-..)	
 Splash	CHASSIS NETWORK	1.2 16v (08-..)	
 Splash	CHASSIS NETWORK	1.3 DDiS (08-..)	
 Splash	ELECTRIC STEERING	1.0 12v (08-..)	
 Splash	ENGINE MANAGEME	1.0 12v (08-..)	
 Splash	ENGINE MANAGEME	1.0 12v (08-..)	EOBD
 Splash	ENGINE MANAGEME	1.2 16v (08-..)	
 Splash	ENGINE MANAGEME	1.3 DDiS (08-..)	EOBD
 Splash	MAINTENANCE	1.0 12v (08-..)	
 Splash	MAINTENANCE	1.2 16v (08-..)	
 Splash	MAINTENANCE	1.3 DDiS (08-..)	
 Swift	ABS	1.3 16v (05-..)	ATE ABS
 Swift	ABS	1.3 DDiS 16v (05-..)	ATE ABS
 Swift	ABS	1.3 DDiS 16v FAP (05-..)	ATE ABS
 Swift	AIRBAG	1.3 16v (05-..)	AirBag No side AirBag
 Swift	AIRBAG	1.3 16v (05-..)	AirBag Side AirBag
 Swift	AIRBAG	1.3 DDiS 16v (05-..)	AirBag No side AirBag
 Swift	AIRBAG	1.3 DDiS 16v (05-..)	AirBag Side AirBag
 Swift	AIRBAG	1.3 DDiS 16v FAP (05-..)	AirBag No side AirBag
 Swift	AIRBAG	1.3 DDiS 16v FAP (05-..)	AirBag Side AirBag
 Swift	CHASSIS NETWORK	1.3 16v (05-..)	Body Computer
 Swift	CHASSIS NETWORK	1.3 DDiS 16v (05-..)	Body Computer
 Swift	CHASSIS NETWORK	1.3 DDiS 16v FAP (05-..)	Body Computer
 Swift	ELECTRIC STEERING	1.3 16v (05-..)	EPS
 Swift	ELECTRIC STEERING	1.3 DDiS 16v (05-..)	EPS
 Swift	ELECTRIC STEERING	1.3 DDiS 16v FAP (05-..)	EPS
 Swift	ENGINE MANAGEME	1.0 (01-..)	EOBD
 Swift	ENGINE MANAGEME	1.3 16v M13A (05-..)	DENSO MPI A/T M/T
 Swift	ENGINE MANAGEME	1.3 16v M13A (05-..)	DENSO MPI M/T
 Swift	ENGINE MANAGEME	1.3 DDiS 16v FAP D13A (08-..)	
 Swift	ENGINE MANAGEME	1.3 DDiS 16v Z13DT (04-05)	Marelli 6JF Common Rail
 Swift	ENGINE MANAGEME	1.3 DDiS 16v Z13DT (06-..)	Marelli 6JF Common Rail
 Swift	IMMOBILIZER	1.3 16v (05-..)	
 Swift	IMMOBILIZER	1.3 DDiS 16v (05-..)	
 Swift	IMMOBILIZER	1.3 DDiS 16v FAP (05-..)	
 Swift	MAINTENANCE	1.3 16v M13A (05-..)	DENSO MPI A/T M/T

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Suzuki

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Swift	MAINTENANCE	1.3 16v M13A (05-..)	DENSO MPI M/T
 Swift	MAINTENANCE	1.3 DDiS 16v FAP D13A (08-..)	
 Swift	MAINTENANCE	1.3 DDiS 16v FAP D13A (08-..)	
 Swift	MAINTENANCE	1.3 DDiS 16v FAP D13A (08-..)	
 SX4	4WD ELECTRONICS	1.6 16v (06-..)	TC
 SX4	4WD ELECTRONICS	1.9 DDiS 16v (06-..)	TC
 SX4	ABS	1.6 16v (06-..)	ABS
 SX4	ABS	1.9 DDiS 16v (06-..)	ABS
 SX4	AIRBAG	1.6 16v (06-..)	SRS No Side AirBag
 SX4	AIRBAG	1.6 16v (06-..)	SRS Side AirBag
 SX4	AIRBAG	1.6 16v (06-..)	SRS Side AirBag-Side curtain AirBag
 SX4	AIRBAG	1.9 DDiS 16v (06-..)	SRS No Side AirBag
 SX4	AIRBAG	1.9 DDiS 16v (06-..)	SRS Side AirBag
 SX4	AIRBAG	1.9 DDiS 16v (06-..)	SRS Side AirBag-Side curtain AirBag
 SX4	CHASSIS NETWORK	1.6 16v (06-..)	Body Computer BCM
 SX4	CHASSIS NETWORK	1.9 DDiS 16v (06-..)	Body Computer BCM
 SX4	ELECTRIC STEERING	1.6 16v (06-..)	EPS TSM
 SX4	ELECTRIC STEERING	1.9 DDiS 16v (06-..)	EPS TSM
 SX4	ENGINE MANAGEME	1.6 16v	DENSO MPI SZK
 SX4	ENGINE MANAGEME	1.9 DDiS 16v	BOSCH EDC 16 Common Rail M-Jet
 SX4	IMMOBILIZER	1.6 16v (06-..)	CODE
 SX4	IMMOBILIZER	1.9 DDiS 16v (06-..)	CODE
 SX4	MAINTENANCE	1.9 DDiS 16v	BOSCH EDC 16 Common Rail M-Jet
 SX4	MAINTENANCE	1.9 DDiS 16v	BOSCH EDC 16 Common Rail M-Jet
 Vitara	ENGINE MANAGEME	2.0 TD Common Rail RHZ (01-..)	BOSCH EDC Common Rail
 Vitara	ENGINE MANAGEME	2.0 TD Common Rail RHZ (01-..)	SIEMENS Diesel SID 801 Common Rail
 Wagon R+	ENGINE MANAGEME	1.3 (01-..)	EOBD
 Wagon R+	ENGINE MANAGEME	1.3 DDiS 16v Z13DT (04-05)	Marelli 6JF Common Rail
 Wagon R+	ENGINE MANAGEME	1.3 DDiS 16v Z13DT (06-..)	Marelli 6JF Common Rail

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS			Tata
MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 146	ABS	1.3 / 1.4	BOSCH ABS 5.3
 Indica	DIESEL MANAGEMEN	1.4 D	LUCAS Diesel DCN2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Toyota

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Auris	MAINTENANCE	1.4 16v (07-09)	
 Auris	MAINTENANCE	1.4 D-4D (07-09)	
 Auris	MAINTENANCE	1.6 16v (07-09)	
 Auris	MAINTENANCE	2.0 D-4D (07-09)	
 Auris	MAINTENANCE	2.2 D-4D (07-09)	
 Auris	SERVICE LIGHT RES	1.4 16v (07-09)	
 Auris	SERVICE LIGHT RES	1.4 D-4D (07-09)	
 Auris	SERVICE LIGHT RES	1.6 16v (07-09)	
 Auris	SERVICE LIGHT RES	2.0 D-4D (07-09)	
 Auris	SERVICE LIGHT RES	2.2 D-4D (07-09)	
 Avensis (03-08)	ENGINE MANAGEME	1.6 VVT-i (03-08)	EOBD
 Avensis (03-08)	ENGINE MANAGEME	1.8 16v (03-08)	EOBD
 Avensis (03-08)	ENGINE MANAGEME	2.0 D-4D (03-08)	Denso EDC Common Rail
 Avensis (03-08)	ENGINE MANAGEME	2.0 D-4D 1CD-FTV (04-08)	EOBD
 Avensis (03-08)	ENGINE MANAGEME	2.0 VVT-i (04-08)	EOBD
 Avensis (03-08)	ENGINE MANAGEME	2.2 16v D (04-08)	EOBD
 Avensis (09-..)	ABS + TRACT. CONT	1.6 VVT-i (08-..)	
 Avensis (09-..)	ABS + TRACT. CONT	1.8 VVT-i (08-..)	
 Avensis (09-..)	ABS + TRACT. CONT	2.0 D-4D (08-..)	
 Avensis (09-..)	ABS + TRACT. CONT	2.0 VVT-i (08-..)	
 Avensis (09-..)	ABS + TRACT. CONT	2.2 D-4D (08-..)	
 Avensis (09-..)	AIRBAG	1.6 VVT-i (08-..)	
 Avensis (09-..)	AIRBAG	1.8 VVT-i (08-..)	
 Avensis (09-..)	AIRBAG	2.0 D-4D (08-..)	
 Avensis (09-..)	AIRBAG	2.0 VVT-i (08-..)	
 Avensis (09-..)	AIRBAG	2.2 D-4D (08-..)	
 Avensis (09-..)	BATTERY REGULATI	1.6 VVT-i (08-..)	
 Avensis (09-..)	BATTERY REGULATI	1.8 VVT-i (08-..)	
 Avensis (09-..)	BATTERY REGULATI	2.0 D-4D (08-..)	
 Avensis (09-..)	BATTERY REGULATI	2.0 VVT-i (08-..)	
 Avensis (09-..)	BATTERY REGULATI	2.2 D-4D (08-..)	
 Avensis (09-..)	CHASSIS NETWORK	1.6 VVT-i (08-..)	Main Body
 Avensis (09-..)	CHASSIS NETWORK	1.8 VVT-i (08-..)	Main Body
 Avensis (09-..)	CHASSIS NETWORK	2.0 D-4D (08-..)	Main Body
 Avensis (09-..)	CHASSIS NETWORK	2.0 VVT-i (08-..)	Main Body
 Avensis (09-..)	CHASSIS NETWORK	2.2 D-4D (08-..)	Main Body
 Avensis (09-..)	CLIMA	1.6 VVT-i (08-..)	
 Avensis (09-..)	CLIMA	1.8 VVT-i (08-..)	
 Avensis (09-..)	CLIMA	2.0 D-4D (08-..)	
 Avensis (09-..)	CLIMA	2.0 VVT-i (08-..)	
 Avensis (09-..)	CLIMA	2.2 D-4D (08-..)	
 Avensis (09-..)	DRIVER SIDE DOOR	1.6 VVT-i (08-..)	
 Avensis (09-..)	DRIVER SIDE DOOR	1.8 VVT-i (08-..)	
 Avensis (09-..)	DRIVER SIDE DOOR	2.0 D-4D (08-..)	
 Avensis (09-..)	DRIVER SIDE DOOR	2.0 VVT-i (08-..)	
 Avensis (09-..)	DRIVER SIDE DOOR	2.2 D-4D (08-..)	
 Avensis (09-..)	ELECTRIC STEERING	1.6 VVT-i (08-..)	
 Avensis (09-..)	ELECTRIC STEERING	1.8 VVT-i (08-..)	
 Avensis (09-..)	ELECTRIC STEERING	2.0 D-4D (08-..)	
 Avensis (09-..)	ELECTRIC STEERING	2.0 VVT-i (08-..)	
 Avensis (09-..)	ELECTRIC STEERING	2.2 D-4D (08-..)	
 Avensis (09-..)	ENGINE MANAGEME	2.0 D-4D (08-..)	Denso EDC Common Rail
 Avensis (09-..)	IMMOBILIZER	1.6 VVT-i (08-..)	
 Avensis (09-..)	IMMOBILIZER	1.8 VVT-i (08-..)	
 Avensis (09-..)	IMMOBILIZER	2.0 D-4D (08-..)	
 Avensis (09-..)	IMMOBILIZER	2.0 VVT-i (08-..)	
 Avensis (09-..)	IMMOBILIZER	2.2 D-4D (08-..)	
 Avensis (09-..)	LEFT REAR DOOR	1.6 VVT-i (08-..)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Toyota

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Avensis (09-..)	LEFT REAR DOOR	1.8 VVT-i (08-..)	
 Avensis (09-..)	LEFT REAR DOOR	2.0 D-4D (08-..)	
 Avensis (09-..)	LEFT REAR DOOR	2.0 VVT-i (08-..)	
 Avensis (09-..)	LEFT REAR DOOR	2.2 D-4D (08-..)	
 Avensis (09-..)	PARK.BRAKE	1.6 VVT-i (08-..)	
 Avensis (09-..)	PARK.BRAKE	1.8 VVT-i (08-..)	
 Avensis (09-..)	PARK.BRAKE	2.0 D-4D (08-..)	
 Avensis (09-..)	PARK.BRAKE	2.0 VVT-i (08-..)	
 Avensis (09-..)	PARK.BRAKE	2.2 D-4D (08-..)	
 Avensis (09-..)	PASS. SIDE DOOR	1.6 VVT-i (08-..)	
 Avensis (09-..)	PASS. SIDE DOOR	1.8 VVT-i (08-..)	
 Avensis (09-..)	PASS. SIDE DOOR	2.0 D-4D (08-..)	
 Avensis (09-..)	PASS. SIDE DOOR	2.0 VVT-i (08-..)	
 Avensis (09-..)	PASS. SIDE DOOR	2.2 D-4D (08-..)	
 Avensis (09-..)	RIGHT REAR DOOR	1.6 VVT-i (08-..)	
 Avensis (09-..)	RIGHT REAR DOOR	1.8 VVT-i (08-..)	
 Avensis (09-..)	RIGHT REAR DOOR	2.0 D-4D (08-..)	
 Avensis (09-..)	RIGHT REAR DOOR	2.0 VVT-i (08-..)	
 Avensis (09-..)	RIGHT REAR DOOR	2.2 D-4D (08-..)	
 Avensis (97-03)	ABS	1.6 16v (97-03)	TOYOTA ABS ABJ 09 W
 Avensis (97-03)	ABS	1.6 VVT-i (97-03)	TOYOTA ABS ABJ 09 W
 Avensis (97-03)	ABS	1.8 16v (00-03)	TOYOTA ABS ABJ 09 W
 Avensis (97-03)	ABS	1.8 VVT-i (97-03)	TOYOTA ABS ABJ 09 W
 Avensis (97-03)	ABS	2.0 16v (97-00)	TOYOTA ABS ABJ 09 W
 Avensis (97-03)	ABS	2.0 TD (97-00)	TOYOTA ABS ABJ 09 W
 Avensis (97-03)	ABS	2.0 Tdi D-4D (00-03)	TOYOTA ABS ABJ 09 W
 Avensis (97-03)	ABS	2.0 VVT-i (97-03)	TOYOTA ABS ABJ 09 W
 Avensis (97-03)	AIRBAG	1.6 16v (97-03)	DENSO AirBag SRS
 Avensis (97-03)	AIRBAG	1.6 VVT-i (97-03)	DENSO AirBag SRS
 Avensis (97-03)	AIRBAG	1.8 16v (00-03)	DENSO AirBag SRS
 Avensis (97-03)	AIRBAG	1.8 VVT-i (97-03)	DENSO AirBag SRS
 Avensis (97-03)	AIRBAG	2.0 16v (97-00)	DENSO AirBag SRS
 Avensis (97-03)	AIRBAG	2.0 TD (97-00)	DENSO AirBag SRS
 Avensis (97-03)	AIRBAG	2.0 Tdi D-4D (00-03)	DENSO AirBag SRS
 Avensis (97-03)	AIRBAG	2.0 VVT-i (97-03)	DENSO AirBag SRS
 Avensis (97-03)	ENGINE MANAGEME	1.6 16v (01-03)	EOBD
 Avensis (97-03)	ENGINE MANAGEME	1.6 16v 3ZZ-FE (02-03)	Denso
 Avensis (97-03)	ENGINE MANAGEME	1.6 16v 4A-FE (97-00)	TCCS MANUAL TCCS
 Avensis (97-03)	ENGINE MANAGEME	1.6 VVT-i (97-03)	EOBD
 Avensis (97-03)	ENGINE MANAGEME	1.8 16v (01-03)	EOBD
 Avensis (97-03)	ENGINE MANAGEME	1.8 16v 7A-FE (00-03)	TCCS MANUAL TCCS
 Avensis (97-03)	ENGINE MANAGEME	1.8 VVT-i (97-03)	EOBD
 Avensis (97-03)	ENGINE MANAGEME	2.0 16v 1AZ-FE (97-00)	Denso (A/T)
 Avensis (97-03)	ENGINE MANAGEME	2.0 16v 1AZ-FE (97-00)	Denso MPI (M/T)
 Avensis (97-03)	ENGINE MANAGEME	2.0 16v 3S-FE (97-00)	TCCS MANUAL TCCS
 Avensis (97-03)	ENGINE MANAGEME	2.0 TD 1CD-FTV (97-00)	TCCS MANUAL TCCS
 Avensis (97-03)	ENGINE MANAGEME	2.0 TD 2C-TE (97-00)	TCCS MANUAL TCCS
 Avensis (97-03)	ENGINE MANAGEME	2.0 Tdi D-4D (00-03)	Denso EDC Common Rail
 Avensis (97-03)	ENGINE MANAGEME	2.0 VVT-i (97-03)	EOBD
 Avensis (97-03)	MAINTENANCE	1.6 16v 4A-FE (97-00)	TCCS MANUAL TCCS
 Avensis (97-03)	MAINTENANCE	1.8 16v 7A-FE (00-03)	TCCS MANUAL TCCS
 Avensis (97-03)	MAINTENANCE	2.0 16v 3S-FE (97-00)	TCCS MANUAL TCCS
 Avensis (97-03)	MAINTENANCE	2.0 TD 1CD-FTV (97-00)	TCCS MANUAL TCCS
 Avensis (97-03)	MAINTENANCE	2.0 TD 2C-TE (97-00)	TCCS MANUAL TCCS
 Avensis SW (97-03)	ABS	1.6 16v (97-03)	TOYOTA ABS ABJ 09 W
 Avensis SW (97-03)	ABS	1.6 VVT-i (97-03)	TOYOTA ABS ABJ 09 W
 Avensis SW (97-03)	ABS	1.8 16v (00-03)	TOYOTA ABS ABJ 09 W
 Avensis SW (97-03)	ABS	1.8 VVT-i (97-03)	TOYOTA ABS ABJ 09 W

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Toyota

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Avensis SW (97-03)	ABS	2.0 16v (97-00)	TOYOTA ABS ABJ 09 W
 Avensis SW (97-03)	ABS	2.0 D-4D (00-03)	TOYOTA ABS ABJ 09 W
 Avensis SW (97-03)	ABS	2.0 TD (97-00)	TOYOTA ABS ABJ 09 W
 Avensis SW (97-03)	ABS	2.0 VVT-i (97-03)	TOYOTA ABS ABJ 09 W
 Avensis SW (97-03)	AIRBAG	1.6 16v (97-03)	DENSO AirBag SRS
 Avensis SW (97-03)	AIRBAG	1.6 VVT-i (97-03)	DENSO AirBag SRS
 Avensis SW (97-03)	AIRBAG	1.8 16v (00-03)	DENSO AirBag SRS
 Avensis SW (97-03)	AIRBAG	1.8 VVT-i (97-03)	DENSO AirBag SRS
 Avensis SW (97-03)	AIRBAG	2.0 16v (97-00)	DENSO AirBag SRS
 Avensis SW (97-03)	AIRBAG	2.0 D-4D (00-03)	DENSO AirBag SRS
 Avensis SW (97-03)	AIRBAG	2.0 TD (97-00)	DENSO AirBag SRS
 Avensis SW (97-03)	AIRBAG	2.0 VVT-i (97-03)	DENSO AirBag SRS
 Avensis SW (97-03)	ENGINE MANAGEME	1.6 16v (01-03)	EOBD
 Avensis SW (97-03)	ENGINE MANAGEME	1.6 16v 3ZZ-FE (02-03)	Denso MPI
 Avensis SW (97-03)	ENGINE MANAGEME	1.6 16v 4A-FE (97-00)	TCCS MANUAL TCCS
 Avensis SW (97-03)	ENGINE MANAGEME	1.6 VVT-i (97-03)	EOBD
 Avensis SW (97-03)	ENGINE MANAGEME	1.8 16v (01-03)	EOBD
 Avensis SW (97-03)	ENGINE MANAGEME	1.8 16v 7A-FE (00-03)	TCCS MANUAL TCCS
 Avensis SW (97-03)	ENGINE MANAGEME	1.8 VVT-i (97-03)	EOBD
 Avensis SW (97-03)	ENGINE MANAGEME	2.0 16v 1AZ-FE (02-..)	Denso MPI (A/T)
 Avensis SW (97-03)	ENGINE MANAGEME	2.0 16v 1AZ-FE (02-..)	Denso MPI (M/T)
 Avensis SW (97-03)	ENGINE MANAGEME	2.0 D-4D (...02)	Denso EDC Common Rail 110 Cv
 Avensis SW (97-03)	ENGINE MANAGEME	2.0 D-4D (03-..)	Denso EDC Common Rail 116 Cv
 Avensis SW (97-03)	ENGINE MANAGEME	2.0 VVT-i (97-03)	EOBD
 Avensis SW (97-03)	MAINTENANCE	1.6 16v 4A-FE (97-00)	TCCS MANUAL TCCS
 Avensis SW (97-03)	MAINTENANCE	1.8 16v 7A-FE (00-03)	TCCS MANUAL TCCS
 Avensis Verso (01-03)	ABS	2.0 16v (01-03)	TOYOTA ABS ABJ 09 W
 Avensis Verso (01-03)	ABS	2.0 D-4D (01-03)	TOYOTA ABS ABJ 09 W
 Avensis Verso (01-03)	AIRBAG	2.0 16v (01-03)	DENSO AirBag SRS
 Avensis Verso (01-03)	AIRBAG	2.0 D-4D (01-03)	DENSO AirBag SRS
 Avensis Verso (01-03)	ENGINE MANAGEME	2.0 16v 1AZ-FE (01-03)	Denso MPI (A/T)
 Avensis Verso (01-03)	ENGINE MANAGEME	2.0 16v 1AZ-FE (01-03)	Denso MPI (M/T)
 Avensis Verso (01-03)	ENGINE MANAGEME	2.0 16v 1AZ-FE (01-03)	EOBD
 Avensis Verso (01-03)	ENGINE MANAGEME	2.0 D-4D (01-03)	Denso EDC Common Rail 110 Cv
 Avensis Verso (01-03)	ENGINE MANAGEME	2.0 D-4D (01-03)	Denso EDC Common Rail 116 Cv
 Aygo (05-..)	ABS	1.0	BOSCH ABS 8.0
 Aygo (05-..)	ABS	1.4 D	BOSCH ABS 8.0
 Aygo (05-..)	AIRBAG	1.0	TRW SAC
 Aygo (05-..)	AIRBAG	1.4 D	TRW SAC
 Aygo (05-..)	ELECTRIC STEERING	1.0	SMI KOYO EMPS
 Aygo (05-..)	ELECTRIC STEERING	1.4 D	SMI KOYO EMPS
 Aygo (05-..)	ENGINE MANAGEME	1.0	BOSCH Motronic ME796
 Aygo (05-..)	ENGINE MANAGEME	1.4 D	EOBD
 Aygo (05-..)	IMMOBILIZER	1.0	
 Aygo (05-..)	IMMOBILIZER	1.4 D	
 Aygo (05-..)	MAINTENANCE	1.0	SMI KOYO EMPS
 Aygo (05-..)	MAINTENANCE	1.4 D	SMI KOYO EMPS
 Camry	ENGINE MANAGEME	2.4 2AZ-FE (01-..)	EOBD
 Camry	ENGINE MANAGEME	3.0 V6 1MZ-FE (01-..)	EOBD
 Carina E (96-98)	ENGINE MANAGEME	1.6 4A-FE (92-98)	TCCS MANUAL TCCS
 Carina E (96-98)	ENGINE MANAGEME	1.8 7A-FE (95-98)	TCCS MANUAL TCCS
 Carina E (96-98)	ENGINE MANAGEME	2.0 3S-FE (92-97)	TCCS MANUAL TCCS
 Carina E (96-98)	ENGINE MANAGEME	2.0 GTi 3S-GE (92-97)	TCCS MANUAL TCCS
 Carina E (96-98)	MAINTENANCE	1.6 4A-FE (92-98)	TCCS MANUAL TCCS
 Carina E (96-98)	MAINTENANCE	1.8 7A-FE (95-98)	TCCS MANUAL TCCS
 Carina E (96-98)	MAINTENANCE	2.0 3S-FE (92-97)	TCCS MANUAL TCCS
 Carina E (96-98)	MAINTENANCE	2.0 GTi 3S-GE (92-97)	TCCS MANUAL TCCS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Toyota

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Carina II	ENGINE MANAGEME	1.6 4A-FE (88-90)	TCCS MANUAL TCCS
 Carina II	ENGINE MANAGEME	2.0 3S-FE (88-92)	TCCS MANUAL TCCS
 Carina II	MAINTENANCE	1.6 4A-FE (88-90)	TCCS MANUAL TCCS
 Carina II	MAINTENANCE	2.0 3S-FE (88-92)	TCCS MANUAL TCCS
 Celica	ABS	1.8 16v (99-..)	TOYOTA Denso ABS ABJ 09 W
 Celica	AIRBAG	1.8 16v (99-..)	DENSO AirBag SRS
 Celica	ENGINE MANAGEME	1.6 4A-FE (90-94)	TCCS MANUAL TCCS
 Celica	ENGINE MANAGEME	1.8 1ZZ (00-01)	EOBD
 Celica	ENGINE MANAGEME	1.8 7A-FE (94-99)	TCCS MANUAL TCCS
 Celica	ENGINE MANAGEME	2.0 3S-GE (90-94)	TCCS MANUAL TCCS
 Celica	ENGINE MANAGEME	2.0 3S-GE (95-99)	TCCS MANUAL TCCS
 Celica	ENGINE MANAGEME	2.0 GT4 3S-GTE (90-94)	TCCS MANUAL TCCS
 Celica	ENGINE MANAGEME	2.0 GT4 3S-GTE (95-97)	TCCS MANUAL TCCS
 Celica	MAINTENANCE	1.6 4A-FE (90-94)	TCCS MANUAL TCCS
 Celica	MAINTENANCE	1.8 7A-FE (94-99)	TCCS MANUAL TCCS
 Celica	MAINTENANCE	2.0 3S-GE (90-94)	TCCS MANUAL TCCS
 Celica	MAINTENANCE	2.0 3S-GE (95-99)	TCCS MANUAL TCCS
 Celica	MAINTENANCE	2.0 GT4 3S-GTE (90-94)	TCCS MANUAL TCCS
 Celica	MAINTENANCE	2.0 GT4 3S-GTE (95-97)	TCCS MANUAL TCCS
 Corolla (97-02)	ENGINE MANAGEME	1.3 2E-E (90-92)	TCCS MANUAL TCCS
 Corolla (97-02)	ENGINE MANAGEME	1.4 16v (00-02)	Denso MPI
 Corolla (97-02)	ENGINE MANAGEME	1.6 3ZZ-FE (01-02)	EOBD
 Corolla (97-02)	ENGINE MANAGEME	1.6 4A-FE (93-97)	TCCS MANUAL TCCS
 Corolla (97-02)	ENGINE MANAGEME	1.8 7A-FE (93-95)	TCCS MANUAL TCCS
 Corolla (97-02)	ENGINE MANAGEME	2.0 D 2C-E (97-00)	TCCS MANUAL TCCS
 Corolla (97-02)	MAINTENANCE	1.3 2E-E (90-92)	TCCS MANUAL TCCS
 Corolla (97-02)	MAINTENANCE	1.6 4A-FE (93-97)	TCCS MANUAL TCCS
 Corolla (97-02)	MAINTENANCE	1.8 7A-FE (93-95)	TCCS MANUAL TCCS
 Corolla (97-02)	MAINTENANCE	2.0 D 2C-E (97-00)	TCCS MANUAL TCCS
 Corolla (02-04)	ABS	1.4 16v (02-04)	BOSCH ABS 5.xx
 Corolla (02-04)	ABS	1.6 16v (02-04)	BOSCH ABS 5.xx
 Corolla (02-04)	ABS	1.8 16v (02-04)	BOSCH ABS 5.xx
 Corolla (02-04)	ABS	2.0 D-4D (02-04)	TOYOTA ABS ABJ 09 W
 Corolla (02-04)	AIRBAG	1.4 16v (02-04)	DENSO AirBag SRS
 Corolla (02-04)	AIRBAG	1.6 16v (02-04)	DENSO AirBag SRS
 Corolla (02-04)	AIRBAG	1.8 16v (02-04)	DENSO AirBag SRS
 Corolla (02-04)	AIRBAG	2.0 D-4D (02-04)	DENSO AirBag SRS
 Corolla (02-04)	ENGINE MANAGEME	1.4 16v (02-04)	Denso MPI
 Corolla (02-04)	ENGINE MANAGEME	1.4 16v 4ZZ-FE (02-04)	EOBD
 Corolla (02-04)	ENGINE MANAGEME	1.6 16v 3ZZ-FE (02-04)	Denso MPI
 Corolla (02-04)	ENGINE MANAGEME	1.8 1ZZ-FE (02-04)	EOBD
 Corolla (02-04)	ENGINE MANAGEME	2.0 D-4D (02-03)	Denso EDC Common Rail 110 Cv
 Corolla (02-04)	ENGINE MANAGEME	2.0 D-4D (03-04)	Denso EDC Common Rail 116 Cv
 Corolla SW (02-04)	ABS	1.4 16v (02-04)	BOSCH ABS 5.xx
 Corolla SW (02-04)	ABS	1.4 16v (02-04)	TOYOTA ABS ABJ 09 W
 Corolla SW (02-04)	ABS	1.6 16v (02-04)	BOSCH ABS 5.xx
 Corolla SW (02-04)	ABS	1.6 16v (02-04)	TOYOTA ABS ABJ 09 W
 Corolla SW (02-04)	ABS	2.0 D-4D (02-04)	BOSCH ABS 5.xx
 Corolla SW (02-04)	ABS	2.0 D-4D (02-04)	TOYOTA ABS ABJ 09 W
 Corolla SW (02-04)	AIRBAG	1.4 16v (02-04)	DENSO AirBag SRS
 Corolla SW (02-04)	AIRBAG	1.6 16v (02-04)	DENSO AirBag SRS
 Corolla SW (02-04)	AIRBAG	2.0 D-4D (02-04)	DENSO AirBag SRS
 Corolla SW (02-04)	ENGINE MANAGEME	1.4 16v (02-04)	Denso MPI
 Corolla SW (02-04)	ENGINE MANAGEME	1.6 16v 3ZZ-FE (02-04)	Denso MPI
 Corolla SW (02-04)	ENGINE MANAGEME	2.0 D-4D (02-04)	Denso EDC Common Rail 110 Cv
 Corolla SW (02-04)	ENGINE MANAGEME	2.0 D-4D (02-04)	Denso EDC Common Rail 116 Cv
 Corolla SW (02-04)	ENGINE MANAGEME	2.0 D-4D (02-04)	Denso EDC Common Rail 90 Cv

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Toyota

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Corolla Verso	ABS	1.6 16v (02-04)	BOSCH ABS 5.xx
 Corolla Verso	ABS	1.6 16v (02-04)	TOYOTA ABS ABJ 09 W
 Corolla Verso	ABS	1.8 16v (02-04)	BOSCH ABS 5.xx
 Corolla Verso	ABS	1.8 16v (02-04)	TOYOTA ABS ABJ 09 W
 Corolla Verso	ABS	2.0 D-4D (02-04)	BOSCH ABS 5.xx
 Corolla Verso	ABS	2.0 D-4D (02-04)	TOYOTA ABS ABJ 09 W
 Corolla Verso	AIRBAG	1.6 16v (02-04)	DENSO AirBag SRS
 Corolla Verso	AIRBAG	1.8 16v (02-04)	DENSO AirBag SRS
 Corolla Verso	AIRBAG	2.0 D-4D (02-04)	DENSO AirBag SRS
 Corolla Verso	ENGINE MANAGEME	1.6 16v VVT-i 3ZZ-FE (02-04)	Denso MPI
 Corolla Verso	ENGINE MANAGEME	2.0 D-4D 90 (02-04)	Denso EDC Common Rail
 Corolla Verso	ENGINE MANAGEME	2.0 D-4D 90 (03-04)	Denso EDC Common Rail
 Corolla Verso	MAINTENANCE	1.6 16v (04-..)	MANUAL
 Corolla Verso	MAINTENANCE	1.6 16v VVT-i (04-..)	MANUAL
 Corolla Verso	MAINTENANCE	1.8 16v (04-..)	MANUAL
 Corolla Verso	MAINTENANCE	2.0 D-4D (04-..)	MANUAL
 Corolla Verso	MAINTENANCE	2.0 D-4D 90 (04-..)	MANUAL
 Corolla Verso	SERVICE LIGHT RES	1.6 16v (04-..)	MANUAL
 Corolla Verso	SERVICE LIGHT RES	1.6 16v VVT-i (04-..)	MANUAL
 Corolla Verso	SERVICE LIGHT RES	1.8 16v (04-..)	MANUAL
 Corolla Verso	SERVICE LIGHT RES	2.0 D-4D (04-..)	MANUAL
 Corolla Verso	SERVICE LIGHT RES	2.0 D-4D 90 (04-..)	MANUAL
 HiAce	ENGINE MANAGEME	2.5 D-4D 2KD-FTV (04-..)	EOBD
 HiAce	ENGINE MANAGEME	2.7 3RZ-FE (01-..)	EOBD
 HiLux	ENGINE MANAGEME	2.5 D-4D 2KD-FTV (04-..)	EOBD
 IQ	ABS	1.0 VVT-i (09-..)	ABS
 IQ	ABS	1.3 VVT-i (09-..)	ABS
 IQ	ABS	1.4 D-4D (09-..)	ABS
 IQ	AIRBAG	1.0 VVT-i (09-..)	AirBag SRS
 IQ	AIRBAG	1.3 VVT-i (09-..)	AirBag SRS
 IQ	AIRBAG	1.4 D-4D (09-..)	AirBag SRS
 IQ	BATTERY CHARGER	1.0 VVT-i (09-..)	
 IQ	BATTERY CHARGER	1.3 VVT-i (09-..)	
 IQ	BATTERY CHARGER	1.4 D-4D (09-..)	
 IQ	CHASSIS NETWORK	1.0 VVT-i (09-..)	Gateway
 IQ	CHASSIS NETWORK	1.0 VVT-i (09-..)	Main Body
 IQ	CHASSIS NETWORK	1.0 VVT-i (09-..)	Master Switch
 IQ	CHASSIS NETWORK	1.3 VVT-i (09-..)	Gateway
 IQ	CHASSIS NETWORK	1.3 VVT-i (09-..)	Main Body
 IQ	CHASSIS NETWORK	1.3 VVT-i (09-..)	Master Switch
 IQ	CHASSIS NETWORK	1.4 D-4D (09-..)	Gateway
 IQ	CHASSIS NETWORK	1.4 D-4D (09-..)	Main Body
 IQ	CHASSIS NETWORK	1.4 D-4D (09-..)	Master Switch
 IQ	CLIMA	1.0 VVT-i (09-..)	Clima
 IQ	CLIMA	1.3 VVT-i (09-..)	Clima
 IQ	CLIMA	1.4 D-4D (09-..)	Clima
 IQ	DASHBOARD	1.0 VVT-i (09-..)	
 IQ	DASHBOARD	1.3 VVT-i (09-..)	
 IQ	DASHBOARD	1.4 D-4D (09-..)	
 IQ	DRIVER SIDE DOOR	1.0 VVT-i (09-..)	
 IQ	DRIVER SIDE DOOR	1.3 VVT-i (09-..)	
 IQ	DRIVER SIDE DOOR	1.4 D-4D (09-..)	
 IQ	ELECTRIC STEERING	1.0 VVT-i (09-..)	EMPS
 IQ	ELECTRIC STEERING	1.3 VVT-i (09-..)	EMPS
 IQ	ELECTRIC STEERING	1.4 D-4D (09-..)	EMPS
 IQ	ENGINE MANAGEME	1.0 VVT-i (09-..)	
 IQ	ENGINE MANAGEME	1.3 VVT-i (09-..)	EOBD
 IQ	ENGINE MANAGEME	1.4 D-4D (09-..)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Toyota

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 IQ	IGNITION SWITCH	1.0 VVT-i (09-..)	
 IQ	IGNITION SWITCH	1.3 VVT-i (09-..)	
 IQ	IGNITION SWITCH	1.4 D-4D (09-..)	
 IQ	PASS. SIDE DOOR	1.0 VVT-i (09-..)	
 IQ	PASS. SIDE DOOR	1.3 VVT-i (09-..)	
 IQ	PASS. SIDE DOOR	1.4 D-4D (09-..)	
 Land Cruiser LB	ABS	3.0 D-4D 16v (02-..)	AISIN ABS
 Land Cruiser LB	ABS	4.2 TD 24v 100 (02-..)	AISIN ABS
 Land Cruiser LB	ABS	4.7 i V8 32v 100 (02-..)	AISIN ABS
 Land Cruiser LB	AIRBAG	3.0 D-4D 16v (02-..)	DENSO AirBag 2
 Land Cruiser LB	AIRBAG	3.0 D-4D 16v (02-..)	DENSO AirBag SRS
 Land Cruiser LB	AIRBAG	4.2 TD 24v 100 (02-..)	DENSO AirBag 2
 Land Cruiser LB	AIRBAG	4.2 TD 24v 100 (02-..)	DENSO AirBag SRS
 Land Cruiser LB	AIRBAG	4.7 i V8 32v 100 (02-..)	DENSO AirBag 2
 Land Cruiser LB	AIRBAG	4.7 i V8 32v 100 (02-..)	DENSO AirBag SRS
 Land Cruiser LB	CRUISE CONTROL	3.0 D-4D 16v (02-..)	CC
 Land Cruiser LB	CRUISE CONTROL	4.2 TD 24v 100 (02-..)	CC
 Land Cruiser LB	CRUISE CONTROL	4.7 i V8 32v 100 (02-..)	CC
 Land Cruiser SB	ABS	3.0 D-4D 16v (02-..)	TOYOTA ABS AISIN
 Land Cruiser SB	AIRBAG	3.0 D-4D 16v (02-..)	DENSO AirBag 2
 Land Cruiser SB	AIRBAG	3.0 D-4D 16v (02-..)	DENSO AirBag SRS
 Land Cruiser SB	CRUISE CONTROL	3.0 D-4D 16v (02-..)	CC
 MR2	ABS	1.8 16v (00-..)	TOYOTA Denso ABS ABJ 09 W
 MR2	AIRBAG	1.8 16v (00-..)	DENSO AirBag SRS
 MR2	ENGINE MANAGEME	1.8 16v 1ZZ-FE (01-..)	EOBD
 MR2	ENGINE MANAGEME	2.0 3S-FE (90-94)	TCCS MANUAL TCCS
 MR2	ENGINE MANAGEME	2.0 3S-GE (90-00)	TCCS MANUAL TCCS
 MR2	MAINTENANCE	2.0 3S-FE (90-94)	TCCS MANUAL TCCS
 MR2	MAINTENANCE	2.0 3S-GE (90-00)	TCCS MANUAL TCCS
 Picnic	ENGINE MANAGEME	2.0 3S-FE (96-00)	TCCS MANUAL TCCS
 Picnic	ENGINE MANAGEME	2.2 Tdi 3C-TE (96-00)	TCCS MANUAL TCCS
 Picnic	MAINTENANCE	2.0 3S-FE (96-00)	TCCS MANUAL TCCS
 Picnic	MAINTENANCE	2.2 Tdi 3C-TE (96-00)	TCCS MANUAL TCCS
 Previa	ABS	2.0 D-4D (02-..)	TOYOTA ABS DENSO 1F
 Previa	AIRBAG	2.0 D-4D (02-..)	DENSO AirBag SRS
 Previa	ENGINE MANAGEME	2.0 D-4D 110 (...02)	Denso EDC Common Rail
 Previa	ENGINE MANAGEME	2.0 D-4D 116 (03-..)	Denso EDC Common Rail
 Previa	ENGINE MANAGEME	2.0 D-4D 1CD-FTV (04-..)	EOBD
 Previa	ENGINE MANAGEME	2.4 2AZ-FE (00-..)	EOBD
 Previa	ENGINE MANAGEME	2.4 2TZ-FE (90-00)	TCCS MANUAL TCCS
 Previa	MAINTENANCE	2.4 2TZ-FE (90-00)	TCCS MANUAL TCCS
 Prius	CLIMA	1.8 HYBRID (09-..)	
 Prius	ENGINE MANAGEME	1.8 HYBRID ZVW30H /ZVW30L (09-..)	
 RAV 4	4WD ELECTRONICS	2.0 16v VVT-i (06-09)	4WD
 RAV 4	4WD ELECTRONICS	2.2 D-4D 136cv (06-09)	4WD
 RAV 4	4WD ELECTRONICS	2.2 D-4D 177cv (06-09)	4WD
 RAV 4	ABS	2.0 16v (02-06)	DENSO ABS 1B
 RAV 4	ABS	2.0 D-4D (02-06)	TOYOTA ABS DENSO 1B
 RAV 4	ABS + TRACT. CONT	2.0 16v VVT-i (06-09)	ABS+ESP
 RAV 4	ABS + TRACT. CONT	2.0 VVT-i 158cv (10-..)	ABS
 RAV 4	ABS + TRACT. CONT	2.2 D-4D 136cv (06-09)	ABS+ESP
 RAV 4	ABS + TRACT. CONT	2.2 D-4D 150cv (10-..)	ABS
 RAV 4	ABS + TRACT. CONT	2.2 D-4D 177cv (06-09)	ABS+ESP
 RAV 4	ABS + TRACT. CONT	2.2 D-CAT 150cv (10-..)	ABS
 RAV 4	ABS + TRACT. CONT	2.2 D-CAT 177cv (10-..)	ABS
 RAV 4	AIRBAG	2.0 16v (02-06)	DENSO AirBag SRS
 RAV 4	AIRBAG	2.0 16v VVT-i (06-09)	SRS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Toyota

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 RAV 4	AIRBAG	2.0 D-4D (02-06)	DENSO AirBag SRS
 RAV 4	AIRBAG	2.0 VVT-i 158cv (10-..)	SRS
 RAV 4	AIRBAG	2.2 D-4D 136cv (06-09)	SRS
 RAV 4	AIRBAG	2.2 D-4D 150cv (10-..)	SRS
 RAV 4	AIRBAG	2.2 D-4D 177cv (06-09)	SRS
 RAV 4	AIRBAG	2.2 D-CAT 150cv (10-..)	SRS
 RAV 4	AIRBAG	2.2 D-CAT 177cv (10-..)	SRS
 RAV 4	CHASSIS NETWORK	2.0 16v VVT-i (06-09)	Body Computer
 RAV 4	CHASSIS NETWORK	2.2 D-4D 136cv (06-09)	Body Computer
 RAV 4	CHASSIS NETWORK	2.2 D-4D 177cv (06-09)	Body Computer
 RAV 4	CLIMA	2.0 16v VVT-i (06-09)	Clima
 RAV 4	CLIMA	2.0 VVT-i 158cv (10-..)	Clima
 RAV 4	CLIMA	2.2 D-4D 136cv (06-09)	Clima
 RAV 4	CLIMA	2.2 D-4D 150cv (10-..)	Clima
 RAV 4	CLIMA	2.2 D-4D 177cv (06-09)	Clima
 RAV 4	CLIMA	2.2 D-CAT 150cv (10-..)	Clima
 RAV 4	CLIMA	2.2 D-CAT 177cv (10-..)	Clima
 RAV 4	CRUISE CONTROL	2.0 16v VVT-i (06-09)	Cruise
 RAV 4	CRUISE CONTROL	2.2 D-4D 136cv (06-09)	Cruise
 RAV 4	CRUISE CONTROL	2.2 D-4D 177cv (06-09)	Cruise
 RAV 4	DASHBOARD	2.0 16v VVT-i (06-09)	Dashboard
 RAV 4	DASHBOARD	2.0 VVT-i 158cv (10-..)	Dashboard
 RAV 4	DASHBOARD	2.2 D-4D 136cv (06-09)	Dashboard
 RAV 4	DASHBOARD	2.2 D-4D 150cv (10-..)	Dashboard
 RAV 4	DASHBOARD	2.2 D-4D 177cv (06-09)	Dashboard
 RAV 4	DASHBOARD	2.2 D-CAT 150cv (10-..)	Dashboard
 RAV 4	DASHBOARD	2.2 D-CAT 177cv (10-..)	Dashboard
 RAV 4	DRIVER SIDE DOOR	2.0 16v VVT-i (06-09)	DriverDoor
 RAV 4	DRIVER SIDE DOOR	2.2 D-4D 136cv (06-09)	DriverDoor
 RAV 4	DRIVER SIDE DOOR	2.2 D-4D 177cv (06-09)	DriverDoor
 RAV 4	ELECTRIC STEERING	2.0 16v VVT-i (06-09)	EMPS
 RAV 4	ELECTRIC STEERING	2.2 D-4D 136cv (06-09)	EMPS
 RAV 4	ELECTRIC STEERING	2.2 D-4D 177cv (06-09)	EMPS
 RAV 4	ENGINE MANAGEME	2.0 16v VVT-i (06-09)	EOBD
 RAV 4	ENGINE MANAGEME	2.0 16v VVT-i 1AZ-FE (02-06)	Denso MPI (A/T)
 RAV 4	ENGINE MANAGEME	2.0 16v VVT-i 1AZ-FE (02-06)	Denso MPI (M/T)
 RAV 4	ENGINE MANAGEME	2.0 3S-FE (94-00)	TCCS MANUAL TCCS
 RAV 4	ENGINE MANAGEME	2.0 D-4D 116cv (...02)	Denso EDC Common Rail
 RAV 4	ENGINE MANAGEME	2.0 D-4D 116cv (03-06)	Denso EDC Common Rail
 RAV 4	ENGINE MANAGEME	2.2 D-4D 136cv (07-09)	DENSO EDC DPF
 RAV 4	ENGINE MANAGEME	2.2 D-4D 136cv (07-09)	DENSO EDC NO DPF
 RAV 4	ENGINE MANAGEME	2.2 D-4D 150cv (10-..)	DENSO EDC
 RAV 4	ENGINE MANAGEME	2.2 D-4D 177cv (07-09)	DENSO EDC DPF
 RAV 4	IMMOBILIZER	2.0 16v VVT-i (06-09)	
 RAV 4	IMMOBILIZER	2.2 D-4D 136cv (06-09)	
 RAV 4	IMMOBILIZER	2.2 D-4D 177cv (06-09)	
 RAV 4	MAINTENANCE	2.0 16v VVT-i (06-09)	Manual
 RAV 4	MAINTENANCE	2.0 3S-FE (94-00)	TCCS MANUAL TCCS
 RAV 4	MAINTENANCE	2.2 D-4D 136cv (06-09)	Manual
 RAV 4	MAINTENANCE	2.2 D-4D 136cv (07-09)	DENSO EDC DPF
 RAV 4	MAINTENANCE	2.2 D-4D 136cv (07-09)	DENSO EDC DPF
 RAV 4	MAINTENANCE	2.2 D-4D 150cv (10-..)	Manual
 RAV 4	MAINTENANCE	2.2 D-4D 177cv (06-09)	Manual
 RAV 4	MAINTENANCE	2.2 D-4D 177cv (07-09)	DENSO EDC DPF
 RAV 4	PASSIVE ENTRY	2.0 16v VVT-i (06-09)	IntelligentKey
 RAV 4	PASSIVE ENTRY	2.2 D-4D 136cv (06-09)	IntelligentKey
 RAV 4	PASSIVE ENTRY	2.2 D-4D 177cv (06-09)	IntelligentKey
 RAV 4	SERVICE LIGHT RES	2.0 16v VVT-i (06-09)	Manual

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Toyota

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 RAV 4	SERVICE LIGHT RES	2.2 D-4D 136cv (06-09)	Manual
 RAV 4	SERVICE LIGHT RES	2.2 D-4D 150cv (10-..)	Manual
 RAV 4	SERVICE LIGHT RES	2.2 D-4D 177cv (06-09)	Manual
 Starlet	ENGINE MANAGEME	1.3 2E-E (90-96)	TCCS MANUAL TCCS
 Starlet	ENGINE MANAGEME	1.3 4E-FE (97-99)	TCCS MANUAL TCCS
 Starlet	MAINTENANCE	1.3 2E-E (90-96)	TCCS MANUAL TCCS
 Starlet	MAINTENANCE	1.3 4E-FE (97-99)	TCCS MANUAL TCCS
 Supra	ENGINE MANAGEME	3.0 T 2JZ-GTE (93-97)	TCCS MANUAL TCCS
 Supra	ENGINE MANAGEME	3.0 T 7M-GTE (88-93)	TCCS MANUAL TCCS
 Supra	MAINTENANCE	3.0 T 2JZ-GTE (93-97)	TCCS MANUAL TCCS
 Supra	MAINTENANCE	3.0 T 7M-GTE (88-93)	TCCS MANUAL TCCS
 Yaris 05	ABS	1.0 VVT-i (07-..)	ABS
 Yaris 05	ABS	1.0 VVT-i (07-..)	Toyota ABS
 Yaris 05	ABS	1.3 VVT-i (07-..)	ABS
 Yaris 05	ABS	1.3 VVT-i (07-..)	Toyota ABS
 Yaris 05	ABS	1.4 D-4D (07-..)	ABS
 Yaris 05	ABS	1.4 D-4D (07-..)	Toyota ABS
 Yaris 05	ABS	1.8 VVT-i TS (07-..)	ABS
 Yaris 05	ABS	1.8 VVT-i TS (07-..)	Toyota ABS
 Yaris 05	AIRBAG	1.0 VVT-i (07-..)	DENSO AirBag SRS
 Yaris 05	AIRBAG	1.3 VVT-i (07-..)	DENSO AirBag SRS
 Yaris 05	AIRBAG	1.4 D-4D (07-..)	DENSO AirBag SRS
 Yaris 05	AIRBAG	1.8 VVT-i TS (07-..)	DENSO AirBag SRS
 Yaris 05	AUTOM. TRANSMISSI	1.0 VVT-i (07-..)	A/T
 Yaris 05	AUTOM. TRANSMISSI	1.3 VVT-i (07-..)	A/T
 Yaris 05	AUTOM. TRANSMISSI	1.4 D-4D (07-..)	A/T
 Yaris 05	AUTOM. TRANSMISSI	1.8 VVT-i TS (07-..)	A/T
 Yaris 05	CHASSIS NETWORK	1.0 VVT-i (07-..)	Body Computer
 Yaris 05	CHASSIS NETWORK	1.3 VVT-i (07-..)	Body Computer
 Yaris 05	CHASSIS NETWORK	1.4 D-4D (07-..)	Body Computer
 Yaris 05	CHASSIS NETWORK	1.8 VVT-i TS (07-..)	Body Computer
 Yaris 05	CLIMA	1.0 VVT-i (07-..)	Climate Control
 Yaris 05	CLIMA	1.3 VVT-i (07-..)	Climate Control
 Yaris 05	CLIMA	1.4 D-4D (07-..)	Climate Control
 Yaris 05	CLIMA	1.8 VVT-i TS (07-..)	Climate Control
 Yaris 05	DASHBOARD	1.0 VVT-i (07-..)	DENSO
 Yaris 05	DASHBOARD	1.3 VVT-i (07-..)	DENSO
 Yaris 05	DASHBOARD	1.4 D-4D (07-..)	DENSO
 Yaris 05	DASHBOARD	1.8 VVT-i TS (07-..)	DENSO
 Yaris 05	ELECTRIC STEERING	1.0 VVT-i (07-..)	EPS
 Yaris 05	ELECTRIC STEERING	1.3 VVT-i (07-..)	EPS
 Yaris 05	ELECTRIC STEERING	1.4 D-4D (07-..)	EPS
 Yaris 05	ELECTRIC STEERING	1.8 VVT-i TS (07-..)	EPS
 Yaris 05	ENGINE MANAGEME	1.0 VVT-i (05-..)	DENSO
 Yaris 05	ENGINE MANAGEME	1.3 VVT-i (07-..)	DENSO
 Yaris 05	ENGINE MANAGEME	1.4 D-4D (07-..)	DENSO
 Yaris 05	ENGINE MANAGEME	1.8 VVT-i TS (07-..)	EOBD
 Yaris 05	IMMOBILIZER	1.0 VVT-i (07-..)	
 Yaris 05	IMMOBILIZER	1.3 VVT-i (07-..)	
 Yaris 05	IMMOBILIZER	1.4 D-4D (07-..)	
 Yaris 05	IMMOBILIZER	1.8 VVT-i TS (07-..)	
 Yaris 05	MAINTENANCE	1.0 VVT-i (05-..)	MANUAL
 Yaris 05	MAINTENANCE	1.3 VVT-i (05-..)	MANUAL
 Yaris 05	MAINTENANCE	1.4 D-4D (05-..)	MANUAL
 Yaris 05	MAINTENANCE	1.8 VVT-i TS (05-..)	MANUAL
 Yaris 05	SERVICE LIGHT RES	1.0 VVT-i (05-..)	MANUAL
 Yaris 05	SERVICE LIGHT RES	1.3 VVT-i (05-..)	MANUAL
 Yaris 05	SERVICE LIGHT RES	1.4 D-4D (05-..)	MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Toyota

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Yaris 05	SERVICE LIGHT RES	1.8 VVT-i TS (05-..)	MANUAL
 Yaris Verso	ABS	1.3 16v VVT-i (00-..)	BOSCH ABS 5.xx
 Yaris Verso	ABS	1.3 16v VVT-i (00-..)	TOYOTA ABS DENSO
 Yaris Verso	ABS	1.4 D-4D (00-..)	BOSCH ABS 5.xx
 Yaris Verso	ABS	1.4 D-4D (00-..)	TOYOTA ABS DENSO
 Yaris Verso	ABS	1.5 16v VVT-i (00-..)	BOSCH ABS 5.xx
 Yaris Verso	ABS	1.5 16v VVT-i (00-..)	TOYOTA ABS DENSO
 Yaris Verso	AIRBAG	1.3 16v VVT-i (00-..)	DENSO AirBag SRS
 Yaris Verso	AIRBAG	1.4 D-4D (00-..)	DENSO AirBag SRS
 Yaris Verso	AIRBAG	1.5 16v VVT-i (00-..)	DENSO AirBag SRS
 Yaris Verso	ENGINE MANAGEME	1.3 16v VVT-i 2NZ-FE (02-..)	Denso
 Yaris Verso	ENGINE MANAGEME	1.4 D-4D 1ND TV (01-..)	BOSCH EDC
 Yaris Verso	ENGINE MANAGEME	1.5 16v VVT-i (01-..)	EOBD
 Yaris Verso	IMMOBILIZER	1.3 16v VVT-i	
 Yaris Verso	IMMOBILIZER	1.4 D-4D	
 Yaris Verso	IMMOBILIZER	1.5 16v VVT-i	
 Yaris	ABS	1.0 16v VVT-i (99-..)	BOSCH ABS 5.xx
 Yaris	ABS	1.0 16v VVT-i (99-..)	DENSO ABS
 Yaris	ABS	1.3 16v VVT-i (99-..)	BOSCH ABS 5.xx
 Yaris	ABS	1.3 16v VVT-i (99-..)	DENSO ABS
 Yaris	ABS	1.4 D-4D (99-..)	BOSCH ABS 5.xx
 Yaris	ABS	1.4 D-4D (99-..)	DENSO ABS
 Yaris	ABS	1.5 16v VVT-i (99-..)	BOSCH ABS 5.xx
 Yaris	ABS	1.5 16v VVT-i (99-..)	DENSO ABS
 Yaris	AIRBAG	1.0 16v VVT-i (99-..)	DENSO AirBag SRS
 Yaris	AIRBAG	1.3 16v VVT-i (99-..)	DENSO AirBag SRS
 Yaris	AIRBAG	1.4 D-4D (99-..)	DENSO AirBag SRS
 Yaris	AIRBAG	1.5 16v VVT-i (99-..)	DENSO AirBag SRS
 Yaris	ENGINE MANAGEME	1.0 16v VVT-i 1NZ-FE (01-..)	Denso
 Yaris	ENGINE MANAGEME	1.0 16v VVT-i 1SZ-FE (02-..)	Denso
 Yaris	ENGINE MANAGEME	1.3 16v VVT-i 2SZ-FE (02-..)	Denso
 Yaris	ENGINE MANAGEME	1.4 D-4D 1ND TV (01-03)	BOSCH EDC
 Yaris	ENGINE MANAGEME	1.5 16v VVT-i 1NZ-FE (02-..)	Denso
 Yaris	IMMOBILIZER	1.0 16v VVT-i	
 Yaris	IMMOBILIZER	1.3 16v VVT-i	
 Yaris	IMMOBILIZER	1.4 D-4D	
 Yaris	IMMOBILIZER	1.5 16v VVT-i	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 850	ABS	2.0 10V (...98)	ATE ABS Mk20
 850	ABS	2.0 20v (...98)	ATE ABS Mk20
 850	ABS	2.0 T (...98)	ATE ABS Mk20
 850	ABS	2.3 T5-R (...98)	ATE ABS Mk20
 850	ABS	2.4 10V (...98)	ATE ABS Mk20
 850	ABS	2.4 20v (...98)	ATE ABS Mk20
 850	ABS	2.5 T (...98)	ATE ABS Mk20
 850	ABS	2.5 TDI (...98)	ATE ABS Mk20
 850	AIRBAG	2.0 10V (...98)	BOSCH - Autoliv AirBag 6.2
 850	AIRBAG	2.0 20v (...98)	BOSCH - Autoliv AirBag 6.2
 850	AIRBAG	2.0 T (...98)	BOSCH - Autoliv AirBag 6.2
 850	AIRBAG	2.3 T5-R (...98)	BOSCH - Autoliv AirBag 6.2
 850	AIRBAG	2.4 10V (...98)	BOSCH - Autoliv AirBag 6.2
 850	AIRBAG	2.4 20v (...98)	BOSCH - Autoliv AirBag 6.2
 850	AIRBAG	2.5 T (...98)	BOSCH - Autoliv AirBag 6.2
 850	AIRBAG	2.5 TDI (...98)	BOSCH - Autoliv AirBag 6.2
 850	DIESEL MANAGEME	2.5 TDI (...98)	BOSCH MSA 15.7
 850	ENGINE MANAGEME	2.0 20v B5204 (...98)	BOSCH Motronic 4.3
 850	ENGINE MANAGEME	2.0 T B5204T (...98)	BOSCH Motronic 4.3
 850	ENGINE MANAGEME	2.0 T B5204T (...98)	BOSCH Motronic 4.4
 850	ENGINE MANAGEME	2.3 T5-R B5234T/T5 (...98)	BOSCH Motronic 4.3
 850	ENGINE MANAGEME	2.3 T5-R B5234T/T5 (...98)	BOSCH Motronic 4.4
 850	ENGINE MANAGEME	2.5 T B5254S (...98)	BOSCH Motronic 4.3
 850	ENGINE MANAGEME	2.5 T B5254S (...98)	BOSCH Motronic 4.4
 850	IMMOBILIZER	2.0 10V (...98)	BOSCH Immobilizer Cartronic 2
 850	IMMOBILIZER	2.0 20v (...98)	BOSCH Immobilizer Cartronic 2
 850	IMMOBILIZER	2.0 T (...98)	BOSCH Immobilizer Cartronic 2
 850	IMMOBILIZER	2.3 T5-R (...98)	BOSCH Immobilizer Cartronic 2
 850	IMMOBILIZER	2.4 10V (...98)	BOSCH Immobilizer Cartronic 2
 850	IMMOBILIZER	2.4 20v (...98)	BOSCH Immobilizer Cartronic 2
 850	IMMOBILIZER	2.5 T (...98)	BOSCH Immobilizer Cartronic 2
 850	IMMOBILIZER	2.5 TDI (...98)	BOSCH Immobilizer Cartronic 2
 850	MAINTENANCE	2.0 10V (...97)	MANUAL
 850	MAINTENANCE	2.0 10V (96-97)	
 850	MAINTENANCE	2.0 20v (...97)	MANUAL
 850	MAINTENANCE	2.0 20v (96-97)	
 850	MAINTENANCE	2.0 T (...97)	MANUAL
 850	MAINTENANCE	2.0 T (96-97)	
 850	MAINTENANCE	2.3 T5-R (...97)	MANUAL
 850	MAINTENANCE	2.3 T5-R (96-97)	
 850	MAINTENANCE	2.4 10V (...97)	MANUAL
 850	MAINTENANCE	2.4 10V (96-97)	
 850	MAINTENANCE	2.4 20v (...97)	MANUAL
 850	MAINTENANCE	2.4 20v (96-97)	
 850	MAINTENANCE	2.5 T (...97)	MANUAL
 850	MAINTENANCE	2.5 T (96-97)	
 850	MAINTENANCE	2.5 TDI (...97)	MANUAL
 850	MAINTENANCE	2.5 TDI (96-97)	
 850	SERVICE LIGHT RES	2.0 10V (...97)	MANUAL
 850	SERVICE LIGHT RES	2.0 10V (96-97)	
 850	SERVICE LIGHT RES	2.0 20v (...97)	MANUAL
 850	SERVICE LIGHT RES	2.0 20v (96-97)	
 850	SERVICE LIGHT RES	2.0 T (...97)	MANUAL
 850	SERVICE LIGHT RES	2.0 T (96-97)	
 850	SERVICE LIGHT RES	2.3 T5-R (...97)	MANUAL
 850	SERVICE LIGHT RES	2.3 T5-R (96-97)	
 850	SERVICE LIGHT RES	2.4 10V (...97)	MANUAL
 850	SERVICE LIGHT RES	2.4 10V (96-97)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 850	SERVICE LIGHT RES	2.4 20v (...97)	MANUAL
 850	SERVICE LIGHT RES	2.4 20v (96-97)	
 850	SERVICE LIGHT RES	2.5 T (...97)	MANUAL
 850	SERVICE LIGHT RES	2.5 T (96-97)	
 850	SERVICE LIGHT RES	2.5 TDI (...97)	MANUAL
 850	SERVICE LIGHT RES	2.5 TDI (96-97)	
 940	AIRBAG	2.0 (...98)	BOSCH - Autoliv AirBag 6.2
 940	AIRBAG	2.0 T (...98)	BOSCH - Autoliv AirBag 6.2
 940	AIRBAG	2.3 (...98)	BOSCH - Autoliv AirBag 6.2
 940	AIRBAG	2.3 T (...98)	BOSCH - Autoliv AirBag 6.2
 940	AIRBAG	2.5 T (...98)	BOSCH - Autoliv AirBag 6.2
 940	ENGINE MANAGEME	2.5 T B5254S (...98)	BOSCH Motronic 4.4
 940	IMMOBILIZER	2.0 (...98)	BOSCH Immobilizer Cartronic 2
 940	IMMOBILIZER	2.0 T (...98)	BOSCH Immobilizer Cartronic 2
 940	IMMOBILIZER	2.3 (...98)	BOSCH Immobilizer Cartronic 2
 940	IMMOBILIZER	2.3 T (...98)	BOSCH Immobilizer Cartronic 2
 940	IMMOBILIZER	2.5 T (...98)	BOSCH Immobilizer Cartronic 2
 940	MAINTENANCE	2.0 (...97)	MANUAL
 940	MAINTENANCE	2.0 T (...97)	MANUAL
 940	MAINTENANCE	2.3 (...97)	MANUAL
 940	MAINTENANCE	2.3 T (...97)	MANUAL
 940	MAINTENANCE	2.5 T (...97)	MANUAL
 940	SERVICE LIGHT RES	2.0 (...97)	MANUAL
 940	SERVICE LIGHT RES	2.0 T (...97)	MANUAL
 940	SERVICE LIGHT RES	2.3 (...97)	MANUAL
 940	SERVICE LIGHT RES	2.3 T (...97)	MANUAL
 940	SERVICE LIGHT RES	2.5 T (...97)	MANUAL
 960	AIRBAG	2.5 T (...98)	BOSCH - Autoliv AirBag 6.2
 960	ENGINE MANAGEME	2.5 T B5254S (...98)	BOSCH Motronic 4.3
 960	ENGINE MANAGEME	2.5 T B5254S (...98)	BOSCH Motronic 4.4
 960	IMMOBILIZER	2.5 T (...98)	BOSCH Immobilizer Cartronic 2
 C30 (06-..)	ABS	1.6 (06-..)	ATE BCM1 Brake Control Module
 C30 (06-..)	ABS	1.6 (06-..)	ATE BCM2 Brake Control Module
 C30 (06-..)	ABS	1.6 (06-..)	ATE BCM3 Brake Control Module
 C30 (06-..)	ABS	1.6 D (06-..)	ATE BCM1 Brake Control Module
 C30 (06-..)	ABS	1.6 D (06-..)	ATE BCM2 Brake Control Module
 C30 (06-..)	ABS	1.6 D (06-..)	ATE BCM3 Brake Control Module
 C30 (06-..)	ABS	1.8 (06-..)	ATE BCM1 Brake Control Module
 C30 (06-..)	ABS	1.8 (06-..)	ATE BCM2 Brake Control Module
 C30 (06-..)	ABS	1.8 (06-..)	ATE BCM3 Brake Control Module
 C30 (06-..)	ABS	1.8 16V FLEXIFUEL (06-..)	ATE BCM1 Brake Control Module
 C30 (06-..)	ABS	1.8 16V FLEXIFUEL (06-..)	ATE BCM2 Brake Control Module
 C30 (06-..)	ABS	1.8 16V FLEXIFUEL (06-..)	ATE BCM3 Brake Control Module
 C30 (06-..)	ABS	2.0 (06-..)	ATE BCM1 Brake Control Module
 C30 (06-..)	ABS	2.0 (06-..)	ATE BCM2 Brake Control Module
 C30 (06-..)	ABS	2.0 (06-..)	ATE BCM3 Brake Control Module
 C30 (06-..)	ABS	2.0 D (06-..)	ATE BCM1 Brake Control Module
 C30 (06-..)	ABS	2.0 D (06-..)	ATE BCM2 Brake Control Module
 C30 (06-..)	ABS	2.0 D (06-..)	ATE BCM3 Brake Control Module
 C30 (06-..)	ABS	2.4 D5 (06-..)	ATE BCM1 Brake Control Module
 C30 (06-..)	ABS	2.4 D5 (06-..)	ATE BCM2 Brake Control Module
 C30 (06-..)	ABS	2.4 D5 (06-..)	ATE BCM3 Brake Control Module
 C30 (06-..)	ABS	2.5 T5 (06-..)	ATE BCM1 Brake Control Module
 C30 (06-..)	ABS	2.5 T5 (06-..)	ATE BCM2 Brake Control Module
 C30 (06-..)	ABS	2.5 T5 (06-..)	ATE BCM3 Brake Control Module
 C30 (06-..)	AIRBAG	1.6 (06-..)	SRS AirBag
 C30 (06-..)	AIRBAG	1.6 D (06-..)	SRS AirBag
 C30 (06-..)	AIRBAG	1.8 (06-..)	SRS AirBag

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C30 (06-..)	AIRBAG	1.8 16V FLEXIFUEL (06-..)	SRS AirBag
 C30 (06-..)	AIRBAG	2.0 (06-..)	SRS AirBag
 C30 (06-..)	AIRBAG	2.0 D (06-..)	SRS AirBag
 C30 (06-..)	AIRBAG	2.4 D5 (06-..)	SRS AirBag
 C30 (06-..)	AIRBAG	2.5 T5 (06-..)	SRS AirBag
 C30 (06-..)	CLIMA	1.6 (06-..)	CLIMA
 C30 (06-..)	CLIMA	1.6 D (06-..)	CLIMA
 C30 (06-..)	CLIMA	1.8 (06-..)	CLIMA
 C30 (06-..)	CLIMA	1.8 16V FLEXIFUEL (06-..)	CLIMA
 C30 (06-..)	CLIMA	2.0 (06-..)	CLIMA
 C30 (06-..)	CLIMA	2.0 D (06-..)	CLIMA
 C30 (06-..)	CLIMA	2.4 D5 (06-..)	CLIMA
 C30 (06-..)	CLIMA	2.5 T5 (06-..)	CLIMA
 C30 (06-..)	DASHBOARD	1.6 (06-..)	DIM Driver Information Module
 C30 (06-..)	DASHBOARD	1.6 D (06-..)	DIM Driver Information Module
 C30 (06-..)	DASHBOARD	1.8 (06-..)	DIM Driver Information Module
 C30 (06-..)	DASHBOARD	1.8 16V FLEXIFUEL (06-..)	DIM Driver Information Module
 C30 (06-..)	DASHBOARD	2.0 (06-..)	DIM Driver Information Module
 C30 (06-..)	DASHBOARD	2.0 D (06-..)	DIM Driver Information Module
 C30 (06-..)	DASHBOARD	2.4 D5 (06-..)	DIM Driver Information Module
 C30 (06-..)	DASHBOARD	2.5 T5 (06-..)	DIM Driver Information Module
 C30 (06-..)	DIESEL ADDITION	1.6 D (06-..)	ADM Additive Dosing Module
 C30 (06-..)	DIESEL ADDITION	2.0 D (06-..)	ADM Additive Dosing Module
 C30 (06-..)	DIESEL ADDITION	2.4 D5 (06-..)	ADM Additive Dosing Module
 C30 (06-..)	DRIVER SIDE DOOR	1.6 (06-..)	DDM Driver Door Module
 C30 (06-..)	DRIVER SIDE DOOR	1.6 D (06-..)	DDM Driver Door Module
 C30 (06-..)	DRIVER SIDE DOOR	1.8 (06-..)	DDM Driver Door Module
 C30 (06-..)	DRIVER SIDE DOOR	1.8 16V FLEXIFUEL (06-..)	DDM Driver Door Module
 C30 (06-..)	DRIVER SIDE DOOR	2.0 (06-..)	DDM Driver Door Module
 C30 (06-..)	DRIVER SIDE DOOR	2.0 D (06-..)	DDM Driver Door Module
 C30 (06-..)	DRIVER SIDE DOOR	2.4 D5 (06-..)	DDM Driver Door Module
 C30 (06-..)	DRIVER SIDE DOOR	2.5 T5 (06-..)	DDM Driver Door Module
 C30 (06-..)	ELECTRIC STEERING	1.6 (06-..)	EPS Electric Power Steering
 C30 (06-..)	ELECTRIC STEERING	1.6 D (06-..)	EPS Electric Power Steering
 C30 (06-..)	ELECTRIC STEERING	1.8 (06-..)	EPS Electric Power Steering
 C30 (06-..)	ELECTRIC STEERING	1.8 16V FLEXIFUEL (06-..)	EPS Electric Power Steering
 C30 (06-..)	ELECTRIC STEERING	2.0 (06-..)	EPS Electric Power Steering
 C30 (06-..)	ELECTRIC STEERING	2.0 D (06-..)	EPS Electric Power Steering
 C30 (06-..)	ELECTRIC STEERING	2.4 D5 (06-..)	EPS Electric Power Steering
 C30 (06-..)	ELECTRIC STEERING	2.5 T5 (06-..)	EPS Electric Power Steering
 C30 (06-..)	ENGINE MANAGEME	1.6 (06-..)	EOBD
 C30 (06-..)	ENGINE MANAGEME	1.6 D (06-..)	EOBD
 C30 (06-..)	ENGINE MANAGEME	1.8 16V FLEXIFUEL (06-..)	EOBD
 C30 (06-..)	ENGINE MANAGEME	1.8 B4184S (06-..)	MPI
 C30 (06-..)	ENGINE MANAGEME	2.0 (06-..)	EOBD
 C30 (06-..)	ENGINE MANAGEME	2.0 D D4204T (06-..)	ECM Common Rail
 C30 (06-..)	ENGINE MANAGEME	2.4 D5 (06-..)	EOBD
 C30 (06-..)	ENGINE MANAGEME	2.5 T5 B5254T3 (06-..)	BOSCH Motronic ME9
 C30 (06-..)	MAINTENANCE	1.6 (06-..)	DIM
 C30 (06-..)	MAINTENANCE	1.6 D (06-..)	DIM
 C30 (06-..)	MAINTENANCE	1.8 (06-..)	DIM
 C30 (06-..)	MAINTENANCE	1.8 16V FLEXIFUEL (06-..)	DIM
 C30 (06-..)	MAINTENANCE	2.0 (06-..)	DIM
 C30 (06-..)	MAINTENANCE	2.0 D (06-..)	DIM
 C30 (06-..)	MAINTENANCE	2.4 D5 (06-..)	DIM
 C30 (06-..)	MAINTENANCE	2.5 T5 (06-..)	DIM
 C30 (06-..)	PARKING HELP	1.6 (06-..)	PAM Park Assist Module
 C30 (06-..)	PARKING HELP	1.6 D (06-..)	PAM Park Assist Module

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C30 (06-..)	PARKING HELP	1.8 (06-..)	PAM Park Assist Module
 C30 (06-..)	PARKING HELP	1.8 16V FLEXIFUEL (06-..)	PAM Park Assist Module
 C30 (06-..)	PARKING HELP	2.0 (06-..)	PAM Park Assist Module
 C30 (06-..)	PARKING HELP	2.0 D (06-..)	PAM Park Assist Module
 C30 (06-..)	PARKING HELP	2.4 D5 (06-..)	PAM Park Assist Module
 C30 (06-..)	PARKING HELP	2.5 T5 (06-..)	PAM Park Assist Module
 C30 (06-..)	PASS. SIDE DOOR	1.6 (06-..)	PDM Passenger Door Module
 C30 (06-..)	PASS. SIDE DOOR	1.6 D (06-..)	PDM Passenger Door Module
 C30 (06-..)	PASS. SIDE DOOR	1.8 (06-..)	PDM Passenger Door Module
 C30 (06-..)	PASS. SIDE DOOR	1.8 16V FLEXIFUEL (06-..)	PDM Passenger Door Module
 C30 (06-..)	PASS. SIDE DOOR	2.0 (06-..)	PDM Passenger Door Module
 C30 (06-..)	PASS. SIDE DOOR	2.0 D (06-..)	PDM Passenger Door Module
 C30 (06-..)	PASS. SIDE DOOR	2.4 D5 (06-..)	PDM Passenger Door Module
 C30 (06-..)	PASS. SIDE DOOR	2.5 T5 (06-..)	PDM Passenger Door Module
 C30 (06-..)	PASSENGER SEAT R	1.6 (06-..)	PSR Power Seat Module Right
 C30 (06-..)	PASSENGER SEAT R	1.6 D (06-..)	PSR Power Seat Module Right
 C30 (06-..)	PASSENGER SEAT R	1.8 (06-..)	PSR Power Seat Module Right
 C30 (06-..)	PASSENGER SEAT R	1.8 16V FLEXIFUEL (06-..)	PSR Power Seat Module Right
 C30 (06-..)	PASSENGER SEAT R	2.0 (06-..)	PSR Power Seat Module Right
 C30 (06-..)	PASSENGER SEAT R	2.0 D (06-..)	PSR Power Seat Module Right
 C30 (06-..)	PASSENGER SEAT R	2.4 D5 (06-..)	PSR Power Seat Module Right
 C30 (06-..)	PASSENGER SEAT R	2.5 T5 (06-..)	PSR Power Seat Module Right
 C30 (06-..)	RADIO / CD	1.6 (06-..)	ACM Audio Module
 C30 (06-..)	RADIO / CD	1.6 (06-..)	IAM Integrated Audio Module
 C30 (06-..)	RADIO / CD	1.6 D (06-..)	ACM Audio Module
 C30 (06-..)	RADIO / CD	1.6 D (06-..)	IAM Integrated Audio Module
 C30 (06-..)	RADIO / CD	1.8 (06-..)	ACM Audio Module
 C30 (06-..)	RADIO / CD	1.8 (06-..)	IAM Integrated Audio Module
 C30 (06-..)	RADIO / CD	1.8 16V FLEXIFUEL (06-..)	ACM Audio Module
 C30 (06-..)	RADIO / CD	1.8 16V FLEXIFUEL (06-..)	IAM Integrated Audio Module
 C30 (06-..)	RADIO / CD	2.0 (06-..)	ACM Audio Module
 C30 (06-..)	RADIO / CD	2.0 (06-..)	IAM Integrated Audio Module
 C30 (06-..)	RADIO / CD	2.0 D (06-..)	ACM Audio Module
 C30 (06-..)	RADIO / CD	2.0 D (06-..)	IAM Integrated Audio Module
 C30 (06-..)	RADIO / CD	2.4 D5 (06-..)	ACM Audio Module
 C30 (06-..)	RADIO / CD	2.4 D5 (06-..)	IAM Integrated Audio Module
 C30 (06-..)	RADIO / CD	2.5 T5 (06-..)	ACM Audio Module
 C30 (06-..)	RADIO / CD	2.5 T5 (06-..)	IAM Integrated Audio Module
 C30 (06-..)	SERVICE LIGHT RES	1.6 (06-..)	DIM
 C30 (06-..)	SERVICE LIGHT RES	1.6 D (06-..)	DIM
 C30 (06-..)	SERVICE LIGHT RES	1.8 (06-..)	DIM
 C30 (06-..)	SERVICE LIGHT RES	1.8 16V FLEXIFUEL (06-..)	DIM
 C30 (06-..)	SERVICE LIGHT RES	2.0 (06-..)	DIM
 C30 (06-..)	SERVICE LIGHT RES	2.0 D (06-..)	DIM
 C30 (06-..)	SERVICE LIGHT RES	2.4 D5 (06-..)	DIM
 C30 (06-..)	SERVICE LIGHT RES	2.5 T5 (06-..)	DIM
 C30 (06-..)	STEERING WHEEL E	1.6 (06-..)	SWM1 Steering Wheel Module
 C30 (06-..)	STEERING WHEEL E	1.6 (06-..)	SWM2 Steering Wheel Module
 C30 (06-..)	STEERING WHEEL E	1.6 D (06-..)	SWM1 Steering Wheel Module
 C30 (06-..)	STEERING WHEEL E	1.6 D (06-..)	SWM2 Steering Wheel Module
 C30 (06-..)	STEERING WHEEL E	1.8 (06-..)	SWM1 Steering Wheel Module
 C30 (06-..)	STEERING WHEEL E	1.8 (06-..)	SWM2 Steering Wheel Module
 C30 (06-..)	STEERING WHEEL E	1.8 16V FLEXIFUEL (06-..)	SWM1 Steering Wheel Module
 C30 (06-..)	STEERING WHEEL E	1.8 16V FLEXIFUEL (06-..)	SWM2 Steering Wheel Module
 C30 (06-..)	STEERING WHEEL E	2.0 (06-..)	SWM1 Steering Wheel Module
 C30 (06-..)	STEERING WHEEL E	2.0 (06-..)	SWM2 Steering Wheel Module
 C30 (06-..)	STEERING WHEEL E	2.0 D (06-..)	SWM1 Steering Wheel Module
 C30 (06-..)	STEERING WHEEL E	2.0 D (06-..)	SWM2 Steering Wheel Module

Systems supported by ECReader / ECDecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C30 (06-..)	STEERING WHEEL E	2.4 D5 (06-..)	SWM1 Steering Wheel Module
 C30 (06-..)	STEERING WHEEL E	2.4 D5 (06-..)	SWM2 Steering Wheel Module
 C30 (06-..)	STEERING WHEEL E	2.5 T5 (06-..)	SWM1 Steering Wheel Module
 C30 (06-..)	STEERING WHEEL E	2.5 T5 (06-..)	SWM2 Steering Wheel Module
 C30 (06-..)	VISUAL/TELEMATIC	1.6 (06-..)	ICM Infotainment Control Module
 C30 (06-..)	VISUAL/TELEMATIC	1.6 D (06-..)	ICM Infotainment Control Module
 C30 (06-..)	VISUAL/TELEMATIC	1.8 (06-..)	ICM Infotainment Control Module
 C30 (06-..)	VISUAL/TELEMATIC	1.8 16V FLEXIFUEL (06-..)	ICM Infotainment Control Module
 C30 (06-..)	VISUAL/TELEMATIC	2.0 (06-..)	ICM Infotainment Control Module
 C30 (06-..)	VISUAL/TELEMATIC	2.0 D (06-..)	ICM Infotainment Control Module
 C30 (06-..)	VISUAL/TELEMATIC	2.4 D5 (06-..)	ICM Infotainment Control Module
 C30 (06-..)	VISUAL/TELEMATIC	2.5 T5 (06-..)	ICM Infotainment Control Module
 C70 (06-..)	ABS	2.0 D (06-..)	ATE BCM2 Brake Control Module
 C70 (06-..)	ABS	2.4 140cv (06-..)	ATE BCM2 Brake Control Module
 C70 (06-..)	ABS	2.4 170cv (06-..)	ATE BCM2 Brake Control Module
 C70 (06-..)	ABS	2.4 D5 (06-..)	ATE BCM2 Brake Control Module
 C70 (06-..)	ABS	2.5 T5 (06-..)	ATE BCM2 Brake Control Module
 C70 (06-..)	CONV. TOP/SUNROO	2.0 D (06-..)	CRM Convertible Roof Module
 C70 (06-..)	CONV. TOP/SUNROO	2.4 140cv (06-..)	CRM Convertible Roof Module
 C70 (06-..)	CONV. TOP/SUNROO	2.4 170cv (06-..)	CRM Convertible Roof Module
 C70 (06-..)	CONV. TOP/SUNROO	2.4 D5 (06-..)	CRM Convertible Roof Module
 C70 (06-..)	CONV. TOP/SUNROO	2.5 T5 (06-..)	CRM Convertible Roof Module
 C70 (06-..)	DASHBOARD	2.0 D (06-..)	DIM Driver Information Module
 C70 (06-..)	DASHBOARD	2.4 140cv (06-..)	DIM Driver Information Module
 C70 (06-..)	DASHBOARD	2.4 170cv (06-..)	DIM Driver Information Module
 C70 (06-..)	DASHBOARD	2.4 D5 (06-..)	DIM Driver Information Module
 C70 (06-..)	DASHBOARD	2.5 T5 (06-..)	DIM Driver Information Module
 C70 (06-..)	ELECTRIC STEERING	2.0 D (06-..)	EPS Electric Power Steering
 C70 (06-..)	ELECTRIC STEERING	2.4 140cv (06-..)	EPS Electric Power Steering
 C70 (06-..)	ELECTRIC STEERING	2.4 170cv (06-..)	EPS Electric Power Steering
 C70 (06-..)	ELECTRIC STEERING	2.4 D5 (06-..)	EPS Electric Power Steering
 C70 (06-..)	ELECTRIC STEERING	2.5 T5 (06-..)	EPS Electric Power Steering
 C70 (06-..)	ENGINE MANAGEME	2.0 D (06-..)	EOBD
 C70 (06-..)	ENGINE MANAGEME	2.4 140cv (06-..)	EOBD
 C70 (06-..)	ENGINE MANAGEME	2.4 170cv (06-..)	EOBD
 C70 (06-..)	ENGINE MANAGEME	2.4 D5 (06-..)	EOBD
 C70 (06-..)	ENGINE MANAGEME	2.5 T5 B5254T3 (06-..)	BOSCH Motronic ME9
 C70 (06-..)	GEARBOX MANAGEM	2.0 D (06-..)	TCM Trasmission Control Module
 C70 (06-..)	GEARBOX MANAGEM	2.4 140cv (06-..)	TCM Trasmission Control Module
 C70 (06-..)	GEARBOX MANAGEM	2.4 170cv (06-..)	TCM Trasmission Control Module
 C70 (06-..)	GEARBOX MANAGEM	2.4 D5 (06-..)	TCM Trasmission Control Module
 C70 (06-..)	GEARBOX MANAGEM	2.5 T5 (06-..)	TCM Trasmission Control Module
 C70 (06-..)	PARKING HELP	2.0 D (06-..)	PAM Park Assist Module
 C70 (06-..)	PARKING HELP	2.4 140cv (06-..)	PAM Park Assist Module
 C70 (06-..)	PARKING HELP	2.4 170cv (06-..)	PAM Park Assist Module
 C70 (06-..)	PARKING HELP	2.4 D5 (06-..)	PAM Park Assist Module
 C70 (06-..)	PARKING HELP	2.5 T5 (06-..)	PAM Park Assist Module
 C70 (06-..)	PASSENGER SEAT R	2.0 D (06-..)	PSR Power Seat Module Right
 C70 (06-..)	PASSENGER SEAT R	2.4 140cv (06-..)	PSR Power Seat Module Right
 C70 (06-..)	PASSENGER SEAT R	2.4 170cv (06-..)	PSR Power Seat Module Right
 C70 (06-..)	PASSENGER SEAT R	2.4 D5 (06-..)	PSR Power Seat Module Right
 C70 (06-..)	PASSENGER SEAT R	2.5 T5 (06-..)	PSR Power Seat Module Right
 C70 (06-..)	STEERING WHEEL E	2.0 D (06-..)	SWM1 Steering Wheel Module
 C70 (06-..)	STEERING WHEEL E	2.4 140cv (06-..)	SWM1 Steering Wheel Module
 C70 (06-..)	STEERING WHEEL E	2.4 170cv (06-..)	SWM1 Steering Wheel Module
 C70 (06-..)	STEERING WHEEL E	2.4 D5 (06-..)	SWM1 Steering Wheel Module
 C70 (06-..)	STEERING WHEEL E	2.5 T5 (06-..)	SWM1 Steering Wheel Module
 C70 Cabrio (99-05)	AIRBAG	2.0 T (99-05)	BOSCH - Autoliv AirBag 6.2

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C70 Cabrio (99-05)	AIRBAG	2.0 T5 (99-05)	BOSCH - Autoliv AirBag 6.2
 C70 Cabrio (99-05)	AIRBAG	2.3 T (99-05)	BOSCH - Autoliv AirBag 6.2
 C70 Cabrio (99-05)	AIRBAG	2.4 T (99-05)	BOSCH - Autoliv AirBag 6.2
 C70 Cabrio (99-05)	ENGINE MANAGEME	2.0 T (01-05)	EOBD
 C70 Cabrio (99-05)	ENGINE MANAGEME	2.0 T5 (01-05)	EOBD
 C70 Cabrio (99-05)	ENGINE MANAGEME	2.3 T (01-05)	EOBD
 C70 Cabrio (99-05)	ENGINE MANAGEME	2.4 T (01-05)	EOBD
 C70 Cabrio (99-05)	IMMOBILIZER	2.0 T (99-05)	BOSCH Immobilizer Cartronic 2
 C70 Cabrio (99-05)	IMMOBILIZER	2.0 T (99-05)	BOSCH Immobilizer Immo 3
 C70 Cabrio (99-05)	IMMOBILIZER	2.0 T5 (99-05)	BOSCH Immobilizer Cartronic 2
 C70 Cabrio (99-05)	IMMOBILIZER	2.0 T5 (99-05)	BOSCH Immobilizer Immo 3
 C70 Cabrio (99-05)	IMMOBILIZER	2.3 T (99-05)	BOSCH Immobilizer Cartronic 2
 C70 Cabrio (99-05)	IMMOBILIZER	2.3 T (99-05)	BOSCH Immobilizer Immo 3
 C70 Cabrio (99-05)	IMMOBILIZER	2.4 T (99-05)	BOSCH Immobilizer Cartronic 2
 C70 Cabrio (99-05)	IMMOBILIZER	2.4 T (99-05)	BOSCH Immobilizer Immo 3
 C70 Cabrio (99-05)	MAINTENANCE	2.0 T (99-05)	MANUAL
 C70 Cabrio (99-05)	MAINTENANCE	2.0 T5 (99-05)	MANUAL
 C70 Cabrio (99-05)	MAINTENANCE	2.3 T (99-05)	MANUAL
 C70 Cabrio (99-05)	MAINTENANCE	2.4 T (99-05)	MANUAL
 C70 Cabrio (99-05)	SERVICE LIGHT RES	2.0 T (99-05)	MANUAL
 C70 Cabrio (99-05)	SERVICE LIGHT RES	2.0 T5 (99-05)	MANUAL
 C70 Cabrio (99-05)	SERVICE LIGHT RES	2.3 T (99-05)	MANUAL
 C70 Cabrio (99-05)	SERVICE LIGHT RES	2.4 T (99-05)	MANUAL
 C70 Coupe (97-02)	AIRBAG	2.0 T (97-02)	BOSCH - Autoliv AirBag 6.2
 C70 Coupe (97-02)	AIRBAG	2.0 T5 (97-02)	BOSCH - Autoliv AirBag 6.2
 C70 Coupe (97-02)	AIRBAG	2.3 T5 (97-02)	BOSCH - Autoliv AirBag 6.2
 C70 Coupe (97-02)	AIRBAG	2.4 T (97-02)	BOSCH - Autoliv AirBag 6.2
 C70 Coupe (97-02)	ENGINE MANAGEME	2.0 T (01-02)	EOBD
 C70 Coupe (97-02)	ENGINE MANAGEME	2.0 T5 (01-02)	EOBD
 C70 Coupe (97-02)	ENGINE MANAGEME	2.3 T5 (01-02)	EOBD
 C70 Coupe (97-02)	ENGINE MANAGEME	2.4 T (01-02)	EOBD
 C70 Coupe (97-02)	IMMOBILIZER	2.0 T (97-02)	BOSCH Immobilizer Cartronic 2
 C70 Coupe (97-02)	IMMOBILIZER	2.0 T (97-02)	BOSCH Immobilizer Immo 3
 C70 Coupe (97-02)	IMMOBILIZER	2.0 T5 (97-02)	BOSCH Immobilizer Cartronic 2
 C70 Coupe (97-02)	IMMOBILIZER	2.0 T5 (97-02)	BOSCH Immobilizer Immo 3
 C70 Coupe (97-02)	IMMOBILIZER	2.3 T5 (97-02)	BOSCH Immobilizer Cartronic 2
 C70 Coupe (97-02)	IMMOBILIZER	2.3 T5 (97-02)	BOSCH Immobilizer Immo 3
 C70 Coupe (97-02)	IMMOBILIZER	2.4 T (97-02)	BOSCH Immobilizer Cartronic 2
 C70 Coupe (97-02)	IMMOBILIZER	2.4 T (97-02)	BOSCH Immobilizer Immo 3
 C70 Coupe (97-02)	MAINTENANCE	2.0 T (97-02)	MANUAL
 C70 Coupe (97-02)	MAINTENANCE	2.0 T5 (97-02)	MANUAL
 C70 Coupe (97-02)	MAINTENANCE	2.3 T5 (97-02)	MANUAL
 C70 Coupe (97-02)	MAINTENANCE	2.4 T (97-02)	MANUAL
 C70 Coupe (97-02)	SERVICE LIGHT RES	2.0 T (97-02)	MANUAL
 C70 Coupe (97-02)	SERVICE LIGHT RES	2.0 T5 (97-02)	MANUAL
 C70 Coupe (97-02)	SERVICE LIGHT RES	2.3 T5 (97-02)	MANUAL
 C70 Coupe (97-02)	SERVICE LIGHT RES	2.4 T (97-02)	MANUAL
 S40 (04-..)	ABS	1.6 (04-07)	ATE BCM1 Brake Control Module
 S40 (04-..)	ABS	1.6 (04-07)	ATE BCM2 Brake Control Module
 S40 (04-..)	ABS	1.6 (04-07)	ATE BCM3 Brake Control Module
 S40 (04-..)	ABS	1.6 D (04-07)	ATE BCM1 Brake Control Module
 S40 (04-..)	ABS	1.6 D (04-07)	ATE BCM2 Brake Control Module
 S40 (04-..)	ABS	1.6 D (04-07)	ATE BCM3 Brake Control Module
 S40 (04-..)	ABS	1.8 (04-07)	ATE BCM1 Brake Control Module
 S40 (04-..)	ABS	1.8 (04-07)	ATE BCM2 Brake Control Module
 S40 (04-..)	ABS	1.8 (04-07)	ATE BCM3 Brake Control Module
 S40 (04-..)	ABS	1.8 FLEXIFUEL (04-07)	ATE BCM1 Brake Control Module
 S40 (04-..)	ABS	1.8 FLEXIFUEL (04-07)	ATE BCM2 Brake Control Module

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 S40 (04-..)	ABS	1.8 FLEXIFUEL (04-07)	ATE BCM3 Brake Control Module
 S40 (04-..)	ABS	2.0 (04-07)	ATE BCM1 Brake Control Module
 S40 (04-..)	ABS	2.0 (04-07)	ATE BCM2 Brake Control Module
 S40 (04-..)	ABS	2.0 (04-07)	ATE BCM3 Brake Control Module
 S40 (04-..)	ABS	2.0 D (04-07)	ATE BCM1 Brake Control Module
 S40 (04-..)	ABS	2.0 D (04-07)	ATE BCM2 Brake Control Module
 S40 (04-..)	ABS	2.0 D (04-07)	ATE BCM3 Brake Control Module
 S40 (04-..)	ABS	2.4 (04-07)	ATE BCM1 Brake Control Module
 S40 (04-..)	ABS	2.4 (04-07)	ATE BCM2 Brake Control Module
 S40 (04-..)	ABS	2.4 (04-07)	ATE BCM3 Brake Control Module
 S40 (04-..)	ABS	2.4 D5 (04-07)	ATE BCM1 Brake Control Module
 S40 (04-..)	ABS	2.4 D5 (04-07)	ATE BCM2 Brake Control Module
 S40 (04-..)	ABS	2.4 D5 (04-07)	ATE BCM3 Brake Control Module
 S40 (04-..)	ABS	2.5 T5 (04-07)	ATE BCM1 Brake Control Module
 S40 (04-..)	ABS	2.5 T5 (04-07)	ATE BCM2 Brake Control Module
 S40 (04-..)	ABS	2.5 T5 (04-07)	ATE BCM3 Brake Control Module
 S40 (04-..)	ABS	2.5 T5 AWD (04-07)	ATE BCM1 Brake Control Module
 S40 (04-..)	ABS	2.5 T5 AWD (04-07)	ATE BCM2 Brake Control Module
 S40 (04-..)	ABS	2.5 T5 AWD (04-07)	ATE BCM3 Brake Control Module
 S40 (04-..)	CLIMA	1.6 (04-..)	CLIMA
 S40 (04-..)	CLIMA	1.6 D (04-..)	CLIMA
 S40 (04-..)	CLIMA	1.8 (04-..)	CLIMA
 S40 (04-..)	CLIMA	1.8 FLEXIFUEL (04-..)	CLIMA
 S40 (04-..)	CLIMA	2.0 (04-..)	CLIMA
 S40 (04-..)	CLIMA	2.0 D (04-..)	CLIMA
 S40 (04-..)	CLIMA	2.4 (04-..)	CLIMA
 S40 (04-..)	CLIMA	2.4 D5 (04-..)	CLIMA
 S40 (04-..)	CLIMA	2.5 T5 (04-..)	CLIMA
 S40 (04-..)	CLIMA	2.5 T5 AWD (04-..)	CLIMA
 S40 (04-..)	DASHBOARD	1.6 (04-..)	DIM Driver Information Module
 S40 (04-..)	DASHBOARD	1.6 D (04-..)	DIM Driver Information Module
 S40 (04-..)	DASHBOARD	1.8 (04-..)	DIM Driver Information Module
 S40 (04-..)	DASHBOARD	1.8 FLEXIFUEL (04-..)	DIM Driver Information Module
 S40 (04-..)	DASHBOARD	2.0 (04-..)	DIM Driver Information Module
 S40 (04-..)	DASHBOARD	2.0 D (04-..)	DIM Driver Information Module
 S40 (04-..)	DASHBOARD	2.4 (04-..)	DIM Driver Information Module
 S40 (04-..)	DASHBOARD	2.4 D5 (04-..)	DIM Driver Information Module
 S40 (04-..)	DASHBOARD	2.5 T5 (04-..)	DIM Driver Information Module
 S40 (04-..)	DASHBOARD	2.5 T5 AWD (04-..)	DIM Driver Information Module
 S40 (04-..)	DIESEL ADDITION	1.6 D (04-..)	ADM Additive Dosing Module
 S40 (04-..)	DIESEL ADDITION	2.0 D (04-..)	ADM Additive Dosing Module
 S40 (04-..)	DIESEL ADDITION	2.4 D5 (04-..)	ADM Additive Dosing Module
 S40 (04-..)	DIFFERENTIAL MANA	2.5 T5 AWD (06-07)	DEM Differenzial Electronic Module
 S40 (04-..)	DRIVER SIDE DOOR	1.6 (04-..)	DDM Driver Door Module
 S40 (04-..)	DRIVER SIDE DOOR	1.6 D (04-..)	DDM Driver Door Module
 S40 (04-..)	DRIVER SIDE DOOR	1.8 (04-..)	DDM Driver Door Module
 S40 (04-..)	DRIVER SIDE DOOR	1.8 FLEXIFUEL (04-..)	DDM Driver Door Module
 S40 (04-..)	DRIVER SIDE DOOR	2.0 (04-..)	DDM Driver Door Module
 S40 (04-..)	DRIVER SIDE DOOR	2.0 D (04-..)	DDM Driver Door Module
 S40 (04-..)	DRIVER SIDE DOOR	2.4 (04-..)	DDM Driver Door Module
 S40 (04-..)	DRIVER SIDE DOOR	2.4 D5 (04-..)	DDM Driver Door Module
 S40 (04-..)	DRIVER SIDE DOOR	2.5 T5 (04-..)	DDM Driver Door Module
 S40 (04-..)	DRIVER SIDE DOOR	2.5 T5 AWD (04-..)	DDM Driver Door Module
 S40 (04-..)	ELECTRIC STEERING	1.6 (04-..)	EPS Electric Power Steering
 S40 (04-..)	ELECTRIC STEERING	1.6 D (04-..)	EPS Electric Power Steering
 S40 (04-..)	ELECTRIC STEERING	1.8 (04-..)	EPS Electric Power Steering
 S40 (04-..)	ELECTRIC STEERING	1.8 FLEXIFUEL (04-..)	EPS Electric Power Steering
 S40 (04-..)	ELECTRIC STEERING	2.0 (04-..)	EPS Electric Power Steering

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 S40 (04-..)	ELECTRIC STEERING	2.0 D (04-..)	EPS Electric Power Steering
 S40 (04-..)	ELECTRIC STEERING	2.4 (04-..)	EPS Electric Power Steering
 S40 (04-..)	ELECTRIC STEERING	2.4 D5 (04-..)	EPS Electric Power Steering
 S40 (04-..)	ELECTRIC STEERING	2.5 T5 (04-..)	EPS Electric Power Steering
 S40 (04-..)	ELECTRIC STEERING	2.5 T5 AWD (04-..)	EPS Electric Power Steering
 S40 (04-..)	ENGINE MANAGEME	1.6 (04-..)	EOBD
 S40 (04-..)	ENGINE MANAGEME	1.6 D (04-..)	EOBD
 S40 (04-..)	ENGINE MANAGEME	1.8 B4184S (04-..)	MPI
 S40 (04-..)	ENGINE MANAGEME	1.8 FLEXIFUEL (04-..)	EOBD
 S40 (04-..)	ENGINE MANAGEME	2.0 (04-..)	EOBD
 S40 (04-..)	ENGINE MANAGEME	2.0 D D4204T (04-..)	ECM Common Rail
 S40 (04-..)	ENGINE MANAGEME	2.4 (04-..)	EOBD
 S40 (04-..)	ENGINE MANAGEME	2.4 D5 (04-..)	EOBD
 S40 (04-..)	ENGINE MANAGEME	2.5 T5 AWD B5254T3 (04-..)	BOSCH Motronic ME9
 S40 (04-..)	ENGINE MANAGEME	2.5 T5 B5254T3 (04-..)	BOSCH Motronic ME9
 S40 (04-..)	GEARBOX MANAGEM	1.6 (06-07)	TCM Trasmission Control Module
 S40 (04-..)	GEARBOX MANAGEM	1.6 D (06-07)	TCM Trasmission Control Module
 S40 (04-..)	GEARBOX MANAGEM	1.8 (06-07)	TCM Trasmission Control Module
 S40 (04-..)	GEARBOX MANAGEM	1.8 FLEXIFUEL (06-07)	TCM Trasmission Control Module
 S40 (04-..)	GEARBOX MANAGEM	2.0 (06-07)	TCM Trasmission Control Module
 S40 (04-..)	GEARBOX MANAGEM	2.0 D (06-07)	TCM Trasmission Control Module
 S40 (04-..)	GEARBOX MANAGEM	2.4 (06-07)	TCM Trasmission Control Module
 S40 (04-..)	GEARBOX MANAGEM	2.4 D5 (06-07)	TCM Trasmission Control Module
 S40 (04-..)	GEARBOX MANAGEM	2.5 T5 (06-07)	TCM Trasmission Control Module
 S40 (04-..)	GEARBOX MANAGEM	2.5 T5 AWD (06-07)	TCM Trasmission Control Module
 S40 (04-..)	MAINTENANCE	1.6 D (04-07)	DIM
 S40 (04-..)	MAINTENANCE	1.8 (04-07)	DIM
 S40 (04-..)	MAINTENANCE	1.8 FLEXIFUEL (04-07)	DIM
 S40 (04-..)	MAINTENANCE	2.0 (04-07)	DIM
 S40 (04-..)	MAINTENANCE	2.0 D (04-07)	DIM
 S40 (04-..)	MAINTENANCE	2.4 (04-07)	DIM
 S40 (04-..)	MAINTENANCE	2.4 D5 (04-07)	DIM
 S40 (04-..)	MAINTENANCE	2.5 T5 (04-07)	DIM
 S40 (04-..)	MAINTENANCE	2.5 T5 AWD (04-07)	DIM
 S40 (04-..)	PARKING HELP	1.6 (06-07)	PAM Park Assist Module
 S40 (04-..)	PARKING HELP	1.6 D (06-07)	PAM Park Assist Module
 S40 (04-..)	PARKING HELP	1.8 (06-07)	PAM Park Assist Module
 S40 (04-..)	PARKING HELP	1.8 FLEXIFUEL (06-07)	PAM Park Assist Module
 S40 (04-..)	PARKING HELP	2.0 (06-07)	PAM Park Assist Module
 S40 (04-..)	PARKING HELP	2.0 D (06-07)	PAM Park Assist Module
 S40 (04-..)	PARKING HELP	2.4 (06-07)	PAM Park Assist Module
 S40 (04-..)	PARKING HELP	2.4 D5 (06-07)	PAM Park Assist Module
 S40 (04-..)	PARKING HELP	2.5 T5 (06-07)	PAM Park Assist Module
 S40 (04-..)	PARKING HELP	2.5 T5 AWD (06-07)	PAM Park Assist Module
 S40 (04-..)	PASS. SIDE DOOR	1.6 (04-..)	PDM Passenger Door Module
 S40 (04-..)	PASS. SIDE DOOR	1.6 D (04-..)	PDM Passenger Door Module
 S40 (04-..)	PASS. SIDE DOOR	1.8 (04-..)	PDM Passenger Door Module
 S40 (04-..)	PASS. SIDE DOOR	1.8 FLEXIFUEL (04-..)	PDM Passenger Door Module
 S40 (04-..)	PASS. SIDE DOOR	2.0 (04-..)	PDM Passenger Door Module
 S40 (04-..)	PASS. SIDE DOOR	2.0 D (04-..)	PDM Passenger Door Module
 S40 (04-..)	PASS. SIDE DOOR	2.4 (04-..)	PDM Passenger Door Module
 S40 (04-..)	PASS. SIDE DOOR	2.4 D5 (04-..)	PDM Passenger Door Module
 S40 (04-..)	PASS. SIDE DOOR	2.5 T5 (04-..)	PDM Passenger Door Module
 S40 (04-..)	PASS. SIDE DOOR	2.5 T5 AWD (04-..)	PDM Passenger Door Module
 S40 (04-..)	PASSENGER SEAT R	1.6 (06-07)	PSR Power Seat Module Right
 S40 (04-..)	PASSENGER SEAT R	1.6 D (06-07)	PSR Power Seat Module Right
 S40 (04-..)	PASSENGER SEAT R	1.8 (06-07)	PSR Power Seat Module Right
 S40 (04-..)	PASSENGER SEAT R	1.8 FLEXIFUEL (06-07)	PSR Power Seat Module Right

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 S40 (04-..)	PASSENGER SEAT R	2.0 (06-07)	PSR Power Seat Module Right
 S40 (04-..)	PASSENGER SEAT R	2.0 D (06-07)	PSR Power Seat Module Right
 S40 (04-..)	PASSENGER SEAT R	2.4 (06-07)	PSR Power Seat Module Right
 S40 (04-..)	PASSENGER SEAT R	2.4 D5 (06-07)	PSR Power Seat Module Right
 S40 (04-..)	PASSENGER SEAT R	2.5 T5 (06-07)	PSR Power Seat Module Right
 S40 (04-..)	PASSENGER SEAT R	2.5 T5 AWD (06-07)	PSR Power Seat Module Right
 S40 (04-..)	RADIO / CD	1.6 (06-07)	IAM Integrated Audio Module
 S40 (04-..)	RADIO / CD	1.6 D (06-07)	IAM Integrated Audio Module
 S40 (04-..)	RADIO / CD	1.8 (06-07)	IAM Integrated Audio Module
 S40 (04-..)	RADIO / CD	1.8 FLEXIFUEL (06-07)	IAM Integrated Audio Module
 S40 (04-..)	RADIO / CD	2.0 (06-07)	IAM Integrated Audio Module
 S40 (04-..)	RADIO / CD	2.0 D (06-07)	IAM Integrated Audio Module
 S40 (04-..)	RADIO / CD	2.4 (06-07)	IAM Integrated Audio Module
 S40 (04-..)	RADIO / CD	2.4 D5 (06-07)	IAM Integrated Audio Module
 S40 (04-..)	RADIO / CD	2.5 T5 (06-07)	IAM Integrated Audio Module
 S40 (04-..)	RADIO / CD	2.5 T5 AWD (06-07)	IAM Integrated Audio Module
 S40 (04-..)	SERVICE LIGHT RES	1.6 D (04-07)	DIM
 S40 (04-..)	SERVICE LIGHT RES	1.8 (04-07)	DIM
 S40 (04-..)	SERVICE LIGHT RES	1.8 FLEXIFUEL (04-07)	DIM
 S40 (04-..)	SERVICE LIGHT RES	2.0 (04-07)	DIM
 S40 (04-..)	SERVICE LIGHT RES	2.0 D (04-07)	DIM
 S40 (04-..)	SERVICE LIGHT RES	2.4 (04-07)	DIM
 S40 (04-..)	SERVICE LIGHT RES	2.4 D5 (04-07)	DIM
 S40 (04-..)	SERVICE LIGHT RES	2.5 T5 (04-07)	DIM
 S40 (04-..)	SERVICE LIGHT RES	2.5 T5 AWD (04-07)	DIM
 S40 (04-..)	STEERING WHEEL E	1.6 (04-07)	SWM1 Steering Wheel Module
 S40 (04-..)	STEERING WHEEL E	1.6 (05-07)	SWM2 Steering Wheel Module
 S40 (04-..)	STEERING WHEEL E	1.6 D (04-07)	SWM1 Steering Wheel Module
 S40 (04-..)	STEERING WHEEL E	1.6 D (05-07)	SWM2 Steering Wheel Module
 S40 (04-..)	STEERING WHEEL E	1.8 (04-07)	SWM1 Steering Wheel Module
 S40 (04-..)	STEERING WHEEL E	1.8 (05-07)	SWM2 Steering Wheel Module
 S40 (04-..)	STEERING WHEEL E	1.8 FLEXIFUEL (04-07)	SWM1 Steering Wheel Module
 S40 (04-..)	STEERING WHEEL E	1.8 FLEXIFUEL (05-07)	SWM2 Steering Wheel Module
 S40 (04-..)	STEERING WHEEL E	2.0 (04-07)	SWM1 Steering Wheel Module
 S40 (04-..)	STEERING WHEEL E	2.0 (05-07)	SWM2 Steering Wheel Module
 S40 (04-..)	STEERING WHEEL E	2.0 D (04-07)	SWM1 Steering Wheel Module
 S40 (04-..)	STEERING WHEEL E	2.0 D (05-07)	SWM2 Steering Wheel Module
 S40 (04-..)	STEERING WHEEL E	2.4 (04-07)	SWM1 Steering Wheel Module
 S40 (04-..)	STEERING WHEEL E	2.4 (05-07)	SWM2 Steering Wheel Module
 S40 (04-..)	STEERING WHEEL E	2.4 D5 (04-07)	SWM1 Steering Wheel Module
 S40 (04-..)	STEERING WHEEL E	2.4 D5 (05-07)	SWM2 Steering Wheel Module
 S40 (04-..)	STEERING WHEEL E	2.5 T5 (04-07)	SWM1 Steering Wheel Module
 S40 (04-..)	STEERING WHEEL E	2.5 T5 (05-07)	SWM2 Steering Wheel Module
 S40 (04-..)	STEERING WHEEL E	2.5 T5 AWD (04-07)	SWM1 Steering Wheel Module
 S40 (04-..)	STEERING WHEEL E	2.5 T5 AWD (05-07)	SWM2 Steering Wheel Module
 S40 (04-..)	VISUAL/TELEMATIC	1.6 (06-07)	ICM Infotainment Control Module
 S40 (04-..)	VISUAL/TELEMATIC	1.6 D (06-07)	ICM Infotainment Control Module
 S40 (04-..)	VISUAL/TELEMATIC	1.8 (06-07)	ICM Infotainment Control Module
 S40 (04-..)	VISUAL/TELEMATIC	1.8 FLEXIFUEL (06-07)	ICM Infotainment Control Module
 S40 (04-..)	VISUAL/TELEMATIC	2.0 (06-07)	ICM Infotainment Control Module
 S40 (04-..)	VISUAL/TELEMATIC	2.0 D (06-07)	ICM Infotainment Control Module
 S40 (04-..)	VISUAL/TELEMATIC	2.4 (06-07)	ICM Infotainment Control Module
 S40 (04-..)	VISUAL/TELEMATIC	2.4 D5 (06-07)	ICM Infotainment Control Module
 S40 (04-..)	VISUAL/TELEMATIC	2.5 T5 (06-07)	ICM Infotainment Control Module
 S40 (04-..)	VISUAL/TELEMATIC	2.5 T5 AWD (06-07)	ICM Infotainment Control Module
 S40 (96-04)	ABS	1.6 (01-04)	ATE ABS
 S40 (96-04)	ABS	1.6 (01-04)	ATE/TEVES ABS Mk60
 S40 (96-04)	ABS	1.6 (96-99)	BOSCH ABS 5.3

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 S40 (96-04)	ABS	1.6 (99-00)	ABS
 S40 (96-04)	ABS	1.8 (01-04)	ATE ABS
 S40 (96-04)	ABS	1.8 (01-04)	ATE/TEVES ABS Mk60
 S40 (96-04)	ABS	1.8 (96-99)	BOSCH ABS 5.3
 S40 (96-04)	ABS	1.8 (99-00)	ABS
 S40 (96-04)	ABS	1.8 BI-FUEL (01-04)	ATE ABS
 S40 (96-04)	ABS	1.8 BI-FUEL (01-04)	ATE/TEVES ABS Mk60
 S40 (96-04)	ABS	1.8 BI-FUEL (96-99)	BOSCH ABS 5.3
 S40 (96-04)	ABS	1.8 BI-FUEL (99-00)	ABS
 S40 (96-04)	ABS	1.9 D (01-04)	ATE ABS
 S40 (96-04)	ABS	1.9 D (01-04)	ATE/TEVES ABS Mk60
 S40 (96-04)	ABS	1.9 D (96-99)	BOSCH ABS 5.3
 S40 (96-04)	ABS	1.9 D (99-00)	ABS
 S40 (96-04)	ABS	1.9 T4 (01-04)	ATE ABS
 S40 (96-04)	ABS	1.9 T4 (01-04)	ATE/TEVES ABS Mk60
 S40 (96-04)	ABS	1.9 T4 (96-99)	BOSCH ABS 5.3
 S40 (96-04)	ABS	1.9 T4 (99-00)	ABS
 S40 (96-04)	ABS	1.9 TD (01-04)	ATE ABS
 S40 (96-04)	ABS	1.9 TD (01-04)	ATE/TEVES ABS Mk60
 S40 (96-04)	ABS	1.9 TD (96-99)	BOSCH ABS 5.3
 S40 (96-04)	ABS	1.9 TD (99-00)	ABS
 S40 (96-04)	ABS	2.0 (01-04)	ATE ABS
 S40 (96-04)	ABS	2.0 (01-04)	ATE/TEVES ABS Mk60
 S40 (96-04)	ABS	2.0 (96-99)	BOSCH ABS 5.3
 S40 (96-04)	ABS	2.0 (99-00)	ABS
 S40 (96-04)	ABS	2.0 T (01-04)	ATE ABS
 S40 (96-04)	ABS	2.0 T (01-04)	ATE/TEVES ABS Mk60
 S40 (96-04)	ABS	2.0 T (96-99)	BOSCH ABS 5.3
 S40 (96-04)	ABS	2.0 T (99-00)	ABS
 S40 (96-04)	ABS	2.0 T4 (01-04)	ATE ABS
 S40 (96-04)	ABS	2.0 T4 (01-04)	ATE/TEVES ABS Mk60
 S40 (96-04)	ABS	2.0 T4 (96-99)	BOSCH ABS 5.3
 S40 (96-04)	ABS	2.0 T4 (99-00)	ABS
 S40 (96-04)	AIRBAG	1.6 (96-98)	BOSCH - Autoliv AirBag 6.2
 S40 (96-04)	AIRBAG	1.6 (99-04)	SRS AirBag
 S40 (96-04)	AIRBAG	1.8 (96-98)	BOSCH - Autoliv AirBag 6.2
 S40 (96-04)	AIRBAG	1.8 (99-04)	SRS AirBag
 S40 (96-04)	AIRBAG	1.8 BI-FUEL (96-98)	BOSCH - Autoliv AirBag 6.2
 S40 (96-04)	AIRBAG	1.8 BI-FUEL (99-04)	SRS AirBag
 S40 (96-04)	AIRBAG	1.9 D (96-98)	BOSCH - Autoliv AirBag 6.2
 S40 (96-04)	AIRBAG	1.9 D (99-04)	SRS AirBag
 S40 (96-04)	AIRBAG	1.9 T4 (96-98)	BOSCH - Autoliv AirBag 6.2
 S40 (96-04)	AIRBAG	1.9 T4 (99-04)	SRS AirBag
 S40 (96-04)	AIRBAG	1.9 TD (96-98)	BOSCH - Autoliv AirBag 6.2
 S40 (96-04)	AIRBAG	1.9 TD (99-04)	SRS AirBag
 S40 (96-04)	AIRBAG	2.0 (96-98)	BOSCH - Autoliv AirBag 6.2
 S40 (96-04)	AIRBAG	2.0 (99-04)	SRS AirBag
 S40 (96-04)	AIRBAG	2.0 T (96-98)	BOSCH - Autoliv AirBag 6.2
 S40 (96-04)	AIRBAG	2.0 T (99-04)	SRS AirBag
 S40 (96-04)	AIRBAG	2.0 T4 (96-98)	BOSCH - Autoliv AirBag 6.2
 S40 (96-04)	AIRBAG	2.0 T4 (99-04)	SRS AirBag
 S40 (96-04)	DASHBOARD	1.6 (99-..)	DIM Dashboard
 S40 (96-04)	DASHBOARD	1.8 (99-..)	DIM Dashboard
 S40 (96-04)	DASHBOARD	1.8 BI-FUEL (99-..)	DIM Dashboard
 S40 (96-04)	DASHBOARD	1.9 D (99-..)	DIM Dashboard
 S40 (96-04)	DASHBOARD	1.9 T4 (99-..)	DIM Dashboard
 S40 (96-04)	DASHBOARD	1.9 TD (99-..)	DIM Dashboard
 S40 (96-04)	DASHBOARD	2.0 (99-..)	DIM Dashboard

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 S40 (96-04)	DASHBOARD	2.0 T (99-..)	DIM Dashboard
 S40 (96-04)	DASHBOARD	2.0 T4 (99-..)	DIM Dashboard
 S40 (96-04)	ENGINE MANAGEME	1.6 (...99)	SIEMENS FENIX 5.1
 S40 (96-04)	ENGINE MANAGEME	1.8 (...99)	SIEMENS FENIX 5.1
 S40 (96-04)	ENGINE MANAGEME	1.8 B4184SM (...99)	Mitsubishi GDI MPI Melco1
 S40 (96-04)	ENGINE MANAGEME	1.8 BI-FUEL (01-..)	EOBD
 S40 (96-04)	ENGINE MANAGEME	1.9 D (04-04)	EOBD
 S40 (96-04)	ENGINE MANAGEME	1.9 T4 (01-..)	EOBD
 S40 (96-04)	ENGINE MANAGEME	1.9 TD (...98)	LUCAS Diesel DCN
 S40 (96-04)	ENGINE MANAGEME	2.0 (...99)	SIEMENS FENIX 5.1
 S40 (96-04)	ENGINE MANAGEME	2.0 T B4194T (99-..)	Siemens MPI EMS 2000
 S40 (96-04)	ENGINE MANAGEME	2.0 T4 (01-..)	EOBD
 S40 (96-04)	IMMOBILIZER	1.6 (...99)	BOSCH Immobilizer Immo 3
 S40 (96-04)	IMMOBILIZER	1.6 (96-99)	BOSCH Immobilizer Cartronic 2
 S40 (96-04)	IMMOBILIZER	1.8 (...99)	BOSCH Immobilizer Immo 3
 S40 (96-04)	IMMOBILIZER	1.8 (96-99)	BOSCH Immobilizer Cartronic 2
 S40 (96-04)	IMMOBILIZER	1.8 BI-FUEL (...99)	BOSCH Immobilizer Immo 3
 S40 (96-04)	IMMOBILIZER	1.8 BI-FUEL (96-99)	BOSCH Immobilizer Cartronic 2
 S40 (96-04)	IMMOBILIZER	1.9 D (...99)	BOSCH Immobilizer Immo 3
 S40 (96-04)	IMMOBILIZER	1.9 D (96-99)	BOSCH Immobilizer Cartronic 2
 S40 (96-04)	IMMOBILIZER	1.9 T4 (...99)	BOSCH Immobilizer Immo 3
 S40 (96-04)	IMMOBILIZER	1.9 T4 (96-99)	BOSCH Immobilizer Cartronic 2
 S40 (96-04)	IMMOBILIZER	1.9 TD (...99)	BOSCH Immobilizer Immo 3
 S40 (96-04)	IMMOBILIZER	1.9 TD (96-99)	BOSCH Immobilizer Cartronic 2
 S40 (96-04)	IMMOBILIZER	2.0 (...99)	BOSCH Immobilizer Immo 3
 S40 (96-04)	IMMOBILIZER	2.0 (96-99)	BOSCH Immobilizer Cartronic 2
 S40 (96-04)	IMMOBILIZER	2.0 T (...99)	BOSCH Immobilizer Immo 3
 S40 (96-04)	IMMOBILIZER	2.0 T (96-99)	BOSCH Immobilizer Cartronic 2
 S40 (96-04)	IMMOBILIZER	2.0 T4 (...99)	BOSCH Immobilizer Immo 3
 S40 (96-04)	IMMOBILIZER	2.0 T4 (96-99)	BOSCH Immobilizer Cartronic 2
 S40 (96-04)	MAINTENANCE	1.6 (01-04)	MANUAL
 S40 (96-04)	MAINTENANCE	1.6 (96-04)	
 S40 (96-04)	MAINTENANCE	1.8 (01-04)	MANUAL
 S40 (96-04)	MAINTENANCE	1.8 (96-04)	
 S40 (96-04)	MAINTENANCE	1.8 BI-FUEL (01-04)	MANUAL
 S40 (96-04)	MAINTENANCE	1.8 BI-FUEL (96-04)	
 S40 (96-04)	MAINTENANCE	1.9 D (01-04)	MANUAL
 S40 (96-04)	MAINTENANCE	1.9 D (96-04)	
 S40 (96-04)	MAINTENANCE	1.9 T4 (01-04)	MANUAL
 S40 (96-04)	MAINTENANCE	1.9 T4 (96-04)	
 S40 (96-04)	MAINTENANCE	1.9 TD (01-04)	MANUAL
 S40 (96-04)	MAINTENANCE	1.9 TD (96-04)	
 S40 (96-04)	MAINTENANCE	2.0 (01-04)	MANUAL
 S40 (96-04)	MAINTENANCE	2.0 (96-04)	
 S40 (96-04)	MAINTENANCE	2.0 T (01-04)	MANUAL
 S40 (96-04)	MAINTENANCE	2.0 T (96-04)	
 S40 (96-04)	MAINTENANCE	2.0 T4 (01-04)	MANUAL
 S40 (96-04)	MAINTENANCE	2.0 T4 (96-04)	
 S40 (96-04)	SERVICE LIGHT RES	1.6 (01-04)	MANUAL
 S40 (96-04)	SERVICE LIGHT RES	1.6 (96-04)	
 S40 (96-04)	SERVICE LIGHT RES	1.8 (01-04)	MANUAL
 S40 (96-04)	SERVICE LIGHT RES	1.8 (96-04)	
 S40 (96-04)	SERVICE LIGHT RES	1.8 BI-FUEL (01-04)	MANUAL
 S40 (96-04)	SERVICE LIGHT RES	1.8 BI-FUEL (96-04)	
 S40 (96-04)	SERVICE LIGHT RES	1.9 D (01-04)	MANUAL
 S40 (96-04)	SERVICE LIGHT RES	1.9 D (96-04)	
 S40 (96-04)	SERVICE LIGHT RES	1.9 T4 (01-04)	MANUAL
 S40 (96-04)	SERVICE LIGHT RES	1.9 T4 (96-04)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 S40 (96-04)	SERVICE LIGHT RES	1.9 TD (01-04)	MANUAL
 S40 (96-04)	SERVICE LIGHT RES	1.9 TD (96-04)	
 S40 (96-04)	SERVICE LIGHT RES	2.0 (01-04)	MANUAL
 S40 (96-04)	SERVICE LIGHT RES	2.0 (96-04)	
 S40 (96-04)	SERVICE LIGHT RES	2.0 T (01-04)	MANUAL
 S40 (96-04)	SERVICE LIGHT RES	2.0 T (96-04)	
 S40 (96-04)	SERVICE LIGHT RES	2.0 T4 (01-04)	MANUAL
 S40 (96-04)	SERVICE LIGHT RES	2.0 T4 (96-04)	
 S40 (96-04)	TRACTION CONTROL	1.6 (99-..)	DSA
 S40 (96-04)	TRACTION CONTROL	1.8 (99-..)	DSA
 S40 (96-04)	TRACTION CONTROL	1.8 BI-FUEL (99-..)	DSA
 S40 (96-04)	TRACTION CONTROL	1.9 D (99-..)	DSA
 S40 (96-04)	TRACTION CONTROL	1.9 T4 (99-..)	DSA
 S40 (96-04)	TRACTION CONTROL	1.9 TD (99-..)	DSA
 S40 (96-04)	TRACTION CONTROL	2.0 (99-..)	DSA
 S40 (96-04)	TRACTION CONTROL	2.0 T (99-..)	DSA
 S40 (96-04)	TRACTION CONTROL	2.0 T4 (99-..)	DSA
 S60 (00-09)	ABS	2.0 T (00-02)	ATE ABS
 S60 (00-09)	ABS	2.0 T (00-09)	ATE/TEVES ABS Mk60
 S60 (00-09)	ABS	2.0 T (01-03)	BCM Brake Control Module
 S60 (00-09)	ABS	2.0 T (02-09)	ATE ABS
 S60 (00-09)	ABS	2.0 T (02-09)	ATE BCM Brake Control Module
 S60 (00-09)	ABS	2.3 T5 (00-02)	ATE ABS
 S60 (00-09)	ABS	2.3 T5 (00-09)	ATE/TEVES ABS Mk60
 S60 (00-09)	ABS	2.3 T5 (01-03)	BCM Brake Control Module
 S60 (00-09)	ABS	2.3 T5 (02-09)	ATE ABS
 S60 (00-09)	ABS	2.3 T5 (02-09)	ATE BCM Brake Control Module
 S60 (00-09)	ABS	2.4 (00-02)	ATE ABS
 S60 (00-09)	ABS	2.4 (00-09)	ATE/TEVES ABS Mk60
 S60 (00-09)	ABS	2.4 (01-03)	BCM Brake Control Module
 S60 (00-09)	ABS	2.4 (02-09)	ATE ABS
 S60 (00-09)	ABS	2.4 (02-09)	ATE BCM Brake Control Module
 S60 (00-09)	ABS	2.4 BI-FUEL (00-02)	ATE ABS
 S60 (00-09)	ABS	2.4 BI-FUEL (00-09)	ATE/TEVES ABS Mk60
 S60 (00-09)	ABS	2.4 BI-FUEL (01-03)	BCM Brake Control Module
 S60 (00-09)	ABS	2.4 BI-FUEL (02-09)	ATE ABS
 S60 (00-09)	ABS	2.4 BI-FUEL (02-09)	ATE BCM Brake Control Module
 S60 (00-09)	ABS	2.4 D (00-02)	ATE ABS
 S60 (00-09)	ABS	2.4 D (00-09)	ATE/TEVES ABS Mk60
 S60 (00-09)	ABS	2.4 D (01-03)	BCM Brake Control Module
 S60 (00-09)	ABS	2.4 D (02-09)	ATE ABS
 S60 (00-09)	ABS	2.4 D (02-09)	ATE BCM Brake Control Module
 S60 (00-09)	ABS	2.4 D5 (00-02)	ATE ABS
 S60 (00-09)	ABS	2.4 D5 (00-09)	ATE/TEVES ABS Mk60
 S60 (00-09)	ABS	2.4 D5 (01-03)	BCM Brake Control Module
 S60 (00-09)	ABS	2.4 D5 (02-09)	ATE ABS
 S60 (00-09)	ABS	2.4 D5 (02-09)	ATE BCM Brake Control Module
 S60 (00-09)	ABS	2.4 T (00-02)	ATE ABS
 S60 (00-09)	ABS	2.4 T (00-09)	ATE/TEVES ABS Mk60
 S60 (00-09)	ABS	2.4 T (01-03)	BCM Brake Control Module
 S60 (00-09)	ABS	2.4 T (02-09)	ATE ABS
 S60 (00-09)	ABS	2.4 T (02-09)	ATE BCM Brake Control Module
 S60 (00-09)	ABS	2.4 T5 (00-02)	ATE ABS
 S60 (00-09)	ABS	2.4 T5 (00-09)	ATE/TEVES ABS Mk60
 S60 (00-09)	ABS	2.4 T5 (01-03)	BCM Brake Control Module
 S60 (00-09)	ABS	2.4 T5 (02-09)	ATE ABS
 S60 (00-09)	ABS	2.4 T5 (02-09)	ATE BCM Brake Control Module
 S60 (00-09)	ABS	2.5 T (00-02)	ATE ABS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 S60 (00-09)	ABS	2.5 T (00-09)	ATE/TEVES ABS Mk60
 S60 (00-09)	ABS	2.5 T (01-03)	BCM Brake Control Module
 S60 (00-09)	ABS	2.5 T (02-09)	ATE ABS
 S60 (00-09)	ABS	2.5 T (02-09)	ATE BCM Brake Control Module
 S60 (00-09)	ABS	2.5 T AWD (00-02)	ATE ABS
 S60 (00-09)	ABS	2.5 T AWD (00-09)	ATE/TEVES ABS Mk60
 S60 (00-09)	ABS	2.5 T AWD (01-03)	BCM Brake Control Module
 S60 (00-09)	ABS	2.5 T AWD (02-09)	ATE ABS
 S60 (00-09)	ABS	2.5 T AWD (02-09)	ATE BCM Brake Control Module
 S60 (00-09)	AIRBAG	2.0 T (01-03)	SRS AirBag
 S60 (00-09)	AIRBAG	2.0 T (06-07)	SRS AirBag
 S60 (00-09)	AIRBAG	2.3 T5 (01-03)	SRS AirBag
 S60 (00-09)	AIRBAG	2.3 T5 (06-07)	SRS AirBag
 S60 (00-09)	AIRBAG	2.4 (01-03)	SRS AirBag
 S60 (00-09)	AIRBAG	2.4 (06-07)	SRS AirBag
 S60 (00-09)	AIRBAG	2.4 BI-FUEL (01-03)	SRS AirBag
 S60 (00-09)	AIRBAG	2.4 BI-FUEL (06-07)	SRS AirBag
 S60 (00-09)	AIRBAG	2.4 D (01-03)	SRS AirBag
 S60 (00-09)	AIRBAG	2.4 D (06-07)	SRS AirBag
 S60 (00-09)	AIRBAG	2.4 D5 (01-03)	SRS AirBag
 S60 (00-09)	AIRBAG	2.4 D5 (06-07)	SRS AirBag
 S60 (00-09)	AIRBAG	2.4 T (01-03)	SRS AirBag
 S60 (00-09)	AIRBAG	2.4 T (06-07)	SRS AirBag
 S60 (00-09)	AIRBAG	2.4 T5 (01-03)	SRS AirBag
 S60 (00-09)	AIRBAG	2.4 T5 (06-07)	SRS AirBag
 S60 (00-09)	AIRBAG	2.5 T (01-03)	SRS AirBag
 S60 (00-09)	AIRBAG	2.5 T (06-07)	SRS AirBag
 S60 (00-09)	AIRBAG	2.5 T AWD (01-03)	SRS AirBag
 S60 (00-09)	AIRBAG	2.5 T AWD (06-07)	SRS AirBag
 S60 (00-09)	CHASSIS NETWORK	2.0 T (01-03)	CEM Central Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.0 T (01-03)	REM Rear Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.0 T (06-07)	CEM Central Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.0 T (06-07)	REM Rear Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.3 T5 (01-03)	CEM Central Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.3 T5 (01-03)	REM Rear Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.3 T5 (06-07)	CEM Central Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.3 T5 (06-07)	REM Rear Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.4 (01-03)	CEM Central Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.4 (01-03)	REM Rear Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.4 (06-07)	CEM Central Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.4 (06-07)	REM Rear Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.4 BI-FUEL (01-03)	CEM Central Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.4 BI-FUEL (01-03)	REM Rear Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.4 BI-FUEL (06-07)	CEM Central Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.4 BI-FUEL (06-07)	REM Rear Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.4 D (01-03)	CEM Central Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.4 D (01-03)	REM Rear Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.4 D (06-07)	CEM Central Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.4 D (06-07)	REM Rear Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.4 D5 (01-03)	CEM Central Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.4 D5 (01-03)	REM Rear Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.4 D5 (06-07)	CEM Central Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.4 D5 (06-07)	REM Rear Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.4 T (01-03)	CEM Central Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.4 T (01-03)	REM Rear Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.4 T (06-07)	CEM Central Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.4 T (06-07)	REM Rear Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.4 T5 (01-03)	CEM Central Electronic Module

Systems supported by ECUREADER / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 S60 (00-09)	CHASSIS NETWORK	2.4 T5 (01-03)	REM Rear Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.4 T5 (06-07)	CEM Central Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.4 T5 (06-07)	REM Rear Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.5 T (01-03)	CEM Central Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.5 T (01-03)	REM Rear Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.5 T (06-07)	CEM Central Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.5 T (06-07)	REM Rear Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.5 T AWD (01-03)	CEM Central Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.5 T AWD (01-03)	REM Rear Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.5 T AWD (06-07)	CEM Central Electronic Module
 S60 (00-09)	CHASSIS NETWORK	2.5 T AWD (06-07)	REM Rear Electronic Module
 S60 (00-09)	CLIMA	2.0 T	CCM Climate Control Unit
 S60 (00-09)	CLIMA	2.3 T5	CCM Climate Control Unit
 S60 (00-09)	CLIMA	2.4	CCM Climate Control Unit
 S60 (00-09)	CLIMA	2.4 BI-FUEL	CCM Climate Control Unit
 S60 (00-09)	CLIMA	2.4 D	CCM Climate Control Unit
 S60 (00-09)	CLIMA	2.4 D5	CCM Climate Control Unit
 S60 (00-09)	CLIMA	2.4 T	CCM Climate Control Unit
 S60 (00-09)	CLIMA	2.4 T5	CCM Climate Control Unit
 S60 (00-09)	CLIMA	2.5 T	CCM Climate Control Unit
 S60 (00-09)	CLIMA	2.5 T AWD	CCM Climate Control Unit
 S60 (00-09)	COLUMN/SEAT REG.	2.0 T (06-07)	PSM Power Seat Module
 S60 (00-09)	COLUMN/SEAT REG.	2.3 T5 (06-07)	PSM Power Seat Module
 S60 (00-09)	COLUMN/SEAT REG.	2.4 (06-07)	PSM Power Seat Module
 S60 (00-09)	COLUMN/SEAT REG.	2.4 BI-FUEL (06-07)	PSM Power Seat Module
 S60 (00-09)	COLUMN/SEAT REG.	2.4 D (06-07)	PSM Power Seat Module
 S60 (00-09)	COLUMN/SEAT REG.	2.4 D5 (06-07)	PSM Power Seat Module
 S60 (00-09)	COLUMN/SEAT REG.	2.4 T (06-07)	PSM Power Seat Module
 S60 (00-09)	COLUMN/SEAT REG.	2.4 T5 (06-07)	PSM Power Seat Module
 S60 (00-09)	COLUMN/SEAT REG.	2.5 T (06-07)	PSM Power Seat Module
 S60 (00-09)	COLUMN/SEAT REG.	2.5 T AWD (06-07)	PSM Power Seat Module
 S60 (00-09)	CONV. TOP/SUNROO	2.0 T (06-07)	UEM Upper Electronic Module
 S60 (00-09)	CONV. TOP/SUNROO	2.3 T5 (06-07)	UEM Upper Electronic Module
 S60 (00-09)	CONV. TOP/SUNROO	2.4 (06-07)	UEM Upper Electronic Module
 S60 (00-09)	CONV. TOP/SUNROO	2.4 BI-FUEL (06-07)	UEM Upper Electronic Module
 S60 (00-09)	CONV. TOP/SUNROO	2.4 D (06-07)	UEM Upper Electronic Module
 S60 (00-09)	CONV. TOP/SUNROO	2.4 D5 (06-07)	UEM Upper Electronic Module
 S60 (00-09)	CONV. TOP/SUNROO	2.4 T (06-07)	UEM Upper Electronic Module
 S60 (00-09)	CONV. TOP/SUNROO	2.4 T5 (06-07)	UEM Upper Electronic Module
 S60 (00-09)	CONV. TOP/SUNROO	2.5 T (06-07)	UEM Upper Electronic Module
 S60 (00-09)	CONV. TOP/SUNROO	2.5 T AWD (06-07)	UEM Upper Electronic Module
 S60 (00-09)	DASHBOARD	2.0 T (01-03)	DIM Driver Information Module
 S60 (00-09)	DASHBOARD	2.0 T (06-07)	DIM Driver Information Module
 S60 (00-09)	DASHBOARD	2.3 T5 (01-03)	DIM Driver Information Module
 S60 (00-09)	DASHBOARD	2.3 T5 (06-07)	DIM Driver Information Module
 S60 (00-09)	DASHBOARD	2.4 (01-03)	DIM Driver Information Module
 S60 (00-09)	DASHBOARD	2.4 (06-07)	DIM Driver Information Module
 S60 (00-09)	DASHBOARD	2.4 BI-FUEL (01-03)	DIM Driver Information Module
 S60 (00-09)	DASHBOARD	2.4 BI-FUEL (06-07)	DIM Driver Information Module
 S60 (00-09)	DASHBOARD	2.4 D (01-03)	DIM Driver Information Module
 S60 (00-09)	DASHBOARD	2.4 D (06-07)	DIM Driver Information Module
 S60 (00-09)	DASHBOARD	2.4 D5 (01-03)	DIM Driver Information Module
 S60 (00-09)	DASHBOARD	2.4 D5 (06-07)	DIM Driver Information Module
 S60 (00-09)	DASHBOARD	2.4 T (01-03)	DIM Driver Information Module
 S60 (00-09)	DASHBOARD	2.4 T (06-07)	DIM Driver Information Module
 S60 (00-09)	DASHBOARD	2.4 T5 (01-03)	DIM Driver Information Module
 S60 (00-09)	DASHBOARD	2.4 T5 (06-07)	DIM Driver Information Module
 S60 (00-09)	DASHBOARD	2.5 T (01-03)	DIM Driver Information Module

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 S60 (00-09)	DASHBOARD	2.5 T (06-07)	DIM Driver Information Module
 S60 (00-09)	DASHBOARD	2.5 T AWD (01-03)	DIM Driver Information Module
 S60 (00-09)	DASHBOARD	2.5 T AWD (06-07)	DIM Driver Information Module
 S60 (00-09)	DRIVER SIDE DOOR	2.0 T (06-07)	DDM Driver Door Module
 S60 (00-09)	DRIVER SIDE DOOR	2.3 T5 (06-07)	DDM Driver Door Module
 S60 (00-09)	DRIVER SIDE DOOR	2.4 (06-07)	DDM Driver Door Module
 S60 (00-09)	DRIVER SIDE DOOR	2.4 BI-FUEL (06-07)	DDM Driver Door Module
 S60 (00-09)	DRIVER SIDE DOOR	2.4 D (06-07)	DDM Driver Door Module
 S60 (00-09)	DRIVER SIDE DOOR	2.4 D5 (06-07)	DDM Driver Door Module
 S60 (00-09)	DRIVER SIDE DOOR	2.4 T (06-07)	DDM Driver Door Module
 S60 (00-09)	DRIVER SIDE DOOR	2.4 T5 (06-07)	DDM Driver Door Module
 S60 (00-09)	DRIVER SIDE DOOR	2.5 T (06-07)	DDM Driver Door Module
 S60 (00-09)	DRIVER SIDE DOOR	2.5 T AWD (06-07)	DDM Driver Door Module
 S60 (00-09)	ELECTRIC STEERING	2.0 T (06-07)	SAS Steering Angle Sensor
 S60 (00-09)	ELECTRIC STEERING	2.3 T5 (06-07)	SAS Steering Angle Sensor
 S60 (00-09)	ELECTRIC STEERING	2.4 (06-07)	SAS Steering Angle Sensor
 S60 (00-09)	ELECTRIC STEERING	2.4 BI-FUEL (06-07)	SAS Steering Angle Sensor
 S60 (00-09)	ELECTRIC STEERING	2.4 D (06-07)	SAS Steering Angle Sensor
 S60 (00-09)	ELECTRIC STEERING	2.4 D5 (06-07)	SAS Steering Angle Sensor
 S60 (00-09)	ELECTRIC STEERING	2.4 T (06-07)	SAS Steering Angle Sensor
 S60 (00-09)	ELECTRIC STEERING	2.4 T5 (06-07)	SAS Steering Angle Sensor
 S60 (00-09)	ELECTRIC STEERING	2.5 T (06-07)	SAS Steering Angle Sensor
 S60 (00-09)	ELECTRIC STEERING	2.5 T AWD (06-07)	SAS Steering Angle Sensor
 S60 (00-09)	ENGINE MANAGEME	2.0 T (01-..)	EOBD
 S60 (00-09)	ENGINE MANAGEME	2.3 T5 (01-..)	EOBD
 S60 (00-09)	ENGINE MANAGEME	2.4 B5244S (01-..)	DENSO MPI M56
 S60 (00-09)	ENGINE MANAGEME	2.4 B5244S (01-..)	NippoDenso
 S60 (00-09)	ENGINE MANAGEME	2.4 B5244S (02-..)	BOSCH Motronic M7
 S60 (00-09)	ENGINE MANAGEME	2.4 B5244T2 (03-04)	Bosch ME 7
 S60 (00-09)	ENGINE MANAGEME	2.4 B5244T3 (00-01)	Bosch ME 7
 S60 (00-09)	ENGINE MANAGEME	2.4 BI-FUEL (01-..)	EOBD
 S60 (00-09)	ENGINE MANAGEME	2.4 D (04-..)	EOBD
 S60 (00-09)	ENGINE MANAGEME	2.4 D5 D5244T (01-..)	BOSCH EDC Common Rail
 S60 (00-09)	ENGINE MANAGEME	2.4 D5 D5244T2 (02-..)	BOSCH EDC Common Rail
 S60 (00-09)	ENGINE MANAGEME	2.4 T (01-..)	EOBD
 S60 (00-09)	ENGINE MANAGEME	2.4 T5 (01-..)	EOBD
 S60 (00-09)	ENGINE MANAGEME	2.5 T (01-..)	EOBD
 S60 (00-09)	ENGINE MANAGEME	2.5 T AWD (01-..)	EOBD
 S60 (00-09)	GEARBOX MANAGEM	2.0 T (06-07)	TCM Trasmission Control Module
 S60 (00-09)	GEARBOX MANAGEM	2.3 T5 (06-07)	TCM Trasmission Control Module
 S60 (00-09)	GEARBOX MANAGEM	2.4 (06-07)	TCM Trasmission Control Module
 S60 (00-09)	GEARBOX MANAGEM	2.4 BI-FUEL (06-07)	TCM Trasmission Control Module
 S60 (00-09)	GEARBOX MANAGEM	2.4 D (06-07)	TCM Trasmission Control Module
 S60 (00-09)	GEARBOX MANAGEM	2.4 D5 (06-07)	TCM Trasmission Control Module
 S60 (00-09)	GEARBOX MANAGEM	2.4 T (06-07)	TCM Trasmission Control Module
 S60 (00-09)	GEARBOX MANAGEM	2.4 T5 (06-07)	TCM Trasmission Control Module
 S60 (00-09)	GEARBOX MANAGEM	2.5 T (06-07)	TCM Trasmission Control Module
 S60 (00-09)	GEARBOX MANAGEM	2.5 T AWD (06-07)	TCM Trasmission Control Module
 S60 (00-09)	MAINTENANCE	2.0 T (01-09)	MANUAL
 S60 (00-09)	MAINTENANCE	2.0 T (02-03)	
 S60 (00-09)	MAINTENANCE	2.0 T (02-09)	ATE ABS
 S60 (00-09)	MAINTENANCE	2.0 T (02-09)	ATE ABS
 S60 (00-09)	MAINTENANCE	2.0 T (99-02)	VDO
 S60 (00-09)	MAINTENANCE	2.3 T5 (01-09)	MANUAL
 S60 (00-09)	MAINTENANCE	2.3 T5 (02-03)	
 S60 (00-09)	MAINTENANCE	2.3 T5 (02-09)	ATE ABS
 S60 (00-09)	MAINTENANCE	2.3 T5 (02-09)	ATE ABS
 S60 (00-09)	MAINTENANCE	2.3 T5 (99-02)	VDO

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 S60 (00-09)	MAINTENANCE	2.4 (01-09)	MANUAL
 S60 (00-09)	MAINTENANCE	2.4 (02-03)	
 S60 (00-09)	MAINTENANCE	2.4 (02-09)	ATE ABS
 S60 (00-09)	MAINTENANCE	2.4 (02-09)	ATE ABS
 S60 (00-09)	MAINTENANCE	2.4 (99-02)	VDO
 S60 (00-09)	MAINTENANCE	2.4 BI-FUEL (01-09)	MANUAL
 S60 (00-09)	MAINTENANCE	2.4 BI-FUEL (02-03)	
 S60 (00-09)	MAINTENANCE	2.4 BI-FUEL (02-09)	ATE ABS
 S60 (00-09)	MAINTENANCE	2.4 BI-FUEL (02-09)	ATE ABS
 S60 (00-09)	MAINTENANCE	2.4 BI-FUEL (99-02)	VDO
 S60 (00-09)	MAINTENANCE	2.4 D (01-09)	MANUAL
 S60 (00-09)	MAINTENANCE	2.4 D (02-03)	
 S60 (00-09)	MAINTENANCE	2.4 D (02-09)	ATE ABS
 S60 (00-09)	MAINTENANCE	2.4 D (02-09)	ATE ABS
 S60 (00-09)	MAINTENANCE	2.4 D (99-02)	VDO
 S60 (00-09)	MAINTENANCE	2.4 D5 (01-09)	MANUAL
 S60 (00-09)	MAINTENANCE	2.4 D5 (02-03)	
 S60 (00-09)	MAINTENANCE	2.4 D5 (02-09)	ATE ABS
 S60 (00-09)	MAINTENANCE	2.4 D5 (02-09)	ATE ABS
 S60 (00-09)	MAINTENANCE	2.4 D5 (99-02)	VDO
 S60 (00-09)	MAINTENANCE	2.4 T (01-09)	MANUAL
 S60 (00-09)	MAINTENANCE	2.4 T (02-03)	
 S60 (00-09)	MAINTENANCE	2.4 T (02-09)	ATE ABS
 S60 (00-09)	MAINTENANCE	2.4 T (02-09)	ATE ABS
 S60 (00-09)	MAINTENANCE	2.4 T (99-02)	VDO
 S60 (00-09)	MAINTENANCE	2.4 T5 (01-09)	MANUAL
 S60 (00-09)	MAINTENANCE	2.4 T5 (02-03)	
 S60 (00-09)	MAINTENANCE	2.4 T5 (02-09)	ATE ABS
 S60 (00-09)	MAINTENANCE	2.4 T5 (02-09)	ATE ABS
 S60 (00-09)	MAINTENANCE	2.4 T5 (99-02)	VDO
 S60 (00-09)	MAINTENANCE	2.5 T (01-09)	MANUAL
 S60 (00-09)	MAINTENANCE	2.5 T (02-03)	
 S60 (00-09)	MAINTENANCE	2.5 T (02-09)	ATE ABS
 S60 (00-09)	MAINTENANCE	2.5 T (02-09)	ATE ABS
 S60 (00-09)	MAINTENANCE	2.5 T (99-02)	VDO
 S60 (00-09)	MAINTENANCE	2.5 T AWD (01-09)	MANUAL
 S60 (00-09)	MAINTENANCE	2.5 T AWD (02-03)	
 S60 (00-09)	MAINTENANCE	2.5 T AWD (02-09)	ATE ABS
 S60 (00-09)	MAINTENANCE	2.5 T AWD (02-09)	ATE ABS
 S60 (00-09)	MAINTENANCE	2.5 T AWD (99-02)	VDO
 S60 (00-09)	NAVIGATION	2.0 T (01-04)	RTI Road Traffic Information
 S60 (00-09)	NAVIGATION	2.3 T5 (01-04)	RTI Road Traffic Information
 S60 (00-09)	NAVIGATION	2.4 (01-04)	RTI Road Traffic Information
 S60 (00-09)	NAVIGATION	2.4 BI-FUEL (01-04)	RTI Road Traffic Information
 S60 (00-09)	NAVIGATION	2.4 D (01-04)	RTI Road Traffic Information
 S60 (00-09)	NAVIGATION	2.4 D5 (01-04)	RTI Road Traffic Information
 S60 (00-09)	NAVIGATION	2.4 T (01-04)	RTI Road Traffic Information
 S60 (00-09)	NAVIGATION	2.4 T5 (01-04)	RTI Road Traffic Information
 S60 (00-09)	NAVIGATION	2.5 T (01-04)	RTI Road Traffic Information
 S60 (00-09)	NAVIGATION	2.5 T AWD (01-04)	RTI Road Traffic Information
 S60 (00-09)	PASS. SIDE DOOR	2.0 T (06-07)	PDM Passenger Door Module
 S60 (00-09)	PASS. SIDE DOOR	2.3 T5 (06-07)	PDM Passenger Door Module
 S60 (00-09)	PASS. SIDE DOOR	2.4 (06-07)	PDM Passenger Door Module
 S60 (00-09)	PASS. SIDE DOOR	2.4 BI-FUEL (06-07)	PDM Passenger Door Module
 S60 (00-09)	PASS. SIDE DOOR	2.4 D (06-07)	PDM Passenger Door Module
 S60 (00-09)	PASS. SIDE DOOR	2.4 D5 (06-07)	PDM Passenger Door Module
 S60 (00-09)	PASS. SIDE DOOR	2.4 T (06-07)	PDM Passenger Door Module
 S60 (00-09)	PASS. SIDE DOOR	2.4 T5 (06-07)	PDM Passenger Door Module

Systems supported by ECUREADER / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 S60 (00-09)	PASS. SIDE DOOR	2.5 T (06-07)	PDM Passenger Door Module
 S60 (00-09)	PASS. SIDE DOOR	2.5 T AWD (06-07)	PDM Passenger Door Module
 S60 (00-09)	RADIO / CD	2.0 T (01-09)	AUM Audio Module
 S60 (00-09)	RADIO / CD	2.0 T (06-07)	ACM Audio Module
 S60 (00-09)	RADIO / CD	2.3 T5 (01-09)	AUM Audio Module
 S60 (00-09)	RADIO / CD	2.3 T5 (06-07)	ACM Audio Module
 S60 (00-09)	RADIO / CD	2.4 (01-09)	AUM Audio Module
 S60 (00-09)	RADIO / CD	2.4 (06-07)	ACM Audio Module
 S60 (00-09)	RADIO / CD	2.4 BI-FUEL (01-09)	AUM Audio Module
 S60 (00-09)	RADIO / CD	2.4 BI-FUEL (06-07)	ACM Audio Module
 S60 (00-09)	RADIO / CD	2.4 D (01-09)	AUM Audio Module
 S60 (00-09)	RADIO / CD	2.4 D (06-07)	ACM Audio Module
 S60 (00-09)	RADIO / CD	2.4 D5 (01-09)	AUM Audio Module
 S60 (00-09)	RADIO / CD	2.4 D5 (06-07)	ACM Audio Module
 S60 (00-09)	RADIO / CD	2.4 T (01-09)	AUM Audio Module
 S60 (00-09)	RADIO / CD	2.4 T (06-07)	ACM Audio Module
 S60 (00-09)	RADIO / CD	2.4 T5 (01-09)	AUM Audio Module
 S60 (00-09)	RADIO / CD	2.4 T5 (06-07)	ACM Audio Module
 S60 (00-09)	RADIO / CD	2.5 T (01-09)	AUM Audio Module
 S60 (00-09)	RADIO / CD	2.5 T (06-07)	ACM Audio Module
 S60 (00-09)	RADIO / CD	2.5 T AWD (01-09)	AUM Audio Module
 S60 (00-09)	RADIO / CD	2.5 T AWD (06-07)	ACM Audio Module
 S60 (00-09)	SERVICE LIGHT RES	2.0 T (01-09)	MANUAL
 S60 (00-09)	SERVICE LIGHT RES	2.0 T (02-03)	
 S60 (00-09)	SERVICE LIGHT RES	2.0 T (03-09)	Service
 S60 (00-09)	SERVICE LIGHT RES	2.0 T (99-02)	VDO
 S60 (00-09)	SERVICE LIGHT RES	2.3 T5 (01-09)	MANUAL
 S60 (00-09)	SERVICE LIGHT RES	2.3 T5 (02-03)	
 S60 (00-09)	SERVICE LIGHT RES	2.3 T5 (03-09)	Service
 S60 (00-09)	SERVICE LIGHT RES	2.3 T5 (99-02)	VDO
 S60 (00-09)	SERVICE LIGHT RES	2.4 (01-09)	MANUAL
 S60 (00-09)	SERVICE LIGHT RES	2.4 (02-03)	
 S60 (00-09)	SERVICE LIGHT RES	2.4 (03-09)	Service
 S60 (00-09)	SERVICE LIGHT RES	2.4 (99-02)	VDO
 S60 (00-09)	SERVICE LIGHT RES	2.4 BI-FUEL (01-09)	MANUAL
 S60 (00-09)	SERVICE LIGHT RES	2.4 BI-FUEL (02-03)	
 S60 (00-09)	SERVICE LIGHT RES	2.4 BI-FUEL (03-09)	Service
 S60 (00-09)	SERVICE LIGHT RES	2.4 BI-FUEL (99-02)	VDO
 S60 (00-09)	SERVICE LIGHT RES	2.4 D (01-09)	MANUAL
 S60 (00-09)	SERVICE LIGHT RES	2.4 D (02-03)	
 S60 (00-09)	SERVICE LIGHT RES	2.4 D (03-09)	Service
 S60 (00-09)	SERVICE LIGHT RES	2.4 D (99-02)	VDO
 S60 (00-09)	SERVICE LIGHT RES	2.4 D5 (01-09)	MANUAL
 S60 (00-09)	SERVICE LIGHT RES	2.4 D5 (02-03)	
 S60 (00-09)	SERVICE LIGHT RES	2.4 D5 (03-09)	Service
 S60 (00-09)	SERVICE LIGHT RES	2.4 D5 (99-02)	VDO
 S60 (00-09)	SERVICE LIGHT RES	2.4 T (01-09)	MANUAL
 S60 (00-09)	SERVICE LIGHT RES	2.4 T (02-03)	
 S60 (00-09)	SERVICE LIGHT RES	2.4 T (03-09)	Service
 S60 (00-09)	SERVICE LIGHT RES	2.4 T (99-02)	VDO
 S60 (00-09)	SERVICE LIGHT RES	2.4 T5 (01-09)	MANUAL
 S60 (00-09)	SERVICE LIGHT RES	2.4 T5 (02-03)	
 S60 (00-09)	SERVICE LIGHT RES	2.4 T5 (03-09)	Service
 S60 (00-09)	SERVICE LIGHT RES	2.4 T5 (99-02)	VDO
 S60 (00-09)	SERVICE LIGHT RES	2.5 T (01-09)	MANUAL
 S60 (00-09)	SERVICE LIGHT RES	2.5 T (02-03)	
 S60 (00-09)	SERVICE LIGHT RES	2.5 T (03-09)	Service
 S60 (00-09)	SERVICE LIGHT RES	2.5 T (99-02)	VDO

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 S60 (00-09)	SERVICE LIGHT RES	2.5 T AWD (01-09)	MANUAL
 S60 (00-09)	SERVICE LIGHT RES	2.5 T AWD (02-03)	
 S60 (00-09)	SERVICE LIGHT RES	2.5 T AWD (03-09)	Service
 S60 (00-09)	SERVICE LIGHT RES	2.5 T AWD (99-02)	VDO
 S60 (00-09)	STEERING WHEEL E	2.0 T (01-04)	SWM Steering Wheel Module
 S60 (00-09)	STEERING WHEEL E	2.3 T5 (01-04)	SWM Steering Wheel Module
 S60 (00-09)	STEERING WHEEL E	2.4 (01-04)	SWM Steering Wheel Module
 S60 (00-09)	STEERING WHEEL E	2.4 BI-FUEL (01-04)	SWM Steering Wheel Module
 S60 (00-09)	STEERING WHEEL E	2.4 D (01-04)	SWM Steering Wheel Module
 S60 (00-09)	STEERING WHEEL E	2.4 D5 (01-04)	SWM Steering Wheel Module
 S60 (00-09)	STEERING WHEEL E	2.4 T (01-04)	SWM Steering Wheel Module
 S60 (00-09)	STEERING WHEEL E	2.4 T5 (01-04)	SWM Steering Wheel Module
 S60 (00-09)	STEERING WHEEL E	2.5 T (01-04)	SWM Steering Wheel Module
 S60 (00-09)	STEERING WHEEL E	2.5 T AWD (01-04)	SWM Steering Wheel Module
 S60 (00-09)	VISUAL./TELEMATIC	2.0 T (06-07)	ICM Infotainment Control Module
 S60 (00-09)	VISUAL./TELEMATIC	2.3 T5 (06-07)	ICM Infotainment Control Module
 S60 (00-09)	VISUAL./TELEMATIC	2.4 (06-07)	ICM Infotainment Control Module
 S60 (00-09)	VISUAL./TELEMATIC	2.4 BI-FUEL (06-07)	ICM Infotainment Control Module
 S60 (00-09)	VISUAL./TELEMATIC	2.4 D (06-07)	ICM Infotainment Control Module
 S60 (00-09)	VISUAL./TELEMATIC	2.4 D5 (06-07)	ICM Infotainment Control Module
 S60 (00-09)	VISUAL./TELEMATIC	2.4 T (06-07)	ICM Infotainment Control Module
 S60 (00-09)	VISUAL./TELEMATIC	2.4 T5 (06-07)	ICM Infotainment Control Module
 S60 (00-09)	VISUAL./TELEMATIC	2.5 T (06-07)	ICM Infotainment Control Module
 S60 (00-09)	VISUAL./TELEMATIC	2.5 T AWD (06-07)	ICM Infotainment Control Module
 S60 (10-..)	ABS	2.0 T	BCM Brake Control Module
 S60 (10-..)	ABS	2.3 T5	BCM Brake Control Module
 S60 (10-..)	ABS	2.4	BCM Brake Control Module
 S60 (10-..)	ABS	2.4 BI-FUEL	BCM Brake Control Module
 S60 (10-..)	ABS	2.4 D	BCM Brake Control Module
 S60 (10-..)	ABS	2.4 D5	BCM Brake Control Module
 S60 (10-..)	ABS	2.4 T	BCM Brake Control Module
 S60 (10-..)	ABS	2.4 T5	BCM Brake Control Module
 S60 (10-..)	ABS	2.5 T	BCM Brake Control Module
 S60 (10-..)	ABS	2.5 T AWD	BCM Brake Control Module
 S60 (10-..)	CHASSIS NETWORK	2.0 T	CEM Central Electronic Module
 S60 (10-..)	CHASSIS NETWORK	2.0 T	DIM
 S60 (10-..)	CHASSIS NETWORK	2.3 T5	CEM Central Electronic Module
 S60 (10-..)	CHASSIS NETWORK	2.3 T5	DIM
 S60 (10-..)	CHASSIS NETWORK	2.4	CEM Central Electronic Module
 S60 (10-..)	CHASSIS NETWORK	2.4	DIM
 S60 (10-..)	CHASSIS NETWORK	2.4 BI-FUEL	CEM Central Electronic Module
 S60 (10-..)	CHASSIS NETWORK	2.4 BI-FUEL	DIM
 S60 (10-..)	CHASSIS NETWORK	2.4 D	CEM Central Electronic Module
 S60 (10-..)	CHASSIS NETWORK	2.4 D	DIM
 S60 (10-..)	CHASSIS NETWORK	2.4 D5	CEM Central Electronic Module
 S60 (10-..)	CHASSIS NETWORK	2.4 D5	DIM
 S60 (10-..)	CHASSIS NETWORK	2.4 T	CEM Central Electronic Module
 S60 (10-..)	CHASSIS NETWORK	2.4 T5	CEM Central Electronic Module
 S60 (10-..)	CHASSIS NETWORK	2.4 T5	DIM
 S60 (10-..)	CHASSIS NETWORK	2.5 T	CEM Central Electronic Module
 S60 (10-..)	CHASSIS NETWORK	2.5 T	DIM
 S60 (10-..)	CHASSIS NETWORK	2.5 T AWD	CEM Central Electronic Module
 S60 (10-..)	CHASSIS NETWORK	2.5 T AWD	DIM
 S60 (10-..)	CLIMA	2.0 T	CCM NO NAV
 S60 (10-..)	CLIMA	2.3 T5	CCM NO NAV
 S60 (10-..)	CLIMA	2.4	CCM NO NAV
 S60 (10-..)	CLIMA	2.4 BI-FUEL	CCM NO NAV
S60 (10-..)	CLIMA	2.4 D	CCM NO NAV

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 S60 (10-..)	CLIMA	2.4 D5	CCM NO NAV
 S60 (10-..)	CLIMA	2.4 T	CCM NO NAV
 S60 (10-..)	CLIMA	2.4 T5	CCM NO NAV
 S60 (10-..)	CLIMA	2.5 T	CCM NO NAV
 S60 (10-..)	CLIMA	2.5 T AWD	CCM NO NAV
 S60 (10-..)	ELECTRIC STEERING	2.0 T	SAS
 S60 (10-..)	ELECTRIC STEERING	2.3 T5	SAS
 S60 (10-..)	ELECTRIC STEERING	2.4	SAS
 S60 (10-..)	ELECTRIC STEERING	2.4 BI-FUEL	SAS
 S60 (10-..)	ELECTRIC STEERING	2.4 D	SAS
 S60 (10-..)	ELECTRIC STEERING	2.4 D5	SAS
 S60 (10-..)	ELECTRIC STEERING	2.4 T	SAS
 S60 (10-..)	ELECTRIC STEERING	2.4 T5	SAS
 S60 (10-..)	ELECTRIC STEERING	2.5 T	SAS
 S60 (10-..)	ELECTRIC STEERING	2.5 T AWD	SAS
 S60 (10-..)	ENGINE MANAGEME	2.4 D5 D5244T	BOSCH EDC Common Rail
 S60 (10-..)	ENGINE MANAGEME	2.4 D5 D5244T2	BOSCH EDC Common Rail
 S60 (10-..)	GEARBOX MANAGEM	2.0 T	TCM Trasmission Control Module
 S60 (10-..)	GEARBOX MANAGEM	2.3 T5	TCM Trasmission Control Module
 S60 (10-..)	GEARBOX MANAGEM	2.4	TCM Trasmission Control Module
 S60 (10-..)	GEARBOX MANAGEM	2.4 BI-FUEL	TCM Trasmission Control Module
 S60 (10-..)	GEARBOX MANAGEM	2.4 D	TCM Trasmission Control Module
 S60 (10-..)	GEARBOX MANAGEM	2.4 D5	TCM Trasmission Control Module
 S60 (10-..)	GEARBOX MANAGEM	2.4 T	TCM Trasmission Control Module
 S60 (10-..)	GEARBOX MANAGEM	2.4 T5	TCM Trasmission Control Module
 S60 (10-..)	GEARBOX MANAGEM	2.5 T	TCM Trasmission Control Module
 S60 (10-..)	GEARBOX MANAGEM	2.5 T AWD	TCM Trasmission Control Module
 S60 (10-..)	MAINTENANCE	2.0 T	BCM Brake Control Module
 S60 (10-..)	MAINTENANCE	2.0 T	PBM
 S60 (10-..)	MAINTENANCE	2.0 T	PBM
 S60 (10-..)	MAINTENANCE	2.0 T	PBM
 S60 (10-..)	MAINTENANCE	2.0 T	TCM Trasmission Control Module
 S60 (10-..)	MAINTENANCE	2.0 T	TCM Trasmission Control Module
 S60 (10-..)	MAINTENANCE	2.0 T	TCM Trasmission Control Module
 S60 (10-..)	MAINTENANCE	2.3 T5	BCM Brake Control Module
 S60 (10-..)	MAINTENANCE	2.3 T5	PBM
 S60 (10-..)	MAINTENANCE	2.3 T5	PBM
 S60 (10-..)	MAINTENANCE	2.3 T5	PBM
 S60 (10-..)	MAINTENANCE	2.3 T5	TCM Trasmission Control Module
 S60 (10-..)	MAINTENANCE	2.3 T5	TCM Trasmission Control Module
 S60 (10-..)	MAINTENANCE	2.3 T5	TCM Trasmission Control Module
 S60 (10-..)	MAINTENANCE	2.4	BCM Brake Control Module
 S60 (10-..)	MAINTENANCE	2.4	PBM
 S60 (10-..)	MAINTENANCE	2.4	PBM
 S60 (10-..)	MAINTENANCE	2.4	PBM
 S60 (10-..)	MAINTENANCE	2.4	TCM Trasmission Control Module
 S60 (10-..)	MAINTENANCE	2.4	TCM Trasmission Control Module
 S60 (10-..)	MAINTENANCE	2.4	TCM Trasmission Control Module
 S60 (10-..)	MAINTENANCE	2.4 BI-FUEL	BCM Brake Control Module
 S60 (10-..)	MAINTENANCE	2.4 BI-FUEL	PBM
 S60 (10-..)	MAINTENANCE	2.4 BI-FUEL	PBM
 S60 (10-..)	MAINTENANCE	2.4 BI-FUEL	PBM
 S60 (10-..)	MAINTENANCE	2.4 BI-FUEL	TCM Trasmission Control Module
 S60 (10-..)	MAINTENANCE	2.4 BI-FUEL	TCM Trasmission Control Module
 S60 (10-..)	MAINTENANCE	2.4 BI-FUEL	TCM Trasmission Control Module
 S60 (10-..)	MAINTENANCE	2.4 D	BCM Brake Control Module
 S60 (10-..)	MAINTENANCE	2.4 D	PBM
 S60 (10-..)	MAINTENANCE	2.4 D	PBM

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 S60 (10-..)	MAINTENANCE	2.4 D	PBM
 S60 (10-..)	MAINTENANCE	2.4 D	TCM Trasmission Control Module
 S60 (10-..)	MAINTENANCE	2.4 D	TCM Trasmission Control Module
 S60 (10-..)	MAINTENANCE	2.4 D	TCM Trasmission Control Module
 S60 (10-..)	MAINTENANCE	2.4 D5	BCM Brake Control Module
 S60 (10-..)	MAINTENANCE	2.4 D5	PBM
 S60 (10-..)	MAINTENANCE	2.4 D5	PBM
 S60 (10-..)	MAINTENANCE	2.4 D5	PBM
 S60 (10-..)	MAINTENANCE	2.4 D5	TCM Trasmission Control Module
 S60 (10-..)	MAINTENANCE	2.4 D5	TCM Trasmission Control Module
 S60 (10-..)	MAINTENANCE	2.4 D5	TCM Trasmission Control Module
 S60 (10-..)	MAINTENANCE	2.4 D5 D5244T	BOSCH EDC Common Rail
 S60 (10-..)	MAINTENANCE	2.4 D5 D5244T2	BOSCH EDC Common Rail
 S60 (10-..)	MAINTENANCE	2.4 T	BCM Brake Control Module
 S60 (10-..)	MAINTENANCE	2.4 T	PBM
 S60 (10-..)	MAINTENANCE	2.4 T	PBM
 S60 (10-..)	MAINTENANCE	2.4 T	PBM
 S60 (10-..)	MAINTENANCE	2.4 T	TCM Trasmission Control Module
 S60 (10-..)	MAINTENANCE	2.4 T	TCM Trasmission Control Module
 S60 (10-..)	MAINTENANCE	2.4 T	TCM Trasmission Control Module
 S60 (10-..)	MAINTENANCE	2.4 T5	BCM Brake Control Module
 S60 (10-..)	MAINTENANCE	2.4 T5	PBM
 S60 (10-..)	MAINTENANCE	2.4 T5	PBM
 S60 (10-..)	MAINTENANCE	2.4 T5	PBM
 S60 (10-..)	MAINTENANCE	2.4 T5	TCM Trasmission Control Module
 S60 (10-..)	MAINTENANCE	2.4 T5	TCM Trasmission Control Module
 S60 (10-..)	MAINTENANCE	2.4 T5	TCM Trasmission Control Module
 S60 (10-..)	MAINTENANCE	2.5 T	BCM Brake Control Module
 S60 (10-..)	MAINTENANCE	2.5 T	PBM
 S60 (10-..)	MAINTENANCE	2.5 T	PBM
 S60 (10-..)	MAINTENANCE	2.5 T	PBM
 S60 (10-..)	MAINTENANCE	2.5 T	TCM Trasmission Control Module
 S60 (10-..)	MAINTENANCE	2.5 T	TCM Trasmission Control Module
 S60 (10-..)	MAINTENANCE	2.5 T	TCM Trasmission Control Module
 S60 (10-..)	MAINTENANCE	2.5 T AWD	BCM Brake Control Module
 S60 (10-..)	MAINTENANCE	2.5 T AWD	PBM
 S60 (10-..)	MAINTENANCE	2.5 T AWD	PBM
 S60 (10-..)	MAINTENANCE	2.5 T AWD	PBM
 S60 (10-..)	MAINTENANCE	2.5 T AWD	TCM Trasmission Control Module
 S60 (10-..)	MAINTENANCE	2.5 T AWD	TCM Trasmission Control Module
 S60 (10-..)	MAINTENANCE	2.5 T AWD	TCM Trasmission Control Module
 S60 (10-..)	PARK.BRAKE	2.0 T	PBM
 S60 (10-..)	PARK.BRAKE	2.3 T5	PBM
 S60 (10-..)	PARK.BRAKE	2.4	PBM
 S60 (10-..)	PARK.BRAKE	2.4 BI-FUEL	PBM
 S60 (10-..)	PARK.BRAKE	2.4 D	PBM
 S60 (10-..)	PARK.BRAKE	2.4 D5	PBM
 S60 (10-..)	PARK.BRAKE	2.4 T	PBM
 S60 (10-..)	PARK.BRAKE	2.4 T5	PBM
 S60 (10-..)	PARK.BRAKE	2.5 T	PBM
 S60 (10-..)	PARK.BRAKE	2.5 T AWD	PBM
 S60 (10-..)	PARKING HELP	2.0 T	PAM
 S60 (10-..)	PARKING HELP	2.3 T5	PAM
 S60 (10-..)	PARKING HELP	2.4	PAM
 S60 (10-..)	PARKING HELP	2.4 BI-FUEL	PAM
 S60 (10-..)	PARKING HELP	2.4 D	PAM
 S60 (10-..)	PARKING HELP	2.4 D5	PAM
 S60 (10-..)	PARKING HELP	2.4 T	PAM

Systems supported by ECUREADER / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 S60 (10-..)	PARKING HELP	2.4 T5	PAM
 S60 (10-..)	PARKING HELP	2.5 T	PAM
 S60 (10-..)	PARKING HELP	2.5 T AWD	PAM
 S70 (96-00)	ABS	2.0 (96-98)	ATE ABS Mk20
 S70 (96-00)	ABS	2.0 (99-00)	ABS
 S70 (96-00)	ABS	2.0 T (96-98)	ATE ABS Mk20
 S70 (96-00)	ABS	2.0 T (99-00)	ABS
 S70 (96-00)	ABS	2.0 T5 (96-98)	ATE ABS Mk20
 S70 (96-00)	ABS	2.0 T5 (99-00)	ABS
 S70 (96-00)	ABS	2.3 T5 (96-98)	ATE ABS Mk20
 S70 (96-00)	ABS	2.3 T5 (99-00)	ABS
 S70 (96-00)	ABS	2.4 (96-98)	ATE ABS Mk20
 S70 (96-00)	ABS	2.4 (99-00)	ABS
 S70 (96-00)	ABS	2.5 (96-98)	ATE ABS Mk20
 S70 (96-00)	ABS	2.5 (99-00)	ABS
 S70 (96-00)	ABS	2.5 BI-FUEL (96-98)	ATE ABS Mk20
 S70 (96-00)	ABS	2.5 BI-FUEL (99-00)	ABS
 S70 (96-00)	ABS	2.5 T (96-98)	ATE ABS Mk20
 S70 (96-00)	ABS	2.5 T (99-00)	ABS
 S70 (96-00)	ABS	2.5 TDI (96-98)	ATE ABS Mk20
 S70 (96-00)	ABS	2.5 TDI (99-00)	ABS
 S70 (96-00)	AIRBAG	2.0 (96-00)	SRS AirBag
 S70 (96-00)	AIRBAG	2.0 (96-98)	BOSCH - Autoliv AirBag 6.2
 S70 (96-00)	AIRBAG	2.0 (99-00)	SRS
 S70 (96-00)	AIRBAG	2.0 T (96-00)	SRS AirBag
 S70 (96-00)	AIRBAG	2.0 T (96-98)	BOSCH - Autoliv AirBag 6.2
 S70 (96-00)	AIRBAG	2.0 T (99-00)	SRS
 S70 (96-00)	AIRBAG	2.0 T5 (96-00)	SRS AirBag
 S70 (96-00)	AIRBAG	2.0 T5 (96-98)	BOSCH - Autoliv AirBag 6.2
 S70 (96-00)	AIRBAG	2.0 T5 (99-00)	SRS
 S70 (96-00)	AIRBAG	2.3 T5 (96-00)	SRS AirBag
 S70 (96-00)	AIRBAG	2.3 T5 (96-98)	BOSCH - Autoliv AirBag 6.2
 S70 (96-00)	AIRBAG	2.3 T5 (99-00)	SRS
 S70 (96-00)	AIRBAG	2.4 (96-00)	SRS AirBag
 S70 (96-00)	AIRBAG	2.4 (96-98)	BOSCH - Autoliv AirBag 6.2
 S70 (96-00)	AIRBAG	2.4 (99-00)	SRS
 S70 (96-00)	AIRBAG	2.5 (96-00)	SRS AirBag
 S70 (96-00)	AIRBAG	2.5 (96-98)	BOSCH - Autoliv AirBag 6.2
 S70 (96-00)	AIRBAG	2.5 (99-00)	SRS
 S70 (96-00)	AIRBAG	2.5 BI-FUEL (96-00)	SRS AirBag
 S70 (96-00)	AIRBAG	2.5 BI-FUEL (96-98)	BOSCH - Autoliv AirBag 6.2
 S70 (96-00)	AIRBAG	2.5 BI-FUEL (99-00)	SRS
 S70 (96-00)	AIRBAG	2.5 T (96-00)	SRS AirBag
 S70 (96-00)	AIRBAG	2.5 T (96-98)	BOSCH - Autoliv AirBag 6.2
 S70 (96-00)	AIRBAG	2.5 T (99-00)	SRS
 S70 (96-00)	AIRBAG	2.5 TDI (96-00)	SRS AirBag
 S70 (96-00)	AIRBAG	2.5 TDI (96-98)	BOSCH - Autoliv AirBag 6.2
 S70 (96-00)	AIRBAG	2.5 TDI (99-00)	SRS
 S70 (96-00)	DASHBOARD	2.0 (99-00)	VDO Dashboard
 S70 (96-00)	DASHBOARD	2.0 T (99-00)	VDO Dashboard
 S70 (96-00)	DASHBOARD	2.0 T5 (99-00)	VDO Dashboard
 S70 (96-00)	DASHBOARD	2.3 T5 (99-00)	VDO Dashboard
 S70 (96-00)	DASHBOARD	2.4 (99-00)	VDO Dashboard
 S70 (96-00)	DASHBOARD	2.5 (99-00)	VDO Dashboard
 S70 (96-00)	DASHBOARD	2.5 BI-FUEL (99-00)	VDO Dashboard
 S70 (96-00)	DASHBOARD	2.5 T (99-00)	VDO Dashboard
 S70 (96-00)	DASHBOARD	2.5 TDI (99-00)	VDO Dashboard
 S70 (96-00)	DIESEL MANAGEMEN	2.5 TDI (96-98)	BOSCH MSA 15.7

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 S70 (96-00)	ENGINE MANAGEME	2.5 T B5254S (96-00)	BOSCH Motronic 4.3
 S70 (96-00)	ENGINE MANAGEME	2.5 T B5254S (96-00)	BOSCH Motronic 4.4
 S70 (96-00)	ENGINE MANAGEME	2.5 TDI (99-00)	BOSCH MSA 15.8
 S70 (96-00)	IMMOBILIZER	2.0 (96-98)	BOSCH Immobilizer Cartronic 2
 S70 (96-00)	IMMOBILIZER	2.0 (96-98)	BOSCH Immobilizer Immo 3
 S70 (96-00)	IMMOBILIZER	2.0 (99-00)	BOSCH Immobilizer Immo 4
 S70 (96-00)	IMMOBILIZER	2.0 T (96-98)	BOSCH Immobilizer Cartronic 2
 S70 (96-00)	IMMOBILIZER	2.0 T (96-98)	BOSCH Immobilizer Immo 3
 S70 (96-00)	IMMOBILIZER	2.0 T (99-00)	BOSCH Immobilizer Immo 4
 S70 (96-00)	IMMOBILIZER	2.0 T5 (96-98)	BOSCH Immobilizer Cartronic 2
 S70 (96-00)	IMMOBILIZER	2.0 T5 (96-98)	BOSCH Immobilizer Immo 3
 S70 (96-00)	IMMOBILIZER	2.0 T5 (99-00)	BOSCH Immobilizer Immo 4
 S70 (96-00)	IMMOBILIZER	2.3 T5 (96-98)	BOSCH Immobilizer Cartronic 2
 S70 (96-00)	IMMOBILIZER	2.3 T5 (96-98)	BOSCH Immobilizer Immo 3
 S70 (96-00)	IMMOBILIZER	2.3 T5 (99-00)	BOSCH Immobilizer Immo 4
 S70 (96-00)	IMMOBILIZER	2.4 (96-98)	BOSCH Immobilizer Cartronic 2
 S70 (96-00)	IMMOBILIZER	2.4 (96-98)	BOSCH Immobilizer Immo 3
 S70 (96-00)	IMMOBILIZER	2.4 (99-00)	BOSCH Immobilizer Immo 4
 S70 (96-00)	IMMOBILIZER	2.5 (96-98)	BOSCH Immobilizer Cartronic 2
 S70 (96-00)	IMMOBILIZER	2.5 (96-98)	BOSCH Immobilizer Immo 3
 S70 (96-00)	IMMOBILIZER	2.5 (99-00)	BOSCH Immobilizer Immo 4
 S70 (96-00)	IMMOBILIZER	2.5 BI-FUEL (96-98)	BOSCH Immobilizer Cartronic 2
 S70 (96-00)	IMMOBILIZER	2.5 BI-FUEL (96-98)	BOSCH Immobilizer Immo 3
 S70 (96-00)	IMMOBILIZER	2.5 BI-FUEL (99-00)	BOSCH Immobilizer Immo 4
 S70 (96-00)	IMMOBILIZER	2.5 T (96-98)	BOSCH Immobilizer Cartronic 2
 S70 (96-00)	IMMOBILIZER	2.5 T (96-98)	BOSCH Immobilizer Immo 3
 S70 (96-00)	IMMOBILIZER	2.5 T (99-00)	BOSCH Immobilizer Immo 4
 S70 (96-00)	IMMOBILIZER	2.5 TDI (96-98)	BOSCH Immobilizer Cartronic 2
 S70 (96-00)	IMMOBILIZER	2.5 TDI (96-98)	BOSCH Immobilizer Immo 3
 S70 (96-00)	IMMOBILIZER	2.5 TDI (99-00)	BOSCH Immobilizer Immo 4
 S70 (96-00)	MAINTENANCE	2.0 (96-00)	
 S70 (96-00)	MAINTENANCE	2.0 (96-00)	MANUAL
 S70 (96-00)	MAINTENANCE	2.0 (99-00)	VDO
 S70 (96-00)	MAINTENANCE	2.0 (99-00)	VDO Dashboard
 S70 (96-00)	MAINTENANCE	2.0 T (96-00)	
 S70 (96-00)	MAINTENANCE	2.0 T (96-00)	MANUAL
 S70 (96-00)	MAINTENANCE	2.0 T (99-00)	VDO
 S70 (96-00)	MAINTENANCE	2.0 T (99-00)	VDO Dashboard
 S70 (96-00)	MAINTENANCE	2.0 T5 (96-00)	
 S70 (96-00)	MAINTENANCE	2.0 T5 (96-00)	MANUAL
 S70 (96-00)	MAINTENANCE	2.0 T5 (99-00)	VDO
 S70 (96-00)	MAINTENANCE	2.0 T5 (99-00)	VDO Dashboard
 S70 (96-00)	MAINTENANCE	2.3 T5 (96-00)	
 S70 (96-00)	MAINTENANCE	2.3 T5 (96-00)	MANUAL
 S70 (96-00)	MAINTENANCE	2.3 T5 (99-00)	VDO
 S70 (96-00)	MAINTENANCE	2.3 T5 (99-00)	VDO Dashboard
 S70 (96-00)	MAINTENANCE	2.4 (96-00)	
 S70 (96-00)	MAINTENANCE	2.4 (96-00)	MANUAL
 S70 (96-00)	MAINTENANCE	2.4 (99-00)	VDO
 S70 (96-00)	MAINTENANCE	2.4 (99-00)	VDO Dashboard
 S70 (96-00)	MAINTENANCE	2.5 (96-00)	
 S70 (96-00)	MAINTENANCE	2.5 (96-00)	MANUAL
 S70 (96-00)	MAINTENANCE	2.5 (99-00)	VDO
 S70 (96-00)	MAINTENANCE	2.5 (99-00)	VDO Dashboard
 S70 (96-00)	MAINTENANCE	2.5 BI-FUEL (96-00)	
 S70 (96-00)	MAINTENANCE	2.5 BI-FUEL (96-00)	MANUAL
 S70 (96-00)	MAINTENANCE	2.5 BI-FUEL (99-00)	VDO
 S70 (96-00)	MAINTENANCE	2.5 BI-FUEL (99-00)	VDO Dashboard

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 S70 (96-00)	MAINTENANCE	2.5 T (96-00)	
 S70 (96-00)	MAINTENANCE	2.5 T (96-00)	MANUAL
 S70 (96-00)	MAINTENANCE	2.5 T (99-00)	VDO
 S70 (96-00)	MAINTENANCE	2.5 T (99-00)	VDO Dashboard
 S70 (96-00)	MAINTENANCE	2.5 TDI (96-00)	
 S70 (96-00)	MAINTENANCE	2.5 TDI (96-00)	MANUAL
 S70 (96-00)	MAINTENANCE	2.5 TDI (99-00)	VDO
 S70 (96-00)	MAINTENANCE	2.5 TDI (99-00)	VDO Dashboard
 S70 (96-00)	SERVICE LIGHT RES	2.0 (96-00)	
 S70 (96-00)	SERVICE LIGHT RES	2.0 (96-00)	MANUAL
 S70 (96-00)	SERVICE LIGHT RES	2.0 (99-00)	VDO
 S70 (96-00)	SERVICE LIGHT RES	2.0 T (96-00)	
 S70 (96-00)	SERVICE LIGHT RES	2.0 T (96-00)	MANUAL
 S70 (96-00)	SERVICE LIGHT RES	2.0 T (99-00)	VDO
 S70 (96-00)	SERVICE LIGHT RES	2.0 T5 (96-00)	
 S70 (96-00)	SERVICE LIGHT RES	2.0 T5 (96-00)	MANUAL
 S70 (96-00)	SERVICE LIGHT RES	2.0 T5 (99-00)	VDO
 S70 (96-00)	SERVICE LIGHT RES	2.3 T5 (96-00)	
 S70 (96-00)	SERVICE LIGHT RES	2.3 T5 (96-00)	MANUAL
 S70 (96-00)	SERVICE LIGHT RES	2.3 T5 (99-00)	VDO
 S70 (96-00)	SERVICE LIGHT RES	2.4 (96-00)	
 S70 (96-00)	SERVICE LIGHT RES	2.4 (96-00)	MANUAL
 S70 (96-00)	SERVICE LIGHT RES	2.4 (99-00)	VDO
 S70 (96-00)	SERVICE LIGHT RES	2.5 (96-00)	
 S70 (96-00)	SERVICE LIGHT RES	2.5 (96-00)	MANUAL
 S70 (96-00)	SERVICE LIGHT RES	2.5 (99-00)	VDO
 S70 (96-00)	SERVICE LIGHT RES	2.5 BI-FUEL (96-00)	
 S70 (96-00)	SERVICE LIGHT RES	2.5 BI-FUEL (96-00)	MANUAL
 S70 (96-00)	SERVICE LIGHT RES	2.5 BI-FUEL (99-00)	VDO
 S70 (96-00)	SERVICE LIGHT RES	2.5 T (96-00)	
 S70 (96-00)	SERVICE LIGHT RES	2.5 T (96-00)	MANUAL
 S70 (96-00)	SERVICE LIGHT RES	2.5 T (99-00)	VDO
 S70 (96-00)	SERVICE LIGHT RES	2.5 TDI (96-00)	
 S70 (96-00)	SERVICE LIGHT RES	2.5 TDI (96-00)	MANUAL
 S70 (96-00)	SERVICE LIGHT RES	2.5 TDI (99-00)	VDO
 S80 (98-06)	ABS	2.0 T (00-03)	BCM Brake Control Module
 S80 (98-06)	ABS	2.0 T (98-06)	ATE ABS
 S80 (98-06)	ABS	2.0 T (98-06)	ATE/TEVES ABS Mk60
 S80 (98-06)	ABS	2.0 T5 (00-03)	BCM Brake Control Module
 S80 (98-06)	ABS	2.0 T5 (98-06)	ATE ABS
 S80 (98-06)	ABS	2.0 T5 (98-06)	ATE/TEVES ABS Mk60
 S80 (98-06)	ABS	2.4 (00-03)	BCM Brake Control Module
 S80 (98-06)	ABS	2.4 (98-06)	ATE ABS
 S80 (98-06)	ABS	2.4 (98-06)	ATE/TEVES ABS Mk60
 S80 (98-06)	ABS	2.4 BI-FUEL (00-03)	BCM Brake Control Module
 S80 (98-06)	ABS	2.4 BI-FUEL (98-06)	ATE ABS
 S80 (98-06)	ABS	2.4 BI-FUEL (98-06)	ATE/TEVES ABS Mk60
 S80 (98-06)	ABS	2.4 D5 (00-03)	BCM Brake Control Module
 S80 (98-06)	ABS	2.4 D5 (98-06)	ATE ABS
 S80 (98-06)	ABS	2.4 D5 (98-06)	ATE/TEVES ABS Mk60
 S80 (98-06)	ABS	2.4 T (00-03)	BCM Brake Control Module
 S80 (98-06)	ABS	2.4 T (98-06)	ATE ABS
 S80 (98-06)	ABS	2.4 T (98-06)	ATE/TEVES ABS Mk60
 S80 (98-06)	ABS	2.5 D (00-03)	BCM Brake Control Module
 S80 (98-06)	ABS	2.5 D (98-06)	ATE ABS
 S80 (98-06)	ABS	2.5 D (98-06)	ATE/TEVES ABS Mk60
 S80 (98-06)	ABS	2.5 T (00-03)	BCM Brake Control Module
 S80 (98-06)	ABS	2.5 T (98-06)	ATE ABS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 S80 (98-06)	ABS	2.5 T (98-06)	ATE/TEVES ABS Mk60
 S80 (98-06)	ABS	2.5 TDI (00-03)	BCM Brake Control Module
 S80 (98-06)	ABS	2.5 TDI (98-06)	ATE ABS
 S80 (98-06)	ABS	2.5 TDI (98-06)	ATE/TEVES ABS Mk60
 S80 (98-06)	ABS	2.8 T6 (00-03)	BCM Brake Control Module
 S80 (98-06)	ABS	2.8 T6 (98-06)	ATE ABS
 S80 (98-06)	ABS	2.8 T6 (98-06)	ATE/TEVES ABS Mk60
 S80 (98-06)	ABS	2.9 (00-03)	BCM Brake Control Module
 S80 (98-06)	ABS	2.9 (98-06)	ATE ABS
 S80 (98-06)	ABS	2.9 (98-06)	ATE/TEVES ABS Mk60
 S80 (98-06)	ABS	2.9 T6 (00-03)	BCM Brake Control Module
 S80 (98-06)	ABS	2.9 T6 (98-06)	ATE ABS
 S80 (98-06)	ABS	2.9 T6 (98-06)	ATE/TEVES ABS Mk60
 S80 (98-06)	AIRBAG	2.0 T (00-03)	SRS AirBag
 S80 (98-06)	AIRBAG	2.0 T5 (00-03)	SRS AirBag
 S80 (98-06)	AIRBAG	2.4 (00-03)	SRS AirBag
 S80 (98-06)	AIRBAG	2.4 BI-FUEL (00-03)	SRS AirBag
 S80 (98-06)	AIRBAG	2.4 D5 (00-03)	SRS AirBag
 S80 (98-06)	AIRBAG	2.4 T (00-03)	SRS AirBag
 S80 (98-06)	AIRBAG	2.5 D (00-03)	SRS AirBag
 S80 (98-06)	AIRBAG	2.5 T (00-03)	SRS AirBag
 S80 (98-06)	AIRBAG	2.5 TDI (00-03)	SRS AirBag
 S80 (98-06)	AIRBAG	2.8 T6 (00-03)	SRS AirBag
 S80 (98-06)	AIRBAG	2.9 (00-03)	SRS AirBag
 S80 (98-06)	AIRBAG	2.9 T6 (00-03)	SRS AirBag
 S80 (98-06)	CHASSIS NETWORK	2.0 T (00-03)	CEM Central Electronic Module
 S80 (98-06)	CHASSIS NETWORK	2.0 T (00-03)	REM Rear Electronic Module
 S80 (98-06)	CHASSIS NETWORK	2.0 T5 (00-03)	CEM Central Electronic Module
 S80 (98-06)	CHASSIS NETWORK	2.0 T5 (00-03)	REM Rear Electronic Module
 S80 (98-06)	CHASSIS NETWORK	2.4 (00-03)	CEM Central Electronic Module
 S80 (98-06)	CHASSIS NETWORK	2.4 (00-03)	REM Rear Electronic Module
 S80 (98-06)	CHASSIS NETWORK	2.4 BI-FUEL (00-03)	CEM Central Electronic Module
 S80 (98-06)	CHASSIS NETWORK	2.4 BI-FUEL (00-03)	REM Rear Electronic Module
 S80 (98-06)	CHASSIS NETWORK	2.4 D5 (00-03)	CEM Central Electronic Module
 S80 (98-06)	CHASSIS NETWORK	2.4 D5 (00-03)	REM Rear Electronic Module
 S80 (98-06)	CHASSIS NETWORK	2.4 T (00-03)	CEM Central Electronic Module
 S80 (98-06)	CHASSIS NETWORK	2.4 T (00-03)	REM Rear Electronic Module
 S80 (98-06)	CHASSIS NETWORK	2.5 D (00-03)	CEM Central Electronic Module
 S80 (98-06)	CHASSIS NETWORK	2.5 D (00-03)	REM Rear Electronic Module
 S80 (98-06)	CHASSIS NETWORK	2.5 T (00-03)	CEM Central Electronic Module
 S80 (98-06)	CHASSIS NETWORK	2.5 T (00-03)	REM Rear Electronic Module
 S80 (98-06)	CHASSIS NETWORK	2.5 TDI (00-03)	CEM Central Electronic Module
 S80 (98-06)	CHASSIS NETWORK	2.5 TDI (00-03)	REM Rear Electronic Module
 S80 (98-06)	CHASSIS NETWORK	2.8 T6 (00-03)	CEM Central Electronic Module
 S80 (98-06)	CHASSIS NETWORK	2.8 T6 (00-03)	REM Rear Electronic Module
 S80 (98-06)	CHASSIS NETWORK	2.9 (00-03)	CEM Central Electronic Module
 S80 (98-06)	CHASSIS NETWORK	2.9 (00-03)	REM Rear Electronic Module
 S80 (98-06)	CHASSIS NETWORK	2.9 T6 (00-03)	CEM Central Electronic Module
 S80 (98-06)	CHASSIS NETWORK	2.9 T6 (00-03)	REM Rear Electronic Module
 S80 (98-06)	DASHBOARD	2.0 T (00-03)	DIM Driver Information Module
 S80 (98-06)	DASHBOARD	2.0 T5 (00-03)	DIM Driver Information Module
 S80 (98-06)	DASHBOARD	2.4 (00-03)	DIM Driver Information Module
 S80 (98-06)	DASHBOARD	2.4 BI-FUEL (00-03)	DIM Driver Information Module
 S80 (98-06)	DASHBOARD	2.4 D5 (00-03)	DIM Driver Information Module
 S80 (98-06)	DASHBOARD	2.4 T (00-03)	DIM Driver Information Module
 S80 (98-06)	DASHBOARD	2.5 D (00-03)	DIM Driver Information Module
 S80 (98-06)	DASHBOARD	2.5 T (00-03)	DIM Driver Information Module
 S80 (98-06)	DASHBOARD	2.5 TDI (00-03)	DIM Driver Information Module

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 S80 (98-06)	DASHBOARD	2.8 T6 (00-03)	DIM Driver Information Module
 S80 (98-06)	DASHBOARD	2.9 (00-03)	DIM Driver Information Module
 S80 (98-06)	DASHBOARD	2.9 T6 (00-03)	DIM Driver Information Module
 S80 (98-06)	ENGINE MANAGEME	2.0 T (01-06)	EOBD
 S80 (98-06)	ENGINE MANAGEME	2.0 T5 (01-06)	EOBD
 S80 (98-06)	ENGINE MANAGEME	2.4 B5244S (01-06)	NippoDenso
 S80 (98-06)	ENGINE MANAGEME	2.4 B5244T2 (03-04)	Bosch ME 7
 S80 (98-06)	ENGINE MANAGEME	2.4 B5244T3 (00-01)	Bosch ME 7
 S80 (98-06)	ENGINE MANAGEME	2.4 BI-FUEL (01-06)	EOBD
 S80 (98-06)	ENGINE MANAGEME	2.4 D5 D5244T (01-06)	BOSCH EDC Common Rail
 S80 (98-06)	ENGINE MANAGEME	2.4 D5 D5244T2 (02-06)	BOSCH EDC Common Rail
 S80 (98-06)	ENGINE MANAGEME	2.4 T (01-06)	EOBD
 S80 (98-06)	ENGINE MANAGEME	2.5 D (04-06)	EOBD
 S80 (98-06)	ENGINE MANAGEME	2.5 T (01-06)	EOBD
 S80 (98-06)	ENGINE MANAGEME	2.5 TDI (04-06)	EOBD
 S80 (98-06)	ENGINE MANAGEME	2.8 T6 B5244S (01-06)	DENSO MPI M56
 S80 (98-06)	ENGINE MANAGEME	2.9 (01-06)	EOBD
 S80 (98-06)	ENGINE MANAGEME	2.9 T6 (01-06)	EOBD
 S80 (98-06)	MAINTENANCE	2.0 T (01-06)	MANUAL
 S80 (98-06)	MAINTENANCE	2.0 T (98-06)	MANUAL
 S80 (98-06)	MAINTENANCE	2.0 T5 (01-06)	MANUAL
 S80 (98-06)	MAINTENANCE	2.0 T5 (98-06)	MANUAL
 S80 (98-06)	MAINTENANCE	2.4 (01-06)	MANUAL
 S80 (98-06)	MAINTENANCE	2.4 (98-06)	MANUAL
 S80 (98-06)	MAINTENANCE	2.4 BI-FUEL (01-06)	MANUAL
 S80 (98-06)	MAINTENANCE	2.4 BI-FUEL (98-06)	MANUAL
 S80 (98-06)	MAINTENANCE	2.4 D5 (01-06)	MANUAL
 S80 (98-06)	MAINTENANCE	2.4 D5 (98-06)	MANUAL
 S80 (98-06)	MAINTENANCE	2.4 T (01-06)	MANUAL
 S80 (98-06)	MAINTENANCE	2.4 T (98-06)	MANUAL
 S80 (98-06)	MAINTENANCE	2.5 D (01-06)	MANUAL
 S80 (98-06)	MAINTENANCE	2.5 D (98-06)	MANUAL
 S80 (98-06)	MAINTENANCE	2.5 T (01-06)	MANUAL
 S80 (98-06)	MAINTENANCE	2.5 T (98-06)	MANUAL
 S80 (98-06)	MAINTENANCE	2.5 TDI (01-06)	MANUAL
 S80 (98-06)	MAINTENANCE	2.5 TDI (98-06)	MANUAL
 S80 (98-06)	MAINTENANCE	2.8 T6 (01-06)	MANUAL
 S80 (98-06)	MAINTENANCE	2.8 T6 (98-06)	MANUAL
 S80 (98-06)	MAINTENANCE	2.9 (01-06)	MANUAL
 S80 (98-06)	MAINTENANCE	2.9 (98-06)	MANUAL
 S80 (98-06)	MAINTENANCE	2.9 T6 (01-06)	MANUAL
 S80 (98-06)	MAINTENANCE	2.9 T6 (98-06)	MANUAL
 S80 (98-06)	NAVIGATION	2.0 T (00-04)	RTI Road Traffic Information
 S80 (98-06)	NAVIGATION	2.0 T5 (00-04)	RTI Road Traffic Information
 S80 (98-06)	NAVIGATION	2.4 (00-04)	RTI Road Traffic Information
 S80 (98-06)	NAVIGATION	2.4 BI-FUEL (00-04)	RTI Road Traffic Information
 S80 (98-06)	NAVIGATION	2.4 D5 (00-04)	RTI Road Traffic Information
 S80 (98-06)	NAVIGATION	2.4 T (00-04)	RTI Road Traffic Information
 S80 (98-06)	NAVIGATION	2.5 D (00-04)	RTI Road Traffic Information
 S80 (98-06)	NAVIGATION	2.5 T (00-04)	RTI Road Traffic Information
 S80 (98-06)	NAVIGATION	2.5 TDI (00-04)	RTI Road Traffic Information
 S80 (98-06)	NAVIGATION	2.8 T6 (00-04)	RTI Road Traffic Information
 S80 (98-06)	NAVIGATION	2.9 (00-04)	RTI Road Traffic Information
 S80 (98-06)	NAVIGATION	2.9 T6 (00-04)	RTI Road Traffic Information
 S80 (98-06)	RADIO / CD	2.0 T (00-03)	AUM Audio Module
 S80 (98-06)	RADIO / CD	2.0 T5 (00-03)	AUM Audio Module
 S80 (98-06)	RADIO / CD	2.4 (00-03)	AUM Audio Module
 S80 (98-06)	RADIO / CD	2.4 BI-FUEL (00-03)	AUM Audio Module

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 S80 (98-06)	RADIO / CD	2.4 D5 (00-03)	AUM Audio Module
 S80 (98-06)	RADIO / CD	2.4 T (00-03)	AUM Audio Module
 S80 (98-06)	RADIO / CD	2.5 D (00-03)	AUM Audio Module
 S80 (98-06)	RADIO / CD	2.5 T (00-03)	AUM Audio Module
 S80 (98-06)	RADIO / CD	2.5 TDI (00-03)	AUM Audio Module
 S80 (98-06)	RADIO / CD	2.8 T6 (00-03)	AUM Audio Module
 S80 (98-06)	RADIO / CD	2.9 (00-03)	AUM Audio Module
 S80 (98-06)	RADIO / CD	2.9 T6 (00-03)	AUM Audio Module
 S80 (98-06)	SERVICE LIGHT RES	2.0 T (01-06)	MANUAL
 S80 (98-06)	SERVICE LIGHT RES	2.0 T (98-06)	MANUAL
 S80 (98-06)	SERVICE LIGHT RES	2.0 T5 (01-06)	MANUAL
 S80 (98-06)	SERVICE LIGHT RES	2.0 T5 (98-06)	MANUAL
 S80 (98-06)	SERVICE LIGHT RES	2.4 (01-06)	MANUAL
 S80 (98-06)	SERVICE LIGHT RES	2.4 (98-06)	MANUAL
 S80 (98-06)	SERVICE LIGHT RES	2.4 BI-FUEL (01-06)	MANUAL
 S80 (98-06)	SERVICE LIGHT RES	2.4 BI-FUEL (98-06)	MANUAL
 S80 (98-06)	SERVICE LIGHT RES	2.4 D5 (01-06)	MANUAL
 S80 (98-06)	SERVICE LIGHT RES	2.4 D5 (98-06)	MANUAL
 S80 (98-06)	SERVICE LIGHT RES	2.4 T (01-06)	MANUAL
 S80 (98-06)	SERVICE LIGHT RES	2.4 T (98-06)	MANUAL
 S80 (98-06)	SERVICE LIGHT RES	2.5 D (01-06)	MANUAL
 S80 (98-06)	SERVICE LIGHT RES	2.5 D (98-06)	MANUAL
 S80 (98-06)	SERVICE LIGHT RES	2.5 T (01-06)	MANUAL
 S80 (98-06)	SERVICE LIGHT RES	2.5 T (98-06)	MANUAL
 S80 (98-06)	SERVICE LIGHT RES	2.5 TDI (01-06)	MANUAL
 S80 (98-06)	SERVICE LIGHT RES	2.5 TDI (98-06)	MANUAL
 S80 (98-06)	SERVICE LIGHT RES	2.8 T6 (01-06)	MANUAL
 S80 (98-06)	SERVICE LIGHT RES	2.8 T6 (98-06)	MANUAL
 S80 (98-06)	SERVICE LIGHT RES	2.9 (01-06)	MANUAL
 S80 (98-06)	SERVICE LIGHT RES	2.9 (98-06)	MANUAL
 S80 (98-06)	SERVICE LIGHT RES	2.9 T6 (01-06)	MANUAL
 S80 (98-06)	SERVICE LIGHT RES	2.9 T6 (98-06)	MANUAL
 S80 (98-06)	STEERING WHEEL E	2.0 T (00-04)	SWM Steering wheel module
 S80 (98-06)	STEERING WHEEL E	2.0 T5 (00-04)	SWM Steering wheel module
 S80 (98-06)	STEERING WHEEL E	2.4 (00-04)	SWM Steering wheel module
 S80 (98-06)	STEERING WHEEL E	2.4 BI-FUEL (00-04)	SWM Steering wheel module
 S80 (98-06)	STEERING WHEEL E	2.4 D5 (00-04)	SWM Steering wheel module
 S80 (98-06)	STEERING WHEEL E	2.4 T (00-04)	SWM Steering wheel module
 S80 (98-06)	STEERING WHEEL E	2.5 D (00-04)	SWM Steering wheel module
 S80 (98-06)	STEERING WHEEL E	2.5 T (00-04)	SWM Steering wheel module
 S80 (98-06)	STEERING WHEEL E	2.5 TDI (00-04)	SWM Steering wheel module
 S80 (98-06)	STEERING WHEEL E	2.8 T6 (00-04)	SWM Steering wheel module
 S80 (98-06)	STEERING WHEEL E	2.9 (00-04)	SWM Steering wheel module
 S80 (98-06)	STEERING WHEEL E	2.9 T6 (00-04)	SWM Steering wheel module
 S90	AIRBAG	2.5 T (...98)	BOSCH - Autoliv AirBag 6.2
 S90	ENGINE MANAGEME	2.5 T B5254S (...98)	BOSCH Motronic 4.3
 S90	ENGINE MANAGEME	2.5 T B5254S (...98)	BOSCH Motronic 4.4
 S90	IMMOBILIZER	2.5 T (...98)	BOSCH Immobilizer Cartronic 2
 V40 (96-04)	ABS	1.6 (01-04)	ATE ABS
 V40 (96-04)	ABS	1.6 (01-04)	ATE/TEVES ABS Mk60
 V40 (96-04)	ABS	1.6 (96-99)	BOSCH ABS 5.3
 V40 (96-04)	ABS	1.6 (99-00)	ABS
 V40 (96-04)	ABS	1.8 (01-04)	ATE ABS
 V40 (96-04)	ABS	1.8 (01-04)	ATE/TEVES ABS Mk60
 V40 (96-04)	ABS	1.8 (96-99)	BOSCH ABS 5.3
 V40 (96-04)	ABS	1.8 (99-00)	ABS
 V40 (96-04)	ABS	1.8 BI-FUEL (01-04)	ATE ABS
V40 (96-04)	ABS	1.8 BI-FUEL (01-04)	ATE/TEVES ABS Mk60

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 V40 (96-04)	ABS	1.8 BI-FUEL (96-99)	BOSCH ABS 5.3
 V40 (96-04)	ABS	1.8 BI-FUEL (99-00)	ABS
 V40 (96-04)	ABS	1.9 D (01-04)	ATE ABS
 V40 (96-04)	ABS	1.9 D (01-04)	ATE/TEVES ABS Mk60
 V40 (96-04)	ABS	1.9 D (96-99)	BOSCH ABS 5.3
 V40 (96-04)	ABS	1.9 D (99-00)	ABS
 V40 (96-04)	ABS	1.9 T4 (01-04)	ATE ABS
 V40 (96-04)	ABS	1.9 T4 (01-04)	ATE/TEVES ABS Mk60
 V40 (96-04)	ABS	1.9 T4 (96-99)	BOSCH ABS 5.3
 V40 (96-04)	ABS	1.9 T4 (99-00)	ABS
 V40 (96-04)	ABS	1.9 TD (01-04)	ATE ABS
 V40 (96-04)	ABS	1.9 TD (01-04)	ATE/TEVES ABS Mk60
 V40 (96-04)	ABS	1.9 TD (96-99)	BOSCH ABS 5.3
 V40 (96-04)	ABS	1.9 TD (99-00)	ABS
 V40 (96-04)	ABS	2.0 (01-04)	ATE ABS
 V40 (96-04)	ABS	2.0 (01-04)	ATE/TEVES ABS Mk60
 V40 (96-04)	ABS	2.0 (96-99)	BOSCH ABS 5.3
 V40 (96-04)	ABS	2.0 (99-00)	ABS
 V40 (96-04)	ABS	2.0 T (01-04)	ATE ABS
 V40 (96-04)	ABS	2.0 T (01-04)	ATE/TEVES ABS Mk60
 V40 (96-04)	ABS	2.0 T (96-99)	BOSCH ABS 5.3
 V40 (96-04)	ABS	2.0 T (99-00)	ABS
 V40 (96-04)	ABS	2.0 T4 (01-04)	ATE ABS
 V40 (96-04)	ABS	2.0 T4 (01-04)	ATE/TEVES ABS Mk60
 V40 (96-04)	ABS	2.0 T4 (96-99)	BOSCH ABS 5.3
 V40 (96-04)	ABS	2.0 T4 (99-00)	ABS
 V40 (96-04)	AIRBAG	1.6 (96-98)	BOSCH - Autoliv AirBag 6.2
 V40 (96-04)	AIRBAG	1.6 (99-04)	SRS AirBag
 V40 (96-04)	AIRBAG	1.8 (96-98)	BOSCH - Autoliv AirBag 6.2
 V40 (96-04)	AIRBAG	1.8 (99-04)	SRS AirBag
 V40 (96-04)	AIRBAG	1.8 BI-FUEL (96-98)	BOSCH - Autoliv AirBag 6.2
 V40 (96-04)	AIRBAG	1.8 BI-FUEL (99-04)	SRS AirBag
 V40 (96-04)	AIRBAG	1.9 D (96-98)	BOSCH - Autoliv AirBag 6.2
 V40 (96-04)	AIRBAG	1.9 D (99-04)	SRS AirBag
 V40 (96-04)	AIRBAG	1.9 T4 (96-98)	BOSCH - Autoliv AirBag 6.2
 V40 (96-04)	AIRBAG	1.9 T4 (99-04)	SRS AirBag
 V40 (96-04)	AIRBAG	1.9 TD (96-98)	BOSCH - Autoliv AirBag 6.2
 V40 (96-04)	AIRBAG	1.9 TD (99-04)	SRS AirBag
 V40 (96-04)	AIRBAG	2.0 (96-98)	BOSCH - Autoliv AirBag 6.2
 V40 (96-04)	AIRBAG	2.0 (99-04)	SRS AirBag
 V40 (96-04)	AIRBAG	2.0 T (96-98)	BOSCH - Autoliv AirBag 6.2
 V40 (96-04)	AIRBAG	2.0 T (99-04)	SRS AirBag
 V40 (96-04)	AIRBAG	2.0 T4 (96-98)	BOSCH - Autoliv AirBag 6.2
 V40 (96-04)	AIRBAG	2.0 T4 (99-04)	SRS AirBag
 V40 (96-04)	DASHBOARD	1.6 (96-04)	DIM Dashboard
 V40 (96-04)	DASHBOARD	1.8 (96-04)	DIM Dashboard
 V40 (96-04)	DASHBOARD	1.8 BI-FUEL (96-04)	DIM Dashboard
 V40 (96-04)	DASHBOARD	1.9 D (96-04)	DIM Dashboard
 V40 (96-04)	DASHBOARD	1.9 T4 (96-04)	DIM Dashboard
 V40 (96-04)	DASHBOARD	1.9 TD (96-04)	DIM Dashboard
 V40 (96-04)	DASHBOARD	2.0 (96-04)	DIM Dashboard
 V40 (96-04)	DASHBOARD	2.0 T (96-04)	DIM Dashboard
 V40 (96-04)	DASHBOARD	2.0 T4 (96-04)	DIM Dashboard
 V40 (96-04)	ENGINE MANAGEME	1.6 (01-04)	EOBD
 V40 (96-04)	ENGINE MANAGEME	1.6 (96-99)	SIEMENS FENIX 5.1
 V40 (96-04)	ENGINE MANAGEME	1.8 (01-04)	EOBD
 V40 (96-04)	ENGINE MANAGEME	1.8 (96-99)	SIEMENS FENIX 5.1
 V40 (96-04)	ENGINE MANAGEME	1.8 B4184SM (96-00)	Mitsubishi MPI Melco1 GDI

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 V40 (96-04)	ENGINE MANAGEME	1.8 BI-FUEL (01-04)	EOBD
 V40 (96-04)	ENGINE MANAGEME	1.9 D (04-04)	EOBD
 V40 (96-04)	ENGINE MANAGEME	1.9 T4 (01-04)	EOBD
 V40 (96-04)	ENGINE MANAGEME	1.9 TD (04-04)	EOBD
 V40 (96-04)	ENGINE MANAGEME	1.9 TD (96-98)	LUCAS Diesel DCN
 V40 (96-04)	ENGINE MANAGEME	2.0 (01-04)	EOBD
 V40 (96-04)	ENGINE MANAGEME	2.0 (96-99)	SIEMENS FENIX 5.1
 V40 (96-04)	ENGINE MANAGEME	2.0 T B4194T (99-04)	Siemens MPI EMS 2000
 V40 (96-04)	ENGINE MANAGEME	2.0 T4 (01-04)	EOBD
 V40 (96-04)	IMMOBILIZER	1.6 (96-99)	BOSCH Immobilizer Cartronic 2
 V40 (96-04)	IMMOBILIZER	1.6 (96-99)	BOSCH Immobilizer Immo 3
 V40 (96-04)	IMMOBILIZER	1.8 (96-99)	BOSCH Immobilizer Cartronic 2
 V40 (96-04)	IMMOBILIZER	1.8 (96-99)	BOSCH Immobilizer Immo 3
 V40 (96-04)	IMMOBILIZER	1.8 BI-FUEL (96-99)	BOSCH Immobilizer Cartronic 2
 V40 (96-04)	IMMOBILIZER	1.8 BI-FUEL (96-99)	BOSCH Immobilizer Immo 3
 V40 (96-04)	IMMOBILIZER	1.9 D (96-99)	BOSCH Immobilizer Cartronic 2
 V40 (96-04)	IMMOBILIZER	1.9 D (96-99)	BOSCH Immobilizer Immo 3
 V40 (96-04)	IMMOBILIZER	1.9 T4 (96-99)	BOSCH Immobilizer Cartronic 2
 V40 (96-04)	IMMOBILIZER	1.9 T4 (96-99)	BOSCH Immobilizer Immo 3
 V40 (96-04)	IMMOBILIZER	1.9 TD (96-99)	BOSCH Immobilizer Cartronic 2
 V40 (96-04)	IMMOBILIZER	1.9 TD (96-99)	BOSCH Immobilizer Immo 3
 V40 (96-04)	IMMOBILIZER	2.0 (96-99)	BOSCH Immobilizer Cartronic 2
 V40 (96-04)	IMMOBILIZER	2.0 (96-99)	BOSCH Immobilizer Immo 3
 V40 (96-04)	IMMOBILIZER	2.0 T (96-99)	BOSCH Immobilizer Cartronic 2
 V40 (96-04)	IMMOBILIZER	2.0 T (96-99)	BOSCH Immobilizer Immo 3
 V40 (96-04)	IMMOBILIZER	2.0 T4 (96-99)	BOSCH Immobilizer Cartronic 2
 V40 (96-04)	IMMOBILIZER	2.0 T4 (96-99)	BOSCH Immobilizer Immo 3
 V40 (96-04)	MAINTENANCE	1.6 (01-04)	MANUAL
 V40 (96-04)	MAINTENANCE	1.6 (96-04)	
 V40 (96-04)	MAINTENANCE	1.8 (01-04)	MANUAL
 V40 (96-04)	MAINTENANCE	1.8 (96-04)	
 V40 (96-04)	MAINTENANCE	1.8 BI-FUEL (01-04)	MANUAL
 V40 (96-04)	MAINTENANCE	1.8 BI-FUEL (96-04)	
 V40 (96-04)	MAINTENANCE	1.9 D (01-04)	MANUAL
 V40 (96-04)	MAINTENANCE	1.9 D (96-04)	
 V40 (96-04)	MAINTENANCE	1.9 T4 (01-04)	MANUAL
 V40 (96-04)	MAINTENANCE	1.9 T4 (96-04)	
 V40 (96-04)	MAINTENANCE	1.9 TD (01-04)	MANUAL
 V40 (96-04)	MAINTENANCE	1.9 TD (96-04)	
 V40 (96-04)	MAINTENANCE	2.0 (01-04)	MANUAL
 V40 (96-04)	MAINTENANCE	2.0 (96-04)	
 V40 (96-04)	MAINTENANCE	2.0 T (01-04)	MANUAL
 V40 (96-04)	MAINTENANCE	2.0 T (96-04)	
 V40 (96-04)	MAINTENANCE	2.0 T4 (01-04)	MANUAL
 V40 (96-04)	MAINTENANCE	2.0 T4 (96-04)	
 V40 (96-04)	SERVICE LIGHT RES	1.6 (01-04)	MANUAL
 V40 (96-04)	SERVICE LIGHT RES	1.6 (96-04)	
 V40 (96-04)	SERVICE LIGHT RES	1.8 (01-04)	MANUAL
 V40 (96-04)	SERVICE LIGHT RES	1.8 (96-04)	
 V40 (96-04)	SERVICE LIGHT RES	1.8 BI-FUEL (01-04)	MANUAL
 V40 (96-04)	SERVICE LIGHT RES	1.8 BI-FUEL (96-04)	
 V40 (96-04)	SERVICE LIGHT RES	1.9 D (01-04)	MANUAL
 V40 (96-04)	SERVICE LIGHT RES	1.9 D (96-04)	
 V40 (96-04)	SERVICE LIGHT RES	1.9 T4 (01-04)	MANUAL
 V40 (96-04)	SERVICE LIGHT RES	1.9 T4 (96-04)	
 V40 (96-04)	SERVICE LIGHT RES	1.9 TD (01-04)	MANUAL
 V40 (96-04)	SERVICE LIGHT RES	1.9 TD (96-04)	
 V40 (96-04)	SERVICE LIGHT RES	2.0 (01-04)	MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 V40 (96-04)	SERVICE LIGHT RES	2.0 (96-04)	
 V40 (96-04)	SERVICE LIGHT RES	2.0 T (01-04)	MANUAL
 V40 (96-04)	SERVICE LIGHT RES	2.0 T (96-04)	
 V40 (96-04)	SERVICE LIGHT RES	2.0 T4 (01-04)	MANUAL
 V40 (96-04)	SERVICE LIGHT RES	2.0 T4 (96-04)	
 V40 (96-04)	TRACTION CONTROL	1.6 (99-04)	DSA
 V40 (96-04)	TRACTION CONTROL	1.8 (99-04)	DSA
 V40 (96-04)	TRACTION CONTROL	1.8 BI-FUEL (99-04)	DSA
 V40 (96-04)	TRACTION CONTROL	1.9 D (99-04)	DSA
 V40 (96-04)	TRACTION CONTROL	1.9 T4 (99-04)	DSA
 V40 (96-04)	TRACTION CONTROL	1.9 TD (99-04)	DSA
 V40 (96-04)	TRACTION CONTROL	2.0 (99-04)	DSA
 V40 (96-04)	TRACTION CONTROL	2.0 T (99-04)	DSA
 V40 (96-04)	TRACTION CONTROL	2.0 T4 (99-04)	DSA
 V50 (04-..)	ABS	1.6 (04-..)	ATE ABS
 V50 (04-..)	ABS	1.6 (04-..)	ATE/TEVES ABS Mk60
 V50 (04-..)	ABS	1.6 (04-07)	BCM1 Brake Control Module
 V50 (04-..)	ABS	1.6 (04-07)	BCM2 Brake Control Module
 V50 (04-..)	ABS	1.6 (04-07)	BCM3 Brake Control Module
 V50 (04-..)	ABS	1.6 D (04-..)	ATE ABS
 V50 (04-..)	ABS	1.6 D (04-..)	ATE/TEVES ABS Mk60
 V50 (04-..)	ABS	1.6 D (04-07)	BCM1 Brake Control Module
 V50 (04-..)	ABS	1.6 D (04-07)	BCM2 Brake Control Module
 V50 (04-..)	ABS	1.6 D (04-07)	BCM3 Brake Control Module
 V50 (04-..)	ABS	1.8 (04-..)	ATE ABS
 V50 (04-..)	ABS	1.8 (04-..)	ATE/TEVES ABS Mk60
 V50 (04-..)	ABS	1.8 (04-07)	BCM1 Brake Control Module
 V50 (04-..)	ABS	1.8 (04-07)	BCM2 Brake Control Module
 V50 (04-..)	ABS	1.8 (04-07)	BCM3 Brake Control Module
 V50 (04-..)	ABS	1.8 FLEXIFUEL (04-..)	ATE ABS
 V50 (04-..)	ABS	1.8 FLEXIFUEL (04-..)	ATE/TEVES ABS Mk60
 V50 (04-..)	ABS	1.8 FLEXIFUEL (04-07)	BCM1 Brake Control Module
 V50 (04-..)	ABS	1.8 FLEXIFUEL (04-07)	BCM2 Brake Control Module
 V50 (04-..)	ABS	1.8 FLEXIFUEL (04-07)	BCM3 Brake Control Module
 V50 (04-..)	ABS	2.0 (04-..)	ATE ABS
 V50 (04-..)	ABS	2.0 (04-..)	ATE/TEVES ABS Mk60
 V50 (04-..)	ABS	2.0 (04-07)	BCM1 Brake Control Module
 V50 (04-..)	ABS	2.0 (04-07)	BCM2 Brake Control Module
 V50 (04-..)	ABS	2.0 (04-07)	BCM3 Brake Control Module
 V50 (04-..)	ABS	2.0 D (04-..)	ATE ABS
 V50 (04-..)	ABS	2.0 D (04-..)	ATE/TEVES ABS Mk60
 V50 (04-..)	ABS	2.0 D (04-07)	BCM1 Brake Control Module
 V50 (04-..)	ABS	2.0 D (04-07)	BCM2 Brake Control Module
 V50 (04-..)	ABS	2.0 D (04-07)	BCM3 Brake Control Module
 V50 (04-..)	ABS	2.4 (04-..)	ATE ABS
 V50 (04-..)	ABS	2.4 (04-..)	ATE/TEVES ABS Mk60
 V50 (04-..)	ABS	2.4 (04-07)	BCM1 Brake Control Module
 V50 (04-..)	ABS	2.4 (04-07)	BCM2 Brake Control Module
 V50 (04-..)	ABS	2.4 (04-07)	BCM3 Brake Control Module
 V50 (04-..)	ABS	2.4 D5 (04-..)	ATE ABS
 V50 (04-..)	ABS	2.4 D5 (04-..)	ATE/TEVES ABS Mk60
 V50 (04-..)	ABS	2.4 D5 (04-07)	BCM1 Brake Control Module
 V50 (04-..)	ABS	2.4 D5 (04-07)	BCM2 Brake Control Module
 V50 (04-..)	ABS	2.4 D5 (04-07)	BCM3 Brake Control Module
 V50 (04-..)	ABS	2.5 T5 (04-..)	ATE ABS
 V50 (04-..)	ABS	2.5 T5 (04-..)	ATE/TEVES ABS Mk60
 V50 (04-..)	ABS	2.5 T5 (04-07)	BCM1 Brake Control Module
 V50 (04-..)	ABS	2.5 T5 (04-07)	BCM2 Brake Control Module

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 V50 (04-..)	ABS	2.5 T5 (04-07)	BCM3 Brake Control Module
 V50 (04-..)	ABS	2.5 T5 AWD (04-..)	ATE ABS
 V50 (04-..)	ABS	2.5 T5 AWD (04-..)	ATE/TEVES ABS Mk60
 V50 (04-..)	ABS	2.5 T5 AWD (04-07)	BCM1 Brake Control Module
 V50 (04-..)	ABS	2.5 T5 AWD (04-07)	BCM2 Brake Control Module
 V50 (04-..)	ABS	2.5 T5 AWD (04-07)	BCM3 Brake Control Module
 V50 (04-..)	AIRBAG	1.6 (04-..)	SRS AirBag
 V50 (04-..)	AIRBAG	1.6 D (04-..)	SRS AirBag
 V50 (04-..)	AIRBAG	1.8 (04-..)	SRS AirBag
 V50 (04-..)	AIRBAG	1.8 FLEXIFUEL (04-..)	SRS AirBag
 V50 (04-..)	AIRBAG	2.0 (04-..)	SRS AirBag
 V50 (04-..)	AIRBAG	2.0 D (04-..)	SRS AirBag
 V50 (04-..)	AIRBAG	2.4 (04-..)	SRS AirBag
 V50 (04-..)	AIRBAG	2.4 D5 (04-..)	SRS AirBag
 V50 (04-..)	AIRBAG	2.5 T5 (04-..)	SRS AirBag
 V50 (04-..)	AIRBAG	2.5 T5 AWD (04-..)	SRS AirBag
 V50 (04-..)	CLIMA	1.6 (04-..)	CLIMA
 V50 (04-..)	CLIMA	1.6 D (04-..)	CLIMA
 V50 (04-..)	CLIMA	1.8 (04-..)	CLIMA
 V50 (04-..)	CLIMA	1.8 FLEXIFUEL (04-..)	CLIMA
 V50 (04-..)	CLIMA	2.0 (04-..)	CLIMA
 V50 (04-..)	CLIMA	2.0 D (04-..)	CLIMA
 V50 (04-..)	CLIMA	2.4 (04-..)	CLIMA
 V50 (04-..)	CLIMA	2.4 D5 (04-..)	CLIMA
 V50 (04-..)	CLIMA	2.5 T5 (04-..)	CLIMA
 V50 (04-..)	CLIMA	2.5 T5 AWD (04-..)	CLIMA
 V50 (04-..)	DASHBOARD	1.6 (04-..)	DIM Driver Information Module
 V50 (04-..)	DASHBOARD	1.6 D (04-..)	DIM Driver Information Module
 V50 (04-..)	DASHBOARD	1.8 (04-..)	DIM Driver Information Module
 V50 (04-..)	DASHBOARD	1.8 FLEXIFUEL (04-..)	DIM Driver Information Module
 V50 (04-..)	DASHBOARD	2.0 (04-..)	DIM Driver Information Module
 V50 (04-..)	DASHBOARD	2.0 D (04-..)	DIM Driver Information Module
 V50 (04-..)	DASHBOARD	2.4 (04-..)	DIM Driver Information Module
 V50 (04-..)	DASHBOARD	2.4 D5 (04-..)	DIM Driver Information Module
 V50 (04-..)	DASHBOARD	2.5 T5 (04-..)	DIM Driver Information Module
 V50 (04-..)	DASHBOARD	2.5 T5 AWD (04-..)	DIM Driver Information Module
 V50 (04-..)	DIESEL ADDITION	1.6 D (04-..)	ADM Additive Dosing Module
 V50 (04-..)	DIESEL ADDITION	2.0 D (04-..)	ADM Additive Dosing Module
 V50 (04-..)	DIESEL ADDITION	2.4 D5 (04-..)	ADM Additive Dosing Module
 V50 (04-..)	DIFFERENTIAL MANA	2.5 T5 AWD (06-07)	DEM Differenzial Electronic Module
 V50 (04-..)	DRIVER SIDE DOOR	1.6 (04-..)	DDM Driver Door Module
 V50 (04-..)	DRIVER SIDE DOOR	1.6 D (04-..)	DDM Driver Door Module
 V50 (04-..)	DRIVER SIDE DOOR	1.8 (04-..)	DDM Driver Door Module
 V50 (04-..)	DRIVER SIDE DOOR	1.8 FLEXIFUEL (04-..)	DDM Driver Door Module
 V50 (04-..)	DRIVER SIDE DOOR	2.0 (04-..)	DDM Driver Door Module
 V50 (04-..)	DRIVER SIDE DOOR	2.0 D (04-..)	DDM Driver Door Module
 V50 (04-..)	DRIVER SIDE DOOR	2.4 (04-..)	DDM Driver Door Module
 V50 (04-..)	DRIVER SIDE DOOR	2.4 D5 (04-..)	DDM Driver Door Module
 V50 (04-..)	DRIVER SIDE DOOR	2.5 T5 (04-..)	DDM Driver Door Module
 V50 (04-..)	DRIVER SIDE DOOR	2.5 T5 AWD (04-..)	DDM Driver Door Module
 V50 (04-..)	ELECTRIC STEERING	1.6 (04-..)	EPS Electric Power Steering
 V50 (04-..)	ELECTRIC STEERING	1.6 D (04-..)	EPS Electric Power Steering
 V50 (04-..)	ELECTRIC STEERING	1.8 (04-..)	EPS Electric Power Steering
 V50 (04-..)	ELECTRIC STEERING	1.8 FLEXIFUEL (04-..)	EPS Electric Power Steering
 V50 (04-..)	ELECTRIC STEERING	2.0 (04-..)	EPS Electric Power Steering
 V50 (04-..)	ELECTRIC STEERING	2.0 D (04-..)	EPS Electric Power Steering
 V50 (04-..)	ELECTRIC STEERING	2.4 (04-..)	EPS Electric Power Steering
 V50 (04-..)	ELECTRIC STEERING	2.4 D5 (04-..)	EPS Electric Power Steering

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 V50 (04-..)	ELECTRIC STEERING	2.5 T5 (04-..)	EPS Electric Power Steering
 V50 (04-..)	ELECTRIC STEERING	2.5 T5 AWD (04-..)	EPS Electric Power Steering
 V50 (04-..)	ENGINE MANAGEME	1.6 (04-..)	EOBD
 V50 (04-..)	ENGINE MANAGEME	1.6 D (04-..)	EOBD
 V50 (04-..)	ENGINE MANAGEME	1.8 B4184S (04-..)	MPI
 V50 (04-..)	ENGINE MANAGEME	1.8 FLEXIFUEL B4184S (04-..)	MPI
 V50 (04-..)	ENGINE MANAGEME	2.0 (04-..)	EOBD
 V50 (04-..)	ENGINE MANAGEME	2.0 D D4204T (04-..)	ECM Common Rail
 V50 (04-..)	ENGINE MANAGEME	2.4 B5244S (04-..)	DENSO MPI M56
 V50 (04-..)	ENGINE MANAGEME	2.4 D5 (04-..)	EOBD
 V50 (04-..)	ENGINE MANAGEME	2.5 T5 AWD B5254T3 (04-..)	BOSCH Motronic ME9
 V50 (04-..)	ENGINE MANAGEME	2.5 T5 B5254T3 (04-..)	BOSCH Motronic ME9
 V50 (04-..)	GEARBOX MANAGEM	1.6 (06-07)	TCM Trasmission Control Module
 V50 (04-..)	GEARBOX MANAGEM	1.6 D (06-07)	TCM Trasmission Control Module
 V50 (04-..)	GEARBOX MANAGEM	1.8 (06-07)	TCM Trasmission Control Module
 V50 (04-..)	GEARBOX MANAGEM	1.8 FLEXIFUEL (06-07)	TCM Trasmission Control Module
 V50 (04-..)	GEARBOX MANAGEM	2.0 (06-07)	TCM Trasmission Control Module
 V50 (04-..)	GEARBOX MANAGEM	2.0 D (06-07)	TCM Trasmission Control Module
 V50 (04-..)	GEARBOX MANAGEM	2.4 (06-07)	TCM Trasmission Control Module
 V50 (04-..)	GEARBOX MANAGEM	2.4 D5 (06-07)	TCM Trasmission Control Module
 V50 (04-..)	GEARBOX MANAGEM	2.5 T5 (06-07)	TCM Trasmission Control Module
 V50 (04-..)	GEARBOX MANAGEM	2.5 T5 AWD (06-07)	TCM Trasmission Control Module
 V50 (04-..)	MAINTENANCE	1.6 (04-..)	DIM
 V50 (04-..)	MAINTENANCE	1.6 (04-..)	MANUAL
 V50 (04-..)	MAINTENANCE	1.6 D (04-..)	DIM
 V50 (04-..)	MAINTENANCE	1.6 D (04-..)	MANUAL
 V50 (04-..)	MAINTENANCE	1.8 (04-..)	DIM
 V50 (04-..)	MAINTENANCE	1.8 (04-..)	MANUAL
 V50 (04-..)	MAINTENANCE	1.8 FLEXIFUEL (04-..)	DIM
 V50 (04-..)	MAINTENANCE	1.8 FLEXIFUEL (04-..)	MANUAL
 V50 (04-..)	MAINTENANCE	2.0 (04-..)	DIM
 V50 (04-..)	MAINTENANCE	2.0 (04-..)	MANUAL
 V50 (04-..)	MAINTENANCE	2.0 D (04-..)	DIM
 V50 (04-..)	MAINTENANCE	2.0 D (04-..)	MANUAL
 V50 (04-..)	MAINTENANCE	2.4 (04-..)	DIM
 V50 (04-..)	MAINTENANCE	2.4 (04-..)	MANUAL
 V50 (04-..)	MAINTENANCE	2.4 D5 (04-..)	DIM
 V50 (04-..)	MAINTENANCE	2.4 D5 (04-..)	MANUAL
 V50 (04-..)	MAINTENANCE	2.5 T5 (04-..)	DIM
 V50 (04-..)	MAINTENANCE	2.5 T5 (04-..)	MANUAL
 V50 (04-..)	MAINTENANCE	2.5 T5 AWD (04-..)	DIM
 V50 (04-..)	MAINTENANCE	2.5 T5 AWD (04-..)	MANUAL
 V50 (04-..)	PARKING HELP	1.6 (06-07)	PAM Park Assist Module
 V50 (04-..)	PARKING HELP	1.6 D (06-07)	PAM Park Assist Module
 V50 (04-..)	PARKING HELP	1.8 (06-07)	PAM Park Assist Module
 V50 (04-..)	PARKING HELP	1.8 FLEXIFUEL (06-07)	PAM Park Assist Module
 V50 (04-..)	PARKING HELP	2.0 (06-07)	PAM Park Assist Module
 V50 (04-..)	PARKING HELP	2.0 D (06-07)	PAM Park Assist Module
 V50 (04-..)	PARKING HELP	2.4 (06-07)	PAM Park Assist Module
 V50 (04-..)	PARKING HELP	2.4 D5 (06-07)	PAM Park Assist Module
 V50 (04-..)	PARKING HELP	2.5 T5 (06-07)	PAM Park Assist Module
 V50 (04-..)	PARKING HELP	2.5 T5 AWD (06-07)	PAM Park Assist Module
 V50 (04-..)	PASS. SIDE DOOR	1.6 (04-..)	PDM Passenger Door Module
 V50 (04-..)	PASS. SIDE DOOR	1.6 D (04-..)	PDM Passenger Door Module
 V50 (04-..)	PASS. SIDE DOOR	1.8 (04-..)	PDM Passenger Door Module
 V50 (04-..)	PASS. SIDE DOOR	1.8 FLEXIFUEL (04-..)	PDM Passenger Door Module
 V50 (04-..)	PASS. SIDE DOOR	2.0 (04-..)	PDM Passenger Door Module
 V50 (04-..)	PASS. SIDE DOOR	2.0 D (04-..)	PDM Passenger Door Module

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 V50 (04-..)	PASS. SIDE DOOR	2.4 (04-..)	PDM Passenger Door Module
 V50 (04-..)	PASS. SIDE DOOR	2.4 D5 (04-..)	PDM Passenger Door Module
 V50 (04-..)	PASS. SIDE DOOR	2.5 T5 (04-..)	PDM Passenger Door Module
 V50 (04-..)	PASS. SIDE DOOR	2.5 T5 AWD (04-..)	PDM Passenger Door Module
 V50 (04-..)	PASSENGER SEAT R	1.6 (06-07)	PSM Power Seat Module
 V50 (04-..)	PASSENGER SEAT R	1.6 D (06-07)	PSM Power Seat Module
 V50 (04-..)	PASSENGER SEAT R	1.8 (06-07)	PSM Power Seat Module
 V50 (04-..)	PASSENGER SEAT R	1.8 FLEXIFUEL (06-07)	PSM Power Seat Module
 V50 (04-..)	PASSENGER SEAT R	2.0 (06-07)	PSM Power Seat Module
 V50 (04-..)	PASSENGER SEAT R	2.0 D (06-07)	PSM Power Seat Module
 V50 (04-..)	PASSENGER SEAT R	2.4 (06-07)	PSM Power Seat Module
 V50 (04-..)	PASSENGER SEAT R	2.4 D5 (06-07)	PSM Power Seat Module
 V50 (04-..)	PASSENGER SEAT R	2.5 T5 (06-07)	PSM Power Seat Module
 V50 (04-..)	PASSENGER SEAT R	2.5 T5 AWD (06-07)	PSM Power Seat Module
 V50 (04-..)	RADIO / CD	1.6 (06-07)	ACM Audio Module
 V50 (04-..)	RADIO / CD	1.6 (06-07)	IAM Integrated Audio Module
 V50 (04-..)	RADIO / CD	1.6 D (06-07)	ACM Audio Module
 V50 (04-..)	RADIO / CD	1.6 D (06-07)	IAM Integrated Audio Module
 V50 (04-..)	RADIO / CD	1.8 (06-07)	ACM Audio Module
 V50 (04-..)	RADIO / CD	1.8 (06-07)	IAM Integrated Audio Module
 V50 (04-..)	RADIO / CD	1.8 FLEXIFUEL (06-07)	ACM Audio Module
 V50 (04-..)	RADIO / CD	1.8 FLEXIFUEL (06-07)	IAM Integrated Audio Module
 V50 (04-..)	RADIO / CD	2.0 (06-07)	ACM Audio Module
 V50 (04-..)	RADIO / CD	2.0 (06-07)	IAM Integrated Audio Module
 V50 (04-..)	RADIO / CD	2.0 D (06-07)	ACM Audio Module
 V50 (04-..)	RADIO / CD	2.0 D (06-07)	IAM Integrated Audio Module
 V50 (04-..)	RADIO / CD	2.4 (06-07)	ACM Audio Module
 V50 (04-..)	RADIO / CD	2.4 (06-07)	IAM Integrated Audio Module
 V50 (04-..)	RADIO / CD	2.4 D5 (06-07)	ACM Audio Module
 V50 (04-..)	RADIO / CD	2.4 D5 (06-07)	IAM Integrated Audio Module
 V50 (04-..)	RADIO / CD	2.5 T5 (06-07)	ACM Audio Module
 V50 (04-..)	RADIO / CD	2.5 T5 (06-07)	IAM Integrated Audio Module
 V50 (04-..)	RADIO / CD	2.5 T5 AWD (06-07)	ACM Audio Module
 V50 (04-..)	RADIO / CD	2.5 T5 AWD (06-07)	IAM Integrated Audio Module
 V50 (04-..)	SERVICE LIGHT RES	1.6 (04-..)	DIM
 V50 (04-..)	SERVICE LIGHT RES	1.6 (04-..)	MANUAL
 V50 (04-..)	SERVICE LIGHT RES	1.6 D (04-..)	DIM
 V50 (04-..)	SERVICE LIGHT RES	1.6 D (04-..)	MANUAL
 V50 (04-..)	SERVICE LIGHT RES	1.8 (04-..)	DIM
 V50 (04-..)	SERVICE LIGHT RES	1.8 (04-..)	MANUAL
 V50 (04-..)	SERVICE LIGHT RES	1.8 FLEXIFUEL (04-..)	DIM
 V50 (04-..)	SERVICE LIGHT RES	1.8 FLEXIFUEL (04-..)	MANUAL
 V50 (04-..)	SERVICE LIGHT RES	2.0 (04-..)	DIM
 V50 (04-..)	SERVICE LIGHT RES	2.0 (04-..)	MANUAL
 V50 (04-..)	SERVICE LIGHT RES	2.0 D (04-..)	DIM
 V50 (04-..)	SERVICE LIGHT RES	2.0 D (04-..)	MANUAL
 V50 (04-..)	SERVICE LIGHT RES	2.4 (04-..)	DIM
 V50 (04-..)	SERVICE LIGHT RES	2.4 (04-..)	MANUAL
 V50 (04-..)	SERVICE LIGHT RES	2.4 D5 (04-..)	DIM
 V50 (04-..)	SERVICE LIGHT RES	2.4 D5 (04-..)	MANUAL
 V50 (04-..)	SERVICE LIGHT RES	2.5 T5 (04-..)	DIM
 V50 (04-..)	SERVICE LIGHT RES	2.5 T5 (04-..)	MANUAL
 V50 (04-..)	SERVICE LIGHT RES	2.5 T5 AWD (04-..)	DIM
 V50 (04-..)	SERVICE LIGHT RES	2.5 T5 AWD (04-..)	MANUAL
 V50 (04-..)	STEERING WHEEL E	1.6 (04-07)	SWM1 Steering Wheel Module
 V50 (04-..)	STEERING WHEEL E	1.6 (05-07)	SWM2 Steering Wheel Module
 V50 (04-..)	STEERING WHEEL E	1.6 D (04-07)	SWM1 Steering Wheel Module
 V50 (04-..)	STEERING WHEEL E	1.6 D (05-07)	SWM2 Steering Wheel Module

Systems supported by ECUREADER / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 V50 (04-..)	STEERING WHEEL E	1.8 (04-07)	SWM1 Steering Wheel Module
 V50 (04-..)	STEERING WHEEL E	1.8 (05-07)	SWM2 Steering Wheel Module
 V50 (04-..)	STEERING WHEEL E	1.8 FLEXIFUEL (04-07)	SWM1 Steering Wheel Module
 V50 (04-..)	STEERING WHEEL E	1.8 FLEXIFUEL (05-07)	SWM2 Steering Wheel Module
 V50 (04-..)	STEERING WHEEL E	2.0 (04-07)	SWM1 Steering Wheel Module
 V50 (04-..)	STEERING WHEEL E	2.0 (05-07)	SWM2 Steering Wheel Module
 V50 (04-..)	STEERING WHEEL E	2.0 D (04-07)	SWM1 Steering Wheel Module
 V50 (04-..)	STEERING WHEEL E	2.0 D (05-07)	SWM2 Steering Wheel Module
 V50 (04-..)	STEERING WHEEL E	2.4 (04-07)	SWM1 Steering Wheel Module
 V50 (04-..)	STEERING WHEEL E	2.4 (05-07)	SWM2 Steering Wheel Module
 V50 (04-..)	STEERING WHEEL E	2.4 D5 (04-07)	SWM1 Steering Wheel Module
 V50 (04-..)	STEERING WHEEL E	2.4 D5 (05-07)	SWM2 Steering Wheel Module
 V50 (04-..)	STEERING WHEEL E	2.5 T5 (04-07)	SWM1 Steering Wheel Module
 V50 (04-..)	STEERING WHEEL E	2.5 T5 (05-07)	SWM2 Steering Wheel Module
 V50 (04-..)	STEERING WHEEL E	2.5 T5 AWD (04-07)	SWM1 Steering Wheel Module
 V50 (04-..)	STEERING WHEEL E	2.5 T5 AWD (05-07)	SWM2 Steering Wheel Module
 V50 (04-..)	VISUAL/TELEMATIC	1.6 (06-07)	ICM Infotainment Control Module
 V50 (04-..)	VISUAL/TELEMATIC	1.6 D (06-07)	ICM Infotainment Control Module
 V50 (04-..)	VISUAL/TELEMATIC	1.8 (06-07)	ICM Infotainment Control Module
 V50 (04-..)	VISUAL/TELEMATIC	1.8 FLEXIFUEL (06-07)	ICM Infotainment Control Module
 V50 (04-..)	VISUAL/TELEMATIC	2.0 (06-07)	ICM Infotainment Control Module
 V50 (04-..)	VISUAL/TELEMATIC	2.0 D (06-07)	ICM Infotainment Control Module
 V50 (04-..)	VISUAL/TELEMATIC	2.4 (06-07)	ICM Infotainment Control Module
 V50 (04-..)	VISUAL/TELEMATIC	2.4 D5 (06-07)	ICM Infotainment Control Module
 V50 (04-..)	VISUAL/TELEMATIC	2.5 T5 (06-07)	ICM Infotainment Control Module
 V50 (04-..)	VISUAL/TELEMATIC	2.5 T5 AWD (06-07)	ICM Infotainment Control Module
 V70 (00-07)	ABS	2.0 T (01-03)	BCM Brake Control Module
 V70 (00-07)	ABS	2.0 T (01-07)	ATE ABS
 V70 (00-07)	ABS	2.0 T (01-07)	ATE/TEVES ABS Mk60
 V70 (00-07)	ABS	2.3 T5 (01-03)	BCM Brake Control Module
 V70 (00-07)	ABS	2.3 T5 (01-07)	ATE ABS
 V70 (00-07)	ABS	2.3 T5 (01-07)	ATE/TEVES ABS Mk60
 V70 (00-07)	ABS	2.4 (01-03)	BCM Brake Control Module
 V70 (00-07)	ABS	2.4 (01-07)	ATE ABS
 V70 (00-07)	ABS	2.4 (01-07)	ATE/TEVES ABS Mk60
 V70 (00-07)	ABS	2.4 BI-FUEL (01-03)	BCM Brake Control Module
 V70 (00-07)	ABS	2.4 BI-FUEL (01-07)	ATE ABS
 V70 (00-07)	ABS	2.4 BI-FUEL (01-07)	ATE/TEVES ABS Mk60
 V70 (00-07)	ABS	2.4 D (01-03)	BCM Brake Control Module
 V70 (00-07)	ABS	2.4 D (01-07)	ATE ABS
 V70 (00-07)	ABS	2.4 D (01-07)	ATE/TEVES ABS Mk60
 V70 (00-07)	ABS	2.4 D5 (01-03)	BCM Brake Control Module
 V70 (00-07)	ABS	2.4 D5 (01-07)	ATE ABS
 V70 (00-07)	ABS	2.4 D5 (01-07)	ATE/TEVES ABS Mk60
 V70 (00-07)	ABS	2.4 D5 AWD (01-03)	BCM Brake Control Module
 V70 (00-07)	ABS	2.4 D5 AWD (01-07)	ATE ABS
 V70 (00-07)	ABS	2.4 D5 AWD (01-07)	ATE/TEVES ABS Mk60
 V70 (00-07)	ABS	2.4 T (01-03)	BCM Brake Control Module
 V70 (00-07)	ABS	2.4 T (01-07)	ATE ABS
 V70 (00-07)	ABS	2.4 T (01-07)	ATE/TEVES ABS Mk60
 V70 (00-07)	ABS	2.4 T AWD (01-03)	BCM Brake Control Module
 V70 (00-07)	ABS	2.4 T AWD (01-07)	ATE ABS
 V70 (00-07)	ABS	2.4 T AWD (01-07)	ATE/TEVES ABS Mk60
 V70 (00-07)	ABS	2.4 T5 (01-03)	BCM Brake Control Module
 V70 (00-07)	ABS	2.4 T5 (01-07)	ATE ABS
 V70 (00-07)	ABS	2.4 T5 (01-07)	ATE/TEVES ABS Mk60
 V70 (00-07)	ABS	2.5 D (01-03)	BCM Brake Control Module
 V70 (00-07)	ABS	2.5 D (01-07)	ATE ABS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 V70 (00-07)	ABS	2.5 D (01-07)	ATE/TEVES ABS Mk60
 V70 (00-07)	ABS	2.5 T (01-03)	BCM Brake Control Module
 V70 (00-07)	ABS	2.5 T (01-07)	ATE ABS
 V70 (00-07)	ABS	2.5 T (01-07)	ATE/TEVES ABS Mk60
 V70 (00-07)	ABS	2.5 T AWD (01-03)	BCM Brake Control Module
 V70 (00-07)	ABS	2.5 T AWD (01-07)	ATE ABS
 V70 (00-07)	ABS	2.5 T AWD (01-07)	ATE/TEVES ABS Mk60
 V70 (00-07)	AIRBAG	2.0 T (01-03)	SRS AirBag
 V70 (00-07)	AIRBAG	2.0 T (06-07)	SRS AirBag
 V70 (00-07)	AIRBAG	2.3 T5 (01-03)	SRS AirBag
 V70 (00-07)	AIRBAG	2.3 T5 (06-07)	SRS AirBag
 V70 (00-07)	AIRBAG	2.4 (01-03)	SRS AirBag
 V70 (00-07)	AIRBAG	2.4 (06-07)	SRS AirBag
 V70 (00-07)	AIRBAG	2.4 BI-FUEL (01-03)	SRS AirBag
 V70 (00-07)	AIRBAG	2.4 BI-FUEL (06-07)	SRS AirBag
 V70 (00-07)	AIRBAG	2.4 D (01-03)	SRS AirBag
 V70 (00-07)	AIRBAG	2.4 D (06-07)	SRS AirBag
 V70 (00-07)	AIRBAG	2.4 D5 (01-03)	SRS AirBag
 V70 (00-07)	AIRBAG	2.4 D5 (06-07)	SRS AirBag
 V70 (00-07)	AIRBAG	2.4 D5 AWD (01-03)	SRS AirBag
 V70 (00-07)	AIRBAG	2.4 D5 AWD (06-07)	SRS AirBag
 V70 (00-07)	AIRBAG	2.4 T (01-03)	SRS AirBag
 V70 (00-07)	AIRBAG	2.4 T (06-07)	SRS AirBag
 V70 (00-07)	AIRBAG	2.4 T AWD (01-03)	SRS AirBag
 V70 (00-07)	AIRBAG	2.4 T AWD (06-07)	SRS AirBag
 V70 (00-07)	AIRBAG	2.4 T5 (01-03)	SRS AirBag
 V70 (00-07)	AIRBAG	2.4 T5 (06-07)	SRS AirBag
 V70 (00-07)	AIRBAG	2.5 D (01-03)	SRS AirBag
 V70 (00-07)	AIRBAG	2.5 D (06-07)	SRS AirBag
 V70 (00-07)	AIRBAG	2.5 T (01-03)	SRS AirBag
 V70 (00-07)	AIRBAG	2.5 T (06-07)	SRS AirBag
 V70 (00-07)	AIRBAG	2.5 T AWD (01-03)	SRS AirBag
 V70 (00-07)	AIRBAG	2.5 T AWD (06-07)	SRS AirBag
 V70 (00-07)	CHASSIS NETWORK	2.0 T (01-03)	CEM Central Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.0 T (01-03)	REM Rear Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.0 T (06-07)	CEM Central Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.0 T (06-07)	REM Rear Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.3 T5 (01-03)	CEM Central Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.3 T5 (01-03)	REM Rear Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.3 T5 (06-07)	CEM Central Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.3 T5 (06-07)	REM Rear Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.4 (01-03)	CEM Central Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.4 (01-03)	REM Rear Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.4 (06-07)	CEM Central Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.4 (06-07)	REM Rear Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.4 BI-FUEL (01-03)	CEM Central Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.4 BI-FUEL (01-03)	REM Rear Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.4 BI-FUEL (06-07)	CEM Central Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.4 BI-FUEL (06-07)	REM Rear Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.4 D (01-03)	CEM Central Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.4 D (01-03)	REM Rear Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.4 D (06-07)	CEM Central Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.4 D (06-07)	REM Rear Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.4 D5 (01-03)	CEM Central Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.4 D5 (01-03)	REM Rear Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.4 D5 (06-07)	CEM Central Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.4 D5 (06-07)	REM Rear Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.4 D5 AWD (01-03)	CEM Central Electronic Module

Systems supported by ECUREADER / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 V70 (00-07)	CHASSIS NETWORK	2.4 D5 AWD (01-03)	REM Rear Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.4 D5 AWD (06-07)	CEM Central Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.4 D5 AWD (06-07)	REM Rear Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.4 T (01-03)	CEM Central Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.4 T (01-03)	REM Rear Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.4 T (06-07)	CEM Central Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.4 T (06-07)	REM Rear Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.4 T AWD (01-03)	CEM Central Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.4 T AWD (01-03)	REM Rear Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.4 T AWD (06-07)	CEM Central Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.4 T AWD (06-07)	REM Rear Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.4 T5 (01-03)	CEM Central Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.4 T5 (01-03)	REM Rear Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.4 T5 (06-07)	CEM Central Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.4 T5 (06-07)	REM Rear Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.5 D (01-03)	CEM Central Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.5 D (01-03)	REM Rear Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.5 D (06-07)	CEM Central Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.5 D (06-07)	REM Rear Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.5 T (01-03)	CEM Central Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.5 T (01-03)	REM Rear Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.5 T (06-07)	CEM Central Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.5 T (06-07)	REM Rear Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.5 T AWD (01-03)	CEM Central Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.5 T AWD (01-03)	REM Rear Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.5 T AWD (06-07)	CEM Central Electronic Module
 V70 (00-07)	CHASSIS NETWORK	2.5 T AWD (06-07)	REM Rear Electronic Module
 V70 (00-07)	CLIMA	2.0 T (06-07)	CCM Climate Control Unit
 V70 (00-07)	CLIMA	2.3 T5 (06-07)	CCM Climate Control Unit
 V70 (00-07)	CLIMA	2.4 (06-07)	CCM Climate Control Unit
 V70 (00-07)	CLIMA	2.4 BI-FUEL (06-07)	CCM Climate Control Unit
 V70 (00-07)	CLIMA	2.4 D (06-07)	CCM Climate Control Unit
 V70 (00-07)	CLIMA	2.4 D5 (06-07)	CCM Climate Control Unit
 V70 (00-07)	CLIMA	2.4 D5 AWD (06-07)	CCM Climate Control Unit
 V70 (00-07)	CLIMA	2.4 T (06-07)	CCM Climate Control Unit
 V70 (00-07)	CLIMA	2.4 T AWD (06-07)	CCM Climate Control Unit
 V70 (00-07)	CLIMA	2.4 T5 (06-07)	CCM Climate Control Unit
 V70 (00-07)	CLIMA	2.5 D (06-07)	CCM Climate Control Unit
 V70 (00-07)	CLIMA	2.5 T (06-07)	CCM Climate Control Unit
 V70 (00-07)	CLIMA	2.5 T AWD (06-07)	CCM Climate Control Unit
 V70 (00-07)	COLUMN/SEAT REG.	2.0 T (06-07)	PSM Power Seat Module
 V70 (00-07)	COLUMN/SEAT REG.	2.3 T5 (06-07)	PSM Power Seat Module
 V70 (00-07)	COLUMN/SEAT REG.	2.4 (06-07)	PSM Power Seat Module
 V70 (00-07)	COLUMN/SEAT REG.	2.4 BI-FUEL (06-07)	PSM Power Seat Module
 V70 (00-07)	COLUMN/SEAT REG.	2.4 D (06-07)	PSM Power Seat Module
 V70 (00-07)	COLUMN/SEAT REG.	2.4 D5 (06-07)	PSM Power Seat Module
 V70 (00-07)	COLUMN/SEAT REG.	2.4 D5 AWD (06-07)	PSM Power Seat Module
 V70 (00-07)	COLUMN/SEAT REG.	2.4 T (06-07)	PSM Power Seat Module
 V70 (00-07)	COLUMN/SEAT REG.	2.4 T AWD (06-07)	PSM Power Seat Module
 V70 (00-07)	COLUMN/SEAT REG.	2.4 T5 (06-07)	PSM Power Seat Module
 V70 (00-07)	COLUMN/SEAT REG.	2.5 D (06-07)	PSM Power Seat Module
 V70 (00-07)	COLUMN/SEAT REG.	2.5 T (06-07)	PSM Power Seat Module
 V70 (00-07)	COLUMN/SEAT REG.	2.5 T AWD (06-07)	PSM Power Seat Module
 V70 (00-07)	CONV. TOP/SUNROO	2.0 T (06-07)	UEM Upper Electronic Module
 V70 (00-07)	CONV. TOP/SUNROO	2.3 T5 (06-07)	UEM Upper Electronic Module
 V70 (00-07)	CONV. TOP/SUNROO	2.4 (06-07)	UEM Upper Electronic Module
 V70 (00-07)	CONV. TOP/SUNROO	2.4 BI-FUEL (06-07)	UEM Upper Electronic Module
 V70 (00-07)	CONV. TOP/SUNROO	2.4 D (06-07)	UEM Upper Electronic Module

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 V70 (00-07)	CONV. TOP/SUNROO	2.4 D5 (06-07)	UEM Upper Electronic Module
 V70 (00-07)	CONV. TOP/SUNROO	2.4 D5 AWD (06-07)	UEM Upper Electronic Module
 V70 (00-07)	CONV. TOP/SUNROO	2.4 T (06-07)	UEM Upper Electronic Module
 V70 (00-07)	CONV. TOP/SUNROO	2.4 T AWD (06-07)	UEM Upper Electronic Module
 V70 (00-07)	CONV. TOP/SUNROO	2.4 T5 (06-07)	UEM Upper Electronic Module
 V70 (00-07)	CONV. TOP/SUNROO	2.5 D (06-07)	UEM Upper Electronic Module
 V70 (00-07)	CONV. TOP/SUNROO	2.5 T (06-07)	UEM Upper Electronic Module
 V70 (00-07)	CONV. TOP/SUNROO	2.5 T AWD (06-07)	UEM Upper Electronic Module
 V70 (00-07)	DASHBOARD	2.0 T (01-03)	DIM Driver Information Module
 V70 (00-07)	DASHBOARD	2.0 T (06-07)	DIM Driver Information Module
 V70 (00-07)	DASHBOARD	2.3 T5 (01-03)	DIM Driver Information Module
 V70 (00-07)	DASHBOARD	2.3 T5 (06-07)	DIM Driver Information Module
 V70 (00-07)	DASHBOARD	2.4 (01-03)	DIM Driver Information Module
 V70 (00-07)	DASHBOARD	2.4 (06-07)	DIM Driver Information Module
 V70 (00-07)	DASHBOARD	2.4 BI-FUEL (01-03)	DIM Driver Information Module
 V70 (00-07)	DASHBOARD	2.4 BI-FUEL (06-07)	DIM Driver Information Module
 V70 (00-07)	DASHBOARD	2.4 D (01-03)	DIM Driver Information Module
 V70 (00-07)	DASHBOARD	2.4 D (06-07)	DIM Driver Information Module
 V70 (00-07)	DASHBOARD	2.4 D5 (01-03)	DIM Driver Information Module
 V70 (00-07)	DASHBOARD	2.4 D5 (06-07)	DIM Driver Information Module
 V70 (00-07)	DASHBOARD	2.4 D5 AWD (01-03)	DIM Driver Information Module
 V70 (00-07)	DASHBOARD	2.4 D5 AWD (06-07)	DIM Driver Information Module
 V70 (00-07)	DASHBOARD	2.4 T (01-03)	DIM Driver Information Module
 V70 (00-07)	DASHBOARD	2.4 T (06-07)	DIM Driver Information Module
 V70 (00-07)	DASHBOARD	2.4 T AWD (01-03)	DIM Driver Information Module
 V70 (00-07)	DASHBOARD	2.4 T AWD (06-07)	DIM Driver Information Module
 V70 (00-07)	DASHBOARD	2.4 T5 (01-03)	DIM Driver Information Module
 V70 (00-07)	DASHBOARD	2.4 T5 (06-07)	DIM Driver Information Module
 V70 (00-07)	DASHBOARD	2.5 D (01-03)	DIM Driver Information Module
 V70 (00-07)	DASHBOARD	2.5 D (06-07)	DIM Driver Information Module
 V70 (00-07)	DASHBOARD	2.5 T (01-03)	DIM Driver Information Module
 V70 (00-07)	DASHBOARD	2.5 T (06-07)	DIM Driver Information Module
 V70 (00-07)	DASHBOARD	2.5 T AWD (01-03)	DIM Driver Information Module
 V70 (00-07)	DASHBOARD	2.5 T AWD (06-07)	DIM Driver Information Module
 V70 (00-07)	DRIVER SIDE DOOR	2.0 T (06-07)	DDM Driver Door Module
 V70 (00-07)	DRIVER SIDE DOOR	2.3 T5 (06-07)	DDM Driver Door Module
 V70 (00-07)	DRIVER SIDE DOOR	2.4 (06-07)	DDM Driver Door Module
 V70 (00-07)	DRIVER SIDE DOOR	2.4 BI-FUEL (06-07)	DDM Driver Door Module
 V70 (00-07)	DRIVER SIDE DOOR	2.4 D (06-07)	DDM Driver Door Module
 V70 (00-07)	DRIVER SIDE DOOR	2.4 D5 (06-07)	DDM Driver Door Module
 V70 (00-07)	DRIVER SIDE DOOR	2.4 D5 AWD (06-07)	DDM Driver Door Module
 V70 (00-07)	DRIVER SIDE DOOR	2.4 T (06-07)	DDM Driver Door Module
 V70 (00-07)	DRIVER SIDE DOOR	2.4 T AWD (06-07)	DDM Driver Door Module
 V70 (00-07)	DRIVER SIDE DOOR	2.4 T5 (06-07)	DDM Driver Door Module
 V70 (00-07)	DRIVER SIDE DOOR	2.5 D (06-07)	DDM Driver Door Module
 V70 (00-07)	DRIVER SIDE DOOR	2.5 T (06-07)	DDM Driver Door Module
 V70 (00-07)	DRIVER SIDE DOOR	2.5 T AWD (06-07)	DDM Driver Door Module
 V70 (00-07)	ELECTRIC STEERING	2.0 T (06-07)	SAS Steering Angle Sensor
 V70 (00-07)	ELECTRIC STEERING	2.3 T5 (06-07)	SAS Steering Angle Sensor
 V70 (00-07)	ELECTRIC STEERING	2.4 (06-07)	SAS Steering Angle Sensor
 V70 (00-07)	ELECTRIC STEERING	2.4 BI-FUEL (06-07)	SAS Steering Angle Sensor
 V70 (00-07)	ELECTRIC STEERING	2.4 D (06-07)	SAS Steering Angle Sensor
 V70 (00-07)	ELECTRIC STEERING	2.4 D5 (06-07)	SAS Steering Angle Sensor
 V70 (00-07)	ELECTRIC STEERING	2.4 D5 AWD (06-07)	SAS Steering Angle Sensor
 V70 (00-07)	ELECTRIC STEERING	2.4 T (06-07)	SAS Steering Angle Sensor
 V70 (00-07)	ELECTRIC STEERING	2.4 T AWD (06-07)	SAS Steering Angle Sensor
 V70 (00-07)	ELECTRIC STEERING	2.4 T5 (06-07)	SAS Steering Angle Sensor
 V70 (00-07)	ELECTRIC STEERING	2.5 D (06-07)	SAS Steering Angle Sensor

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 V70 (00-07)	ELECTRIC STEERING	2.5 T (06-07)	SAS Steering Angle Sensor
 V70 (00-07)	ELECTRIC STEERING	2.5 T AWD (06-07)	SAS Steering Angle Sensor
 V70 (00-07)	ENGINE MANAGEME	2.0 T (01-..)	EOBD
 V70 (00-07)	ENGINE MANAGEME	2.3 T5 (01-..)	EOBD
 V70 (00-07)	ENGINE MANAGEME	2.4 B5244S (00-07)	NippoDenso
 V70 (00-07)	ENGINE MANAGEME	2.4 B5244S (01-07)	DENSO MPI M56
 V70 (00-07)	ENGINE MANAGEME	2.4 B5244T2 (03-04)	Bosch ME 7
 V70 (00-07)	ENGINE MANAGEME	2.4 B5244T3 (00-01)	Bosch ME 7
 V70 (00-07)	ENGINE MANAGEME	2.4 BI-FUEL B5244S (00-07)	NippoDenso
 V70 (00-07)	ENGINE MANAGEME	2.4 BI-FUEL B5244S (01-07)	DENSO MPI M56
 V70 (00-07)	ENGINE MANAGEME	2.4 BI-FUEL B5244T2 (03-04)	Bosch ME 7
 V70 (00-07)	ENGINE MANAGEME	2.4 BI-FUEL B5244T3 (00-01)	Bosch ME 7
 V70 (00-07)	ENGINE MANAGEME	2.4 D (04-..)	EOBD
 V70 (00-07)	ENGINE MANAGEME	2.4 D5 AWD D5244T (01-07)	BOSCH EDC Common Rail
 V70 (00-07)	ENGINE MANAGEME	2.4 D5 AWD D5244T2 (02-07)	BOSCH EDC Common Rail
 V70 (00-07)	ENGINE MANAGEME	2.4 D5 D5244T (01-07)	BOSCH EDC Common Rail
 V70 (00-07)	ENGINE MANAGEME	2.4 D5 D5244T2 (02-07)	BOSCH EDC Common Rail
 V70 (00-07)	ENGINE MANAGEME	2.4 T (01-..)	EOBD
 V70 (00-07)	ENGINE MANAGEME	2.4 T AWD (01-..)	EOBD
 V70 (00-07)	ENGINE MANAGEME	2.4 T5 (01-..)	EOBD
 V70 (00-07)	ENGINE MANAGEME	2.5 D (04-..)	EOBD
 V70 (00-07)	ENGINE MANAGEME	2.5 T (01-..)	EOBD
 V70 (00-07)	ENGINE MANAGEME	2.5 T AWD (01-..)	EOBD
 V70 (00-07)	GEARBOX MANAGEM	2.0 T (06-07)	TCM Trasmission Control Module
 V70 (00-07)	GEARBOX MANAGEM	2.3 T5 (06-07)	TCM Trasmission Control Module
 V70 (00-07)	GEARBOX MANAGEM	2.4 (06-07)	TCM Trasmission Control Module
 V70 (00-07)	GEARBOX MANAGEM	2.4 BI-FUEL (06-07)	TCM Trasmission Control Module
 V70 (00-07)	GEARBOX MANAGEM	2.4 D (06-07)	TCM Trasmission Control Module
 V70 (00-07)	GEARBOX MANAGEM	2.4 D5 (06-07)	TCM Trasmission Control Module
 V70 (00-07)	GEARBOX MANAGEM	2.4 D5 AWD (06-07)	TCM Trasmission Control Module
 V70 (00-07)	GEARBOX MANAGEM	2.4 T (06-07)	TCM Trasmission Control Module
 V70 (00-07)	GEARBOX MANAGEM	2.4 T AWD (06-07)	TCM Trasmission Control Module
 V70 (00-07)	GEARBOX MANAGEM	2.4 T5 (06-07)	TCM Trasmission Control Module
 V70 (00-07)	GEARBOX MANAGEM	2.5 D (06-07)	TCM Trasmission Control Module
 V70 (00-07)	GEARBOX MANAGEM	2.5 T (06-07)	TCM Trasmission Control Module
 V70 (00-07)	GEARBOX MANAGEM	2.5 T AWD (06-07)	TCM Trasmission Control Module
 V70 (00-07)	MAINTENANCE	2.0 T (00-02)	VDO
 V70 (00-07)	MAINTENANCE	2.0 T (00-07)	MANUAL
 V70 (00-07)	MAINTENANCE	2.0 T (03-07)	Service
 V70 (00-07)	MAINTENANCE	2.3 T5 (00-02)	VDO
 V70 (00-07)	MAINTENANCE	2.3 T5 (00-07)	MANUAL
 V70 (00-07)	MAINTENANCE	2.3 T5 (03-07)	Service
 V70 (00-07)	MAINTENANCE	2.4 (00-02)	VDO
 V70 (00-07)	MAINTENANCE	2.4 (00-07)	MANUAL
 V70 (00-07)	MAINTENANCE	2.4 (03-07)	Service
 V70 (00-07)	MAINTENANCE	2.4 BI-FUEL (00-02)	VDO
 V70 (00-07)	MAINTENANCE	2.4 BI-FUEL (00-07)	MANUAL
 V70 (00-07)	MAINTENANCE	2.4 BI-FUEL (03-07)	Service
 V70 (00-07)	MAINTENANCE	2.4 D (00-02)	VDO
 V70 (00-07)	MAINTENANCE	2.4 D (00-07)	MANUAL
 V70 (00-07)	MAINTENANCE	2.4 D (03-07)	Service
 V70 (00-07)	MAINTENANCE	2.4 D5 (00-02)	VDO
 V70 (00-07)	MAINTENANCE	2.4 D5 (00-07)	MANUAL
 V70 (00-07)	MAINTENANCE	2.4 D5 (03-07)	Service
 V70 (00-07)	MAINTENANCE	2.4 D5 AWD (00-02)	VDO
 V70 (00-07)	MAINTENANCE	2.4 D5 AWD (00-07)	MANUAL
 V70 (00-07)	MAINTENANCE	2.4 D5 AWD (03-07)	Service
 V70 (00-07)	MAINTENANCE	2.4 T (00-02)	VDO

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 V70 (00-07)	MAINTENANCE	2.4 T (00-07)	MANUAL
 V70 (00-07)	MAINTENANCE	2.4 T (03-07)	Service
 V70 (00-07)	MAINTENANCE	2.4 T AWD (00-02)	VDO
 V70 (00-07)	MAINTENANCE	2.4 T AWD (00-07)	MANUAL
 V70 (00-07)	MAINTENANCE	2.4 T AWD (03-07)	Service
 V70 (00-07)	MAINTENANCE	2.4 T5 (00-02)	VDO
 V70 (00-07)	MAINTENANCE	2.4 T5 (00-07)	MANUAL
 V70 (00-07)	MAINTENANCE	2.4 T5 (03-07)	Service
 V70 (00-07)	MAINTENANCE	2.5 D (00-02)	VDO
 V70 (00-07)	MAINTENANCE	2.5 D (00-07)	MANUAL
 V70 (00-07)	MAINTENANCE	2.5 D (03-07)	Service
 V70 (00-07)	MAINTENANCE	2.5 T (00-02)	VDO
 V70 (00-07)	MAINTENANCE	2.5 T (00-07)	MANUAL
 V70 (00-07)	MAINTENANCE	2.5 T (03-07)	Service
 V70 (00-07)	MAINTENANCE	2.5 T AWD (00-02)	VDO
 V70 (00-07)	MAINTENANCE	2.5 T AWD (00-07)	MANUAL
 V70 (00-07)	MAINTENANCE	2.5 T AWD (03-07)	Service
 V70 (00-07)	NAVIGATION	2.0 T (01-03)	RTI Road Traffic Information
 V70 (00-07)	NAVIGATION	2.3 T5 (01-03)	RTI Road Traffic Information
 V70 (00-07)	NAVIGATION	2.4 (01-03)	RTI Road Traffic Information
 V70 (00-07)	NAVIGATION	2.4 BI-FUEL (01-03)	RTI Road Traffic Information
 V70 (00-07)	NAVIGATION	2.4 D (01-03)	RTI Road Traffic Information
 V70 (00-07)	NAVIGATION	2.4 D5 (01-03)	RTI Road Traffic Information
 V70 (00-07)	NAVIGATION	2.4 D5 AWD (01-03)	RTI Road Traffic Information
 V70 (00-07)	NAVIGATION	2.4 T (01-03)	RTI Road Traffic Information
 V70 (00-07)	NAVIGATION	2.4 T AWD (01-03)	RTI Road Traffic Information
 V70 (00-07)	NAVIGATION	2.4 T5 (01-03)	RTI Road Traffic Information
 V70 (00-07)	NAVIGATION	2.5 D (01-03)	RTI Road Traffic Information
 V70 (00-07)	NAVIGATION	2.5 T (01-03)	RTI Road Traffic Information
 V70 (00-07)	NAVIGATION	2.5 T AWD (01-03)	RTI Road Traffic Information
 V70 (00-07)	PASS. SIDE DOOR	2.0 T (06-07)	PDM Passenger Door Module
 V70 (00-07)	PASS. SIDE DOOR	2.3 T5 (06-07)	PDM Passenger Door Module
 V70 (00-07)	PASS. SIDE DOOR	2.4 (06-07)	PDM Passenger Door Module
 V70 (00-07)	PASS. SIDE DOOR	2.4 BI-FUEL (06-07)	PDM Passenger Door Module
 V70 (00-07)	PASS. SIDE DOOR	2.4 D (06-07)	PDM Passenger Door Module
 V70 (00-07)	PASS. SIDE DOOR	2.4 D5 (06-07)	PDM Passenger Door Module
 V70 (00-07)	PASS. SIDE DOOR	2.4 D5 AWD (06-07)	PDM Passenger Door Module
 V70 (00-07)	PASS. SIDE DOOR	2.4 T (06-07)	PDM Passenger Door Module
 V70 (00-07)	PASS. SIDE DOOR	2.4 T AWD (06-07)	PDM Passenger Door Module
 V70 (00-07)	PASS. SIDE DOOR	2.4 T5 (06-07)	PDM Passenger Door Module
 V70 (00-07)	PASS. SIDE DOOR	2.5 D (06-07)	PDM Passenger Door Module
 V70 (00-07)	PASS. SIDE DOOR	2.5 T (06-07)	PDM Passenger Door Module
 V70 (00-07)	PASS. SIDE DOOR	2.5 T AWD (06-07)	PDM Passenger Door Module
 V70 (00-07)	RADIO / CD	2.0 T (01-03)	AUM Audio Module
 V70 (00-07)	RADIO / CD	2.0 T (06-07)	ACM Audio Module
 V70 (00-07)	RADIO / CD	2.3 T5 (01-03)	AUM Audio Module
 V70 (00-07)	RADIO / CD	2.3 T5 (06-07)	ACM Audio Module
 V70 (00-07)	RADIO / CD	2.4 (01-03)	AUM Audio Module
 V70 (00-07)	RADIO / CD	2.4 (06-07)	ACM Audio Module
 V70 (00-07)	RADIO / CD	2.4 BI-FUEL (01-03)	AUM Audio Module
 V70 (00-07)	RADIO / CD	2.4 BI-FUEL (06-07)	ACM Audio Module
 V70 (00-07)	RADIO / CD	2.4 D (01-03)	AUM Audio Module
 V70 (00-07)	RADIO / CD	2.4 D (06-07)	ACM Audio Module
 V70 (00-07)	RADIO / CD	2.4 D5 (01-03)	AUM Audio Module
 V70 (00-07)	RADIO / CD	2.4 D5 (06-07)	ACM Audio Module
 V70 (00-07)	RADIO / CD	2.4 D5 AWD (01-03)	AUM Audio Module
 V70 (00-07)	RADIO / CD	2.4 D5 AWD (06-07)	ACM Audio Module
 V70 (00-07)	RADIO / CD	2.4 T (01-03)	AUM Audio Module

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 V70 (00-07)	RADIO / CD	2.4 T (06-07)	ACM Audio Module
 V70 (00-07)	RADIO / CD	2.4 T AWD (01-03)	AUM Audio Module
 V70 (00-07)	RADIO / CD	2.4 T AWD (06-07)	ACM Audio Module
 V70 (00-07)	RADIO / CD	2.4 T5 (01-03)	AUM Audio Module
 V70 (00-07)	RADIO / CD	2.4 T5 (06-07)	ACM Audio Module
 V70 (00-07)	RADIO / CD	2.5 D (01-03)	AUM Audio Module
 V70 (00-07)	RADIO / CD	2.5 D (06-07)	ACM Audio Module
 V70 (00-07)	RADIO / CD	2.5 T (01-03)	AUM Audio Module
 V70 (00-07)	RADIO / CD	2.5 T (06-07)	ACM Audio Module
 V70 (00-07)	RADIO / CD	2.5 T AWD (01-03)	AUM Audio Module
 V70 (00-07)	RADIO / CD	2.5 T AWD (06-07)	ACM Audio Module
 V70 (00-07)	SERVICE LIGHT RES	2.0 T (00-02)	VDO
 V70 (00-07)	SERVICE LIGHT RES	2.0 T (00-07)	MANUAL
 V70 (00-07)	SERVICE LIGHT RES	2.0 T (03-07)	Service
 V70 (00-07)	SERVICE LIGHT RES	2.3 T5 (00-02)	VDO
 V70 (00-07)	SERVICE LIGHT RES	2.3 T5 (00-07)	MANUAL
 V70 (00-07)	SERVICE LIGHT RES	2.3 T5 (03-07)	Service
 V70 (00-07)	SERVICE LIGHT RES	2.4 (00-02)	VDO
 V70 (00-07)	SERVICE LIGHT RES	2.4 (00-07)	MANUAL
 V70 (00-07)	SERVICE LIGHT RES	2.4 (03-07)	Service
 V70 (00-07)	SERVICE LIGHT RES	2.4 BI-FUEL (00-02)	VDO
 V70 (00-07)	SERVICE LIGHT RES	2.4 BI-FUEL (00-07)	MANUAL
 V70 (00-07)	SERVICE LIGHT RES	2.4 BI-FUEL (03-07)	Service
 V70 (00-07)	SERVICE LIGHT RES	2.4 D (00-02)	VDO
 V70 (00-07)	SERVICE LIGHT RES	2.4 D (00-07)	MANUAL
 V70 (00-07)	SERVICE LIGHT RES	2.4 D (03-07)	Service
 V70 (00-07)	SERVICE LIGHT RES	2.4 D5 (00-02)	VDO
 V70 (00-07)	SERVICE LIGHT RES	2.4 D5 (00-07)	MANUAL
 V70 (00-07)	SERVICE LIGHT RES	2.4 D5 (03-07)	Service
 V70 (00-07)	SERVICE LIGHT RES	2.4 D5 AWD (00-02)	VDO
 V70 (00-07)	SERVICE LIGHT RES	2.4 D5 AWD (00-07)	MANUAL
 V70 (00-07)	SERVICE LIGHT RES	2.4 D5 AWD (03-07)	Service
 V70 (00-07)	SERVICE LIGHT RES	2.4 T (00-02)	VDO
 V70 (00-07)	SERVICE LIGHT RES	2.4 T (00-07)	MANUAL
 V70 (00-07)	SERVICE LIGHT RES	2.4 T (03-07)	Service
 V70 (00-07)	SERVICE LIGHT RES	2.4 T AWD (00-02)	VDO
 V70 (00-07)	SERVICE LIGHT RES	2.4 T AWD (00-07)	MANUAL
 V70 (00-07)	SERVICE LIGHT RES	2.4 T AWD (03-07)	Service
 V70 (00-07)	SERVICE LIGHT RES	2.4 T5 (00-02)	VDO
 V70 (00-07)	SERVICE LIGHT RES	2.4 T5 (00-07)	MANUAL
 V70 (00-07)	SERVICE LIGHT RES	2.4 T5 (03-07)	Service
 V70 (00-07)	SERVICE LIGHT RES	2.5 D (00-02)	VDO
 V70 (00-07)	SERVICE LIGHT RES	2.5 D (00-07)	MANUAL
 V70 (00-07)	SERVICE LIGHT RES	2.5 D (03-07)	Service
 V70 (00-07)	SERVICE LIGHT RES	2.5 T (00-02)	VDO
 V70 (00-07)	SERVICE LIGHT RES	2.5 T (00-07)	MANUAL
 V70 (00-07)	SERVICE LIGHT RES	2.5 T (03-07)	Service
 V70 (00-07)	SERVICE LIGHT RES	2.5 T AWD (00-02)	VDO
 V70 (00-07)	SERVICE LIGHT RES	2.5 T AWD (00-07)	MANUAL
 V70 (00-07)	SERVICE LIGHT RES	2.5 T AWD (03-07)	Service
 V70 (00-07)	STEERING WHEEL E	2.0 T (01-04)	SWM Steering wheel module
 V70 (00-07)	STEERING WHEEL E	2.3 T5 (01-04)	SWM Steering wheel module
 V70 (00-07)	STEERING WHEEL E	2.4 (01-04)	SWM Steering wheel module
 V70 (00-07)	STEERING WHEEL E	2.4 BI-FUEL (01-04)	SWM Steering wheel module
 V70 (00-07)	STEERING WHEEL E	2.4 D (01-04)	SWM Steering wheel module
 V70 (00-07)	STEERING WHEEL E	2.4 D5 (01-04)	SWM Steering wheel module
 V70 (00-07)	STEERING WHEEL E	2.4 D5 AWD (01-04)	SWM Steering wheel module
 V70 (00-07)	STEERING WHEEL E	2.4 T (01-04)	SWM Steering wheel module

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 V70 (00-07)	STEERING WHEEL E	2.4 T AWD (01-04)	SWM Steering wheel module
 V70 (00-07)	STEERING WHEEL E	2.4 T5 (01-04)	SWM Steering wheel module
 V70 (00-07)	STEERING WHEEL E	2.5 D (01-04)	SWM Steering wheel module
 V70 (00-07)	STEERING WHEEL E	2.5 T (01-04)	SWM Steering wheel module
 V70 (00-07)	STEERING WHEEL E	2.5 T AWD (01-04)	SWM Steering wheel module
 V70 (00-07)	VISUAL./TELEMATIC	2.0 T (06-07)	ICM Infotainment Control Module
 V70 (00-07)	VISUAL./TELEMATIC	2.3 T5 (06-07)	ICM Infotainment Control Module
 V70 (00-07)	VISUAL./TELEMATIC	2.4 (06-07)	ICM Infotainment Control Module
 V70 (00-07)	VISUAL./TELEMATIC	2.4 BI-FUEL (06-07)	ICM Infotainment Control Module
 V70 (00-07)	VISUAL./TELEMATIC	2.4 D (06-07)	ICM Infotainment Control Module
 V70 (00-07)	VISUAL./TELEMATIC	2.4 D5 (06-07)	ICM Infotainment Control Module
 V70 (00-07)	VISUAL./TELEMATIC	2.4 D5 AWD (06-07)	ICM Infotainment Control Module
 V70 (00-07)	VISUAL./TELEMATIC	2.4 T (06-07)	ICM Infotainment Control Module
 V70 (00-07)	VISUAL./TELEMATIC	2.4 T AWD (06-07)	ICM Infotainment Control Module
 V70 (00-07)	VISUAL./TELEMATIC	2.4 T5 (06-07)	ICM Infotainment Control Module
 V70 (00-07)	VISUAL./TELEMATIC	2.5 D (06-07)	ICM Infotainment Control Module
 V70 (00-07)	VISUAL./TELEMATIC	2.5 T (06-07)	ICM Infotainment Control Module
 V70 (00-07)	VISUAL./TELEMATIC	2.5 T AWD (06-07)	ICM Infotainment Control Module
 V70 (08-..)	ABS	1.6 T4	BCM
 V70 (08-..)	ABS	2.0 D3	BCM
 V70 (08-..)	ABS	2.0 T	BCM
 V70 (08-..)	ABS	2.0 T5	BCM
 V70 (08-..)	ABS	2.4 D5	BCM
 V70 (08-..)	ABS	2.4 D5 AWD	BCM
 V70 (08-..)	ABS	3.0 T6 AWD	BCM
 V70 (08-..)	AIRBAG	1.6 T4	SRS
 V70 (08-..)	AIRBAG	2.0 D3	SRS
 V70 (08-..)	AIRBAG	2.0 T	SRS
 V70 (08-..)	AIRBAG	2.0 T5	SRS
 V70 (08-..)	AIRBAG	2.4 D5	SRS
 V70 (08-..)	AIRBAG	2.4 D5 AWD	SRS
 V70 (08-..)	AIRBAG	3.0 T6 AWD	SRS
 V70 (08-..)	AUTOM. TRANSMISSI	1.6 T4	TCM
 V70 (08-..)	AUTOM. TRANSMISSI	2.0 D3	TCM
 V70 (08-..)	AUTOM. TRANSMISSI	2.0 T	TCM
 V70 (08-..)	AUTOM. TRANSMISSI	2.0 T5	TCM
 V70 (08-..)	AUTOM. TRANSMISSI	2.4 D5	TCM
 V70 (08-..)	AUTOM. TRANSMISSI	2.4 D5 AWD	TCM
 V70 (08-..)	AUTOM. TRANSMISSI	3.0 T6 AWD	TCM
 V70 (08-..)	CENTRAL LOCKING	1.6 T4	POT Baule
 V70 (08-..)	CENTRAL LOCKING	2.0 D3	POT Baule
 V70 (08-..)	CENTRAL LOCKING	2.0 T	POT Baule
 V70 (08-..)	CENTRAL LOCKING	2.0 T5	POT Baule
 V70 (08-..)	CENTRAL LOCKING	2.4 D5	POT Baule
 V70 (08-..)	CENTRAL LOCKING	2.4 D5 AWD	POT Baule
 V70 (08-..)	CENTRAL LOCKING	3.0 T6 AWD	POT Baule
 V70 (08-..)	CHASSIS NETWORK	1.6 T4	CEM
 V70 (08-..)	CHASSIS NETWORK	1.6 T4	DIM
 V70 (08-..)	CHASSIS NETWORK	2.0 D3	CEM
 V70 (08-..)	CHASSIS NETWORK	2.0 D3	DIM
 V70 (08-..)	CHASSIS NETWORK	2.0 T	CEM
 V70 (08-..)	CHASSIS NETWORK	2.0 T	DIM
 V70 (08-..)	CHASSIS NETWORK	2.0 T5	CEM
 V70 (08-..)	CHASSIS NETWORK	2.0 T5	DIM
 V70 (08-..)	CHASSIS NETWORK	2.4 D5	CEM
 V70 (08-..)	CHASSIS NETWORK	2.4 D5	DIM
 V70 (08-..)	CHASSIS NETWORK	2.4 D5 AWD	CEM
 V70 (08-..)	CHASSIS NETWORK	2.4 D5 AWD	DIM

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 V70 (08-..)	CHASSIS NETWORK	3.0 T6 AWD	CEM
 V70 (08-..)	CHASSIS NETWORK	3.0 T6 AWD	DIM
 V70 (08-..)	CLIMA	1.6 T4	CCM
 V70 (08-..)	CLIMA	2.0 D3	CCM
 V70 (08-..)	CLIMA	2.0 T	CCM
 V70 (08-..)	CLIMA	2.0 T5	CCM
 V70 (08-..)	CLIMA	2.4 D5	CCM
 V70 (08-..)	CLIMA	2.4 D5 AWD	CCM
 V70 (08-..)	CLIMA	3.0 T6 AWD	CCM
 V70 (08-..)	ELECTRIC STEERING	1.6 T4	SAS
 V70 (08-..)	ELECTRIC STEERING	2.0 D3	SAS
 V70 (08-..)	ELECTRIC STEERING	2.0 T	SAS
 V70 (08-..)	ELECTRIC STEERING	2.0 T5	SAS
 V70 (08-..)	ELECTRIC STEERING	2.4 D5	SAS
 V70 (08-..)	ELECTRIC STEERING	2.4 D5 AWD	SAS
 V70 (08-..)	ELECTRIC STEERING	3.0 T6 AWD	SAS
 V70 (08-..)	ENGINE MANAGEME	2.4 D5	ECM
 V70 (08-..)	ENGINE MANAGEME	2.4 D5 AWD	ECM
 V70 (08-..)	MAINTENANCE	1.6 T4	MANUAL
 V70 (08-..)	MAINTENANCE	1.6 T4	PBM
 V70 (08-..)	MAINTENANCE	1.6 T4	PBM
 V70 (08-..)	MAINTENANCE	1.6 T4	PBM
 V70 (08-..)	MAINTENANCE	1.6 T4	TCM
 V70 (08-..)	MAINTENANCE	2.0 D3	MANUAL
 V70 (08-..)	MAINTENANCE	2.0 D3	PBM
 V70 (08-..)	MAINTENANCE	2.0 D3	PBM
 V70 (08-..)	MAINTENANCE	2.0 D3	PBM
 V70 (08-..)	MAINTENANCE	2.0 D3	TCM
 V70 (08-..)	MAINTENANCE	2.0 T	MANUAL
 V70 (08-..)	MAINTENANCE	2.0 T	PBM
 V70 (08-..)	MAINTENANCE	2.0 T	PBM
 V70 (08-..)	MAINTENANCE	2.0 T	PBM
 V70 (08-..)	MAINTENANCE	2.0 T	TCM
 V70 (08-..)	MAINTENANCE	2.0 T5	MANUAL
 V70 (08-..)	MAINTENANCE	2.0 T5	PBM
 V70 (08-..)	MAINTENANCE	2.0 T5	PBM
 V70 (08-..)	MAINTENANCE	2.0 T5	PBM
 V70 (08-..)	MAINTENANCE	2.0 T5	TCM
 V70 (08-..)	MAINTENANCE	2.4 D5	ECM
 V70 (08-..)	MAINTENANCE	2.4 D5	MANUAL
 V70 (08-..)	MAINTENANCE	2.4 D5	PBM
 V70 (08-..)	MAINTENANCE	2.4 D5	PBM
 V70 (08-..)	MAINTENANCE	2.4 D5	PBM
 V70 (08-..)	MAINTENANCE	2.4 D5	TCM
 V70 (08-..)	MAINTENANCE	2.4 D5 AWD	ECM
 V70 (08-..)	MAINTENANCE	2.4 D5 AWD	MANUAL
 V70 (08-..)	MAINTENANCE	2.4 D5 AWD	PBM
 V70 (08-..)	MAINTENANCE	2.4 D5 AWD	PBM
 V70 (08-..)	MAINTENANCE	2.4 D5 AWD	PBM
 V70 (08-..)	MAINTENANCE	2.4 D5 AWD	TCM
 V70 (08-..)	MAINTENANCE	3.0 T6 AWD	MANUAL
 V70 (08-..)	MAINTENANCE	3.0 T6 AWD	PBM
 V70 (08-..)	MAINTENANCE	3.0 T6 AWD	PBM
 V70 (08-..)	MAINTENANCE	3.0 T6 AWD	PBM
 V70 (08-..)	MAINTENANCE	3.0 T6 AWD	TCM
 V70 (08-..)	PARK.BRAKE	1.6 T4	PBM
 V70 (08-..)	PARK.BRAKE	2.0 D3	PBM
 V70 (08-..)	PARK.BRAKE	2.0 T	PBM

Systems supported by ECUREADER / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 V70 (08-..)	PARK.BRAKE	2.0 T5	PBM
 V70 (08-..)	PARK.BRAKE	2.4 D5	PBM
 V70 (08-..)	PARK.BRAKE	2.4 D5 AWD	PBM
 V70 (08-..)	PARK.BRAKE	3.0 T6 AWD	PBM
 V70 (08-..)	SERVICE LIGHT RES	1.6 T4	MANUAL
 V70 (08-..)	SERVICE LIGHT RES	2.0 D3	MANUAL
 V70 (08-..)	SERVICE LIGHT RES	2.0 T	MANUAL
 V70 (08-..)	SERVICE LIGHT RES	2.0 T5	MANUAL
 V70 (08-..)	SERVICE LIGHT RES	2.4 D5	MANUAL
 V70 (08-..)	SERVICE LIGHT RES	2.4 D5 AWD	MANUAL
 V70 (08-..)	SERVICE LIGHT RES	3.0 T6 AWD	MANUAL
 V70 (96-00)	ABS	2.0 (96-98)	ATE ABS Mk20
 V70 (96-00)	ABS	2.0 (99-00)	ABS
 V70 (96-00)	ABS	2.0 T (99-00)	ABS
 V70 (96-00)	ABS	2.0 T5 (96-98)	ATE ABS Mk20
 V70 (96-00)	ABS	2.0 T5 (99-00)	ABS
 V70 (96-00)	ABS	2.0 T5 AWD (96-98)	ATE ABS Mk20
 V70 (96-00)	ABS	2.0 T5 AWD (99-00)	ABS
 V70 (96-00)	ABS	2.3 T5 (96-98)	ATE ABS Mk20
 V70 (96-00)	ABS	2.3 T5 (99-00)	ABS
 V70 (96-00)	ABS	2.3 T5 AWD (96-98)	ATE ABS Mk20
 V70 (96-00)	ABS	2.3 T5 AWD (99-00)	ABS
 V70 (96-00)	ABS	2.4 T5 AWD (96-98)	ATE ABS Mk20
 V70 (96-00)	ABS	2.4 T5 AWD (99-00)	ABS
 V70 (96-00)	ABS	2.5 TDI (96-98)	ATE ABS Mk20
 V70 (96-00)	ABS	2.5 TDI (99-00)	ABS
 V70 (96-00)	AIRBAG	2.0 (96-98)	
 V70 (96-00)	AIRBAG	2.0 (96-98)	BOSCH - Autoliv AirBag 6.2
 V70 (96-00)	AIRBAG	2.0 (99-00)	SRS
 V70 (96-00)	AIRBAG	2.0 T (96-98)	
 V70 (96-00)	AIRBAG	2.0 T (96-98)	BOSCH - Autoliv AirBag 6.2
 V70 (96-00)	AIRBAG	2.0 T (99-00)	SRS
 V70 (96-00)	AIRBAG	2.0 T5 (96-98)	
 V70 (96-00)	AIRBAG	2.0 T5 (96-98)	BOSCH - Autoliv AirBag 6.2
 V70 (96-00)	AIRBAG	2.0 T5 (99-00)	SRS
 V70 (96-00)	AIRBAG	2.0 T5 AWD (96-98)	
 V70 (96-00)	AIRBAG	2.0 T5 AWD (96-98)	BOSCH - Autoliv AirBag 6.2
 V70 (96-00)	AIRBAG	2.0 T5 AWD (99-00)	SRS
 V70 (96-00)	AIRBAG	2.3 T5 (96-98)	
 V70 (96-00)	AIRBAG	2.3 T5 (96-98)	BOSCH - Autoliv AirBag 6.2
 V70 (96-00)	AIRBAG	2.3 T5 (99-00)	SRS
 V70 (96-00)	AIRBAG	2.3 T5 AWD (96-98)	
 V70 (96-00)	AIRBAG	2.3 T5 AWD (96-98)	BOSCH - Autoliv AirBag 6.2
 V70 (96-00)	AIRBAG	2.3 T5 AWD (99-00)	SRS
 V70 (96-00)	AIRBAG	2.4 T5 AWD (96-98)	
 V70 (96-00)	AIRBAG	2.4 T5 AWD (96-98)	BOSCH - Autoliv AirBag 6.2
 V70 (96-00)	AIRBAG	2.4 T5 AWD (99-00)	SRS
 V70 (96-00)	AIRBAG	2.5 TDI (96-98)	
 V70 (96-00)	AIRBAG	2.5 TDI (96-98)	BOSCH - Autoliv AirBag 6.2
 V70 (96-00)	AIRBAG	2.5 TDI (99-00)	SRS
 V70 (96-00)	DASHBOARD	2.0 (99-00)	VDO Dashboard
 V70 (96-00)	DASHBOARD	2.0 T (99-00)	VDO Dashboard
 V70 (96-00)	DASHBOARD	2.0 T5 (99-00)	VDO Dashboard
 V70 (96-00)	DASHBOARD	2.0 T5 AWD (99-00)	VDO Dashboard
 V70 (96-00)	DASHBOARD	2.3 T5 (99-00)	VDO Dashboard
 V70 (96-00)	DASHBOARD	2.3 T5 AWD (99-00)	VDO Dashboard
 V70 (96-00)	DASHBOARD	2.4 T5 AWD (99-00)	VDO Dashboard
 V70 (96-00)	DASHBOARD	2.5 TDI (99-00)	VDO Dashboard

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 V70 (96-00)	DIESEL MANAGEMEN	2.5 TDI (96-00)	BOSCH MSA 15.7
 V70 (96-00)	ENGINE MANAGEME	2.0 T B5204T (96-00)	BOSCH Motronic 4.4
 V70 (96-00)	ENGINE MANAGEME	2.5 T B5254S (96-00)	BOSCH Motronic 4.3
 V70 (96-00)	ENGINE MANAGEME	2.5 T B5254S (96-00)	BOSCH Motronic 4.4
 V70 (96-00)	ENGINE MANAGEME	2.5 TDI (96-00)	BOSCH MSA 15.8
 V70 (96-00)	IMMOBILIZER	2.0 (96-98)	BOSCH Immobilizer Cartronic 2
 V70 (96-00)	IMMOBILIZER	2.0 (96-98)	BOSCH Immobilizer Immo 3
 V70 (96-00)	IMMOBILIZER	2.0 (99-00)	BOSCH Immobilizer Immo 4
 V70 (96-00)	IMMOBILIZER	2.0 T (96-98)	BOSCH Immobilizer Cartronic 2
 V70 (96-00)	IMMOBILIZER	2.0 T (96-98)	BOSCH Immobilizer Immo 3
 V70 (96-00)	IMMOBILIZER	2.0 T (99-00)	BOSCH Immobilizer Immo 4
 V70 (96-00)	IMMOBILIZER	2.0 T5 (96-98)	BOSCH Immobilizer Cartronic 2
 V70 (96-00)	IMMOBILIZER	2.0 T5 (96-98)	BOSCH Immobilizer Immo 3
 V70 (96-00)	IMMOBILIZER	2.0 T5 (99-00)	BOSCH Immobilizer Immo 4
 V70 (96-00)	IMMOBILIZER	2.0 T5 AWD (96-98)	BOSCH Immobilizer Cartronic 2
 V70 (96-00)	IMMOBILIZER	2.0 T5 AWD (96-98)	BOSCH Immobilizer Immo 3
 V70 (96-00)	IMMOBILIZER	2.0 T5 AWD (99-00)	BOSCH Immobilizer Immo 4
 V70 (96-00)	IMMOBILIZER	2.3 T5 (96-98)	BOSCH Immobilizer Cartronic 2
 V70 (96-00)	IMMOBILIZER	2.3 T5 (96-98)	BOSCH Immobilizer Immo 3
 V70 (96-00)	IMMOBILIZER	2.3 T5 (99-00)	BOSCH Immobilizer Immo 4
 V70 (96-00)	IMMOBILIZER	2.3 T5 AWD (96-98)	BOSCH Immobilizer Cartronic 2
 V70 (96-00)	IMMOBILIZER	2.3 T5 AWD (96-98)	BOSCH Immobilizer Immo 3
 V70 (96-00)	IMMOBILIZER	2.3 T5 AWD (99-00)	BOSCH Immobilizer Immo 4
 V70 (96-00)	IMMOBILIZER	2.4 D (99-00)	BOSCH Immobilizer Immo 4
 V70 (96-00)	IMMOBILIZER	2.4 T5 AWD (96-98)	BOSCH Immobilizer Cartronic 2
 V70 (96-00)	IMMOBILIZER	2.4 T5 AWD (96-98)	BOSCH Immobilizer Immo 3
 V70 (96-00)	IMMOBILIZER	2.4 T5 AWD (99-00)	BOSCH Immobilizer Immo 4
 V70 (96-00)	IMMOBILIZER	2.5 TDI (96-98)	BOSCH Immobilizer Cartronic 2
 V70 (96-00)	IMMOBILIZER	2.5 TDI (96-98)	BOSCH Immobilizer Immo 3
 V70 (96-00)	IMMOBILIZER	2.5 TDI (99-00)	BOSCH Immobilizer Immo 4
 V70 (96-00)	MAINTENANCE	2.0 (96-00)	
 V70 (96-00)	MAINTENANCE	2.0 (99-00)	MANUAL
 V70 (96-00)	MAINTENANCE	2.0 (99-00)	VDO Dashboard
 V70 (96-00)	MAINTENANCE	2.0 T (96-00)	
 V70 (96-00)	MAINTENANCE	2.0 T (99-00)	MANUAL
 V70 (96-00)	MAINTENANCE	2.0 T (99-00)	VDO Dashboard
 V70 (96-00)	MAINTENANCE	2.0 T5 (96-00)	
 V70 (96-00)	MAINTENANCE	2.0 T5 (99-00)	MANUAL
 V70 (96-00)	MAINTENANCE	2.0 T5 (99-00)	VDO Dashboard
 V70 (96-00)	MAINTENANCE	2.0 T5 AWD (96-00)	
 V70 (96-00)	MAINTENANCE	2.0 T5 AWD (99-00)	MANUAL
 V70 (96-00)	MAINTENANCE	2.0 T5 AWD (99-00)	VDO Dashboard
 V70 (96-00)	MAINTENANCE	2.3 T5 (96-00)	
 V70 (96-00)	MAINTENANCE	2.3 T5 (99-00)	VDO Dashboard
 V70 (96-00)	MAINTENANCE	2.3 T5 AWD (96-00)	
 V70 (96-00)	MAINTENANCE	2.3 T5 AWD (99-00)	MANUAL
 V70 (96-00)	MAINTENANCE	2.3 T5 AWD (99-00)	VDO Dashboard
 V70 (96-00)	MAINTENANCE	2.4 T5 AWD (96-00)	
 V70 (96-00)	MAINTENANCE	2.4 T5 AWD (99-00)	MANUAL
 V70 (96-00)	MAINTENANCE	2.4 T5 AWD (99-00)	VDO Dashboard
 V70 (96-00)	MAINTENANCE	2.5 TDI (96-00)	
 V70 (96-00)	MAINTENANCE	2.5 TDI (99-00)	MANUAL
 V70 (96-00)	MAINTENANCE	2.5 TDI (99-00)	VDO Dashboard
 V70 (96-00)	SERVICE LIGHT RES	2.0 (96-00)	
 V70 (96-00)	SERVICE LIGHT RES	2.0 (99-00)	MANUAL
 V70 (96-00)	SERVICE LIGHT RES	2.0 T (96-00)	
 V70 (96-00)	SERVICE LIGHT RES	2.0 T (99-00)	MANUAL
 V70 (96-00)	SERVICE LIGHT RES	2.0 T5 (96-00)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 V70 (96-00)	SERVICE LIGHT RES	2.0 T5 (99-00)	MANUAL
 V70 (96-00)	SERVICE LIGHT RES	2.0 T5 AWD (96-00)	
 V70 (96-00)	SERVICE LIGHT RES	2.0 T5 AWD (99-00)	MANUAL
 V70 (96-00)	SERVICE LIGHT RES	2.3 T5 (96-00)	
 V70 (96-00)	SERVICE LIGHT RES	2.3 T5 AWD (96-00)	
 V70 (96-00)	SERVICE LIGHT RES	2.3 T5 AWD (99-00)	MANUAL
 V70 (96-00)	SERVICE LIGHT RES	2.4 T5 AWD (96-00)	
 V70 (96-00)	SERVICE LIGHT RES	2.4 T5 AWD (99-00)	MANUAL
 V70 (96-00)	SERVICE LIGHT RES	2.5 TDI (96-00)	
 V70 (96-00)	SERVICE LIGHT RES	2.5 TDI (99-00)	MANUAL
 V90	AIRBAG	2.5 T (...98)	BOSCH - Autoliv AirBag 6.2
 V90	ENGINE MANAGEME	2.5 T B5254S (...98)	BOSCH Motronic 4.3
 V90	ENGINE MANAGEME	2.5 T B5254S (...98)	BOSCH Motronic 4.4
 V90	IMMOBILIZER	2.5 T (...98)	BOSCH Immobilizer Cartronic 2
 XC60 (08-..)	ABS	2.0 T (08-..)	BCM
 XC60 (08-..)	ABS	2.4 D3 (08-..)	BCM
 XC60 (08-..)	ABS	2.4 D3 AWD (08-..)	BCM
 XC60 (08-..)	ABS	2.4 D5 AWD (08-..)	BCM
 XC60 (08-..)	ABS	DRIVE (08-..)	BCM
 XC60 (08-..)	ABS	T6 AWD (08-..)	BCM
 XC60 (08-..)	AIRBAG	2.0 T (08-..)	SRS AirBag
 XC60 (08-..)	AIRBAG	2.4 D3 (08-..)	SRS AirBag
 XC60 (08-..)	AIRBAG	2.4 D3 AWD (08-..)	SRS AirBag
 XC60 (08-..)	AIRBAG	2.4 D5 AWD (08-..)	SRS AirBag
 XC60 (08-..)	AIRBAG	DRIVE (08-..)	SRS AirBag
 XC60 (08-..)	AIRBAG	T6 AWD (08-..)	SRS AirBag
 XC60 (08-..)	AUTOM. TRANSMISSI	2.0 T (08-..)	TCM
 XC60 (08-..)	AUTOM. TRANSMISSI	2.4 D3 (08-..)	TCM
 XC60 (08-..)	AUTOM. TRANSMISSI	2.4 D3 AWD (08-..)	TCM
 XC60 (08-..)	AUTOM. TRANSMISSI	2.4 D5 AWD (08-..)	TCM
 XC60 (08-..)	AUTOM. TRANSMISSI	DRIVE (08-..)	TCM
 XC60 (08-..)	AUTOM. TRANSMISSI	T6 AWD (08-..)	TCM
 XC60 (08-..)	CHASSIS NETWORK	2.0 T (08-..)	CEM Central Electronic Module
 XC60 (08-..)	CHASSIS NETWORK	2.0 T (08-..)	DIM
 XC60 (08-..)	CHASSIS NETWORK	2.4 D3 (08-..)	CEM Central Electronic Module
 XC60 (08-..)	CHASSIS NETWORK	2.4 D3 (08-..)	DIM
 XC60 (08-..)	CHASSIS NETWORK	2.4 D3 AWD (08-..)	CEM Central Electronic Module
 XC60 (08-..)	CHASSIS NETWORK	2.4 D3 AWD (08-..)	DIM
 XC60 (08-..)	CHASSIS NETWORK	2.4 D5 AWD (08-..)	CEM Central Electronic Module
 XC60 (08-..)	CHASSIS NETWORK	2.4 D5 AWD (08-..)	DIM
 XC60 (08-..)	CHASSIS NETWORK	DRIVE (08-..)	CEM Central Electronic Module
 XC60 (08-..)	CHASSIS NETWORK	DRIVE (08-..)	DIM
 XC60 (08-..)	CHASSIS NETWORK	T6 AWD (08-..)	CEM Central Electronic Module
 XC60 (08-..)	CHASSIS NETWORK	T6 AWD (08-..)	DIM
 XC60 (08-..)	CLIMA	2.0 T (08-..)	CCM NO NAV
 XC60 (08-..)	CLIMA	2.4 D3 (08-..)	CCM NO NAV
 XC60 (08-..)	CLIMA	2.4 D3 AWD (08-..)	CCM NO NAV
 XC60 (08-..)	CLIMA	2.4 D5 AWD (08-..)	CCM NO NAV
 XC60 (08-..)	CLIMA	DRIVE (08-..)	CCM NO NAV
 XC60 (08-..)	CLIMA	T6 AWD (08-..)	CCM NO NAV
 XC60 (08-..)	DRIVER SIDE DOOR	2.0 T (08-..)	DDM
 XC60 (08-..)	DRIVER SIDE DOOR	2.4 D3 (08-..)	DDM
 XC60 (08-..)	DRIVER SIDE DOOR	2.4 D3 AWD (08-..)	DDM
 XC60 (08-..)	DRIVER SIDE DOOR	2.4 D5 AWD (08-..)	DDM
 XC60 (08-..)	DRIVER SIDE DOOR	DRIVE (08-..)	DDM
 XC60 (08-..)	DRIVER SIDE DOOR	T6 AWD (08-..)	DDM
 XC60 (08-..)	ELECTRIC STEERING	2.0 T (08-..)	SAS
 XC60 (08-..)	ELECTRIC STEERING	2.4 D3 (08-..)	SAS

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 XC60 (08-..)	ELECTRIC STEERING	2.4 D3 AWD (08-..)	SAS
 XC60 (08-..)	ELECTRIC STEERING	2.4 D5 AWD (08-..)	SAS
 XC60 (08-..)	ELECTRIC STEERING	DRIVE (08-..)	SAS
 XC60 (08-..)	ELECTRIC STEERING	T6 AWD (08-..)	SAS
 XC60 (08-..)	ENGINE MANAGEME	2.0 T (08-..)	EOBD
 XC60 (08-..)	ENGINE MANAGEME	2.4 D3 (08-..)	ECM
 XC60 (08-..)	ENGINE MANAGEME	2.4 D3 AWD (08-..)	ECM
 XC60 (08-..)	ENGINE MANAGEME	2.4 D5 AWD (08-..)	ECM
 XC60 (08-..)	ENGINE MANAGEME	DRIVE (08-..)	EOBD
 XC60 (08-..)	ENGINE MANAGEME	T6 AWD (08-..)	EOBD
 XC60 (08-..)	MAINTENANCE	2.0 T (08-..)	BCM
 XC60 (08-..)	MAINTENANCE	2.0 T (08-..)	MANUAL
 XC60 (08-..)	MAINTENANCE	2.0 T (08-..)	PBM
 XC60 (08-..)	MAINTENANCE	2.0 T (08-..)	PBM
 XC60 (08-..)	MAINTENANCE	2.0 T (08-..)	PBM
 XC60 (08-..)	MAINTENANCE	2.0 T (08-..)	TCM
 XC60 (08-..)	MAINTENANCE	2.0 T (08-..)	TCM
 XC60 (08-..)	MAINTENANCE	2.0 T (08-..)	TCM
 XC60 (08-..)	MAINTENANCE	2.4 D3 (08-..)	BCM
 XC60 (08-..)	MAINTENANCE	2.4 D3 (08-..)	ECM
 XC60 (08-..)	MAINTENANCE	2.4 D3 (08-..)	MANUAL
 XC60 (08-..)	MAINTENANCE	2.4 D3 (08-..)	PBM
 XC60 (08-..)	MAINTENANCE	2.4 D3 (08-..)	PBM
 XC60 (08-..)	MAINTENANCE	2.4 D3 (08-..)	PBM
 XC60 (08-..)	MAINTENANCE	2.4 D3 (08-..)	TCM
 XC60 (08-..)	MAINTENANCE	2.4 D3 (08-..)	TCM
 XC60 (08-..)	MAINTENANCE	2.4 D3 (08-..)	TCM
 XC60 (08-..)	MAINTENANCE	2.4 D3 AWD (08-..)	BCM
 XC60 (08-..)	MAINTENANCE	2.4 D3 AWD (08-..)	ECM
 XC60 (08-..)	MAINTENANCE	2.4 D3 AWD (08-..)	MANUAL
 XC60 (08-..)	MAINTENANCE	2.4 D3 AWD (08-..)	PBM
 XC60 (08-..)	MAINTENANCE	2.4 D3 AWD (08-..)	PBM
 XC60 (08-..)	MAINTENANCE	2.4 D3 AWD (08-..)	PBM
 XC60 (08-..)	MAINTENANCE	2.4 D3 AWD (08-..)	TCM
 XC60 (08-..)	MAINTENANCE	2.4 D3 AWD (08-..)	TCM
 XC60 (08-..)	MAINTENANCE	2.4 D3 AWD (08-..)	TCM
 XC60 (08-..)	MAINTENANCE	2.4 D5 AWD (08-..)	BCM
 XC60 (08-..)	MAINTENANCE	2.4 D5 AWD (08-..)	ECM
 XC60 (08-..)	MAINTENANCE	2.4 D5 AWD (08-..)	MANUAL
 XC60 (08-..)	MAINTENANCE	2.4 D5 AWD (08-..)	PBM
 XC60 (08-..)	MAINTENANCE	2.4 D5 AWD (08-..)	PBM
 XC60 (08-..)	MAINTENANCE	2.4 D5 AWD (08-..)	PBM
 XC60 (08-..)	MAINTENANCE	2.4 D5 AWD (08-..)	TCM
 XC60 (08-..)	MAINTENANCE	2.4 D5 AWD (08-..)	TCM
 XC60 (08-..)	MAINTENANCE	2.4 D5 AWD (08-..)	TCM
 XC60 (08-..)	MAINTENANCE	DRIVE (08-..)	BCM
 XC60 (08-..)	MAINTENANCE	DRIVE (08-..)	MANUAL
 XC60 (08-..)	MAINTENANCE	DRIVE (08-..)	PBM
 XC60 (08-..)	MAINTENANCE	DRIVE (08-..)	PBM
 XC60 (08-..)	MAINTENANCE	DRIVE (08-..)	PBM
 XC60 (08-..)	MAINTENANCE	DRIVE (08-..)	TCM
 XC60 (08-..)	MAINTENANCE	DRIVE (08-..)	TCM
 XC60 (08-..)	MAINTENANCE	DRIVE (08-..)	TCM
 XC60 (08-..)	MAINTENANCE	T6 AWD (08-..)	BCM
 XC60 (08-..)	MAINTENANCE	T6 AWD (08-..)	MANUAL
 XC60 (08-..)	MAINTENANCE	T6 AWD (08-..)	PBM
 XC60 (08-..)	MAINTENANCE	T6 AWD (08-..)	PBM
 XC60 (08-..)	MAINTENANCE	T6 AWD (08-..)	PBM

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 XC60 (08-..)	MAINTENANCE	T6 AWD (08-..)	TCM
 XC60 (08-..)	MAINTENANCE	T6 AWD (08-..)	TCM
 XC60 (08-..)	MAINTENANCE	T6 AWD (08-..)	TCM
 XC60 (08-..)	PARK.BRAKE	2.0 T (08-..)	PBM
 XC60 (08-..)	PARK.BRAKE	2.4 D3 (08-..)	PBM
 XC60 (08-..)	PARK.BRAKE	2.4 D3 AWD (08-..)	PBM
 XC60 (08-..)	PARK.BRAKE	2.4 D5 AWD (08-..)	PBM
 XC60 (08-..)	PARK.BRAKE	DRIVE (08-..)	PBM
 XC60 (08-..)	PARK.BRAKE	T6 AWD (08-..)	PBM
 XC60 (08-..)	PARKING HELP	2.0 T (08-..)	PAM
 XC60 (08-..)	PARKING HELP	2.4 D3 (08-..)	PAM
 XC60 (08-..)	PARKING HELP	2.4 D3 AWD (08-..)	PAM
 XC60 (08-..)	PARKING HELP	2.4 D5 AWD (08-..)	PAM
 XC60 (08-..)	PARKING HELP	DRIVE (08-..)	PAM
 XC60 (08-..)	PARKING HELP	T6 AWD (08-..)	PAM
 XC60 (08-..)	PASS. SIDE DOOR	2.0 T (08-..)	PDM
 XC60 (08-..)	PASS. SIDE DOOR	2.4 D3 (08-..)	PDM
 XC60 (08-..)	PASS. SIDE DOOR	2.4 D3 AWD (08-..)	PDM
 XC60 (08-..)	PASS. SIDE DOOR	2.4 D5 AWD (08-..)	PDM
 XC60 (08-..)	PASS. SIDE DOOR	DRIVE (08-..)	PDM
 XC60 (08-..)	PASS. SIDE DOOR	T6 AWD (08-..)	PDM
 XC60 (08-..)	PHONE	2.0 T (08-..)	BPM
 XC60 (08-..)	PHONE	2.4 D3 (08-..)	BPM
 XC60 (08-..)	PHONE	2.4 D3 AWD (08-..)	BPM
 XC60 (08-..)	PHONE	2.4 D5 AWD (08-..)	BPM
 XC60 (08-..)	PHONE	DRIVE (08-..)	BPM
 XC60 (08-..)	PHONE	T6 AWD (08-..)	BPM
 XC60 (08-..)	RADIO / CD	2.0 T (08-..)	IAM
 XC60 (08-..)	RADIO / CD	2.4 D3 (08-..)	IAM
 XC60 (08-..)	RADIO / CD	2.4 D3 AWD (08-..)	IAM
 XC60 (08-..)	RADIO / CD	2.4 D5 AWD (08-..)	IAM
 XC60 (08-..)	RADIO / CD	DRIVE (08-..)	IAM
 XC60 (08-..)	RADIO / CD	T6 AWD (08-..)	IAM
 XC60 (08-..)	SERVICE LIGHT RES	2.0 T (08-..)	MANUAL
 XC60 (08-..)	SERVICE LIGHT RES	2.4 D3 (08-..)	MANUAL
 XC60 (08-..)	SERVICE LIGHT RES	2.4 D3 AWD (08-..)	MANUAL
 XC60 (08-..)	SERVICE LIGHT RES	2.4 D5 AWD (08-..)	MANUAL
 XC60 (08-..)	SERVICE LIGHT RES	DRIVE (08-..)	MANUAL
 XC60 (08-..)	SERVICE LIGHT RES	T6 AWD (08-..)	MANUAL
 XC60 (08-..)	VISUAL./TELEMATIC	2.0 T (08-..)	ICM NO NAV
 XC60 (08-..)	VISUAL./TELEMATIC	2.4 D3 (08-..)	ICM NO NAV
 XC60 (08-..)	VISUAL./TELEMATIC	2.4 D3 AWD (08-..)	ICM NO NAV
 XC60 (08-..)	VISUAL./TELEMATIC	2.4 D5 AWD (08-..)	ICM NO NAV
 XC60 (08-..)	VISUAL./TELEMATIC	DRIVE (08-..)	ICM NO NAV
 XC60 (08-..)	VISUAL./TELEMATIC	T6 AWD (08-..)	ICM NO NAV
 XC70 (00-07)	ABS	2.4 D5 AWD (01-04)	BCM Brake Control Module
 XC70 (00-07)	ABS	2.4 D5 AWD (05-07)	BCM Brake Control Module
 XC70 (00-07)	ABS	2.4 T AWD (01-04)	BCM Brake Control Module
 XC70 (00-07)	ABS	2.4 T AWD (05-07)	BCM Brake Control Module
 XC70 (00-07)	ABS	2.5 T AWD (01-04)	BCM Brake Control Module
 XC70 (00-07)	ABS	2.5 T AWD (05-07)	BCM Brake Control Module
 XC70 (00-07)	AIRBAG	2.4 D5 AWD (01-03)	SRS AirBag
 XC70 (00-07)	AIRBAG	2.4 D5 AWD (06-07)	SRS AirBag
 XC70 (00-07)	AIRBAG	2.4 T AWD (01-03)	SRS AirBag
 XC70 (00-07)	AIRBAG	2.4 T AWD (06-07)	SRS AirBag
 XC70 (00-07)	AIRBAG	2.5 T AWD (01-03)	SRS AirBag
 XC70 (00-07)	AIRBAG	2.5 T AWD (06-07)	SRS AirBag
 XC70 (00-07)	CHASSIS NETWORK	2.4 D5 AWD (01-03)	CEM Central Electronic Module

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 XC70 (00-07)	CHASSIS NETWORK	2.4 D5 AWD (01-03)	REM Rear Electronic Module
 XC70 (00-07)	CHASSIS NETWORK	2.4 D5 AWD (06-07)	CEM Central Electronic Module
 XC70 (00-07)	CHASSIS NETWORK	2.4 D5 AWD (06-07)	REM Rear Electronic Module
 XC70 (00-07)	CHASSIS NETWORK	2.4 T AWD (01-03)	CEM Central Electronic Module
 XC70 (00-07)	CHASSIS NETWORK	2.4 T AWD (01-03)	REM Rear Electronic Module
 XC70 (00-07)	CHASSIS NETWORK	2.4 T AWD (06-07)	CEM Central Electronic Module
 XC70 (00-07)	CHASSIS NETWORK	2.4 T AWD (06-07)	REM Rear Electronic Module
 XC70 (00-07)	CHASSIS NETWORK	2.5 T AWD (01-03)	CEM Central Electronic Module
 XC70 (00-07)	CHASSIS NETWORK	2.5 T AWD (01-03)	REM Rear Electronic Module
 XC70 (00-07)	CHASSIS NETWORK	2.5 T AWD (06-07)	CEM Central Electronic Module
 XC70 (00-07)	CHASSIS NETWORK	2.5 T AWD (06-07)	REM Rear Electronic Module
 XC70 (00-07)	CLIMA	2.4 D5 AWD (06-07)	CCM Climate Control Unit
 XC70 (00-07)	CLIMA	2.4 T AWD (06-07)	CCM Climate Control Unit
 XC70 (00-07)	CLIMA	2.5 T AWD (06-07)	CCM Climate Control Unit
 XC70 (00-07)	COLUMN/SEAT REG.	2.4 D5 AWD (06-07)	PSM Power Seat Module
 XC70 (00-07)	COLUMN/SEAT REG.	2.4 T AWD (06-07)	PSM Power Seat Module
 XC70 (00-07)	COLUMN/SEAT REG.	2.5 T AWD (06-07)	PSM Power Seat Module
 XC70 (00-07)	CONV. TOP/SUNROO	2.4 D5 AWD (06-07)	UEM Upper Electronic Module
 XC70 (00-07)	CONV. TOP/SUNROO	2.4 T AWD (06-07)	UEM Upper Electronic Module
 XC70 (00-07)	CONV. TOP/SUNROO	2.5 T AWD (06-07)	UEM Upper Electronic Module
 XC70 (00-07)	DASHBOARD	2.4 D5 AWD (01-03)	DIM Driver Information Module
 XC70 (00-07)	DASHBOARD	2.4 D5 AWD (06-07)	DIM Driver Information Module
 XC70 (00-07)	DASHBOARD	2.4 T AWD (01-03)	DIM Driver Information Module
 XC70 (00-07)	DASHBOARD	2.4 T AWD (06-07)	DIM Driver Information Module
 XC70 (00-07)	DASHBOARD	2.5 T AWD (01-03)	DIM Driver Information Module
 XC70 (00-07)	DASHBOARD	2.5 T AWD (06-07)	DIM Driver Information Module
 XC70 (00-07)	DRIVER SIDE DOOR	2.4 D5 AWD (05-07)	DDM Driver Door Module
 XC70 (00-07)	DRIVER SIDE DOOR	2.4 T AWD (05-07)	DDM Driver Door Module
 XC70 (00-07)	DRIVER SIDE DOOR	2.5 T AWD (05-07)	DDM Driver Door Module
 XC70 (00-07)	ELECTRIC STEERING	2.4 D5 AWD (06-07)	SAS Steering Angle Sensor
 XC70 (00-07)	ELECTRIC STEERING	2.4 T AWD (06-07)	SAS Steering Angle Sensor
 XC70 (00-07)	ELECTRIC STEERING	2.5 T AWD (06-07)	SAS Steering Angle Sensor
 XC70 (00-07)	ENGINE MANAGEME	2.4 D5 AWD D5244T (01-07)	BOSCH EDC Common Rail
 XC70 (00-07)	ENGINE MANAGEME	2.4 D5 AWD D5244T2 (02-07)	BOSCH EDC Common Rail
 XC70 (00-07)	ENGINE MANAGEME	2.4 T AWD (01-07)	EOBD
 XC70 (00-07)	ENGINE MANAGEME	2.5 T AWD (01-07)	EOBD
 XC70 (00-07)	GEARBOX MANAGEM	2.4 D5 AWD (06-07)	TCM Trasmission Control Module
 XC70 (00-07)	GEARBOX MANAGEM	2.4 T AWD (06-07)	TCM Trasmission Control Module
 XC70 (00-07)	GEARBOX MANAGEM	2.5 T AWD (06-07)	TCM Trasmission Control Module
 XC70 (00-07)	MAINTENANCE	2.4 D5 AWD (00-07)	MANUAL
 XC70 (00-07)	MAINTENANCE	2.4 T AWD (00-07)	MANUAL
 XC70 (00-07)	MAINTENANCE	2.4 T AWD (02-07)	MANUAL
 XC70 (00-07)	MAINTENANCE	2.5 T AWD (00-07)	MANUAL
 XC70 (00-07)	MAINTENANCE	2.5 T AWD (02-07)	MANUAL
 XC70 (00-07)	NAVIGATION	2.4 D5 AWD (01-04)	RTI Road Traffic Information
 XC70 (00-07)	NAVIGATION	2.4 T AWD (01-04)	RTI Road Traffic Information
 XC70 (00-07)	NAVIGATION	2.5 T AWD (01-04)	RTI Road Traffic Information
 XC70 (00-07)	PASS. SIDE DOOR	2.4 D5 AWD (06-07)	PDM Passenger Door Module
 XC70 (00-07)	PASS. SIDE DOOR	2.4 T AWD (06-07)	PDM Passenger Door Module
 XC70 (00-07)	PASS. SIDE DOOR	2.5 T AWD (06-07)	PDM Passenger Door Module
 XC70 (00-07)	RADIO / CD	2.4 D5 AWD (01-03)	AUM Audio Module
 XC70 (00-07)	RADIO / CD	2.4 D5 AWD (06-07)	ACM Audio Module
 XC70 (00-07)	RADIO / CD	2.4 T AWD (01-03)	AUM Audio Module
 XC70 (00-07)	RADIO / CD	2.4 T AWD (06-07)	ACM Audio Module
 XC70 (00-07)	RADIO / CD	2.5 T AWD (01-03)	AUM Audio Module
 XC70 (00-07)	RADIO / CD	2.5 T AWD (06-07)	ACM Audio Module
 XC70 (00-07)	SERVICE LIGHT RES	2.4 D5 AWD (00-07)	MANUAL
 XC70 (00-07)	SERVICE LIGHT RES	2.4 T AWD (00-07)	MANUAL

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 XC70 (00-07)	SERVICE LIGHT RES	2.4 T AWD (02-07)	MANUAL
 XC70 (00-07)	SERVICE LIGHT RES	2.5 T AWD (00-07)	MANUAL
 XC70 (00-07)	SERVICE LIGHT RES	2.5 T AWD (02-07)	MANUAL
 XC70 (00-07)	STEERING WHEEL E	2.4 D5 AWD (01-04)	SWM Steering Wheel Module
 XC70 (00-07)	STEERING WHEEL E	2.4 T AWD (01-04)	SWM Steering Wheel Module
 XC70 (00-07)	STEERING WHEEL E	2.5 T AWD (01-04)	SWM Steering Wheel Module
 XC70 (00-07)	VISUAL./TELEMATIC	2.4 D5 AWD (06-07)	ICM Infotainment Control Module
 XC70 (00-07)	VISUAL./TELEMATIC	2.4 T AWD (06-07)	ICM Infotainment Control Module
 XC70 (00-07)	VISUAL./TELEMATIC	2.5 T AWD (06-07)	ICM Infotainment Control Module
 XC90 (02-..)	ABS	2.4 D5 AWD (02-03)	BCM Brake Control Module
 XC90 (02-..)	ABS	2.5 T AWD (02-03)	BCM Brake Control Module
 XC90 (02-..)	ABS	2.9 T6 AWD (02-03)	BCM Brake Control Module
 XC90 (02-..)	ABS	3.2 AWD (02-03)	BCM Brake Control Module
 XC90 (02-..)	ABS	4.4 V8 AWD (02-03)	BCM Brake Control Module
 XC90 (02-..)	AIRBAG	2.4 D5 AWD (02-03)	SRS AirBag
 XC90 (02-..)	AIRBAG	2.4 D5 AWD (06-07)	SRS AirBag
 XC90 (02-..)	AIRBAG	2.5 T AWD (02-03)	SRS AirBag
 XC90 (02-..)	AIRBAG	2.5 T AWD (06-07)	SRS AirBag
 XC90 (02-..)	AIRBAG	2.9 T6 AWD (02-03)	SRS AirBag
 XC90 (02-..)	AIRBAG	2.9 T6 AWD (06-07)	SRS AirBag
 XC90 (02-..)	AIRBAG	3.2 AWD (02-03)	SRS AirBag
 XC90 (02-..)	AIRBAG	3.2 AWD (06-07)	SRS AirBag
 XC90 (02-..)	AIRBAG	4.4 V8 AWD (02-03)	SRS AirBag
 XC90 (02-..)	AIRBAG	4.4 V8 AWD (06-07)	SRS AirBag
 XC90 (02-..)	CHASSIS NETWORK	2.4 D5 AWD (02-03)	CEM Central Electronic Module
 XC90 (02-..)	CHASSIS NETWORK	2.4 D5 AWD (02-03)	REM Rear Electronic Module
 XC90 (02-..)	CHASSIS NETWORK	2.4 D5 AWD (06-07)	CEM Central Electronic Module
 XC90 (02-..)	CHASSIS NETWORK	2.4 D5 AWD (06-07)	REM Rear Electronic Module
 XC90 (02-..)	CHASSIS NETWORK	2.5 T AWD (02-03)	CEM Central Electronic Module
 XC90 (02-..)	CHASSIS NETWORK	2.5 T AWD (02-03)	REM Rear Electronic Module
 XC90 (02-..)	CHASSIS NETWORK	2.5 T AWD (06-07)	CEM Central Electronic Module
 XC90 (02-..)	CHASSIS NETWORK	2.5 T AWD (06-07)	REM Rear Electronic Module
 XC90 (02-..)	CHASSIS NETWORK	2.9 T6 AWD (02-03)	CEM Central Electronic Module
 XC90 (02-..)	CHASSIS NETWORK	2.9 T6 AWD (02-03)	REM Rear Electronic Module
 XC90 (02-..)	CHASSIS NETWORK	2.9 T6 AWD (06-07)	CEM Central Electronic Module
 XC90 (02-..)	CHASSIS NETWORK	2.9 T6 AWD (06-07)	REM Rear Electronic Module
 XC90 (02-..)	CHASSIS NETWORK	3.2 AWD (02-03)	CEM Central Electronic Module
 XC90 (02-..)	CHASSIS NETWORK	3.2 AWD (02-03)	REM Rear Electronic Module
 XC90 (02-..)	CHASSIS NETWORK	3.2 AWD (06-07)	CEM Central Electronic Module
 XC90 (02-..)	CHASSIS NETWORK	3.2 AWD (06-07)	REM Rear Electronic Module
 XC90 (02-..)	CHASSIS NETWORK	4.4 V8 AWD (02-03)	CEM Central Electronic Module
 XC90 (02-..)	CHASSIS NETWORK	4.4 V8 AWD (02-03)	REM Rear Electronic Module
 XC90 (02-..)	CHASSIS NETWORK	4.4 V8 AWD (06-07)	CEM Central Electronic Module
 XC90 (02-..)	CHASSIS NETWORK	4.4 V8 AWD (06-07)	REM Rear Electronic Module
 XC90 (02-..)	CLIMA	2.4 D5 AWD (06-07)	CCM Climate Control Unit
 XC90 (02-..)	CLIMA	2.5 T AWD (06-07)	CCM Climate Control Unit
 XC90 (02-..)	CLIMA	2.9 T6 AWD (06-07)	CCM Climate Control Unit
 XC90 (02-..)	CLIMA	3.2 AWD (06-07)	CCM Climate Control Unit
 XC90 (02-..)	CLIMA	4.4 V8 AWD (06-07)	CCM Climate Control Unit
 XC90 (02-..)	COLUMN/SEAT REG.	2.4 D5 AWD (06-07)	PSM Power Seat Module
 XC90 (02-..)	COLUMN/SEAT REG.	2.5 T AWD (06-07)	PSM Power Seat Module
 XC90 (02-..)	COLUMN/SEAT REG.	2.9 T6 AWD (06-07)	PSM Power Seat Module
 XC90 (02-..)	COLUMN/SEAT REG.	3.2 AWD (06-07)	PSM Power Seat Module
 XC90 (02-..)	COLUMN/SEAT REG.	4.4 V8 AWD (06-07)	PSM Power Seat Module
 XC90 (02-..)	CONV. TOP/SUNROO	2.4 D5 AWD (06-07)	UEM Upper Electronic Module
 XC90 (02-..)	CONV. TOP/SUNROO	2.5 T AWD (06-07)	UEM Upper Electronic Module
 XC90 (02-..)	CONV. TOP/SUNROO	2.9 T6 AWD (06-07)	UEM Upper Electronic Module
 XC90 (02-..)	CONV. TOP/SUNROO	3.2 AWD (06-07)	UEM Upper Electronic Module

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 XC90 (02-..)	CONV. TOP/SUNROO	4.4 V8 AWD (06-07)	UEM Upper Electronic Module
 XC90 (02-..)	DASHBOARD	2.4 D5 AWD (02-03)	DIM Driver Information Module
 XC90 (02-..)	DASHBOARD	2.4 D5 AWD (06-07)	DIM Driver Information Module
 XC90 (02-..)	DASHBOARD	2.5 T AWD (02-03)	DIM Driver Information Module
 XC90 (02-..)	DASHBOARD	2.5 T AWD (06-07)	DIM Driver Information Module
 XC90 (02-..)	DASHBOARD	2.9 T6 AWD (02-03)	DIM Driver Information Module
 XC90 (02-..)	DASHBOARD	2.9 T6 AWD (06-07)	DIM Driver Information Module
 XC90 (02-..)	DASHBOARD	3.2 AWD (02-03)	DIM Driver Information Module
 XC90 (02-..)	DASHBOARD	3.2 AWD (06-07)	DIM Driver Information Module
 XC90 (02-..)	DASHBOARD	4.4 V8 AWD (02-03)	DIM Driver Information Module
 XC90 (02-..)	DASHBOARD	4.4 V8 AWD (06-07)	DIM Driver Information Module
 XC90 (02-..)	DIFFERENTIAL MANA	2.4 D5 AWD (02-03)	DEM Differenzial Electronic Module
 XC90 (02-..)	DIFFERENTIAL MANA	2.5 T AWD (02-03)	DEM Differenzial Electronic Module
 XC90 (02-..)	DIFFERENTIAL MANA	2.9 T6 AWD (02-03)	DEM Differenzial Electronic Module
 XC90 (02-..)	DIFFERENTIAL MANA	3.2 AWD (02-03)	DEM Differenzial Electronic Module
 XC90 (02-..)	DIFFERENTIAL MANA	4.4 V8 AWD (02-03)	DEM Differenzial Electronic Module
 XC90 (02-..)	DRIVER SIDE DOOR	2.4 D5 AWD (06-07)	DDM Driver Door Module
 XC90 (02-..)	DRIVER SIDE DOOR	2.5 T AWD (06-07)	DDM Driver Door Module
 XC90 (02-..)	DRIVER SIDE DOOR	2.9 T6 AWD (06-07)	DDM Driver Door Module
 XC90 (02-..)	DRIVER SIDE DOOR	3.2 AWD (06-07)	DDM Driver Door Module
 XC90 (02-..)	DRIVER SIDE DOOR	4.4 V8 AWD (06-07)	DDM Driver Door Module
 XC90 (02-..)	ELECTRIC STEERING	2.4 D5 AWD (06-07)	SAS Steering Angle Sensor
 XC90 (02-..)	ELECTRIC STEERING	2.5 T AWD (06-07)	SAS Steering Angle Sensor
 XC90 (02-..)	ELECTRIC STEERING	2.9 T6 AWD (06-07)	SAS Steering Angle Sensor
 XC90 (02-..)	ELECTRIC STEERING	3.2 AWD (06-07)	SAS Steering Angle Sensor
 XC90 (02-..)	ELECTRIC STEERING	4.4 V8 AWD (06-07)	SAS Steering Angle Sensor
 XC90 (02-..)	ENGINE MANAGEME	2.4 D5 AWD D5244T (02-07)	BOSCH EDC Common Rail
 XC90 (02-..)	ENGINE MANAGEME	2.4 D5 AWD D5244T4 (08-..)	ECM Common Rail
 XC90 (02-..)	ENGINE MANAGEME	2.5 T AWD (02-..)	EOBD
 XC90 (02-..)	ENGINE MANAGEME	2.9 T6 AWD (02-..)	EOBD
 XC90 (02-..)	ENGINE MANAGEME	3.2 AWD (02-..)	EOBD
 XC90 (02-..)	ENGINE MANAGEME	4.4 V8 AWD (02-..)	EOBD
 XC90 (02-..)	GEARBOX MANAGEM	2.4 D5 AWD (06-07)	TCM Trasmission Control Module
 XC90 (02-..)	GEARBOX MANAGEM	2.5 T AWD (06-07)	TCM Trasmission Control Module
 XC90 (02-..)	GEARBOX MANAGEM	2.9 T6 AWD (06-07)	TCM Trasmission Control Module
 XC90 (02-..)	GEARBOX MANAGEM	3.2 AWD (06-07)	TCM Trasmission Control Module
 XC90 (02-..)	GEARBOX MANAGEM	4.4 V8 AWD (06-07)	TCM Trasmission Control Module
 XC90 (02-..)	MAINTENANCE	2.4 D5 AWD (01-..)	MANUAL
 XC90 (02-..)	MAINTENANCE	2.5 T AWD (01-..)	MANUAL
 XC90 (02-..)	MAINTENANCE	2.9 T6 AWD (01-..)	MANUAL
 XC90 (02-..)	MAINTENANCE	3.2 AWD (01-..)	MANUAL
 XC90 (02-..)	MAINTENANCE	4.4 V8 AWD (01-..)	MANUAL
 XC90 (02-..)	NAVIGATION	2.4 D5 AWD (02-04)	RTI Road Traffic Information
 XC90 (02-..)	NAVIGATION	2.5 T AWD (02-04)	RTI Road Traffic Information
 XC90 (02-..)	NAVIGATION	2.9 T6 AWD (02-04)	RTI Road Traffic Information
 XC90 (02-..)	NAVIGATION	3.2 AWD (02-04)	RTI Road Traffic Information
 XC90 (02-..)	NAVIGATION	4.4 V8 AWD (02-04)	RTI Road Traffic Information
 XC90 (02-..)	PASS. SIDE DOOR	2.4 D5 AWD (06-07)	PDM Passenger Door Module
 XC90 (02-..)	PASS. SIDE DOOR	2.5 T AWD (06-07)	PDM Passenger Door Module
 XC90 (02-..)	PASS. SIDE DOOR	2.9 T6 AWD (06-07)	PDM Passenger Door Module
 XC90 (02-..)	PASS. SIDE DOOR	3.2 AWD (06-07)	PDM Passenger Door Module
 XC90 (02-..)	PASS. SIDE DOOR	4.4 V8 AWD (06-07)	PDM Passenger Door Module
 XC90 (02-..)	RADIO / CD	2.4 D5 AWD (02-..)	AUM Audio Module
 XC90 (02-..)	RADIO / CD	2.4 D5 AWD (06-07)	ACM Audio Module
 XC90 (02-..)	RADIO / CD	2.4 D5 AWD (08-..)	IAM Integrate Audio Module
 XC90 (02-..)	RADIO / CD	2.5 T AWD (02-..)	AUM Audio Module
 XC90 (02-..)	RADIO / CD	2.5 T AWD (06-07)	ACM Audio Module
 XC90 (02-..)	RADIO / CD	2.5 T AWD (08-..)	IAM Integrate Audio Module

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 XC90 (02-..)	RADIO / CD	2.9 T6 AWD (02-..)	AUM Audio Module
 XC90 (02-..)	RADIO / CD	2.9 T6 AWD (06-07)	ACM Audio Module
 XC90 (02-..)	RADIO / CD	2.9 T6 AWD (08-..)	IAM Integrate Audio Module
 XC90 (02-..)	RADIO / CD	3.2 AWD (02-..)	AUM Audio Module
 XC90 (02-..)	RADIO / CD	3.2 AWD (06-07)	ACM Audio Module
 XC90 (02-..)	RADIO / CD	3.2 AWD (08-..)	IAM Integrate Audio Module
 XC90 (02-..)	RADIO / CD	4.4 V8 AWD (02-..)	AUM Audio Module
 XC90 (02-..)	RADIO / CD	4.4 V8 AWD (06-07)	ACM Audio Module
 XC90 (02-..)	RADIO / CD	4.4 V8 AWD (08-..)	IAM Integrate Audio Module
 XC90 (02-..)	SERVICE LIGHT RES	2.4 D5 AWD (01-..)	MANUAL
 XC90 (02-..)	SERVICE LIGHT RES	2.5 T AWD (01-..)	MANUAL
 XC90 (02-..)	SERVICE LIGHT RES	2.9 T6 AWD (01-..)	MANUAL
 XC90 (02-..)	SERVICE LIGHT RES	3.2 AWD (01-..)	MANUAL
 XC90 (02-..)	SERVICE LIGHT RES	4.4 V8 AWD (01-..)	MANUAL
 XC90 (02-..)	STEERING WHEEL E	2.4 D5 AWD (02-04)	SWM Steering Wheel Module
 XC90 (02-..)	STEERING WHEEL E	2.5 T AWD (02-04)	SWM Steering Wheel Module
 XC90 (02-..)	STEERING WHEEL E	2.9 T6 AWD (02-04)	SWM Steering Wheel Module
 XC90 (02-..)	STEERING WHEEL E	3.2 AWD (02-04)	SWM Steering Wheel Module
 XC90 (02-..)	STEERING WHEEL E	4.4 V8 AWD (02-04)	SWM Steering Wheel Module
 XC90 (02-..)	VISUAL./TELEMATIC	2.4 D5 AWD (06-07)	ICM Infotainment Control Module
 XC90 (02-..)	VISUAL./TELEMATIC	2.5 T AWD (06-07)	ICM Infotainment Control Module
 XC90 (02-..)	VISUAL./TELEMATIC	2.9 T6 AWD (06-07)	ICM Infotainment Control Module
 XC90 (02-..)	VISUAL./TELEMATIC	3.2 AWD (06-07)	ICM Infotainment Control Module
 XC90 (02-..)	VISUAL./TELEMATIC	4.4 V8 AWD (06-07)	ICM Infotainment Control Module

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

VW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Beetle (5C) (11-..)	AIRBAG	(11-..)	
 Beetle (5C) (11-..)	AUTOM. TRANSMISSI	(11-..)	
 Beetle (5C) (11-..)	CLIMA	(11-..)	
 Beetle (5C) (11-..)	DASHBOARD	(11-..)	
 Beetle (5C) (11-..)	MAINTENANCE	(11-..)	
 Beetle (5C) (11-..)	MAINTENANCE	(11-..)	
 Beetle (5C) (11-..)	SOUND SYSTEM	(11-..)	
 Bora (1J) (99-05)	4WD ELECTRONICS	(..-05)	
 Bora (1J) (99-05)	ABS	(..-05)	
 Bora (1J) (99-05)	ABS	(..-05)	ATE TEVES Mk60 No ASR
 Bora (1J) (99-05)	AIRBAG	(..-05)	
 Bora (1J) (99-05)	AUTOM. TRANSMISSI	(..-05)	
 Bora (1J) (99-05)	CENTRAL LOCKING	(..-05)	
 Bora (1J) (99-05)	CHASSIS NETWORK	(..-05)	
 Bora (1J) (99-05)	CLIMA	(..-05)	
 Bora (1J) (99-05)	COMFORT SYSTEM	(..-05)	
 Bora (1J) (99-05)	DASHBOARD	(..-05)	
 Bora (1J) (99-05)	DRIVER SEAT CONT	(..-05)	
 Bora (1J) (99-05)	EMERGENCY CALL	(..-05)	
 Bora (1J) (99-05)	ENGINE MANAGEME	(..-05)	
 Bora (1J) (99-05)	ENGINE MANAGEME	(..-05)	
 Bora (1J) (99-05)	ENGINE MANAGEME	(..-05)	
 Bora (1J) (99-05)	HEADLIGHT LEVEL	(..-05)	
 Bora (1J) (99-05)	LH RIGHT MODULATI	(..-05)	
 Bora (1J) (99-05)	MAINTENANCE	(..-05)	
 Bora (1J) (99-05)	MAINTENANCE	(..-05)	
 Bora (1J) (99-05)	MAINTENANCE	(..-05)	
 Bora (1J) (99-05)	MAINTENANCE	(..-05)	
 Bora (1J) (99-05)	MAINTENANCE	(..-05)	ATE TEVES Mk60 No ASR
 Bora (1J) (99-05)	MAINTENANCE	(..-05)	MANUAL
 Bora (1J) (99-05)	MAINTENANCE	(99-99)	MANUAL
 Bora (1J) (99-05)	NAVIGATION	(..-05)	
 Bora (1J) (99-05)	PARKING HELP	(..-05)	
 Bora (1J) (99-05)	RADIO / CD	(..-05)	
 Bora (1J) (99-05)	REMOTE CONTROL E	(..-05)	MANUAL
 Bora (1J) (99-05)	RH LIGHT MODULATI	(..-05)	
 Bora (1J) (99-05)	SERVICE LIGHT RES	(..-05)	
 Bora (1J) (99-05)	SERVICE LIGHT RES	(99-99)	MANUAL
 Bora (1J) (99-05)	SOUND SYSTEM	(..-05)	
 Bora (1J) (99-05)	STEERING WHEEL E	(..-05)	
 Bora (1J) (99-05)	TV SYSTEM	(..-05)	
 Caddy (2K) (04-..)	ABS	(04-10)	
 Caddy (2K) (04-..)	AIRBAG	(04-10)	
 Caddy (2K) (04-..)	AUTOM. TRANSMISSI	(04-10)	
 Caddy (2K) (04-..)	AUX. HEATING	(04-10)	CAN Gateway
 Caddy (2K) (04-..)	CENTRAL ELECTRIC	(04-10)	
 Caddy (2K) (04-..)	CHASSIS NETWORK	(04-10)	CAN Gateway
 Caddy (2K) (04-..)	CLIMA	(04-10)	
 Caddy (2K) (04-..)	COMFORT SYSTEM	(04-10)	
 Caddy (2K) (04-..)	DASHBOARD	(04-10)	
 Caddy (2K) (04-..)	DRIVER SIDE DOOR	(04-10)	CAN Gateway
 Caddy (2K) (04-..)	ELECTRIC STEERING	(04-10)	
 Caddy (2K) (04-..)	ENGINE MANAGEME	(04-10)	CAN
 Caddy (2K) (04-..)	ENGINE MANAGEME	1.9 TDI BKC (04-10)	
 Caddy (2K) (04-..)	HEADLIGHT LEVEL	(04-10)	CAN Gateway
 Caddy (2K) (04-..)	IMMOBILIZER	(04-10)	
 Caddy (2K) (04-..)	MAINTENANCE	(04-10)	
 Caddy (2K) (04-..)	MAINTENANCE	(04-10)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

VW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Caddy (2K) (04-..)	MAINTENANCE	(04-10)	
 Caddy (2K) (04-..)	MAINTENANCE	(04-10)	
 Caddy (2K) (04-..)	MAINTENANCE	(04-10)	CAN
 Caddy (2K) (04-..)	MAINTENANCE	(04-10)	CAN
 Caddy (2K) (04-..)	MAINTENANCE	(04-10)	CAN
 Caddy (2K) (04-..)	MAINTENANCE	(04-10)	CAN
 Caddy (2K) (04-..)	MAINTENANCE	(04-10)	CAN
 Caddy (2K) (04-..)	MAINTENANCE	(04-10)	CAN Gateway
 Caddy (2K) (04-..)	MAINTENANCE	(04-10)	CAN Gateway
 Caddy (2K) (04-..)	MAINTENANCE	(04-10)	MANUAL
 Caddy (2K) (04-..)	MAINTENANCE	(04-10)	NO CAN
 Caddy (2K) (04-..)	MAINTENANCE	1.9 TDI BKC (04-10)	
 Caddy (2K) (04-..)	NAVIGATION	(04-10)	CAN Gateway
 Caddy (2K) (04-..)	PASS. SIDE DOOR	(04-10)	CAN Gateway
 Caddy (2K) (04-..)	PHONE	(04-10)	CAN Gateway
 Caddy (2K) (04-..)	RADIO / CD	(04-10)	
 Caddy (2K) (04-..)	SERVICE LIGHT RES	(04-10)	CAN
 Caddy (2K) (04-..)	SERVICE LIGHT RES	(04-10)	MANUAL
 Caddy (2K) (04-..)	SERVICE LIGHT RES	(04-10)	NO CAN
 Caddy (2K) (04-..)	STEERING WHEEL E	(04-10)	
 Caddy (2K) (04-..)	SUPP HEATER/AUTO	(04-10)	
 Caddy (2K) (04-..)	TRANSPORT MODALI	(04-10)	
 Caddy (9K) (96-03)	AIRBAG	(..-03)	
 Caddy (9K) (96-03)	ENGINE MANAGEME	(..-03)	
 Caddy (9K) (96-03)	ENGINE MANAGEME	(..-03)	
 Caddy (9K) (96-03)	ENGINE MANAGEME	(..-03)	
 Caddy (9K) (96-03)	IMMOBILIZER	(..-03)	
 Caddy (9K) (96-03)	MAINTENANCE	(93-96)	MANUAL
 Caddy (9K) (96-03)	MAINTENANCE	(97-98)	MANUAL
 Caddy (9K) (96-03)	SERVICE LIGHT RES	(93-96)	MANUAL
 Caddy (9K) (96-03)	SERVICE LIGHT RES	(97-98)	MANUAL
 Corrado (50) (89-95)	ABS	(..-95)	
 Corrado (50) (89-95)	AIRBAG	(..-95)	
 Corrado (50) (89-95)	CENTRAL LOCKING	(..-95)	
 Corrado (50) (89-95)	CLIMA	(..-95)	
 Corrado (50) (89-95)	CONV. TOP/SUNROO	(..-95)	
 Corrado (50) (89-95)	ENGINE MANAGEME	(..-95)	
 Corrado (50) (89-95)	ENGINE MANAGEME	(..-95)	
 Corrado (50) (89-95)	ENGINE MANAGEME	(..-95)	
 Corrado (50) (89-95)	IMMOBILIZER	(..-95)	
 Corrado (50) (89-95)	MAINTENANCE	(..-95)	
 Corrado (50) (89-95)	MAINTENANCE	(..-95)	
 Corrado (50) (89-95)	MAINTENANCE	(..-95)	
 Corrado (50) (89-95)	MAINTENANCE	(93-95)	MANUAL
 Corrado (50) (89-95)	SERVICE LIGHT RES	(93-95)	MANUAL
 Crafter (2E-2F) (06-..)	ABS + TRACT. CONT	2.5 TDI 109cv (06-10)	
 Crafter (2E-2F) (06-..)	ABS + TRACT. CONT	2.5 TDI 130cv (06-10)	
 Crafter (2E-2F) (06-..)	ABS + TRACT. CONT	2.5 TDI 164cv (06-10)	
 Crafter (2E-2F) (06-..)	ABS + TRACT. CONT	2.5 TDI 89cv (06-10)	
 Crafter (2E-2F) (06-..)	AIRBAG	2.5 TDI 109cv (06-10)	
 Crafter (2E-2F) (06-..)	AIRBAG	2.5 TDI 130cv (06-10)	
 Crafter (2E-2F) (06-..)	AIRBAG	2.5 TDI 164cv (06-10)	
 Crafter (2E-2F) (06-..)	AIRBAG	2.5 TDI 89cv (06-10)	
 Crafter (2E-2F) (06-..)	AUTOM. TRANSMISSI	2.5 TDI 109cv (06-10)	
 Crafter (2E-2F) (06-..)	AUTOM. TRANSMISSI	2.5 TDI 130cv (06-10)	
 Crafter (2E-2F) (06-..)	AUTOM. TRANSMISSI	2.5 TDI 164cv (06-10)	
 Crafter (2E-2F) (06-..)	AUTOM. TRANSMISSI	2.5 TDI 89cv (06-10)	
 Crafter (2E-2F) (06-..)	DASHBOARD	2.5 TDI 109cv (06-10)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

VW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Crafter (2E-2F) (06-..)	DASHBOARD	2.5 TDI 130cv (06-10)	
 Crafter (2E-2F) (06-..)	DASHBOARD	2.5 TDI 164cv (06-10)	
 Crafter (2E-2F) (06-..)	DASHBOARD	2.5 TDI 89cv (06-10)	
 Crafter (2E-2F) (06-..)	ENGINE MANAGEME	2.5 TDI 109cv (06-10)	
 Crafter (2E-2F) (06-..)	ENGINE MANAGEME	2.5 TDI 130cv (06-10)	
 Crafter (2E-2F) (06-..)	ENGINE MANAGEME	2.5 TDI 164cv (06-10)	
 Crafter (2E-2F) (06-..)	ENGINE MANAGEME	2.5 TDI 89cv (06-10)	
 Crafter (2E-2F) (06-..)	MAINTENANCE	2.5 TDI 109cv (06-10)	MANUAL
 Crafter (2E-2F) (06-..)	MAINTENANCE	2.5 TDI 130cv (06-10)	MANUAL
 Crafter (2E-2F) (06-..)	MAINTENANCE	2.5 TDI 164cv (06-10)	MANUAL
 Crafter (2E-2F) (06-..)	MAINTENANCE	2.5 TDI 89cv (06-10)	MANUAL
 Crafter (2E-2F) (06-..)	SERVICE LIGHT RES	2.5 TDI 109cv (06-10)	MANUAL
 Crafter (2E-2F) (06-..)	SERVICE LIGHT RES	2.5 TDI 130cv (06-10)	MANUAL
 Crafter (2E-2F) (06-..)	SERVICE LIGHT RES	2.5 TDI 164cv (06-10)	MANUAL
 Crafter (2E-2F) (06-..)	SERVICE LIGHT RES	2.5 TDI 89cv (06-10)	MANUAL
 Fox (5Z) (05-..)	ABS	(05-10)	
 Fox (5Z) (05-..)	AIRBAG	(05-10)	
 Fox (5Z) (05-..)	AUTOM. TRANSMISSI	(05-10)	
 Fox (5Z) (05-..)	CENTRAL ELECTRIC	(05-10)	
 Fox (5Z) (05-..)	CHASSIS NETWORK	(05-10)	
 Fox (5Z) (05-..)	CLIMA	(05-10)	
 Fox (5Z) (05-..)	COMFORT SYSTEM	(05-10)	
 Fox (5Z) (05-..)	DASHBOARD	(05-10)	
 Fox (5Z) (05-..)	ELECTRIC STEERING	(05-10)	
 Fox (5Z) (05-..)	ENGINE MANAGEME	(05-10)	
 Fox (5Z) (05-..)	ENGINE MANAGEME	(05-10)	
 Fox (5Z) (05-..)	ENGINE MANAGEME	(05-10)	
 Fox (5Z) (05-..)	ENGINE MANAGEME	(05-10)	
 Fox (5Z) (05-..)	MAINTENANCE	(05-10)	
 Fox (5Z) (05-..)	MAINTENANCE	(05-10)	
 Fox (5Z) (05-..)	MAINTENANCE	(05-10)	
 Fox (5Z) (05-..)	MAINTENANCE	(05-10)	
 Fox (5Z) (05-..)	RADIO / CD	(05-10)	
 Golf III (1E-1H) (92-97)	ABS	(..-6/98)	
 Golf III (1E-1H) (92-97)	AIRBAG	(..-6/98)	
 Golf III (1E-1H) (92-97)	AUTOM. TRANSMISSI	(..-6/98)	
 Golf III (1E-1H) (92-97)	CLIMA	(..-6/98)	
 Golf III (1E-1H) (92-97)	CLUTCH ELECTRONI	(..-6/98)	
 Golf III (1E-1H) (92-97)	ENGINE MANAGEME	(..-6/98)	
 Golf III (1E-1H) (92-97)	ENGINE MANAGEME	(..-6/98)	
 Golf III (1E-1H) (92-97)	ENGINE MANAGEME	(..-6/98)	
 Golf III (1E-1H) (92-97)	IMMOBILIZER	(..-6/98)	
 Golf III (1E-1H) (92-97)	MAINTENANCE	(..-6/98)	
 Golf III (1E-1H) (92-97)	MAINTENANCE	(..-6/98)	
 Golf III (1E-1H) (92-97)	MAINTENANCE	(93-96)	MANUAL
 Golf III (1E-1H) (92-97)	MAINTENANCE	(97-98)	MANUAL
 Golf III (1E-1H) (92-97)	RADIO / CD	(..-6/98)	
 Golf III (1E-1H) (92-97)	SERVICE LIGHT RES	(93-96)	MANUAL
 Golf III (1E-1H) (92-97)	SERVICE LIGHT RES	(97-98)	MANUAL
 Golf IV (1J) (98-04)	4WD ELECTRONICS	(..-04)	
 Golf IV (1J) (98-04)	ABS	(..-04)	
 Golf IV (1J) (98-04)	ABS	(..-04)	ATE TEVES Mk60 No ASR
 Golf IV (1J) (98-04)	AIRBAG	(..-04)	
 Golf IV (1J) (98-04)	AUTOM. TRANSMISSI	(..-04)	
 Golf IV (1J) (98-04)	CENTRAL LOCKING	(..-04)	
 Golf IV (1J) (98-04)	CHASSIS NETWORK	(..-04)	
 Golf IV (1J) (98-04)	CLIMA	(..-04)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

VW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Golf IV (1J) (98-04)	COMFORT SYSTEM	(..-04)	
 Golf IV (1J) (98-04)	DASHBOARD	(..-04)	
 Golf IV (1J) (98-04)	DRIVER SEAT CONT	(..-04)	
 Golf IV (1J) (98-04)	ELECTRIC ACTUATIO	(..-04)	
 Golf IV (1J) (98-04)	EMERGENCY CALL	(..-04)	
 Golf IV (1J) (98-04)	ENGINE MANAGEME	(..-04)	
 Golf IV (1J) (98-04)	ENGINE MANAGEME	(..-04)	
 Golf IV (1J) (98-04)	ENGINE MANAGEME	(..-04)	
 Golf IV (1J) (98-04)	HEADLIGHT LEVEL	(..-04)	
 Golf IV (1J) (98-04)	IMMOBILIZER	(..-04)	
 Golf IV (1J) (98-04)	LH RIGHT MODULATI	(..-04)	
 Golf IV (1J) (98-04)	MAINTENANCE	(..-04)	
 Golf IV (1J) (98-04)	MAINTENANCE	(..-04)	
 Golf IV (1J) (98-04)	MAINTENANCE	(..-04)	
 Golf IV (1J) (98-04)	MAINTENANCE	(..-04)	
 Golf IV (1J) (98-04)	MAINTENANCE	(..-04)	ATE TEVES Mk60 No ASR
 Golf IV (1J) (98-04)	MAINTENANCE	(..-04)	ATE TEVES Mk60 No ASR
 Golf IV (1J) (98-04)	MAINTENANCE	(..-04)	ATE TEVES Mk60 No ASR
 Golf IV (1J) (98-04)	MAINTENANCE	(..-04)	ATE TEVES Mk60 No ASR
 Golf IV (1J) (98-04)	MAINTENANCE	(..-04)	ATE TEVES Mk60 No ASR
 Golf IV (1J) (98-04)	MAINTENANCE	(..-04)	MANUAL
 Golf IV (1J) (98-04)	MAINTENANCE	(..-5/99)	(no trip comp.)
 Golf IV (1J) (98-04)	MAINTENANCE	(..-98)	MANUAL
 Golf IV (1J) (98-04)	PARKING HELP	(..-04)	
 Golf IV (1J) (98-04)	POWER BRAKE	(..-04)	
 Golf IV (1J) (98-04)	RADIO / CD	(..-04)	
 Golf IV (1J) (98-04)	REMOTE CONTROL E	(..-04)	MANUAL
 Golf IV (1J) (98-04)	RH LIGHT MODULATI	(..-04)	
 Golf IV (1J) (98-04)	SERVICE LIGHT RES	(..-04)	
 Golf IV (1J) (98-04)	SERVICE LIGHT RES	(..-5/99)	(no trip comp.)
 Golf IV (1J) (98-04)	SERVICE LIGHT RES	(..-98)	MANUAL
 Golf IV (1J) (98-04)	SOUND SYSTEM	(..-04)	
 Golf IV (1J) (98-04)	STEERING WHEEL E	(..-04)	
 Golf IV (1J) (98-04)	TV SYSTEM	(..-04)	
 Golf Plus (1K) (05-..)	4WD ELECTRONICS	(05-09)	
 Golf Plus (1K) (05-..)	ABS	(05-09)	
 Golf Plus (1K) (05-..)	AIRBAG	(05-08)	
 Golf Plus (1K) (05-..)	AIRBAG	(09-10)	
 Golf Plus (1K) (05-..)	AUTOM. TRANSMISSI	(05-08)	
 Golf Plus (1K) (05-..)	AUTOM. TRANSMISSI	(09-09)	0AM 7 Speed
 Golf Plus (1K) (05-..)	AUX. HEATING	(05-08)	
 Golf Plus (1K) (05-..)	CENTRAL ELECTRIC	(05-09)	Electric central system
 Golf Plus (1K) (05-..)	CHASSIS NETWORK	(05-09)	CAN Gateway
 Golf Plus (1K) (05-..)	CLIMA	(05-08)	
 Golf Plus (1K) (05-..)	CLIMA	(09-10)	Climatronic
 Golf Plus (1K) (05-..)	COMFORT SYSTEM	(05-08)	Comfort system
 Golf Plus (1K) (05-..)	DASHBOARD	(05-08)	
 Golf Plus (1K) (05-..)	DASHBOARD	(09-10)	
 Golf Plus (1K) (05-..)	DIGITAL RADIO TUNE	(05-09)	
 Golf Plus (1K) (05-..)	DRIVER SEAT CONT	(05-09)	
 Golf Plus (1K) (05-..)	DRIVER SIDE DOOR	(05-09)	
 Golf Plus (1K) (05-..)	ELECTRIC STEERING	(05-09)	
 Golf Plus (1K) (05-..)	ENGINE MANAGEME	(05-09)	CAN
 Golf Plus (1K) (05-..)	ENGINE MANAGEME	1.4 TSI 118 Kw (08-09)	CAVD
 Golf Plus (1K) (05-..)	ENGINE MANAGEME	1.4 TSI 90 Kw (07-08)	CAXA
 Golf Plus (1K) (05-..)	ENGINE MANAGEME	CAVD (09-09)	1.4 TSI 118 Kw
 Golf Plus (1K) (05-..)	HEADLIGHT LEVEL	(05-08)	
 Golf Plus (1K) (05-..)	IMMOBILIZER	(05-08)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

VW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Golf Plus (1K) (05-..)	IMMOBILIZER	(09-10)	
 Golf Plus (1K) (05-..)	LEFT REAR DOOR	(05-09)	
 Golf Plus (1K) (05-..)	MAINTENANCE	(05-08)	
 Golf Plus (1K) (05-..)	MAINTENANCE	(05-08)	
 Golf Plus (1K) (05-..)	MAINTENANCE	(05-08)	DIAG
 Golf Plus (1K) (05-..)	MAINTENANCE	(05-08)	DIAG
 Golf Plus (1K) (05-..)	MAINTENANCE	(05-08)	DIAG
 Golf Plus (1K) (05-..)	MAINTENANCE	(05-08)	MANUAL
 Golf Plus (1K) (05-..)	MAINTENANCE	(05-09)	
 Golf Plus (1K) (05-..)	MAINTENANCE	(05-09)	
 Golf Plus (1K) (05-..)	MAINTENANCE	(05-09)	
 Golf Plus (1K) (05-..)	MAINTENANCE	(05-09)	CAN
 Golf Plus (1K) (05-..)	MAINTENANCE	(05-09)	CAN
 Golf Plus (1K) (05-..)	MAINTENANCE	(09-10)	
 Golf Plus (1K) (05-..)	MAINTENANCE	(09-10)	
 Golf Plus (1K) (05-..)	MAINTENANCE	(09-10)	DIAG
 Golf Plus (1K) (05-..)	MAINTENANCE	(09-10)	MANUAL INFO DISPLAY
 Golf Plus (1K) (05-..)	MAINTENANCE	(09-10)	MANUAL NO INFO DISPLAY
 Golf Plus (1K) (05-..)	NAVIGATION	(05-09)	
 Golf Plus (1K) (05-..)	PARKING HELP	(05-09)	
 Golf Plus (1K) (05-..)	PASS. SIDE DOOR	(05-09)	
 Golf Plus (1K) (05-..)	PHONE	(05-09)	
 Golf Plus (1K) (05-..)	RADIO / CD	(05-09)	
 Golf Plus (1K) (05-..)	RIGHT REAR DOOR	(05-09)	
 Golf Plus (1K) (05-..)	SERVICE LIGHT RES	(05-08)	DIAG
 Golf Plus (1K) (05-..)	SERVICE LIGHT RES	(05-08)	MANUAL
 Golf Plus (1K) (05-..)	SERVICE LIGHT RES	(09-10)	DIAG
 Golf Plus (1K) (05-..)	SERVICE LIGHT RES	(09-10)	MANUAL INFO DISPLAY
 Golf Plus (1K) (05-..)	SERVICE LIGHT RES	(09-10)	MANUAL NO INFO DISPLAY
 Golf Plus (1K) (05-..)	SOUND SYSTEM	(05-09)	
 Golf Plus (1K) (05-..)	SPECIAL FUNCTION	(05-09)	
 Golf Plus (1K) (05-..)	STEERING WHEEL E	(05-09)	
 Golf Plus (1K) (05-..)	SUPP HEATER/AUTO	(05-09)	
 Golf Plus (1K) (05-..)	TIRE PRESSURE	(05-09)	
 Golf Plus (1K) (05-..)	TOW FUNCTION	(05-09)	
 Golf Plus (1K) (05-..)	TRANSPORT MODALI	(05-08)	
 Golf Plus (1K) (05-..)	TV SYSTEM	(05-09)	
 Golf Plus (1K) (05-..)	VEICHLE POSITION R	(05-09)	
 Golf V (1K) (04-08)	4WD ELECTRONICS	(05-09)	
 Golf V (1K) (04-08)	ABS	(04-08)	
 Golf V (1K) (04-08)	AIRBAG	(04-08)	
 Golf V (1K) (04-08)	AUTOM. TRANSMISSI	(04-08)	
 Golf V (1K) (04-08)	AUX. HEATING	(04-08)	
 Golf V (1K) (04-08)	CENTRAL ELECTRIC	(04-08)	Electric central system
 Golf V (1K) (04-08)	CHASSIS NETWORK	(05-09)	CAN Gateway
 Golf V (1K) (04-08)	CLIMA	(04-08)	
 Golf V (1K) (04-08)	COMFORT SYSTEM	(04-08)	Comfort system
 Golf V (1K) (04-08)	DASHBOARD	(04-08)	
 Golf V (1K) (04-08)	DIGITAL RADIO TUNE	(05-09)	
 Golf V (1K) (04-08)	DRIVER SEAT CONT	(05-09)	
 Golf V (1K) (04-08)	DRIVER SIDE DOOR	(04-08)	
 Golf V (1K) (04-08)	ELECTRIC STEERING	(04-08)	
 Golf V (1K) (04-08)	ENGINE MANAGEME	(04-08)	CAN
 Golf V (1K) (04-08)	ENGINE MANAGEME	1.4 TSI 118 Kw (08-09)	CAVD
 Golf V (1K) (04-08)	ENGINE MANAGEME	1.4 TSI 90 Kw (07-08)	CAXA
 Golf V (1K) (04-08)	HEADLIGHT LEVEL	(04-08)	
 Golf V (1K) (04-08)	IMMOBILIZER	(04-08)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

VW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Golf V (1K) (04-08)	LEFT REAR DOOR	(04-08)	
 Golf V (1K) (04-08)	MAINTENANCE	(04-08)	
 Golf V (1K) (04-08)	MAINTENANCE	(04-08)	
 Golf V (1K) (04-08)	MAINTENANCE	(04-08)	
 Golf V (1K) (04-08)	MAINTENANCE	(04-08)	
 Golf V (1K) (04-08)	MAINTENANCE	(04-08)	
 Golf V (1K) (04-08)	MAINTENANCE	(04-08)	CAN
 Golf V (1K) (04-08)	MAINTENANCE	(04-08)	CAN
 Golf V (1K) (04-08)	MAINTENANCE	(04-08)	DIAG
 Golf V (1K) (04-08)	MAINTENANCE	(04-08)	DIAG
 Golf V (1K) (04-08)	MAINTENANCE	(04-08)	DIAG
 Golf V (1K) (04-08)	MAINTENANCE	(04-08)	MANUAL
 Golf V (1K) (04-08)	NAVIGATION	(05-09)	
 Golf V (1K) (04-08)	PARKING HELP	(05-09)	
 Golf V (1K) (04-08)	PASS. SIDE DOOR	(04-08)	
 Golf V (1K) (04-08)	PHONE	(05-09)	
 Golf V (1K) (04-08)	RADIO / CD	(04-08)	
 Golf V (1K) (04-08)	RIGHT REAR DOOR	(04-08)	
 Golf V (1K) (04-08)	SERVICE LIGHT RES	(04-08)	DIAG
 Golf V (1K) (04-08)	SERVICE LIGHT RES	(04-08)	MANUAL
 Golf V (1K) (04-08)	SOUND SYSTEM	(05-09)	
 Golf V (1K) (04-08)	SPECIAL FUNCTION	(05-09)	
 Golf V (1K) (04-08)	STEERING WHEEL E	(04-08)	
 Golf V (1K) (04-08)	SUPP HEATER/AUTO	(05-09)	
 Golf V (1K) (04-08)	TIRE PRESSURE	(05-09)	
 Golf V (1K) (04-08)	TOW FUNCTION	(05-09)	
 Golf V (1K) (04-08)	TRANSPORT MODALI	(04-08)	
 Golf V (1K) (04-08)	TV SYSTEM	(05-09)	
 Golf V (1K) (04-08)	VEICHL E POSITION R	(05-09)	
 Golf VI (1K) (08-..)	ABS	(08-10)	
 Golf VI (1K) (08-..)	AIRBAG	(08-10)	
 Golf VI (1K) (08-..)	AUTOM. TRANSMISSI	(08-10)	0AM 7 Speed
 Golf VI (1K) (08-..)	BATTERY REGULATI	(08-10)	
 Golf VI (1K) (08-..)	CENTRAL ELECTRIC	(08-10)	
 Golf VI (1K) (08-..)	CLIMA	(08-10)	CLIMA MANUAL
 Golf VI (1K) (08-..)	CLIMA	(08-10)	Climatronic
 Golf VI (1K) (08-..)	DASHBOARD	(08-10)	
 Golf VI (1K) (08-..)	DPF REGENERATION	2.0 GTD 125 Kw (08-..)	DPF regeneration
 Golf VI (1K) (08-..)	DPF REGENERATION	2.0 TDI 100 Kw (08-..)	DPF regeneration
 Golf VI (1K) (08-..)	DPF REGENERATION	2.0 TDI 103 Kw (08-..)	DPF regeneration
 Golf VI (1K) (08-..)	DPF REGENERATION	2.0 TDI 81 Kw (08-..)	DPF regeneration
 Golf VI (1K) (08-..)	DRIVER SIDE DOOR	(08-10)	DRIVER DOOR
 Golf VI (1K) (08-..)	ELECTRIC STEERING	(08-10)	
 Golf VI (1K) (08-..)	ENGINE MANAGEME	(08-10)	DIESEL
 Golf VI (1K) (08-..)	ENGINE MANAGEME	(08-10)	GASOLINE
 Golf VI (1K) (08-..)	ENGINE MANAGEME	1.4 TSI 118 Kw (08-10)	CAVD
 Golf VI (1K) (08-..)	ENGINE MANAGEME	1.4 TSI 90 Kw (08-10)	CAXA
 Golf VI (1K) (08-..)	ENGINE MANAGEME	1.6 TDI 66 Kw (08-10)	CAYB
 Golf VI (1K) (08-..)	ENGINE MANAGEME	1.6 TDI 77 Kw (08-10)	CAYC
 Golf VI (1K) (08-..)	ENGINE MANAGEME	2.0 GTD 125 Kw (08-10)	CBBB
 Golf VI (1K) (08-..)	ENGINE MANAGEME	2.0 GTD 125 Kw BMN (08-10)	
 Golf VI (1K) (08-..)	HEADLIGHT LEVEL	(08-10)	
 Golf VI (1K) (08-..)	IMMOBILIZER	(08-10)	
 Golf VI (1K) (08-..)	LEFT REAR DOOR	(08-10)	RL DOOR
 Golf VI (1K) (08-..)	MAINTENANCE	(08-10)	
 Golf VI (1K) (08-..)	MAINTENANCE	(08-10)	
 Golf VI (1K) (08-..)	MAINTENANCE	(08-10)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

VW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Golf VI (1K) (08-..)	MAINTENANCE	(08-10)	
 Golf VI (1K) (08-..)	MAINTENANCE	(08-10)	
 Golf VI (1K) (08-..)	MAINTENANCE	(08-10)	
 Golf VI (1K) (08-..)	MAINTENANCE	(08-10)	
 Golf VI (1K) (08-..)	MAINTENANCE	(08-10)	
 Golf VI (1K) (08-..)	MAINTENANCE	(08-10)	DIAG
 Golf VI (1K) (08-..)	MAINTENANCE	(08-10)	MANUAL INFO DISPLAY
 Golf VI (1K) (08-..)	MAINTENANCE	(08-10)	MANUAL NO INFO DISPLAY
 Golf VI (1K) (08-..)	MAINTENANCE	2.0 GTD 125 Kw (08-10)	CBBB
 Golf VI (1K) (08-..)	MAINTENANCE	2.0 GTD 125 Kw (08-10)	CBBB
 Golf VI (1K) (08-..)	MAINTENANCE	2.0 GTD 125 Kw (08-10)	CBBB
 Golf VI (1K) (08-..)	MAINTENANCE	2.0 GTD 125 Kw BMN (08-10)	
 Golf VI (1K) (08-..)	PASS. SIDE DOOR	(08-10)	PASSENGER DOOR
 Golf VI (1K) (08-..)	RIGHT REAR DOOR	(08-10)	RR DOOR
 Golf VI (1K) (08-..)	SERVICE LIGHT RES	(08-10)	DIAG
 Golf VI (1K) (08-..)	SERVICE LIGHT RES	(08-10)	MANUAL INFO DISPLAY
 Golf VI (1K) (08-..)	SERVICE LIGHT RES	(08-10)	MANUAL NO INFO DISPLAY
 Golf VII (5G) (12-..)	AUTOM. TRANSMISSI	(12-..)	
 Golf VII (5G) (12-..)	DRIVER SIDE DOOR	(12-..)	DRIVER DOOR
 Golf VII (5G) (12-..)	PASS. SIDE DOOR	(12-..)	PASSENGER DOOR
 Jetta (1K) (05-..)	4WD ELECTRONICS	(05-09)	
 Jetta (1K) (05-..)	ABS	(05-09)	
 Jetta (1K) (05-..)	AIRBAG	(05-09)	
 Jetta (1K) (05-..)	AUTOM. TRANSMISSI	(05-09)	
 Jetta (1K) (05-..)	AUX. HEATING	(05-09)	
 Jetta (1K) (05-..)	CENTRAL ELECTRIC	(05-09)	Electric central system
 Jetta (1K) (05-..)	CHASSIS NETWORK	(05-09)	CAN Gateway
 Jetta (1K) (05-..)	CLIMA	(05-09)	
 Jetta (1K) (05-..)	COMFORT SYSTEM	(05-09)	Comfort system
 Jetta (1K) (05-..)	DASHBOARD	(05-09)	
 Jetta (1K) (05-..)	DIGITAL RADIO TUNE	(05-09)	
 Jetta (1K) (05-..)	DRIVER SEAT CONT	(05-09)	
 Jetta (1K) (05-..)	DRIVER SIDE DOOR	(05-09)	
 Jetta (1K) (05-..)	ELECTRIC STEERING	(05-09)	
 Jetta (1K) (05-..)	ENGINE MANAGEME	(05-09)	CAN
 Jetta (1K) (05-..)	ENGINE MANAGEME	1.4 TSI 118 Kw (08-10)	CAVD
 Jetta (1K) (05-..)	HEADLIGHT LEVEL	(05-09)	
 Jetta (1K) (05-..)	IMMOBILIZER	(05-09)	
 Jetta (1K) (05-..)	LEFT REAR DOOR	(05-09)	
 Jetta (1K) (05-..)	MAINTENANCE	(05-09)	
 Jetta (1K) (05-..)	MAINTENANCE	(05-09)	
 Jetta (1K) (05-..)	MAINTENANCE	(05-09)	
 Jetta (1K) (05-..)	MAINTENANCE	(05-09)	
 Jetta (1K) (05-..)	MAINTENANCE	(05-09)	
 Jetta (1K) (05-..)	MAINTENANCE	(05-09)	
 Jetta (1K) (05-..)	MAINTENANCE	(05-09)	CAN
 Jetta (1K) (05-..)	MAINTENANCE	(05-09)	CAN
 Jetta (1K) (05-..)	MAINTENANCE	(05-09)	DIAG
 Jetta (1K) (05-..)	MAINTENANCE	(05-09)	DIAG
 Jetta (1K) (05-..)	MAINTENANCE	(05-09)	DIAG
 Jetta (1K) (05-..)	MAINTENANCE	(05-09)	MANUAL
 Jetta (1K) (05-..)	NAVIGATION	(05-09)	
 Jetta (1K) (05-..)	PARKING HELP	(05-09)	
 Jetta (1K) (05-..)	PASS. SIDE DOOR	(05-09)	
 Jetta (1K) (05-..)	PHONE	(05-09)	
 Jetta (1K) (05-..)	RADIO / CD	(05-09)	
Jetta (1K) (05-..)	RIGHT REAR DOOR	(05-09)	
Jetta (1K) (05-..)	SERVICE LIGHT RES	(05-09)	DIAG

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

VW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Jetta (1K) (05-..)	SERVICE LIGHT RES	(05-09)	MANUAL
 Jetta (1K) (05-..)	SOUND SYSTEM	(05-09)	
 Jetta (1K) (05-..)	SPECIAL FUNCTION	(05-09)	
 Jetta (1K) (05-..)	STEERING WHEEL E	(05-09)	
 Jetta (1K) (05-..)	SUPP HEATER/AUTO	(05-09)	
 Jetta (1K) (05-..)	TIRE PRESSURE	(05-09)	
 Jetta (1K) (05-..)	TOW FUNCTION	(05-09)	
 Jetta (1K) (05-..)	TRANSPORT MODALI	(05-09)	
 Jetta (1K) (05-..)	TV SYSTEM	(05-09)	
 Jetta (1K) (05-..)	VEICHL E POSITION R	(05-09)	
 LT (21-28) (92-96)	ABS	(..-6/96)	MANUAL
 LT (21-28) (92-96)	ENGINE MANAGEME	(..-6/96)	
 LT (21-28) (92-96)	ENGINE MANAGEME	(..-6/96)	
 LT (21-28) (92-96)	ENGINE MANAGEME	(..-6/96)	
 LT (21-28) (92-96)	IMMOBILIZER	(..-6/96)	
 LT (21-28) (92-96)	MAINTENANCE	(..-6/96)	
 LT (21-28) (92-96)	MAINTENANCE	(..-6/96)	
 LT (21-28) (92-96)	MAINTENANCE	(..-6/96)	
 LT (21-28) (92-96)	MAINTENANCE	(93-96)	
 LT (21-28) (92-96)	SERVICE LIGHT RES	(93-96)	
 LT (2D) (97-06)	ABS	(..-06)	ABS/ABD 5.3
 LT (2D) (97-06)	AIRBAG	(..-06)	
 LT (2D) (97-06)	ENGINE MANAGEME	(..-06)	
 LT (2D) (97-06)	IMMOBILIZER	(..-01)	
 LT (2D) (97-06)	IMMOBILIZER	(..-06)	
 LT (2D) (97-06)	MAINTENANCE	(98-98)	
 LT (2D) (97-06)	SERVICE LIGHT RES	(98-98)	
 Lupo (6E-6X) (99-05)	ABS	(99-05)	ATE TEVES Mk60 No ASR
 Lupo (6E-6X) (99-05)	ABS	(99-05)	
 Lupo (6E-6X) (99-05)	AIRBAG	(99-05)	
 Lupo (6E-6X) (99-05)	AUTOM. TRANSMISSI	(99-05)	
 Lupo (6E-6X) (99-05)	CHASSIS NETWORK	(99-05)	
 Lupo (6E-6X) (99-05)	DASHBOARD	(99-05)	
 Lupo (6E-6X) (99-05)	ENGINE MANAGEME	(99-05)	
 Lupo (6E-6X) (99-05)	ENGINE MANAGEME	(99-05)	
 Lupo (6E-6X) (99-05)	ENGINE MANAGEME	(99-05)	
 Lupo (6E-6X) (99-05)	HEADLIGHT LEVEL	(99-05)	
 Lupo (6E-6X) (99-05)	MAINTENANCE	(99-05)	ATE TEVES Mk60 No ASR
 Lupo (6E-6X) (99-05)	MAINTENANCE	(99-05)	
 Lupo (6E-6X) (99-05)	MAINTENANCE	(99-05)	
 Lupo (6E-6X) (99-05)	MAINTENANCE	(99-05)	
 Lupo (6E-6X) (99-05)	MAINTENANCE	(99-05)	
 Lupo (6E-6X) (99-05)	MAINTENANCE	(99-05)	
 Lupo (6E-6X) (99-05)	MAINTENANCE	(99-05)	
 Lupo (6E-6X) (99-05)	MAINTENANCE	(99-05)	
 Lupo (6E-6X) (99-05)	SERVICE LIGHT RES	(99-05)	
 Lupo (6E-6X) (99-05)	SERVICE LIGHT RES	(99-05)	
 New Beetle (1C-1Y-9C-AG)	4WD ELECTRONICS	(..-06)	ATE TEVES Mk60 No ASR
 New Beetle (1C-1Y-9C-AG)	ABS	(01-06)	
 New Beetle (1C-1Y-9C-AG)	AIRBAG	(..-06)	
 New Beetle (1C-1Y-9C-AG)	AUTOM. TRANSMISSI	(..-06)	
 New Beetle (1C-1Y-9C-AG)	CENTRAL LOCKING	(..-06)	
 New Beetle (1C-1Y-9C-AG)	CHASSIS NETWORK	(..-06)	
 New Beetle (1C-1Y-9C-AG)	CLIMA	(..-06)	
 New Beetle (1C-1Y-9C-AG)	COMFORT SYSTEM	(..-06)	
 New Beetle (1C-1Y-9C-AG)	CONV. TOP/SUNROO	(..-06)	
 New Beetle (1C-1Y-9C-AG)	DASHBOARD	(..-06)	
 New Beetle (1C-1Y-9C-AG)	EMERGENCY CALL	(..-06)	
 New Beetle (1C-1Y-9C-AG)	ENGINE MANAGEME	(..-06)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

VW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 New Beetle (1C-1Y-9C-AG)	ENGINE MANAGEME	(..-06)	
 New Beetle (1C-1Y-9C-AG)	ENGINE MANAGEME	(..-06)	
 New Beetle (1C-1Y-9C-AG)	HEADLIGHT LEVEL	(..-06)	
 New Beetle (1C-1Y-9C-AG)	IMMOBILIZER	(..-06)	
 New Beetle (1C-1Y-9C-AG)	MAINTENANCE	(..-06)	
 New Beetle (1C-1Y-9C-AG)	MAINTENANCE	(..-06)	MANUAL
 New Beetle (1C-1Y-9C-AG)	MAINTENANCE	(01-06)	ATE TEVES Mk60 No ASR
 New Beetle (1C-1Y-9C-AG)	NAVIGATION	(..-06)	
 New Beetle (1C-1Y-9C-AG)	RADIO / CD	(..-06)	
 New Beetle (1C-1Y-9C-AG)	SERVICE LIGHT RES	(..-06)	
 New Beetle (1C-1Y-9C-AG)	SERVICE LIGHT RES	(..-06)	MANUAL
 New Beetle (1C-1Y-9C-AG)	SPOILER CONTROL	(..-06)	
 Passat (3A) (94-96)	ABS	(94-96)	
 Passat (3A) (94-96)	AIRBAG	(94-96)	
 Passat (3A) (94-96)	AUTOM. TRANSMISSI	(94-96)	
 Passat (3A) (94-96)	ENGINE MANAGEME	(94-96)	
 Passat (3A) (94-96)	ENGINE MANAGEME	(94-96)	
 Passat (3A) (94-96)	ENGINE MANAGEME	(94-96)	
 Passat (3A) (94-96)	IMMOBILIZER	(94-96)	
 Passat (3A) (94-96)	MAINTENANCE	(94-96)	
 Passat (3A) (94-96)	MAINTENANCE	(94-96)	
 Passat (3A) (94-96)	MAINTENANCE	(94-96)	MANUAL
 Passat (3A) (94-96)	SERVICE LIGHT RES	(94-96)	MANUAL
 Passat (3B) (97-05)	ABS	(01-03)	ATE TEVES Mk60 No ASR
 Passat (3B) (97-05)	ABS	(97-05)	
 Passat (3B) (97-05)	AIRBAG	(97-05)	
 Passat (3B) (97-05)	AUTOM. TRANSMISSI	(97-05)	
 Passat (3B) (97-05)	CENTRAL LOCKING	(97-05)	
 Passat (3B) (97-05)	CHASSIS NETWORK	(97-05)	
 Passat (3B) (97-05)	CLIMA	(97-05)	
 Passat (3B) (97-05)	COMFORT SYSTEM	(97-05)	
 Passat (3B) (97-05)	DASHBOARD	(97-05)	
 Passat (3B) (97-05)	DRIVER SEAT CONT	(97-05)	
 Passat (3B) (97-05)	ENGINE MANAGEME	(97-05)	
 Passat (3B) (97-05)	ENGINE MANAGEME	(97-05)	
 Passat (3B) (97-05)	ENGINE MANAGEME	(97-05)	
 Passat (3B) (97-05)	HEADLIGHT LEVEL	(97-05)	
 Passat (3B) (97-05)	IMMOBILIZER	(97-05)	
 Passat (3B) (97-05)	MAINTENANCE	(..-6/98)	
 Passat (3B) (97-05)	MAINTENANCE	(01-03)	ATE TEVES Mk60 No ASR
 Passat (3B) (97-05)	MAINTENANCE	(97-05)	
 Passat (3B) (97-05)	MAINTENANCE	(97-05)	
 Passat (3B) (97-05)	MAINTENANCE	(97-05)	MANUAL
 Passat (3B) (97-05)	MAINTENANCE	(97-05)	
 Passat (3B) (97-05)	MAINTENANCE	(99-05)	
 Passat (3B) (97-05)	NAVIGATION	(97-05)	
 Passat (3B) (97-05)	PARKING HELP	(97-05)	
 Passat (3B) (97-05)	PHONE	(97-05)	
 Passat (3B) (97-05)	RADIO / CD	(97-05)	
 Passat (3B) (97-05)	SERVICE LIGHT RES	(..-6/98)	
 Passat (3B) (97-05)	SERVICE LIGHT RES	(97-05)	MANUAL
 Passat (3B) (97-05)	SERVICE LIGHT RES	(99-05)	
 Passat (3B) (97-05)	SOUND SYSTEM	(97-05)	
 Passat (3B) (97-05)	STEERING WHEEL E	(97-05)	
 Passat (3B) (97-05)	TV SYSTEM	(97-05)	
 Passat (3C) (05-..)	4WD ELECTRONICS	(05-08)	
 Passat (3C) (05-..)	ABS	(05-08)	

CARS **VW**

Page 1100 of 1129

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

VW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Passat (3C) (05-..)	NAVIGATION	(05-08)	
 Passat (3C) (05-..)	PARK.BRAKE	(05-10)	
 Passat (3C) (05-..)	PARKING HELP	(05-08)	
 Passat (3C) (05-..)	PARKING HELP	(05-08)	
 Passat (3C) (05-..)	PASS. SIDE DOOR	(05-09)	
 Passat (3C) (05-..)	PASS. SIDE DOOR	(09-10)	PASSENGER DOOR
 Passat (3C) (05-..)	PHONE	(05-08)	
 Passat (3C) (05-..)	RADIO / CD	(05-10)	
 Passat (3C) (05-..)	RIGHT REAR DOOR	(05-09)	
 Passat (3C) (05-..)	SERVICE LIGHT RES	(05-08)	DIAG
 Passat (3C) (05-..)	SERVICE LIGHT RES	(05-09)	MANUAL
 Passat (3C) (05-..)	SERVICE LIGHT RES	(09-10)	DIAG
 Passat (3C) (05-..)	SOUND SYSTEM	(05-08)	
 Passat (3C) (05-..)	SPECIAL FUNCTION	(05-08)	
 Passat (3C) (05-..)	STEERING WHEEL E	(05-09)	
 Passat (3C) (05-..)	STEERING WHEEL E	(09-10)	
 Passat (3C) (05-..)	SUPP HEATER/AUTO	(05-08)	
 Passat (3C) (05-..)	TIRE PRESSURE	(05-08)	
 Passat (3C) (05-..)	TOW FUNCTION	(05-08)	
 Passat (3C) (05-..)	TRANSPORT MODALI	(05-10)	
 Passat (3C) (05-..)	TV SYSTEM	(05-08)	
 Passat (3C) (05-..)	VEICHL E POSITION R	(05-08)	
 Phaeton (3D) (02-..)	4WD ELECTRONICS	(02-07)	
 Phaeton (3D) (02-..)	ABS	(02-07)	
 Phaeton (3D) (02-..)	AIRBAG	(02-07)	
 Phaeton (3D) (02-..)	AUTOM. TRANSMISSI	(02-07)	
 Phaeton (3D) (02-..)	BRAKE POWER SUP	(02-07)	
 Phaeton (3D) (02-..)	CENTRAL ELECTRIC	(02-07)	
 Phaeton (3D) (02-..)	CLIMA	(02-07)	
 Phaeton (3D) (02-..)	COLUMN/SEAT REG.	(02-07)	
 Phaeton (3D) (02-..)	COMFORT SYSTEM	(02-07)	
 Phaeton (3D) (02-..)	CONV. TOP/SUNROO	(02-07)	
 Phaeton (3D) (02-..)	DASHBOARD	(02-07)	
 Phaeton (3D) (02-..)	DISTANCE REGULATI	(02-07)	
 Phaeton (3D) (02-..)	ELECTRONIC TRIM	(02-07)	
 Phaeton (3D) (02-..)	EMERGENCY MODUL	(02-07)	
 Phaeton (3D) (02-..)	ENGINE MANAGEME	(02-07)	
 Phaeton (3D) (02-..)	ENGINE MANAGEME	V10 TDI - W12 (02-07)	
 Phaeton (3D) (02-..)	IDENT./COMMAND U	(02-07)	
 Phaeton (3D) (02-..)	IMMOBILIZER	(02-07)	
 Phaeton (3D) (02-..)	LH RIGHT MODULATI	(02-07)	
 Phaeton (3D) (02-..)	MAINTENANCE	(02-07)	
 Phaeton (3D) (02-..)	MAINTENANCE	(02-07)	
 Phaeton (3D) (02-..)	MAINTENANCE	(02-07)	
 Phaeton (3D) (02-..)	MAINTENANCE	(02-07)	
 Phaeton (3D) (02-..)	MAINTENANCE	(02-07)	
 Phaeton (3D) (02-..)	MAINTENANCE	(02-07)	CAN
 Phaeton (3D) (02-..)	MAINTENANCE	(02-07)	CAN
 Phaeton (3D) (02-..)	MAINTENANCE	(02-07)	CAN
 Phaeton (3D) (02-..)	MAINTENANCE	(02-07)	No CAN
 Phaeton (3D) (02-..)	NAVIGATION	(02-07)	
 Phaeton (3D) (02-..)	PARKING HELP	(02-07)	
 Phaeton (3D) (02-..)	PASSENGER SEAT R	(02-07)	
 Phaeton (3D) (02-..)	PHONE	(02-07)	
 Phaeton (3D) (02-..)	RADIO / CD	(02-07)	
 Phaeton (3D) (02-..)	REAR CLIMA	(02-07)	
 Phaeton (3D) (02-..)	REAR CONTROL INDI	(02-07)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

VW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Phaeton (3D) (02-..)	REAR SEAT REG.	(02-07)	CAN No CAN
 Phaeton (3D) (02-..)	RELEV/SWITCON	(02-07)	
 Phaeton (3D) (02-..)	RH LIGHT MODULATI	(02-07)	
 Phaeton (3D) (02-..)	ROOF MANAGEMENT	(02-07)	
 Phaeton (3D) (02-..)	SERVICE LIGHT RES	(02-07)	
 Phaeton (3D) (02-..)	SERVICE LIGHT RES	(02-07)	
 Phaeton (3D) (02-..)	SOUND SYSTEM	(02-07)	
 Phaeton (3D) (02-..)	STEERING WHEEL E	(02-07)	
 Phaeton (3D) (02-..)	TIRE PRESSURE	(02-07)	
 Phaeton (3D) (02-..)	TOW FUNCTION	(02-07)	
 Phaeton (3D) (02-..)	TV SYSTEM	(02-07)	
 Phaeton (3D) (02-..)	VEICHL E POSITION R	(02-07)	
 Phaeton (3D) (02-..)	WIPERS	(02-07)	
 Polo (6N-6K) (95-02)	ABS	(..-02)	ATE TEVES Mk60 No ASR
 Polo (6N-6K) (95-02)	ABS	(01-02)	
 Polo (6N-6K) (95-02)	AIRBAG	(..-02)	
 Polo (6N-6K) (95-02)	AUTOM. TRANSMISSI	(..-02)	
 Polo (6N-6K) (95-02)	CHASSIS NETWORK	(..-02)	
 Polo (6N-6K) (95-02)	CLIMA	(..-02)	
 Polo (6N-6K) (95-02)	CLIMA	(..-02)	
 Polo (6N-6K) (95-02)	DASHBOARD	(..-02)	
 Polo (6N-6K) (95-02)	ENGINE MANAGEME	(..-02)	
 Polo (6N-6K) (95-02)	ENGINE MANAGEME	(..-02)	
 Polo (6N-6K) (95-02)	ENGINE MANAGEME	(..-02)	
 Polo (6N-6K) (95-02)	HEADLIGHT LEVEL	(..-02)	
 Polo (6N-6K) (95-02)	MAINTENANCE	(..-02)	
 Polo (6N-6K) (95-02)	MAINTENANCE	(..-02)	MANUAL ATE TEVES Mk60 No ASR MANUAL MANUAL MANUAL MANUAL
 Polo (6N-6K) (95-02)	MAINTENANCE	(..-02)	
 Polo (6N-6K) (95-02)	MAINTENANCE	(..-96)	
 Polo (6N-6K) (95-02)	MAINTENANCE	(01-02)	
 Polo (6N-6K) (95-02)	MAINTENANCE	(97-98)	
 Polo (6N-6K) (95-02)	MAINTENANCE	(99-02)	
 Polo (6N-6K) (95-02)	SERVICE LIGHT RES	(..-96)	
 Polo (6N-6K) (95-02)	SERVICE LIGHT RES	(97-98)	
 Polo (6N-6K) (95-02)	SERVICE LIGHT RES	(99-02)	
 Polo (6R) (09-..)	AIRBAG	(09-10)	Electric central system CAN Gateway Diagnostic bus interface Climatic
 Polo (6R) (09-..)	AUTOM. TRANSMISSI	(09-10)	
 Polo (6R) (09-..)	CENTRAL ELECTRIC	(09-10)	
 Polo (6R) (09-..)	CENTRAL ELECTRIC	(09-10)	
 Polo (6R) (09-..)	CHASSIS NETWORK	(09-10)	
 Polo (6R) (09-..)	CHASSIS NETWORK	(09-10)	
 Polo (6R) (09-..)	CLIMA	(09-10)	
 Polo (6R) (09-..)	DASHBOARD	(09-10)	
 Polo (6R) (09-..)	ENGINE MANAGEME	1.2 CGPA (09-10)	
 Polo (6R) (09-..)	ENGINE MANAGEME	1.2 TDI 75cv CFWA (09-10)	
 Polo (6R) (09-..)	ENGINE MANAGEME	Gasoline (09-10)	
 Polo (6R) (09-..)	HEADLIGHT LEVEL	(09-10)	
 Polo (6R) (09-..)	IMMOBILIZER	(09-10)	
 Polo (6R) (09-..)	MAINTENANCE	(09-10)	
 Polo (6R) (09-..)	MAINTENANCE	(09-10)	
 Polo (6R) (09-..)	MAINTENANCE	(09-10)	
 Polo (6R) (09-..)	MAINTENANCE	(09-10)	
 Polo (6R) (09-..)	MAINTENANCE	(09-10)	
 Polo (6R) (09-..)	MAINTENANCE	1.2 TDI 75cv CFWA (09-10)	
 Polo (6R) (09-..)	MAINTENANCE	1.2 TDI 75cv CFWA (09-10)	
 Polo (6R) (09-..)	MAINTENANCE	1.2 TDI 75cv CFWA (09-10)	
 Polo (6R) (09-..)	MAINTENANCE	1.2 TDI 75cv CFWA (09-10)	
 Polo (6R) (09-..)	MAINTENANCE	Gasoline (09-10)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

VW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Polo (6R) (09-...)	SERVICE LIGHT RES	(09-10)	
 Polo (9N) (02-09)	ABS	(..-09)	
 Polo (9N) (02-09)	ABS	(02-09)	ATE TEVES Mk60 No ASR
 Polo (9N) (02-09)	AIRBAG	(..-09)	
 Polo (9N) (02-09)	AUTOM. TRANSMISSI	(..-09)	
 Polo (9N) (02-09)	CHASSIS NETWORK	(..-09)	
 Polo (9N) (02-09)	CLIMA	(..-09)	CLIMATIC
 Polo (9N) (02-09)	CLIMA	(..-09)	CLIMATRONIC
 Polo (9N) (02-09)	COMFORT SYSTEM	(..-09)	
 Polo (9N) (02-09)	DASHBOARD	(..-09)	
 Polo (9N) (02-09)	ELECTRIC STEERING	(..-09)	
 Polo (9N) (02-09)	ENGINE MANAGEME	(..-06)	
 Polo (9N) (02-09)	ENGINE MANAGEME	(..-06)	
 Polo (9N) (02-09)	ENGINE MANAGEME	(..-06)	
 Polo (9N) (02-09)	ENGINE MANAGEME	(06-09)	NO CAN
 Polo (9N) (02-09)	MAINTENANCE	(..-09)	
 Polo (9N) (02-09)	MAINTENANCE	(..-09)	
 Polo (9N) (02-09)	MAINTENANCE	(..-09)	
 Polo (9N) (02-09)	MAINTENANCE	(..-09)	
 Polo (9N) (02-09)	MAINTENANCE	(..-09)	MANUAL
 Polo (9N) (02-09)	MAINTENANCE	(02-09)	ATE TEVES Mk60 No ASR
 Polo (9N) (02-09)	MAINTENANCE	(06-09)	NO CAN
 Polo (9N) (02-09)	NAVIGATION	(..-09)	
 Polo (9N) (02-09)	PARKING HELP	(..-09)	
 Polo (9N) (02-09)	RADIO / CD	(..-09)	
 Polo (9N) (02-09)	SERVICE LIGHT RES	(..-09)	
 Polo (9N) (02-09)	SERVICE LIGHT RES	(..-09)	MANUAL
 Sharan (7M) (96-...)	4WD ELECTRONICS	(..-04)	
 Sharan (7M) (96-...)	4WD ELECTRONICS	(04-09)	CAN
 Sharan (7M) (96-...)	4WD ELECTRONICS	(04-09)	KWP 2000
 Sharan (7M) (96-...)	ABS	(..-04)	
 Sharan (7M) (96-...)	ABS	(04-09)	CAN
 Sharan (7M) (96-...)	ABS	(04-09)	KWP 2000
 Sharan (7M) (96-...)	AIRBAG	(..-04)	
 Sharan (7M) (96-...)	AIRBAG	(04-09)	CAN
 Sharan (7M) (96-...)	AIRBAG	(04-09)	KWP 2000
 Sharan (7M) (96-...)	AUTOM. TRANSMISSI	(..-04)	
 Sharan (7M) (96-...)	AUTOM. TRANSMISSI	(04-09)	CAN
 Sharan (7M) (96-...)	AUTOM. TRANSMISSI	(04-09)	KWP 2000
 Sharan (7M) (96-...)	AUX. HEATING	(..-04)	
 Sharan (7M) (96-...)	AUX. HEATING	(04-09)	CAN
 Sharan (7M) (96-...)	CENTRAL ELECTRIC	(04-09)	CAN
 Sharan (7M) (96-...)	CENTRAL ELECTRIC	(04-09)	KWP 2000
 Sharan (7M) (96-...)	CHASSIS NETWORK	(..-04)	
 Sharan (7M) (96-...)	CHASSIS NETWORK	(04-09)	CAN
 Sharan (7M) (96-...)	CLIMA	(..-04)	
 Sharan (7M) (96-...)	CLIMA	(04-09)	CAN
 Sharan (7M) (96-...)	CLIMA	(04-09)	KWP 2000
 Sharan (7M) (96-...)	DASHBOARD	(..-04)	
 Sharan (7M) (96-...)	DASHBOARD	(04-09)	CAN
 Sharan (7M) (96-...)	DASHBOARD	(04-09)	KWP 2000
 Sharan (7M) (96-...)	ELECTRIC STEERING	(..-04)	EPS
 Sharan (7M) (96-...)	ELECTRIC STEERING	(04-09)	CAN
 Sharan (7M) (96-...)	ENGINE MANAGEME	(..-04)	
 Sharan (7M) (96-...)	ENGINE MANAGEME	(..-04)	
Sharan (7M) (96-...)	ENGINE MANAGEME	(..-04)	
Sharan (7M) (96-...)	ENGINE MANAGEME	(04-09)	CAN
Sharan (7M) (96-...)	ENGINE MANAGEME	(04-09)	KWP 2000

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

VW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sharan (7M) (96-..)	IMMOBILIZER	(..-04)	
 Sharan (7M) (96-..)	IMMOBILIZER	(04-09)	CAN
 Sharan (7M) (96-..)	IMMOBILIZER	(04-09)	KWP 2000
 Sharan (7M) (96-..)	MAINTENANCE	(..-04)	
 Sharan (7M) (96-..)	MAINTENANCE	(..-04)	
 Sharan (7M) (96-..)	MAINTENANCE	(..-04)	
 Sharan (7M) (96-..)	MAINTENANCE	(..-98)	
 Sharan (7M) (96-..)	MAINTENANCE	(..-98)	
 Sharan (7M) (96-..)	MAINTENANCE	(..-98)	MANUAL
 Sharan (7M) (96-..)	MAINTENANCE	(04-09)	CAN
 Sharan (7M) (96-..)	MAINTENANCE	(04-09)	CAN
 Sharan (7M) (96-..)	MAINTENANCE	(04-09)	CAN
 Sharan (7M) (96-..)	MAINTENANCE	(04-09)	CAN
 Sharan (7M) (96-..)	MAINTENANCE	(04-09)	CAN
 Sharan (7M) (96-..)	MAINTENANCE	(04-09)	CAN
 Sharan (7M) (96-..)	MAINTENANCE	(04-09)	CAN
 Sharan (7M) (96-..)	MAINTENANCE	(04-09)	CAN
 Sharan (7M) (96-..)	MAINTENANCE	(04-09)	CAN
 Sharan (7M) (96-..)	MAINTENANCE	(04-09)	KWP 2000
 Sharan (7M) (96-..)	MAINTENANCE	(04-09)	KWP 2000
 Sharan (7M) (96-..)	MAINTENANCE	(04-09)	KWP 2000
 Sharan (7M) (96-..)	MAINTENANCE	(04-09)	KWP 2000
 Sharan (7M) (96-..)	MAINTENANCE	(04-09)	KWP 2000
 Sharan (7M) (96-..)	MAINTENANCE	(04-09)	KWP 2000
 Sharan (7M) (96-..)	MAINTENANCE	(04-09)	KWP 2000
 Sharan (7M) (96-..)	MAINTENANCE	(04-09)	KWP 2000
 Sharan (7M) (96-..)	MAINTENANCE	(04-09)	MANUAL
 Sharan (7M) (96-..)	MAINTENANCE	(99-04)	
 Sharan (7M) (96-..)	NAVIGATION	(..-04)	
 Sharan (7M) (96-..)	NAVIGATION	(04-09)	CAN
 Sharan (7M) (96-..)	NAVIGATION	(04-09)	KWP 2000
 Sharan (7M) (96-..)	PARKING HELP	(..-04)	
 Sharan (7M) (96-..)	PARKING HELP	(04-09)	CAN
 Sharan (7M) (96-..)	PARKING HELP	(04-09)	KWP 2000
 Sharan (7M) (96-..)	RADIO / CD	(..-04)	
 Sharan (7M) (96-..)	RADIO / CD	(04-09)	CAN
 Sharan (7M) (96-..)	RADIO / CD	(04-09)	KWP 2000
 Sharan (7M) (96-..)	SERVICE LIGHT RES	(..-98)	
 Sharan (7M) (96-..)	SERVICE LIGHT RES	(..-98)	MANUAL
 Sharan (7M) (96-..)	SERVICE LIGHT RES	(04-09)	CAN
 Sharan (7M) (96-..)	SERVICE LIGHT RES	(04-09)	KWP 2000
 Sharan (7M) (96-..)	SERVICE LIGHT RES	(04-09)	MANUAL
 Sharan (7M) (96-..)	SERVICE LIGHT RES	(99-04)	
 Sharan (7M) (96-..)	TRANSPORT MODALI	(04-09)	CAN
 Sharan (7N) (11-..)	AIRBAG	(11-..)	
 Sharan (7N) (11-..)	CHANGE BRAKE PAD	(11-..)	
 Sharan (7N) (11-..)	DASHBOARD	(11-..)	
 Sharan (7N) (11-..)	DRIVER SIDE DOOR	(11-..)	
 Sharan (7N) (11-..)	LEFT REAR DOOR	(11-..)	
 Sharan (7N) (11-..)	MAINTENANCE	(11-..)	
 Sharan (7N) (11-..)	MAINTENANCE	(11-..)	
 Sharan (7N) (11-..)	MAINTENANCE	(11-..)	
 Sharan (7N) (11-..)	MAINTENANCE	(11-..)	
 Sharan (7N) (11-..)	PASS. SIDE DOOR	(11-..)	
 Sharan (7N) (11-..)	RADIO / CD	(11-..)	
 Sharan (7N) (11-..)	RIGHT REAR DOOR	(11-..)	
 Sharan (7N) (11-..)	SERVICE LIGHT RES	(11-..)	
 T4-Caravelle (70-7H-7J) (90	ABS	(..-03)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

VW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 T4-Caravelle (70-7H-7J) (90)	AIRBAG	(..-03)	
 T4-Caravelle (70-7H-7J) (90)	AUTOM. TRANSMISSI	(..-03)	
 T4-Caravelle (70-7H-7J) (90)	CENTRAL LOCKING	(..-03)	
 T4-Caravelle (70-7H-7J) (90)	CHASSIS NETWORK	(..-03)	
 T4-Caravelle (70-7H-7J) (90)	CLIMA	(..-03)	
 T4-Caravelle (70-7H-7J) (90)	DASHBOARD	(..-03)	
 T4-Caravelle (70-7H-7J) (90)	ENGINE MANAGEME	(..-03)	
 T4-Caravelle (70-7H-7J) (90)	ENGINE MANAGEME	(..-03)	
 T4-Caravelle (70-7H-7J) (90)	ENGINE MANAGEME	(..-03)	
 T4-Caravelle (70-7H-7J) (90)	IMMOBILIZER	(..-03)	
 T4-Caravelle (70-7H-7J) (90)	MAINTENANCE	(..-03)	
 T4-Caravelle (70-7H-7J) (90)	MAINTENANCE	(..-03)	
 T4-Caravelle (70-7H-7J) (90)	MAINTENANCE	(..-03)	
 T4-Caravelle (70-7H-7J) (90)	MAINTENANCE	(93-96)	MANUAL
 T4-Caravelle (70-7H-7J) (90)	MAINTENANCE	(97-98)	MANUAL
 T4-Caravelle (70-7H-7J) (90)	MAINTENANCE	(99-03)	
 T4-Caravelle (70-7H-7J) (90)	RADIO / CD	(..-03)	
 T4-Caravelle (70-7H-7J) (90)	SERVICE LIGHT RES	(93-96)	MANUAL
 T4-Caravelle (70-7H-7J) (90)	SERVICE LIGHT RES	(97-98)	MANUAL
 T4-Caravelle (70-7H-7J) (90)	SERVICE LIGHT RES	(99-03)	
 T4-Transporter (70-7H-7J) (	ABS	(..-03)	
 T4-Transporter (70-7H-7J) (	AIRBAG	(..-03)	
 T4-Transporter (70-7H-7J) (	AUTOM. TRANSMISSI	(..-03)	
 T4-Transporter (70-7H-7J) (	CENTRAL LOCKING	(..-03)	
 T4-Transporter (70-7H-7J) (	CHASSIS NETWORK	(..-03)	
 T4-Transporter (70-7H-7J) (	CLIMA	(..-03)	
 T4-Transporter (70-7H-7J) (	DASHBOARD	(..-03)	
 T4-Transporter (70-7H-7J) (	ENGINE MANAGEME	(..-03)	
 T4-Transporter (70-7H-7J) (	ENGINE MANAGEME	(..-03)	
 T4-Transporter (70-7H-7J) (	ENGINE MANAGEME	(..-03)	
 T4-Transporter (70-7H-7J) (	IMMOBILIZER	(..-03)	
 T4-Transporter (70-7H-7J) (	MAINTENANCE	(..-03)	
 T4-Transporter (70-7H-7J) (	MAINTENANCE	(..-03)	
 T4-Transporter (70-7H-7J) (	MAINTENANCE	(..-03)	
 T4-Transporter (70-7H-7J) (	MAINTENANCE	(93-96)	MANUAL
 T4-Transporter (70-7H-7J) (	MAINTENANCE	(97-98)	MANUAL
 T4-Transporter (70-7H-7J) (	MAINTENANCE	(99-02)	
 T4-Transporter (70-7H-7J) (	RADIO / CD	(..-03)	
 T4-Transporter (70-7H-7J) (	SERVICE LIGHT RES	(93-96)	MANUAL
 T4-Transporter (70-7H-7J) (	SERVICE LIGHT RES	(97-98)	MANUAL
 T4-Transporter (70-7H-7J) (	SERVICE LIGHT RES	(99-02)	
 T5-Caravelle (70-7H-7J) (03)	4WD ELECTRONICS	(03-06)	
 T5-Caravelle (70-7H-7J) (03)	ABS	(03-06)	
 T5-Caravelle (70-7H-7J) (03)	AIRBAG	(03-06)	
 T5-Caravelle (70-7H-7J) (03)	AUTOM. TRANSMISSI	(03-06)	
 T5-Caravelle (70-7H-7J) (03)	CENTRAL ELECTRIC	(03-06)	
 T5-Caravelle (70-7H-7J) (03)	CLIMA	(03-06)	
 T5-Caravelle (70-7H-7J) (03)	DASHBOARD	(03-06)	
 T5-Caravelle (70-7H-7J) (03)	ENGINE MANAGEME	(03-06)	
 T5-Caravelle (70-7H-7J) (03)	HEADLIGHT LEVEL	(03-06)	
 T5-Caravelle (70-7H-7J) (03)	IMMOBILIZER	(03-06)	
 T5-Caravelle (70-7H-7J) (03)	MAINTENANCE	(03-06)	
 T5-Caravelle (70-7H-7J) (03)	MAINTENANCE	(03-06)	
 T5-Caravelle (70-7H-7J) (03)	MAINTENANCE	(03-06)	
 T5-Caravelle (70-7H-7J) (03)	MAINTENANCE	(03-06)	
 T5-Caravelle (70-7H-7J) (03)	NAVIGATION	(03-06)	
 T5-Caravelle (70-7H-7J) (03)	PARKING HELP	(03-06)	
 T5-Caravelle (70-7H-7J) (03)	PHONE	(03-06)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

VW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 T5-Caravelle (70-7H-7J) (03	RADIO / CD	(03-06)	
 T5-Caravelle (70-7H-7J) (03	SERVICE LIGHT RES	(03-06)	
 T5-Caravelle (70-7H-7J) (03	STEERING WHEEL E	(03-06)	
 T5-Caravelle (70-7H-7J) (03	SUPP HEATER/AUTO	(03-06)	
 T5-Caravelle (70-7H-7J) (03	TOW FUNCTION	(03-06)	
 T5-Transporter (70-7H-7J) (	4WD ELECTRONICS	(03-06)	
 T5-Transporter (70-7H-7J) (	ABS	(03-06)	
 T5-Transporter (70-7H-7J) (	AIRBAG	(03-06)	
 T5-Transporter (70-7H-7J) (	AUTOM. TRANSMISSI	(03-06)	
 T5-Transporter (70-7H-7J) (	CENTRAL ELECTRIC	(03-06)	
 T5-Transporter (70-7H-7J) (	CLIMA	(03-06)	
 T5-Transporter (70-7H-7J) (	DASHBOARD	(03-06)	
 T5-Transporter (70-7H-7J) (	ENGINE MANAGEME	(03-06)	
 T5-Transporter (70-7H-7J) (	HEADLIGHT LEVEL	(03-06)	
 T5-Transporter (70-7H-7J) (	IMMOBILIZER	(03-06)	
 T5-Transporter (70-7H-7J) (	MAINTENANCE	(03-06)	
 T5-Transporter (70-7H-7J) (	MAINTENANCE	(03-06)	
 T5-Transporter (70-7H-7J) (	MAINTENANCE	(03-06)	
 T5-Transporter (70-7H-7J) (	MAINTENANCE	(03-06)	
 T5-Transporter (70-7H-7J) (	NAVIGATION	(03-06)	
 T5-Transporter (70-7H-7J) (	PARKING HELP	(03-06)	
 T5-Transporter (70-7H-7J) (	PHONE	(03-06)	
 T5-Transporter (70-7H-7J) (	RADIO / CD	(03-06)	
 T5-Transporter (70-7H-7J) (	SERVICE LIGHT RES	(03-06)	
 T5-Transporter (70-7H-7J) (	STEERING WHEEL E	(03-06)	
 T5-Transporter (70-7H-7J) (	SUPP HEATER/AUTO	(03-06)	
 T5-Transporter (70-7H-7J) (	TOW FUNCTION	(03-06)	
 Taro (7A) (89-97)	AIRBAG	(..-97)	
 Taro (7A) (89-97)	ENGINE MANAGEME	(..-97)	
 Taro (7A) (89-97)	ENGINE MANAGEME	(..-97)	
 Taro (7A) (89-97)	ENGINE MANAGEME	(..-97)	
 Taro (7A) (89-97)	IMMOBILIZER	(..-97)	
 Taro (7A) (89-97)	MAINTENANCE	(..-97)	MANUAL
 Taro (7A) (89-97)	MAINTENANCE	(93-96)	MANUAL
 Taro (7A) (89-97)	SERVICE LIGHT RES	(..-97)	MANUAL
 Taro (7A) (89-97)	SERVICE LIGHT RES	(93-96)	MANUAL
 Tiguan (5N) (08-..)	4WD ELECTRONICS	(08-..)	
 Tiguan (5N) (08-..)	ABS	(08-..)	
 Tiguan (5N) (08-..)	AIRBAG	(08-..)	
 Tiguan (5N) (08-..)	CENTRAL ELECTRIC	(08-..)	
 Tiguan (5N) (08-..)	CHANGE BRAKE PAD	(08-..)	
 Tiguan (5N) (08-..)	CHASSIS NETWORK	(08-..)	
 Tiguan (5N) (08-..)	CLIMA	(08-..)	
 Tiguan (5N) (08-..)	DASHBOARD	(08-..)	
 Tiguan (5N) (08-..)	ELECTRIC STEERING	(08-..)	
 Tiguan (5N) (08-..)	ENGINE MANAGEME	1.4 TSI 118 Kw (11-..)	CAVD
 Tiguan (5N) (08-..)	ENGINE MANAGEME	1.4 TSI 90 Kw (10-11)	CAXA
 Tiguan (5N) (08-..)	ENGINE MANAGEME	2.0 TDI 125 Kw (08-11)	CBBB
 Tiguan (5N) (08-..)	IMMOBILIZER	(08-..)	
 Tiguan (5N) (08-..)	MAINTENANCE	(08-..)	
 Tiguan (5N) (08-..)	MAINTENANCE	(08-..)	
 Tiguan (5N) (08-..)	MAINTENANCE	(08-..)	
 Tiguan (5N) (08-..)	MAINTENANCE	(08-..)	
 Tiguan (5N) (08-..)	MAINTENANCE	(08-..)	
 Tiguan (5N) (08-..)	MAINTENANCE	(08-..)	
 Tiguan (5N) (08-..)	MAINTENANCE	2.0 TDI 125 Kw (08-11)	CBBB
 Tiguan (5N) (08-..)	MAINTENANCE	2.0 TDI 125 Kw (08-11)	CBBB
 Tiguan (5N) (08-..)	MAINTENANCE	2.0 TDI 125 Kw (08-11)	CBBB

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

VW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Tiguan (5N) (08-..)	PHONE	(08-..)	
 Tiguan (5N) (08-..)	RADIO / CD	(08-..)	
 Touareg (7L) (03-..)	4WD ELECTRONICS	(03-06)	
 Touareg (7L) (03-..)	ABS	(03-06)	
 Touareg (7L) (03-..)	AIRBAG	(03-06)	
 Touareg (7L) (03-..)	AUTOM. TRANSMISSI	(03-06)	
 Touareg (7L) (03-..)	CENTRAL ELECTRIC	(03-06)	
 Touareg (7L) (03-..)	CHASSIS NETWORK	(03-06)	Control head roof
 Touareg (7L) (03-..)	CLIMA	(03-06)	
 Touareg (7L) (03-..)	COLUMN/SEAT REG.	(03-06)	
 Touareg (7L) (03-..)	COMFORT SYSTEM	(03-06)	
 Touareg (7L) (03-..)	DASHBOARD	(03-06)	
 Touareg (7L) (03-..)	DIFFERENTIAL LOCK	(03-06)	
 Touareg (7L) (03-..)	ELECTRONIC TRIM	(03-06)	
 Touareg (7L) (03-..)	EMERGENCY MODUL	(03-06)	
 Touareg (7L) (03-..)	ENGINE MANAGEME	(03-06)	
 Touareg (7L) (03-..)	ENGINE MANAGEME	V10 TDI - W12 (03-06)	
 Touareg (7L) (03-..)	HEADLIGHT LEVEL	(03-06)	
 Touareg (7L) (03-..)	IMMOBILIZER	(03-06)	
 Touareg (7L) (03-..)	LH RIGHT MODULATI	(03-06)	
 Touareg (7L) (03-..)	MAINTENANCE	(03-06)	
 Touareg (7L) (03-..)	MAINTENANCE	(03-06)	
 Touareg (7L) (03-..)	MAINTENANCE	(03-06)	
 Touareg (7L) (03-..)	MAINTENANCE	(03-06)	
 Touareg (7L) (03-..)	MAINTENANCE	(03-06)	
 Touareg (7L) (03-..)	MAINTENANCE	(03-06)	DIAG
 Touareg (7L) (03-..)	MAINTENANCE	(03-06)	MANUAL
 Touareg (7L) (03-..)	NAVIGATION	(03-06)	
 Touareg (7L) (03-..)	PARKING HELP	(03-06)	
 Touareg (7L) (03-..)	PASSENGER SEAT R	(03-06)	
 Touareg (7L) (03-..)	PHONE	(03-06)	
 Touareg (7L) (03-..)	RADIO / CD	(03-06)	
 Touareg (7L) (03-..)	RELEV/SWITCON	(03-06)	
 Touareg (7L) (03-..)	RH LIGHT MODULATI	(03-06)	
 Touareg (7L) (03-..)	SERVICE LIGHT RES	(03-06)	DIAG
 Touareg (7L) (03-..)	SERVICE LIGHT RES	(03-06)	MANUAL
 Touareg (7L) (03-..)	SOUND SYSTEM	(03-06)	
 Touareg (7L) (03-..)	STABILIZERS	(03-06)	
 Touareg (7L) (03-..)	STEERING WHEEL E	(03-06)	
 Touareg (7L) (03-..)	SUPP HEATER/AUTO	(03-06)	
 Touareg (7L) (03-..)	TIRE PRESSURE	(03-06)	
 Touareg (7L) (03-..)	TOW FUNCTION	(03-06)	
 Touareg (7L) (03-..)	TV SYSTEM	(03-06)	
 Touareg (7L) (03-..)	VEICHLE POSITION R	(03-06)	
 Touareg (7L) (03-..)	WIPERS	(03-06)	
 Touran (1T) (03-..)	ABS	(03-10)	
 Touran (1T) (03-..)	AIRBAG	(03-10)	
 Touran (1T) (03-..)	AUTOM. TRANSMISSI	(03-10)	
 Touran (1T) (03-..)	AUX. HEATING	(03-10)	
 Touran (1T) (03-..)	CENTRAL ELECTRIC	(03-10)	
 Touran (1T) (03-..)	CHASSIS NETWORK	(03-10)	
 Touran (1T) (03-..)	CLIMA	(03-10)	
 Touran (1T) (03-..)	DASHBOARD	(03-10)	
 Touran (1T) (03-..)	DRIVER SIDE DOOR	(03-10)	
 Touran (1T) (03-..)	ENGINE MANAGEME	(03-10)	CAN
 Touran (1T) (03-..)	IMMOBILIZER	(03-10)	
 Touran (1T) (03-..)	LEFT REAR DOOR	(03-10)	

Systems supported by ECUreader / ECUdecoder (up to V6.90)

CARS

VW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Touran (1T) (03-..)	MAINTENANCE	(03-10)	
 Touran (1T) (03-..)	MAINTENANCE	(03-10)	
 Touran (1T) (03-..)	MAINTENANCE	(03-10)	
 Touran (1T) (03-..)	MAINTENANCE	(03-10)	
 Touran (1T) (03-..)	MAINTENANCE	(03-10)	
 Touran (1T) (03-..)	MAINTENANCE	(03-10)	
 Touran (1T) (03-..)	MAINTENANCE	(03-10)	CAN
 Touran (1T) (03-..)	MAINTENANCE	(03-10)	CAN
 Touran (1T) (03-..)	NAVIGATION	(03-10)	
 Touran (1T) (03-..)	PARKING HELP	(03-10)	
 Touran (1T) (03-..)	PASS. SIDE DOOR	(03-10)	
 Touran (1T) (03-..)	PHONE	(03-10)	
 Touran (1T) (03-..)	RADIO / CD	(03-10)	
 Touran (1T) (03-..)	RIGHT REAR DOOR	(03-10)	
 Touran (1T) (03-..)	SERVICE LIGHT RES	(03-10)	
 Touran (1T) (03-..)	STEERING WHEEL E	(03-10)	
 Touran (1T) (03-..)	SUPP HEATER/AUTO	(03-10)	
 Touran (1T) (03-..)	TOW FUNCTION	(03-10)	
 Touran (1T) (03-..)	TRANSPORT MODALI	(03-10)	
 up! (11-..)	DASHBOARD	(11-..)	
 up! (11-..)	MAINTENANCE	(11-..)	
 Vento (1H) (92-98)	ABS	(..-98)	
 Vento (1H) (92-98)	AIRBAG	(..-98)	
 Vento (1H) (92-98)	AUTOM. TRANSMISSI	(..-98)	
 Vento (1H) (92-98)	CHASSIS NETWORK	(..-98)	
 Vento (1H) (92-98)	CLIMA	(..-98)	
 Vento (1H) (92-98)	CLUTCH ELECTRONI	(..-98)	
 Vento (1H) (92-98)	DASHBOARD	(..-98)	
 Vento (1H) (92-98)	ENGINE MANAGEME	(..-98)	
 Vento (1H) (92-98)	ENGINE MANAGEME	(..-98)	
 Vento (1H) (92-98)	ENGINE MANAGEME	(..-98)	
 Vento (1H) (92-98)	IMMOBILIZER	(..-98)	
 Vento (1H) (92-98)	MAINTENANCE	(..-98)	
 Vento (1H) (92-98)	MAINTENANCE	(..-98)	
 Vento (1H) (92-98)	MAINTENANCE	(..-98)	
 Vento (1H) (92-98)	MAINTENANCE	(92-96)	MANUAL
 Vento (1H) (92-98)	MAINTENANCE	(98-98)	MANUAL
 Vento (1H) (92-98)	RADIO / CD	(..-98)	
 Vento (1H) (92-98)	SERVICE LIGHT RES	(92-96)	MANUAL
 Vento (1H) (92-98)	SERVICE LIGHT RES	(98-98)	MANUAL

Systems supported by ECUREADER / ECUDECODER (up to V6.90)

CARS

Zastava

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 10	ABS	1.2 8v (03-..)	BOSCH ABS 8
 10	AIRBAG	1.2 8v (03-..)	TRW AirBag MY 97 (2F-I)
 10	AIRBAG	1.2 8v (03-..)	TRW AirBag MY 99 (2F-2P-2L-2T-2I-S)
 10	AIRBAG	1.2 8v (03-..)	TRW AirBag MY 99 (2F-2P-I-S)
 10	AIRBAG	1.2 8v (03-..)	TRW AirBag MY 99 (2F-4P-4L-2T-2I-S)
 10	CHASSIS NETWORK	1.2 8v (03-..)	DELPHI/Marelli Dashboard Body Computer
 10	CHASSIS NETWORK	1.2 8v (03-..)	Fiat CAN Info
 10	CHASSIS NETWORK	1.2 8v (03-..)	Fiat Proxi Alignement
 10	DASHBOARD	1.2 8v (03-..)	Marelli Dashboard Comfort
 10	ELECTRIC STEERING	1.2 8v (03-..)	DELPHI EPS
 10	ENGINE MANAGEME	1.2 8v (03-..)	Marelli IAW 5AF
 10	ENGINE MANAGEME	1.2 8v (03-..)	Marelli IAW 5AF NY
 10	KEY ENCODE	1.2 8v (03-..)	DELPHI/Marelli CODE Body Computer
 10	MAINTENANCE	1.2 8v (03-..)	DELPHI EPS
 10	MAINTENANCE	1.2 8v (03-..)	Marelli
 10	MAINTENANCE	1.2 8v (03-..)	Marelli Dashboard Comfort
 10	MAINTENANCE	1.2 8v (03-..)	Marelli Dashboard Comfort
 10	MAINTENANCE	1.2 8v (03-..)	Marelli IAW 5AF
 10	MAINTENANCE	1.2 8v (03-..)	Marelli IAW 5AF NY
 10	SERVICE LIGHT RES	1.2 8v (03-..)	Marelli
 Florida	ENGINE MANAGEME	IN 1.1 L (02-06)	BOSCH Motronic M 7.4.4
 Florida	ENGINE MANAGEME	IN 1.6 L (02-06)	BOSCH Motronic M 7.4.4
 Koral	ENGINE MANAGEME	IN 1.1 L (02-06)	BOSCH Motronic M 7.4.4

Systems supported by ECUreader / ECUdecoder (up to V6.90)

MOTORCYCLES

Aprilia

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atlantic	ENGINE MANAGEME	400	Marelli MIU
 Atlantic	ENGINE MANAGEME	500	Marelli IAW 15P
 Atlantic	ENGINE MANAGEME	500	Marelli MIU
 Atlantic	IMMOBILIZER	400	Marelli MIU
 Atlantic	IMMOBILIZER	500	Marelli
 Atlantic	IMMOBILIZER	500	Marelli MIU
 Capo Nord	ENGINE MANAGEME	1000	Sagem MC 1000
 Capo Nord	SERVICE LIGHT RES	1000	MANUAL
 Leonardo	SERVICE LIGHT RES	(04-..)	MANUAL
 Pegaso	ENGINE MANAGEME	650	SAGEM MC 650
 RST Futura	ENGINE MANAGEME	990	Sagem MC 1000
 RST Futura	SERVICE LIGHT RES	1000	MANUAL
 RSV 1000	SERVICE LIGHT RES	1000	MANUAL
 RSV Tuono	SERVICE LIGHT RES	1000	MANUAL
 Scarabeo	ENGINE MANAGEME	250	Marelli MIU
 Scarabeo	ENGINE MANAGEME	400	Marelli MIU
 Scarabeo	ENGINE MANAGEME	50	DITECH Synerject
 Scarabeo	ENGINE MANAGEME	500	Marelli IAW 15P
 Scarabeo	ENGINE MANAGEME	500	Marelli MIU
 Scarabeo	IMMOBILIZER	250	Marelli MIU
 Scarabeo	IMMOBILIZER	400	Marelli MIU
 Scarabeo	IMMOBILIZER	500	Marelli
 Scarabeo	IMMOBILIZER	500	Marelli MIU
 SL 1000 Falco	SERVICE LIGHT RES	1000	MANUAL
 Sport City	SERVICE LIGHT RES	125 (04-..)	MANUAL
 Sport City	SERVICE LIGHT RES	200 (04-..)	MANUAL
 SR	ENGINE MANAGEME	50	DITECH Synerject

Systems supported by ECUreader / ECUdecoder (up to V6.90)

MOTORCYCLES

BMW Motorrad

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 K 100 RS 16v	ABS	1000	BOSCH ABS
 K 100 RS 16v	ELECTRONIC INJECT	1000	BOSCH
 K 100	ELECTRONIC INJECT	1000	BOSCH
 K 1100 LT	ENGINE MANAGEME	1100	BOSCH Motronic MA 2.2
 K 1200 GT	ENGINE MANAGEME	1200	BOSCH Motronic MA 2.4
 K 1200 LT	ENGINE MANAGEME	1200	BOSCH Motronic MA 2.4
 K1	ELECTRONIC INJECT	1000	BOSCH
 K75 RT	ELECTRONIC INJECT	750	BOSCH
 K75 S	ELECTRONIC INJECT	750	BOSCH
 K75	ELECTRONIC INJECT	750	BOSCH
 R 1100 GS Adventure	ENGINE MANAGEME	1100	BOSCH Motronic MA 2.2
 R 1100 GS	ABS	1100	BOSCH ABS
 R 1100 GS	ENGINE MANAGEME	1100	BOSCH Motronic MA 2.2
 R 1100 R	ENGINE MANAGEME	1100	BOSCH Motronic
 R 1100 R	ENGINE MANAGEME	1100	BOSCH Motronic MA 2.2
 R 1100 RS	ENGINE MANAGEME	1100	BOSCH Motronic MA 2.2
 R 1100 RT	ABS	1100	BOSCH ABS
 R 1100 RT	ENGINE MANAGEME	1100	BOSCH Motronic MA 2.2
 R 1100 S	ENGINE MANAGEME	1100	BOSCH Motronic MA 2.4
 R 1150 R Rockster	ENGINE MANAGEME	1150	BOSCH Motronic MA 2.4
 R 1150 RS	ENGINE MANAGEME	1150	BOSCH Motronic MA 2.4
 R 1150 RT	ENGINE MANAGEME	1150	BOSCH Motronic MA 2.4
 R 1200 C	ENGINE MANAGEME	1200	BOSCH Motronic MA 2.2
 R 850 GS	ENGINE MANAGEME	850	BOSCH Motronic
 R 850 R	ENGINE MANAGEME	850	BOSCH Motronic
 R 850 R	ENGINE MANAGEME	850	BOSCH Motronic MA 2.4
 R 850 RT	ENGINE MANAGEME	850	BOSCH Motronic MA 2.4

Systems supported by ECUreader / ECUdecoder (up to V6.90)

MOTORCYCLES

Cagiva

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Navigator	ENGINE MANAGEME	1000	Denso MANUAL Denso
 Raptor	ENGINE MANAGEME	1000	Denso MANUAL Denso
 V-Raptor	ENGINE MANAGEME	1000	Denso MANUAL Denso
 X-tra Raptor	ENGINE MANAGEME	1000	Denso MANUAL Denso

Systems supported by ECUreader / ECUdecoder (up to V6.90)

MOTORCYCLES

Ducati

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 620 Dark IE Monster	ENGINE MANAGEME	618	Marelli IAW 59M S16 DG 118
 620 Dark IE Monster	SERVICE LIGHT RES	618 (02-..)	MANUAL
 620 IE Monster	ENGINE MANAGEME	618	Marelli IAW 59M S16 DG 118
 620 IE Monster	SERVICE LIGHT RES	618 (02-..)	MANUAL
 620S IE Monster	ENGINE MANAGEME	618	Marelli IAW 59M S16 DG 118
 620S IE Monster	SERVICE LIGHT RES	618 (02-..)	MANUAL
 748 IE Biposto	ENGINE MANAGEME	750	Marelli IAW 6F/M
 748 R	ENGINE MANAGEME	748	Marelli IAW
 748S IE	ENGINE MANAGEME	750	Marelli IAW 6F/M
 749	ENGINE MANAGEME	750	Marelli 59 M
 749	SERVICE LIGHT RES	750	Marelli 59 M
 749R	ENGINE MANAGEME	750	Marelli 59 M
 749R	SERVICE LIGHT RES	750	Marelli 59 M
 749S	ENGINE MANAGEME	750	Marelli 59 M
 749S	SERVICE LIGHT RES	750	Marelli 59 M
 750 Dark IE Monster	ENGINE MANAGEME	750	Marelli IAW 59M S16 DG 118
 750 IE Monster	ENGINE MANAGEME	750	Marelli IAW 59M S16 DG 118
 900 Dark IE Monster	ENGINE MANAGEME	900	Marelli IAW 59M S16 DG 118
 900 IE Monster	ENGINE MANAGEME	900	Marelli IAW 59M S16 DG 118
 900 IE Monster	ENGINE MANAGEME	900 (..-00)	Marelli IAW
 900 IE Monster	SERVICE LIGHT RES	900 (02-..)	MANUAL
 996 IE Biposto	ENGINE MANAGEME	996	Marelli IAW 6F/M
 996 R	ENGINE MANAGEME	996	Marelli IAW 59M 61600.630.00
 996 SPS	ENGINE MANAGEME	996	Marelli IAW
 998 Biposto	ENGINE MANAGEME	998	Marelli IAW 59M 61600.630.00
 998 R	ENGINE MANAGEME	998	Marelli IAW 59M 61600.630.00
 998 S	ENGINE MANAGEME	998	Marelli IAW 59M 61600.630.00
 999	ENGINE MANAGEME	1000	Marelli 59 M
 999	SERVICE LIGHT RES	1000	Marelli 59 M
 Monster IE S4	ENGINE MANAGEME	900	Marelli IAW 59M S16 DG 118
 Monster IE S4	SERVICE LIGHT RES	900 (02-..)	MANUAL
 Monster	ENGINE MANAGEME	1000 Twin s	Marelli 59 M
 Monster	ENGINE MANAGEME	400	Marelli 59 M
 Monster	ENGINE MANAGEME	620 (03-03)	Marelli 59 M
 Monster	ENGINE MANAGEME	620 (04-..)	Marelli 59 M
 Monster	ENGINE MANAGEME	620 6 Speed (04-..)	Marelli 59 M
 Monster	ENGINE MANAGEME	750	Marelli 59 M
 Monster	ENGINE MANAGEME	800 (03-..)	Marelli 59 M
 Monster	ENGINE MANAGEME	900 (02-..)	Marelli 59 M
 Monster	ENGINE MANAGEME	MS4 (01-..)	Marelli 59 M
 Monster	ENGINE MANAGEME	MS4 (02-..)	Marelli 59 M
 Monster	ENGINE MANAGEME	S4 (02-..)	Marelli 59 M
 Monster	ENGINE MANAGEME	S4R (03-..)	Marelli 59 M
 Monster	SERVICE LIGHT RES	1000 Twin s (04-..)	Marelli 59 M
 Monster	SERVICE LIGHT RES	400 (04-..)	Marelli 59 M
 Monster	SERVICE LIGHT RES	620 (04-..)	Marelli 59 M
 Monster	SERVICE LIGHT RES	620 6 Speed (04-..)	Marelli 59 M
 Monster	SERVICE LIGHT RES	750 (04-..)	Marelli 59 M
 Monster	SERVICE LIGHT RES	800 (04-..)	Marelli 59 M
 Monster	SERVICE LIGHT RES	900 (04-..)	Marelli 59 M
 Monster	SERVICE LIGHT RES	MS4 (04-..)	Marelli 59 M
 Monster	SERVICE LIGHT RES	S4 (04-..)	Marelli 59 M
 Monster	SERVICE LIGHT RES	S4R (04-..)	Marelli 59 M

Systems supported by ECUreader / ECUdecoder (up to V6.90)

MOTORCYCLES

Ducati

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sport	ENGINE MANAGEME	750	Marelli IAW 15M
 Sport	ENGINE MANAGEME	750 S	Marelli IAW 15M
 Sport	ENGINE MANAGEME	900 S	Marelli IAW 15M
 ST3	ENGINE MANAGEME	1000 (04-..)	Marelli 59 M
 ST4S	ENGINE MANAGEME	1000	Marelli 59 M
 ST4S	ENGINE MANAGEME	1000 (03-..)	Marelli 59 M
 ST4S	ENGINE MANAGEME	1000 (04-..)	Marelli 59 M
 ST4S	SERVICE LIGHT RES	1000	Marelli 59 M
 Super Sport	ENGINE MANAGEME	1000 TS (04-..)	Marelli 59 M
 Super Sport	ENGINE MANAGEME	620	Marelli 59 M
 Super Sport	ENGINE MANAGEME	800	Marelli 59 M
 Super Sport	SERVICE LIGHT RES	1000 TS (04-..)	Marelli 59 M
 Super Sport	SERVICE LIGHT RES	620	Marelli 59 M
 Super Sport	SERVICE LIGHT RES	800	Marelli 59 M

Systems supported by ECUreader / ECUdecoder (up to V6.90)

MOTORCYCLES

GAS GAS

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 EC 400 FSE	ENGINE MANAGEME	399 (02-..)	Marelli IAW 1.5
 EC 450 FSE	ENGINE MANAGEME	443 (02-..)	Marelli IAW 1.5
 SM 400	ENGINE MANAGEME	399 (02-..)	Marelli IAW 1.5
 SM 450 FSE	ENGINE MANAGEME	443 (02-..)	Marelli IAW 1.5
 WILD MP 400 QUAD	ENGINE MANAGEME	399 (02-..)	Marelli IAW 1.5

Systems supported by ECUreader / ECUdecoder (up to V6.90)

MOTORCYCLES

Gilera

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 FUOCO	ENGINE MANAGEME	500	Marelli MPI MIU
 FUOCO	IMMOBILIZER	500	Marelli MPI MIU
 Nexus	ENGINE MANAGEME	500 (03-..)	Marelli IAW
 Nexus	IMMOBILIZER	500 (03-..)	Marelli
 Runner	ENGINE MANAGEME	50	Hi-PER2 PRO

Systems supported by ECUreader / ECUdecoder (up to V6.90)

MOTORCYCLES

Harley Davidson

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Dyna Wide Glide	ENGINE MANAGEME	1450 (02-..)	Marelli IAW
 Electra Glide	ENGINE MANAGEME	1450 (02-..)	Marelli IAW
 Fat Boy	ENGINE MANAGEME	1450 (02-..)	Marelli IAW
 Heritage Classic	ENGINE MANAGEME	1450 (02-..)	Marelli IAW
 Heritage Softail Classic	ENGINE MANAGEME	1450 (02-..)	Marelli IAW
 Road King Classic	ENGINE MANAGEME	1450 (02-..)	Marelli IAW
 Road King	ENGINE MANAGEME	1450 (02-..)	Marelli IAW
 Softail Deuce	ENGINE MANAGEME	1450 (02-..)	Marelli IAW
 Softail Springer	ENGINE MANAGEME	1450 (02-..)	Marelli IAW

Systems supported by ECUreader / ECUdecoder (up to V6.90)

MOTORCYCLES

Honda

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 CBF 600 N	ENGINE MANAGEME	600 (08-..)	PGM-FI
 CBF 600 S	ENGINE MANAGEME	600 (07-..)	PGM-FI
 CBR 600 RR	ENGINE MANAGEME	600 (07-..)	PGM-FI
 CBR F	ENGINE MANAGEME	600 (02-..)	Honda EFI MANUAL PGM-FI
 CBR RR2 FIREBLADE	ENGINE MANAGEME	900 (02-..)	Honda EFI MANUAL PGM-FI
 CBR RRY FIREBLADE	ENGINE MANAGEME	900 (02-..)	Honda EFI MANUAL PGM-FI
 CBR SFY X11	ENGINE MANAGEME	1100 (02-..)	Honda EFI MANUAL PGM-FI
 CBR XX1	ENGINE MANAGEME	1100 (02-..)	Honda EFI MANUAL PGM-FI
 CBR XX	ENGINE MANAGEME	1100 (02-..)	Honda EFI MANUAL PGM-FI
 Deauville	ENGINE MANAGEME	700 (06-..)	PGM-FI
 DN-01	ENGINE MANAGEME	700 (08-..)	PGM-FI
 GOLDWING GL A	ENGINE MANAGEME	1800 (02-..)	Honda EFI MANUAL PGM-FI
 HORNET 900 S	ENGINE MANAGEME	900 (02-..)	Honda EFI MANUAL PGM-FI
 HORNET CB F22	ENGINE MANAGEME	900 (02-..)	Honda EFI MANUAL PGM-FI
 Hornet	ENGINE MANAGEME	600 (07-..)	PGM-FI
 PAN-EUROPEAN ST/A	ENGINE MANAGEME	1300 (02-..)	Honda EFI MANUAL PGM-FI
 Shadow	ENGINE MANAGEME	750 (07-..)	PGM-FI
 SILVER WING FJS	ENGINE MANAGEME	600 (02-..)	Honda EFI MANUAL PGM-FI
 VFR A2 VTEC	ABS	800 (04-..)	Honda ABS
 VFR A2 VTEC	ENGINE MANAGEME	800 (02-..)	Honda EFI MANUAL PGM-FI
 VFR FIW	ENGINE MANAGEME	800 (02-..)	Honda EFI MANUAL PGM-FI
 VFR FIY	ENGINE MANAGEME	800 (02-..)	Honda EFI MANUAL PGM-FI
 VTR SP2.2	ENGINE MANAGEME	1000 (02-..)	Honda EFI MANUAL PGM-FI
 VTR SPY	ENGINE MANAGEME	1000 (02-..)	Honda EFI MANUAL PGM-FI
 VTX C	ENGINE MANAGEME	1800 (02-..)	Honda EFI MANUAL PGM-FI
 XL 700 Transalp	ENGINE MANAGEME	700 (07-..)	PGM-FI

Systems supported by ECUreader / ECUdecoder (up to V6.90)

MOTORCYCLES

Kawasaki

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 ER-6F	ENGINE MANAGEME	650	EFI
 ER-6N	ENGINE MANAGEME	650	EFI
 Ninja ZX-12R	ENGINE MANAGEME	1200	Kawasaki DFI MANUAL
 Versys	ENGINE MANAGEME	650	EFI
 Z 750	ENGINE MANAGEME	750 (05-..)	EFI Dynojet
 Z 750s	ENGINE MANAGEME	750 (05-..)	EFI Dynojet

Systems supported by ECUreader / ECUdecoder (up to V6.90)

MOTORCYCLES

KVN Motor

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Yak 500 QUAD	ENGINE MANAGEME	460 (04-...)	Marelli IAW 15P

Systems supported by ECUreader / ECUdecoder (up to V6.90)

MOTORCYCLES

Laverda

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sport	ENGINE MANAGEME	750	Marelli IAW 1.6M

Systems supported by ECUreader / ECUdecoder (up to V6.90)

MOTORCYCLES

Malaguti

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Spidermax 500	ENGINE MANAGEME	460 (03-...)	Marelli IAW 15P
 Spidermax 500	IMMOBILIZER	460 (03-...)	Marelli

Systems supported by ECUreader / ECUdecoder (up to V6.90)

MOTORCYCLES

Moto Guzzi

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 1.1 Sport Corsa	ENGINE MANAGEME	1000	Marelli IAW
 Brevia	ENGINE MANAGEME	1100 (05-..)	Marelli 59 M
 Brevia	ENGINE MANAGEME	750 (03-..)	Marelli IAW 15M 1.1
 Brevia	ENGINE MANAGEME	850 (05-..)	Marelli 59 M
 California EV 80	ENGINE MANAGEME	1000 (01-..)	Marelli IAW
 California EV Touring	ENGINE MANAGEME	1000 (01-..)	Marelli IAW
 California EV	ENGINE MANAGEME	1000 (01-..)	Marelli IAW
 California Special Sport Alu	ENGINE MANAGEME	1000	Marelli IAW
 California Special Sport	ENGINE MANAGEME	1000	Marelli IAW
 California Stone Metal	ENGINE MANAGEME	1000	Marelli IAW
 California Stone	ENGINE MANAGEME	1000	Marelli IAW
 Centauro	ENGINE MANAGEME	1000	Marelli IAW
 Daytona RS	ENGINE MANAGEME	1000	Marelli IAW
 Griso	ENGINE MANAGEME	1100 (06-..)	Marelli 59 M
 Griso	ENGINE MANAGEME	850 (05-..)	Marelli 59 M
 Jackal	ENGINE MANAGEME	1000	Marelli IAW
 Norge	ENGINE MANAGEME	1200 (06-..)	Marelli 59 M
 Stelvio	ENGINE MANAGEME	1200 (07-..)	Marelli 59 M
 V 11 Ballabio	ENGINE MANAGEME	1000 (01-..)	Marelli IAW 15M 1.1
 V 11 Le Mans Rosso Corsa	ENGINE MANAGEME	1000 (01-..)	Marelli IAW 15M 1.1
 V 11 Le Mans	ENGINE MANAGEME	1000 (01-..)	Marelli IAW 15M 1.1
 V 11 Scura	ENGINE MANAGEME	1000 (01-..)	Marelli IAW 15M 1.1
 V 11	ENGINE MANAGEME	1000 (01-..)	Marelli IAW 15M 1.1

Systems supported by ECUreader / ECUdecoder (up to V6.90)

MOTORCYCLES

MV

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Agusta Brutale	ENGINE MANAGEME	750	Marelli IAW 6F/M
 Agusta F4	ENGINE MANAGEME	750	Marelli IAW 6F/M

Systems supported by ECUreader / ECUdecoder (up to V6.90)

MOTORCYCLES

Piaggio

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Beverly	ENGINE MANAGEME	250	Marelli SPI MIU
 Beverly	ENGINE MANAGEME	400	Marelli SPI MIU
 Beverly	ENGINE MANAGEME	500	Marelli IAW
 Beverly	ENGINE MANAGEME	500	Marelli SPI MIU
 Beverly	IMMOBILIZER	250	Marelli SPI MIU
 Beverly	IMMOBILIZER	400	Marelli SPI MIU
 Beverly	IMMOBILIZER	500	Marelli
 Beverly	IMMOBILIZER	500	Marelli SPI MIU
 MP3	ENGINE MANAGEME	250	Marelli SPI MIU
 MP3	ENGINE MANAGEME	400	Marelli SPI MIU
 MP3	IMMOBILIZER	250	Marelli SPI MIU
 MP3	IMMOBILIZER	400	Marelli SPI MIU
 NRG Power 50 PureJet	ENGINE MANAGEME	50	Hi-PER2 PRO
 Vespa	ENGINE MANAGEME	GTS 250	Marelli SPI MIU
 Vespa	IMMOBILIZER	GTS 250	Marelli SPI MIU
 X8	ENGINE MANAGEME	400	Marelli SPI MIU
 X8	IMMOBILIZER	400	Marelli SPI MIU
 X9	ENGINE MANAGEME	500	Marelli IAW
 X9	IMMOBILIZER	500	Marelli
 XEVO	ENGINE MANAGEME	250	Marelli SPI MIU
 XEVO	ENGINE MANAGEME	400	Marelli SPI MIU
 XEVO	IMMOBILIZER	250	Marelli SPI MIU
 XEVO	IMMOBILIZER	400	Marelli SPI MIU
 Zip Sp	ENGINE MANAGEME	50	Hi-PER2 PRO

MOTORCYCLES

Sherco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 4,5 i	ENGINE MANAGEME	443	Marelli IAW

Systems supported by ECUreader / ECUdecoder (up to V6.90)

MOTORCYCLES

Suzuki

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 GSX	ENGINE MANAGEME	1400	Denso MANUAL Denso
 GSX-R	ENGINE MANAGEME	1000	Denso MANUAL Denso
 GSX-R	ENGINE MANAGEME	1300	Denso MANUAL Denso
 GSX-R	ENGINE MANAGEME	600	Denso MANUAL Denso
 GSX-R	ENGINE MANAGEME	750	Denso MANUAL Denso
 TL-S	ENGINE MANAGEME	1000	Denso MANUAL Denso

Systems supported by ECUreader / ECUdecoder (up to V6.90)

MOTORCYCLES

Triumph

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 509T Speed Triple	ENGINE MANAGEME	955	Sagem MC 1000
 955i Speed Triple	ENGINE MANAGEME	955	Sagem EOBD
 955i Speed Triple	ENGINE MANAGEME	955	Sagem MC 1000
 Baby Speed	ENGINE MANAGEME	600	Sagem MC 1000
 Daytona centenary edition	ENGINE MANAGEME	955	Sagem EOBD
 Daytona centenary edition	ENGINE MANAGEME	955	Sagem MC 1000
 Daytona	ENGINE MANAGEME	955	Sagem EOBD
 Daytona	ENGINE MANAGEME	955	Sagem MC 1000
 Speed Four	ENGINE MANAGEME	600	Sagem EOBD
 Speed Four	ENGINE MANAGEME	600	Sagem MC 1000
 Sprint RS	ENGINE MANAGEME	955	Sagem EOBD
 Sprint RS	ENGINE MANAGEME	955	Sagem MC 1000
 Sprint ST	ENGINE MANAGEME	955	Sagem EOBD
 Sprint ST	ENGINE MANAGEME	955	Sagem MC 1000
 Tiger	ENGINE MANAGEME	955	Sagem EOBD
 Tiger	ENGINE MANAGEME	955	Sagem MC 1000
 TT	ENGINE MANAGEME	600	Sagem EOBD
 TT	ENGINE MANAGEME	600	Sagem MC 1000

Systems supported by ECUreader / ECUdecoder (up to V6.90)

MOTORCYCLES

Yamaha

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 FJR	ENGINE MANAGEME	1300 (01-..)	EFI MANUAL
 TDM	ENGINE MANAGEME	900 (02-..)	EFI MANUAL
 Tmax	SERVICE LIGHT RES	500 (04-..)	oil MANUAL
 Tmax	SERVICE LIGHT RES	500 (04-..)	strap MANUAL
 YZF R1	ENGINE MANAGEME	1000 (02-..)	EFI MANUAL
 YZF R6	ENGINE MANAGEME	600 (02-..)	EFI MANUAL